## 1999 4.3 (LF6 and L35)S/T-truck, M/L-van, C/K-truck, G-van (includes Isuzu Hombre)4L60-ETRANSMISSIONDIAGNOSTICPARAMETERS

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Vehicle Speed Sensor - Low input	P0502	0 RPM to 6000 RPM This DTC detects a low vehicle speed when the vehicle has a large engine speed in a drive gear range.	Output Speed < 150 rpm	Gear Range is not Park/Neutral     No TPS high or low DTC's set     No Map Sensor DTC's set     No PSA DTC set     Vacuum: 0 to 105 KPA     Engine Torque: 40 to 400 ft-lbs     Throttle Position > 20%     Engine Soed > 3000 RPM	2.5 seconds Continuous	DTC Type B
Vehicle Speed Sensor - Intermittent	P0503	0 RPM to 6000 RPM This DTC detects an unrealistic large drop in vehicle speed.	In <b>P/N:</b> Output Speed drop > 8000 RPM <b>Not P/N:</b> Output Speed drop >1300 RPM	<ul> <li>Time since last Gear Range Change &gt; 6 Seconds</li> <li>Engine Speed &gt; 450 rpm for 5 seconds and not in fuel cutoff</li> <li>No Output Speed rise &gt; 600 rpm within 6 seconds</li> <li>No PSA DTC set</li> </ul>	In park or neutral 409 seconds Not in park or neutral 3 seconds	DTC Type B
TCC Enable Solenoid Electrical	P0740	0V to 12V This DTC detects a continuous open or short to ground in the TCC circuit or the TCC solenoid	Fail Counter >43 Counts out of 50 Total Counts	<ul> <li>System Voltage: 10 to 16 volts</li> <li>Engine Speed &gt; 450 rpm for 5 seconds and not in fuel cutoff</li> </ul>	Continuous	DTC Type B
TCC System Stuck ON	P0742	This DTC detects low torque converter slip when the TCC is commanded off.	TCC Slip: -20 to +20 RPM Fail Counter >= 2	<ul> <li>Engine Speed &gt; 450 rpm for 5 seconds and not in fuel cutoff</li> <li>No Range change within 5 sec.</li> <li>No MAP low and high DTC set</li> <li>No TP high or low sensor DTC's</li> <li>No VSS DTC's</li> <li>No TCC Enable Sol. DTC's</li> <li>No TCC Control Sol. DTC's</li> <li>No PSA DTC set</li> <li>Eng Torque: 50 to 400 ft-lbs</li> <li>Vacuum: 0 to 105 kPa</li> <li>Commanded Gear is not 1st</li> <li>Gear Range is D4</li> <li>Throttle Position: 17% to <b>45%</b></li> <li>TCC is commanded off</li> <li>Engine Speed: 1000 to 3000 rpm</li> <li>Speed Ratic: 0.64 to 1.35</li> <li>Vehicle Speed: 15 to 50 mph</li> </ul>	5 seconds Continuous	DTC Type B

### 1999 4.3 (LF6 and L35)S/T-truck, M/L-van, C/K-truck, G-van (includes Isuzu Hombre)4L60-ETRANSMISSIONDIAGNOSTICPARAMETERS

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Shift Solenoid A Performance	P0751	This DTC detects abnormal shift patterns: Stuck OFF: 2-2-3-3 pattern Stuck ON: 1-1-4-4 pattern	Fail Counter >=3.         The fail counter is incremented when the following fail cases are true:         Stuck OFF:         1,2,3,& 4         Stuck ON:         1,2,3, & 5	General         -Engine Speed > 450 rpm for 5 seconds and not in fuel cutoff         -Gear range is D4         -No TP high or low DTC's         -No VSS low or intermittent DTC's         -No ODE TC 742         -No PSA DTC set         -Time since last shift is >0 sec         -Vehicle speed >5 mph         -Trans Temp:: 20 C to 130 C         Fail Case 1         - Commanded 1-2 shift         - TPS: 10% to 45%         - Vehicle Speed: 5 to 35 mph         - After 2 seconds, engine speed in 2nd gear must be 80 rpm > last speed in 1st gear         Fail Case 2         - Commanded 2-3 shift         - TPS: 10% to 45%         - TPS constant within +/- 7%         - Vehicle Speed: 2 to 50 mph         - After 2 sec, negine speed in 3rd gear must be 100 rpm < last speed in 2nd gear	Continuous	DTC Type A
Shift Solenoid A Electrical	P0753	0V to 12V This DTC detects a continuous open or short to ground in the SSA circuit or the SSA solenoid	Fail Counter >43 Counts out of 50 Total Counts To set the fault:	<ul> <li>System Voltage: 10 to 16 volts</li> <li>Engine Speed &gt; 450 rpm for 5 seconds and not in fuel cutoff</li> </ul>	Continuous	DTC Type B

# 1999 4.3 (LF6 and L35)S/T-truck, M/L-van, C/K-truck, G-van (includes Isuzu Hombre)4L60-ETRANSMISSIONDIAGNOSTICPARAMETERS

#### 99t43WXLD\_aT.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Shift Solenoid B Performance	P0756	This DTC detects abnormal shift patterns: Stuck OFF: 4-3-3-4 pattern Stuck ON: 1-2-2-1 pattern	Fail Counter >=3. The fail counter is incremented when the following fail cases are true: Stuck OFF: 1 and 3, or 2 and 3 Stuck ON: 3 and 4	<ul> <li>Engine Speed &gt; 450 rpm for 5 seconds and not in fuel cutoff</li> <li>Gear Range is D4</li> <li>No TPS DTC's</li> <li>No VSS DTC's</li> <li>No VCS Stuck On DTC.</li> <li>No PSA DTC set</li> <li>No TCA Stuck On DTC.</li> <li>No PSA DTC set</li> <li>Vacuum: 0 to 105 kpa</li> <li>Engine Torque: 5 to 450 ft lbs</li> <li>Trans Temp DTC's Set.</li> <li>Vehicle Speed &gt; 5 MPH</li> </ul> <b>Fail Case 1</b> <ul> <li>1st gear commanded &gt; 2.0 sec.</li> <li>Output Speed: 400 to 1500 rpm</li> <li>Speed Ratio: 0.5 to 3.0</li> <li>Throttle Position &gt; 15%</li> <li>TCC Slip: -3000 to -100 rpm</li> <li>for &gt; 1.0 seconds</li> </ul> <b>Fail Case 2</b> <ul> <li>2nd gear command &gt; 409.5 sec</li> <li>Engine Torque: 8 to 450 ft lbs</li> <li>Vacuum: 0 to 105 kpa</li> </ul> For CC Slip: 8191 to 8191 rpm <ul> <li>Output speed: 8191 to 8191 rpm</li> <li>Speed Ratio: 8 to 8</li> <li>Throttle Position &gt; 99.9%</li> <li>Fail Time &gt; 409.5 sec</li> </ul> <b>Fail Time</b> > 409.5 sec <b>Fail Time</b> > 500 rpm Speed Ratio: 8 to 8 Throttle Position > 99.9% Fail Time > 409.5 sec <b>Fail Time</b>	Continuous	DTC Type A
Shift Solenoid B Electrical	P0758	0V to 12V This DTC detects a continuous open or short to ground in the SSB circuit or the SSB solenoid	Fail Counter >43 Counts out of 50 Total Counts	- System Voltage: 10 to 16 volts - Engine Speed > 450 rpm for 5 seconds and not in fuel cutoff	Continuous	DTC Type A
3-2 Downshift Solenoid Electrical	P0785	0V to 12V This DTC detects a continuous open or short to ground in the SSB circuit or the SSB solenoid	Fail Counter >43 Counts out of 50 Total Counts	- System Voltage: 10 to 16 volts - Engine Speed > 450 rpm for 5 seconds and not in fuel cutoff	Continuous	DTC Type A

### 1999 4.3 (LF6 and L35)S/T-truck, M/L-van, C/K-truck, G-van(includes Isuzu Hombre)4L60-ETRANSMISSIONDIAGNOSTICPARAMETERS

#### 99t43WXLD\_aT.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
PSA Circuit Malfunction	P1810	0V to 12V This DTC detects an invalid state of the PSA sensor or the PSA circuit by deciphering the PSA inputs.	Fail Case 1         Illegal Trans Pressure Switch State (111) or (101)         Fail Case 2         Gear range is D2, D4, or Reverse during engine startup.         Fail Case 3         Gear range is Park or Neutral when operating in D4.	Fail Case 1         - Engine Speed > 450 rpm for 5 seconds and not in fuel cutoff         - System Voltage: 10 to 16 volts         Fail Case 2         - System Voltage: 10 to 16 volts         - No VSS DTC's         - Vehicle Speed < 20 rpm for > 0.1 seconds, then,         2. Engine Speed: 80 to 550 rpm for > 0.1 seconds, then,         3. Engine Speed: 80 to 550 rpm         Fail Case 3         - Engine Speed > 450 rpm for 5 seconds and not in fuel cutoff         - System Voltage: 10 to 16 volts         - Hingine Speed > 450 rpm for 5 seconds and not in fuel cutoff         - System Voltage: 10 to 16 volts         - Hingine Torque: 40 to 400 ft-lbs         - Vacuum: 0 to 105 kPa         - TCC Locked On         - No VSS DTC's         - Speed Ratio: 0.60 to 0.75`         - TPS: 10% to 50%	Fail Case 1         60 seconds         Fail Case 2         5 Seconds         Fail Case 3         10 seconds         Continuous	DTC Type B
TCC PWM Solenoid Electrical	P1860	0V to 12V This DTC detects a continuous open or short to ground in the TCC PWM circuit or the TCC PWM sensor	Fail Counter >43 Counts out of 50 Total Counts	<ul> <li>System Voltage: 10 to 16 volts</li> <li>Engine Speed &gt; 450 rpm for 5 seconds and not in fuel cutoff</li> <li>Commanded Gear is 1st</li> <li>TCC Duty Cycle &lt; 10% or &gt; 90%</li> </ul>	Continuous	DTC Type B
Transmission Component Slipping	P1870	This DTC detects excessive TCC slip when the torque converter clutch should be engaged.	If TCC slip is: <b>130 to 800 rpm</b> for 7 seconds, then increment the Trans Slip Counter by one. When the counter reaches 3, set the code.	<ul> <li>Engine Speed &gt; 450 rpm for 5 seconds and not in fuel cutoff</li> <li>Gear is not 1st</li> <li>Gear Range is D4</li> <li>No PSA DTC's set</li> <li>No TPS High or Low DTC's</li> <li>No solenoid electrical DTC's</li> <li>No trans temp: 20 C to 130C</li> <li>Engine Torque: 50 to 400 ft-lbs</li> <li>Vac: 0 to 105 kpa</li> <li>Speed ratio: 0.69 to 0.88</li> <li>Engine Speed: 1500 to 3000 rpm</li> <li>Vehicle Speed: 30 to 70 mph</li> </ul> Fail Case 1 <ul> <li>TCC commanded on for &gt; 5 sec and at max duty cycle (95%).</li> </ul>	Continuous	DTC Type B

### 1999 4.3 (LF6 and L35)S/T-truck, M/L-van, C/K-truck, G-van(includes Isuzu Hombre)4L60-ETRANSMISSIONDIAGNOSTICPARAMETERS

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Four Wheel Drive Low Circuit Performance	P1875	OV to 12V This DTC detects a continuous open or short to ground in the Four Wheel Drive low Circuit	Stuck On         Engine Spd Divided by Transfer Case Output         Spd Ratio:         .8 to 1.2         Stuck Off         Engine Spd Divided by Transfer Case Output         Spd Ratio:         2.5 to 2.9	<ul> <li>Engine Speed &gt; 450 rpm for 5 seconds and not at fuel cut off</li> <li>No TPS DTC's set</li> <li>No PSA DTC's set</li> <li>Gear Range is D4</li> <li>Shift Solenoid Performance Counters are zero</li> <li>No VSS Low DTC's set</li> <li>No TCC Enable Sol. DTC's set</li> <li>No TCC Control Sol. DTC's set</li> <li>No SSA Sol. DTC's set</li> <li>No SSA Sol. DTC's set</li> <li>No SSB Sol. DTC's set</li> <li>Store Sole Sole Sole Sole Sole Sole Sole Sol</li></ul>	Stuck ON: 5 Seconds Stuck OFF: 10 Seconds 1 Occurance Continuous	DTC Type B