when used with 2.0L (LK9, LQ8) 2.3L (LU4, LJ3, L88)

in these vehicles: Saab 9-3, 9-5

# TRANSMISSION DIAGNOSTIC PARAMETERS

Component / System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters / Enable Conditions	Time Required	MIL Illumin.	Extra Prep
TCM, Internal Fault	P0605	ROM checksum or RAM	Calculated checksum differs		Ignition ON	Immediately	Immediately	
TOM, Internal Fault	F0003	error	from stored.		Number of failed calculations: 2	Continuous	illillediately	
Locat					Engine rpm > 500 rpm once within the driving cycle	4 sec		
Lost communication	U0100	Frame missing from ECM	Detect no Status CAN frame from ECM		Ignition ON + 3 sec	Continuous	Immediately	
with ECM (Engine)			IIOIII ECIVI		Battery voltage >10,2 V			
					Limp home mode = Off			
					Engine rpm > 400 rpm	4 sec		
					Not lost communication with ECM	Continuous		
Invalid data from ECM	P1895	Engine Torque signal is indicated invalid	Invalid Torque data from ECM		Ignition ON > 3 sec		Immediately	
2011					Battery voltage > 10,2 V			
					Limp home mode = Off			
		Circuit continuity check			Engine rpm > 400 rpm	500 msec	Immediately	
	P0985	Circuit continuity check  ← →	Short-cut ground		Engine rpm > 400 rpm Limp home mode = Off	500 msec Continuous	Immediately	
Solenoid S1	P0985 P0986		Short-cut ground  Not connected or short-cut Ubatt				Immediately	
Solenoid S1		$\leftarrow$ $\rightarrow$	Not connected or short-cut		Limp home mode = Off		Immediately	
Solenoid S1		$\leftarrow$ $\rightarrow$	Not connected or short-cut		Limp home mode = Off  Time after ctrl status change > 25 ms		Immediately	
		← → ← →	Not connected or short-cut		Limp home mode = Off  Time after ctrl status change > 25 ms  Battery voltage > 10,2 V	Continuous	,	
Solenoid S1 Solenoid S2	P0986	← → ← → Circuit continuity check	Not connected or short-cut Ubatt		Limp home mode = Off  Time after ctrl status change > 25 ms  Battery voltage > 10,2 V  Engine rpm > 400 rpm	Continuous 500 msec	,	
	P0986 P0973	← →  ← →  Circuit continuity check  ← →	Not connected or short-cut Ubatt  Short-cut ground  Not connected or short-cut		Limp home mode = Off  Time after ctrl status change > 25 ms  Battery voltage > 10,2 V  Engine rpm > 400 rpm  Limp home mode = Off	Continuous 500 msec	,	
	P0986 P0973	$\begin{array}{ccc} \longleftarrow \longrightarrow & \\ \longleftarrow \longrightarrow & \\ \\ \longleftarrow \longrightarrow & \\ \longleftarrow \longrightarrow & \\ \longleftarrow \longrightarrow & \\ \end{array}$	Not connected or short-cut Ubatt  Short-cut ground  Not connected or short-cut		Limp home mode = Off  Time after ctrl status change > 25 ms  Battery voltage > 10,2 V  Engine rpm > 400 rpm  Limp home mode = Off  Time after ctrl status change > 25 ms	Continuous 500 msec	,	
Solenoid S2	P0986 P0973	← →  ← →  Circuit continuity check  ← →	Not connected or short-cut Ubatt  Short-cut ground  Not connected or short-cut Ubatt  Short-cut ground		Limp home mode = Off  Time after ctrl status change > 25 ms  Battery voltage > 10,2 V  Engine rpm > 400 rpm  Limp home mode = Off  Time after ctrl status change > 25 ms  Battery voltage > 10,2 V	Continuous  500 msec  Continuous	Immediately	
	P0986 P0973 P0974	$\begin{array}{c} \longleftarrow \longrightarrow \\ \longleftarrow \longrightarrow \\ \\ \text{Circuit continuity check} \\ \longleftarrow \longrightarrow \\ \longleftarrow \longrightarrow \\ \\ \text{Circuit continuity check} \\ \end{array}$	Not connected or short-cut Ubatt  Short-cut ground  Not connected or short-cut Ubatt		Limp home mode = Off  Time after ctrl status change > 25 ms  Battery voltage > 10,2 V  Engine rpm > 400 rpm  Limp home mode = Off  Time after ctrl status change > 25 ms  Battery voltage > 10,2 V  Engine rpm > 400 rpm	Continuous 500 msec Continuous 500 msec	Immediately	

2005trans7.xls Page 1 of 9

when used with 2.0L (LK9, LQ8) 2.3L (LU4, LJ3, L88) in these vehicles: Saab 9-3, 9-5

### TRANSMISSION DIAGNOSTIC PARAMETERS

Component / System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters / Enable Conditions	Time Required	MIL Illumin.	Extra Prep
	B0070	Circuit continuity check	Object and property		Engine rpm > 400 rpm	500 msec	Immediately	
Solenoid S4	P0979 P0980	$\begin{array}{ccc} & \leftarrow & \rightarrow & \\ & \leftarrow & \rightarrow & \end{array}$	Short-cut ground  Not connected or short-cut Ubatt		Limp home mode = Off  Time after ctrl status change > 25 ms	Continuous		
			Oball		Battery voltage > 10,2 V			
		Circuit continuity check			Engine rpm > 400 rpm	500 msec	Immediately	
Solenoid S5	P0982	$\leftarrow$ $\rightarrow$	Short-cut ground		Limp home mode = Off	Continuous		
	P0983	$\leftarrow$ $\rightarrow$	Not connected or short-cut Ubatt		Time after ctrl status change > 25 ms			
					Battery voltage > 10,2 V			
					Engine rpm > 400 rpm	12 sec	Immediately	
					Throttle > 20%	Continuous		
					Trans. Input rpm signal OK			
					CAN BUS signals OK ( validity )			
Torque Converter	D0744	Comparison of engine speed			Engine rpm < 4000 rpm			
Clutch Slips	P0741	and transmission input speed			SLU target current >= 1000mA			
					Time after shifting > 0,5 sec			
					Limp home mode = Off			
					Battery voltage > 10,2 V			
					Lock-up activated			
					Active gear: 3, 4, or 5			
					Lock-up status: OFF	Continuous		
					Trans. Input rpm signal < 3000 rpm			
					Engine torque in defined range			
Torque Converter		Comparison of engine speed	(Eng. Rpm - Trans. Input rpm) <		Oil temperature > 20 deg C			
Clutch Stuck On	P0742	and transmission input speed	50 Converter clutch is locked when it should be slipping		Battery voltage > 10,2 V			
					Engine speed > 400 rpm			
					Time after shifter status change > 8 sec			
					Time after shifting > 0,5 sec			
					Time after ignition ON > 3 sec			

2005trans7.xls Page 2 of 9

when used with 2.0L (LK9, LQ8) 2.3L (LU4, LJ3, L88) in these vehicles: Saab 9-3, 9-5

## TRANSMISSION DIAGNOSTIC PARAMETERS

Component / System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters / Enable Conditions	Time Required	MIL Illumin.	Extra Prep
Pressure solenoid SLU	P2764	Circuit continuity check	Short-cut ground or open	Low current, <92 mA, AD < 68	Limp home mode = Off  Engine speed > 400 rpm  Battery voltage > 10,2 V	12,5 sec Continuous	Immediately	
	P2762		Terminal short	Error current > 80 mA	Limp home mode = Off Engine speed > 400 rpm Oil temp > 20 deg C System voltage change < 0,2V System voltage 11 -16 V Output current target > 835mA and not changed during detection.	2,75 sec Continuous	Immediately	
	P2763		Short-cut Ubatt	Measured Current > 1,356 mA, AD > 1000	Limp home mode = Off Engine speed > 400 rpm Battery voltage > 10,2 V	2 sec Continuous	Immediately	
	P0962	Circuit continuity check	Short-cut ground or open	Low current, <92 mA, AD < 68	Limp home mode = Off Engine rpm > 400 Battery voltage > 10,2 V	12.5 sec Continuous	Immediately	
Pressure solenoid SLT	P0961		Terminal short	Error current > 80 mA	Limp home mode = Off Engine speed > 400 rpm Oil temp > 20 deg C System voltage change < 0,2V System voltage 11 -16 V Output current target > 835mA and not changed during detection.	2.75 sec Continuous	Immediately	
	P0963		Short-cut Ubatt	Measured Current > 1,356 mA, AD > 1000	Limp home mode = Off Engine speed > 400 rpm Battery voltage > 10,2 V	2 sec Continuous	Immediately	

2005trans7.xls Page 3 of 9

AF33-5

when used with 2.0L (LK9, LQ8) 2.3L (LU4, LJ3, L88) in these vehicles: Saab 9-3, 9-5

## TRANSMISSION DIAGNOSTIC PARAMETERS

Component / System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters / Enable Conditions	Time Required	MIL Illumin.	Extra Prep
Timing solenoid SLS	P0787	Circuit continuity check	Short-cut ground or open	Low current, <92 mA, AD < 68	Limp home mode = Off Engine rpm > 400 Battery voltage > 10,2 V	12.5 sec Continuous	Immediately	
	P0786		Terminal short	Error current > 80 mA	Limp home mode = Off  Engine speed > 400 rpm  Oil temp > 20 deg C  System voltage change < 0,2V  System voltage 11 -16 V  Output current target > 835mA and not changed during detection.	2.75 sec Continuous	Immediately	
	P0788		Short-cut Ubatt	Measured Current > 1,356 mA, AD > 1000	Limp home mode = Off Engine rpm > 400 Battery voltage > 10,2 V	2 sec Continuous	Immediately	
Shift Malfunction	P0780	Shift time check	Shift time is too long, too short or "tie up" occurs		Oil temp > 60 deg C  No other failure is detected  Limp home mode = Off  Shifter position: D, 4, 3, L, or M	5 times detection during DCY Continuous	Immediately	
CAN Bus Off Counter Overrun	U0001	CAN controller continuity check	CAN controller Bus Off is detected	Counter reaches 64	Limp home mode = Off  3 sec after Ignition ON or reset of CAN controller.  Battery voltage > 10,2 V	12,7 - 28 sec Continuous	Immediately	

2005trans7.xls Page 4 of 9

AF33-5

when used with 2.0L (LK9, LQ8) 2.3L (LU4, LJ3, L88)

in these vehicles: Saab 9-3, 9-5

### TRANSMISSION DIAGNOSTIC PARAMETERS

Component / System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters / Enable Conditions	Time Required	MIL Illumin.	Extra Prep
Transmission input speed sensor	P0717	Circuit continuity check	No pulse	No pulse of Input speed sensor during 3000 pulses of output speed sensor	Limp home mode = Off  Shifter position: D, 4, 3, or L	Speed dependent (e.g 4 sec at 100 km/h)	Immediately	
				In rpm = 0 AND Speed from ABS sensor > 20 km/h	Limp home mode = off	2,30 sec		
			Pulses incorrect		Limp nome mode – on	2,30 Sec	Immediately	
	P0716				3 sec after Ignition ON or reset of CAN controller.	Continuous		
	1 07 10			Short to Ubatt or	Limp home mode = off	3,30 sec	Immediately	
				to ground	DO # 000	Continuous		
					DS_active???			
					Limp home mode = off	4 sec	Immediately	
Invalid signal from	P1820	Accelerator pedal position	Data from ECM indicated as		3 sec after Ignition ON or reset of CAN controller.	Continuous	Immediately	
ECM	. 1020	signal is invalid	invalid		Engine speed > 400 rpm			
					Battery voltage > 10,2 V			

2005trans7.xls Page 5 of 9

when used with 2.0L (LK9, LQ8) 2.3L (LU4, LJ3, L88) in these vehicles: Saab 9-3, 9-5

## TRANSMISSION DIAGNOSTIC PARAMETERS

Component / System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters / Enable Conditions	Time Required	MIL Illumin.	Extra Prep
Trans. Output speed sensor	P0722	Description	Criteria No pulse	No pulse of Output speed sensor during 6000 pulses of input speed sensor  Out Rpm = 0 AND Speed ABS > 20 km /h	Limp home mode = Off Out Rpm calculated from ABS > 3000 Selected gear D, 4, 3, L No temperature failure No ABS failure Limp home mode = Off Out Rpm calculated from ABS > 3000 Selected gear D, 4, 3, L No temperature failure No ABS failure	6000 pulses Continuous  2.30 sec Continuous	Immediately	Tiep
				Short to Ubatt or GND	Limp home mode = off	3.30 sec Continuous	Immediately	
	P0721		Incorrect rpm	Difference > 15% compared to calculated from input speed		10 sec		
	P0721					Continuous		
				Calculated ratio differs more than 10% from expected	Limp home mode = Off	12 sec Continuous	Immediately	
Gear error, hydraulic fault	P0730	Rationality	Calculation of actual gear ratio is not correct	Driving on 5th gear - gear ratio equals ratio for 3rd gear	out Rpm > 500			
				Driving on 4 <sup>th</sup> gear - gear ratio equals ratio for 3rd gear	throttle > 10 %			
Transmission range switch	P0705	Check of switch output pattern	Failure combination of signals from Gear Selector range switch		Limp home mode = Off Engine speed > 400 rpm Battery voltage > 10,2 V	5 sec Continuous	Immediately	

2005trans7.xls Page 6 of 9

AF33-5

when used with 2.0L (LK9, LQ8) 2.3L (LU4, LJ3, L88) in these vehicles: Saab 9-3, 9-5

### TRANSMISSION DIAGNOSTIC PARAMETERS

Component / System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters / Enable Conditions	Time Required	MIL Illumin.	Extra Prep
					Limp home mode = Off	15 min	Two DCY	
					Oil temp sensor AD >10 & < 1000	Once / DCY		
				5°C	Oil temp at initialization < 20 °C			
	P0711	Rationality	Oil temp change less than		Selected gear R, D, 4, 3, L			
	F0711	Nationality	Oil temp change less than	3 0	Eng. rpm > 400 rpm			
					15min driving time			
					Vehicle speed > 40 km/h once			
					Battery voltage > 10,2 V			
Transmission oil temperature sensor					Limp home mode = off	5 min	Two DCY	
	P0712	Circuit continuity check	Short-cut ground	Voltage < 50 mV, AD < 10	Engine speed > 400 rpm	Continuous	TWO DCT	
					Battery voltage > 10,2 V			
					Limp home mode = off	12 sec + 15 min	Two DCY	
					Engine speed > 400 rpm	Continuous		
	P0713	Circuit continuity check	Chart aut I lhat ar anan aircuit	AD > 1000	ECT > 50 deg C			
	PU/ 13	Circuit continuity check	Short-cut Ubat or open circuit	AD > 1000	ECT signal valid			
					15 min driving time			
					Battery voltage > 10,2 V			

2005trans7.xls Page 7 of 9

when used with 2.0L (LK9, LQ8) 2.3L (LU4, LJ3, L88) in these vehicles: Saab 9-3, 9-5

## TRANSMISSION DIAGNOSTIC PARAMETERS

Component / System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters / Enable Conditions	Time Required	MIL Illumin.	Extra Prep
	P0731	Rationality	Calculation of actual gear ratio for 1st gear is not correct.	Calculated ratio for 1st gear differs more than 4% from expected	Limp home mode = Off Selected gear D, 4, 3, L 500 < output shaft speed < 1260 (rpm) No other failure detection A/T oil temp. > 20 °C	12 sec Continuous	Immediately	
	P0732	Rationality	Calculation of actual gear ratio for 2nd gear is not correct.	Calculated ratio for 2nd gear differs more than 20% from expected	Throttle > 10%  0,5 sec after shifting control done  Current gear = 2  out Rpm >= 500	12 sec Continuous	Immediately	
	P0733	Rationality	Calculation of actual gear ratio for 3rd gear is not correct.	Calculated ratio for 3rd gear differs more than 20% from expected	Throttle > 10%  Current gear = 3  out Rpm >= 500	12 sec Continuous	Immediately	
Gear error, hydraulic fault	P0734	Rationality	Calculation of actual gear ratio for 4th gear is not correct.	Calculated ratio for 4th gear differs more than 20% from expected, but not equals 3 <sup>rd</sup> gears.ratio +- 4%	Throttle > 10%  Current gear = 4  out Rpm >= 500	12 sec Continuous	Immediately	
	P0735	Rationality	Calculation of actual gear ratio for 5th gear is not correct.	Calculated ratio for 5th gear differs more than 20% from expected	Throttle > 10%  Current gear = 5  out Rpm >= 500	12 sec Continuous	Immediately	
	P0736	Rationality	Calculation of actual gear ratio for Reverse gear is not correct	Calculated ratio for Reverse gear differs more than 20% from expected	Limp home mode = Off Selected gear R A/T oil temp. > 20 °C Throttle > 10% 0,5 sec after shifting Eng. Rpm > 400 rpm 8 sec after N-R-D shift IG voltage > 10,5 V out Rpm >= 500 out Rpm stable value	12 sec Continuous	Immediately	

2005trans7.xls

Page 8 of 9

AF33-5

when used with 2.0L (LK9, LQ8)

2.3L (LU4, LJ3, L88)

in these vehicles: Saab 9-3, 9-5

<b>TRANSMISSION</b>	DIAGNOSTIC	<b>PARAMETERS</b>
---------------------	------------	-------------------

Component / System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters / Enable Conditions	Time Required	MIL Illumin.	Extra Prep
	P0562	Voltage low		< 8,68 V	Limp home mode = Off	20 sec	Immediately	
Battery voltage	P0563	Voltage high		> 18 V	Transmission input speed > 800 rpm	Continuous		
					Ignition ON			
					Ignition on > 3 sec	4 sec	Immediately	
Engine speed	P0725	Signal from ECM stated as			Engine speed > 500 rpm	Continuous		
signal	10723	unreliable			Limp home mode = Off			
					Battery voltage > 10,2 V			

Note: All components/system (DTCs) have a test frequency of 30~60ms

2005trans7.xls Page 9 of 9