		ACCEPTABLE	PRIMARY	SECONDARY	MONITORING		FAULT CODE
SENSED PARAMETER	FAULT	OPERATING	MALFUNCTION	MONITORING	TIME LENGTH	MONITORING	STORAGE AND MIL
OLINOLD I AIVAIVILTEIX	CODE	RANGE AND	DETECTION	PARAMETERS	AND FREQUENCY	METHOD	ILLUMINATIO
		RATIONALITY	PARAMETERS	AND CONDITIONS	OF CHECK		N
	P00>	XX Fuel and Air Metering and Auxiliary	Emission Controls				
Crankshaft Position (CKP)-	P0016	Calculation of crank position by CKP sensor	PATH 1) Difference between CKP position as			Cam sensor (CMP	Α
Camshaft Position (CMP)		and CMP sensor disagree by < 6deg crank	calculated by CKP sensor and CMP sensor is		crankshaft increments	sensor) and Crank	
Correlation		angle. Detects implausible camshaft/crankshaft sensor correlation by comparing the differences		Engine Speed ≥ 50 rpm	(60 increments/revolution)	sensor (CKP sensor)	
		between calculated camshaft and crankshaft	PATH 2) Difference between CKP position as		PATH 2) 5 cam phases	301301)	
		positions.	calculated by CKP sensor and CMP sensor is		(4 phases/cam		
			< 6 degrees crank angle, but the CMP position		revolution)		
			tolerance is > 12 degrees (cam). CMP				
			position tolerance is the error between TDC and first edge of cam detection. Prevents false				
Turbocharger Boost Control	P003A	Position of the vanes opened during a learn :		P117,P118,P2563,	Diagnostic fail	Turbocharger	В
Position Not Learned		vane position > 5.54%, OR vane position <	vane position < 5.54%, OR vane position >		conditions true for for	Vane Position	
		36.94%	36.94%		30 seconds. Performed	Sensor.	
		Position of the vanes <u>closed</u> during a learn :	Position of the vanes <u>closed</u> during a learn :	commanding vanes open or closed during a	once per ignition cycle		
		vane position >69.92%, OR vane position < 95.60%. Detects in range vane position errors	vane position <69.92%, OR vane position > 95.60%	position learn process Injected Fuel <30 mm^3/S			
		during a vane sweep to lea	93.00%	600 rpm< engine speed <750 rpm			
		daming a vario owoop to loa		0 mph< vehicle speed< 200 kph			
				71C< Engine Coolant Temp <96C			
Turbocharger Boost Control	P0047	Electronic out-put driver circuitry determines the	Electronic out-put driver circuitry determines	60 kna <=Baro <=110 kna Ignition On	Diagnostic fail	ECM Electronic out	В
Solenoid Circuit Low	1 0047	faults (open/short/no load) do not exist on the	the faults (open/short/no load) do exist on the	ignition on	conditions true for 4	put driver circuitry	
		Turbo Boost Solenoid Cntrl Circuit.	Turbo Boost Solenoid Cntrl Circuit.		seconds. Test	ľ	
					performed continuously		
Turbocharger Boost Control	P0048	Electronic out-put driver circuitry determines the	Electronic out-put driver circuitry determines	Ignition On	Diagnostic fail	ECM Electronic out	В
Solenoid Circuit High		faults (open/short/no load) do not exist on the	the faults (open/short/no load) do exist on the		conditions true for 4	put driver circuitry	
		Turbo Boost Solenoid Cntrl Circuit.	Turbo Boost Solenoid Cntrl Circuit.		seconds. Test		
					performed continuously		
Fuel Rail Pressure [FRP]	D0097	22.5 Mpa to 198 Mpa	Path 1: Measured Rail Pressure sensor > 15	P0090,P0192,P0193, DTCs are not set	Path1: Diagnostic fail	Rail Pressure	A
Too Low	F0067	Measured Rail Pressure sensor < 15 MPa	MPa below Desired rail Pressure.		condition true for	Sensor	A
100 2011		below Desired rail Pressure. AND	Path2: Measured Rail Pressure <= 22.5 MPa	•	10seconds. Test	Concor	
		Measured Rail Pressure sensor > = 22.5 MPa		engine traniations from crank to Run mode)			
					Path2: Diagnostic fail		
					conditions true for 12.5		
Fuel Deil Dressure (FDD)	Dooos	22.5 Mag to 100 Mag	DATILA) Magazirod Dall Discours	D0007 D0402 D0402 DTC	seconds . Test	Doil Drees	
Fuel Rail Pressure [FRP] Too High	20088	22.5 Mpa to 198 Mpa Measured Rail Pressure sensor < 20 MPa	<u>PATH 1</u>) Measured Rail Pressure sensor > 20 MPa above Desired rail Pressure AND Rail		PATH 1) 10 seconds continuous	Rail Pressure Sensor	А
100 riigii		above Desired rail Pressure. AND	Pressure Desired Fuel Flow <= 100 mm3/sec.	(closed loop RP control occurs when	PATH 2) 6 seconds	0011001	
		Measured Rail Pressure sensor < = 189 MPa	AND fuel injection qty > 1 mm3/stroke.	engine transitions from crank to Run mode)	,		
			PATH2: Measured Rail Pressure sensor	"Rail Pressure Desired Fuel Flow is			
			>189Mpa	calculated based on RPM and FR			

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Fuel Rail Pressure Regulator Control Circuit		Electronic out-put driver circuitry determines the faults (open/short/no load) do not exist on the Fuel Pressure Regulator Cntrl Circuit.	Electronic out-put driver circuitry determines the faults do exist on the Fuel Pressure Regulator Cntrl Circuit. PATH 1) open (no load) PATH 2) Low side short to ground PATH 3) Low side short to battery Voltage PATH 4) High side short to ground		· ·	ECM Electronic out put driver circuitry	А
Fuel Rail Pressure Relief (PRV) valve performance		FRP is to be between 25Mpa - 189Mpa during engine run. Measured FRP gradients must be < negative compared to FRP gradients to detect NO open PRV	Test Enabler: FRP > 189 Mpa Condition #1 to detect open PRV 3 Measured FRP gradients must be more negative_then compared gradient to detect open PRV. Condition #2 to detect open PRV 1 Measured FRP gradient must be more negative then compared gradient, AND the SUM of all 3 measured FRP gradients must be		Peformed continuoulsy when FRP is > then 189 Mpa		A

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Intake Air Temperature (IAT) Sensor 2 Circuit Low Voltage	P0097	0.10 volt to 4.8 volts -40degC to 200 degC Detects a sensor circuit short to ground	Air temperature sensor voltage <= 0.10 volt -same as- Air temperature>200degC	Ignition On	Diagnostic fail conditions true for 1 seconds Test performed continuously 100msec rate	Air temperature sensor	В
Intake Air Temperature (IAT) Sensor 2 Circuit High Voltage	P0098	0.10 volt to 4.8 volts -40degC to 200 degC Detects a sensor circuit short high voltage or a sensor circuit open	Air temperature sensor voltage>=4.8 volt -same as- Air temperature<-40degC	Ignition On	Diagnostic fail conditions true for 1 seconds Test performed continuously	Air temperature sensor	В
		X Fuel and Air Metering					
Mass Air Flow (MAF) Sensor Performance	P0101	106 kg/hr to 1800 kg/hr. (309 us to 109 us) 0 .87 < Normalized air flow ratio < 1.15 The normalized air flow ratio is derived by dividing the reference air flow by the actual air flow.	Normalized air flow ratio < 0.87 OR Normalized air flow ratio > 1.15	P2229,P0117,P0118,P0112,P0113,P0652,	Diagnostic fail conditions true for 16 seconds Test performed continuously .	Mass Air Flow Sensor	В
Mass Air Flow (MAF) Sensor Circuit Low Voltage	P0102	106 kg/hr to 1800 kg/hr. (309 us to 109 us) Signal > 90 us same as Flow > 2970 kg/hr Lower threshold for the SRC of the raw airmass signal HFM6 sensor.	Signal > 106 us same as Flow > 1900 kg/hr	500 < RPM < 3100.	Diagnostic fail conditions true for 3 seconds Test performed continuously	Mass Air Flow Sensor	В
Mass Air Flow (MAF) Sensor Circuit High Voltage	P0103	106 kg/hr to 1800 kg/hr. (309 us to 109 us) Signal > 881 us same as Flow > 10 kg/hr Lower threshold for the SRC of the raw airmass signal HFM6 sensor.	Signal < 360 us same as Flow > 72 kg/hr	Ignition On	Diagnostic fail conditions true for 3 seconds Test performed	Mass Air Flow Sensor	В
Manifold Absolute Pressure (MAP) Sensor Performance	P0106	43.9 mv - 4149 mv (10 kPA - 307kPa) Absolute value (Baro - MAP) < 15kPa	Absolute value (Baro - MAP) > 15kPa	P0107,P0108,P2228,P2229 DTCs are not set. ECM powered On, RPM < 750.	Diagnostic fail conditions true for 10 sec. Test performed	Manifold Absolute Pressure (MAP) Sensor and Baro	А
Manifold Absolute Pressure (MAP) Sensor Circuit Low Voltage	P0107	43.9 mv - 4149 mv (10 kPA - 307kPa) Detects MAP sensor circuit open or short to ground	MAP Sensor Signal <43.9 mv same as 10kpa	Ignition voltage >11 volts Engine Run time >1sec	Diagnostic fail condition true for 2 seconds Test performed continuously	Manifold Absolute Pressure (MAP) Sensor	А
Manifold Absolute Pressure (MAP) Sensor Circuit High Voltage	P0108	43.9 mv - 4149 mv (10 kPA - 307kPa) Detects MAP sensor circuit short to high voltage	MAP Sensor Signal >4149 mv same as 307kpa	Engine Run time >1sec	Diagnostic fail condition true for 2 seconds Test performed continuously	Manifold Absolute Pressure (MAP) Sensor	A
Intake Air Temperature (IAT) Sensor Circuit Low Voltage	P0112	0.10 volt to 4.8 volts -40degC to 150 degC Detects a sensor circuit short to ground	Intake Air temperature sensor voltage <= 0.10 volt -same as- Air temperature>150degC	Ignition On	Diagnostic set conditions true for 1 second Test performed continuously	Intake Air temperature sensor	В
Intake Air Temperature (IAT) Sensor Circuit High Voltage	P0113	0.10 volt to 4.8 volts -40degC to 150 degC Detects a sensor circuit short high voltage or a sensor circuit open	Intake Air temperature sensor voltage>=4.8 volt -same as- Air temperature<-40degC	Ignition On	Diagnostic set conditions true for 1 second Test performed continuously 100msec rate	Intake Air temperature sensor	В

-							
SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Engine Coolant Temperature (ECT) Sensor Performance	P0116	absolute value of (Startup Coolant Temperature Sensor - Startup Air Temperature Sensor 2) < 15degC. Detects biased Air Temperature Sensor 2	PATH 1) absolute value of (Startup Coolant Temperature Sensor - Air Temperature Sensor 2) > 15degC AND block heater influenced determined to be not true. Block heater influence is true if after 6.5 mins at VSS	PATH 1) absolute value of (Startup Coolant Temperature Sensor - Air Temperature Sensor 2) > 15degC AND block heater influence determined to be not true. Block heater influence is true if after	fail Test performed once per key cycle	Coolant Temperature Sensor and Intake Air Temperature Sensor 2	В
Engine Coolant Temperature (ECT) Sensor Circuit Low Voltage		0.065 V to 4.75 V -40degC to 150 degC Detects a sensor circuit short to ground	Coolant Temperature Sensor voltage <= 0.065 volt -same as- Coolant Temperature>150degC		Diagnostic set conditions true for 15 second Test performed continuously	Coolant Temperature Sensor	В
Engine Coolant Temperature (ECT) Sensor Circuit High Voltage		0.065 V to 4.75 V -40degC to 150 degC Detects a sensor circuit short high voltage or a sensor circuit open	-same as- Coolant Temperature >-40 degC		Diagnostic set conditions true for 60 second Test performed continuously	Coolant Temperature Sensor	В
Engine Coolant Temperature (ECT 1/ ECT2) Corrolation	P011A	absolute value of (Engine Coolant Temperature 1 - Engine Coolant Temperature 2) < 5deg C. Detects biased Coolant Temperature Sensor (ECT1 or ECT 2)	absolute value of (Engine Coolant Temperature 1 - Engine Coolant Temperature 2) > 5deg C. Detects biased Coolant Temperature Sensor (ECT1 or ECT 2)	,	Diagnostic set conditions true for 4 seconds. Test performed continuously	Engine Coolant temperature sensor 1 and Engine Coolant temperature	В
Engine Coolant Temperature (ECT) Below Thermostat Regulating Temperature	P0128	Engine Temperature at start < 65 degC AND ambient air temperature > 10 degC OR Engine Temperature at start < 45 degC AND ambient air temperature <= 10 degC. Detects thermostat failures causing engine to run cooler than expected.	PATH 1 High Region) Modeled coolant temp predicts coolant temp should be > 80 deg C AND Actual coolant temp is < 72 degC PATH 2 Low Region) Modeled coolant temp > 55 and Actual coolant temp < 50 degC	P0128 not yet passed; AND P0112, P0113,P0116,P0117,P0118 DTCs are not set PATH 1 High Region) Ambient air temp >10 deg C PATH 2 Low Region) Ambient air temp <=10 deg C '-7 degC <ambient -40degc="" 100="" 65degc;="" <="" air="" degc;="" engine="" is="" running:<="" start-up="" td="" temp=""><td>Test performed once from start-up until a pass/fail/disable condition exists.</td><td>Engine coolant temperature sensor. IAT 1 sensor</td><td>В</td></ambient>	Test performed once from start-up until a pass/fail/disable condition exists.	Engine coolant temperature sensor. IAT 1 sensor	В
Fuel Tempertaure Sensor Performance	P0181	absolute value of (Startup Intake Air Temperature Sensor - Startup Fuel Temperature Sensor) < 10 degC. Detects bias Fuel Temperature Sensor or Intake Air Temperature Sensor	PATH 1) absolute value of (Startup Intake Air Temperature Sensor - Startup Fuel Temperature Sensor) > 10degC AND block heater influenced determined to be not true. Block heater influence is true if after 6.5 mins at VSS > 24kph the IAT drops 2.5degC		fail Test performed once per key cycle	Intake Air Temperature Sensor and Fuel Temperature Sensor	В
Fuel Temperature Sensor Circuit Low Voltage	P0182	0.12V -4.57V -30degC to 120degC Detects a sensor circuit short to ground	Fuel temperature<0.07 V - same as - Fuel temperature > 120degC	Ignition On	Diagnostic set conditions true for 1 seconds Test performed continuously at	Fuel temperature sensor	В
Fuel Temperature Sensor Circuit High Voltage	P0183	0.12V -4.57V -30degC to 120 degC Detects a sensor short to high voltage or sensor circuit open	Fuel temperature > 4.72 V - same as - Fuel temperature < -30degC	Ignition On	Diagnostic set conditions true for 1 seconds Test performed continuously100msec	Fuel temperature sensor	В

FAULT CODE

MONITORING

ressure A (P)
<u> </u>
ire A
ire A
or A out-put itry
or A out-put itry
or A out-put itry
ct c

						•	
SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Injector 4 Control Circuit	P0204	Electronic out-put driver circuitry determines that the faults (open/shert/no load) do not exist.	Electronic out-put driver circuitry determines that the faults (open/short/no load) do exist	Engine running. Injection event is being attempted for Cly 4	Fault exists for 6 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	Α
Injector 5 Control Circuit	P0205	Electronic out-put driver circuitry determines that the faults (open/short/no load) do not exist.	Electronic out-put driver circuitry determines that the faults (open/short/no load) do exist	Engine running. Injection event is being attempted for Cly 5		ECM Injector Electronic out-put driver circuitry	А
Injector 6 Control Circuit	P0206	Electronic out-put driver circuitry determines that the faults (open/short/no load) do not exist.	Electronic out-put driver circuitry determines that the faults (open/ short /no load) <u>do</u> exist	Engine running. Injection event is being attempted for Cly 6	Fault exists for 3 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	А
Injector 7 Control Circuit	P0207	Electronic out-put driver circuitry determines that the faults (open/shert/no load) do not exist.	Electronic out-put driver circuitry determines that the faults (open/short/no load) do exist	Engine running. Injection event is being attempted for Cly 7	Fault exists for 3 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	А
Injector 8 Control Circuit	P0208	Electronic out-put driver circuitry determines that the faults (open/shert/no load) do not exist.	Electronic out-put driver circuitry determines that the faults (open/short/no load) do exist	Engine running. Injection event is being attempted for Cly 8	Fault exists for 3 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	А
Turbocharger Engine Overboost	P0234	Measured Boost is < (see Worksheet Boost Deviation Map) above desired boost. Detects an Overboost condition or a biased high boost sensor.	Measured Boost is>(see Worksheet Boost Deviation Map) above desired boost Detects an Overboost condition or a biased high boost sensor.	P2564,P2565 DTCs are not set 800 rpm <= Engine RPM <=3600 rpm	Diagnostic fail condition true for 10 second Test performed continuously	MAP Sensor (aka Boost Sensor)	А
Turbochager Engine Underboost	P0299	Measured Boost is < (see Worksheet Boost Deviation Map) <u>below</u> Desired Boost Detects an underboost condition or a biased low sensor.	Measured Boost is > (see Worksheet Boost Deviation Map) <u>below</u> Desired Boost Detects an underboost condition or a biased low sensor.	P2564,P2565 DTCs are not set 800 rpm <= Engine RPM <=3600 rpm	Diagnostic fail condition true for 10 second Test performed continuously	MAP Sensor (aka Boost Sensor)	A
Cylinder 1 Injector Leaking	P029D	Cylinder #1, FBC is < -7.0	Cylinder #1, FBC is to be > -7.0	RPM 600 - 850, coolant temp > 40c, Fueling < 15mm3, Vehicle speed < 5km/hr.	Diagnostic fail condition true for 1 minute Test performed once per key cycle.	Monitor FBC (fuel balance control)	В
Cylinder 2 Injector Leaking	P02A1	Cylinder #2, FBC is < -7.0	Cylinder #2, FBC is to be > -7.0	RPM 600 - 850, coolant temp > 40c, Fueling < 15mm3, Vehicle speed < 5km/hr.	Diagnostic fail condition true for 1 minute Test performed once	Monitor FBC (fuel balance control)	В
Cylinder 3 Injector Leaking	P02A5	Cylinder #3, FBC is < -7.0	Cylinder #3, FBC is to be > -7.0	RPM 600 - 850, coolant temp > 40c, Fueling < 15mm3, Vehicle speed < 5km/hr.	Diagnostic fail condition true for 1 minute Test performed once per key cycle.	Monitor FBC (fuel balance control)	В
Cylinder 4 Injector Leaking	P02A9	Cylinder #4, FBC is < -7.0	Cylinder #4, FBC is to be > -7.0	RPM 600 - 850, coolant temp > 40c, Fueling < 15mm3, Vehicle speed < 5km/hr.	Diagnostic fail condition true for 1 minute Test performed once per key cycle.	Monitor FBC (fuel balance control)	В
Cylinder 5 Injector Leaking	P02AD	Cylinder #5, FBC is < -7.0	Cylinder #5, FBC is to be > -7.0	RPM 600 - 850, coolant temp > 40c, Fueling < 15mm3, Vehicle speed < 5km/hr.	Diagnostic fail condition true for 1 minute Test performed once per key cycle.	Monitor FBC (fuel balance control)	В

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Cylinder 6 Injector Leaking	P02B1	Cylinder #6, FBC is < -7.0	Cylinder #6, FBC is to be > -7.0	RPM 600 - 850, coolant temp > 40c, Fueling < 15mm3, Vehicle speed < 5km/hr.	Diagnostic fail condition true for 1 minute Test performed once per key cycle.	Monitor FBC (fuel balance control)	В
Cylinder 7 Injector Leaking		Cylinder #7, FBC is < -7.0	Cylinder #7, FBC is to be > -7.0	RPM 600 - 850, coolant temp > 40c, Fueling < 15mm3, Vehicle speed < 5km/hr.	Diagnostic fail condition true for 1 minute Test performed once per key cycle.	(fuel balance control)	В
Cylinder 8 Injector Leaking		Cylinder #8, FBC is < -7.0	Cylinder #8, FBC is to be > -7.0	RPM 600 - 850, coolant temp > 40c, Fueling < 15mm3, Vehicle speed < 5km/hr.	Diagnostic fail condition true for 1 minute Test performed once per key cycle.	(fuel balance control)	В
Throttle Valve Actuator Solenoid Control Circuit		At a 10% or greater TVA duty cycle signal, circuit current > 25 mA	At a 10% or greater EGR duty cycle signal, circuit current < 25 mA	ECM powered up > 0.5sec 10% < TVA Duty Cycle	Diagnostic fail condition true for 1 second Test performed continuously	ECM Electronic out put driver circuitry	В
Throttle Valve Actuator (TVA) Position Sensor Performance		Delta from target position < = +/- 3% Delta is the difference between desired TVA position and actual TVA position. TVA is adjusted to achieve desired air flows during regeneration. Detects in range TVA position errors	Delta from target position > = +/- 3%	P02E0,P02E8,P02E9,P0642,P0643 DTCs are not set TVA Actively being controlled	Diagnostic set conditions true for 10 sec. Test performed continously during TVA operation	TVA Position Sensor	В
Throttle Valve Actuator (TVA) Position Sensor Circuit low Voltage	P02E8	0.102 v to 4.75 v (0% to 100% position) Detects a sensor circuit Low voltage.	TVA Position sensor >= 0.102 v (0% position)	P0698,P0699 DTCs are not set Ignition on	Diagnostic fail condition true for 3 seconds Test performed continuously	EGR Position Sensor	В
Throttle Valve Actuator (TVA) Position Sensor High Voltage	P02E9	0.102 v to 4.75 v (0% to 100% position) Detects a sensor circuit High voltage.	TVA Position sensor <= 4745 mv (100% position)	P0698,P0699 DTCs are not set Ignition on	Diagnostic fail condition true for 3 seconds Test performed continuously	EGR Position Sensor	В
	P03)	XX Ignition System or Misfire					
Engine Misfire Detected	P0300	Misfires do not exist on more than one clyinder	Misfires do exist on more than one clyinder	Ignition On	Diagnostic sets on first fail Test performed once per key cycle	Cylinder to Cylinder engine speed. SW Poling	В

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Cylinder 1 Misfire Detected	P0301	Cylinder #1 RPM >= minimum average cylinder speed after an injection event. The minimum average cly speed is calculated every 2 rotations and represents the average speed that all cly are rotating at after a combustion event.	Cylinder #1 RPM < minimum average cylinder speed. after an injection event for at least 130 counts	2, P0203,P0204,P0205,P0206,P0207,P0208,	Diagnostic fail condition true for 180 revolutions. Test performend once per key cycle in a total of 440 revolutions	Cylinder to Cylinder engine speed	В
Cylinder 2 Misfire Detected	P0302	Cylinder #2 RPM >= minimum average cylinder speed after an injection event. The minimum average cly speed is calculated every 2 rotations and represents the average speed that all cly are rotating at after a combustion event.	speed. after an injection event for at least 130 counts	1)P0335,P0336,P0117,P0118,P0201,P020 2,	Test performend once per key cycle in a total of 440 revolutions	Cylinder to Cylinder engine speed	В
Cylinder 3 Misfire Detected	P0303	Cylinder #3 RPM >= minimum average cylinder speed after an injection event. The minimum average cly speed is calculated every 2 rotations and represents the average speed that all cly are rotating at after a combustion event.	Cylinder #3 RPM < minimum average cylinder speed after an injection event for at least 130 counts	1)P0335,P0336,P0117,P0118,P0201,P020 2, P0203,P0204,P0205,P0206,P0207,P0208, P2146,P2149,P2152,P2155,P0502,P062C DTCs are not set. 2)Engine is running 3)Coolant temperature >= 40degC 4)600 rpm < Engine speed < 1300 rpm 5) 3 mm3/S < injected fuel < 25 mm3/S 6)vehicle speed <= 3 Kph	Test performend once per key cycle in a total of 440 revolutions	Cylinder to Cylinder engine speed	В
Cylinder 4 Misfire Detected	P0304	Cylinder #4 RPM >= minimum average cylinder speed after an injection event. The minimum average cly speed is calculated every 2 rotations and represents the average speed that all cly are rotating at after a combustion event.	Cylinder #4 RPM < minimum average cylinder speed after an injection event for at least 130 counts 07i-2009MY calibration	1)P0335,P0336,P0117,P0118,P0201,P020 2,	Test performend once per key cycle in a total of 440 revolutions	Cylinder to Cylinder engine speed	В

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Cylinder 5 Misfire Detected	P0305	Cylinder #5 RPM >= minimum average cylinder speed after an injection event. The minimum average cly speed is calculated every 2 rotations and represents the average speed that all cly are rotating at after a combustion event.	Cylinder #5 RPM < minimum average cylinder speed after an injection event for at least 130 counts	1)P0335,P0336,P0117,P0118,P0201,P020 2, P0203,P0204,P0205,P0206,P0207,P0208, P2146,P2149,P2152,P2155,P0502,P062C DTCs are not set. 2)Engine is running 3)Coolant temperature >= 40degC 4)600 rpm < Engine speed < 1300 rpm 5) 3 mm3/S < injected fuel < 25 mm3/S 6)vehicle speed <= 3 Kph 7)Engine run time > 10 seconds	Test performend once per key cycle in a total of 440 revolutions	Cylinder to Cylinder engine speed	В
Cylinder 6 Misfire Detected	P0306	Cylinder #6 RPM >= minimum average cylinder speed after an injection event. The minimum average cly speed is calculated every 2 rotations and represents the average speed that all cly are rotating at after a combustion event.	Cylinder #6 RPM < minimum average cylinder speed after an injection event for at least 130 counts	1)P0335,P0336,P0117,P0118,P0201,P020 2, P0203,P0204,P0205,P0206,P0207,P0208, P2146,P2149,P2152,P2155,P0502,P062C DTCs are not set. 2)Engine is running 3)Coolant temperature >= 40degC 4)600 rpm < Engine speed < 1300 rpm 5) 3 mm3/S < injected fuel < 25 mm3/S 6)vehicle speed <= 3 Kph 7)Engine run time > 10 seconds	Test performend once per key cycle in a total of 440 revolutions	Cylinder to Cylinder engine speed	В
Cylinder 7 Misfire Detected	P0307	Cylinder #7 RPM >= minimum average cylinder speed after an injection event. The minimum average cly speed is calculated every 2 rotations and represents the average speed that all cly are rotating at after a combustion event.	Cylinder #7 RPM < minimum average cylinder speed after an injection event for at least 130 counts	1)P0335,P0336,P0117,P0118,P0201,P020 2, P0203,P0204,P0205,P0206,P0207,P0208, P2146,P2149,P2152,P2155,P0502,P062C DTCs are not set. 2)Engine is running 3)Coolant temperature >= 40degC 4)600 rpm < Engine speed < 1300 rpm 5) 3 mm3/S < injected fuel < 25 mm3/S 6)vehicle speed<= 3 Kph 7)Engine run time > 10 seconds	Test performend once per key cycle in a total of 440 revolutions	Cylinder to Cylinder engine speed	В
Cylinder 8 Misfire Detected	P0308	Cylinder #8 RPM >= minimum average cylinder speed after an injection event. The minimum average cly speed is calculated every 2 rotations and represents the average speed that all cly are rotating at after a combustion event.	Cylinder #8 RPM < minimum average cylinder speed after an injection event for at least 130 counts	71-roine fur time > 10 seconds 1)P0335,P0336,P0117,P0118,P0201,P020 2, P0203,P0204,P0205,P0206,P0207,P0208, P2146,P2149,P2152,P2155,P0502,P062C DTCs are not set. 2)Engine is running 3)Coolant temperature >= 40degC 4)600 rpm < Engine speed < 1300 rpm 5) 3 mm3/S < injected fuel < 25 mm3/S 6)yehicle speed <= 3 Kph 7)Engine run time > 10 seconds	Test performend once per key cycle in a total of 440 revolutions	Cylinder to Cylinder engine speed	В
Crankshaft Position [CKP] Sensor Circuit	P0335	Receiving valid signals from CKP sensor while CMP sensor is also sending valid signals. Detects crankshaft sensor circuit failure.	edge transitions measured in CKP signal.)	/II-naine run time > 10 seconds P0652, P0653 not set Ignition is ON Engine is running	Failure exists for 20 camshaft phases (4 phases per cam revolution)	Crankshaft Position Sensor (CKP)	А

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Crankshaft Position [CKP] Sensor Performance	P0336	Receiving valid signals from CKP. Detects implausible crankshaft sensor operation (correct pattern not detected).	A.) CKP pattern not yet recognized AND no transitions in CKP signal are seen. OR B	P0652, P0653 not set Ignition is ON, Engine running Engine Speed < 0 rpm for one sample (implies engine CKP speed is being calculated but sign	A.) Failure exists for 312 crankshaft increments B.) Failure exists for 312 increments (elapsed from A.) AND	Crankshaft Position Sensor (CKP)	A
Camshaft Position [CMP] Sensor Circuit	P0340	Receiving valid signals from CMP sensor while CKP sensor is also sending valid signals. Detects camshaft sensor circuit failure.	edge transitions measured in CMP signal.)	P0642, P0643, P0335, P0336 not set Ignition is ON Engine Speed ≥ 50 rpm (implies engine	Failure exists for 132 crankshaft increments	Camshaft Position Sensor (CMP)	А
Camshaft Position [CMP] Sensor Performance	P0341	Receiving valid signals from CMP. Detects implausible camshaft sensor operation (correct pattern not detected).	CKP signal pattern detected as calibrated AND CMP pattern NOT detected as calibrated.	P0335, P0336 not set Ignition is ON Engine Speed ≥ 50 rpm (implies engine	Failure exists for 240 crankshaft (CKP) increments.	Camshaft Position Sensor (CMP)	А
Wait to Start Lamp (WTS) Control Circuit	P0381	Electronic out-put driver circutry determines that faults (open/short and no load) do not exist on the WTS circuit.	Electronic out-put driver circutry determines faults (open/short and no load) do exist on the WTS circuit.	Lamp must be commanded on for short to battery/open faults. Lamp must be commanded off for shot to ground/no load	Failure exists for 3 sec. Monitoring is continuos	Sensing circuity in the out put drver electronics.	В
	P04)	X EGR System					
Exhaust Gas Recirculation(EGR) Flow Insufficient	P0401	Measured Mass Air Flow values < 60 mg/cly above Desired MAF values. Measured MAF verses Desired MAF indicates EGR flow. When Measured MAF is above Desired MAF, EGR flow has been reduced. Conversion is (mg/cly) / (RPM/15) = grams per second	Measured Mass Air Flow values ,60 mg/cly <u>above</u> Desired MAF values.	P0101,P0102,P0103,P0403,P0405,P0406 DTCs are not set. EGR Actively being controlled	Diagnostic fail condition true for 15 seconds Test performed continuously	Mass Airflow sensor	В
Exhaust Gas Recirculation(EGR) Flow Excessive	P0402	Measured Mass Air Flow values < 50 mg/hub below Desired MAF values. Measured MAF verses Desired MAF indicates EGR flow. When Measured MAF is below Desired MAF, EGR flow has been increased. Conversion is (mg/cly) / (RPM/15) = grams per second	Measured Mass Air Flow values > 50 mg/hub below Desired MAF values.	P0101,P0102,P0103,P0403,P0405,P0406 DTCs are not set EGR Actively being controlled	Diagnostic fail condition true for 15 seconds Test performed continuously	Mass Airflow sensor	В
Exhaust Gas Recirculation (EGR) Solenoid Control Circuit	P0403	At a 10% or greater EGR duty cycle signal, circuit current > 25 mA	At a 10% or greater EGR duty cycle signal, circuit current < 25 mA	ECM Power Up Time > 0.5sec Engine running 10% < EGR Duty Cycle	Diagnostic fail condition true for 1 second Test performed	ECM Electronic out put driver circuitry	В
Exhaust Gas Recirculation(EGR) Position Sensor Circuit Low Voltage	P0405	0.254 v to 4.75 v (0% to 100% position) Detects a sensor circuit Low voltage.	EGR Position sensor <= 254 mv (0% position)	P0698,P0699 DTCs are not set Ignition on	Diagnostic fail condition true for 3 seconds Test performed	EGR Position Sensor	В
Exhaust Gas Recirculation(EGR) Position Sensor Circuit High Voltage	P0406	0.254 v to 4.75 v (0% to 100% position) Detects a sensor circuit High voltage.	EGR Position sensor >= 4745 mv (100% position)	P0698,P0699 DTCs are not set Ignition on	Diagnostic fail condition true for 3 seconds Test performed	EGR Position Sensor	В
Exhaust Gas Recirculation(EGR) Temperature Sensor	P040C	0.0 v to 5.00 v -40 deg C to 900 deg C Detects a sensor circuit Low voltage.	EGR Temperature sensor <= 395 mv Engine run time >30 seconds	Ignition on	Diagnostic fail condition true for 3 seconds Test performed	EGR Position Sensor	В

		ACCEPTABLE	PRIMARY	SECONDARY	MONITORING		FAULT CODE
SENSED PARAMETER	FAULT CODE	OPERATING RANGE AND RATIONALITY	MALFUNCTION DETECTION PARAMETERS	MONITORING PARAMETERS AND CONDITIONS	TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	STORAGE AND MIL ILLUMINATIO N
Exhaust Gas Recirculation(EGR) Temperature Sensor	P040D	0.0 v to 5.00 v -40 deg C to 900 deg C Detects a sensor circuit High voltage.	EGR Temperature sensor >= 4700 mv Engine run time >30 seconds	Ignition on	Diagnostic fail condition true for 3 seconds Test performed	EGR Position Sensor	В
Exhaust Gas Recirculation(EGR) Temperature Sensor	P040F	Absolute value of (Exhuast Temperature 1- Exhaust Temperature 2) < 40 deg C Detects biased Exhaust Temperature Sensors	EGR Temperature sensor #1 <= 40 deg to temperature sensor #2 Engine Time off > 5 hrs	P040C,P040D,P041C, P041D DTCs are not set Ignition on	Diagnostic fail condition true for 3 seconds Test performed	EGR Position Sensor	В
Exhaust Gas Recirculation(EGR) Temperature Sensor 2	P041C	0.0 v to 5.00v -40 deg C to 900 deg C Detects a sensor circuit Low voltage.	EGR Temperature sensor <= 395 mv Engine run time >30 seconds	Ignition on	Diagnostic fail condition true for 3 seconds Test performed	EGR Position Sensor	В
Exhaust Gas Recirculation(EGR) Temperature Sensor 2	P041D	0.0 v to 5.00 v -40 deg C to 900 deg C Detects a sensor circuit High voltage.	EGR Temperature sensor >= 4700 mv Engine run time >30 seconds	Ignition on	Diagnostic fail condition true for 3 seconds Test performed	EGR Position Sensor	В
Catalyst System Low Efficiency	P0420	DOC out temp > 585 deg C at the start of regen.	DOC out temp < 585 deg C at the start of regen.	Must be in Regen	Diagnostic set when conditions true for 222 secs. Test performed once per regen event	Exhaust Gas Temp sensor (DOC out)	В
Fuel Level Sensor 1 Performance	P0461	Difference between Maximum fuel volume and Minimum fuel volume > 3 Liters.	PATH1:Difference between Maximum fuel volume and Minimum fuel volume < 3 Liters. AND Difference between current vehicle driven distance and vehicle distance at beginning of diagnostic > =160 Km OR PATH2:Initial volume in tank 1 – current volume in tank 1 < 0.8 L AND Initial volume in tank 2 – current volume in tank 2 >=0.8 L	PATH1:P0462,P0463 not set Engine run time > 10 secIgnition is ON Transfer pump is OFF PATH2:P0461,P0462,P0463,P2067,P2068 not set Fuel transfer pump ON for 200 seconds vehicle speed <=0	Monitor time is 100msec. Continuous	Fuel Level 1 Fault Detection	В
Fuel Level Sensor 1 Circuit Low	P0462	0.2V to 4.81V Detects circuit faults which causes the fuel level voltage to fall below 200mV	fuel level 1 voltage < 0.2V	Ignition on Engine run time > 1 sec or Powerup time > 1 sec	Monitor time is 100msec. Continuous	Fuel Level 1 Fault Detection	В
Fuel Level Sensor 1 Circuit High	P0463	0.2V to 4.81V Detects circuit faults which causes the fuel level voltage to rise above 4.8 V	fuel level 2 voltage > 4.8V	Ignition on Engine run time > 1 sec or Powerup time > 1 sec	Monitor time is 100msec. Continuous	Fuel Level 1 Fault Detection	В
Exhaust Gas Recirculation(EGR) Position Sensor Performance		Delta from target position < = +/- 3% Delta is the difference between desired EGR position and actual EGR position. Detects in range EGR valve positi	Delta from target position > = +/- 3%	P0401,P0402,P0403,P0642,P0643 DTCs are not set EGR Actively being controlled	Diagnostic set conditions true for 5 sec. Test performed continously during EGR	EGR Position Sensor	В

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Cooling Fan Speed Output Circuit	P0480	Electronic out-put driver circutry determines tha faults (open/short and no load) do not exist on the Fan Speed Output circuit.	Electronic out-put driver circuitry determines that faults (open/short and no load) do exist on the Fan Speed Output circuit.	Cooling Fan must be commanded on for short to battery/open faults. Cooling Fan must be commanded off for short to ground/no load	Failure exists for 600ms . Monitoring is continuos 20msec rate	Sensing circuity in the out put drIver electronics.	В
Cooling Fan System Performance	P0483	(Actual Cooling Fan Speed - Commanded Cooling Fan Speed) is <+/- 500 rpm.	(Actual Cooling Fan Speed - Commanded Cooling Fan Speed) is < +/- 500 rpm.	Cooling Fan Output Driver Duty Cycle>= 36% Cooling Fan Input Shaft speed < 6000 rpm Cooling Fan Input Shaft speed > 1700	30 seconds of weighted, accumulated difference. Monitoring is continuous 20msec rate	sensor	В
Cooling Fan Speed High	P0495	Cooling Fan Speed is within a tolerance of the Cooling Fan Input speed as indicated in worksheet P0495 Tables dragspeed.	Cooling Fan Speed is <u>not</u> within a tolerance of the Cooling Fan Input speed as indicated in worksheet P0495 tables drag speed.	Cooling Fan Output Driver Duty Cycle <= 35% Cooling Fan clutch fluid model indicates < 15ml in fan clutch working chamber AND Cooling Fan Input Speed > 1500 rpm	Diagnostic set conditions true for timer dependent on altitude (see Worksheet P0495 tables pump out times) Test performed continuously.	Cooling Fan speed sensor	В
Idle Speed Too Low	P0506	Actual Engine Speed < 100 rpm below TargetTarget Idle Speed	Actual Engine Speed > 100 rpm below TargetTarget Idle Speed	No Related fault code set(P0016,P0117,P0118,P0335,P0336) Engine is running Engine RPM > 300	Diagnostic set for 20 seconds. Samples taken every 100msec	Monitoring Engine Speed	В
Idle Speed Too High	P0507	Actual Engine Speed < 200 rpm above TargetTarget Idle Speed	Actual Engine Speed > 200 rpm above TargetTarget Idle Speed	No Related fault code set(P0016,P0117,P0118,P0335,P0336,) Engine is running Engine RPM > 300	Diagnostic set for 20 seconds. Samples taken every 100msec	Monitoring Engine Speed	В
Cooling Fan Speed Sensor Circuit	P0526	Fan speed pulses present Detects lack of target wheel pulses	No pulses detected	Engine running	Diagnostic set conditions true for 3000ms . Test performed	Fan Speed Sensor	В
Exhaust Gas Temperature (EGT) Sensor 1 Circuit Low Voltage	P0545	0.318 v - 3.37 v (-40 degC - 1000 degC) Detects EGT 1 sensor circuit short to ground	Exhaust Temp Sensor 1 Signal <0.318 v same as -40 degC	Ignition on	Diagnostic fail condition true for 1 sec Test performed continuously	Exhaust Gas Temperature sensor 1	A
Exhaust Gas Temperature (EGT) Sensor 1 Circuit High Voltage	P0546	0.318 v - 3.37 v (-40 degC - 1000 degC) Detects EGT 1 sensor circuit short to high voltage or sensor circuit open.	Exhaust Temp Sensor 1 Signal > 3.37 v same as 1000 degC	Ignition on	Diagnostic fail condition true for 1sec Test performed continuously	Exhaust Gas Temperature sensor 1	А
	P06>	X Computer and Auxiliary Outputs					
Control Module Not Programmed	P0602	ECM is programmed.	ECM is not programmed (K_Check_Service_Calibration = TRUE.)	Ignition on	Run every key cycle		А

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Control Module Internal Performance		ECM is operating correctly at proper voltage. All internal hardware modules are communicating correctly. Injector power stages can be properly shut off by ECM during start-up test. Internal watchdog module reports that microprocessor responds to querie	detected by hardware-based diagnositcs. PATH2: Internal SPI bus communication error	PATH1: None. PATH2: None. PATH3: None.	PATH1: Continuous PATH2: Continuous PATH3: Continuous PATH4: Continuous	ALL: Internal ECM Hardware Fault Detection	A
Control Module Analog to Digital Performance	P060B	ADC is correctly converting signals within the correct time periods.	Converted ADC voltage from special channel connected to 3.5V microprocessor supply >=	ECM powered up Engine speed >= 400rpm for engine -speed sync ADC queue test APP2 test impulse carried out for APP2	Continuous	Analog to Digital Converter	A
Internal Control Module Engine RPM Performance	P061C	Main and redundant engine speed calculations agree. Detects failure in engine speed	Difference between CKP engine speed and redundantly-calculated engine speed > 320	Engine speed < 1300 rpm.	Failure exists for 880 ms.	Crankshaft Position Sensor	А
TPU error on VSS signal	P062C	Electronic ECM circuitry determines that faults related to the TPU chip used to calculate Vehicle speed do not exist.	Electronic ECM circuitry determines that faults related to the TPU chip used to calculate Vehicle speed do exist.	Ignition on		ECM electronic circuitry	А
Control Module Long Term Memory Performance	P062F	Each data block of memory is read for a check sum error and flags a fault is found.		Ignition on	once at key-up	ECM Hardware Fault Detection	А
Intake Air (IA) Heater Switch/Control Circuit	P0640	digital response signal = low when heartbeat signal is activated	digital response signal = high when heartbeat signal is activated	1)IAH Commanded OFF 2)11.7 = FALSE	Monitor time is 650msec. Test is conducted every 2 seconds.	Monitored by GPCM and message transferred by CAN	В
5 Volt Reference 1 Circuit Low Voltage	P0642	4.86V to 5.1V Detects circuit faults which lower the 5V reference 1 supply voltage out of regulation	5 Volt Reference 1 < 4.86V	Ignition on	Monitor time is 160msec. Continuous	ECM Hardware Fault Detection	А
5 Volt Reference 1 Circuit High Voltage	P0643	4.86V to 5.1V Detects circuit faults which <u>raise</u> the 5V reference 1 supply voltage out of regulation	5 Volt Reference 1 > 5.1V	Ignition on	Monitor time is 160msec. Continuous	ECM Hardware Fault Detection	A

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Glow Plug Control Module Performance	P064C	P064C Error Message <u>not</u> received from the Glow Plug Control Module via GMLAN	P064C Error Message received from the Glow Plug Control Module via GMLAN indicating one or more of the conditions below; 1) Any of the 8 glow plug switches is defective 2)No IGN1 voltage 3)GPCM is overtemp 4)GPCM is overvoltage or undervoltage 5)Internal voltage supply to the Intake Air heater is too low 6)Difference between IGN1 and KI 30 (Battery) voltage is too high 7)Difference between battery voltage measured by ECM and battery voltage measured by the GPCM is too high		Monitor time is 3000msec. Frequency is every 250msec.	GPCM detects the faults and sends serial data message via GMLAN to the ECM	В
Malfunction Indicator Lamp (MIL) Control Circuit	P0650	Electronic out-put driver circutry determines that faults (open/short and no load) do not exist on the MIL circuit.	Electronic out-put driver circutry determines faults (open/short and no load) do exist on the MIL circuit.	Lamp must be commanded on for short to battery/open faults. Lamp must be commanded off for shot to ground/no load	Fault exists for 2 sec monitored continuosly	ECM electronic circuitry	A
5 Volt Reference 2 Circuit Low Voltage	P0652	4.86V to 5.1V Detects circuit faults which lower the 5V reference 2 supply voltage out of regulation	5 Volt Reference 2 < 4.86V	Ignition on	Monitor time is 160msec. Continuous	ECM Hardware Fault Detection	А
5 Volt Reference 2 Circuit High Voltage	P0653	4.86V to 5.1V Detects circuit faults which <u>raise</u> the 5V reference 2 supply voltage out of regulation	5 Volt Reference 2 > 5.1V	Ignition on	Monitor time is 160msec. Continuous	ECM Hardware Fault Detection	A
Cylinder #1 Glow Plug Control Circuit	P0671	P0671 Error Message <u>not</u> received from the Glow Plug Control Module via GMLAN indicating an error on Cyl #1 Glow Plug	1)Glow Plug line is open 2)Glow Plug line is shorted 3)Glow Plug line high resistance 4)Glow Plug line low resistance SEE "GPCM Cert Doc" worksheet	Ignition on Glow plugs commanded on	Monitor time is 1 sec. Frequency is every 250msec.	GPCM detects the faults and sends serial data message via GMLAN to the	В
Cylinder #2 Glow Plug Control Circuit	P0672	P0672 Error Message <u>not</u> received from the Glow Plug Control Module via GMLAN indicating an error on Cyl #2 Glow Plug	1)Glow Plug line is open 2)Glow Plug line is shorted 3)Glow Plug line high resistance 4)Glow Plug line low resistance SEE "GPCM Cert Doc" worksheet	Ignition on Glow plugs commanded on	Monitor time is 1 sec. Frequency is every 250msec.	GPCM detects the faults and sends serial data message via GMLAN to the	В
Cylinder #3 Glow Plug Control Circuit	P0673	P0673 Error Message <u>not</u> received from the Glow Plug Control Module via GMLAN indicating an error on Cyl #3 Glow Plug	1)Glow Plug line is open 2)Glow Plug line is shorted 3)Glow Plug line high resistance 4)Glow Plug line low resistance SEE "GPCM Cert Doc" worksheet	Ignition on Glow plugs commanded on	Monitor time is 1 sec. Frequency is every 250msec.	GPCM detects the faults and sends serial data message via GMLAN to the	В
Cylinder #4 Glow Plug Control Circuit	P0674	P0674 Error Message <u>not</u> received from the Glow Plug Control Module via GMLAN indicating an error on Cyl #4 Glow Plug	1)Glow Plug line is open 2)Glow Plug line is shorted 3)Glow Plug line high resistance 4)Glow Plug line low resistance SEE "GPCM Cert Doc" worksheet	Ignition on Glow plugs commanded on	Monitor time is 1 sec. Frequency is every 250msec.	GPCM detects the faults and sends serial data message via GMLAN to the	В

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND	PRIMARY MALFUNCTION DETECTION	SECONDARY MONITORING PARAMETERS	MONITORING TIME LENGTH AND FREQUENCY	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO
		RATIONALITY	PARAMETERS	AND CONDITIONS	OF CHECK		N
Cylinder #5 Glow Plug Control Circuit	P0675	P0675 Error Message <u>not</u> received from the Glow Plug Control Module via GMLAN indicating an error on Cyl #5 Glow Plug	1)Glow Plug line is open 2)Glow Plug line is shorted 3)Glow Plug line high resistance 4)Glow Plug line low resistance SEE "GPCM Cert Doc" worksheet	Ignition on Glow plugs commanded on	Monitor time is 1 sec. Frequency is every 250msec.	GPCM detects the faults and sends serial data message via GMLAN to the	В
Cylinder #6 Glow Plug Control Circuit	P0676	P0676 Error Message <u>not</u> received from the Glow Plug Control Module via GMLAN indicating an error on Cyl #6 Glow Plug	1)Glow Plug line is open 2)Glow Plug line is shorted 3)Glow Plug line high resistance 4)Glow Plug line low resistance SEE "GPCM Cert Doc" worksheet	Ignition on Glow plugs commanded on	Monitor time is 1 sec. Frequency is every 250msec.	GPCM detects the faults and sends serial data message via GMLAN to the	В
Cylinder #7 Glow Plug Control Circuit	P0677	P0677 Error Message <u>not</u> received from the Glow Plug Control Module via GMLAN indicating an error on Cyl #7 Glow Plug	1)Glow Plug line is open 2)Glow Plug line is shorted 3)Glow Plug line high resistance 4)Glow Plug line low resistance SEE "GPCM Cert Doc" worksheet	Ignition on Glow plugs commanded on	Monitor time is 1 sec. Frequency is every 250msec.	GPCM detects the faults and sends serial data message via GMLAN to the	В
Cylinder #8 Glow Plug Control Circuit	P0678	P0678 Error Message <u>not</u> received from the Glow Plug Control Module via GMLAN indicating an error on Cyl #8 Glow Plug	1)Glow Plug line is open 2)Glow Plug line is shorted 3)Glow Plug line high resistance 4)Glow Plug line low resistance SEE "GPCM Cert Doc" worksheet	Ignition on Glow plugs commanded on	Monitor time is 1 sec. Frequency is every 250msec.	GPCM detects the faults and sends serial data message via GMLAN to the	В
5 Volt Reference 3 Circuit Low Voltage	P0698	4.86V to 5.1V Detects circuit faults which lower the 5V reference 3 supply voltage out of regulation	5 Volt Reference 3 < 4.86V	Ignition on	Monitor time is 160msec. Continuous	ECM Hardware Fault Detection	A
5 Volt Reference 3 Circuit High Voltage	P0699	4.86V to 5.1V Detects circuit faults which raise the 5V reference 3 supply voltage out of regulation	5 Volt Reference 3 > 5.1V	Ignition on	Monitor time is 160msec. Continuous	ECM Hardware Fault Detection	А
	P07)	(X-P08XX Transmission				·	
Transmission Control Module (TCM) Requested MIL Illumination	P0700	Serial Data communication from the TCM indicates a fault exists with the transmission.	Serial Data communication from the TCM indicates no faults exists with the transmission.	Ignition on	active on first message received. Monitored continuosly	GMLAN Bus	А
Park/Neutral Position (PNP) Switch Circuit Low Voltage		GMLAN Message for PNP position indicates park nuetral position and agrees with ECM sensed position based on PNP switch inputs to	GMLAN Message for PNP position indicates park nuetral and <u>dis-agrees</u> with ECM sensed position based on PNP switch inputs to ECM	11v < Battery voltage < 18v , No GMLAN error messages, P0852 not active	Failure being transmitted for 5 sec.	GMLAN, PNP switch inputs to	В
Park/Neutral Position (PNP) Switch Circuit High Voltage	P0852	ECM sensed position based on PNP switch inputs to ECM indacates not park or nuetral.	ECM sensed position based on PNP switch inputs to ECM indacates park or nuetral.	Engine speed > 650rpm, Vehicle speed > 24kPH, Actual Engine Torque > 120 newton meters, 11v < Battery voltage < 18v, No GMLAN error messages, P0851	Failure being transmitted for 5 sec. Checked continuosly	GMLAN, PNP switch inputs to ECM	В
	P12	XX-P22XX Fuel and Air Metering and A	uxiliary Emission Controls	tratadira ADDO CO/	•		

	,				1		LEALUT CODE
SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Injector 1 Control Circuit Shorted	P1224	Electronic out-put driver circuitry determines that the faults (short load) do not exist.	Electronic out-put driver circuitry determines that the faults (short load) <u>do</u> exist	Engine running. Injection event is being attempted for Cly 1	Fault exists for 3 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	A
Injector 2 Control Circuit Shorted	P1227	Electronic out-put driver circuitry determines that the faults (short load) do not exist.	Electronic out-put driver circuitry determines that the faults (short load) do exist	Engine running. Injection event is being attempted for Cly 2	Fault exists for 3 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	А
Injector 3 Control Circuit Shorted	P122A	Electronic out-put driver circuitry determines that the faults (short load) do not exist.	Electronic out-put driver circuitry determines that the faults (short load) do exist	Engine running. Injection event is being attempted for Cly 3	Fault exists for 3 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	А
Injector 4 Control Circuit Shorted	P1233	Electronic out-put driver circuitry determines that the faults (short load) do not exist.	Electronic out-put driver circuitry determines that the faults (short load) do exist	Engine running. Injection event is being attempted for Cly 4	Fault exists for 6 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	А
Injector 5 Control Circuit Shorted	P1236	Electronic out-put driver circuitry determines that the faults (short load) do not exist.	Electronic out-put driver circuitry determines that the faults (short load) do exist	Engine running. Injection event is being attempted for Cly 5	Fault exists for 3 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	А
Injector 6 Control Circuit Shorted	P1239	Electronic out-put driver circuitry determines that the faults (short load) do not exist.	Electronic out-put driver circuitry determines that the faults (short load) do exist	Engine running. Injection event is being attempted for Cly 6	Fault exists for 3 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	А
Injector 7 Control Circuit Shorted	P1242	Electronic out-put driver circuitry determines that the faults (short load) do not exist.	Electronic out-put driver circuitry determines that the faults (short load) do exist	Engine running. Injection event is being attempted for Cly 7	Fault exists for 3 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	А
Injector 8 Control Circuit Shorted	P1247	Electronic out-put driver circuitry determines that the faults (short load) do not exist.	Electronic out-put driver circuitry determines that the faults (short load) do exist	Engine running. Injection event is being attempted for Cly 8	Fault exists for 3 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	А
Diesel Particulate Filter Regeneration Frequency Too Low	P1448	Average time between the last two DPF regenerations <= 20 hours	Running average of time between the last two completed DPF regens (with idle time subtraced out) > 20 hours.	Engine running	Diagnostic fail condition true 1 time. Test performed continuously.	Running average of the time between the last two completed DPF	А
Intake Air (IA) Heater Feedback Circuit	P154A	digital response signal = high	digital response signal = low and current IAH > 20 A	1)IAH Commanded ON 2)Battery Voltage at IAH > 8.6 Volt	Monitor time is 650msec. Frequency is every 10msec.	Monitored by GPCM and message transferred by CAN	В
Intake Air (IA) Heater Voltage Signal Circuit	P154B	6.9 volts <= IAH Battery voltage <= 16.0 volts	IAH Battery voltage > 16.0 Volt AND 8.0 volts < GPCM Battery voltage GPCMKL30 < 16.0 Volt	1)IAH Commanded ON	Monitor time is 650msec. Frequency is every 10msec.	Monitored by	В
Intake Air (IA) Heater Current Signal Circuit	P154C	No failures detected on the IAH line current	IAH current line detected open, shorted to ground or shorted to battery	1)IAH Commanded ON 2)Battery Voltage at IAH > 6.9 Volt 3)GPCM Ignition voltage >= 6.9 Volt	Monitor time is 320 msec. Frequency is every 10msec.	Monitored by GPCM and message transferred by CAN	В

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Intake Air (IA) Heater Temperature Signal Circuit	P154D	No failures detected on the temperature signal	IAH temperature line detected open, shorted to ground or shorted to battery	1)IAH Commanded ON 2)6.9 volts < Battery Voltage at IAH > 16.0 volts	every 10msec.	Monitored by GPCM and message transferred by CAN	B
Engine Calibration Information Not Programmed – GPCM		P160C Error Message not received from the Glow Plug Control Module via GMLAN	P160C Error Message received from the Glow Plug Control Module via GMLAN indicating IQA data has <u>not</u> been programmed in the GPCM	Ignition ON	second. Frequency is	GPCM detects the fault and sends serial data message via GMLAN to the	A
Intake Air (IA) Heater Over Temperature	P166B	Temperature IAH <80 °C	Temperature IAH > 80 °C	1)IAH Commanded ON 2)engine run time > 40 sec 3)Battery Voltage at IAH > 8.6 Volt	Monitor time is 1 second. Frequency is every 160msec.	GPCM detects the	В
Intake Air (IA) Heater Resistance	P166C	Calculated resistance <= 500 mOhm	Calculated resistance > 500 mOhm and current IAH > 20 A	1)IAH Commanded ON 2)Battery Voltage at IAH > 8.6 Volt	Monitor time is 1 second. Frequency is every 160msec.	GPCM detects the	В
Diesel Particulate Filter Efficiency Below Threshold Bank 1	P2002	Res flow > f(Delta Pressure and exhaust flow) (see Chart 3A below) detects 8X the standard.	standard.	Time since successful regen < = 600 seconds. Distance since successful regen <= 18.6 Miles. Accumulated soot <=40 grams.	Diagnostic set when conditions true for 30 sec. Test performed after a regen	DPF Delta pressure sensor	В

Chart 3a

Calculated Res Flow= DPF Delta pressure /

Volume of exhaust Flow in meters^3 / hours	exhaust flow in hPa/(meters^3/hours)
0	-0.0418
25	-0.0418
50	-0.0418
100	-0.0418
200	-0.0418
400	-0.0418
1000	-0.0468
1001	-0.0468
1002	-0.0468
1600	-0.0518
1601	-0.0518
1602	-0.0518
1800	-0.0518
2000	-0.0518
2200	-0.0518
2400	-0.0518

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Exhaust Gas Temperature (EGT) Sensor 2 Circuit Low Voltage	P2032	0.318 v - 3.37 v (-40 degC - 1000 degC) Detects EGT 2 sensor circuit open or short to ground	Exhaust Temp Sensor 2 Signal <0.318 v same as -40 degC	Ignition on	Diagnostic fail condition true for 1 sec Test performed continuously	Exhaust Gas Temperature sensor 2	A
Exhaust Gas Temperature (EGT) Sensor 2 Circuit High Voltage		0.307 v - 3.37 v (-40 degC - 1000 degC) Detects EGT 2 sensor circuit open or short to ground	Exhaust Temp Sensor 2 Signal > 3.37 v same as 1000 degC	Ignition on	Diagnostic fail condition true for 1 sec Test performed continuously	Exhaust Gas Temperature sensor 2	А
Fuel Level Sensor 2 Performance	P2066	Initial volume in tank 2 – current volume in tank 2 >=0.8 L	Initial volume in tank 2 – current volume in tank 2 < 0.8 L	PATH1:P0462,P0463 not set Engine run time > 10 sec, Transfer pump is OFF PATH2:P0461,P0462,P0463,P2067,P2068 not set Fuel transfer pump ON for 240 seconds OR tank indication < 72 L Vehicle speed <=0		Fuel Level 2 input	В
Exhaust Gas Temperature (EGT) Sensor 1-2 Correlation	P20E2	absolute value of (Startup Exhaust Gas Temperature 1 Sensor - Startup Exhaust Gas Temperature 2 Sensor) <= 20 degC.	absolute value of (Startup Exhaust Gas Temperature 1 Sensor - Startup Exhaust Gas Temperature 2 Sensor) > 20 degC.	P0545,P0546,P2032,P2033 DTCs are not	Diagnostic sets on first fail Test performed once per key cycle	EGT Temperature sensor 1 and EGT Temperature sensor 2	В
Accelerator Pedal Position (APP) Sensor 1 Circuit Low Voltage	P2122	0.806 volt to 4.75 volts Detects a sensor circuit short to ground	Accelerator pedal supply voltage <= 0.806 volts	P2122, P2123 are not currently set No sensor supply errors. No A-to-D pulse test Ignition ON	Diagnostic fail conditions true for 0.24 seconds Test performed continuously 100msec	Accelerator pedal sensor 1	С
Accelerator Pedal Position (APP) Sensor 1 Circuit High Voltage	P2123	0.806 volt to 4.75 volts Detects a sensor circuit short high voltage or a sensor circuit open	1 11 7 9	P2122, P2123 are not currently set No sensor supply errors. No A-to-D pulse test Ignition ON	Diagnostic fail conditions true for 0.24 seconds Test performed continuously 100msec	Accelerator pedal sensor 1	С
Accelerator Pedal Position (APP) Sensor 2 Circuit Low Voltage	P2127	0.308 volt to 2.5 volts Detects a sensor circuit short to ground	Accelerator pedal supply voltage <= 0.308 volts	P2127, P2128 are not currently set No sensor supply errors. No A-to-D pulse test Ignition ON	Diagnostic fail conditions true for 0.24 seconds Test performed continuously 100msec	Accelerator pedal sensor 2	С
Accelerator Pedal Position (APP) Sensor 2 Circuit High Voltage	P2128	0.308 volt to 2.5 volts Detects a sensor circuit short high voltage or a sensor circuit open	Accelerator pedal supply voltage >= 2.5 volts	P2127, P2128 are not currently set No sensor supply errors. No A-to-D pulse test Ignition ON	Diagnostic fail conditions true for 0.24 seconds Test performed continuously 100msec	Accelerator pedal sensor 2	С
Accelerator Pedal Position (APP) Sensor 1-2 Correlation	P2138	0.806 volt to 4.75 volts Detects a sensor 1 to sensor 2 correlation error	•	P2122, P2123, P2127, P2128 are not currently set. No sensor supply errors. Ignition ON	Diagnostic fail conditions true for 0.3 seconds Test performed continuously 100msec	Accelerator pedal sensor 1 & 2	С

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Injector Positive Voltage Control Circuit Group 1	P2146	Electronic out-put driver circuitry determines the faults (open/short/no load) do not exist	Electronic out-put driver circuitry determines the faults (open/short/no load) do exist	Engine running. Injection event is being attempted for injectors 1&4 connected to bank 1	Fault exists for 6 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	А
Injector Positive Voltage Control Circuit Group 2	P2149	Electronic out-put driver circuitry determines the faults (open/short/no load) do not exist	Electronic out-put driver circuitry determines the faults (open/short/no load) do exist	Engine running. Injection event is being attempted for injectors 7&6 connected to bank 2	Fault exists for 6 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	А
Injector Positive Voltage Control Circuit Group 3		Electronic out-put driver circuitry determines the faults (open/short/no load) do not exist	Electronic out-put driver circuitry determines the faults (open/short/no load) do exist	Engine running. Injection event is being attempted for injectors 2&5 connected to bank 3	Fault exists for 6 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	А
Injector Positive Voltage Control Circuit Group 4	P2155	Electronic out-put driver circuitry determines the faults (open/short/no load) do not exist	Electronic out-put driver circuitry determines the faults (open/short/no load) do exist	Engine running. Injection event is being attempted for injectors 8&3 connected to bank 4	Fault exists for 6 msec. Monitored continuosly	ECM Injector Electronic out-put driver circuitry	А
Engine Coolant Temperature (ECT) Sensor 2 Circuit Low Voltage		0.065 V to 4.75 V -40degC to 150 degC Detects a sensor circuit short to ground	Coolant Temperature Sensor voltage <= 0.065 volt -same as- Coolant Temperature>150degC	Ignition On	Diagnostic set conditions true for 15 second Test performed continuously 100msec rate	Coolant Temperature Sensor	В
Engine Coolant Temperature (ECT) Sensor 2 Circuit High Voltage	P2185	0.065 V to 4.75 V -40degC to 150 degC Detects a sensor circuit short high voltage or a sensor circuit open	Coolant Temperature Sensor voltage >= 4.8 V -same as- Coolant Temperature >-40 degC	Ignition On	Diagnostic set conditions true for 60 second Test performed continuously 100msec rate	Coolant Temperature Sensor	В
Barometric Pressure (BARO) Circuit Low Input		1.5 v - 4.8 v (60kPA - 120kPa) Detects Baro sensor circuit open or grounded	Baro Sensor Signal <1.5 v	P0652,P0653 DTCs not set Ignition On	Diagnostic fail condition true for 800msec Test performed continuously	Barometric Pressure (Baro) Sensor	В
Barometric Pressure (BARO) Circuit High Input		1.5 v - 4.8 v (60kPA - 120kPa) Detects Baro sensor circuit shorted to high voltage	Baro Sensor Signal >4.8v	P0652,P0653 DTCs not set Ignition On	Diagnostic fail condition true for 800msec Test performed	Barometric Pressure (Baro) Sensor	В
Diesel Particulate Filter Differential Pressure Too High	P244B	Differential pressure less than a calibration map See Worksheet 244B Temp Map.	Differential pressure sensor > calibration map based on exhaust flow rate and DPF temperature	Engine running	Diagnostic fail conditions true for 30 sec. Test performed continuously	Differential pressure sensor	A
Catalyst Temperature Too Low During Regeneration	P244C	Exhaust temperature before the DPF within 100 deg of the control target temperature. See Worksheet 244C Target Temp Map.	Exhaust temperature sensor before the DPF below the control target temperature by 100 Deg C.	Control system in active DPF regeneration	Diagnostic fail conditions true for 5 min. Test performed continuously.	Exhaust temperature sensor before the DPF	В

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Diesel Particulate Filter Differential Pressure Sensor Performance	P2453	Not more than + or - 41 hPa from the differential pressure sensor value with engine off. Or sensor detects and increase in pressure with increase in exhaust flow. Or sensor detects and decrease in pressure with decrease in exhaust flow.	 abs(Differential pressure sensor signal) > 41 hPa. Or Differential pressure sensor gradient > 6 hPa/sec. Or Differential pressure sensor gradient < 6 hPa/sec. 	2.Engine running and when a change in the exahust flow gradient > 200 m^3/h/sec.	Fail conditions true for 500 msec. Test performed once during ECM power down. Fail conditions true for 900 msec. Test performed continuously. Fail conditions true for 900 msec. Test performed continuously.	Differential pressure sensor	A
Diesel Particulate Filter Differential Pressure Sensor Circuit Low Voltage	P2454	0.930 v - 4.745 v (-144 hPA to 1000 hPa) Detects differential pressure sensor circuit short to low voltage	Differential pressure sensor signal < .930 v (20Hpa)	Ignition On	Diagnostic fail condition true for 3.75 seconds. Test performed continuously	Differential pressure sensor	A
Diesel Particulate Filter Differential Pressure Sensor Circuit High Voltage	P2455	0.930 v - 4.745 v (-144 hPA to 1000 hPa) Detects differential pressure sensor circuit short to high voltage	Differential pressure sensor signal > 4.745 v (1000Hpa)	Ignition On	Diagnostic fail condition true for 3.75 seconds. Test performed continuously	Differential pressure sensor	A
Exhaust Gas (EGR) Cooler Performance	P2457	Temperature difference between temperature sensor #2 and temperature sensor #1 is => MAP	Temperature difference between temperature sensor #2 and temperature sensor #1 is => MAP	P040C,P040D,P041C, P041D and P040F DTCs are not set Ignition on	Diagnostic fail condition true for 3 seconds Test performed		В
Diesel Particulate Filter Regeneration Frequency Too High	P2459	Average time between last two DPF regenerations > 1 Hr, 10 min	Running average of the time between the last two <i>completed</i> DPF regens < 1 hours 10 min.	Engine running	Diagnostic fail condition true 1 time. Test performed continuously.	Time between DPF regeneration.	A
Diesel Particulate Filter - Soot Accumulation	P2463	DPF has accumulated < 70 grams of particulates	DPF has accumulated >= 70 grams of particulates	Engine running	Diagnostic fail condition true for 5 mins. Test performed continuosly	DPF Delta pressure sensor	А
	P25)	(X Auxiliary Inputs					
ECM Power Relay Circuit	P2510	Relay is responding corectly to ECM command to turn off.	Relay is responding incorrectly to ECM command to turn off.	Engine has tranistioned from start to run or After run (Power down) has occurred	Diagnostic set conditions !st failure Test performed twice a drive cycle	Updates to the EEPROM Variables.	A
Turbocharger Boost Control Position Sensor Performance	P2563	Delta from target turbo vane position < +/- 15%. Delta is the difference between desired turbo vane position and the actual turbo vane position. Detects turbo vane position	Delta from target turbo vane position > +/- 15%.	P0045, P2564 Engine Run time>30 sec	Diagnostic set conditions true for for 5 sec Test performed continuously	Turbocharger Vane Position Sensor.	В

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Turbocharger Boost Control Position Sensor Circuit Low Voltage	P2564	0.277 v to 4.780 v (0% to 100% position) Detects Turbocharger Vane Position sensor circuit open and shorted to ground	Turbocharger Vane Position Sensor Signal < 0.277v	Engine Run time>3sec	Diagnostic set condition true for 1Seconds Test performed continuously	Turbocharger Vane Position Sensor.	В
Turbocharger Boost Control Position Sensor Circuit High Voltage	P2565	0.277 v to 4.780 v (0% to 100% position) DetectsTurbocharger Vane Position sensor circuit shorted to high voltage voltage	Turbocharger Vane Position Sensor Signal > 4.78v	Engine Run time>3sec	Diagnostic set condition true for 1 seconds Test performed continuously	Turbocharger Vane Position Sensor.	В
	P26	XX Computer and Auxiliary Outputs					
Control Module Ignition Off Timer Performance	P2610	ignition off time delta = 1sec AND ignition off timer >= 0 sec AND ignition off timer <= 10 sec AND timer is incrementing Detects a faulty Ignition off Timer circuit.	Ignition off timer reads < 0 sec OR Ignition off timer reads <=5 sec >10 sec OR timer unchanged for 60 sec OR	ECM powered up	Diagnostic set conditions 1st failure Test performed once during drive cycle and once at after run	SW calculation	В
Fuel Transfer Pump Flow Insufficient	P2636	Initial volume in tank 1 – current volume in tank 1 >= 0.8 L AND Initial volume in tank 2 – current volume in tank 2 >= 0.8 L	Initial volume in tank 1 – current volume in tank 1 < 0.8 L AND Initial volume in tank 2 – current volume in tank 2 < 0.8 L	Transfer pump is ON for 200 seconds	Monitor time is 100msec. Continuous	Transfer pump Fault Detection	В
Fuel Injector Calibration Not Programmed	P268A	Injector Calibration Data (IQA) is programmed in the ECM	Injector Calibration Data (IQA) is not programmed in the ECM	Ignition on	Diagnostic set conditions 1st failure Test performed once at key-up	SW calculation	А
Cylinder 1 Injector Data Incorrect (IQA)	P268C	Cylinder #1, IQA values are to be = between ECM and GPCM for successful pass	Cylinder #1 IQA values are not = between ECM and GPCM	NONE	Runs continuously at key on, engine run	Compare IQA values stored in ECM and GPCM. Must be equal to	А
Cylinder2 Injector Data Incorrect (IQA)	P268D	Cylinder #2, IQA values are to be = between ECM and GPCM for successful pass	Cylinder #2 IQA values are not = between ECM and GPCM	NONE	Runs continuously at key on, engine run	Compare IQA values stored in ECM and GPCM. Must be equal to pass.	А
Cylinder 3 Injector Data Incorrect (IQA)	P268E	Cylinder #3, IQA values are to be = between ECM and GPCM for successful pass	Cylinder #3 IQA values are not = between ECM and GPCM	NONE	Runs continuously at key on, engine run	Compare IQA values stored in ECM and GPCM. Must be equal to pass.	А
Cylinder 4 Injector Data Incorrect (IQA)	P268F	Cylinder #4, IQA values are to be = between ECM and GPCM for successful pass	Cylinder #4 IQA values are not = between ECM and GPCM	NONE	Runs continuously at key on, engine run	Compare IQA values stored in ECM and GPCM. Must be equal to pass.	А

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	MONITORING METHOD	FAULT CODE STORAGE AND MIL ILLUMINATIO N
Cylinder 5 Injector Data Incorrect (IQA)		Cylinder #5, IQA values are to be = between ECM and GPCM for successful pass	Cylinder #5 IQA values are not = between ECM and GPCM	NONE	Runs continuously at key on, engine run	Compare IQA values stored in ECM and GPCM. Must be equal to pass.	А
Cylinder 6 Injector Data Incorrect (IQA)		Cylinder #6, IQA values are to be = between ECM and GPCM for successful pass	Cylinder #6 IQA values are not = between ECM and GPCM	NONE	Runs continuously at key on, engine run	Compare IQA values stored in ECM and GPCM. Must be equal to pass.	A
Cylinder 7 Injector Data Incorrect (IQA)	P2692	Cylinder #7, IQA values are to be = between ECM and GPCM for successful pass	Cylinder #7 IQA values are not = between ECM and GPCM	NONE	Runs continuously at key on, engine run	Compare IQA values stored in ECM and GPCM. Must be equal to pass.	A
Cylinder 8 Injector Data Incorrect (IQA)		Cylinder #8, IQA values are to be = between ECM and GPCM for successful pass	Cylinder #8 IQA values are not = between ECM and GPCM	NONE	Runs continuously at key on, engine run	Compare IQA values stored in ECM and GPCM. Must be equal to pass.	A
	UXX	XX Communications					
Lost communications with Transmission Control System	U0101	ECM reports no loss of communication with the TCM	PATH 1)The ECM fails to receive messages \$19D, \$0F9, \$1F5, \$4C9 or \$199	Ignition on	Monitor time is 1000msec. Frequency is every 160msec.	CAN Message from the TCM	A
Lost Communications with Glow Plug Control Module			PATH 1)The ECM fails to receive message \$3BD. PATH 2)GPCM reports message \$3B9 from ECM is missing	Ignition on	Monitor time is 1000msec. Frequency is every 160msec.	Message from GPCM and ECM signal indicating loss of	В

LOOK-UP TABLES

COOLER MAP				RPM		
		800	1000	2000	2500	3000
	5	-10	-30	-30	-30	-30
injection qty mm	10	-10	-30	-30	-30	-30
	15	-10	-30	-30	-30	-30
	20	-10	-30	-30	-30	-30
	25	-10	-30	-30	-30	-30

	. =	_			
BOOST DEVI	ATION MA	AP .			
AirCtl_mMaxE	Ovt_MAP				
y/x	40	1800	2000	3000	4000
1	400	400	100	300	400
20	400	400	100	300	400
40	400	400	100	300	400
80	400	400	400	400	400
125	400	400	400	400	400
AirCtl_mMinD	vt_MAP				
y/x	40	1800	2000	3000	4000
1	-400	-400	100	300	-400
20	-400	-400	100	300	-400
40	-400	-400	100	300	-400
80	-400	-400	-400	-400	-400
125	-400	-400	-400	-400	-400
_					

DTC P0495	Barometric pressure												
		760 hpa						1000					
		(>= 8000	761 hpa	805 hpa	850 hpa	910 hpa	990 hpa	hpa					
		ft)	(7966 ft)	(6500 ft)	(5000 ft)	(3000 ft)	(1000 ft)	(0 ft)					
0	-6.74	20min	19.96	19.96	18.13	13.76	10.43	10					
Тетр	-6.04	20	19.96	19.96	18.13	13.76	10.43	10					
Te	36.96	20	19.96	19.96	18.13	13.76	10.43	10					
t S	99.96	20	19.96	19.96	18.13	13.76	10.43	10					
<u>ola</u>	101	30	29.92	19.96	18.13	13.76	10.43	10					
Coolant °C	103	40	40	40	18.13	13.76	10.43	10					
Ü	105	1092.23	1092.23	1092.23	1092.23	1092.23	10.43	10					
Fan Input Spee	400	800	1200	1600				3200	3600	4000	4400	4800	5200
Fan Speed	400	800	1200	1600	1700	1700	1700	1750	1750	1750	1750	1750	1750

244B TEMP MAP

Diesel Particulate Filter Differential Pressure Too High cal r

		DPF Surface Temperature [deg. C]																
		100	200	275	300	325	350	375	400	425	450	475	500	525	550	600	650	
	100	40	40	40	40	40	40	47	47	47	47	47	47	47	47	47	47	52
	300	58	65	90	95	87	79	82	86	89	93	96	88	92	96	96	100	
$\overline{}$	400	102	105	111	117	98	96	99	99	98	98	110	124	128	132	136	140	
3/hr]	500	145	145	132	138	109	113	116	112	107	103	125	129	164	168	172	180	
<_	600	182	182	168	178	167	198	174	167	160	132	160	157	208	212	216	224	
프	700	218	218	204	217	224	284	233	223	213	162	196	185	173	161	260	268	
ate	900	312	312	316	227	214	216	214	225	230	235	247	260	266	272	274	364	
<u> </u>	1100	448	432	428	428	432	432	436	440	308	332	373	382	392	383	377	480	
flow	1300	620	600	584	584	584	580	580	584	584	384	412	435	465	494	481	620	
₽	1500	620	764	740	736	732	728	724	724	728	732	469	511	558	605	587	756	
<u>st</u>	1700	620	1000	980	988	996	988	980	968	968	964	960	960	960	960	625	968	
ar	1900	620	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	
X	2100	620	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	
Ш	2400	620	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	
	2700	620	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	
	3000	620	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	

Catalyst Temperature Too Low/High During Regeneration Target Temp Map 244C											
			Engine	RPM							
		800	1000	1500	2100						
	0	620	651.5	651.5	651.5						
tor	40	620	651.5	651.5	651.5						
nject	50	620	651.5	651.5	651.5						
<u>=</u>	60	620	651.5	651.5	651.5						