Component/	Fault		Malfunction	Threshold	Secondary	Enable		MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Intake Camshaft Actuator Solenoid Circuit – Bank 1	P0010		The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		System supply voltage is within limits Output driver is commanded on, Ignition switch is in crank or run position	> 11 Volts, and < 32 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Trips 2 B Type
Intake Camshaft System Performance – Bank 1	P0011		Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	1)Cam Position Error > KtPHSD_phi_CamPo sErrorLimIc1 Deg (see Supporting	P0010 IntkCMP B1 Circuit IntakeCamSensorTFT KO CrankSensorTFTKO	System Voltage > 11 Volts, and System Voltage < 32 Volts Both Desired & Measured cam positions cannot be < KtPHSD_phi_CamPosErrorLimlc1 or > than (30.0 - KtPHSD_phi_CamPosErrorLimlc1). Desired cam position cannot vary more than 3.0 Cam Deg for at least KtPHSD_t_StablePositionTimelc1 seconds (see Supporting Tables)	100 failures out of 125 samples	Trips 2 B Type
					Engine is running VVT is enabled Desired camshaft position > 0 Power Take Off (PTO) not active		100 ms /sample	
Exhaust Camshaft Actuator Solenoid Circuit – Bank 1	P0013		The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		System supply voltage is within limits Output driver is commanded on, Ignition switch is in crank or run position	> 11 Volts, and < 32 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Trips 2 B Type

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Exhaust Camshaft System Performance – Bank 1	system error by [absolute variance – comparing the desired and actual position)]	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if		DTC's are NOT active: P0013 IntkCMP B1 Circuit ExhaustCamSensorT FTKO CrankSensorTFTKO	System Voltage > 11 Volts, and System Voltage < 32 Volts Both Desired & Measured cam positions cannot be < KtPHSD_phi_CamPosErrorLimEc 1 or > than (Exh22.5 - KtPHSD_phi_CamPosErrorLimEc 1). Desired cam position cannot vary more than 3.0 Cam Deg for at least KtPHSD_t_StablePositionTimeEc 1 seconds (see Supporting Tables)	100 failures out of 125 samples		
					Engine is running VVT is enabled Desired camshaft position > 0 Power Take Off (PTO) not active	145.00)	100 ms /sample	
Crankshaft Position (CKP)-Camshaft Position (CMP) Correlation Bank 1 Sensor A	P0016	Detects cam to crank misalignment by monitoring if cam sensor pulse for bank 1 sensor A occurs during the incorrect crank position	3 cam sensor pulses more than -10 crank degrees before or 10 crank degrees after nominal position in one cam revolution.		Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in		2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position.	2 trips
				"parked" position No Active DTCs: Time since last	P0335, P0336 P0340, P0341 5VoltReferenceA_FA 5VoltReferenceB_FA	This time is defined by the table "Cam Correlation Oil Temperature Threshold".		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					diagnostic	< 1.0 seconds		
							One sample per cam rotation	
Crankshaft Position (CKP)-Camshaft Position (CMP) Correlation Bank 1 Sensor B	P0017		3 cam sensor pulses more than -10 crank degrees before or 10 crank degrees after nominal position in one cam revolution.		Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic	P0335, P0336 P0365, P0366 5VoltReferenceA_FA 5VoltReferenceB_FA < 1.0 seconds	2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table "Cam Correlation Oil Temperature Threshold".	2 trips
							One sample per cam rotation	

Fault	0,	Malfunction				Time	MIL
			value			· · · · · · · · · · · · · · · · · · ·	illum.
P0030	Heater Output Driver circuit for electrical integrity.	open state (indicates short-to-ground or open circuit) or voltage high during driver closed state (indicates short to		Ignition Voltage	11.0 < Volts < 32.0	25 samples 250 ms / sample	2 trips Type B
P0033	Bypass Valve - Open Circuit	ECM detects that commanded and actual states of output driver do not match because the		Powertrain relay Voltage Ignition run crank voltage	Disabled >= 11.00 Volts >= 6.00 Volts		Type B 2 trips
P0034	Bypass Valve - Shorted to Ground	commanded and actual states of output driver do not match because the		Diagnosis Enabled Powertrain relay Voltage	Disabled >= 11.00 Volts >= 6.00 Volts	10 failures out of 20 samples 1 sample every 100ms	Type B 2 trips
P0035	Bypass Valve - Shorted to Power	commanded and actual states of output driver do not match because the		Powertrain relay Voltage Ignition run crank voltage	Disabled >= 11.00 Volts >= 6.00 Volts	10 failures out of 20 samples 1 sample every 100ms	Type B 2 trips
P0036	Heater Output Driver circuit for electrical integrity.	open state (indicates short-to-ground or open circuit) or voltage high during driver closed state (indicates short to		Ignition Voltage	11.0 < Volts < 32.0	20 failures out of 25 samples 250 ms / sample Continuous	2 trips Type B
	P0033 P0034 P0035	P0030 This DTC checks the Heater Output Driver circuit for electrical integrity. P0031 Detect Turbocharger Bypass Valve - Open Circuit P0034 Detect Turbocharger Bypass Valve - Shorted to Ground P0035 Detect Turbocharger Bypass Valve - Shorted to Power P0036 This DTC checks the Heater Output Driver circuit for electrical integrity.	P0030 This DTC checks the Heater Output Driver circuit for electrical integrity. P0033 Detect Turbocharger Bypass Valve - Shorted to Ground P0034 Detect Turbocharger Bypass Valve - Shorted to Ground P0035 Detect Turbocharger Bypass Valve - Shorted to Ground P0036 This DTC checks the Heater Output Driver circuit for electrical integrity. P0036 This DTC checks the Heater Output Driver circuit for electrical integrity. P0036 This DTC checks the Heater Output Driver circuit for electrical integrity. P0037 Detect Turbocharger Bypass Valve - Shorted to Power Short-to-ground or open circuit) or voltage high during driver closed state	P0030 This DTC checks the Heater Output Driver circuit for electrical integrity. P0033 Detect Turbocharger Bypass Valve - Shorted to Ground Shorted to Power Shorted to Power Shorted to Power Shorted to Power P0036 This DTC checks the Heater Output Driver circuit for electrical integrity. P0036 This DTC checks the Heater Output Driver circuit for electrical integrity. P0036 This DTC checks the Heater Output Driver circuit for electrical integrity. P0036 P0036 This DTC checks the Heater Output Driver circuit for electrical integrity. P0036 P0036	Poscription Criteria Value Parameters	Pool	P0030 This DTC checks the Voltage to

Component/	Fault	• • • • • • • • • • • • • • • • • • • •	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
HO2S Heater Resistance Bank 1 Sensor 1	P0053	Detects an oxygen sensor heater having an incorrect or out of	Heater Resistance	7.5 < Ω < 13.0		ECT_Sensor_FA P2610 IAT_SensorFA	Once per valid cold start	2 trips Type B
		range resistance value.			Coolant – IAT	< 8.0 °C		
		value.			Engine Soak Time Coolant Temp	> 28820 seconds -30.0 < °C < 45.0		
					Ignition Voltage	< 31.9 volts		
					Engine Run time			
HO2S Heater Resistance Bank 1 Sensor 2	P0054	Detects an oxygen sensor heater having an incorrect or out of range resistance	Heater Resistance	7.5 < Ω < 13.0	No Active DTC's Coolant – IAT	ECT_Sensor_FA P2610 IAT_SensorFA	Once per valid cold start	2 trips Type B
	value.	value.			Engine Soak Time	> 28820 seconds -30.0 < °C < 45.0		
					Engine Run time			
MAP / MAF / Throttle Position Correlation	P0068	and MAF do not match estimated engine airflow as established by the TPS	Difference between MAP and estimated MAP exceeds threshold (kPa), or P0651 (5 Volt Ref), or P0107 (MAP circuit low), or P0108 (MAP circuit high) have failed this key cycle, then MAP portion of diagnostic fails	Table, f(TPS). See supporting tables	Engine Speed	> 800 RPM Run/Crank voltage or Powertrain relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	Continuously fail MAP and MAF portions of diagnostic for 0.1875 s Continuous in MAIN processor	Trips: 1 Type: A MIL: YES

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Absolute difference between MAF and estimated MAF exceed threshold (grams/sec), or P0102 (MAF circuit low), or P0103 (MAF circuit hi) have failed this key cycle, or maximum MAF versus RPM (Table) is greater than or equal to maximum MAF versus battery voltage, then MAF portion	Table, f(TPS). See supporting tables				
Intake Air Temperature Sensor 2 Circuit Performance (applications with humidity sensor and manifold temperature sensor)	P0096	Detects an IAT2 sensor that has stuck in range by comparing to IAT and IAT3 at startup	ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up IAT - Power Up IAT3) AND ABS(Power Up IAT2 - Power Up IAT3)	> 25 deg C <= 25 deg C > 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.00 Volts >= 0.9seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

•		Monitor Strategy	Malfunction	Threshold	,	Enable		MIL
ystem (Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Power Up IAT is between Power Up IAT2 and Power Up IAT3 AND ABS(Power Up IAT2 - Power Up IAT3) AND ABS(Power Up IAT - Power Up IAT - Power Up IAT2) > ABS(Power Up IAT - Power Up IAT - Power Up IAT - Power Up IAT - Power Up IAT3)	> 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:		Executes once at the beginning of each ignition cycle if enable conditions are met	
			Power Up IAT3 is between Power Up IAT and Power Up IAT2 AND ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up IAT3 - Power Up IAT3) - Power Up IAT2) > ABS(Power Up IAT3 - Power Up IAT3)	> 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Intake Air Temperature Sensor Circuit 2 Low (applications with humidity)	P0097	Detects a continuous short to ground or open in the IAT 2 signal circuit	Raw IAT 2 Input	< 10 Hertz (~-60 deg C)	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B 2 trips
IIntake Air Temperature Sensor Circuit 2 High (applications with humidity)	P0098	Detects a continuous high frequency in the IAT 2 signal circuit	Raw IAT 2 Input	> 390 Hertz (~150 deg C)	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B 2 trips
Radiator Coolant Temp Sensor Circuit Low Voltage	P00B3	This DTC detects a short to ground in the RCT signal circuit or the RCT sensor.	RCT Resistance (@ 150°C)	< 34 Ohms	Or	> 10.0 seconds ≤ 70.3 °C	5 failures out of 10 samples 1 sec/ sample Continuous	2 trips Type B
Radiator Coolant Temp Sensor Circuit High Voltage	P00B4	Circuit Continuity This DTC detects a short to high or open in the RCT signal circuit or the RCT sensor.	RCT Resistance (@ -60°C)	> 260000 Ohms	Or	> 60.0 seconds ≥ -7.0 °C	5 failures out of 10 samples 1 sec/ sample Continuous	2 trips Type B

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Radiator Coolant Temp - Engine Coolant Temp ECT) Correlation	difference between ECT and RCT after a soak condition. 1) Absolute difference between ECT at power up is a an IAT based threshold table lookup value(fast fail). 2) Absolute difference between ECT at power up is a by 20.0 C and a block heater has not been detected. 3) ECT at power up by 20.0 and the time special conditions or continuous and the time special continuous and time	1) Absolute difference between ECT at power up & RCT at power up is ≥ an IAT based threshold table lookup value(fast	See "P00B6: Fail if	No Active DTC's Engine Off Soak Time	VehicleSpeedSensor_FA IAT_SensorCircuitFA THMR_RCT_Sensor_Ckt_FA THMR_ECT_Sensor_Ckt_FA IgnitionOffTimeValid TimeSinceEngineRunningValid > 28800 seconds	1 failure 500 msec/ sample Once per valid cold start	2 trips Type B	
		between ECT at power up & RCT at power up is > by 20.0 C and a block heater has not been		Test complete this trip Test aborted this trip	= Not occurred = False = False ≥ -7 °C	_		
		3) ECT at power up > IAT at power up by 20.0 C and the time spent cranking the engine without starting is greater than 10.0 seconds with the		when either 1) ECT at power up > IAT at power up by 2) Cranking time	> 20.0 °C			
		LowFuelConditionDiag	= False	2) occurs. where 1a) Vehicle drive time 1b) Vehicle speed 1c) Additional Vehicle drive time is provided to 1a when Vehicle speed is below 1b as follows:	> 400 Seconds with > 14.9 MPH and			

Component/	Fault		Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					1d) IAT drops from power up IAT			
					2a) ECT drops from power up ECT 2b) Engine run time	> 2 °C Within		
					3) Engine run time with vehicle speed below 1b 4) Minimum IAT			
					during test	≤ -7.0 °C		
Engine Coolant Flow Insufficient	P00B7	Insufficient Flow	Engine Coolant Temp (ECT) is greater than 120		No Active DTC's	THMR_RCT_Sensor_Ckt_FA THMR_ECT_Sensor_Ckt_FA	30 failures out of 300 samples	2 trips Type B
	greater than 40 De	between ECT and RCT is greater than 40 Deg C. When above is present		Engine run time	> 30 seconds	1 sec/ sample		
			for more than 5 seconds, fail counts start.		Engine Coolant Temp		Continuous	
Intake Air Pressure	P00C7	Detects an	ABS(Manifold Pressure -		Time between current		4 failures out of 5	Type B
Measurement System - Multiple Sensor Correlation	1 0007	inconsistency between pressure sensors in the	Baro Pressure)	> 10.0 kPa	ignition cycle and the last time the engine was running		samples 1 sample every	2 trips
(turbocharged)		which a particular sensor cannot be identified as the failed sensor	ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro	<= 10.0 kPa	Engine is not rotating	> 10.0 seconds	12.5 msec	
			Pressure)	<= 10.0 kPa	Manifold Pressure	>= 50.0 kPa		

ECM SECTION Page 10 of 215

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			OR					
					Manifold Pressure	<= 115.0 kPa		
			ABS(Manifold Pressure -		Baro Pressure	>= 50.0 kPa		
			Baro Pressure)		Baro Pressure	<= 115.0 kPa		
				<= 10.0 kPa	Turbocharger Boost			
			AND		Pressure	>= 50.0 kPa		
			ABS(Turbocharger Boost		Turbocharger Boost			
			Pressure - Manifold		Pressure	<= 115.0 kPa		
			Pressure)	> 10.0 kPa				
			AND		No Active DTCs:	EngModeNotRunTmErr		
			ABS(Turbocharger Boost		1.107.101.102.100.	MAP_SensorFA		
			Pressure - Baro			AAP_SnsrFA		
			Pressure)	<= 10.0 kPa		AAP2_SnsrFA		
			,	10.0 Ki u		7 ti Z_chen /t		
			OR		No Pending DTCs:	MAP_SensorCircuitFP		
			OK .		No r chaing bros.	AAP_SnsrCktFP		
			ABS(Manifold Pressure -			AAP2_SnsrCktFP		
			Baro Pressure)			AAI Z_SIISIOKII I		
			Baro i ressure)	<= 10.0 kPa				
			AND	10.0 Ki a				
			ABS(Turbocharger Boost					
			Pressure - Manifold					
			Pressure)	<= 10.0 kPa				
			AND	<= 10.0 KPa				
			ABS(Turbocharger Boost Pressure - Baro					
			Pressure - Baro Pressure)	. 40.0 l-D-				
			Fressure)	> 10.0 kPa				
			OR					
			A DO (MA LIFE LA D					
			ABS(Manifold Pressure -					
			Baro Pressure)	40.015				
				> 10.0 kPa				
			AND					
			ABS(Turbocharger Boost					
			Pressure - Manifold					
			Pressure)	> 10.0 kPa				
			AND					
			ABS(Turbocharger Boost					
1			Pressure - Baro					
			Pressure)					
	1			> 10.0 kPa				

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Mass Air Flow System Performance (naturally aspirated)	P0101	Determines if the MAF sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 500 kPa*(g/s) > 15 grams/sec > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 7000 RPM >= -7 Deg C <= 125 Deg C >= -20 Deg C <= 125 Deg C	Continuous Calculation are performed every 12.5 msec	Type B 2 trips
				25.0 Ni a		>= 0.25 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM		
						Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor Based on MAF Est		
						MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM		
					No Active DTCs:	See table "IFRD Residual Weighting Factors". MAP_SensorCircuitFA EGRValve_FP EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Mass Air Flow System Performance (turbocharged)	P0101	Determines if the MAF sensor is stuck within the normal operating range	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC.		Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 100 Deg C	Continuous Calculation are performed every 12.5 msec	Type E 2 trips
		MAF model fails when			>= 0.50			
			ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when	> 16 grams/sec		Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor Based on MAF Est		
	ABS(Mea MAP Mod	ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when	> 20.0 kPa		MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM			
			ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when	> 25.0 kPa		MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM		
			ABS(Measured MAP – MAP Model 3) Filtered	> 25.0 kPa		MAP Model 3 Error multiplied by MAP Residual Weight Factor based on RPM		
		TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered	> 25.0 kPa		TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM			

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
ystem	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
	Code		TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine	> 250 kPa*(g/s) > 25.0 kPa	No Active DTCs:	Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM See table "IFRD Residual Weighting Factors". MAP_SensorCircuitFA EGRValve_FP EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA ECT_Sensor_FA IAT_SensorCircuitFP IAT2_SensorFA IAT2_SensorFA IAT2_SensorCircuitFP TC_BoostPresSnsrCktFA AmbientAirDefault	Required	illum.
			TIAP Correlation is valid when High Engine Air Flow has					
			been TRUE for a period of time OR High Engine Air Flow has been TRUE for a period of time	> 2.0 seconds				
				> 2.0 seconds				

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			High Engine Air Flow is					
			TRUE when					
			Mass Air Flow					
				> a threshold in				
				gm/sec as a function				
				of engine speed				
				See table "TIAP-MAP				
				Correlation Min Air				
				Flow"				
			AND					
			Manifold Pressure					
				> a threshold in kPa				
				as a function of				
				engine speed				
				See table "TIAP-MAP				
				Correlation Min MAP"				
			AND					
			Filtered Mass Air Flow -					
			Mass Air Flow					
				< 2.0 gm/sec				
			Low Engine Air Flow is					
			TRUE when					
			Mass Air Flow					
				< a threshold in				
				gm/sec as a function				
				of engine speed				
				See table "TIAP-Baro				
				Correlation Max Air				
				Flow"				
			AND					
			Manifold Pressure					
				< a threshold in kPa				
				as a function of				
	1	1		engine speed	ĺ			

Component/	Fault	•	Malfunction	Threshold	Secondary	Enable		MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			AND Mass Air Flow - Filtered Mass Air Flow	See table "TIAP-Baro Correlation Max MAP"				
Mass Air Flow Sensor Circuit Low Frequency	P0102	Detects a continuous short to low or a open in either the signal circuit or the MAF sensor	MAF Output	<= 1837 Hertz (~ 0.39 gm/sec) (KtMAFI_dm_EngAir Flow)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 10.0 Volts >= 1.0 seconds	200 failures out of 250 samples 1 sample every cylinder firing event	Type B 2 trips
Mass Air Flow Sensor Circuit High Frequency	P0103	Detects a high frequency output from the MAF sensor	MAF Output	>= 13200 Hertz (~ 810.00 gm/sec) (KtMAFI_dm_EngAir Flow)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 10.0 Volts >= 1.0 seconds	200 failures out of 250 samples 1 sample every cylinder firing event	Type B 2 trips
Manifold Absolute Pressure Sensor Performance (naturally aspirated)	P0106	MAP sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 500 kPa*(g/s) > 25.0 kPa > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 7000 RPM >= -7 Deg C <= 125 Deg C >= -20 Deg C <= 125 Deg C >= 0.25 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM	Continuous Calculations are performed every 12.5 msec	Type B 2 trips

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
ystem	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					No Active DTCs:	MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM See table "IFRD Residual Weighting Factors". MAP_SensorCircuitFA EGRValve_FP EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA ECT_Sensor_FA IAT_SensorFA IAT_SensorCircuitFP		
			Engine Not Rotating Case: Manifold Pressure OR Manifold Pressure	< 50.0 kPa > 115.0 kPa	Time between current ignition cycle and the last time the engine was running	> 6.0 seconds	4 failures out of 5 samples 1 sample every 12.5 msec	
					Engine is not rotating			
					No Active DTCs:	EngModeNotRunTmErr MAP_SensorFA		
					No Pending DTCs:	AAP_SnsrFA MAP_SensorCircuitFP AAP_SnsrCktFP		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
/lanifold Absolute	P0106	Determines if the	See table "Turbocharger		Engine Speed	>= 400 RPM	Continuous	Type I
Pressure Sensor		MAP sensor is stuck	Intake Flow Rationality		Engine Speed	<= 6000 RPM		2 trips
Performance		within the normal	Diagnostic Failure Matrix"		Coolant Temp	> -7 Deg C	Calculation are	
turbocharged)		operating range	for combinations of model		Coolant Temp	< 125 Deg C	performed every	
			failures that can set this		Intake Air Temp	> -20 Deg C	12.5 msec	
			DTC.		Intake Air Temp	< 100 Deg C		
					Minimum total weight			
				factor (all factors				
					multiplied together)			
		MAF model fails when			>= 0.50			
		ABS(Measured Flow –			Modeled Air Flow Error multiplied			
			Modeled Air Flow)			by MAF Residual Weight Factor		
			Filtered	> 16 grams/sec		based on RPM and MAF Residual		
				Ĭ		Weight Factor Based on MAF Est		
			MAP1 model fails when					
			ABS(Measured MAP –					
			MAP Model 1) Filtered			MAP Model 1 Error multiplied by		
				> 20.0 kPa		MAP1 Residual Weight Factor		
						based on RPM		
			MAP2 model fails when					
			ABS(Measured MAP –			MAP Model 2 Error multiplied by		
			MAP Model 2) Filtered			MAP2 Residual Weight Factor		
				> 25.0 kPa		based on RPM		
			MAP3 model fails when					
						MAP Model 3 Error multiplied by		
			ABS(Measured MAP –			MAP Residual Weight Factor		
			MAP Model 3) Filtered			based on RPM		
				> 25.0 kPa				
			TIAP1 model fails when			TIAP Model 1 Error multiplied by		
					TIAP Residual Weight Factor			
			ABS(Measured TIAP –			based on RPM		
		TIAP Model 1) Filtered						
			> 25.0 kPa					

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
ystem	Code	Description	Criteria	Value	Parameters		Required	illum.
	Code	Description	TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table "TIAP-MAP Correlation Offset" OR Low Engine Air Flow is TRUE AND	Value > 250 kPa*(g/s)	Parameters No Active DTCs:	Conditions Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM See table "IFRD Residual Weighting Factors". MAP_SensorCircuitFA EGRValve_FP EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA IAT_SensorCircuitFP IAT2_SensorFA	Required	illum.
			Measured TIAP - measured Baro - offset as a function of engine	> 25.0 kPa		IAT2_SensorCircuitFP TC_BoostPresSnsrCktFA AmbientAirDefault		
			TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR High Engine Air Flow has been TRUE for a period of time	> 2.0 seconds				
			or unic	> 2.0 seconds				

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			High Engine Air Flow is					
			TRUE when					
			Mass Air Flow					
				> a threshold in				
				gm/sec as a function				
				of engine speed				
				See table "TIAP-MAP				
				Correlation Min Air				
				Flow"				
			AND					
			Manifold Pressure					
				> a threshold in kPa				
				as a function of				
				engine speed				
				See table "TIAP-MAP				
				Correlation Min MAP"				
			AND	Correlation Will WAP				
			Filtered Mass Air Flow -					
			Mass Air Flow					
			Mass All I low	< 2.0 gm/sec				
				2.0 gm/300				
			Low Engine Air Flow is					
			TRUE when					
			1					
			Mass Air Flow					
				< a threshold in				
				gm/sec as a function				
				of engine speed				
				See table "TIAP-Baro				
				Correlation Max Air				
				Flow"				
			AND					
			Manifold Pressure					
				< a threshold in kPa				
				as a function of				
				engine speed	1			1

Component/	Fault	Monitor Strategy	Malfunction	Threshold		Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
				See table "TIAP-Baro				
				Correlation Max				
				MAP"				
			AND					
			Mass Air Flow - Filtered					
			Mass Air Flow					
				< 2.0 gm/sec				
1			Engine Not Rotating					
			Case:					
			Manifold Pressure	< 50.0 kPa	Time between current		4 failures out of 5	
			OR		ignition cycle and the		samples	
			Manifold Pressure	> 115.0 kPa	last time the engine		'	
					was running		1 sample every	
							12.5 msec	
						> 10.0 seconds		
			OR			10.0 00001140		
					Engine is not rotating			
			ABS(Manifold Pressure -		Lingino lo not rotating			
			Baro Pressure)	> 10.0 kPa				
			Bare i receare)	10.0 10				
			AND		No Active DTCs:	EngModeNotRunTmErr		
			7.11412			MAP_SensorFA		
						TC_BoostPresSnsrCktFA		
			ABS(Turbocharger Boost			TO_BOOM TOO HOLONG A		
			Pressure - Manifold					
			Pressure)	> 10.0 kPa				
			1 10000.0)	10.0 141 4		AAP2_SnsrFA		
			AND			MAP_SensorCircuitFP		
			AND			AAP_SnsrCktFP		
			ABS(Turbocharger Boost			AAP2_SnsrCktFP		
			Pressure - Baro					
			Pressure)					
			1 1003010)	<= 10.0 kPa				
				10.0 Ki u				
1								
	I	1			1			

Component/	Fault	0,	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Manifold Absolute Pressure Sensor Circuit Low	P0107	Detects a continuous short to low or open in either the signal circuit or the MAP sensor.	MAP Voltage	< 3.0 % of 5 Volt Range (0.2 Volts = 3.5 kPa)	Continuous		320 failures out of 400 samples 1 sample every	Type B 2 trips
Manifold Absolute	P0108		MAP Voltage	> 90.0 % of 5 Volt	Continuous		12.5 msec 320 failures out of	
Pressure Sensor Circuit High		sensor ground or continuous short to high in either the signal circuit or the		Range (4.5 Volts = 115.0 kPa)			400 samples 1 sample every	2 trips
		MAP sensor.					12.5 msec	
Intake Air Temperature Sensor Circuit Performance (no humidity or manifold temperature	P0111	Detects an IAT sensor that has stuck in range by comparing to engine coolant temperature at startup	ABS(Power Up IAT - Power Up ECT)	> 40 deg C	Time between current ignition cycle and the last time the engine was running	> 28800 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B 2 trips
sensors)					Power Up ECT No Active DTCs:	< 60 deg C ECT_Sensor_Ckt_FA IAT_SensorCircuitFA		
Intake Air Temperature Sensor Circuit Performance (applications with humidity sensor and	P0111		ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up IAT - Power Up IAT3)	> 25 deg C > 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time	> 28800 seconds >= 11.00 Volts	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B 2 trips
temperature sensor)			AND ABS(Power Up IAT2 - Power Up IAT3)	<= 25 deg C	No Active DTCs:	>= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA		

Component/		Monitor Strategy		Threshold		Enable		MIL
System	Code	Description		Value		Conditions	· · · ·	illum.
			Power Up IAT2 is between Power Up IAT and Power Up IAT3 AND ABS(Power Up IAT - Power Up IAT3) AND ABS(Power Up IAT2 - Power Up IAT) > ABS(Power Up IAT2 - Power Up IAT3)	> 25 deg C	No Active DTCs:	> 28800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	
			Power Up IAT3 is between Power Up IAT and Power Up IAT2 AND ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up IAT3 - Power Up IAT) > ABS(Power Up IAT3 - Power Up IAT3 -	> 25 deg C		> 28800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	
Intake Air Temperature Sensor Circuit Low (High Temperature)	P0112	Detects a continuous short to ground in the IAT signal circuit or the IAT sensor	Raw IAT Input	< 94 Ohms (~150 deg C)	Engine Run Time	> 0.0 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B 2 trips

Component/	Fault		Malfunction	Threshold	Secondary	Enable		MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Intake Air Temperature Sensor Circuit High (Low Temperature)	P0113	Detects a continuous open circuit in the IAT signal circuit or the IAT sensor	Raw IAT Input	> 63000 Ohms (~-60 deg C)	Engine Run Time	> 0.0 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B 2 trips
Intake Air Temperature Sensor Intermittent In-Range	P0114		Change in IAT reading between consecutive 100 millisecond samples Change in IAT is multiplied by IAT Intermittent Weight Factor based on Filtered IAT. Filtered IAT = 0.10 * Current IAT + 0.90 * Filtered IAT from 100 milliseconds before	> 10 DegC	Continuous		20 failures out of 200 samples 1 sample every 100 msec	Type B 2 trips
Intake Air Temperature Sensor Intermittent In-Range	P0114	Detects a noisy or erratic IAT signal circuit or IAT sensor		> 99,999,997,952.00 DegC 10 consecutive IAT samples			4 failures out of 5 samples	Type B 2 trips

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
ngine Coolant emperature (ECT) ensor erformance	P0116	This DTC detects ECT temp sensor stuck in mid range.	A failure will be reported if any of the following occur: 1) ECT at power up > IAT at power up by an IAT based table lookup value	See "P0116: Fail if power up ECT exceeds IAT by these values" in the Supporting tables section	No Active DTC's Non-volatile memory initization Test complete this trip Test aborted this trip IAT LowFuelCondition Diag Block Heat when either 1) ECT at power up > IAT at power up by 2) Cranking time Block Hediagnostic occurs. Diagi	VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_Ckt_FA IgnitionOffTimeValid TimeSinceEngineRunningValid = Not occurred = False = False ≥ -7 °C = False er detection is enabled of the following occurs: > 20.0 °C < 10.0 Seconds eater is detected and is aborted when 1) or 2) nostic is aborted when 3) or 4) occurs: > 400 Seconds with > 14.9 MPH 0.50 times the seconds with vehicle speed below 1b	1 failure 500 msec/ sample Once per valid cold start	2 trips Type E

Component/ System	Fault Code		Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL illum.
					2a) ECT drops from power up ECT 2b) Engine run time 3) Engine run time with vehicle speed below 1b 4) Minimum IAT during test	> 2 °C Within > 60 Seconds > 1800 Seconds		
Engine Coolant Temp Sensor Circuit Low	P0117	Circuit Continuity This DTC detects a short to ground in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ 150°C)	< 34 Ohms			5 failures out of 6 samples 1 sec/ sample Continuous	2 trips Type B
Engine Coolant Temp Sensor Circuit High	P0118	Circuit Continuity This DTC detects a short to high or open in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ - 60°C)		Or	> 15.0 seconds ≥ -7.0 °C	5 failures out of 6 samples 1 sec/ sample Continuous	2 trips Type B
Engine Coolant Temperature (ECT) Sensor Circuit Intermittent	P0119	Circuit Continuity This DTC detects large step changes in the ECT signal circuit or the ECT sensor. Allowable high and low limits are calculated for the next sample based on the previous sample.	ECT temperature step change: 1) postive step change is greater than high limit OR 2) negitive step change is lower than low limit.		No Active DTC's	P0117 P0118	3 failures out of 4 samples 1 sec/ sample Continuous	2 trips Type B

System Throttle Position Sensor Performance		Description		i e		Enable		
Sensor	P0121		Criteria	Value	Parameters	Conditions	Required	illum.
	10121		Filtered Throttle Model		Engine Speed	>= 400 RPM	Continuous	Туре В
Performance			Error	> 500 kPa*(g/s)	Engine Speed	<= 7000 RPM		2 trips
		Sensor input is stuck	AND		Coolant Temp	> -7 Deg C	Calculation are	
(naturally		within the normal	ABS(Measured Flow –		Coolant Temp	< 125 Deg C	performed every	
aspirated)		operating range	Modeled Air Flow)		Intake Air Temp	> -20 Deg C	12.5 msec	
			Filtered	> 15 grams/sec	Intake Air Temp	< 125 Deg C		
			AND		Minimum total weight			
			ABS(Measured MAP –		factor (all factors			
			MAP Model 2) Filtered		multiplied together)			
				<= 25.0 kPa				
						>= 0.25		
						Filtered Throttle Model Error		
						multiplied by TPS Residual Weight Factor based on RPM		
						Weight Factor based on RPM		
1						Modeled Air Flow Error multiplied		
						by MAF Residual Weight Factor		
						based on RPM and MAF Residual		
						Weight Factor Based on MAF Est		
						Con table WEDD Decidual		
						See table "IFRD Residual		
					No Active DTCo.	Weighting Factors".		
					No Active DTCs:	MAP_SensorCircuitFA		
						EGRValve_FP		
						EGRValvePerformance_FA		
						MAF_SensorCircuitFA		
						CrankSensor_FA		
						ECT_Sensor_FA		
						ECT_Sensor_Ckt_FP		
						IAT_SensorFA		
						IAT_SensorCircuitFP		

Component/	Fault		Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Throttle Position Sensor Performance (turbocharged)	P0121	Determines if the Throttle Position Sensor input is stuck within the normal	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC.		Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 100 Deg C	Continuous Calculation are performed every 12.5 msec	Type B 2 trips
			MAF model fails when		multiplied together)	>= 0.50		
			ABS(Measured Flow – Modeled Air Flow) Filtered	> 16 grams/sec		Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor Based on MAF Est		
			MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when	> 20.0 kPa		MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM		
			ABS(Measured MAP – MAP Model 2) Filtered	> 25.0 kPa		MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM		
			MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered	> 25.0 kPa		MAP Model 3 Error multiplied by MAP Residual Weight Factor based on RPM		
			TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered	20.0 0		TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM		
				> 25.0 kPa				

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
system	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
				> 250 kPa*(g/s)				
			See table "TIAP-Baro Correlation Offset" TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR High Engine Air Flow has been TRUE for a period of time	> 2.0 seconds > 2.0 seconds				

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
ystem	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			High Engine Air Flow is					
			TRUE when					
			Mass Air Flow					
				> a threshold in				
				gm/sec as a function				
				of engine speed				
				See table "TIAP-MAP				
				Correlation Min Air				
				Flow"				
			AND					
			Manifold Pressure					
				> a threshold in kPa				
				as a function of				
				engine speed				
				Januar Para				
				See table "TIAP-MAP				
				Correlation Min MAP"				
			AND					
			Filtered Mass Air Flow -					
			Mass Air Flow					
				< 2.0 gm/sec				
				2.0 9117000				
			Low Engine Air Flow is					
			TRUE when					
			Mass Air Flow					
				< a threshold in				
				gm/sec as a function				
				of engine speed				
				See table "TIAP-Baro				
				Correlation Max Air				
				Flow"				
			AND					
			Manifold Pressure					
			IVIAIIIIUIU FIESSUIE					
				< a threshold in kPa				
				as a function of				
				engine speed				
				ongine speed				
				See table "TIAP-Baro				
				Correlation Max				
				MAP"				

Component/	Fault		Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			AND					
			Mass Air Flow - Filtered Mass Air Flow					
				< 2.0 gm/sec				
or intermit	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage <	0.325		Run/Crank voltage or Powertrain relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	79/159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	1	
						No 5V reference error or fault for # 4 5V reference circuit (P06A3)		
FPS1 Circuit High	P0123	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage >	4.75		Run/Crank voltage or Powertrain relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	79/159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	1
								A MIL: YES
						No 5V reference error or fault for # 4 5V reference circuit (P06A3)		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable		MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Engine Coolant Temperature Below Stat Regulating Temperature	P0128	This DTC detects if the engine coolant temperature rises too slowly due to an ECT or Cooling system fault	Engine run time is accumulated when airflow is ≥ 11 grams per sec during Range #1 or #2: Range #1 (Primary)	Maximum Accumulated Time	No Active DTC's	MAF_SensorFA IAT_SensorFA THMR_RCT_Sensor_Ckt_FA THMR_ECT_Sensor_Ckt_FA	1 failure to set DTC 1 sec/ sample	2 trips Type B
			ECT reaches Commanded temperature minus 26.0 °C when IAT min is < 65.0°C and ≥ 10.0°C.		run time	≥ 1800 seconds 22 ≤ Eng Run Tme ≤ 1800 seconds Ethanol ≤ 100%	Once per ignition key cycle	
			Range #2 (Alternate) ECT reaches Commanded temperature minus 46.0 °C when IAT		Range #1 (Primary) Test ECT at start run Average Airflow T-Stat Heater duty commanded cycle	≥ 11.0 gps		
			min is < 10.0°C and ≥ - 7.0°C.		Range #2 (Alternate) Test ECT at start run Average Airflow T-Stat Heater duty commanded cycle	≥ 11.0 gps		
O2S Circuit Low Voltage Bank 1 Sensor 1	P0131	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 20 mVolts	No Active DTC's AIR intrusive test Fuel intrusive test Idle intrusive test	= Not active	380 failures out of 475 samples Frequency: Continuous in 100 milli - second loop	2 trips Type B

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					EGR intrusive test	= Not active		
					System Voltage	10.0 < Volts < 32.0		
					EGR Device Control	= Not active		
					Idle Device Control	= Not active		
					Fuel Device Control	= Not active		
					AIR Device Control	= Not active		
					Low Fuel Condition			
					Diag	= False		
						0.9912 < ratio < 1.0137		
					Air Per Cylinder	60 < mgram < 500		
					Fuel Control State	= Closed Loop		
					Closed Loop Active	= TRUE		
					All Fuel Injectors for			
					active Cylinders			
					Fuel Condition	Ethanol ≤ 87%		
					Fuel State	DFCO not active		
					All of the above met			
					for	> 3.0 seconds		
							-	
O2S Circuit High	P0132	This DTC	Oxygen Sensor Signa	al			100 failures out of	2 trip
Voltage Bank 1		determines if the O2		> 1050 mvolts	Op	en Test Criteria	125 samples	Type
Sensor 1		sensor circuit is				TPS_ThrottleAuthorityDefaulted		71
		shorted to high.			110 7 10 11 0 0	MAF_SensorFA		
						EthanolCompositionSensor_FA	Frequency:	
					System Voltage	10.0 < Volts < 32.0	Continuous in	
						= All Cylinders active	100 milli - second	
					Heater Warm-up		loop	
						= Complete		
					Engine Run Time			
					Engine Run Accum			
					Fuel Condition	≤ 87 % Ethanol		
						MAP SensorFA	_	
					No Active B103	EvapPurgeSolenoidCircuit FA		
						EvapFlowDuringNonPurge_FA		
						EvapVentSolenoidCircuit FA		
						EvapSmallLeak_FA		
						EvapEmissionSystem_FA		
					FuelTankPressureSnsrCkt FA			
					FuelInjectorCircuit FA			
					Low Final Condition	AIR System FA		
					Low Fuel Condition			
		1		1	Diag	= False		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					Fuel Condition	n ≤ 87 % Ethanol		
					Initial delay after			
						> 10.0 seconds when		
					met (cold star	t engine soak time > 28820		
					condition	seconds		
					Initial delay after	r		
					Open Test Criteria	> 10.0 seconds when		
					met (not cold star	t engine soak time ≤ 28820		
					condition	seconds		
					Equivalence Ration	0.9912 ≤ ratio ≤ 1.0137		
					Air Per Cylinde	r 60.0 ≤ mgram ≤ 500.0		
					Fuel Control State	not = Power Enrichment		
					All of the above me	1	1	
					for	r > 3.0 seconds		
							1	
O2S Slow	P0133	This DTC	The average response		No Active DTC's	3	Sample time is 60	2 trips
Response Bank 1			time is caluclated over		10710070	TPS_ThrottleAuthorityDefaulted	seconds	Type B
Sensor 1		sensor response	the test time, and			MAP_SensorFA		71
		time is degraded.	compared to the			IAT_SensorFA		
			threshold. Refer to			ECT_Sensor_FA	Frequency:	
			"P0133 - O2S Slow			AmbientAirDefault	Once per trip	
			Response Bank 1			MAF SensorFA		
			Sensor 1" Pass/Fail			EvapPurgeSolenoidCircuit_FA		
			Threshold table in the			EvapFlowDuringNonPurge_FA		
			Supporting Tables tab.			EvapVentSolenoidCircuit_FA		
						EvapSmallLeak_FA		
						EvapEmissionSystem_FA		
						FuelTankPressureSnsrCkt FA		
						FuelInjectorCircuit_FA		
						AIR System FA		
						EthanolCompositionSensor_FA		
						EngineMisfireDetected_FA		
						P0131		
						P0132		
						P0134		
					System Voltage	e 10.0 < Volts < 32.0		
					EGR Device Contro			
					Idle Device Contro			
					Fuel Device Contro			
					AIR Device Contro			
					Low Fuel Condition			
		1	1	1	Diag	= False		I

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
						= Not Valid, See definition of		
						Green Sensor Delay Criteria		
					Green O2S Condition	(B1S1) in Supporting Tables tab.		
					O2 Heater on for			
					Learned Htr			
					resistance			
					Engine Coolant			
						> -40 °C		
					Engine run Accum			
					Time since any AFM			
						> 2.0 seconds		
					Time since Purge On			
						> 2.0 seconds		
					Time since Purge Off			
						> 2.0 seconds		
					Purge duty cycle	≥ 0 % duty cycle		
						8 ≤ grams per second ≤ 30		
						1200 <= RPM <= 3500		
					Fuel	< 87 % Ethanol		
						> 70 kpa		
					Air Per Cylinder			
					Low Fuel Condition			
						= False		
					Fuel Control State			
					Closed Loop Active			
					LTM fuel cell			
					L i Wilder Cell	- Lilabled		
					Transiant Fuel Mass	< 400 0 m supers		
					Transient Fuel Mass			
						= Not Defaulted		
						not = Power Enrichment		
						DFCO not active		
					Commanded			
					Proportional Gain			
					All of the above met			
					for	> 1.0 seconds	l	
							Ī	
	1							

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
O2S Circuit Insufficient Activity Bank 1 Sensor 1	P0134	This DTC determines if the O2 sensor circuit is open.	Oxygen Sensor Signal	> 1700 mvolts	AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum	TPS_ThrottleAuthorityDefaulted MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds	100 failures out of 125 samples. Frequency: Continuous 100msec loop	2 trips Type B
O2S Heater Performance Bank 1 Sensor 1	P0135	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current	0.3 < Amps < 2.5	Heater Warm-up delay O2S Heater device	ECT_Sensor_FA 10.0 < Volts < 32.0 = Complete = Not active	8 failures out of 10 samples Frequency: 2 tests per trip 10 seconds delay between tests and 1 second execution rate	2 trips Type B
O2S Circuit Low Voltage Bank 1 Sensor 2	P0137	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 20 mvolts	for		380 failures out of 475 samples Frequency: Continuous in 100 milli - second loop	2 trips Type B

ECM SECTION Page 36 of 215

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					Idle intrusive test	= Not active		
					EGR intrusive test	= Not active		
					System Voltage	10.0 < Volts < 32.0		
					EGR Device Control	= Not active		
					Idle Device Control	= Not active		
					Fuel Device Control	= Not active		
					AIR Device Control	= Not active		
					Low Fuel Condition			
					Diag	= False		
						0.9912 ≤ ratio ≤ 1.0137		
						100 ≤ mgrams ≤ 500		
					Fuel Control State	= Closed Loop		
					Closed Loop Active	= TRUE		
					All Fuel Injectors for			
					active Cylinders			
					Fuel Condition	Ethanol <= 87%		
						DFCO not active		
					All of the above met			
					for	> 5.0 seconds		
O2S Circuit High	P0138	This DTC	Oxygen Sensor Signal	İ	Ор	en Test Criteria	100 failures out of	2 trips
Voltage Bank 1		determines if the O2		> 1050 mvolts		TPS_ThrottleAuthorityDefaulted	125 samples	Type E
00				1000 11110110	IND ACTIVE DICS	THE THIOMICAUTIONTY DCIAUTICA	120 Samples	I I ypc L
Sensor 2		sensor circuit is		1000 IIIVollo	NO Active DTC s	MAF_SensorFA	120 samples	Type L
Sensor 2		sensor circuit is shorted to high.		1000 mvoito	NO ACTIVE DTC'S			Туре L
Sensor 2				Todo involto		MAF_SensorFA EthanolCompositionSensor_FA	Frequency: Continuous in	Type L
Sensor 2				Toda invoice	System Voltage	MAF_SensorFA	Frequency:	
Sensor 2				Todo Involto	System Voltage AFM Status	MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active	Frequency: Continuous in	
Sensor 2				Todo Involto	System Voltage AFM Status Heater Warm-up	MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active	Frequency: Continuous in 100 milli - second	
Sensor 2				Todo Involto	System Voltage AFM Status Heater Warm-up	MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete	Frequency: Continuous in 100 milli - second	
Sensor 2				Todo Involto	System Voltage AFM Status Heater Warm-up delay Engine Run Time	MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds	Frequency: Continuous in 100 milli - second	
Sensor 2				Todo Involto	System Voltage AFM Status Heater Warm-up delay Engine Run Time Fuel Condition	MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds ≤ 87 % Ethanol	Frequency: Continuous in 100 milli - second	
Sensor 2				Todo Involto	System Voltage AFM Status Heater Warm-up delay Engine Run Time Fuel Condition	MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds ≤ 87 % Ethanol MAP_SensorFA	Frequency: Continuous in 100 milli - second	
Sensor 2					System Voltage AFM Status Heater Warm-up delay Engine Run Time Fuel Condition	MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds ≤ 87 % Ethanol MAP_SensorFA EvapPurgeSolenoidCircuit_FA	Frequency: Continuous in 100 milli - second	
Sensor 2					System Voltage AFM Status Heater Warm-up delay Engine Run Time Fuel Condition	MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds ≤ 87 % Ethanol MAP_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA	Frequency: Continuous in 100 milli - second	
Sensor 2					System Voltage AFM Status Heater Warm-up delay Engine Run Time Fuel Condition	MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds ≤ 87 % Ethanol MAP_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA	Frequency: Continuous in 100 milli - second	
Sensor 2					System Voltage AFM Status Heater Warm-up delay Engine Run Time Fuel Condition	MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds ≤ 87 % Ethanol MAP_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA	Frequency: Continuous in 100 milli - second	
Sensor 2					System Voltage AFM Status Heater Warm-up delay Engine Run Time Fuel Condition	MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds ≤ 87 % Ethanol MAP_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA	Frequency: Continuous in 100 milli - second	
Sensor 2					System Voltage AFM Status Heater Warm-up delay Engine Run Time Fuel Condition	MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds ≤ 87 % Ethanol MAP_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA	Frequency: Continuous in 100 milli - second	
Sensor 2					System Voltage AFM Status Heater Warm-up delay Engine Run Time Fuel Condition	MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds ≤ 87 % Ethanol MAP_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA	Frequency: Continuous in 100 milli - second	
Sensor 2					System Voltage AFM Status Heater Warm-up delay Engine Run Time Fuel Condition No Active DTC's	MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds ≤ 87 % Ethanol MAP_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA AIR System FA	Frequency: Continuous in 100 milli - second	
Sensor 2					System Voltage AFM Status Heater Warm-up delay Engine Run Time Fuel Condition No Active DTC's	MAF_SensorFA EthanolCompositionSensor_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds ≤ 87 % Ethanol MAP_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA AIR System FA	Frequency: Continuous in 100 milli - second	

Component/	Fault		Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
D2 Sensor Slow Response Rich to Lean Bank 1 Gensor 2	P013A	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Rich to Lean voltages range during Rich to Lean transition. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Post O2 sensor normalized integral value OR The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 9.5 units > 10 grams (upper threshold is mvolts	Initial delay after Open Test Criteria met (cold start condition) Initial delay after Open Test Criteria met (not cold start condition) Equivalence Ratio Air Per Cylinder Fuel Control State All of the above met for No Active DTC's B1S2 Failed this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition Low Fuel Condition	> 10.0 seconds when engine soak time > 28820 seconds > 10.0 seconds when engine soak time ≤ 28820 seconds 0.9912 ≤ ratio ≤ 1.0137 100 ≤ mgrams ≤ 500 not = Power Enrichment > 3.0 seconds TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013B, P013E, P013F, P2270 or P2271 10.0 < Volts < 32.0 = Valid = Not Valid = Not Valid, See definition of Green Sensor Delay Criteria (B1S2) in Supporting Tables tab. = False = enabled	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc= FALSE for the given Fuel Bank OR NaPOPD_b_Rapi dResponseActive = TRUE, multiple tests per trip are allowed.	1 trips Type A EWMA

Component/	Fault		Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					DTC's Passed	P013E (and P014A if applicable)		
					After above conditions DFCO mode is continu	are met: led (wo driver initiated pedal input).		
O2 Sensor Slow Response Lean to Rich Bank 1 Sensor 2	P013B	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Lean to Rich voltages range during Lean to Rich transition. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	The EWMA of the Post O2 sensor normalized integral value OR The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 9.5 units > 140 grams (lower	B1S2 Failed this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition Low Fuel Condition	= Valid = Not Valid = Not Valid, See definition of Green Sensor Delay Criteria (B1S2) in Supporting Tables tab. = False = enabled	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc= FALSE for the given Fuel Bank OR NaPOPD_b_Rapi dResponseActive = TRUE, multiple tests per trip are allowed.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL illum.
					After above condition Fuel Enrich mode con			
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 2	P013E	This DTC determines if the post catalyst O2 sensor has an initial delayed response to an A/F change from Rich to Lean. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	Post O2 sensor voltage AND The Accumulated mass air flow monitored during the Delayed Response Test	> mvolts	B1S2 Failed this ke cycl System Voltag Learned heate resistand ICAT MAT Burno dela Green O2S Conditio Low Fuel Conditio Dia Post fuel ce DTC's Passe	e = Valid fff y = Not Valid = Not Valid, See definition of Green Sensor Delay Criteria n (B1S2) in Supporting Tables tab. n g = False = enabled P2270 (and P2272 if applicable)	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc= FALSE for the given Fuel Bank OR NaPOPD_b_Rapi dResponseActive = TRUE, multiple tests per trip are allowed.	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 2	P013F	This DTC determines if the post catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	AND The Accumulated mass air flow monitored during the Delayed Response Test	< mvolts	B1S2 Failed this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition Low Fuel Condition	= Valid = Not Valid = Not Valid, See definition of Green Sensor Delay Criteria (B1S2) in Supporting Tables tab. = False = enabled	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc= FALSE for the given Fuel Bank OR NaPOPD_b_Rapi dResponseActive = TRUE, multiple tests per trip are allowed	
					After above conditions Fuel Enrich mode ente			
O2S Circuit Insufficient Activity	P0140	This DTC determines if the O2	Oxygen Sensor Signal	> 1700 mvolts		TPS_ThrottleAuthorityDefaulted MAF_SensorFA	100 failures out of 125 samples.	2 trips Type B
Bank 1 Sensor 2		sensor circuit is open.			,	EthanolCompositionSensor_FA 10.0 <volts 32.0="All" <="" active<="" cylinders="" td=""><td>Frequency: Continuous 100msec loop</td><td>71.5 =</td></volts>	Frequency: Continuous 100msec loop	71.5 =

ECM SECTION Page 41 of 215

Component/	Fault	•	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					Engine Run Time Engine Run Accum	= Complete > 5 seconds		
02S Heater Performance Bank Sensor 2	P0141	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current	0.3 > amps > 2.5	System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	= Complete = Not active	8 failures out of 10 samples Frequency: 2 tests per trip 10 seconds delay between tests and 1 second execution rate.	2 trips
D2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 1	P015A	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Rich to Lean. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	OR	> 0.40 EWMA (sec)		TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA P0131 P0132 P0134 10.0 < Volts < 32.0	Frequency: Once per trip Note: if NaESPD_b_FastI nitRespIsActive = TRUE for the given Fuel Bank OR NaESPD_b_Rapi dResponseIsActi ve = TRUE, multiple tests per trip are allowed	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
ystem	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					Idle Device Contro	I = Not active		
					Fuel Device Control	I = Not active		
					AIR Device Control	I = Not active		
					Low Fuel Condition			
						= False		
					Green O2S Condition			
						= Not Valid, See definition of		
						Green Sensor Delay Criteria		
						(B1S1) in Supporting Tables tab.		
					O2 Heater on for			
					Learned Htr			
					resistance			
					Engine Coolant			
						> -40 °C		
					Engine run Accum			
					Engine Speed to			
						t 1400 ≤ RPM ≤ 3500		
					Engine Speed range			
					to keep test enabled			
					(after initially enabled)			
					(after fillitially chabled)	/ 1350 ≤ RPM ≤ 3650		
					Engine Airfley			
					Engine Airflow	-		
					Vehicle Speed to			
						28.0 ≤ MPH ≤ 77.7		
					Vehicle Speed range			
					to keep test enabled			
					(after initially enabled)			
						24.9 ≤ MPH ≤ 80.8 mph		
						0.92 ≤ C/L Int ≤ 1.08		
					Closed Loop Active			
						not in control of purge		
						not in estimate mode		
					Post fuel cel	= enabled		
					EGR Intrusive			
					diagnostic	= not active		
					All post sensor heater			
					delays	= not active		
					O2S Heater on Time	e ≥ 40.0 sec		
					Predicted Catalyst	t		
						550 ≤ °C ≤ 900		
						e = DFCO possible		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
						for at least 1.5 seconds, and then the intrusive stage is requested.		
					Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders After above con	≥ 690 mvolts = DFCO active		
					entered (wo d	inver initiated pedal input).	_	
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 1	P015B	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test which runs in an enriched fuel mode to achieve the required response.	OR [The Accumulated time monitored during the L2R Delayed Response Test (Gross failure). AND Pre O2 sensor voltage is	> 0.40 EWMA (sec) ≥ 2.00 Seconds	No Active DTC's	TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA AIR System FA	Frequency: Once per trip Note: if NaESPD_b_FastI nitRespIsActive = TRUE for the given Fuel Bank OR NaESPD_b_Rapi dResponseIsActi ve = TRUE, multiple tests per trip are allowed	
			below] OR At end of Cat Rich stage the Pre O2 sensor output is	< 350 mvolts	EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition	= Not active = Not active = Not active		

| ECM SECTION Page 44 of 215

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					Green O2S Condition	וו		
						= Not Valid, See definition of		
						Green Sensor Delay Criteria		
						(B1S1) in Supporting Tables tab.		
					O2 Heater on fo			
					Learned Ht	r		
					resistance	e = Valid		
					Engine Coolan	t > 60 °C		
					IAT	- > -40 °C		
					Engine run Accum	> 150 seconds		
					Engine Speed to			
						t 1400 ≤ RPM ≤ 3500		
					Engine Speed range			
					to keep test enabled			
					(after initially enabled			
						1350 ≤ RPM ≤ 3650		
					Engine Airflow			
					Vehicle Speed to			
						t 28.0 ≤ MPH ≤ 77.7		
					Vehicle Speed range			
					to keep test enabled			
					(after initially enabled			
						24.9 ≤ MPH ≤ 80.8 mph		
					Closed loop integra	0.92 ≤ C/L Int ≤ 1.08		
					Closed Loop Active			
						not in control of purge		
						not in estimate mode		
					Post fuel cel			
					EGR Intrusive			
						c = not active		
					All post sensor heate			
					uelays	s = not active		
					O2C Haatan an Time	> 40.0 000		
					O2S Heater on Time			
					Predicted Catalys			
						0 550 ≤ °C ≤ 900		
						e = DFCO inhibit		
						≥ 1 cylinders		
						ove conditions are met:		
					Fuel E	nrich mode entered.		
	1							

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Fuel System Too Lean Bank 1	P0171	Determines if the fuel control system is in a lean condition, based on the filtered long-term and short-term fuel trim.	The filtered long-term	>= 1.250 >= 0.100	Engine speed BARO Coolant Temp MAP Inlet Air Temp MAF	400 <rpm< 7000=""> 70 kPa -20 <°C< 150 10 <kpa< -20="" 1.0="" 150="" 255="" 512.0="" <g="" <°c<="" s<=""> 10 % or if fuel sender is faulty > 20.1 seconds of data must accumulate on each trip, with at least 0.1 seconds of data in the current fuel trim cell before a pass or fail decision can be made. Please see "Supporting Tables" Tab for a list of cells utilized for diagnosis</kpa<></rpm<>	Frequency: 100 ms Continuous Loop Development data indicates that the Fuel Adjustment System Diagnostic (FASD) is typically enabled during 90 % of the EPAIII drive cycle. This is also typical of real- world driving, however values will vary (higher or lower) based on the actual conditions present during	2 Trip(s) Type B
					Closed Loop Long Term FT EGR Diag. Catalyst Diag.	Enabled Enabled Please see "Closed Loop Enable Criteria" and "Long Term FT Enable Criteria" in Supporting Tables. Intrusive Test Not Active Intrusive Test Not Active	the drive cycle.	
					Post O2 Diag. Device Control EVAP Diag. No	Intrusive Test Not Active Intrusive Test Not Active Not Active "tank pull down" Not Active D active DTCs: SystemRPM_FA IAP_SensorFA		

Component/	Fault		Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
						MAF_SensorFA		
					V	IAF_SensorTFTKO		
						AIR System FA		
						urgeSolenoidCircuit_FA		
					The state of the s	IowDuringNonPurge_FA		
					-	VentSolenoidCircuit_FA		
						EvapSmallLeak_FA		
						pEmissionSystem_FA		
					FuelTank	:PressureSensorCircuit_FA		
						nanol Comp Snsr FA		
						FuelInjectorCkt_FA		
						gMisfireDetected_FA		
						EGRValvePerf_FA		
						EGRValveCkt_FA		
					MA	P_EngVacuumStatus		
						mbPresDfltdStatus		
					TO	C_BoostPresSnsrFA		
					02	Snsr_B1_Snsr_1_FA		
Fuel System Too	P0172	Determines if the	Passive Test: The filtered	<= 0.750		Secondary Parameters and	Frequency:	2 Trip(s
Rich Bank 1		1	Non-Purge Long Term			Enable Conditions are identical to		Type B
		in a rich condition, based on the filtered	Fuel Trim metric			those for P0171, with the exception that fuel level is not	Continuous	
		long-term fuel trim				considered.	Loop	
		metric.				considered.	Development	
		inouno.	AND				data indicates	
		There are two	The filtered Short Term	<= 2.000			that the Fuel	
		methods to	Fuel Trim metric (cal >				Adjustment	
		determine a Rich	1.05 indicates cal-out)				System	
		fault. They are			_		Diagnostic	
		Passive and	Intrusive Test: The filtered	<= 0.755			(FASD) is	
			Purge Long Term Fuel				typically enabled	
		Test decision cannot be made when	rim metric				during 90 % of the EPAIII drive	
		Purge is enabled.					cycle. This is also	
		The Intrusive test is	AND				typical of real-	
		described below:	The filtered Non-Purge	<= 0.750			world driving,	
			Long Term Fuel Trim				however values	
			metric				will vary (higher	
			AND				or lower) based	
			The filtered Short Term	<= 2.000 for			on the actual	

Component/	Fault		Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Fuel Trim metric (cal >	2 out of 3 intrusive			conditions	
			1.05 indicates cal-out)	segments			present during	
							the drive cycle.	
		Intrusive Test:	Segment Def'n:		1			
		When the filtered	Segments can last up to					
			60 seconds and are					
			separated by the lesser of					
			20 seconds of purge-on					
			time or enough time to					
			purge 36 grams of vapor.					
		purge vapor is the	, , , , , , , , , , , , , , , , , , ,					
			A maximum of 3					
			completed segments or					
			20 attempts are allowed					
		Long Term Fuel Trim	for each intrusive test.					
		metric > 0.755, the						
		test passes without	After an intrusive test					
		checking the filtered						
			another intrusive test					
			cannot occur for 100					
		metric.	seconds to allow					
			sufficient time to purge					
			excess vapors from the					
			canister. During this					
			period, fuel trim will pass					
			if the filtered Purge-on					
			Long Term fuel trim >					
			Purge Rich Limit Table for					
			at least 150 seconds,					
			indicating that the					
			canister has been					
			purged.					

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Injector 1	P0201	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control ciruit do not match		Powertrain Relay Voltage within range and stable according to Enable Conditions Engine Running	11 volts ≤ Voltage ≤ 32 volts greater than 1 seconds	20 failures out of 25 samples 250 ms /sample Continuous	2 trips Type B
Injector 2	P0202	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control ciruit do not match		Powertrain Relay Voltage within range and stable according to Enable Conditions Engine Running	11 volts ≤ Voltage ≤ 32 volts greater than 1 seconds	20 failures out of 25 samples 250 ms /sample Continuous	2 trips Type B
Injector 3	P0203	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control ciruit do not match		Powertrain Relay Voltage within range and stable according to Enable Conditions Engine Running	11 volts ≤ Voltage ≤ 32 volts greater than 1 seconds	20 failures out of 25 samples 250 ms /sample Continuous	2 trips Type B
Injector 4	P0204	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control ciruit do not match		Powertrain Relay Voltage within range and stable according to Enable Conditions Engine Running	11 volts ≤ Voltage ≤ 32 volts greater than 1 seconds	20 failures out of 25 samples 250 ms /sample Continuous	2 trips Type B
TPS2 Circuit Low	P0222	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage <	0.25		Run/Crank voltage or Powertrain relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	79/159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	1
						No 5V reference error or fault for # 4 5V reference circuit (P06A3)		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
TPS2 Circuit High	P0223	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage >	4.59		relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	79/159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	1
						No 5V reference error or fault for # 4 5V reference circuit (P06A3)		
Turbo Charger Engine Overboost	P0234	Detect Negative Boost Pressure Control Deviation	Desired Boost Pressure - Actual Boost Pressure	(KtBSTD_p_CntrlDev NegLim - KtBSTD_p_CntrlDev AmbAirCorr) See Tables in Supporting Tables Sheet	Diagnosis Enabled Engine Speed Engine Speed Desired Boost Pressure Desired Boost Pressure Desired Boost Pressure Derivative Desired Boost Pressure Derivative Ambient Pressure Ambient Pressure Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Wait for steady state: No Active DTCs:	Disabled > 2450 rpm < 6000 rpm > 135.0 kPa < 220.0 kPa < 220.0 kPa/s > -70.0 kPa/s > 60.0 kPa < 120.0 kPa < 120.0 kPa > -40.0 Deg C < 120.0 Deg C > -40.0 Deg C required stabilization time as a function of engine speed, see KtBSTD_t_CntrlDevEnblDelay in Supporting Tables Sheet Desired Boost Pressure > Basic Pressure AmbientAirDefault_Snsr BSTR_b_PCA_CktFA BSTR_b_TurboBypassCktFA	20 failures out of 20 samples 1 sample every 100ms	Type B 2 trips

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
						BSTR_b_ExcsvBstTFTKO BSTR_b_PCA_CktTFTKO TC_BoostPresSnsrFA AnyCamPhaser_FA BSTR_b_PresCntrlTooLoTFTKO BSTR_b_PresCntrlTooHiTFTKO EnginePowerLimited		
					No Active DVCs:	BSTR_b_DVC_PCA_DC_Actv BSTR_b_DVC_PCA_PstnActv BSTR_b_DVC_TurboComprBypA ctv		
Turbocharger	P0236	Determines if the	See table "Turbocharger		Engine Speed	>= 400 RPM	Continuous	Type B
Boost Pressure (TIAP) Sensor Performance		(TIAP) Pressure	Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC.		Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	<= 6000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 100 Deg C	Calculation are performed every 12.5 msec	2 trips
			MAF model fails when			>= 0.50		
			ABS(Measured Flow – Modeled Air Flow) Filtered	> 16 grams/sec		Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor Based on MAF Est		
			MAP1 model fails when					
			ABS(Measured MAP – MAP Model 1) Filtered	> 20.0 kPa		MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM		
			MAP2 model fails when					
			ABS(Measured MAP – MAP Model 2) Filtered	> 25.0 kPa		MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
ystem	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			MAP3 model fails when			MAP Model 3 Error multiplied by		
			ABS(Measured MAP –			MAP Residual Weight Factor		
			MAP Model 3) Filtered			based on RPM		
				> 25.0 kPa				
			TIAP1 model fails when			TIAP Model 1 Error multiplied by TIAP Residual Weight Factor		
			ABS(Measured TIAP – TIAP Model 1) Filtered			based on RPM		
				> 25.0 kPa				
			TPS model fails when			Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM		
			Filtered Throttle Model Error	> 250 kPa*(g/s)				
				(9.5)		See table "IFRD Residual		
			TIAP Correlation model fails when			Weighting Factors".		
			High Engine Air Flow is TRUE AND		No Active DTCs:	MAP_SensorCircuitFA EGRValve_FP		
			Measured TIAP - measured MAP - offset as a function of engine			EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA		
			speed	> 25.0 kPa		ECT_Sensor_FA		
			See table "TIAP-MAP	20.0 Ki d		ECT_Sensor_Ckt_FP		
			Correlation Offset"			IAT_SensorFA		
						IAT_SensorCircuitFP		
			OR			IAT2_SensorFA		
			Low Engine Air Flow is			IAT2_SensorCircuitFP		
			TRUE AND			TC_BoostPresSnsrCktFA		
			Measured TIAP -			 AmbientAirDefault		
			measured Baro - offset as a function of engine speed					
				> 25.0 kPa				
			See table "TIAP-Baro Correlation Offset"					

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			TIAP Correlation is valid					
			when					
			High Engine Air Flow has					
			been TRUE for a period					
			of time					
				> 2.0 seconds				
			OR					
			High Engine Air Flow has					
			been TRUE for a period					
			of time					
				> 2.0 seconds				
				≥ ∠.u seconds				
			High Engine Air Flouris					
			High Engine Air Flow is TRUE when					
			The whole					
			Mass Air Flow					
				> a threshold in				
				gm/sec as a function				
				of engine speed				
				See table "TIAP-MAP				
				Correlation Min Air				
				Flow"				
			AND					
			Manifold Pressure					
				> a threshold in kPa				
				as a function of				
				engine speed				
				See table "TIAP-MAP				
				Correlation Min MAP"				

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			AND					
			Filtered Mass Air Flow -					
			Mass Air Flow					
				< 2.0 gm/sec				
			Low Engine Air Flow is					
			TRUE when					
1			Mass Air Flow					
			Widoo 7 tii 1 low					
1				< a threshold in				
İ				gm/sec as a function				
				of engine speed				
				les engine speed				
				See table "TIAP-Baro				
				Correlation Max Air				
				Flow"				
			AND					
			Manifold Pressure					
1								
				< a threshold in kPa				
				as a function of engine speed				
				engine speed				
				See table "TIAP-Baro				
				Correlation Max	'			
				MAP"				
			AND	177				
			Mass Air Flow - Filtered					
			Mass Air Flow - Fillered					
			11.000 / 11 / 1000					
i				< 2.0 gm/sec				

Component/	Fault		Malfunction	Threshold	Secondary	Enable		MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Engine Not Rotating Case: Turbocharger Boost Pressure OR Turbocharger Bosst Pressure	< 50.0 kPa > 115.0 kPa	Time between current ignition cycle and the last time the engine was running		4 failures out of 5 samples 1 sample every 12.5 msec	
						> 10.0 seconds		
					Engine is not rotating			
					No Active DTCs:	EngModeNotRunTmErr MAP_SensorFA TC_BoostPresSnsrCktFA AAP2 SnsrFA		
					No Pending DTCs:	MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP		
Turbocharger Boost Pressure Sensor Circuit Low	P0237	Detects a continuous short to low or open in either the signal circuit or the turbocharger boost pressure sensor.	Turbocharger Boost Pressure Voltage	< 20.0 % of 5 Volt Range (This is equal to 1.00 Volts, or 328.1 kPa)	Engine Run Time		80 failures out of 100 samples 1 sample every 12.5 msec	Type B 2 trips
Turbocharger Boost Pressure Sensor Circuit High	P0238	Detects an open sensor ground or continuous short to high in either the signal circuit or the turbocharger boost pressure sensor.	Turbocharger Boost Pressure Voltage	> 93.0 % of 5 Volt Range (This is equal to 4.65 Volts, or 323.5 kPa)	Engine Run Time	> 0.00 seconds	80 failures out of 100 samples 1 sample every 12.5 msec	Type B 2 trips

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Turbocharger Wastegate Boost Solenoid A Control Circuit	P0243	Detect Turbocharger Boost Solenoid - Open Circuit	ECM detects that commanded and actual states of output driver do not match because the output is open circuit		Diagnosis Enabled Powertrain relay Voltage Ignition run crank voltage Engine is not cranking	Disabled >= 11.00 Volts >= 6.00 Volts	10 failures out of 20 samples 1 sample every 100ms	Type B 2 trips
Turbocharger Wastegate Boost Solenoid A Control Circuit Low	P0245	Detect Turbocharger Boost Solenoid - Shorted to ground	ECM detects that commanded and actual states of output driver do not match because the output is shorted to ground		Diagnosis Enabled Powertrain relay Voltage Ignition run crank voltage Engine is not cranking	Disabled >= 11.00 Volts >= 6.00 Volts	10 failures out of 20 samples 1 sample every 100ms	Type B 2 trips
Turbocharger Wastegate Boost Solenoid A Control Circuit High	P0246	Detect Turbocharger Boost Solenoid - Shorted to Power	ECM detects that commanded and actual states of output driver do not match because the output is shorted to power		Diagnosis Enabled Powertrain relay Voltage Ignition run crank voltage Engine is not cranking	Disabled >= 11.00 Volts >= 6.00 Volts	10 failures out of 20 samples 1 sample every 100ms	Type B 2 trips
Turbo Charger Engine Underboost	P0299	Detect Positive Boost Pressure Control Deviation	Desired Boost Pressure - Actual Boost Pressure	AmbAirCorr) See Tables in Supporting Tables Sheet	Engine Speed Desired Boost Pressure Desired Boost Pressure Desired Boost Pressure Derivative Desired Boost Pressure Derivative Ambient Pressure Ambient Pressure Coolant Temp Coolant Temp	Disabled > 2450 rpm < 6000 rpm > 135.0 kPa < 220.0 kPa > -70.0 kPa/s < 55.0 kPa/s < 60.0 kPa < 120.0 kPa > -40.0 Deg C < 120.0 Deg C < 80.0 Deg C	25 failures out of 25 samples 1 sample every 100ms	Type B 2 trips

ECM SECTION Page 56 of 215

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					Wait for steady state: No Active DTCs:	required stabilization time as a function of engine speed, see KtBSTD_t_CntrlDevEnblDelay in Supporting Tables Sheet Desired Boost Pressure > Basic Pressure AmbientAirDefault_Snsr		
						BSTR_b_PCA_CktFA BSTR_b_TurboBypassCktFA ECT_Sensor_FA IAT_SensorFA BSTR_b_ExcsvBstTFTKO BSTR_b_PCA_CktTFTKO TC_BoostPresSnsrFA AnyCamPhaser_FA BSTR_b_PresCntrlTooLoTFTKO		
					No Active DVCs:	BSTR_b_PresCntrlTooHiTFTKO EnginePowerLimited BSTR_b_DVC_PCA_DC_Actv BSTR_b_DVC_PCA_PstnActv BSTR_b_DVC_TurboComprBypA ctv		
Random Misfire Detected	P0300	These DTC's will determine if a random or a cylinder	Deceleration index vs. Engine Speed Vs Engine load	(>Idle SCD AND > Idle SCD ddt Tables)	Engine Run Time ECT	> 2 crankshaft revolutions -7°C < ECT < 125°C	Emission Exceedence = any (5) failed 200	2 Trips Type B
Cylinder 1 Misfire Detected	P0301	specific misfire is occurring by monitoring	Deceleration index calculation is tailored to	OR (>SCD Delta AND > SCD Delta ddt	If ECT at startup	.=	rev blocks out of (16) 200 rev block tests	(Mil Flashes with
Cylinder 2 Misfire Detected	P0302	crankshaft velocity	specific veh. Tables used are 1st tables encountered that are not				Failure reported for (1)	Catalyst Damagin g Misfire)
Cylinder 3 Misfire Detected	P0303		max of range. Undetectable region at a given speed/load point is	> Idle Cyl Mode ddt Tables) OR	then ECT	21°C < ECT < 125°C	Exceedence in 1st (16) 200 rev block tests, or (4)	
Cylinder 4 Misfire Detected	P0304		where all tables are max of range point. see Algorithm Description Document for additional details.	(>Cyl Mode AND > Cyl Mode ddt Tables) OR (>Rev Mode Table) OR	+ Throttle delta - Throttle delta	9.00 < volts < 32.00 < 95.00% per 25 ms < 95.00% per 25 ms	Exceedences thereafter.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL illum.
				(> AFM Table in Cyl Deact mode)				
			Misfire Percent Emission Failure Threshold	≥ 3.00% P0300 ≥ 3.00% emission				
			Misfire Percent Catalyst Damage	> "Catalyst Damaging Misfire Percentage" Table whenever secondary conditions are met.	Engine Speed Engine Load Misfire counts (at low speed/loads, one cylinder may not cause cat damage)	> 1000 rpm AND > 25 % load AND < 180 counts on one cylinder	any Catalyst Exceedence = (1) 200 rev block as data supports for catalyst damage. Failure reported with (1 or 3) Exceedences in FTP, or (1) Exceedence outside FTP.	
			When engine speed and load are less than the FTP cals (3) catalyst damage exceedences are allowed.	≤ 0 FTP rpm AND ≤ 0 FTP % load			Continuous	

Code	Monitor Strategy Description	Criteria	l	Secondary		•	
		Ciliteria	Value	Parameters	Conditions	Required	illum.
				Engine Speed	500 < rpm < 6500 - 400	4 cycle delay	
					Engine speed limit is a function of inputs like Gear and temperature		
					Engine Speed Limit = 6500 rpm (Rev, Gears 1-6) Engine Speed Limit = 4000 rpm (P,N)		
			disable				
			conditions:	No active DTCs:	TPS_FA EnginePowerLimited MAF_SensorTFTKO MAP_SensorTFTKO IAT_SensorTFTKO ECT_Sensor_Ckt_TFTKO	4 cycle delay	
					5VoltReferenceB_FA		
					CrankSensorTestFailedTKO		
					CrankSensorFaultActive		
					CrankIntakeCamCorrelationFA		
					CrankExhaustCamCorrelationFA		
					CrankCamCorrelationTFTKO		
					AnyCamPhaser_FA		
					AnyCamPhaser_TFTKO		
					If Monitor Rough Road=1 and RoughRoadSource="TOSS"		
					Transmission Output Shaft Angular Velocity Validity (Auto Trans only) Clutch Sensor FA (Manual Trans only)		
						Engine Speed Limit = 6500 rpm (Rev, Gears 1-6) Engine Speed Limit = 4000 rpm (P,N) disable conditions: No active DTCs: TPS_FA EnginePowerLimited MAF_SensorTFTKO MAP_SensorTFTKO IAT_SensorTFTKO ECT_Sensor_Ckt_TFTKO 5VoltReferenceB_FA CrankSensorFaultActive CrankIntakeCamCorrelationFA CrankCamCorrelationFA CrankCamCorrelationFA CrankCamCorrelationFA CrankCamCorrelationFA CrankCamCorrelationFA CrankCamCorrelationFA Transmission Output Shaft Angular Velocity Validity (Auto Trans only) Clutch Sensor FA (Manual Trans	Engine Speed Limit = 6500 rpm (Rev, Gears 1-6) Engine Speed Limit = 4000 rpm (P,N) disable conditions: No active DTCs: TPS_FA EnginePowerLimited EnginePowerLimited EnginePowerLimited MAF_SensorTFTKO MAP_SensorTFTKO MAP_SensorTFTKO IAT_SensorTFTKO SVoltReferenceB_FA CrankSensorTestFalledTKO CrankSensorTestFalledTKO CrankSensorTestFalledTKO CrankSensorTestFalledTKO CrankSensorTestFalledTKO CrankSensorTestFalledTKO CrankSensorTestFalledTKO CrankSensorTestFalledTKO CrankCamCorrelationFA CrankCamCorrelationFTFKO AnyCamPhaser_FA AnyCamPhaser_FA AnyCamPhaser_TFTKO If Monitor Rough Road=1 and RoughRoadSource="TOSS" Transmission Output Shaft Angular Velocity Validity (Auto Trans only) Clutch Sensor FA (Manual Trans only) Clutch Sensor FA (Manual Trans only) Clutch Sensor FA (Manual Trans only)

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					P0315 & engine	> 1000 rpm		
					speed			
					Fuel Level Low	LowFuelConditionDiagnostic	500 cycle delay	
					Cam and Crank	in sync with each other	4 cycle delay	
					Sensors		l systematical	
					Misfire requests TCC	Not honored because	4 cycle delay	
					unlock	Transmission in hot mode or		
						POPD intrusive diagnostic		
						running		
					Fuel System Status	≠ Fuel Cut	4 cycle delay	
					Active Fuel	Transition in progress	7 cycle delay	
					Management		'	
					Undetectable engine	invalid speed load range in decel	4 cycle delay	
					speed and engine	index tables		
					load region			
						> 8192 rpm	0 cycle delay	
					Speed			
					Below zero torque	< "Zero torque engine load" in	4 cycle delay	
					(except CARB	Supporting Tables tab		
					approved 3000 rpm to			
					redline triangle.)			
					Below zero torque:		4 cycle delay	
					TPS	≤ 1%		
					Veh Speed	> 30 mph		
					EGR Intrusive test	Active	12 cycle delay	
					Manual Trans	Clutch shift	4 cycle delay	
					Throttle Position	> 95.00%	7 cycle delay	
					AND Automatic			
					transmission shift			
					Driveline Ring Filter			
					active			
					After a low level			
					misfire, another			
					misfire may not be detectable until			
					driveline ringing			1
					ceases. If no ringing			
					seen, stop filter early.			
					Section, stop interesting.			
	1	1	ī	1		1	I	1

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					Filter Driveline ring:			
					Stop filter early:	 "Ring Filter" in Supporting Tables tab engine cycles after misfire "Number of Normals" in Supporting Tables tab engine cycles after misfire 		
					Abnormal engine speed oscillations: (Rough road etc) Off Idle, number of consecutive decelerating cylinders after accelerating,: (Number of decels can vary with misfire detection equation) TPS Engine Speed Veh Speed SCD Cyl Mode Rev Mode	> 1 % > 1000 rpm		
						> 3 mph > SCD Mode > Cylinder Mode > Rev Mode in Supporting Tables tab		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					Misfire Pattern Recognition Enabled: Validates misfire vs. false detection	1 (1 = Enabled)		
					Engine Speed			
					Veh Speed Final crank oscillations within:	Between > 630 RPM and < 6100 RPM > 5 kph > "min multiplier" or < "max multiplier" in Supporting Tables tab of misfire threshold for a given engine speed and load		
					Rough Road Section: Monitor Rough Road RoughRoadSource IF Rough Road is monitored, then ONE of the following Rough Road Sources will be used:	0 (1=Yes) TOSS		
					Rough Road Source = "TOSS" Rough Road			

Rough Road Source = "WheelSpeedInECM" ABS/TCS system RoughRoad vSES detected active Rough Road Source = "FromABS" ABS/TCS system RoughRoad active Rough Road Source = "FromABS" ABS/TCS system RoughRoad active Crankshaft Position P0315 Monitor for valid Sum of Compensation ≥ 2.0040 OBD Manufacturer 0 0.50 seconds 1 Tri	Component/	Fault		Malfunction				Time	MIL
"WheelSpeedInECM" ABS/TCS system RoughRoad VSES ABS/TCS system Rough Road Source = "FromABS" ABS/TCS system RoughRoad active VSES detected active VSES detected active VSES Trankshaft Position System Variation Volt Learned ABS/TCS system RoughRoad active VSES Trankshaft Position RoughRoad active VSES Trankshaft Position RoughRoad active VSES Trankshaft Position RoughRoad Source = "FromABS" ABS/TCS system RoughRoad active VSES Trankshaft Position RoughRoad Source = "FromABS" ABS/TCS system RoughRoad active VSES Trankshaft Position RoughRoad Source = "FromABS" ABS/TCS system RoughRoad active VSES Trankshaft Position RoughRoad Source = "FromABS" ABS/TCS system RoughRoad active VSES Trankshaft Position RoughRoad active Trankshaft Position Trankshaft Position RoughRoad Source = "FromABS" ABS/TCS system RoughRoad active VSES Trankshaft Position RoughRoad Source = "FromABS" ABS/TCS system RoughRoad Source = "FromABS" ABS/TCS system RoughRoad active VSES Trankshaft Position RoughRoad Source = "FromABS" ABS/TCS system RoughRoad Source = "FromABS" ABS/TCS system RoughRoad active VSES Trankshaft Position RoughRoad Source = "FromABS" ABS/TCS system RoughRoad Source = "FromABS" ABS/TCS system RoughRoad Source = "FromABS" ABS/TCS system RoughRoad active VSES Trankshaft Position RoughRoad Source = "FromABS" ABS/TCS system RoughRoad Source = "FromABS" ABS/TCS s	System	Code	Description	Criteria	Value			Required	illum.
ABS/TCS system RoughRoad VSES Rough Road Source = "FromABS" ABS/TCS system RoughRoad active RoughRoad Source = "FromABS" ABS/TCS system RoughRoad active VSES detected active VSES detected active System RoughRoad active VSES detected active Frequency Frequency Frequency Frequency Frequency Continuous						Rough Road Source =			
RoughRoad active Rough Road Source = "FromABS" ABS/TCS system RoughRoad active VSES ABS/TCS system RoughRoad active VSES ABS/TCS system RoughRoad active VSES ABS/TCS system RoughRoad active FromABS" ABS/TCS system RoughRoad active ABS/TCS system RoughRoad active FromABS" ABS/TCS system RoughRoad active VSES ABS/TCS system RoughRoad active FromABS" ABS/TCS system RoughRoad active Type Crankshaft Position Frequency Enable Counter Frequency Continuous						"WheelSpeedInECM"			
RoughRoad active Rough Road Source = "FromABS" ABS/TCS system RoughRoad active VSES ABS/TCS system RoughRoad active VSES ABS/TCS system RoughRoad active VSES ABS/TCS system RoughRoad active FromABS" ABS/TCS system RoughRoad active ABS/TCS system RoughRoad active FromABS" ABS/TCS system RoughRoad active VSES ABS/TCS system RoughRoad active FromABS" ABS/TCS system RoughRoad active Type Crankshaft Position Frequency Enable Counter Frequency Continuous						ADC/TCC avatam			
Crankshaft Position System Variation Not Learned P0315 Monitor for valid crankshaft error compensation factors Sum of Compensation factors P15 P25						ABS/TCS System			
Crankshaft Position System Variation Not Learned P0315 Monitor for valid crankshaft error compensation factors Sum of Compensation factors P15 P25						RoughRoad			
Rough Road Source = "FromABS" ABS/TCS system RoughRoad active VSES detected active Crankshaft Position Pystem Variation Not Learned P0315 Monitor for valid crankshaft error compensation factors System Variation Not Learned P0315 Monitor for valid crankshaft error compensation factors Sum of Compensation OR ≤ 1.9960 Enable Counter P1707 Prequency Continuous							active		
Rough Road Source = "FromABS" ABS/TCS system RoughRoad VSES detected active Crankshaft Position System Variation Not Learned Not Learned Rough Road Source = "FromABS" ABS/TCS system RoughRoad VSES detected active OBD Manufacturer OR ≤ 1.9960 Enable Counter Enable Counter Frequency Continuous Frequency					VSES				
Rough Road Source = "FromABS" ABS/TCS system RoughRoad active VSES detected active Crankshaft Position System Variation Not Learned P0315 Monitor for valid crankshaft error compensation factors Sum of Compensation factors P0315 OR ≤ 1.9960 P1315 Rough Road Source = "FromABS" ABS/TCS system RoughRoad active VSES detected active 0 0 0.50 seconds 1 Tri Type Frequency Continuous							detected		
Rough Road Source = "FromABS" ABS/TCS system RoughRoad active VSES detected active Crankshaft Position System Variation Not Learned P0315 Monitor for valid crankshaft error compensation factors Sum of Compensation factors P0315 OR ≤ 1.9960 P1315 Rough Road Source = "FromABS" ABS/TCS system RoughRoad active VSES detected active 0 0 0.50 seconds 1 Tri Type Frequency Continuous							active		
Trankshaft Position System Variation Not Learned P0315 Monitor for valid crankshaft error compensation factors P0315 Sum of Compensation factors P0315 Sum of Compensation factors P0315 Sum of Compensation factors P0316 Sum of Compensation factors P0317 OR ≤ 1.9960 Enable Counter Prequency Continuous							active		
Trankshaft Position System Variation Not Learned P0315 Monitor for valid crankshaft error compensation factors P0315 Sum of Compensation factors P0315 Sum of Compensation factors P0315 Sum of Compensation factors P0316 Sum of Compensation factors P0317 OR ≤ 1.9960 Enable Counter Prequency Continuous						D. I. D. I.O.			
ABS/TCS system RoughRoad active VSES detected active Crankshaft Position System Variation Not Learned P0315 Monitor for valid crankshaft error compensation factors ABS/TCS system RoughRoad active OBD Manufacturer Frequency Continuous OR ≤ 1.9960 Enable Counter Frequency Continuous						Rough Road Source =			
RoughRoad active VSES detected active Crankshaft Position P0315 System Variation Not Learned Not Learned RoughRoad active OBD Manufacturer Enable Counter OR ≤ 1.9960 Enable Counter Frequency Continuous						FIUITADS			
RoughRoad active VSES detected active Crankshaft Position P0315 System Variation Not Learned Not Learned RoughRoad active OBD Manufacturer Enable Counter OR ≤ 1.9960 Enable Counter Frequency Continuous						ABS/TCS system			
VSES detected active Crankshaft Position System Variation Not Learned P0315 Monitor for valid crankshaft error compensation factors Sum of Compensation factors P0315 Monitor for valid crankshaft error factors OR ≤ 1.9960 Enable Counter Prequency Continuous									
Crankshaft Position System Variation Not Learned Crankshaft Position Frequency Continuous Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid cranksh						RoughRoad	active		
Crankshaft Position System Variation Not Learned Crankshaft Position Frequency Continuous Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft Position P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid crankshaft error compensation factors Crankshaft P0315 Monitor for valid cranksh						VCEC	datastad		
Crankshaft Position System Variation Not Learned P0315 Monitor for valid crankshaft error compensation factors Sum of Compensation factors OR ≤ 1.9960 Enable Counter OR Sum of Compensation factors OR ≤ 1.9960 Frequency Continuous						VSES	detected		
Crankshaft Position System Variation Not Learned P0315 Monitor for valid crankshaft error compensation factors Sum of Compensation factors OR ≤ 1.9960 Enable Counter OR Sum of Compensation factors OR ≤ 1.9960 Frequency Continuous							active		
System Variation Not Learned crankshaft error compensation factors Frequency factors System Variation Not Learned compensation factors System Variation Not Learned Compensation factors System Variation Frequency Continuous System Variation Frequency Continuous System Variation Not Learned Not Learned N									
System Variation Not Learned crankshaft error compensation factors Frequency factors System Variation Not Learned compensation factors System Variation Not Learned Compensation factors System Variation Frequency Continuous System Variation Frequency Continuous System Variation Not Learned Not Learned N									
System Variation Not Learned crankshaft error compensation factors Frequency factors System Variation Not Learned compensation factors System Variation Not Learned Compensation factors System Variation Frequency Continuous System Variation Frequency Continuous System Variation Not Learned Not Learned N									
System Variation Not Learned crankshaft error compensation factors Frequency factors System Variation Not Learned compensation factors System Variation Not Learned Compensation factors System Variation Frequency Continuous System Variation Frequency Continuous System Variation Not Learned Not Learned N									
System Variation Not Learned crankshaft error compensation factors Frequency factors System Variation Not Learned compensation factors System Variation Not Learned Compensation factors System Variation Frequency Continuous System Variation Frequency Continuous System Variation Not Learned Not Learned N									
System Variation Not Learned crankshaft error compensation factors Frequency factors System Variation Not Learned compensation factors System Variation Not Learned Compensation factors System Variation Frequency Continuous System Variation Frequency Continuous System Variation Not Learned Not Learned N									
System Variation Not Learned crankshaft error compensation factors Frequency factors System Variation Not Learned compensation factors System Variation Not Learned Compensation factors System Variation Frequency Continuous System Variation Frequency Continuous System Variation Not Learned Not Learned N									
System Variation Not Learned crankshaft error compensation factors Frequency factors System Variation Not Learned compensation factors System Variation Not Learned Compensation factors System Variation Frequency Continuous System Variation Frequency Continuous System Variation Not Learned Not Learned N	Crankshaft Position	P0315	Monitor for valid	Sum of Compensation	≥ 2.0040	OBD Manufacturer	0	0.50 seconds	1 Trips
factors	System Variation		crankshaft error						Type A
	Not Learned					1			
100 msec			factors						
								100 msec	

Component/	Fault		Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Knock Sensor (KS) Performance Per	P0324	This diagnostic checks for knock	Common Enable Criteria		Diagnostic Enabled?	Disabled	First Order Lag Filter with Weight	
Cylinder		sensor performance					Coefficient	Trips: 2
		out of the normal			Engine Speed	≤ 8500 RPM		
		expected range due to:			Engine Air Flow	≥ 40 mg/cylinder and ≤ 2000 mg/cylinder		
		1) Excessive knock			ECT	≥ -40 deg's C		
		and			IAT	≥ -40 deg's C		
		2) Abnormal engine						
	cylinder basis	noise on a per cylinder basis	Specific Enable Criteria and Thresholds					
			Filtered Knock Intensity	> 0.6150	Engine Speed	≥ 1000 RPM	Weight	1
		(for Excessive Knock)		Engine running	≥ 0.8 seconds	Coefficient = 0.0400		
		VaKNKD_k_PerfCylKnoc kIntFilt				Updated each engine event		
							ongine event	
			2. Filtered FFT Intensity:	< Abnormal Noise	Engine Speed	≥ 8500 RPM	Weight	
			(for Abnormal Noise)	Threshold (see	Engine running	≥ 0.4 seconds	Coefficient =	
				supporting tables)			0.0100	
			VaKNKD_k_PerfCylAbnFi					
			ItIntnsity					
							Updated each	
							engine event	
Knock Sensor (KS)	P0325	This diagnostic	Filtered FFT Output	> OpenCktThrshMin	Diagnostic Enabled?	Enabled	First Order Lag	Type: B
Circuit Bank 1 ` ´		checks for an open	(VaKNKD k OpenFiltInte				Filter with Weight	
		in the knock sensor	nsity[0])	< OpenCktThrshMax			Coefficient	Trips: 2
		circuit	,,,,,	· .	Engine Speed	≥ 600 RPM and		·
						≤ 8500 RPM		
				See Supporting	Engine Air Flow	≥ 40 mg/cylinder and		
				Tables for		≤ 2000 mg/cylinder	Weight	1
				OpenCktThrshMin &	ECT	≥ -40 deg's C	Coefficient =	
				Max	IAT	≥ -40 deg's C	0.0100	
					Engine running	≥ 5.0 seconds		
						Updated each engine event		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable		MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Knock Sensor (KS)	P0326	This diagnostic	Common Enable Criteria		Diagnostic Enabled?	Enabled	First Order Lag	Type: B
Performance Bank		checks for knock					Filter with Weight	
1		sensor performance					Coefficient	Trips: 2
		out of the normal			Engine Speed	≤ 8500 RPM		
		expected range due to 1. Excessive			Engine Air Flow	≥ 40 mg/cylinder and		
		knock or 2.			FOT	≤ 2000 mg/cylinder		
		Abnormal engine			ECT IAT	≥ -40 deg's C		
		noise on a per			IAI	≥ -40 deg's C		
		bank/sensor basis	Filtered Knock Intensity	> 0.6150	Engine Speed	≥ 1000 RPM	Weight	-
			(for Excessive Knock)	0.0150	Engine Speed Engine running	≥ 3.0 seconds	Coefficient =	
			VaKNKD_k_PerfKnockInt		Engine running	2 3.0 Seconds	0.0100	
			Filt				0.0100	
							Updated each	
							engine event	
							1	
			2. Filtered FFT Intensity:	< Abnormal Noise	Engine Speed	≥ 3500 RPM	Weight	1
			(for Abnormal Noise)	Threshold (see	Engine running	≥ 0.9 seconds	Coefficient =	
			VaKNKD_k_PerfAbnFiltIn	supporting tables)			0.0100	
			tnsity					
							Updated each	
Knock Sensor (KS)	P0327	This diagnostic	Sensor Input Signal Line	< 0.57 Volts	Diagnostic Enabled?	Enabled	50 Failures out of	
Circuit Low Bank 1		checks for an out of					63 Samples	MIL: YES
		range low knock						Trips:
		sensor signal			Engine Speed	> 0 RPM and	100	2
			or			< 8500 RPM	100 msec rate	
			Sensor Return Signal	< 0.40 Volts				
			Line					
					_			
Knock Sensor (KS)	P0328	This diagnostic	Sensor Input Signal Line	> 2.76 Volts	Diagnostic Enabled?	Enabled	50 Failures out of	Type: B
Circuit High Bank 1	F0320	checks for an out of	Serisor input Signal Line	2.70 VOILS	Diagnostic Enabled:	Lilabled		MIL: YES
Circuit riigir barik r		range high knock					00 Gampies	Trips:
		sensor signal			Engine Speed	> 0 RPM and		2
ser		or			< 8500 RPM	100 msec rate		
			Sensor Return Signal	> 1.95 Volts				
			Line					
					1			
		-	•	•	•	•	- '	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Crankshaft Position (CKP) Sensor A Circuit	P0335	Determines if a fault exists with the crank position sensor signal			Engine-Cranking Crankshaft Test:			Type B 2 trips
		Signal	Time since last crankshaft position sensor pulse received	>= 4.0 seconds	AND DTC P0102 AND DTC P0103 AND	= FALSE = FALSE = FALSE > 3.0 grams/second))	Continuous every 100 msec	
		Time-Based Crankshaft Test: No crankshaft pulses received	>= 0.1 seconds	Time-Based Crankshaft Test: Engine is Running Starter is not engaged		Time-Based Crankshaft Test: Continuous every 12.5 msec		
		Event-Based Crankshaft Test: No crankshaft pulses received		No DTC Active: Event-Based Crankshaft Test: Engine is Running OR Starter is engaged	5VoltReferenceB_FA	Event-Based Crankshaft Test: 2 failures out of 10 samples		
				No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA P0365 P0366	One sample per engine revolution		

Component/	Fault	0,5		Threshold	Secondary	Enable		MIL
System	Code	Description	•	Value	Parameters	Conditions		illum.
Crankshaft Position (CKP) Sensor A Performance	P0336	Determines if a performance fault exists with the crank position sensor signal	Crank Re-synchronization Test: Time in which 10 or more crank re-synchronizations occur Time-Based Crankshaft Test: No crankshaft synchronization gap found		Crank Re- synchronization Test: Engine Air Flow Cam-based engine speed No DTC Active: Time-Based Crankshaft Test: Engine is Running Starter is not engaged	>= 3.0 grams/second > 450 RPM 5VoltReferenceB_FA P0335	Crank Re-	Type B 2 trips
			Engine Start Test during Crank: Time since starter engaged without detecting crankshaft synchronization gap		No DTC Active: Engine Start Test during Crank: Starter engaged	5VoltReferenceB_FA	Engine Start Test during Crank: Continuous every 100 msec	
					AND (cam pulses being received			
			>= 1.5 seconds	OR (DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow	= FALSE = FALSE = FALSE > 3.0 grams/second))			

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Event-Based Crankshaft Test: Crank Pulses received in one engine revolution OR Crank Pulses received in one engine revolution	< 51 > 65	Event-Based Crankshaft Test: Engine is Running OR Starter is engaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA P0365 P0366	Event-Based Crankshaft Test: 8 failures out of 10 samples One sample per engine revolution	
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor A	P0340	Determines if a fault exists with the cam position bank 1 sensor A signal	Engine Cranking Camshaft Test: Time since last camshaft position sensor pulse received OR Time that starter has been engaged without a camshaft sensor pulse	>= 5.5 seconds >= 4.0 seconds	Engine Cranking Camshaft Test: Starter engaged AND (cam pulses being received OR (DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow	= FALSE = FALSE = FALSE > 3.0 grams/second))	Engine Cranking Camshaft Test: Continuous every 100 msec	Type B 2 trips
			Time-Based Camshaft Test: Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Time-Based Camshaft Test: Engine is Running Starter is not engaged No DTC Active:		Time-Based Camshaft Test: Continuous every 100 msec	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
		·	Fast Event-Based		Fast Event-Based		Fast Event-Based	
			Camshaft Test:		Camshaft Test:		Camshaft Test:	
			No camshaft pulses		Crankshaft is		Continuous every	
			received during first 12		synchronized		MEDRES event	
			MEDRES events		Starter must be engaged to enable the			
					diagnostic, but the			
,			(There are 12 MEDRES		diagnostic will not disable when the			
ļ			events per engine cycle)		starter is disengaged			
,								
					No DTC Active:	5VoltReferenceA FA		
ļ						5VoltReferenceB_FA		
ļ						CrankSensor_FA		
ļ			Slow Event-Based		Slow Event-Based		Slow Event-	
ļ			Camshaft Test:		Camshaft Test:		Based Camshaft	
							Test:	
			The number of camshaft		Crankshaft is		8 failures out of	
,			pulses received during		synchronized	E1/ HD (A EA	10 samples	
ļ			100 engine cycles	= 0		5VoltReferenceA_FA 5VoltReferenceB_FA	Continuous every	
ļ				ŭ		CrankSensor_FA	engine cycle	
	50011							
Camshaft Position (CMP) Sensor	P0341	Determines if a performance fault	Fast Event-Based Camshaft Test:		Fast Event-Based Camshaft Test:		Fast Event-Based Camshaft Test:	Type B 2 trips
Performance Bank		exists with the cam					<u> </u>	,00
1 Sensor A		position bank 1 sensor A signal	The number of camshaft		Crankshaft is			
ļ		_	pulses received during first 12 MEDRES events		synchronized		Continuous every MEDRES event	
ļ			is less than 4 or greater		Starter must be			
,			than 6		engaged to enable the diagnostic, but the			
					diagnostic will not			
			(There are 12 MEDRES		disable when the			
			events per engine cycle)		starter is disengaged			
1								

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA		
			Slow Event-Based Camshaft Test:		Slow Event-Based Camshaft Test:		Slow Event- Based Camshaft Test:	
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle	
IGNITION CONTROL #1	P0351	This diagnostic checks the circuit for	The ECM detects that the commanded state of the		Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples	MIL: YES
CIRCUIT		electrical integrity during operation. Monitors EST for Cylinder 1	driver and the actual state of the control circuit do not match.				100 msec rate	Trips: 2
IGNITION CONTROL #2 CIRCUIT	P0352		The ECM detects that the commanded state of the driver and the actual state of the control circuit do		Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type: B MIL: YES Trips: 2
		Monitors EST for Cylinder 2	not match.					

Component/	Fault	Monitor Strategy	Malfunction	Threshold		Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
IGNITION CONTROL #3 CIRCUIT	P0353	checks the circuit for	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type: B MIL: YES Trips: 2
IGNITION CONTROL #4 CIRCUIT	P0354		The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25Samples 100 msec rate	Type: B MIL: YES Trips: 2
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor B	P0365	position bank 1 sensor B signal	Engine Cranking Camshaft Test: Time since last camshaft position sensor pulse received OR Time that starter has been engaged without a camshaft sensor pulse Time-Based Camshaft Test:	>= 5.5 seconds >= 4.0 seconds	AND DTC P0102 AND DTC P0103 AND	= FALSE = FALSE = FALSE > 3.0 grams/second))	Engine Cranking Camshaft Test: Continuous every 100 msec Time-Based Camshaft Test:	Type B 2 trips

omponent/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
/stem	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Fewer than 4 camshaft		Engine is Running		Continuous every	
			pulses received in a time	> 2.0 accords	Ctartar is mat amazarad		100 msec	
				> 3.0 seconds	Starter is not engaged			
					No DTC Active:	5VoltReferenceA_FA		
			Fast Event-Based		Fast Event-Based		Fast Event-Based	
			Camshaft Test:		Camshaft Test:		Camshaft Test:	
			No camshaft pulses		Crankshaft is		Continuous every	
			received during first 12		synchronized		MEDRES event	
			MEDRES events		Starter must be			
					engaged to enable the			
			(There are 40 MEDDEO		diagnostic, but the diagnostic will not			
			(There are 12 MEDRES events per engine cycle)		disable when the			
			events per engine cycle)		starter is disengaged			
					No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA		
			Slow Event-Based		Slow Event-Based		Slow Event-	
			Camshaft Test:		Camshaft Test:		Based Camshaft	
							Test:	
			The number of camshaft		Crankshaft is		8 failures out of	
			pulses received during		synchronized		10 samples	
			100 engine cycles		No DTC Active:	5VoltReferenceA_FA		
				= 0		5VoltReferenceB_FA	Continuous every	
						CrankSensor_FA	engine cycle	
						_		
	1							

Component/	Fault	Monitor Strategy	Malfunction	Threshold		Enable	Time	MIL
System	Code	Description	Criteria	Value		Conditions	Required	illum.
Camshaft Position	P0366	Determines if a	Fast Event-Based		Fast Event-Based		Fast Event-Based	
CMP) Sensor		performance fault	Camshaft Test:		Camshaft Test:		Camshaft Test:	2 trips
Performance Bank		exists with the cam						
I Sensor B		position bank 1	The number of camshaft		Crankshaft is			
		sensor B signal	pulses received during		synchronized		Continuous every	
			first 12 MEDRES events is less than 4 or greater		Starter must be		MEDRES event	
			than 6		engaged to enable the			
			than o		diagnostic, but the			
					diagnostic will not			
			(There are 12 MEDRES		disable when the			
			events per engine cycle)		starter is disengaged			
			overne per engine eyele)					
					No DTC Active:	5VoltReferenceA_FA		
						5VoltReferenceB_FA		
					CrankSensor_FA			
			Slow Event-Based		Slow Event-Based		Slow Event-	
			Camshaft Test:		Camshaft Test:		Based Camshaft	
							Test:	
			The number of camshaft		Crankshaft is		8 failures out of	
			pulses received during		synchronized		10 samples	
			100 engine cycles			5VoltReferenceA FA	To samples	
			l co ongino oyonoo	< 398	No BTO Active.	5VoltReferenceB FA	Continuous every	
			OR	> 402		CrankSensor_FA	engine cycle	
				**-				

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Catalyst System Low Efficiency Bank 1	P0420	Oxygen Storage	Normalized Ratio OSC Value (EWMA filtered)	< 0.100		Idle Period Criteria	1 test attempted per valid idle period	Type A 1 Trip(s)
		Cerium Oxide reactilean A/F excursions (I.e. Cerium Oxid	pat contains Cerium Oxide. ts with NO and O2 during to store the excess oxygen lation). During rich A/F		final accel pedal posi	e accel pedal. This checks that the ition (comprehending deadband and sis) is essentially zero.	per trip	
		H2 to release this s	Oxide reacts with CO and stored oxygen (I.e. Cerium			d < 1.24 MPH	Maximum of 8 tests per trip	
		Storage Capacity, o is to "measure" the C	referred to as the Oxygen r OSC. CatMon's strategy OSC of the catalyst through			d > 1100 RPM for a minimum of 5 seconds since end of last idle period.	Frequency: Fueling Related : 12.5 ms	
		Normalized Ratio Information 1. Raw OSC Calcul time - pre of 2. BestFailing OSC table (based on ter 3. WorstPassing O and exh Normalized Ratio of A Normalized Ratio a good part and	OSC Value Calculation and Definitions = ation = (post cat O2 Respect O2 Respect O2 Respect O2 Respect O3 Respect O4 Respect O5 Respe		Tests attempted thin tri The catalyst diagnorm Catalyst Idi General Valid Idi Green Converter	p postic has not yet completed for the current trip. Description of the c	OSC Measurements: 100 ms Temp Prediction: 1000ms	
		The Catalyst Monitoring Test is done during idle. Several conditions must be meet in order to execute this test. These conditions and their related values are listed in the secondary parameters area of this document.			Intrusive test(s Fueltrir Post O EVA EGI	ir -20 < ° C < 250): Not Active 2 P R e Not Active		
		ps.s	<u>I</u>			e > 10.90 Volts n NOT in Progress T 40 < ° C < 140		

Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
				Barometric Pressure	> 70 KPA		
				speed			
				Short Term Fuel Trim	0.80 < ST FT < 1.30		
				Predicted c	atalyst temp > 550 degC		
					AND		
				vvarmedupe	vents counter resets to 0.)		
				for at least 15 secon	ds with a closed throttle time < 60		
				seconds consecutiv	ely (closed throttle consideration		
				the Valid Idle	e Period Criteria Section) .		
				Alaa in andanta inana			
				1.0.0			
				Closed	loop fueling Enabled		
				Diagon and HOLes and	Loon Emphis Outtowick acceptance of		
				the "Supporti	ng Tables" tab for details.		
					PRNDL		
				is in Drive Range o	n an Auto Transmission vehicle		
1				13 III DIIVE Range 0	an an Auto Transmission vehicle.		
	Code	Code Description	Code Description Criteria	Code Description Criteria Value	Barometric Pressure Idle Time before going intrusive is Idle time is Incremented if Vehicle speed Short Term Fuel Trim Predicted of Engine Airflow > Min. (refer to "to (Based on en WarmedUpE) for at least 15 second seconds consecutive involves having the direct through the Very and the Valid (Based on en WarmedUpE) Also, in order to increase of counter must exceed speed must exceed must NOT be off the Idle Period Closed I Please see "Closed the "Supportite the "Suppo	Barometric Pressure 70 KPA Idle Time before going 50 Seconds intrusive is Idle time is 1.24 MPH and the drivers foot is Idle time is 4.1.24 MPH and the drivers foot is Incremented if Vehicle off accel pedal and the idle speed speed control system is active as Idle time is 4.1.24 MPH and the drivers foot is Idle time is 4.1.24 MPH and the drivers foot is Idle time is 4.1.24 MPH and the drivers foot is Idle time is 4.1.24 MPH and the drivers foot is Idle time is 4.1.24 MPH and the drivers foot is Idle time in the Valid Idle Period Criteria Section Increment the WarmedUpEvents counter resets to Idle time in the WarmedUpEvents counter (counter must sceed 15 cal value), either the vehicle Idle time in the Valid Idle Period Criteria Section Idle time in the Valid Idle Period Criteria Section Idle time in the Valid Idle Period Criteria Section Idle time in the Valid Idle Period Criteria Section Idle Time Interview Idle Time Interview Idle Time Interview Idle	Barometric Pressure > 70 KPA Idle Time before going < 50 Seconds intrusive is Idle time is < 1.24 MPH and the drivers foot is Incremented if Vehicle off accel pedal and the idle speed speed control system is active as identified in the Valid Idle Period Criteria section. Short Term Fuel Trim 0.80 < ST FT < 1.30 Predicted catalyst temp > 550 degC AND Engine Airflow > MinAirflowToWarmCatalyst table (g/s) ((refer to "Supporting Tables" tab) (Based on engine coolant at the time the WarmedUpEvents counter resets to 0.) for at least 15 seconds with a closed throttle time < 60 seconds consecutively (closed throttle consideration involves having the driver off the accel pedal as stated in the Valid idle Period Criteria Section). Also, in order to increment the WarmedUpEvents counter (counter must exceed 15 cal value), either the vehicle speed must exceed 15 cal value), either the vehicle speed must exceed the vehicle speed cal or the driver must NOT be off the acple gold as stated in the Valid Idle Period Criteria section above. Closed loop fueling Enabled Please see "Closed Loop Enable Criteria" section of the "Supporting Tables" tab for details.

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
						iteria :: Must hold true from after		
					Catalyst Idle (Conditions Met to the end of test		
						MAF 1.50 < g/s < 7.00	-	
						alyst < 950 degC		
					tempera		_	
					Engine Fueling	Criteria at Beginning of Idle Period		
						eling related must also be met fron	ו	
						7 seconds after the Catalyst Idle		
						Criteria has been met for at least 4		
					seconds pri	or to allowing intrusive control		
					Number of pre	-O2 >= 2	-	
					switc			
						Trim 0.960 < ST FT Avg < 1.040		
						Avg		
					Rapid Step Re	sponse (RSR) feature will initiate	7	
						multiple tests:		
					If the difference h	petween current EWMA value and the	_	
						nalized Ratio value is > 0.490 and the		
						Normalized Ratio value is < 0.430 and the		
					Garrent Goor	Tormanizou Hado Valdo To Vol. 100		
					Maximum of 24 R	SR tests to detect failure when RSR	s	
					Meximum or 2110	enabled.		
					Green	Converter Delay Criteria	-	
					This is a set of the	about for the Oatel at the Oatel		
						check for the Catalyst Idle Conditions Met Criteria section	5	
					The diagnostic wil	I not be enabled until the following ha	s	
						been met:		
						200111101.		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					Predicted cataly	yst temperature > 0 ° C for 0 seconds		
						non-continuously.		
						re is only enabled when the vehicle is		
					new and	I cannot be enabled in service		
						PTO Not Active	1	
						General Enable]	
						DTC's Not Set		
						MAF_SensorFA	_	
						MAF_SensorTFTKO	_	
						AmbPresDfltdStatus	_	
						IAT_SensorCircuitFA	_	
					IA	T_SensorCircuitTFTKO	1	
						ECT_Sensor_FA	_	
					O29	S_Bank_1_Sensor_1_FA	_	
					O29	S_Bank_1_Sensor_2_FA	_	
					O29	S_Bank_2_Sensor_1_FA	_	
					O28	S_Bank_2_Sensor_2_FA	_	
					F	uelTrimSystemB1_FA	_	
					Fue	elTrimSystemB1_TFTKO	_	
					F	uelTrimSystemB2_FA	_	
					Fue	elTrimSystemB2_TFTKO	_	
					En	gineMisfireDetected_FA	_	
					Evap	PurgeSolenoidCircuit_FA	_	
						IAC_SystemRPM_FA	_	
					EG	RValvePerformance_FA		
						EGRValveCircuit_FA		
					Ca	mSensorAnyLocationFA	_	
						CrankSensor_FA		
					7	ΓPS_Performance_FA		
						EnginePowerLimited		
					Ve	ehicleSpeedSensor_FA	1	

Component/	Fault	• • • • • • • • • • • • • • • • • • • •	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Evaporative	P0442		The total delta from peak		Fuel Level	10 % ≤ Percent ≤ 90 %	Once per trip,	1 trip
Emission (EVAP) System Small Leak		a small leak (≥ 0.020") in the EVAP	pressure to peak vacuum during the test is		Drive Time	≥ 600 seconds	during hot soak	Type A EWMA
Detected			normalized against a		Drive length	≥ 5.0 miles	(up to 2400 sec.).	_ ⊏VVIVIA
Beleeted		fuel fill cap and the	calibration pressure		ECT	≥ 70 °C	No more than 2	Average
			threshold table that is		Baro	- 70 kPa	unsuccessful	run length
		engine off natural	based upon fuel level and				attempts between	
		vacuum method	ambient temperature.		Odometer	≥ 10.0 miles	completed tests.	normal
		(EONV) is used.	(See P0442: EONV		Engine not run time			condition
		EONV is an evaporative system	Pressure Threshold Table on Supporting Tables		before key off must be			S
		leak detection	Tab). The normalized			≤ refer to "P0442: Engine Off		Run
		diagnostic that runs	value is calculated by the			Time Before Vehicle Off Maximum		length is
			following equation: 1 -			as a Function of Estimated		3 to 6
			(peak pressure - peak			Ambient Temperature table" in		trips after
		conditions are met.	vacuum) / pressure			Supporting Tables.		code
		Prior to sealing the	threshold. The					clear or
		system and	normalized value is					non-
		performing the	entered into EWMA (with					volatile
		diagnostic, the fuel volatility is analyzed.	0= perfect pass and 1=					reset
		In an open system	periectiali).		Time since last			
		(Canister Vent			complete test	≥ 17 hours		
		Solenoid [CVS]			if normalized result			
		open) high volatility			and EWMA is passing			
		fuel creates enough			and Evrivia is passing			
		flow to generate a						
		measurable						
		pressure differential			OR			
		relative to						
		atmospheric.			Time since last			
					complete test	≥ 10 hours		
					if normalized result or			
					EWMA is failing			
					Estimated ambient			
					temperature at end of			
					drive			
						0 °C ≤ Temperature ≤ 34 °C		

Component/	Fault	9,	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					Estimate of Ambient			
					Air Temperature Valid			
			When EWMA is	> 0.54	Conditions for		1	
				(EWMA Fail	Estimate of Ambient			
				Threshold)	Air Temperature to			
				,	be valid:			
			, the DTC light is		Do vana.			
			illuminated.					
		After the volatility			1. Cold Start			
		check, the vent	The DTC light can be		Startup delta deg C	≤8°C		
		solenoid will close.	turned off if the EWMA is		(ECT-IAT)	S O C		
		After the vent is						
		closed, typically a		≤ 0.35				
		build up of pressure from the hot soak		(EWMA Re-Pass	OR			
		begins (phase-1).		Threshold)	2. Short Soak and			
		The pressure	and stave below the		Previous EAT Valid			
		typically will peak	and stays below the EWMA fail threshold for 2					
		and then begin to	additional consecutive					
		decrease as the fuel	trins					
		cools. When the	1po.		Previous time since	4 7000 d-		
		pressure drops (-			engine off	≤ 7200 seconds		
		62.27) Pa from peak						
		pressure, the vent is			OR			
		then opened for 60			3. Less than a short			
		seconds to			soak and Previous			
		normalize the			EAT Not Valid			
		system pressure.						
		The vent is again						
		closed to begin the						
		vacuum portion of the test (phase-2).			Previous time since	≤ 7200 seconds		
		As the fuel			engine off			
		temperature			AND			
		continues to fall, a			Must expire Estimate	Vehicle Speed ≥ 18.6 mph		
		vacuum will begin			of Ambient	AND		
		- account will bogin			Temperature Valid	Mass Air Flow ≥ 7 g/sec		

Component/	Fault		Malfunction	Threshold		Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
		forming. The			Conditioning Time.			
		vacuum will continue			"P0442: Estimate of			
		until it reaches a			Ambient			
		vacuum peak. When			Temperature Valid			
		the pressure rises			Conditioning Time"			
		62.27 Pa from			in Supporting Tables			
		vacuum peak, the			Tab.			
		test then completes.						
		If the key is turned						
		on while the						
		diagnostic test is in						
		progress, the test						
		will abort.						
					OR			
					4. Not a Cold Start			
					and greater than a			
					Short Soak			
					B	7200		
						> 7200 seconds		
					engine off			
					AND			
						Vehicle Speed ≥ 18.6 mph		
						AND		
						Mass Air Flow ≥ 7 g/sec		
					Valid Conditioning			
					Time. Please see			
					"P0442: Estimate of			
					Ambient			
					Temperature Valid			
					Conditioning Time"			
					in Supporting Tables			
					Tab.			
	I	1		1			_	

Component/	Fault	Monitor Strategy	Malfunction	Threshold		Enable	Time	MIL
System	Code	Description	Criteria	Value		Conditions	Required	illum.
				Abort Conditions:	1. High Fuel			
					Volatility			
					l'olutility			
					During the volatility			
					phase, pressure in the			
					fuel tank is integrated			
					vs. time. If the			
					integrated pressure is			
						< -5		
					then test aborts and			
					unsuccessful attempts			
					is incremented.			
					OR			
					2. Vacuum			
					Refueling Detected			
					Refuelling Detected			
					0 00454 5 11			
					See P0454 Fault			
					Code for information			
					on vacuum refueling			
					algorithm.			
					OR			
					3. Fuel Level			
					Refueling Detected			
					See P0464 Fault			
					Code for information			
					on fuel level refueling.			
					OR			
					4. Vacuum Out of			
					Range and No			
	I				Refueling	1		

Component/	Fault	Monitor Strategy	Malfunction	Threshold		Enable	Time	MIL
System	Code	Description	Criteria	Value	•	Conditions	Required	illum.
					See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.			
					OR 5. Vacuum Out of Range and Refueling Detected			
					See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.			
					OR 6. Vent Valve Override Failed			
					Device control using an off-board tool to control the vent solenoid, cannot exceed during the EONV test	0.50 seconds		
					OR 7. Key up during EONV test			

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					No active DTCs:	FuelLevelDataFault MAF_SensorFA ECT_Sensor_FA IAT_SensorFA VehicleSpeedSensor_FA IgnitionOffTimeValid AmbientAirDefault P0443 P0446 P0449 P0452 P0453 P0455 P0496		
Evaporative Emission (EVAP) Canister Purge Solenoid Valve Circuit (ODM)	P0443	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		PT Relay Voltage	11 volts ≤ Voltage ≤ 32 volts	20 failures out of 25 samples 250 ms / sample Continuous with solenoid operation	2 trips Type B
Evaporative Emission (EVAP) Vent System Performance	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filler, vent hose or EVAP canister. This test runs with normal purge and vent valve is open.	Vent Restriction Prep Test: Vented Vacuum OR Vented Vacuum for 60 seconds Vent Restriction Test: Tank Vacuum	< -623 Pa > 1245 Pa > 2989 Pa	Fuel Level System Voltage Startup IAT Startup ECT BARO No active DTCs:	10% ≤ Percent ≤ 90% 11 volts ≤ Voltage ≤ 32 volts 4 °C ≤ Temperature ≤ 30 °C ≤ 35 °C ≥ 70 kPa MAP_SensorFA TPS_FA VehicleSpeedSensor_FA	Once per Cold Start Time is dependent on driving conditions	2 trips Type B
			for 5 seconds BEFORE	≥ 8 liters		IAT_SensorCircuitFA ECT_Sensor_FA AmbientAirDefault		

Component/	Fault		Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code		After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time.	Value	Parameters	EnginePowerLimited P0443 P0449 P0452 P0453 P0454	Required Maximum time before test abort is 1000 seconds	illum.
Evaporative Emission (EVAP) Vent Solenoid Control Circuit (ODM)	P0449	circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage Run/Crank voltage goes to 0 volts at key off	11 volts ≤ Voltage ≤ 32 volts	20 failures out of 25 samples 250 ms / sample Continuous with solenoid operation	2 trips Type B
Fuel Tank Pressure (FTP) Sensor Circuit Performance	P0451	if the fuel tank vacuum sensor is out of range when it tries to re-zero prior to the phase-1 or phase-2 portions of the engine-off natural vacuum small leak test.	The tank vacuum sensor voltage is compared to a window about the nominal sensor voltage offset (~1.5 volts) Upper voltage threshold (voltage addition above the nominal voltage) Lower voltage threshold (voltage subtraction below the nominal voltage)	0.2 volts	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		This test is executed during an engine-off natural vacuum small leak test. The number of times that it executes can range from zero to two per engine-off period.	1 trip Type A EWMA Average run length: Run length i 2 trips after coc clear o

Component/	Fault		Malfunction	Threshold	Secondary	Enable		MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			The difference between tank vacuum sensor voltage and the nominal offset voltage is then normalized against the appropriate threshold listed above to produce a ratio between 0.0 and 1.0. This normalized re-zero ratio is then filtered with a EWMA (with 0= perfect pass and 1=perfect fail).				The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.	non- volatile reset
			When EWMA is , the DTC light is illuminated. The DTC light can be turned off if the EWMA is	> 0.73 (EWMA Fail Threshold) ≤ 0.40 (EWMA Re-Pass				
			and stays below the EWMA fail threshold for 2 additional consecutive trips.	Threshold)				
Fuel Tank Pressure (FTP) Sensor Circuit Low Voltage	P0452	This DTC will detect a fuel tank pressure sensor signal that is too low out of range.	Fuel tank pressure sensor signal	< 0.15 volts (3 % of Vref or ~ 1681 Pa)	Time delay after sensor power up for sensor warm-up		640 failures out of 800 samples	2 trips Type B
			The normal operating range of the fuel tank pressure sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~-3736 Pa).		ECM State ≠ crank	is 0.10 seconds	100 ms / sample Continuous	

Component/	Fault		Malfunction	Threshold	Secondary	Enable	Time	MIL
system	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					Stops 6.0 seconds			
					after key-off			
uel Tank Pressure	P0453	This DTC will detect	Fuel tank pressure	> 4.85 volts (97% of	Time delay after		640 failures out of	2 trips
FTP) Sensor		a fuel tank pressure	sensor signal	Vref or ~ -4172 Pa)	sensor power up for		800 samples	Type B
Circuit High		sensor signal that is			sensor warm-up		·	**
/oltage		too high out of						
		range.						
			The normal operating			is 0.10 seconds		
			range of the fuel tank				100 ms / sample	
			pressure sensor is 0.5 volts (~1245 Pa) to 4.5		ECM State ≠ crank			
			volts (*1245 Fa) to 4.5					
			(~ -3736 Pa).				0	
							Continuous	
					Stops 6.0 seconds			
					after key-off			
Fuel Tank Pressure	P0454	This DTC will detect	If an abrupt change in		This test will execute		This test is	1 trips
(FTP) Sensor		intermittent tank	tank vacuum is detected		whenever the engine-		executed during	Type A
Circuit Intermittent		vacuum sensor	the engine-off natural		off natural vacuum		an engine-off	
		signals that would	vacuum test is aborted		small leak test		natural vacuum	
		have caused the	due to an apparent		(P0442) executes		small leak test.	
		engine-off natural	refueling event.				The test can only	
			Subsequent to the abort,				execute up to	
			a refueling rationality test				once per engine-	
		an apparent re-	is executed to confirm				off period.	
		fueling event.	that a refueling event					
			occurred. If a refueling is					
			confirmed, then the test sample is considered					
			passing. Otherwise, the					
			sample is considered					
			failing indicating an					
			intermittent signal					
			problem.					
			ľ					
							The length of the	
							test is determined	
							by the refueling	
							rationality test,	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
							which can take	
							up to 600	
							seconds to	
							complete.	
							The test will	
			An abwent abance is				report a failure if	
			An abrupt change is				2 out of 3	
			defined as a change in vacuum:				samples are	
			vacuum.				failures.	
				>112 Pa				
				/112 Fa				
			in the span of 1.0					
			seconds.					
			But	< 249 Pa				
				\ 249 F a				
			in 12.5 msec.				12.5 ms / sample	
			A refueling event is					
			confirmed if the fuel level					
			has a persistent change				Continuous when	
			That a percision sharige				vent solenoid is	
				. 5 4 0 0/			closed.	
				of 10 %				
			for 30 seconds.					
	1							

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Evaporative Emission (EVAP)	P0455	This DTC will detect a weak vacuum	Purge volume	> 15 liters	Fuel Level	10% ≤ Percent ≤ 90%	Once per cold start	2 trips
System Large Leak		condition (large leak	while		System Voltage	11 volts ≤ Voltage ≤ 32 volts	Start	Type E
Detected		or purge blockage)	Tank vacuum	≤ 2740 Pa				
		in the EVAP system.			BARO	≥ 70 kPa	Time is	
			After setting the DTC for		Purge Flow	≥ 2.80 %	dependent on	
			the first time, 2 liters of		No active DTCs:	MAP SensorFA	driving conditions	
		purge flow) and vent	fuel must be consumed			_		
		valve is commanded	before setting the DTC for the second time.			TPS_FA		
		closed.	the second time.			VehicleSpeedSensor_FA		
						IAT_SensorCircuitFA		
						ECT_Sensor_FA	Maximum time	
						AmbientAirDefault	before test abort	
						EnginePowerLimited	is 1000 seconds	
						P0443		
			Weak Vacuum Follow-up			P0449		
			Test (fuel cap			P0452		
			replacement test)			P0453		
			Weak Vacuum Test			P0454		
			Passes if tank vacuum	≥ 2740 Pa				
							Weak Vacuum	
							Follow-up Test	
			Note: Weak Vacuum					
			Follow-up Test can only report a pass.		Cold Start Test		With large leak detected, the	
					If ECT > IAT, Startup		follow-up test is	
					temperature delta		limited to 1300	
					(ECT-IAT):		seconds. Once	
						≤8°C	the MIL is on, the	
					Cold Test Timer	≤ 1000 seconds	follow-up test runs indefinitely.	
					Startup IAT	4 80 4 Tamananat as 400 80	runs indefinitely.	
					Startup ECT	4 °C ≤ Temperature ≤ 30 °C ≤ 35 °C		
					Weak Vacuum Follow-			
		I		Ī	up Test	1	1	

O461	This DTC will detect a fuel sender stuck in range in the	Delta Fuel Volume change	Value	Secondary Parameters This test can run following a weak vacuum failure or on a hot restart. Engine Running	Conditions		illum.
	a fuel sender stuck in range in the		. 40 14	following a weak vacuum failure or on a hot restart.			
	a fuel sender stuck in range in the		40 84	Engine Running		· ·	
		over an accumulated 149 miles.	< 10 liters	No active DTCs:	VehicleSpeedSensor_FA	250 ms / sample Continuous	2 trips Type B
	a fuel sender stuck out of range low in	Fuel level Sender % of 5V range	< 10 %	Run/Crank Voltage Run/Crank voltage goes to 0 volts at key off	11 volts ≤ Voltage ≤ 32 volts	100 failures out of 125 samples 100 ms / sample	2 trips Type B
	a fuel sender stuck out ofrange high in	Fuel level Sender % of 5V range	> 60 %	Run/Crank Voltage Run/Crank voltage goes to 0 volts at key off	11 volts ≤ Voltage ≤ 32 volts	Continuous 100 failures out of 125 samples 100 ms / sample	2 trips Type B
						Continuous	
	163	a fuel sender stuck out of range low in the primary fuel tank.	a fuel sender stuck out of range low in the primary fuel tank. This DTC will detect a fuel sender stuck out ofrange high in range	a fuel sender stuck out of range low in the primary fuel tank. This DTC will detect a fuel sender stuck out ofrange high in range < 10 % Fuel level Sender % of 5V range > 60 %	a fuel sender stuck out of range low in the primary fuel tank. This DTC will detect a fuel sender stuck out ofrange high in the primary fuel tank. Fuel level Sender % of 5V range Fuel level Sender % of 5V range > 60 % Run/Crank Voltage Run/Crank Voltage Run/Crank Voltage Run/Crank voltage Run/Crank voltage Run/Crank voltage Run/Crank voltage Run/Crank voltage	a fuel sender stuck out of range low in the primary fuel tank. This DTC will detect a fuel sender stuck out ofrange high in the primary fuel tank. Fuel level Sender % of 5V range > 60 % Run/Crank voltage goes to 0 volts at key Run/Crank Voltage 11 volts ≤ Voltage ≤ 32 volts	a fuel sender stuck out of range low in the primary fuel tank. This DTC will detect a fuel sender stuck out ofrange high in the primary fuel tank. Fuel level Sender % of 5V range Fuel level Sender % of 5V range Fuel level Sender % of 5V range Run/Crank Voltage Run/Crank Voltage Run/Crank Voltage Run/Crank Voltage Run/Crank Voltage Run/Crank voltage goes to 0 volts at key off 100 ms / samples 100 ms / samples 100 ms / samples 100 ms / samples

ECM SECTION Page 89 of 215

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description		Value	Parameters	Conditions		illum.
Fuel Level Sensor 1 Circuit Intermittent	P0464	This DTC will detect	If a change in fuel level is detected, the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that an actual refueling event occurred. If a refueling event is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem.		This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period.	1 trips Type A
							The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.	
			and does not remain	by 10 %			The test will report a failure if 2 out of 3 samples are failures.	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			for 30 seconds during a 600 second refueling rationality test.				100 ms / sample	
Cooling Fan 1 Relay Control Circuit (ODM)	P0480	circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do		Run/Crank Voltage	11 volts ≤ Voltage ≤ 32 volts	50 failures out of 63 samples	2 trips Type B
			not match.		Engine Speed	≥ 400 RPM	100 ms / sample	Not use on systems with Mechan
							Continuous with fan operation	al Fan)
Cooling Fan 2 Relay Control Circuit (ODM)	P0481	circuit for electrical	The ECM detects that the commanded state of the driver and the actual state		Run/Crank Voltage	11 volts ≤ Voltage ≤ 32 volts	50 failures out of 63 samples	2 trips Type B
			of the control circuit do not match.		Engine Speed	≥ 400 RPM	100 ms / sample	Not use on systems with
							Continuous with fan operation	Mechan al Fan)

Component/		Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
Emission (EVAP)	P0496	determine if the	Tank Vacuum	> 2491 Pa	Fuel Level System Voltage	10% ≤ Percent ≤ 90% 11 volts ≤ Voltage ≤ 32 volts	Once per cold start	2 trips Type B
Evaporative Emission (EVAP) System Flow During Non-Purge	P0496	This DTC will determine if the purge solenoid is leaking to engine manifold vacuum. This test will run with the purge valve closed and the vent valve closed.	Tank Vacuum for 5 seconds BEFORE Test time	> 2491 Pa ≥ refer to "P0496: Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level table" in Supporting Tables Tab.	Fuel Level System Voltage BARO Startup IAT Startup ECT Engine Off Time No active DTCs:	Conditions 10% ≤ Percent ≤ 90% 11 volts ≤ Voltage ≤ 32 volts ≥ 70 kPa	Required Once per cold start Cold start: max time is 1000 seconds	illum. 2 trips Type B
						EnginePowerLimited P0443 P0449		
						P0452 P0453 P0454		
						1 0737		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Transmission Output Speed Sensor (TOSS)	P0502	No activity in the TOSS circuit	TOSS Raw Speed	≤ 60 RPM	Engine Torque Minimum Throttle opening Engine Speed Ignition voltage PTO EngineTorqueEstInac curate OR If KeETQC_b_MinTrans Remedial = 1 (KeETQC_b_MinTran sRemedial = 0)	90.0 ≤ N-M ≤ 8191.8 ≥ 15.0 % 1500 ≤ RPM ≤ 6500 11.0 ≤ Volts ≤ 32.0 not active FALSE Not MAF_SensorTFTKO Not MAP_SensorTFTKO Not EngineMisfireDetected_FA	≥ 4.5 sec	Type B 2 trips
Transmission	P0503	TOSS Signal	Loop-to-Loop change in		P0503	Not failed this key cycle		Туре В
Output Speed Sensor (TOSS)		Intermittent	TOSS	≥ 350 RPM	Time since transfer case range change Ignition voltage Engine Speed Vehicle Speed PTO	> 200 RPM for ≥ 2.0 sec ≤ 150 RPM for ≥ 2.0 sec ≥ 3.0 sec 11.0 ≤ Volts ≤ 32.0 200 ≤ RPM ≤ 7500 for ≥ 5.0 seconds ≤ 155 MPH for ≥ 5.0 sec not active	≥ 3.3 sec	2 trips
Low Engine Speed Idle System	P0506	This DTC will determine if a low idle exists	Filtered Engine Speed Error	> 91.00 rpm	Baro	> 70 kPa	Diagnostic runs in every 12.5 ms loop	2 trips Type B
			filter coefficient	0.003	Coolant Temp	> 60 °C and < 120 °C Must verify KfECTI_T_EngCoolHotLoThresh is less than KfECTI_T_EngCoolHotHiThresh	Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					Engine run time	≥ 60 sec		
					Ignition voltage	32 ≥ volts ≥ 11		
					Time since gear			
						≥ 3 sec		
					Time since a TCC			
					mode change	> 3 sec		
					IAT	> -20 °C	<u> </u>	
					Vehicle speed			
					Commanded RPM			
						≤ 25 rpm		
						> 10 sec		
					For manual			
					transmissions:			
					Clutch Pedal Position			
					or Clutch Pedal Position	> 90.00 pct		
					Cidtorr Edair Osition			
						< 15.00 pct		
						PTO not active		
						LowState		
						Off-vehicle device control (service		
						bay control) must not be active.		
						following conditions not TRUE: (VeTESR_e_EngSpdReqIntvType		
						= CeTESR_e_EngSpdMinLimit		
						AND		
						VeTESR_e_EngSpdReqRespTyp		
						e = CeTESR_e_NoSuggestion)	ļ	
						Clutch is not depressed		
					No active DTCs	TC_BoostPresSnsrFA		
						ECT_Sensor_FA		
						EnginePowerLimited		
						EGRValveCircuit_FA		
						EGRValvePerformance_FA		
						IAT_SensorCircuitFA	1	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
						EvapFlowDuringNonPurge_FA		
						FuelTrimSystemB1_FA		
						FuelTrimSystemB2_FA		
						FuelInjectorCircuit_FA		
						MAF_SensorFA		
						EngineMisfireDetected_FA		
						IgnitionOutputDriver_FA		
						TPS_FA		
						TPS_Performance_FA		
						VehicleSpeedSensor_FA		
						FuelLevelDataFault		
						LowFuelConditionDiagnostic		
						Clutch Sensor FA		
						AmbPresDfltdStatus		
						P2771		
					All of the above met	10.000		
High Engine	P0507	This DTC will	Filtered Engine Speed	< -182.00 rpm	for Idle time Baro		Diagnostic runs in	2 trins
Speed Idle System	F0307	determine if a high idle exists	Error	×-102.00 τριτί	Баго	> 70 kPa	every 12.5 ms	Type B
			filter coefficient	0.003		> 60 °C and < 120 °C Must verify KfECTI_T_EngCoolHotLoThresh is less than KfECTI_T_EngCoolHotHiThresh	Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	
					Engine run time	≥ 60 sec		
					Ignition voltage	32 ≥ volts ≥ 11		
					Time since gear			
						≥ 3 sec		
					Time since a TCC mode change			
				+		> -20 °C		1
					Vehicle speed			
					Commanded RPM			
						≤ 25 rpm		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					For manua transmissions Clutch Pedal Position oi Clutch Pedal Position	> 90.00 pct		
						< 15.00 pct		
						PTO not active		
						Transfer Case not in 4WD LowState		
						Off-vehicle device control (service bay control) must not be active.		
						following conditions not TRUE: (VeTESR_e_EngSpdReqIntvType = CeTESR_e_EngSpdMinLimit AND VeTESR_e_EngSpdReqRespTyp e = CeTESR_e_NoSuggestion)		
						Clutch is not depressed		
					No active DTCs	TC_BoostPresSnsrFA		
						ECT_Sensor_FA		
						EnginePowerLimited		
						EGRValveCircuit_FA		
						EGRValvePerformance_FA		
						IAT_SensorCircuitFA		
						EvapFlowDuringNonPurge_FA		
						FuelTrimSystemB1_FA		
						FuelTrimSystemB2_FA		
						FuelInjectorCircuit_FA		
						MAF_SensorFA		
						EngineMisfireDetected_FA		
						IgnitionOutputDriver_FA		
						TPS_FA		
						TPS_Performance_FA		
						VehicleSpeedSensor_FA		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
ystem	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
						FuelLevelDataFault		
						LowFuelConditionDiagnostic		
						Clutch Sensor FA		
						AmbPresDfltdStatus		
						P2771		
					All of the above met for Idle time			
						> 10 sec		
ngine Oil ressure (EOP) witch	P0520	When criteria are met that assure no oil pressure should	State of Engine Oil Pressure (EOP) switch circuit	Detecting.a.ground.w ill.set.a.fault	Run/Crank powermode active	= True		
VICII		be present, read state of oil pressure	Circuit		Engine movement detected	= False		
		switch circuit			Key in crank position			1
						= False		trip(s
					Power down engine coolant	> 80 Deg C	Fail detected for >= 5.0 Sec.	Type C
					Powertrain relay voltage	>= 11 and <= 32 Volts		
					Run/Crank Ignition voltage	>= 11 and <= 32 Volts		
						AND	1	
					Time since engine last running	> 3600 Seconds	250 msec loop	
					Timer for time since engine last running validity	= True	Continuous	
						OR		
					Engine coolant at power up	< (Power down engine coolant) minus 10 Deg C		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL illum.
ejetem	3000	Docompaion	ontona	valuo	Diagnostic enabled/ disabled	Enabled	rtoquirou	
					No active DTC's	Fault bundles: ECT_Sensor_Ckt_FA		
Air Conditioning Refrigerant Pressure Sensor Circuit Low Voltage	P0532	Determines if the Air Conditioning Refrigerant Pressure circuit voltage is too	(AC Pressure Sensor Voltage) / 5 Volts	< 2.0 percent	AC Pressure Sensor diagnostic enabled	Enabled	120 failures	1 Trip(s) Type C Not
onean Low Voltage		low			AC pressure sensor present	Present	Performed every 25 msec	"Special Type C"
Air Conditioning Refrigerant Pressure Sensor Circuit High	P0533	Determines if the Air Conditioning Refrigerant Pressure circuit voltage is too	(AC Pressure Sensor Voltage) / 5 Volts	> 98.0 percent	AC Pressure Sensor diagnostic enabled	Enabled	120 failures	1 Trip(s) Type C Not
Voltage		high			AC pressure sensor present	Present	Performed every 25 msec	"Special Type C"
System Voltage Low	P0562	This DTC determines if the current system voltage is below the minimum required voltage for proper ECM operation.	System voltage	≤ 9 volts	Ignition is "ON" Engine Speed	≥ 400 RPM	5 failures out of 6 samples 1 second / sample	Type C
		LOW Operation.					Continuous	"Special Type C"

Component/	Fault		Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	•	Criteria	Value	Parameters	Conditions	Required	illum.
System Voltage High	P0563	This DTC determines if the current system voltage is above the	System voltage	≥ 18 volts	Ignition is "ON"		5 failures out of 6 samples	1 trip Type C
		maximum allowed voltage for proper ECM operation.					1 second / sample	Not "Special
							Continuous	Type C"
Cruise Control Mutil- Functon Switch Circuit	P0564	control multi-function switch circuit (analog) voltage is in an illegal range	calibratable period of time for cruise switch states		CAN cruise switch diagnostic enable in ECM	Enabled	fail continuously for greater than 0.500 seconds	Type: C MIL: NO
			that are received over serial data					Trips:
Cruise Control Resume Circuit	P0567	the cruise resume switch in a continously applied	Cruise Control Resume switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	Enabled	fail continuously for greater than 90.000 seconds	Type:
								MIL:
								NO
								Trips:
								1

Component/	Fault	0,	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Cruise Control Set Circuit	P0568		Cruise Control Set switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	Enabled	fail continuously for greater than 90.000 seconds	Type:
								MIL: NO
							fail continuously for greater than 90.000 seconds	Trips:
				•	,		•	1
Cruise Control Input Circuit	P0575		If x of y rolling count / protection value faults occur, disable cruise for duration of fault		Cruise Control Switch Serial Data Error Diagnostic Enable	Enabled	5/10 counts	Type:
								NO NO
								Trips:
Thermostat Heater Control Open Circuit	P0597	T-stat Heater Driver Output circuit for	Voltage low during driver open state (indicates short-to-ground or open		Run Crank Ignition in	n e = True	15 failures out of 30 samples	2 trips Type E
state f	circuit). Fault present state for Open circuit is determined from output		Engine not crankinţ Run Crank active	g = True	1 sec/ sample			
			driver status byte.		A	bove is true and		
					Last Open Circuit Tes	t		
						= not Indeterminate	Continuous	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL illum.
Thermostat Heater Control Circuit Low	P0598	This DTC checks the T-stat Heater Driver Output circuit for electrical integrity.	Voltage low during driver open state (indicates short-to-ground or open circuit). Fault present state for Ground Short circuit is determined from		Run Crank Ignition in Range Engine not cranking Run Crank active	= True = True	15 failures out of 30 samples 1 sec/ sample	2 trips Type B
			output driver status byte.		Ab	ove is true and	₫ '	
					Last Ground Short Circuit Test		Continuous	
						= not Indeterminate	-	
Thermostat Heater	P0599		Voltage high during driver				15 failures out of	2 trips
Control Circuit High		T-stat Heater Driver Output circuit for electrical integrity.	closed state (indicates short-to-power). Fault present state for Power Short circuit is		Run Crank Ignition in Range Engine not cranking	= True	30 samples	Type B
			determined from output driver status byte.		Run Crank active	= True	1 sec/ sample	
			anvoi status syte.		Ab Last Power Short	ove is true and	-	
					Circuit Test		Continuous	
						= not Indeterminate		
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if the calibration check sum is incorrect or	The Primary Processor's calculated checksum does not match the stored checksum value.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs			Diagnostic runs continuously in the background	Trips: 1 Type:
		the flash memory detects an uncorrectable error via the Error Correcting Code.	Covers all software and calibrations.	after the first pass is complete.				A MIL: YES
		Correcting Code.						

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Error Correcting Code	254 failures detected via Error Correcting Code			Diagnostic runs continuously via the flash hardware	
			does not match the	2 consecutive failures detected or 5 total failures detected.			Diagnostic runs continuously. Will report a detected fault within 200 ms.	
			checksum does not	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background	
				In all cases, the failure count is cleared when controller shuts down				
Control Module Not Programmed	P0602	This DTC will be stored if the PCM is a service PCM that has not been programmed.	Output state invalid			= crank or run PCM is identified through calibration as a Service PCM	Diagnostic runs at powerup and once per second continuously after that	Type A 1 trips

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Control Module	P0603		Checksum at power-up				Diagnostic runs	Type A
ong Term Memory			does not match				at powerup	1 trips
Reset		controller power-up	checksum at power-down					
							Diagnostic	4
							reports a fault if 1	
							failure occurs	
							landic occurs	
CM RAM Failure	P0604	Indicates that the			1		İ	Trips:
		ECM has detected a						1
		RAM fault:						Type:
								A
		Primary Processor					Will finish first	MIL:
		System RAM Fault					memory scan	YES
							within 30 seconds	S
							at all engine	
							conditions -	
			Indicates that the primary				diagnostic runs	
			processor is unable to				continuously	
			correctly read data from				(background	
			or write data to system				loop)	
			RAM. Detects data read					
			does not match data					
			written >=	254 counts				
		Primary Processor					Will finish first	7
		Cache RAM Fault					memory scan	
							within 30 seconds	3
							at all engine	
							conditions -	
							diagnostic runs	
							continuously	
							(background	
			Indicates that the primary				loop)	
			processor is unable to					
			correctly read data from					
			or write data to cached					
			RAM. Detects data read					
			does not match data	254 courts				
			written >=	254 counts				

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable		MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
		Primary Processor					Will finish first	
		TPU RAM Fault					memory scan	
							within 30 seconds	
							at all engine	
							conditions -	
							diagnostic runs	
							continuously	
			L. P. H. G. G. G. G. G.				(background	
			Indicates that the primary				loop)	
			processor is unable to				100р)	
			correctly read data from					
			or write data to TPU					
			RAM. Detects data read					
			does not match data					
			written >=	5 counts				
		Primary Processor	Indicates that the primary				When dual store	1
		Update Dual Store	processor detects a				updates occur.	
		RAM Fault	mismatch between the					
		TO WIT GOIL	data and dual data is					
			found during RAM					
			updates. Detects a					
			mismatch in data and					
			dual data updates >					
				0 44000				
		D: D		0.44000 seconds			D: "	ļ
		Primary Processor	Indicates that the primary				Diagnostic runs	
		Write Protected	processor detects an				continuously	
		RAM Fault	illegal write attempt to				(background	
			protected RAM. Number				loop)	
			of illegal writes are >					
				65534 counts				

Component/	Fault	• • • • • • • • • • • • • • • • • • • •	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Indicates that the secondary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions, diagnostic runs continuously (background loop)	
Internal ECM Processor Integrity Fault	P0606	Indicates that the ECM has detected an internal processor integrity fault:		o counto				Trips: 1 Type: A MIL: YES
		SPI Fault Detected	from the Secondary	Loss or invalid message at initialization detected or loss or invalid message after a valid message was recieved		Run/Crank voltage >= 11.00, else the failure will be reported for all conditions	In the primary processor, 159/399 counts intermittent or 39 counts continuous; 39 counts continuous @ initialization. 12.5 ms /count in the ECM main processor	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code		Criteria	Value	Parameters	Conditions	Required	illum.
		Detected	from the Primary Processor at initialization detected by the				In the secondary processor, 20/200 counts intermittent or 0 counts continuous; 0 counts continuous @ initialization. 12.5 ms /count in the ECM main processor	
		Secondary Processor Stack Fault	Checks for stack over or underflow in secondary processorby looking for corruption of known pattern at stack boundaries. Checks number of stack over/under flow since last powerup reset >=			KeMEMD_b_StackLimitTestEnbl == 1 Value of KeMEMD_b_StackLimitTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
		Secondary processor received incorrect Keys	MAIN processor is verified by responding to a seed sent from the secondary with a key response to secondary. Checks number of incorrect keys received > or Secondary processor has not received a new within time limit	5 2 incorrect seeds within 8 messages, 0.200 seconds		Ignition in Run or Crank	150 ms for one seed continually failing	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
		MAIN processor did not receive seed within time limit	Time new seed not received exceeded			always running	0.450 seconds	
		MAIN processor test for seeds to arrive in a known sequence	MAIN processor receives seed in wrong order			always running	3 / 17 counts intermittent. 50 ms/count in the ECM main	
		Secondary processor ALU check	2 fails in a row in the Secondary processor's ALU check			KePISD_b_ALU_TestEnbId == 1 Value of KePISD_b_ALU_TestEnbId is: 1. (If 0, this test is disabled)	25 ms	
		Secondary processor register configuration check	2 fails in a row in the Secondary processor's configuration register masks versus known good data			KePISD_b_ConfigRegTestEnbId == 1 Value of KePISD_b_ConfigRegTestEnbId is: 1. (If 0, this test is disabled)	12.5 to 25 ms	_
		MAIN processor discrete fault:	Secondary processor detects an error in the toggling of a hardware discrete line controlled by the MAIN processor: number of discrete changes >= or <= over time window(50ms)			KePISD_b_MainCPU_SOH_FItEn bld == 1 time from initialization >= 0.488 seconds Value of KePISD_b_ConfigRegTestEnbId is: 1. (If 0, this test is disabled)	50 ms	_
				7 1	7			

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illu
		MAIN detected corruption in throttle or pedal critical RAM data	memory and complement memory do not agree				0.19 seconds	
		MAIN Processor Performance Check	1. Software tasks loops > schedule tasks loop 2. 12.5ms task loop sequence does not complete >=	See supporting tables 0.19 seconds		KePISD_b_SeedUpdKeyStorFItE nbl== 1 Value of KePISD_b_SeedUpdKeyStorFItE nbl is: 1. (If 0, this test is disabled) KePISD_b_12p5msSeqTestEnbld == 1 Value of KePISD_b_12p5msSeqTestEnbld is: 1. (If 0, this test is disabled)		
		MAIN Processor Performance Check	Software background task first pass time to complete exceeds		Powertrain relay	> 6.41 V	360.000 seconds	3
		MAIN processor ALU check	2 fails in a row in the MAIN processor's ALU check			KePISD_b_ALU_TestEnbId == 1 Value of KePISD_b_ALU_TestEnbId is: 1. (If 0, this test is disabled)		

omponent/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
stem	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
		configuration register check	2 fails in a row in the MAIN processor's configuration register masks versus known good data			KePISD_b_ConfigRegTestEnbld == 1 Value of KePISD_b_ConfigRegTestEnbld is: 1. (If 0, this test is disabled)	12.5 to 25 ms	
		MAIN Stack Fault	Checks number of stack over/under flow since last powerup reset >=	5		KeMEMD_b_StackLimitTestEnbl == 1 Value of KeMEMD_b_StackLimitTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
		MAIN processor ADC test	Voltage deviation >	0.495		KePISD_b_A2D_CnvrtrTestEnbId == 1 Value of KePISD_b_A2D_CnvrtrTestEnbId is: 1. (If 0, this test is disabled)	0.150 seconds continuous; 50	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occured since last controller initialization. Counter >=			KeMEMD_b_FlashECC_CktTestE nbl == 1 Value of KeMEMD_b_FlashECC_CktTestE nbl is: 1. (If 0, this test is disabled)	on length of time to access flash	
				3 (results in MIL), 5(results in MIL and remedial action)				

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occured since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_RAM_ECC_CktTest Enbl == 1 Value of KeMEMD_b_RAM_ECC_CktTest Enbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	
		check	MAIN processor DMA transfer from Flask to RAM has 1 failure			KePISD_b_DMA_XferTestEnbId == 1 Value of KePISD_b_DMA_XferTestEnbId is: 0. (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM	
Starter Relay	P0615	This DTC checks the	The ECM detects that the		Run/Crank Voltage	11 volts ≤ Voltage ≤ 32 volts	8 failures out of	1 trip
Control Circuit		circuit for electrical	commanded state of the driver and the actual state of the control circuit do not match.		Engine Speed	≥ 0 RPM	10 samples	Type C Not "Special Type C"
							Continuous	

Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
P0621		Key-On Test:		Key-On diagnostic	Enabled	>=1 seconds	1 Trip(s)
	1						
			>=1 seconds				Type C
		ground for:				250 msec	
							Not
	(Engine_Run Test)						"Special
							Type C"
				is detected (no RPM)			
			No CamSensorFA			<u> </u>	
					>=2 seconds		
				active for			
		Engine-Run Test		Engine-Run	Enabled	>=15 seconds	
		Linging real root.			Lindbiod	10 00001100	
				L-Terminal is enabled			
				No CrankSensorFA			
		L-Terminal shorted to	> = 15 seconds	Power mode is			
		ground or to power for:		Run/Crank			
				No CamSensorFA			
				Engine off time			
P0622		Key-On Test:		Key-On diagnostic	Enabled	>=5 seconds	1 Trip(s)
	1	Filtered F-Terminal Duty	>=65 %		Drecent	Performed every	Type C
	or with engine	Cycle is	/-03 /0	1 - Terminar is present	i resent	50 msec	Type C
	running	for	>=5 seconds	No crank sensor Fault Active			Not "Special
							Type C"
				active			71 - 1
				No CrankSensorFA			1
				Power mode is			
					Drocont		-
				Control is not present	Present		
	P0621	P0621 Determines if the L- Terminal is shorted to ground (Key_On Test) or shorted to ground or power (Engine_Run Test) P0622 Determines if the F- Terminal is faulted either during key-on	P0621 Determines if the L- Terminal is shorted to ground (Key_On Test) or shorted to ground or power (Engine_Run Test) Engine-Run Test: Engine-Run Test: Engine-Run Test: P0622 Determines if the F- Terminal is faulted either during key-on or with engine Criteria Key-On Test: L-Terminal shorted to ground for: L-Terminal shorted to ground or to power for: Key-On Test: Filtered F-Terminal Duty Cycle is	Pode Description Criteria Value	Poscription Criteria Value Parameters	Code Description Criteria Value Parameters Conditions	Determines if the Freminal is from the Formal shorted to ground (Key_On test)

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					No engine movement			
					is detected (no RPM)			
					, , ,			
					No CamSensorFA			
			Engine-Run Test:		Engine-Run	Enabled	>=30 seconds	
					diagnostic enabled			
			Filtered F-Terminal Duty	<=5 %	F-Terminal is present	Present		
			Cycle is		i cirimia is present			
			for	>=30 seconds	- 			
			101	-00 30001103	L-Terminal is enabled			
					No CrankSensorFA			
					Power mode is			
					Run/Crank			
					No CamSensorFA	+		
					Engine RPM is	< 1000		
					L-Terminal fault is not			
					active			
Fuel Pump Relay	P0627	This DTC checks for	The ECM detects that the		Run/Crank Voltage	11 volts ≤ Voltage ≤ 32 volts	8 failures out of	2 trips
Control Circuit			commanded state of the				10 samples	Type B
Open			driver and the actual state					
			of the control circuit do					
		commanded off.	not match.		Engine Speed	≥ 0 RPM	250 ms / sample	
							Continuous with	
							device off	
Fuel Pump Relay	P0628	This DTC checks for	The ECM detects that the		Run/Crank Voltage	11 volts ≤ Voltage ≤ 32 volts	8 failures out of	2 trips
Control Circuit Low	P0020		commanded state of the		Run/Crank voltage	11 voits \(\text{voitage} \(\text{s} \)	10 samples	Type B
Voltage			driver and the actual state				To Samples	туре в
voitage			of the control circuit do					
		commanded on.	not match.		F		050 /	
			inot materi.		Engine Speed	≥ 0 RPM	250 ms / sample	
							Continuous with	
							device on	
								<u> </u>

Component/	Fault	0,	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Fuel Pump Relay Control Circuit High Voltage	P0629	an open and shorted high circuit while the device is	The ECM detects that the commanded state of the driver and the actual state of the control circuit do		Run/Crank Voltage	11 volts ≤ Voltage ≤ 32 volts	8 failures out of 10 samples	2 trips Type B
		commanded off.	not match.		Engine Speed ≥ 0 RPM		250 ms / sample	
							Continuous with device off	
Control Module EEPROM Error	P062F	Indicates that the NVM Error flag has	The next write to NVM will not succeed or the		Ignition State	= unlock/accesory, run, or crank	1 test failure	Type A 1 trips
		not been cleared	assembly calibration integrity check failed.				Diagnostic runs once at powerup	
VIN Not Programmed or Mismatched - Engine Control Module (ECM)	P0630	This DTC checks VIN is correctly written	At least one of programed VIN's digit	= 00 or FF	OBD Manufacturer Enable Counter	= 0	250 ms / test Continuous	Type A 1 trips
5 Volt Reference #1 Circuit	P0641	Detects a continuous or intermittent short on th 5 volt reference circuit #1	ECM Vref1 < or ECM Vref1 > or the difference between ECM filtered Vref1 and Vref1 >	5.125		Run/Crank voltage or Powertrain relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Trips: 1 Type: A MIL: YES
Air Conditioning Clutch Relay Control Circuit	P0645	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	11 volts ≤ Voltage ≤ 32 volts	20 failures out of 25 samples	0 trip Type X
					Engine Speed	≥ 400 RPM	250 ms / sample	Not "Special Type C"

Component/ System	Fault Code	0,	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL illum.
							Continuous	
Malfunction Indicator Lamp (MIL) Control Circuit (ODM)	P0650	circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	11 volts ≤ Voltage ≤ 32 volts	20 failures out of 25 samples	2 trip Type B
			not matori.		Remote Vehicle Start is not active		250 ms / sample	NO MIL
							Continuous	
5 Volt Reference #2 Circuit	P0651	Detects a continuous or intermittent short on th 5 volt reference circuit #2	ECM Vref2 < or ECM Vref2 > or the difference between ECM filtered Vref2 and Vref2 >	5.125		Run/Crank voltage or Powertrain relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Trips: 1 Type: A MIL:
				0.05				YES
Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Bank 1	P0660	Tuning (IMT) Valve	ECM detects that commanded and actual states of output driver do not match		Powertrain Relay Voltage Powertrain Relay Voltage Engine Speed	>= 11.00 Volts <= 32.00 Volts >= 400 RPM	320 failures out of 400 samples 1 sample every 12.5 msec	Type B 2 trips
Powertrain Relay Control (ODM)	P0685	circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do		Run/Crank Voltage	11 volts ≤ Voltage ≤ 32 volts	8 failures out of 10 samples	2 trips Type B
			not match.				250 ms / sample	
							Continuous	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Powertrain Relay Feedback Circuit Low	P0689	This DTC is a check to determine if the Powertrain relay is	PT Relay feedback voltage is	≤ 5 volts	Run/Crank Voltage	≥ 11 volts	5 failures out of 6 samples	1 trips Type C
		functioning properly.			Powertrain relay commanded On		1 second / sample	Not "Special Type C"
					No active DTCs:	PowertrainRelayStateOn_FA		
Powertrain Relay Feedback Circuit High	P0690	This DTC is a check to determine if the Powertrain relay is functioning properly.	High Voltage test When PT relay is commanded On, PT Relay feedback voltage is	Disabled	No active DTCs:	PowertrainRelayStateOn_FA	5 failures out of 6 samples	2 trips Type B
				≥ 18 volts			1 second / sample	
			Voltage Stuck High test	Enabled	No active DTCs:	PowertrainRelayStateOn_FA	100 ms/ sample	<u>.</u>
			After PT Relay is commanded Off for PT Relay feedback voltage is	≥ 2 seconds,			Continuous	
				> 4 volts				
5 Volt Reference #3 Circuit	P0697	Detects a continuous or intermittent short on th 5 volt reference circuit #1	ECM Vref3 < or ECM Vref3 > or the difference between ECM filtered Vref3 and Vref3 >	5.125		Run/Crank voltage or Powertrain relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Trips: 1 Type: A MIL:
				0.05				YES

ECM SECTION Page 115 of 215

Component/	Fault		Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Fuel Pump Control Module (FPCM) Requested MIL Illumination	P069E	Monitors the FPCM MIL request line to determine when the FPCM has detected a MIL illuminating fault.	Fuel Pump Control Module Emissions- Related DTC set			Time since power-up > 3 seconds	Continuous	Type A 1 trips
5 Volt Reference #4 Circuit	P06A3	Detects a continuous or intermittent short on th 5 volt reference circuit #2	or ECM Vref4 >	5.125			19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	1
			or the difference between ECM filtered Vref3 and Vref3 >					Type:
				0.05				MIL: YES
Internal Control Module Knock Sensor Processor	P06B6	This diagnostic checks for a fault with the internal test	Gated FFT Diagnostic Output	> OpenTestThreshLo and < OpenTestThreshHi	Diagnostic Enabled?	Enabled	First Order Lag Filter with Weight Coefficient	Type: B MIL: YES Trips:
1 Performance		of the Open Circuit	(VaKNKD_k_OpenTestCk tIntFilter[0])	See Supporting Tables	Engine Speed	> 600 RPM and < 4250 RPM		
		Diagnostic			Engine Air Flow Engine running	≥ 40 mg/cylinder and ≤ 2000 mg/cylinder ≥ 5.0 seconds	Weight Coefficient = 0.0100	
						Updated each engine event		

Component/	Fault		Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Transmission Control Module (TCM) Requested MIL Illumination	P0700	Monitors the TCM MIL request line to determine when the TCM has detected a MIL illuminating fault.	Transmission Emissions- Related DTC set			Time since power-up > 3 seconds	Continuous	Type A 1 trips MIL: NO
Clutch Pedal	P0806	Detects if Clutch	Filtered Clutch Pedal		N/TOS Ratio	Must match actual gear (i.e.		
Position Sensor	1 0000	Pedal Position	Position Error	> 2 %	14/100 Ratio	vehicle in gear)	25 ms loop	1 Trip(s)
Circuit Range /		Sensor is Stuck in a		2 70	Transfer Case	Not in 4WD Low range	Continuous	1
Performance		range indicative of a	determined to be in gear		vehicle speed	> 1.2 MPH	1	Type A
T Griormanice		vehicle NOT in gear, when the vehicle is determined to be in gear. Gear determination is made by verifying that engine RPM/ Trans Output Speed (N/TOS) ratio represents a valid gear.			Engine Torque	> EngTorqueThreshold Table		Туре А
					Clutch Pedal Position	< ResidualErrEnableLow Table OR		
					Olistala Da dal Da sitiana	OK T	-	
					Clutch Pedal Position			
						> ResidualErrEnableHigh Table		
					No	Active DTCs:		
						sitionSensorCktLo FA		
					C Trans Output S	rankSensorFA haft Angular Velocity Validity eSpeedSensor_FA		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Clutch Pedal	P0807	Detects Continuous	Clutch Position Sensor		Engine Not Cranking		25 ms loop	
Position Sensor		Circuit Out-of-Range		< 4 % of Vref	System Voltage	> 9.0 Volts	Continuous	1 Trip(s)
Circuit Low		Low or Open	for	200 counts out of			_	
				250 samples				Type A
					No active DTCs:	5VoltReferenceB_FA		
Clutch Pedal	P0808	Detects Continuous	Clutch Position Sensor		Engine Not Cranking		25 ms loop	
Position Sensor	1 0000	Circuit Out-of-Range		> 96 % of Vref	System Voltage	> 9.0 Volts	Continuous	1 Trip(s)
Circuit High		High		200 counts out of	- Joseph Volkago	0.0 1010	Continuous	1 1110(0)
		19		250 samples			4	T A
								Type A
					No active DTCs:	5VoltReferenceB_FA		
Clutch Pedal	P080A	Detects Invalid	Fully Applied Learn	< 9.0 %	OBD Manufacturer		250 ms loop	1 Trip(s)
Position Not		Clutch Pedal Fully	Position	3.0 /0	Enable Counter		Continuous	
Learned		Applied Learn				= 0	Continuous	T A
		Position values						Type A
			OR					
			Fully Applied Learn	> 33.0 %				
			Position					
Traction Control	P0856	Determines if torque	Serial Communication 2's	Message <> 2's			All except	
Torque Request		request from the	complement message -	complement of			Class2 PWM:	
Circuit		EBTCM is valid	(\$140 for PPEI2 or \$1C9	message	Social communication	No loss of communication	Count of 2's	
			for PPEI3, \$1CA for		to EBTCM (U0108)	No loss of confindingation	complement	
			Hybrid))		to LB row (Go 100)		values not equal	
							>= 16	
					Power Mode	= Run	Performed every	
					Engine Running	= True	12.5 msec	
						1		
			OR	1				
			Serial Communication	Message rolling	Status of traction in		6 rolling count	
			message (\$140 for PPEI2		GMLAN message	= Traction Present	failures out of 10	
			or \$1C9 for PPEI3, \$1CA	previous message	(\$4E9)	- Haction Heacht	samples	
			for Hybrid)) rolling count	rolling count value			Performed every	
			value	plus one			12.5 msec	
	1						I .	1

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			time period Torque request greater	Requested torque			>= 3 multi- transitions out of 5 samples. Performed every 200 ms >= 6 out of 10 samples Performed every 12.5 msec	1 trip(s) Special Type C
Inlet Airflow System Performance (naturally aspirated)	P1101	Determines if there are multiple air induction problems affecting airflow and/or manifold pressure.	Filtered Throttle Model Error AND (ABS(Measured Flow – Modeled Air Flow) Filtered OR ABS(Measured MAP – MAP Model 1) Filtered	<= 500 kPa*(g/s) > 15 grams/sec > 25.0 kPa)	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 7000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 125 Deg C > 125 Deg C >= 0.25 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM	Continuous Calculation are performed every 12.5 msec	Type B 2 trips

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			ABS(Measured MAP – MAP Model 2) Filtered	> 25.0 kPa		Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor Based on MAF Est		
						MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM		
						MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM		
					No Active DTCs:	See table "IFRD Residual Weighting Factors". MAP_SensorCircuitFA EGRValve_FP EGRValvePerformance_FA MAF_SensorCircuitFA		
						CrankSensor_FA ECT_Sensor_FA ECT_Sensor_Ckt_FP IAT_SensorFA IAT_SensorCircuitFP		
Inlet Airflow System	P1101	Determines if there	See table "Turbocharger		Engine Speed	>= 400 RPM	Continuous	Туре В
Performance (turbocharged)		are multiple air induction problems affecting airflow and/or manifold pressure.	Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC.		Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	<= 6000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 100 Deg C	Calculation are performed every 12.5 msec	2 trips
			MAF model fails when			>= 0.50		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			ABS(Measured Flow – Modeled Air Flow) Filtered	> 16 grams/sec		Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor Based on MAF Est		
			MAP1 model fails when					
			ABS(Measured MAP – MAP Model 1) Filtered	> 20.0 kPa		MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM		
			MAP2 model fails when ABS(Measured MAP –			MAP Model 2 Error multiplied by		
			MAP Model 2) Filtered			MAP2 Residual Weight Factor based on RPM		
				> 25.0 kPa				
			MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered	> 25.0 kPa		MAP Model 3 Error multiplied by MAP Residual Weight Factor based on RPM		
			TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered			TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM		
			TPS model fails when	> 25.0 kPa		Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM		
			Filtered Throttle Model Error	> 250 kPa*(g/s)				
			TIAP Correlation model fails when			See table "IFRD Residual Weighting Factors".		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			High Engine Air Flow is TRUE AND					
			Measured TIAP - measured MAP - offset as a function of engine speed See table "TIAP-MAP Correlation Offset" OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as	> 25.0 kPa	No Active DTCs:	MAP_SensorCircuitFA EGRValve_FP EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA ECT_Sensor_Ckt_FP IAT_SensorFA IAT_SensorCircuitFP IAT2_SensorFA IAT2_SensorCircuitFP		
			a function of engine speed			TC_BoostPresSnsrCktFA AmbientAirDefault		
			See table "TIAP-Baro Correlation Offset"	> 25.0 kPa				
			TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time					
			OR High Engine Air Flow has been TRUE for a period of time	> 2.0 seconds				
				> 2.0 seconds				
			High Engine Air Flow is TRUE when					
			Mass Air Flow					
				> a threshold in gm/sec as a function of engine speed				

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			AND	See table "TIAP-MAP Correlation Min Air Flow"				
l			Manifold Pressure	> a threshold in kPa as a function of engine speed				
			AND Filtered Mass Air Flow -	See table "TIAP-MAP Correlation Min MAP"				
			Mass Air Flow	< 2.0 gm/sec				
			Low Engine Air Flow is TRUE when					
			Mass Air Flow					
				< a threshold in gm/sec as a function of engine speed				
			AND	See table "TIAP-Baro Correlation Max Air Flow"				
			Manifold Pressure	< a threshold in kPa as a function of engine speed				
			AND	See table "TIAP-Baro Correlation Max MAP"				
			AND Mass Air Flow - Filtered Mass Air Flow					
				< 2.0 gm/sec				

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable		MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Intake Air Temperature Sensor 3 Circuit Performance (applications with humidity sensor and manifold temperature sensor)	Air erature or 3 t mance cations umidity r and old erature P112B Detects an IAT3 sensor that has stuck in range by comparing to IAT and IAT2 at startup	ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up IAT - Power Up IAT3) AND ABS(Power Up IAT2 - Power Up IAT3)	<= 25 deg C > 25 deg C > 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA		Type B 2 trips	
			Power Up IAT is between Power Up IAT2 and Power Up IAT3 AND ABS(Power Up IAT2 - Power Up IAT3) AND ABS(Power Up IAT - Power Up IAT3) > ABS(Power Up IAT - Power Up IAT3) > ABS(Power Up IAT - Power Up IAT3) > ABS(Power Up IAT - Power Up IAT2)	> 25Deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Power Up IAT2 is between Power Up IAT and Power Up IAT3 AND ABS(Power Up IAT - Power Up IAT3) AND ABS(Power Up IAT2 - Power Up IAT3) > ABS(Power Up IAT2 - Power Up IAT3) > ABS(Power Up IAT2 - Power Up IAT3) >	> 25Deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	
Intake Air Temperature Sensor Circuit 3 Low (applications with manifold temperature and humidity)	P112C	Detects a continuous short to ground in the IAT 3 signal circuit or the IAT 3 sensor	Raw IAT 3 Input	< 49 Ohms (~150 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B 2 trips
Intake Air Temperature Sensor Circuit 3 High (applications with manifold temperature and humidity)	P112D	Detects a continuous open circuit in the IAT 3 signal circuit or the IAT 3 sensor	Raw IAT 3 Input	> 169,523 Ohms (~-60 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B 2 trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL illum.
Humidity Sensor Circuit Low	P11C2	· · · · · · · · · · · · · · · · · · ·	Humidity Duty Cycle	<= 5.0%	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B 2 trips
Humidity Sensor Circuit High	P11C3	Detects a continuous open or short to low in the Humidity Sensor circuit	Humidity Duty Cycle	>= 95.0%	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B 2 trips
Cold Start Emissions Reduction System Fault	P1400	Model based test computes power from exhaust flow and thermal energy resulting from elevated idle speed and retarded spark advance. Detects if the cold start emission reduction system has failed resulting in the delivered power being out of range.	Average desired accumulated exhaust power - Average estimated accumulated exhaust power OR Average desired accumulated exhaust power - Average estimated accumulated exhaust power (EWMA filtered)	< -32.00 KJ/s (high RPM failure mode) > 6.50 KJ/s (low RPM failure mode)		agnostic, the Cold Start Emission y must be Active per the following:	Runs once per trip when the cold start emission reduction strategy is active Frequency: 100ms Loop Test completes after 10 seconds of accumulated qualified data.	
				-	Catalyst Temperate Engine Cools The Cold Start Embe exiting. The second Start Emperate Catalyst Temperate Engine Run Time	<u> </u>		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
ystem	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					Engine Coola	nt >= 40.00 degC		
						her Enable Criteria		
						ed < 1.24 MPH he accel pedal. This checks that the	4	
						sition (comprehending deadband and		
						esis) is essentially zero.		
						,		
					A change in throttle	e position (tip-in/tip-out) will initiate a	-	
						tion of the average qualified residual		
						value. When the		
					OBD Manufactur	er 0	1	
					Enable Count			
						> 5.00 seconds		
					Timer			
					the diagnosti	c will continue the calculation.		
					Clutch Pedal Top o	of Travel Achieved and Clutch Pedal	-	
						hieved. Refer to the "Clutch Pedal		
					Top of Travel Ach	nieved criteria" and "Clutch Pedal		
						Achieved criteria" section of the		
					"Suppo	rting Tables" tab criteria		
							1	
					Idle Speed Control	Active		
					System	1	-	
						General Enable		
						DTC's Not Set		
						eleratorPedalFailure		
						ECT_Sensor_FA	-	
						T_SensorCircuitFA C2 SensorCircuitFA	-	
						nkSensorFaultActive	1	
						ellnjectorCircuit_FA	1	
						MAF_SensorFA	1	
						MAP_SensorFA		
						neMisfireDetected_FA		
						Clutch Sensor FA		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					IAC_	SystemRPM_FA		-
						nOutputDriver_FA]	
					P050A (C	coldStrt_IAC_SysPerf)]	
					P050B (0	ColdStrtIgnTmngPerf)]	
						TPS_FA]	
						eSpeedSensor_FA	J	
						erenceMAP_OOR_FIt	J	
						sionEngagedState_FA	1	
					· ·	eTorqueInaccurate		
Transmission Engine Speed Request Circuit	P150C	Determines if engine speed request from the TCM is valid	Serial Communication rolling count value	+ 1 from previous \$19D message (PTEI3)	Diagnostic enable bit	1	Diagnostic runs in 12.5 ms loop	2 trips Type B
·			Transmission engine speed protection	not equal to 2's complement of transmission engine speed request + Transmission alive rolling count	Engine run time	0.50 sec		
					# of Protect Errors	16 protect errors out of 10 samples		
						5 rolling count errors out of 10 samples		
						IAC_SystemRPM_FA		
						(U0101)		
					Engine Running	= TRUE		
						Run Crank Active		
Steady State Actuation Fault	P1516	Detect an inablity to maintain a steady state throttle position	Throttle is considered to be steady state when: Change in throttle position over 12.5 msec is <	0.25 percent		Run/crank voltage or Powertrain relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	0.49 ms	Trips: 1 Type: A MIL: YES

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Ignition Voltage Correlation	P1682	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage & the Powertrain Relay Ignition Voltage	Run/Crank – ETC Run/Crank >		voltage > and Run/crank voltage >		240/480 counts or 0.1750sec continuous; 12.5 ms/count in main processor	Trips: 1 Type: A MIL: YES
Internal Control Module Redundant Memory Performance	P16F3	Detect Processor Calculation faults due to RAM corruptions, ALU failures and ROM failures	Desired engine torque request greater than redundant calculation plus threshold	59.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	Trips: 1 Type: A MIL: YES
			Cylinders active greater than commanded AFM apps only Does not apply to E83	1 cylinder		Engine speed greater than 0rpm and less than 3200rpm	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11
			Difference between Cruise Axle Torque Arbitrated Request and Cruise Axle Torque Request exceeds threshold	221.05 Nm		Cruise has been engaged for more than 4.00 seconds	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL illum.
oyatem T	Code	Description		60.00 Nm	i arameters	Ignitions Ignition in unlock/accessory, run or crank	Up/down timer 138 ms continuous, 0.5 down time multipier	mun.
			No fast unmanaged retarded spark above the applied spark plus the threshold	Table, f(Erpm). See supporting tables		Engine speed greater than 0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Absolute difference of adjustment factor based on temperature and its dual store above threshold	2.76 m/s		Ignition in unlock/accessory, run or crank	Up/down timer 228 ms continuous, 0.5 down time multipier	
			1) Absolute difference of redundant calculated engine speed above threshold 2)Time between lores events and its dual store do not match	KeEPSD_n_LoresSe curBndry 1052 RPM		Engine speed greater than 0 RPM	Up/down timer 128 ms continuous, 0.5 down time multipier	
			After throttle blade pressure and its dual store do not match	N/A		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
ystem	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Speed Control's Preditcted Torque Request and its dual store do not match	N/A		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Engine oil temperature and its dual store do not match	N/A		Ignition in unlock/accessory, run or crank	Up/down timer 438 ms continuous, 0.5 down time multipier	
			Desired throttle position greater than redundant calculation plus threshold	9.32 percent		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference of the rate limited pre-throttle pressure and its redundant calculation greater than threshold	1.88 kpa		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Throttle desired torque above desired torque plus threshold	60.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Desired filtered throttle torque exceeds the threshold plus the higher of desired throttle torque or modeled throttle torque	60.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Torque feedback proportional term is out of allowable range or its dual store copy does not match	High Threshold 30.00 Nm Low Threshold -30.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
				56.25 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Difference of Final Torque feedback proportional plus integral term and its redundant calculation is out of bounds given by threshold range	High Threshold 60.00 Nm Low Threshold -60.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Difference of torque desired throttle area and its redundant calculation is out of bounds given by threshold range	High Threshold 0.50% Low Threshold -0.50%		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			model coefficients and its	High Threshold 0.0002110 Low Threshold -0.0002110		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Difference of base friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 60.00Nm Low Threshold -60.00Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Accessory drive friction torque is out of bounds given by threshold range	High Threshold 60.00 Nm Low Threshold 0.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			AC friction torque is greater than commanded by AC control software or less than threshold limit			Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Difference of Oil temperature delta friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 60.00 Nm Low Threshold -60.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11
			Generator friction torque is out of bounds given by threshold range	High Threshold 60.00 Nm Low Threshold 0.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
				High Threshold 60.00 Nm Low Threshold 0.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Filtered Torque error magnitude or its increase rate of change is out of allowable range or its dual store copy do not match	High Threshold 60.00 Nm Low Threshold -60.00 Nm Rate of change threshold 3.75 Nm/loop		Engine speed >0rpm MAF, MAP and Baro DTCs are false	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Torque error compensation is out of bounds given by threshold range	High Threshold 60.00 Nm Low Threshold 0.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Delta Torque Baro compensation is out of bounds given by threshold range	High Threshold 5.30 Nm Low Threshold -2.19 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			1) Difference of reserve torque value and its redundant calculation exceed threshold 2) Reserve request does not agree with operating conditions or Difference of final predicted torque and its redundant calculation exeed threshold 3) Rate of change of reserve torque exceeds threshold, increasing direction only 4) Reserve engine torque above allowable capacity threshold	1) 59.00 Nm 2) NA 3) 59.00 Nm 4) 59.00 Nm		1&2) Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 60.00 Nm 3&4) Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			AC friction torque is greater than commanded by AC control software	40.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 1

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Absolute difference of the calculated spark offset for equivalence ratio and its redundant calculation greater than threshold	13.38 degrees		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Engine Vacuum and its dual store do not match	N/A		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference of the calculated Intake Manifold Pressure during engine event versus during time event is greater than threshold	Table, f(Engine Torque). See supporting tables		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Min. Axle Torque Capacity is greater than threshold	0.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Predicted torque for zero pedal determination is greater than calc'ed limit.	Table, f(Engine, Oil Temp). See supporting tables + 60.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Commanded Predicted Axle Torque and its dual store do not match	1 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
ystem	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Steady State Estimated Engine Torque and its dual store are not equal	N/A		AFM not changing from Active to Inactive and preload torque not changing and one loop after React command Engine speed >0rpm	Up/down timer 1988 ms continuous, 0.5 down time multipier	
			Difference of Weighting factor for number of cylinders fueled and its redundant calculation is above threshold	0.26		Engine run flag = TRUE > 10.00s	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Difference of minimum spark advance limit and its redundant calculation is out of bounds given by threshold range	13.38 degrees		Ignition in unlock/accessory, run or crank	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Difference of commanded spark advance and adjusted delivered is out of bounds given by threshold range	13.38 degrees		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Estimated Engine Torque and its dual store do not match	60.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Estimated Engine Torque without reductions due to torque control and its dual store are not match			Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description		Value	Parameters	Conditions	Required	illum.
			Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by threshold range	13.38 degrees		Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 60.00 Nm	Up/down timer 428 ms continuous, 0.5 down time multipier	
			Absolute difference of Engine Capacity Minimum Running Immediate Brake Torque Excluding Cylinder Sensitivity and its redundant calculation is out of bounds given by threshold range	60.00 Nm		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multipier	
			cylinder greater than two	Threshold: Dynamically calculated based on current engine conditions Fault Pending Threshold: 100 ms		Engine speed > 500rpm	Up/down timer 428 ms continuous, 0.5 down time multipier	
			Rate limited cruise axle torque request and its dual store do not match	221.05 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 163 ms continuous, 0.5 down time multipier	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
oystem .	Code	Description	1) Absolute difference of	1) 5.00 % 2) NA 3) NA	Parameters	Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	illum.
			Commanded axle torque is greater than its redundant calculation by threshold	1768.40 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded axle torque is less than its redundant calculation by threshold	-65535.00 Nm		Ignition in unlock/accessory, run or crank Redundant commanded axle torque <65535.00 Nm	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Preload Throttle Area is greater than its redundant calculation by threshold AFM apps only	10.00%		Engine speed >0rpm	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not use Series 1

ECM SECTION Page 138 of 215

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Does not apply to E83					
			Preload timer and its redundant calculation do not equal	NA		Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11
			AFM apps only					
			Does not apply to E83					
			Preload Throttle Area and its dual store do not equal			Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time	Not used Series 11
			AFM apps only				multipier	
			Does not apply to E83					
			Commanded engine torque due to fast actuators and its dual store do not equal	NA		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded engine torque due to slow actuators and its dual store do not equal	NA		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Arbitrated Air-Per- Cylinder filter coefficient is out of bounds given by threshold range	High Threshold 1.000 Low Threshold 0.074		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Launch spark is active but the launch spark redundant path indicates it should not be active	NA		Engine speed < 7800.00 or 7900.00 rpm (hysteresis pair)	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Rate limited vehicle speed and its dual store do not equal	NA		Time since first CAN message with vehicle speed >= 0.500sec	10/20 counts; 25.0msec/count	
			transfer case neutral request from four wheel drive logic does not match with operating conditions	NA			32/6 counts; 25.0msec/count	
			FWD Apps only transfer case neutral and			Ignition in unlock/accessory, run	255/6 counts;	
			its dual store do not equal FWD Apps only			or crank	25.0msec/count	
			Throttle progression mode and its dual store do not equal	NA		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			conversion factor is out of bounds given by threshold range	High Threshold 1.10 T/C Range Hi 0.10 T/C Range Lo Low Threshold 1.10 T/C Range Hi 0.10 T/C Range Lo		Ignition in unlock/accessory, run or crank	255/6 counts; 25.0msec/count	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			TOS to wheel speed conversion factor and its dual store do not equal	NA		Ignition in unlock/accessory, run or crank	255/6 counts; 25.0msec/count	
			Cylinders active greater than commanded	2 cylinders		Engine run flag = TRUE > 2.00s Number of cylinder events since engine run > 24 No fuel injector faults active	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Absolute difference of Friction torque and its redundant calculation is out of bounds given by threshold range	60.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference of Accessory torque and its redundant calculation is out of bounds given by threshold range	60.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference of Filtered Air-per-cylinder and its redundant calculation is out of bounds given by threshold range	112.54 mg		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference between the previous Final Advance and the current Final Advance not Adjusted for Equivalence Ratio is out of bounds given by threshold range	13.38 degrees		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Desired Throttle Area calculated does not equal its redundant calculation	N/A		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Equivance Ratio torque compensation exceeds threshold	-60.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Absolute difference between Equivance Ratio torque compensation and its dual store out of bounds given bt threshold	60.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Commanded Predicted Engine Torque and its dual store do not match	N/A		Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11
			Zero pedal axle torque is out of bounds given by threshold range	High Threshold 1768.40 Nm Low Threshold -65535.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Creep Coast Axle Torque is out of bounds given by threshold range	High Threshold 1768.40 Nm Low Threshold -65535.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Torque Learn offset is out of bounds given by threshold range	High Threshold 0.00 Nm Low Threshold 0.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			One step ahead calculation of air-per-cylinder and two step ahead is greater than threshold	80.00 mg		Engine speed >500rpm	Up/down timer 428 ms continuous, 0.5 down time multipier	
			Difference between Unmanaged Spark and PACS Spark is greater than threshold	13.38 degrees		Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11
			Predicted torque for uncorrected zero pedal determination is greater than calc'ed limit.	Table, f(Engine, Oil Temp). See supporting tables + 60.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Idle speed control calculated predicted minimum torque request exceeds calculated torque limit	Table, f(Engine, Oil Temp). See supporting tables + 60.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Idle speed control calculated predicted minimum torque without reserves exceeds calculated torque limit	Table, f(Engine, Oil Temp). See supporting tables + 60.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Difference between Driver Requested Immediate Torque primary path and its secondary exceeds threshold	1768.40 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11
			PTO Torque Request exceeds allowed rate limited PRO Torque Request	500.00 Nm/25ms		Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11
			Engine Speed Lores Intake Firing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Engine Speed Lores Intake Firing timing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Engine Speed Lores Intake Firing (12.5ms based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Cold Delta Friction Torque and its dual store do not match	N/A		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Driver Predicted Request is greater than its redundant calculation plus threshold Driver Predicted Request is less than its redundant calculation minus threshold	1768.40 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Driver Immediate Request is less than its redundant calculation minus threshold	1768.40 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded Immediate Request is greater than its redundant calculation plus threshold Commanded Immediate Request is less than its redundant calculation minus threshold	1768.40 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11
			Commanded Immediate Response Type is set to Inactive	N/A		Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11
			Commanded Immediate Engine Request is greater than its redundant calculation plus threshold	60.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Commanded Predicted Engine Request is greater than its redundant calculation plus threshold	60.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded Hybrid Predicted Crankshaft Request is greater than its redundant calculation plus threshold	4096.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11
			Commanded Hybrid Immediate Crankshaft Request is less than its redundant calculation minus threshold	4096.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11
			Engine Predicted Request Without Motor is greater than its redundant calculation plus threshold	59.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/	Fault Code	Monitor Strategy	Malfunction	Threshold	Secondary Parameters	Enable	Time	MIL
System	Code	Description	Criteria Engine Immediate Request Without Motor is greater than its redundant calculation plus threshold	Value 59.00 Nm	Parameters	Conditions Ignition in unlock/accessory, run or crank	Required Up/down timer 175 ms continuous, 0.5 down time multipier	illum.
			Positive Torque Offset is greater than its redundant calculation plus threshold Positive Torque Offset is less than its redundant calculation minus threshold			Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Engine Capacity Minimum Immediate Without Motor is greater than its dual store plus threshold	60.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Engine Capacity Minimum Engine Off is greater than threshold	0 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Engine Capacity Minimum Engine Immediate Without Motor is greater than threshold	0 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11
			Regeneration Brake Assist is not within a specified range	Brake Regen Assist < 0 Nm or Brake Regen Assist > 1000.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 2048 ms continuous, 0.5 down time multipier	Not used Series 11
			Does not apply to E83					
			Cylinder Spark Delta Correction exceeds the absolute difference as compared to Unadjusted Cylinder Spark Delta	13.38 degrees		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Cylinder Torque Offset exceeds step size threshold 2. Sum of Cylinder Torque Offset exceeds sum threshold	1. 20.00 Nm 2. 10.00 Nm		Ignition in unlock/accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable		MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Intake Manifold Tuning (IMT) Valve Stuck Open	P2070	Detects an Intake Manifold Tuning Valve that is stuck in the open position	Time after the close command without the Intake Manifold Tuning Valve reaching the closed position	>= 5.00 seconds	Intake Manifold Tuning Valve is commanded closed No Active DTCs:	P0660 P2077 P2078	320 failures out of 400 samples 1 sample every 12.5 msec	Type B 2 trips
Intake Manifold Tuning (IMT) Valve Stuck Closed		Detects an Intake Manifold Tuning Valve that is stuck in the closed position	Time after the open command without the Intake Manifold Tuning Valve reaching the open position	>= 5.00 seconds	Intake Manifold Tuning Valve is commanded closed No Active DTCs:	P0660 P2077 P2078	320 failures out of 400 samples 1 sample every 12.5 msec	Type B 2 trips
Intake Manifold Tuning (IMT) Valve Position Sensor/ Switch Circuit Range/ Performance		Valve Actuator that has initiated its learn sequence for too long a period of time, or too many times per ignition cycle	for	>= 5.0% <= 35.0% >= 5.0 seconds >= 5.0% <= 35.0% >= 0.2 seconds >= 10 times in one ignition cycle	Powertrain Relay Voltage Powertrain Relay Voltage Engine Run Time	>= 11.00 Volts <= 999.00 Volts >= 1.0 seconds		Type B 2 trips
Intake Manifold Tuning (IMT) Valve Position Sensor/ Switch Circuit Low		Detects a continuous open or short to low in the Intake Manifold Tuning Valve Position Sensor circuit	Valve Position	>= 95.0%	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B 2 trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL illum.
Intake Manifold Tuning (IMT) Valve Position Sensor/ Switch Circuit High	P2078	Detects a continuous short to high in the Intake Manifold Tuning Valve Position Sensor circuit		<= 5.0%	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	
Post Catalyst Fuel Trim System Low Limit Bank 1 (Too Rich)	P2096	Determines if the post catalyst O2 sensor based fuel control system has been unable to adapt to a rich exhaust gas condition for too long.	Bank 1 Rich Fail Timer: Note: These timers will reset to 0 when the sample period of 50.0 seconds is reached. Evaluation will then start again.	> 35.0 seconds during a 50.0 second sample period.	Intrusive diagnostic fuel control:	> 1.0 seconds NOT active FALSE (i.e. catalyst monitor diagnostic) Please see "Long Term Secondary Fuel Trim Enable Criteria" in Supporting Tables	Frequency: Continuous Monitoring in 100ms loop	2 Trip(s) Type B
	Additiona	al notes, strategy and	l enable requirements:			l.		
	, taaitioiit	Note: If the post	Bank 1 Sample Timer wi					
		catalyst O2 voltage is too rich, the post catalyst O2 integral	The current post O2 airflow Accumulated Cell Time is		ell	See supporting tables: Selected Cells See supporting tables: Cell		
		offset voltage is decreased. The	7.1004.114.104.004.1111.110.10	g a		Accum Time Min	_	
		offset is applied to	Bank 1 Rich Fail Timer w	vill ingrament if some	la timar inaramanta Al	ND.		
		the front O2 sensor	Filtered post O2 voltage is			See supporting tables:	See supporting	
		rich/lean switchpoint in attempt to adjust the bulk average exhaust air/fuel ratio.	(filtered with first order la			O2RichThrsh	tables: Out of Window Timer	
		With a functional system, decreasing the switchpoint	Post catalyst O2 integral o	offset is less than		See supporting tables: Integral Offset Min		
		results in leaner gas. The adjusted offset value is retained between trips.						

Component/	Fault	Monitor Strategy	Malfunction	Threshold	,	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Post Catalyst Fuel Trim System High Limit Bank 1 (Too Lean)	P2097	adapt to a lean exhaust gas	Bank 1 Lean Fail Timer: Note: These timers will reset to 0 when the sample period of 50.0 seconds is reached. Evaluation will then start again.	> 35.0 seconds during a 50.0 second sample period.	Intrusive diagnostic fuel control:	> 1.0 seconds NOT active FALSE (i.e. catalyst monitor diagnostic) Please see "Long Term Secondary Fuel Trim Enable Criteria" in Supporting Tables	Frequency: Continuous Monitoring in 100ms loop	2 Trip(s) Type B
	Additiona	ı notes, strategy and	l enable requirements:	<u> </u>	<u> </u>	I	1	<u> </u>
			Bank 1 Sample Timer wi	Il increment if:				
		catalyst O2 voltage is too lean, the post	The current post O2 airflov		ell	See supporting tables: Selected Cells		
			Accumulated Cell Time is	greater than		See supporting tables: Cell	1	
		increased. The				Accum Time Min		
		offset is applied to	Bank 1 Lean Fail Timer v					,
		the front O2 sensor rich/lean switchpoint in attempt to adjust	nt (filtered with first order lag filt			See supporting tables: O2LeanThrsh	See supporting tables: Out of	
		the bulk average exhaust air/fuel ratio.					Window Timer	
		With a functional system, increasing	Post catalyst O2 integral o	ffset is greater than		See supporting tables: Integral Offset Max		_
		the switchpoint results in richer gas. The adjusted offset value is retained between trips.						

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Control Module Throttle Actuator Position Performance	P2101	Detect a throttle positioning error	Difference between measured throttle position and modeled throttle position >		not active and Throttle is being Controlled	, ,	1. 15 counts; 12.5 ms/count in the primary processor	Trips: 1 Type: A MIL: YES
			Difference between modeled throttle position and measured throttle position >		Ignition voltage failure is false (P1682)	11 5.5		
		2) Detect throttle control is driving the throttle in the incorrect direction or exceed the reduced power limit	Throttle Position > Throttle Position >	·	TPS minimum learn is active Reduced Power is True		2. 11 counts; 12.5 ms/count in the primary processor	
					Powertrain relay voltage	> 6.41 Volts		
Throttle return to default	P2119	Throttle unable to return to default throttle position after de-energizing ETC motor.	TPS1 Voltage > AND TPS2 Voltage >	1.757	Throttle de-energized No TPS circuit faults	Run/Crank voltage or Powertrain relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	0.4969 sec	Trips: 1 Type: C MIL: NO
					PT Relay Voltage >	No 5V reference error or fault for # 4 5V reference circuit (P06A3) 5.5		
Accelerator Pedal Position (APP) Sensor 1 Lo	P2122	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage <	0.463		relay voltage > 6.41 and reduced	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Trips: 1 Type: A MIL: YES
						No 5V reference error or fault for		

Component/	Fault		Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
						# 4 5V reference circuit (P06A3)		
Position (APP) or intermit or open in sensor #1	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage >	4.75		Run/Crank voltage or Powertrain relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Trips: 1 Type: A MIL: YES	
						No 5V reference error or fault for # 4 5V reference circuit (P06A3)		
Accelerator Pedal Position (APP) Sensor 2 Lo	P2127	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage <	0.325		Run/Crank voltage or Powertrain relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Trips: 1 Type: A MIL: YES
						No 5V reference error or fault for # 4 5V reference circuit (P0697)		
Accelerator Pedal Position (APP) Sensor 2 Hi	P2128	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage >	2.6		Run/Crank voltage or Powertrain relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Trips: 1 Type: A MIL: YES
						No 5V reference error or fault for # 4 5V reference circuit (P0697)		
Throttle Position (TP) Sensor 1-2 Correlation	P2135	1. Detects a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor	between TPS1 displaced >			Run/Crank voltage or Powertrain relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	1 & 2: 79/159 counts or 58 counts continuous; 3.125 ms/count in the main processor	1 Type:

ECM SECTION Page 153 of 215

Component/	Fault	0,	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			2. Difference between (normalized min TPS1) and (normalized min TPS2) >			No TPS sensor faults (P0122, P0123, P0222, P0223) No 5V reference error or fault for # 4 5V reference circuit (P06A3)		
						" Tov relevence should (Fooke)		
Accelerator Pedal Position (APP) Sensor 1-2 Correlation	P2138	Detects a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor	Difference between APP1 displaced and APP2 displaced >			Run/Crank voltage or Powertrain relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	1 & 2: 19/39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	Trips: 1 Type: A MIL: YES
			2. Difference between (normalized min APP1) and (normalized min APP2) >			No APP sensor faults (P2122, P2123,P2127, P2128)		
			,	2. 5.000% Vref		No 5V reference errors or faulst for # 3 & # 4 5V reference circuits (P06A3, P0697)		
Minimum Throttle Position Not Learned	P2176	TP sensors were not in the minmum learn window after multiple attempts to learn the minimum.	During TPS min learn on the Main processor, TPS Voltage >			Run/crank voltage or Powertrain relay voltage > 6.41 and reduced power is false, else the failure will be reported for all conditions	2.0 secs	Trips: 1 Type: A MIL:
			Number of learn attempts >	10 counts				YES
Cooling System Performance	P2181	This DTC detects thermostat malfunction (i.e. stuck open)	Engine Coolant Temp (ECT) is ≤ commanded temperature minus 11 Deg C and normalized ratio is ≤ than 1. When above is present for more than 0 seconds, fail counts start.		No Active DTC's Engine not run time Engine run time	120 ≤ Time ≤ 1400 seconds	225 failures out of 280 samples 1 sec/ sample Once per ignition key cycle	2 trips Type B

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					Fuel Condition	Ethanol ≤ 100%		
			Engine total airgrams is	1		-20.0 ≤ ECT ≤ 45.0 °C		
			accumulated when 11 ≤			-7°C ≤ IAT ≤ 60°C.		
			AirFlow ≤ 100 grams per					
			second.					
					T-Stat Heater duty			
					cycle commanded			
				1		11.0 ≤ Airflow ≤ 100.0 GPS		
			Ratio Definition:	i		11.0 = 7 timew = 100.0 Gr G		
			Current temp difference	1				
			between ECT and RCT					
			minus PwrUp difference					
			divided by total airgrams.					
			Note: Minimum total					
			airgrams is 500.0 grams.					
				ļ				
Barometric	P2227	Compares baro	Difference between baro	l	No Active DTCs:	AmbientAirPressCktFA	320 failures out of	Type P
Pressure (BARO)	F Z Z Z I	sensor to the	sensor reading and		NO ACTIVE DTCS.	ECT_Sensor_Ckt_FA	400 samples	2 trips
Sensor		calculated baro	estimated baro			IAT SensorFA	400 Samples	Z trips
Performance		estimate (part	estimated baro	> 15.0 kPa		MAF_SensorFA		
(turbocharged)		throttle calculation or		7 10.0 Ki a		AfterThrottlePressureFA	1 sample every	
(12		unthrottled MAP)	when distance since last			TPS_FA	12.5 msec	
		,	estimated baro update			TPS_Performance_FA	12.0 111300	
			estimated baro apadic			VehicleSpeedSensor_FA		
				<= 0.06 miles		Verileicopeedocrisor_i A		
				1 0.00 miles	Engine Run Time			
			OR		Linginio reali riinio	> 0.00 seconds		
						0.00 3000103		
			Difference between baro					
			sensor reading and					
			estimated baro					
				> 20.0 kPa				
				20.0 Ki d				
			when distance since last					
			estimated baro update					
			Sommatou baro apaato					
I				> 0.06 miles				
				0.00 1111100				
			Engine Not Rotating					
			- ngmo riot riotating	I		Ī	1	1

Component/	Fault		Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			Case: Barometric Pressure OR	< 50.0 kPa	Time between current ignition cycle and the last time the engine was running		4 failures out of 5 samples	
			Barometric Pressure	> 115.0 kPa	was ranning	> 10.0 seconds	1 sample every 12.5 msec	
					Engine is not rotating			
					No Active DTCs:	EngModeNotRunTmErr MAP_SensorFA AAP_SnsrFA SCIAP_SensorFA AAP2_SnsrFA		
					No Pending DTCs:	MAP_SensorCircuitFP AAP_SnsrCktFP SCIAP_SensorCircuitFP AAP2_SnsrCktFP		
Barometric Pressure (BARO) Sensor Circuit Low	P2228	Detects a continuous short to low or open in either the signal circuit or the BARO sensor.	BARO Voltage	< 40.0 % of 5 Volt Range (2.0 Volts = 42.6 kPa)	Engine Run Time	> 0.00 seconds	80 failures out of 100 samples	Type B 2 trips
							12.5 msec	
Barometric Pressure (BARO) Sensor Circuit High (boosted	P2229	Detects an open sensor ground or continuous short to high in either the	BARO Voltage	> 90.0 % of 5 Volt Range (3.0 Volts = 61.4 kPa)	Engine Run Time	> 0.00 seconds	80 failures out of 100 samples	Type B 2 trips
applications)		signal circuit or the BARO sensor.					1 sample every 12.5 msec	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL illum.
Barometric Pressure (BARO) Sensor Circuit Intermittent (boosted applications)	essure (BARO) nsor Circuit ermittent posted plications) rbo/Super P2261 Detect Stuck		String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current BARO reading - BARO reading from 12.5 milliseconds previous)		No Active DTCs:	AmbientAirPressCktFA ECT_Sensor_FA IAT_SensorFA MAF_SensorFA AfterThrottlePressure_NA TPS_FA TPS_Performance_FA VehicleSpeedSensorError	10 failures out of 20 samples	Type B 2 trips
Turbo/Super Charger Bypass Valve - Mechanical Turbocharge r with	P2261	Detect Stuck Closed Bypass Valve	Accumulation time is high pass filtered. Accumulated air mass flow or boost pressure larger then thresholds	0.25 Second < Accumulation time < 0.85 Second	Diagnosis Enabled Engine Speed Pressure ratio over the compressor	Disabled >= 1800 rpm > KtBSTD_r_ExcsvBstPresLim Enable condition kept true for 1.5 seconds extra	5 Failed tests out of 5 Tests 1 sample every 25ms	Type B 2 trips
wastegate. Not supercharge r with mechanical compressor			Filter Frequency Filtered Air Mass Flow Filtered Boost Pressure	12.00 Hz > 50.000 g/s > 40.00 kPa	Relative Boost Pressure (Boost - Ambient) and Negative Transient in Manifold Air Pressure	See Tables in Supporting Tables Sheet IF (RelativeBoost < 3.0 kPa OR DerivativeMAP > 50.00 kPa/s)		
					Bypass Valve Commanded Opened	> 6.0 percent Enable condition kept true for 0.70 seconds extra		
					No Active DTCs:	TC_BoostPresSnsrFA MAF_SensorFA BSTR_b_TurboBypassCktFA		

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
O2 Sensor Signal Stuck Lean Bank 1 Sensor 2	P2270	This DTC determines if the post catalyst O2 sensor is stuck in a normal lean voltage range and thereby can no longer be used for post oxygen sensor fuel control or for catalyst monitoring. The diagnostic is an intrusive test (during coast) which increases the delivered fuel to achieve the required rich threshold.	Post O2 sensor signal AND The Accumulated mass air flow monitored during the Stuck Lean Voltage Test	< 260 mvolts > 60 grams	B1S2 Failed this key cycle System Voltage ICAT MAT Burnoff delay Green O2S Condition Low Fuel Condition Diag Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enable test Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enable test) Closed Ioop integral (after initially enabled) Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013A, P013B, P013E, P013F, P2270 or P2271 10.0 < Volts < 32.0 = Not Valid = Not Valid, See definition of Green Sensor Delay Criteria (B1S2) in Supporting Tables tab. = False 1400 ≤ RPM ≤ 3500 1350 ≤ RPM ≤ 3500 1350 ≤ RPM ≤ 3650 2 ≤ gps ≤ 20 28.0 ≤ MPH ≤ 77.7 24.9 ≤ MPH ≤ 80.8 mph 0.92 ≤ C/L Int ≤ 1.08 = TRUE not in control of purge not in estimate mode = enabled	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc= FALSE for the given Fuel Bank OR NaPOPD_b_Rapi dResponseActive = TRUE, multiple tests per trip are allowed.	2 trips Type B

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					All post sensor heater			
						= not active		
					O2S Heater on Time	≥ 40.0 sec		
					Predicted Catalyst			
					temp	550 ≤ °C ≤ 900		
					Fuel State	= DFCO possible		
							1	
						for at least 1.5 seconds, and then		
					the Force Cat Ric	h intrusive stage is requested.	-	
O2 Sensor Signal	P2271	This DTC	Post O2 sensor signal		No Active DTC's	TPS_ThrottleAuthorityDefaulted	_	2 trips
Stuck Rich Bank 1		determines if the	AND	> 100 mvolts		ECT_Sensor_FA	Frequency:	Type E
Sensor 2		post catalyst O2 sensor is stuck in a	AND			IAT_SensorFA	Once per trip	
		normal rich voltage	The Accumulated mass			MAF_SensorFA	Note: if NaPOPD_b_Res	
		range and thereby	air flow monitored during			MAP_SensorFA	etFastRespFunc=	
		can no longer be	the Stuck Rich Voltage			AIR System FA	FALSE for the	
		used for post oxygen				FuelInjectorCircuit_FA	given Fuel Bank	
		sensor fuel control or				FuelTrimSystemB1_FA	OR	
		for catalyst		> 30 grams		FuelTrimSystemB2_FA	NaPOPD_b_Rapi	
		monitoring. The				EngineMisfireDetected_FA	dResponseActive	
		diagnostic is an			D400 Felle 4 (15)	EthanolCompositionSensor_FA	= TRUE, multiple	
		intrusive test which				P013A, P013B, P013E, P013F or	tests per trip are	
		requests the DFCO				P2270 10.0 < Volts < 32.0	allowed.	
		mode to achieve the						
		required lean			ICAT MAT Burnoff			
		threshold.			delay	= Not Valid		4
						= Not Valid, See definition of		
						Green Sensor Delay Criteria		
					Green O2S Condition	(B1S2) in Supporting Tables tab.		
					Low Fuel Condition			
						= False		
						1400 ≤ RPM ≤ 3500		
					Engine Airflow	12 ≤ gps ≤ 20		
						28.0 ≤ MPH ≤ 77.7		
						0.92 ≤ C/L Int ≤ 1.08		
					Closed Loop Active	= TRUE		

System Code Description Criteria Value Parameters Conditions Evap Ethanol Post fuel cell Power Take Off EGR Intrusive diagnostic All post sensor heater delays O2S Heater on Time Predicted Catalyst temp Fuel State DTC's Passed DTC's Passed DTC's Passed DTC's Passed Parameters Conditions not in control of purge not in estimate mode enabled enot active and in estimate mode enabled enot active and in estimate mode enabled enot active and active and active and active and active and active and active active and active and active and active and active and active and active and active and active and active and active and active active and active and active and active and active and active and active and active active and active and active ac	Required	illum.
Ethanol Post fuel cell Power Take Off EGR Intrusive diagnostic All post sensor heater delays O2S Heater on Time Predicted Catalyst temp Fuel State DTC's Passed DTC's Passed DTC's Passed Power Take Off EGR Intrusive diagnostic and active = not active 40.0 sec 550 ≤ °C ≤ 900 = DFCO possible DTC's Passed = P2270 (and P2272 if applice) DTC's Passed = P013E (and P014A if	;able)	
Post fuel cell Power Take Off EGR Intrusive diagnostic All post sensor heater delays O2S Heater on Time Predicted Catalyst temp Fuel State DTC's Passed Post fuel cell enot active = not active > 40.0 sec > 550 ≤ °C ≤ 900 Fuel State DTC's Passed = P2270 (and P2272 if applic = P013E (and P014A if	;able)	
Power Take Off EGR Intrusive diagnostic All post sensor heater delays O2S Heater on Time Predicted Catalyst temp Fuel State DTC's Passed Predicted Cand P2272 if applic DTC's Passed Power Take Off EGR Intrusive diagnostic and active 1 02S Heater on Time Predicted Catalyst temp Fuel State DTC's Passed P2270 (and P2272 if applic	;able)	
EGR Intrusive diagnostic = not active All post sensor heater delays = not active O2S Heater on Time ≥ 40.0 sec Predicted Catalyst temp Fuel State DTC's Passed DTC's Passed = P2270 (and P2272 if applic DTC's Passed = P013E (and P014A if	;able)	
diagnostic = not active All post sensor heater delays = not active O2S Heater on Time ≥ 40.0 sec Predicted Catalyst temp 550 ≤ °C ≤ 900 Fuel State DTC's Passed = P2270 (and P2272 if applic DTC's Passed = P013E (and P014A if	:able)	
All post sensor heater delays O2S Heater on Time ≥ 40.0 sec Predicted Catalyst temp Fuel State DTC's Passed DTC's Passed DTC's Passed DTC's Passed Policy (and P2272 if applicy)	:able)	
delays O2S Heater on Time Predicted Catalyst temp Fuel State DTC's Passed DTC's Passed DTC's Passed DTC's Passed = not active ≥ 40.0 sec Predicted Catalyst temp Fuel State DFCO possible = P2270 (and P2272 if applic	;able)	
O2S Heater on Time Predicted Catalyst temp Fuel State DTC's Passed DTC's Passed DTC's Passed DTC's Passed DTC's Passed DTC's Passed	;able)	
Predicted Catalyst temp 550 ≤ °C ≤ 900 Fuel State DTC's Passed = P2270 (and P2272 if applic DTC's Passed = P013E (and P014A if	;able)	
Predicted Catalyst temp 550 ≤ °C ≤ 900 Fuel State DTC's Passed = P2270 (and P2272 if applic DTC's Passed = P013E (and P014A if	;able)	
temp Fuel State = DFCO possible DTC's Passed = P2270 (and P2272 if applic DTC's Passed = P013E (and P014A if	:able)	
DTC's Passed = P2270 (and P2272 if applic DTC's Passed = P013E (and P014A if	cable)	
= P2270 (and P2272 if applic DTC's Passed = P013E (and P014A if	cable)	
DTC's Passed = P013E (and P014A if	cable)	
applicable)		
DTC's Passed = P013A (and P013C if		
applicable)		
After above conditions are met:		
DFCO mode is continued (wo driver initiated pedal in	nnut)	
Di de mode is continued (wo driver initiated pedar in	iput).	
Transmission P2544 Determines if the Protect error - Serial Message <> two's	>= 16 Protect	
Control Torque torque request from Communication message complement of Diagnostic enabled/	errors during ke	ey
Request Circuit the TCM is valid - (\$199 - PTEI3) message displaying disabled	cycle.	´
	Performed ever	y
	12.5 msec	
		2 trip(s
OR OR		— ' ' '
Rolling count error - Message <> previous	>= 6 Rolling	Type E
Serial Communication message rolling	count errors out	t
message (\$199 - PPEI3) count value + one	of ten samples.	
rolling count value	Performed ever	у
Power Mode = Run	12.5 msec	

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
			OR	•				
			RAM error - Serial	Transmission torque	Engine Running	= True	>= 16 RAM errors	1
			Communication message	request value or			out of 32	
			(\$199 - PPEI3)	request type dual		> 0.50 Sec	samples.	
				store not equal	Run/Crank Active	0.50 Sec	Performed every	
						•	12.5 msec	
			OR					_
				> 450 Nm			>= 6 out of 10	
			Communication message				samples.	
			- (\$199 - PTEI3) TCM				Performed every	
			Requested Torque				12.5 msec	
			Increase					
			OR	I			> = 4 may albi	-
			Multi-transition error -				>= 4 multi- transitions out of	
			Trans torque intervention				5 samples.	
			type request change				Performed every	
							200 msec	
				Requested torque			200 111000	
				intervention type				
				toggles from not				
				increasing request to increasing request				1
ECM/PCM Internal	P2610	This DTC	Count Up Test:	increasing request	IAT Temperature	-256 °C ≤ Temperature ≤ 256 °C	Count Up Test:	2 trips
Engine Off Timer	1 2010	determines if the	Count of root.		li ti Tomporataro	200 0 = 10111porataro = 200 0	Count op 100t.	Type B
Performance		engine mode not	Time difference between		No active DTCs:		4 failures out of	. , , , ,
		running timer does	the current read and the			IAT_SensorFA	20 samples	
		not initialize or count	previous read of the				'	
		properly. There are	Timer					DTC sets
		two tests to ensure		> 1.50 seconds	Count Up Test:		1 sec / sample	on next
		proper functioning of					'	key cycle
		the timer: Count Up			Ignition key off			if failure
		Test (CUT) and			OR		Continuous from	detected
		Range Test (RaTe).			Engine off		key off or engine	
			Range Test:				off until controller	
			The variation of the				shutdown.	
			HWIO timer and mirror					
				> 25 %	Range Test:			
			at controller shutdown.		ECM is powering			
					down			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL illum.
		Count Up Test (CUT): Verifies that the HWIO timer is counting up with the proper increment.					Range Test: One time when the controller is powered down.	
		Range Test (RaTe): Runs a mirror timer to the HWIO timer. The mirror timer is started when the Engine Mode Not Run Timer is started. When the engine starts or when a controller shutdown is requested, the HWIO timer and mirror timer are compared.						
Control Module Communication Bus A Off	U0073	This DTC monitors for a BUS A off condition	Bus off failures	≥ 5 counts	CAN hardware is bus OFF for	> 0.1125 seconds	Diagnostic runs in 12.5 ms loop	2 Trip(s)
				≥ 5 counts	Diagnostic enable timer	> 3.0000 seconds		Туре В
			out of these samples					

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Lost Communication With TCM	U0101	for a loss of	Message is not received from controller for this amount of time.	Type B time = 10s Type C time = 12s Torque Security Ucode = varied and possibly much shorter time.	Run/Crank Voltage	11 volts ≤ Voltage ≤ 32 volts	The fail diagnostic runs in the 6.25 ms loop with pass conditions reported to the DFIR in the 1000ms loop.	1 Trip(s)
					Power mode is RUN			Type A
					Communication bus is not OFF			
					or is typed as a C code			
					Normal Communication is enabled			
					Normal Transmit capability is TRUE			
					The diagnostic system is not disabled			
					The bus has been on for	> 3.0000 seconds		
					A message has been selected to monitor.			
Lost Communication With Fuel Pump Control Module	U0109	for a loss of	Message is not received from controller for this amount of time.	Type B time = 10s Type C time = 12s Torque Security Ucode = varied and possibly much shorter time.	Run/Crank Voltage	11 volts ≤ Voltage ≤ 32 volts	The fail diagnostic runs in the 6.25 ms loop with pass conditions reported to the DFIR in the 1000ms loop.	2 Trip(s)
					Power mode is RUN			Туре В
					Communication bus is not OFF			
					or is typed as a C code			

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
					Normal Communication is enabled			
					Normal Transmit capability is TRUE			
					The diagnostic system is not disabled			
					The bus has been on for	> 3.0000 seconds		
					A message has been selected to monitor.			
Lost Communication With Anti-Lock Brake System (ABS) Control Module	U0121	This DTC monitors for a loss of communication with the ABS control module.	Message is not received from controller for this amount of time.	Type B time = 10s Type C time = 12s Torque Security Ucode = varied and possibly much shorter time.	Run/Crank Voltage	11 volts ≤ Voltage ≤ 32 volts	The fail diagnostic runs in the 6.25 ms loop with pass conditions reported to the DFIR in the 1000ms loop.	1 Trip(s)
					Power mode is RUN			Type C
					Communication bus is not OFF			Special Type C
					or is typed as a C code			
					Normal Communication is enabled			
					Normal Transmit capability is TRUE			
					The diagnostic system is not disabled			
					The bus has been on for	> 3.0000 seconds		
					A message has been selected to monitor.			

Component/	Fault	Monitor Strategy	Malfunction	Threshold	Secondary	Enable	Time	MIL
System	Code	Description	Criteria	Value	Parameters	Conditions	Required	illum.
Lost Communication With Body Control Module	U0140	This DTC monitors for a loss of communication with the Body Control Module.	Message is not received from controller for this amount of time.	Type B time = 10s Type C time = 12s Torque Security Ucode = varied and possibly much shorter time.	Run/Crank Voltage	11 volts ≤ Voltage ≤ 32 volts	The fail diagnostic runs in the 6.25 ms loop with pass conditions reported to the DFIR in the 1000ms loop.	1 Trip(s)
					Power mode is RUN			Type C
					Communication bus is not OFF			Special Type C
					or is typed as a C code			
					Normal Communication is enabled			
					Normal Transmit capability is TRUE			
					The diagnostic system is not disabled			
					The bus has been on for	> 3.0000 seconds		
					A message has been selected to monitor.			

ECM Supporting Tables

	-40.0000	-28.0000	-16.0000	-4.0000	8.0000	20.0000	32.0000	44.0000	56.0000	68.0000	80.0000	92.0000	104.0000	116.0000	128.0000	140.0000	152.0000
400	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
800	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
1200	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
1600	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
2000	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
2400	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
2800	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
3200	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
3600	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
4000	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
4400	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
4800	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
5200	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
5600	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
6000	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
6400	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
6800	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000

P0014 KtPHSD_phi_CamPosErrorLimEc1

X axis is Deg C

	Y	axis is RPM															
_	-40.0000	-28.0000	-16.0000	-4.0000	8.0000	20.0000	32.0000	44.0000	56.0000	68.0000	80.0000	92.0000	104.0000	116.0000	128.0000	140.0000	152.0000
400	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
800	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
1200	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
1600	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
2000	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
2400	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
2800	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
3200	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
3600	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
4000	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
4400	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
4800	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
5200	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
5600	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
6000	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
6400	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000
6800	10.0000	10.0000	10.0000	8.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000	6.0000

P0011 KtPHSD_t_StablePositionTimeIc1

X axis is Deg C Y axis is RPM

	-40.0000	-28.0000	-16.0000	-4.0000	8.0000	20.0000	32.0000	44.0000	56.0000	68.0000	80.0000	92.0000	104.0000	116.0000	128.0000	140.0000	152.0000
400	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
800	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
1200	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
1600	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
2000	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
2400	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
2800	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
3200	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
3600	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
4000	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
4400	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
4800	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
5200	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
5600	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
6000	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
6400	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000
6800	100.000	80.000	20.000	12.000	9.000	6.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	3.000	5.000	5.000	8.000

ECM Supporting Tables

P0014
KtPHSD_t_StablePositionTimeEc1

X axis is Deg C Y axis is RPM 92.0000 -40.0000 -28.0000 -16.0000 -4.0000 8.0000 20.0000 32.0000 44.0000 56.0000 68.0000 80.0000 104.0000 116.0000 128.0000 140.0000 152.0000 3.000 3.000 3.000 800 100.000 80.000 20.000 12.000 9.000 6.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 5.000 5.000 8.000 1200 100.000 80.000 20.000 12.000 9.000 6.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 5.000 5.000 8.000 1600 100.000 80.000 20.000 12.000 9.000 6.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 5.000 5.000 8.000 2000 80.000 20.000 12.000 9.000 6.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 5.000 5.000 8.000 100.000 2400 2800 100.000 80.000 20.000 12.000 9.000 6.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 5.000 5.000 8.000 12.000 8.000 80.000 20.000 100.000 9.000 6.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 5.000 5.000 3200 3600 12.000 100.000 80 000 20 000 9 000 6 000 3 000 3.000 3.000 3.000 3.000 3.000 3 000 3.000 5 000 5.000 8.000 12.000 6 000 3 000 3 000 3 000 3 000 5 000 8.000 100 000 80 000 20 000 9 000 3 000 3 000 3 000 3 000 5 000 4000 12.000 3.000 5.000 8.000 100.000 80.000 20.000 9.000 6.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 5.000 4400 4800 100.000 80 000 20.000 12.000 9 000 6 000 3 000 3.000 3.000 3.000 3.000 3.000 3.000 3 000 5 000 5.000 8.000 100.000 80 000 20 000 12.000 9 000 6 000 3 000 3 000 3.000 3.000 3 000 3.000 3 000 3.000 5 000 5 000 8.000 5200 100.000 80.000 20.000 12.000 9.000 6.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 5.000 5.000 8.000 5600 100.000 80.000 20.000 12.000 9.000 6.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 5.000 5.000 8.000 6000 100.000 80.000 20.000 12.000 9.000 6.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 3.000 5.000 5.000 8.000 6400 100.000 80.000 12.000 9.000 6.000 3.000 3.000 3.000 3.000 3.000 5.000 5.000 8.000 8.000

P0420, P0430

MinimumEngineRunTime

 Coolant Temp
 40
 50
 60
 70
 80

 Engine Run Time
 120
 120
 120
 120
 120

MinAirflowToWarmCatalyst

Engine Coolant 0 45 90 MinAirFlowToWrmCat 6 4 2

P0300-P0308: Idle SCD dt

(decel index (> Idle SCD dt AND > Idle SCD ddt Tables))

Load

_	400	500	600	700	800	900	1000	1100	1200	1400	1600	1800	2000
8	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
9	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
11	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
12	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
13	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
14	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
15	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
16	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
17	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
18	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
19	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
21	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
22	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
24	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
25	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
27	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
30	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768

P0300-P0308: Idle SCD ddf

Load

	400	500	600	700	800	900	1000	1100	1200	1400	1600	1800	2000
8	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
9	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
11	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
12	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
13	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
14	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
15	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
16	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
17	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
18	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
19	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
21	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
22	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
24	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
25	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
27	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
30	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768

P0300-P0308:	Off	Idle	SCD	dt

ECM Supporting Tables
OR (decel index >Off Idle SCD dt AND > Off Idle SCD dtt Tables)) Load

	400	500	600	700	800	900	1000	1100	1200	1400	1600	1800	2000
8	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
9	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
11	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
12	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
13	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
15	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
17	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
19	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
22	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
25	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
29	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
33	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
38	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
42	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
48	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
54	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
61	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768

P0300-P0308: Off Idle SCD ddt

Load

	_												
	400	500	600	700	800	900	1000	1100	1200	1400	1600	1800	2000
8	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
9	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
11	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
12	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
13	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
15	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
17	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
19	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
22	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
25	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
29	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
33	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
38	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
42	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
48	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
54	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
61	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768

P0300-P0308: Idle Cyl Mode dt

Load

	500	600	700	800	900	1000	1100	1200	1300	1400	1600	1800	2000
8	3000	2500	1700	1450	800	650	600	500	400	400	400	400	400
9	3000	2500	1700	1450	800	650	600	500	400	400	400	400	400
11	3000	2800	1700	1450	800	700	600	500	400	400	400	400	400
12	3100	3000	1700	1450	900	750	600	500	400	400	400	400	400
13	3500	3000	1700	1500	1000	750	600	500	400	400	400	400	400
14	3500	3000	1700	1500	1000	750	700	500	400	400	400	400	400
15	4000	3000	1800	1500	1000	800	700	500	400	400	400	400	400
16	4500	3000	1800	1600	1200	800	800	500	400	400	400	400	400
17	5000	3400	2100	1600	1200	950	800	550	500	500	500	500	500
18	5000	3400	2100	1600	1250	950	800	550	500	500	500	500	500
19	5600	3400	2300	1600	1250	950	800	550	500	500	500	500	500
21	5600	3500	2300	1800	1250	1000	800	550	500	500	500	500	500
22	5600	3600	2300	1850	1300	1050	800	550	500	500	500	500	500
24	5600	3600	2400	1900	1300	1100	800	550	500	500	500	500	500
25	7000	4000	2400	1900	1300	1100	800	550	500	500	500	500	500
27	7500	4000	2500	1900	1600	1400	900	600	550	550	550	550	550
30	8000	4000	2500	2200	1600	1400	900	600	600	600	600	600	600

P0300-P0308: Idle Cyl Mode ddt

Load

30	8000	4000	2500	2200	1600	1400	900	600	600	600	600	600	600
	500	600	700	800	900	1000	1100	1200	1300	1400	1600	1800	2000
8	4000	2800	1900	1400	950	750	550	500	400	400	400	400	400
9	4000	2800	1900	1400	1000	750	550	500	400	400	400	400	400
11	4000	3000	1900	1500	1000	750	550	500	400	400	400	400	400
12	4000	3000	1900	1500	1050	800	550	500	400	400	400	400	400
13	4000	3000	2000	1500	1100	800	600	500	400	400	400	400	400
14	4000	3000	2200	1500	1150	800	600	600	400	400	400	400	400
15	4500	3000	2300	1600	1200	900	600	600	400	400	400	400	400
16	4500	3000	2400	1900	1500	900	700	600	450	450	450	450	450
17	5000	3500	2800	2000	1550	1100	800	650	500	500	500	500	500
18	5000	3500	3000	2000	1600	1100	800	650	500	500	500	500	500
19	7000	3500	3000	2100	1600	1100	800	700	500	500	500	500	500
21	7000	3500	3000	2200	1600	1200	850	700	500	500	500	500	500
22	7000	4000	3000	2200	1600	1400	1000	750	550	550	550	550	550
24	7000	4000	3000	2200	1800	1400	1100	750	600	600	600	600	600
25	7000	4500	3000	2200	2000	1550	1100	800	600	600	600	600	600
27	7500	4500	3000	2400	2200	1800	1100	850	625	625	625	625	625
30	8000	5000	3000	2400	2200	1800	1100	850	625	625	625	625	625

P0300-P0308: Cyl Mode dt

ECM Supporting Tables OR (decel index > Cvl Mode dt AND > Cvl Mode dtt Tables))

,

	_		(icx - Oyi ividac			,,											
	400	500	600	700	800	900	1000	1100	1200	1400	1600	1800	2000	2200	2400	2600	2800	3000
8	2000	2000	1800	1200	850	575	450	260	250	180	130	70	70	45	35	30	29	20
9	2000	2000	1800	1200	850	575	450	260	250	180	130	70	70	45	35	30	29	20
11	2000	2000	1800	1200	850	575	450	260	250	180	130	70	70	45	35	30	29	20
12	2000	2000	1800	1200	850	575	450	260	250	180	140	70	70	45	35	31	29	20
13	2000	2000	1800	1250	850	620	500	300	250	180	140	70	75	50	35	33	29	20
15	2000	2000	1800	1300	850	750	700	500	350	190	150	75	75	55	42	35	30	23
17	2200	2200	1900	1400	1100	1000	800	650	458	200	200	115	100	60	44	39	40	27
19	2250	2250	2000	1650	1400	1100	900	750	479	250	210	140	100	74	51	44	40	33
22	2500	2500	2400	2100	1600	1300	1000	800	502	340	232	170	140	80	60	60	50	45
25	2800	2800	2600	2200	1750	1500	1100	925	600	360	276	190	150	105	90	70	60	45
29	3100	3100	2900	2350	1900	1600	1200	1050	700	400	320	200	160	112	100	80	60	50
33	3200	3200	3000	2600	2000	1750	1375	1100	800	450	354	250	180	120	100	90	70	59
38	3500	3500	3200	2700	2300	2000	1486	1157	850	550	407	280	200	140	120	100	90	64
42	3800	3800	3300	2800	2450	2200	1650	1250	900	600	525	310	250	152	140	110	100	78
48	4000	4000	3450	3000	2550	2250	1800	1550	950	700	550	400	280	180	160	120	110	82
54	4200	4200	3700	3200	2800	2550	2000	1800	1100	750	600	450	300	200	180	150	120	100
61	4400	4400	4000	3450	3050	2800	2250	1900	1300	850	650	500	350	250	200	170	150	120

	3500	4000	4500	5000	5500	6000	6500	7000
8	12	9	8	7	5	4	4	4
9	12	9	8	7	5	4	4	4
11	12	9	8	7	5	4	4	4
12	12	9	8	7	5	4	4	4
13	13	9	8	7	5	4	4	4
15	16	10	8	7	5	4	4	4
17	16	11	8	7	5	4	4	4
19	18	12	9	8	5	4	4	4
22	20	16	10	8	6	5	5	5
25	26	19	14	11	8	6	6	6
29	30	20	16	13	10	7	7	7
33	32	22	18	15	10	9	9	9
38	38	25	20	18	12	10	10	10
42	45	28	24	18	13	11	11	11
48	52	35	25	20	15	12	12	12
54	60	40	30	23	16	13	13	13
61	75	48	32	26	20	16	16	16

P0300-P0308: Cyl Mode ddt

oad

	400	500	600	700	800	900	1000	1100	1200	1400	1600	1800	2000	2200	2400	2600	2800	3000
																	2000	
8	2100	2100	1800	1200	1100	975	700	400	375	250	180	130	100	70	55	55	45	40
9	2100	2100	1800	1200	1100	975	700	400	375	250	180	130	100	70	55	55	45	40
11	2100	2100	1800	1200	1100	975	700	400	375	250	180	130	100	70	55	55	45	40
12	2100	2100	1800	1200	1100	1000	700	400	375	280	230	130	120	70	65	55	45	40
13	2100	2100	1800	1250	1150	1050	700	600	419	325	260	160	150	80	70	55	45	40
15	2500	2500	2000	1550	1225	1100	1000	689	522	380	300	220	180	130	100	75	60	40
17	2800	2800	2400	1700	1400	1350	1100	796	547	450	350	250	200	150	120	75	62	45
19	3000	3000	2600	2000	1621	1450	1200	1050	800	500	400	300	200	150	120	80	62	55
22	3000	3000	2900	2500	1989	1900	1500	1300	950	600	440	320	300	200	150	120	80	65
25	3300	3300	3000	3000	2500	2100	1800	1350	1050	694	469	350	300	200	170	150	100	74
29	3800	3800	3300	3200	2700	2700	2000	1800	1400	708	535	480	300	250	200	150	100	88
33	4000	4000	3700	3500	3000	2800	2100	2000	1500	850	704	500	350	280	200	180	120	95
38	4250	4250	3900	3800	3300	2900	2400	2030	1650	1110	790	550	420	300	220	210	150	109
42	4500	4500	4250	4000	3550	3500	2650	2150	1700	1200	863	600	500	350	300	230	150	121
48	4800	4800	4500	4250	3775	3500	2900	2200	1750	1300	925	750	550	400	300	240	200	141
54	5100	5100	4800	4500	4000	3800	3100	2400	1800	1400	1111	780	680	500	350	300	220	162
61	5500	5500	5100	4800	4500	4250	3400	2600	2150	1450	1233	900	700	550	400	310	250	197

	3500	4000	4500	5000	5500	6000	6500	7000
8	19	14	11	10	9	8	8	8
9	19	14	11	10	9	8	8	8
11	19	14	11	10	9	8	8	8
12	19	14	11	10	9	8	8	8
13	20	15	11	10	9	8	8	8
15	26	20	12	10	9	8	8	8
17	30	21	13	12	9	8	8	8
19	33	22	17	14	9	8	8	8
22	35	30	20	16	11	10	10	10
25	40	36	21	20	15	10	10	10
29	50	38	22	23	17	13	13	13
33	60	42	30	25	19	14	14	14
38	65	45	32	30	21	14	14	14
42	78	55	34	32	23	14	14	14
48	90	65	38	34	25	15	15	15
54	100	68	40	39	30	16	16	16
61	130	80	45	42	38	22	22	22

ECM Supporting Tables

P0300-P0308: Rev Mode Table

OR (decel index > Rev Mode Table) 32768

P0300-P0308: AFM Mode Table

OP (decel index > AEM Table if active fuel management)

Load

Load

	_		OK (decei ind	iex > AFIVI Tabi	ie ii active iuei	management)												
	400	500	600	700	800	900	1000	1100	1200	1400	1600	1800	2000	2200	2400	2600	2800	3000	3500
0	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
6	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
13	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
19	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
25	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
31	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
38	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
44	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
50	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
56	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
63	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
69	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
75	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
81	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
88	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
94	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
100	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768

P0300-P0308: Zero torque engine load

RPM Pct load 400 12.52 500 12.52 600 12.52 600 12.52 700 12.14 800 11.76 900 11.52 1000 11.01 1100 10.93 1200 10.86 1400 10.62 1800 10.64 2000 10.36 2200 10.41 2400 10.29 2600 10.25 2800 10.22 3500 11.33 4000 12.94 4500 14.55 5000 16.17 5500 17.78	rs act
\$600 12.52 \$600 12.52 \$700 12.14 \$800 11.76 \$900 11.52 \$1000 11.01 \$1100 10.93 \$1200 10.86 \$1400 10.62 \$1800 10.62 \$1800 10.82 \$2000 10.36 \$2000 10.25 \$2000 10.25 \$2800 10.25 \$2800 10.25 \$2800 10.25 \$2800 11.33 \$4000 12.94 \$4500 14.55 \$5000 14.55	
600 12.52 700 12.14 800 11.76 900 11.52 1000 11.01 1100 11.01 1100 10.93 1200 10.86 1400 10.76 1600 10.62 1800 10.64 2000 10.36 2200 10.41 2400 10.29 2600 10.25 2800 10.22 3000 9.72 3500 11.33 4000 12.94 4500 14.55 5000 16.17	
700 12.14 800 11.76 900 11.52 1000 11.01 1100 10.93 1200 10.86 1400 10.62 1800 10.62 1800 10.64 2000 10.36 2200 10.41 2400 10.29 2600 10.25 2800 10.25 2800 10.25 2800 11.33 4000 12.94 4500 14.55 5000 16.17	
800 11.76 900 11.52 1000 11.01 1100 10.93 1200 10.86 1400 10.76 1600 10.62 1800 10.84 2000 10.36 2200 10.41 2400 10.29 2600 10.25 2800 10.25 2800 10.25 3500 11.33 4000 12.94 4500 14.55 5000 14.55	
900 11.52 1000 11.01 1100 10.93 1200 10.86 1400 10.76 1600 10.62 1800 10.64 2000 10.36 2200 10.41 2400 10.29 2600 10.25 2800 10.25 2800 10.22 3000 9.72 3500 11.33 4000 12.94 4500 14.55 5000 16.17	
1000 11.01 1100 10.93 1200 10.86 1400 10.76 1600 10.62 1800 10.62 1800 10.62 2000 10.36 2200 10.41 2400 10.29 2600 10.25 2800 10.25 2800 10.25 3500 11.33 4000 12.94 4500 14.55 5000 16.17	
1100 10.93 1200 10.86 1400 10.76 1600 10.62 1800 10.64 2000 10.36 2200 10.41 2400 10.29 2600 10.25 2800 10.25 2800 10.25 3000 9.72 3500 11.33 4000 12.94 4500 14.55 5000 16.17	.
1200 10.86 1400 10.76 1600 10.62 1800 10.64 2000 10.36 2200 10.41 2400 10.29 2600 10.25 2800 10.25 2800 10.25 3500 11.33 4000 12.94 4500 14.55 5000 16.17	
1400 10.76 1600 10.62 1800 10.64 2000 10.36 2200 10.41 2400 10.29 2600 10.25 2800 10.25 2800 10.22 3000 9.72 3500 11.33 4000 12.94 4500 14.55 5000 16.17	
1600 10.62 1800 10.64 2000 10.36 2200 10.41 2400 10.29 2600 10.25 2800 10.22 3000 9.72 3500 11.33 4000 12.94 4500 14.55 5000 15.67	
1800 10.64 2000 10.36 2200 10.41 2400 10.29 2600 10.25 2800 10.25 2800 10.25 3500 9.72 3500 11.33 4000 12.94 4500 14.55 5000 16.17	
2000 10.36 2200 10.41 2400 10.29 2600 10.25 2800 10.22 3500 11.33 4000 12.94 4500 14.55 5000 16.17	
2200 10.41 2400 10.29 2600 10.25 2800 10.22 3000 9.72 3500 11.33 4000 12.94 4500 14.55 5000 16.17	
2400 10.29 2600 10.25 2800 10.25 3000 9.72 3500 11.33 4000 12.94 4500 14.55 5000 16.17	
2600 10.25 2800 10.22 3000 9.72 3500 11.33 4000 12.94 4500 14.55 5000 16.17	
2800 10.22 3000 9.72 3500 11.33 4000 12.94 4500 14.55 5000 16.17	
3000 9.72 3500 11.33 4000 12.94 4500 14.55 5000 16.17	
3500 11.33 4000 12.94 4500 14.55 5000 16.17	
4000 12.94 4500 14.55 5000 16.17	
4500 14.55 5000 16.17	
5000 16.17	. 1
5500 17.78	
6000 19.38	
6500 21.00	
7000 22.61	

Baro KPa	Multiplier
65	0.82
70	0.85
75	0.88
80	0.90
85	0.93
90	0.95
95	0.97
100	1.00
105	1.03

Zero Torque: Active Fuel Management (AFM)

400	
400	25.00
500	24.00
600	24.00
700	23.00
800	23.00
900	22.00
1000	22.00
1100	21.00
1200	21.00
1400	21.00
1600	21.00
1800	21.00
2000	20.00
2200	20.00
2400	20.00
2600	21.00
2800	22.00
3000	23.00
3500	25.00
4000	30.00
4500	35.00
5000	40.00
5500	45.00
6000	50.00
6500	55.00
7000	60.00

Note: Zero torque is adjusted for Baro. Misfire thresholds are relative to (maximum air density PID \$1188 SAE xxx) and do not shift appreciably with altitude compared to (current density as defined PID \$04 SAE1979)

ECM Supporting Tables

Catalyst Damaging Misfire Percentage

Load

	0	1000	2000	3000	4000	5000	6000	7000
0	22.5	22.5	22.5	22.5	22.5	12.5	12.5	12.5
10	22.5	22.5	22.5	22.5	22.5	12.5	12.5	8.0
20	22.5	22.5	22.5	12.5	12.5	12.5	8.0	6.3
30	22.5	22.5	22.5	12.5	12.5	8.0	6.3	6.3
40	22.5	22.5	12.5	12.5	12.5	8.0	5.0	5.0
50	22.5	22.5	12.5	12.5	8.0	6.3	5.0	5.0
60	22.5	12.5	12.5	12.5	6.3	5.0	5.0	5.0
70	12.5	12.5	12.5	8.0	6.3	5.0	5.0	5.0
80	12.5	12.5	8.0	6.3	6.3	5.0	5.0	5.0
90	12.5	12.5	8.0	6.3	6.3	5.0	5.0	5.0
100	12.5	12.5	8.0	6.3	6.3	5.0	5.0	5.0

RoughRoadSource = CeRRDR_e_TOSS

Rough Road Threshold

-			- 4
-	·Dε	Э.	:O
	г.	-	

	Engine Speed	1																	
	600	800	1000	1200	1400	1600	1800	2000	2200	2400	2600	2800	3000	3500	4000	4500	5000	5500	6000
100	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
200	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
300	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
400	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
500	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
600	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
700	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
800	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
900	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1000	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1100	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1200	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1300	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1400	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

RoughRoadSource = CeRRDR_e_WheelSpeedInECM or CeRRDR_e_SerialDataFromABS Rough Road Threshold

Kph	0	12	24	36	48	60	72	84	96	108	120	132	144	158	170	181	194
Accel	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05

P0300-P0308: Abnormal Engine Speed

Cylinder Mode									
RPM	0	1000	2000	3000	4000	5000	6000	7000	8000
Multiplier	2.00	2.00	2.00	4.00	4.00	4.00	4.00	4.00	4.00
SCD Mode									
RPM	0	1000	2000	3000	4000	5000	6000	7000	8000
Multiplier	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00
Rev Mode									
RPM	0	1000	2000	3000	4000	5000	6000	7000	8000
Multiplier	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00

P0300-P0308: Pattern Recognition Min and Max Multipliers

Min Multiplier									
RPM	0	1000	2000	2500	3000	3500	4000	5000	6500
Multiplier	1.10	1.10	0.75	0.85	0.85	0.60	0.70	0.80	0.80
Max Multiplier									
RPM	0	1000	2000	2500	3000	3500	4000	5000	6500
Multiplier	1.30	1.30	1.20	0.80	0.80	1.00	1.20	1.40	1.40

P0300-P0308: Driveline Ring Filter

Ring Filter									
RPM	0	1000	2000	3000	4000	5000	6000	7000	8000
Multiplier	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00
Number of No	rmals								
RPM	0	1000	2000	3000	4000	5000	6000	7000	8000
Multiplier	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00

7000 1.000

7000

0.950

1.000

7000 1.000

7000 1.000

7000 1.000

1.00 1.000

7000 1.000 7000 1.000

6500

0.950

1.000

6500

1.000

5625 1.000

6500 1.000

1.000

1.000

12 OBDG02 Engine Diagnostics

Temp	-40	0	40	emperature in 80	120	160	200								
	1.00	1.00	1.00	1.00	1.00	1.00	1.00								
P0101, P0106, P0121, P012B, P0236,															
	TPS Residual \														
RPM	0	1500	2200	2500	2700	3100	3200	3300	3500	3700	4000	4200	4500	5000	525
	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.00
	MAF Residual												.=		
RPM	0	800	1500	2500	2800	3100	3200	3300	3500	3700	4000	4200	4500	5000	550
	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.900	0.950	0.950	1.00
	MAF Residual				70.0	79.0	82.0	85.0	00.0	05.0	100.0	110.0	120.0	150.0	200.
gm/sec	0.0	50.0 1.000	70.0 1.000	73.0 1.000	76.0 1.000	1.000	1.000		89.0	95.0	1.000	110.0	120.0		
	1.000				1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.00
RPM	MAP1 Residua	800	or based on i	2500	2800	3100	3200	3300	3500	3700	4000	4200	4500	5000	5500
CFIVI															
	0.900 MAP2 Residua	0.900	0.900	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.00
RPM	MAP2 Residua 0	800	or based on i	2500	2800	3100	3200	3300	3500	3700	4000	4200	4500	5000	5500
ZI IAI	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.00
	MAP3 Residua				1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.00
RPM	0	1500	2200	2500	2700	3100	3200	3300	3500	3700	4000	4200	4500	5000	525
IXI IVI	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.00
	TIAP1 Residua				1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.00
RPM	0	1500	2200	2500	2700	3100	3200	3300	3500	3700	4000	4200	4500	5000	5250
XI WI	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.00
	SCIAP1 Residu				1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.00
RPM	0	1500	2200	2500	2800	3100	3200	3300	3500	3700	4000	4200	4500	5000	5500
	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.00
	SCIAP2 Residu				1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.500	1.500	1.00
RPM	0	1500	2200	2500	2800	3100	3200	3300	3500	3700	4000	4200	4500	5000	5500
	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.00
	Boost Residua				000	000	000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.00
% Boost	0.00	0.06	0.13	0.19	0.25	0.31	0.38	0.44	0.50	0.56	0.63	0.69	0.75	0.81	0.88
	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.00
				1.000					1.000		1.000				
P0101, P0106, P0121, P0236, P1101:	TIAP-MAP Corre	lation Offset	based on RPI	м											
RPM	1000	1750	2500	3250	4000	4750	5500	6250	7000						
	1.0	1.0	1.0	1.0	2.0	2.0	2.0	3.0	3.0						
					-	-	-		- · -						
P0101, P0106, P0121, P0236, P1101:	TIAP-MAP Corre	lation Min Air	r Flow based	on RPM											
RPM	1000	1750	2500	3250	4000	4750	5500	6250	7000						
	15.0	27.0	32.0	32.0	32.0	32.0	32.0	32.0	32.0						
		-													
P0101, P0106, P0121, P0236, P1101:	TIAP-MAP Corre	lation Min MA	AP based on I	RPM											
RPM	1000	1750	2500	3250	4000	4750	5500	6250	7000						
	124.0	126.0	127.0	128.0	129.0	128.0	127.0	127.0	127.0						
									4						
P0101, P0106, P0121, P0236, P1101:	TIAP-Baro Corre	lation Offset	based on RP	M											
RPM	1000	1750	2500	3250	4000	4750	5500	6250	7000						
	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0						
	_														
P0101, P0106, P0121, P0236, P1101:	TIAP-Baro Corre	lation Max Ai	ir Flow based	on RPM											
RPM	1000	1750	2500	3250	4000	4750	5500	6250	7000						
	2.6	3.3	4.5	5.4	7.0	8.8	11.0	12.4	12.4						
							,								
P0101, P0106, P0121, P0236, P1101:															
P0101, P0106, P0121, P0236, P1101: RPM	TIAP-Baro Corre	elation Max M 1750	AP based on 2500	RPM 3250	4000	4750	5500	6250	7000						
					4000 25.7	4750 24.1	5500 29.5	6250 29.4	7000 29.4						

	Turbochar	ger Intake Flo	ow Rationality	Diagnostic	Failure Matrix			
MAF Model Failure	MAP 1 Model	MAP 2	MAP 3	TIAP 1	TPS Model	TIAP	TIAP	DTC Set
	Failure	Model	Model	Model	Failure	Correlation	Correlation	
		Failure	Failure	Failure		Failure	Valid	
F	F	F	F	F	F	F	F	No DTC
F	F	F	F	F	F	F	Т	No DTC
F	F	F	F	F	F	T	F	No DTC
F	F	F	F	F	F	T	Т	No DTC
F	F	F	F	F	T	F	F	No DTC
F	F	F	F	F	T	F	Т	No DTC
F	F	F	F	F	T	T	F	No DTC
F	F	F	F	F	T	T	Т	No DTC
F	F	F	F	T	F	F	F	No DTC
F	F	F	F	Т	F	F	Т	No DTC
F	F	F	F	T	F	T	F	No DTC
F	F	F	F	T	F	T	Т	No DTC

		n't	ure Matrix, Co	agnostic Fail	Rationality Di	intake Flow	Turbocharger	
DTC Se	TIAP	TIAP	TPS Model	TIAP 1	MAP 3	MAP 2	MAP 1 Model	MAF Model Failure
	Correlation	Correlation	Failure	Model	Model	Model	Failure	
	Valid	Failure		Failure	Failure	Failure		
P1101	F	F	Т	T	F	F	F	F
P0121	Т	F	Т	Т	F	F	F	F
P1101	F	T	T	T	F	F	F	F
P0236	T	Т	Т	Т	F	F	F	F
P1101	F	F	F	F	T	F	F	E
P1101	T	F	F	F	Ť	F	F	F
P1101	F	T	F	F	i i	F	F	F
P1101	T	T	F	F	Т	F	F	F
P1101	F	F	Т	F	Т	F	F	F
P1101	T	F	Т	F	Т	F	F	F
P1101	F	T	Т	F	Т	F	F	F
P1101	T	T	T	F	T	F	F	F
P1101	F	F	F	T	Т	F	F	F
P1101	T	F	F	T	T	F	F	F
P1101	F	T	F	Т	Т	F	F	F
P1101	T	Ť	F	Ť	Ť	F	F	F
	F	Ė	÷	÷	÷	F	F	F
P1101		Г						
P1101	T	F	Т	T	Т	F	F	F
P1101	F	Т	Т	Т	T	F	F	F
P1101	Т	Т	T	Т		F	F	F
P1101	F	F	F	F	F	Т	F	F
P1101	T	F	F	F	F	Т	F	F
P1101	F	Т	F	F	F	Т	F	F
P1101	T	Ť	F	F	F	Ť	F	F.
P1101	F	Ė	÷	F	F		F	F
					- 1			
P1101	Т	г	Ţ	F	Г	T	F	<u> </u>
P1101	F	Т	Т	F	F	Т	F	F
P1101	T	Т	Т	F	F	Т	F	F
P1101	F	F	F	T	F	T	F	F
P1101	Т	F	F	Т	F	Т	F	F
P1101	F	T	F	T	F	T	F	F
P1101	T	Ť	F	T	F	Ť	E	Ē
P1101	F	Ė	Ť	÷	F	- i -	Ė	F F
P1101		F	Ť		F	÷	F	F
	Т			T				
P1101	F	Т	Т	Т	F	Т	F	F
P1101	Т	T	Т	Т	F	Т	F	F
P1101	F	F	F	F	Т	Т	F	F
P1101	Т	F	F	F	Т	Т	F	F
P1101	F	T	F	F	Т	Т	F	F
P1101	T	T	F	F	Т	Т	F	F
P1101	F	F	T	F	Ť	Ť	E	E
P1101	Ť	F	Ť	F	Ť	-i	Ė	F F
P1101	F	T	Т	F	T	T	F	<u> </u>
P1101	Т	Т	Т	F	Т	Т	F	F
No DT	F	F	F	Т	Т	Т	F	F
No DT	T	F	F	T	Т	T	F	F
No DT	F	Т	F	Т	T	Т	F	F
No DT	Т	Т	F	Т	Т	Т	F	F
P1101	F	F	T	Ť	Ť	Ť	F	F
P1101	Ť	F	÷	÷	- i	- i -	Ė	F F
P1101	F	T	÷	÷	Ť	'	F	F F
P1101		i i		Ì	1	<u> </u>	F	F F
	Т							
P1101	F	F	F	F	F	F	Т	F
P1101	Т	F	F	F	F	F	T	F
P1101	F	Т	F	F	F	F	Т	F
P0236	Т	Т	F	F	F	F	Т	F
P1101	F	F	T	F	F	F	T	F
P0121	Т	F	Т	F	F	F	T	F
P1101	F	Ť	Ť	F	F	F	i i	E
P0236	Ť	Ť	i i	F	F	Ė	 	F
P1101	F	F	F	Ť	-	F	 	F F
			F	-	r			·
P1101	T	F		T	F	F	T	F
P1101	F	Т	F	Т	F	F	Т	F
P0236	Т	Т	F	Т	F	F	Т	F
P1101	F	F	T	Т	F	F	T	F
P0121	Т	F	Т	Т	F	F	T	F
P1101	Ė	÷	÷	÷	F	Ė	i i	
P0236	T	- i	İ	Ť	F	F	 	F F
								· ·
P1101	F	F	F	F	Т	F	Т	F
P1101		F	F	F		F		F
P1101	F	Т	F	F	Т	F	Т	F
D1104	Т	Т	F	F	Т	F	Т	F
P1101								
P1101 P1101	F	F	T	F	T	F	T	F

rting Ta		n't	ure Matrix, Co	agnostic Fail	Rationality Di	Intake Flow	Turbocharger	
DTC Set	TIAP	TIAP	TPS Model	TIAP 1	MAP 3	MAP 2	MAP 1 Model	MAF Model Failure
	Correlation	Correlation	Failure	Model	Model	Model	Failure	
	Valid	Failure		Failure	Failure	Failure		
P1101	F	T	Т	F	Т	F	T	F
P1101	Т	T	Т	F	Т	F	Т	F
P1101	F	F	F	T	Т	F	T	F
P1101	T	F	F	T	Т	F	T	F
P1101	F	Ţ	F	T	Ţ	F	Ţ	F
P1101	T	T	F	T	T	F	Ţ	F
P1101	F	F	Т	T	T	F	T	F
P1101	T	F	Т	T	Т	F	T	F
P1101	F	T	Т	T	Т	F	Т	F
P1101	Т	Т	Т	Т	Т	F	Т	F
P1101	F	F	F	F	F	T	Т	F
P1101	Т	F	F	F	F	T	Т	F
P1101	F	Т	F	F	F	T	Т	F
P1101	Т	Т	F	F	F	T	Т	F
P1101	F	F	Т	F	F	Т	T	F
P1101	Т	F	Т	F	F	Т	Т	F
P1101	F	Т	Т	F	F	Т	T	F
P1101	Т	Т	T	F	F	Т	Т	F
P1101	F	F	F	T	F	T	Т	F
P1101	T	F	F	T	F	Т	Т	F
P1101	F	T	F	Т	F	Т	T	F
P1101	T	T	F	Т	F	Т	Т	F
P1101	F	F	Т	T	F	T	T	F
P1101	Т	F	Т	Т	F	T	Т	F
P1101	F	Т	Т	T	F	T	T	F
P1101	Т	Т	Т	Т	F	T	Т	F
P0106	F	F	F	F	Т	Т	T	F
P0106	Т	F	F	F	T	Т	T	F
P0106	F	T	F	F	Т	Т	Т	F
P0106	Т	Т	F	F	Т	T		F
P1101	F	F	Т	F	Т	Т	T	F
P1101	Т	F	Т	F	Т	Т	T	F
P1101	F	T	Ť	F	Ť	T	1	F
P1101	T	Ť	Ť	F	Ť	Ť	Ť	F
P1101	F	F	F	Ť	Ť	Ť		F
P1101	Ť	F	F	Ť	Ť	Ť		F
P1101	Ė	÷	F	÷	Ť	÷	 	<u>.</u> E
P1101	-	÷	F	÷	· ·		 	F
P1101	F	Ė	Ť	÷	÷	÷	 	F
P1101	-	F.	÷	÷	· i	-i	 	<u>'</u>
P1101	Ė	Ť	÷	÷	÷	Ť	 	- 'F
P1101	· ·	Ť	i i	÷	i i		 	F
P1101	F	F	F	F	Ė	F	Ė	'
	Ť	F	F	F	-	F	F	i
P1101 P1101	Ė	T	F	F	F	F	F	<u>!</u>
P0236	T	· ·	F	F	F	F	F	'
	F	F		F	F	F	F	'
P1101			Ţ		Г			I T
P0121	Ţ	F	Ţ	F	F	F	F	1
P1101	F	T	Ţ	F	F		F	I T
P0236	Ţ	Ţ	T	F	F	F	F	Ţ
P1101	F	F	F	T	F	F	F	Ţ
P1101	T	F	F	Ţ	F	F	F	T
P1101	F	Ţ	F	T	F	F	F	<u> </u>
P0236	Т	T	F	T	F	F	F	T
P1101	F	F	Ţ	T	F	F	F	<u> </u>
P0121	T	F	T	T	F	F	F	Т
P1101	F	Т	Т	T	F	F	F	Т
P0236	Т	Т	Т	Т	F	F	F	Т
P1101	F	F	F	F	Т	F	F	Т
P1101	Т	F	F	F	Т	F	F	Т
P1101	F	Т	F	F	Т	F	F	Т
P1101	Т	Т	F	F	Т	F	F	Т
P1101	F	F	T	F	T	F	F	Т
P1101	T	F	T	F	Т	F	F	Т
P1101	F	Т	Т	F	Т	F	F	T
P1101	Т	Т	Т	F	Т	F	F	Т
P1101	F	F	F	Т	Т	F	F	Т
P1101	T	F	F	Ť	Ť	F	F	Ť
P1101	F	T	F	Ť	Ť	F	F	Ť
P1101	Ť	Т	F	Ť	Ť	F	F	Т
P1101	F	F	Ť	Ť	Ť	F	F	T
				÷	÷	F	F	
P1101	T	F	Т					
P1101 P1101	T F	F	T	T	1	F	F	- i

		nτ	ure Matrix, Co	agnostic Fail	Rationality Di	IIIIake Flow	rurbocharger	
DTC S	TIAP	TIAP	TPS Model	TIAP 1	MAP 3	MAP 2	MAP 1 Model	MAF Model Failure
i	Correlation	Correlation	Failure	Model	Model	Model	Failure	
	Valid	Failure	_	Failure	Failure	Failure		
P1101	F	F	F	F	F	Т	F	Т
P1101	Т	F	F	F	F	Т	F	T
P1101	F	Т	F	F	F	Т	F	Т
P1101	Т	Т	F	F	F	Т	F	Т
P1101	F	F	T	F	F	T	F	T
P1101	Т	F	Т	F	F	Т	F	Т
P1101	F	Т	Т	F	F	T	F	Т
P1101		Т	Т	F	F	Т	F	T
P1101	F	F	F	Ť	F	Ť	F	Ť
P1101	<u> </u>	F	F	Ť	F	- i -	F	- i
P1101	F	÷	F	÷	F	÷	F	
P1101	Ť	Ť	F	÷	F		F	- i
	Ė	F	· ·	i i	F	'	F	<u>+</u>
P1101	- F	F	÷	÷	F	÷	E	<u> </u>
P1101 P1101								!
	F	Т	Т	T	F	T	F	T
P1101	Т	T	Т	Т	F	T	F	T
P1101	F	F	F	F	Т	Т	F	T
P1101	Т	F	F	F	Т	Т	F	T
P1101	F	Т	F	F	T	Т	F	T
P1101	Т	Т	F	F	T	Т	F	Т
P1101	F	F	Т	F	Т	Т	F	Т
P1101	Т	F	Т	F	Т	Т	F	Т
P1101	F	T	Ť	F	Ť	T	F	T T
P1101	Ť	Ť	Ť	F	Ť	Ť	F	Ť
P0101	Ė	Ė	F	'	÷		F	
P0101	Ť	F	F	Ť	÷	÷	F	'
	F	T	F	Ť	+	'	F	<u>'</u>
P0101 P0101	T	<u> </u>	F	İ	1	Ť	F	<u> </u>
P0101								·
P1101	F	F	Т	Т	Т	T	F	Т
P1101	Т	F	Т	Т	Т	T	F	Т
P1101	F	Т	Т	Т	Т	Т	F	Т
P1101	Т	Т	Т	Т	Т	Т	F	T
P1101	F	F	F	F	F	F	T	Т
P1101	Т	F	F	F	F	F	Т	Т
P1101	F	Т	F	F	F	F	Т	Т
P0236	T	T	F	F	F	F	T	Т
P1101	F	F	Т	F	F	F	T	T
P0121		F	Ť	F	F	F	1	Ť
P1101	F	Ť	Ť	F	F	F	Ť	Ť
P0236	Ť	- i	÷	F	F	Ė	i i	
P1101	F	Ė	F	÷	F	F	i i	- i
P1101	- f	F	F	÷	F	F	i i	
		T	F			F		
P1101	F			T	F		T	Ţ
P0236	Т	Т	F	T	F	F	Т	T
P1101	F	F	Т	T	F	F	Т	T
P0121	Т	F	Т	Т	F	F	Т	Т
P1101	F	Т	Т	Т	F	F	Т	Т
P0236	T	T	T	T	F	F	T	T
P1101	F	F	F	F	Т	F	Т	T
P1101	Т	F	F	F	Т	F	T	Т
P1101	F	Т	F	F	Т	F	Т	Т
P1101	Т	Т	F	F	Т	F	T	Т
P1101	F	F	T	F	Ť	F	Ť	T
P1101	÷	F	Ť	F	Ť	F	 	Ť
P1101	Ė	- i	÷	F	- i	F	i	
P1101	÷	÷	Ť	F	- i	F	+	
P1101	F	F	F	T	+	F	+ +	<u> </u>
P1101	T	F	F	Ť	+	F	i i	T
P1101	F	F T	F	T	Ţ	F	+ +	<u> </u>
P1101								
P1101	Ţ	T	F	T	T	F	T	Ţ
P1101	F	F	Т	T	Т	F	Т	T
P1101	Т	F	Т	Т	Т	F	Т	Т
P1101	F	T	T	T	Т	F	Т	Т
P1101	T	Т	Т	Т	Т	F	Т	Т
P1101	F	F	F	F	F	Т	T	Т
P1101	Т	F	F	F	F	Т	Т	Т
P1101	F	Ť	F	F	F	Ť	i i	Ť
P1101	Ť	- i	F	F	F	- i -	i i	i
P1101	F	F	Ť	F	F	- i -	+	
P1101	- f	F	- i	F	F	- i -	 	
	F	T	T	F	F		i i	
P1101						Ţ		I T
P1101	Т	Т	Т	F	F	Ţ	T	- I
	F	F	F	T	F	T	T	1
P1101 P1101	÷	F	F	Т	F	T	T	T

ECM Supporting Tables

	Turbocharger	Intake Flow	Rationality Di	agnostic Fail	ure Matrix, Co		от отрес	
MAF Model Failure	MAP 1 Model Failure	MAP 2 Model Failure	MAP 3 Model Failure	TIAP 1 Model Failure	TPS Model Failure	TIAP Correlation Failure	TIAP Correlation Valid	DTC Set
Т	Т	Т	F	Т	F	Т	F	P1101
Т	T	T	F	Т	F	Т	T	P1101
T	Т	Т	F	T	Т	F	F	P1101
Т	Т	Т	F	Т	Т	F	Т	P1101
T	Т	Т	F	Т	Т	Т	F	P1101
Т	Т	Т	F	Т	Т	T	Т	P1101
T	Т	Т	Т	F	F	F	F	P1101
Т	Т	T	T	F	F	F	Т	P1101
Т	Т	Т	Т	F	F	T	F	P1101
Т	Т	T	T	F	F	T	Т	P1101
Т	Т	Т	Т	F	T	F	F	P1101
Т	Т	T	T	F	Т	F	Т	P1101
Т	T	T	T	F	T	T	F	P1101
Т	T	Т	Т	F	T	Т	Т	P1101
Т	T	T	T	T	F	F	F	P1101
Т	T	Т	Т	Т	F	F	Т	P1101
Т	T	T	T	T	F	T	F	P1101
Т	Т	Т	Т	Т	F	Т	Т	P1101
Т	Т	Т	Т	Т	Т	F	F	P1101
Т	Т	Т	Т	Т	Т	F	Т	P1101
Т	Т	Т	Т	Т	Т	Т	F	P1101
Т	Т	Т	T	Т	Т	Т	Т	P1101

P00B6: Fail if power up ECT exceeds RCT by these values

Z axis is the Fast Failure temp difference (° C)

X axis is IAT Temperature at Power up (° C)

	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
ſ	80	80	80	60	60	40	40	30	30	30	30	30	30	30	30	30	30

P0116: Fail if power up ECT exceeds IAT by these values

Z axis is the Fast Failure temp difference (° C)

X axis is IAT Temperature at Power up (° C)

																152
106	94	82	70	60	46	40	30	30	30	30	30	30	30	37	49	61

P0128: Maximum Accumulated Airflow for IAT and Start-up ECT conditions

Z axis is the accumulated time failure threshold (seconds)

X axis is ECT Temperature at Power up (° C)

Y axis is IAT min during test (° C)

Remove for applications with single coolant sensor Primary Alternate

IAT R	ange											
Low	Hi	-40	-28	-16	-4	8	20	32	44	56	68	80
10.0 ° C	65.0 ° C	1100	1100	1000	990	870	750	700	640	565	500	410
-7.0 ° C	10.0 ° C	1100	1000	850	645	547	500	410	350	350	300	200

ECM Supporting Tables

P0133 - O2S Slow Response Bank 1 Sensor 1" Pass/Fail Threshold table

Z axis is the pass/fail result (see note below) X axis is Lean to Rich response time (msec)

Y axis is Rich to Lean response time (msec)

Note: If the cell contains a "0" then the fault is not indicated, if it contains a "1" a fault is indicated

	0.000	0.035	0.050	0.060	0.080	0.090	0.100	0.110	0.120	0.130	0.140	0.160	0.180	0.199	0.225	0.250	0.300
0.000	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0	0
0.035	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0	0
0.050	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0	0
0.060	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
0.080	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
0.090	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
0.100	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
0.110	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0
0.120	0	0	0	1	1	1	1	1	1	1	1	0	0	0	0	0	0
0.130	0	0	0	0	0	1	1	1	1	1	1	0	0	0	0	0	0
0.140	0	0	0	0	0	0	0	1	1	1	1	0	0	0	0	0	0
0.160	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
0.180	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
0.199	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
0.225	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
0.250	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
0.300	0	0	0	Ö	Ö	0	0	Ó	Ö	Ö	0	Ö	Ö	0	0	0	0

P0153 - O2S Slow Response Bank 2 Sensor 1" Pass/Fail Threshold table

Z axis is the pass/fail result (see note below)

X axis is Lean to Rich response time (msec)

Y axis is Rich to Lean response time (msec)

Note: If the cell contains a "0" then the fault is not indicated, if it contains a "1" a fault is indicated

	0.000	0.050	0.100	0.149	0.159	0.170	0.180	0.189	0.199	0.210	0.220	0.229	0.239	0.250	0.300	0.350	0.399
0.000	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.050	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.100	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.149	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.159	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.170	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.180	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.189	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.199	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.210	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.220	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.229	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.239	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.250	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.300	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.350	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0.399	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1

Green Sensor Delay Criteria:

The specific diagnostic (from summary table) will not be enabled until the next ignition cycle after the airflow criteria below (by sensor location) has been met:

- * B1S1 Airflow greater than 20 gps for 100000 grams of accumulated flow non-continuously.
- * B1S2 Airflow greater than 20 gps for 100000 grams of accumulated flow non-continuously.
- * B2S1 Airflow greater than 20 gps for 100000 grams of accumulated flow non-continuously.

* B2S2 Airflow greater than 20 gps for 100000 grams of accumulated flow non-continuously.

Note that all other enable criteria must be met on the next ignition cycle for the test to run on that ignition cycle. Note: This feature is only enabled when the vehicle is new and cannot be enabled in service

P0234, P0299

ECM Supporting Tables

KtBSTD_p_CntrlDevNegLim [kPa]

X axis pressure [kPa] Y axis is Engine Speed [rpm]

	100.0000	120.0000	140.0000	160.0000	170.0000	180.0000	190.0000	200.0000	210.0000	220.0000
1000.0000	-24.3600	-30.4500	-28.0140	-26.7960	-24.3600	-24.3600	-24.3600	-26.7960	-26.7960	-28.0018
1500.0000	-48.7200	-36.5400	-28.0140	-26.7960	-24.3600	-24.3600	-24.3600	-26.7960	-26.7960	-28.0018
2000.0000	-73.0800	-48.7200	-26.7960	-25.5780	-24.3600	-24.3600	-24.3600	-25.4562	-25.4562	-28.0018
2500.0000	-80.3880	-53.5920	-26.7960	-22.7766	-21.6378	-22.9106	-24.1834	-25.4562	-25.4562	-28.0018
3000.0000	-73.0800	-48.7200	-24.3600	-19.4880	-19.6707	-20.8278	-21.9849	-23.1420	-23.1420	-25.4562
3500.0000	-73.0800	-48.7200	-19.4880	-19.4880	-19.6707	-20.8278	-21.9849	-23.1420	-23.1420	-25.4562
4000.0000	-73.0800	-48.7200	-19.4880	-19.4880	-19.6707	-20.8278	-21.9849	-23.1420	-23.1420	-25.4562
4500.0000	-73.0800	-48.7200	-19.4880	-19.4880	-19.6707	-20.8278	-21.9849	-23.1420	-23.1420	-25.4562
5000.0000	-73.0800	-48.7200	-19.4880	-19.4880	-19.6707	-20.8278	-21.9849	-23.1420	-23.1420	-25.4562
6000.0000	-73.0800	-48.7200	-19.4880	-19.4880	-19.6707	-20.8278	-21.9849	-23.1420	-23.1420	-25.4562

KtBSTD_p_CntrlDevPosLim [kPa]

X axis is pressure [kPa] Y axis is Engine Speed [rpm]

	100.0000	120.0000	140.0000	160.0000	170.0000	180.0000	190.0000	200.0000	210.0000	220.0000
1000.0000	40.0000	35.0000	45.0000	67.0000	85.0000	107.0000	125.0000	137.0000	169.0000	189.0000
1500.0000	30.0000	25.0000	27.0000	42.0000	52.0000	60.0000	79.0000		102.0000	135.0000
2000.0000	30.0000	27.6000	26.4000	25.2000	24.0000	30.0000	36.0000	42.0000	48.0000	48.0000
2500.0000	30.0000	27.6000	24.0000	20.4000	20.4000	21.6000	22.8000	24.0000	25.2000	26.4000
3000.0000	30.0000	27.6000	21.6000	19.2000	20.4000	21.6000	22.8000	24.0000	25.2000	26.4000
3500.0000	30.0000	27.6000	20.4000	19.2000	20.4000	21.6000	22.8000	24.0000	25.2000	26.4000
4000.0000	30.0000	27.6000	20.4000	19.2000	20.4000	21.6000	22.8000	24.0000	25.2000	26.4000
4500.0000	30.0000	27.6000	20.4000	19.2000	20.4000	21.6000	22.8000	24.0000	25.2000	26.4000
5000.0000	30.0000	27.6000	20.4000		20.4000	21.6000	22.8000		25.2000	26.4000
6000.0000	30.0000	27.6000	20.4000	19.2000	20.4000	21.6000	22.8000	24.0000	25.2000	26.4000

KtBSTD_p_CntrlDevAmbAirCorr [kPa]

X axis is pressure [kPa] Y axis is Ambient Pressure [kPa]

- [60.0000	70.0000	80.0000	90.0000	100.0000	110.0000
Г	2000.0000	100.0000	100.0000	80.0000	30.0000	15.0000	0.0000
ſ	2500.0000	100.0000	100.0000	50.0000	15.0000	0.0000	0.0000
ſ	3000.0000	100.0000	50.0000	20.0000	10.0000	0.0000	0.0000
I	4000.0000		20.0000	10.0000	5.0000	0.0000	
П	5000.0000	100.0000	10.0000	5.0000	0.0000	0.0000	0.0000
ſ	6000.0000	100.0000	5.0000	5.0000	0.0000	0.0000	0.0000

KtBSTD_t_CntrlDevEnblDelay [s]

Engine Speed (RPM):	1000	1500	2000	2500	3000	3500	4000	4500	5000	6000
KtBSTD_t_CntrlDevEnblDelay	1.7500	1.5000	1.3750	1.1250	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000

P00C4, P2261

KtBSTD_r_SurgeLim [-]

Axis is Corrected Air Mass Flow [g/s]

16.0000	1.1200
18.0000	1.2300
36.0000	1.6000
41.0000	1.8500
77.0000	2.4600
103.0000	3.2000

P226B

KtBSTD_r_ExcsvBstPresLim [-]

Axis is Corrected Air Mass Flow [g/s]

103.0000	3.2040
111.0000	3.2220
119.0000	3.1860
128.0000	3.1050
135.0000	2.9790
143.0000	2.7810
149.0000	2.5110
149.0000	2.5110

ECM Supporting Tables

P0324/P0326 Abnormal Noise Threshold (same table used for both):

X-axis: Engine Air Flow (mg per cylinder) Y-axis: Engine Speed (RPM) 100 300 0.0450 0.0450 0.0450 0.0450 1000 0.0450 0.0450 0.0450 0.0450 0.0450 0.0450 0.0450 2000 0.0450 0.0450 0.0450 0.0450 0.0450 2500 0.0450 0.0450 0.0450 3000 0.0450 0.0450 0.0450 0.0450 3500 0.0450 0.0450 0.0450 0.0450 4000 0.0450 0.0450 0.0450 0.0450 4500 0.0450 0.0450 0.0450 0.0450 5000 5500 0.0450 0.0450 0.0450 0.0450 0.0450 0.0450 0.0450 0.0450 6000 0.0450 0.0450 0.0450 0.0450 6500 0.0450 0.0450 0.0450 0.0450 7000 0.0450 0.0450 0.0450 0.0450 7500 0.0450 0.0450 0.0450 0.0450 8000 0.0450 0.0450 0.0450 0.0450 0.0450 8500 0.0450 0.0450 0.0450

P0325/P0330

Two methods are used for the Knock Sensor Open Circuit Diagnostic:

1) 20 kHz Method: 20 kHz signal is internally injected on one sensor line (Signal) and the output of the differential checked to verify the 20 kHz travels through the back to the second sensor input

2) Normal Noise: The amplitude of the FFT (in the knock frequency range) is checked to verify there is a knock signal within an expected range.

KtKNKD_e_OpenMethod is the cal table used to determine which Open Circuit method is used: '0' = Disabled; '1' = 20 kHz Method; '2' = Normal Noise Method

X-axis: Engine Air Flow (mg per cylinder) Y-axis: Engine Speed (RPM) 300 1200 1000 1500 2000 2500 3000 3500 4000 4500 5000 5500 6000 6500 7000 2 7500 2 2 8000 8500

8000

0.4609

8000

1.0703

8000

0.0000

8000

0.1895

8000

0.0000

0.3496

8500

0.4609

8500

1.0703

8500

0.0000

8500

0.1895

8500

0.0000

8500

0.3496

12 OBDG02 Engine Diagnostics

ECM Supporting Tables

ECM Supporting Tables																	
	Open Circuit Thresh	olds:															
	1. 20 kHz Method:																
	Engine Speed (F	RPM):	700	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500
	OpenCktThrsh	nMin: 1.	.1289	1.1250	0.9512	0.8828	0.7051	0.5820	0.4395	0.3438	0.3926	0.4160	0.4258	0.4434	0.4609	0.4609	0.4609
	Engine Speed (F	PM).	700	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500
	OpenCktThrsh		.6035	2.5938	2.1992	2.0371	1.6348	1.3516	1.0137	0.7891	0.8984	0.9492	0.9883	1.0293	1.0703	1.0703	1.0703
	2. Normal Noise Met	hod:															
	Engine Speed (F	PM).	700	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500
	OpenCktThrsh		.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
	Engine Speed (F		700	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500
	OpenCktThrsh	Max: 0.	.0410	0.0410	0.0449	0.0508	0.0508	0.0527	0.0586	0.0625	0.0723	0.0879	0.0996	0.1406	0.1895	0.1895	0.1895
P06B6/P06B7																	
	Engine Speed (F	PM).	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500
OpenTestThreshl			.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000
	·																
Engine Speed (RPM): OpenTestThreshH			.0898	0.0898	1500 0.0898	2000 0.0898	2500 0.0898	3000 0.1094	3500 0.1094	4000 0.1250	4500 0.1504	5000 0.1992	5500 0.2500	0.3008	6500 0.3496	7000 0.3496	7500 0.3496
	Openirestriii	esiini 0.	.0090	0.0090	0.0090	0.0090	0.0090	0.1094	0.1094	0.1230	0.1304	0.1992	0.2300	0.3006	0.3490	0.3490	0.3490
P0068: MAP / MAF / TPS Correleation																	
		is TPS (%)															
X-axis	0.69 5.0	MAP thresh	nold (kPa) 10.00	15.00	20.00	25.00	30.00	40.00	55.00								
Data	42.00 41		39.92	31.00	28.60	28.32	29.14	70.00	110.00								
		is TPS (%)															
		MAF thresh															
X-axis Data	0.69 5. 10.00 11		10.00	15.00 14.33	20.00 16.32	25.00 22.16	30.00 28.16	40.00 70.00	55.00 120.00								
Data	10.00	.40 1	13.30	14.33	10.32	22.10	20.10	70.00	120.00								
	X axis	is Engine Sp	peed (RPM	1)													
		max MAF v	vs RPM (g														
X-axis	600.00 140		200.00	3000.00	3800.00	4600.00	5400.00	6200.00	7000.00								
Data	20.00 20	.00 2	20.00	20.00	20.00	20.00	20.00	20.00	20.00								
	X avie	is Battery Vo	oltage (\/\														
				(grams/sec)													
X-axis	6.00 7.	00 8	8.00	9.00	10.00	11.00	12.00	13.00	14.00								
Data	511.99 511	.99 5	11.99	511.99	511.99	511.99	511.99	511.99	511.99								
P1682: Ignition Voltage Correlaction	n																
P1682: Ignition Voltage Correleation																	

X-axis is IAT (DegC) Data is Voltage threshold (V)

95.00

9.00

105.00

9.20

125.00

10.00

85.00

8.70

23.00

7.00

X-axis Data

ECM Supporting Tables

P0606: Processor Performance Check - ETC software is not executed in proper order

X-axis is task loop time

Data is threshold (seconds)

X-axis CePISR_e_6p25msSeq CePISR_e_12p5msSeq CePISR_e_25msSeq CePISR_e_LORES_C Data 0.200 0.200 0.200 409.594

X-axis is task loop time

Data indicates if feature is enabled

X-axis CePISR_e_8p25msSeq CePISR_e_12p5msSeq CePISR_e_25msSeq CePISR_e_LORES_C

1 1 0 Data

P16F3: No fast unmanaged retarded spark above the applied spark

Y-axis is Air per Clyinder (mg)

Data is spark delta threshold (kPa)

KtSPRK_phi_DeltTorqueScrtyAdv

PC/Frnm			

р.	Doit: 0. quoo.	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,															
_	500.00	980.74	1461.48	1942.23	2422.97	2903.71	3384.45	3865.20	4345.94	4826.68	5307.42	5788.16	6268.91	6749.65	7230.39	7711.13	8191.88
80.00	66.53	65.61	74.64	74.84	68.17	66.78	64.83	62.25	59.05	55.95	53.86	52.88	52.27	52.09	52.09	52.09	52.09
160.00	60.66	56.70	63.02	57.88	51.11	48.41	47.02	45.31	42.17	39.30	36.95	35.59	34.72	34.48	34.48	34.48	34.48
240.00	49.52	46.05	52.03	44.97	40.02	36.55	35.25	34.22	32.47	30.28	28.13	26.81	26.00	25.77	25.77	25.77	25.77
320.00	41.56	37.98	43.95	36.77	32.09	28.98	28.06	27.38	25.78	24.36	22.70	21.52	20.78	20.58	20.58	20.58	20.58
400.00	35.80	32.31	37.69	31.05	26.80	24.02	23.31	22.80	21.33	20.11	18.89	17.97	17.30	17.13	17.13	17.13	17.13
480.00	31.44	28.13	32.97	26.88	23.00	20.50	19.94	19.53	18.19	17.09	16.08	15.34	14.81	14.66	14.66	14.66	14.66
560.00	29.08	25.89	30.44	24.67	21.02	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
640.00	29.08	25.89	30.44	24.67	21.02	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
720.00	29.08	25.89	30.44	24.67	21.02	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
800.00	29.08	25.89	30.44	24.67	21.02	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
880.00	29.08	25.89	30.44	24.67	21.02	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
960.00	29.08	25.89	30.44	24.67	21.02	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
1040.00	29.08	25.89	30.44	24.67	21.02	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
1120.00	29.08	25.89	30.44	24.67	21.02	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
1200.00	29.08	25.89	30.44	24.67	21.02	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
1280.00	29.08	25.89	30.44	24.67	21.02	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
1360.00	29.08	25.89	30.44	24.67	21.02	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38

P16F3: Absolute difference of the calculated Intake Manifold Pressure during engine event versus during time event

X-axis is engine torque (Nm) Data is MAP delta threshold (kPa)

10.00 25.00 50.00 100.00 150.00 X-axis Data 29.69 29.69 29.69 29.69

P16F3: Table to calculate limit for predicted torque for zero pedal determination.

X-axis is engine oil temp in C deg Y-axis is engine speed RPM

	U	ata is Torque	(Nm)			
_	-40.00	-20.00	-10.00	0.00	50.00	90.00
200.00	4096.00	4096.00	4096.00	4096.00	4096.00	4096.00
400.00	1412.00	1412.00	1412.00	1412.00	1412.00	1412.00
600.00	150.00	150.00	150.00	150.00	150.00	150.00
700.00	150.00	150.00	150.00	150.00	150.00	150.00
1000.00	150.00	150.00	150.00	150.00	150.00	150.00
1200.00	150.00	150.00	150.00	150.00	150.00	150.00
1600.00	150.00	150.00	150.00	150.00	150.00	150.00
2000.00	150.00	150.00	150.00	150.00	150.00	150.00
2500.00	150.00	150.00	150.00	150.00	150.00	150.00
3000.00	150.00	150.00	150.00	150.00	150.00	150.00
3500.00	150.00	150.00	150.00	150.00	150.00	150.00
4000.00	150.00	150.00	150.00	150.00	150.00	150.00
4500.00	150.00	150.00	150.00	150.00	150.00	150.00
5000.00	150.00	150.00	150.00	150.00	150.00	150.00
6000.00	150.00	150.00	150.00	150.00	150.00	150.00
7000.00	150.00	150.00	150.00	150.00	150.00	150.00
8000.00	150.00	150.00	150.00	150.00	150.00	150.00

ECM Supporting Tables

P0442: EONV Pressure Threshold Table (in Pascals)

X axis is fuel level in %

Y axis is temperature in deg (

	I axis is terrip	erature in deg	C														
	0.0000	6.2499	12.4998	18.7497	24.9996	31.2495	37.4994	43.7493	49.9992	56.2491	62.4990	68.7490	74.9989	81.2488	87.4987	93.7486	99.9985
-10.0000	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
-4.3750	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
1.2500	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
6.8750	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
12.5000	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
18.1250	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
23.7500	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
29.3750	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
35.0000	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
40.6250	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
46.2500	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
51.8750	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
57.5000	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
63.1250	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
68.7500	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
74.3750	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788
80.0000	-448.3143	-448.3143	-448.3143	-423.5025	-398.4475	-373.6358	-348.8240	-323.7690	-298.9573	-273.9023	-249.0905	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788	-224.2788

P0442: Estimate of Ambient Temperature Valid Conditioning Time

EAT Valid Conditioning Time (in seconds)

Axis is Ignition Off Time (in seconds)

Axis	o .g	Curve
	0	178
	600	345
	1200	345
	1800	345
	2400	345
	3000	345
	3600	285
	4200	283
	4800	281
	5400	279
	6000	276
	6600	274
	7200	272
	7800	270
	8400	268
	9000	266
	9600	263
	10200	261
	10800	259
	11700	256
	12600	253
	13500	249
	14400	246
	15300	244
	16200	243
	17100	241
	18000	240
	19200	237
_	20400 21600	235 233
	22800	233
	24000	224
	25200	220

P0442: Engine Off Time Before Vehicle Off Maximum as a Function of Estimated Ambient Temperature

	Engine Off Ti	ime Before V	ehicle Off Ma	aximum Table	in seconds)		Axis is Estimated Ambient Coolant in Deg C										
Axis	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
Curve	44	44	44	44	68	82	105	153	320	480	480	480	480	480	480	480	480

ECM Supporting Tables

P0496: Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level

Purge Valve Leak Test Engine Vacuum Test Time (in seconds) Avis is Fuel I evel in %

	Level III %
Axis	Curve
0	100
6	100
12	80
19	75
25	70
31	65
37	60
44	60
50	60
56	60
62	60
69	55
75	50
81	45
87	40
94	30
100	30

P0461, P2066, P2636: Transfer Pump Enable

TransferPumpOnTimeLimit (in seconds) Axis is Fuel Level in %

Axis	Cur	ve
	0	0
	3	0
	6	0
	9	0
1	3	0
1	6	0
1	9	0
2	22	0
2	25	0
2	28	0
3	31	0
3	34	0
3	38	0
	11	0
	14	0
4	17	0
	50	0
	3	0
	6	0
	9	0
6	3	0
6	66	0
6	69	0
7	'2	0
7	'5	0
7	'8	0
3	31	0
8	34	0
8	38	0
9	91	0
9	94	0
9	97	0
10	00	0

Tables supporting Clutch Diagnostics

Curve

P0806 EngTorqueThreshold Table axis is Percent Clutch Pedal Position, 0 = bottom of travel 6.2485 18.7455 24.994 31.2425 37.491 43.7395 49.988 62.485 68.7335 Axis

74.982 87.479 93.7275 99.976 12.497 81.2305 30.0 50.0 60.0 Curve 50.0

neutral

P0806 ResidualErrorEnableLow Table axis is Gear Axis 2nd rev Curve

P0806 ResidualErrorEnableHigh Table axis is Gear Axis 2nd 5th 6th neutral 0.0

ECM Supporting Tables

Tables supporting Clutch Pedal Position Status (analog Clutch Pedal Position Sensor applications only):

Clutch Pedal Top of Travel Achieved co												
The clutch pedal Top of Travel state will transition from FALSE to TRUE when the following occurs:												
Clutch Pedal Position	<= 90 %											
for	> 3 counts	each count is equal to 12.5ms										
Clutch Disengaged criteria												
The clutch state will transition from engag	ed to disengaged when the t	following occurs:										
Clutch Pedal Position	<= 58 %											
for	> 3 counts	each count is equal to 12.5ms										

Clutch Pedal Bottom of Travel Achieved criteria The clutch pedal Bottom of Travel state will transition from FALSE to TRUE when the following occurs:

Clutch Pedal Position each count is equal to 12.5ms

FASD Section P0171, P0172, P0174, P0175

zed for FASD diagnosis (cells identified with a "Yes" are enabled, and with a "NO" are disabled)

Long-Term Fuel Trim Cell Usage

	CeFADR_e_	CeFADR_e_	CeFADR_e_	CeFADR_e_	CeFADR_e_	CeFADR_e_	CeFADR_e_	CeFADR_e_C	CeFADR_e_	CeFADR_e_	CeFADR_e_	CeFADR_e_	CeFADR_e_	CeFADR_e_	CeFADR_e_	CeFADR_e_
	Cell00_PurgO	Cell01_Purg	Cell02_Purg	Cell03_Purg	Cell04_Purg	Cell05_Purg	Cell06_Purg	ell07_PurgOn	Cell08_Purg	Cell09_Purg	Cell10_Purg	Cell11_Purg	Cell12_Purg	Cell13_Purg	Cell14_Purg	Cell15_Purg
Cell I.D.	nAirMode5	OnAirMode4	OnAirMode3	OnAirMode2	OnAirMode1	OnAirMode0	Onldle	Decel	OffAirMode5	OffAirMode4	OffAirMode3	OffAirMode2	OffAirMode1	OffAirMode0	OffIdle	OffDecel
	CeFADD_e_S	CeFADD_e_	CeFADD_e_	CeFADD_e_	CeFADD_e_	CeFADD_e_	CeFADD_e_	CeFADD_e_N	CeFADD_e_	CeFADD_e_	CeFADD_e_	CeFADD_e_	CeFADD_e_	CeFADD_e_	CeFADD_e_	CeFADD_e_
	electedPurge	SelectedPur	SelectedPur	SelectedPur	SelectedPurg	SelectedPurg	SelectedPurg	onSelectedCe	SelectedNon	SelectedNon	SelectedNon	SelectedNon	SelectedNon	SelectedNon	SelectedNon	NonSelected
FASD Cell Usage	Cell	geCell	geCell	geCell	eCell	eCell	eCell	II	PurgeCell	PurgeCell	PurgeCell	PurgeCell	PurgeCell	PurgeCell	PurgeCell	Cell
ASD Enabled in Cell?	Yes	Yes	Yes	Yes	Yes	Yes	Yes	NO	Yes							

FAPD Section Ian MacEwen P2096, P2097, P2098, P2099

Cell Accum Tir	ne Min										
								Bank1 Light	Bank2 Light	Bank1	Bank2
	Post O2 Air Flow Mode Bank1 De	ecel Bank2 [Decel Bank1 I	ldle	Bank2 Idle	Bank1 Cruise	Bank2 Cruise	Accel	Accel	Heavy Accel	Heavy Accel
Cell Accum Min	Count	300	300	300	300	100	100	100	100	300	300
Cell Accum Min	Time [seconds] (time =										
counts / 10)		0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
Integral Offset	Max										
	Post O2 Air Flow Mode Decel	Idle	Cruise		Light Accel	Heavy Accel					
Post O2 Integra	I Offset Max [mV]	0.0	0.0	0.0	0.0	0.0)				
Integral Offset	Min										
	Post O2 Air Flow Mode Decel	ldle	Cruise		Light Accel	Heavy Accel					
Post O2 Integra	I Offset Min [mV]	0.0	0.0	0.0	0.0	0.0)				
O2 Lean Thres	h										
								Bank1 Light	Bank2 Light	Bank1	Bank2
P	ost O2 Airflow Mode Cell Bank1 De	ecel Bank2 [Decel Bank1 I	ldle	Bank2 Idle	Bank1 Cruise	Bank2 Cruise	Accel	Accel	Heavy Accel	Heavy Accel
O2 Lean Thresh	nold [mV]	650	650	650	650	650	650	650	650		650
	• •										

O2 Rich Thre	esh							
				Ba	nk1 Light	Bank2 Light	Bank1	Bank2
	Post O2 Airflow Mode Cell Rank1 Decel	Rank? Decel Rank1 Idle	Bank2 Idle	Bank1 Cruise Bank2 Cruise Ac	rel	Accel	Heavy Accel	Heavy Accel

O2 Rich Threshold [mV]

Out Of Window Timer Cruise Post O2 Airflow Mode Cell Decel Idle Light Accel Heavy Accel Out of Window Counts 100 100 100 100 Out of Window Time [seconds] (time = counts / 10) 0.0

Bank1 Light Bank2 Light Bank1 Selected Cells Bank1 Decel Bank2 Decel Bank1 Idle Bank2 Idle Bank1 Cruise Bank2 Cruise Accel Accel Heavy Accel Heavy Accel Heavy Accel Post O2 Airflow Mode Selected Cell 0 0 0 0 0 if not selected, 1 if selected

P2096, P2097, P2098, P2099 Cell Accum Time Min

							Bank1 Light	Bank2 Light	Bank1	Bank2
Post O2 Air Flow Mode Ban	k1 Decel I	Bank2 Decel	Bank1 Idle	Bank2 Idle	Bank1 Cruise	Bank2 Cruise	Accel	Accel	Heavy Accel	Heavy Accel
Cell Accum Min Count	300	300	300	300	100	100	100	100	300	300
Cell Accum Min Time [seconds] (time = counts / 10)	30.0	30.0	30.0	30.0	10.0	10.0	10.0	10.0	30.0	30.0

152 0.0

152 1.0

80 92 104 116 128 140 0.0 0.0 0.0 0.0 0.0 0.0

80 92 104 116 128 140 2.0 1.0 1.0 1.0 1.0 1.0

12 OBDG02 Engine Diagnostics

ECM Supporting Tables

						E	CM Suppo	orting Table	es	
Integral Offset Max Post O2 Air Flow Mode Post O2 Integral Offset Max [mV]	Decel #REF!	Idle #REF!	Cruise #REF!	Light Accel #REF!	Heavy Accel					
Integral Offset Min										
Post O2 Integral Offset Min [mV]	Decel #RFF!	Idle #RFFI	Cruise #REF!	Light Accel #REF!	Heavy Accel #REF!					
O2 Lean Thresh	#ICEL:	midel :	#INCI :	#INCI:	mile!					
Post O2 Airflow Mode Cell	Rank1 Decel	Bank? Decel	Rank1 Idle	Bank2 Idle	Bank1 Cruice	Bank2 Cruise	Bank1 Light	Bank2 Light Accel	Bank1 Bar Heavy Accel Hea	
D2 Lean Threshold [mV]	650									650
02 Rich Thresh							Bank1 Light	Bank2 Light	Bank1 Bar	nk2
Post O2 Airflow Mode Cell O2 Rich Threshold [mV]	Bank1 Decel 770			Bank2 Idle 770		Bank2 Cruise 770	Accel	Accel	Heavy Accel Hea	avy Accel 770
Out Of Window Timer Post O2 Airflow Mode Cell	Docal	Idle	Cruise	Light Accel	Heavy Accel					
Out of Window Counts	100)				
Out of Window Time [seconds] time = counts / 10)	0.0	0.0	0.0	0.0	0.0)				
							Bank1 Light		Bank1 Bar	
elected Cells lost O2 Airflow Mode Selected Cell if not selected, 1 if selected	Bank1 Decel 0	Bank2 Decel		Bank2 Idle	Bank1 Cruise	Bank2 Cruise 1	Accel 1		Heavy Accel Hea	avy Accel 1
losed Loop Enable Criteria										
Engine run time greater than KtFSTA_t_ClosedLoopAutostart	(HYBRID ONI	V)								
AutoStart Coolant Close Loop Enable Time	-40 0.0	-28					32 0.0		56 0.0	68 0.0
nd .	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
tFSTA_t_ClosedLoopTime Start-Up Coolant	-40				-				56	68
Close Loop Enable Time nd pre converter 02 sensor voltage le FFULC_U_O2_SensorReadyThrshLo	< 950	120.0) 60.0	40.0) 15.0	15.0	13.0	12.0	6.0	4.0
Voltage or	milliVolts	J								
cFULC_O2_SensorReadyEvents Time (events * 12.5 milliseconds)	> 40 events	1								
nd OSC (Converter Oxygen Storage Co		bled								
ind Consumed AirFuel Ratio is stoichiom			protection							
and POPD or Catalyst Diagnostic not intru	-									
ind Turbo Scavenging Mode not enabled										
ind	46:		ablad							
All cylinders whose valves are active a										
O2S_Bank_ 1_TFTKO, O2S_Bank_ 2_	TFTKO, Fuellr	njectorCircuit	_FA and Cyln	derDeacDrive	erTFTKO = Fa	lse				
Long Term FT Enable Criteria										
Closed Loop Enable and Coolant greater than										
KFCLL_T_AdaptiveLoCoolant Coolant	> 40 Celcius	1								
or less than KFCLL_T_AdaptiveHiCoolant		•								
Coolant	< 120 Celcius	1								
nd		1								
tFCLL_p_AdaptiveLowMAP_Limit Barometric Pressure	65						95		105	
Manifold Air Pressure	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	
<pre>FPS_ThrottleAuthorityDefaulted = Fal- and</pre>										
Flex Fuel Estimate Algorithm is not ac and	tive									
Excessive fuel vapors boiling off from and	the engine o	il algorithm (I	BOFR) is not	enabled						

Catalyst or EVAP large leak test not intrusive

X10

X11

X12

X13

X14

X15

X16

X17

ECM Supporting Tables

Secondary Fuel Trim Enable Criteria

Closed Loop Enable and KfFCLP_U_O2ReadyThrshLo

< 1000

Voltage milliVolts

KcFCLP_Cnt_O2RdyCyclesThrsh

Time (events * 12.5 milliseconds) > 80 events

Long Term Secondary Fuel Trim Enable Criteria

KtFCLP_t_PostIntglDisableTime

Y10 Y11 Y12 Y13 Y14 Y15 Y16 Y17 50 73 118 Start-Up Coolant -29 -18 28 39 106 129 140 Post Integral Enable Time 170.0 170.0 170.0 170.0 170.0 170.0 170.0 170.0 170.0 170.0 170.0 170.0 170.0 170.0 170.0 170.0 170.0 Plus X10 X12 X13 X14 X16 X17 KtFCLP_t_PostIntglRampInTime Y10 Y11 Y12 Y13 Y14 Y15 Y16 Y17 Start-Up Coolant 39 140 10.0 10.0 10.0 10.0 10.0 10.0 10.0 10.0 10.0 10.0 10.0 10.0 10.0 10.0 Post Integral Ramp In Time 10.0 10.0 10.0

and

KeFCLP_T_IntegrationCatalystMax

< 830 Celcius

Modeled Catalyst Temperature

KeFCLP_T_IntegrationCatalystMin

> 450 Celcius

Modeled Catalyst Temperature

PO2S_Bank_1_Snsr_2_FA and PO2S_Bank_2_Snsr_2_FA = False

		Fault Bundles Produced (Fault Bundles Consumed - from line 364)	Cert Doc Bundle Name	P0040	Pcodes
		GetPHSR_b_PhaserBndlFlagFA GetPHSR b PhaserBndlFlagTFTKO	AnyCamPhaser_FA AnyCamPhaser TFTKO	P0010 P0010	P0011 P0013 P0014 P0020 P0021 P0023 P0024 P0011 P0013 P0014 P0020 P0021 P0023 P0024
		GetPHSR_b_lcPhaserBndlFlagFA	IntkCamPhaser_FA	P0010	P0011 P0020 P0021
Dilution DDT	FODD	GetEGRR_b_EGR_ValvePerf_FA	EGRValvePerformance_FA	P0401	P042E
Dilution PDT	EGRR	GetEGRR_b_EGR_ValveCkt_FA	EGRValveCircuit_FA	P0403	P0404 P0405 P0406
Dilution PDT	EGRR	GetEGRR_b_EGR_ValveFP	EGRValve_FP	P0405	P0406 P042E
Dilution PDT	EGRR	GetEGRR b EGR ValveCktTFTKO	EGRValveCircuit_TFTK0	P0403	P0404 P0405 P0406
Dilution PDT	EGRR	GetEGRR_b_EGR_ValvePerfTFTKO	EGRValvePerformance_TFTKO	P0401	P042E
	CATR	GetCATR b CatSysEffLoB1 FA	CatalystSysEfficiencyLoB1 FA	P0420	
		GetCATD_b_CatSysEffLoB2_FA	CatalystSysEfficiencyLoB2_FA	P0430	
Misfire PDT	MCED	GetMSFR_b_EngMisfDtctd_TFTKO	EngineMisfireDetected_TFTKC	D0200	P0301 P0302 P0303 P0304 P0305 P0306 P0307 P0308
WISHIE FD1	WISH	GetMSFR b EngMisfDtctd FA	EngineMisfireDetected_FA	P0300	P0301 F0302 F0303 F0304 F0305 F0306 F0307 F0308 F0307 F0308 F0307 F0308
			• • • • • • • • • •		
Air Measurement	ΔΔΡΡ	GetAAPR_b_AAP_SnsrFA	AAP_SnsrFA	naturally aspirated:	P2227 P2228 P2229 P2230
Weddaremen	704114	OCDAN N_D_ANI _ONSN A	AN COIST A	turbocharged:	P0237 P0238
		GetAAPR_b_AAP_SnsrCktFP	AAP_SnsrCktFP	naturally aspirated: turbocharged:	P2228 P2229 P0237 P0238
				turbochargeu.	
		GetAAPR_b_AAP_SnsrTFTKO	AAP_SnsrTFTKO	naturally aspirated:	P2227 P2228 P2229 P2230
				turbocharged:	P0237 P0238
		GetAAPR_b_AAP2_SnsrFA	AAP2_SnsrFA	P2227	P2228 P2229 P2230
		GetAAPR_b_AAP2_SnsrCktFP	AAP2_SnsrCktFP	P2228	P2229
		GetAAPR_b_AAP2_SnsrTFTKO GetAAPR b TC BoostPresSnsrCktFA	AAP2_SnsrTFTKO TC_BoostPresSnsrCktFA	P2227 P0237	P2228 P2229 P2230 P0238
		GetAAPR_b_TC_BoostPresSnsrFA	TC BoostPresSnsrFA	P0236	P0237 P0238
		GetAAPR b AmbPresSnsrCktFA	AmbPresSnsrCktFA	P2228	P2229
		GetAAPR_b_AmbPresSnsrCktFP	AmbPresSnsrCktFP	P2228	P2229
		GetAAPR b AmbientAirPresDfltd	AmbientAirDefault	baro or TIAP sensor:	P2227 P2228 P2229 P2230
		==		no baro or TIAP sensor:	P0101 P0102 P0103 P0106 P0107 P0108 P0111 P0112 P0113 P0114 P0121 P0122 P0123 P012B P012C P012D P0222 P0223 P1
		GetAAPR_e_AmbPresDfltdStatus	AmbPresDfltdStatus	baro or TIAP sensor:	P2227 P2228 P2229 P2230
		GEMARK_E_AITIDFTESDITUSTATUS	AmbriesDilluStatus	no baro or TIAP sensor:	P0101 P0102 P0103 P0106 P0107 P0108 P0111 P0112 P0113 P0114 P0121 P0122 P0123 P012B P012C P012D P0222 P0223 P1
Air Measurement	EITD	GetEITR_b_IAT_SnsrCktTFTKO	IAT SensorCircuitTFTKO	P0112	P0113
Measurement	LIIIX	GetEITR_b_IAT_ShiriCktF1 TRO	IAT_SensorCircuitFA	P0112	P0113
		GetEITR_b_IAT_SnsrCktFP	IAT_SensorCircuitFP	P0112	P0113
		GetEITR_b_IAT_SnsrTFTKO	IAT_SensorTFTKO	P0111	P0112 P0113
		GetEITR_b_IAT_SnsrFA GetEITR_b_IAT_2_SnsrCktTFTKO	IAT_SensorFA IAT2_SensorCktTFTKO	P0111 IAT2 Present	P0112 P0113 P0097 P0098
		GELETT D_IAT_Z_STISTORTFTRO	IATZ_SellsolcktifTKO	IAT2 Not Present	P0112 P0113
		GetEITR_b_IAT_2_SnsrCktFA	IAT2_SensorCircuitFA	IAT2 Present IAT2 Not Present	P0097 P0098 P0112 P0113
				INTERIOR FROM	10112 10110
		GetEITR_b_IAT_2_SnsrCktFP	IAT2_SensorcircuitFP	IAT2 Present	P0097 P0098
				IAT2 Not Present	P0112 P0113
		GetEITR_b_IAT_2_SnsrTFTKO	IAT2_SensorTFTKO	IAT2 Present	P0096 P0097 P0098
			_	IAT2 Not Present	P0111 P0112 P0113
		GetEITR b IAT 2 SnsrFA	IAT2 SensorFA	IAT2 Present	P0096 P0097 P0098
		OCETIV_D_IAT_Z_ORBITA	IATE_OCISOTIA	IAT2 Not Present	P0111 P0112 P0113
		OUESTED I TILLIT OF TETMO	TT. 0. TETKO	IAT2 Present	P0096 P0097 P0098
		GetEITR_b_ThrotTempSnsrTFTKO	ThrotTempSensorTFTKO	IAT2 Present IAT2 Not Present	P0096 P0097 P0098 P0111 P0112 P0113
		GetEITR_b_ThrotTempSnsrFA	ThrotTempSensorFA	IAT2 Present IAT2 Not Present	P0096 P0097 P0098 P0111 P0112 P0113
				IA12 NOt Present	P0111 P0112 P0113
Air					
Measurement	HUMR	GetHUMR_b_HumidityFA	HumidityFA	P0097	
Air					
Measurement	IFRR	GetIFRR_b_ChgrBypVlvFault	SuperchargerBypassValveFA	P2261	
		GetIFRR_b_CylDeacSys_TFTKO	CylDeacSystemTFTKO	P3400	
		GetIFRR_b_MAF_SnsrPerfFault GetIFRR b MAF SnsrPerf TFTKO	MAF_SensorPerfFA MAF SensorPerfTFTKO	P0101 P0101	
		GetIFRR_b_MAP_SnsrPerfFault	MAP_SensorPerfFA	P0101 P0106	
		GetIFRR_b_MAP_SnsrPerf_TFTKO	MAP_SensorPerfTFTKO	P0106	
		GetIFRR_b_SCIAP_SnsrPerfFault	SCIAP_SensorPerfFA	P012B	
		GetIFRR_b_SCIAP_SnsrPerf_TFTKO	SCIAP_SensorPerfTFTKO	P012B	
		GetIFRR_b_TP_SnsrPerfFault	ThrottlePositionSnsrPerfFA	P0121	
		GetIFRR_b_TP_SnsrPerf_TFTKO GetIFRR_b_TIAP_SnsrPerfFault	ThrottlePositionSnsrPerfTFTKO TIAP_SensorPerfFA	P0121 P0236	
					P0102 P0103

	Fault Bundles Produced (Fault Bundles Consumed - from line 364)	Cert Doc Bundle Name											codes			
Air			Postos	DC::												
Measurement MAF	R GetMAFR_b_MAF_SnsrFA GetMAFR_b_MAF_SnsrTFTKO	MAF_SensorFA MAF_SensorTFTKO	P0101 P0101	P0102 P0103	2 P010	103										
	GetMAFR b MAF SnsrFP	MAF SensorFP	P0102	P0103												
	GetMAFR_b_MAF_SnsrCktFA	MAF_SensorCircuitFA	P0102	P0103	3											
	GetMAFR_b_MAF_SnsrCktTFTKO	MAF_SensorCircuitTFTKO	P0102	D040												
Air				P0107	7 P010	108										
	PR GetMAPR b MAP SnsrTFTKO	MAP SensorTFTKO	P0106	P0107	7 P010	108										
	GetMAPR_b_MAP_SnsrFA	MAP_SensorFA	P0106	P0108												
	GetMAPR_b_MAP_SnsrCktFP	MAP_SensorCircuitFP SCIAP_SensorFA	P0107	P0120												
	GetMAPR_b_SCIAP_SnsrFA GetMAPR_b_SCIAP_SnsrTFTKO	SCIAP_SensorFA SCIAP_SensorTFTKO	P012B P012B	P0120	C P012	120										
	GetMAPR_b_SCIAP_SnsrCktFP	SCIAP_SensorCircuitFP	P012C	1 0126												
				P0106	9 P010	107 P	20108									
	GetMAPR_b_AfterThrotBlade_FA	AfterThrottlePressureFA	naturally aspirated, turbocharged	D012E	B P012	12C D	2012D									
	GetWAFIX_D_AILEI FIIIOLDIAGE_FA	Alter miother ressurer A	supercharged	FUIZE	5 1012	120 1	0120									
				P0106	9 P010	107 P	0108									
			naturally aspirated,													
	GetMAPR_b_AftThrotVacSnsr_TFTKO	AfterThrottleVacuumTFTKO	turbocharged supercharged	P012E	3 P012	12C P	2012D									
			superchargeu	P012)											
	GetMAPR_b_SCIAP_SnsrCktFA	SCIAP_SensorCircuitFA	P012C													
				P0106	P010	107 P	20108									
	GetMAPR b AftThrotPresSnsrTFTKO	AfterThrottlePressTFTKO	naturally aspirated, turbocharged	P012F	3 P012	12C P	012D									
	County N_D_ARTHOR ROSONS IT THO	, mon minuted reading into	supercharged			0	0120									
			-	P0108	3											
	GetMAPR_b_MAP_SnsrCktFA	MAP_SensorCircuitFA	P0107	D0400 /												
	GetMAPR_e_EngVacStatus() == CeMAPR_e_Defaulted	MAP_EngineVacuumStatus	MAP_SensorFA OR P0107,	P0108 F P0017	Penaing 7 P00°	g)18 P	20019									
Engine							00.0									
Positioning EPS	R GetEPSR_b_CkpToCamCorr_TFTKO	CrankCamCorrelationTFTKO	P0016	P0336												
	GetEPSR_b_CrankSnsr_FA GetEPSR b CrankSnsr TFTKO	CrankSensorFA CrankSensorTFTKO	P0335 P0335	P0336 P0017)18 P	20010	D0240	D0244	D0245	5 P0346	: D03/	e Dose	6 P0390	P0391	
	GetEPSR_b_CrankSnsr_FA GetEPSR_b_CamSnsr_FA	CamSensorFA	P0335 P0016	P0017				P0340			P0346					
	GetEPSR b CamSnsr TFTKO	CamSensorTFTKO	P0016	P0018		,10 1	0015	1 0040	1 0041	1 00-10	7 1 00-10	, 100	00 1 000	0 1 0000	1 0001	
	GetEPSR_b_CkpToCamCorrInt_FA	CrankIntakeCamCorrelationFA	P0016	P0019												
	GetEPSR_b_CkpToCamCorrExh_FA	CrankExhaustCamCorrelationFA		P0018			0341 0341	P0345 P0345	P0346 P0346							
	GetEPSR_b_CamSnsrIntake_TFTKO GetEPSR_b_CamSnsrIntake_FA	IntakeCamSensorTFTKO IntakeCamSensorFA	P0016 P0016	P0018				P0345 P0390	P0346 P0391							
	GetEPSR_b_CamSnsrExhaust_TFTKO	ExhaustCamSensorTFTKO	P0017	P0019				P0390	P0391							
	GetEPSR_b_CamSnsrExhaust_FA	ExhaustCamSensorFA	P0017	P0018	B P034	340 P	0341	P0345	P0346							
	GetEPSR_b_IntakeSnsrFaultActive	IntakeCamSensor_FA	P0016	P0018				P0345	P0346							
	GetEPSR_b_IntakeSnsrTestFailTKO GetEPSR_b_ExhSnsrFaultActive	IntakeCamSensor_TFTKO ExhaustCamSensor_FA	P0016 P0017	P0019		365 P 365 P		P0390 P0390	P0391 P0391							
	GetEPSR_b_ExhSnsrTestFailTKO	ExhaustCamSensor_TFTKO	P0017	P0018		J03 F	0300	1 0330	1 0001							
	GetEPSR_b_CkpToCamCorrInt	CrankIntakeCamCorrFA	P0016	P0019												
	GetEPSR_b_CkpToCamCorrExh	CrankExhaustCamCorrFA	P0017	P0336												
	GetEPSR_b_CrankSnsrFaultActive GetEPSR b CrkSnsrFA	CrankSensorFaultActive CrankSensor FA	P0335 P0335	P0336												
	GetEPSR_b_CrankSnsrTestFailTKO	CrankSensorTestFailedTKO	P0335	P0336												
	GetEPSR_b_CrkSnsrTFTKO	CrankSensor_TFTKO	P0335	P0017	7 P00			P0340			P0346					
	GetEPSR_b_CamSnsrFaultActive	CamSensor_FA	P0016	P0017				P0340						6 P0390		
	GetEPSR_b_CamSnsrLctnAnyFA GetEPSR_b_CamSnsrTestFailTKO	CamSensorAnyLocationFA CamSensor TFTKO	P0016 P0016	P0017	7 P001)18 P	20019	P0340	P0341	P0345	5 P0346	P036	65 P036	6 P0390	P0391	
	Octal or b_ballions rest air No	Camochsol_11 11CO	1 00 10													
		= =														
Engine Moding EMI	DR GetEMDR_b_EngModeNotRunTmErr	EngModeNotRunTmErr	P2610	P0118	3											
Cooling System				1 0110	-											
PDT ECT		ECT_Sensor_Ckt_FA	P0117	P0118												
	NeECTI_b_ECT_SnsrCktTPTKO	ECT_Sensor_Ckt_TPTKO	P0117	P0118												
	NeECTI_b_ECT_SnsrCktTFTKO	ECT_Sensor_Ckt_TFTKO ECT_Sensor_DefaultDetected	P0117 P0117	P0118	B P01		20119 20119	D0120								
	NeECTI_b_DfltECT_CondDtctd NeECTI_b_ECT_SnsrFA	ECT_Sensor_FA	P0117 P0117		3 P01		20119	P0128								
	NeECTI_b_ECT_SnsrTFTKO	ECT_Sensor_TFTKO	P0117													
	NeECTI_b_ECT_SnsrPerfFA	ECT_Sensor_Perf_FA	P0116	P0118	3											
	VeECTI_b_ECT_SnsrCktFP	ECT_Sensor_Ckt_FP	P0117													
	GetECTI_b_ECT_SnsrCktHiFP GetETCI_b_ECT_SnsrCktLoFP	ECT_Sensor_Ckt_High_FP ECT_Sensor_Ckt_Low_FP	P0118 P0117													
THN	MD NeTHMD_b_InsuffCintFlwFA	THMR_Insuff_Flow_FA	P00B7 P0597	P0598		599										
	NeTHMD_b_ThstCntrlFA NeTHMD_b_ERTSnsrCktFA	THMR_Therm_Control_FA THMR_RCT_Sensor_Ckt_FA	P0597 P00B3	P00B4		116 P	OUUBE									
	NeTHMD_b_ECTSnsrCktFA NeTHMD_b_ECTSnsrCktFA	THMR_ECT_Sensor_Ckt_FA THMR_ECT_Sensor_Ckt_FA	P00B3 P0117	F U 1 16	, rul	10 P	0000									
				P0132			2A00									
O2 PDT OXY	'R VaOXYI_O2_TestFailedThisKeyOn[CiFADR_FuelBank1 VaOXYI_O2_TestFailedThisKeyOn[CiFADR_FuelBank2]	O2S_Bank_ 1_TFTKO O2S_Bank_ 2_TFTKO	P0131 P0151	P0152 P0131			P2A03	D0424	D0435	DOOL	D4400	D041	5A D045	D Dunan		
	NeOXYI b Bank1Snsr1 FA	O2S_Bank_1_Sensor_1_FA	P2A00	P0131				P0134 P2270						B P0030 1 P0054	P0036	
	NeOXYI_b_Bank1Snsr2_FA	O2S_Bank_1_Sensor_2_FA	P013A	P0151	1 P015	152 P	0153	P0154	P0155	P0059	P1153	P01	C P015	D P0050		
	NeOXYI_b_Bank2Snsr1_FA	O2S_Bank_2_Sensor_1_FA	P2A03	P013E	D P014	I4A P	014B	P2272	P2273	P0157	7 P0158	P016	0 P016	1 P0060	P0056	

		Fault Bundles Produced (Fault Bundles Consumed - from line 364)	Cert Doc Bundle Name		Pcodes
		NeOXYI_b_Bank2Snsr2_FA	O2S_Bank_2_Sensor_2_FA	P013C	P0138 P0140 P0036 P0054 P0141 P2270 P2271
		NeOXYI_b_PO2_CntrlBank1Snsr2_FA	PO2S_Bank_1_Snsr_2_FA	P0137	P0158 P0160 P0056 P0060 P0161 P2277 P2273
		NeOXYI_b_PO2_CntrlBank2Snsr2_FA	PO2S_Bank_2_Snsr_2_FA	P0157	10.00 10.00 10.000 10.000 122.2 122.0
					P0202 P0203 P0204 P0205 P0206 P0207 P0208
	FULR	GetFULR_b_FuelInjCkt_FA	FuelInjectorCircuit_FA	P0201	P0264 P0267 P0270 P0273 P0276 P0279 P0282
				P0261	P0265 P0268 P0271 P0274 P0277 P0280 P0283
				P0262	P2150 P2153 P2156 P216B P216E P217B P217E
				P2147	P2151 P2154 P2157 P216C P216F P217C P217F
				P2148	P1249 P124A P124B P124C P124D P124E P124F
				P1248	P0202 P0203 P0204 P0205 P0206 P0207 P0208
	EIIID	GetFULR_b_FuelInjCkt_TFTKO	FuelInjectorCircuit_TFTKO	P0201	PUZUZ PUZU3 PUZU4 PUZU5 PUZU5 PUZU6 PUZU6 PUZU6 PUZU6 PUZU6 PUZU6 PUZU6 PUZU6 PUZU7
	I OLIV	oca oca oca oca oca oca oca oca oca oca	r delinjectorolicut_11 110	P0261	P0265 P0268 P0271 P0274 P0277 P0280 P0283
				P0262	P2150 P2153 P2156 P216B P216E P217B P217C
				P2147	P2151 P2154 P2157 P216C P216F P217C P217F
				P2148	P1249 P124A P124B P124C P124D P124E P124F
				P1248	
					P0091 P0092 P00C8 P00C9 P00CA
		GetFHPR_b_PumpCkt_FA	FHPR_b_PumpCkt_FA	P0090	P0091 P0092 P00C8 P00C9 P00CA
	FHPR	GetFHPR_b_PumpCkt_TFTKO	FHPR_b_PumpCkt_TFTKO	P0090	
	FURD	0.45400 4.500 0.04.54	FUDD 1 FDD 0 011 F4	D0400	P0193
	FHPR	GetFHPR_b_FRP_SnsrCkt_FA	FHPR_b_FRP_SnsrCkt_FA	P0192	P0193
	FHPR	GetFHPR_b_FRP_SnsrCkt_TFTKO	FHPR_b_FRP_SnsrCkt_TFTKO	P0192	
	EMOR	GetEMOC b EngMetalOvertempActv true for calibrated time	EngineMetalOvertempActive	P1258	
	EIVIUR	GetEMICO_D_ETIGNICIATIONETERIIPAGIV true for calibrated time	Enginelivietal Overtempactive	r 1200	
					P0034 P0035 P0045 P0047 P0048 P0243 P0245 P0246 P0247 P0249 P0250
Charging					1000 1000 1000 1000 1000 1000 1000 1000 1000
Controls PDT	BSTR	GetBSTR_b_PCA_CktFA	BSTR_b_PCA_CktFA	P0033	P0034 P0035 P0045 P0047 P0048 P0243 P0245 P0246 P0247 P0249 P0250
		GetBSTR_b_PCA_CktTFTKO	BSTR_b_PCA_CktTFTKO	P0033	P0047 P0245 P0249
		GetBSTR_b_PCA_CktLoTFTKO	BSTR_b_PCA_CktLoTFTKO	P0034	P0047 P0245 P0249
		GetBSTR_b_PCA_CktLoFA	BSTR_b_PCA_CktLoFA	P0034	P166E
		GetBSTR_b_PstnCntrlFA	BSTR_b_PstnCntrlFA	P166D	
		GetBSTR_b_PstnCntrlTooLoFA	BSTR_b_PstnCntrlTooLoFA	P166D	
		GetBSTR_b_PstnCntrlTooHiFA	BSTR_b_PstnCntrlTooHiFA	P166E	
		GetBSTR_b_PstnCntrlTooLoTFTKO	BSTR_b_PstnCntrlTooLoTFTKC		
		GetBSTR_b_PstnCntrlTooHiTFTKO	BSTR_b_PstnCntrlTooHiTFTKO		P2564 P2565
		GetBSTR_b_PCA_PstnSnsrFA GetBSTR_b_PCA_PstnSnsrTFTKO	BSTR_b_PCA_PstnSnsrFA BSTR b PCA PstnSnsrTFTKO	P003A	P.2564 P.2565 P.0034 P.0035 P.00C0 P.00C1 P.00C2
		GetBSTR_b_PCA_PstriSristTFTRO GetBSTR_b_TurboBypassCktFA	BSTR_b_PCA_PStriSriSriFTRO BSTR_b_TurboBypassCktFA	P003A P0033	P0034 P0035 P00C0 P00C1 P00C2 P0034 P0035 P00C0 P00C1 P00C2
		GetBSTR_b_TurboBypassCktTFTKO	BSTR_b_TurboBypassCktTFTK		P023C P00C0 P00C1 P00C2
		GetBSTR_b_IC_PmpCktFA	BSTR_b_IC_PmpCktFA	P023A	P0299 P0033 P0034 P0035 P0045 P0047 P0048 P0243 P0245 P0246 P2261 P0247 P0249 P0250
		GetBSTR b PCA FA	BSTR b PCA FA	P0234	P0299 P0033 P0034 P0035 P0045 P0047 P0048 P0243 P0245 P0246 P2261 P0247 P0249 P0250
		GetBSTR_b_PCA_TFTKO	BSTR_b_PCA_TFTKO	P0234	7.0200 7.0000 7.0000 7.0000 7.0000 7.0000 7.0210 7.0210 7.0210 7.0210 7.0210
		GetBSTR_b_ExcsvBstFA	BSTR_b_ExcsvBstFA	P226B	
		GetBSTR b ExcsvBstTFTKO	BSTR b ExcsvBstTFTKO	P226B	
		GetBSTR_b_PresCntrlTooLoTFTKO	BSTR_b_PresCntrlTooLoTFTKC	P0299	
		GetBSTR_b_PresCntrlTooHiTFTKO	BSTR_b_PresCntrlTooHiTFTKO	P0234	
		GetBSTR_b_PresCntrlTooLoFA	BSTR_b_PresCntrlTooLoFA	P0299	
		GetBSTR_b_PresCntrlTooHiFA	BSTR_b_PresCntrlTooHiFA	P0234	P00C1 P00C2
		GetBSTR_b_TurboBypB_CktFA	BSTR_b_TurboBypB_CktFA	P00C0	P00C1 P00C2
		GetBSTR_b_TurboBypB_CktTFTKO	BSTR_b_TurboBypB_CktTFTKC	P00C0	
0 1/500	I/AII/D	V MANUEL NO ONE PARE	1/0 OLL D / D4D0 E4	D0004	P0325 P0326 P0327 P0328 P0330 P0332 P0333 P06B6 P06B7
Spark/ESC	KNKK	VeKNKR_b_KS_CktPerfB1B2_FA	KS_Ckt_Perf_B1B2_FA	P0324	P0352 P0353 P0354 P0355 P0356 P0357 P0358
Spark/ESC	CDVD	VeSPKR_b_EST_DriverFltActive	IgnitionOutputDriver_F#	P0351	PU302 PU303 PU304 PU305 PU306 PU307 PU308
Spark/ESC	SPKR	VeSPKR_D_EST_DIIVEIFILACIIVE	ignitionOutputDriver_FF	P0351	P0507
Speed Control	SPDR	GetSPDR_b_IAC_SysRPM_FA	IAC_SystemRPM_FA	P0506	1000
		MGetDFIR_e_TCM_EngSpdReqCkt	TCM_EngSpdReqCkt	P150C	
opood oonaoi		Woods West of the Control of the Con	. o.iE.igopai.toqoiit	. 1000	P2123 P06A3
ETC	APSR	GetAPSR_PPS_1_OOR_Fit_Composite()	PPS1_OutOfRange_Composite	P2122	P2128 P0697
		GetAPSR_PPS_2_OOR_Flt_Composite()	PPS2_OutOfRange_Composite	P2127	P2123 P06A3
		GetAPSR_b_PPS_1_OOR_Flt_Cmposite()	PPS1_OutOfRange_Composite	P2122	P2128 P0697
		GetAPSR_b_PPS_2_OOR_Flt_Cmposite()	PPS2_OutOfRange_Composite		P2123
		GetAPSR_b_PPS_1_OutofRangeFlt()	PPS1_OutOfRange	P2122	P2128
		GetAPSR_b_PPS_2_OutofRangeFlt()	PPS2_OutOfRange	P2127	P2123
		GetAPSR_PPS_1_OutofRangeFlt()	PPS1_OutOfRange	P2122	P2128
		GetAPSR_PPS_2_OutofRangeFlt()	PPS2_OutOfRange	P2127	P2123 P2127 P2128 P2138 P0697 P06A3
		GetAPSR_b_PedalFailure	AcceleratorPedalFailure	P2122	
	MEMR	GetMEMR_b_CM_RAM_ErrFA()	ControllerRAM_Error_FA	P0604	
	PISR	GetPISR_b_ECU_ProcPerf_FA()	ControllerProcessorPerf_FA	P0606	P0123 P06A3
	TPSR	GetTPSR_b_TPS1_OOR_FltComposite()	TPS1_OutOfRange_Composite	P0122	P0223 P06A3
		GetTPSR_b_TPS2_OOR_FltComposite()	TPS2_OutOfRange_Composite	P0222	P0123 P0222 P0223 P2135
		GetTPSR_b_FaultActive_TPS()	TPS_FA	P0122	P0123 P0222 P0223 P2135
		GetTPSR_b_TFTKO_TPS()	TPS_TFTKO	P0122	P0121 P1104 P2100 P2101 P2102 P2103
		GetTPSR_b_PerfFaultActive_TPS()	TPS_Performance_FA	P0068	P0121 P1104 P2100 P2101 P2102 P2103
		GetTPSR_b_PerfTFTKO_TPS()	TPS_Performance_TFTKO	P0068	P0123 P0222 P0233 P2135 P0123 P0222 P023 P2135
		GetTPSR_FaultPending_TPS() GetTPSR_b_FaultPending_TPS()	TPS_FaultPending TPS_FaultPending	P0122 P0122	P0123 P0222 P0223 P2135 P0122 P0123 P0222 P0223 P16F3 P1104 P2100 P2101 P2102 P2103 P2135
		GetTPSR_b_FaultPending_TPS() GetTPSR ThrotAuthDefault()	TPS_FaultPending TPS_ThrottleAuthorityDefaulted		P0122 P0123 P0222 P0223 P10F3 P1104 P2100 P2101 P2102 P2103 P2135 P2135 P0122 P0223 P0223 P0203 P0606 P16F3 P1104 P2100 P2101 P2102 P2103
	SRAR	GetSRAR_b_EnginePowerLimited()	EnginePowerLimited	P0068	P160D P0191 P0192 P0193 P0008 P0005 P0005 P0005 P0090 P0091 P0092 P228C
	3.0			P160E	P2138 P2122 P2123 P2127 P2128 P228D P06A3 P0697
				P2135	

		Fault Bundles Produced (Fault Bundles Consumed - from line 364)	Cert Doc Bundle Name		Pcodes
	VLTR	GetVLTR_b_V5A_FA()	5VoltReferenceA_FA	P0641	
		GetVLTR_b_V5B_FA() GetVLTR_b_MAP_OOR_Flt()	5VoltReferenceB_FA 5VoltReferenceMAP_OOR_Fit	P0651 P0697	
_					
Evap	EVPR	GetEVPR_b_Purg1SIndCkt_FA	EvapPurgeSolenoidCircuit_FA	P0443 P0496	
		GetEVPR_b_FlowDurNonPurg_FA GetEVPR b VentSIndCkt FA	EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit FA	P0449 P0449	
		GetEVPR b SmallLeak FA	EvapSmallLeak_FA	P0442	P0446
		GetEVPR b EmissionSys_FA GetEVPR b FTP Circuit FA	EvapEmissionSystem_FA FuelTankPressureSnsrCkt FA	P0455	P0453
		GetEVPR_b_F1P_Circuit_FA	Fuel lankPressureSnsrCkt_FA	P0452	
Eng Interface	FANR	GetFANR_b_FanSpeedTooHiFA	CoolingFanSpeedTooHigh_FA	P0495	P0481 P0482
		GetFANR_b_OutputDriver_FA	FanOutputDriver_FA	P0480	P0462 P0463 P2066 P2067 P2068 P0977
Evap	FLVR	GetFLVR_b_FuelLvlDataFit	FuelLevelDataFault	P0461	FU912 FU903 F2000 F2007 F2000 F0917
_ :					P07C0 P182E P1915
Engine	PMDR	GetPMDR_b_PT_RelayFlt GetPMDC_b_PT_RelayStOnFA	PowertrainRelayFault PowertrainRelayStateOn_FA	P1682 P0685	
		GetPMDC_b_PT_RelayStOnError	PowertrainRelayStateOn_Error	P0685	P07C0
		GetPMDR_b_lgnOffTmFA	IgnitionOffTimer_FA	P2610	
		GetPMDR_b_IgnOffTmeVId GetEMDR b EngModeNotRunTmErr	IgnitionOffTimeValid EngineModeNotRunTimerError	P2610 P2610	P07C0 P182E P1915
		GetEMDR_b_EngModeNotRunTmFA	EngineModeNotRunTimer_FA	P2610	P07C0 F102E F1915
		·	J		P0503 P0722 P0723
Vehicle					
Infrastructure PMT	VSPR	GetVSPR_b_VehicleSpeedFA	VehicleSpeedSensor_FA	P0502	
					P0503 P0722 P0723
		GetVSPR_b_VehicleSpeedError	VehicleSpeedSensorError	P0502	2005
Trans	TGPP	GetTGRR TransGrDfltd	TransmissionGearDefaultec	MYD/MYC/MYB:	P182E P1915 P1915 P182A P182C P182D P182E P182F
Trails	TOTAL	octrorite_fraisorbile	Transmission Gear Deladice	M30/M32/M70:	
	TDCT	0 (7000) 7		10/D40/O46/-	P182E P1915
	IRGR	GetTRGR_b_TransEngdStEmisFlt	TransmissionEngagedState_FA	MYD/MYC/MYB: M30/M32/M70:	P1915 P182A P182C P182D P182E P182F
					P0722 P0723 P077D P077C
		0-4T00D b T00 FA	Transmission Output Shaft	MYD/MYC/MYB:	P0722 P0723
		GetTOSR_b_TOS_FA	Angular Velocity Validity	M30/M32/M70:	PU/22 PU/23
					P0751 P0752 P0756 P0757 P0973 P0974 P0976
		GetSHPR_b_ShfSIndFlt GetTOSR_b_OutRotRollgCntValid	no validity name is assigned to Trans Output Rotations Rolling		P0722 P0723 P077C P077D P0716 P0717 P0722 P0723 P077C P077D P07BF
		GetTGRR_TransGrDfltd	Trans Output Rotations Rolling Transmission Actual Gear Vali		P0717 P0722 P0723 P077C P077D P07BF P182E P1915
		GetTRGR_b_TransEngdStEmisFlt	Transmission Engaged State V		P182E P1915
		GetTGRR_TransGrDfltd	Transmission Estimated Gear	Validity	P0716 P0717 P0722 P0723 P077C P077D P07BF
		GetTRTR_GearRatioValidity	Transmission Gear Ratio Valid Transmission Gear Selector Po		P182E P1915 P0667 P0668 P0669 P0711 P0712 P0713
		GetTRGR_PRNDL_StateDfltd GetTFTR_b_TransOilVId	Transmission Gear Selector Po		PUGE PUGES PUGES PUGES PUTT PUTT PUTT PUTTS PUTT
		GetTRTR_b_TransOverallRatioVld	Transmission Overall Actual T	orque Ratio Validity	P0716 P0717 P0722 P0723 P077C P077D P07BF
		GetTRTR_b_TransOverallRatioVld	Transmission Overall Estimate		P182E P1915
		GetTRGR_PRNDL_StateDfltd GetTBNR_TurbineSpdValid	Transmission Shift Lever Posit Transmission Turbine Angular		P0716 P0717 P07BF P07C0
		Oct Date_Turbineopuvanu	Transmission Turbine Angular	volucity validity	
Oil Attributes					
PDT If consor	EOTR	n GetEOTI_b_EngOilTempSnsrCktFA()	EngOilTempSensorCircuitFA	P0197	P0198 IAT_SensorCircuitFA
		n GetEOTI_b_EngOiTempSnsrCktFA() I GetEOTI_b_EngOilModelValid	EngOil I empSensorCircuitFA EngOilModeledTempValid	P0197 ECT_Sensor_FA	IA1_SelbulciliculifA
			J=		
Oil Attribut					P0523
Oil Attributes PDT	EOPR	GetEOPR_b_ValidEngOil	EngOilPressureSensorCktFA	P0522	P0522 P0523
	_0	GetEOPR_b_EOP_SnsrFA	EngOilPressureSensorFA	P0521	
AFM PDT	CDAB	CotCDAR & AllDoorDriver TETKO	CuladorDonoDrive-TETICO	P3401	P3409 P3417 P3425 P3433 P3441 P3449
AFM PD1	CDAR	GetCDAR_b_AllDeacDriver_TFTKO	CylnderDeacDriverTFTKO	P3401	
					P0557 P0558
AFM PDT	BTRR	GetBBVR_b_BrakeBoostVacFA n GetBBVR_b_BrkBoostVacVld	BrakeBoosterSensorFA BrakeBoosterVacuumValid	P0556 P0556	P0557 P0558 MAP SensorFA
		n GetBBVR_b_BrkBoostVacVld I GetBBVR_b_BrkBoostVacVld	BrakeBoosterVacuumValid BrakeBoosterVacuumValid	P0556 VehicleSpeedSensor_FA	WAF_DELISOI FA
					P3409 P3417 P3425 P3433 P3441 P3449
AFM PDT	CDAR	GetCDAR_b_AllDeacDriver_TFTKO	CylnderDeacDriverTFTKO	P3401	
					FuelInjecFuelInjecFuelTrimFuelTrimMAF Se MAP Se EGRValuePerforamnce FA
Engine Torque					
PDT	ETQR	GetETQR_EngineTorqueInaccurate	EngineTorqueEstInaccurate	EngineMisfireDetected_FA	D0470
FASD	FADR	GetFADR_b_FuelTrimSysB1_FA	FuelTrimSystemB1_FA	P0171	P0172 P0175
- *		GetFADR_b_FuelTrimSysB2_FA	FuelTrimSystemB2_FA	P0174	P0172
		GetFADR_b_FuelTrimSysB1_TFTKO	FuelTrimSystemB1_TFTKO	P0171	P0175
		GetFADR_b_FuelTrimSysB2_TFTKO	FuelTrimSystemB2_TFTKO	P0174	

				1					
		Fault Bundles Produced (Fault Bundles Consumed - from line 364)	Cert Doc Bundle Name						Pcodes
Closed Loop Fuel System									
Diagnostics	FADR	None (no diagnaostics disable based on secondary fuel trim faults)	N/A	N/A					
AFIM	OXYR	GetDFIR_FaultActive(CeDFIR_e_FuelTrimCylBalB1 GetDFIR_FaultActive(CeDFIR_e_FuelTrimCylBalB2)	A/F Imbalance Bank1 A/F Imbalance Bank2	P219A P219B					
Secondary Air	AIRR	GetAIRR_b_AIR_PresSensorFaul GetAIRR_b_AIR_Sys_FA GetDFIR_FaultActive(CeDFIR_e_AIR_SIndCktB1) GetDFIR_FaultActive(CeDFIR_e_AIR_PmpCktB1)	AIRSystemPressureSensor FA AIR System FA AIRValveControlCircuit FA AIRPumpControlCircuit FA	P2430 P0411 P0412 P0418	P2431 P2432 P24 P2440 P2444 P0807 P0808	133 P2435 P2	436 P2437 P2	2438	
Clutch	MTCR	GetMTCR_b_CichPstnEmisFA GetDFIR_FaultActive(CeDFIR_e_CichPstnSnsrCktLo) GetDFIR_FaultActive(CeDFIR_e_CichPstnSnsrCktHi) GetDFIR_FaultActive(CeDFIR_e_CichPstnNotLmd)	Clutch Sensor FA ClutchPositionSensorCircuitLo FA ClutchPositionSensorCircuitHi FA ClutchPositionSensorNotLearned	P0806 A P0807 A P0808 I P080A	P0179 P2269				
Closed Loop Flex Fue	E85R	GetE85R_b_FFS_CompFA	Ethanol Composition Sensor FA	P0178					
		Other Definitions			_				
Evap	FLVD	GetFLVR_b_LowFuelConditionDiag	LowFuelConditionDiagnostic	Flag set to TRUE if the fuel lev AND No Active DTCs: for at least 30 seconds.	evel <10 % FuelLevelDat P0462 P0463	taFault			
	FLVD	GetFLVC_b_FuelPump2_StOn	Transfer Pump is Commanded On	Fuel Volume in Primary Fuel T AND Fuel Volume in Secondary Fue AND Transfer Pump on Time < Tran AND Transfer Pump had been Off for AND Evap Diagnostic (Purge Valve Leak Test, Large Leak Test, and Waiting for Purge) is not running AND Engine Running	uel Tank≥ 0.0 liters ansferPumpOnTimeLin f for at least0.0 seconds	nit Table			
			Long Name Bank Brake Circuit Engine Fault Active Intake Naturally Aspirated Performance Position Pressure Sensor Supercharged System Test Failed This Key On Rough Road	Short Name B B B B R Ckt Eng FA Intk NA Perf Pstn Fress Snsr SC Sys TFTKO RR					
FASD	FADR	GetSPDR_b_IAC_SysRPM_FA GetMAPR_b_MAP_SnstFA GetMARR_b_MAF_SnstFA GetMARR_b_MAF_SnstFA GetMARR_b_MAF_SnstFA GetMARR_b_MAF_SnstFA GetEVPR_b_Purg1SindCkt_FA GetEVPR_b_FlowDurNonPurg_FA GetEVPR_b_FlowDurNonPurg_FA GetEVPR_b_Smallteak_FA GetEVPR_b_Smallteak_FA GetEVPR_b_TFD_Circuit_FA GetEVPR_b_TFD_Circuit_FA GetEVPR_b_TFD_Circuit_FA GetEVPR_b_EmissionSys_FA GetEVPR_b_GetFT_CIrcuit_FA GetEVR_b_TellinJCkt_FA GetEVR_b_EngMistDictd_FA GetEGRR_b_EGR_ValvePerf_FA GetEGRR_b_EGR_ValvePerf_FA GetEGRR_b_EGR_ValveCkt_FA							

		Fault Bundles Produced (Fault Bundles Consumed - from line 364)	Cert Doc Bundle Name		Pcodes
		GetMAPR_e_EngVacStatus GetAAPR_e_AmbPresDflidStatus GetAAPR_b_TC_BoostPresSnsrFA GetOXYR_b_Bank1Snsr1_FA GetOXYR_b_Bank2Snsr1_FA			
Closed Loop Fuel System Diagnostics	FADR	None (secondary fuel trim diagnostic does not disable for any faults)	N/A	N/A	
Clutch	MTCR	GetEPSR_b_CrankSnsr_FA GetVSPR_b_VehicleSpeedFA	CrankSensorFA VehicleSpeedSensor_FA Transmission Output Shaft		
		GetTOSR_b_TOS_FA GetDFIR_FaultActive(CeDFIR_e_ClchPstnSnsrCktLo) GetDFIR_FaultActive(CeDFIR_e_ClchPstnSnsrCktHi) GetVLTR_b_V5B_FA()	Angular Velocity Validity ClutchPositionSensorCktLo FA ClutchPositionSensorCktHi FA 5VoltReferenceB_FA		
Secondary Air	AIRR	GetAIRD_b_AIR_PresSensorFaul GetDFIR_FaultActive(CeDFIR_e_AIR_SIndCktB1) GetDFIR_FaultActive(CeDFIR_e_AIR_SIndCktB1) GetDFIR_FaultActive(CeDFIR_e_AIR_PmpCktB1) GetMAFR_b_MAF_SnsrFA GetAMPR_e_AAP_DfltdStatus GetEITR_b_IAT_SnsrFA GetEITR_b_ECT_SnsrFA GetECTR_b_ECT_SnsrFA GetMSFR_b_EngMisfDtct_FA GetCATR_b_CatSysEffLoB1_FA GetCATR_b_CatSysEffLoB1_FA GetCATR_b_CatSysEffLoB2_FA GetMEMR_b_ECM_ProcPerf_FA GetVLTR_b_VSA_FA GetVLTR_b_VSA_FA GetVLTR_b_USB_FA GESPKR_b_ESST_priverFitActive GetFULR_b_FuelInjCkt_FA			
Closed Loop Flex Fue	E85R	None			

Component/ System		Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Fuel Rail Pressure (FRP) Sensor Performance (rationality)	P018B	This DTC detects a fuel pressure sensor response stuck within the normal operating range	Absolute value of fuel pressure change as sensed during intrusive test.	<= 30 kPa	1. FRP Circuit Low DTC (P018C) 2. FRP Circuit High DTC (P018D) 3. FuelPump Circuit Low DTC (P0231) 4. FuelPump Circuit High 5. FuelPump Circuit Open DTC (P023F)	Not active Not active Not active Not active Not active Not active	Frequency: Continuous; 12.5 ms loop. 60 seconds between intrusive tests that pass Intrusive test requested if fuel system is clamped for >= 5 seconds or fuel pressure error variance <= typically (0.3 to 0.6) (calculated over a 2.5sec period); otherwise report pass Duration of intrusive test is fueling related (5 to 12 seconds). Intrusive test is run when fuel flow is below Max allowed fuel flow rate (Typical values in the range of 11 to 50 g/s)	DTC Type A 1 trip
					6. Reference Voltage DTC (P0641) 7. Fuel Pump Control Module Driver Overtemperature DTC (P064A)	Not active		
					8. Control Module Internal Performance DTC (P0606)	Not active		
					9. Engine run time 10. Emissions fuel level (PPEI \$3FB) 11. Fuel pump control	>=5 seconds Not low Enabled		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					12. Fuel pump control state13. Engine fuel flow14. ECM fuel control system failure (PPEI \$1ED)	Normal or FRP rationality control > 0.047 g/s Not failed		
Fuel Rail Pressure (FRP) Sensor Circuit Low Voltage	P018C	This DTC detects if the fuel pressure sensor circuit is shorted low	FRP sensor voltage	< 0.14 V	Ignition	Run or Crank	72 failures out of 80 samples 1 sample/12.5 ms	DTC Type A 1 trip
Fuel Rail Pressure (FRP) Sensor Circuit High Voltage	P018D	This DTC detects if the fuel pressure sensor circuit is shorted high	FRP sensor voltage	> 4.86 V			72 failures out of 80 samples 1 sample/12.5 ms	DTC Type A 1 trip
Fuel Pump Control Circuit Low Voltage	P0231	This DTC detects if the fuel pump control circuit is shorted to low	Fuel Pump Current	> 14.48A	Ignition Ignition OR HS Comm OR Fuel Pump Control AND Ignition Run/Crank Voltage	Run or Crank Run or Crank enabled enabled 9V < voltage < 32V	72 test failures in 80 test samples if Fuel Pump Current <100A 1 sample/12.5 ms	DTC Type A 1 trip
Fuel Pump Control Circuit High Voltage		This DTC detects if the fuel pump control circuit is shorted to high	Voltage measured at fuel pump circuit	> 3.86 V	Commanded fuel pump output	0% duty cycle (off)	36 test failures in 40 test samples; 1 sample/12.5ms	DTC Type A 1 trip

	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					Fuel pump control enable Time that above conditions	False >=4.0 seconds	Pass/Fail determination made only once per trip	
Fuel Pump Control Circuit (Open)	P023F	This DTC detects if the fuel pump control circuit is open	Fuel Pump Current	<=0.5A			72 test failures in 80 test samples; 1 sample/12.5ms	DTC Type A 1 trip
			AND Fuel Pump Duty	>20%	OR	Run or Crank enabled enabled 9V < voltage < 32V		
Fuel System Control Module Enable Control Circuit		This DTC detects if there is a fault in the fuel pump control enable circuit		≠ Fuel Pump Control Module Enable Control Circuit	Ignition AND PPEI Fuel System Request	Run or Crank valid	72 failures out of 80 samples 1 sample/12.5 ms	DTC Type A 1 trip
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if any software or calibration check sum is incorrect	Calculated Checksum (CRC16)		OR	Run or Crank enabled	1 failure if it occurs during the first ROM test of the ignition cycle, otherwise 5 failures Frequency: Runs continuously in the background	DTC Type A 1 trip
						enabled		

•	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Control Module Not Programmed	P0602	Indicates that the FSCM needs to be programmed		= TRUE			Runs once at power up	DTC Type A 1 trip
			KeMEMD_b_NoStart Cal		Ignition OR	Run or Crank		
					HS Comm OR	enabled		
					Fuel Pump Control	enabled		
Long Term	P0603		Checksum at power- up	≠ checksum at power-down			1 failure	DTC Type A 1 trip
Memory Reset		controller power-up					Frequency: Once at power-up	
					Ignition OR	Run or Crank		
					HS Comm OR	enabled		
					Fuel Pump Control	enabled		
Control Module Random Access Memory (RAM)		Indicates that control module is unable to correctly write and read data to and from RAM	Data read	≠ Data written			1 failure if it occurs during the first RAM test of the ignition cycle, otherwise 5 failures	DTC Type A 1 trip
					Ignition	Run or Crank		
					OR		Frequency:	
					HS Comm	enabled	Runs continuously in the background.	
					OR			
Control Module	DOCOC	This DTC indicates the			Fuel Pump Control	enabled	Tests 1 and 2	DTO T A
Internal	P0606	FSCM has detected an					1 failure	DTC Type A 1 trip
Performance		internal processor fault					Frequency:	l trip
Circinano		or external watchdog					Continuously (12.5ms)	
1. Main		6 11 (DID 0000	1. For all I/O					
Processor		discriminates the source	configuration register					
Configuration Register Test		of the fault)	faults:					
			•Register contents	Incorrect value.	Ignition	Run or Crank		

Component/ System		Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
			For Processor Clock Fault:		OR HS Comm OR Fuel Pump Control 1. For all I/O configuration register faults:	enabled enabled	Test 3	
Processor clock test			•EE latch flag in EEPROM. OR	0x5A5A	•KeMEMD_b_ProcFltCfgRe gEnbl	TRUE	3 failures out of 15 samples 1 sample/12.5 ms	
CIOCK (est			RAM latch flag.	0x5A	2. For Processor Clock Fault: •KeMEMD_b_ProcFltCLKD iagEnbl	TRUE	1 Sample/12.5 ms	
3. External watchdog test			For External Watchdog Fault: Software control of fuel pump driver	Control Lost	3. For External Watchdog Fault: •KeFRPD_b_FPExtWDogD iagEnbl	TOUS		
					3. For External Watchdog Fault: •Control Module ROM(P0601)	TRUE		
					3. For External Watchdog Fault: •Control Module RAM(P0604)	not active		
Control Module Long Term Memory (EEPROM)	P062F	Indicates that the NVM Error flag has not been cleared	Last EEPROM write	Did not complete			1 test failure Once on controller power- up	DTC Type A 1 trip
Performance					Ignition OR HS Comm OR	Run or Crank enabled		
					Fuel Pump Control	enabled		

•	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
5Volt Reference Circuit (Short High/Low/Out of Range)		Detects continuous short or out of range on the #1 5V sensor reference circuit	Reference voltage AND Output OR Reference voltage AND Output OR Reference voltage AND Output OR Reference voltage AND Output OR Reference voltage	>= 0.5V inactive >= 5.5V active <= 4.5V active > 105% nominal (i.e., 5.25V) OR <95% nominal (i.e., 4.75V)	Ignition	Run or Crank	15 failures out of 20 samples 1 sample/12.5 ms	DTC Type A 1 trip
Control Module - Driver Over-		condition exists under normal operating conditions	Pump Driver Temp	> 150C	KeFRPD_b_FPOverTemp DiagEnbl Ignition Run/Crank	Run or Crank Enabled Enabled TRUE 9V <voltage<32v< td=""><td>3 failures out of 15 samples 1 sample/12.5 ms</td><td>DTC Type B 2 trips</td></voltage<32v<>	3 failures out of 15 samples 1 sample/12.5 ms	DTC Type B 2 trips
Ignition 1 Switch Circuit Low Voltage	P2534	This DTC detects if the Ignition1 Switch circuit is shorted to low or open	Ignition 1 voltage	<= 6 V	Engine	Running	180 failures out of 200 samples 1 sample/25.0 ms	DTC Type A 1 trip

Component/ System		Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Fuel Pump Flow Performance (rationality)	P2635	This DTC detects degradation in the performance of the SIDI electronic return-less fuel system	Filtered fuel rail pressure error	<= Low Threshold (function of desired fuel rail pressure and fuel flow rate. 15% of resultant Target Pressure) OR >= High Threshold (function of desired fuel rail pressure and fuel flow rate. 15% of resultant Target Pressure) (See Supporting Tables tab)	(P018C)		Filtered fuel rail pressure error Time Constant = 12.5 seconds Frequency: Continuous 12.5 ms loop	DTC Type B 2 trips
					2. FRP Circuit High DTC (P018D)	Not active .		
					3. Fuel Rail Pressure Sensor Performance DTC (P018B)	Not active		
					4. FuelPump Circuit Low DTC (P0231)	Not active		
1					5. FuelPump Circuit High DTC (P0232)	Not active		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					6. FuelPump Circuit Open DTC (P023F)	Not active		
					,	Not active		
					(P0641)	INOL active		
					8. Fuel Pump Control	Not active		
					Module Driver Over-	1101 401110		
					temperature DTC's			
					(P064A)			
					9. Control Module Internal	Not active		
					Performance DTC (P0606)			
					10. An ECM fuel control	Not occurred		
					system failure (PPEI			
					\$1ED)			
					11. The Barometric	Valid (for absolute fuel		
1					pressure (PPEI \$4C1)	pressure sensor)		
İ					signal			
					12. Engine run time	>= 30 seconds		
					13. Emissions fuel level	Not low		
					(PPEI \$3FB)			
					14. Fuel pump control	Enabled		
					15. Fuel pump control state	Normal		
					16. Battery Voltage	11V<=voltage=<32V		
1					17. Fuel flow rate	> 0.047 g/s		
					(See Supporting Tables	AND		
					tab)	<= Max allowed fuel		
						flow rate as a function		
						of desired rail		
						pressure & Vbatt		
						(Typical values in the		
						range of 11 to 50 g/s)		

Component/ System		Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					18. Fuel Pressure Control System	Is not responding to an over-pressurization due to pressure build during DFCO or a decreasing desired pressure command.		
Control Module Communication Bus "A" Off	U0073	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off state	Bus Status	Off	Power mode	Run/Crank	5 failures out of 5 samples (5 seconds)	DTC Type B 2 trips
Lost Communication With ECM/PCM "A"		Detects that CAN serial data communication has been lost with the ECM	Message \$0C9	Undetected	1. Power mode	Run/Crank	12 failures out of 12 samples (12 seconds)	DTC Type B 2 trips
					2. Ignition Run/Crank Voltage 3. U0073	11V <voltage<32v< td=""><td></td><td></td></voltage<32v<>		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Fuel Rail Pressure (FRP) Sensor Performance (rationality)	P018B	This DTC detects a fuel pressure sensor response stuck within the normal operating range	Absolute value of fuel pressure change as sensed during intrusive test.	<= 30 kPa			Frequency: Continuous; 12.5 ms loop. 60 seconds between intrusive tests that pass	DTC Type A 1 trip
					2. FRP Circuit High DTC	Not active	Intrusive test requested if fuel system is clamped for >= 5 seconds or fuel pressure error variance <= typically (0.3 to 0.6) (calculated over a 2.5sec period); otherwise report pass	
					3. FuelPump Circuit Low DTC (P0231)		Duration of intrusive test is fueling related (5 to 12 seconds).	
					4. FuelPump Circuit High	Not active Not active Not active	Intrusive test is run when fuel flow is below Max allowed fuel flow rate (Typical values in the range of 11 to 50 g/s)	
					(P0641) 7. Fuel Pump Control Module Driver Over-temperature DTC (P064A)	Not active Not active Not active		
					Performance DTC (P0606) 9. Engine run time	>=5 seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					10. Emissions fuel level (PPEI \$3FB) 11. Fuel pump control 12. Fuel pump control state 13. Engine fuel flow	Not low Enabled Normal or FRP rationality control > 0.047 g/s		
Fuel Rail Pressure (FRP) Sensor Circuit Low Voltage	P018C	This DTC detects if the fuel pressure sensor circuit is shorted low	FRP sensor voltage	< 0.14 V	14. ECM fuel control system	Run or Crank	72 failures out of 80 samples 1 sample/12.5 ms	DTC Type A 1 trip
Fuel Rail Pressure (FRP) Sensor Circuit High Voltage	P018D	This DTC detects if the fuel pressure sensor circuit is shorted high	FRP sensor voltage	> 4.86 V			72 failures out of 80 samples 1 sample/12.5 ms	DTC Type A 1 trip
					Ignition	Run or Crank		
Fuel Pump Control Circuit Low Voltage	P0231	This DTC detects if the fuel pump control circuit is shorted to low	Fuel Pump Current	> 14.48A	Ignition OR HS Comm OR Fuel Pump Control AND Ignition Run/Crank Voltage	Run or Crank enabled enabled 9V < voltage < 32V	72 test failures in 80 test samples if Fuel Pump Current <100A 1 sample/12.5 ms	DTC Type A 1 trip

• •	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Fuel Pump Control Circuit High Voltage	P0232	This DTC detects if the fuel pump control circuit is shorted to high	Voltage measured at fuel pump circuit	> 3.86 V	Commanded fuel pump output	0% duty cycle (off)	36 test failures in 40 test samples; 1 sample/12.5ms	DTC Type A 1 trip
					Fuel pump control enable	False	Pass/Fail determination made	
					Time that above conditions	>=4.0 seconds		
Fuel Pump Control Circuit (Open)	P023F	This DTC detects if the fuel pump control circuit is open	Fuel Pump Current	<=0.5A			72 test failures in 80 test samples; 1 sample/12.5ms	DTC Type A 1 trip
			AND		Ignition OR	Run or Crank		
			Fuel Pump Duty Cycle	>20%	HS Comm OR	enabled		
					Fuel Pump Control AND	enabled		
					Ignition Run/Crank Voltage	9V < voltage < 32V		
Fuel System Control Module	P025A	This DTC detects if there is a fault in the fuel pump control enable circuit	PPEI (PPEI (Powertrain Platform Electrical Interface) Fuel System	≠ Fuel Pump Control Module Enable Control			72 failures out of 80 samples	DTC Type A 1 trip
Enable		Control enable circuit	Request (\$1ED)	Circuit			1 sample/12.5 ms	
Control Circuit			ποφασσε (ψ125)		Ignition AND	Run or Crank	r sample. (2.6 m)	
					PPEI Fuel System Request (\$1ED)	valid		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illumination
Mechanical Actuator Performance (Functionality)		Compare commanded shutter position to sensed position	Failure to achieve commanded position	Two (2) consecutive intrusive tests fail to achieve commanded position. Intrusive tests are triggered immediately following any failure to achieve a commanded position.		Run/Crank		DTC Type B 2 trips
					Shutter Control Ignition Run/Crank Voltage	Enabled 11V < voltage < 32V		
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if any software or calibration check sum is incorrect	Calculated Checksum (CRC16)	≠ stored checksum for any of the parts (boot, software, application calibration, system calibration)				DTC Type A 1 trip
					Ignition OR HS Comm OR Fuel Pump Control	Run or Crank enabled enabled	Frequency: Runs continuously in the background	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Control Module Not Programmed	P0602	Indicates that the FSCM needs to be programmed	This DTC is set via calibration, when KeMEMD_b_NoStartCal				Runs once at power up	DTC Type A 1 trip
					Ignition OR HS Comm	Run or Crank enabled		
					OR Fuel Pump Control	enabled		
Control Module Long Term Memory Reset	P0603	Non-volatile memory checksum error at controller power-up	Checksum at power-up	≠ checksum at power-down	Ignition OR	Run or Crank	1 failure Frequency: Once at power-up	DTC Type A 1 trip
					HS Comm OR Fuel Pump Control	enabled enabled		
Control Module Random Access Memory (RAM)	P0604	Indicates that control module is unable to correctly write and read data to and from RAM	Data read	≠ Data written			1 failure if it occurs during the first RAM test of the ignition cycle, otherwise 5 failures	DTC Type A 1 trip
					Ignition OR HS Comm OR Fuel Pump Control	Run or Crank enabled enabled	Frequency: Runs continuously in the background.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Control Module Internal Performance 1. Main Processor Configuration Register Test	P0606	This DTC indicates the FSCM has detected an internal processor fault or external watchdog fault (PID 2032 discriminates the source of the fault)	For all I/O configuration register faults:				-	DTC Type A 1 trip
2. Processor			•Register contents 2. For Processor Clock Fault: •EE latch flag in EEPROM. OR	Incorrect value. 0x5A5A	Ignition OR HS Comm OR Fuel Pump Control 1. For all I/O configuration register faults: •KeMEMD_b_ProcFltCfgReg Enbl	Run or Crank enabled enabled TRUE	Test 3 3 failures out of 15 samples	
clock test			RAM latch flag.	0x5A	2. For Processor Clock Fault: •KeMEMD_b_ProcFltCLKDia gEnbl	TRUE	1 sample/12.5 ms	
3. External watchdog test			3. For External Watchdog Fault: • Software control of fuel pump driver	Control Lost	3. For External Watchdog Fault: •KeFRPD_b_FPExtWDogDia gEnbl 3. For External Watchdog Fault: •Control Module ROM(P0601) 3. For External Watchdog Fault: •Control Module ROM(P0604)	TRUE not active		

Component/ System		Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Control Module Long Term Memory (EEPROM) Performance	P062F	Indicates that the NVM Error flag has not been cleared	Last EEPROM write	Did not complete			1 test failure Once on controller power-up	DTC Type A 1 trip
					Ignition OR HS Comm	Run or Crank enabled		
					OR Fuel Pump Control	enabled		
5Volt Reference Circuit (Short	P0641	Detects continuous short or out of range on the #1 5V sensor reference			Ignition	Run or Crank	15 failures out of 20 samples	DTC Type A 1 trip
High/Low/Out of Range)		circuit	Reference voltage AND	>= 0.5V			1 sample/12.5 ms	
			Output OR Reference voltage	inactive >= 5.5V				
			AND Output OR	active				
			Reference voltage AND	<= 4.5V				
			Output OR	active	_			-
			Reference voltage	> 105% nominal (i.e., 5.25V) OR <95% nominal (i.e., 4.75V)				
Fuel Pump	P064A	This DTC detects if an					3 failures out of 15	DTC Type B
Control Module -	17004A	internal fuel pump driver overtemperature	Pump Driver Temp	> 150C	Ignition	Run or Crank	samples	2 trips
		condition exists under normal operating conditions	. , , =		OR HS Comm OR Fuel Pump Control	Enabled Enabled	1 sample/12.5 ms	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					KeFRPD_b_FPOverTempDia	9V <voltage<32v< td=""><td></td><td></td></voltage<32v<>		
Ignition 1 Switch Circuit Low Voltage	P2534	This DTC detects if the Ignition1 Switch circuit is shorted to low or open	Ignition 1 voltage	<= 6 V	Engine	Running	180 failures out of 200 samples 1 sample/25.0 ms	DTC Type A 1 trip
Fuel Pump Flow Performance (rationality)	P2635	This DTC detects degradation in the performance of the SIDI electronic return-less fuel system	Filtered fuel rail pressure error	<= Low Threshold (function of desired fuel rail pressure and fuel flow rate. 15% of resultant Target Pressure) OR >= High Threshold (function of desired fuel rail pressure and fuel flow rate. 15% of resultant Target Pressure) (See Supporting Tables tab)	1. FRP Circuit Low DTC (P018C) 2. FRP Circuit High DTC (P018D) 3. Fuel Rail Pressure Sensor Performance DTC (P018B) 4. FuelPump Circuit Low DTC (P0231) 5. FuelPump Circuit High DTC (P0232) 6. FuelPump Circuit Open DTC (P023F)	Not active Not active Not active Not active Not active Not active Not active	Filtered fuel rail pressure error Time Constant = 12.5 seconds Frequency: Continuous 12.5 ms loop	DTC Type B 2 trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					7. Reference Voltage DTC (P0641)	Not active		
					8. Fuel Pump Control Module Driver Over-temperature DTC's (P064A)	Not active		
					9. Control Module Internal Performance DTC (P0606)	Not active	-	
					10. An ECM fuel control system failure (PPEI \$1ED)	Not occurred	-	
					11. The Barometric pressure (PPEI \$4C1) signal	Valid (for absolute fuel pressure sensor)		
					12. Engine run time	>= 30 seconds		
					13. Emissions fuel level (PPEI \$3FB)	Not low	-	
					14. Fuel pump control	Enabled		
					15. Fuel pump control state	Normal		
					16. Battery Voltage	11V<=voltage=<32V	-	
					17. Fuel flow rate (See Supporting Tables	> 0.047 g/s AND	-	
					tab)	<= Max allowed fuel		
					,	flow rate as a		
						function of desired		
						rail pressure & Vbatt		
						(Typical values in		
						the range of 11 to 50		
						g/s)		

Component/ System		Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illumination
					18. Fuel Pressure Control System	Is not responding to an over- pressurization due to pressure build during DFCO or a decreasing desired pressure command.		
Control Module Communicatio n Bus "A" Off	U0073	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off state	Bus Status	Off	Power mode	Run/Crank	5 failures out of 5 samples (5 seconds)	DTC Type B 2 trips
Lost Communicatio n With ECM/PCM "A"	U0100	Detects that CAN serial data communication has been lost with the ECM	Message \$0C9	Undetected	1. Power mode	Run/Crank	12 failures out of 12 samples (12 seconds)	DTC Type B 2 trips
					Ignition Run/Crank Voltage 3. U0073	11V <voltage<32v< td=""><td></td><td></td></voltage<32v<>		
Lost Communicatio n With "Actuator"	U0284	Detects loss of communication condition has occurred between ECU and device Active Grill Air Shutter "A" actuator	PWM Message	Undetected	1. Power mode	Run/Crank		DTC Type B 2 trips
					2. Ignition Run/Crank Voltage	11V < voltage < 32V		

FSCM Supporting Tables LUJ, LUV

P2635 Fuel Pump Performance Maximum Fuel Flow map (grams / second)

X-axis= Desired Fuel Pressure (kiloPascals)

Y-axis= Battery voltage (volts)

I -UNIS-	· Dallel y	voitag	e (voita	,					
	200	250	300	350	400	450	500	550	600
4.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	8.438	6.016
6	10.87	10.87	10.87	10.87	10.87	10.87	10.87	8.438	6.016
7.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	8.438	6.016
9	10.87	10.87	10.87	10.87	10.87	10.87	10.87	8.438	6.016
10.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	8.438	6.016
12	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
13.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
15	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
16.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
18	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
19.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
21	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
22.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
24	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
25.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
27	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
28.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87

P2635 Fuel Injector curve (grams / second)

X-axis= Fuel Pressure (kiloPascals)

128	148	168	188	208	228	248	268	288	308	328	348	368	388	408	428	
3.163	3.255	3.347	3.439	3.531	3.622	3.714	3.806	3.898	3.99	4.082	4.174	4.266	4.358	4.449	4.542	
															-	
448	468	488	508	528	548	568	588	608	628	648	668	688	708	728	748	768
4.633	4.725	4.817	4.909	5.001	5.093	5.185	5.277	5.368	5.46	5.552	5.644	5.736	5.828	5.92	6.012	6.104

FSCM Supporting Tables LUJ, LUV

P2635 Maximum Engine Intake Boost curve (kiloPascals)

X-axis= barometric pressure (kiloPascals)

40	50	60	70	80	90	100	110	120
125	155	185	205	215	215	215	215	215

P2635 Minimum Fuel Injector Pulse Width curve (seconds)

X-axis= engine speed (revolutions / minute)

	<u> </u>		,		/											
0	512	1024	1536	2048	2560	3072	3584	4096	4608	5120	5632	6144	6656	7168	7680	8192
0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25

FSCM Supporting Tables LUW

P2635 Fuel Pump Performance Maximum Fuel Flow map (grams / second)

X-axis= Desired Fuel Pressure (kiloPascals)

Y-axis= Battery voltage (volts)

1 -axi5-	· Dallery	voitag	e (voits)					
	200	250	300	350	400	450	500	550	600
4.5	11.7	11.7	11.7	11.7	11.7	11.66	8.758	6.078	3.602
6	11.7	11.7	11.7	11.7	11.7	11.66	8.758	6.078	3.602
7.5	11.7	11.7	11.7	11.7	11.7	11.66	8.758	6.078	3.602
9	11.7	11.7	11.7	11.7	11.7	11.66	8.758	6.078	3.602
10.5	11.7	11.7	11.7	11.7	11.7	11.66	8.758	6.078	3.602
12	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	9.063
13.5	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
15	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
16.5	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
18	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
19.5	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
21	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
22.5	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
24	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
25.5	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
27	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
28.5	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7

FSCM Supporting Tables LUW

P2635 Fuel Injector Flow curve (grams / second)

X-axis= Fuel Pressure (kiloPascals)

N-uxi3-	I del I I	Coourc	(Kilol c	iscais												
128	148	168	188	208	228	248	268	288	308	328	348	368	388	408	428	
2.087	2.201	2.316	2.43	2.544	2.658	2.772	2.886	3	3.115	3.229	3.343	3.457	3.571	3.637	3.719	
448	468	488	508	528	548	568	588	608	628	648	668	688	708	728	748	768
3.802	3.852	3.953	4.087	4.189	4.291	4.393	4.495	4.597	4.699	4.801	4.903	5.006	5.108	5.21	5.312	5.414

P2635 Minimum Fuel Injector Pulse Width curve (seconds)

X-axis= engine speed (revolutions / minute)

	<u> </u>	-														
0	512	1024	1536	2048	2560	3072	3584	4096	4608	5120	5632	6144	6656	7168	7680	8192
0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797