Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Open – Bank 1	P0010	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: $\leq 0.5 \Omega$ impedance between signal and controller power Open Circuit: $\geq 200 \text{ K } \Omega$ impedance between signal and controller ground	System supply voltage is within limits Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples250 ms / sample, continuous	Type B, 2 Trips

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

# 13 OBDG02A Engine Diagnostics

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Performance – Bank 1	P0011	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Intake cam Bank 1) Cam Position Error > 6.00 deg.	DTC's are NOT active: P0010, IntakeCamSensorTFTKO CrankSensorTFTKO CrankIntakeCamCorrelati onFA.	System Voltage > 11.00 Volts, Engine is running VVT is enabled Desired cam position > 0 Power Take Off (PTO) not active Both Desired & Measured cam positions cannot be < 6.00 or have both > 24.00 deg. Desired cam position cannot vary more than 3.00 Cam Deg for at least 3.00 sec.	100.00 failures out of 125.00 samples100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Open – Bank 1	P0013	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: $\leq 0.5 \Omega$ impedance between signal and controller power Open Circuit: $\geq 200 \text{ K} \Omega$ impedance between signal and controller ground	System supply voltage is within limitsOutput driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples250 ms / sample, continuous	Type B, 2 Trips

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

# 13 OBDG02A Engine Diagnostics

	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft System Performance – Bank 1	P0014	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Exhaust cam Bank 1) Cam Position Error > 6.00 deg.	DTC's are NOT active: P0013, ExhaustCamSensorTFTK O CrankSensorTFTKO CrankExhaustCamCorrela tionFA	System Voltage > 11.00 Volts, Engine is running VVT is enabled Desired cam position > 0 Power Take Off (PTO) not active Both Desired & Measured cam positions cannot be < 6.00 deg or have both > (16.50). Desired cam position cannot vary more than 3.00 Cam Deg for at least 3.00 sec.	100.00 failures out of 125.00 samples100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft - Sprocket Correlation Diagnostic	P0016 and P0017	On engines with a dual intermediate sprocket between the crankshaft and the camshafts, this diagnostic detects a timing misalignment between the crankshaft, sprocket and camshafts that will cause the bank 1 camshafts to be misaligned.	Bank 1 Cam Sensor A pulses more than -7.0 crank degrees before or 9.0 crank degrees after nominal position in one cam revolution + Bank 1 Cam Sensor B pulses more than -7.0 crank degrees before or 9.0 crank degrees after nominal position in one cam revolution.	>= 8	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs:	P0335, P0336 P0340, P0341 P0365, P0366 5VoltReferenceA_FA 5VoltReferenceB_FA	2 failures out of 3 tests. A failed test is 1 out of 10 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table "Cam Correlation Oil Temperature Threshold". One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 1	P0030	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0031 may also set

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0031	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short- to-ground).	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0030 may also set

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0032	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power).	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 2	P0036	Diagnoses the Heater Output low side driver circuit for circuit faults.		Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0037 may also set

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0037	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short- to-ground).	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0036 may also set

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0038	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power).	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 1	P0053	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	7.5 < Ω < 13.0	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,820 seconds -30.0 < °C < 45.0 < 31.9 volts < 0.17 seconds	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0054	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	7.5 < Ω < 13.0	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,820 seconds -30.0 < °C < 45.0 < 31.9 volts < 0.17 seconds	Once per valid cold start	Type B, 2 Trips

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

# 13 OBDG02A Engine Diagnostics

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
MAP / MAF / P0068 Throttle Position Correlation	P0068	Detect when MAP and MAF do not match estimated engine airflow as established by the TPS	Difference between MAP and estimated MAP exceeds threshold (kPa), or P0651 (5 Volt Ref), or P0107 (MAP circuit low), or P0108 (MAP circuit high) have failed this key cycle, then MAP portion of diagnostic fails	Table, f(TPS). See supporting tables: <b>Delta MAP Threshold</b> f(TPS)	Engine Speed	> 800 RPM Run/Crank voltage > 6.41	Continuously fail MAP and MAF portions of diagnostic for 0.1875 s Continuous in MAIN processor	Type A, 1 Trips
			threshold (grams/sec), or supporting tables:	Delta MAF Threshold				
		MAF versus battery voltage, then MAF portion of diagnostic fails Table supp Maxi	than or equal to maximum MAF versus battery voltage, then MAF portion	Table, f(RPM). See supporting tables: Maximum MAF f (RPM)				
			Table, f(Volts). See supporting tables: Maximum MAF f (Volts)					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0096	Detects an IAT2 sensor that has stuck in range by comparing to IAT and engine coolant temperature at startup	ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up ECT – Power Up IAT2) >= ABS(Power Up ECT – Power Up IAT)	> 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	<ul> <li>&gt; 28,800 seconds</li> <li>&gt;= 11.00 Volts</li> <li>&gt;= 0.9 seconds</li> <li>PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA</li> </ul>	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 Low (applications with humidity)	P0097	Detects a continuous short to ground or open in the IAT 2 signal circuit	Raw IAT 2 Input	< 13 Hertz (~-60 deg C)	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 High (applications with humidity)	P0098	Detects a continuous high frequency in the IAT 2 signal circuit	Raw IAT 2 Input	(~150 deg C)	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

# 13 OBDG02A Engine Diagnostics

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Intermittent In-Range	P0099	Detects a noisy or erratic IAT 2 signal circuit or IAT 2 sensor	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current IAT 2 reading - IAT 2 reading from 100 milliseconds previous)	<ul> <li>&gt; 125.00 DegC</li> <li>10 consecutive IAT 2 samples</li> </ul>	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp Sensor Circuit Low Voltage	P00B3	This DTC detects a short to ground in the RCT signal circuit or the RCT sensor.	RCT Resistance (@ 150°C)	< 34 Ohms	Engine run time OR IAT min	> 10.0 seconds ≤ 70.3 °C	5 failures out of 10 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp Sensor Circuit High Voltage	P00B4	Circuit Continuity This DTC detects a short to high or open in the RCT signal circuit or the RCT sensor.	RCT Resistance (@ -60°C)	> 260,000 Ohms	Engine run time OR IAT min	> 60.0 seconds ≥ -7.0 °C	5 failures out of 10 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp - Engine Coolant Temp (ECT) Correlation	P00B6	This DTC detects a difference between ECT and RCT after a soak condition.	<ul> <li>A failure will be reported if any of the following occur:</li> <li>1) Absolute difference between ECT at power up &amp; RCT at power up is ≥ an IAT based threshold table lookup value(fast fail).</li> <li>2) Absolute difference between ECT at power up is &gt; by 20.0 °C and a block heater has not been detected.</li> </ul>	See the table named: <b>P00B6_Fail if power</b> <b>up ECT exceeds RCT</b> <b>by these values</b> in the Supporting tables section	No Active DTC's Engine Off Soak Time Propulsion Off Soak Time Non-volatile memory initization Test complete this trip Test aborted this trip IAT LowFuelCondition Diag	VehicleSpeedSensor_FA IAT_SensorCircuitFA THMR_RCT_Sensor_Ckt _FA THMR_ECT_Sensor_Ckt _FA IgnitionOffTimeValid TimeSinceEngineRunning Valid > 28,800 seconds > 0 seconds = Not occurred = False = False ≥ -7 °C = False	1 failure 500 msec/ sample Once per valid cold start	Type B, 2 Trips
			3) ECT at power up > IAT at power up by 20.0 °C and the time spent cranking the engine without starting is greater than 10.0 seconds with the LowFuelConditionDiag	= False	<ul> <li>Block Heater detection is enabled when either of the following occurs:</li> <li>1) ECT at power up &gt; IAT at power up by</li> <li>2) Cranking time</li> <li>Block Heater is detected and diagnostic is aborted when 1) or 2) occurs.</li> <li>1a) Vehicle drive time</li> <li>1b) Vehicle speed</li> <li>1c) Additional Vehicle drive time is provided to 1a when Vehicle speed is</li> </ul>	<ul> <li>&gt; 20.0 °C</li> <li>&lt; 10.0 Seconds</li> <li>====================================</li></ul>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					below 1b as follows:	1b		
					1d) IAT drops from power up IAT	≥ 3.3°C		
					2a) ECT drops from power up ECT	> 2°C		
					2b) Engine run time	Within > 60 Seconds		
					Diagnostic is aborted when 3) or 4) occurs:			
					3) Engine run time with vehicle speed below 1b	> 1800 Seconds		
					4) Minimum IAT during test	≤ -7.0 °C		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Flow Insufficient	P00B7	This DTC detects a Insufficient Flow Condition (i.e Stuck Closed Thermostat)	Engine Coolant Temp (ECT) is greater than 120 Deg C and Difference between ECT and RCT is greater than 40 Deg C. When above is present for more than 5 seconds, fail counts start.		No Active DTC's Engine run time OR Engine Coolant Temp	THMR_RCT_Sensor_Ckt _FA THMR_ECT_Sensor_Ckt _FA > 300 seconds > 105.5 Deg C	30 failures out of 300 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (naturally aspirated)	P0101	Determines if the MAF sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 500 kPa*(g/s) > 15 grams/sec > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	<ul> <li>&gt;= 400 RPM</li> <li>&lt;= 7,000 RPM</li> <li>&gt;= -7 Deg C</li> <li>&lt;= 125 Deg C</li> <li>&gt;= -20 Deg C</li> <li>&lt;= 125 Deg C</li> <li>&gt;= 0.25</li> <li>Filtered Throttle Model</li> <li>Error multiplied by TPS</li> <li>Residual Weight Factor</li> <li>based on RPM</li> <li>Modeled Air Flow Error</li> <li>multiplied by MAF</li> <li>Residual Weight Factor</li> <li>based on RPM and MAF</li> <li>Residual Weight Factor</li> <li>based on RPM and MAF</li> <li>Residual Weight Factor</li> <li>based on MAF Est</li> <li>MAP Model 2 Error</li> <li>multiplied by MAP2</li> <li>Residual Weight Factor</li> <li>based on RPM</li> </ul>	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips
					No Active DTCs: No Pending DTCs:	See "Residual Weight Factor" tables. MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit Low Frequency	P0102	Detects a continuous short to low or a open in either the signal circuit or the MAF sensor	MAF Output	<= 1,837 Hertz (~ 0.00 gm/sec)		<ul> <li>&gt; 1.0 seconds</li> <li>&gt;= 300 RPM</li> <li>&gt;= 10.0 Volts</li> <li>&gt;= 1.0 seconds</li> </ul>	200 failures out of 250 samples 1 sample every cylinder firing event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit High Frequency	P0103	Detects a high frequency output from the MAF sensor	MAF Output	>= 13,200 Hertz (~ 820.9 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	<ul> <li>&gt; 1.0 seconds</li> <li>&gt;= 300 RPM</li> <li>&gt;= 10.0 Volts</li> <li>&gt;= 1.0 seconds</li> </ul>	200 failures out of 250 samples 1 sample every cylinder firing event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (naturally aspirated)	P0106	Determines if the MAP sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 500 kPa*(g/s) > 25.0 kPa > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	<ul> <li>&gt;= 400 RPM</li> <li>&lt;= 7,000 RPM</li> <li>&gt;= -7 Deg C</li> <li>&lt;= 125 Deg C</li> <li>&gt;= -20 Deg C</li> <li>&lt;= 125 Deg C</li> <li>&gt;= 0.25</li> <li>Filtered Throttle Model</li> <li>Error multiplied by TPS</li> <li>Residual Weight Factor</li> <li>based on RPM</li> <li>MAP Model 1 Error</li> <li>multiplied by MAP1</li> <li>Residual Weight Factor</li> <li>based on RPM</li> <li>MAP Model 2 Error</li> <li>multiplied by MAP2</li> <li>Residual Weight Factor</li> <li>based on RPM</li> <li>See "Residual Weight</li> <li>Factor" tables.</li> </ul>	Continuous Calculations are performed every 12.5 msec	Type B, 2 Trips
					No Active DTCs:	MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA		
				No Pending DTCs:	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP			
			Manifold Pressure OR	< 50.0 kPa	Time between current ignition cycle and the last		4 failures out of 5 samples	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Manifold Pressure	> 115.0 kPa	time the engine was running Engine is not rotating	> 6.0 seconds	1 sample every 12.5 msec	
					No Active DTCs:	EngineModeNotRunTimer Error MAP_SensorFA AAP_SnsrFA		
					No Pending DTCs:	MAP_SensorCircuitFP AAP_SnsrCktFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit Low	P0107	Detects a continuous short to low or open in either the signal circuit or the MAP sensor.		< 3.0 % of 5 Volt Range (This is equal to 0.15 Volts or 3.5 kPa)	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit High	P0108	Detects an open sensor ground or continuous short to high in either the signal circuit or the MAP sensor.	MAP Voltage	> 90.0 % of 5 Volt Range (This is equal to 4.50 Volts, or 115.0 kPa)	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)		Detects an IAT sensor that has stuck in range by comparing to IAT2 and engine coolant temperature at startup	ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up ECT – Power Up IAT) > ABS(Power Up ECT – Power Up IAT2)	> 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	<ul> <li>&gt; 28,800 seconds</li> <li>&gt;= 11.00 Volts</li> <li>&gt;= 0.9 seconds</li> <li>PowertrainRelayFault ECT_Sensor_Ckt_FA</li> <li>IAT_SensorCircuitFA</li> <li>MnfdTempSensorCktFA</li> <li>HumTempSnsrCktFA</li> </ul>	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Intake Air Temperature Sensor Circuit Low		Detects a continuous short to ground in the IAT signal circuit or the IAT sensor	Raw IAT Input	< 94 Ohms (~150 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Intake Air Temperature Sensor Circuit High	P0113	Detects a continuous open circuit in the IAT signal circuit or the IAT sensor	Raw IAT Input	> 63,000 Ohms (~-60 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Intermittent In-Range	P0114	Detects a noisy or erratic IAT signal circuit or IAT sensor	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current IAT reading - IAT reading from 100 milliseconds previous)	<ul> <li>&gt; 125.00 DegC</li> <li>10 consecutive IAT samples</li> </ul>	Continuous		4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

# 13 OBDG02A Engine Diagnostics

	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Performance	P0116	This DTC detects ECT temp sensor stuck in mid range.	A failure will be reported if any of the following (1-3) occur after the following soak conditions, Engine off time > 28,800 seconds Propulsion system off time > 0 seconds 1) ECT at power up > IAT at power up by an IAT based table lookup value (fast fail). 2) ECT at power up > IAT at power up by 20.0 Deg C and a block heater has not been detected. 3) ECT at power up > IAT at power up by 20.0 Deg C and the time spent cranking the engine without starting is greater than 10.0 seconds with the LowFuelConditionDiag	See the table named: P0116_Fail if power up ECT exceeds IAT by these values in the Supporting tables section = False	No Active DTC's Non-volatile memory initization Test complete this trip Test aborted this trip IAT LowFuelCondition Diag ======= Block Heater detection is enabled when either of the following occurs: 1) ECT at power up > IAT at power up by 2) Cranking time ======= Block Heater is detected and diagnostic is aborted when 1) or 2) occurs: 1a) Vehicle drive time 1b) Vehicle speed 1c) Additional Vehicle drive time is provided to 1a when Vehicle speed is below 1b as follows:	VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_Ckt_FA IgnitionOffTime Valid = Not occurred = False ≥ -7 °C = False ====================================	1 failure 500 msec/ sample Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					up IAT	≥3.3 °C		
					2a) ECT drops from power up ECT 2b) Engine run time	≥ 2 °C Within ≤ 60 seconds		
					Diagnostic is aborted when 3) or 4) occurs:			
					3) Engine run time with vehicle speed below 1b	> 1800 seconds		
					4) Minimum IAT during test	≤ -7 °C		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit Low		Circuit Continuity This DTC detects a short to ground in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ 150ºC)	< 34 Ohms			5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit High	P0118	Circuit Continuity This DTC detects a short to high or open in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ -60°C)	> 260,000 Ohms	Engine run time OR IAT min	> 15.0 seconds ≥ -7.0 °C	5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Circuit Intermittent	P0119	Circuit Continuity This DTC detects large step changes in the ECT signal circuit or the ECT sensor. Allowable high and low limits are calculated for the next sample based on the previous sample.	ECT temperature step change: 1) postive step change is greater than calculated high limit OR 2) negitive step change is lower than calculated low limit. The calculated high and low limits use the following calibrations: 1) Sensor time constant 2) Sensor low limit 3) Sensor high limit *****Generic Example***** If the last ECT reading was 90 Deg C, the Time constant was calibrated at 10 seconds, the low limit was calibrated to -80 Deg C and the high limit was calibrated to 200 Deg C the caluculated limits are 101 Deg C and 73 Deg C. The next reading (after the 90 Deg C reading) must be between 73 Deg C and 101 Deg C to be valid.	15.0 seconds -65.0 Deg C 200.0 Deg C	No Active DTC's	P0117 P0118	3 failures out of 4 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (naturally aspirated)	P0121	Determines if the Throttle Position Sensor input is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	> 500 kPa*(g/s) > 15 grams/sec <= 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	<ul> <li>&gt;= 400 RPM</li> <li>&lt;= 7,000 RPM</li> <li>&gt; -7 Deg C</li> <li>&lt; 125 Deg C</li> <li>&gt; -20 Deg C</li> <li>&lt; 125 Deg C</li> <li>&gt; = 0.25</li> <li>Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM</li> <li>Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est</li> <li>See "Residual Weight Factor" tables.</li> </ul>	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips
					No Active DTCs:	MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA		
					No Pending DTCs:	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit Low	P0122	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage <	0.3250		Run/Crank voltage > 6.41	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips
						No 5V reference error or fault for # 4 5V reference circuit (P06A3)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit High	P0123	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage >	4.750		Run/Crank voltage > 6.41	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips
						No 5V reference error or fault for # 4 5V reference circuit (P06A3)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine	P0128	This DTC detects if the	Energy is accumulated		No Active DTC's	ECT_Sensor_Ckt_FA	1 failure to set	Type B,
Coolant		engine coolant	after the first conbustion			VehicleSpeedSensor_FA	DTC	2 Trips
Temperature		temperature rises too	event using Range #1 or			OAT_PtEstFiltFA	1	
Below Stat Regulating		slowly due to an ECT or Cooling system fault	#2 below:			IAT_SensorCircuitFA MAF_SensorFA	1 sec/ sample	
Temperature		or Cooling system laut	Thermostat type is divided			THMR_AWP_AuxPumpF	Once per ignition	
) (energy			into normal (non-heated)			A	key cycle	
based			and electrically heated.			THMR_AHV_FA		
"Deluxe"						THMR_SWP_Control_FA		
method			For this application the			ECT_Sensor_Perf_FA		
			"type" cal					
			(KeTHMG_b_TMS_ElecT		Engine not run time			
			hstEquipped) = 1		(soaking time before	> 1.000 accorde		
			If the type cal is equal to one, the application has		current trip)	≥ 1,800 seconds		
			an electrically heated t-			30 ≤ Eng Run Tme ≤		
			stat, if equal to zero the		Engine run time	1.800 seconds		
			the application has an non			.,		
			heated t-stat. See		Fuel Condition	Ethanol ≤87 %		
			appropiate section below.					
			*****		Distance traveled	≥ 1.00 km		
			Type cal above = 1 (Electrically heated t-stat)		****	****		
				See the two tables	If Engine RPM is			
			Range #1 (Primary) ECT	named:	continuously greater than	9,999 rpm		
			reaches Commanded	P0128_Maximum	for this time period	5.0 seconds		
			temperature minus 26 °C	Accumulated Energy				
			when Ambient min is ≤	for Start-up ECT	The diagnostic test for this			
			52 °C and > 10 °C.	conditions - Primary	key cycle will abort			
			Note: Warm up target for	and	*********	******		
			range #1 will be at least 79 °C	P0128_Maximum Accumulated Energy	****	****		
			79 C	for Start-up ECT	If T-Stat Heater			
		Range #2 (Alternate) ECT	conditions - Alternate	commanded duty cycle	> 20.0 % duty cycle			
		reaches Commanded	in the Supporting	for this time period	> 9,999.0 seconds			
		temperature minus 46 °C	tables section.		-,			
			when Ambient min is ≤		The diagnostic test for this			
			10 °C and > -7 °C.	This diagnostic models	key cycle will abort			
			Note: Warm up target for	the net energy into and				
			range #2 will be at least	out of the cooling	*******	*****		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			59 °C Type cal above = 0 (non - heated t-stat) == == == Range #1 (Primary) ECT reaches 94 °C when Ambient min is $\leq$ 52 °C and > 10 °C. == == == Range #2 (Alternate) ECT reaches 94 °C when Ambient min is $\leq$ 10 °C and > -7 °C.	system during the warm-up process. The five energy terms are: heat from combustion, heat from after-run, heat loss to enviroment, heat loss to cabin and heat loss to DFCO.	ECT at start run	-60 ≤ ECT ≤ 74 °C		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 1	P0131	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 20.0 mVolts	No Active DTC's AIR intrusive test Fuel intrusive test Idle intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Idle Device Control AIR Device Control Low Fuel Condition Diag Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active All Fuel Injectors for active Cylinders Fuel Condition Fuel State All of the above met for	TPS_ThrottleAuthorityDef aulted MAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA = Not active = Not acti	380 failures out of 475 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 1	P0132	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	== Open Test Criteria == No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition	<pre>====================================</pre>	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips
					No Active DTC's Low Fuel Condition Diag Fuel Condition	MAP_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FueITankPressureSnsrCkt _FA FueIInjectorCircuit_FA AIR System FA = False ≤ 87 % Ethanol		
					Initial delay after Open Test Criteria met (cold start condition) Initial delay after Open Test Criteria met (not cold start condition)	<ul> <li>&gt; 10.0 seconds when engine soak time &gt; 28,820 seconds</li> <li>&gt; 10.0 seconds when engine soak time ≤ 28,820 seconds</li> </ul>		
					Equivalence Ratio Air Per Cylinder Fuel Control State	0.9912 ≤ ratio ≤ 1.0137 60 ≤ mgram ≤ 500 not = Power Enrichment		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for	> 3.0 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Slow Response Bank 1 Sensor 1) (For use with ESPD	ponsethe O2 sensork 1response time issor 1)degraded.use with	Fault condition present when the average response time is caluclated over the test time, and compared to the threshold.	Refer to <b>P0133_O2S</b> Slow Response Bank <b>1 Sensor 1 "Pass/Fail</b> <b>Threshold table"</b> in the Supporting Tables tab	No Active DTC's	TPS_ThrottleAuthorityDef aulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg	Sample time is 60 seconds Frequency: Once per trip	Type E 2 Trips	
			Slope Time L/R Switches	< 5		e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA		
			OR Slope Time R/L Switches	< 5		EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA		
						AIR System FA EthanolCompositionSens or_FA EngineMisfireDetected_F		
					Bank 1 Sensor 1 DTC's not active	A P0131, P0132, P0134		
					System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control	10.0 < Volts < 32.0 = Not active = Not active = Not active = Not active		
					Low Fuel Condition Diag Green O2S Condition	= False = Not Valid, See definition of Multiple DTC Use_Green Sensor		
					Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for			
					the following locations: B1S1, B2S1 (if applicable)			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					O2 Heater on for Learned Htr resistance Engine Coolant IAT Engine run Accum	in Supporting Tables tab. ≥ 40 seconds = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" ) > 60 °C > -40 °C > 150 seconds		
					Time since any AFM status change Time since Purge On to Off change Time since Purge Off to On change Engine airflow Engine speed Fuel Condition Baro Air Per Cylinder	<ul> <li>&gt; 2.0 seconds</li> <li>&gt; 2.0 seconds</li> <li>&gt; 2.0 seconds</li> <li>&gt; 2.0 seconds</li> <li>8 ≤ grams/second ≤ 30 1,200 &lt;= RPM &lt;= 3,500</li> <li>&lt; 87 % Ethanol</li> <li>&gt; 70 kpa</li> <li>≥ 100 mGrams</li> </ul>		
					Fuel Control State Closed Loop Active LTM fuel cell Transient Fuel Mass Baro Fuel Control State Fuel State Commanded Proportional Gain ====================================	<ul> <li>= Closed Loop</li> <li>= TRUE</li> <li>= Enabled</li> <li>≤ 100.0 mgrams</li> <li>= Not Defaulted</li> <li>not = Power Enrichment</li> <li>DFCO not active</li> <li>≥ 0.0 %</li> <li>====================================</li></ul>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Insufficient Activity Bank 1 Sensor 1	P0134	This DTC determines if the O2 sensor circuit is open.	Oxygen Sensor Signal	> 1,700 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition	TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 50 seconds ≤ 87 % Ethanol	100 failures out of 125 samples. Frequency: Continuous 100 msec loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 1	P0135	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.		0.3 < Amps < 2.5	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA 10.0 < Volts < 32.0 = Complete = Not active > zero > 30 seconds	8 failures out of 10 samples Frequency: 2 tests per trip 10 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0137	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 20 mvolts	AIR intrusive test Fuel intrusive test Idle intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active All Fuel Injectors for active Cylinders Fuel Condition Fuel State All of the above met for	TPS_ThrottleAuthority DefaultedMAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapSmallLeak_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA = Not active = Not a	380 failures out of 475 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0138	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	== Open Test Criteria ==         No Active DTC's         System Voltage         AFM Status         Heater Warm-up delay         Engine Run Time         Fuel Condition         ====================================	====================================	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for	> 3.0 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Rich to Lean Bank 1 Sensor 2	P013A	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Rich to Lean voltages range during Rich to Lean transition. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Post O2 sensor normalized integral value OR The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 9.5 units > 10.0 grams (upper voltage threshold is 450 mvolts and lower voltage threshold is 150 mvolts)	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013B, P013E, P013F, P2270 or P2271 10.0 < Volts < 32.0 = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" ) = Not Valid = Not Valid, See definition of <b>Multiple DTC</b> <b>Use_Green Sensor</b> <b>Delay Criteria - Airflow</b> and <b>Multiple DTC</b> <b>Use_Green Sensor</b> <b>Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA
					Low Fuel Condition Diag Post fuel cell	= False = enabled		
					DTC's Passed	P2270 (and P2272 if applicable)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						P013E (and P014A if applicable)		
					After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).			
							_	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Lean to Rich Bank 1 Sensor 2	P013B	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Lean to Rich voltages range during Lean to Rich transition. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	The EWMA of the Post O2 sensor normalized integral value OR The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	<ul> <li>9.5 units</li> <li>140 grams (lower voltage threshold is 350 mvolts and upper voltage threshold is 650 mvolts)</li> </ul>	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013A, P013E, P013F, P2270 or P2271 10.0 < Volts < 32.0 = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA
					ICAT MAT Burnoff delay	= Not Valid		
					Green O2S Condition	= Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.		
					Condition	= Not Valid, System is not valid until accumulated airflow is greater than		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						360,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).		
					Low Fuel Condition Diag Post fuel cell	= False = enabled		
					DTC's Passed	P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable) P013F (and P014B if applicable)		
					After above conditions are met: Fuel Enrich mode continued.			
					ETRIE STATES THE STATES THE STATES THE STATES THE STATES THE STATES AND STAT			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 2	P013E	This DTC determines if the post catalyst O2 sensor has an initial delayed response to an A/F change from Rich to Lean. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	Post O2 sensor voltage AND The Accumulated mass air flow monitored during the Delayed Response Test under DFCO DFCO begins after: 1) Catalyst has been rich for a minimum of AND 2) Catalyst Rich Accumulation Air Flow is greater or equal to	> 450 mvolts > 20 grams > 1 secs > 6 grams	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA AIR System FA FuelInjectorCircuit_FA FueITrimSystemB1_FA FueITrimSystemB2_FA EngineMisfireDetected_F A EthanoICompositionSens or_FA P013A, P013B, P013F, P2270 or P2271 10.0 < Volts < 32.0 = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" ) = Not Valid = Not Valid, See definition	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips
					Green O2S Condition	<ul> <li>Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.</li> <li>= False = enabled</li> </ul>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					DTC's Passed	P2270 (and P2272 if applicable)		
					Number of fueled cylinders	≤ 3 cylinders		
					After above conditions are met: DFCO mode entered (wo driver initiated pedal input).			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 2	P013F	This DTC determines if the post catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	Post O2 sensor voltage AND The Accumulated mass air flow monitored during the Delayed Response Test	< 350 mvolts	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013A, P013B, P013E, P2270 or P2271 10.0 < Volts < 32.0 = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed	Type B, 2 Trips
					ICAT MAT Burnoff delay	= Not Valid		
					Green O2S Condition Green Cat System Condition	<ul> <li>Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.</li> <li>Not Valid, System is not valid until accumulated airflow is greater than</li> </ul>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						360,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).		
					Low Fuel Condition Diag Post fuel cell	= False = enabled		
					DTC's Passed Number of fueled cylinders	P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable) ≥ 1 cylinders		
					<pre>====================================</pre>			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Insufficient Activity Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0140	This DTC determines if the O2 sensor circuit is open.	Oxygen Sensor Signal	> 1,700 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition	TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 50 seconds ≤ 87 % Ethanol	100 failures out of 125 samples. Frequency: Continuous 100 msec loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0141	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.3 > amps > 2.5	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA 10.0 < Volts < 32.0 = Complete = Not active > zero > 30 seconds	8 failures out of 10 samples Frequency: 2 tests per trip 10 seconds delay between tests and 1 second execution rate.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 1	P015A	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Rich to Lean. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Pre O2 sensor normalized R2L time delay value OR [The Accumulated time monitored during the R2L Delayed Response Test (Gross failure). AND Pre O2 sensor voltage is	<ul> <li>&gt; 0.5 EWMA (sec)</li> <li>≥ 2.5 Seconds</li> <li>&gt; 550 mvolts</li> </ul>	No Active DTC's System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition	TPS_ThrottleAuthorityDef aulted MAP_SensorFA IAT_SensorFA ECT_SensorFA ECT_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapSmallLeak_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSens or_FA EngineMisfireDetected_F A P0131, P0132, P0134 10.0 < Volts < 32.0 = Not active = Not	Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_Rap idResponselsAct ive = TRUE, multiple tests per trip are allowed	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					O2 Heater (pre sensor) on for Learned Htr resistance	the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. ≥ 40 seconds = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )		
					Engine Coolant IAT Engine run Accum	> 60 °C > -40 °C > 150 seconds		
					Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)	1,500 ≤ RPM ≤2,800 1,400 ≤ RPM ≤2,900		
					Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)	2 ≤ gps ≤ 20 43.5 ≤ MPH ≤ 68.4 40.4 ≤ MPH ≤ 71.5		
					Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell	$0.92 \le C/L$ Int $\le 1.08$ = TRUE not in control of purge not in estimate mode = enabled		
					EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State	<ul> <li>not active</li> <li>not active</li> <li>40.0 sec</li> <li>550 ≤ °C ≤ 900</li> <li>DFCO possible</li> </ul>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for at least 1.5 seconds, and then the Force Cat Rich intrusive stage is requested. Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders After above conditions are met: DFCO Mode is entered (wo driver initiated pedal input).	<ul> <li>=========</li> <li>≥ 690 mvolts</li> <li>= DFCO active</li> <li>≤ 3 cylinders</li> <li>=========</li> </ul>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 1	P015B	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test which runs in an enriched fuel mode to achieve the required response.	The EWMA of the Pre O2 sensor normalized L2R time delay value OR [The Accumulated time monitored during the L2R Delayed Response Test (Gross failure). AND Pre O2 sensor voltage is OR At end of Cat Rich stage the Pre O2 sensor output is	<ul> <li>&gt; 0.5 EWMA (sec)</li> <li>≥ 2.5 Seconds</li> <li>&lt; 350 mvolts</li> <li>&lt; 690 mvolts</li> </ul>	No Active DTC's System Voltage EGR Device Control Idle Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition	TPS_ThrottleAuthorityDef aulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapSmallLeak_FA EvapSmallLeak_FA EvapEmissionSystem_FA FueITankPressureSnsrCkt _FA FueIInjectorCircuit_FA AIR System FA FueITrimSystemB1_FA FueITrimSystemB2_FA EthanolCompositionSens or_FA EngineMisfireDetected_F A P0131, P0132, P0134 10.0 < Volts < 32.0 = Not active = Not active	Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_Rap idResponselsAct ive = TRUE, multiple tests per trip are allowed	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					O2 Heater (pre sensor) on for Learned Htr resistance	the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. ≥ 40 seconds = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance		
					Engine Coolant IAT Engine run Accum	DTC's" ) > 60 °C > -40 °C > 150 seconds		
					Engine Speed to initially enable test Engine Speed range to keep test enabled (after	1,500 ≤ RPM ≤ 2,800		
					initially enabled) Engine Airflow Vehicle Speed to initially	1,400 ≤ RPM ≤2,900 2 ≤ gps ≤20		
					enable test Vehicle Speed range to keep test enabled (after initially enabled)	43.5≤ MPH ≤68.4 40.4≤ MPH ≤71.5		
					Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor)	0.92 ≤ C/L Int ≤ 1.08 = TRUE not in control of purge not in estimate mode = enabled = not active = not active		
					on Time Predicted Catalyst temp	≥ 40.0 sec 550 ≤ °C ≤ 900		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Fuel State Number of fueled cylinders	= DFCO inhibit ≥ 1 cylinders		
					When above conditions are met: Fuel Enrich mode is entered.			
					======================================	 3≤ gps ≤ 15		
					and the delta Engine Airflow over 12.5msec must be :	≤ 3.0 gps		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Lean Bank 1	P0171	Determines if the fuel control system is in a lean condition, based on the filtered long- term and short-term fuel trim.	The filtered long-term fuel trim metric AND The filtered short-term fuel trim metric (a value < 0.95 effectively nullifies the short-term fuel trim criteria)	>= 1.300	Engine speed BARO Coolant Temp MAP Inlet Air Temp MAF Fuel Level Long Term Fuel Trim data accumulation:	400 <rpm< 7,000<br="">&gt; 70 kPa -20 &lt;°C&lt; 150 10 <kpa< 255<br="">-20 &lt;°C&lt; 150 1.0 <g 512.0<br="" s<="">&gt; 10 % or if fuel sender is faulty &gt; 34.0 seconds of data must accumulate on each trip, with at least 14.0 seconds of data in the current fuel trim cell before a pass or fail decision can be made.</g></kpa<></rpm<>	Frequency: 100 ms Continuous Loop	Type B, 2 Trips
					Sometimes, certain Long- Term Fuel Trim Cells are not utilized for control and/or diagnosis	(Please see <b>"Long-Term</b> <b>Fuel Trim Cell Usage"</b> in Supporting Tables for a list of cells utilized for diagnosis)		
					Closed Loop Long Term FT	Enabled Enabled (Please see "Closed Loop Enable Criteria" and "Long Term FT Enable Criteria" in Supporting Tables.)		
					Fuel Consumed	<ul> <li>&gt; 0.2 liters of fuel consumed after a fuel fill event ("Virtual Flex Fuel Sensor applications only)</li> </ul>		
					EGR Diag.	Intrusive Test Not Active Intrusive Test Not Active		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Catalyst Diag. Post O2 Diag. Device Control EVAP Diag.	Intrusive Test Not Active Not Active "tank pull down" Not Active		
					No active DTC:	IAC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR System FA EvapExcessPrgePsbl_FA Ethanol Comp Snsr FA FuelInjectorCkt_FA EngMisfireDetected_FA EGRValvePerf_FA EGRValvePerf_FA EGRValveCkt_FA MAP_EngVacuumStatus AmbPresDfltdStatus TC_BoostPresSnsrFA O2Snsr_B1_Snsr_1_FA		

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Rich Bank 1	P0172	Determines if the fuel control system is in a rich condition, based on the filtered long- term fuel trim metric.	Passive Test: The filtered Non-Purge Long Term Fuel Trim metric AND	<= 0.700		Secondary Parameters and Enable Conditions are identical to those for P0171, with the exception that fuel level is not considered.	Frequency: 100 ms Continuous Loop	Type B, 2 Trips
		There are two methods to determine a Rich fault. They are Passive and Intrusive. A Passive Test decision cannot be made when Purge is enabled. The Intrusive test is	The filtered Short Term Fuel Trim metric (a value > 1.05 effectively nullifies the short-term fuel trim criteria)	<= 2.000				
		described below: Intrusive Test: When the filtered Purge Long Term Fuel Trim metric is <= 0.705, purge is ramped off to determine if excess	Intrusive Test: For 2 out of 3 intrusive segments, the filtered Purge Long Term Fuel Trim metric AND	<= 0.705				
		purge vapor is the cause of the rich condition. If the filtered Purge Long Term Fuel Trim metric > 0.705, the test passes without	The filtered Non-Purge Long Term Fuel Trim metric AND	<= 0.700				
		checking the filtered Non-Purge Long Term Fuel Trim metric. Performing intrusive tests too frequently	The filtered Short Term Fuel Trim metric (a value > 1.05 effectively nullifies the short-term fuel trim criteria)	<= 2.000				
		may also affect EVAP and EPAIII emissions, and the execution frequency of other diagnostics.	Segment Def'n: Segments can last up to 60 seconds and are separated by the lesser of 20 seconds of purge-on time or enough time to purge 36 grams of vapor.					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			A maximum of 3 completed segments or 20 attempts are allowed for each intrusive test. After an intrusive test report is completed, another intrusive test cannot occur for 100 seconds to allow sufficient time to purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge-on Long Term fuel trim > 0.705 for at least 150 seconds, indicating that the canister has been purged.					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Open Circuit (PFI) - 3 DTC Implmentatio n	P0201	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0261 may also set (Injector 1 Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Open Circuit (PFI) - 3 DTC Implmentatio n	P0202	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0264 may also set (Injector 2 Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Open Circuit (PFI) - 3 DTC Implmentatio n	P0203	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0267 may also set (Injector 3 Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Open Circuit (PFI) - 3 DTC Implmentatio n	P0204	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P027( may also set (Injector 4 Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit Low	P0222	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage <	0.250		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit High	P0223	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage >	4.590		Run/Crank voltage > 6.41	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips
						No 5V reference error or fault for # 4 5V reference circuit (P06A3)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to ground (PFI)	P0261	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0201 may also set (Injector 1 Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Injector 1 Low side circuit shorted to power (PFI)	P0262	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: $\leq 0.5 \Omega$ impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running		20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to ground (PFI)	P0264	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0202 may also set (Injector 2 Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Injector 2 Low side circuit shorted to power (PFI)	P0265	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: $\leq 0.5 \Omega$ impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running		20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to ground (PFI)	P0267	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0203 may also set (Injector 3 Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Injector 3 Low side circuit shorted to power (PFI)	P0268	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: $\leq 0.5 \Omega$ impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running		20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to ground (PFI)	P0270	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0204 may also set (Injector 4 Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to power (PFI)	P0271	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: $\leq 0.5 \Omega$ impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running		20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Random Misfire Detected Cylinder 1 Misfire Detected Cylinder 2 Misfire Detected Cylinder 3 Misfire Detected Cylinder 4 Misfire Detected	P0300 P0301 P0302 P0303 P0304	These DTC's will determine if a random or a cylinder specific misfire is occurring by monitoring various terms derived from crankshaft velocity. The rate of misfire over an interval is compared to both emissions and catalyst damaging thresholds. The pattern of crankshaft acceleration after the misfire is checked to differentiate between real misfire and other sources of crank shaft noise.	Deceleration Value vs. Engine Speed and Engine load The equation used to calculate deceleration value is tailored to specific vehicle operating conditions. The selection of the equation used is based on the 1st tables encountered that are not max of range. If all tables are max of range at a given speed/load, that speed load region is an <b>Undetectable region</b> see Algorithm Description Document for additional details. Misfire Percent Emission Failure Threshold	[ (>IdleSCD_Decel AND > IdleSCD_Jerk) OR (>SCD_Decel AND > SCD_Jerk) OR (>IdleCyIModeDecel AND > IdleCyIModeJerk) OR (>CyIMode_Decel AND > CyIMode_Jerk) OR (>RevMode_Decel) OR WHILE in Cylinder Deactivation mode: (> AFM_Decel) ] - see details on Supporting Tables Tab (P0300 Section) ≥ 3.30 % P0300	Engine Run Time Engine Coolant Temp Or If ECT at startup Then ECT System Voltage + Throttle delta - Throttle delta Early Termination option: (used on plug ins that may not have enough engine run time at end of trip for normal interval to complete.)	> 2 crankshaft revolution          -7 °C < ECT < 125 °C	Emission Exceedence = any (5) failed 200 rev blocks out of (16) 200 rev block tests Failure reported for (1) Exceedence in 1st (16) 200 rev block tests, or (4) Exceedences thereafter. OR when Early Termination Reporting = Enabled and engine rev > 1,000 revs and < 3,200 revs at end of trip any Catalyst Exceedence = (1) 200 rev block as data supports for catalyst damage. Failure reported with (1 or 3) Exceedences in	Type B, 2 Trips (Mil Flashes with Catalyst damage level of Misfire)
			Misfire Percent Catalyst Damage	> Catalyst_Damage_ Misfire_Percentage in Supporting Tables	(at low speed/loads, one cylinder may not cause cat damage)		FTP, or (1) Exceedence outside FTP.	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			When engine speed and load are less than the FTP cals (3) catalyst damage exceedences are allowed.	whenever secondary conditions are met. ≤ 0 FTP rpm AND ≤ 0 FTP % load	Engine Speed Engine Load Misfire counts	> 1,000 rpm AND > 25 % load AND < 180 counts on one cylinder	Continuous	
				disable conditions:	Engine Speed	520 < rpm < ((Engine Over Speed Limit) - 400 Engine speed limit is a function of inputs like Gear and temperature see EngineOverSpeedLimit in supporting tables	4 cycle delay	
					No active DTCs:	TPS_FA EnginePowerLimited MAF_SensorTFTKO IAT_SensorTFTKO IAT_SensorTFTKO ECT_Sensor_Ckt_TFTKO 5VoltReferenceB_FA CrankSensorTFTKO CrankSensorFA CamLctnIntFA CamLctnIntFA CamSensorAnyLctnTFTK O AnyCamPhaser_FA AnyCamPhaser_TFTKO AmbPresDfltdStatus	4 cycle delay	

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P0315 & engine speed	> 1,000 rpm	4 cycle delay	
					Fuel Level Low	LowFuelConditionDiagnos	500 cycle delay	
					Cam and Crank Sensors	tic in sync with each other	4 cycle delay	
					Misfire requests TCC unlock	Not honored because Transmission in hot mode or POPD intrusive diagnostic running	4 cycle delay	
					Fuel System Status	≠ Fuel Cut	4 cycle delay	
					Active FuelManagement	Transition in progress	7 cycle delay	
					Undetectable engine speed and engine load region	<i>Undetectable region</i> from Malfunction Criteria	4 cycle delay	
					Abusive Engine Over Speed	> 7,250 rpm	0 cycle delay	
					Below zero torque (except CARB approved 3000 rpm to redline triangle.)	< ZeroTorqueEngLoad in Supporting Tables	4 cycle delay	
					Below zero torque: TPS Vehicle Speed	≤ 1 % > 30 mph	4 cycle delay	
					EGR Intrusive test	Active	12 cycle delay	
					Manual Trans	Clutch shift	4 cycle delay	
					Accel Pedal Position AND Automatic transmission shift	> 95.00 %	7 cycle delay	
					Driveline Ring Filter active			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early. Filter Driveline ring: Stop filter early:	<ul> <li>"Ring Filter" # of engine cycles after misfire in Supporting Tables</li> <li>"Number of Normals" # of engine cycles after misfire in Supporting Tables tab.</li> </ul>		
					Engine Speed Veh Speed Consecutive decels while in SCD Mode	<ul> <li>&gt; 1 %</li> <li>&gt; 1,000 rpm</li> <li>&gt; 3 mph</li> <li>&gt; Abnormal SCD Mode</li> <li>&gt; Abnormal Cyl Mode</li> <li>&gt; Abnormal Rev Mode</li> <li>in Supporting Tables</li> </ul>		
					Misfire Crankshaft Pattern Recognition checks each "misfire" candidate in 100 engine Cycle test to see if it looks like real misfire, or some disturbance like rough road. The check is			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					based on a multiplier times the ddt_jerk value used to detect misfire at that speed and load. At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present. Pattern Recog Enabled: Engine Speed Veh Speed "misfire" unrecognized if: Crankshaft snap after: isolated "misfire"	Enabled 630 < rpm < 6,100 > 3.1 mph > Min_PatternMultiplier > Max_PatternMultiplier		
					Ratio of Unrecog/Recog	in Supporting Tables	discard test	
					Rough Road: Non-Crankshaft based: Rough Road Source	Disabled TOSS		
					IF Rough Road Source = WheelSpeedInECM ABS/TCS Wheel speed noise VSES	active > WSSRoughRoadThres active	discard test	
					IF Rough Road Source = "FromABS" ABS/TCS RoughRoad VSES	active detected active	discard test	
					IF Rough Road Source = "TOSS"			

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					TOSS dispersion	>TOSSRoughRoadThres in supporting tables	discard test	
					AND No Active DTCs	Transmission Output Shaft Angular Velocity Validity TransmissionEngagedStat e_FA (Auto Trans only) Clutch Sensor FA (Manual Trans only)	4 cycle delay	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position System Variation Not Learned	P0315	Monitor for valid crankshaft error compensation factors	Sum of Compensation factors. Each Cylinder pair shares one compensation factor. A perfect factor would be 1.0000. Unlearned factors are defaulted out of range so the sum of factors would be out of range.	≥ 2.0040 OR ≤ 1.9960	OBD Manufacturer Enable Counter	MEC = 0	0.50 seconds Frequency Continuous100 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Per Cylinder	P0324	This diagnostic checks for knock sensor performance out of the normal expected range on a per cylinder basis due to: 1. Excessive knock or 2. Abnormal engine noise or 3. Flat signal	Common Enable Criteria (Applies to all 3 parts of the performance diag) Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag: 1. Excessive Knock Diag: Filtered Knock Intensity VaKNKD_k_PerfCylKnock IntFilt (where 'Knock Intensity' =	> 0.45 (no units)	Diagnostic Enabled? Engine Run Time Engine Speed Engine Air Flow ECT IAT Engine Speed Cumlative Number of Engine Revs Above Min Eng Speed (per key cycle)	Yes ≥ 2.0 seconds ≤ 8,500 RPM ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder ≥ -40 deg's C ≥ -40 deg's C = ≥ 1,500 RPM ≥ 100 Revs	First Order Lag Filters with Weight Coefficients  Excessive Knk Weight Coefficient = 0.0400 Updated each engine event	Type B, 2 Trips
			0 with no knock; and > 0 & proportional to knock magnitude with knock) 	< AbnormalNoise_Thre shold (see Supporting Tables)	Individual Cylinders enabled for Abnormal Noise Engine Speed Cumlative Number of Engine Revs Above Min Eng Speed (per key	See AbnormalNoise_ CylsEnabled (Supporting Tables) ≥ 8,500 RPM ≥ 400 Revs	Abn Noise Weight Coefficient = 0.0100 Updated each engine event	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					cycle)			
			3. Flat Signal Diag: Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock) VaKNKD_k_PerfCyIFlatFil tInt	< 0.008 (no units)	Engine Speed Cumlative Number of Engine Revs Above Min Eng Speed (per keycycle)	≥ 8,500 RPM ≥ 400 Revs	Flat Signal Weight Coefficient = 0.010 Updated each engine event	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank	P0325	This diagnostic checks for an open in the knock sensor circuit	Filtered FFT Output	> OpenCktThrshMin and < OpenCktThrshMax	Diagnostic Enabled? Engine Run Time	Yes ≥ 2.0 seconds	First Order Lag Filter with Weight Coefficient	Type B, 2 Trips
				See Supporting Tables	Engine Speed	≥ 570 RPM and ≤ 8,500 RPM	Weight Coefficient = 0.0100	
				Thresholds for OpenMethod = 20 kHz: <b>OpenCktThrshMin</b> (20 kHz) & <b>OpenCktThrshMax</b> (20 kHz)	Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)	≥ 100 revs	Updated each engine event	
				Thresholds for OpenMethod = NormalNoise: OpenCktThrshMin (Normal Noise) & OpenCktThrshMax	Engine Air Flow	≥ 40 mg/cylinder and ≤ 2,000 mg/cylinder		
				(Normal Noise)	ECT IAT	≥ -40 deg's C ≥ -40 deg's C		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Bank 1	P0326	This diagnostic checks for knock sensor performance out of the normal expected range, on a per sensor basis, due to 1. Excessive knock or 2. Abnormal engine noise or 3. Flat signal	Common Enable Criteria (Applies to all 3 parts of the performance diag) Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag: 1. Excessive Knock Diag: Filtered Knock Intensity (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)	> 0.45 (no units)	Diagnostic Enabled? Engine Run Time Engine Speed Engine Air Flow ECT IAT Engine Speed Cumlative Number of Engine Revs Above Min Eng Speed (per key cycle)	Yes ≥ 2.0 seconds ≤ 8,500 RPM ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder ≥ -40 deg's C ≥ -40 deg's C ≥ 1,500 RPM ≥ 100 Revs	First Order Lag Filters with Weight Coefficients Excessive Knk Weight Coefficient = 0.0100 Updated each engine event	Type B, 2 Trips
			2. Abnormal Noise Diag: Filtered FFT Intensity: (where 'FFT Intensity' = Non-knocking, background noise)	< <b>AbnormalNoise_</b> <b>Threshold</b> (see Supporting Tables)	Individual Cylinders enabled for Abnormal Noise Engine Speed Cumlative Number of Engine Revs Above Min Eng Speed (per key	See AbnormalNoise_ CylsEnabled (Supporting Tables) ≥ 2,500 RPM ≥ 100 Revs	Abnormal Noise Weight Coefficient = 0.0100 Updated each engine event	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					cycle)			
			3. Flat Signal Diag: Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock)	< 0.008 (no units)	Engine SpeedCumlative Number of Engine Revs Above Min Eng Speed (per keycycle)	≥ 8,500 RPM ≥ 100 Revs	Flat Signal Weight Coefficient = 0.010 Updated each engine event	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 1	P0327	This diagnostic checks for an out of range low knock sensor signal	Sensor Input or Return Signal Line	< 8.0 Percent (of 5 V reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 1	P0328	This diagnostic checks for an out of range high knock sensor signal		> 39.0 Percent (of 5 Volt Reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
	P0335	Determines if a fault exists with the crank position sensor signal	Time since last crankshaft position sensor pulse received	>= 4.0 seconds	Starter engaged AND (cam pulses being received OR ( DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow	= FALSE = FALSE = FALSE > 3.0 grams/second ) )	Continuous every 100 msec	Type B, 2 Trips
			No crankshaft pulses received	>= 0.1 seconds	Engine is Running Starter is not engaged No DTC Active:	5VoltReferenceB_FA	Continuous every 12.5 msec	
			No crankshaft pulses received		Engine is Running OR Starter is engaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA P0365 P0366	2 failures out of 10 samples One sample per engine revolution	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft P Position (CKP) Sensor A Performance	P0336	Determines if a performance fault exists with the crank position sensor signal	Time in which 10 or more crank re- synchronizations occur	< 10.0 seconds	Engine Air Flow Cam-based engine speed No DTC Active:	>= 3.0 grams/second > 450 RPM 5VoltReferenceB_FA P0335	Continuous every 250 msec	Type B, 2 Trips
			No crankshaft synchronization gap found	>= 0.4 seconds	Engine is Running Starter is not engaged No DTC Active:	5VoltReferenceB_FA	Continuous every 12.5 msec	
		en de sy	Time since starter engaged without detecting crankshaft synchronization gap	>= 1.5 seconds	Starter engaged AND (cam pulses being received OR ( DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow	= FALSE = FALSE = FALSE > 3.0 grams/second ) )	Continuous every 100 msec	
			Crank pulses received in one engine revolution OR Crank pulses received in one engine revolution	< 51 > 65	Engine is Running OR Starter is engaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA P0365 P0366	8 failures out of 10 samples One sample per engine revolution	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
	P0340	Determines if a fault exists with the cam position bank 1 sensor A signal	Time since last camshaft position sensor pulse received OR Time that starter has been engaged without a camshaft sensor pulse Fewer than 4 camshaft pulses received in a time	>= 5.5 seconds >= 4.0 seconds > 3.0 seconds	Starter engaged AND (cam pulses being received OR ( DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow Engine is running	= FALSE = FALSE = FALSE > 3.0 grams/second ) )	Continuous every 100 msec Continuous every 100 msec	Type B, 2 Trips	
					Starter is not engaged No DTC Active:	5VoltReferenceA_FA			
	re 1 (7 M			No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	Continuous every MEDRES event	
		The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle	-		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor A	P0341	Determines if a performance fault exists with the cam position bank 1 sensor A signal	The number of camshaft pulses received during first 12 MEDRES events is OR (There are 12 MEDRES events per engine cycle)	< 4 >6	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT	P0351	Diagnoses the Ignition Control (EST) low side driver circuit for circuit faults. Monitors EST for Cylinder 1 (Cylinders 1 and 4 for V6 with waste spark).	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver off state (indicates short- to-ground or open circuit)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground <u>Open Circuit</u> : ≥ 200 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips
			Voltage high during driver on state (indicates short- to-power)	Short to power: $\leq 0.5 \Omega$ impedance between signal and controller power				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT	P0352	Diagnoses the Ignition Control (EST) low side driver circuit for circuit faults. Monitors EST for Cylinder 2 (Cylinders 2 and 5 for V6 with waste spark).	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver off state (indicates short- to-ground or open circuit)	<u>Short to ground</u> : ≤ 0.5 Ω impedance between signal and controller ground <u>Open Circuit</u> : ≥ 200 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips
			Voltage high during driver on state (indicates short- to-power)	Short to power: $\leq 0.5 \Omega$ impedance between signal and controller power				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT	P0353	Diagnoses the Ignition Control (EST) low side driver circuit for circuit faults. Monitors EST for Cylinder 3 (Cylinders 3 and 6 for V6 with waste spark).	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver off state (indicates short- to-ground or open circuit)	<u>Short to ground</u> : ≤ 0.5 Ω impedance between signal and controller ground <u>Open Circuit</u> : ≥ 200 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips
			Voltage high during driver on state (indicates short- to-power)	<u>Short to power</u> : $\leq 0.5 \Omega$ impedance between signal and controller power				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT	P0354	Diagnoses the Ignition Control (EST) low side driver circuit for circuit faults. Monitors EST for Cylinder 4 (if applicable).	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver off state (indicates short- to-ground or open circuit)	<u>Short to ground</u> : ≤ 0.5 Ω impedance between signal and controller ground <u>Open Circuit</u> : ≥ 200 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips
			Voltage high during driver on state (indicates short- to-power)	<u>Short to power</u> : $\leq 0.5 \Omega$ impedance between signal and controller power				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor B	aft P0365 Determines if a fault exists with the cam position bank 1 sensor B signal	Time since last camshaft position sensor pulse received OR Time that starter has been engaged without a camshaft sensor pulse Fewer than 4 camshaft pulses received in a time	>= 5.5 seconds >= 4.0 seconds > 3.0 seconds	Starter engaged AND (cam pulses being received OR ( DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow Engine is running	= FALSE = FALSE = FALSE > 3.0 grams/second ) )	Continuous every 100 msec Continuous every 100 msec	Type B, 2 Trips	
					Starter is not engaged No DTC Active:	5VoltReferenceA_FA		
			No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	Continuous every MEDRES event	
		The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle	-	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor B	P0366	Determines if a performance fault exists with the cam position bank 1 sensor B signal	The number of camshaft pulses received during first 12 MEDRES events is OR (There are 12 MEDRES events per engine cycle)	< 4 >6	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 1	P0420	NOTE: The information contained below applies to applications that use the Idle Catalyst Monitor Algorithm The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (I.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Lean and Rich A/F excursions	Normalized Ratio OSC Value (EWMA filtered)	< 0.10	There must be a valid idle period. The criteria are: Driver must be off the accel pedal. This checks that the final accel pedal position (comprehending deadband and hysteresis) is essentially zero. Idle Speed Control System Is Active Vehicle Speed Engine speed Engine run time	< 1.24 MPH > 1,100 RPM for a minimum of 5 seconds since end of last idle period. > CatmonMinEngineRunTi meToEnable This is a function of Coolant Temperature, please see "Supporting Tables" for details.	1 test attempted per valid idle period Minimum of 1 test per trip Maximum of 8 tests per trip Frequency: Fueling Related : 12.5 ms OSC Measurements: 100 ms Temp Prediction: 12.5ms	Type A, 1 Trips
		Normalized Ratio OSC Value Calculation Information and Definitions = 1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time) 2. BestFailing OSC value from a calibration table (based on temp and exhaust gas flow)			Tests attempted this trip The catalyst diagnostic has not yet completed for the current trip. Catalyst Idle Conditions Met Criteria is satified which includes the General Enable met and the Valid Idle Period	< 255		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		3. WorstPassing OSC			Criteria met, as well as:			
		value (based on temp and exhaust gas flow)			Green Converter Delay	Not Active		
		Normalized Ratio Calculation = (1-2) / (3-2)			Induction Air	> -20 ° C < 250 ° C		
		A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part. The Catalyst Monitoring			Intrusive test(s): Fueltrim Post O2 EVAP EGROther vehicle functions:	Not Active		
		Test is done during idle. Several conditions must be meet in order to execute this test. These conditions and			Power Take Off RunCrank Voltage Ethanol Estimation	Not Active > 10.90 Volts NOT in Progress		
		their related values are listed in the secondary parameters area of this document.			ECT	> 40 ° C < 140 ° C		
					Barometric Pressure	> 70 KPA		
					Idle Time before going intrusive is	< 50 Seconds		
					Idle time is incremented if Vehicle speed	< 1.24 MPH and the drivers foot is off accel pedal and the idle speed control system is active as identified in the Valid Idle Period Criteria section.		
					Short Term Fuel Trim	> 0.80 < 1.30		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Predicted catalyst temp	> 550.00 degC		
					Engine Airflow	> CatmonMinAirflowForW armCatalystDeterminati on		
						table (g/s) (refer to "Supporting Tables" tab) (Based on engine coolant at the time the WarmedUpEvents counter resets to 0.)		
					for at least	15 seconds		
					with a closed throttle time	< 60 seconds consecutively (closed throttle consideration involves having the driver off the accel pedal as stated in the Valid Idle Period Criteria Section).		
					Also, in order to increment the WarmedUpEvents counter, either the vehicle speed must exceed the vehicle speed cal or the driver must NOT be off the accel pedal as stated in the Valid Idle Period Criteria section above.			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Closed loop fueling (Please see "Closed Loop Enable Criteria" section of the "Supporting Tables" tab for details.)			
					PRNDL	Enabled in Drive Range on an Auto Transmission vehicle.		
					Idle Stable Criteria:	Must hold true from after Catalyst Idle Conditions Met to the end of test		
					MAF	> 1.50 g/s < 7.00g/s		
					Predicted catalyst temperature	< 950 degC		
					Engine Fueling Criteria at Beginning of Idle Period The following fueling related must also be met from between 4 and 7 seconds after the Catalyst Idle Conditions Met Criteria has been met for at least 4 seconds prior to allowing intrusive control:			
					Number of pre-O2 switches	>= 2		
					Short Term Fuel Trim Avg	> 0.96 < 1.04		
					Rapid Step Response			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(RSR) feature will initiate multiple tests:			
					If the difference between current EWMA value and the current OSC Normalized Ratio value is	> 0.49		
					and the current OSC Normalized Ratio value is	< 0.10		
					Maximum RSR tests to detect failure when RSR is enabled.	24		
					Green Converter Delay Criteria This is part of the check for the Catalyst Idle Conditions Met Criteria section			
					The diagnostic will not be enabled until the following has been met:			
					Predicted catalyst temperature for	> 0 ° C 0 seconds non- continuously.		
					Note: this feature is only enabled when the vehicle is new and cannot be enabled in service	Not Active		
					PTO General Enable DTC's Not Set	MAF_SensorFA MAF_SensorTFTKO AmbPresDfltdStatus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						IAT_SensorCircuitFA IAT_SensorCircuitTFTKO ECT_Sensor_FA O2S_Bank_1_Sensor_1_ FA O2S_Bank_2_Sensor_2_ FA O2S_Bank_2_Sensor_2_ FA O2S_Bank_2_Sensor_2_ FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelTrimSystemB2_FA FuelTrimSystemB2_TFTK O EngineMisfireDetected_F A EvapPurgeSolenoidCircuit _FA IAC_SystemRPM_FA EGRValvePerformance_FA CamSensorFA TPS_Performance_FA EnginePowerLimited		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Small Leak Detected (Not Sealed Fuel System)	P0442	This DTC will detect a small leak ( $\geq$ 0.020") in the EVAP system between the fuel fill cap and the purge solenoid. On some applications a small leak is defined as $\geq$ 0.025", 0.030", or 0.150". The engine off natural vacuum method (EONV) is used. EONV is an evaporative system leak detection diagnostic that runs when the vehicle is shut off when enable conditions are met. Prior to sealing the system and performing the diagnostic, the fuel volatility is analyzed. In an open system (Canister Vent Solenoid [CVS] open) high volatility fuel creates enough flow to generate a measurable pressure differential relative to atmospheric.After the volatility check, the vent solenoid will close. After the vent is closed, typically a build up of pressure from the hot soak begins (phase-1). The pressure typically will peak and then begin to decrease as the fuel cools. When	Threshold (Pascals) Table in Supporting Tables). The normalized value is calculated by the following equation: 1 - (peak pressure - peak vacuum) / pressure threshold. The normalized value is entered into EWMA (with 0= perfect pass and 1= perfect fail).	<ul> <li>&gt; 0.54 (EWMA Fail Threshold),</li> <li>≤ 0.35 (EWMA Re- Pass Threshold)</li> </ul>	Fuel Level Drive Time Drive length ECT Baro Distance since assembly plant Engine not run time before key off must be Time since last complete test if normalized result and EWMA is passing OR Time since last complete test if normalized result or EWMA is failing Estimated ambient temperature at end of drive Estimate of Ambient Air Temperature Valid ************************************	10 % ≤ Percent ≤ 90 % ≥ 600 seconds ≥ 70 °C ≥ 70 kPa ≥ 10.0 miles ≤ refer to P0442: Engine Off Time Before Vehicle Off Maximum as a Function of Estimated Ambient Temperature Table in Supporting Tables. ≥ 17 hours ≥ 10 hours 0 °C≤Temperature≤ 34 °C	Once per trip, during hot soak (up to 2,400 sec.). No more than 2 unsuccessful attempts between completed tests.	Type A, 1 Trips EWMA Average run length is 8 to 12 trips under normal condition s Run length is 3 to 6 trips after code clear or non- volatile reset

	<sup>-</sup> ault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System C	Code	the pressure drops (-62.27) Pa from peak pressure, the vent is then opened for 60 seconds to normalize the system pressure. The vent is again closed to begin the vacuum portion of the test (phase-2). As the fuel temperature continues to fall, a vacuum will begin forming. The vacuum will continue until it reaches a vacuum peak. When the pressure rises 62.27 Pa from vacuum peak, the test then completes. If the key is turned on while the diagnostic test is in progress, the test will abort.			<ul> <li>Startup delta deg C (ECT-IAT)</li> <li>OR</li> <li>Short Soak and Previous EAT Valid</li> <li>Previous time since engine off</li> <li>OR</li> <li>Less than a short soak and Previous EAT Not Valid</li> <li>Previous time since engine off</li> <li>AND</li> <li>Vehicle Speed</li> <li>AND</li> <li>Vehicle Speed</li> <li>AND</li> <li>Mass Air Flow</li> <li>Must expire Estimate of Ambient Temperature</li> <li>Valid Conditioning Time.</li> <li>P0442: Estimate of Ambient Temperature</li> <li>Valid Conditioning Time</li> <li>Table in Supporting Tables.</li> <li>OR</li> <li>Not a Cold Start and greater than a Short Soak</li> <li>Previous time since engine off AND</li> </ul>	<ul> <li>≤ 8 °C</li> <li>≤ 7,200 seconds</li> <li>≥ 30 mph</li> <li>≥ 7 g/sec</li> <li>&gt; 7,200 seconds</li> </ul>		Illum.

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Must expire maximum value in Estimate of Ambient Temperature Valid Conditioning Time. Please see <b>P0442:</b> <b>Estimate of Ambient</b> <b>Temperature Valid</b> <b>Conditioning Time</b> in Supporting Tables.			
					<ol> <li>High Fuel Volatility         During the volatility             phase, pressure in the             fuel tank is integrated vs.             time. If the integrated             pressure is             then test aborts and             unsuccessful attempts is             incremented.         </li> <li>OR         <ol> <li>Vacuum Refueling             Detected</li> </ol> </li> </ol>	< -5		
					See P0454 Fault Code for information on vacuum refueling algorithm. OR 3. Fuel Level Refueling Detected			
					See P0464 Fault Code for information on fuel level refueling.			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					4. Vacuum Out of Range and No Refueling			
					See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.			
					OR 5. Vacuum Out of Range and Refueling Detected			
					See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.			
					OR 6. Vent Valve Override Failed			
					Device control using an off-board tool to control the vent solenoid, cannot exceed during the EONV test	0.50 seconds		
					OR 7. Key up during EONV test			
					No active DTCs:	MAF_SensorFA ECT_Sensor_FA IAT_SensorFA VehicleSpeedSensor_FA IgnitionOffTimeValid AmbientAirDefault		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						P0443 P0446 P0449 P0452 P0453 P0455 P0496		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent System Performance (Not Sealed Fuel System)	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filler, vent hose or EVAP canister. This test runs with normal purge and vent valve is open.	Vent Restriction Prep Test: Vented Vacuum for OR Vented Vacuum for Vent Restriction Test: Tank Vacuum for before Purge Volume After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time.	<-623 Pa 60 seconds > 1,245 Pa 60 seconds > 2,989 Pa 5 seconds ≥ 8 liters	Fuel Level System Voltage Startup IAT Startup ECT BARO No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts 4 °C ≤ Temperature ≤ 30 °C ≤ 35 °C ≥ 70 kPa MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0443 P0452 P0453 P0454	Once per Cold Start Time is dependent on driving conditions Maximum time before test abort is 1,000 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent Solenoid Control Circuit (ODM) (Not Sealed Fuel System and For Single DTC Implementati on Only)	P0449	Diagnoses the vent solenoid low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit or short-to-ground) Voltage high during driver on state (indicates short to power) If the P0449 is active, an intrusive test is performed with the vent solenoid commanded closed for 15 seconds.	Open circuit: $\geq 200 \text{ K} \Omega$ impedence between signal and controller ground: $\leq 0.5 \Omega$ impedence between signal and controller ground Short to power: $\leq 0.5 \Omega$ impedence between signal and controller power			20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Performance (Not Sealed Fuel System)	P0451	The DTC will be set if the fuel tank vacuum sensor is out of range when it tries to re-zero prior to the phase-1 or phase-2 portions of the engine-off natural vacuum small leak test.	The tank vacuum sensor voltage is compared to a window about the nominal sensor voltage offset (~1.5 volts) Upper voltage threshold (voltage addition above the nominal voltage) Lower voltage threshold (voltage subtraction below the nominal voltage) The difference between tank vacuum sensor voltage and the nominal offset voltage is then normalized against the appropriate threshold listed above to produce a ratio between 0.0 and 1.0. This normalized re-zero ratio is then filtered with a EWMA (with 0= perfect pass and 1=perfect fail). When EWMA is the DTC light is illuminated. The DTC light can be	0.2 volts 0.2 volts > 0.73 (EWMA Fail Threshold),	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		This test is executed during an engine-off natural vacuum small leak test. The number of times that it executes can range from zero to two per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.	Type A, 1 Trips EWMA Average run length: 6 Run length is 2 trips after code clear or non- volatile reset
		and sta EWMA	turned off if the EWMA is and stays below the EWMA fail threshold for 3 additional consecutive trips.	≤0.40 (EWMA Re-Pass Threshold)				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Low Voltage (Not Sealed Fuel System)	P0452	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too low out of range.	FTP sensor signal The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~ -3736 Pa).	< 0.15 volts ( 3.0 % of Vref or ~ 1,681 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples 12.5 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit High Voltage (Not Sealed Fuel System)	P0453	Fuel Tank Pressure (FTP) sensor signal	FTP sensor signal The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~ -3736 Pa).	> 4.85 volts ( 97 % of Vref or ~ -4,172 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples 12.5 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Intermittent (Not Sealed Fuel System)	P0454	This DTC will detect intermittent tank vacuum sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	If an abrupt change in tank vacuum is detected the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that a refueling event occurred. If a refueling is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem. An abrupt change is defined as a change in vacuum: in the span of 1.0 seconds. But in 12.5 msec. A refueling event is confirmed if the fuel level has a persistent change of for 30 seconds.	> 112 Pa < 249 Pa 10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes and the canister vent solenoid is closed		This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine- off period.The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.The test will report a failure if 2 out of 3 samples are failures. 12.5 ms / sample	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Large Leak Detected (Not Sealed Fuel System)	P0455	This DTC will detect a weak vacuum condition (large leak or purge blockage) in the EVAP system. Purge valve is controlled (to allow purge flow) and vent valve is commanded closed.	Purge volume while Tank vacuum After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time. Weak Vacuum Follow-up Test (fuel cap replacement test) Weak Vacuum Test failed. Passes if tank vacuum	> 15 liters ≤2,740 Pa ≥2,740 Pa	Fuel Level System Voltage BARO Purge Flow No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts ≥ 70 kPa ≥ 2.80 % MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449	Once per cold start Time is dependent on driving conditions Maximum time before test abort is 1,000 seconds Weak Vacuum Follow-up Test With large leak detected, the	Type B, 2 Trips
			Note: Weak Vacuum Follow-up Test can only report a pass.		Cold Start Test If ECT > IAT, Startup temperature delta (ECT- IAT): Cold Test Timer Startup IAT Startup ECT	P0452 P0453 P0454 ≤ 8 °C ≤ 1,000 seconds 4 °C≤Temperature≤ 30 °C ≤ 35 °C	follow-up test is limited to 1,300 seconds. Once the MIL is on, the follow-up test runs indefinitely.	
					Weak Vacuum Follow-up Test This test can run following a weak vacuum failure or on a hot restart.			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Performance	P0461	This DTC will detect a fuel sender stuck in range in the primary fuel tank.	Delta fuel volume change over an accumulated 149 miles.	< 3 liters	Engine Running No active DTCs:	VehicleSpeedSensor_FA	250 ms / sample	Type B, 2 Trips
(For use on vehicles with a single fuel tank)								

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Fuel Level Sensor 1 Circuit Low	P0462	This DTC will detect a fuel sender stuck out of range low in the	Fuel level Sender % of 5V range	< 10 %			100 failures out of 125 samples	Type B, 2 Trips
Voltage		primary fuel tank.					100 ms / sample	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Fuel Level Sensor 1 Circuit High	P0463	This DTC will detect a fuel sender stuck out of range high in the	Fuel level Sender % of 5V range	> 60 %			100 failures out of 125 samples	Type B, 2 Trips
Voltage		primary fuel tank.					100 ms / sample	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Intermittent (Not Sealed Fuel System)	P0464	This DTC will detect intermittent fuel level sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	If a change in fuel level is detected, the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that an actual refueling event occurred. If a refueling event is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem. An intermittent change in fuel level is defined as: The fuel level changes by and does not remain for 30 seconds during a 600 second refueling rationality test.	10 % > 10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine- off period.The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.The test will report a failure if 2 out of 3 samples are failures. 100 ms / sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Open (ODM) (Not used on EREV)	P0480	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0691 may also set (Fan 1 Short to Ground).

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Open (ODM)	P0481	Diagnoses the cooling fan 2 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0693 may also set (Fan 2 Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Flow During Non- Purge (Not Sealed Fuel System)	P0496	This DTC will determine if the purge solenoid is leaking to engine manifold vacuum. This test will run with the purge valve closed and the vent valve closed.	Tank Vacuum for Test time	<ul> <li>&gt; 2,491 Pa</li> <li>5 seconds</li> <li>≥ refer to P0496:</li> <li>Purge Valve Leak</li> <li>Test Engine Vacuum</li> <li>Test Time (Cold Start)</li> <li>as a Function of Fuel</li> <li>Level Table in</li> <li>Supporting Tables.</li> </ul>	Fuel Level System Voltage BARO Startup IAT Startup ECT Engine Off Time No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts ≥ 70 kPa 4 °C≤Temperature≤ 30 °C ≤ 35 °C ≥ 28,800.0 seconds MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454	Once per cold start Cold start: max time is 1,000 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Low Engine Speed Idle System	P0506	This DTC will determine if a low idle exists	Filtered Engine Speed Error	> 91.00 rpm	Baro	> 70 kPa	Diagnostic runs in every 12.5 ms loop	Type B, 2 Trips
			filter coefficient	0.00300	Coolant Temp	> KeSPDD_T_EnblECT_Mi n (60 °C) and < KfECTI_T_EngCoolHotHi Thresh (124 °C) Must verify KfECTI_T_EngCoolHotLo Thresh ( 120) is less than KfECTI_T_EngCoolHotHi Thresh ( 124 )	Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	
					Engine run time	≥ 60 sec		
					Ignition voltage	32 ≥ volts ≥ 11		
					Time since gear change	≥ 3 sec		
					Time since a TCC mode change	> 3 sec		
					IAT	> -20 °C		
					Vehicle speed	≤ 1.24 kph		
					Commanded RPM delta	≤ 25 rpm		
					Idle time	> 10 sec		
					For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 80.00 pct < 12.00 pct		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						PTO not active		
						Transfer Case not in 4WD LowState		
						Off-vehicle device control (service bay control) must not be active.		
						following conditions not TRUE: (VeTESR_e_EngSpdReqI ntvType = CeTESR_e_EngSpdMinLi mit AND VeTESR_e_EngSpdReqR espType = CeTESR_e_NoSuggestio n) Clutch is not depressed		
					No active DTCs	TC_BoostPresSnsrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorCircuitFA EvapFlowDuringNonPurg e_FA FueITrimSystemB1_FA FueITrimSystemB2_FA FueIInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_F A		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA FuelLevelDataFault LowFuelConditionDiagnos tic Clutch Sensor FA AmbPresDfltdStatus P2771		
					All of the above met for Idle time	> 10 sec		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Engine Speed Idle System	P0507	This DTC will determine if a high idle exists	Filtered Engine Speed Error	< -182.00 rpm	Baro	> 70 kPa	Diagnostic runs in every 12.5 ms loop	Type B, 2 Trips
			filter coefficient	0.00300	Coolant Temp Engine run time	> KeSPDD_T_EnblECT_Mi n (60 °C) and < KfECTI_T_EngCoolHotHi Thresh (124 °C) Must verify KfECTI_T_EngCoolHotLo Thresh ( 120 ) is less than KfECTI_T_EngCoolHotHi Thresh ( 124 ) ≥ 60 sec	Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	
					-			
					Ignition voltage	$32 \ge \text{volts} \ge 11$		
					Time since gear change	≥ 3 sec		
					Time since a TCC mode change	> 3 sec		
					IAT	> -20 °C		
					Vehicle speed	≤ 1.24 kph		
					Commanded RPM delta	≤ 25 rpm		
					For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 80.00 pct < 12.00 pct		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						PTO not active		1
						Transfer Case not in 4WD LowState		
						Off-vehicle device control (service bay control) must not be active.		
						following conditions not TRUE: (VeTESR_e_EngSpdReqI ntvType = CeTESR_e_EngSpdMinLi mit AND VeTESR_e_EngSpdReqR espType = CeTESR_e_NoSuggestio n) Clutch is not depressed		
					No active DTCs	TC_BoostPresSnsrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorCircuitFA EvapFlowDuringNonPurg e_FA FueITrimSystemB1_FA FueITrimSystemB2_FA FueIInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_F A IgnitionOutputDriver_FA TPS_FA TPS_Performance_FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						FuelLevelDataFaultLow FuelConditionDiagnostic Clutch SensorFA AmbPresDfltdStatus P2771		
					All of the above met for Idle time	> 10 sec		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Air Conditioning High Side Pressure Sensor (HSPS) Sensor Performance	P0531	Determines if the Air Conditioning High Side Pressure Sensor circuit voltage is stuck or biased in range	The pressure sensor has to be greater than a threshold value when propulsion system is off for a ambient stabilization time	Cold Test Pressure > Cold_Test_Threshold Cold_Test_Threshold (function of ambient temperature). (P0531 Cold Test Details on Supporting Tables)	Diagnostic enabled/ disabled Cold Test enabled/ disabled AC has been enabled this Trip Enable Timer AC Soak Timer - the soak timer can be established (via calibration enable) to be minimum of the Engine Off Time, and/or the Propulsion System Off Time, and/or the Battery Thermal Conditioning Off Time Difference between Coolant Temperature and Air Temperature No active DTC's	Disabled Disabled FALSE Enabled Time > 1.0 Sec. Minimum Soak Time => 28,800 Sec. Use Engine Off Soak Time = FALSE Use Propulsion Off Soak Time= FALSE Use Battery Off Soak Time = FALSE Use Battery Off Soak Time = FALSE Temp Diff < 0.0 Deg C Fault bundles: ACHighSidePressSnsrCkt FA ACFailedOnSD ACThrmlRefrigSpdVld ACCMLostComm ECT_Sensor_DefaultDete cted	80 failures out of 100 samples Report Once per trip	Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Mutil- Functon Switch Circuit	P0564	Detect when cruise control multi-function switch circuit (analog) voltage is in an illegal range	Cruise Control analog circuit voltage must be in an "illegal range" or "between ranges" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 0.500 seconds	MIL: Type C No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control On Switch Circuit	P0565		Cruise Control On switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	MIL Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Resume Circuit	P0567	cruise resume switch in	Cruise Control Resume switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 90.000 seconds	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Set Circuit	P0568	Detects a failure of the cruise set switch in a continously applied state	Cruise Control Set switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 90.000 seconds	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Input Circuit	P0575	Detects rolling count or protection value errors in Cruise Control Switch Status serial data signal	If x of y rolling count / protection value faults occur, disable cruise for duration of fault		Cruise Control Switch Serial Data Error Diagnostic Enable	1.00	5 / 10 counts	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Range/ Performance	Position monitors the Brake Bensor Pedal Position Sense Circuit for a stuck in range Range/ failure	Pedal Position Sensor for a stuck in range			Brake Pedal Position Sensor Circuit Range / Performance Diagnostic Enable	1.00 ignition voltage > 10.00		MIL: Type A, 1 Trips
			Calculated EWMA value must be greater than calibratable theshold after calibratable number of tests have completed to report a "test passed" for P057B	EWMA value looked up in supporting table P057B KtBRKI_K_FastTestPoi ntWeight as a function of calculated brake pedal position delta EWMA value is > 0.70	calculated brake pedal position delta sample counter > 250.00 for fast test OR calculated brake pedal position delta sample counter > 1,000.00 for slow test	calculated brake pedal position delta > 100.00 OR (for slow test) shift lever has been in park once this key cycle vehicle speed >= 5.00 accelerator pedal position < 5.00	total number of EWMA tests > 2.00	
			Calculated EWMA Value must be less than calibratable threshold after calibratable number of tests have completed to report a "test failed" for P057B. This test runs once per key cycle	EWMA value looked up in supporting table P057B KtBRKI_K_CmpltTestP ointWeight as a function of calculated brake pedal position delta EWMA value is less thatn 0.30	no DTC's active (P057C, P057D)	shift lever has been in park once this key cycle vehicle speed >= 5.00 accelerator pedal position < 5.00	total number of EWMA tests > 2.00	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Low	P057C	detects short to ground for brake pedal position sensor		5.00	Brake Pedal Position Sensore Low Voltage Diagnostic Enable	1.00	20 / 32.00 counts	MIL: Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit High	P057D	detects open circuit for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	95.00	Brake Pedal Position Sensore High Voltage Diagnostic Enable	1.00	20.00 / 32.00 counts	MIL: Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi- function Circuit Low Voltage	P0580	detects short to ground failure for cruise multi- function switch circuit	Cruise Control analog circuit voltage must be in an "Open Short To Ground" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	MIL: Type C No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi- function Circuit High Voltage	P0581		Cruise Control analog circuit voltage must be in an "Short To Power" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control	P0597	Diagnoses the T-stat Heater low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and	Run Crank Ignition in Range	= True	15 failures out of 30 samples	Type B, 2 Trips Note: In
Open Circuit			,	controller ground.	Engine not cranking Run Crank active	= True = True	1 sec/ sample Continuous	certian controlle rs P0598
					== Above is true and ==	======		may also set
					Last Open Circuit Test	= not Indeterminate		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control	P0598	Diagnoses the T-stat Heater low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short- to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and	Run Crank Ignition in Range	= True	15 failures out of 30 samples	Type B, 2 Trips Note: In
Circuit Low				controller ground	Engine not cranking Run Crank active	= True = True	1 sec/ sample	certian controlle
					== Above is true and ==		Continuous	rs P0597 may also set
					Last Ground Short Circuit Test	= not Indeterminate		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control Circuit High	P0599	Diagnoses the T-stat Heater low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Run Crank Ignition in Range Engine not cranking Run Crank active == Above is true and == Last Power Short Circuit Test	= True = True = True =	<ul><li>15 failures out of 30 samples</li><li>1 sec/ sample</li><li>Continuous</li></ul>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if the calibration check sum is incorrect or the flash memory detects an uncorrectable error via the Error Correcting Code.	The Primary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	Type A, 1 Trips
			The Primary Processor's Error Correcting Code hardware in the flash memory detects an error. Covers all software and calibrations.	254 failures detected via Error Correcting Code			Diagnostic runs continuously via the flash hardware.	
		The Primary Processor's calculated checksum does not match the stored checksum value for a selected subset of the calibrations.	2 consecutive failures detected or 5 total failures detected.			Diagnostic runs continuously. Will report a detected fault within 200 ms.		
			The Secondary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	
				In all cases, the failure count is cleared when controller shuts down				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Not Programmed	P0602	This DTC will be stored if the PCM is a service PCM that has not been programmed.	Output state invalid		PCM State	= crank or run PCM is identified through calibration as a Service PCM	Diagnostic runs at powerup and once per second continuously after that	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Long Term Memory Reset	P0603	Non-volatile memory checksum error at controller power-up	Checksum at power-up does not match checksum at power-down				Diagnostic runs at powerup Diagnostic reports a fault if 1 failure occurs	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM RAM Failure	P0604	Indicates that the ECM has detected a RAM fault	Indicates that the primary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	Type A, 1 Trips
			Indicates that the primary processor is unable to correctly read data from or write data to cached RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor is unable to correctly read data from or write data to TPU RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
		Indicates that the primary processor detects a mismatch between the data and dual data is found during RAM updates. Detects a mismatch in data and dual data updates >	0.44000 s			When dual store updates occur.		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Indicates that the primary processor detects an illegal write attempt to protected RAM. Number of illegal writes are >	65,534 counts			Diagnostic runs continuously (background loop)	
			Indicates that the secondary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Fault	P0606	Indicates that the ECM has detected an internal processor integrity fault	Loss or invalid message of SPI communication from the Secondary Processor at initialization detected by the Primary Processor or loss or invalid message of SPI communication from the Secondary Processor after a valid message was received by the Primary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was recieved		Run/Crank voltage >= 6.41 or Run/Crank voltage >= 11.00, else the failure will be reported for all conditions	In the primary processor, 159 / 399 counts intermittent or 39 counts continuous; 39 counts continuous @ initialization. 12.5 ms /count in the ECM main processor	Type A, 1 Trips
			of SPI communication from the Primary Processor at initialization detected by the Secondary Processor or loss or invalid message of SPI communication from the Primary Processor after a valid message was received by the Secondary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was recieved			In the secondary processor, 20/200 counts intermittent or 0.1875 s continuous; 0.4750 s continuous @ initialization. 12.5 ms /count in the ECM secondary processor	
			Checks for stack over or underflow in secondary processor by looking for corruption of known pattern at stack boundaries. Checks number of stack over/ under flow since last powerup reset >=	5		KeMEMD_b_StackLimitTe stEnbl == 1 Value of KeMEMD_b_StackLimitTe stEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
		MAIN processor is verified by responding to a seed sent from the secondary with a key response to secondary. Checks number of incorrect keys	2 incorrect seeds within 8 messages, 0.2000 seconds		ignition in Run or Crank	150 ms for one seed continually failing		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			received > or Secondary processor has not received a new within time limit					
			Time new seed not received exceeded			always running	0.450 seconds	
			MAIN processor receives seed in wrong order			always running	3 / 17 counts intermittent. 50 ms/count in the ECM main processor	
			2 fails in a row in the Secondary processor's ALU check			KePISD_b_ALU_TestEnbl d == 1 Value of KePISD_b_ALU_TestEnbl d is: 1. (If 0, this test is disabled)	25 ms	
			2 fails in a row in the Secondary processor's configuration register masks versus known good data			KePISD_b_ConfigRegTes tEnbld == 1 Value of KePISD_b_ConfigRegTes tEnbld is: 1. (If 0, this test is disabled)	12.5 to 25 ms	
			Secondary processor detects an error in the toggling of a hardware discrete line controlled by the MAIN processor: number of discrete changes > = or < = over time window(50ms)	7 17		KePISD_b_MainCPU_SO H_FItEnbld == 1 Value of KePISD_b_ConfigRegTes tEnbld is: 1 (If 0, this test is disabled) time from initialization >= 0.4875 seconds	50 ms	
			memory and complement memory do not agree				0.19 seconds	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Software background task first pass time to complete exceeds			Run/Crank voltage > 6.41	360.000 seconds	
			2 fails in a row in the MAIN processor's ALU check			KePISD_b_ALU_TestEnbl d == 1 Value of KePISD_b_ALU_TestEnbl d is: 1. (If 0, this test is disabled)	25 ms	
			2 fails in a row in the MAIN processor's configuration register masks versus known good data			KePISD_b_ConfigRegTes tEnbld == 1 Value of KePISD_b_ConfigRegTes tEnbld is: 1. (If 0, this test is disabled)	12.5 to 25 ms	
			Checks number of stack over/under flow since last powerup reset >=	5		KeMEMD_b_StackLimitTe stEnbl == 1 Value of KeMEMD_b_StackLimitTe stEnbl is: 1. . (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			Voltage deviation >	0.4950		KePISD_b_A2D_CnvrtrTe stEnbld == 1 Value of KePISD_b_A2D_CnvrtrTe stEnbld is: 1. (If 0, this test is disabled)	5 / 10 counts or 0.150 seconds continuous; 50 ms/count in the ECM main processor	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occured since last	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_FlashECC_ CktTestEnbl == 1 Value of KeMEMD_b_FlashECC_ CktTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			controller initialization. Counter >=					
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occured since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_RAM_ECC_ CktTestEnbl == 1 Value of KeMEMD_b_RAM_ECC_ CktTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to write flash to RAMvariable, depends on length of time to write flash to RAM	
			MAIN processor DMA transfer from Flash to RAM has 1 failure			KePISD_b_DMA_XferTest Enbld == 1 Value of KePISD_b_DMA_XferTest Enbld is: 0. (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM	
			Safety critical software is not executed in proper order.	>= 1 incorrect sequence.		Table, f(Loop Time). See supporting tables: <b>Program Sequence</b> <b>Watch Enable f(Loop</b> <b>Time)</b> (If 0, this Loop Time test is disabled)	Fail Table, f(Loop Time). See supporting tables: <b>PSW</b> <b>Sequence Fail f</b> (Loop Time)	
							Sample Table, f (Loop Time)See supporting tables: <b>PSW</b> <b>Sequence</b> <b>Sample f(Loop</b> <b>Time)</b>	
							counts	
							50 ms/count in	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							the ECM main processor	
			MAIN processor determines a seed has not changed within a specified time period within the 50ms task.	Previous seed value equals current seed value.		KePISD_b_SeedUpdKey StorFItEnbl == 1 Value of KePISD_b_SeedUpdKey StorFItEnbl is: 1. (If 0, this test is disabled)	Table, f(Loop Time). See supporting tables: Last Seed Timeout f (Loop Time)	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Control Circuit Open - For 3 DTC implementati on only	P0615	Diagnoses the starter relay high side driver circuit for circuit faults	Voltage high during driver off states (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Run/Crank Voltage Engine Speed	Voltage ≥ 11 volts ≥ 0 RPM	8 failures out of 10 samples 50 ms / sample	Type C, No MIL Not "Special Type C" Note: In certain controlle rs P0617 may also set (Starter Relay Control Short to Power)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Control Circuit Low Voltage	P0616	Diagnoses the starter relay high side driver circuit for circuit faults		≤ 0.5 Ω impedance between signal and	Run/Crank Voltage Engine Speed	Voltage ≥ 11 volts ≥ 0 RPM	8 failures out of 10 samples 50 ms / sample	Type C, No MIL Not "Special
								Type C"

	Fault I Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
-	P0617 [	Diagnoses the starter relay high side driver circuit for circuit faults	Voltage high during driver off states (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Run/Crank Voltage Engine Speed	Voltage ≥ 11 volts ≥ 0 RPM	8 failures out of 10 samples 50 ms / sample	Type C, No MIL Not "Special Type C" Note: In certain controlle rs P0618 may also set (Starter Relay Control

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit Open	P0627	Diagnoses the fuel pump relay control high side driver circuit for circuit faults	Voltage high during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Run/Crank Voltage Engine Speed	Voltage ≥ 11 volts ≥ 0 RPM	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In
Circuit Open								certain controlle rs P062S may also set (Fue Pump Relay Control Short to Power)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control	P0628		Voltage low during driver on state (indicates short to ground)	Short to ground: ≤ 0.5 Ω impedance between signal and	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples	Type B, 2 Trips
Circuit Low Voltage		circuit faults		controller ground	Engine Speed	≥0 RPM	250 ms / sample	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control	P0629	Diagnoses the fuel pump relay control high side driver circuit for	Voltage high during driver off state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples	Type B, 2 Trips
Circuit High Voltage		circuit faults		controller power	Engine Speed	≥0 RPM	250 ms / sample	Note: In certain controlle rs P062 may also set (Fue Pump Relay Control Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module EEPROM Error	P062F	Indicates that the NVM Error flag has not been cleared	The next write to NVM will not succeed or the assembly calibration integrity check failed.		Ignition State	= unlock/accessory, run, or crank	1 test failure Diagnostic runs once at powerup	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VIN Not Programmed or Mismatched - Engine Control Module (ECM)	P0630	This DTC checks that the VIN is correctly written	At least one of the programmed VIN digits	= 00 or FF	OBD Manufacturer Enable Counter	= 0	250 ms / test Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #1 Circuit	P0641	Detects a continuous or intermittent short on the 5 volt reference circuit #1		4.875 5.125 0.0495		Run/Crank voltage > 6.41	19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Open - For 3 DTC implementati on only	P0650	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11 volts	20 failures out of 25 samples 250 ms / sample	Type B, No MIL NO MIL Note: In certain controlle rs P263A may also set (MIL Control Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #2 Circuit		Detects a continuous or intermittent short on the 5 volt reference circuit #2		4.875 5.125 0.0495		Run/Crank voltage > 6.41	19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Bank 1	P0660	Diagnoses the Intake Manifold Tuning (IMT) Valve low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: >= 200K Ohms impedance between signal and controller ground	Powertrain Relay Voltage Engine Speed	>= 11.00 Volts >= 400 RPM	32 failures out of 40 samples 1 sample every 12.5 msec	Type B, 2 Trips Note in certain controlle rs P0661 may also set (Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Low Voltage Bank 1)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Low Voltage Bank 1	P0661	Diagnoses the Intake Manifold Tuning (IMT) Valve low side driver circuit for circuit faults	Voltage low during driver off state (indicates short- to-ground or open circuit)	Short to ground: <= 0.5 Ohms impedance between signal and controller ground Open Circuit: >= 200K Ohms impedance between signal and controller ground	Powertrain Relay Voltage Engine Speed	>= 11.00 Volts >= 400 RPM	32 failures out of 40 samples 1 sample every 12.5 msec	Type B, 2 Trips Note in certain controlle rs P0660 may also set (Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Bank 1)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit High Voltage Bank 1	P0662	Diagnoses the Intake Manifold Tuning (IMT) Valve low side driver circuit for circuit faults	Voltage low during driver on state (indicates short- to-power)	Short to power: <= 0.5 Ohms impedance between signal and controller power	Powertrain Relay Voltage Engine Speed	>= 11.00 Volts >= 400 RPM	32 failures out of 40 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Open - For 3 DTC implementati on only	P0685	Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω ohms impedance between signal and controller ground	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0686 may also set (Powertr ain Relay Control Short to Ground).

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Low	P0686	Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short- to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0685 may also set (Powertr ain Relay Control Open Circuit).

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Powertrain Relay Control (ODM) High		Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage high during driver on state (indicates short to power)	Short to power: $\leq 0.5 \Omega$ impedance between signal and controller power	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Feedback Circuit Low	P0689	This DTC is a check to determine if the Powertrain relay is functioning properly.	PT Relay feedback voltage is	≤5 volts	Run/Crank Voltage Powertrain relay commanded "ON"	≥ 11 volts	5 failures out of 6 samples 1 second/sample	Type B, 2 Trips
					No active DTCs:	PowertrainRelayStateOn_ FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Feedback Circuit High	P0690	This DTC is a check to determine if the Powertrain relay is functioning properly.	Powertrain Relay Voltage	>= 4.00 volts will increment the fail counter	Powertrain relay commanded "OFF" No active DTCs:	>= 2.00 seconds PowertrainRelayStateOn_ FA	50 failures out of 63 samples 100ms / Sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Low Voltage (ODM)	P0691	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short- to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0480 may also set (Fan 1 Open Circuit).

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit High Voltage (ODM)	P0692	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	on state (indicates short	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Low Voltage (ODM)	P0693	Diagnoses cooling fan 2 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short- to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0481 may also set (Fan 2 Open Circuit).

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit High Voltage (ODM)		Diagnoses the cooling fan 2 relay control low side driver circuit for circuit faults	Voltage high during driver on state (indicates short to power)	Short to power: $\leq 0.5 \Omega$ impedance between signal and controller power	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #3 Circuit		Detects a continuous or intermittent short on the 5 volt reference circuit #3		4.875 5.125 0.0495		Run/Crank voltage > 6.41	19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Control Module (FPCM) Requested MIL Illumination	P069E		Fuel Pump Control Module Emissions- Related DTC set			Time since power-up > 3 seconds	Continuous	Type A, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #4 Circuit	P06A3	Detects a continuous or intermittent short on the 5 volt reference circuit #4		4.875 5.125 0.0495		Run/Crank voltage > 6.41	19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 1 Performance	P06B6	This diagnostic checks for a fault with the internal test circuit used only for the '20 kHz' method of the Open Circuit Diagnostic	FFT Diagnostic Output	> OpenTestCktThrshMin and < OpenTestCktThrshMax See Supporting Tables	Diagnostic Enabled? Engine Run Time Engine Speed Cumlative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above) Engine Air Flow	Yes ≥ 2.0 seconds > 570 RPM and < 5,000 RPM ≥ 200 Revs ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient Weight Coefficient = 0.0100 Updated each engine event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Control Module (TCM) Requested MIL Illumination	P0700	Monitors the TCM MIL request line to determine when the TCM has detected a MIL illuminating fault.	Transmission Emissions- Related DTC set			Time since power-up > 3 seconds	Continuous	Type A, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Traction Control Torque Request Circuit	P0856	Determines if torque request from the EBTCM is valid	Serial Communication 2's complement message - (\$140 for PPEI2 or \$1C9 for PPEI3, \$1CA/\$1C6 for Hybrid))	Message <> 2's complement of message	Serial communication to EBTCM (U0108)	No loss of communication	Count of 2's complement values not equal >= 16	Type C, No MIL
					Power Mode Engine Running	= Run = True	Performed on every received message	
			OR Serial Communication message (\$140 for PPEI2 or \$1C9 for PPEI3, \$1CA/ \$1C6 for Hybrid)) rolling count value	Message rolling count value <> previous message rolling count value plus one	Status of traction in GMLAN message (\$4E9)	= Traction Present	6 rolling count failures out of 10 samples Performed on every received message	
			OR Too many minimum limit torque request transitions occur from TRUE to FALSE to TRUE within a time period	Requested torque intervention type toggles from not increasing request to increasing request			>= 3 multi- transitions out of 5 samples. Performed every 200 ms	
			Torque request greater than torque request diagnostic maximum threshold	<ul> <li>&gt; 250 Nm</li> <li>for engine based</li> <li>traction torque system,</li> <li>OR</li> <li>&gt; 1,000,000 Nm</li> <li>for axle based traction</li> <li>torque system</li> </ul>			>= 6 out of 10 samples Performed on every received message	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (naturally aspirated)	P1101	Determines if there are multiple air induction problems affecting airflow and/or manifold pressure.	Filtered Throttle Model Error AND (ABS(Measured Flow – Modeled Air Flow) Filtered OR ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 500 kPa*(g/s) > 15 grams/sec > 25.0 kPa ) > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	<ul> <li>&gt;= 400 RPM</li> <li></li></ul> <li><ul> <li>7,000 RPM</li> <li><ul> <li>7 Deg C</li> <li><ul> <li>125 Deg C</li> <li><ul> <li>&gt;= 0.25</li> </ul> </li> <li>Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM</li> <li>Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor Based on MAF Est</li> <li>MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM</li> <li>MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM</li> </ul></li></ul></li></ul></li>	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips
					No Active DTCs:	MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						IAT_SensorFA		
					No Pending DTCs:	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Low		Detects a continuous short to power in the Humidity Sensor circuit	Humidity Duty Cycle	<= 5.0 %	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit High	P11C3	Detects a continuous open or short to low in the Humidity Sensor circuit	Humidity Duty Cycle	>= 95.0 %	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Intermittent	P11C4	Detects a noisy or erratic humidity sensor input	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current Humidity reading - Humidity reading from 100 milliseconds previous)	> 120 % 10 consecutive Humidity samples	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	4 failures out of 5 samples Each sample takes 1.00 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Emissions Reduction System Fault	P1400	Model based test computes power from exhaust flow and thermal energy resulting from elevated idle speed and retarded spark advance. Detects if the cold start emission reduction system has failed resulting in the delivered power being out of range.	Average desired accumulated exhaust power - Average actual accumulated exhaust power (too much energy delivered to catalyst) Average desired accumulated exhaust power - Average actual accumulated exhaust power (too little energy delivered to catalyst) (EWMA filtered)	< -32.00 KJ/s (high RPM failure mode) > 6.50 KJ/s (low RPM failure mode)	To enable the diagnostic, the Cold Start Emission Reduction Strategy must be Active per the following: Catalyst Temperature AND Engine Coolant AND Barometric Pressure The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following: Catalyst Temperature AND Engine Run Time OR Engine Run Time OR Barometric Pressure Barometric Pressure	< 300.00 degC > -10.00 degC <= 40.00 degC >= 70.00 KPa >= 700.00 degC >= 30.00 seconds > CatalystLightOffExtende dEngineRunTimeExit This Extended Engine run time exit is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details. < 70.00 KPa	Runs once per trip when the cold start emission reduction strategy is active Frequency: 100ms Loop Test completes after 10 seconds of accumulated qualified data.	EWMA Based - Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					OBD Manufacturer Enable Counter	0		
					Vehicle Speed	< 1.2 MPH		
					Allow diagnostic to calculate residual in an off-idle state. If the value of the OffIdleEnable is equal to 1 then the "DriverOffAccelPedal" will not be checked. However, if the value of OffIdleEnable is 0 then driver must be off the accel pedal	0 (A value of 1 allows diagnostic to run and calculate the residual while off idle. A value of 0 requires calculation of the residual at idle)		
					A change in throttle position (tip-in/tip-out) will initiate a delay in the calculation of the average qualified residual value. Therefore: When the Pedal Close Delay Timer is : the diagnostic will continue the calculation.	> 5.00 seconds		
					For Manual Transmission vehicles:	Clutch Pedal Top of Travel Achieved and Clutch Pedal Bottom of Travel Achieved. Refer to the "Clutch Pedal Top of Travel Achieved criteria" and "Clutch Pedal Bottom of Travel Achieved criteria" section of the "Supporting Tables" tab criteria		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					The diagnostic will delay calculation of the residual value and potentially weight the residual calculation differently based on engine run time. This is to ensure the diagnostic is operating in idle speed control as well as during the peak catalyst light off period. The time weighting factor must be :	> 0 These are scalar values that are a function of engine run time. Refer to ColdStartDiagnosticDel ayBasedOnEngineRunTi me and the cal axis, ColdStartDiagnosticDel ayBasedOnEngineRunTi meCalAxis in the "Supporting Tables" for details.		
					General Enable:			
					DTC's Not Set:	AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFP CrankSensorFaultActive FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_F A Clutch Sensor FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA 5VoltReferenceMAP_OO R_FIt TransmissionEngagedStat e FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EngineTorqueInaccurate		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Engine Speed Request	P150C	Determines if engine speed request from the TCM is valid	Serial Communication rolling count value	+ 1 from previous \$19D message (PTEI3)	Diagnostic enable bit	1	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips
Circuit			Transmission engine speed protection	not equal to 2's complement of transmission engine speed request + Transmission alive rolling count	Engine run time	0.50 sec		
					# of Protect Errors	16 protect errors out of 10 samples		
					# of Alive Rolling Errors	5 rolling count errors out of 10 samples		
					No idle diagnostic 506/507 code	IAC_SystemRPM_FA		
					No Serial communication loss to TCM	(U0101)		
					Engine Running	= TRUE		
					Power mode	Run Crank Active		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Steady State Actuation Fault	P1516	Detect an inablity to maintain a steady state throttle position	The absolute difference between desired and indicated throttle position is >	2.00 percent		Run/Crank voltage > 6.41 Ignition voltage failure is false (P1682) TPS minimum learn is not active and Throttle is being Controlled Throttle is considered in a steadystate condition when the desired throttle position over a 12.5 ms period is < 0.25 percent for a settling time period > 4.00 s	0.49 ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation	P1682	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage & the Powertrain Relay Ignition Voltage	Run/Crank – PT Relay Ignition  >	3.00 Volts		Powertrain commanded on AND (Run/Crank voltage > Table, f(IAT). See supporting tables: PT Relay Pull-in Run/Crank Voltage f(IAT) OR PT Relay Ignition voltage > 5.50 ) AND Run/Crank voltage > 5.50.	240 / 480 counts or 0.1750 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Redundant Memory Performance	P16F3	Detect Processor Calculation faults due to RAM corruptions, ALU failures and ROM failures For all of the following cases: If the individual	Desired Throttle Area calculated does not equal its redundant calculation	N/A	Ignition State	Accessory, run or crank	ank Up/down timer 175 ms continuous, 0.5 down time multipier	Type A, 1 Trips
		cases: If the individual diagnostic threshold is equal to 2048 ms, this indivudual case is not applicable. If any of the following cases are X out of Y diagnostics and the fail (x) is greater than the sample (Y), this individual case is also	Equivance Ratio torque compensation exceeds threshold	-57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	-
	not applicable.	Absolute difference between Equivance Ratio torque compensation and its dual store out of bounds given by threshold	57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier		
		Absolute difference of Accessory torque and its redundant calculation is out of bounds given by threshold range	57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	_	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Filtered Air-per-cylinder and its redundant calculation is out of bounds given by threshold range	108.59 mg	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	-
			Absolute difference between the previous Final Advance and the current Final Advance not Adjusted for Equivalence Ratio is out of bounds given by threshold range	12.70 degrees		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	-
			Torque Learn offset is out of bounds given by threshold range	High Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold 0.00 Nm			multipier	
			One step ahead calculation of air-per- cylinder and two step ahead is greater than threshold	80.00 mg		Engine speed > 500 rpm	Up/down timer 428 ms continuous, 0.5 down time multipier	
			Difference between Unmanaged Spark and PACS Spark is greater than threshold	12.71 degrees	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded Predicted Engine Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multipier	
			Zero pedal axle torque is out of bounds given by threshold range	High Threshold 1,624.42 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Creep Coast Axle Torque is out of bounds given by threshold range	High Threshold 1,624.42 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Absolute difference of Friction torque and its redundant calculation is out of bounds given by threshold range	57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multipier	
			Arbitrated Air-Per-Cylinder filter coefficient is out of bounds given by threshold range	High Threshold 1.000 Low Threshold 0.074	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Launch spark is active but the launch spark redundant path indicates it should not be active	N/A		Engine speed < 7,800.00 or 7,900.00 rpm (hysteresis pair)	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Rate limited vehicle speed and its dual store do not equal	N/A		Time since first CAN message with vehicle speed >= 0.500 sec	10 / 20 counts; 25.0msec/count	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Preload Throttle Area and its dual store do not equal	N/A	Ignition State	Accessory, run or crank AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Commanded engine torque due to fast actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded engine torque due to slow actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			TOS to wheel speed conversion factor is out of bounds given by threshold	High Threshold: 1.10	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	

	range	T/C Range Hi 0.10 T/C Range Lo Low Threshold: 1.10 T/C Range Hi				
		1.10				
		T/C Range Hi				
		0.10 T/C Range Lo				
	TOS to wheel speed conversion factor and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	
	Cylinders active greater than commanded	2 cylinders		Engine run flag = TRUE > 2.00 s Number of cylinder events since engine run > 24	Up/down timer 128 ms continuous, 0.5 down time multipier	
		Cylinders active greater	conversion factor and its dual store do not equal         Cylinders active greater       2	conversion factor and its dual store do not equal         Cylinders active greater than commanded       2 cylinders	conversion factor and its dual store do not equal       and its dual store do not equal       and its dual store do not equal         Cylinders active greater than commanded       2       cylinders       Engine run flag = TRUE > 2.00 s         Number of cylinder events since engine run >       and cylinder events       since engine run >	conversion factor and its dual store do not equal       counts;       25.0msec/count         Cylinders active greater than commanded       2 cylinders       2 cylinders       Engine run flag = TRUE > 2.00 s Number of cylinder events since engine run > 24       Up/down timer 128 ms continuous, 0.5 down time multipier

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						active		
			Transfer case neutral request from four wheel drive logic does not match with operating conditions	N/A	Ignition State	Accessory, run or crank Transfer case range valid and not over-ridden FWD Apps only	32 / 6 counts; 25.0msec/count	
			Transfer case neutral and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	
			Driver progression mode and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Predicted torque for uncorrected zero pedal determination is greater than calculated limit.	Table, f(Engine, Oil Temp). See supporting tables + 57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Engine Predicted Request Without Motor is greater than its redundant calculation plus threshold	56.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Engine Immediate Request Without Motor is greater than its redundant calculation plus threshold	56.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Positive Torque Offset is greater than its redundant calculation plus threshold OR	57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Positive Torque Offset is less than its redundant calculation minus threshold					
			Commanded Predicted Engine Request is greater than its redundant calculation plus threshold	57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Hybrid Predicted Crankshaft Request is greater than its redundant calculation plus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Commanded Hybrid Immediate Crankshaft Request is less than its redundant calculation minus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Regeneration Brake	Brake Regen Assist <	Ignition State	Accessory, run or crank	Up/down timer	
			Assist is not within a specified range	0 Nm or Brake Regen Assist >	<b>U</b>		2,048 ms continuous,	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				0.00 Nm			0.5 down time multipier	
			Cylinder Spark Delta Correction exceeds the absolute difference as compared to Unadjusted Cylinder Spark Delta	12.71 degrees	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			1. Cylinder Torque Offset exceeds step size threshold OR	1. 57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			2. Sum of Cylinder Torque Offset exceeds sum threshold	2. 57.00 Nm				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Capacity Minimum Immediate Without Motor is greater than its dual store plus threshold	57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Engine Capacity Minimum Engine Off is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Engine Capacity Minimum Engine Immediate Without Motor is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Immediate Engine Request is greater than its redundant calculation plus threshold	57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	-
			PTO Torque Request exceeds allowed rate limited PTO Torque Request	7.13 Nm/25ms	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Engine Speed Lores Intake Firing (event based) calculation does not equal its redundant	N/A		Engine speed greater than 0rpm	Up/down timer 128 ms continuous, 0.5	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			calculation				down time multipier	
			Engine Speed Lores Intake Firing timing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Idle speed control calculated predicted minimum torque request exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: <b>Speed Control</b> <b>External Load f(Oil</b> <b>Temp, RPM)</b> + 57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Idle speed control calculated predicted minimum torque without reserves exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: <b>Speed Control</b> <b>External Load f(Oil</b> <b>Temp, RPM)</b> + 57.00	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Nm				
			Difference between Driver Requested Immediate Torque primary path and its secondary exceeds threshold	1,624.42 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Driver Immediate Request is less than its redundant calculation minus threshold	1,624.42 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded Immediate Request is greater than its redundant calculation plus threshold	1,624.42 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR Commanded Immediate Request is less than its redundant calculation minus threshold					
			Commanded Immediate Response Type is set to Inactive	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Difference between Cruise Axle Torque Arbitrated Request and Cruise Axle Torque Request exceeds threshold	203.05 Nm		Cruise has been engaged for more than 4.00 seconds	Up/down timer 2,048 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired engine torque request greater than redundant calculation plus threshold	56.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	-
			Engine min capacity above threshold	57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 138 ms continuous, 0.5 down time multipier	
			No fast unmanaged retarded spark above the applied spark plus the threshold	Table, f(RPM,APC). See supporting tables: Delta Spark Threshold f (RPM,APC)		Engine speed greater than 0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Absolute difference of adjustment factor based on temperature and its dual store above threshold	2.76 m/s	Ignition State	Accessory, run or crank	Up/down timer 228 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			1. Absolute difference of redundant calculated engine speed above threshold	1,403 RPM		Engine speed greater than 0 RPM	Up/down timer 128 ms continuous, 0.5 down time multipier	
			After throttle blade pressure and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Speed Control's Preditcted Torque Request and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine oil temperature and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 438 ms continuous, 0.5 down time multipier	
			Desired throttle position greater than redundant calculation plus threshold	8.60 percent	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference of the rate limited pre-throttle pressure and its redundant calculation greater than threshold	0.06 kpa	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Throttle desired torque above desired torque plus threshold	57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired filtered throttle torque exceeds the threshold plus the higher of desired throttle torque or modeled throttle torque	57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Torque feedback proportional term is out of allowable range or its dual store copy does not match	High Threshold 28.50 Nm Low Threshold -28.50 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Torque feedback integral term magnitude or rate of change is out of allowable range or its dual store	High Threshold 53.44 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			copy do not match	Low Threshold -57.00 Nm Rate of change threshold 3.56 Nm/loop			down time multipier	
			Difference of Final Torque feedback proportional plus integral term and its redundant calculation is out of bounds given by threshold range	High Threshold 57.00 Nm Low Threshold - 57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Difference of torque	High Threshold	Ignition State	Accessory, run or crank	Up/down timer	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			its redundant calculation is out of bounds given by threshold range	0.50 % Low Threshold - 0.50 %			ms continuous, 0.5 down time multipier	
			Difference of torque model coefficients and its redundant calculation is out of bounds given by threshold range	High Threshold 0.0002000 Low Threshold - 0.0002000	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Difference of base friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 57.00 Nm Low Threshold - 57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Accessory drive friction torque is out of bounds given by threshold range	High Threshold 57.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			AC friction torque is greater than commanded by AC control software or less than threshold limit	High Threshold 40.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Difference of Oil temperature delta friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold - 57.00 Nm				
			Generator friction torque is out of bounds given by threshold range	High Threshold 57.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Supercharger friction torque is out of bounds given by threshold range	High Threshold 57.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Filtered Torque error magnitude or its increase rate of change is out of allowable range or its dual store copy do not match	High Threshold 57.00 Nm Low Threshold -57.00 Nm Rate of change threshold 3.56 Nm/loop		Engine speed >0rpm MAF, MAP and Baro DTCs are false	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Torque error compensation is out of bounds given by threshold range	High Threshold 57.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Delta Torque Baro	High Threshold	Ignition State	Accessory, run or crank	Up/down timer	
			compensation is out of bounds given by threshold range	1.90 Nm Low Threshold			175 ms continuous, 0.5 down time multipier	
				-0.70 Nm				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<ol> <li>Difference of reserve torque value and its redundant calculation exceed threshold</li> <li>OR</li> <li>Reserve request does not agree with operating conditions or Difference of final predicted torque and its redundant calculation exeed threshold</li> <li>OR</li> <li>Rate of change of reserve torque exceeds threshold, increasing direction only</li> <li>OR</li> <li>Reserve engine torque above allowable capacity threshold</li> </ol>	1.56.00 Nm 2. N/A 3.56.00 Nm 4.56.00 Nm	3. & 4.: Ignition State	<ol> <li>&amp; 2.: Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) &gt; 57.00 Nm</li> <li>3. &amp; 4.: Accessory, run or crank</li> </ol>	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Engine Vacuum and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference of the calculated Intake Manifold Pressure during engine event versus during time	Table, f(Desired Engine Torque). See supporting tables: <b>Delta MAP Threshold</b>		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			event is greater than threshold	f(Desired Engine Torque)			down time multipier	
			Min. Axle Torque Capacity is greater than threshold	0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Driver Predicted Request is greater than its redundant calculation plus threshold OR	1,624.42 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Driver Predicted Request is less than its redundant calculation minus threshold					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Cold Delta Friction Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Predicted torque for zero pedal determination is greater than calculated limit.	Table, f(Oil Temp, RPM). See supporting tables: <b>Speed Control</b> <b>External Load f(Oil</b> <b>Temp, RPM)</b> + 57.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	-
			Commanded Predicted Axle Torque and its dual store do not match	1 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	-
			Steady State Estimated Engine Torque and its dual store are not equal	N/A		AFM not changing from Active to Inactive and preload torque not changing and one loop	Up/down timer 1,988 ms continuous, 0.5	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						after React command Engine speed >0rpm	down time multipier	
			Difference of Weighting factor for number of cylinders fueled and its redundant calculation is above threshold	0.26		Engine run flag = TRUE > 10.00 s	Up/down timer 175 ms continuous, 0.5 down time multipier	-
			Difference of minimum spark advance limit and its redundant calculation is out of bounds given by threshold range	12.70 degrees	Ignition State	Accessory, run or crank	Up/down timer 128 ms continuous, 0.5 down time multipier	-
			Difference of commanded spark advance and adjusted delivered is out of bounds given by threshold range	12.70 degrees		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference between Estimated Engine Torque and its dual store are above a threshold	57.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multipier	-
			Absolute difference between Estimated Engine Torque without reductions due to torque control and its dual store are above a threshold	57.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by threshold range	12.70 degrees		Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 57.00 Nm	Up/down timer 428 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Engine Capacity Minimum Running Immediate Brake Torque Excluding Cylinder Sensitivity and its redundant calculation is out of bounds given by threshold range	57.00 Nm		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multipier	
				Threshold: Dynamically calculated based on current engine conditions Fault Pending Threshold: 100 ms		Engine speed > 500 rpm	Up/down timer 428 ms continuous, 0.5 down time multipier	
			Rate limited cruise axle torque request and its dual store do not match within a threshold	203.05 Nm	Ignition State	Accessory, run or crank	Up/down timer 163 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			1. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its redundant calculation is out of bounds given by threshold range	1. 5.00 % 2. N/A 3. N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	-
			2. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its dual store do not equal					
			OR 3. Absolute difference of Calculated accelerator pedal position and its dual store do not equal					
			Commanded axle torque	1,624.42 Nm	Ignition State	Accessory, run or crank	Up/down timer	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			redundant calculation by threshold				ms continuous, 0.5 down time multipier	
			Commanded axle torque is less than its redundant calculation by threshold	-65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Preload timer and its redundant calculation do not equal	N/A	Ignition State	Accessory, run or crank AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			AC friction torque is greater than commanded by AC control software	40.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Engine Speed Lores	N/A		Engine speed >0rpm	Up/down timer	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Intake Firing (time based) calculation does not equal its redundant calculation				175 ms continuous, 0.5 down time multipier	
			Absolute difference of the calculated spark offset for equivalence ratio and its redundant cacluation is greater than a threshold	12.70 degrees		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Transmission Torque Request cacluations do not equal their dual stores	N/A		Run or Crank = TRUE > 0.50 s	16/32 counts; 25.0msec/count	-
			Absolute difference of the predicted motor torque ACS and its redundant cacluation is greater than a threshold	0.01 Nm			Up/down timer 2,048 ms continuous, 0.5 down time multipier	-
			Absolute difference of maximum throttle area and its redundant	15 mm2			Up/down timer 228 ms continuous,	]

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			cacluation is greater than a threshold				0.5 down time multipier	
			Absolute difference of Desired TIAP and its redundant cacluation is greater than a threshold	5.00 kPa			Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Stuck Open	P2070	Detects an Intake Manifold Tuning Valve that is stuck in the open position	Time after the close command without the Intake Manifold Tuning Valve reaching the closed position	>= 5.00 seconds	Intake Manifold Tuning Valve is commanded closed No Active DTCs:	P0660 P2077 P2078	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Stuck Closed	P2071	Detects an Intake Manifold Tuning Valve that is stuck in the closed position	Time after the open command without the Intake Manifold Tuning Valve reaching the open position	>= 5.00 seconds	Intake Manifold Tuning Valve is commanded closed No Active DTCs:	P0660 P2077 P2078	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Position Sensor/ Switch Circuit Range/ Performance	P2076	Detects an Intake Manifold Tuning Valve Actuator that has initiated its learn sequence for too long a period of time, or too many times per ignition cycle	Valve Position AND Valve Position for a time period OR Valve Position AND Valve Position for a time period	>= 5.0 % <= 35.0 % >= 5.0 % <= 35.0 % >= 0.2 seconds >= 10 times in one ignition cycle	Powertrain Relay Voltage Powertrain Relay Voltage Engine Run Time	>= 11.00 Volts <= 999.00 Volts >= 1.0 seconds	Executes every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Position Sensor/ Switch Circuit Low	P2077	Detects a continuous open or short to low in the Intake Manifold Tuning Valve Position Sensor circuit	Valve Position	>= 95.0 %	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Position Sensor/ Switch Circuit High		Detects a continuous short to high in the Intake Manifold Tuning Valve Position Sensor circuit	Valve Position	<= 5.0 %	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Low– Bank 1	P2088	, ,	commanded state of the driver and the actual state of the control circuit do not match.	Short to ground: $\leq 0.5 \Omega$ to a voltage source within the Vehicle Ground Voltage Range relative to PWRGND	System supply voltage is within limits. Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples250 ms / sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit High – Bank 1	P2089	Diagnoses the VVT system high side driver circuit for circuit faults.	driver off state (indicates short to power or open circuit)	Short to power: $\leq 0.5 \Omega$ impedance between signal and controller power Open Circuit: $\geq 200 \text{ K } \Omega$ impedance between signal and controller ground	System supply voltage is within limits. Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples250 ms / sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Low – Bank 1	P2090	, ,	driver and the actual state of the control circuit do not match.	$\leq 0.5 \Omega$ to a voltage	System supply voltage is within limits. Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples250 ms / sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit High – Bank 1	P2091	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: $\leq 0.5 \Omega$ impedance between signal and controller power Open Circuit: $\geq 200 \text{ K } \Omega$ impedance between signal and controller ground	System supply voltage is within limits. Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples250 ms / sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Low Limit Bank 1 (Too Rich)	P2096	Determines if the post catalyst O2 sensor based fuel control system has reached it's low limit authority, indicating a rich emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too rich, the post catalyst O2 integral offset control is decreased. This results in lean bias fuel control in an attempt to correct the rich post O2 voltage.	Rich Fail counter High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18 % for >= 1.0 seconds. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14 % for >= 5.0 seconds.	>= 350 counts per 500 sample counts Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration The following conditions must be true for > 1.0 seconds: Ambient Air Pressure Engine AirFlow Intake Manifold Pressure Induction Air Temperature Start-up Coolant Temp. PTO Intrusive diag. fuel control Long Term Secondary Fuel Trim Enabled (see "Long Term Secondary Fuel Trim Enable Criteria" in Supporting Tables)	No No No No >= 70 kPa >= 0.0 g/s <= 10,000.0 >= 0 kPa <= 200 >= -20 deg. C <= 200 >= -20 deg. C Not Active Not Active	Frequency: Continuous Monitoring in 100ms loop. Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips
					High Vapor Conditions No Fault Active for:	Not Present AmbientAirDefault AIR System FA Ethanol Composition Sensor FA ECT_Sensor_FA EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorFA CamSensorAnyLocationF A EvapEmissionSystem_FA		

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System	Code				The above general enable conditions must be true for: Minimum accumulated counts in each cell required before counters will increment: Deceleration Idle Cruise Light Acceleration Heavy Acceleration Fail counter will increment if sample counter increments AND	EvapFlowDuringNonPurg e_FA FuelTankPressureSnsrCkt _FA EvapPurgeSolenoidCircuit _FA EvapSmallLeak_FA EvapVentSolenoidCircuit_ FA FuelInjectorCircuit_FA MAF_SensorFA MAF_SensorFA MAF_SensorFA MAP_EngineVacuumStat us EngineMisfireDetected_F A A/F Imbalance Bank1 O2S_Bank_1_Sensor_1_ FA O2S_Bank_1_Sensor_2_ FA		
					Post oxygen sensor control integral offset (in			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					mV) is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Heavy Acceleration	<= 10 (control min.=0) 10 (control min.=0) -465 (control min.=-475) -465 (control min.=-475) -465 (control min.=-475) > 760 mV 760 mV 760 mV 760 mV 760 mV		

	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System High Limit Bank 1 (Too Lean)	P2097	Determines if the post catalyst O2 sensor based fuel control system has reached it's high limit authority, indicating a lean emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too lean, the post catalyst O2 integral offset control is increased. This results in rich bias fuel control in an attempt to correct the lean post O2 voltage.	Lean Fail counter High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18 % for >= 1.0 seconds. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14 % for >= 5.0 seconds.	>= 350 counts per 500 sample counts Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	Same as P2096 except for the following: Fail counter will increment if sample counter increments AND Post oxygen sensor control integral offset (in mV) is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Idle	>= 75 (control max.= 100) 75 (control max.= 100) 450 (control max.= 475) 450 (control max.= 475) 450 (control max.= 475) < 650 mV 650 mV 650 mV 650 mV 650 mV	Frequency: Continuous Monitoring in 100ms loop. Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Throttle Actuator Position Performance	Throttle control is driving the throttle in the incorrect direction3) Throttle control exceeds the reduced power limit Difference between modeled throttle	measured throttle position and modeled throttle position > OR Difference between modeled throttle position and measured throttle	8.00 percent 8.00 percent	TPS minimum learn is not active and Throttle is being Controlled and (Engine Running or Ignition Voltage > or Ignition Voltage > )	Run/Crank voltage > 6.41 Ignition voltage failure is false (P1682) TPS minimum learn is not active and Throttle is being Controlled AND ((Engine Running AND Ignition Voltage > 5.50 ) OR Ignition Voltage > 11.00 )	15 counts; 12.5 ms/count in the primary processor	Type A, 1 Trips	
		Throt	Throttle Position >	38.37 percent		Powertrain Relay voltage > 6.41 TPS minimum learn is active	11 counts; 12.5 ms/count in the primary processor	
			Throttle Position >	40.00 percent		Powertrain Relay voltage > 6.41 Reduced Power is True	11 counts; 12.5 ms/count in the primary processor	

Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
P2119	Throttle unable to return to default throttle position after de-	(Normalized TPS1 Voltage > AND	1.6470		Throttle de-energized for Actuator, Controller, or Ignition Faults (P21104,	0.4969 s	Type C, No MIL
energizing EIC motor.	> On the main processor)	1.7570 P2100, P2101, P2102, P2103, P1682, P0068, P16F3) No TPS circuit faults PT Relay Voltage > 5.500					
		OR			No 5V reference error or		
		(Normalized TPS1 Voltage <	1.1370No 5V reference error or fault for # 4 5V reference circuit (P06A3)				
		Normailzed TPS2 Voltage <	1.0270				
		· ,					-
			1.6470			1.5000 s	
		AND	1.7570				
		Normailzed TPS2 Voltage			TPS circuit faults PT		
		On the main processor)			Relay Voltage > 5.500		
	OR	1.1370		No 5V reference error or fault for # 4 5V reference circuit (P06A3)			
	(Normalized TPS1 Voltage < AND Normailzed TPS2 Voltage < On the main processor)	1.0270					
	Code	Code       P2119     Throttle unable to return to default throttle	Code       Throttle unable to return to default throttle position after de- energizing ETC motor.       (Normalized TPS1 Voltage > AND Normailzed TPS2 Voltage > On the main processor)         OR       (Normalized TPS1 Voltage < AND Normalized TPS1 Voltage < AND Normalized TPS1 Voltage < AND Normalized TPS2 Voltage > On the main processor)         (Normalized TPS1 Voltage < AND Normalized TPS2 Voltage  On the main processor)         (Normalized TPS1 Voltage > AND Normalized TPS1 Voltage > AND Normalized TPS2 Voltage  On the main processor)         (Normalized TPS1 Voltage > AND Normalized TPS1 Voltage > AND Normalized TPS2 Voltage > AND Normalized TPS1 Voltage > AND Normalized TPS1 Voltage > AND Normalized TPS1 Voltage > AND Normalized TPS1 Voltage > AND Normalized TPS1 Voltage > AND Normalized TPS1 Voltage > AND Normalized TPS1 Voltage > AND 	CodeImage: constraint of the second seco	Code     Image: Code service of the serv	Code         Image: constraint of the second se	Code </td

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Lo	P2122	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage <	0.4625		Run/Crank voltage > 6.41	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips
						No 5V reference error or fault for # 4 5V reference circuit (P06A3)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Hi	P2123	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage >	4.7500		Run/Crank voltage > 6.41	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips
						No 5V reference error or fault for # 4 5V reference circuit (P06A3)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Lo	P2127	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage <	0.3250		Run/Crank voltage > 6.41	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips
						No 5V reference error or fault for # 4 5V reference circuit (P0697)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Hi	P2128	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage >	2.6000		Run/Crank voltage > 6.41	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips
						No 5V reference error or fault for # 4 5V reference circuit (P0697)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position (TP) Sensor 1-2 Correlation	P2135	Detects a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor	Difference between TPS1 displaced and TPS2 displaced >	<ul> <li>7.022</li> <li>% offset at min. throttle position with a linear threshold to</li> <li>9.664</li> <li>% at max. throttle position</li> </ul>		Run/Crank voltage > 6.41 No TPS sensor faults (P0122, P0123, P0222, P0223) No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts or 58 counts continuous; 3.125 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min TPS1 ) and (normalized min TPS2) >	5.000 % Vref		Run/Crank voltage > 6.41 No TPS sensor faults (P0122, P0123, P0222, P0223) No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts or 58 counts continuous; 3.125 ms/count in the main processor	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1-2 Correlation	P2138	Detects a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor	Difference between APP1 displaced and APP2 displaced >	5.000 % offset at min. pedal position with a linear threshold to 10.001 % at max. pedal position		Run/Crank voltage > 6.41 No APP sensor faults (P2122, P2123,P2127, P2128) No 5V reference errors or faulst for # 3 & # 4 5V reference circuits (P06A3, P0697)	19/39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min APP1 ) and (normalized min APP2) >	5.000 % Vref		Run/Crank voltage > 6.41 No APP sensor faults (P2122, P2123,P2127, P2128) No 5V reference errors or faulst for # 3 & # 4 5V reference circuits (P06A3, P0697)	19/39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Vehicle Speed – Output Shaft Speed Correlation	P215B	Detect invalid vehicle speed source.	The absolute difference between wheel speed vehicle speed and TOS vehicle speed greater than > OR Secure vehicle speed source is unavailable	6.21 mph		Time since first CAN activity > 0.5000 s Secure vehicle speed source is TOS vehicle speed or wheel speed vehicle speed Trans engaged state is equal to engaged.	400 / 800 counts for wheel speed correlation or 400 / 800 counts for TOS correlation; 25ms/count	Type X, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Minimum Throttle Position Not Learned	P2176	TP sensors were not in the minmum learn window after multiple attempts to learn the minimum.	During TPS min learn on the Main processor, TPS Voltage > AND	0.9550		Run/Crank voltage > 6.41 TPS minimum learn is active	2.0 secs	Type A, 1 Trips
			Number of learn attempts >	10 counts				

SECTION 1 Initial DTCs 1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling System Performance	P2181	This DTC detects thermostat malfunction (i.e. stuck open)	Engine Coolant Temp (ECT) is ≤ commanded temperature minus 11 Deg C and normalized ratio is ≤ than 0.65. When above is present for more than 0 seconds, fail counts start. Engine total airgrams is accumulated when 11 ≤ AirFlow ≤ 100 grams per second. == Ratio Definition:=== Current temp difference between ECT and RCT minus PwrUp difference divided by total airgrams. Note: Minimum total airgrams is 500.0 grams.		No Active DTC's Engine not run time Engine run time Fuel Condition ECT at Power Up IAT min T-Stat Heater duty cycle commanded Airflow	MAF_SensorFA IAT_SensorFA THMR_RCT_Sensor_Ckt _FA THMR_ECT_Sensor_Ckt _FA ≥ 7,200 seconds $120 \le \text{Time} \le 1,400$ seconds Ethanol ≤ 100 % -40.0 ≤ ECT ≤ 45.0 °C -7 °C ≤ IAT ≤ 60 °C. ≤ 10 % $11.0 \le \text{Airflow} \le 100.0 \text{ gps}$	225 failures out of 280 samples 1 sec/ sample Once per ignition key cycle	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric I Pressure (BARO) Sensor Performance (naturally aspirated)	P2227	Compares baro sensor to the calculated baro estimate (part throttle calculation or unthrottled MAP)	Difference between baro sensor reading and estimated baro when distance since last estimated baro update OR Difference between baro sensor reading and estimated baro when distance since last estimated baro update	<ul> <li>&gt; 15.0 kPa</li> <li>&lt;= 0.06 miles</li> <li>&gt; 20.0 kPa</li> <li>&gt; 0.06 miles</li> </ul>	Engine Run Time No Active DTCs:	> 0.00 seconds AmbPresSnsrCktFA ECT_Sensor_Ckt_FA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips
			Barometric Pressure OR Barometric Pressure	< 50.0 kPa > 115.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating No Active DTCs: No Pending DTCs:	<ul> <li>&gt; 6.0 seconds</li> <li>EngineModeNotRunTimer Error MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA</li> <li>MAP_SensorCircuitFP AAP_SnsrCktFP AAP2 SnsrCktFP</li> </ul>	<ul> <li>4 failures out of</li> <li>5 samples</li> <li>1 sample every</li> <li>12.5 msec</li> </ul>	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (non- boosted applications)	P2228	Detects a continuous short to low or open in either the signal circuit or the BARO sensor.	BARO Voltage	< 40.0 % of 5 Volt Range (2.0 Volts = 50.9 kPa)	Engine Run Time	> 0.00 seconds	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (non- boosted applications)	P2229	Detects an open sensor ground or continuous short to high in either the signal circuit or the BARO sensor.	BARO Voltage	> 90.0 % of 5 Volt Range (4.5 Volts = 115.0 kPa)	Engine Run Time	> 0.00 seconds	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Intermittent	P2230	Detects a noisy or erratic barometric pressure input	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current BARO reading - BARO reading from 12.5 milliseconds previous)	<ul> <li>&gt; 40 kPa</li> <li>5 consecutive BARO samples</li> </ul>	No Active DTCs:	AmbPresSnsrCktFA ECT_Sensor_Ckt_FA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA	10 failures out of 15 samples Each sample takes 0.06 seconds	Type B, 2 Trips

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Lean Bank 1 Sensor 2	P2270	This DTC determines if the post catalyst O2 sensor is stuck in a normal lean voltage range and thereby can no longer be used for post oxygen sensor fuel control or for catalyst monitoring. The diagnostic is an intrusive test (during coast) which increases the delivered fuel to achieve the required rich threshold.	Post O2 sensor signal AND The Accumulated mass air flow monitored during the Stuck Lean Voltage Test	< 775 mvolts	No Active DTC's B1S2 DTC's Not active this key cycle System Voltage ICAT MAT Burnoff delay Green O2S Condition	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013A, P013B, P013E, P013F, P2270 or P2271 10.0 < Volts < 32.0 = Not Valid = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips
					Low Fuel Condition Diag Pedal position	= False ≤ 3.0 %		
					Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)	1,500 ≤ RPM ≤ 2,800 1,400 ≤ RPM ≤ 2,900		
					Engine Airflow	2≤gps≤20		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Vehicle Speed to initially enable test Vehicle Speed range to	43.5≤ MPH ≤68.4		
					keep test enabled (after initially enabled)	40.4 ≤ MPH ≤ 71.5		
					Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State ===================================	$0.92 \le C/L$ Int $\le 1.08$ = TRUE not in control of purge not in estimate mode = enabled = not active $\ge 40.0 \sec$ $550 \le ^{\circ}C \le 900$ = DFCO possible		
					requested. ====================================			

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Rich Bank 1 Sensor 2	P2271	This DTC determines if the post catalyst O2 sensor is stuck in a normal rich voltage range and thereby can no longer be used for post oxygen sensor fuel control or for catalyst monitoring. The diagnostic is an intrusive test which requests the DFCO mode to achieve the required lean threshold.	Post O2 sensor signal AND The Accumulated mass air flow monitored during the Stuck Rich Voltage Test	> 100 mvolts > 30 grams	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage ICAT MAT Burnoff delay Green O2S Condition	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013A, P013B, P013E, P013F or P2270 10.0 < Volts < 32.0 = Not Valid = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips
					Low Fuel Condition Diag Engine Speed Engine Airflow Vehicle Speed Closed loop integral Closed Loop Active	= False 1,500 ≤ RPM ≤ 2,800 2 ≤ gps ≤ 20 43.5 ≤ MPH ≤ 68.4 0.92 ≤ C/L Int ≤ 1.08 = TRUE		
					Evap Ethanol Post fuel cell	not in control of purge not in estimate mode = enabled		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Take Off EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State DTC's Passed ===================================	<ul> <li>= not active</li> <li>= not active</li> <li>= not active</li> <li>≥ 40.0 sec</li> <li>550 ≤ °C ≤ 900 DFCO possible</li> <li>= P2270 (and P2272 if applicable)</li> <li>= P013E (and P014A if applicable)</li> <li>= P013A (and P013C if applicable)</li> <li>====================================</li></ul>		

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Control Torque Request	P2544	Determines if the torque request from the TCM is valid	Protect error - Serial Communication message - (\$199 - PTEI3)	Message <> two's complement of message	Diagnostic enabled/ disabled	Enabled	>= 16 Protect errors during key cycle.	Type B, 2 Trips
Circuit			OR		Power Mode	= Run	Performed on every received message	
			Rolling count error - Serial Communication message (\$199 - PPEI3) rolling count value	Message <> previous message rolling count value + one	Ignition Voltage	> 6.41 volts	>= 6 Rolling count errors out of 10 samples.	
		OR		Engine Running Run/Crank Active	= True > 0.50 Sec	Performed on every received message		
			Range Error - Serial Communication message - (\$199 - PTEI3) TCM Requested Torque Increase	> 450 Nm	No Serial communication loss to TCM (U0101)	No loss of communication	>= 6 range errors out of 10 samples. Performed on every received message	
			OR Multi-transition error - Trans torque intervention type request change	Requested torque intervention type toggles from not increasing request to increasing request			>= 4 multi- transitions out of 5 samples. Performed every 200 msec	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM/PCM Internal Engine Off Timer Performance	P2610	This DTC determines if the hardware timer does not initialize or count properly. There are two tests to ensure proper functioning of the timer: Count Up Test (CUT) and Range Test (RaTe). Count Up Test (CUT): Verifies that the HWIO timer is counting up with the proper increment.	Count Up Test: Time difference between the current read and the previous read of the timer	> 1.50 seconds			Count Up Test: 4 failures out of 20 samples 1 sec / sample Continuous while run/crank is not active and until controller shutdown is initiated.	Type B, 2 Trips
		Range Test (RaTe): When the run/crank is not active both the hardware and mirror timers are started. The timers are compared when ECM shutdown is initiated or run/crank becomes active.	Range Test: The variation of the HWIO timer and mirror timer is	> 25 %.			Range Test: Once per trip when controller shutdown is initiated or run/ crank becomes active.	

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Low	P263A	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short- to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11 volts	20 failures out of 25 samples 250 ms / sample	Type A, No MIL NO MIL Note: In certain controlle rs P0650 may also set (MIL Control Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) High	P263B	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11 volts	20 failures out of 25 samples 250 ms / sample	Type A, No MIL NO MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communicati on Bus A Off	U0073	This DTC monitors for a BUS A off condition	Bus off failures exceeds before the sample time of is reached	5 counts (equivalent to 0.06 seconds) 0.56 seconds	General Enable Criteria:U0073Normal CAN transmission on Bus ADevice ControlHigh Voltage Virtual Network ManagementIgnition Voltage Criteria:Ignition voltagePower ModeOff Cycle Enable Criteria:KeCAND_b_OffKeyCycle DiagEnblIgnition Accessory Line and Battery VoltageGeneral Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria and either Ignition Voltage Criteria met for > 3.0000 secondsCAN hardware is bus OFF for	Not Active on Current Key Cycle Enabled Not Active Not Active >= 11.00 or >= 6.41 = run = 1 ( 1 indicates enabled) = Active > 11.00	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With TCM	U0101	This DTC monitors for a loss of communication with the transmission control module	Message is not received from controller for Message \$0AB Message \$0BD Message \$0C7 Message \$0F9 Message \$189 Message \$190 Message \$19D Message \$1AF Message \$1BE Message \$1BF Message \$1F5 Message \$4C9	<ul> <li>≥ 10.0 seconds</li> </ul>	General Enable Criteria:U0073Normal CAN transmission on Bus ADevice ControlHigh Voltage Virtual Network ManagementIgnition Voltage Criteria:Ignition voltagePower ModeOff Cycle Enable Criteria:KeCAND_b_OffKeyCycle DiagEnblIgnition Accessory Line and Battery VoltageGeneral Enable Criteria and either Ignition VoltageGeneral Enable Criteria and either Ignition VoltagePower Mode is in accessory or run or crank and High Voltage Virtual Network Management is	Not Active on Current Key Cycle Enabled Not Active Not Active >= 11.00 or >= 6.41 = run = 1 (1 indicates enabled) = Active > 11.00	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				not active for	> 0.4000 seconds		
				U0101	Not Active on Current Key Cycle		
				тсм	is present on the bus		
	Fault Code	Fault Code       Monitor Description         Image: Code       Image: Code         Image: Code       Image: Cod	Fault Code       Monitor Description       Malfunction Criteria         Image: Code       Image: Code       Image: Code       Image: Code         Image: Code       Image: Code       Image: Code       Image: Code       Image: Code         Image: Code       Image: Code       Image: Code       Image: Code       Image: Code       Image: Code         Image: Code       Image:	Fault Code       Monitor Description       Malfunction Criteria       Threshold Value         Image: Code       Image: Code       Image: Code       Image: Code       Image: Code         Image: Code       Image: Code       Image: Code       Image: Code       Image: Code       Image: Code         Image: Code       Image: Code       Image: Code       Image: Code       Image: Code       Image: Code         Image: Code       Image: Code       Image: Code       Image: Code       Image: Code       Image: Code       Image: Code         Image: Code       Image:	U0101	Image: Not active for       > 0.4000 seconds         U0101       Not Active on Current Key Cycle	not active for     > 0.4000 seconds       U0101     Not Active on Current Key Cycle

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Fuel Pump Control Module	U0109	This DTC monitors for a loss of communication with the fuel pump control module	Message is not received from controller for Message \$1EB Message \$4D9	≥ 10.0 seconds ≥ 10.0 seconds	General Enable Criteria:         U0073         Normal CAN transmission on Bus A         Device Control         High Voltage Virtual Network Management         Ignition Voltage Criteria:         Ignition voltage         Power Mode         Off Cycle Enable Criteria:         Ignition Accessory Line and Battery Voltage         General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds         Power Mode is in accessory or run or crank and High Voltage Virtual	Not Active on Current Key Cycle Enabled Not Active Not Active >= 11.00 or >= 6.41 = run = 1 (1 indicates enabled) = Active > 11.00	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					not active for	> 0.4000 seconds		
					U0109	Not Active on Current Key Cycle		
					Fuel Pump Control Module	is present on the bus		
I								

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Anti- Lock Brake System (ABS) Control Module	U0121	This DTC monitors for a loss of communication with the Anti-Lock Brake System (ABS) Control Module (Non-OBD Module ID 243).	Message is not received from controller for Message \$0C1 Message \$0C5 Message \$0D1 Message \$1C6 Message \$1C7 Message \$1E9 Message \$2F1	<ul> <li>≥ 10.0 seconds</li> </ul>	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Ignition voltage	Not Active on Current Key Cycle Enabled Not Active Not Active >= 11.00 or	Diagnostic runs in 12.5 ms loop	Type C, No MIL "Special Type C"
			Message \$2F9	≥ 10.0 seconds	<ul> <li>Power Mode</li> <li>Off Cycle Enable Criteria:</li> <li>KeCAND_b_OffKeyCycle DiagEnbl</li> <li>Ignition Accessory Line and Battery Voltage</li> <li>General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for &gt; 3.0000 seconds</li> <li>Power Mode is in accessory or run or crank and High Voltage Virtual</li> </ul>	>= 6.41 = run = 1 (1 indicates enabled) = Active > 11.00		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Network Management is not active for	> 0.4000 seconds		
					U0121	Not Active on Current Key Cycle		
					Anti-Lock Brake System Control Module	is present on the bus		

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Body Control Module	U0140	This DTC monitors for a loss of communication with the Body Control Module.	Message is not received from controller for Message \$0F1 Message \$12A Message \$1E1 Message \$1F1 Message \$1F3 Message \$3C9 Message \$3C9 Message \$3F1 Message \$451 Message \$451 Message \$4E1 Message \$4E9	<ul> <li>≥ 10.0 seconds</li> </ul>	General Enable Criteria:U0073Normal CAN transmission on Bus ADevice ControlHigh Voltage Virtual Network ManagementIgnition Voltage Criteria:Ignition voltagePower ModeOff Cycle Enable Criteria:KeCAND_b_OffKeyCycle DiagEnblIgnition Accessory Line and Battery VoltageGeneral Enable Criteria and either Ignition VoltageGeneral Enable Criteria and either Ignition VoltagePower Mode is in accessory or run or crank and High Voltage Virtual Network Management is	Not Active on Current Key Cycle Enabled Not Active Not Active >= 11.00 or >= 6.41 = run = 1 (1 indicates enabled) = Active > 11.00	Diagnostic runs in 12.5 ms loop	Type C, No MIL "Special Type C"

#### SECTION 1 Initial DTCs 1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					not active for			
					U0140	Not Active on Current Key Cycle		
					Body Control Module	is present on the bus		

SECTION 2 Unique DTCs 2 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Output Speed Sensor (TOSS)	P0502	No activity in the TOSS circuit	TOSS Raw Speed	≤ 60 RPM	Engine TorqueMinimum Throttle openingEngine Speed Ignition voltage PTO EngineTorqureInaccurate	90.0 ≤ N-M ≤ 8,191.8 ≥ 15.0 % 1,500 ≤ RPM ≤ 6,500 9.0 ≤ Volts ≤ 16.00 not active KeETQC_b_MinTransRe medial = TRUE: MSFR_b_EngMisfDtctd_F A, MAFR_b_MAF_SnsrTFT KO, MAPR_b_MAP_SnsrTFT KO	≥ 4.5 sec	Type B, 2 Trips
					P0503	KeETQC_b_MinTransRe medial = FALSE: FULR_b_FueIInjCkt_TFT KO, MAFR_b_MAF_SnsrTFT KO, XOYR_b_SecurityFlt, Not failed this key cycle		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Output Speed Sensor (TOSS)	P0503	TOSS Signal Intermittent	Loop-to-Loop change in TOSS	≥ 350 RPM	Raw Output Speed Output Speed change Time since transfer case range change Ignition voltage Engine Speed Vehicle Speed PTO	> 200 RPM for ≥ 2.0 sec ≤ 150 RPM for ≥ 2.0 sec ≥ 3.0 sec 9.0 ≤ Volts ≤ 16.00 200 ≤ RPM ≤ 7,500 for ≥ 5.0 seconds ≤ 250.00 MPH for ≥ 5.0 sec not active	≥ 3.3 sec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Range / Performance	P0806	Detects if Clutch Pedal Position Sensor is Stuck in a range indicative of a vehicle NOT in gear, when the vehicle is determined to be in gear. Gear determination is made by verifying that the ratio of engine RPM versus Transmission Output Speed (N/TOS) represents a valid gear.	Filtered Clutch Pedal Position Error when the vehicle is determined to be in gear	> 3 %	N/TOS Ratio: Transfer Case: Vehicle speed: Engine Torque: Clutch Pedal Position: OR No Active DTCs:	Must match actual gear (i.e. vehicle in gear) Not in 4WD Low range > 18.6 MPH > EngTorqueThreshold (see Supporting Tables) < ResidualErrEnableLow (see Supporting Tables) > ResidualErrEnableHigh (see Supporting Tables) ClutchPstnSnsrCktHi FA ClutchPstnSnsrCktLo FA CrankSensor_FA Transmission Output Shaft Angular Velocity Validity VehicleSpeedSensor_FA	25 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Low	P0807	Detects Continuous Circuit Out-of-Range Low or Open	Clutch Position Sensor Circuit for		Engine Not Cranking System Voltage No active DTCs:	> 9.0 Volts	25 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit High	P0808	Detects Continuous Circuit Out-of-Range High	Clutch Position Sensor Circuit for		Engine Not Cranking System Voltage No active DTCs:	> 9.0 Volts	25 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Clutch Pedal Position Not Learned	P080A	Detects Invalid Clutch Pedal Fully Applied Learn Position values	Fully Applied Learn Position OR	< 12.0 % > 35.0 %	OBD Manufacturer's Enable Counter	= 0	250 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve Control Circuit	P0033	Detect Turbocharger Bypass Valve - Open Circuit	ECM detects that commanded and actual states of output driver do not match because the output is open circuit		Diagnostic Enabled EnabledPowertrain relay Voltage Ignition run crank voltage Engine is not cranking	1 >= 11.00 Volts >= 5.00 Volts	10 failures out of 20 samples 1 sample every 100ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve Control Circuit Low	P0034	Detect Turbocharger Bypass Valve - Shorted to Ground	ECM detects that commanded and actual states of output driver do not match because the output is shorted to ground		Diagnostic Enabled EnabledPowertrain relay Voltage Ignition run crank voltage Engine is not cranking	1 >= 11.00 Volts >= 5.00 Volts	10 failures out of 20 samples 1 sample every 100ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve Control Circuit High	P0035	Detect Turbocharger Bypass Valve - Shorted to Power	ECM detects that commanded and actual states of output driver do not match because the output is shorted to power		Diagnostic Enabled EnabledPowertrain relay Voltage Ignition run crank voltage Engine is not cranking	1 >= Volts 11.00 >= 5.00 Volts	10 failures out of 20 samples 1 sample every 100ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Pressure Measuremen t System -	P00C7	Detects an inconsistency between pressure sensors in the induction system in	ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost	> 10.0 kPa	Time between current ignition cycle and the last time the engine was running	> 10.0 seconds	4 failures out of 5 samples 1 sample every	Type B, 2 Trips
Multiple Sensor Correlation		which a particular sensor cannot be identified as the failed	Pressure - Manifold Pressure) AND	<= 10.0 kPa	Engine is not rotating		12.5 msec	
(turbocharge d)		sensor	ABS(Turbocharger Boost Pressure - Baro Pressure) OR	<= 10.0 kPa	Manifold Pressure Manifold Pressure Baro Pressure Baro Pressure	>= 50.0 kPa <= 115.0 kPa >= 50.0 kPa <= 115.0 kPa		
			ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost	<= 10.0 kPa	Turbocharger Boost Pressure Turbocharger Boost Pressure	>= 50.0 kPa <= 115.0 kPa		
			Pressure - Manifold Pressure) AND ABS(Turbocharger Boost	> 10.0 kPa	No Active DTCs:	EngineModeNotRunTimer Error MAP_SensorFA AAP_SnsrFA		
			Pressure - Baro Pressure) OR	<= 10.0 kPa	No Pending DTCs:	AAP2_SnsrFA MAP_SensorCircuitFP		
			ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost	<= 10.0 kPa		AAP_SnsrCktFP AAP2_SnsrCktFP		
			Pressure - Manifold Pressure) AND	<= 10.0 kPa				
			ABS(Turbocharger Boost Pressure - Baro Pressure)	> 10.0 kPa				
			OR					
			ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold	> 10.0 kPa				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	> 10.0 kPa > 10.0 kPa				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (turbocharge d)	P0101	Determines if the MAF sensor is stuck within the normal operating range	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC. MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error	<ul> <li>&gt; 16 grams/sec</li> <li>&gt; 20.0 kPa</li> <li>&gt; 25.0 kPa</li> <li>&gt; 25.0 kPa</li> <li>&gt; 25.0 kPa</li> <li>&gt; 25.0 kPa</li> </ul>	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	<ul> <li>&gt;= 400 RPM</li> <li>= 6,000 RPM</li> <li>-7 Deg C</li> <li>&lt; 125 Deg C</li> <li>-20 Deg C</li> <li>&gt; -20 Deg C</li> <li>&lt; 100 Deg C</li> </ul> >= 0.50 Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips
			TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed	> 25.0 kPa		TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			See table "TIAP-MAP Correlation Offset" OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset"	> 25.0 kPa	No Active DTCs:	See "Residual Weight Factor" tables. MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault		
			TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time	> 2.0 seconds > 2.0 seconds	No Pending DTCs:	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP		
			High Engine Air Flow is TRUE when Mass Air Flow AND Manifold Pressure AND	<ul> <li>&gt; a threshold in gm/sec as a function of engine speed See table "TIAP-MAP Correlation Min Air Flow"</li> <li>&gt; a threshold in kPa as a function of engine speed See table "TIAP-MAP Correlation Min MAP"</li> </ul>				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Filtered Mass Air Flow - Mass Air Flow	< 2.0 gm/sec				
			Low Engine Air Flow is TRUE when Mass Air Flow	< a threshold in gm/sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow"				
			AND Manifold Pressure	< a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP"				
			AND Mass Air Flow - Filtered Mass Air Flow	< 2.0 gm/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (turbocharge d)	P0106	Determines if the MAP sensor is stuck within the normal operating range	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC. MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table "TIAP-MAP	<ul> <li>&gt; 16 grams/sec</li> <li>&gt; 20.0 kPa</li> <li>&gt; 25.0 kPa*(g/s)</li> </ul>	Engine Speed Engine Speed Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	<ul> <li>&gt;= 400 RPM</li> <li>= 6,000 RPM</li> <li>-7 Deg C</li> <li>125 Deg C</li> <li>-20 Deg C</li> <li>100 Deg C</li> <li>&gt;= 0.50</li> <li>Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est</li> <li>MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM</li> <li>MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM</li> <li>MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM</li> <li>TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM</li> <li>TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM</li> <li>Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM</li> </ul>	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Correlation Offset" OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset" TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time High Engine Air Flow is TRUE when Mass Air Flow	> 25.0 kPa > 2.0 seconds	No Active DTCs:	See "Residual Weight Factor" tables. MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault EGRValve_FP ECT_SensorCircuitFP MnfdTempSensorCktFP		
			AND Filtered Mass Air Flow - Mass Air Flow	< 2.0 gm/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Low Engine Air Flow is TRUE when Mass Air Flow	< a threshold in gm/sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow"				
			AND Manifold Pressure	< a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP"				
			AND Mass Air Flow - Filtered Mass Air Flow	< 2.0 gm/sec				
			Manifold Pressure OR Manifold Pressure OR	< 50.0 kPa > 115.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating	> 10.0 seconds	<ul><li>4 failures out of</li><li>5 samples</li><li>1 sample every</li><li>12.5 msec</li></ul>	
			ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND	> 10.0 kPa > 10.0 kPa	No Active DTCs:	EngineModeNotRunTimer Error MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA		
			ABS(Turbocharger Boost Pressure - Baro Pressure)	<= 10.0 kPa	No Pending DTCs:	MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (turbocharge d)	P0121	Determines if the Throttle Position Sensor input is stuck within the normal operating range	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC. MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table "TIAP-MAP	<ul> <li>&gt; 16 grams/sec</li> <li>&gt; 20.0 kPa</li> <li>&gt; 25.0 kPa</li> <li>&gt; 25.0 kPa</li> <li>&gt; 25.0 kPa</li> <li>&gt; 250 kPa*(g/s)</li> </ul>	Engine Speed Engine Speed Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	<ul> <li>&gt;= 400 RPM</li> <li>= 6,000 RPM</li> <li>-7 Deg C</li> <li>&lt; 125 Deg C</li> <li>-20 Deg C</li> <li>&lt; 100 Deg C</li> <li>&gt;= 0.50</li> <li>Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est</li> <li>MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM</li> <li>MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM</li> <li>MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM</li> <li>TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM</li> <li>TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM</li> <li>TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM</li> <li>Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM</li> </ul>	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Jystelli	Code		Correlation Offset" OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset" TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time	> 2.0 seconds	No Active DTCs:	See "Residual Weight Factor" tables. MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP		
			High Engine Air Flow is TRUE when Mass Air Flow AND Manifold Pressure	<ul> <li>&gt; a threshold in gm sec as a function of engine speed</li> <li>See table "TIAP-MAP Correlation Min Air Flow"</li> <li>&gt; a threshold in kPa as a function of engine speed</li> <li>See table "TIAP-MAP Correlation Min MAP"</li> </ul>				
			AND Filtered Mass Air Flow - Mass Air Flow	< 2.0 gm/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Low Engine Air Flow is TRUE when Mass Air Flow AND Manifold Pressure AND Mass Air Flow - Filtered Mass Air Flow	< a threshold in gm sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow" < a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP" < 2.0 gm/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Engine Overboost Turbocharge r with wastegate. Not supercharge r with mechanical compressor	P0234	Detect Negative Boost Pressure Control Deviation	Desired Boost Pressure - Actual Boost Pressure	< (KtBSTD_p_CntrlDevN egLim - KtBSTD_p_CntrlDevA mbAirCorr) See Tables in Supporting Tables Sheet	Diagnostic Enabled Engine Speed Engine Speed Desired Boost Pressure Desired Boost Pressure Derivative Desired Boost Pressure Derivative Ambient Pressure Ambient Pressure Coolant Temp Intake Air Temp Intake Air Temp Wait for steady state:	1 > 2,450 rpm < 6,000 rpm > 135.0 kPa < 220.0 kPa < 220.0 kPa > -70.0 kPa/s < 55.0 kPa/s > 60.0 kPa < 120.0 kPa < 120.0 Deg C < 120.0 Deg C < 40.0 Deg C < 40.0 Deg C < 80.0 Deg C > -40.0 Deg C > -40.0 Deg C > by the set of th	20 failures out of 20 samples 1 sample every 100ms	Type B, 2 Trips
						AmbientAirDefault_Snsr BSTR_b_PCA_CktFA BSTR_b_TurboBypassCkt FA ECT_Sensor_FAIAT_Sen		

#### SECTION 2 Unique DTCs 2 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Active DVCs:	sorFA BSTR_b_ExcsvBstTFTK O BSTR_b_PCA_CktTFTK O TC_BoostPresSnsrFA AnyCamPhaser_FA BSTR_b_PresCntrlTooLo TFTKO BSTR_b_PresCntrlTooHiT FTKO EnginePowerLimited BSTR_b_DVC_PCA_DC_ Actv BSTR_b_DVC_PCA_Pstn Actv BSTR_b_DVC_TurboCom prBypActv		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r Boost Pressure (TIAP) Sensor Performance	P0236	Determines if the Turbocharger Boost (TIAP) Pressure Sensor input is stuck within the normal operating range	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC. MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP - TIAP Model 1) Filtered TIAP1 model fails when ABS(Measured TIAP - TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table "TIAP-MAP Correlation Offset"	<ul> <li>&gt; 16 grams/sec</li> <li>&gt; 20.0 kPa &gt; 25.0 kPa</li> <li>&gt; 25.0 kPa</li> <li>&gt; 25.0 kPa</li> <li>&gt; 250 kPa*(g/s)</li> <li>&gt; 25.0 kPa</li> </ul>	Engine Speed Engine Speed Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	<ul> <li>&gt;= 400 RPM</li> <li>= 6,000 RPM</li> <li>-7 Deg C</li> <li>125 Deg C</li> <li>-20 Deg C</li> <li>100 Deg C</li> <li>&gt;= 0.50</li> <li>Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est</li> <li>MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM</li> <li>MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM</li> <li>MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM</li> <li>TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM</li> <li>TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM</li> <li>Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM</li> </ul>	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

# SECTION 2 Unique DTCs 2 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset"	> 25.0 kPa	No Active DTCs:	See "Residual Weight Factor" tables. MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA		
			TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time	> 2.0 seconds	No Pending DTCs:	TC_BoostPresSnsrCktFA AmbientAirDefault EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP		
			High Engine Air Flow is TRUE when Mass Air Flow	> a threshold in gm/sec as a function of engine speed See table "TIAP-MAP Correlation Min Air Flow"				
			AND Manifold Pressure	> a threshold in kPa as a function of engine speed See table "TIAP-MAP Correlation Min MAP"				
			AND Filtered Mass Air Flow - Mass Air Flow	< 2.0 gm/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Low Engine Air Flow is TRUE when Mass Air Flow	< a threshold in gm/sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow"				
			AND Manifold Pressure	< a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP"				
				< 2.0 gm/sec				
			AND Mass Air Flow - Filtered Mass Air Flow					
			Turbocharger Boost Pressure OR	< 50.0 kPa	Time between current ignition cycle and the last time the engine was		4 failures out of 5 samples	
			Turbocharger Bosst Pressure	> 115.0 kPa	running Engine is not rotating	> 10.0 seconds	1 sample every 12.5 msec	
			OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost	<= 10.0 kPa	No Active DTCs:	EngineModeNotRunTimer Error MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA		
			Pressure - Manifold Pressure) AND ABS(Turbocharger Boost	> 10.0 kPa	No Pending DTCs:	MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP		
			Pressure - Baro Pressure)	> 10.0 kPa				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r Boost Pressure Sensor Circuit Low		Detects a continuous short to low or open in either the signal circuit or the turbocharger boost pressure sensor.		< 17.0 % of 5 Volt Range (This is equal to 0.85 Volts, or 49.6 kPa)	Engine Run Time	> 0.00 seconds	80 failures out of 100 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r Boost Pressure Sensor Circuit High	P0238	Detects an open sensor ground or continuous short to high in either the signal circuit or the turbocharger boost pressure sensor.		> 78.0 % of 5 Volt Range (This is equal to 3.90 Volts, or 250.6 kPa)	Engine Run Time	> 0.00 seconds	80 failures out of 100 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r	P0243	Detect Turbocharger Boost Solenoid -Open	ECM detects that commanded and actual		Diagnostic Enabled	1	10	Type B, 2 Trips
Wastegate / Supercharge		Circuit	states of output driver do not match because the		Powertrain relay voltage	>= 11.00 Volts	failures out of 20	
r Boost			output is open circuit		Ignition run crank voltage			
Solenoid A Control					Engine is not cranking	>= 5.00 Volts	samples	
Circuit							1 sample every 100ms	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r Wastegate / Supercharge r Boost Solenoid A Control	P0245	Detect Turbocharger Boost Solenoid - Shorted to ground	ECM detects that commanded and actual states of output driver do not match because the output is shorted to ground		Diagnostic Enabled Powertrain relay voltage Ignition run crank voltage Engine is not cranking	1 >= 11.00 Volts >= 5.00 Volts	10 failures out of 20 samples	Type B, 2 Trips
Circuit Low							1 sample every 100ms	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r	P0246	Detect Turbocharger Boost Solenoid -	ECM detects that commanded and actual		Diagnostic Enabled	1	10	Type B, 2 Trips
Wastegate / Supercharge		Shorted to Power	states of output driver do not match because the		Powertrain relay voltage	>= 11.00 Volts	failures out of 20	
r Boost			output is shorted to power		Ignition run crank voltage			
Solenoid A Control					Engine is not cranking	>= 5.00 Volts	samples	
Circuit High							1 sample every 100ms	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger	P0299	Detect Positive Boost Pressure Control	Desired Boost Pressure - Actual Boost Pressure	> (KtBSTD_p_CntrlDevP	Diagnostic Enabled	1	25 failures out of	Type B, 2 Trips
Engine Underboost		Deviation		osLim + KtBSTD_p_CntrlDevA	Engine Speed	> 2,450 rpm	25 samples	
Turbocharge r with				mbAirCorr)	Engine Speed	< 6,000 rpm	1 sample every	
wastegate. Not					Desired Boost Pressure	> 135.0 kPa	100ms	
supercharge r with				See Tables in Supporting Tables	Desired Boost Pressure	< 220.0 kPa		
mechanical compressor				Sheet	Desired Boost Pressure Derivative	> -70.0 kPa/s		
					Desired Boost Pressure Derivative	< 55.0 kPa/s		
					Ambient Pressure	> 60.0 kPa		
					Ambient Pressure	< 120.0 kPa		
					Coolant Temp	> -40.0 Deg C		
					Coolant Temp	< 120.0 Deg C		
					Intake Air Temp	> -40.0 Deg C		
					Intake Air Temp	< 80.0 Deg C		
					Wait for steady state:	> KtBSTD_t_CntrlDevEnblD elay See Table in Supporting Tables Sheet		
					No Active DTCs:	Desired Boost Pressure > Basic Pressure		
						AmbientAirDefault_Snsr BSTR_b_PCA_CktFA BSTR_b_TurboBypassCkt FA ECT_Sensor_FA		

# SECTION 2 Unique DTCs 2 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Active DVCs:	IAT_SensorFA BSTR_b_ExcsvBstTFTK O BSTR_b_PCA_CktTFTK O TC_BoostPresSnsrFA AnyCamPhaser_FA BSTR_b_PresCntrITooLo TFTKO BSTR_b_PresCntrITooHiT FTKO EnginePowerLimited BSTR_b_DVC_PCA_DC_ Actv BSTR_b_DVC_PCA_Pstn Actv BSTR_b_DVC_TurboCom prBypActv		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (turbocharge d)	P1101	Determines if there are multiple air induction problems affecting airflow and/or manifold pressure.	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC. MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error	<ul> <li>&gt; 16 grams/sec</li> <li>&gt; 20.0 kPa</li> <li>&gt; 25.0 kPa</li> <li>&gt; 25.0 kPa</li> <li>&gt; 25.0 kPa</li> <li>&gt; 25.0 kPa</li> </ul>	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	<ul> <li>&gt;= 400 RPM</li> <li>&lt;= 6,000 RPM</li> <li>&gt; -7 Deg C</li> <li>&lt; 125 Deg C</li> <li>&gt; -20 Deg C</li> <li>&gt; -20 Deg C</li> <li>&lt; 100 Deg C</li> <li>&gt;= 0.50</li> <li>Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est</li> <li>MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM</li> <li>MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM</li> <li>MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM</li> </ul>	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips
			TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table "TIAP-MAP	> 25.0 kPa		TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Correlation Offset" OR			See "Residual Weight Factor" tables.		
			Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset" TIAP Correlation is valid when	> 25.0 kPa	No Active DTCs:	MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault		
			High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time	> 2.0 seconds > 2.0 seconds	No Pending DTCs:	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP		
			High Engine Air Flow is TRUE when Mass Air Flow	<ul> <li>&gt; a threshold in gm sec as a function of engine speed</li> <li>See table "TIAP-MAP Correlation Min Air Flow"</li> </ul>				
			AND Manifold Pressure	<ul> <li>a threshold in kPa as a function of engine speed</li> <li>See table "TIAP-MAP Correlation Min MAP"</li> </ul>				
			AND Filtered Mass Air Flow - Mass Air Flow	< 2.0 gm/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Low Engine Air Flow is TRUE when Mass Air Flow AND Manifold Pressure AND Mass Air Flow - Filtered	< a threshold in gm sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow" < a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP"				
			Mass Air Flow	< 2.0 gm/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Performance (turbocharge d)	P2227	Compares baro sensor to the calculated baro estimate (part throttle calculation or unthrottled MAP)	Difference between baro sensor reading and estimated baro when distance since last estimated baro update OR Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 15.0 kPa <= 0.06 miles > 20.0 kPa > 0.06 miles	Engine Run Time No Active DTCs:	> 0.00 seconds AmbPresSnsrCktFA ECT_Sensor_Ckt_FA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips
			Barometric Pressure OR Barometric Pressure OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	< 50.0 kPa > 115.0 kPa > 10.0 kPa <= 10.0 kPa > 10.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating No Active DTCs: No Pending DTCs:	<ul> <li>&gt; 10.0 seconds</li> <li>EngineModeNotRunTimer Error</li> <li>MAP_SensorFA</li> <li>TC_BoostPresSnsrCktFA</li> <li>AAP2_SnsrFA</li> <li>MAP_SensorCircuitFP</li> <li>AAP_SnsrCktFP</li> <li>AAP2_SnsrCktFP</li> </ul>	<ul><li>4 failures out of</li><li>5 samples</li><li>1 sample every</li><li>12.5 msec</li></ul>	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (boosted applications)		Detects a continuous short to low or open in either the signal circuit or the BARO sensor.	BARO Voltage	< 40.0 % of 5 Volt Range (2.0 Volts = 50.9 kPa)	Engine Run Time	> 0.00 seconds	80 failures out of 100 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (boosted applications)	P2229	Detects an open sensor ground or continuous short to high in either the signal circuit or the BARO sensor.	Ū	> 90.0 % of 5 Volt Range (4.5 Volts = 115.0 kPa)	Engine Run Time	> 0.00 seconds	80 failures out of 100 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve - Mechanical Turbocharge r with wastegate. Not supercharge r with mechanical compressor	P2261	Detect Stuck Closed Bypass Valve	Accumulation time is high pass filtered. Accumulated air mass flow or boost pressure larger then thresholds Filter Frequency Filtered Air Mass Flow Filtered Boost Pressure	0.25 Second < Accumulation time < 0.85 Second 12.00 Hz > 50.000 g/s > 40.00 kPa	Diagnostic Enabled Engine Speed Pressure ratio over the compressor Relative Boost Pressure (Boost - Ambient) and Negative Transient in Manifold Air Pressure	1 >= 1,800 rpm >KtBSTD_r_ExcsvBstPre sLim Enable condition kept true for 1.5 seconds extra See Tables in Supporting Tables Sheet IF ( RelativeBoost < 3.0 kPa OR DerivativeMAP > 50.00 kPa/s ) [FALSE ] Else ( RelativeBoost >= 40.0 kPa AND DerivativeMAP <= -150.00 kPa ) [ TRUE ] > 6.0 percentEnable condition kept true for 0.70 seconds extra	3 Failed tests out of 3 Tests 1 sample every 25ms	Type B, 2 Trips
					Bypass Valve Commanded Open No Active DTCs:	TC_BoostPresSnsrFA MAF_SensorFABSTR_b_ TurboBypassCktFA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r/ Supercharge r Boost Pressure Too High - Mechanical Turbocharge r with wastegate. Not supercharge r with mechanical compressor		Detect Too High Boost Pressure	Pressure ratio over the compressor	< KtBSTD_r_ExcsvBstPr esLim See Tables in Supporting Tables Sheet	Diagnostic Enabled Engine Speed No Active DTCs:	0 >= 2,000 rpm TC_BoostPresSnsrFA AmbientAirDefault_Snsr MAF_SensorFA	30 failures out of 60 samples 1 sample every 25ms	Type X, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Bank 1 Air- Fuel Ratio Imbalance	P219A	This monitor determines if a cylinder-to-cylinder air- fuel ratio imbalance is present on bank 1.	Filtered Ratio > Note: The input to this metric is the pre catalyst oxygen sensor voltage. This voltage is used to generate a Variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to	0.75 If the diagnostic has reported a failure on the prior trip, the Filtered Ratio must fall below 0.25 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing	System Voltage Fuel Level Engine Coolant Temperature Cumulative engine run time	no lower than 11.0 Volts for more than 0.2 seconds > 10.0 percent AND no fuel level sensor fault > -20 degrees C > 30.0 seconds	Minimum of 1 test per trip, up to 15 tests per trip during RSR or FIR. The front O2 sensor voltage is sampled once per cylinder event. Therefore, the	Type A, 1 Trips
			the air-fuel ratio imbalance (variance is higher with an imbalance than without). Multiple samples are collected in making a decision. The observed Variance is dependant on engine	when the Filtered Ratio remains near the initial failure threshold of 0.75.	Diagnostic enabled at Idle (regardless of other operating conditions) Engine speed range Engine speed delta during a short term sample period	Yes 1,200 to 3,200 RPM <100 RPM	time required to complete a single test (when all enable conditions are met) decreases as engine speed increases. For example,	
			speed and load and so each result is normalized for speed and load by comparing it to a known "good system" result for that speed and load, and		Mass Airflow (MAF) range Cumulative delta MAF during a short term sample period	0 to 200 g/s <5 g/s	16.20 seconds of data is required at 1000 rpm while double this time is required at 500 rpm and	
			generating a Ratio metric. The Ratio metric is calculated by selecting the appropriate threshold calibration from a 17x17 table (Supporting Table		Filtered MAF delta between samples Note: first order lag filter coefficient applied to MAF = 0.050	<0.20 g/s	half this time is required at 2000 rpm. This data is collected only when enable conditions are met, and as such	
			"Variance Threshold Bank1") and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table		Air Per Cylinder (APC) APC delta during short term sample period Filtered APC delta between samples	200 to 700 mg/cylinder <75 mg/cylinder <9.99 percent	significantly more operating time is required than is indicated above. Generally, a report will be	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			(Supporting Table		Note: first order lag filter		made within 5	
			"Normalizer Bank1").		coefficient applied to APC		minutes of	
			This quotient is then		= 0.100		operation.	
			multiplied by a quality					
			factor calibration from a		Spark Advance	0 to 60 degrees	For RSR or FIR,	
			17 x 17 table (Supporting				15 tests must	
			Table "Quality Factor		Throttle Area (percent of	0 to 100 percent	complete before	
			Bank1"). This result is		max)		the diagnostic	
			referred to as the Ratio.				can report.	
			Note that the quality factor ranges between 0 and 1		Intake Cam Phaser Angle	0 to 28 degrees		
			and represents		Exhaust Cam Phaser	0 to 28 degrees		
			robustness to false		Angle			
			diagnosis in the current					
			operating region. Regions		Quality Factor (QF)	>= 0.99		
			with low quality factors		QF calibrations are			
			are not used.		located in a 17x17 lookup			
					table versus engine speed			
			Finally, a EWMA filter is		and load (Supporting			
			applied to the Ratio metric to generate the Filtered		Table "Quality Factor Bank1"). QF values less			
			Ratio malfunction criteria		than "1" indicate that we			
			metric. Generally, a		don't have 4sigma/2sigma			
			normal system will result		robustness in that region.			
			in a negative Filtered		The quality of the data is			
			Ratio while a failing		determined via statistical			
			system will result in a		analysis of Variance data.			
			positive Filtered Ratio.					
					Fuel Control Status			
			The range of the Filtered		Closed Loop and Long	>= 1.2 seconds		
			Ratio metric is application		Term FT Enabled for:	(Please see "Closed		
			specific since both the			Loop Enable Criteria"		
			emissions sensitivity and			and "Long Term FT		
			relationship between			Enable Criteria" in		
			imbalance and the			Supporting Tables)		
			Variance metric are		AIR pump not on			
			application specific.		CASE learn not active			
					EGR - no device control,			
			Some applications may		no intrusive diagnostics			
			need to command a		EVAP - no device control,			
			unique cam phaser value		no intrusive diagnostics			
			before performing the		Engine OverSpeed			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			above calculations since cam phasing has been shown to have an impact on overall signal quality. This application Does Not Use this feature.		Protection Not Active Idle speed control normal PTO Not Active Injector base pulse width above min limit Rapid Step Response (RSR): RSR will trigger if the Ratio result from the last test is AND it exceeds the last Filtered ratio by Once triggered, the filtered ratio is reset to: Fast Initial Response (FIR): FIR will trigger when an NVM reset or code clear occurs. Once triggered, the filtered ratio is reset to: No Fault Active for:	>= 0.50 >= 1.00 0.10 0.10 EngineMisfireDetected_F A MAP_SensorFA MAF_SensorFA ECT_SensorFA TPS_ThrottleAuthorityDef aulted FuelInjectorCircuit_FA AIR System FA EvapExcessPurgePsbl_F A CamSensorAnyLocationF A		

	Oleand Lean First				ine Diagn		0		_		
	Closed Loop Enal	ble Clarifi	cation: C	alibratio	n values a	are in the	Support	ing lable	S		
-	n time greater than										
KtFSTA_t		RID ONLY									
	AutoStart CoolantX1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
	Close Loop Enable TimeY1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11
and											
	_ClosedLoopTime	VO	Vo	V4	VE	VG	<b>V7</b>	VO	VO	V10	V11
	Start-Up CoolantX1 Close Loop Enable TimeY1	X2 Y2	X3 Y3	X4 Y4	X5 Y5	X6 Y6	X7 Y7	X8 Y8	X9 Y9	X10 Y10	X11 Y11
and nro c	onverter 02 sensor voltage less		15	14	10	10	17	10	19	110	T I I
than	onverter 02 sensor voltage less										
	J_O2_SensorReadyThrsh										
Lo											
	Voltage< XXX	(XmilliVol	ts								
for											
	O2_SensorReadyEvents										
	(events * 12.5 milliseconds) > XXX	Xevents									
and	(										
	onverter Oxygen Storage Contro	ol) not									
enabled		,									
and											
Consume	d AirFuel Ratio is stoichiometry	/ i.e. not i	n compo	nent							
protectior	1		-								
and											
POPD or (	Catalyst Diagnostic not intrusiv	е									
and											
	avenging Mode not										
enabled											
and		_									
	ers whose valves are active also	o have th	eir inject	ors							
enabled											
	k_ 1_TFTKO, O2S_Bank_ 2_TF1	KO, Fue	InjectorC	F/	and						
O2S_Banl	eacDriverTFTKO = False										
O2S_Banl CyInderDo											

# Closed Loop Enable Clarification: Calibration values are in the Supporting Tables

								-	
Closed Loop Enable and									
Coolant greater than									
KfFCLL_T_AdaptiveLoCoolant									
Coolant <u>&gt; XX</u>	XXCelcius	;							
or less than									
KfFCLL_T_AdaptiveHiCoolant									
Coolant <u>&lt; XX</u>	XXCelcius	;							
and									
KtFCLL_p_AdaptiveLowMAP_Limit									
Barometric PressureX1	X2	X3	X4	X5	X6	X7	X8	X9	
Manifold Air PressureY1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	
and									
<pre>FPS_ThrottleAuthorityDefaulted =</pre>									
False									
and									
Flex Fuel Estimate Algorithm is not active	е								
and Even a size for low one hailing off from th				<b>-D</b> ) :	1				
Excessive fuel vapors boiling off from th	e engine	oli algori	thm (BOI	-R) is not					
enabled									
and Catalyst ar EVAR large lask test not									
Catalyst or EVAP large leak test not intrusive									
IIIIIusive									
Secondary Fuel Trim Enable									
Criteria									
Sintenia									
Closed Loop Enable and									
KfFCLP_U_O2ReadyThrshLo									
Voltage XXX	XXmilliVol	ts							
for									
KcFCLP_Cnt_O2RdyCyclesThrsh									
Time (events * 12.5 milliseconds) > XXX	XXevents								
,									
Long Term Secondary Fuel Trim									
Enable Criteria									
KtFCLP_t_PostIntglDisableTime									

		13 OBD	G02A Eng	jine Diagn	ostics					
Closed Loop Enab	le Clarific	cation: C	alibratio	n values	are in the	Support	ing Table	s		
Start-Up CoolantX1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Post Integral Enable TimeY1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11
Plus										
KtFCLP_t_PostIntgIRampInTime										
Start-Up CoolantX1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Post Integral Ramp In TimeY1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11
and										
KeFCLP_T_IntegrationCatalystMax										
Modeled Catalyst Temperature < <u>&lt; XXX</u>	XCelcius									
and										
KeFCLP_T_IntegrationCatalystMin										
Modeled Catalyst Temperature > XXX	XCelcius									
and <u> </u>										
PO2S Bank 1 Snsr 2 FA and										
PO2S Bank 2 Snsr 2 FA = False										
and										
(KeFCLP_Pct_CatAccuSlphrPostDsbl										
Modeled converter sulfur percent < XXXX	Percent									
and										
Post Integral < KaFCLP_U_SIphrIntglOfst	Thrsh)									
	,									
X axis: Post O2 Sensor										
Y axis: Post O2 Mode										
Z: Post Integral threshold										

# Supporting Table - P0101\_P0106\_P0121\_P0236\_P1101 Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

**Description:** Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

Notes: This table describes combinations of individual model failures that will set P0101, P0106, P0121, P0236 and P1101 on turbocharged applications.

y/x	1	2	3	4	5	6	7	8	9
1	MAF Model	MAP1 Model	MAP2 Model	MAP3 Model	TIAP1 Model	TPS Model	TIAP Correlation	TIAP Correlation	DTC Set
	Failed	Failed	Failed	Failed	Failed	Failed	Failed	Valid	
;	F	F	F	F	F	F	F	F	No DTC
	F	F	F	F	F	F	F	Т	No DTC
;	F	F	F	F	F	F	Т	F	No DTC
i	F	F	F	F	F	F	Т	Т	No DTC
	F	F	F	F	F	Т	F	F	No DTC
;	F	F	F	F	F	Т	F	Т	No DTC
)	F	F	F	F	F	Т	Т	F	No DTC
0	F	F	F	F	F	Т	Т	Т	No DTC
1	F	F	F	F	Т	F	F	F	No DTC
2	F	F	F	F	Т	F	F	Т	No DTC
3	F	F	F	F	Т	F	Т	F	No DTC
4	F	F	F	F	Т	F	Т	Т	No DTC
5	F	F	F	F	Т	Т	F	F	P1101
6	F	F	F	F	Т	Т	F	Т	P0121
7	F	F	F	F	Т	Т	Т	F	P1101
8	F	F	F	F	Т	Т	Т	Т	P0236
9	F	F	F	Т	F	F	F	F	P1101
20	F	F	F	Т	F	F	F	Т	P1101
21	F	F	F	Т	F	F	Т	F	P1101
22	F	F	F	T	F	F	T	Т	P1101
.3	F	F	F	Т	F	Т	F	F	P1101
24	F	F	F	Т	F	Т	F	Т	P1101
25	F	F	F	Т	F	Т	Т	F	P1101
26	F	F	F	Т	F	Т	Т	Т	P1101
27	F	F	F	Т	Т	F	F	F	P1101
.8	F	F	F	Т	Т	F	F	Т	P1101
9	F	F	F	Т	Т	F	Т	F	P1101
0	F	F	F	Т	Т	F	Т	Т	P1101
31	F	F	F	Т	Т	Т	F	F	P1101
2	F	F	F	Т	Т	Т	F	Т	P1101
3	F	F	F	Т	Т	Т	Т	F	P1101
34	F	F	F	İΤ	Îт	Тт	Т	Т	P1101

Sur	pporting Tab	le - P0101 P0	106_P0121_P0	236 P1101 Tu			ationality Dia	anostic Failu	re Matrix
					j-		<b>j</b>	<u> </u>	
35	F	F	Т	F	F	F	F	F	P1101
36	F	F	Т	F	F	F	F	Т	P1101
37	F	F	Т	F	F	F	Т	F	P1101
38	F	F	Т	F	F	F	Т	Т	P1101
39	F	F	Т	F	F	T	F	F	P1101
40	F	F	Т	F	F	Т	F	Т	P1101
41	F	F	Т	F	F	Т	Т	F	P1101
42	F	F	Т	F	F	Т	Т	Т	P1101
43	F	F	Т	F	Τ	F	F	F	P1101
44	F	F	Т	F	T	F	F	Т	P1101
45	F	F	Т	F	Т	F	Т	F	P1101
46	F	F	Т	F	Т	F	Т	Т	P1101
47	F	F	Т	F	Т	Т	F	F	P1101
48	F	F	T	F	Τ	Т	F	Т	P1101
49	F	F	Т	F	Т	Т	Т	F	P1101
50	F	F	Т	F	Т	Т	Т	Т	P1101
51	F	F	Т	т	F	F	F	F	P1101
52	F	F	Т	Т	F	F	F	Т	P1101
53	F	F	Т	Т	F	F	Т	F	P1101
54	F	F	Т	Т	F	F	Т	Т	P1101
55	F	F	Т	т	F	Т	F	F	P1101
56	F	F	т	т	F	т	F	Т	P1101
57	F	F	Т	Т	F	Т	Т	F	P1101
58	F	F	Т	т	F	Т	Т	Т	P1101
59	F	F	т	Т	Т	F	F	F	No DTC
60	F	F	Т	Т	Т	F	F	Т	No DTC
61	F	F	Т	т	Т	F	Т	F	No DTC
62	F	F	Т	Т	Т	F	Т	Т	No DTC
63	F	F	Т	Т	Т	Т	F	F	P1101
64	F	F		Τ	Τ	Т	F	Т	P1101
65	F	F	Т	Т	Т	Т	Т	F	P1101
66	F	F	Т	Т	Т	т	Т	Т	P1101
67	F	Т	F	F	F	F	F	F	P1101
68	F	Т	F	F	F	F	F	Т	P1101
69	F	Т	F	F	F	F	T	F	P1101
70	F	Т	F	F	F	F	T	T	P0236
71	F	Т	F	F	F	Т	F	F	P1101
72	F	T T	F	F	F	T	F	T	P0121

Suj	pporting Tab	le - P0101_P0	106_P0121_P		urbocharger	Intake Flow R	ationality Dia	ignostic Failu	re Matrix
73	F	Т	F	F	F	Т	Т	F	P1101
74	F	Т	F	F	F	Т	Т	Т	P0236
75	F	T	F	F	Т	F	F	F	P1101
76	F	Т	F	F	Т	F	F	Т	P1101
77	F	Т	F	F	Т	F	Т	F	P1101
78	F	Т	F	F	Т	F	Τ	Т	P0236
79	F	Т	F	F	Т	Т	F	F	P1101
80	F	Т	F	F	Т	Т	F	Т	P0121
81	F	Т	F	F	Т	Т	Т	F	P1101
82	F	Т	F	F	Т	Т	Т	Т	P0236
83	F	Т	F	Т	F	F	F	F	P1101
84	F	Т	F	Т	F	F	F	Т	P1101
85	F	Т	F	Τ	F	F	Т	F	P1101
86	F	T	F	T	F	F	T	Т	P1101
87	F	Т	F	Т	F	Т	F	F	P1101
88	F	Т	F	Т	F	Т	F	Т	P1101
89	F	Т	F	Т	F	Т	Т	F	P1101
90	F	Т	F	Т	F	Т	Т	Т	P1101
91	F	Т	F	Т	Т	F	F	F	P1101
92	F	Т	F	Т	Т	F	F	Т	P1101
93	F	Т	F	Т	Т	F	Т	F	P1101
94	F	Т	F	Т	Т	F	Т	Т	P1101
95	F	Т	F	Т	Т	Т	F	F	P1101
96	F	Т	F	Т	Т	Т	F	Т	P1101
97	F	Т	F	Т	Т	Т	Т	F	P1101
98	F	Т	F	Т	Т	Т	Т	Т	P1101
99	F	Т	Т	F	F	F	F	F	P1101
100	F	Т	Т	F	F	F	F	Т	P1101
101	F	Т	Т	F	F	F	Т	F	P1101
102	F	T	Т	F	F	F	T	Т	P1101
103	F	Т	Т	F	F	Т	F	F	P1101
104	F	Т	Т	F	F	Т	F	Т	P1101
105	F	Т	Т	F	F	Т	Т	F	P1101
106	F	Т	Т	F	F	Т	Т	Т	P1101
107	F	T	Т	F	T	F	F	F	P1101
108	F	Т	Т	F	Τ	F	F	Т	P1101
109	F	Т	Т	F	Τ	F	Т	F	P1101
110	F	Т	Т	F	Т	F	Т	Т	P1101

Sup	porting Tabl	e - P0101 P0	106_P0121_P		urbocharger		ationality Dia	anostic Failu	re Matrix
	<b>J</b>				<b>J</b>			5	
111	F	Т	Т	F	Т	Т	F	F	P1101
112	F	Т	Т	F	Т	Т	F	Т	P1101
113	F	Т	Т	F	Т	Т	Т	F	P1101
114	F	Т	Т	F	Т	Т	Т	Т	P1101
115	F	Т	Т	Т	F	F	F	F	P0106
116	F	Т	Т	Т	F	F	F	Т	P0106
117	F	T	Т	Т	F	F	ÎΤ	F	P0106
118	F	Т	Т	Т	F	F	ÎΤ	Т	P0106
119	F	Т	Т	Т	F	T	F	F	P1101
120	F	T	Т	Т	F	T	F	Т	P1101
121	F	Т	Т	Т	F	Т	Т	F	P1101
122	F	Τ	Т	Т	F	Т	Τ	Т	P1101
123	F	Т	Т	Т	Т	F	F	F	P1101
124	F	Τ	Т	Т	Т	F	F	Т	P1101
125	F	Т	Т	Т	Т	F	Т	F	P1101
126	F	Т	Т	Т	Т	F	T	Т	P1101
127	F	T	Т	Т	Т	Т	F	F	P1101
128	F	Т	Т	Т	Т	Т	F	Т	P1101
129	F	Τ	Т	Т	Т	Т	ΪT	F	P1101
130	F	Т	Т	Т	Т	Т	Т	Т	P1101
131	Т	F	F	F	F	F	F	F	P1101
132	Т	F	F	F	F	F	F	Т	P1101
133	Т	F	F	F	F	F	T	F	P1101
134	Т	F	F	F	F	F	T	Т	P0236
135	Т	F	F	F	F	Т	F	F	P1101
136	Т	F	F	F	F	Т	F	Т	P0121
137	Т	F	F	F	F	Т	Τ	F	P1101
138	Т	F	F	F	F	Т	Т	Т	P0236
139	Т	F	F	F	Т	F	F	F	P1101
140	Т	F	F	F	Т	F	F	Т	P1101
141	Т	F	F	F	Т	F	Τ	F	P1101
142	Т	F	F	F	Т	F	Т	Т	P0236
143	Т	F	F	F	Т	Т	F	F	P1101
144	Т	F	F	F	Т	Т	F	Т	P0121
145	Т	F	F	F	T	Т	T	F	P1101
146	Т	F	F	F	Т	Т	Т	Т	P0236
147	Т	F	F	т	F	F	F	F	P1101
148	Т	F	F	Т	F	F	F	Т	P1101

Sup	porting Table	e - P0101_P0	106_P0121_P0		urbocharger		ationality Dia	gnostic Failu	re Matrix
149	Т	F	F	Т	F	F	Т	F	P1101
150	Т	F	F	Т	F	F	T	Т	P1101
151	Т	F	F	Τ	F	т	F	F	P1101
152	Т	F	F	Т	F	Т	F	Т	P1101
153	Т	F	F	T	F	Т	T	F	P1101
154	Т	F	F	T	F	Т	Τ	Т	P1101
155	Т	F	F	Т	Т	F	F	F	P1101
156	Т	F	F	T	Т	F	F	Т	P1101
157	Т	F	F	Т	Т	F	Т	F	P1101
158	Т	F	F	T	Т	F	T	Т	P1101
159	Т	F	F	Т	Т	Т	F	F	P1101
160	Т	F	F	Т	Т	Т	F	Т	P1101
161	Т	F	F	T	Т	Т	Т	F	P1101
162	Т	F	F	T	Т	Т	Τ	Т	P1101
163	Т	F	Т	F	F	F	F	F	P1101
164	Т	F	Т	F	F	F	F	Т	P1101
165	Т	F	Т	F	F	F	Т	F	P1101
166	Т	F	Т	F	F	F	Т	Т	P1101
167	Т	F	T	F	F	Т	F	F	P1101
168	Т	F	Т	F	F	Т	F	Т	P1101
169	Т	F	Т	F	F	Т	Т	F	P1101
170	Т	F	Т	F	F	Т	Т	Т	P1101
171	Т	F	Т	F	Т	F	F	F	P1101
172	Т	F	Т	F	Т	F	F	Т	P1101
173	Т	F	Т	F	Т	F	Т	F	P1101
174	Т	F	Т	F	Т	F	Т	Т	P1101
175	Т	F	Т	F	Т	Т	F	F	P1101
176	Т	F	Т	F	Т	Т	F	Т	P1101
177	Т	F	Т	F	Т	Т	Т	F	P1101
178	Т	F	Т	F	T	Т	Т	Т	P1101
179	Т	F	Т	Т	F	F	F	F	P1101
180	Т	F	Т	Т	F	F	F	Т	P1101
181	Т	F	Т	Т	F	F	Т	F	P1101
182	Т	F	Т	Т	F	F	Т	Т	P1101
183	Т	F	Т	T	F	Т	F	F	P1101
184	Т	F	Т	Т	F	Т	F	Т	P1101
185	Т	F	Т	Т	F	Т	Т	F	P1101
186	Т	F	Т	Т	F	Т	Т	Т	P1101

Sur	oporting Tabl	e - P0101 P0	106 P0121 P		urbocharger	Intake Flow R	ationality Dia	anostic Failu	re Matrix
					j.		<b>j</b>		
187	Т	F	Т	Т	Т	F	F	F	P1101
188	Т	F	Т	Т	Т	F	F	Т	P1101
189	Т	F	Т	Т	Т	F	Τ	F	P1101
190	Т	F	Т	Т	Т	F	T	Т	P1101
191	Т	F	Т	Т	Т	Т	F	F	P1101
192	Т	F	Т	Т	Т	Т	F	Т	P1101
193	Т	F	Т	Т	Т	Т	Τ	F	P1101
194	Т	F	Т	Т	Т	Т	Т	Т	P1101
195	Т	Т	F	F	F	F	F	F	P1101
196	Т	Т	F	F	F	F	F	Т	P1101
197	Т	Т	F	F	F	F	Т	F	P1101
198	Т	Т	F	F	F	F	Т	Т	P0236
199	Т	Т	F	F	F	Τ	F	F	P1101
200	Т	Τ	F	F	F	Т	F	Т	P0121
201	Т	Т	F	F	F	Т	Τ	F	P1101
202	Т	Т	F	F	F	Т	Г	Т	P0236
203	T	<u>т</u>	F	F	T T	F	F	F	P1101
204	T	<u>т</u>	F	F	T T	F	F	T	P1101
205	T	<u></u> Т	F	F	T	F	<u></u> Гт	F	P1101
206	T	ι· Τ	F	 F	ΠT	F	 Τ	і Т	P0236
207	T	<u>т</u>	F	 F	і Т	т	F	F	P1101
208	T	<u></u> т	F	 F	і Тт	т	F	і Т	P0121
209	T	<u>т</u>	F	 F	і Т	т	!.  т	F	P1101
210	T	і т	F	 F	! Т	т		і Т	P0236
211	T	<u></u> т	!	<u>т</u>	F	F	F	F	P1101
212	T	т Т	F	!' Т	F	F	F	г Т	P1101
213	T		'	<u></u> т	'	'	!  т	F	P1101
214	T	<u>г</u>	'	! Т	F	F	! Т	<u>г</u>	P1101
215	T	і Т	'	! Т	F	і Т	F	F	P1101
216	T	 	/	<u></u> Тт		і Т	I	<u>г</u> Т	P1101
217	T	<u>г</u>	'	! Т	F	і Т	! Т	F	P1101
218	T		F	' Т	! F	T		' Т	P1101
210	T	і т	F	і Т	<u>г</u> Т	F	F	F	P1101
220	T	і т	F	і Т	і Т	F	F	Г Т	P1101
220	т Т	! Т	F	T	і т	F	Г  т	F	P1101
222	т Т		F	і Т		F		<u>г</u> Т	P1101
	т Т		F	і Т	і Т	г	F	F	P1101
223	Т		F	і Т	і Т	і Т	F	<u>г</u>	
224	1	1	Г	I	I'	1	F	1	P1101

Sup	oporting Tabl	le - P0101_P0	106_P0121_P0	)236_P1101 T	urbocharger	Intake Flow R	ationality Dia	agnostic Failu	re Matrix
225	Т	Т	F	Т	Т	Т	Т	F	P1101
226	Т	Т	F	Т	Т	Т	Т	Т	P1101
227	Т	Т	Т	F	F	F	F	F	P1101
228	Т	Т	Т	F	F	F	F	Т	P1101
229	T	T	Т	F	F	F	Т	F	P1101
230	Т	T	Т	F	F	F	Τ	Т	P1101
231	Т	T	Т	F	F	Т	F	F	P1101
232	Т	T	Т	F	F	Т	F	Т	P1101
233	Т	T	Т	F	F	Т	Т	F	P1101
234	Т	T	Т	F	F	Т	Т	Т	P1101
235	Т	Т	Т	F	Т	F	F	F	P1101
236	Т	Т	Т	F	Т	F	F	Т	P1101
237	Т	T	Т	F	Т	F	Т	F	P1101
238	Т	Т	Т	F	Т	F	T	Т	P1101
239	Т	T	Т	F	Т	Т	F	F	P1101
240	Т	Т	Т	F	Т	Т	F	Т	P1101
241	Т	Т	Т	F	Т	Т	Т	F	P1101
242	Т	Т	Т	F	Т	Т	Т	Т	P1101
243	Т	T	Т	T	F	F	F	F	P1101
244	Т	Т	Т	Т	F	F	F	Т	P1101
245	Т	Т	Т	Т	F	F	Т	F	P1101
246	Т	Т	Т	Т	F	F	Т	Т	P1101
247	Т	Т	Т	Т	F	Т	F	F	P1101
248	Т	Т	Т	Т	F	Т	F	Т	P1101
249	Т	Т	Т	Т	F	Т	Т	F	P1101
250	Т	Т	Т	Т	F	Т	Т	Т	P1101
251	Т	Т	Т	Т	Т	F	F	F	P1101
252	Т	Т	Т	Т	Т	F	F	Т	P1101
253	Т	Т	Т	Т	Т	F	Т	F	P1101
254	T	Т	Т	Т	Т	F	T	Т	P1101
255	Т	Т	Т	Т	Т	Т	F	F	P1101
256	Т	Т	Т	Т	Т	Т	F	Т	P1101
257	Т	Т	Т	Т	Τ	Т	Τ	F	P1101
258	Т	Т	Т	Т	Т	Т	Т	Т	P1101

# Supporting Table - P0101\_P0106\_P0121\_P012B\_P0236\_P1101 TPS Residual Weight Factor based on RPM

Description: P0101\_P0106\_P0121\_P012B\_P0236\_P1101 TPS Residual Weight Factor based on RPM

Notes																	
y/x	0	1,500	2,200	2,500	2,700	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,250	5,625	7,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

# Supporting Table - P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAF Residual Weight Factor based on RPM

Description: P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAF Residual Weight Factor based on RPM

Notes:																	
y/x	0	800	1,500	2,500	2,800	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,500	6,500	7,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.900	0.950	0.950	1.000	0.950	0.950

# Supporting Table - P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAF Residual Weight Factor based on MAF Est

Description: P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAF Residual Weight Factor based on MAF Est

Notes:																	
y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

# Supporting Table - P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP1 Residual Weight Factor based on RPM

Description: P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP1 Residual Weight Factor based on RPM

Notes:																	
y/x	0	800	1,500	2,500	2,800	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,500	6,500	7,000
1	0.900	0.900	0.900	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

# Supporting Table - P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP2 Residual Weight Factor based on RPM

Description: P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP2 Residual Weight Factor based on RPM

Notes:																	
y/x	0	800	1,500	2,500	2,800	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,500	6,500	7,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

# Supporting Table - P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP3 Residual Weight Factor based on RPM

Description: P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP3 Residual Weight Factor based on RPM

Notes:																	
y/x	0	1,500	2,200	2,500	2,700	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,250	5,625	7,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

# 13 OBDG02A Engine Diagnostics Supporting Table - P0101\_P0106\_P0121\_P0236\_P1101 TIAP Residual Weight Factor based on RPM

### Notes:

y/x	0	1,500	2,200	2,500	2,700	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,250	5,625	7,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

# 13 OBDG02A Engine Diagnostics Supporting Table - P0101\_P0106\_P0121\_P0236\_P1101 TIAP-MAP Correlation Offset

Description: P01	Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Offset													
Notes:	Notes:													
y/x	r/x 1,000 1,750 2,500 3,250 4,000 4,750 5,500 6,250 7,000													
1	1.0	1.0	1.0	1.0	2.0	2.0	2.0	3.0	3.0					

# 13 OBDG02A Engine Diagnostics Supporting Table - P0101\_P0106\_P0121\_P0236\_P1101 TIAP-Baro Correlation Offset

Description: P01	Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Offset													
Notes:	Notes:													
y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000					
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0					

# 13 OBDG02A Engine Diagnostics Supporting Table - P0101\_P0106\_P0121\_P0236\_P1101 TIAP-MAP Correlation Min Air Flow

Description: P01	Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min Air Flow													
Notes:	lotes:													
y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000					
1	15.0	27.0	32.0	32.0	32.0	32.0	32.0	32.0	32.0					

# 13 OBDG02A Engine Diagnostics Supporting Table - P0101\_P0106\_P0121\_P0236\_P1101 TIAP-Baro Correlation Max Air Flow

Description: P01	Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Max Air Flow													
Notes:	Notes:													
y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000					
1	2.6	3.3	4.5	5.4	7.0	8.8	11.0	12.4	12.4					

# 13 OBDG02A Engine Diagnostics Supporting Table - P0101\_P0106\_P0121\_P0236\_P1101 TIAP-MAP Correlation Min MAP

Description: P01	Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min MAP													
Notes:	Notes:													
y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000					
1	124.0	126.0	127.0	128.0	129.0	128.0	127.0	127.0	127.0					

# 13 OBDG02A Engine Diagnostics Supporting Table - P0101\_P0106\_P0121\_P0236\_P1101 TIAP-Baro Correlation Max MAP

Description: P01	01_P0106_P0121_	_P0236_P1101 TIAI	P-Baro Correlation	Max MAP										
Notes:	Notes:													
y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000					
1	34.1	27.3	26.1	25.4	25.7	24.1	29.5	29.4	29.4					

# 13 OBDG02A Engine Diagnostics Supporting Table - P0101\_P0106\_P0121\_P012B\_P1101 Boost Residual Weight Factor based on % of Boost

Descript	Description: P0101_P0106_P0121_P012B_P1101 Boost Residual Weight Factor based on % of Boost																
Notes:	Notes:																
y/x	x 0 0 0 0 0 0 0 0 1 1 1 1 1 1 1 1 1 1																
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

# Supporting Table - P0101\_P0106\_P0121\_P012B\_P1101 SCIAP1 Residual Weight Factor based on RPM

Description: P0101\_P0106\_P0121\_P012B\_P1101 SCIAP1 Residual Weight Factor based on RPM

Notes																	
y/x	0	1,500	2,200	2,500	2,800	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,500	6,500	7,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

# 13 OBDG02A Engine Diagnostics Supporting Table - P0234\_P0299\_EnableDelay

					_					
Description:										
Notes:										
y/x	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	6,000
1	1.750	1.500	1.375	1.125	1.000	0.875	0.750	0.625	0.500	0.500

# 13 OBDG02A Engine Diagnostics Supporting Table - P0806 EngTorqueThreshold Table

<b>Description:</b> The diagnostic is inhibited if torque (NM) is less than this value. Prevents false fails in regions where false in-gear N/TOS ratios are possible due to low torque, where high torque would otherwise cause slip and prevent a valid in-gear state.																	
Notes: DTCs: P0806; Calibration Name: KtMTCI_M_TorqueEnable; Axis is Percent Clutch Pedal Position (%), 0% = bottom of pedal travel.																	
y/x	0.00	6.25	12.50	18.75	25.00	31.25	37.50	43.75	50.00	56.25	62.50	68.75	75.00	81.25	87.50	93.75	100.00
1	10.0	10.0	15.0	25.0	30.0	50.0	50.0	60.0	70.0	75.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

# 13 OBDG02A Engine Diagnostics Supporting Table - P0806 ResidualErrEnableLow Table

Description: Repre	sents the lower thres	hold of a deadband w	here the diagnostic v	vill be inhibited to prev	vent false fails due to	clutch slip that can fa	lsely indicate a valid i	n-gear N/TOS ratio.
Notes: DTCs: P080	6; Calibration Name:	KaMTCI_Pct_ResidE	ErrCalcEnbLow; Axis	identifies Gear, where	e "0" - "5" is gear 1 - 6	6, respectively; "6" is	reverse and "7" is neu	ıtral
y/x	0	1	2	3	4	5	6	7
1	100.0	100.0	100.0	100.0	100.0	100.0	100.0	100.0

## Supporting Table - Closed Loop Enable Clarification - KaFCLP\_U\_SlphrIntglOfst\_Thrsh

Description: Integral Offset voltage thresholds (bank and cell specific cals) used with KeFCLP\_Pct\_CatAccuSlphrPostDsbl to check for sulphur poisoning.

Notes: millivolts		
y/x	CiOXYR_O2_PostCat1	CiOXYR_O2_PostCat2
CiFCLP_Decel	2,048	2,048
CiFCLP_Idle	2,048	2,048
CiFCLP_Cruise	2,048	2,048
CiFCLP_LightAccel	2,048	2,048
CiFCLP_HeavyAccel	2,048	2,048

	Supporting	Table - P0128_Ma	aximum Accumu	Ilated Energy for	r Start-up ECT co	onditions - Primar	У
Description:	Maximum Total Energy tr	ansferred to Cooling Sys	tem for Ambient and S	tart-up ECT conditions	(Primary Test)		
Notes: Z axis	is the cooling system ene	ergy failure threshold (kJ	), X axis is ECT Tempe	erature at Power up (° C	c) , (Deluxe version)		
y/x	-20	-5	10	30	45	60	75
1	17,000	15,200	13,400	11,000	9,200	7,400	5,600

	Supporting 1	Fable - P0128_Ma	ximum Accumu	lated Energy fo	r Start-up ECT co	nditions - Alterna	te
Description:	Maximum Total Energy tra	ansferred to Cooling Sys	stem for Ambient and S	Start-up ECT conditions	s (Alternate Test)		
Notes: Z axis	is the cooling system ene	ergy failure threshold (kJ	), X axis is ECT Tempe	erature at Power up (°	C), (Deluxe version)		
y/x	-20	-5	10	30	45	60	75
1	15,000	13,200	11,400	9,000	7,200	5,400	3,600

### Supporting Table - P1400\_ColdStartDiagnosticDelayBasedOnEngineRunTime

**Description:** Quality weight-based on engine run time. This allows adjustment of the weighting factors at various engine run times in order to prevent the updating of the cumulative quality timer or to change the value of the average qualified residual energy calculation to prevent false Fails of the diagnostic under circumstances inappropriate to update the calculation of the average qualified residual value.

**Notes:** KtCSED\_K\_TimeWght - This is used for P1400.

y/x	0	2	3	4	7	10	15	20	30
1	0	0	1	1	1	1	1	1	1

# 13 OBDG02A Engine Diagnostics Supporting Table - P1400\_ColdStartDiagnosticDelayBasedOnEngineRunTimeCalAxis

Description: This	is the x-axis for the	e KtCSED_K_Time	Wght calibration tal	ole. Refer to the de	escription for KtCSE	ED_K_TimeWght fo	r details.		
Notes: KnCSED_	t_TimeWght - This	is used for P1400.							
y/x	1	2	3	4	5	6	7	8	9
1	0	2	3	4	7	10	15	20	30

## Supporting Table - P0011\_CamPosErrorLimIc1

#### **Description:** P0011 - Cam Position Error Limit for performance diagnostic

**Notes:** KtPHSD\_phi\_CamPosErrorLimIc1

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

# Supporting Table - P0014\_CamPosErrorLimEc1

Description: P0014 - Cam Position Error Limit for performance diagnostic

Notes: KtPHSD\_phi\_CamPosErrorLimEc1

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

## Supporting Table - P0021\_CamPosErrorLimIc2

#### Description: P0021 - Cam Position Error Limit for performance diagnostic

**Notes:** KtPHSD\_phi\_CamPosErrorLimIc2

Notes.		phi_CamPo															
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

# Supporting Table - P0024\_CamPosErrorLimEc2

#### Description: P0024 - Cam Position Error Limit for performance diagnostic

**Notes:** KtPHSD\_phi\_CamPosErrorLimEc2

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

152

8.0

8.0 8.0

8.0

8.0

8.0 8.0

8.0

8.0 8.0

8.0

8.0

8.0

8.0

8.0

8.0 8.0

# Supporting Table - P0011\_StablePositionTimeIc1

#### Description: P0011 - Delay after transient move

Descri		IT Delay														
Notes:	KtPHSD_	t_StablePo	ositionTime	lc1												
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140
400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
1,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
1,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
2,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
2,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
2,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
3,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
3,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
4,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
4,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
4,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
5,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
5,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
6,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
6,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0
6,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0

# Supporting Table - P0014\_StablePositionTimeEc1

#### Description: P0014 - Delay after transient move

<b>Notes:</b> KtPHSD_t_StablePositionTimeEc1
--

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
1,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
1,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
3,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
3,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0

# Supporting Table - P0021\_StablePositionTimeIc2

#### Description: P0021 - Delay after transient move

<b>Notes:</b> KtPHSD_t_StablePositionTimeIc2
--

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
1,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
1,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
2,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
2,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
2,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
3,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
3,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
4,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
4,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
4,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
5,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
5,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
6,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
6,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
6,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0

# Supporting Table - P0024\_StablePositionTimeEc2

#### Description: P0024 - Delay after transient move

Notes: KtPHSD_t_StablePositionTime	Ec2
------------------------------------	-----

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
1,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
1,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
2,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
2,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
2,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
3,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
3,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
4,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
4,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
4,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
5,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
5,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
6,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
6,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0
6,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	8.0	10.0

## Supporting Table - P0401\_StepSamplesPerTrip

Description: P04	Description: P0401 - Maximum number of samples per trip after a step change													
Notes: KtEGRD_	Notes: KtEGRD_Cnt_StepSamplesPerTrip													
y/x	x 65 70 75 80 85 90 95 100 105													
1	8	7	7	6	6	6	5	5	5					

# 13 OBDG02A Engine Diagnostics Supporting Table - P0401 StepDelta

Г

Supporting Table - P0401_StepDelta														
Description: P04	Description: P0401 - Minimum difference between MAPDIFF and EWMA to trigger multiple tests for step change.													
Notes: KtEGRD_	Notes: KtEGRD_p_StepDelta													
y/x	/x 65 70 75 80 85 90 95 100 105													
1	1.9	2.0	2.1	2.2	2.3	2.5	2.7	3.0	3.2					

# 13 OBDG02A Engine Diagnostics Supporting Table - P0401 StepMAP DIFF

Description: P04	Description: P0401 - Minimum value of MAPDIFF to trigger multiple tests for step change.													
Notes: KtEGRD	Notes: KtEGRD_p_StepMAP_DIFF													
y/x	x 65 70 75 80 85 90 95 100 105													
1	0.3	0.4	0.5	0.6	0.8	0.8	0.8	0.8	0.8					

## Supporting Table - P0401\_SamplesAfterStep

Г

Description: P04	Description: P0401 - Total number of samples needed after a step change.													
Notes: KtEGRD_	Notes: KtEGRD_Cnt_SamplesAfterStep													
y/x	<ul> <li>65</li> <li>70</li> <li>75</li> <li>80</li> <li>85</li> <li>90</li> <li>95</li> <li>100</li> <li>105</li> </ul>													
1	46	42	39	36	34	32	30	29	28					

## Supporting Table - P0401\_SamplesAfterReset

Description: P04	Description: P0401 - Total number of samples allowed after a reset.													
Notes: KtEGRD_	lotes: KtEGRD_Cnt_SamplesAfterReset													
y/x	65	70	75	80	85	90	95	100	105					
1	36	31	26	21	16	15	13	12	10					

# 13 OBDG02A Engine Diagnostics Supporting Table - P0011\_PerfMaxIc1

Descr	Description: P0011 - Range of phaser travel where diagnostic cannot make a decision if both desired & measured positions are greater than																
Notes	:																
y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
2	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
3	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
1	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
5	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
6	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
7	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
}	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
)	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
0	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
1	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
2	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
3	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
4	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
5	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
6	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
17	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0

# 13 OBDG02A Engine Diagnostics Supporting Table - P0014\_PerfMaxEc1

Descr	iption: P00	14 - Range	e of phase	r travel whe	ere diagnos	tic cannot	make a de	cision if bo	oth desired	& measure	ed position	s are great	ter than				
Notes	:																
y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
2	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
3	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
4	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
5	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
6	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
7	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
8	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
9	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
10	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
11	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
12	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
13	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
14	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
15	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
16	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
17	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5

13 OBDG02A Engine Diagnostics Supporting Table - P0021\_PerfMaxIc2

Descri	ption:																
Notes:																	
//x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
2	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
3	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
1	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
5	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
6	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
7	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
}	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
)	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
10	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
11	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
12	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
13	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
14	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
5	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
6	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
17	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0

13 OBDG02A Engine Diagnostics Supporting Table - P0021\_PerfMaxEc2

Descri	iption:																
Notes	:																
//x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
2	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
3	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
1	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
3	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
7	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
3	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
)	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
10	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
11	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
12	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
13	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
14	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
15	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
16	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
17	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5

# 13 OBDG02A Engine Diagnostics Supporting Table - P0016 P0017 P0018 P0019 Cam Correlation Oil Temperature Threshold

Descript	ion: KtEP	SI_t_RtnHc	omeDlyLm	t													
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	300.0	300.0	160.0	18.0	18.0	18.0	18.0	10.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0

Suppo	orting 7	Table - I	P0442: I	Engine O	off Time	e Before	Vehicle	Off Ma	aximum	i as a Fi	unction	of Estin	nated A	mbient	Temper	rature T	able
			e Off Time ïmeBefVeł	Before Vehi	cle Off M	aximum Tat	ole (in seco	nds) and .	Axis is Est	imated Am	bient Coola	ant in Deg (	C				
					10	10	04	00	25	4.4	40	50	50	<b>C</b> 2	00	74	00
y/x 1	-10 44	-4	1	1	68	18 82	24 105	29 153	35 320	41	46 480	52 480	58 480	63 480	69 480	74 480	80 480

Description: Data is Purge Valve Leak Test Engine Vacuum Test Time (in seconds) and Axis is Fuel Level in %         Notes: KtEVPD_t_PVLT_EngineVacTimeCold         v/x       0       6       12       19       25       31       37       44       50       56       62       69       75       81       87       94	Su	ipporti	ng Table	e - P049	6: Purge	e Valve	Leak Te	est Engi	ne Vac	uum Te	st Time	(Cold S	tart) as	a Func	tion of F	uel Lev	vel Tabl	Ð
y/x 0 6 12 19 25 31 37 44 50 56 62 69 75 81 87 94						ne Vacuur	n Test Time	e (in second	ds) and A	xis is Fuel I	_evel in %							
1 100 100 80 75 70 65 60 60 60 60 60 55 50 45 40 30	y/x	0	6	12	19	25	31	37	44	50	56	62	69	75	81	87	94	100 30

# 13 OBDG02A Engine Diagnostics Supporting Table - P0461, P2066, P2636: Transfer Pump Enable Time Table

Des	cripti	on: D	ata is	Trans	sferPu	ımpOr	nTime	Limit	(in se	conds	) and	Axis	is Fue	l Leve	el in %	6																	
Note	es: Kt	FLVC	_t_Xf	erFue	IPmp	OnTm	Lim																										
y/x	0	3	6	9	13	16	19	22	25	28	31	34	38	41	44	47	50	53	56	59	63	66	69	72	75	78	81	84	88	91	94	97	100
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

# 13 OBDG02A Engine Diagnostics Supporting Table - P219A Variance Threshold Bank1 Table

Notes	DTCs: P2	19A; Calib	oration Nan	ne: KtFABD	0_U_VarTh	resh1; Ho	rizontal ax	s is RPM;	Vertical Ax	is is Air Pe	r Cylinder	(APC) in m	g/cylinder				
/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,500	4,000	4,500	5,000	6,000
.0	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	8.75	8.75	11.25	11.25	14.25
30	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	8.75	8.75	11.25	11.25	14.25	14.25	17.00
20	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	8.75	8.75	11.25	11.25	14.25	14.25	17.00	17.00	22.50
160	5.75	5.75	5.75	5.75	5.75	5.75	8.75	8.75	11.25	11.25	14.25	14.25	17.00	17.00	22.50	22.50	28.25
200	8.75	8.75	8.75	8.75	8.75	8.75	11.25	11.25	14.25	14.25	17.00	17.00	22.50	22.50	28.25	28.25	33.75
40	11.25	11.25	11.25	11.25	11.25	11.25	14.25	14.25	17.00	17.00	22.50	22.50	28.25	28.25	33.75	33.75	39.50
280	14.25	14.25	14.25	14.25	14.25	14.25	17.00	17.00	22.50	22.50	28.25	28.25	33.75	33.75	39.50	39.50	45.00
320	17.00	17.00	17.00	17.00	17.00	17.00	22.50	22.50	28.25	28.25	33.75	33.75	39.50	39.50	45.00	45.00	50.75
360	22.50	22.50	22.50	22.50	22.50	22.50	28.25	28.25	33.75	33.75	39.50	39.50	45.00	45.00	50.75	50.75	56.25
100	28.25	28.25	28.25	28.25	28.25	28.25	33.75	33.75	39.50	39.50	45.00	45.00	50.75	50.75	56.25	56.25	62.00
40	33.75	33.75	33.75	33.75	33.75	33.75	39.50	39.50	45.00	45.00	50.75	50.75	56.25	56.25	62.00	62.00	67.50
80	39.50	39.50	39.50	39.50	39.50	39.50	45.00	45.00	50.75	50.75	56.25	56.25	62.00	62.00	67.50	67.50	67.50
520	45.00	45.00	45.00	45.00	45.00	45.00	50.75	50.75	56.25	56.25	62.00	62.00	67.50	67.50	67.50	67.50	67.50
60	50.75	50.75	50.75	50.75	50.75	50.75	56.25	56.25	62.00	62.00	67.50	67.50	67.50	67.50	67.50	67.50	67.50
40	56.25	56.25	56.25	56.25	56.25	56.25	62.00	62.00	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50
20	62.00	62.00	62.00	62.00	62.00	62.00	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50
300	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50

# 13 OBDG02A Engine Diagnostics Supporting Table - P219B Variance Threshold Bank2 Table

Descr	iption: Ban	k 2 lookup	table of Va	riance met	tric used to	calculate t	he Ratio fo	or the curre	ent sample	period							
Notes	: DTCs: P2	19A; Calib	oration Nam	e: KtFABD	_U_VarTh	resh2; Ho	rizontal axi	s is RPM;	Vertical Ax	is is Air Pe	r Cylinder (	(APC) in m	g/cylinder				
y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,500	4,000	4,500	5,000	6,000
40	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	8.75	8.75	11.25	11.25	14.25
80	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	8.75	8.75	11.25	11.25	14.25	14.25	17.00
120	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	8.75	8.75	11.25	11.25	14.25	14.25	17.00	17.00	22.50
160	5.75	5.75	5.75	5.75	5.75	5.75	8.75	8.75	11.25	11.25	14.25	14.25	17.00	17.00	22.50	22.50	28.25
200	8.75	8.75	8.75	8.75	8.75	8.75	11.25	11.25	14.25	14.25	17.00	17.00	22.50	22.50	28.25	28.25	33.75
240	11.25	11.25	11.25	11.25	11.25	11.25	14.25	14.25	17.00	17.00	22.50	22.50	28.25	28.25	33.75	33.75	39.50
280	14.25	14.25	14.25	14.25	14.25	14.25	17.00	17.00	22.50	22.50	28.25	28.25	33.75	33.75	39.50	39.50	45.00
320	17.00	17.00	17.00	17.00	17.00	17.00	22.50	22.50	28.25	28.25	33.75	33.75	39.50	39.50	45.00	45.00	50.75
360	22.50	22.50	22.50	22.50	22.50	22.50	28.25	28.25	33.75	33.75	39.50	39.50	45.00	45.00	50.75	50.75	56.25
400	28.25	28.25	28.25	28.25	28.25	28.25	33.75	33.75	39.50	39.50	45.00	45.00	50.75	50.75	56.25	56.25	62.00
440	33.75	33.75	33.75	33.75	33.75	33.75	39.50	39.50	45.00	45.00	50.75	50.75	56.25	56.25	62.00	62.00	67.50
480	39.50	39.50	39.50	39.50	39.50	39.50	45.00	45.00	50.75	50.75	56.25	56.25	62.00	62.00	67.50	67.50	67.50
520	45.00	45.00	45.00	45.00	45.00	45.00	50.75	50.75	56.25	56.25	62.00	62.00	67.50	67.50	67.50	67.50	67.50
560	50.75	50.75	50.75	50.75	50.75	50.75	56.25	56.25	62.00	62.00	67.50	67.50	67.50	67.50	67.50	67.50	67.50
640	56.25	56.25	56.25	56.25	56.25	56.25	62.00	62.00	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50
720	62.00	62.00	62.00	62.00	62.00	62.00	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50
800	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50

# 13 OBDG02A Engine Diagnostics Supporting Table - P219A Quality Factor Bank1 Table

Descri	intion <sup>.</sup> Bar	k 1 lookun	table of Qu	ality Facto	ors used in	the calcula	tion of the	Ratio for t	ne current	sample ne	riod						
Notes	: DTCs: P2	19A; Calib	oration Nam	e: KtFABD	_K_QualFa	actor1; Ho	rizontal ax	is is RPM;	Vertical Ax	tis is Air Pe	er Cylinder	(APC) in n	ng/cylinder				
/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,500	4,000	4,500	5,000	6,000
0	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
0	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
200	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
280	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
320	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
860	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
80	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
520	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
300	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

# Supporting Table - P219B Normalizer Bank2 Table

Descri	i <b>ption:</b> Banl	k 2 Norma	lizer table	used in the	calculation	n of the Ra	tio for the o	current sar	nple period								
Notes	DTCs: P21	19B; Calib	ration Nam	ne: KtFABD	_U_Norma	alizer2; Ho	orizontal ax	is is RPM;	Vertical Ax	is is Air Pe	er Cylinder	(APC) in m	ıg/cylinder				
y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,500	4,000	4,500	5,000	6,000
40	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	8.75	8.75	11.25	11.25	14.25
80	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	8.75	8.75	11.25	11.25	14.25	14.25	17.00
120	5.75	5.75	5.75	5.75	5.75	5.75	5.75	5.75	8.75	8.75	11.25	11.25	14.25	14.25	17.00	17.00	22.50
160	5.75	5.75	5.75	5.75	5.75	5.75	8.75	8.75	11.25	11.25	14.25	14.25	17.00	17.00	22.50	22.50	28.25
200	8.75	8.75	8.75	8.75	8.75	8.75	11.25	11.25	14.25	14.25	17.00	17.00	22.50	22.50	28.25	28.25	33.75
240	11.25	11.25	11.25	11.25	11.25	11.25	14.25	14.25	17.00	17.00	22.50	22.50	28.25	28.25	33.75	33.75	39.50
280	14.25	14.25	14.25	14.25	14.25	14.25	17.00	17.00	22.50	22.50	28.25	28.25	33.75	33.75	39.50	39.50	45.00
320	17.00	17.00	17.00	17.00	17.00	17.00	22.50	22.50	28.25	28.25	33.75	33.75	39.50	39.50	45.00	45.00	50.75
360	22.50	22.50	22.50	22.50	22.50	22.50	28.25	28.25	33.75	33.75	39.50	39.50	45.00	45.00	50.75	50.75	56.25
400	28.25	28.25	28.25	28.25	28.25	28.25	33.75	33.75	39.50	39.50	45.00	45.00	50.75	50.75	56.25	56.25	62.00
440	33.75	33.75	33.75	33.75	33.75	33.75	39.50	39.50	45.00	45.00	50.75	50.75	56.25	56.25	62.00	62.00	67.50
480	39.50	39.50	39.50	39.50	39.50	39.50	45.00	45.00	50.75	50.75	56.25	56.25	62.00	62.00	67.50	67.50	67.50
520	45.00	45.00	45.00	45.00	45.00	45.00	50.75	50.75	56.25	56.25	62.00	62.00	67.50	67.50	67.50	67.50	67.50
560	50.75	50.75	50.75	50.75	50.75	50.75	56.25	56.25	62.00	62.00	67.50	67.50	67.50	67.50	67.50	67.50	67.50
640	56.25	56.25	56.25	56.25	56.25	56.25	62.00	62.00	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50
720	62.00	62.00	62.00	62.00	62.00	62.00	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50
800	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50	67.50

# 13 OBDG02A Engine Diagnostics Supporting Table - P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage

Description: Identifies which Long	Term Fuel Trim Cell I.D.s are used for c	liagnosis. Only cells identified as "CeF	ADD_e_NonSelectedCell" are not use	d for diagnosis.
Notes: DTCs: P0171, P0172, P017	4, P0175; Calibration Name: KaFADD	_e_SelectCellSet; Axis is Long Term F	uel Trim Cell I.D.	
P0171_P0172_P0174_P0175 Long	g-Term Fuel Trim Cell Usage - Part 1			
y/x	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR_e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell
P0171_P0172_P0174_P0175 Long	g-Term Fuel Trim Cell Usage - Part 2			
y/x	CeFADR_e_Cell04_PurgOnAirMode	CeFADR_e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_NonSelectedCell
P0171_P0172_P0174_P0175 Long	g-Term Fuel Trim Cell Usage - Part 3			
y/x	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR_e_Cell10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell
P0171_P0172_P0174_P0175 Long	g-Term Fuel Trim Cell Usage - Part 4			
y/x	CeFADR_e_Cell12_PurgOffAirMode	CeFADR_e_Cell13_PurgOffAirMode	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_NonSelectedCell

Bundle Name: 5VoltReferenceA_FA
P0641
Bundle Name: 5VoltReferenceB_FA
P0651
Bundle Name: 5VoltReferenceMAP_OOR_FIt
P0697
Bundle Name: A/F Imbalance Bank1
P219A
Bundle Name: A/F Imbalance Bank2
P219B
Bundle Name: AAP_SnsrCktFP
Naturally aspirated: P2228, P2229. Turbocharged: P0237, P0238
Bundle Name: AAP_SnsrFA
Naturally Aspirated: P2227, P2228, P2229, P2230. Turbocharged: P0237, P0238.
Bundle Name: AAP_SnsrTFTKO
Naturally Aspirated: P2227, P2228, P2229, P2230. Turbocharged: P0237, P0238.
Bundle Name: AAP2_SnsrCktFP
P2228, P2229
Bundle Name: AAP2_SnsrFA
P2227, P2228, P2229, P2230
Bundle Name: AAP2_SnsrTFTKO
P2227, P2228, P2229, P2230
Bundle Name: AccCktLo_FA
P2537
Bundle Name: AcceleratorPedalFailure
P2122, P2123, P2127, P2128, P2138, P0697, P06A3
Bundle Name: ACCMLostComm
U016B
Bundle Name: ACFailedOnSD
See ACCM Document
Bundle Name: ACHighSidePressSnsrCktFA
P0532, P0533
Bundle Name: ACThrmlRefrigSpdVld
See ACCM Document
Bundle Name: AfterThrottlePressTFTKO
Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.
Bundle Name: AfterThrottlePressureFA
Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.

Fault Bundle Definitions

Γ

Fault Bundle Definitions
Bundle Name: AfterThrottleVacuumTFTKO
Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.
Bundle Name: AIR System FA
P0411, P2440, P2444
Bundle Name: AIRPumpControlCircuit FA
P0418
Bundle Name: AIRSystemPressureSensor FA
P2430, P2431, P2432, P2433, P2435, P2436, P2437, P2438
Bundle Name: AIRValveControlCircuit FA
P0412
Bundle Name: AmbientAirDefault
Baro Sensor Present: P2227, P2228, P2229, P2230. No Baro Sensor Present: P0101, P0102, P0103, P0106, P0107, P0108, P0111, P0112, P0113, P0114, P0121, P0122, P0123, P012B, P012C, P012D, P0222, P0223, P1221
Bundle Name: AmbPresDfltdStatus
Baro Sensor Present: P2227, P2228, P2229, P2230. No Baro Sensor Present: P0101, P0102, P0103, P0106, P0107, P0108, P0111, P0112, P0113, P0114, P0121, P0122, P0123, P012B, P012C, P012D, P0222, P0223, P1221
Bundle Name: AmbPresSnsrCktFA
P2228, P2229
Bundle Name: AmbPresSnsrCktFP
P2228, P2229
Bundle Name: AnyCamPhaser_FA
P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024
Bundle Name: AnyCamPhaser_TFTKO
P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024
Bundle Name: BrakeBoosterSensorFA
P0556, P0557, P0558
Bundle Name: BrakeBoosterVacuumValid
P0556, P0557, P0558
Bundle Name: BSTR_b_ExcsvBstFA
P226B
Bundle Name: BSTR_b_ExcsvBstTFTKO
P226B
Bundle Name: BSTR_b_IC_PmpCktFA
P023A, P023C
Bundle Name: BSTR_b_PCA_CktFA
P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P0247, P0249, P0250
Bundle Name: BSTR_b_PCA_CktLoFA

P0034, P0047, P0245, P0249
Bundle Name: BSTR_b_PCA_CktLoTFTKO
P0034, P0047, P0245, P0249
Bundle Name: BSTR_b_PCA_CktTFTKO
P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P0247, P0249, P0250
Bundle Name: BSTR_b_PCA_FA
P0234, P0299, P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P2261, P0247, P0249, P0250
Bundle Name: BSTR_b_PCA_PstnSnsrFA
P003A, P2564, P2565
Bundle Name: BSTR_b_PCA_PstnSnsrTFTKO
P003A, P2564, P2565
Bundle Name: BSTR_b_PCA_TFTKO
P0234, P0299, P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P2261, P0247, P0249, P0250
Bundle Name: BSTR_b_PresCntrlTooHiFA
P0234
Bundle Name: BSTR_b_PresCntrlTooHiTFTKO
P0234
Bundle Name: BSTR_b_PresCntrlTooLoFA
P0299
Bundle Name: BSTR_b_PresCntrlTooLoTFTKO
P0299
Bundle Name: BSTR_b_PstnCntrlFA
P166D, P166E
Bundle Name: BSTR_b_PstnCntrlTooHiFA
P166E
Bundle Name: BSTR_b_PstnCntrlTooHiTFTKO
P166E
Bundle Name: BSTR_b_PstnCntrlTooLoFA
P166D
Bundle Name: BSTR_b_PstnCntrlTooLoTFTKO
P166D
Bundle Name: BSTR_b_TurboBypassCktFA
P0033, P0034, P0035, P00C0, P00C1, P00C2
Bundle Name: BSTR_b_TurboBypassCktTFTKO
P0033, P0034, P0035, P00C0, P00C1, P00C2
Bundle Name: BSTR_b_TurboBypB_CktFA
P00C0, P00C1, P00C2
Bundle Name: BSTR_b_TurboBypB_CktTFTKO

P00C0, P00C1, P00C2
Bundle Name: CamLctnExhFA
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: CamLctnIntFA
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: CamSensor_FA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensor_TFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorAnyLctnTFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorAnyLocationFA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorFA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorTFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CatalystSysEfficiencyLoB1_FA
P0420
Bundle Name: CatalystSysEfficiencyLoB2_FA
P0430
Bundle Name: ClutchPstnSnsr FA
P0806, P0807, P0808
Bundle Name: ClutchPstnSnsrCktHi FA
P0808
Bundle Name: ClutchPstnSnsrCktLo FA
P0807
Bundle Name: ClutchPstnSnsrNotLearned
P080A
Bundle Name: CoolingFanSpeedTooHigh_FA
P0495
Bundle Name: CrankCamCorrelationTFTKO
P0016, P0017, P0018, P0019
Bundle Name: CrankExhaustCamCorrelationFA
P0017, P0019
Bundle Name: CrankExhaustCamCorrFA
P0017, P0019
Bundle Name: CrankIntakeCamCorrelationFA

P0016, P0018
Bundle Name: CrankIntakeCamCorrFA
P0016, P0018
Bundle Name: CrankSensor_FA
P0335, P0336
Bundle Name: CrankSensor_TFTKO
P0335, P0336
Bundle Name: CrankSensorFA
P0335, P0336
Bundle Name: CrankSensorFaultActive
P0335, P0336
Bundle Name: CrankSensorTestFailedTKO
P0335, P0336
Bundle Name: CrankSensorTFTKO
P0335, P0336
Bundle Name: CylDeacSystemTFTKO
P3400
Bundle Name: CyInderDeacDriverTFTKO
P3401, P3409, P3417, P3425, P3433, P3441, P3449
Bundle Name: ECT_Sensor_Ckt_FA
P0117, P0118, P0119
Bundle Name: ECT_Sensor_Ckt_FP
P0117, P0118
Bundle Name: ECT_Sensor_Ckt_High_FP
P0118
Bundle Name: ECT_Sensor_Ckt_Low_FP
P0117
Bundle Name: ECT_Sensor_Ckt_TFTKO
P0117, P0118, P0119
Bundle Name: ECT_Sensor_Ckt_TPTKO
P0117, P0118, P0019
Bundle Name: ECT_Sensor_DefaultDetected
P0117, P0118, P0116, P0125
Bundle Name: ECT_Sensor_FA
P0117, P0118, P0116, P0125, P0128
Bundle Name: ECT_Sensor_Perf_FA
P0116
Bundle Name: ECT_Sensor_TFTKO

P0117, P0118, P0116, P0125, P0119
Bundle Name: EGRValve_FP
P0405, P0406, P042E
Bundle Name: EGRValveCircuit_FA
P0403, P0404, P0405, P0406
Bundle Name: EGRValveCircuit_TFTKO
P0403, P0404, P0405, P0406
Bundle Name: EGRValvePerformance_FA
P0401, P042E
Bundle Name: EGRValvePerformance_TFTKO
P0401, P042E
Bundle Name: EngineMetalOvertempActive
P1258
Bundle Name: EngineMisfireDetected_FA
P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308
Bundle Name: EngineMisfireDetected_TFTKO
P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308
Bundle Name: EngineModeNotRunTimer_FA
P2610
Bundle Name: EngineModeNotRunTimerError
P2610
Bundle Name: EnginePowerLimited
P0068, P0122, P0123, P0222, P0223, P0601, P0604, P0606, P1682, P16F3, P1104, P2100, P2101, P2102, P2103, P2176, P160E, P160D, P0191, P0192, P0193, P00C8, P00C9, P16A0, P16A1, P16A2
Bundle Name: EngineTorqueEstInaccurate
EngineMisfireDetected_FA, FueIInjedtorCircuit_FA, FueIInjedtorCircuit_TFTKO, FueITrimSystemB1_FA, FueITrimSystemB2_FA, MAF_SensorTFTKO, MAP_SensorTFTKO, EGRValuePerforamnce_FA
Bundle Name: EngModeNotRunTmErr
P2610
Bundle Name: EngOilModeledTempValid
ECT_Sensor_FA, IAT_SensorCircuitFA
Bundle Name: EngOilPressureSensorCktFA
P0522, P0523
Bundle Name: EngOilPressureSensorFA
P0521, P0522, P0523
Bundle Name: EngOilTempFA
EngOilTempSensorCircuitFA, EngOilModeledTempValid, P16F3
EngOilTempFA - Other Definitions: P16F3 with GetXOYR_b_SecurityFlt(CeXOYR_e_EOTR_SecurityFlt)

Bundle Name: EngOilTempSensorCircuitFA
P0197, P0198
Bundle Name: Ethanol Composition Sensor FA
P0178, P0179, P2269
Bundle Name: EvapExcessPurgePsbl_FA
Conventional fuel system, P0442, P0455, P0458, P0496
Bundle Name: EvapPurgeSolenoidCircuit_FA
P0443, P0458, P0459
Bundle Name: EvapReducedPurgePsbl_FA
Only EREV sealed fuel system, P0443, P0446, P0449, P0459, P0497, P0499, P2419, P2422
Bundle Name: EvapVentSolenoidCircuit_FA
P0449, P0498, P0499
Bundle Name: ExhaustCamSensor_FA
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: ExhaustCamSensor_TFTKO
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: ExhaustCamSensorFA
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: ExhaustCamSensorTFTKO
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: FanOutputDriver_FA
P0480, P0481, P0482, P0691, P0692, P0693, P0694, P0695, P0696, P1485 (EREV), P1486 (EREV), P1487 (EREV)
Bundle Name: FHPD_b_HPC_PresErrNeg_FA
P228D
Bundle Name: FHPD_b_HPC_PresErrNeg_TFTKO
P228D
Bundle Name: FHPD_b_HPC_PresErrPos_FA
P228C
Bundle Name: FHPD_b_HPC_PresErrPos_TFTKO
P228C
Bundle Name: FHPD_b_HPC_Windup_ TFTKO
P0089
Bundle Name: FHPD_b_HPC_Windup_FA
P0089
Bundle Name: FHPD_b_PumpCurr_FA
P163A
Bundle Name: FHPD_b_PumpCurr_TFTKO
P163A

Bundle Name: FHPR_b_FRP_SnsrCkt_FA
P0192, P0193
Bundle Name: FHPR_b_FRP_SnsrCkt_TFTKO
P0192, P0193
Bundle Name: FHPR_b_FRP_SnsrPerfDiag_FA
P0191
Bundle Name: FHPR_b_FRP_SnsrPerfDiag_TFTKO
P0191
Bundle Name: FHPR_b_PumpCkt_FA
P0090, P0091, P0092, P00C8, P00C9, P00CA
Bundle Name: FHPR_b_PumpCkt_TFTKO
P0090, P0091, P0092, P00C8, P00C9, P00CA
Bundle Name: FuelInjectorCircuit_FA
P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P02074, P0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216E, P217B, P217E, P2148, P2151, P2154, P2157, P216C, P216F, P217C, P217F, P1248, P1248, P1249, P124A, P124B, P124C, P124D, P124E, P124F
Bundle Name: FuelInjectorCircuit_TFTKO
P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P02074, P0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216E, P217B, P217E, P2148, P2151, P2154, P2157, P216C, P216F, P217C, P217F, P1248, P1248, P1249, P124A, P124B, P124C, P124D, P124E, P124F
Bundle Name: FuelLevelDataFault
P0461, P0462, P0463, P2066, P2067, P2068
Bundle Name: FuelTrimSystemB1_FA
P0171, P0172
Bundle Name: FuelTrimSystemB1_TFTKO
P0171, P0172
Bundle Name: FuelTrimSystemB2_FA
P0174, P0175
Bundle Name: FuelTrimSystemB2_TFTKO
P0174, P0175
Bundle Name: HumidityFA
P0097, P0098, P11C2, P11C3, P2227, P2228, P2229, P2230
Bundle Name: HumTempSnsrCktFA
P0097, P0098
Bundle Name: HumTempSnsrCktFP
P0097, P0098
Bundle Name: HumTempSnsrFA
P0096, P0097, P0098, P0099
Bundle Name: IAC_SystemRPM_FA

P0506, P0507
Bundle Name: IAT_ContCorrFA
P2199
Bundle Name: IAT_SensorCircuitFA
P0112, P0113
Bundle Name: IAT_SensorCircuitFP
P0112, P0113
Bundle Name: IAT_SensorCircuitTFTKO
P0112, P0113
Bundle Name: IAT_SensorFA
P0111, P0112, P0113, P0114
Bundle Name: IAT_SensorTFTKO
P0111, P0112, P0113, P0114
Bundle Name: IgnitionOffTimer_FA
P2610
Bundle Name: IgnitionOffTimeValid
P2610
Bundle Name: IgnitionOutputDriver_FA
P0351, P0352, P0353, P0354, P0355, P0356, P0357, P0358
Bundle Name: IntakeCamSensor_FA
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntakeCamSensor_TFTKO
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntakeCamSensorFA
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntakeCamSensorTFTKO
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntkCamPhaser_FA
P0010, P0011, P0020, P0021
Bundle Name: KS_Ckt_Perf_B1B2_FA
P0324, P0325, P0326, P0327, P0328, P0330, P0332, P0333, P06B6, P06B7
Bundle Name: Long Name
Short Name
Bundle Name: LowFuelConditionDiagnostic
LowFuelConditionDiagnostic - Other Definitions: Flag set to TRUE if the fuel level < 10.0 % AND
No Active DTCs: FuelLevelDataFault, P0462, P0463 for at least 30.0 seconds

Bundle Name: MAF_SensorCircuitFA
P0102, P0103, P010C, P010D
Bundle Name: MAF_SensorCircuitTFTKO
P0102, P0103, P010C, P010D
Bundle Name: MAF_SensorFA
P0101, P0102, P0103, P010C, P010D
Bundle Name: MAF_SensorFP
P0102, P0103, P010C, P010D
Bundle Name: MAF_SensorPerfFA
P0101
Bundle Name: MAF_SensorPerfTFTKO
P0101
Bundle Name: MAF_SensorTFTKO
P0101, P0102, P0103, P010C, P010D
Bundle Name: MAF_SnsrCktFA
P121B, P121C
Bundle Name: MAF_SnsrCktTFTKO
P121B, P121C
Bundle Name: MAP_EngineVacuumStatus
P0106, P0107, P0108 Fault Active OR P0107, P0108 Fault Pending
Bundle Name: MAP_SensorCircuitFA
P0107, P0108
Bundle Name: MAP_SensorCircuitFP
P0107, P0108
Bundle Name: MAP_SensorFA
P0106, P0107, P0108
Bundle Name: MAP_SensorPerfFA
P0106
Bundle Name: MAP_SensorPerfTFTKO
P0106
Bundle Name: MAP_SensorTFTKO
P0106, P0107, P0108
Bundle Name: MnfdTempSensorCktFA
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
Bundle Name: MnfdTempSensorCktFP
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
Bundle Name: MnfdTempSensorCktTFTKO
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.

#### Fault Bundle Definitions

#### Bundle Name: MnfdTempSensorFA

Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.

Bundle Name: MnfdTempSensorTFTKO

Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.

Bundle Name: ModuleOffTime\_FA

P2610

Bundle Name: ModuleOffTimeErr

P2610

Bundle Name: no validity name is assigned to this fault bundle

#### Bundle Name: OAT\_AmbientFilteredFA

ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, IAT\_SensorFA, ECT\_Sensor\_DefaultDetected, MAF\_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, ECT\_Sensor\_DefaultDetected. IAT-Based OAT: not applicable. All other cases: not applicable.

#### Bundle Name: OAT\_AmbientSensorFA

ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, ECT\_Sensor\_DefaultDetected. IAT-Based OAT: not applicable. All other cases: not applicable.

#### Bundle Name: OAT\_PtEstFiltFA

ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, IAT\_SensorFA, ECT\_Sensor\_DefaultDetected, MAF\_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, ECT\_Sensor\_DefaultDetected. IAT-Based OAT: VehicleSpeedSensor\_FA, IAT\_SensorFA, MAF\_SensorFA. All other cases: EngModeNotRunTmErr, VehicleSpeedSensor\_FA, IAT\_SensorFA, ECT\_SensorFA, ECT\_Sensor\_DefaultDetected.

#### Bundle Name: OAT\_PtEstRawFA

ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, ECT\_Sensor\_DefaultDetected. IAT-Based OAT: IAT\_SensorFA. All other cases: IAT\_SensorFA, ECT\_Sensor\_DefaultDetected.

Bundle Name: OilPmpCktFA

P06DA, P06DB, P06DC

OilPmpCktFA - Other Definitions:

Output Driver Codes

Bundle Name: OilPmpFA

P06DA, P06DB, P06DC, P06DD, P06DE

#### OilPmpFA - Other Definitions:

FA only for Output Driver and rationality

Bundle Name: OilPmpStuckHigh

P06DA, P06DB, P06DD

#### OilPmpStuckHigh - Other Definitions:

TFTKO and FA

Bundle Name: OilPmpStuckLow

P06DC, P06DE

OilPmpStuckLow - Other Definitions:

TFTKO and FA
Bundle Name: OilPmpTFTKO
P06DA, P06DB, P06DC, P06DD, P06DE
OilPmpTFTKO - Other Definitions:
TFTKO only for Output Driver and rationality
Bundle Name: PowertrainRelayFault
P1682
Bundle Name: PowertrainRelayStateOn_Error
P0685
Bundle Name: PowertrainRelayStateOn_FA
P0685
Bundle Name: PPS1_OutOfRange
P2122, P2123
Bundle Name: PPS1_OutOfRange_Composite
P2122, P2123, P06A3
Bundle Name: PPS2_OutOfRange
P2127, P2128
Bundle Name: PPS2_OutOfRange_Composite
P2127, P2128, P0697
Bundle Name: SCIAP_SensorCircuitFA
P012C, P012D
Bundle Name: SCIAP_SensorCircuitFP
P012C, P012D
Bundle Name: SCIAP_SensorFA
P012B, P012C, P012D
Bundle Name: SCIAP_SensorPerfFA
P012B
Bundle Name: SCIAP_SensorPerfTFTKO
P012B
Bundle Name: SCIAP_SensorTFTKO
P012B, P012C, P012D
Bundle Name: SuperchargerBypassValveFA
P2261
Bundle Name: SystemVoltageHigh_FA
P0563
Bundle Name: SystemVoltageLow_FA
P0562
Bundle Name: TC_BoostPresSnsrCktFA

P0237, P0238
Bundle Name: TC_BoostPresSnsrFA
P0236, P0237, P0238
Bundle Name: TCM_EngSpdReqCkt
P150C
Bundle Name: THMR_AHV_FA
P2681, P26A3, P26A6, P26A7, P26A9
Bundle Name: THMR_AWP_AuxPumpFA
B2920, B2923, B2922
Bundle Name: THMR_ECT_Sensor_Ckt_FA
P0116, P0117, P0118, P00B6
Bundle Name: THMR_Insuff_Flow_FA
P00B7
Bundle Name: THMR_RCT_Sensor_Ckt_FA
P00B3, P00B4
Bundle Name: THMR_SWP_Control_FA
P261D, P261A, P261C
Bundle Name: THMR_Therm_Control_FA
P0597, P0598, P0599
Bundle Name: ThrotTempSensorFA
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
Bundle Name: ThrotTempSensorTFTKO
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
Bundle Name: ThrottlePositionSnsrPerfFA
P0121
Bundle Name: ThrottlePositionSnsrPerfTFTKO
P0121
Bundle Name: TIAP_SensorPerfFA
P0236
Bundle Name: TPS_FA
P0122, P0123, P0222, P0223, P2135
Bundle Name: TPS_FaultPending
P0122, P0123, P0222, P0223, P2135
Bundle Name: TPS_Performance_FA
P0068, P0121, P1104, P2100, P2101, P2102, P2103
Bundle Name: TPS_Performance_TFTKO

P0068, P0121, P1104, P2100, P2101, P2102, P2103
Bundle Name: TPS_TFTKO
P0122, P0123, P0222, P0223, P2135
Bundle Name: TPS_ThrottleAuthorityDefaulted
P0068, P0122, P0123, P0222, P0223, P16F3, P1104, P2100, P2101, P2102, P2103, P2135
Bundle Name: TPS1_OutOfRange_Composite
P0122, P0123, P06A3
Bundle Name: TPS2_OutOfRange_Composite
P0222, P0223, P06A3
Bundle Name: Trans Output Rotations Rolling Count Validity
Bundle Name: Transfer Pump is Commanded On
Transfer Dump is Commanded On Other Definitions:
<b>Transfer Pump is Commanded On - Other Definitions:</b> Fuel Volume in Primary Fuel Tank < 0.0 liters AND
Fuel Volume in Secondary Fuel Tank ≥ 0.0 liters AND
Transfer Pump on Time < P0461, P2066, P2636: Transfer Pump Enable (see supporting table for numeric value) AND
Transfer Pump had been Off for at least 0.0 seconds AND Evap Diagnostic (Purge Valve Leak Test, Large Leak Test, and Waiting for Purge) is not running AND
Evap Diagnostic (Purge valve Leak Test, Large Leak Test, and Walting for Purge) is not running AND Engine Running
Bundle Name: Transmission Actual Gear Validity
Bundle Name: Transmission Engaged State Validity
Bundle Name: Transmission Estimated Gear Validity
Bundle Name: Transmission Gear Ratio Validity
Bundle Name: Transmission Gear Selector Position Validity
Bundle Name: Transmission Oil Temperature Validity
Bundle Name: Transmission Output Shaft Angular Velocity Validity
Bundle Name: Transmission Overall Actual Torque Ratio Validity
Bundle Name: Transmission Overall Estimated Torque Ratio Validity
Bundle Name: Transmission Shift Lever Position Validity

### Fault Bundle Definitions

Bundle Name: Transmission Turbine Angular Velocity Validity

Bundle Name: TransmissionEngagedState\_FA

MYD/MYC/MYB:, P182E, P1915

Bundle Name: TransmissionGearDefaulted

MYD/MYC/MYB:, P182E, P1915

Bundle Name: VehicleSpeedSensor\_FA

P0502, P0503, P0722, P0723

Bundle Name: VehicleSpeedSensorError

P0502, P0503, P0722, P0723