Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Heater Coolant Pump Control Circuit Open	B269A	Controller specific output driver circuit diagnoses the Heater Coolant Pump Control Circuit low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between signal and controller ground.	Run Crank Ignition in Range Engine not cranking == Above is true and == Last Open Circuit Test	= True = True ========== not Indeterminate	5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips Note: In certian controllers B269C may also set

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Heater Coolant Pump Control Circuit Low	B269C	Controller specific output driver circuit diagnoses the Heater Coolant Pump Control Circuit low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between signal and controller ground	Run Crank Ignition in Range Engine not cranking == Above is true and == Last Open Circuit Test	= True = True ========== not Indeterminate	5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips Note: In certian controllers B269A may also set

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Heater Coolant Pump Control Circuit High	B269D	Controller specific output driver circuit diagnoses the Heater Coolant Pump Control Circuit low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between signal and controller power.	Run Crank Ignition in Range Engine not cranking == Above is true and == Last Open Circuit Test	= True = True ========== not Indeterminate	5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Steering Wheel Angle Sensor Signal Message Counter Incorrect	C1211	This DTC monitors for an error in the Steering Wheel Angle Sensor Signal Message Counter	Communication of the Alive Rolling Count or Protection Value from the Steering Wheel Angle Sensor over CAN bus is incorrect for out of total samples	 >= 8.00 counts >= 10.00 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 10ms loop.	Type C, No SVS "Safety Emissions Neutral Diagnostic"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Open – Bank 1	P0010	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between signal and controller ground.	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Performance – Bank 1	P0011	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated.	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive.	(Intake cam Bank 1) Cam Position Error > (**P0011_CamPosErrorLimIc1**) deg	**Intake Cam Phsr Enable** System Voltage Engine Running Power Take Off (PTO) active Desired cam position Desired AND Measured cam position Desired cam position variation No Active DTCs	= TRUE > 11.00 Volts = TRUE = FALSE > 0 deg > (**P0011_CamPosErrorLimIc1**) deg AND < (**CalculatedPerfMaxIc1**) deg < 7.50 deg for (**P0011_P05CC_StablePositionTimeIc1**) seconds P0010 P2088 P2089	100.00 failures out of 500.00 samples 100 ms /sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)-Camshaft Position (CMP) Correlation Bank 1 Sensor A (end-park phaser)	P0016	Detects cam to crank misalignment by monitoring if the cam sensor pulse for bank 1 sensor A occurs during the incorrect crank position, diagnostic passes when the cam sensor pulse is in the expected range	2 cam sensor pulses less than or greater than nominal position in one cam revolution.	-11.0 Crank Degrees 11.0 Crank Degrees	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic Delay diagnostic if Engine RPM and Cam is Enabled for	 CrankSensor_FA P0340, P0341 < 1.0 seconds > 8,200.00 < 3.00	2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table **P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold** . One sample per cam rotation	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 1	P0030	Controller specific output driver circuit diagnoses the heater output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controllers P0031 may also set

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0031	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controllers P0030 may also set

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0032	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between output and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 2	P0036	Controller specific output driver circuit diagnoses the heater output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controllers P0037 may also set

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0037	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controllers P0036 may also set

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0038	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between output and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 2 Sensor 1	P0050	Controller specific output driver circuit diagnoses the heater output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controllers P0051 may also set

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank2 Sensor1	P0051	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controllers P0050 may also set

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank2 Sensor1	P0052	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between output and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 1	P0053	Detects an oxygen sensor heater having an incorrect or out of range resistance value. This test calculates the heater's resistance (using voltage and current) at engine start after a longer soak condition and compares it to the expected values for the released sensor. This fault is set if the heater resistance is outside the expected range.	Heater Resistance outside of the expected range of	3.1 < ohms < 8.4	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P262B IAT_SensorFA < 8.0 ºC > 28,800 seconds ≥ -30.0 ºC < 32.0 volts < 0.04 seconds	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0054	Detects an oxygen sensor heater having an incorrect or out of range resistance value. This test calculates the heater's resistance (using voltage and current) at engine start after a soak condition and compares it to the expected values for the released sensor. This fault is set if the heater resistance is outside the expected range.	Heater Resistance outside of the expected range of	3.1 < ohms < 8.4	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P262B IAT_SensorFA < 8.0 ºC > 28,800 seconds ≥ -30.0 ºC < 32.0 volts < 0.04 seconds	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 2 Sensor 2	P0056	Controller specific output driver circuit diagnoses the heater output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controllers P0057 may also set

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank2 Sensor2	P0057	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controllers P0056 may also set

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank2 Sensor2	P0058	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between output and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 2 Sensor 1	P0059	Detects an oxygen sensor heater having an incorrect or out of range resistance value.. This test calculates the heater's resistance (using voltage and current) at engine start after a soak condition and compares it to the expected values for the released sensor. This fault is set if the heater resistance is outside the expected range.	Heater Resistance outside of the expected range of	3.4 < ohms < 8.6	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P262B IAT_SensorFA < 8.0 ºC > 28,800 seconds ≥ -30.0 ºC < 32.0 volts < 0.09 seconds	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 2 Sensor 2	P0060	Detects an oxygen sensor heater having an incorrect or out of range resistance value. This test calculates the heater's resistance (using voltage and current) at engine start after a soak condition and compares it to the expected values for the released sensor. This fault is set if the heater resistance is outside the expected range.	Heater Resistance outside of the expected range of	3.4 < ohms < 8.6	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P262B IAT_SensorFA < 8.0 ºC > 28,800 seconds ≥ -30.0 ºC < 32.0 volts < 0.09 seconds	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
MAP / MAF / Throttle Position Correlation	P0068	Detect when MAP and MAF do not match estimated engine airflow as established by the TPS	Difference between MAP and estimated MAP exceeds threshold (kPa), or P0651 (5 Volt Ref), or P0107 (MAP circuit low), or P0108 (MAP circuit high) have failed this key cycle, then MAP portion of diagnostic fails	Table, f(TPS). See supporting tables: **P0068_Delta MAP Threshold f(TPS)**	Engine Speed Run/Crank voltage	> 800 RPM > 6.41 Volts	Continuously fail MAP and MAF portions of diagnostic for 0.1875 s Continuous in MAIN processor	Type A, 1 Trips
			Absolute difference between MAF and estimated MAF exceed threshold (grams/sec), or P0102 (MAF circuit low), or P0103 (MAF circuit hi) have failed this key cycle, or maximum MAF versus RPM (Table) is greater than or equal to maximum MAF versus battery voltage, then MAF portion of diagnostic fails	Table, f(TPS). See supporting tables: **P0068_Delta MAF Threshold f(TPS)** Table, f(RPM). See supporting tables: **P0068_Maximum MAF f(RPM)** Table, f(Volts). See supporting tables: **P0068_Maximum MAF f(Volts)**			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Circuit Performance (OAT wired to ECM)	P0071	Detects an Outside Air Temperature (OAT) sensor that is stuck in range. There are two components to the test: an engine off component, and an engine running component. If the engine has been off for a long enough period of time, and the coolant temperature and Intake Air Temperature (IAT) values are similar, then the air temperature values in the engine compartment of the vehicle are considered to have equalized. In this case, the engine off component of the diagnostic can be enabled. If the IAT and the OAT values are similar, then the OAT Performance Diagnostic passes. If the IAT and OAT values are not similar, the diagnostic will continue to monitor the IAT and the OAT as the vehicle starts to move. For applications that have ability to move without engaging the internal combustion	**Engine Off:** If IAT >= OAT: IAT - OAT If IAT < OAT: OAT - IAT If either of the following conditions are met, this diagnostic will pass: If IAT >= OAT: IAT - OAT If IAT < OAT: OAT - IAT	 > 15.0 deg C > 15.0 deg C <= 15.0 deg C <= 15.0 deg C	Time between current ignition cycle and the last time the engine was running Engine is not running Vehicle Speed Coolant Temperature - IAT IAT - Coolant Temperature OAT-to-IAT engine off equilibrium counter The "OAT-to-IAT engine off equilibrium counter" is a counter that is incremented or decremented based on vehicle speed when the engine is off. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared. The value that is added or subtracted to the counter every 100 msec is contained in table **P0071: OAT Performance Drive Equilibrium Engine Off** No Active DTCs:	 >= 28,800.0 seconds >= 15.5 MPH < 15.0 deg C < 15.0 deg C >= 300.0 counts

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		engine, the engine off test will continue. If the vehicle has been moving quickly enough for a long enough period of time, the IAT and OAT values should have reached an equilibrium. This period of time is defined by the "OAT-to-IAT engine off equilibrium counter". The "OAT-to-IAT engine off equilibrium counter" is a counter that is incremented or decremented based on vehicle speed when the engine is off. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared. While the "OAT-to-IAT engine off equilibrium counter" is counting, IAT and OAT are monitored for similarity. If they are similar, the OAT Performance Diagnostic passes. If the counter reaches an equilibrium and the IAT and OAT values are not similar, the OAT Performance Diagnostic will fail.	**Engine Running:** If IAT >= OAT: IAT - OAT If IAT < OAT: OAT - IAT If either of the following conditions are met, this diagnostic will pass: If IAT >= OAT: IAT - OAT If IAT < OAT: OAT - IAT	> 15.0 deg C > 15.0 deg C <= 15.0 deg C <= 15.0 deg C	Time between current ignition cycle and the last time the engine was running Engine is running Vehicle Speed Engine air flow OAT-to-IAT engine running equilibrium counter The "OAT-to-IAT engine running equilibrium counter" is a counter that is incremented or decremented based on vehicle speed and engine air flow when the engine is running. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared. The value that is added or subtracted to the counter every 100 msec is contained in table **P0071: OAT Performance Drive Equilibrium Engine Running** No Active DTCs:	>= 28,800.0 seconds >= 15.5 MPH >= 10.0 grams/second >= 300.0 counts

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		If the engine off component of the diagnostic was enabled, but did not make a pass or fail decision, the engine running component will begin executing when the internal combustion engine starts to run. If the vehicle has been moving quickly enough for a long enough period of time, the IAT and OAT values should have reached an equilibrium. This period of time is defined by the "OAT-to-IAT engine running equilibrium counter". The "OAT-to-IAT engine running equilibrium counter" is a counter that is incremented or decremented based on vehicle speed when the engine is running. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared. While the "OAT-to-IAT engine running equilibrium counter" is counting, IAT and OAT are monitored for						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		similarity. If they are similar, the OAT Performance Diagnostic passes. If the counter reaches an equilibrium and the IAT and OAT values are not similar, the OAT Performance Diagnostic will fail.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Circuit Low	P0072	Detects a continuous short to ground in the Outside Air Temperature (OAT) signal circuit by monitoring the OAT sensor output resistance and failing the diagnostic when the OAT resistance is too low. The OAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. A lower resistance is equivalent to a higher temperature.	Raw OAT Input	<= 46 Ohms (~150 deg C)	None		40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Circuit High	P0073	Detects a continuous open circuit in the Outside Air Temperature (OAT) signal circuit by monitoring the OAT sensor output resistance and failing the diagnostic when the OAT resistance is too high. The OAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. A higher resistance is equivalent to a lower temperature.	Raw OAT Input	>= 427,757 Ohms (~-60 deg C)	None		40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Intermittent In-Range	P0074	Detects a noisy or erratic signal in the OAT circuit by monitoring the OAT sensor and failing the diagnostic when the OAT signal has a noisier output than is expected. When the value of the OAT signal in °C is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of OAT readings. The result of this summation is called a “string length”. Since the OAT signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic OAT signal. The diagnostic will fail if the string length is too high.	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current OAT reading - OAT reading from 100 milliseconds previous)	> 100 deg C 10 consecutive OAT readings	None		4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module SIDI High Pressure Pump min/ max authority	P0089	This DTC determines when the high pressure pump control has reached to its max or min authority	High Pressure Fuel Pump Delivery Angle OR High Pressure Fuel Pump Delivery Angle	>= 130 ° <= 0 °	High Pressure Pump Performance Diagnostic Enable Battery Voltage Low Side Fuel Pressure Barometric Pressure Inlet Air Temp Fuel Temp Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) andCam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In	True >= 11 Volts > 0.275 MPa Enabled when a code clear is not active or not exiting device control Engine is not cranking >= 70.0 KPA >= -12.0 degC -12 <= Temp degC <= 132	Windup High/ Low 10.00 seconds failures out of 12.50 Seconds samples	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Control Solenoid Enable Low Side Open Circuit	P0090	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	>= 200 KOhms impedance between signal and controller ground	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Control Solenoid Enable Low Side Short to Ground	P0091	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 0.1 Amps between signal and controller ground	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Cntrl Solenoid Enable Low Side Short to Power	P0092	Controller specific output driver circuit diagnoses diagnoses High Pressure pump Control Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1.1 or 15 Amps selectable thershold based on High pressure Pump .	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0096	Detects an Intake Air Temperature 2 (IAT2) sensor value that is stuck in range by comparing the IAT2 sensor value against the IAT and coolant temperature sensor values and failing the diagnostic if the IAT2 value is more different than the IAT and coolant temperature values than is expected. If the engine has been off for a long enough period of time, the air temperature values in the engine compartment of the vehicle are considered to have equalized, and the diagnostic can be enabled. The diagnostic will fail if the IAT and coolant temperature values are similar, and the IAT2 value is not similar to the IAT and coolant temperature values. This diagnostic is executed once per ignition cycle if the enable conditions are met.	ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up ECT – Power Up IAT2) >= ABS(Power Up ECT – Power Up IAT)	> 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time If application has a LIN MAF: LIN Communications established with MAF No Active DTCs:	> 28,800 seconds >= 11.0 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA HumTempSnsrCktFA EngineModeNotRunTimerError	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 Low (applications with LIN MAF)	P0097	Detects an erroneously low value being reported over the LIN serial connection from the Intake Air Temperature 2 (IAT2) sensor. The diagnostic monitors the IAT2 sensor output temperature and fails the diagnostic when the IAT2 temperature is too low. The IAT2 sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. The temperature value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.	IAT 2 Temperature	< -60 degrees C	Powertrain Relay Voltage for a time LIN Communications established with MAF No Active DTCs:	>= 11.0 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 High (applications with LIN MAF)	P0098	Detects an erroneously high value being reported over the LIN serial connection from the Intake Air Temperature 2 (IAT2) sensor. The diagnostic monitors the IAT2 sensor output temperature and fails the diagnostic when the IAT2 temperature is too high. The IAT2 sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. The temperature value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.	IAT 2 Temperature	> 150 degrees C	Powertrain Relay Voltage for a time LIN Communications established with MAF No Active DTCs:	>= 11.0 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Intermittent In-Range (applications with humidity)	P0099	Detects a noisy or erratic signal in the Intake Air Temperature 2 (IAT2) circuit by monitoring the IAT2 sensor and failing the diagnostic when the IAT2 signal has a noisier output than is expected. When the value of the IAT2 signal in °C is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of IAT2 readings. The result of this summation is called a “string length”. Since the IAT2 signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic IAT2 signal. The diagnostic will fail if the string length is too high.	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current IAT 2 reading - IAT 2 reading from 100 milliseconds previous)	> 100.00 deg C 10 consecutive IAT 2 readings	Powertrain Relay Voltage for a time If application has a LIN MAF: LIN Communications established with MAF No Active DTCs:	>= 11.0 Volts >= 0.9 seconds PowertrainRelayFault	4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Start Diagnostic	P00C6	The DTC Diagnoses the high side fuel pressure during engine cranking.	The ECM detects that the fuel pressure is not rising or has fallen beyond acceptable limits during engine cranking Pressure Rise Test: Sensed High Pressure Fuel Rail Pressure value Pressure Fall Test: Sensed High Pressure Fuel Rail Pressure value	< **P00C6 - Minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery** (see Supporting Table) <= **P00C6 - Minimum acceptable value of fuel rail pressure after High Pressure Start** (see Supporting Table)	High Pressure Rise Diagnostic During Start High Pressure Fail Diagnostic During Start Low side feed fuel pressure Engine Run Time Run/Crank Voltage Engine Coolant For each engine start, only 1 diagnostic is performed. The pressure rise test will run if HIgh side fuel pressure is less than KtFHPC_p_HighPressStart, otherwise, the pressure fall diagnostic will run The pressure fall runs when the engine is cranking.	True False >= 0 KPA < = 0 sec > 8 Volts -100 <= °C <= 132 All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT, IAT2 and ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control	Pressure Rise Test: Crank Time >= **P00C6 - High Pressure Pump Control Mode timeout** (see Supporting Table) 6.25 ms per sample Pressure Fall Test: Injected cylinder events >= **P00C6 - maximum acceptable counts of fuel rail pressure below KtFHPD_p_HPS_PressFallLoThrsh after High Pressure Start** (see Supporting Table) 8 samples per engine rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active		
					Barometric Pressure Inlet Air Temp	>= 70.0 KPA >= -12.0 DegC		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Pressure Measurement System - Multiple Sensor Correlation (naturally aspirated with TIAP/ Baro sensor)	P00C7	Detects an inconsistency between pressure sensors in the induction system in which a particular sensor cannot be identified as the failed sensor. If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The Manifold Pressure (MAP) and Barometric Pressure (BARO) sensors values are checked to see if they are within the normal expected atmospheric pressure range. If they are, then MAP and BARO are compared to see if their values are similar. If the MAP and BARO values are not similar, there are no other pressure sensors to compare against to identify which sensor is not rational. The Multiple Pressure Sensor Correlation Diagnostic will fail in this case.	ABS(Manifold Pressure - Baro Pressure)	> 10.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating Manifold Pressure Manifold Pressure Baro Pressure Baro Pressure If application has a LIN MAF: LIN Communications established with MAF No Active DTCs: No Pending DTCs:	> 5.0 seconds >= 50.0 kPa <= 115.0 kPa >= 50.0 kPa <= 115.0 kPa EngineModeNotRunTimer Error MAP_SensorFA AAP_SnsrFA AAP_LIN1_SnsrCktFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP_LIN1_SnsrCktFP	4 failures out of 5 samples 1 sample every 12.5 msec for applications without LIN MAF 1 sample every 25 msec for applications with LIN MAF	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Press Regulator Solenoid Supply Voltage Control High Side Circuit Short to ground	P00C9	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1.1 or 15 Amps selectable thershold based on High pressure Pump.	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Press Regulator Solenoid Supply Voltage Control High Side Circuit Short to power	P00CA	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 0.1 Amps between signal and controller power	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Low (applications with LIN MAF)	P00F4	Detects an eroneously low value being reported over the LIN serial connection from the humidity sensor. The diagnostic monitors the humidity sensor relative humidity output and fails the diagnostic when the humidity percentage is too low. The humidity sensor converts the capacitance across the sensor to a relative humidity. The relative humidity percentage value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.	Relative Humidity	<= -6.25 %	Powertrain Relay Voltage for a time LIN Communications established with MAF No Active DTCs:	>= 11.0 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit High (applications with LIN MAF)	P00F5	Detects an eroneously high value being reported over the LIN serial connection from the humidity sensor. The diagnostic monitors the humidity sensor relative humidity output and fails the diagnostic when the humidity percentage is too high. The humidity sensor converts the capacitance across the sensor to a relative humidity. The relative humidity percentage value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.	Relative Humidity	>= 106.25 %	Powertrain Relay Voltage for a time LIN Communications established with MAF No Active DTCs:	>= 11.0 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Intermittent	P00F6	Detects a noisy or erratic signal in the humidity circuit by monitoring the humidity sensor and failing the diagnostic when the humidity signal has a noisier output than is expected. When the value of relative humidity in % is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of humidity readings. The result of this summation is called a “string length”. Since the humidity signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic humidity signal. The diagnostic will fail if the string length is too high.	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current Humidity reading - Humidity reading from 100 milliseconds previous)	> 80 % 10 consecutive Humidity readings	Powertrain Relay Voltage for a time If application has a LIN MAF: LIN Communications established with MAF No Active DTCs:	>= 11.0 Volts >= 0.9 seconds PowertrainRelayFault	4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (naturally aspirated)	P0101	Detects a performance failure in the Mass Air Flow (MAF) sensor, such as when a MAF value is stuck in range. This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Manifold Pressure (MAP) sensor and Throttle Position sensor (TPS). These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the MAF sensor. In this case, the MAF Performance diagnostic will fail.	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 250 kPa*(g/s) > 25.0 grams/sec > 22.0 kPa	Engine Speed Engine Speed (Coolant Temp OR OBD Coolant Enable Criteria (Coolant Temp OR OBD Max Coolant Achieved Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together) See Residual Weight Factor tables.	>= 400 RPM <= 5,400 RPM >= -9 Deg C = TRUE) <= 129 Deg C = FALSE) >= -20 Deg C <= 129 Deg C >= 0.50 Filtered Throttle Model Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM** Modeled Air Flow Error multiplied by **P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM** and **P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est**	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						MAP Model 2 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP_SensorCircuitFA EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		
					No Active DTCs: No Pending DTCs:			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit Low Frequency (Continental MAF)	P0102	Detects a continuous short to ground in the MAF sensor circuit or a MAF sensor that is outputting a frequency that is too low. The diagnostic monitors the MAF sensor frequency output and fails the diagnostic when the MAF frequency is too low. A low MAF frequency is associated with a high engine air flow. The MAF sensor monitors the temperature of a circuit in the air flow of the engine. The temperature of this circuit is related to the mass air flow across the sensor. The mass air flow value is converted by the sensor to a frequency value in Hertz. A digital square wave signal is transmitted by the sensor to the ECM. The ECM calculates the frequency of the square wave signal and converts that frequency to a mass air flow value in grams/second through a transfer function.	MAF Output	<= 850 Hertz (>= 314.5 gm/sec)	Engine Run Time Engine Speed Powertrain Relay Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 8.5 Volts >= 1.0 seconds	400 failures out of 500 samples 1 sample every cylinder firing event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit High Frequency (Continental MAF)	P0103	Detects a MAF sensor that is outputting a frequency signal that is too high. The diagnostic monitors the MAF sensor frequency output and fails the diagnostic when the MAF frequency is too high. A high MAF frequency is associated with a low engine air flow. The MAF sensor monitors the temperature of a circuit in the air flow of the engine. The temperature of this circuit is related to the mass air flow across the sensor. The mass air flow value is converted by the sensor to a frequency value in Hertz. A digital square wave signal is transmitted by the sensor to the ECM. The ECM calculates the frequency of the square wave signal and converts that frequency to a mass air flow value in grams/second through a transfer function.	MAF Output	>= 14,500 Hertz (<= 0.00 gm/sec)	Engine Run Time Engine Speed Powertrain Relay Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 8.5 Volts >= 1.0 seconds	400 failures out of 500 samples 1 sample every cylinder firing event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (naturally aspirated)	P0106	Detects a performance failure in the Manifold Pressure (MAP) sensor, such as when a MAP value is stuck in range. If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The MAP sensor value is checked to see if it is within the normal expected atmospheric pressure range. If it is not, then the MAP performance diagnostic will fail. The engine running portion of this diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Mass Air Flow (MAF) sensor and Throttle Position sensor (TPS). These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model	**Engine Running:** Filtered Throttle Model Error AND ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	 <= 250 kPa*(g/s) > 22.0 kPa > 22.0 kPa	Engine Speed Engine Speed (Coolant Temp OR OBD Coolant Enable Criteria (Coolant Temp OR OBD Max Coolant Achieved Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together) See Residual Weight Factor tables. No Active DTCs:	>= 400 RPM <= 5,400 RPM >= -9 Deg C = TRUE) <= 129 Deg C = FALSE) >= -20 Deg C <= 129 Deg C >= 0.50 Filtered Throttle Model Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM** MAP Model 1 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM** MAP Model 2 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP_SensorCircuitFA	Continuous Calculations are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the MAP sensor. In this case, the MAP Performance diagnostic will fail.				EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		
			Engine Not Rotating: Manifold Pressure OR Manifold Pressure	 < 50.0 kPa > 115.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating If application has a LIN MAF: LIN Communications established with MAF No Active DTCs: No Pending DTCs:	 > 5.0 seconds EngineModeNotRunTimerError MAP_SensorCircuitFA AAP_SnsrCktFA AAP_LIN1_SnsrCktFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP_LIN1_SnsrCktFP	4 failures out of 5 samples 1 sample every 12.5 msec for applications without LIN MAF 1 sample every 25 msec for applications with LIN MAF	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit Low	P0107	Detects a continuous short to ground in the Manifold Absolute Pressure (MAP) signal circuit by monitoring the MAP sensor output voltage and failing the diagnostic when the MAP voltage is too low. The MAP sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	MAP Voltage	< 3.0 % of 5 Volt Range (This is equal to 6.1 kPa)	None		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit High	P0108	Detects a continuous short to power or open circuit in the Manifold Absolute Pressure (MAP) signal circuit by monitoring the MAP sensor output voltage and failing the diagnostic when the MAP voltage is too high. The MAP sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	MAP Voltage	> 90.0 % of 5 Volt Range (This is equal to 115.1 kPa)	None		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0111	Detects an Intake Air Temperature (IAT) sensor value that is stuck in range by comparing the IAT sensor value against the IAT2 and coolant temperature sensor values and failing the diagnostic if the IAT value is more different than the IAT2 and coolant temperature values than is expected. If the engine has been off for a long enough period of time, the air temperature values in the engine compartment of the vehicle are considered to have equalized, and the diagnostic can be enabled. The diagnostic will fail if the IAT2 and coolant temperature values are similar, and the IAT value is not similar to the IAT2 and coolant temperature values. This diagnostic is executed once per ignition cycle if the enable conditions are met.	ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up ECT – Power Up IAT) > ABS(Power Up ECT – Power Up IAT2)	> 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time If application has a LIN MAF: LIN Communications established with MAF No Active DTCs:	> 28,800 seconds >= 11.0 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA HumTempSnsrCktFA EngineModeNotRunTimerError	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Low (applications with LIN MAF)	P0112	Detects an erroneously low value being reported over the LIN serial connection from the Intake Air Temperature (IAT) sensor. The diagnostic monitors the IAT sensor output temperature and fails the diagnostic when the IAT temperature is too low. The IAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. The temperature value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.	IAT Temperature	< -60 degrees C	LIN Communications established with MAF		40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit High (applications with LIN MAF)	P0113	Detects an erroneously high value being reported over the LIN serial connection from the Intake Air Temperature (IAT) sensor. The diagnostic monitors the IAT sensor output temperature and fails the diagnostic when the IAT temperature is too high. The IAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. The temperature value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.	IAT Temperature	> 150 degrees C	LIN Communications established with MAF		40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Intermittent In-Range	P0114	Detects a noisy or erratic signal in the Intake Air Temperature (IAT) circuit by monitoring the IAT sensor and failing the diagnostic when the IAT signal has a noisier output than is expected. When the value of the IAT signal in °C is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of IAT readings. The result of this summation is called a “string length”. Since the IAT signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic IAT signal. The diagnostic will fail if the string length is too high.	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current IAT reading - IAT reading from 100 milliseconds previous)	> 80.00 deg C 10 consecutive IAT readings	If application has a LIN MAF: LIN Communications established with MAF		4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Performance	P0116	This DTC detects an ECT (Engine Coolant temperature) sensor that is biased high or stuck above the thermostat monitoring diagnostic. This check is performed after a soak condition.	A failure will be reported if any of the following occur: 1) ECT at power up > IAT at power up by an IAT based table lookup value after a minimum 28,800 second soak (fast fail). 2) ECT at power up > IAT at power up by 19.3 ºC after a minimum 28,800 second soak and a block heater has not been detected. 3) ECT at power up > IAT at power up by 19.3 C after a minimum 28,800 seconds soak and the time spent cranking the engine without starting is greater than 10.0 seconds with the LowFuelConditionDiag	See **P0116_Fail if power up ECT exceeds IAT by these values** in the Supporting tables section = False	No Active DTC's Non-volatile memory initization Test complete this trip Test aborted this trip IAT LowFuelCondition Diag ========== Block Heater detection is enabled when either of the following occurs: 1) ECT at power up > IAT at power up by 2) Cranking time ========== Block Heater is detected and diagnostic is aborted when 1) or 2) occurs: 1a) Vehicle drive time 1b) Vehicle speed 1c) Additional Vehicle drive time is provided to 1a when Vehicle speed is below 1b as follows:	VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_Ckt_FA IgnitionOffTimeValid TimeSinceEngineRunning Valid = Not occurred = False = False ≥ -9 ºC = False ========== > 19.3 ºC < 10.0 seconds ========== > 400 seconds with > 15 MPH 0.00 times the seconds with vehicle speed below 1b	1 failure 500 msec/ sample Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					1d) IAT drops from power up IAT 2a) ECT drops from power up ECT 2b) Engine run time ========== Diagnostic is aborted when 3) or 4) occurs: 3) Engine run time with vehicle speed below 1b 4) Minimum IAT during test	≥ 3.3 ºC ≥ 1 ºC Within ≤ 30 seconds ========== > 1800 seconds ≤ -9 ºC		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit Low	P0117	Circuit Continuity This DTC detects a short to ground in the ECT (Engine Coolant temperature) signal circuit or the ECT sensor. This is accomplished by monitoring the resistance of the circuit. If the resistance goes out of the expected range the DTC is set.	ECT Resistance (@ 150ºC)	< 55 Ohms			5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit High	P0118	Circuit Continuity This DTC detects a short to high or open in the ECT (Engine Coolant temperature) signal circuit or the ECT sensor. This is accomplished by monitoring the resistance of the circuit. If the resistance goes out of the expected range the DTC is set.	ECT Resistance (@ -60ºC)	> 134,000 Ohms	Engine run time OR IAT min	> 10.0 seconds ≥ -9.0 °C	5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Circuit Intermittent	P0119	Circuit Erratic This DTC detects large step changes in the ECT (Engine Coolant temperature) signal circuit or the ECT sensor. Allowable high and low limits are calculated for the next sample based on the previous sample and sensor time constant. If the sensor responds faster than should be possible the DTC is set.	ECT temperature step change: 1) postive step change is greater than calculated high limit OR 2) negitive step change is lower than calculated low limit. The calculated high and low limits for the next reading use the following calibrations: 1) Sensor time constant 2) Sensor low limit 3) Sensor high limit *****Generic Example***** If the last ECT reading was 90 Deg C, the Time constant was calibrated at 10 seconds, the low limit was calibrated to -80 Deg C and the high limit was calibrated to 200 Deg C the caluculated limits are 101 Deg C and 73 Deg C. The next reading (after the 90 Deg C reading) must be between 73 Deg C and 101 Deg C to be valid. **********	 13.0 seconds -60.0 Deg C 200.0 Deg C	No Active DTC's	ECT_Sensor_Ckt_FP	3 failures out of 4 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (naturally aspirated)	P0121	Detects a performance failure in the Throttle Position sensor (TPS) sensor, such as when a TPS value is stuck in range. This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Manifold Pressure (MAP) sensor and Mass Air Flow (MAF) sensor. These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the TPS sensor. In this case, the TPS Performance diagnostic will fail.	Filtered Throttle Model Error AND ABS(Measured MAP – MAP Model 2) Filtered	> 250 kPa*(g/s) <= 22.0 kPa	Engine Speed Engine Speed (Coolant Temp OR OBD Coolant Enable Criteria (Coolant Temp OR OBD Max Coolant Achieved Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together) See Residual Weight Factor tables. No Active DTCs:	>= 400 RPM <= 5,400 RPM >= -9 Deg C = TRUE) <= 129 Deg C = FALSE) >= -20 Deg C <= 129 Deg C >= 0.50 Filtered Throttle Model Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM** MAP Model 2 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP_SensorCircuitFA EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Pending DTCs:	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit Low	P0122	Detects a continuous or intermittent short low or open in TPS1 circuit by monitoring the TPS 1 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too low. This diagnostic only runs when battery voltage is high enough.	TPS1 % Vref <	0.3250 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P06A3	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit High	P0123	Detects a continuous or intermittent short high in TPS1 circuit by monitoring the TPS 1 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too high. This diagnostic only runs when battery voltage is high enough.	TPS1 % Vref >	4.750 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P06A3	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature Below Stat Regulating Temperature	P0128	This DTC detects if the ECT (EngineCoolant temperature) does not achieve the required target temperature after an allowed energy accumulation by the engine. This can be caused by an ECT sensor biased low or a cooling system that is not warming up correctly because of a stuck open thermostat or other fault.	Energy is accumulated after the first conbustion event using Range #1 or #2 below: Thermostat type is divided into normal (non-heated) and electrically heated. For this application the "type" cal (KeTHMG_b_TMS_ElecThstEquipped) = 0 If the type cal is equal to one, the application has an electrically heated t-stat, if equal to zero the the application has an non heated t-stat. See appropiate section below. ********** Type cal above = 1 (Electrically heated t-stat) == == == == Range #1 (Primary) ECT reaches Commanded temperature minus 11 °C when Ambient min is ≤ 50 °C and > 10 °C. Note: Warm up target for range #1 will be at least 75 °C == == == == Range #2 (Alternate) ECT reaches Commanded temperature minus 11 °C when Ambient min is ≤ 10 °C and > -9 °C. Note: Warm up target for range #2 will be at least	See the two tables named: **P0128_Maximum Accumulated Energy for Start-up ECT conditions - Primary** and **P0128_Maximum Accumulated Energy for Start-up ECT conditions - Alternate** in the Supporting tables section. This diagnostic models the net energy into and out of the cooling	No Active DTC's Engine not run time (soaking time before current trip) Engine run time Fuel Condition Distance traveled ********** If Engine RPM is continuously greater than for this time period The diagnostic test for this key cycle will abort ********** ********** If T-Stat Heater commanded duty cycle for this time period	ECT_Sensor_Ckt_FA ECT_Sensor_Perf_FA VehicleSpeedSensor_FA OAT_PtEstFiltFA IAT_SensorCircuitFA MAF_SensorFA THMR_AWP_AuxPumpFA THMR_AHV_FA THMR_SWP_Control_FA THMR_SWP_NoFlow_FA THMR_SWP_FlowStuckOn_FA EngineTorqueEstInaccurate ≥ 1,800 seconds 30 ≤ Eng Run Tme ≤ 1,470 seconds Ethanol ≤ 87 % ≥ 0.75 miles ********** 6,000 rpm 5.0 seconds ********** ********** > 20.0 % duty cycle > 5.0 seconds	1 failure to set DTC 1 sec/ sample Once per ignition key cycle	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			65 °C ********** Type cal above = 0 (non - heated t-stat) == == == == Range #1 (Primary) ECT reaches 75 °C when Ambient min is ≤ 50 °C and > 10 °C. == == == == Range #2 (Alternate) ECT reaches 65 °C when Ambient min is ≤ 10 °C and > -9 °C. **********	system during the warm-up process. The five energy terms are: heat from combustion (with AFM correction), heat from after-run, heat loss to enviroment, heat loss to cabin and heat loss to DFCO.	The diagnostic test for this key cycle will abort ********** ECT at start run	********** -60 ≤ ECT ≤ 56 °C		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 1	P0131	This DTC determines if the O2 sensor signal circuit is shorted low. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold. The diagnostic failure counter is incremented if the O2S signal is below the threshold value. This DTC is set based on the fail and sample counters.	Oxygen Sensor Signal	< 40.0 mVolts	No Active DTC's AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Only when FuelLevelDataFault Commanded Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active	TPS_ThrottleAuthorityDefaulted MAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA = Not active = Not active = Not active = Not active 11.0 < Volts = Not active = Not active = Not active = Not active = False = False 0.9922 < ratio < 1.0137 175 < mgram < 700 = Closed Loop = TRUE (Please see “**Closed Loop Enable Clarification**” in Supporting Tables).	285 failures out of 350 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All Fuel Injectors for active Cylinders Fuel Condition Ethanol Estimation in Progress Fuel State All of the above met for	Enabled (On) Ethanol ≤ 87 % = Not Active (Please see “**Ethanol Estimation in Progress**” in Supporting Tables). DFCO not active > 5.0 seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 1	P0132	This DTC determines if the O2 sensor signal circuit is shorted high or open. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold. The diagnostic failure counter is incremented if the O2S signal is above the threshold value. This DTC is set based on the fail and sample counters.	Oxygen Sensor Signal	> 1,050 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Low Fuel Condition Diag Only when FuelLevelDataFault ********** Secondary delay after above conditions are complete (cold start condition) Secondary delay after above conditions are complete (not cold start condition) Commanded Equivalence Ratio ********** All of the above met for	TPS_ThrottleAuthorityDefaulted MAF_SensorFA MAP_SensorFA EvapExcessPurgePsbl_FA FuelInjectorCircuit_FA Ethanol Composition Sensor FA AIR System FA 11.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds = False = False ********** > 235.0 seconds when engine soak time > 28,800 seconds > 235.0 seconds when engine soak time ≤ 28,800 seconds ≤ 1.014 EQR ********** > 2.0 seconds	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Slow Response Bank 1 Sensor 1) (For use with ESPD and w/o WRAF	P0133	This DTC determines if the Bank 1 primary O2 sensor has a slow response (in the Rich to Lean (R2L) or Lean to Rich (L2R) direction) and thereby can no longer be used for closed loop fuel control based on emission correlation testing. This diagnostic runs passively (see enable conditions) and monitors the time the O2 sensor signal is between an upper and lower voltage thresholds over the sample period. The diagnostic also monitors the O2 sensor signal for the number of Slope Time (ST) switches in each direction between the same upper and lower voltage thresholds over the sample period. When the required data is collected, an average R2L and L2R response time and individual R2L and L2R Slope Time (ST) switch count is calculated. This fault is set when the L2R and R2L response test results are compared to the	Fault condition present when the average response time is caluclated over the test time, and compared to the threshold. OR Slope Time L/R Switches OR Slope Time R/L Switches	Refer to **P0133_O2S Slow Response Bank 1 Sensor 1 Pass/Fail Threshold table** in the Supporting Tables tab < 3 < 3 The test averages the signal response time over 60.0 seconds when the signal is transitioning between 300 mvolts and 600 mvolts. An average rich to lean time and lean to rich time are each calculated separately. Note: the table listed above uses the following calibratable X axis: **P0133_KnEOSD_t_ST_LRC_LimRS1** and calibratable Y axis: **P0133_KnEOSD_t_ST_RLC_LimRS1**	No Active DTC's Bank 1 Sensor 1 DTC's not active System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Only when FuelLevelDataFault Green O2S Condition	TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA AIR System FA Ethanol Composition Sensor FA EngineMisfireDetected_FA P0131, P0132, P0134 > 11.0 Volts = Not active = Not active = Not active = Not active = False = False = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than	Sample time is 60 seconds Frequency: Once per trip	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		"P0133_O2S Slow Response Bank 1 Sensor 1 "Pass/Fail Threshold Table" and the outcome determines a response faulted condition. Additionally, this fault is set when the L2R or R2L slope time switch count test results are less than the ST individual thresholds.				**Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.		
					O2 Heater on for Learned Htr resistance	≥ 40 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")		
					Engine Coolant (Or OBD Coolant Enable Criteria	> 50 ºC = TRUE)		
					IAT	> -40 ºC		
					Engine run Accum	> 30 seconds		
					Time since any AFM status change	> 0.0 seconds		
					Time since Purge On to Off change	> 1.0 seconds		
					Time since Purge Off to On change	> 2.0 seconds		
					Engine airflow	20 ≤ grams/sec ≤ 60		
					Engine speed	1,000 ≤ RPM ≤ 3,000		
					Fuel Condition	< 87 % Ethanol		
					Baro	> 70 kpa		
					Air Per Cylinder	≥ 200 mGrams		
					Fuel Control State Closed Loop Active	= Closed Loop = TRUE (Please see "**Closed Loop Enable**		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						Clarification" in Supporting Tables). = Enabled, refer to **Multiple DTC Use - Response Cell Enable Table** for additional info.		
					LTM (Block Learn) fuel cell			
					Transient Fuel Mass Baro Fuel Control State Fuel State Commanded Proportional Gain	≤ 100.0 mgrams = Not Defaulted not = Power Enrichment DFCO not active ≥ 0.0 %		
					========== All of the above met for	========== > 2.0 seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 1	P0135	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit. This test compares the measured heater current (monitored thru the low side driver) and compares it to the expected values (over the voltage range provided) for the released sensor. The diagnostic failure counter is incremented if the heater current is outside the expected range. This DTC is set based on the fail and sample counters.	Heater Current outside of the expected range of	0.3 < Amps < 3.1	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA > 11.0 Volts = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0137	This DTC determines if the O2 sensor signal circuit is shorted low. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold. The diagnostic failure counter is incremented if the O2S signal is below the threshold value. This DTC is set based on the fail and sample counters.	Oxygen Sensor Signal	< 50 mvolts	No Active DTC's

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All Fuel Injectors for active Cylinders Fuel Condition Ethanol Estimation in Progress Fuel State All of the above met for	Enabled (On) Ethanol ≤ 87 % = Not Active (Please see “**Ethanol Estimation in Progress**” in Supporting Tables). DFCO not active > 5.0 seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0138	This DTC determines if the O2 sensor signal circuit is shorted high or open. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold. The diagnostic failure counter is incremented if the O2S signal is above the threshold value. This DTC is set based on the fail and sample counters.	Oxygen Sensor Signal	> 1,050 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Low Fuel Condition Only when FuelLevelDataFault ********** Secondary delay after above conditions are complete (cold start condition) Secondary delay after above conditions are complete (not cold start condition) Commanded Equivalence Ratio ********** All of the above met for	TPS_ThrottleAuthorityDefaulted MAF_SensorFA MAP_SensorFA EvapExcessPurgePsbl_FA FuelInjectorCircuit_FA Ethanol Composition Sensor FA AIR System FA 11.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds = False = False ********** > 235.0 seconds when engine soak time > 28,800 seconds > 235.0 seconds when engine soak time ≤ 28,800 seconds ≤ 1.014 EQR ********** > 2.0 seconds	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Rich to Lean Bank 1 Sensor 2	P013A	The P013A diagnostic is the third in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, & P013B. This DTC determines if the secondary O2 sensor has an slow response to an A/F change from Rich to Lean and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow. Note: The Primary method is used when the secondary O2 sensor signal transitions from above the upper threshold to below the lower threshold, otherwise the Secondary method is used. <u>Primary method</u>: The P013A diagnostic measures the secondary O2 sensor voltage response rate	Primary Method: The EWMA of the Post O2 sensor normalized integral value. The EWMA repass limit is The EWMA calculation uses a 0.28 coefficient. OR Secondary Method: The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units ≤ 7.5 units > 70.0 grams (upper voltage threshold is 450 mvolts and lower voltage threshold is 150 mvolts)	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance Green O2S Condition	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_ 1_TFTKO O2S_Bank_ 2_TFTKO P013B, P013E, P013F, P2270 or P2271 > 11.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.	Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		between an upper and lower voltage threshold. The response rate is then normalized to mass air flow rate and scaled resulting in a normalized intregral value. The normalized integral is fed into a 1st order lag filter to update the final EWMA result. DTC P013A is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value. Secondary method:			Low Fuel Condition Only when FuelLevelDataFault Post fuel cell Crankshaft Torque DTC's Passed ========== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	= False = False = Enabled, refer to **Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests** for additional info. < 125.0 Nm P2270 (and P2272 if applicable) P013E (and P014A if applicable) ==========		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		This fault is set if the secondary O2 sensor does not achieve the required lower voltage threshold before the accumulated mass air flow threshold is reached.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Lean to Rich Bank 1 Sensor 2	P013B	The P013B diagnostic is the sixth in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, & P013B. This DTC determines if the secondary O2 sensor has an slow response to an A/F change from Lean to Rich and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow. Note: The Primary method is used when the secondary O2 sensor signal transitions from below the lower threshold to above the upper threshold, otherwise the Secondary method is used. <u>Primary method</u>: The P013B diagnostic measures the secondary O2 sensor voltage response rate	Primary Method: The EWMA of the Post O2 sensor normalized integral value. The EWMA repass limit is The EWMA calculation uses a 0.28 coefficient. OR Secondary Method: The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units ≤ 7.5 units > 200 grams (lower voltage threshold is 350 mvolts and upper voltage threshold is 650 mvolts)	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance Green O2S Condition	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_ 1_TFTKO O2S_Bank_ 2_TFTKO P013A, P013E, P013F, P2270 or P2271 > 11.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow	Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		between an lower and upper voltage threshold. The response rate is then normalized to mass air flow rate and scaled resulting in a normalized intregral value. The normalized integral is fed into a 1st order lag filter to update the final EWMA result. DTC P013B is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value. Secondary method:			Green Cat System Condition Low Fuel Condition Only when FuelLevelDataFault Post fuel cell DTC's Passed ========== After above conditions are met: Fuel Enrich mode continued. ==========	is above 22.0 grams/sec. = Not Valid, Green Cat System condition is considered valid until accumulated airflow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is greater than 22.0 grams/ sec. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service). = False = False = Enabled, refer to **Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests** for additional info. P2270 P013E P013A P2271 P013F ==========		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		This fault is set if the secondary O2 sensor does not achieve the required upper voltage threshold before the accumulated mass air flow threshold is reached.			During this test the following must stay TRUE or the test will abort: 0.950 ≤ Base Commanded EQR ≤ 1.100			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Rich to Lean Bank 2 Sensor 2	P013C	The P013C diagnostic is the third in a sequence of six intrusive secondary O2 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, & P013D. This DTC determines if the secondary O2 sensor has an slow response to an A/F change from Rich to Lean and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow. Note: The Primary method is used when the secondary O2 sensor signal transitions from above the upper threshold to below the lower threshold, otherwise the Secondary method is used. <u>Primary method</u>: The P013C diagnostic measures the secondary O2 sensor voltage response rate	Primary Method: The EWMA of the Post O2 sensor normalized integral value. The EWMA repass limit is The EWMA calculation uses a 0.28 coefficient. OR Secondary Method: The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units ≤ 7.5 units > 70.0 grams (upper voltage threshold is 450 mvolts and lower voltage threshold is 150 mvolts)	No Active DTC's B2S2 DTC's Not Active this key cycle System Voltage Learned heater resistance Green O2S Condition	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_ 1_TFTKO O2S_Bank_ 2_TFTKO P013D, P014A, P014B, P2272 or P2273 > 11.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S2, B2S2 in Supporting Tables tab. Airflow accumulation is only enabled when airflow	Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		between an upper and lower voltage threshold. The response rate is then normalized to mass air flow rate and scaled resulting in a normalized intregral value. The normalized integral is fed into a 1st order lag filter to update the final EWMA result. DTC P013C is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value. Secondary method:			 Low Fuel Condition Only when FuelLevelDataFault Post fuel cell Crankshaft Torque DTC's Passed ========== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	is above 22.0 grams/sec. = False = False = Enabled, refer to **Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests** for additional info. < 125.0 Nm P2272 P014A ==========		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		This fault is set if the secondary O2 sensor does not achieve the required lower voltage threshold before the accumulated mass air flow threshold is reached.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Lean to Rich Bank 2 Sensor 2	P013D	The P013D diagnostic is the sixth in a sequence of six intrusive secondary O2 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, & P013D. This DTC determines if the secondary O2 sensor has an slow response to an A/F change from Lean to Rich and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow. Note: The Primary method is used when the secondary O2 sensor signal transitions from below the lower threshold to above the upper threshold, otherwise the Secondary method is used. <u>Primary method</u>: The P013D diagnostic measures the secondary O2 sensor voltage response rate	Primary Method: The EWMA of the Post O2 sensor normalized integral value. The EWMA repass limit is The EWMA calculation uses a 0.28 coefficient. OR Secondary Method: The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units ≤ 7.5 units > 200 grams (lower voltage threshold is 350 mvolts and upper voltage threshold is 650 mvolts)	No Active DTC's B2S2 DTC's Not Active this key cycle System Voltage Learned heater resistance Green O2S Condition	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_ 1_TFTKO O2S_Bank_ 2_TFTKO P013C, P014A, P014B, P2272 or P2273 > 11.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S2, B2S2 in Supporting Tables tab. Airflow accumulation is only enabled when airflow	Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		between an lower and upper voltage threshold. The response rate is then normalized to mass air flow rate and scaled resulting in a normalized intregral value. The normalized integral is fed into a 1st order lag filter to update the final EWMA result. DTC P013D is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value. Secondary method:			Green Cat System Condition Low Fuel Condition Only when FuelLevelDataFault Post fuel cell DTC's Passed ========== After above conditions are met: Fuel Enrich mode continued. ========== During this test the	is above 22.0 grams/sec. = Not Valid, Green Cat System condition is considered valid until accumulated airflow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is greater than 22.0 grams/ sec. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service). = False = False = Enabled, refer to **Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests** for additional info. P2272 P014A P013C P2273 P014B ==========		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		This fault is set if the secondary O2 sensor does not achieve the required upper voltage threshold before the accumulated mass air flow threshold is reached.			following must stay TRUE or the test will abort: 0.950 ≤ Base Commanded EQR ≤ 1.100			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 2	P013E	The P013E diagnostic is the second in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, & P013B. This DTC determines if the secondary O2 sensor has an initial delayed response to an A/F change from Rich to Lean and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow. This fault is set if the secondary O2 sensor does not achieve the required voltage before the accumulated mass air flow threshold is reached.	Post O2 sensor voltage AND The Accumulated mass air flow monitored during the Delayed Response Test under DFCO DFCO begins after: 1) Catalyst has been rich for a minimum of AND 2) Catalyst Rich Accumulation Air Flow is	> 450 mvolts > 70 grams > 1 secs ≥ 3.0 grams	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance Green O2S Condition	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_ 1_TFTKO O2S_Bank_ 2_TFTKO P013A, P013B, P013F, P2270 or P2271 > 11.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow	Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						is above 22.0 grams/sec.		
					Low Fuel Condition Only when FuelLevelDataFault	= False = False		
					Post fuel cell	= Enabled, refer to **Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests** for additional info.		
					Crankshaft Torque	< 125.0 Nm		
					DTC's Passed	P2270		
					Number of fueled cylinders ========== After above conditions are met: DFCO mode entered (wo driver initiated pedal input).	≤ 7 cylinders ==========		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 2	P013F	The P013F diagnostic is the fifth in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, & P013B. This DTC determines if the secondary O2 sensor has an initial delayed response to an A/F change from Lean to Rich and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow. This fault is set if the secondary O2 sensor does not achieve the required voltage before the accumulated mass air flow threshold is reached.	Post O2 sensor voltage AND The Accumulated mass air flow monitored during the Delayed Response Test	< 350 mvolts > 400 grams	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance Green O2S Condition	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_ 1_TFTKO O2S_Bank_ 2_TFTKO P013A, P013B, P013E, P2270 or P2271 > 11.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow	Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						is above 22.0 grams/sec.		
					Green Cat System Condition	= Not Valid, Green Cat System condition is considered valid until accumulated airflow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is greater than 22.0 grams/ sec. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).		
					Low Fuel Condition	= False		
					Only when FuelLevelDataFault	= False		
					Post fuel cell	= Enabled, refer to **Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests** for additional info.		
					DTC's Passed	P2270 P013E P013A P2271		
					Number of fueled cylinders	≥ 1 cylinders		
					========== After above conditions are met: Fuel Enrich mode entered. ========== During this test the	==========		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					following must stay TRUE or the test will abort: 0.950 ≤ Base Commanded EQR ≤ 1.100 ========== During this test: Engine Airflow must stay: and the delta Engine Airflow over 12.5msec must be :	gps ≤ 20.0 KePOPD_dm_L2R_AirFlowMaxAbor ≤ KePOPD_dm_L2R_AirFlowDeltaAbortgps		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0141	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit. This test compares the measured heater current (monitored thru the low side driver) and compares it to the expected values (over the voltage range provided) for the released sensor. The diagnostic failure counter is incremented if the heater current is outside the expected range. This DTC is set based on the fail and sample counters.	Heater Current outside of the expected range of	0.3 > amps > 2.9	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA > 11.0 Volts = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 2 Sensor 2	P014A	The P014A diagnostic is the second in a sequence of six intrusive secondary O2 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, & P013D. This DTC determines if the secondary O2 sensor has an initial delayed response to an A/F change from Rich to Lean and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow. This fault is set if the secondary O2 sensor does not achieve the required voltage before the accumulated mass air flow threshold is reached.	Post O2 sensor voltage AND The Accumulated mass air flow monitored during the Delayed Response Test under DFCO DFCO begins after: 1) Catalyst has been rich for a minimum of AND 2) Catalyst Rich Accumulation Air Flow is	> 450 mvolts > 70 grams > 1 secs ≥ 3.0 grams	No Active DTC's B2S2 DTC's Not Active this key cycle System Voltage Learned heater resistance Green O2S Condition	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_ 1_TFTKO O2S_Bank_ 2_TFTKO P013C, P013D, P014B, P2272 or P2273 > 11.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S2, B2S2 in Supporting Tables tab. Airflow accumulation is only enabled when airflow	Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						is above 22.0 grams/sec.		
					Low Fuel Condition Only when FuelLevelDataFault	= False = False		
					Post fuel cell	= Enabled, refer to **Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests** for additional info.		
					Crankshaft Torque	< 125.0 Nm		
					DTC's Passed	P2272		
					Number of fueled cylinders ========== After above conditions are met: DFCO mode entered (wo driver initiated pedal input).	≤ 7 cylinders ==========		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 2 Sensor 2	P014B	The P014B diagnostic is the fifth in a sequence of six intrusive secondary O2 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, & P013D. This DTC determines if the secondary O2 sensor has an initial delayed response to an A/F change from Lean to Rich and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow. This fault is set if the secondary O2 sensor does not achieve the required voltage before the accumulated mass air flow threshold is reached.	Post O2 sensor AND The Accumulated mass air flow monitored during the Delayed Response Test	< 350 mvolts > 400 grams.	No Active DTC's B2S2 DTC's Not Active this key cycle System Voltage Learned heater resistance Green O2S Condition	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_ 1_TFTKO O2S_Bank_ 2_TFTKO P013C, P013D, P014A, P2272 or P2273 > 11.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S2, B2S2 in Supporting Tables tab. Airflow accumulation is only enabled when airflow	Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						is above 22.0 grams/sec.		
					Green Cat System Condition	= Not Valid, Green Cat System condition is considered valid until accumulated airflow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is greater than 22.0 grams/ sec. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).		
					Low Fuel Condition	= False		
					Only when FuelLevelDataFault	= False		
					Post fuel cell	= Enabled, refer to **Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests** for additional info.		
					DTC's Passed	P2272 P014A P013C P2273		
					Number of fueled cylinders	≥ 1 cylinders		
					========== After above conditions are met: Fuel Enrich mode entered. ========== During this test the	==========		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					following must stay TRUE or the test will abort: 0.950 ≤ Base Commanded EQR ≤ 1.100			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 2 Sensor 1	P0151	This DTC determines if the O2 sensor signal circuit is shorted low. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold. The diagnostic failure counter is incremented if the O2S signal is below the threshold value. This DTC is set based on the fail and sample counters.	Oxygen Sensor Signal	< 40 mvolts	No Active DTC's

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All Fuel Injectors for active Cylinders Fuel Condition Ethanol Estimation in Progress Fuel State All of the above met for	**Clarification**" in Supporting Tables). Enabled (On) ≤ 87 % Ethanol = Not Active (Please see "**Ethanol Estimation in Progress**" in Supporting Tables). DFCO not active > 5.0 seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 2 Sensor 1	P0152	This DTC determines if the O2 sensor signal circuit is shorted high or open. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold. The diagnostic failure counter is incremented if the O2S signal is above the threshold value. This DTC is set based on the fail and sample counters.	Oxygen Sensor Signal	> 1,050 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Low Fuel Condition Only when FuelLevelDataFault ********** Secondary delay after above conditions are complete (cold start condition) Secondary delay after above conditions are complete (not cold start condition) Commanded Equivalence Ratio ********** All of the above met for	TPS_ThrottleAuthorityDefaulted MAF_SensorFA MAP_SensorFA EvapExcessPurgePsbl_FA FuelInjectorCircuit_FA Ethanol Composition Sensor FA AIR System FA 11.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds = False = False ********** > 280.0 seconds when engine soak time > 28,800 seconds > 280.0 seconds when engine soak time ≤ 28,800 seconds ≤ 1.014 EQR ********** > 2 seconds	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Slow Response Bank 2 Sensor 1) (For use with ESPD and w/o WRAF	P0153	This DTC determines if the Bank 2 primary O2 sensor has a slow response (in the Rich to Lean (R2L) or Lean to Rich (L2R) direction) and thereby can no longer be used for closed loop fuel control based on emission correlation testing. This diagnostic runs passively (see enable conditions) and monitors the time the O2 sensor signal is between an upper and lower voltage thresholds over the sample period. The diagnostic also monitors the O2 sensor signal for the number of Slope Time (ST) switches in each direction between the same upper and lower voltage thresholds over the sample period. When the required data is collected, an average R2L and L2R response time and individual R2L and L2R Slope Time (ST) switch count is calculated. This fault is set when the L2R and R2L response test results are compared to the	Fault condition present when the average response time is caluclated over the test time, and compared to the threshold. OR Slope Time L/R Switches OR Slope Time R/L Switches	Refer to **P0153_O2S Slow Response Bank 2 Sensor 1 Pass/Fail Threshold table** in the Supporting Tables tab < 3 < 3 The test averages the signal response time over 60.0 seconds when the signal is transitioning between 300 mvolts and 600 mvolts. An average rich to lean time and lean to rich time are each calculated separately. Note: the table listed above uses the following calibratable X axis: **P0153_KnEOSD_t_ST_LRC_LimRS2** and calibratable Y axis:	No Active DTC's Bank 2 Sensor 1 DTC's not active System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Only when FuelLevelDataFault Green O2S Condition	TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA AIR System FA Ethanol Composition Sensor FA EngineMisfireDetected_FA = P0151, P0152 or P0154 > 11.0 Volts = Not active = Not active = Not active = Not active = False = False = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than	Sample time is 60 seconds Frequency: Once per trip	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		"P0153_O2S Slow Response Bank 1 Sensor 1 "Pass/Fail Threshold Table" and the outcome determines a response faulted condition. Additionally, this fault is set when the L2R or R2L slope time switch count test results are less than the ST individual thresholds.		**P0153_KnEOSD_t_ST_RLC_LimRS2**		**Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S1, B2S1 in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.		
					O2 Heater on for Learned Htr resistance	≥ 40 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")		
					Engine Coolant (Or OBD Coolant Enable Criteria	> 50 ºC = TRUE)		
					IAT	> -40 ºC		
					Engine run Accum	> 30 seconds		
					Time since any AFM status change	> 0.0 seconds		
					Time since Purge On to Off change	> 1.0 seconds		
					Time since Purge Off to On change	> 2.0 seconds		
					Engine airflow Engine speed Fuel Condition Baro Air Per Cylinder Fuel Control State Closed Loop Active	20 ≤ grams/sec ≤ 60 1,000 ≤ RPM ≤ 3,000 < 87 % Ethanol > 70 kpa ≥ 200 mGrams = Closed Loop = TRUE (Please see "**Closed Loop Enable Clarification**" in		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					LTM (Block Learn) fuel cell Transient Fuel Mass Baro Fuel Control State Fuel State Commanded Proportional Gain ========== All of the above met for	Supporting Tables). = Enabled, refer to **Multiple DTC Use - Response Cell Enable Table** for additional info. ≤ 100.0 mgrams = Not Defaulted not = Power Enrichment DFCO not active ≥ 0.0 % ========== > 2.0 seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 2 Sensor 1	P0155	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit. This test compares the measured heater current (monitored thru the low side driver) and compares it to the expected values (over the voltage range provided) for the released sensor. The diagnostic failure counter is incremented if the heater current is outside the expected range. This DTC is set based on the fail and sample counters.	Heater Current outside of the expected range of	0.3 > amps > 3.1	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA > 11.0 Volts = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 2 Sensor 2	P0157	This DTC determines if the O2 sensor signal circuit is shorted low. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold. The diagnostic failure counter is incremented if the O2S signal is below the threshold value. This DTC is set based on the fail and sample counters.	Oxygen Sensor Signal	< 50 mvolts	No Active DTC's

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All Fuel Injectors for active Cylinders Fuel Condition Ethanol Estimation in Progress Fuel State All of the above met for	Enabled (On) ≤ 87 % Ethanol = Not Active (Please see “**Ethanol Estimation in Progress**” in Supporting Tables). DFCO not active > 5.0 seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 2 Sensor 2	P0158	This DTC determines if the O2 sensor signal circuit is shorted high or open. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold. The diagnostic failure counter is incremented if the O2S signal is above the threshold value. This DTC is set based on the fail and sample counters.	Oxygen Sensor Signal	> 1,050 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Low Fuel Condition Only when FuelLevelDataFault ********** Secondary delay after above conditions are complete (cold start condition) Secondary delay after above conditions are complete (not cold start condition) Commanded Equivalence Ratio ********** All of the above met for	TPS_ThrottleAuthorityDefaulted MAF_SensorFA MAP_SensorFA EvapExcessPurgePsbl_FA FuelInjectorCircuit_FA Ethanol Composition Sensor FA AIR System FA 11.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds = False = False ********** > 280.0 seconds when engine soak time > 28,800 seconds > 280.0 seconds when engine soak time ≤ 28,800 seconds ≤ 1.014 EQR ********** > 2 seconds	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 1) (For use w/o WRAF	P015A	DTC P015A detects that the primary oxygen sensor for Bank 1 has delayed response when the air fuel ratio transitions from rich to lean condition. This diagnostic runs simultaneously with the intrusive secondary O2 monitor rich to lean tests (P013E / P013A / P2271), which commands fuel cut off. Note: The Primary method is used when the primary O2 sensor signal transitions from above to below the O2 voltage threshold, otherwise the Secondary method is used. Primary method: The P015A diagnostic measures the primary O2 sensor response time between a rich condition above a starting voltage threshold and a lower voltage threshold. The response time is then scaled and normalized to mass air flow rate, engine speed, Baro, and intake air temperature resulting in a normalized delay	Primary Method: The EWMA of the Pre O2 sensor normalized R2L time delay value. The EWMA repass limit is The EWMA calculation uses a 0.25 coefficient. This method calculates the result when the Pre O2 sensor voltage is OR Secondary Method: The Accumulated time monitored during the R2L Delayed Response Test. AND Pre O2 sensor voltage is	> 0.60 EWMA (sec) ≤ 0.53 EWMA (sec) < 550 mvolts ≥ 2.5 Seconds > 99.0 mvolts	No Active DTC's System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Only when FuelLevelDataFault Green O2S Condition	TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA P0131, P0132, P013A, P013B, P013E, P013F, P2270, P2271 > 11.0 Volts = Not active = Not active = Not active = Not active = False = False = Not Valid, Green O2S condition is	Frequency: Once per trip Note: if NaESPD_b_FastInitRespIsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponseIsActive = TRUE, multiple tests per trip are allowed	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		value. The normalized delay is fed into a 1st order lag filter to update the final EWMA result. DTC P015A is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value. Secondary method: This fault is set if the primary O2 sensor does not achieve the required lower voltage threshold before a delay time threshold is reached.			O2 Heater (pre sensor) on for Learned Htr resistance Engine Coolant (Or OBD Coolant Enable Criteria IAT Engine run Accum Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) Closed loop integral	considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec. ≥ 40 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") > 50 ºC = TRUE) > -40 ºC > 30 seconds 1,000 ≤ RPM ≤ 2,500 950 ≤ RPM ≤ 2,550 4.0 ≤ gps ≤ 20.0 39.8 ≤ MPH ≤ 74.6 37.3 ≤ MPH ≤ 77.7 0.75 ≤ C/L Int ≤ 1.08		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Closed Loop Active Evap Ethanol Estimation in Progress Baro Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State ========== All of the above met for at least 0.8 seconds, and then the Force Cat Rich intrusive stage is requested. ========== Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders ========== After above conditions are met: DFCO Mode is entered (wo driver	= TRUE (Please see “**Closed Loop Enable Clarification**” in Supporting Tables). not in control of purge = Not Active (Please see **“Ethanol Estimation in Progress**” in Supporting Tables). > 70 kpa = enabled = not active = not active ≥ 60.0 sec 600 ≤ ºC ≤ 900 = DFCO possible ========== ========== ≥ 690 mvolts = DFCO active ≤ 7 cylinders ==========		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					initiated pedal input).			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 1) (For use w/o WRAF	P015B	DTC P015B detects that the primary oxygen sensor for Bank 1 has delayed response when the air fuel ratio transitions from lean to rich condition. This diagnostic runs simultaneously with the intrusive secondary O2 monitor lean to rich tests (P013F / P013B), which commands fuel enrichment. Note: The Primary method is used when the primary O2 sensor signal transitions from lean condition to above the O2 voltage threshold, otherwise the Secondary method is used. <u>Primary method</u>: The P015B diagnostic measures the primary O2 sensor response time between a lean condition and a higher voltage threshold. The response time is then scaled and normalized to mass air flow rate, engine speed, Baro, and intake air temperature resulting in a normalized delay value. The normalized delay is fed into a 1st	Primary method: The EWMA of the Pre O2 sensor normalized L2R time delay value. The EWMA repass limit is The EWMA calculation uses a 0.25 coefficient. OR Secondary method: The Accumulated time monitored during the L2R Delayed Response Test. AND Pre O2 sensor voltage is OR At end of Cat Rich stage the Pre O2 sensor output is	> 0.60 EWMA (sec) ≤ 0.52 EWMA (sec) ≥ 2.5 Seconds < 350 mvolts < 690 mvolts	No Active DTC's

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		order lag filter to update the final EWMA result. DTC P015B is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value. <u>Secondary method</u>: This fault is set if the primary O2 sensor does not achieve the required higher voltage threshold before a delay time threshold is reached.			Green O2S Condition O2 Heater (pre sensor) on for Learned Htr resistance Engine Coolant (Or OBD Coolant Enable Criteria IAT Engine run Accum Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after	= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec. ≥ 40 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") > 50 ºC = TRUE) > -40 ºC > 30 seconds 1,000 ≤ RPM ≤ 2,500 950 ≤ RPM ≤ 2,550 4.0 ≤ gps ≤ 20.0 39.8 ≤ MPH ≤ 74.6		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					initially enabled)	37.3 ≤ MPH ≤ 77.7		
					Closed loop integral Closed Loop Active	0.75 ≤ C/L Int ≤ 1.08 = TRUE (Please see "**Closed Loop Enable Clarification**" in Supporting Tables).		
					Evap	not in control of purge		
					Ethanol Estimation in Progress	= Not Active (Please see "**Ethanol Estimation in Progress**" in Supporting Tables).		
					Baro Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time	> 70 kpa = enabled = not active = not active ≥ 60.0 sec		
					Predicted Catalyst temp Fuel State Number of fueled cylinders	600 ≤ ºC ≤ 900 = DFCO inhibit ≥ 1 cylinders		
					========== When above conditions are met: Fuel Enrich mode is entered. ========== During this test: Engine Airflow must stay between: and the delta Engine Airflow over 12.5msec	========== ========== 4 ≤ gps ≤ 20		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					must be :	≤ 15.0 gps		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 2 Sensor 1) (For use w/o WRAF	P015C	DTC P015C detects that the primary oxygen sensor for Bank 2 has delayed response when the air fuel ratio transitions from rich to lean condition. This diagnostic runs simultaneously with the intrusive secondary O2 monitor rich to lean tests (P014A / P013C / P2273), which commands fuel cut off. Note: The Primary method is used when the primary O2 sensor signal transitions from above to below the O2 voltage threshold, otherwise the Secondary method is used. <u>Primary method</u>: The P015C diagnostic measures the primary O2 sensor response time between a rich condition above a starting voltage threshold and a lower voltage threshold. The response time is then scaled and normalized to mass air flow rate, engine speed, Baro, and intake air temperature resulting in a normalized delay	Primary method: The EWMA of the Pre O2 sensor normalized R2L time delay value. The EWMA repass limit is The EWMA calculation uses a 0.25 coefficient. This method calculates the result when the Pre O2 sensor voltage is OR Secondary method: The Accumulated time monitored during the R2L Delayed Response Test. AND Pre O2 sensor voltage is above	> 0.60 EWMA (sec) ≤ 0.53 EWMA (sec) < 550 mvolts ≥ 2.5 Seconds > 99 mvolts	No Active DTC's System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Only when FuelLevelDataFault Green O2S Condition	TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA P0151, P0152, P013C, P013D, P014A, P014B, P2272, P2273 > 11.0 Volts = Not active = Not active = Not active = Not active = False = False = Not Valid, Green O2S condition is	Frequency: Once per trip Note: if NaESPD_b_FastInitRespIsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponseIsActive = TRUE, multiple tests per trip are allowed	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		value. The normalized delay is fed into a 1st order lag filter to update the final EWMA result. DTC P015C is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value. Secondary method: This fault is set if the primary O2 sensor does not achieve the required lower voltage threshold before a delay time threshold is reached.			O2 Heater (pre sensor) on for Learned Htr resistance Engine Coolant (Or OBD Coolant Enable Criteria IAT Engine run Accum Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)	considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec. ≥ 40 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") > 50 ºC = TRUE) > -40 ºC > 30 seconds 1,000 ≤ RPM ≤ 2,500 950 ≤ RPM ≤ 2,550 4.0 ≤ gps ≤ 20.0 39.8 ≤ MPH ≤ 74.6 37.3 ≤ MPH ≤ 77.7		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Closed loop integral Closed Loop Active Evap Ethanol Estimation in Progress Baro Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State ========== All of the above met for at least 0.8 seconds, and then the Force Cat Rich intrusive stage is requested. ========== Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders ========== After above conditions are	0.75 ≤ C/L Int ≤ 1.08 = TRUE (Please see "**Closed Loop Enable Clarification**" in Supporting Tables). not in control of purge = Not Active (Please see "**Ethanol Estimation in Progress**" in Supporting Tables). > 70 kpa = enabled = not active = not active ≥ 60.0 sec 600 ≤ ºC ≤ 900 = DFCO possible ========== ========== ≥ 690 mvolts = DFCO active <= 7 cylinders ==========		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					met: DFCO Mode is entered (wo driver initiated pedal input).			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 2 Sensor 1) (For use w/o WRAF	P015D	DTC P015D detects that the primary oxygen sensor for Bank 2 has delayed response when the air fuel ratio transitions from lean to rich condition. This diagnostic runs simultaneously with the intrusive secondary O2 monitor lean to rich tests (P014B / P013D), which commands fuel enrichment. Note: The Primary method is used when the primary O2 sensor signal transitions from lean condition to above the O2 voltage threshold, otherwise the Secondary method is used. <u>Primary method</u>: The P015D diagnostic measures the primary O2 sensor response time between a lean condition and a higher voltage threshold. The response time is then scaled and normalized to mass air flow rate, engine speed, Baro, and intake air temperature resulting in a normalized delay value. The normalized delay is fed into a 1st	Primary method: The EWMA of the Pre O2 sensor normalized L2R time delay value. The EWMA repass limit is The EWMA calculation uses a 0.25 coefficient. OR Secondary method: The Accumulated time monitored during the L2R Delayed Response Test. AND Pre O2 sensor voltage is below OR At end of Cat Rich stage the Pre O2 sensor output is	> 0.60 EWMA (sec) ≤ 0.52 EWMA (sec) ≥ 2.5 Seconds < 350 mvolts < 690 mvolts	No Active DTC's

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		order lag filter to update the final EWMA result. DTC P015D is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value. <u>Secondary method</u>: This fault is set if the primary O2 sensor does not achieve the required higher voltage threshold before a delay time threshold is reached.			Green O2S Condition O2 Heater (pre sensor) on for Learned Htr resistance Engine Coolant (Or OBD Coolant Enable Criteria IAT Engine run Accum Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)	= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec. ≥ 40 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") > 50 ºC = TRUE) > -40 ºC > 30 seconds 1,000 ≤ RPM ≤ 2,500 950 ≤ RPM ≤ 2,550 4.0 ≤ gps ≤ 20.0 39.8 ≤ MPH ≤ 74.6 37.3 ≤ MPH ≤ 77.7		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Closed loop integral Closed Loop Active	0.75 ≤ C/L Int ≤ 1.08 = TRUE (Please see "**Closed Loop Enable Clarification**" in Supporting Tables).		
					Evap	not in control of purge		
					Ethanol Estimation in Progress	= Not Active (Please see "**Ethanol Estimation in Progress**" in Supporting Tables).		
					Baro Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time	> 70 kpa = enabled = not active = not active ≥ 60.0 sec		
					Predicted Catalyst temp Fuel State Number of fueled cylinders	600 ≤ ºC ≤ 900 = DFCO inhibit ≥ 1 cylinders		
					========== When above conditions are met: Fuel Enrich mode is entered. ========== During this test: Engine Airflow must stay between: and the delta Engine Airflow over 12.5msec must be :	========== ========== 4 ≤ gps ≤ 20 ≤ 15.0 gps		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 2 Sensor 2	P0161	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit. This test compares the measured heater current (monitored thru the low side driver) and compares it to the expected values (over the voltage range provided) for the released sensor. The diagnostic failure counter is incremented if the heater current is outside the expected range. This DTC is set based on the fail and sample counters.	Heater Current outside of the expected range of	0.3 > amps > 2.9	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA > 11.0 Volts = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Lean Bank 1	P0171	Determines if the primary fuel control system for Bank 1 is in a lean condition, based on the filtered long-term and short-term fuel trim. A normally operating system operates centered around long-term fuel trim metric of 1.0. For lean conditions extra fuel trim is required therefor values > 1.0 indicate a Lean condition. A fault is determined, when the long term fuel metric exceeds the threshold value. In addition to the long-term fuel trim limit, the short-term fuel trim metric can be monitored and the fault sets once both threshold values are exceeded. The short-term fuel trim metric is only monitored on programs that have acceptable emissions when the long-term fuel metric reaches its full authority.	The filtered long-term fuel trim metric AND The filtered short-term fuel trim metric (Note: any value below 0.95 effectively nullifies the short-term fuel trim criteria)	>= 1.350 >= 0.100 If a fault has been detected the long-term fuel trim metric must be < 1.350 and the short-term fuel trim metric must be < 1.150 to repass the diagnostic.	Engine speed BARO Coolant Temp Coolant Temp MAP Inlet Air Temp MAF Fuel Level Long Term Fuel Trim data accumulation: Sometimes, certain Long-Term Fuel Trim Cells are not utilized for control and/or diagnosis	400 <rpm< 7,000 > 70 kPa > -20 °C (or OBD Coolant Enable Criteria = TRUE) < 150 °C 10 <kPa< 255 -20 <°C< 150 1 <g/s< 1,000 > 10 % or if fuel sender is faulty the diagnostic will bypass the fuel level criteria. > 19.00 seconds of data must accumulate on each trip, with at least 10.00 seconds of data in the current fuel trim cell before a pass or fail decision can be made. Additional time can be required for cold ambient starts to accommodate larger minimum LTM's for startability reasons. See **Startup Engine Coolant adjusment to Minimum accumulation time** . (Please see **P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage** in Supporting Tables for a list of cells utilized for diagnosis)	Frequency: 100 ms Continuous Loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Closed Loop Long Term FT EGR Diag. Catalyst Diag. Post O2 Diag. Device Control EVAP Diag. No active DTC:	Enabled Enabled (Please see "**Closed Loop Enable Clarification**" and "**Long Term FT Enable Criteria**" in Supporting Tables.) Intrusive Test Not Active Intrusive Test Not Active Intrusive Test Not Active Not Active Large Leak Diagnostic (P0455) Not Active IAC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR System FA EvapExcessPurgePsbl_FA Ethanol Composition Sensor FA FuelInjectorCircuit_FA EngineMisfireDetected_FA EGRValvePerformance_FA EGRValveCircuit_FA MAP_EngineVacuumStatus AmbPresDfltdStatus TC_BoostPresSnsrFA O2S_Bank_1_Sensor_1_FA		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Rich Bank 1	P0172	Determines if the fuel control system is in a rich condition, based on the filtered long-term fuel trim metric.A normally operating system operates centered around long-term fuel trim metric of 1.0. For rich conditions less fuel trim is required therefor values < 1.0 indicate a rich condition. There are two methods to determine a Rich fault. They are Passive and Intrusive. A Passive Test decision can be made up until the time that purge is first enabled. From that point forward, rich faults can only be detected by turning purge off intrusively. If during this period of time the filtered long-term fuel trim metric exceeds the threshold a fault will be set. In addition to the long-term fuel trim limit, the short-term fuel trim metric can be monitored and the fault sets once both threshold values are exceeded. The short-	**Passive Test:** The filtered Non-Purge Long Term Fuel Trim metric AND The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria) ********** **Intrusive Test:** For 3 out of 5 intrusive segments The filtered Purge Long Term Fuel Trim metric AND The filtered Non-Purge Long Term Fuel Trim metric AND The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)	<= 0.710 ********** <= 0.700 <= 0.710 <= 2.000 If a fault has been detected (by the passive or intrusive test) the long-term fuel trim metric must be > 0.715 and the short-	********** Purge Vapor Fuel	Secondary Parameters and Enable Conditions are identical to those for P0171, with the exception that fuel level is not considered. ********** <= 100.00 % Intrusive Test is inhibited when Purge Vapor percentage is greater than this threshold. (Note: values greater than 50% indicate the Purge Vapor Fuel requirement is not being used) A minimum number of accumlated Fuel Trim Data samples are required to adequately learn a correct Purge Vapor Fuel value. See the table **Minimum Non-Purge Samples for Purge (Vapor Fuel)** for the Purge Off cells used to validate the Purge Vapor Fuel parameter.	Frequency: 100 ms Continuous Loop ********** **Segment Definition:** Segments can last up to 60 seconds and are separated by the lesser of 20.00 seconds of purge-on time or enough time to purge 36 grams of vapor. A maximum of 5 completed segments or 20 attempts are allowed for each intrusive test. After an intrusive test report is completed, another intrusive test cannot occur for 300 seconds to allow sufficient	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		term fuel trim metric is only monitored on programs that have acceptable emissions when the long-term fuel metric reaches its full authority. Once purge is enabled if the filtered Purge Long Term Fuel Trim metric > 0.700 , the test passes without intrusively checking the filtered Non-Purge Long Term Fuel Trim metric. However if the filtered Purge Long Term Fuel Trim metric is <= 0.700 , the Intrusive test is invoked. The purge is ramped off to determine if excess purge vapor is the cause of the rich condition. If during 3 out of 5 intrusive segments, the filtered Purge Long Term Fuel Trim metric <= 0.710 the fault will set. Performing intrusive tests too frequently may also affect EVAP and EPAIII emissions, and the execution frequency of other diagnostics. This is why the intrusive test is operated over several		term fuel trim metric must be > 0.850 to repass the diagnostic. The intrusive test will be enabled at long-term fuel metric values < 0.79 until the diagnostic repasses after a failure.		If the accumulated purge volume is > 0.0 grams, the intrusive test will not be inhibited even if Purge Vapor Fuel is > 100.0 %.	time to purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge Long Term Fuel Trim metric > 0.700 for at least 200.00 seconds, indicating that the canister has been purged.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		segments allowing Purge to renable between segments. Likewise, for these reasons, if after the 5 intrusive segments the diagnostic continues to pass, there is a delay period of 300 seconds to allow sufficient time to purge excess vapors from the canister, before re-evaluating a Rich condition if it still exists.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Lean Bank 2	P0174	Determines if the primary fuel control system for Bank 2 is in a lean condition, based on the filtered long-term and short-term fuel trim. A normally operating system operates centered around long-term fuel trim metric of 1.0. For lean conditions extra fuel trim is required therefor values > 1.0 indicate a Lean condition. A fault is determined, when the long term fuel metric exceeds the threshold value. In addition to the long-term fuel trim limit, the short-term fuel trim metric can be monitored and the fault sets once both threshold values are exceeded. The short-term fuel trim metric is only monitored on programs that have acceptable emissions when the long-term fuel metric reaches its full authority.	The filtered long-term fuel trim metric AND The filtered short-term fuel trim metric (Note: any value below 0.95 effectively nullifies the short-term fuel trim criteria)	>= 1.350 >= 0.100 If a fault has been detected the long-term fuel trim metric must be < 1.350 and the short-term fuel trim metric must be < 1.150 to repass the diagnostic.	Engine speed BARO Coolant Temp Coolant Temp MAP Inlet Air Temp MAF Fuel Level Long Term Fuel Trim data accumulation:

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Long Term FT EGR Diag. Catalyst Diag. Post O2 Diag. Device Control EVAP Diag. No active DTC:	Enabled (Please see "**Closed Loop Enable Clarification**" and "**Long Term FT Enable Criteria**" in Supporting Tables.) Intrusive Test Not Active Intrusive Test Not Active Intrusive Test Not Active Not Active Large Leak Diagnostic (P0455) Not Active IAC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR System FA EvapExcessPurgePsbl_FA Ethanol Composition Sensor FA FuelInjectorCircuit_FA EngineMisfireDetected_FA EGRValvePerformance_FA EGRValveCircuit_FA MAP_EngineVacuumStatus AmbPresDfltdStatus TC_BoostPresSnsrFA O2S_Bank_2_Sensor_1_FA		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Rich Bank 2	P0175	Determines if the fuel control system is in a rich condition, based on the filtered long-term fuel trim metric.A normally operating system operates centered around long-term fuel trim metric of 1.0. For rich conditions less fuel trim is required therefor values < 1.0 indicate a rich condition. There are two methods to determine a Rich fault. They are Passive and Intrusive. A Passive Test decision can be made up until the time that purge is first enabled. From that point forward, rich faults can only be detected by turning purge off intrusively. If during this period of time the filtered long-term fuel trim metric exceeds the threshold a fault will be set. In addition to the long-term fuel trim limit, the short-term fuel trim metric can be monitored and the fault sets once both threshold values are exceeded. The short-	**Passive Test:** The filtered Non-Purge Long Term Fuel Trim metric AND The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria) ********** **Intrusive Test:** For 3 out of 5 intrusive segments, the filtered Purge Long Term Fuel Trim metric AND The filtered Non-Purge Long Term Fuel Trim metric AND The filtered Short Term Fuel Trim metric (Note: any value above1.05 effectively nullifies the short-term fuel trim criteria)	<= 0.710 AND <= 2.000 ********** <= 0.700 AND <= 0.710 AND <= 2.000 If a fault has been detected (by the passive or intrusive test) the long-term fuel trim metric must be >	********** Purge Vapor Fuel	Secondary Parameters and Enable Conditions are identical to those for P0174, with the exception that fuel level is not considered. ********** <= 100.00 % Intrusive Test is inhibited when Purge Vapor percentage is greater than this threshold. (Note: values greater than 50% indicate the Purge Vapor Fuel requirement is not being used) A minimum number of accumlated Fuel Trim Data samples are required to adequately learn a correct Purge Vapor Fuel value. See the table **Minimum Non-Purge Samples for Purge (Vapor Fuel)** for the Purge Off cells used to validate the Purge Vapor Fuel parameter. If the accumulated purge volume is > 0.0 grams,	Frequency: 100 ms Continuous Loop ********** **Segment Definition:** Segments can last up to 60 seconds and are separated by the lesser of 20.00 seconds of purge-on time or enough time to purge 36 grams of vapor. A maximum of 5 completed segments or 20 attempts are allowed for each intrusive test. After an intrusive test report is completed, another intrusive test cannot occur for 300 seconds to allow sufficient time to	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		term fuel trim metric is only monitored on programs that have acceptable emissions when the long-term fuel metric reaches its full authority. Once purge is enabled if the filtered Purge Long Term Fuel Trim metric > 0.700 , the test passes without intrusively checking the filtered Non-Purge Long Term Fuel Trim metric. However if the filtered Purge Long Term Fuel Trim metric is <= 0.700 , the Intrusive test is invoked. The purge is ramped off to determine if excess purge vapor is the cause of the rich condition. If during 3 out of 5 intrusive segments, the filtered Purge Long Term Fuel Trim metric <= 0.710 the fault will set. Performing intrusive tests too frequently may also affect EVAP and EPAIII emissions, and the execution frequency of other diagnostics. This is why the intrusive test is operated over several		0.715 and the short-term fuel trim metric must be > 0.850 to repass the diagnostic. The intrusive test will be enabled at long-term fuel metric values < 0.79 until the diagnostic repasses after a failure.		the intrusive test will not be inhibited even if Purge Vapor Fuel is > 100.0 %. (Note: values greater than 50% indicate the Purge Vapor Fuel requirement is not being used)	purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge Long Term Fuel Trim metric > 0.700 for at least 200.00 seconds, indicating that the canister has been purged.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		segments allowing Purge to renable between segments. Likewise, for these reasons, if after the 5 intrusive segments the diagnostic continues to pass, there is a delay period of 300 seconds to allow sufficient time to purge excess vapors from the canister, before re-evaluating a Rich condition if it still exists.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pressure Sensor "B" Circuit Range/ Performance	P018B	This DTC detects a fuel pressure sensor response stuck within the normal operating range using an intrusive test (as follows) a] Intrusive Test Trigger: 1] Fuel Pump Duty Cycle Clamped Time (min or max duty cycle) >= 5 sec Or 2] Fuel Pres Err Variance <= calibration value KeFDBR_cmp_FPSS_MinPres Variance ; Otherwise, Report status as Pass b] Intrusive test freq limit: 60 sec between intrusive tests that pass, c] Intrusive test Fuel Flow limit: Fuel Flow Actual < Max allowed Fuel Flow rate	Sensed fuel pressure change [absolute value, during intrusive test]	<= 30 kPa	a) Diagnostic enabled [FDBR_b_FPSS_DiagEnbld] b) Timer Engine Running [FDBR_t_EngModeRunCoarse] c1) Fuel Flow Rate Valid c2) FDB_FuelPresSnsrCktFA c3) Reference Voltage Fault Status [DTC P0641] c4) FAB_FuelPmpCktFA c5) Fuel Control Enable Fault Active [DTC P12A6] c6) Fuel Pump Driver Module OverTemp Fault Active [DTC P1255] c7) Fuel Pump Speed Fault Active [DTC P129F] c8) CAN Sensor Bus message $0C3 Comm Fault [CFMR_b_FTZM_Info1_UcodeCmFA DTC P165C] c9) CAN Sensor Bus Fuel Pmp Spd Command ARC and Checksum Comm Fault Code [CFMR_b_FTZM_Cmd1_UcodeCmFA DTC]	a) == TRUE b) >= 5.00 seconds c1) == TRUE c2) <> TRUE c3) <> TRUE c4] <> TRUE c5) <> TRUE c6) <> TRUE c7) <> TRUE c8) <> TRUE c9] <> TRUE	1 sample / 12.5 millisec Intrusive Test Duration: Fuel Flow - related (5 to 12 sec)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					c10) Fuel Pump Duty Cycle Fault Active	c10) <> TRUE		
					c11) Sensor Configuration [FDBR_e_FuelPresSnsrConfig]	c11) == CeFDBR_e_WiredTo_ECM		
					c12) Sensor Bus Relay On	c12) == TRUE		
					d) Emissions Fuel Level Low [Message $3FB]	d) <> TRUE		
					e) Fuel Control Enable	e) == TRUE		
					f) Fuel Pump Control State	f) == Normal Control OR == Fuel Pres Sensor Stuck Control		
					g) Instantaneous Fuel Flow [FCBR_dm_InstFuelFlow]	g) >= 0.05 gm/sec		
					h) Diagnostic System Disabled [DRER_b_DiagSysDsb]	h) <> TRUE		
					j1) Fuel Pmp Speed Command Alive Rolling Count and Checksum Error [CAN Bus B $0CE] [CFMR_b_FTZM_Cmd1_ARC_ChkErr DTC]	j1) <> TRUE		
					j2) CAN Sensor Bus message $0C3_Available	j2) == TRUE		
					j3) Fuel Pres Sensor Ref Voltage Status Message Counter Incorrect Alive Rolling Count and	j3) <> TRUE		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Checksum Error [CAN Bus B $0C3] [CFMR_b_FTZM_Info1_ARC_ChkErr DTC]			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pressure Sensor "B" Circuit Low	P018C	This DTC detects if the fuel pressure sensor circuit is shorted low Values are analyzed as percent of sensor reference voltage [[Abs [5.0V - SensorVoltsActual] / 5.0V] *100%]	Fuel Pressure Sensor output % [re. full range as percent of 5.0V reference]	< 4.00 % or [0 kPa gauge]	a) Diagnostic enabled [FDBR_b_FPSnsrCktLoDiagEnbl] b) Run_Crank Active [PMDR_b_RunCrankActive c) Diagnostic System Disabled [DRER_b_DiagSysDsbl] d) Pressure Sensor Configuration [FDBR_e_FuelPresSnsrConfig]	a) == TRUE b) == TRUE c) <> TRUE d1) IF calibration CeFDBR_e_WiredTo_ECM == WiredTo ECM d2) IF NOT, then see Case2	64.00 failures / 80.00 samples 1 sample/12.5 ms	Type B, 2 Trips
			Fuel Pressure Sensor output % [re. full range as percent of 5.0V reference]	< 4.00 % or [0 kPa gauge]	a) Diagnostic enabled [FDBR_b_FPSnsrCktLoDiagEnbl] b) Run_Crank Active [PMDR_b_RunCrankActive c) Diagnostic System Disabled [DRER_b_DiagSysDsbl] d1) Pressure Sensor Configuration [FDBR_e_FuelPresSnsrConfig] d2) Sensor Bus Relay On d3) CAN Sensor Bus message $0C3_Available d4) Fuel Pres Sensor Ref	a) == TRUE b) == TRUE c) <> TRUE d1) IF calibration CeFDBR_e_WiredTo_ECM == WiredTo FTZM d2) == TRUE d3) == TRUE d4) <> TRUE	64.00 failures / 80.00 samples 1 sample/12.5 ms	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Voltage Status Message Counter Incorrect Alive Rolling Count and Checksum Error [CAN Bus B $0C3] [CFMR_b_FTZM_Info1_ARC_ChkErr DTC]	d2) IF calibration CeFDBR_e_WiredTo_ECM <> WiredTo FTZM, then see Case1		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pressure Sensor "B" Circuit High	P018D	This DTC detects if the fuel pressure sensor circuit is shorted High Values are analyzed as percent of sensor reference voltage [[Abs [5.0V - SensorVoltsActual] / 5.0V] *100%]	Fuel Pressure Sensor output % [re. full range as percent of 5.0V reference]	> 96.00 % or [743 kPa ga]	a) Diagnostic enabled [FDBR_b_FPSnsrCktLoDiagEnbl] b) Run_Crank Active [PMDR_b_RunCrankActive c) Diagnostic System Disabled [DRER_b_DiagSysDsbl] d) Pressure Sensor Configuration [FDBR_e_FuelPresSnsrConfig]	a) == TRUE b) == TRUE c) <> TRUE d1) IF calibration CeFDBR_e_WiredTo_ECM == WiredTo ECM d2) IF NOT, then see Case2	64.00 failures / 80.00 samples 1 sample/12.5 ms	Type B, 2 Trips
			Fuel Pressure Sensor output % [re. full range as percent of 5.0V reference]	> 96.00 % or [743 kPa ga]	a) Diagnostic enabled [FDBR_b_FPSnsrCktLoDiagEnbl] b) Run_Crank Active [PMDR_b_RunCrankActive c) Diagnostic System Disabled [DRER_b_DiagSysDsbl] d1) Pressure Sensor Configuration [FDBR_e_FuelPresSnsrConfig] d2) Sensor Bus Relay On d3) CAN Sensor Bus message $0C3_Available d4) Fuel Pres Sensor Ref	a) == TRUE b) == TRUE c) <> TRUE d1) IF calibration CeFDBR_e_WiredTo_ECM == WiredTo FTZM d2) == TRUE d3) == TRUE d4) <> TRUE	64.00 failures / 80.00 samples 1 sample/12.5 ms	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Voltage Status Message Counter Incorrect Alive Rolling Count and Checksum Error [CAN Bus B $0C3] [CFMR_b_FTZM_Info1_ARC_ChkErr DTC]	d2) IF calibration CeFDBR_e_WiredTo_ECM <> WiredTo FTZM, then see Case1		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT SIDI High Pressure Sensor Performance	P0191	The DTC determines if there is a skewed control fuel rail sensor (Sensor1) via a comparison to diagnostic sensor (sensor2) continuously when the engine is running and the commanded pressure is steady.	Primary sensor (P1) vs. Secondary sensor (P2) performance rationality **(**(Low Limit fail Filtered Fuel Control Error) OR (High Limit Fail: Filtered Fuel Control Error)**)** AND (FIltered Absolute delta between sensor1 and sensor2	<= **P0191 - Low fail limit of fuel control due to pressure sensor skewed low** (See supporting table) >= **P0191 - High fail limit of fuel control due to high pressure sensor skewed High** (see Supporting table) >= 1.00 mpa Note: fuel control error is calcuated based on the squreroot of senor1 divided by sensor2, this value is filter to ensure proper failure detection. Absolute delta between sensor1 and sensor2 value is filter to ensure proper failure detection.	Commanded Pressure rate of change (increasing or dercresing) for a period of time	< 0.70 mpa >= 1.25 seconds Enabled when a code clear is not active or not exiting device control	Filter Fuel Control Error term and Absolute delta between sensor1 and sensor2 exceed Low or High Fail limit for a duration >= 1.50 seconds This is diagnostic runs Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure Sensor 1 Out of Range	P0192	This DTC diagnose SENT high pressure sensor 1 that is too low out of range. If the sensor digital value (represnting the refernce voltage) is below the lower digital threshold, the low fail counter then increments. If the low fail counter reaches its threshold then a fail is reported. A pass is reported for this DTC if the low sample counter reaches its threshold.	High Pressure Rail Sensor 1 SENT digital read value	=< 94			Time Based: 400 Failuer out of 500 Samples 6.25 ms per Sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Temperature (EOT) Sensor Performance	P0196	Determines if the engine oil temperature (EOT) sensor is stuck or biased in range. Three independent tests can be used.1) Cold Start Test Compares EOT to ECT and IAT at powerup after a long soak (Fast and regular tests). 2) Warm Up Test Compares EOT to a target EOT after a large enough accumulated airflow has occurred. 3) Continuous Test Compares the measured EOT to modeled EOT on a continuous basis on a warm engine.	**Fast Cold Start Test** <u>To indicate an fast fail:</u> Absolute value of Powerup EOT - Powerup ECT AND Absolute value of Powerup IAT - Powerup ECT <u>To indicate a fast pass</u>: Absolute value of Powerup EOT - Powerup ECT AND Absolute value of Powerup EOT - Powerup IAT	 EOT Temp Diff > **P0196_FastFailTemp Diff** (See P0196 details on Supporting Tables Tab) AND < 16 degrees C < 16 degrees C AND < 16 degrees C	EOT Diagnostic main Status AND Engine Running Cold Start Specific EOT Test Conditions: Use Cold Start Diagnostic Engine Off Time Engine Off Timer Validity No active DTC's	Enabled = True Disabled > 540 Seconds = True Fault bundles: IgnitionOffTimer_FA IAT_SensorFA ECT_Sensor_Ckt_FA MAF_SensorFA EngOilTempSensorCircuit FA	Cold Start Fast Test - one failure out of one sample - test performed once per second	Type B, 2 Trips
			Cold Start Test <u>Pass Condition 1:</u> Absolute value of Powerup EOT - Powerup ECT AND Absolute value of Powerup EOT - minIAT OR <u>Pass Condition 2:</u> Absolute value of Powerup EOT - Powerup ECT	 <= 16 Deg C <= 16 Deg C OR > 16 Deg C	All three tests (Cold/ Warm/Continuous) EOT Diagnostic main enable AND Engine Running Cold Start Specific EOT Test Conditions: Use Cold Start Diagnostic Engine Off Time Engine Off Timer Validity	 Enabled = True Disabled > 540 Seconds = True	Cold Start Regular Test - one failure out of one sample - test performed once per second	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AND (IAT minimum observed with Block Heater or (IAT minimum observed and Absolute value of power up IAT - min. observed IAT)) AND Absolute value of Powerup EOT - Powerup IAT AND Absolute value of Powerup EOT - minIAT <u>Fail Condition:</u> Absolute value of Powerup EOT - Powerup ECT AND (IAT minimum observed with Block Heater or (IAT minimum observed and Absolute value of power up IAT - min. observed IAT)) AND (Absolute value of Powerup EOT - Powerup IAT or Absolute value of Powerup EOT - minIAT) AND Absolute value of Powerup ECT - Powerup IAT	AND > 222 Deg C > -10 Deg C <= 5 Deg C AND <= 16 Deg C <= 16 Deg C > 16 Deg C AND > 222 Deg C > -10 Deg C <= 5 Deg C AND > 16 Deg C > 16 Deg C AND <= 16 Deg C	Time above Minimum Vehicle Speed Time less than Vehicle speed resets above timer No active DTC's	> 9 MPH for > 400 seconds < 15.0 for > 20.0 seconds Fault bundles: IgnitionOffTimer_FA IAT_SensorFA ECT_Sensor_Ckt_FA MAF_SensorFA EngOilTempSensorCircuit FA		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AND Absolute value of Powerup ECT - minIAT	AND <= 16 Deg C				
			Warmup Test <u>Warm Up Fail Condition:</u> EOT <u>Warm Up Test Pass Condition:</u> EOT	 < 70 Deg C => 70 Deg C	 EOT Diagnostic main enable Engine Running Warm Up EOT Test Specific Conditions: Use Warm Up EOT Diagnostic Power up ECT Power up ECT Total accumulated engine airflow since engine start DISABLE CONDITIONS (for all three tests)No active DTC's	 Enabled = True Disabled > 200 degrees C < 200 degrees C >= **P0196_TotalAccumulatedFlow** (See P0196 details on Supporting Tables Tab) Fault bundles: IAT_SensorFA ECT_Sensor_Ckt_FA MAF_SensorFA EngOilTempSensorCircuit FA	Warm up Tests - one failure out of one sample - test performed once per second	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Continuous Test <u>Pass Condition:</u> (Measured Oil Temperature - Modeled Oil Temperature) OR Absolute value of (Measured Oil Temperature - Modeled Oil Temperature) <u>Fail Condition:</u> (Measured Oil Temperature - Modeled Oil Temperature) AND Absolute value of (Measured Oil Temperature - Modeled Oil Temperature)	 >= 0 and <= 40.0 OR >= 0 and <= 40.0 > 40.0 AND > 40.0	EOT Diagnostic main enable Engine Running Continuous EOT Test Specific Conditions: Use Continuous Diagnostic Power up ECT and ECT All of three criteria above AND EOT Model Oil Temperature reach Equilibrium OR Use quick transition to equilibrium state and ECT DISABLE CONDITIONS (for all three tests)No active DTC's	Enabled = True Enabled >= -7 and <= 105 Deg C >= 45 and <= 105 Deg C >= 93 Deg C Enabled and >= ECT from 5 sec previous Fault bundles: IAT_SensorFA ECT_Sensor_Ckt_FA MAF_SensorFA EngOilTempSensorCircuit FA IAT_SensorCircuitFA EngOilModeledTempValid	Continuous Test 70 failures out of 100 samples performed once per second	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Temperature (EOT) Circuit Low	P0197	Controller specific output driver circuit diagnoses the Engine Oil Temperature (EOT) Sensor low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Engine Oil Temperature Sensor (EOT) Circuit Resistance	< 25 ohms	Diagnostic Status	Enabled	222 failures out of 50 samples Sampled every 1 second	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Temperature (EOT) Circuit High	P0198	Controller specific output driver circuit diagnoses the Engine Oil Temperature (EOT) Sensor low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Engine Oil Temperature Sensor (EOT) Circuit Resistance	> 450,000 ohms	Diagnostic Status Engine Run Time OR ECT	Enabled > 20.0 seconds >= -20 Deg C	222 failures out of 50 samples Sampled every 1 second	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Temperature Sensor (EOT) Circuit Intermittent	P0199	Determines if an intermittent fault exists on the engine oil temperature sensor circuit. This diagnostic compares each temperature sample to the previous sample and measures cumulative error over a sample period.	**Continuous Test** Pass/Fail Condition: Temperature signal string length, cumulative sum of absolute value of (Oil Temperature - Previous Oil Temperature)	String Length >= 10.00 °C	None	Enabled AND EngOilTempFA = FALSE	4 failures out of 5 samples, sampled every 2 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Coolant Temperature Dropped Below Diagnostic Monitoring Temperature	P01F0	This DTC detects an unexplained cooling system cool down below the OBD monitoring threshold during normal operating conditions. This check is run throughout the key cycle.	For this application the "type" cal (KeTHMG_b_TMS_ElecThstEquipped) = 0 If the type cal is equal to one, the application has an electrically heated t-stat, if equal to zero the the application has an non heated t-stat. See appropiate section below. ********** Type cal above = 0 (non - heated t-stat) == == == ==		No Active DTC's	ECT_Sensor_Ckt_FA VehicleSpeedSensor_FA OAT_PtEstFiltFA THMR_AWP_AuxPumpFA THMR_AHV_FA THMR_SWP_Control_FA EngineTorqueEstInaccurate ECT_Sensor_Perf_FA THMR_SWP_NoFlow_FA THMR_SWP_FlowStuckOn_FA	30 seconds out of a 60 seconds window	Type B, 2 Trips
					Engine Runtime	≥ 0.0 seconds		
			Engine coolant temperature	≤ 74.0 Deg C	Distance traveled this key cycle	≥ 1.2 km		
			**********		Ambient air pressure	≥ 55.0 kPa		
			Type cal above = 1 (Electrically heated t-stat) == == == ==		Ambient air temperature	≥ -9.0 Deg C		
					**********			
			Engine coolant temperature	≤ 78.4 Deg C	Engine coolant temperature At least once during the key cycle			
					Type 0 (non-heated t-stat)	≥ 75 Deg C		
					Type 1 (Electrically heated T-stat)	≥ 79.4 to 94.4 Deg C		
					**********			
					Heat to coolant	≥ **P01F0 - Heat To Coolant Min**		
					DFCO time	≤ 0.0 seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Thermostat duty cycle RPM Active Fuel Management is not in	≤ 20.0 % ≤ 8,192 Half Cylinder Mode		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Open Circuit - (SIDI)	P0201	Controller specific output driver circuit diagnoses Injector 1 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. Or Controller specific output driver circuit diagnoses Injector 1 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit. Or Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	>= 200 KOhms impedance between signal and controller ground >= 200 KOhms impedance between signal and controller ground	Battery Voltage Engine Running	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Open Circuit - (SIDI)	P0202	Controller specific output driver circuit diagnoses Injector 2 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. Or Controller specific output driver circuit diagnoses Injector 2 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit. Or Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	>= 200 KOhms impedance between signal and controller ground >= 200 KOhms impedance between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Open Circuit - (SIDI)	P0203	Controller specific output driver circuit diagnoses Injector 3 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. Or Controller specific output driver circuit diagnoses Injector 3 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit. Or Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	>= 200 KOhms impedance between signal and controller ground >= 200 KOhms impedance between signal and controller ground	Battery Voltage Engine Running	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Open Circuit - (SIDI)	P0204	Controller specific output driver circuit diagnoses Injector 4 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. Or Controller specific output driver circuit diagnoses Injector 4 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit. Or Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	>= 200 KOhms impedance between signal and controller ground >= 200 KOhms impedance between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 Open Circuit - (SIDI)	P0205	Controller specific output driver circuit diagnoses Injector 5 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. Or Controller specific output driver circuit diagnoses Injector 5 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit. Or Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	>= 200 KOhms impedance between signal and controller ground >= 200 KOhms impedance between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 Open Circuit - (SIDI)	P0206	Controller specific output driver circuit diagnoses Injector 6 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. Or Controller specific output driver circuit diagnoses Injector 6 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit. Or Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	>= 200 KOhms impedance between signal and controller ground >= 200 KOhms impedance between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 Open Circuit - (SIDI)	P0207	Controller specific output driver circuit diagnoses Injector 7 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. Or Controller specific output driver circuit diagnoses Injector 7 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit. Or Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	>= 200 KOhms impedance between signal and controller ground >= 200 KOhms impedance between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 8 Open Circuit - (SIDI)	P0208	Controller specific output driver circuit diagnoses Injector 7 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. Or Controller specific output driver circuit diagnoses Injector 7 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit. Or Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	>= 200 KOhms impedance between signal and controller ground >= 200 KOhms impedance between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit Low	P0222	Detects a continuous or intermittent short low or open in TPS2 circuit by monitoring the TPS 2 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too low. This diagnostic only runs when battery voltage is high enough.	TPS2 % Vref <	0.250 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P06A3	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit High	P0223	Detects a continuous or intermittent short high in TPS2 circuit by monitoring the TPS 2 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too high. This diagnostic only runs when battery voltage is high enough.	TPS2 % Vref >	4.590 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P06A3	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to ground (SIDI)	P0261	Controller specific output driver circuit diagnoses Injector 1 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	 <= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to power (SIDI)	P0262	Controller specific output driver circuit diagnoses Injector 1 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to ground (SIDI)	P0264	Controller specific output driver circuit diagnoses Injector 2 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	 <= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to power (SIDI)	P0265	Controller specific output driver circuit diagnoses Injector 2 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to ground (SIDI)	P0267	Controller specific output driver circuit diagnoses Injector 3 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	 <= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to power (SIDI)	P0268	Controller specific output driver circuit diagnoses Injector 3 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to ground (SIDI)	P0270	Controller specific output driver circuit diagnoses Injector 4 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	 <= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to power (SIDI)	P0271	Controller specific output driver circuit diagnoses Injector 4 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 Low side circuit shorted to ground (SIDI)	P0273	Controller specific output driver circuit diagnoses Injector 5 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	 <= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 Low side circuit shorted to power (SIDI)	P0274	Controller specific output driver circuit diagnoses Injector 5 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 Low side circuit shorted to ground (SIDI)	P0276	Controller specific output driver circuit diagnoses Injector 6 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	 <= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 Low side circuit shorted to power (SIDI)	P0277	Controller specific output driver circuit diagnoses Injector 6 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 Low side circuit shorted to ground (SIDI)	P0279	Controller specific output driver circuit diagnoses Injector 7 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	 <= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 Low side circuit shorted to power (SIDI)	P0280	Controller specific output driver circuit diagnoses Injector 7 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 8 Low side circuit shorted to ground (SIDI)	P0282	Controller specific output driver circuit diagnoses Injector 8 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	 <= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 8 Low side circuit shorted to power (SIDI)	P0283	Controller specific output driver circuit diagnoses Injector 8 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Per Cylinder	P0324	This diagnostic checks for knock sensor performance out of the normal expected range on a per cylinder basis due to Excessive Knock (either real or false knock). In the knock detection algorithm, the term “Knock Intensity” (KI) is used to define the relative size of a knock event, and is calculated as (KI = current knock event - knock threshold). This results in a KI amplitude that is proportional to the size of the knock event (as seen by the knock sensor). In addition, Knock Intensity cannot be less than zero as it is forced/limited to be = 0 with no knock detected (i.e. whenever the current knock event < knock threshold, KI = 0). This diagnostic calculates a first-order lag filter version of the Knock Intensity and sets a fault when: (Filtered KI) > (Excessive Knock Diagnostic Threshold)	Filtered Knock Intensity (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)	**> P0324_PerCyl_ExcessiveKnock_Threshold** (no units)	Diagnostic Enabled? Engine Run Time Engine Speed Engine Air Flow Engine Coolant Temperature or OBD Coolant Enable Criteria Inlet Air Temperature Cumlative Number of Engine Revs Above Min Eng Speed (per key cycle)	Yes ≥ 2.0 seconds ≥ 400 RPM AND ≤ 8,500 RPM ≥ 200 mg/cylinder AND ≤ 2,000 mg/cylinder ≥ -40 deg's C = TRUE ≥ -40 deg's C ≥ 80 revs	First Order Lag Filters with Weight Coefficient = 0.0500 Updated each engine event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank 1	P0325	This diagnostic checks for an open in the knock sensor circuit Sensor 1/Bank 1. There are two possible methods used: 1. **20 kHz Method**: This method injects a 20 kHz signal (internal to the ECU) onto one of the Knock Sensor inputs. For a normal/ good circuit the 20 kHz signal will propogate through the Knock sensor and back to the ECU through the sensor return circuit. The 20 kHz signal is processed through the Fast Fourier Transform (FFT) and then filtered with a first-order lag filter. Since the Knock Detection algorithm uses a Differential Op-Amp to compare the input from the two knock sensor wires, the FFT 20 kHz diagnostic signal will have either: A. Low output with a good circuit (because the 20 kHz injected signal is detected on both of the sensor inputs) or B, High output for an Open Circuit (because	Open Circuit Method chosen (2 possible methods: 20 kHz or Normal Noise): Filtered FFT Output Filtered FFT Output	= **P0325_P0330_OpenMethod_2** **Case 1 (20 kHz Method):** **>** **P0325_P0330_OpenCktThrshMin (20 kHz)** **AND** **<** **P0325_P0330_OpenCktThrshMax (20 kHz)** **Case 2 (Normal Noise Method):** **>** **P0325_P0330_OpenCktThrshMin (Normal Noise)** **AND** **<** **P0325_P0330_OpenCktThrshMax (Normal Noise)**	Diagnostic Enabled? Engine Run Time Engine Speed Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above) Engine Air Flow Engine Coolant Temperature or OBD Coolant Enable Criteria Inlet Air Temperature	Yes ≥ 2.0 seconds ≥ 400 RPM and ≤ 8,500 RPM ≥ 102 revs ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder ≥ -40 deg's C = TRUE ≥ -40 deg's C	First Order Lag Filter with Weight Coefficient Weight Coefficient = 0.0100 Updated each engine event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		the 20 kHz injected signal is detected only on one of the sensor inputs). The 20 kHz method is typically used for the entire operating region of the engine. However, some engines may not have adequate separation between good and bad circuits at high engine speed. In these cases the 20 kHz method is used at low and medium engine speeds, and the "Normal Noise" method is used at high engine speed only. 2. **Normal Noise**: The Normal Noise method monitors the background engine noise level for a selected frequency range output of the knock detection FFT. The background noise (i.e. Normal Noise) is filtered with a first-order lag filter. A good circuit is determined when the filtered Normal Noise signal is greater than the threshold. See Supporting Tables for method definition: **P0325_P0330_OpenM**						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		ethod defines which of the two diagnostic methods is used as a fucntion of engine speed (RPM). Typical implementations: A. Use 20 kHz method at allengine RPM (used when acceptable separation achieved at all RPM) or B. Use 20 kHz method at low/medium RPM and Normal Noise at high RPM						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Bank 1	P0326	This diagnostic checks for knock sensor performance out of the normal expected range, on a per sensor basis. This diagnostic is specifically designed to identify the fault condition where the knock sensor is properly attached electrically, but produces an abnormally low output due to being unattached (or loosely attached) with the mounting bolt (and thus unable to properly transfer the engine vibration energy from the engine block to the knock sensor). The term "Abnormal (engine) Noise" is used to define this diagnostic method. A fault condition is identified when a first-order lag filtered version of the Abnormal Noise signal falls below the diagnostic threshold.	Filtered FFT Intensity (where 'FFT Intensity' = Non-knocking, background engine noise for a selected frequency) OR Filtered FFT Intensity	**Case 1: Engine not in AFM mode** **P0326_P0331_AbnormalNoise_Threshold** (Supporting Table) **Case 2: Engine is in AFM mode** **P0326_P0331_AbnormalNoise_Thresh_AFM** (Supporting Table; Engine is in AFM mode)	Diagnostic Enabled? Engine Run Time Engine Speed Engine Air Flow Engine Coolant Temperature or OBD Coolant Enable Criteria Inlet Air Temperature Individual Cylinders enabled for Abnormal Noise Cumlative Number of Engine Revs Above Min Eng Speed (per key cycle)	Yes ≥ 2.0 seconds ≥ 2,150 RPM (not in AFM mode) OR ≥ 2,100 (in AFM mode) AND ≤ 8,500 RPM ≥ 300 mg/cylinder AND ≤ 2,000 mg/cylinder ≥ -40 deg's C = TRUE ≥ -40 deg's C **P0326_P0331_AbnormalNoise_CylsEnabled** (Supporting Table) ≥ 232 Revs	First Order Lag Filters with Weight Coefficient = 0.0050 Updated each engine event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 1	P0327	This diagnostic checks for an out of range low knock sensor signal. A 3-resistor bias network at each sensor input to the ECM provides a DC diagnostic voltage that will remain within a normal range when the external knock sensor circuit is free of short circuit faults. The diagnostic output is reported as a percentage (0 to 100%) when compared to the 5.0 volt reference voltage.	Sensor Input or Return Signal Line	< 8.0 Percent (of 5.0 Volt reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 1	P0328	This diagnostic checks for an out of range high knock sensor signal. A 3-resistor bias network at each sensor input to the ECM provides a DC diagnostic voltage that will remain within a normal range when the external knock sensor circuit is free of short circuit faults. The diagnostic output is reported as a percentage (0 to 100%) when compared to the 5.0 volt reference voltage.	Sensor Input or Return Signal Line	> 39.0 Percent (of 5 Volt Reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank 2	P0330	This diagnostic checks for an open in the knock sensor circuit Sensor 2/Bank 2 There are two possible methods used: 1. **20 kHz Method**: This method injects a 20 kHz signal (internal to the ECU) onto one of the Knock Sensor inputs. For a normal/ good circuit the 20 kHz signal will propogate through the Knock sensor and back to the ECU through the sensor return circuit. The 20 kHz signal is processed through the Fast Fourier Transform (FFT) and then filtered with a first-order lag filter. Since the Knock Detection algorithm uses a Differential Op-Amp to compare the input from the two knock sensor wires, the FFT 20 kHz diagnostic signal will have either: A. Low output with a good circuit (because the 20 kHz injected signal is detected on both of the sensor inputs) or B, High output for an	**Open Circuit Method chosen** (2 possible methods: 20 kHz or Normal Noise):

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Open Circuit (because the 20 kHz injected signal is detected only on one of the sensor inputs). The 20 kHz method is typically used for the entire operating region of the engine. However, some engines may not have adequate separation between good and bad circuits at high engine speed. In these cases the 20 kHz method is used at low and medium engine speeds, and the "Normal Noise" method is used at high engine speed only. 2. **Normal Noise**: The Normal Noise method monitors the background engine noise level for a selected frequency range output of the knock detection FFT. The background noise (i.e. Normal Noise) is filtered with a first-order lag filter. A good circuit is determined when the filtered Normal Noise signal is greater than the threshold. See Supporting Tables						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		for method definition: **P0325_P0330_OpenMethod** defines which of the two diagnostic methods is used as a fucntion of engine speed (RPM). Typical implementations: A. Use 20 kHz method at allengine RPM (used when acceptable separation achieved at all RPM) or B. Use 20 kHz method at low/medium RPM and Normal Noise at high RPM						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Bank 2	P0331	This diagnostic checks for knock sensor performance out of the normal expected range, on a per sensor basis. This diagnostic is specifically designed to identify the fault condition where the knock sensor is properly attached electrically, but produces an Abnormally low output due to being unattached (or loosely attached) with the the mounting bolt (and thus unable to properly transfer the engine vibration energy from the engine block to the knock sensor). The term "Abnormal (engine) Noise" is used to define this diagnostic method. A fault condition is identified when a first-order lag filtered version of the Abnormal Noise signal falls below the diagnostic threshold.	Filtered FFT Intensity (where 'FFT Intensity' = Non-knocking, background engine noise) Filtered FFT Intensity	**Case 1: Engine <u>not</u> in AFM mode** < **P0326_P0331_AbnormalNoise_Threshold** (Supporting Table) OR **Case 2: Engine <u>is</u> in AFM mode** < **P0326_P0331_AbnormalNoise_Thresh_AFM** (Supporting Table)	Diagnostic Enabled? Engine Run Time Engine Speed Engine Air Flow Engine Coolant Temperature or OBD Coolant Enable Criteria Inlet Air Temperature Individual Cylinders enabled for Abnormal Noise Cumlative Number of Engine Revs Above Min Eng Speed (per key cycle)	Yes ≥ 2.0 seconds ≥ 2,150 RPM (not in AFM mode) OR > 2,100 (in AFM mode) AND ≤ 8,500 RPM ≥ 300 mg/cylinder AND ≤ 2,000 mg/cylinder ≥ -40 deg's C = TRUE ≥ -40 deg's C **P0326_P0331_AbnormalNoise_CylsEnabled** (Supporting Table) ≥ 232 Revs	First Order Lag Filters with Weight Coefficient = 0.0050 Updated each engine event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 2	P0332	This diagnostic checks for an out of range low knock sensor signal. A 3-resistor bias network at each sensor input to the ECM provides a DC diagnostic voltage that will remain within a normal range when the external knock sensor circuit is free of short circuit faults. The diagnostic output is reported as a percentage (0 to 100%) when compared to the 5.0 volt reference voltage.	Sensor Input or Return Signal Line	< 8.0 Percent (of 5 Volt Reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 2	P0333	This diagnostic checks for an out of range high knock sensor signal. A 3-resistor bias network at each sensor input to the ECM provides a DC diagnostic voltage that will remain within a normal range when the external knock sensor circuit is free of short circuit faults. The diagnostic output is reported as a percentage (0 to 100%) when compared to the 5.0 volt reference voltage.	Sensor Input or Return Signal Line	> 39.00 Percent (of 5 Volt Reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Circuit	P0335	Diagnostic will fail if a crank sensor pulse was not received during a period of time; if crank sensor pulses are received the diagnostic will pass.	Time since last crankshaft position sensor pulse received	>= 4.0 seconds	Starter engaged AND (cam pulses being received OR (MAF_SensorFA AND Engine Air Flow	 = FALSE > 3.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips
			No crankshaft pulses received	>= 0.3 seconds	Engine is Running Starter is not engaged		Continuous every 12.5 msec	
			No crankshaft pulses received		Engine is Running OR Starter is engaged No DTC Active:	 P0340 P0341	2 failures out of 10 samples One sample per engine revolution	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Performance	P0336	1. Fail counts will occur if the engine goes out of synchronization repeatedly over a period of time and will pass if the engine stays in synchronization. 2. Diagnostic will fail if synchronization gap is not found in a specified period of time and will pass if the synchronization gap is found. 3. Diagnostic will fail if the incorrect number of crank sensor teeth are detected in-between detecting the synchronization gap and will pass if the correct number of teeth are seen.	Time in which 10 or more crank re-synchronizations occur	< 10.0 seconds	Engine Air Flow Cam-based engine speed No DTC Active:	>= 3.0 grams/second > 450 RPM P0335	Continuous every 250 msec	Type B, 2 Trips
			No crankshaft synchronization gap found	>= 0.4 seconds	Engine is Running Starter is not engaged		Continuous every 12.5 msec	
			Time since starter engaged without detecting crankshaft synchronization gap	>= 3.3 seconds	Starter engaged AND (cam pulses being received OR (MAF_SensorFA AND Engine Air Flow	 = FALSE > 3.0 grams/second))	Continuous every 100 msec	
			Crank pulses received in one engine revolution OR Crank pulses received in one engine revolution	< 1 > 65,535	Engine is Running OR Starter is engaged No DTC Active:	 P0340 P0341	8 failures out of 10 samples One sample per engine revolution	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor A	P0340	Diagnostic will fail if a cam sensor pulse was not received during a period of time; if cam sensor pulses are received the diagnostic will pass.	Time since last camshaft position sensor pulse received OR Time that starter has been engaged without a camshaft sensor pulse	>= 5.5 seconds >= 4.0 seconds	Starter engaged AND (crank pulses being received OR (MAF_SensorFA AND Engine Air Flow	 = FALSE > 3.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged		Continuous every 100 msec	
			No camshaft pulses received during first 24 MEDRES events (There are 24 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	 CrankSensor_FA	Continuous every MEDRES event	
			The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	 CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor A	P0341	Diagnostic will fail if an incorrect number of cam sensor pulses are detected over a number of engine cycles and will pass if the number of cam pulses is correct.	The number of camshaft pulses received during first 24 MEDRES events is OR (There are 24 MEDRES events per engine cycle)	< 4 > 8	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	CrankSensor_FA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position Sensor - Crankshaft Start Position Incorrect	P034A	Monitors the position of the crankshaft during auto-start's to verify that the crankshaft is in the expected position- diagnostic will fail if the crankshaft is not in the expected range otherwise the diagnostic will pass	Crankshaft position is in error by a number of crankshaft wheel teeth	> 1 crankshaft teeth	Engine has started rotating during a hybrid auto-start Crankshaft position is being verified No Active DTCs:	CrankSensor_FA	1 failures out of 3 samples a sample occurs each time the engine is started	Type B, 2 Trips
			Crankshaft position is in error by at least one crankshaft wheel tooth		Engine has started rotating during a hybrid auto-start Crankshaft position is being verified No Active DTCs:	CrankSensor_FA	4 failures out of 5 samples a sample occurs each time the engine is started	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position Sensor - Crankshaft Direction Incorrect	P034B	Detects if the crankshaft is not rotating in the correct direction- will fail if the engine is reported to be spinning backwards while the engine is running otherwise the diagnostic will pass.	Number of crankshaft sensor reversals within a period of time	>= 3 <= 10.0 seconds	Engine Speed Engine Speed Engine Air Flow Engine Movement Detected No Active DTCs:	> 400 RPM < 2,000 RPM >= 3.0 grams/second CrankSensor_FA	Continuous Every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT	P0351	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	$\geq$ 30 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT	P0352	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	$\geq$ 30 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT	P0353	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	$\geq$ 30 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT	P0354	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	$\geq$ 30 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #5 CIRCUIT	P0355	Diagnoses Cylinder #5 Ignition Control (EST) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	$\geq$ 30 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #6 CIRCUIT	P0356	Diagnoses Cylinder #6 Ignition Control (EST) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 30 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #7 CIRCUIT	P0357	Diagnoses Cylinder #7 Ignition Control (EST) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	$\geq$ 30 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #8 CIRCUIT	P0358	Diagnoses Cylinder #8 Ignition Control (EST) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 30 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 1	P0420	NOTE: The information below applies to applications that use the Decel Catalyst Monitor Algorithm Oxygen Storage. The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (I.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Rich (intrusive rich) and Lean (decel fuel cutoff) A/F excursions Normalized Ratio OSC Value Calculation Information and Definitions = 1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time) 2. BestFailing OSC value from a calibration	Normalized Ratio OSC Value (EWMA filtered)	< 0.35	All enable criteria associated with P0420 can be found under P2270 - (O2 Sensor Signal Stuck Lean Bank 1 Sensor 2) Rapid Step Response (RSR) feature will initiate multiple tests: If the difference between current EWMA value and the current OSC Normalized Ratio value is and the current OSC Normalized Ratio value is Maximum number of RSR tests to detect failure when RSR is enabled. MAF Predicted catalyst temperature Front O2 Sensor or Front WRAF Rear O2 Sensor General Enable Criteria In addition to the p-codes listed under P2270, the following DTC's shall also	 > 0.52 < 0.13 6 > 4.00 g/s < 20.00 g/s < 850 ° C > 680.00 mV or > 1.25 EQR > 825.00 mV	1 test attempted per valid decel period Minimum of 1 test per trip Maximum of 3 tests per trip Frequency: Fueling Related : 12.5 ms OSC Measurements: 100 ms Temp Prediction: 12.5ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		table (based on temp and exhaust gas flow) 3. WorstPassing OSC value (based on temp and exhaust gas flow) Normalized Ratio Calculation = (1-2) / (3-2) A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part. Refer to the **P0420_WorstPassingOSCTableB1** and **P0420_BestFailingOSCTableB1** in Supporting Tables tab for details The Catalyst Monitoring Test is completed during a decel fuel cutoff event. This fuel cutoff event occurs following a rich instrusive fueling event initiated by the O2 Sensor Signal Stuck Lean Bank 1 Sensor 2 test (P2270). Several conditions must be met in order to execute this test. Additional conditions and their related values			not be set: For switching O2 sensors: For WRAF O2 sensors:	 O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_2_FA WRAF_Bank_1_FA WRAF_Bank_2_FA **P0420_WorstPassingOSCTableB1** **P0420_BestFailingOSCTableB1**		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		are listed in the "Secondary Parameters" and "Enable Conditions" section of this document for P2270 (O2 Sensor Signal Stuck Lean Bank 1 Sensor 2)						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 2	P0430	Note: The information below applies to applications that use the Decel Catalyst Monitor Algorithm Oxygen Storage. The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (I.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Rich (intrusive rich) and Lean (decel fuel cutoff) A/F excursions Normalized Ratio OSC Value Calculation Information and Definitions = 1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time) 2. BestFailing OSC value from a calibration	Normalized Ratio OSC Value (EWMA filtered)	< 0.35	All enable criteria associated with P0430 can be found under P2272 - (O2 Sensor Signal Stuck Lean Bank 2 Sensor 2) Rapid Step Response (RSR) feature will initiate multiple tests: If the difference between current EWMA value and the current OSC Normalized Ratio value is and the current OSC Normalized Ratio value is Maximum number of RSR tests to detect failure when RSR is enabled. MAF Predicted catalyst temperature Front O2 Sensor or Front WRAF Rear O2 Sensor General Enable Criteria In addition to the p-codes listed under P2272, the following DTC's shall also	 > 0.50 < 0.13 6 > 4.00 g/s < 20.00 g/s < 850 ° C > 680.00 mV or > 1.25 EQR > 825.00 mV	1 test attempted per valid decel period Minimum of 1 test per trip Maximum of 3 tests per trip Frequency: Fueling Related : 12.5 ms OSC Measurements: 100 ms Temp Prediction: 12.5ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		table (based on temp and exhaust gas flow) 3. WorstPassing OSC value (based on temp and exhaust gas flow) Normalized Ratio Calculation = (1-2) / (3-2) A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part. Refer to the **P0430_WorstPassingOSCTableB2** and **P0430_BestFailingOSCTableB2** in Supporting Tables tab for details The Catalyst Monitoring Test is completed during a decel fuel cutoff event. This fuel cutoff event occurs following a rich instrusive fueling event initiated by the O2 Sensor Signal Stuck Lean Bank 2 Sensor 2 test (P2272). Several conditions must be met in order to execute this test. Additional conditions and their related values			not be set: For switching O2 sensors: For WRAF O2 sensors:	 O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_2_FA WRAF_Bank_1_FA WRAF_Bank_2_FA **P0430_WorstPassingOSCTableB2** **P0430_BestFailingOSCTableB2**		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		are listed in the "Secondary Parameters" and "Enable Conditions" section of this document for P2272 (O2 Sensor Signal Stuck Lean Bank 2 Sensor 2)						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Small Leak Detected (No ELCP - Conventional EVAP Diagnostic - with EAT using OAT Sensor - with Fuel Tank Zome Module (FTZM))	P0442	This DTC will detect a small leak (≥ 0.020") in the EVAP system between the fuel fill cap and the purge solenoid. On some applications a small leak is defined as ≥ 0.025", 0.030", or 0.150". The engine off natural vacuum method (EONV) is used. EONV is an evaporative system leak detection diagnostic that runs when the vehicle is shut off when enable conditions are met. Prior to sealing the system and performing the diagnostic, the fuel volatility is analyzed. In an open system (Canister Vent Solenoid [CVS] open) high volatility fuel creates enough flow to generate a measurable pressure differential relative to atmospheric.After the volatility check, the vent solenoid will close. After the vent is closed, typically a build up of pressure from the hot soak begins (phase-1). The pressure typically will peak and then begin to decrease as the fuel cools. When	The total delta from peak pressure to peak vacuum during the test is normalized against a calibration pressure threshold table that is based upon fuel level and ambient temperature. (Please see **P0442 EONV Pressure Threshold (Pascals)** in Supporting Tables). The normalized value is calculated by the following equation: 1 - (peak pressure - peak vacuum) / pressure threshold. The normalized value is entered into EWMA (with 0= perfect pass and 1= perfect fail). When EWMA is the DTC light is illuminated. The DTC light can be turned off if the EWMA is and stays below the EWMA fail threshold for 3 additional consecutive trips.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		the pressure drops (-62) Pa from peak pressure, the vent is then opened for 60 seconds to normalize the system pressure. The vent is again closed to begin the vacuum portion of the test (phase-2). As the fuel temperature continues to fall, a vacuum will begin forming. The vacuum will continue until it reaches a vacuum peak. When the pressure rises 62 Pa from vacuum peak, the test then completes. If the key is turned on while the diagnostic test is in progress, the test will abort.			Valid ********** 1. Startup OAT is less than previous trip EAT OR 2. Startup ECT - previous trip EAT OR 3. Engine off time OR 4. At startup, time since previous EAT valid and able to learn OR 5. EAT - current OAT OR 6. EAT < current OAT and speed timer and current OAT - EAT Speed timer increments at 100 msec rate and increments vary based on vehicle speed as follows: vehicle speed < 10 mph 10 mph<speed< 35 mph 35 mph<speed< 124 124 mph<speed< 124 Speed timer can never be less than 0 seconds ********** 1. High Fuel Volatility During the volatility	********** ≤ 0 °C ≥ 3,600 seconds ≤ 3,600 seconds 0 °C ≤ difference ≤ 2 °C ≥ 240 seconds ≤ 2 °C - 0.2 seconds 0.10 seconds 0.33 seconds 0.33 seconds ********** 		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					phase, pressure in the fuel tank is integrated vs. volatility time. If the integrated pressure is then test aborts and unsuccessful attempts is incremented. This value equates to an average integrated fuel tank pressure > 1,245 Pa. Please see **P0442 Volatility Time as a Function of Estimate of Ambient Temperature** in Supporting Tables. OR 2. Vacuum Refueling Detected See P0454 Fault Code for information on vacuum refueling algorithm. OR 3. Fuel Level Refueling Detected See P0464 Fault Code for information on fuel level refueling. OR 4. Vacuum Out of Range and No Refueling See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.	< -5		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					OR 5. Vacuum Out of Range and Refueling Detected See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling. OR 6. Vent Valve Override Failed Device control using an off-board tool to control the vent solenoid, cannot exceed during the EONV test OR 7. Key up during EONV test No active DTCs: No Active DTC's TFTKO	0.50 seconds MAF_SensorFA ECT_Sensor_FA IAT_SensorFA VehicleSpeedSensor_FA IgnitionOffTimeValid AmbientAirDefault FuelLevelDataFault P0443 P0446 P0449 P0452 P0453 P0455 P0458 P0459		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						P0498 P0499 P0496 P1001 P1005 P11FF P130F U18A2		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Canister Purge Solenoid Valve Circuit (ODM) (No ELCP - Conventional EVAP Diagnostic)	P0443	Controller specific output driver circuit diagnoses the canister purge solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between output and controller ground.	Powertrain relay voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controllers P0458 may also set (Canister Purge Solenoid Short to Ground)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent System Performance (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filler, vent hose or EVAP canister. This diagnostic runs with normal purge control and canister vent solenoid commanded open. The diagnostic fails when the FTP sensor vacuum measurement is above a vacuum threshold before it accumulates purge volume above a threshold. The diagnostic passes when it accumulates purge volume above a threshold before the FTP sensor vacuum measurement is above a vacuum threshold.	Vent Restriction Prep Test: Vented Vacuum for OR Vented Vacuum for Vent Restriction Test: Tank Vacuum for before Purge Volume After setting the DTC for the first time, 0 liters of fuel must be consumed before setting the DTC for the second time.	 < -623 Pa 60 seconds > 1,245 Pa 60 seconds > 2,989 Pa 5 seconds ≥ 8 liters	Fuel Level System Voltage Startup IAT Startup ECT BARO No active DTCs: No Active DTC's TFTKO	10 % ≤ Percent ≤ 90 % ≥ 10.0 volts 4 °C≤Temperature≤ 35 °C ≤ 35 °C ≥ 70 kPa MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454 P0458 P0459 P0498 P0499 P1001 P1005 P11FF P130F U18A2	Once per Cold Start Time is dependent on driving conditions Maximum time before test abort is 1,400 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent Solenoid Control Circuit (ODM) (No ELCP - Conventional EVAP Diagnostic - without Fuel Tank Zone Module (FTZM))	P0449	Controller specific output driver circuit diagnoses the vent solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedence between output and controller ground			20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controllers P0498 may also set (Vent Solenoid Short to Ground)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Performance (No ELCP - Conventional EVAP Diagnostic)	P0451	The DTC will be set if the fuel tank vacuum sensor is out of range when it tries to re-zero prior to the phase-1 or phase-2 portions of the engine-off natural vacuum small leak test. During the EONV test, the fuel tank vacuum sensor is re-zeroed. A re-zero occurs: 1) At the transition from the volatility phase to the pressure phase. 2) At the transition from the pressure phase to the vacuum phase. The re-zero test determines if the tank vacuum signal falls within a calibratable window about atmospheric pressure. If after some time, the tank vacuum signal does not fall to within the window, the re-zero test exits to the refueling rationality test. The refueling rationality test determines if a refueling event caused the re-zero problem. If so, the re-zero problem is ignored. If a refueling event is not	The tank vacuum sensor voltage is compared to a window about the nominal sensor voltage offset (~1.5 volts) Upper voltage threshold (voltage addition above the nominal voltage) Lower voltage threshold (voltage subtraction below the nominal voltage) The difference between tank vacuum sensor voltage and the nominal offset voltage is then normalized against the appropriate threshold listed above to produce a ratio between 0.0 and 1.0. This normalized re-zero ratio is then filtered with a EWMA (with 0= perfect pass and 1=perfect fail). When EWMA is the DTC light is illuminated. The DTC light can be turned off if the EWMA is and stays below the EWMA fail threshold for 3 additional consecutive trips.	0.2 volts 0.2 volts > 0.73 (EWMA Fail Threshold), ≤ 0.40 (EWMA Re-Pass Threshold)	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		This test is executed during an engine-off natural vacuum small leak test. The number of times that it executes can range from zero to two per engine-off period.The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.	Type A, 1 Trips EWMA Average run length: 6 Run length is 2 trips after code clear or non-volatile reset

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		detected, then the results of the re-zero test are used to determine if there is a re-zero problem. 1) An individual re-zero test generates a re-zero ratio. The ratio goes from 0.0 to 1.0. 2) A 0.0 means that the re-zero pressure signal achieved exactly atmospheric pressure. 3) A ratio of 1.0 means that the re-zero pressure did not get within the window. 4) Re-zero pressure within the window generates values between 0.0 and 1.0. If a refueling event is not detected, then the resulting re-zero ratio is filtered using an exponentially weighted moving average (EWMA). When the EWMA exceeds a fail threshold, the vacuum re-zero test reports a failure. Once the vacuum re-zero test fails, the EWMA fall below a lower re-pass threshold before it can pass the vacuum re-zero test again.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Low Voltage (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0452	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too low out of range. The FTP sensor circuit out of range diagnostic compares the raw sensor voltage to a lower voltage threshold. It is an X out of Y diagnostic that runs continuously anytime the controller is awake. If the sensor voltage is below the lower voltage threshold, the low fail counter then increments. If the low fail counter reaches its threshold then a fail is reported for P0452 DTC. A pass is reported for P0452 DTC if the low sample counter reaches its threshold.	FTP sensor signal The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~ -3736 Pa).	< 0.15 volts (3.0 % of Vref or ~ 1,495 Pa)	No active DTC's:	P1001 P1005 U18A2	640 failures out of 800 samples 12.5 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit High Voltage (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0453	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too high out of range. The FTP sensor circuit out of range diagnostic compares the raw sensor voltage to an upper voltage threshold. It is an X out of Y diagnostic that runs continuously anytime the controller is awake. If the sensor voltage is above the upper voltage threshold, the high fail counter then increments. If the high fail counter reaches its threshold then a fail is reported for P0453 DTC. A pass is reported for P0453 DTC if the high sample counter reaches its threshold.	FTP sensor signal The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~ -3736 Pa).	> 4.85 volts (97.0 % of Vref or ~ -3,985 Pa)	No active DTCs:	P1001 P1005 U18A2	640 failures out of 800 samples 12.5 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Intermittent (No ELCP - Conventional EVAP Diagnostic)	P0454	This DTC will detect intermittent tank vacuum sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event. During the EONV test, an abrupt change in fuel tank vacuum is identified as a possible refueling event. If the abrupt change occurs while the vent valve is closed, the EONV small-leak test aborts and the refueling rationality test starts. If the refueling rationality test detects a refueling event, then the vacuum change is considered “rational.” If the refueling rationality test does not detect a refueling event, then the vacuum change is considered “irrational.” The vacuum change rationality diagnostic is an “X out of Y” test. 1) Each time the EONV test completes, the (Y) sample counter is incremented. 2) Each time the	If an abrupt change in tank vacuum is detected the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that a refueling event occurred. If a refueling is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem. An abrupt change is defined as a change in vacuum in the span of 1.0 seconds. But in 12.5 msec. A refueling event is confirmed if the fuel level has a persistent change of for 30 seconds during a 600 second refueling rationality test.	> 112 Pa < 249 Pa >10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes and the canister vent solenoid is closed		This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period.The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.The test will report a failure if 2 out of 3 samples are failures. 12.5 ms / sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		rationality test has an irrational result; the (X) fail counter is incremented. 3) If the (X) fail counter reaches the fail limit before the (Y) sample counter reaches the sample limit, the vacuum change rationality test fails. 4) If the (Y) sample counter reaches the limit before the (X) fail counter fails, the vacuum change rationality test passes.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Large Leak Detected (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0455	This DTC will detect a weak vacuum condition (large leak or purge blockage) in the EVAP system. This mode checks for large leaks and blockages when proper driving conditions are met. If these conditions are met, the diagnostic commands the vent valve closed and controls the purge duty cycle to allow purge flow to purge the fuel tank and canister system while monitoring the fuel tank vacuum level. The algorithm accumulates purge flow during the test to determine a displaced purge volume as the test proceeds. If the displaced purge volume reaches a threshold before the fuel tank vacuum level reaches its passing threshold, then a large leak failure is detected. On fuel systems with fuel caps If the first failure of	Purge volume while Tank vacuum After setting the DTC for the first time, 0 liters of fuel must be consumed before setting the DTC for the second time. Weak Vacuum Follow-up Test (fuel cap replacement test) Weak Vacuum Test failed. Passes if tank vacuum Note: Weak Vacuum Follow-up Test can only report a pass.	> 9 liters ≤ 2,740 Pa ≥ 2,740 Pa	Fuel Level System Voltage BARO Purge Flow No active DTCs: No Active DTC's TFTKO If ECT > IAT, Startup temperature delta (ECT-IAT): Startup IAT Startup ECT Weak Vacuum Follow-up Test This test can run following a weak vacuum failure or on a hot restart.	10 % ≤ Percent ≤ 90 % ≥ 10.0 volts ≥ 70 kPa ≥ 2.50 % MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454 P0458 P0459 P0498 P0499 P1001 P1005 P11FF P130F U18A2 ≤ 8 °C 4 °C≤Temperature≤ 35 °C ≤ 35 °C	Once per cold start Time is dependent on driving conditions Maximum time before test abort is 1,400 seconds Weak Vacuum Follow-up Test With large leak detected, the follow-up test is limited to 0 seconds. Once the MIL is on, the follow-up test runs indefinitely.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		P0455 occurred after a refueling event was detected and the MIL is off for P0455, the MIL will be commanded off after the first pass of P0455 is reported. If the first failure of P0455 did not occur after a refueling event was detected, the MIL will be commanded off on the ignition cycle after the third consecutive pass of P0455 is reported.the MIL will be commanded off on the ignition cycle after the third consecutive pass of P0455 is reported. On fuel systems without fuel caps The P0455 MIL will be commanded off on the ignition cycle after the third consecutive pass of P0455 is reported.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Purge Control Valve Circuit Low (No ELCP - Conventional EVAP Diagnostic)	P0458	Controller specific output driver circuit diagnoses the canister purge solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedence between output and controller ground	Powertrain relay voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controllers P0443 may also set (Canister Purge Solenoid Open Circuit)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Purge Control Valve Circuit High (No ELCP - Conventional EVAP Diagnostic)	P0459	Controller specific output driver circuit diagnoses the canister purge solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedence between output and controller power	Powertrain relay voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Performance (For use on vehicles with a single fuel tank)	P0461	This DTC will detect a primary fuel tank level sensor stuck in-range.	a) Sensed fuel volume change is b) while engine fuel consumption is	a) < 3 liters b) >= 27.81 liters	1. Diagnostic Enabled 2. Engine Operational State	1. == True 2. == Running	250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Low Voltage	P0462	This DTC will detect a primary fuel tank sensor stuck out-of-range low.	Fuel level Sender % of 5V range	< 10 % or 85.08 liters	a) Diagnostic enabled status b) Fuel Level Sensor Initialized status c) Fuel Level Sensor Data Available Status d) Communication faults status	a) == True b) == True c) == True d) <> True	100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit High Voltage	P0463	This DTC will detect a primary fuel tank level sensor stuck out-of-range high.	Fuel level Sender % of 5V range	> 60 % or 4.78 liters	a) Diagnostic enabled status b) Fuel Level Sensor Initialized status c) Fuel Level Sensor Data Available Status d) Communication faults status	a) == True b) == True c) == True d) <> True	100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Intermittent (No ELCP - Conventional EVAP Diagnostic)	P0464	This DTC will detect intermittent fuel level sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event. During the EONV test, a change in fuel level is identified as a possible refueling event. If the change occurs while the vent valve is closed, the EONV small-leak test aborts and the refueling rationality test starts. If the refueling rationality test detects a refueling event, the fuel level change is considered “rational.” If the refueling rationality test does not detect refueling, the fuel level change is considered “irrational.” The fuel level change rationality diagnostic is an “X out of Y” test. 1) Each time the EONV test completes, the (Y) sample counter is incremented. 2) Each time the rationality test has an	If a change in fuel level is detected, the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that an actual refueling event occurred. If a refueling event is confirmed, then the test sample is considered passing. Otherwise, if a refueilng event is not confirmed, then the test sample is considered failing which indicates an intermittent signal problem. An intermittent fuel level signal problem is defined as: The fuel level changes by and does not remain for 30 seconds during a 600 second refueling rationality test.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		irrational result; the (X) fail counter is incremented. 3) If the (X) fail counter reaches the fail limit before the (Y) sample counter reaches the sample limit, the fuel level change rationality test fails. 4) If the (Y) sample counter reaches the limit before the (X) fail counter fails, the fuel level change rationality test passes.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Open (Output Driver Monitor) (Not used on EREV/ PHEV/ HEV)	P0480	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50.00 failures out of 63.00 samples 100 ms / sample	Type B, 2 Trips Note: In certain controllers P0691 may also set (Fan 1 Short to Ground).

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Flow During Non-Purge (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0496	This DTC will determine if the purge solenoid is leaking to engine manifold vacuum. This test checks for purge valve leaks to intake manifold vacuum such that there would always be a small amount of purge flow present. It does this by sealing the EVAP system (purge and vent valve closed) and then monitors fuel tank vacuum level. The fuel tank vacuum level should not increase. If tank vacuum increases above a threshold, a malfunction is indicated. Additional Information This diagnostic test detects purge valve leaks to intake manifold vacuum. It is not intended to detect purge valve leaks to the atmosphere which are monitored by the EONV small leak diagnostic (P0442). The purge valve leak diagnostic exists to helps service replace	Tank Vacuum for Test time	> 2,491 Pa 5 seconds ≤ refer to **P0496 Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level** in Supporting Tables. Test time only increments when engine vacuum ≥ 10.0 kPa.	Fuel Level System Voltage BARO Startup IAT Startup ECT Engine Off Time No active DTCs: No Active DTC's TFTKO	10 % ≤ Percent ≤ 90 % ≥ 10.0 volts ≥ 70 kPa 4 °C≤Temperature≤ 35 °C ≤ 35 °C ≥ 28,800.0 seconds MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454 P0458 P0459 P0498 P0499 P1001 P1005 P11FF P130F U18A2	Once per cold start Cold start: max time is 1,400 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		leaking purge valves that could otherwise be detected with the EONV small leak diagnostic (P0442).						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Vent Solenoid Control Circuit Low (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0498	Controller specific output driver circuit diagnoses the vent solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedence between output and controller ground	No active DTC's:	P1005 P130F U18A2	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controllers P0449 may also set (Vent Solenoid Open Circuit)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Vent Solenoid Control Circuit High (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0499	Controller specific output driver circuit diagnoses the vent solenoid low sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. If the P0499 is active, an intrusive test is performed with the vent solenoid commanded closed for 15 seconds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedence between output and controller power	No active DTC's:	P1005 P130F U18A2	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Low Engine Speed Idle System	P0506	This DTC indicates that actual engine speed is lower than desired engine speed at idle so that it is out of speed control capability. Testing is performed when basic conditions are met. If filtered engine speed error exceeds a calibrated threshold for a calibrated duration, code is set. This testing is performed continuously per trip if basic conditions are met	Filtered Engine Speed Error. It is calculated with a calibrated filter coefficient Filter coefficient	> 91.00 rpm 0.00300	Baro Coolant Temp Engine run time Ignition voltage Time since gear change Time since a TCC mode change IAT Vehicle speed Commanded RPM delta Idle time For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa > 60 °C ≥ 30 sec 32 ≥ volts ≥ 11 ≥ 3 sec > 3 sec > -20 °C ≤ 1.24 mph, 2kph ≤ 25 rpm > 10 sec > 12.00 pct < 75.00 pct PTO not active Transfer Case not in 4WD LowState	Diagnostic runs in every 12.5 ms loop Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	Off-vehicle device control (service bay control) must not be active. following conditions not TRUE: (VeTESR_e_EngSpdReqIntvType = CeTESR_e_EngSpdMinLimit AND VeTESR_e_EngSpdReqRespType = CeTESR_e_NoSuggestion) Clutch is not depressed TC_BoostPresSnsrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorCircuitFA EvapFlowDuringNonPurge_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_FA IgnitionOutputDriver_FA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA FuelLevelDataFault LowFuelConditionDiagnostic Clutch Sensor FA AmbPresDfltdStatus		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for Idle time	P2771 > 10 sec The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop vehicle)		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Engine Speed Idle System	P0507	This DTC indicates that actual engine speed is higher than desired engine speed at idle so that it is out of speed control capability. Testing is performed when basic conditions are met. If filtered engine speed error exceeds a calibrated threshold for a calibrated duration, code is set. This testing is performed continuously per trip if basic conditions are met	Filtered Engine Speed Error. It is calculated with a calibrated filter coefficient Filter coefficient	< -182.00 rpm 0.00300	Baro Coolant Temp Engine run time Ignition voltage Time since gear change Time since a TCC mode change IAT Vehicle speed Commanded RPM delta For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa > 60 °C ≥ 30 sec 32 ≥ volts ≥ 11 ≥ 3 sec > 3 sec > -20 °C ≤ 1.24 mph, 2kph ≤ 25 rpm > 12.00 pct < 75.00 pct PTO not active Transfer Case not in 4WD LowState Off-vehicle device control (service bay control) must not be active.	Diagnostic runs in every 12.5 ms loop Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						following conditions not TRUE: (VeTESR_e_EngSpdReqIntvType = CeTESR_e_EngSpdMinLimit AND VeTESR_e_EngSpdReqRespType = CeTESR_e_NoSuggestion) Clutch is not depressed TC_BoostPresSnsrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorCircuitFA EvapFlowDuringNonPurge_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_FA IgnitionOutputDriver_FA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA FuelLevelDataFaultLow FuelConditionDiagnostic Clutch SensorFA AmbPresDfltdStatus P2771	
					No active DTCs			
					All of the above met	> 10 sec		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					for Idle time	The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop vehicle)		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Rough Idle	P050D	Monitors the combustion performance when the cold start emission reduction strategy is active by accumulating and determining the percentage of engine cycles that have less than complete combustion relative to the total number of engine cycles in which Dual Pulse is active.	Deceleration index vs. Engine Speed Vs Engine load Deceleration index calculation is tailored to specific vehicle. Tables used are 1st tables encountered that are not max of range. Undetectable region at a given speed/load point is where all tables are max of range point. Incomplete combustion identified by P0300 threshold tables:	(>Idle SCD AND >Idle SCD ddt Tables) OR (>Idle Cyl Mode AND > Idle Cyl Mode ddt Tables)	Misfire Algorithm Enabled (Refer to P0300 for Enablement Requirements) OBD Manufacturer Enable Counter To enable the diagnostic, the Cold Start Emission Reduction Strategy Must Be Active per the following: Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure In addition, Dual Pulse Strategy Is Enabled and Active Per the following: Engine Speed Accel Position Engine Run Time For the engine speeds and loads in which Dual Pulse is active:	= 0 < 300.00 degC > 6.00 degC <= 66.00 degC >= 70.00 KPa >= 550.00 RPM <= 2,000.00 RPM <= 10.00 Pct < 100 seconds	Runs once per trip when the cold start emission reduction strategy is active and Dual Pulse is enabled and active. Frequency: 100ms Test completes after Dual Pulse is no longer active OR The first 500 engine cycles have been reached	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Dual Pulse Error induced misfires percentage	>= catalyst damaging misfire		
					Dual Pulse Error induced misfires percentage	< 90% of the maximum achieveable catalyst damaging misfire.		
					Engine Cycles	>= 50 < 501		
					The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following:			
					Catalyst Temperature AND Engine Run Time	>= 800.00 degC >= 1.00 seconds		
					OR Engine Run Time	> **P050D_P1400_CatalystLightOffExtendedEngineRunTimeExit** This Extended Engine run time exit table is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details.		
					OR Barometric Pressure	< 70.00 KPa		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Dual Pulse Strategy will exit per the following:			
					Engine Speed OR Accel Position	> 2,350.00 RPM > 30.00 Pct		
					Engine Run Time	>= 100 seconds		
					Dual Pulse Strategy will also exit if the any of the "Additional Dual Pulse Enabling Criteria" is not satisfied:			
					"Additional Dual Pulse Enabling Criteria":			
					Green Engine Enrichment	Not Enabled		
					Misfire Converter Protection strategy	Not being requested		
					Engine Metal Overtemp strategy	Not being requested		
					Fuel control state	Open Loop		
					Output State Control	Not being requested for fuel		
					DOD Or DFCO	Not Active		
					Power Enrichment	Not Active		
					Dynamic Power Enrichment	Not Active		
					Piston Protection	Not Active		
					Hot Coolant Enrichment	Not Active		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Injector Flow Test General Enable DTC's Not Set:	Not Active AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFA CrankSensor_FA FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA AnyCamPhaser_TFTKO ClutchPstnSnsr FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA FuelInjectorCircuit_TFTKO FHPR_b_FRP_SnsrCkt_FA FHPR_b_FRP_SnsrCkt_TFTKO FHPR_b_PumpCkt_FA FHPR_b_PumpCkt_TFTKO TransmissionEngagedState_FA EngineTorqueEstInaccurate FuelPumpRlyCktFA		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Sensor Performance - Single Stage Oil Pump	P0521	Determines if the Engine Oil Pressure (EOP) Sensor is stuck or biased in range. The engine oil pressure rationality diagnostic has two parts: engine runing test and engine off test. The engine running test compares the sensed oil pressure to a mathematical prediction of oil pressure; while the engine off test checks for a biased high engine oil pressure sensor after the engine has stopped rotating.	**Single Stage Oil Pump EOP Sensor Test with Engine Running** If enabled: <u>To fail a currently passing test:</u> The filtered, weighted difference between measured EOP and predicted EOP (a function of engine speed and engine oil temp.): <u>To pass a currently failing test:</u> The filtered, weighted difference between measured EOP and predicted EOP (a function of engine speed and engine oil temp.):	< -50.0 kPa OR > 50.0 kPa > -47.0 kPa AND < 47.0 kPa	Two Stage Oil Pump is Present = FALSE Diagnostic Status Oil Pressure Sensor In Use Quality or weighting factor values less than “1” indicate that we don’t have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data. Regions where diagnosis is possible have a quality or weighting factor value that is a function of engine speed, engine oil temperature, predicted oil pressure, and engine load stability. (**P0521_RPM_Weighting_Factor - Single Stage Oil Pump** * **P0521_Oil_Temp_Weighting_Factor - Single Stage Oil Pump** * **P0521_Eng_Load_Stability_Weighting_Factor - Single Stage Oil Pump** * **P0521_Eng_Oil_Pred_Weighting_Factor - Single Stage Oil Pump**	FALSE Enabled Yes >= 0.30 weighting	Performed every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					) with a first order filter coefficient of 0.01 (See Details on P0521 Supporting Tables Tab) **P0521_RPM_Weighting_Factor - Single Stage Oil Pump** **P0521_Oil_Temp_Weighting_Factor - Single Stage Oil Pump** **P0521_Eng_Load_Stability_Weighting_Factor - Single Stage Oil Pump** **P0521_Eng_Oil_Pred_Weighting_Factor - Single Stage Oil Pump** No active DTC's	Fault bundles: EngOilPressureSensorCktFA CrankSensor_FA ECT_Sensor_FA MAF_SensorFA IAT_SensorFA		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Sensor Circuit Low Voltage	P0522	Determines if the Engine Oil Pressure (EOP) Sensor circuit voltage is too low. This diagnostic compares the EOP circuit voltage to the reference voltage.	(Engine Oil Pressure Sensor Circuit Voltage) ÷ 5 Volts) *100	< 5.00 percent Deadband: < 5 percent or > 95 percent	Engine Speed Enable Engine Speed Disable Oil Pressure Sensor In Use Diagnostic Status	> 400 rpm < 350 rpm Yes Enabled	800 failures out of 1,000 samples Performed every 6.25 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Sensor Circuit High Voltage	P0523	Determines if the Engine Oil Pressure (EOP) Sensor circuit voltage is too high. This diagnostic compares the EOP circuit voltage to the reference voltage.	(Engine Oil Pressure Sensor Circuit Voltage) ÷ 5 Volts) *100	> 95.00 percent Deadband: < 5 percent or > 95 percent	Oil Pressure Sensor In Use Diagnostic Status	Yes Enabled	800 failures out of 1,000 samples Performed every 6.25 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Air Conditioning High Side Pressure Sensor (HSPS) Circuit Low Voltage	P0532	Determines if the Air Conditioning High Side Pressure Sensor circuit voltage is too low	(AC High Side Pressure Sensor Circuit Voltage) ÷ 5 Volts) *100	< 3 percent	AC HSP Sensor Present Diagnostic Status	Yes Enabled	80 failures out of 100 samples Performed every 25 msec	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Air Conditioning High Side Pressure Sensor (HSPS) Circuit High Voltage	P0533	Determines if the Air Conditioning High Side Pressure Sensor circuit voltage is too high	(AC High Side Pressure Sensor Circuit Voltage) ÷ 5 Volts) *100	> 95 percent	AC HSP Sensor Present Diagnostic Status	Yes Enabled	80 failures out of 100 samples Performed every 25 msec	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System Voltage Performance	P0561	Detects a low performing 12V battery system. This diagnostic reports the DTC when the absolute value of the difference between the battery voltage and the run/ crank voltage exceeds a calibrated value.	Run Crank voltage low and high	ABS(Battery voltage - Run Crank voltage) > 3.00	Battery voltage B+ line present = TRUE Battery voltage low and high diag enable = TRUE Run Crank voltage	1.00 1.00 Voltage ≥ 5.00 volts	50 failures out of 63 samples 100 ms / sample	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System Voltage Low	P0562	Detects a low 12V battery system. This diagnostic reports the DTC when battery voltage is low. Monitoring occurs when the engine speed is above a calibrated value.	System voltage low	Battery voltage <= 9.00	System voltage low diag enable = TRUE Run Crank voltage Engine speed >=	1.00 Voltage ≥ 5.00 volts 400.00	400 failures out of 500 samples 12.5 ms / sample	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System Voltage High	P0563	Detects a high 12V battery system. This diagnostic reports the DTC when battery voltage is high.	System voltage high	Battery voltage >= 18.00	System voltage high diag enable = TRUE Run Crank voltage	1.00 Voltage ≥ 5.00 volts	400 failures out of 500 samples 12.5 ms / sample	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Mutil-Functon Switch Circuit	P0564	Detect when cruise control multi-function switch circuit (analog) voltage is in an invalid range	Cruise Control analog circuit voltage must be "between ranges" for greater than a calibratable period of time.	The cruise control analog voltage A/D count ratio is considerred to be "between ranges" when the ratio is measured in the following ranges: 0.28 -0.31, 0.415-0.445, 0.585 - 0.615 0.78 - 0.81, 1.005 - 1.035	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 0.500 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control On Switch Circuit	P0565	Detects a failure of the cruise on/off switch in a continously applied state	Cruise Control On switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 20.00 seconds	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Resume Circuit	P0567	Detects a failure of the cruise resume switch in a continously applied state	Cruise Control Resume switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 89.000 seconds	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 89.000 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Set Circuit	P0568	Detects a failure of the cruise set switch in a continously applied state	Cruise Control Set switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 89.000 seconds	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 89.000 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Cancel Switch Circuit	P056C	Detects a failure of the cruise cancel switch in a continously applied state	Cruise Control Cancel switch remains applied for greater than a calibratable period of time.	fail continously in the applied state for greater than 20.00 seconds	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Input Circuit	P0575	Determines if cruise switch state received from the BCM is valid.	If x of y rolling count / protection value faults occur, disable cruise for duration of fault	Message <> 2's complement of message Message rollling count<>previous message rolling count value plus one	Cruise Control Switch Serial Data Error Diagnostic Enable Serial communication to BCM Power Mode Engine Running	1.00 No loss of communication = RUN = TRUE	9 failures out of / 17 samples Performed on every received message 9 rolling count failures out of / 17 samples Performed on every received messagw	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Range/ Performance	P057B	This diagnostic monitors the Brake Pedal Position Sensor for a stuck in range failure	.Brake pedal position sensor movement diagnostic cal is enabled 1.00	True	Brake Pedal Position Sensor Circuit Range / Performance Diagnostic Enable	1.00 ignition voltage > 10.00		MIL: Type A, 1 Trips
			Calculated EWMA value must be greater than calibratable theshold after calibratable number of tests have completed to report a "test passed" for P057B	EWMA value looked up in supporting table **P057B KtBRKI_K_FastTestPointWeight** P057B as a function of calculated brake pedal position delta EWMA value is > 0.80	calculated brake pedal position delta sample counter > 50.00 for fast test OR calculated brake pedal position delta sample counter > 1,000.00 for slow test	calculated brake pedal position delta > 3.17 OR (for slow test) shift lever has been in park once this key cycle vehicle speed >= 5.00 accelerator pedal position < 5.00	total number of EWMA tests > 20.00	
			Calculated EWMA Value must be less than calibratable threshold after calibratable number of tests have completed to report a "test failed" for P057B. This test runs once per key cycle	EWMA value looked up in supporting table **P057B KtBRKI_K_CmpltTest PointWeight** P057B as a function of calculated brake pedal position delta EWMA value is less thatn 0.40	no DTC's active (P057C, P057D)	shift lever has been in park once this key cycle vehicle speed >= 5.00 accelerator pedal position < 5.00	total number of EWMA tests > 2.00	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Low	P057C	detects short to ground for brake pedal position sensor	If x of y samples are observed below failure threshold, default brake pedal position to zero percent.	5.00	Brake Pedal Position Sensore Low Voltage Diagnostic Enable	1.00	20 / 32.00 counts	MIL: Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit High	P057D	detects open circuit for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	95.00	Brake Pedal Position Sensore High Voltage Diagnostic Enable	1.00	20.00 / 32.00 counts	MIL: Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Intermittent/ Erratic	P057E	detects noisy / erratic ouput for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	25.00	Brake Pedal Position Sensor Circuit Intermittent / Erratic Diagnostic Enable	1.00	5.00 / 20.00 counts	MIL: Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi-function Circuit Low Voltage	P0580	detects short to ground failure for cruise multi-function switch circuit	Cruise Control analog circuit voltage must be in an "Open Short To Ground" range for greater than a calibratable period of time.	The cruise control analog voltage A/D count ratio is considerred to be "open short to ground when the ratio is measured in the following rangs: 0 - 0.185	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi-function Circuit High Voltage	P0581	detects short to power failure for cruise multi-function switch circuit	Cruise Control analog circuit voltage must be in "Short To Power" range for greater than a calibratable period of time.	The cruise control analog voltage A/D count ratio is considered to be "short to power" when the ratio is measured in the following range: 1.005 - 1.035	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Active Grill Air Shutter A Performance /Stuck OFF	P059F	A 2-part diagnostic. Part 1 continuously monitors for failure to achieve a commanded shutter actuator position [Suspect Stuck Condtion] when X failures occur in Y samples after an electronic command latency delay. A Part 1 failure result then enables Part 2 which makes a fixed number of repeat attempts to reach the commanded postion [ReTry to clear obstruction]. The DTC is set when the calibrated fault threshold count of repeat attempts is reached without achieving the original commanded shutter position.	Smart Shutter Actuator 1 Position Response AND Shutter 1 Diagnostic Delay Threshold count	<> Smart Shutter Actuator 1 Commanded Position percent AND Counter > 99.00 counts	a. Ignition Run_Crank Active, b. Ignition Run_Crank AND Ignition Accessory AND ECU Awake, c. Command Shutter1 Enable	a. = TRUE, b. = FALSE AND = FALSE AND = TRUE, c. = 1.00	1.00 failures out of 1.00 samples 1 sample / 100 milliseconds	Type B, 2 Trips
			Shutter 1 Performance Test count	= 5.00 counts	a. Ignition Run_Crank Active, b. Ignition Run_Crank AND Ignition Accessory AND ECU Awake, c. Command Shutter1 Enable	a. = TRUE, b. = FALSE AND = FALSE AND = TRUE, c. = 1.00	1-5 actuator cycles [1 cycle typically requires 10-25 seconds]	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if the calibration check sum is incorrect or the flash memory detects an uncorrectable error via the Error Correcting Code.	The Primary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5.00 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	Type A, 1 Trips
			The Primary Processor's Error Correcting Code hardware in the flash memory detects an error. Covers all software and calibrations.	254 failures detected via Error Correcting Code			Diagnostic runs continuously via the flash hardware.	
			The Primary Processor's calculated checksum does not match the stored checksum value for a selected subset of the calibrations.	2 consecutive failures detected or 5 total failures detected.			Diagnostic runs continuously. Will report a detected fault within 200 ms.	
				In all cases, the failure count is cleared when controller shuts down				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Not Programmed	P0602	This DTC will be stored if the ECU is a service part that has not been programmed.	Service (reflash) controller calibration present	= 1		none	Diagnostic runs at powerup and once per second continuously after that	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM Long Term Memory Reset	P0603	This DTC detects an invalid NVM which includes a Static NVM, Perserved NVM, ECC ROM in NVM Flash Region, and Perserved NVM during shut down.	Static NVM region error detected during initialization				Diagnostic runs at controller power up.	Type A, 1 Trips
			Perserved NVM region error detected during initialization				Diagnostic runs at controller power up.	
			Perserved NVM region error detected during shut down.				Diagnostic runs at controller power down.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM RAM Failure	P0604	Indicates that the ECM has detected a RAM fault. This includes Primary Processor System RAM Fault, Primary Processor Cache RAM Fault, Primary Processor TPU RAM Fault, Primary Processor Update Dual Store RAM Fault, Primary Processor Write Protected RAM Fault, and Secondary Processor RAM Fault. This diagnostic runs continuously.	Indicates that the primary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	Type A, 1 Trips
			Indicates that the primary processor is unable to correctly read data from or write data to cached RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor is unable to correctly read data from or write data to TPU RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor detects a mismatch between the data and dual data is found during RAM updates. Detects a mismatch in data and dual data updates >	0.47272 s			When dual store updates occur.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Indicates that the primary processor detects an illegal write attempt to protected RAM. Number of illegal writes are >	0 counts			Diagnostic runs continuously (background loop)	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Fault	P0606	Indicates that the ECM has detected an internal processor integrity fault. These include diagnostics done on the SPI Communication as well as a host of diagnostics for both the primary and secondary processsors.	Time new seed not received exceeded			always running	0.450 seconds	Type A, 1 Trips
			MAIN processor receives seed in wrong order			always running	3 / 18 counts intermittent. 50 ms/count in the ECM main processor	
			2 fails in a row in the MAIN processor's ALU check			KePISD_b_ALU_TestEnbld == 1 Value of KePISD_b_ALU_TestEnbld is: 1.00 . (If 0, this test is disabled)	25 ms	
			2 fails in a row in the MAIN processor's configuration register masks versus known good data			KePISD_b_ConfigRegTestEnbld == 1 Value of KePISD_b_ConfigRegTestEnbld is: 1 . (If 0, this test is disabled)	12.5 to 25 ms	
			Checks number of stack over/under flow since last powerup reset >=	3.00		KeMEMD_b_StackLimitTestEnbl == 1 Value of KeMEMD_b_StackLimitTestEnbl is: 1.00 . . (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			Voltage deviation >	0.4950		KePISD_b_A2D_CnvrtrTestEnbld == 1 Value of KePISD_b_A2D_CnvrtrTestEnbld is: 1 . (If 0, this test is disabled)	5 / 10 counts or 0.150 seconds continuous; 50 ms/count in the ECM main processor	
			Checks for ECC (error correcting code) circuit	3 (results in MIL), 5 (results in MIL and		KeMEMD_b_FlashECC_CktTestEnbl == 1 Value of	variable, depends on	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occured since last controller initialization. Counter >=	remedial action)		KeMEMD_b_FlashECC_ CktTestEnbl is: 1 . (If 0, this test is disabled)	length of time to access flash with corrupted memory	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occured since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_RAM_ECC_ CktTestEnbl == 1 Value of KeMEMD_b_RAM_ECC_ CktTestEnbl is: 1 . (If 0, this test is disabled)	variable, depends on length of time to write flash to RAMvariable, depends on length of time to write flash to RAM	
			MAIN processor DMA transfer from Flash to RAM has 1 failure			KePISD_b_DMA_XferTest Enbld == 1 Value of KePISD_b_DMA_XferTest Enbld is: 0 . (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM	
			Safety critical software is not executed in proper order.	>= 1 incorrect sequence.		Table, f(Core, Loop Time). See supporting tables: **P0606_Program Sequence Watch Enable f(Core, Loop Time)** (If 0, this Loop Time test is disabled)	Fail Table, f(Loop Time). See supporting tables: **P0606_PSW Sequence Fail f (Loop Time)** / Sample Table, f (Loop Time)See supporting tables:	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							P0606_PSW Sequence Sample f(Loop Time) counts 50 ms/count in the ECM main processor	
			MAIN processor determines a seed has not changed within a specified time period within the 50ms task.	Previous seed value equals current seed value.		KePISD_b_SeedUpdKey StorFltEnbl == 1 Value of KePISD_b_SeedUpdKey StorFltEnbl is: 1 . (If 0, this test is disabled)	Table, f(Loop Time). See supporting tables: **P0606_Last Seed Timeout f (Loop Time)**	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Performance	P0607	Indicates that the ECM has detected an internal processor integrity performance.	Performs the failure diagnostic for the offline and online BIST results.			KePISD_b_BIST_FailDiag Enbl == 1 Value of KePISD_b_BIST_FailDiag Enbl is: 0 . (If 0, this test is disabled)	5 counts background task/ count in the ECM main processor	Type A, 1 Trips
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occured since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_FlashECC_ CktTestEnbl == 1 Value of KeMEMD_b_FlashECC_ CktTestEnbl is: 1 . (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occured since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_RAM_ECC_ CktTestEnbl == 1 Value of KeMEMD_b_RAM_ECC_ CktTestEnbl is: 1 . (If 0, this test is disabled)	variable, depends on length of time to write flash to RAMvariable, depends on length of time to write flash to RAM	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Control Circuit Open (12VSS)	P0615	Controller specific output driver circuit diagnoses the Starter relay (12VSS) low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	>= 200 KOhms impedance between signal and controller ground.	Starter control diag enable = TRUE Engine speed Run Crank voltage	1.00 >= 0.00 RPM >= 11.00 volts	40 failures out of 50 samples 50 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Control Circuit Low Voltage (12VSS)	P0616	Controller specific output driver circuit diagnoses the Starter relay (12VSS) low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 0.5 Ohms impedance between signal and controller ground	Starter control diag enable = TRUE Engine speed Run Crank voltage	1.00 >= 0.00 RPM >= 6.41 volts	8 failures out of 10 samples 50 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Control Circuit High Voltage (12VSS)	P0617	Controller specific output driver circuit diagnoses the Starter relay low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 0.5 Ohms impedance between signal and controller power	Starter control diag enable = TRUE Engine speed Run Crank voltage	1.00 >= 0.00 RPM >= 6.41 volts	40 failures out of 50 samples 50 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Fuel Injector Control Performance	P062B	This DTC determines the internal fuel injctor control module circuit is faulted. The faulted status is set on any failure that could potentially damage the drivers or injectors, or could result in uncontrolled fueling. The following general classes of failures shall be covered: Communication error with control circuit Internal corruption of control circuit values, Invalid interface values (from control circuit)	Internal ECU Boost Voltage OR Internal ECU Boost Voltage OR Driver Status OR Driver Status	>= 90 Volts <= 40 Volts = Not Ready = Uninitialized	Battery Voltage	>= 8 or >= 11 Enabled when a code clear is not active or not exiting device control Engine is not cranking Powertrain Relay Voltage within range	High Voltage - 160 failures out of 200 samples Low Voltage - 160 failures out of 200 samples Driver Status Not Ready- 160 failures out of 200 samples Driver Status Uninitialized - Uninitialized state for >= 100 counts All at 12.5ms per sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Internal Control Module EEPROM Error	P062F	This DTC detects a NVM long term performance. There are two types of diagnostics that run during controller power up. One for HWIO reports that writing to NVM (at shutdown) will not succeed, and the other HWIO reports the assembly calibration integrity check has failed.	HWIO reports that writing to NVM (at shutdown) will not succeed				Diagnostic runs at controller power up.	Type B, 2 Trips
			HWIO reports the assembly calibration integrity check has failed				Diagnostic runs at controller power up.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VIN Not Programmed or Mismatched - Engine Control Module (ECM)	P0630	This DTC checks that the VIN is correctly written	At least one of the programmed VIN digits	= 00 or FF	OBD Manufacturer Enable Counter	= 0	250 ms / test Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #1 Circuit	P0641	Detects a continuous or intermittent short on the 5 volt reference circuit #1 by monitoring the reference percent Vref1 and failing the diagnostic when the percent Vref1 is too low or too high or if the delta between the filtered percent Vref1 and non-filtered percent Vref1 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref1 < or ECM percent Vref1 > or the difference between ECM filtered percent Vref1 and percent Vref1 >	4.875 % Vref1 5.125 % Vref1 0.0495 % Vref1	Diagnostic enabled AND [(Run/Crank voltage for Time period AND Starter engaged) OR (Run/Crank voltage AND Starter engaged)]	= 1 > 6.41 Volts = 0.02 Seconds = FALSE > 8.41 Volts = TRUE	19 / 39 counts; or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Open	P0650	Detects an inoperative malfunction indicator lamp control low side driver circuit. This diagnostic reports the DTC when an open circuit is detected.	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11.00 volts	1 failures out of 1 samples 50 ms / sample	Type B, No MIL NO MIL Note: In certain controllers P263A may also set (MIL Control Short to Ground)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #2 Circuit	P0651	Detects a continuous or intermittent short on the 5 volt reference circuit #2 by monitoring the reference percent Vref2 and failing the diagnostic when the percent Vref2 is too low or too high or if the delta between the filtered percent Vref2 and non-filtered percent Vref2 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref2 < or ECM percent Vref2 > or the difference between ECM filtered percent Vref2 and percent Vref2 >	4.875 % Vref2 5.125 % Vref2 0.0495 % Vref2	Diagnostic enabled AND [(Run/Crank voltage for Time period AND Starter engaged) OR (Run/Crank voltage AND Starter engaged)]	= 1 > 6.41 Volts = 0.02 Seconds = FALSE > 8.41 Volts = TRUE	19 / 39 counts; or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Open	P0685	Detects an open circuit in the Powertrain Relay driver. This diagnostic reports the DTC when an open circuit failure is present. Monitoring occurs when the output is powered off. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 K Ω ohms impedance between output and controller ground	Run/Crank Voltage	Voltage ≥ 11.00 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controllers P0686 may also set (Powertrain Relay Control Short to Ground).

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Low	P0686	Detects a short to ground in the Powertrain Relay low side driver. This diagnostic reports the DTC when a short to ground failure is present. Monitoring occurs when the output is powered off. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to ground: ≤ 0.5 Ω impedance between output and controller ground	Run/Crank Voltage	Voltage ≥ 11.00 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controllers P0685 may also set (Powertrain Relay Control Open Circuit).

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) High	P0687	Detects a short to power in the Powertrain Relay low side driver. This diagnostic reports the DTC when a short to power failure is present. Monitoring occurs when the output is powered off. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to power: ≤ 0.5 Ω impedance between output and controller power	Run/Crank Voltage	Voltage ≥ 11.00 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Relay Feedback Circuit Low Voltage	P0689	Detects low voltage in the control module relay feedback circuit. This diagnostic reports the DTC when low voltage is present. Monitoring occurs when run crank voltage is above a calibrated value.	Control module relay feedback circuit low voltage	Powertrain relay voltage <= 5.00	Powertrain relay short low diagnostic enable Run Crank voltage Powertrain relay state	= 1.00 > 9.00 = ON	5 failures out of 6 samples 1000 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Feedback Circuit High	P0690	Detects higher than expected voltage in the powertrain relay feedback circuit. This diagnostic reports the DTC when higher than expected voltage is present. For example, the powertrain relay could be stuck on. Monitoring occurs when the relay is commanded "off" for a calibrated duration.	Powertrain Relay Voltage	>= 4.00 volts will increment the fail counter	Powertrain relay commanded “OFF” No active DTCs:	>= 2.00 seconds PowertrainRelayStateOn_FA	50 failures out of 63 samples 100ms / Sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Low Voltage (Output Driver Monitor)	P0691	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50.00 failures out of 63.00 samples 100 ms / sample	Type B, 2 Trips Note: In certain controllers P0480 may also set (Fan 1 Open Circuit).

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit High Voltage (ODM)	P0692	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50.00 failures out of 63.00 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #3 Circuit	P0697	Detects a continuous or intermittent short on the 5 volt reference circuit #3 by monitoring the reference percent Vref3 and failing the diagnostic when the percent Vref3 is too low or too high or if the delta between the filtered percent Vref3 and non-filtered percent Vref3 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref3 < or ECM percent Vref3 > or the difference between ECM filtered percent Vref3 and percent Vref3 >	4.875 % Vref3 5.125 % Vref3 0.0495 % Vref3	Diagnostic enabled AND [(Run/Crank voltage for Time period AND Starter engaged) OR (Run/Crank voltage AND Starter engaged)]	= 1 > 6.41 Volts = 0.02 Seconds = FALSE > 8.41 Volts = TRUE	19 / 39 counts; or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #4 Circuit	P06A3	Detects a continuous or intermittent short on the 5 volt reference circuit #4 by monitoring the reference percent Vref4 and failing the diagnostic when the percent Vref4 is too low or too high or if the delta between the filtered percent Vref4 and non-filtered percent Vref4 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref4 < or ECM percent Vref4 > or the difference between ECM filtered percent Vref4 and percent Vref4 >	4.875 % Vref4 5.125 % Vref4 0.0495 % Vref4	Diagnostic enabled AND [(Run/Crank voltage for Time period AND Starter engaged) OR (Run/Crank voltage AND Starter engaged)]	= 1 > 6.41 Volts = 0.02 Seconds = FALSE > 8.41 Volts = TRUE	19 / 39 counts; or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 1 Performance	P06B6	This diagnostic checks for a fault with the internal test circuit (sensor #1) used only for the '20 kHz' method of the Open Circuit Diagnostic. A fault is present when the signal level from the 20 kHz range of the FFT output falls between the Open Test Circuit thresholds.	FFT Diagnostic Output	**> P06B6_P06B7_OpenTestCktThrshMin** **AND** **< P06B6_P06B7_OpenTestCktThrshMax** **See Supporting Tables**	Diagnostic Enabled? Engine Run Time Engine Speed Cumlative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above) Engine Air Flow	Yes ≥ 2.0 seconds > 400 RPM and < 4,000 RPM ≥ 200 Revs ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient Weight Coefficient = 0.0099 Updated each engine event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 2 Performance	P06B7	This diagnostic checks for a fault with the internal test circuit (sensor #2) used only for the '20 kHz' method of the Open Circuit Diagnostic. A fault is present when the signal level from the 20 kHz range of the FFT output falls between the Open Test Circuit thresholds.	FFT Diagnostic Output	**> P06B6_P06B7_OpenTestCktThrshMin** **AND** **< P06B6_P06B7_OpenTestCktThrshMax** **See Supporting Tables**	Diagnostic Enabled? Engine Run Time Engine Speed Cumlative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above) Engine Air Flow	Yes ≥ 2.0 seconds > 400 RPM and < 4,000 RPM ≥ 200 Revs ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient Weight Coefficient = 0.0099 Updated each engine event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Module (TCM) Requested MIL Illumination	P0700	Monitors the TCM MIL request message to determine when the TCM has detected a MIL illuminating fault.	Transmission Control Module Emissions-Related DTC set and module is requesting MIL	Transmission Control Module Emissions-Related DTC set and module is requesting MIL		Time since power-up ≥ 3 seconds	Continuous	Type A, No MIL

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Traction Control Torque Request Circuit	P0856	Determines if torque request from the EBCM is valid	Serial Communication 2's complement message - ($1C7/$1C9 for engine torque, $1CA/$1C6 for axle torque)	Message <> 2's complement of message	Active Communication with EBCM	Received serial data	>= 6 failures out of 10 Performed on every received message	Type C, No SVS Safety Special Type C
					Power Mode Engine Running	= Run = True		
					Status of traction in GMLAN message ($4E9)	= Traction Present		
			OR Serial Communication message ($1C7/$1C9 for engine torque, $1CA/ $1C6 for axle torque) rolling count index value	Message rolling count value <> previous message rolling count value plus one	Run/Crank Active	> 0.50 seconds	6 rolling count failures out of 10 samples	
					Ignition Voltage	> 6.41 volts	Performed on every received message	
			OR Too many minimum limit torque request transitions occur from TRUE to FALSE to TRUE within a time period	Requested torque intervention type toggles from not increasing request to increasing request			>= 3 multi-transitions out of 5 samples. Performed every 200 ms	
			Torque request greater than torque request diagnostic maximum threshold	> 251 Nm for engine torque based traction torque system, OR > 4,000 Nm for axle torque based traction torque system			>= 4 out of 10 samples Performed on every received message	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Reset Signal Message Counter Incorrect	P1000	This DTC monitors for an error in communication with the Fuel Pump Driver Control Module Reset Signal	Communication of the Alive Rolling Count or Protection Value from the FPDCM over CAN bus is incorrect for out of total samples	 >= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage And Sensor Bus Relay	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Signals Message Counter Incorrect	P1001	This DTC monitors for an error in communication with the Evaporative Emission (EVAP) System Signal	Communication of the Alive Rolling Count or Protection Value from the EVAP System over CAN bus is incorrect for out of total samples	 >= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage And Sensor Bus Relay	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module System Voltage Performance (Only on applications that use an FTZM)	P1002	Detects low system voltage performance of the fuel pump driver control module system. This diagnostic reports the DTC when the absolute value of the difference between the fuel pump driver battery voltage and the fuel pump driver run/crank voltage exceeds a calibrated value.	Fuel Pump Driver Control Module Run Crank voltage low and high	ABS (Fuel Pump Driver Control Module Battery voltage - Fuel Pump Driver Control Module Run Crank voltage) > 3.00	Fuel Tank Zone Module (FTZM) is present on vehicle Fuel Pump Driver Control Module System Voltage Performance diagnostic is enabled Fuel Tank Zone Module (FTZM) serial messages are available FTZM Run Crank Active is TRUE Starter motor not engaged Sensor Bus relay is commanded ON	= 1	50 failures out of 63 samples 12.5 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Control System Signals Message Counter Incorrect	P1003	This DTC monitors for an error in communication with the Fuel Control System Signals	Communication of the Alive Rolling Count or Protection Value from the Fuel Control System over CAN bus is incorrect for out of total samples	>= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage And Sensor Bus Relay	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Reset Error	P1005	This DTC monitors for a reset error in the Fuel Pump Driver Control Module	If the received value for the time since the last FPDCM reset has reset and the newly received value or previous value is for out of total samples	 <= 0.50 seconds >= 2.00 counts >= 400.00 counts	DTC is enabled Sensor bus relay Battery voltage P1000 U18A2	1.00 (1 indicates enabled) On > 11.00 Volts Not active Not active	Diagnostic runs in 50 ms loop.	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Ignition Switch Run/ Start Position Circuit High (Only on applications that use an FTZM)	P1007	Detects high voltage of the fuel pump driver control module ignition switch circuit. This diagnostic reports the DTC when the fuel pump driver control module ignition switch circuit voltage exceeds a calibrated value.	Fuel Pump Driver Control Module Ignition switch Run/Start position circuit high	FTZM Run Crank Active is TRUE	Fuel Tank Zone Module (FTZM) is present on vehicle Fuel Pump Driver Control Module Ignition Switch Run/Start Position Circuit High diagnostic is enabled Fuel Tank Zone Module (FTZM) serial messages are available Run Crank Active Sensor Bus relay is commanded ON	 = 1 = FALSE	40 failures out of 50 samples 50 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Temperature (Fuel Tank Zone Module) Too High Signal Message Counter Incorrect	P1009	This DTC monitors for an error in communication with the Fuel Pump Driver Control Module (FTZM) Temperature Too High Signal Message	Communication of the Alive Rolling Count or Protection Value from the Fuel Pump Driver Control Module over CAN bus is incorrect for out of total samples	 >= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage Sensor Bus Relay	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts = On (if present)	Executes in 100ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Temperature Erratic	P100C	This DTC monitors for an erratic Temperature signal via LIN bus from the Battery Monitor Module	Communication of the Temperature signal from the Battery Monitor Module has become erratic or is incorrect for out of total samples	>= 4 counts >= 5 counts	The diagnostic is enabled All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= 1 (1 indicates enabled) >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	LIN bus communication executes in 500ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Internal Temperature Circuit Erratic	P100D	This DTC monitors for an erratic Temperature Circuit signal via LIN bus from the Battery Monitor Module	Communication of the Temperature Circuit signal from the Battery Monitor Module has become erratic or is incorrect for out of total samples	>= 4 counts >= 5 counts	The diagnostic is enabled All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= 1 (1 indicates enabled) >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	LIN bus communication executes in 500ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Phase U-V-W Circuit Open	P1029	This DTC detects if any of the 3phase fuel pump control circuits is Open [system configuration "Brushless"] The diagnostic can detect open circuit faults when the fuel pump is not rotating. In the "stopped" state, small currents are injected into each motor phase circuit pair by an internal fixed source and corresponding back-EMF voltage is monitored. A fault is reported when the monitored voltage falls into a specific range [adjusted for source voltage]. This process is completed in less than 1 millisecond. The FTZM ERFS control samples back-Electromotive Force [EMF] for zero voltage-level crossings as a detection method to enable closed loop control brushless commutation. Back EMF is an electrical characteristic of the inactive phase of the 3-phase signal wherein only 2 phases are	Phased-pair circuit voltage	3V <= V [back-EMF] <= 6V	a) Sensed fuel pump speed b) Device configuration FCBR_e_ChassisFuelPresSysType c) Diagnostic Enabled - KeFABR_b_OpenCktDiagEnbl d) CAN Sensor Bus message $3EC_Avail e) Sensor Bus Relay On f) Sensor Bus B Message $3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_ARC_ChkErr]	a) == 0 RPM b) CeFCBR_e_DSL_ECM_FTZM_BLDC_Sys c) == TRUE d) == TRUE e) == TRUE f) <> TRUE	40.00 failures / 80.00 samples 1 sample / 12.5 ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		active at any moment. Brushless fuel pump speed is inferred using the rate of zero-crossings detection and number of motor pole-pairs. Speed is reported to the ECM as serial data every 10 milliseconds. This open circuit diagnostic follows "smart device" Component Technical Specifications.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Phase U-V-W Circuit Low	P102A	This DTC detects if the fuel pump control circuit is shorted to low [Short to Ground] The diagnostic detects short-to-ground faults using 2 methods depending on whether the fuel pump is rotating. 1) In the "rotating" state, voltage drop across each phase-pair high-side drive is monitored, or 2) in the "stopped" state, small currents are injected into each motor phase circuit pair	Phased-pair circuit voltage Difference	Vdelta > 0.145 V	a) Device configuration FCBR_e_ChassisFuelPresSysType b) Diagnostic KeFABR_b_GshtCktDiagEnbl c) CAN Sensor Bus message $3EC_Avail d) Sensor Bus Relay On e) Sensor Bus Message $3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_ARC_ChkErr]	a) == CeFCBR_e_DSL_ECM_FTZM_BLDC_Sys b) == TRUE c) == TRUE d) == TRUE e) <> TRUE	40.00 failures / 80.00 samples 1 sample / 12.5 ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		by an internal fixed source and corresponding back-EMF voltage is monitored. A fault is reported when the monitored voltage falls into a specific range [adjusted for source voltage]. The FTZM ERFS control samples back-Electromotive Force [EMF] for zero voltage-level crossings as a detection method to enable closed loop control brushless commutation. Back EMF is an electrical characteristic of the inactive phase of the 3-phase signal wherein only 2 phases are active at any moment. Brushless fuel pump speed is inferred using the rate of zero-crossings detection and number of motor pole-pairs. Speed is reported to the ECM as serial data every 10 milliseconds. This open circuit diagnostic follows "smart device" Component Technical Specifications.	Phased-pair circuit voltage	V [back-EMF] >= 6 V	a) Sensed fuel pump speed b) Device configuration FCBR_e_ChassisFuelPresSysType c) Diagnostic KeFABR_b_GshtCktDiagEnbl d) CAN Sensor Bus message $3EC_Avail e) Sensor Bus Relay On f) Sensor Bus Message $3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_ARC_ChkErr]	a) == 0 RPM b) == CeFCBR_e_DSL_ECM_FTZM_BLDC_Sys c) == TRUE d) == TRUE e) == TRUE f) <> TRUE	40.00 failures / 80.00 samples 1 sample / 12.5 ms	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Phase U-V-W Circuit High	P102B	This DTC detects if the fuel pump control circuit is shorted to high voltage [Short to Battery] The diagnostic detects short-to-battery faults using 2 methods depending on whether the fuel pump is rotating. 1) In the "rotating" state, voltage drop across each phase-pair low-side current shunt is monitored, or 2) in the "stopped" state, small currents are injected	Phased-pair circuit voltage Difference	Vdelta > 0.4 V	a) Device configuration FCBR_e_ChassisFuelPresSysType b) Diagnostic KeFABR_b_PshtCktDiagEnbl c) CAN Sensor Bus message $3EC_Avail d) Sensor Bus Relay On e) Sensor Bus Message $3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_ARC_ChkErr]	a) == CeFCBR_e_DSL_ECM_FTZM_BLDC_Sys b) == TRUE c) == TRUE d) == TRUE e) <> TRUE	40.00 failures / 80.00 samples 1 sample / 12.5 ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		into each motor phase circuit pair by an internal fixed source and corresponding back-EMF voltage is monitored. A fault is reported when the monitored voltage falls into a specific range [adjusted for source voltage]. The FTZM ERFS control samples back-Electromotive Force [EMF] for zero voltage-level crossings as a detection method to enable closed loop control brushless commutation. Back EMF is an electrical characteristic of the inactive phase of the 3-phase signal wherein only 2 phases are active at any moment. Brushless fuel pump speed is inferred using the rate of zero-crossings detection and number of motor pole-pairs. Speed is reported to the ECM as serial data every 10 milliseconds. This open circuit diagnostic follows "smart device" Component Technical Specifications.	Phased-pair circuit voltage	V[backEMF] > 6 V	a) Sensed fuel pump speed b) Device configuration FCBR_e_ChassisFuelPresSysType b) Diagnostic KeFABR_b_PshtCktDiagEnbl c) CAN Sensor Bus message $3EC_Avail d) Sensor Bus Relay On e) Sensor Bus Message $3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_ARC_ChkErr]	a) == 0 RPM b) == CeFCBR_e_DSL_ECM_FTZM_BLDC_Sys b) == TRUE c) == TRUE d) == TRUE e) <> TRUE	40.00 failures / 80.00 samples 1 sample / 12.5 ms	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Phase U-V-W Circuit Shorted	P102C	The fuel pump 3phase bridge driver [FTZM embedded] is capable of phase-to-phase circuit fault detection during the intrusive diagnostic phase (MOSFETs off, pump stopped and intrusive diagnostic test executed). The bridge driver is polled by the microcontroller once after successful completion of the intrusive diagnostic. The intrusive diagnostic is re-executed if the circuit fault is not removed and the pump initialization fails its motor alignment phase (an indication of a permanent fault). Diagnostic software [FABR ring] processes the data in a state transition diagnostic. In the "stopped" state, each motor phase circuit driver pair is enabled for a short duration and corresponding back-EMF voltage is monitored. A fault is reported when the monitored voltage difference falls into a specific range relative to 1/2 source voltage.	Phased-pair circuit voltage Difference	Vdelta > 3 V [relative to 1/2 source input voltage]	a) Sensed fuel pump speed b) Device configuration FCBR_e_ChassisFuelPresSysType c) Diagnostic Enabled [KeFABR_b_PshtCktDiagEnbl] d) CAN Sensor Bus message $3EC_Available e) Sensor Bus Relay On f) Sensor Bus Message $3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_ARC_ChkErr]	a) == 0 rpm b) == CeFCBR_e_DSL_ECM_FTZM_BLDC_Sys c) == TRUE d) == TRUE e) == TRUE f) == TRUE	1 sample / 100 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 1 Signal Message Counter Incorrect	P10B6	This DTC monitors for an error in communication with the Intake Air Temperature Sensor 1 Signal	Communication of the Alive Rolling Count or Protection Value of the Intake Air Temperature 1 from the Intake Air Temperature Sensor 1 over LIN bus is incorrect for out of total samples	>= 8.00 counts >= 10.00 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 10ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Humidity Sensor Signal Message Counter Incorrect	P10B8	This DTC monitors for an error in communication with the Intake Air Humidity Sensor Signal	Communication of the Alive Rolling Count or Protection Value of the Current Status from the Intake Air Humidity Sensor over LIN bus is incorrect for out of total samples	 >= 8.00 counts >= 10.00 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 10ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor Signals Message Counter Incorrect	P10B9	This DTC monitors for an error in communication with the Barometric Pressure Sensor Signals	Communication of the Alive Rolling Count or Protection Value of the Throttle Inlet Absolute Pressure 1 from the Barometric Pressure Sensor over LIN bus is incorrect for out of total samples Or Communication of the Alive Rolling Count or Protection Value of the Throttle Inlet Absolute Pressure 2 from the Barometric Pressure Sensor over LIN bus is incorrect for out of total samples	 >= 8.00 counts >= 10.00 counts >= 8.00 counts >= 10.00 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 10ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (naturally aspirated)	P1101	Detects a performance failure in the Manifold Pressure (MAP) sensor, Throttle Position sensor (TPS) or Mass Air Flow (MAF) sensor that cannot be uniquely identified as a failure in one individual sensor. This diagnostic can set when more than one of these sensors has a performance concern. This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from these three sensors. These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the system, but no	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered OR ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	> 250 kPa*(g/s) > 25.0 grams/sec > 22.0 kPa) > 22.0 kPa	Engine Speed Engine Speed (Coolant Temp OR OBD Coolant Enable Criteria (Coolant Temp OR OBD Max Coolant Achieved Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together) See Residual Weight Factor tables.	>= 400 RPM <= 5,400 RPM >= -9 Deg C = TRUE) <= 129 Deg C = FALSE) >= -20 Deg C <= 129 Deg C >= 0.50 Filtered Throttle Model Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM** Modeled Air Flow Error multiplied by **P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM** and **P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est**	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		single failed sensor can uniquely be identified. In this case, the Inlet Airflow System Performance diagnostic will fail.				MAP Model 1 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM** MAP Model 2 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP_SensorCircuitFA EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		
					No Active DTCs: No Pending DTCs:			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module 5V Reference 1 Circuit	P1176	This DTC monitors for an error in the Fuel Pump Driver Control Module 5V Reference 1 Circuit	Raw Fuel Pump Driver Control Module 5V Reference 1 is or Raw Fuel Pump Driver Control Module 5V Reference 1 is or Absolute difference of the filtered Fuel Pump Driver Control Module 5V Reference 1 and Raw Fuel Pump Driver Control Module 5V Reference 1 is For a non-continuous failure of out of For a continuous failure of	> 92.25 Percent < 87.75 Percent > 0.90 Percent 40.00 counts 80.00 counts 0.20 seconds	Diagnostic is enabled Run/Crank Ignition Voltage U0076 PT Sensor Bus Relay Communication with the Fuel Tank Zone Module is not lost	1.00 (1 indicates enabled) >= 11.00 Volts Is not active Commanded on (if present)	Executes in 12.5ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module 5V Reference 2 Circuit	P1177	This DTC monitors for an error in the Fuel Pump Driver Control Module 5V Reference 2 Circuit	Raw Fuel Pump Driver Control Module 5V Reference 2 is or Raw Fuel Pump Driver Control Module 5V Reference 2 is or Absolute difference of the filtered Fuel Pump Driver Control Module 5V Reference 2 and Raw Fuel Pump Driver Control Module 5V Reference 2 is For a non-continuous failure of out of For a continuous failure of	> 92.25 Percent < 87.75 Percent > 0.90 Percent 40.00 counts 80.00 counts 0.20 seconds	Diagnostic is enabled Run/Crank Ignition Voltage U0076 PT Sensor Bus Relay Communication with the Fuel Tank Zone Module is not lost	1.00 (1 indicates enabled) >= 11.00 Volts Is not active Commanded on (if present)	Executes in 12.5ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Fuel Level Sensor 1 Internal Supply Circuit	P1178	This DTC monitors for an error in the Fuel Pump Driver Control Module Fuel Level Sensor 1 Internal Supply Circuit	Raw Fuel Pump Driver Control Module Fuel Level Sensor 1 Internal Supply Circuit is or Raw Fuel Pump Driver Control Module Fuel Level Sensor 1 Internal Supply Circuit is or Absolute difference of the filtered Fuel Pump Driver Control Module Fuel Level Sensor 1 Internal Supply Circuit and Raw Fuel Pump Driver Control Module Fuel Level Sensor 1 Internal Supply Circuit is For a non-continuous failure of out of For a continuous failure of	> 92.25 Percent < 87.75 Percent > 0.90 Percent 40.00 counts 80.00 counts 0.20 seconds	Diagnostic is enabled Run/Crank Ignition Voltage U0076 PT Sensor Bus Relay Communication with the Fuel Tank Zone Module is not lost	1.00 (1 indicates enabled) >= 11.00 Volts Is not active Commanded on (if present)	Executes in 50.0ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Command Signal Message Counter Incorrect	P11FF	This DTC monitors for an error in communication with the Fuel Pump Command Signals	Communication of the Alive Rolling Count or Protection Value from the Fuel Control System over CAN bus is incorrect for out of total samples	>= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage And Sensor Bus Relay	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Signal Message Counter Incorrect	P1200	This DTC monitors for an error in communication with the Fuel Pump Control Module (FTZM) Fuel Level Sensor 1 Signal Message Counter	Communication of the Fuel Level Sensor 1 Signal Message Counter from the Fuel Pump Control Module (FTZM) over CAN bus is incorrect for out of total samples	>= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage Sensor Bus Relay	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 low side circuit shorted to high side circuit	P1248	Controller specific output driver circuit diagnoses injector 1 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 low side circuit shorted to high side circuit	P1249	Controller specific output driver circuit diagnoses injector 2 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 low side circuit shorted to high side circuit	P124A	Controller specific output driver circuit diagnoses injector 3 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 low side circuit shorted to high side circuit	P124B	Controller specific output driver circuit diagnoses injector 4 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 low side circuit shorted to high side circuit	P124C	Controller specific output driver circuit diagnoses injector 5 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 low side circuit shorted to high side circuit	P124D	Controller specific output driver circuit diagnoses injector 6 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 low side circuit shorted to high side circuit	P124E	Controller specific output driver circuit diagnoses injector 7 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 8 low side circuit shorted to high side circuit	P124F	Controller specific output driver circuit diagnoses injector 8 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Over Temperature	P1255	To detect if an internal fuel pump driver over-temperature condition exists under normal operating conditions. The FTZM ERFS control may adjust the PWM slew rate or frequency as a self-protection method, but may not reduce pump rotational speed or impact pumping performance in any way due to an over-temperature condition.	Fuel Pump Driver Temperature	T > 160 degC	a) Diagnostic enabled [KeFABR_b_OvertempDiagEnbl] b) Sensor Bus Relay On c) CAN Sensor Bus message $3EC_Available d) Sensor Bus Message $3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_ARC_ChkErr]	a) == TRUE b) == TRUE c) == TRUE d) <> TRUE	5.00 failures / 10.00 samples 1 sample / 100 millisec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail High Pressure Sensor 2 Out of Range	P127C	This DTC diagnose SENT high pressure sensor 2 that is too low out of range. If the sensor digital value (represnting the refernce voltage) is below the lower digital threshold, the low fail counter then increments. If the low fail counter reaches its threshold then a fail is reported. A pass is reported for this DTC if the low sample counter reaches its threshold.	High Pressure Rail Sensor 2 SENT digital read value	=< 94			Time Based: 400 Failuer out of 500 Samples 6.25 ms per Sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure Sensor 1 Internal Performance	P128A	This DTC determines if there is internal error within the SENT pressure sensor 1 (i.e. Broken wire bond internal to the SENT Sensor). Once the internal error is detected a fixed faulted digital values is communicated to the ECU.	Digital pressure sesnor 1 value	>= 4,089	SENT Fuel Rail Pressure Sensor Internal Performance Enable Not Fault Pending	Enabled when a code clear is not active or not exiting device control True P16E4 P16E5 P128F	400 failures out of 500 samples 6.25 ms per Sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure Sensor 2 Internal Performance	P128B	This DTC determines if there is internal error within the SENT pressure sensor 2 (i.e. Broken wire bond internal to the SENT Sensor). Once the internal error is detected a fixed faulted digital values is communicated to the ECU.	Digital pressure sesnor 2 value	>= 4,089	SENT Fuel Rail Pressure Sensor Internal Performance Enable Not Fault Pending	Enabled when a code clear is not active or not exiting device control True P16E4 P16E5 P128F	400 failures out of 500 samples 6.25 ms per Sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure & Temperature Sensor Pressure Message Incorrect	P128F	This DTC determines if there is any SENT signal waveform for discrepancies (i.e. too many pulse, too few pulse, clock shift). The SENT HWIO Determines message waveform fault (i.e.too many pulse, too few pulse, clock shift) and if the message age is too long.	SENT HWIO Determines message fault (i.e.too many pulse, too few pulse, clock shift) Message Age	= true > 1.94 ms	SENT signal Serial waveform diagnostics enable SENT power up delay No Fault Active on	True >= 0.00 seconds Enabled when a code clear is not active or not exiting device control P16E4 P16E5	400 failures out of 500 samples 6.25 ms per sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module System Voltage Low (Only on applications that use an FTZM)	P129B	Detects low voltage of the fuel pump driver control module. This diagnostic reports the DTC when the fuel pump driver control module voltage drops below a calibrated value.	Fuel Pump Driver Control Module System Voltage Low	Fuel Tank Zone Module (FTZM) Battery Voltage <= 9.00	Fuel Tank Zone Module (FTZM) is present on vehicle Fuel Pump Driver Control Module System Voltage Low diagnostic is enabled Fuel Tank Zone Module (FTZM) serial messages are available Starter motor not engaged Sensor Bus relay is commanded ON	= 1	400 failures out of 500 samples 12.5 ms / sample	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module System Voltage High (Only on applications that use an FTZM)	P129C	Detects high voltage of the fuel pump driver control module. This diagnostic reports the DTC when the fuel pump driver control module voltage exceeds a calibrated value.	Fuel Pump Driver Control Module System Voltage High	Fuel Tank Zone Module (FTZM) Battery Voltage >= 18.00	Fuel Tank Zone Module (FTZM) is present on vehicle Fuel Pump Driver Control Module System Voltage Low diagnostic is enabled Fuel Tank Zone Module (FTZM) serial messages are available Sensor Bus relay is commanded ON	= 1	400 failures out of 500 samples 12.5 ms / sample	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module System Ignition Switch Run/ Start Position Circuit Low (Only on applications that use an FTZM)	P129D	Detects low voltage of the fuel pump driver control module ignition switch circuit. This diagnostic reports the DTC when the fuel pump driver control module ignition switch circuit voltage is below a calibrated value.	Fuel Pump Driver Control Module Ignition switch Run/Start position circuit low	FTZM Run Crank Active is FALSE	Fuel Tank Zone Module (FTZM) is present on vehicle Fuel Pump Driver Control Module Ignition Switch Run/Start Position Circuit High diagnostic is enabled Fuel Tank Zone Module (FTZM) serial messages are available Run Crank Active Sensor Bus relay is commanded ON	 = 1 = TRUE	40 failures out of 50 samples 50 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Fuel Pump Speed Signal Incorrect	P129F	FTZM ERFS control samples back-Electromotive Force [EMF] for zero voltage-level crossings as a detection method to enable closed loop control brushless commutation. Back EMF is an electrical characteristic of the inactive phase of the 3-phase signal wherein only 2 phases are active at any moment. Brushless pump speed is inferred using rate of zero-crossings detection and number of motor pole-pairs. Speed is reported to the ECM as serial data every 10 millisecs. Diagnostic software [FABR ring] calculates the error between the commanded, arbitrated fuel pump speed [FCBR ring] and the FTZM sensed fuel pump speed. The error is filtered and evaluated against calibratable threshold limits to determine pass/fail status. Any failure that exists on the fuel pump output circuit (3 phases) will be manifested in a Fuel Pump Speed	Sensed Filtered Fuel Pump Speed Error	> Speed Error Low Threshold [Supporting Table] **P129F Threshold Low** OR < Speed Error High Threshold [Supporting Table] **P129F Threshold High**	a) Diagnostic Enabled FABR Speed Rationality Diagnostic b) CAN Sensor Bus message $0CB_Available c) FABR Fuel Control Enable Fault Active d) Fuel Pmp Speed Command Alive Rolling Count and Checksum Error [CAN Bus B $0CE] [CFMR_b_FTZM_Cmd1_ARC_ChkErr] e) FABR Fuel Pump Ckt FA f) FABR Driver OverTemp FA g) Run_Crank input Voltage h) Sensor Bus Relay On j) CAN Sensor Bus message $0CB Data Fault [CFMR_b_FTZM_Info8_ARC_ChkErr] k) CAN Sensor Bus message $0CB Comm Fault [CFMR_b_FTZM_Info8_UcodeCmFA] l) Fuel Pmp Spd Command ARC and Checksum Comm Fault Code [CFMR_b_FTZM_Cmd1_UcodeCmFA] m) Timer - FABR Rising Edge Diagnostic Delay n) Timer - FABR Falling Edge Diagn Delay	a) == TRUE b) == TRUE c) <> TRUE d) <> TRUE e) <> TRUE f) <> TRUE g) > 11.00 volts h) == TRUE j) <> TRUE k) <> TRUE l) <> TRUE m) > 1.00 seconds n) > 1.00 seconds	1 sample / 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Rationality Diagnostic fault. Reported fuel pump speed data will only be consumed in this same diagnostic.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Enable Circuit Performance	P12A6	The purpose of the Fuel Pump Driver Control Module Enable Circuit Performance diagnostic is to detect if the state of the fuel control enable circuit is valid. This is done by comparing the fuel control enable circuit state [high or low] sensed by the Fuel Tank Zone Module device to the commanded state of the fuel control enable signal from the ECM [in serial data]. When the sensed state does not match the commanded state, the fail counter increments.	Sensed Fuel Control Enable circuit state [Fuel Tank Zone Module device]	<> Fuel Control Enable Active command [serial data]	a) Diagnostic enabled [KeFABR_b_FuelCntrlEnblDiagEnbl] b) Sensor Bus message $0CC Fuel Pump Command Message Signal Counter Incorrect [CFMR_b_FTZM_Info2_ARC_ChkErr] c) CAN Sensor Bus message $0CC_Available d) Sensor Bus Relay On e) Timer [FABR_t_RunCrankActive]	a) == TRUE b) <> TRUE c) == TRUE d) == TRUE e) >= 0.00 seconds	40.00 failures / 80.00 samples 1 sample / 12.5 millisec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Control Module (Fuel Tank Zone Module) Control Signal Message Counter Incorrect	P12A8	This DTC monitors for an error in communication with the Fuel Pump Control Module (FTZM) Control Signal Message	Communication of the Alive Rolling Count or Protection Value from the Fuel Pump Control Module (FTZM) over CAN bus is incorrect for out of total samples	>= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage Sensor Bus Relay	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Coil Positive Voltage Circuit Group 1 * * SIDI ONLY * *	P135A	This diagnostic checks for minimum voltage at the fuse which supplies power to the Ignition Coils (applicable only for SIDI applications). A diagnostic failure indicates a blown fuse.	Ignition Module Supply Voltage.	< 2.5 Volts	Diagnostic Enabled? Three possible Ignition Coil Power Sources (only 1 used): Ignition Coil Power Source = <u>Case 1: Battery</u> Delay starting at Key-On <u>Case 2: Ignition Run/ Crank</u> Ignition Run/Crank Voltage <u>Case 3: PT Relay</u> PT Relay Voltage	Yes PT Relay (Case 3) 5 Engine Revs > 5.0 volts > 11.0 volts	50 Failures out of 63 Samples 6.25 msec rate	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Coil Positive Voltage Circuit Group 2 * * SIDI ONLY * *	P135B	This diagnostic checks for minimum voltage at the fuse which supplies power to the Ignition Coils (applicable only for SIDI applications). A diagnostic failure indicates a blown fuse.	Ignition Module Supply Voltage.	< 2.5 Volts	Diagnostic Enabled? Three possible Ignition Coil Power Sources (only 1 used): Ignition Coil Power Source = <u>Case 1: Battery</u> Delay starting at Key-On <u>Case 2: Ignition Run/ Crank</u> Ignition Run/Crank Voltage <u>Case 3: PT Relay</u> PT Relay Voltage	Yes PT Relay (Case 3) 5 Engine Revs > 5.0 volts > 11.0 volts	50 Failures out of 63 Samples 6.25 msec rate	Type: Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Emissions Reduction System Fault	P1400	Model based test computes power from exhaust flow and thermal energy resulting from elevated idle speed and retarded spark advance. Detects if the cold start emission reduction system has failed resulting in the delivered power being out of range.	Average desired accumulated exhaust power - Average actual accumulated exhaust power (too much energy delivered to catalyst) Average desired accumulated exhaust power - Average actual accumulated exhaust power (too little energy delivered to catalyst) (EWMA filtered) Average Power = output of **P1400_EngineSpeedResidual_Table** * output of **P1400_SparkResidual_Table** NOTE: Desired accumulated power would use the desired catalyst light off spark and desired engine speed and the actual accumuated power would use the final commanded spark and actual engine speed. Refer to the Supporting Tables for details	< -32.00 KJ/s (high RPM failure mode) > 3.50 KJ/s (low RPM failure mode)	To enable the diagnostic, the Cold Start Emission Reduction Strategy must be Active per the following: Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following: Catalyst Temperature AND Engine Run Time OR Engine Run Time OR Barometric Pressure	< 300.00 degC > 6.00 degC < = 66.00 degC >= 70.00 KPa >= 800.00 degC >= 1.00 seconds > **P050D_P1400_CatalystLightOffExtendedEngineRunTimeExit** This Extended Engine run time exit is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details. < 70.00 KPa	Runs once per trip when the cold start emission reduction strategy is active Frequency: 100ms Loop Test completes after 10 seconds of accumulated qualified data.	EWMA Based - Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Other Enable Criteria:			
					OBD Manufacturer Enable Counter	0		
					Vehicle Speed	< 1.86 MPH		
					Allow diagnostic to calculate residual in an off-idle state. If the value of the OffIdleEnable is equal to 1 then the "DriverOffAccelPedal" will not be checked. However, if the value of OffIdleEnable is 0 then driver must be off the accel pedal	0 (A value of 1 allows diagnostic to run and calculate the residual while off idle. A value of 0 requires calculation of the residual at idle)		
					A change in throttle position (tip-in/tip-out) will initiate a delay in the calculation of the average qualified residual value. Therefore when the:			
					Pedal Close Delay Timer	> 2.00 seconds		
					the diagnostic will continue the calculation.			
					A change in gear will initiate a delay in the calculation of the average qualified residual value to			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					allow time for the actual engine speed and actual final commanded spark to achieve their desired values. Therefore, when the: Gear Shift Delay Timer the diagnostic will continue the calculation For Manual Transmission vehicles: Clutch Pedal Position Clutch Pedal Position The diagnostic will delay calculation of the residual value and potentially weight the residual calculation differently based on engine run time. This is to ensure the diagnostic is operating in idle speed control as well as during the peak catalyst light off period. The time weighting factor must be :	> 1.50 seconds > 12.00 % < 75.00 % > 0 These are scalar values that are a function of engine run time. Refer to		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						P1400_ColdStartDiagnosticDelayBasedOnEngineRunTime and the cal axis, **P1400_ColdStartDiagnosticDelayBasedOnEngineRunTimeCalAxis** in the "Supporting Tables" for details. General Enable: DTC's Not Set: AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFP CrankSensor_FA FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA EngineMisfireDetected_FA ClutchPstnSnsr FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA 5VoltReferenceMAP_OOR_Flt TransmissionEngagedState_FA EngineTorqueEstInaccurate		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor A Reference Feedback Range/ Performance	P1434	This DTC monitors for an error with the FTZM Fuel Level Sensor A Reference Feedback Range/Performance Circuit	The difference between the actual and commanded FTZM reference voltage period or The difference between the actual and commanded FTZM reference voltage pulse width error	> 25.00 ms > 1.50 ms	Diagnostic is enabled Message $2D7 is being received Reference Voltage Pulse Width Signal has been available for Reference Voltage Period Signal has been available for System Diagnostics Disabled Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	1.00 (1 indicates enabled) True >= 1.25 seconds >= 0.75 seconds False = Run >= 11.00 Volts >= 11.00 Volts	16 failed samples within 20 total samples Executes in 250ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Engine Speed Request Circuit	P150C	This DTC monitors for an error in communication with the Transmission Engine Speed Request signal in $19D	Communication of the Alive Rolling Count or Protection Value in the Transmission Engine Speed signal over CAN bus is incorrect for out of total samples	>= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 25ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Steady State Actuation Fault	P1516	Detect an inablity to maintain a steady state throttle position.	The absolute difference between desired and indicated throttle position is >	2.00 percent	Run/Crank voltage TPS minimum learn is not active AND Throttle is being Controlled Throttle is considered in a steady state condition when the desired throttle position over a 12.5 ms period is For a settling time period Ignition voltage failure is false	> 6.41 Volts < 0.25 percent > 4.00 seconds P1682	0.49 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Communication Error with Active Grill Air Shutter Module “A”	P151E	This DTC monitors for an internal error or error in communication with the Active Grill Air Shutter Module A	Communication of the Alive Rolling Count from the Shutter Module A over LIN bus is incorrect or the Shutter Module A signals has an internal error for out of total samples	 >= 8.00 counts >= 10.00 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	LIN bus communication executes in 500ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Switch State Undetermined	P155A	Detects when cruise switch state cannot be determined, such as low voltage conditions	cruise switch state is received as "undetermined" for greater than a calibratable time	fail continuously for greater than 3.0 seconds			fail continuously for greater than 3.0 seconds	Type C, No SVS, "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Actuator Voltage Signal Message Counter Incorrect	P155E	This DTC monitors for an error in communication with the DC/DC Converter Actuator Voltage Signal	Communication of the Alive Rolling Count or Protection Value from the DC/DC Converter over CAN bus is incorrect for out of total samples	>= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 10ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Ignition Switch Run/ Start Position Signal Message Counter Incorrect	P156D	This DTC monitors for an error in communication with the DC/DC Converter Run/ Crank Terminal Status Signal	Communication of the Alive Rolling Count or Protection Value from the DC/DC Converter over CAN bus is incorrect for out of total samples	>= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 10ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Crank Control Signal Message Counter Incorrect	P156E	This DTC monitors for an error in communication with the DC/DC Converter Crank Control Terminal Signal	Communication of the Alive Rolling Count or Protection Value from the DC/DC Converter over CAN bus is incorrect for out of total samples	>= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 10ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Bus Relay Feedback Circuit High Voltage	P157A	Detects unexpected CAN activity on the sensor bus. This diagnostic reports the DTC when controller-specific CAN frames are received while the sensor bus relay is commanded "off."	Continued reception of sensor bus CAN frames during driver off state indicates a stuck on circuit failure. Controller specific received CAN frames are selected to determine continued CAN activity.		Sensor Bus Relay feedback circuit high voltage diagnostic enabled Sensor Bus Relay commanded “OFF” No Sensor Bus active DTCs:	= 1 P16D7, P16D8, P16D9	6 failures out of 10 samples 250ms / Sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Calibration Incorrect	P158A	Type of cruise in Body Control Module does not match that in the Engine Control Module for 2.5 seconds	Type of cruise system in GMLAN $4E9 does not match with that in the Engine Control Module for a fix time.	2.5 seconds	DID $40 from BCM says cruise system is present (ECM recieves programmble information from Body Control Module) OR ECM will not receive Programmable information for Cruise from Body Control Module	 True	fail continuously for greater than 2.5 seconds.	Type C, No SVS "Emissions Neutral Diagnostics – Special Type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Analog Mode Switch Circuit Low	P159F	This DTC will detect an analog driver mode switch input that is too low out of range.	For button type Normal_Button Analog Mode Switch low voltage threshold % of 5V range For button type Enhanced_Button Analog Mode Switch low voltage threshold % of 5V range For button type Mulitple_Button Analog Mode Switch low voltage threshold % of 5V range	< 29.00 % < 24.30 % < 21.20 %	Vehicle mode analog switch button type	= CeDMDG_e_Seven_Buttons	200 failures out of 250 samples 25 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Analog Mode Switch Circuit High	P15A0	This DTC will detect an analog driver mode switch input that is too high out of range.	For button type Normal_Button Analog Mode Switch high voltage threshold % of 5V range For button type Enhanced_Button Analog Mode Switch high voltage threshold % of 5V range For button type Mulitple_Button Analog Mode Switch high voltage threshold % of 5V range	 >= 88.80 % >= 94.10 % >= 95.30 %	Vehicle mode analog switch button type	= CeDMDG_e_Seven_Buttons	200 failures out of 250 samples 25 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Analog Mode Switch Performance	P15A1	This DTC will detect an analog driver mode switch input that is in an indeterminate range.	For button type Normal_Button Analog Mode Switch indeterminate region % of 5V range For button type Enhanced_Button Analog Mode Switch indeterminate regions % of 5V range For button type Mulitple_Button Analog Mode Switch indeterminate regions % of 5V range	66.80 % ≤ % of 5 volts < 72.80 % 63.50 % ≤ % of 5 volts < 65.50 % 83.50 % ≤ % of 5 volts < 85.50 % 52.90 % ≤ % of 5 volts < 54.10 % 74.10 % ≤ % of 5 volts < 75.30 % 87.50 % ≤ % of 5 volts < 88.60 %	Vehicle mode analog switch button type	= CeDMDG_e_Seven_Buttons	200 failures out of 250 samples 25 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Front Object Detection Control Module Torque Request Signal Message Counter Incorrect	P15F6	Detects rolling count or protection value errors in Collision Preparation System Axle Torque Command serial data signal	If x of y rolling count / protection value faults occur, disable collision preparation system for duration of fault		Front Object Detection Module Torque Request Serial Data Error Diagnostic Enable	1.00	4 / 10 counts	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Automatic Braking Engine Torque Request Signal Message Incorrect	P15F8	Detects rolling count or protection value errors Rear Virtual Bumper Axle Torque Command serial data signal	If x of y rolling count / protection value faults occur, disable rear virtual bumper or collision preparation system for duration of fault		Automatic Braking Engine Torque Request Serial Data Error Diagnostic Enable	1.00	4 / 10 counts	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Wheel Speed Sensor Sequence Number Incorrect	P15FD	This DTC monitors wheel speed signals for an incorrect sequence	Communication of the wheel speed sequence numbers from the ABS / Brake Control Module is incorrect. A complete set of sequence numbers has not been received for and this state is continuous for out of a total sample time of	 > 10.00 seconds > 4.00 seconds > 5.00 seconds	Sequence Number Error DTC is enabled Power Mode Run/Crank Ignition Voltage Driven and non-driven wheel rotational status is currently being received and not failsoft.	= 1 (1 indicates enabled) = Run or Crank >= 11.00 Volts	Diagnostic executes in 25ms loop	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Sensor Signal Message Counter Incorrect	P15FF	This DTC monitors for an internal error or error in communication with the Battery Monitor Signal	Communication of the Alive Rolling Count from the Battery Monitor Module in frame 1E over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for out of total samples Or Communication of the Alive Rolling Count from the Battery Monitor Module in frame 15 over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for out of total samples Or Communication of the Alive Rolling Count from the Battery Monitor Module in frame 16 over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for out of total samples Or Communication of the Alive Rolling Count from	>= 8.00 counts >= 10.00 counts >= 8.00 counts >= 10.00 counts >= 8.00 counts >= 10.00 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Fastest periodic communication rate to Battery Monitor Module on LIN bus executes at 250ms.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			the Battery Monitor Module in frame 17 over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for	>= 8.00 counts				
			out of total samples	>= 10.00 counts				
			Or					
			Communication of the Alive Rolling Count from the Battery Monitor Module in frame 18 over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for	>= 8.00 counts				
			out of total samples	>= 10.00 counts				
			Or					
			Communication of the Alive Rolling Count from the Battery Monitor Module in frame 19 over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for	>= 8.00 counts				
			out of total samples	>= 10.00 counts				
			Or					
			Communication of the Alive Rolling Count from the Battery Monitor Module in frame 1D over LIN bus is incorrect or the					

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Battery Monitor Module signals it has an internal error for out of total samples Or Communication of the Alive Rolling Count from the Battery Monitor Module in frame 1A over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for out of total samples Or Communication of the Alive Rolling Count from the Battery Monitor Module in frame 1B over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for out of total samples Or Communication of the Alive Rolling Count from the Battery Monitor Module in frame 1C over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for	>= 8.00 counts >= 10.00 counts >= 8.00 counts >= 10.00 counts >= 8.00 counts >= 10.00 counts >= 8.00 counts				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			out of total samples	>= 10.00 counts				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module SIDI High Pressure Pump current monitor	P163A	This DTC Diagnoses the current from the control area and compares it with calibrated thresholds to set current high and low flags	SIDI fuel pump High Current Test Current SIDI fuel pump Low Current Test Current	 >= 11.00 Amps <= 0.10 Amps	Battery Voltage Low Side Fuel Pressure Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false andEngine movement detected is true and Manufacturers enable	>= 11 Volts > 0.275 MPa Enabled when a code clear is not active or not exiting device control Engine is not cranking	Current High/ Low 10 seconds failures out of 12.50 seconds sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active and Barometric Pressure Inlet Air Temp Fuel Temp	 >= 70.0 KPA >= -12.0 degC -12 <= Temp degC <= 132		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Reference Voltage Status Message Counter Incorrect	P165C	This DTC monitors for an error in communication with the Sensor Reference Voltage Status Signals	Communication of the Alive Rolling Count or Protection Value from the Fuel Control System over CAN bus is incorrect for out of total samples	 >= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage And Sensor Bus Relay	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Voltage Signal Message Counter Incorrect	P167F	This DTC monitors for an error in the FTZM Battery Voltage Signal Message Counter	Communication of the Alive Rolling Count or Protection Value from the Fuel Pump Control Module (FTZM) over CAN bus is incorrect for out of total samples	>= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage Sensor Bus Relay	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation	P1682	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage and the Powertrain Relay Ignition Voltage. The diagnostic monitors the difference in voltage between Run/Crank Voltage and the Powertrain Relay Ignition Voltage and fails the diagnostic when the voltage difference is too high. This diagnostic only runs when the powertrain is commanded on and the Run/Crank Voltage is greater than a threshold based on IAT or the powertrain ignition voltage is high enough the Run/Crank voltage is high enough.	|Run/Crank – PT Relay Ignition| >	3.00 Volts		Powertrain Relay commanded on AND (Run/Crank voltage > Table, f(IAT). See supporting tables: **P1682_PT Relay Pull-in Run/Crank Voltage f(IAT)** OR PT Relay Ignition voltage > 5.50 Volts) AND Run/Crank voltage > 5.50 Volts	240 / 480 counts; or 0.175 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS SENT Comm Circuit Low (Gasoline applications ONLY)	P16A0	Detects a continuous or intermittent short low or open fault in the TPS SENT Communication Circuit by monitoring the voltage and failing the diagnostic when the voltage for the wave pulse is below state threshold as defined by SAE J2716 SENT Protocol. This diagnostic only runs when battery voltage is high enough.	Voltage for wave pulse is below state threshold as defined by SAE J2716 SENT Protocol	0.5 V	Run/Crank voltage	> 6.41 Volts	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS SENT Comm Circuit High (Gasoline applications ONLY)	P16A1	Detects a continuous or intermittent short high fault in the TPS SENT Communication Circuit by monitoring the voltage and failing the diagnostic when the voltage for the wave pulse is above state threshold as defined by SAE J2716 SENT Protocol. This diagnostic only runs when battery voltage is high enough. Detects a High Circuit Fault in the TPS SENT Communication Circuit	Voltage for wave pulse is above state threshold as defined by SAE J2716 SENT Protocol	4.1 V	Run/Crank voltage	> 6.41 Volts	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS SENT Comm Circuit Performance (Gasoline applications ONLY)	P16A2	Detects a message fault in the TPS SENT Communication Circuit by monitoring the message pulse time and failing the diagnostic when the time for the pulse is above a low time threshold or above a high time threshold or if the message age limit is greater than a time threshold. This diagnostic only runs when battery voltage is high enough. Detects a Message Fault in the TPS SENT Communication Circuit	Message Pulse < Message Pulse > or Message Age Limit >= or Signal CRC fails	0.125977 ms 0.209991 ms 3.125 ms	Run/Crank voltage	> 6.41 Volts	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation #2	P16A7	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage and the Powertrain Relay Ignition Voltage #2. The diagnostic monitors the difference in voltage between Run/Crank Voltage and the Powertrain Relay Ignition Voltage and fails the diagnostic when the voltage difference is too high. This diagnostic only runs when the powertrain is commanded on and the Run/Crank Voltage is greater than a threshold based on IAT or the powertrain ignition voltage is high enough the Run/Crank voltage is high enough. Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage & the Powertrain Relay Ignition Voltage #2.	|Run/Crank – PT Relay Ignition| >	3.00 Volts		Powertrain commanded on AND (Run/Crank voltage > Table, f(IAT). See supporting tables: **P1682_PT Relay Pull-in Run/Crank Voltage f(IAT)** OR PT Relay Ignition voltage > 5.50 Volts) AND Run/Crank voltage > 5.50 Volts	240 / 480 counts; or 0.175 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Controls Ignition Relay Feedback Circuit 2 Low Voltage - (GEN III Controllers ONLY)	P16AF	Detects low voltage in the engine controls ignition relay feedback circuit 2. This diagnostic reports the DTC when low voltage is present. Monitoring occurs when run crank voltage is above a calibrated value.	Engine controls ignition relay feedback circuit 2 low voltage	Relay voltage <= 5.00	Powertrain relay low diag enable Powertrain relay voltage Run Crank voltage Powertrain relay state	= 1.00 >= 11.00 > 9.00 = ON	5 failures out of 6 samples 1000 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Controls Ignition Relay Feedback Circuit 2 High Voltage - (GEN III Controllers ONLY)	P16B3	Detects high voltage in the engine controls ignition relay feedback circuit 2. This diagnostic reports the DTC when high voltage is present. Monitoring occurs when the relay state is inactive.	Engine controls ignition relay feedback circuit 2 high voltage	Relay voltage >= 4.00	Powertrain relay high diag enable Powertrain relay state	= 1.00 = INACTIVE	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation #3	P16BC	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage & the Powertrain Relay Ignition Voltage #2	|Run/Crank – PT Relay Ignition| >	3.00 Volts		Powertrain commanded on AND (Run/Crank voltage > Table, f(IAT). See supporting tables: **P1682_PT Relay Pull-in Run/Crank Voltage f(IAT)** OR PT Relay Ignition voltage > 5.50 Volts) AND Run/Crank voltage > 5.50 Volts	240 / 480 counts; or 0.175 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Controls Ignition Relay Feedback Circuit 3 Low Voltage - (Diesel Controllers ONLY)	P16BD	Detects low voltage in the engine controls ignition relay feedback circuit 3. This diagnostic reports the DTC when low voltage is present. Monitoring occurs when run crank voltage is above a calibrated value.	Engine controls ignition relay feedback circuit 3 low voltage	Relay voltage <= 5.00	Powertrain relay low diag enable Powertrain relay voltage Run Crank voltage Powertrain relay state	= 1.00 >= 11.00 > 9.00 = ON	5 failures out of 6 samples 1000 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Controls Ignition Relay Feedback Circuit 3 High Voltage - (Diesel Controllers ONLY)	P16BF	Detects high voltage in the engine controls ignition relay feedback circuit 3. This diagnostic reports the DTC when high voltage is present. Monitoring occurs when the relay state is inactive.	Engine controls ignition relay feedback circuit 3 high voltage	Relay voltage >= 4.00	Powertrain relay high diag enable Powertrain relay state	= 1.00 = INACTIVE	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Circuit Low Voltage	P16D4	This DTC monitors for a battery module low voltage circuit fault	Battery Module signals a low voltage circuit fault via LIN bus VeVITR_U_12VBattVolt	< 3.00 Volts for 200 fail counts out of 250 sample counts	The diagnostic is enabled System Diagnostics Disabled Power Mode 12V System Reference Voltage LIN Bus Off or Battery Module Communication Faults Active Outside Air Temperature Outside Air Temperature Validity Bit	= 1 (1 indicates enabled) = False Not equal off > 9.00 Volts = False > -20.00 Celsius and < 50.00 Celsius = True	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Circuit High Voltage	P16D5	This DTC monitors for a battery module high voltage circuit fault	Battery Module signals a high voltage circuit fault via LIN bus VeVITR_U_12VBattVolt	> 26.00 Volts for 200 fail counts out of 250 sample counts	The diagnostic is enabled System Diagnostics Disabled Power Mode 12V System Reference Voltage LIN Bus Off or Battery Module Communication Faults Active Outside Air Temperature Outside Air Temperature Validity Bit	= 1 (1 indicates enabled) = False Not equal off > 9.00 Volts = False > -20.00 Celsius and < 50.00 Celsius = True	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Current Low	P16D6	This DTC monitors for a battery module current low fault	Battery Module signals a current low fault via LIN bus VeVITR_I_12VBattCurrRaw	< -1400 Amps for 200 fail counts out of 250 sample counts	The diagnostic is enabled System Diagnostics Disabled Power Mode 12V System Reference Voltage LIN Bus Off or Battery Module Communication Faults Active Outside Air Temperature Outside Air Temperature Validity Bit	= 1 (1 indicates enabled) = False Not equal off > 9.00 Volts = False > -20.00 Celsius and < 50.00 Celsius = True	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Bus Relay Control Circuit Open	P16D7	Detects an open circuit in the sensor bus relay circuit. This diagnostic reports the DTC when an open circuit is present. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 K Ω ohms impedance between output and controller ground	Run/Crank Voltage	Voltage ≥ 11.00 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controllers P16D8 may also set (Sensor Bus Relay Control Circuit Low).

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Bus Relay Control Circuit Low	P16D8	Detects a short to ground in the sensor bus relay circuit. This diagnostic reports the DTC when a short to ground is present. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to ground: ≤ 0.5 Ω impedance between output and controller ground	Run/Crank Voltage	Voltage ≥ 11.00 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controllers P16D7 may also set (Sensor Bus Relay Control Circuit Open).

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Bus Relay Control Circuit High	P16D9	Detects a short to power in the sensor bus relay circuit. This diagnostic reports the DTC when a short to power is present. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to power: ≤ 0.5 Ω impedance between output and controller power	Run/Crank Voltage	Voltage ≥ 11.00 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Module Monitor Timer Performance	P16DC	This DTC monitors for a battery module timer performance fault	Battery Module shall fail when either of the following criteria are met. Case 1: Wake Up Test A: LIN Bus Off Timer / 1,800.00 seconds or B: (LIN Bus Off Timer + 1,800.00 seconds) / 1,800.00 seconds or C: (LIN Bus Off Timer - 1,800.00 seconds) / 1,800.00 seconds Case 2: Sequential Test Sequential Test is enabled	If the calculated wakeup value is smaller than 24.00 counts, then the smaller value will be outputed. If the calculated wakeup value is greater than 24.00 counts, then the calibration itself is outputed. If any outputs above are not not equal to the IBS maximum down counter counts, the diagnostic fails. This portion of the diagnostic is not used. = 0 (1 indicates enabled)	The diagnostic is enabled System Diagnostics Disabled Power Mode 12V System Reference Voltage LIN Bus Off or Battery Module Communication Faults Active Outside Air Temperature Outside Air Temperature Validity Bit Historical Temperature Data Trigger Request Module Off Timer Fault Active Run Crank Low Timer Error Code Clear Request IBS Measure Temperaure Data Available	= 1 (1 indicates enabled) = False Not equal off > 9.00 Volts = False > -20.00 Celsius and < 50.00 Celsius = True = 1 (initializes to 0 then transitions to 1 once data is available- NEED TO SEE POSITIVE RISING EDGE) = False = False = False (latched when set True) = True	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					TPTKO OR TFTKO	= False (when KeVITD_b_TimerPerf_DFIRDisable = 0) Calibration is set to 0		
					IBS Down Counter Value	Not equal to 25.00		
					Spurious Reset	= False		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Current High	P16DD	This DTC monitors for a battery module current high fault	Battery Module signals a current high fault via LIN bus VeVITR_I_12VBattCurrRaw	> +1400 Amps for 200 fail counts out of 250 sample counts	The diagnostic is enabled System Diagnostics Disabled Power Mode 12V System Reference Voltage LIN Bus Off or Battery Module Communication Faults Active Outside Air Temperature Outside Air Temperature Validity Bit	= 1 (1 indicates enabled) = False Not equal off > 9.00 Volts = False > -20.00 Celsius and < 50.00 Celsius = True	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Internal Temperature Circuit Low	P16DE	This DTC monitors for a battery module internal temperature circuit low fault	Battery Module raw temperature 1 value	> 120.00 Celsius	The historical mode diagnostic is enabled and / or The continuous mode diagnostic is enabled System Diagnostics Disabled Power Mode 12V System Reference Voltage LIN Bus Off or Battery Module Communication Faults Active Outside Air Temperature Outside Air Temperature Validity Bit For Historical Mode IBS Down Counter (over LIN bus) For Continuous Mode IBS Down Counter (over LIN bus) IBS Measure Temperature Data Available over LIN bus	= 1 (1 indicates enabled) = 1 (1 indicates enabled) = False Not equal off > 9.00 Volts = False > -20.00 Celsius and < 50.00 Celsius = True Between 1 and 24 or zero = zero = True	4 failed samples within 5 total samples Diagnostic runs in the 250 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Internal Temperature Circuit High	P16DF	This DTC monitors for a battery module internal temperature circuit high fault	Battery Module raw temperature 1 value	< -43.00 Celsius	The historical mode diagnostic is enabled and / or The continuous mode diagnostic is enabled System Diagnostics Disabled Power Mode 12V System Reference Voltage LIN Bus Off or Battery Module Communication Faults Active Outside Air Temperature Outside Air Temperature Validity Bit For Historical Mode IBS Down Counter (over LIN bus) For Continuous Mode IBS Down Counter (over LIN bus) IBS Measure Temperature Data Available over LIN bus	= 1 (1 indicates enabled) = 1 (1 indicates enabled) = False Not equal off > 9.00 Volts = False > -20.00 Celsius and < 50.00 Celsius = True Between 1 and 24 = zero = True	4 failed samples within 5 total samples Diagnostic runs in the 250 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Random Access Memory (RAM) Error	P16E1	This DTC monitors for a battery module RAM memory fault	Battery Module signals a RAM memory fault via LIN bus VeVITR_e_IBS_IntRAM_ Fault	= CeVITR_e_DiagFailed	The diagnostic is enabled System Diagnostics Disabled Power Mode 12V System Reference Voltage LIN Bus Off or Battery Module Communication Faults Active Outside Air Temperature Outside Air Temperature Validity Bit	= 1 (1 indicates enabled) = False Not equal off > 9.00 Volts = False > -20.00 Celsius and < 50.00 Celsius = True	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Read Only Memory (ROM) Error	P16E2	This DTC monitors for a battery module ROM memory fault	Battery Module signals a ROM memory fault via LIN bus VeVITR_e_IBS_IntROM_ Fault	= CeVITR_e_DiagFailed	The diagnostic is enabled System Diagnostics Disabled Power Mode 12V System Reference Voltage LIN Bus Off or Battery Module Communication Faults Active Outside Air Temperature Outside Air Temperature Validity Bit	= 1 (1 indicates enabled) = False Not equal off > 9.00 Volts = False > -20.00 Celsius and < 50.00 Celsius = True	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Data Incompatible	P16E3	This DTC monitors for a battery module data incompatible fault	Battery Module data received over LIN bus is incompatible. (Measured by any of the following)		The historical mode diagnostic is enabled and / or The continuous mode diagnostic is enabled	= 1 (1 indicates enabled) = 1 (1 indicates enabled)	Diagnostic runs in the 250 ms loop	Type B, 2 Trips
			Historical Test	Upon IBS wakeup, if any of the below Historical Test conditions are satisfied, the diagnostic fails.	System Diagnostics Disabled Power Mode 12V System Reference Voltage LIN Bus Off or Battery Module Communication Faults Active Outside Air Temperature Outside Air Temperature Validity Bit IBS Configuration Data Available over LIN bus Historical Test Only Host Controller MEC Counter	= False Not equal off > 9.00 Volts = False > -20.00 Celsius and < 50.00 Celsius = True = True <= 0	
			Absolute value of IBS battery capacity C20 data (IBS Return Nominal C20 - 70.00 Ah)	> 5.00 Ah				
			or					
			IBS Returns a battery type that is not equal to	CeBSER_e_IBS_Cfg BatAGM				
			or					
			Absolute value of (IBS Return Battery Calibration#1 U40@25 C - 12.08 V)	> 0.50 Volts				
			or					
			Absolute value of (IBS Return Battery Calibration#1 U80@25 C - 12.64 V)	> 0.50 Volts				
			Continuous Test	If any of the below conditions are satisfied for 16.00 fail counts				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				out of 20.00 sample counts, the diagnostic fails.				
			Absolute value of IBS battery capacity C20 data (IBS Return Nominal C20 - 70.00 Ah)	> 5.00 Ah				
			or					
			IBS Returns a battery type that is not equal to	CeBSER_e_IBS_Cfg BatAGM				
			or					
			Absolute value of (IBS Return Battery Calibration#1 U40@25 C - 12.08 V)	> 0.50 Volts				
			or					
			Absolute value of (IBS Return Battery Calibration#1 U80@25 C - 12.64 V)	> 0.50 Volts				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure & Temperature Sensor Communication Circuit 3 Low Voltage	P16E4	This DTC determines if the SENT signal shorted low, this is determined by monitoring the number pulses on the SENT signal line received at the ECU and the SENT Signal Line State always indicating low.	The number pulses on the SENT signal line SENT Signal Line State	<= 35 = Low	SENT Sensor Communication Circuit Diagnostic Enabled SENT power up delay	True >= 0.00 seconds Enabled when a code clear is not active or not exiting device control	400 failures out of 500 samples 6.25 ms per sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure & Temperature Sensor Communication Circuit 3 High Voltage	P16E5	This DTC determines if the SENT signal shorted low, this is determined by monitoring the number pulses on the SENT signal line received at the ECU and the SENT Signal Line State always indicating high.	The number pulses on the SENT signal line SENT Signal Line State	<= 35 = High	SENT Sensor Communication Circuit Diagnostic Enabled SENT power up delay	True >= 0.00 seconds Enabled when a code clear is not active or not exiting device control	400 failures out of 500 samples 6.25 ms per sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Redundant Memory Performance (Gasoline applications ONLY)	P16F3	Detect Processor Calculation faults due to RAM corruptions, ALU failures and ROM failures For all of the following cases: If the individual diagnostic threshold is equal to 2048 ms, this individual case is not applicable. If any of the following cases are X out of Y diagnostics and the fail (x) is greater than the sample (Y), this individual case is also not applicable.	Equivance Ratio torque compensation exceeds threshold	-101.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	Type A, 1 Trips
			Absolute difference between Equivance Ratio torque compensation and its dual store out of bounds given by threshold	101.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference of Accessory torque and its redundant calculation is out of bounds given by threshold range	101.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Filtered Air-per-cylinder and its redundant calculation is out of bounds given by threshold range	63.43 mg	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference between the previous Final Advance and the current Final Advance not Adjusted for Equivalence Ratio is out of bounds given by threshold range	15.00 degrees		Engine speed >0rpm	Up/down timer 429 ms continuous, 0.5 down time multipier	
			Torque Learn offset is out of bounds given by threshold range	High Threshold 0.00 Nm Low Threshold 0.00	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Nm				
			One step ahead calculation of air-per-cylinder and two step ahead is greater than threshold	80.00 mg		Engine speed > 550 rpm	Up/down timer 460 ms continuous, 0.5 down time multipier	
			Difference between Unmanaged Spark and PACS Spark is greater than threshold	15.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded Predicted Engine Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Zero pedal axle torque is out of bounds given by threshold range	High Threshold 1,396.00 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Creep Coast Axle Torque is out of bounds given by threshold range	High Threshold 1,396.00 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Absolute difference of Friction torque and its redundant calculation is out of bounds given by threshold range	101.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Arbitrated Air-Per-Cylinder filter coefficient is out of bounds given by threshold range	High Threshold 1.000 Low Threshold 0.074	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Launch spark is active but the launch spark redundant path indicates it should not be active	N/A		Engine speed < 7,900.00 or 8,000.00 rpm (hysteresis pair)	Up/down timer 160 ms continuous, 0.5 down time multipier	
			Rate limited vehicle speed and its dual store do not equal	N/A		Time since first CAN message with vehicle speed >= 0.500 sec	10 / 20 counts; 25.0msec/count	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded engine torque due to fast actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded engine torque due to slow actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			TOS to wheel speed conversion factor is out of bounds given by threshold range	High Threshold: 1.10 T/C Range Hi 0.10 T/C Range Lo Low Threshold: 1.10 T/C Range Hi 0.10 T/C Range Lo	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Cylinders active greater than commanded	3 cylinders		Engine run flag = TRUE > 2.00 s Number of cylinder events since engine run > 24 No fuel injector faults active	Up/down timer 460 ms continuous, 0.5 down time multipier	
			Transfer case neutral request from four wheel drive logic does not match with operating conditions	N/A	Ignition State	Accessory, run or crank Transfer case range valid and not over-ridden FWD Apps only	7.00 / 10.00 counts; 25.0msec/count	
			Driver progression mode and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multipier	
			Predicted torque for uncorrected zero pedal determination is greater than calculated limit.	Table, f(Engine, Oil Temp). **P16F3_Speed Control External Load f(Oil Temp, RPM)** + 101.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Engine Predicted Request Without Motor is greater than its redundant calculation plus threshold	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Engine Immediate Request Without Motor is greater than its redundant calculation plus threshold	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							down time multipier	
			Positive Torque Offset is greater than its redundant calculation plus threshold OR Positive Torque Offset is less than its redundant calculation minus threshold	202.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Commanded Predicted Engine Request is greater than its redundant calculation plus threshold	101.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, down time	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multipier 0.5	
			Commanded Hybrid Predicted Crankshaft Request is greater than its redundant calculation plus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Commanded Hybrid Immediate Crankshaft Request is less than its redundant calculation minus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Regeneration Brake Assist is not within a specified range	Brake Regen Assist < 0 Nm or Brake Regen Assist > 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Cylinder Spark Delta Correction exceeds the absolute difference as compared to Unadjusted Cylinder Spark Delta	15.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			1. Cylinder Torque Offset exceeds step size threshold OR	1. 101.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			2. Sum of Cylinder Torque Offset exceeds sum threshold	2. 101.00 Nm				
			Engine Capacity Minimum Immediate Without Motor is greater than its dual store plus threshold	101.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Engine Capacity Minimum Engine Off is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Capacity Minimum Engine Immediate Without Motor is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Commanded Immediate Engine Request is greater than its redundant calculation plus threshold	101.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Engine Speed Lores Intake Firing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 160 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Speed Lores Intake Firing timing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 160 ms continuous, 0.5 down time multipier	
			Idle speed control calculated predicted minimum torque request exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: **P16F3_Speed Control External Load f(Oil Temp, RPM)** + 101.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Idle speed control calculated predicted minimum torque without reserves exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: **P16F3_Speed Control External Load f(Oil Temp, RPM)** +	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				101.00 Nm				
			Difference between Driver Requested Immediate Torque primary path and its secondary exceeds threshold	1,396.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Driver Immediate Request is less than its redundant calculation minus threshold	1,396.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded Immediate Request is greater than its redundant calculation plus threshold	1,396.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR Commanded Immediate Request is less than its redundant calculation minus threshold				multipier	
			Commanded Immediate Response Type is set to Inactive	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Difference between Cruise Axle Torque Arbitrated Request and Cruise Axle Torque Request exceeds threshold	52.35 Nm		Cruise has been engaged for more than 4.00 seconds	Up/down timer 2,048 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired engine torque request greater than redundant calculation plus threshold	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Engine min capacity above threshold	101.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 69 ms continuous, 0.5 down time multipier	
			No fast unmanaged retarded spark above the applied spark plus the threshold	15.00 Degree		Engine speed greater than 0rpm	Up/down timer 429 ms continuous, 0.5 down time multipier	
			Absolute difference of adjustment factor based on temperature and its dual store above threshold	2.76 m/s	Ignition State	Accessory, run or crank	Up/down timer 97 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			1. Absolute difference of redundant calculated engine speed above threshold	500 RPM		Engine speed greater than 0 RPM	Up/down timer 160 ms continuous, 0.5 down time multipier	
			After throttle blade pressure and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Speed Control's Preditcted Torque Request and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine oil temperature and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 233 ms continuous, 0.5 down time multipier	
			Desired throttle position greater than redundant calculation plus threshold	8.06 percent	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference of the rate limited pre-throttle pressure and its redundant calculation greater than threshold	0.06 kpa	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Throttle desired torque above desired torque plus threshold	202.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired filtered throttle torque exceeds the threshold plus the higher of desired throttle torque or modeled throttle torque	101.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Torque feedback proportional term is out of allowable range or its dual store copy does not match	High Threshold 101.00 Nm Low Threshold -101.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Torque feedback integral term magnitude or rate of change is out of allowable range or its dual store	High Threshold 94.69 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			copy do not match	Low Threshold -101.00 Nm Rate of change threshold 6.31 Nm/loop			down time multipier	
			Difference of Final Torque feedback proportional plus integral term and its redundant calculation is out of bounds given by threshold range	High Threshold 202.00 Nm Low Threshold - 202.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Difference of torque desired throttle area and	High Threshold	Ignition State	Accessory, run or crank	Up/down timer 475	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			its redundant calculation is out of bounds given by threshold range	1.06 % Low Threshold - 1.06 %			ms continuous, 0.5 down time multipier	
			Difference of torque model coefficients and its redundant calculation is out of bounds given by threshold range	High Threshold 0.0001639 Low Threshold - 0.0001639	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Difference of base friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 202.00 Nm Low Threshold - 202.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Accessory drive friction torque is out of bounds given by threshold range	High Threshold 101.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			AC friction torque is greater than commanded by AC control software or less than threshold limit	High Threshold 40.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Difference of Oil temperature delta friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 202.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold - 202.00 Nm				
			Generator friction torque is out of bounds given by threshold range	High Threshold 101.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Absolute difference between the Supercharger friction torque and its redundant calculation greater than threshold	101.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Filtered Torque error magnitude or its increase rate of change is out of	High Threshold 101.00		Engine speed >0rpm MAF, MAP and Baro DTCs are false	Up/down timer 475 ms continuous,	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			allowable range or its dual store copy do not match	Nm Low Threshold -101.00 Nm Rate of change threshold 6.31 Nm/loop			0.5 down time multipier	
			Torque error compensation is out of bounds given by threshold range	High Threshold 101.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Delta Torque Baro compensation is out of bounds given by threshold	High Threshold 15.39	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous,	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			range	Nm Low Threshold -25.41 Nm			0.5 down time multipier	
			1. Difference of reserve torque value and its redundant calculation exceed threshold OR 2. Reserve request does not agree with operating conditions or Difference of final predicted torque and its redundant calculation exeed threshold OR 3. Rate of change of reserve torque exceeds threshold, increasing direction only OR 4. Reserve engine torque above allowable capacity threshold	1. 100.00 Nm 2. N/A 3. 100.00 Nm 4. 100.00 Nm	3. & 4.: Ignition State	1. & 2.: Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 101.00 Nm 3. & 4.: Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Vacuum and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference of the calculated Intake Manifold Pressure during engine event versus during time event is greater than threshold	Table, f(Desired Engine Torque). See supporting tables: **P16F3_Delta MAP Threshold f(Desired Engine Torque)**		Engine speed >0rpm	Up/down timer 160 ms continuous, 0.5 down time multipier	
			Min. Axle Torque Capacity is greater than threshold	0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Driver Predicted Request is greater than its redundant calculation plus threshold OR	1,396.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Driver Predicted Request is less than its redundant calculation minus threshold					
			Cold Delta Friction Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Predicted torque for zero pedal determination is greater than calculated limit.	Table, f(Oil Temp, RPM). See supporting tables: **Speed Control External Load f(Oil Temp, RPM)** + 101.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Commanded Predicted	1 Nm	Ignition State	Accessory, run or crank	Up/down timer	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Axle Torque and its dual store do not match				475 ms continuous, 0.5 down time multipier	
			Steady State Estimated Engine Torque and its dual store are not equal	N/A		AFM not changing from Active to Inactive and preload torque not changing and one loop after React command Engine speed >0rpm	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Difference of Weighting factor for number of cylinders fueled and its redundant calculation is above threshold	0.26		Engine run flag = TRUE > 10.00 s	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Difference of minimum spark advance limit and its redundant calculation is out of bounds given by threshold range	15.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 160 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference of commanded spark advance and adjusted delivered is out of bounds given by threshold range	15.00 degrees		Engine speed >0rpm	Up/down timer 429 ms continuous, 0.5 down time multipier	
			Absolute difference between Estimated Engine Torque and its dual store are above a threshold	101.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Absolute difference between Estimated Engine Torque without reductions due to torque control and its dual store are above a threshold	101.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by threshold range	15.00 degrees		Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 101.00 Nm	Up/down timer 460 ms continuous, 0.5 down time multipier	
			Absolute difference of Engine Capacity Minimum Running Immediate Brake Torque Excluding Cylinder Sensitivity and its redundant calculation is out of bounds given by threshold range	101 Nm		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multipier	
			One step ahead calculation of air-per-cylinder greater than two step ahead calculation by threshold for time	Threshold: Dynamically calculated based on current engine conditions Fault Pending Threshold: 100		Engine speed > 550 rpm	Up/down timer 460 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				ms				
			Rate limited cruise axle torque request and its dual store do not match within a threshold	52.35 Nm	Ignition State	Accessory, run or crank	Up/down timer 163 ms continuous, 0.5 down time multipier	
			1. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its redundant calculation is out of bounds given by threshold range OR 2. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its dual store do not equal OR	1. 3.50 % 2. N/A 3. N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			3. Absolute difference of Calculated accelerator pedal position and its dual store do not equal					
			Commanded axle torque is greater than its redundant calculation by threshold	1,396.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded axle torque is less than its redundant calculation by threshold	2,094.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Preload timer and its redundant calculation do not equal	N/A	Ignition State	Accessory, run or crank AFM apps only	Up/down timer 160 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AC friction torque is greater than commanded by AC control software	40.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Engine Speed Lores Intake Firing (time based) calculation does not equal its redundant calculation	N/A		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference of the calculated spark offset for equivalence ratio and its redundant cacluation is greater than a threshold	15.00 degrees		Engine speed >0rpm	Up/down timer 160 ms continuous, 0.5 down time multipier	
			Transmission Torque Request cacluations do not equal their dual stores	N/A		Run or Crank = TRUE > 0.50 s	16 / 32 counts; 25.0msec/count	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of the predicted motor torque ACS and its redundant cacluation is greater than a threshold	0.01 Nm			Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Absolute difference of maximum throttle area and its redundant cacluation is greater than a threshold	15 mm2			Up/down timer 97 ms continuous, 0.5 down time multipier	
			Absolute difference of Desired TIAP and its redundant cacluation is greater than a threshold	5.00 kPa			Up/down timer 475 ms continuous, 0.5 down time multipier	
			Pedal learns and their redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Throttle learns and their redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired Throttle Position and its redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM/PCM Power Relay Request Signal Message Counter Incorrect	P16FF	This DTC monitors for an error in communication with the ECM Power Relay Request Signal	Communication of the Alive Rolling Count or Protection Value of the ECM Power Relay Request Signal over CAN bus is incorrect for out of total samples	>= 10.00 counts >= 16.00 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is avaialble >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 250ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transfer Case Control Module Transfer Case Command State Rationality - 4WD high or 4WD low command not 4wd high or 4WD low ratio	P17D4	The diagnostic monitor compares measured transfer case ratio to the transfer case control module commanded transfer case state. When the measured transfer case gear ratio is 4WD neutral ratio, while, the transfer case control module command state is 4WD high ratio or 4WD low ratio, the DTC is set. The 4WD neutral ratio regions are considered ratios outside the nominal 4WD high and nominal 4WD low ratios. The 4WD ratio is calculated as transmission output shaft speed divided by the transfer case output shaft speed, both speed are measured values based on speed sensors.	transfer case contol module transfer case command state AND measured transfer case ratio is NOT in 4WD low ratio window AND measured transfer case ratio is NOT in 4WD high window AND measured transfer case ratio is NOT in 4WD low ratio window AND measured transfer case ratio is NOT in 4WD high window OR vehicle is stopped: transfer case output shaft speed transmission output shaft speed vehicle stopped secondary parameter thresholds met (measured transfer case ratio = transmission output speed / transfer case output speed)	≠ 4WD neutral 4WD low ratio window ≤ 3.00 ≥ 2.40 4WD high ratio window ≤1.30 ≥ 0.70 ≥ 2.90 ≤ 2.00 ≥ 1.20 ≤ 0.80 ≤ 10.0 RPM ≥ 500.0 RPM	vehicle stopped: transmission output shaft speed engine torque engine speed accelerator pedal position accelerator pedal position brake pedal position transmssion gear is forward gear: transmission output shaft speed engine torque engine speed accelerator pedal position accelerator pedal position brake pedal position transmssion gear is reverse gear: transmission output shaft speed engine torque engine speed accelerator pedal position accelerator pedal position brake pedal position diagnsotic monitor enable PTO active engine power limited DTCs not fault active	≥ 500.0 RPM ≥ 100.0 Nm ≥ 300.0 RPM ≥ 5.0 % hysteresis high NOT ≤ 3.0 % hysteresis low ≤ 100.0 % ≥ 500.0 RPM ≥ -20.0 Nm ≥ 0.0 RPM ≥ 0.0 % hysteresis high NOT ≤ 0.0 % hysteresis low ≤ 100.0 % ≥ 500.0 RPM ≥ 90.0 Nm ≥ 300.0 PRM ≥ 6.0 % hysteresis high NOT ≤ 3.0 % hysteresis low ≤ 100.0 % = 1 Boolean = FALSE = FALSE CrankSensor_FA VehicleSpeedSensor_FA EngineTorqueEstInaccurate P057B, P057C, P057D,	fail time ≥ 10.50 seconds out of sample time ≥ 15.00 seconds update rate 12.5 milliseconds	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			update rate 12.5 milliseconds			P057E, P279A, P279B, P279C, P0502, P0503, P0722, P0723, P2160, P2161		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transfer Case Shift Pending	P185F	Detects an error in the ECM transfer case shift pending command value relative to the ECM transfer case command state. The transfer case executes a shift out of 4WD high, 4WD low, or 4WD neutral using the ECM engine torque control and TCM holding clutch control to manage the torque on the transfer case input shaft. As the transfer case is executing one of these shifts, the state is considered “shift pending”. It is not possible for the transfer case to command both a “shift pending” and a constant 4WD high or 4WD low or 4WD neutral state; if this condition occurs the DTC is set.	trasnfer case shift pending AND transfer case commnd state OR trasnfer case shift pending AND transfer case commnd state OR trasnfer case shift pending AND transfer case commnd state OR trasnfer case shift pending AND transfer case commnd state	= shift out of 4wd high = 4wd low = shift out of 4wd high = 4wd neutral = shift out of 4wd low = 4wd high = shift out of 4wd neutral = 4wd low	engine mode run run/crank voltage P2771 four wheel drive low circuit, fault fault active transfer case shift pending monitor delay time	= TRUE >= 9.00 volts = FALSE >= 5.00	>= 5 counts (one count per 25 milliseconds)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Park Assistance System Performance	P18CB	Determines if Park assist active bit from EBCM is valid	Speed Error - APA active ($1C6/$1C7) above a vehicle speed threshold	> 10.00	Active Communication with EBCM Power Mode Engine Running	Received serial data = Run = True	>= 6 failures out of 10 Performed every 12.5ms	Type C, No SVS
			OR Initialization Error - APA active ($1C6/$1C7) without an active torque request	APA active boolean transitions from False to True with Torque Intervention = No request	Status of traction in GMLAN message ($4E9) Run/Crank Active Ignition Voltage	= Traction Present > 0.50 seconds > 6.41 volts	>= 6 failures out of 10 Performed every 12.5ms	
			OR Exit Error - APA transitions to inactive during active torque request above a vehicle speed threshold	APA active boolean transitions from True to False with Torque Intervention <> No request when vehicle speed is > 1.00			When transition occurs, no number of samples Performed every 12.5ms	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Low–Bank 1	P2088	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between signal and controller ground	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit High – Bank 1	P2089	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between signal and controller power	System supply Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Too Lean Bank 1	P2096	Determines if the post catalyst O2 sensor based fuel control system is indicating a lean exhaust gas condition. If the lean condition is such that the control system utilizes all or most of its available high limit authority (high limit = 100% authority), then P2096 will set. The monitor can be calibrated to fail based on the Average Integral Offset % Authority, the Average Total Offset % Authority or both combined. The Average Total Offset metric consists of the average of the Integral Offset+ Proportional Offset. Note: When the post catalyst O2 voltage is too lean, the post catalyst O2 integral and proportional offset control is increased (positive % authority). This applies a lean bias to fuel control in an attempt to counteract the lean condition. A perfectly balanced control system (no rich or lean bias required) is represented by integral	The Average Integral Offset % Authority AND The Average Total Offset % Authority (Note: any value greater than or equal to +100% effectively nullifies the Average Total Offset % Authority criteria) High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18 % for >= 5.0 seconds AND the % Authority metric is approaching the failure threshold. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14 % for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.	>= 97.5 % >= 90.0 % If the P2096 is actively failing then the Average Integral Offset must be < 95.0 % and the Average Total Offset must be < 65.0 % for the diagnostic to report a pass.	The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration Ambient Air Pressure Engine AirFlow Intake Manifold Pressure Induction Air Temperature Start-up Coolant Temp. PTO Intrusive diag. fuel control Ethanol Estimation in Progress O2 Heater Learned Resistance Long Term Secondary Fuel Trim Enabled for (see "**Long Term Secondary Fuel Trim Enable Criteria**" in Supporting Tables) High Vapor Conditions Green Cat System Condition	 No No Yes Yes Yes >= 70 kPa >= 0.0 g/s <= 10,000.0 >= 0 kPa <= 256 >= -20 deg. C <= 200 >= -20 deg. C (or OBD Coolant Enable Criteria = TRUE) Not Active Not Active Not Active = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") >= 0.1 seconds Not Present = Not Valid, Green Cat System condition is considered valid until the	Frequency: Continuous Monitoring in 100ms loop. The Integral and Total Offset % Authority metrics are sampled every 100ms and an average is calculated every 40.0 seconds (400 samples) before comparing to their respective failure thresholds.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and proportional offset values of “0” (i.e. 0% authority) and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean).				accumulated air flow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is above 22 grams/sec.		
					No Fault Active for:	AmbientAirDefault AIR System FA Ethanol Composition Sensor FA ECT_Sensor_FA EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorFA CamSensorAnyLocationFA EvapEmissionSystem_FA EvapFlowDuringNonPurge_FA FuelTankPressureSnsrCkt_FA EvapPurgeSolenoidCircuit_FA EvapSmallLeak_FA EvapVentSolenoidCircuit_FA FuelInjectorCircuit_FA MAF_SensorFA MAF_SensorTFTKO MAP_SensorFA MAP_EngineVacuumStatus EngineMisfireDetected_FA A/F Imbalance Bank1 O2S_Bank_1_Sensor_1_FA		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					For the cells identified as enabled (i.e. those containing a "Yes" at the beginning of the Enable Conditions column), the minimum accumulated samples required before the fuel control metric is considered usable for that cell (1 sample = 100ms): Deceleration Idle Cruise Light Acceleration Heavy Acceleration (Note: A value in any of the above operating "cells" that is an order of magnitude (or more) higher than other cells is an indication that the diagnostic is not capable of diagnosing in that cell).	O2S_Bank_1_Sensor_2_FA 300 300 0 200 300		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Too Rich Bank 1	P2097	Determines if the post catalyst O2 sensor based fuel control system is indicating a rich exhaust gas condition. If the rich condition is such that the control system utilizes all or most of its available low limit authority (low limit = -100% authority), then P2097 will set. The monitor can be calibrated to fail based on the Average Integral Offset % Authority, the Average Total Offset % Authority or both combined. The Average Total Offset metric consists of the average of the Integral Offset+ Proportional Offset. Note: When the post catalyst O2 voltage is too rich, the post catalyst O2 integral and proportional offset control is decreased (negative % authority). This applies a lean bias to fuel control in an attempt to counteract the rich condition. A perfectly balanced control system (no rich or lean bias required) is represented by integral	The Average Integral Offset % Authority AND The Average Total Offset % Authority (Note: any value less than or equal to -100% effectively nullifies the Average Total Offset % Authority criteria) High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18 % for >= 5.0 seconds. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14 % for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.	<= -97.5 % <= -90.0 % If the P2097 is actively failing then the Average Integral Offset must be > -95.0 % and the Average Total Offset must be > -65.0 % for the diagnostic to report a pass.	Same as P2096	Same as P2096	Frequency: Continuous Monitoring in 100ms loop. The Integral and Total Offset % Authority metrics are sampled every 100ms and an average is calculated every 40.0 seconds (400 samples) before comparing to their respective failure thresholds.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and proportional offset values of "0" (i.e. 0% authority) and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean).						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Too Lean Bank 2	P2098	Determines if the post catalyst O2 sensor based fuel control system is indicating a lean exhaust gas condition. If the lean condition is such that the control system utilizes all or most of its available high limit authority (high limit = 100% authority), then P2098 will set. The monitor can be calibrated to fail based on the Average Integral Offset % Authority, the Average Total Offset % Authority or both combined. The Average Total Offset metric consists of the average of the Integral Offset+ Proportional Offset. Note: When the post catalyst O2 voltage is too lean, the post catalyst O2 integral and proportional offset control is increased (positive % authority). This applies a rich bias to fuel control in an attempt to counteract the lean condition. A perfectly balanced control system (no rich or lean bias required) is represented by integral	The Average Integral Offset % Authority AND The Average Total Offset % Authority (Note: any value greater than or equal to +100% effectively nullifies the Average Total Offset % Authority criteria) High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18 % for >= 5.0 seconds AND the % Authority metric is approaching the failure threshold. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14 % for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.	>= 97.5 % >= 90.0 % If the P2098 is actively failing then the Average Integral Offset must be < 95.0 % and the Average Total Offset must be < 65.0 % for the diagnostic to report a pass.	The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration Ambient Air Pressure Engine AirFlow Intake Manifold Pressure Induction Air Temperature Start-up Coolant Temp. PTO Intrusive diag. fuel control Ethanol Estimation in Progress O2 Heater Learned Resistance Long Term Secondary Fuel Trim Enabled for (see "Long Term Secondary Fuel Trim Enable Criteria" in Supporting Tables) High Vapor Conditions Green Cat System Condition	 No No Yes Yes Yes >= 70 kPa >= 0.0 g/s <= 10,000.0 >= 0 kPa <= 256 >= -20 deg. C <= 200 >= -20 deg. C (or OBD Coolant Enable Criteria = TRUE) Not Active Not Active Not Active = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") >= 0.1 seconds Not Present = Not Valid, Green Cat System condition is considered valid until the	Frequency: Continuous Monitoring in 100ms loop. The Integral and Total Offset % Authority metrics are sampled every 100ms and an average is calculated every 40.0 seconds (400 samples) before comparing to their respective failure thresholds.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and proportional offset values of “0” (i.e. 0% authority) and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean).				accumulated air flow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is above 22 grams/sec. AmbientAirDefault AIR System FA Ethanol Composition Sensor FA ECT_Sensor_FA EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorFA CamSensorAnyLocationFA EvapEmissionSystem_FA EvapFlowDuringNonPurge_FA FuelTankPressureSnsrCkt_FA EvapPurgeSolenoidCircuit_FA EvapSmallLeak_FA EvapVentSolenoidCircuit_FA FuelInjectorCircuit_FA MAF_SensorFA MAF_SensorTFTKO MAP_SensorFA MAP_EngineVacuumStatus EngineMisfireDetected_FA A/F Imbalance Bank2 O2S_Bank_2_Sensor_1_FA	No Fault Active for:		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					For the cells identified as enabled (i.e. those containing a "Yes" above), the minimum accumulated samples required before the fuel control metric is considered usable for that cell (1 sample = 100ms): Deceleration Idle Cruise Light Acceleration Heavy Acceleration Note: A value in any of the above operating "cells" that is an order of magnitude (or more) higher than other cells is an indication that the diagnostic is not capable of diagnosing in that cell).	O2S_Bank_2_Sensor_2_FA 300 300 0 200 300		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Too Rich Bank 2	P2099	Determines if the post catalyst O2 sensor based fuel control system is indicating a rich exhaust gas condition. If the rich condition is such that the control system utilizes all or most of its available low limit authority (low limit = -100% authority), then P2099 will set. The monitor can be calibrated to fail based on the Average Integral Offset % Authority, the Average Total Offset % Authority or both combined. The Average Total Offset metric consists of the average of the Integral Offset+ Proportional Offset. Note: When the post catalyst O2 voltage is too rich, the post catalyst O2 integral and proportional offset control is decreased (negative % authority). This applies a lean bias to fuel control in an attempt to counteract the rich condition. A perfectly balanced control system (no rich or lean bias required) is represented by integral	The Average Integral Offset % Authority AND The Average Total Offset % Authority (Note: any value less than or equal to -100% effectively nullifies the Average Total Offset % Authority criteria) High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18 % for >= 5.0 seconds. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14 % for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.	>= -97.5 % . >= -90.0 % If the P2099 is actively failing then the Average Integral Offset must be < -95.0 % and the Average Total Offset must be < -65.0 % for the diagnostic to report a pass.	Same as P2098	Same as P2098	Frequency: Continuous Monitoring in 100ms loop. The Integral and Total Offset % Authority metrics are sampled every 100ms and an average is calculated every 40.0 seconds (400 samples) before comparing to their respective failure thresholds.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and proportional offset values of "0" (i.e. 0% authority) and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean).						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Throttle Actuator Position Performance	P2101	1) Detect a throttle positioning error. This is determined if the difference between measured throttle position and modeled throttle position is greater than a threshold or less than a threshold. This diagnostic only runs when the engine is running and the ignition voltage is high enough and there is not an ignition votage failure and the throttle position minimum learn is not active and the throttle is being controlled 2) Throttle control is driving the throttle in the incorrect direction. This is determined if the throttle position is greater than a threshold percent and the powertrain relay voltage is high enough and the throttle position minimum learn is active.	Difference between measured throttle position and modeled position, (modeled = MAX (Commanded vs. Commanded Filtered)) > OR Difference between modeled position (modeled = MIN (Commanded vs. Commanded Filtered)) and measured throttle position >	8.06 percent 8.06 percent	TPS minimum learn is not active AND Powertrain Relay Contact1 Fault is FALSE (no P1682 fault) AND Throttle Control is not in Service or DVT control Throttle is being Controlled AND ((Engine Running AND Run/Crank Voltage) OR Run Crank Voltage)	> 5.50 Volts > 8.41 Volts	15 counts; 12.5 ms/count in the primary processor	Type A, 1 Trips
			Throttle Position >	36.00 percent	TPS minimum learn active AND Powertrain Relay Contact1 Fault is FALSE (no P1682 fault) AND Throttle Control is not in Service or DVT control	= TRUE	11 counts; 12.5 ms/count in the primary processor	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Return to Default Performance	P2119	Throttle unable to return to default throttle position after de-energizing ETC motor.	(Normalized TPS1 percent Vref > AND Normailzed TPS2 percent Vref > On the main processor) OR (Normalized TPS1 percent Vref < AND Normailzed TPS2 percent Vref < On the main processor)	1.7560 % Vref 1.7590 % Vref 1.4340 % Vref 1.4310 % Vref	Throttle de-energized due to one of the following conditions: Powerup Default Learn OR Default Throttle Authority OR PT Relay Voltage OR Main System Shutdown OR Battery Saver Active OR (Powertrain Relay On AND Run/Crank Active)	 = TRUE = TRUE < 5.500 Volts = TRUE = TRUE = FALSE = FALSE	0.4969 s if ETC motor command is STOP (when Default Throttle Authority or Main System Shutdown is causing Throttle de-energize) 5.0000 s if ETC motor command is not STOP	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Lo	P2122	Detects a continuous or intermittent short low or open in the APP sensor #1 by monitoring the APP1 sensor percent Vref and failing the diagnostic when the APP1 percent Vref is too low. This diagnostic only runs when battery voltage is high enough. Detects a continuous or intermittent short low or open in the APP sensor #1 on the Main processor.	APP1 percent Vref	< 0.4625 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P06A3	19 / 39 counts; or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Hi	P2123	Detects a continuous or intermittent short high in the APP sensor #1 by monitoring the APP1 sensor percent Vref and failing the diagnostic when the APP1 percent Vref is too high. This diagnostic only runs when battery voltage is high enough. Detect a continuous or intermittent short high in the APP sensor #1 on the Main processor.	APP1 percent Vref >	4.7500 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P06A3	19 / 39 counts; or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Lo	P2127	Detects a continuous or intermittent short low or open in the APP sensor #2 by monitoring the APP2 sensor percent Vref and failing the diagnostic when the APP2 percent Vref is too low. This diagnostic only runs when battery voltage is high enough. Detects a continuous or intermittent short low or open in the APP sensor #2 on the Main processor.	APP2 percent Vref <	0.3250 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P0697	19 / 39 counts; or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Hi	P2128	Detects a continuous or intermittent short high in the APP sensor #2 by monitoring the APP2 sensor percent Vref and failing the diagnostic when the APP2 percent Vref is too high. This diagnostic only runs when battery voltage is high enough. Detect a continuous or intermittent short high in the APP sensor #2 on the Main processor.	APP2 percent Vref >	2.6000 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P0697	19 / 39 counts; or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position (TP) Sensor 1-2 Correlation	P2135	Detect a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor. 1.) The diagnostic monitors the difference in position between TPS1 and the TPS2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. 2.) The diagnostic monitors the difference in reference voltage between normalized min TPS1 and the normalized min TPS2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. Detects a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor	Difference between TPS1 displaced and TPS2 displaced >	6.797 % offset at min. throttle position with a linear threshold to 9.720 % at max. throttle position	Run/Crank voltage No TPS sensor faults No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts (P0122, P0123, P0222, P0223) P06A3	79 / 159 counts; or 58 counts continuous; 3.125 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min TPS1) and (normalized min TPS2) >	5.000 % Vref	Run/Crank voltage No TPS sensor faults No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts (P0122, P0123, P0222, P0223) P06A3	79 / 159 counts; or 58 counts continuous; 3.125 ms/count in the main processor	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1-2 Correlation	P2138	Detect a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor. 1.) The diagnostic monitors the difference in position between APP1 and the APP2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. 2.) The diagnostic also monitors the difference in reference voltage between normalized min APP1 and the normalized min APP2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. Detects a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor	Difference between APP1 displaced and APP2 displaced >	5.000 % offset at min. pedal position with a linear threshold to 10.001 % at max. pedal position	Run/Crank voltage No APP sensor faults No 5V reference errors or faulst for # 3 & # 4 5V reference circuits	> 6.41 Volts (P2122, P2123,P2127, P2128) (P06A3, P0697)	19 / 39 counts intermittent; or 15 counts continuous, 12.5 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min APP1) and (normalized min APP2) >	3.500 % Vref	Run/Crank voltage No APP sensor faults No 5V reference errors or faulst for # 3 & # 4 5V reference circuits	> 6.41 Volts (P2122, P2123,P2127, P2128) (P06A3, P0697)	19 / 39 counts intermittent; or 15 counts continuous, 12.5 ms/count in the main processor	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 high side circuit shorted to ground	P2147	Controller specific output driver circuit diagnoses Injector 1 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 high side circuit shorted to power	P2148	Controller specific output driver circuit diagnoses Injector 1 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 high side circuit shorted to ground	P2150	Controller specific output driver circuit diagnoses Injector 2 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 high side circuit shorted to power	P2151	Controller specific output driver circuit diagnoses Injector 2 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	 <= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 high side circuit shorted to ground	P2153	Controller specific output driver circuit diagnoses Injector 3 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 high side circuit shorted to power	P2154	Controller specific output driver circuit diagnoses Injector 3 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 high side circuit shorted to ground	P2156	Controller specific output driver circuit diagnoses Injector 4 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 high side circuit shorted to power	P2157	Controller specific output driver circuit diagnoses Injector 4 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Vehicle Speed – Output Shaft Speed Correlation	P215B	Detect invalid vehicle speed source. This failure is set by two different conditions. Either the absolute difference between wheel speed vehicle speed and TOS vehicle speed is too high, or secure vehicle speed is not available.	The absolute difference between wheel speed vehicle speed and TOS vehicle speed greater than > OR Secure vehicle speed source is unavailable	6.21 mph		Time since first CAN activity > 0.5000 s Secure vehicle speed source is TOS vehicle speed or wheel speed vehicle speed Trans engaged state is equal to engaged.	400 / 800 counts for wheel speed correlation or 400 / 800 counts for TOS correlation; 25ms/count	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 high side circuit shorted to ground	P216B	Controller specific output driver circuit diagnoses Injector 5 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 high side circuit shorted to power	P216C	Controller specific output driver circuit diagnoses Injector 5 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 high side circuit shorted to ground	P216E	Controller specific output driver circuit diagnoses Injector 6 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 high side circuit shorted to power	P216F	Controller specific output driver circuit diagnoses Injector 6 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Minimum Throttle Position Not Learned	P2176	Detect when the throttle position minimum learn on the main processor is not learned. This diagnostic detects this by monitoring if the throttle position is greater than a threshold and the number of learn attempts is greater than a threshold. This diagnostic only runs when the battery voltage is high enough and the throttle position minimum learn is active. Throttle position sensors were not in the minmum learn window after multiple attempts to learn the minimum.	During TPS min learn on the Main processor, TPS percent Vref > AND Number of learn attempts >	0.5740 % Vref 10 counts	Run/Crank voltage TPS minimum learn is active No previous TPS min learn values stored in long term memory	> 6.41 Volts = TRUE	2.0 secs	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 high side circuit shorted to ground	P217B	Controller specific output driver circuit diagnoses Injector 7 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 high side circuit shorted to power	P217C	Controller specific output driver circuit diagnoses Injector 7 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 8 high side circuit shorted to ground	P217E	Controller specific output driver circuit diagnoses Injector 8 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 8 high side circuit shorted to power	P217F	Controller specific output driver circuit diagnoses Injector 7 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 1 / 2 Correlation	P2199	Detects when the Intake Air Temperature (IAT) sensor and IAT2 sensor values do not correlate with each other. These two temperature sensors are both in the induction system, although they do have different sensor time constants and different positional relationships with components that produce heat. If these two temperature values differ by a large enough amount, the Intake Air Temperature 1 / 2 Correlation Diagnostic will fail.	ABS (IAT - IAT2)	> 55.0 deg C	Powertrain Relay Voltage for a time If application has a LIN MAF: LIN Communications established with MAF No Active DTCs:	>= 11.0 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Bank 1 Air-Fuel Ratio Imbalance	P219A	This monitor determines if there is an Air Fuel Imbalance in the fueling system for a cylinder on Bank 1. Detection is based on a the pre catalyst oxygen sensor voltage. The pre catalyst O2 voltage is used to generate a variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to the air-fuel ratio imbalance (variance is higher with an imbalance than without). The observed Variance is dependent on engine speed and load and is normalized by comparing it to a known "good system" result for that speed and load, and generating a Ratio metric. The Ratio metric is calculated by selecting the appropriate threshold calibration from a 17x17 table (see Supporting Table	Standard Mode Filtered Ratio Optional Mode Filtered Ratio For this program the Optional Mode is NOT used	> 0.80 If the diagnostic has reported a failure on the prior trip, the Filtered Ratio must fall below 0.21 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing. > 0.50 If the diagnostic has reported a failure on the prior trip, the Optional Mode Filtered Ratio must fall below 0.25 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing.	System Voltage Fuel Level Engine Coolant Temperature Cumulative engine run time Diagnostic enabled at Idle (regardless of other operating conditions) Engine speed range Engine speed delta during a short term sample period Mass Airflow (MAF) range Cumulative delta MAF during a short term sample period Filtered MAF delta between samples Note: first order lag filter coefficient applied to MAF = 0.050 Air Per Cylinder (APC) APC delta during short term sample period	no lower than 10.0 Volts for more than 0.2 seconds > 10.0 percent AND no fuel level sensor fault > -20 deg. C (or OBD Coolant Enable Criteria = TRUE) > 0.0 seconds No 800 to 3,750 RPM < 200 RPM 5 to 1,000 g/s < 5 g/s < 0.70 g/s 100 to 720 mg/cylinder < 90 mg/cylinder	Minimum of 1 test per trip, up to 4 tests per trip during RSR or FIR. The front O2 sensor voltage is sampled once per cylinder event. Therefore, the time required to complete a single test (when all enable conditions are met) decreases as engine speed increases. For example, 10.50 seconds of data is required at 1000 rpm while double this time is required at 500 rpm and half this time is required at 2000 rpm. This data is collected only when enable conditions are met, and as such significantly more operating time is required than is indicated above. Generally, a report will be	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		P219A Variance Threshold Bank1 Table) and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table (see Supporting Table **P219A Normalizer Bank1 Table**). This quotient is then multiplied by a quality factor calibration from a 17 x 17 table (see Supporting Table **P219A Quality Factor Bank1 Table**) . This result is referred to as the Ratio. Note that the quality factor ranges between 0 and 1 and represents robustness to false diagnosis in the current operating region. Regions with low quality factors are not used. Finally, a EWMA filter is applied to the Ratio metric to generate the Filtered Ratio malfunction criteria metric. Generally, a normal system will result in a negative Filtered Ratio while a failing system will result in a positive Filtered			Filtered APC delta between samples Note: first order lag filter coefficient applied to APC = 0.050 Spark Advance Throttle Area (percent of max) Intake Cam Phaser Angle Exhaust Cam Phaser Angle --- Electronic Waste Gate (eWG) present If eWG = yes then Waste Gate Position Intrusive eWG Feature If intrusive Waste Gate positin is enabled then the electronic Waste Gate will be commanded to the following range when the other enable conditions have been met. Intrusive Waste Gate Position Min Intrusive Waste Gate Position Max --- Active Fuel Management Firing Fraction	< 5.00 percent 5 to 55 degrees 0 to 200 percent 0 to 25 degrees 0 to 25 degrees --- No 0.0 to 100.0 Disabled 0.0 101.0 --- 0.99 to 1.10	made within 5 minutes of operation. For RSR or FIR, 8 tests must complete before the diagnostic can report.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Ratio. The range of the Filtered Ratio metric is application specific since both the emissions sensitivity and relationship between imbalance and the Variance metric are application specific. Some applications may need to command a unique cam phaser value before performing the above calculations since cam phasing has been shown to have an impact on overall signal quality. This application Does Not Use his feature. For programs using Active Fuel Management or Multiple Cam profiles a secondary Imbalance Ratio can be calculated while in the secondary operating modes. This secondary ratio is an optional calculation and is labeled as the "Optional Mode Ratio". The Optional Mode Ratio is calculated the same as explained above with the following supporting			if the Optional Mode is enabled (see Malfunction Criteria) Active Fuel Management Firing fraction for Optional Mode calculations Intrusive Firing Fraction during Fast Initial Response or Rapid Step Response If the intrusive Firing Fraction feature is enabled the Active Fuel Management firing fraction will be forced to a value above this threshold when in Fast Initial Response or in Rapid Step Response. ---------- For programs using multi-step cam profiles: High Lift Cam Profile will use: Low Lift Cam Profile will use: Quality Factor (QF) QF calibrations are located in a 17x17 lookup table versus engine speed and load (see Supporting Table	0.99 to 0.01 Disabled >= 0.99 ---------- Standard Mode Filtered Ratio Optional Mode Filtered Ratio >= 0.99		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		tables: **P219A Variance Threshold Bank1 Opt Table** , **P219A Normalizer Bank1 Opt Table** , and **P219A Quality Factor Bank1 Opt Table**			**P219A Quality Factor Bank1 Table**). QF values less than “1” indicate that we don’t have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data. Fuel Control Status Closed Loop and Long Term FT Enabled for: Device Control AIR pump CASE learn EGR EVAP Engine Over Speed Protection Idle speed control PTO Injector base pulse width O2 learned htr resistance Rapid Step Response (RSR): RSR will trigger if the Ratio result from the last test is AND it exceeds the last Filtered ratio by	>= 1.2 seconds (Please see "**Closed Loop Enable Clarification**" and "**Long Term FT Enable Criteria**" in Supporting Tables) Not active Not on Not active Not intrusive Not intrusive Not Active Normal Not Active Above min pulse limit = Valid (the O2 heater resistance has learned since NVM reset) >= 0.25 >= 0.30		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Once triggered, the filtered ratio is reset to: Fast Initial Response (FIR): FIR will trigger when an NVM reset or code clear occurs. Once triggered, the filtered ratio is reset to: No Fault Active for:	0.10 0.10 EngineMisfireDetected_FA MAP_SensorFA MAF_SensorFA ECT_Sensor_FA TPS_ThrottleAuthorityDefaulted FuelInjectorCircuit_FA AIR System FA EvapExcessPurgePsbl_FA CamSensorAnyLocationFA FuelTrimSystemB1_FA O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA WRAF_Bank_1_FA		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Bank 2 Air-Fuel Ratio Imbalance	P219B	This monitor determines if there is an Air Fuel Imbalance in the fueling system for a cylinder on a Bank 2. Detection is based on a the pre catalyst oxygen sensor voltage. The pre catalyst O2 voltage is used to generate a variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to the air-fuel ratio imbalance (variance is higher with an imbalance than without). The observed Variance is dependant on engine speed and load and is normalized by comparing it to a known "good system" result for that speed and load, and generating a Ratio metric. The Ratio metric is calculated by selecting the appropriate threshold calibration from a 17x17 table (see Supporting Table	Standard Mode Filtered Ratio Optional Mode Filtered Ratio For this program the Optional Mode is NOT used	> 0.80 If the diagnostic has reported a failure on the prior trip, the Filtered Ratio must fall below 0.60 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing. > 0.50 If the diagnostic has reported a failure on the prior trip, the Filtered Ratio must fall below 0.25 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing	System Voltage Fuel Level Engine Coolant Temperature Cumulative engine run time Diagnostic enabled at Idle (regardless of other operating conditions) Engine speed range Engine speed delta during a short term sample period Mass Airflow (MAF) range Cumulative delta MAF during a short term sample period Filtered MAF delta between samples Note: first order lag filter coefficient applied to MAF = 0.050 Air Per Cylinder (APC) APC delta during short term sample period	no lower than 10.0 Volts for more than 0.2 seconds > 10.0 percent AND no fuel level sensor fault > -20 deg. C (or OBD Coolant Enable Criteria = TRUE) > 0.0 seconds No 800 to 3,750 RPM < 200 RPM 5 to 1,000 g/s < 5 g/s < 0.70 g/s 100 to 720 mg/cylinder < 90 mg/cylinder	Minimum of 1 test per trip, up to 4 tests per trip during RSR or FIR. The front O2 sensor voltage is sampled once per cylinder event. Therefore, the time required to complete a single test (when all enable conditions are met) decreases as engine speed increases. For example, 10.50 seconds of data is required at 1000 rpm while double this time is required at 500 rpm and half this time is required at 2000 rpm. This data is collected only when enable conditions are met, and as such significantly more operating time is required than is indicated above. Generally, a report will be made within 5	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		P219B Variance Threshold Bank2 Table) and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table (see Supporting Table **P219B Normalizer Bank2 Table**) This quotient is then multiplied by a quality factor calibration from a 17 x 17 table (see Supporting Table **P219B Quality Factor Bank2 Table**) . This result is referred to as the Ratio. Note that the quality factor ranges between 0 and 1 and represents robustness to false diagnosis in the current operating region. Regions with low quality factors are not used. Finally, a EWMA filter is applied to the Ratio metric to generate the Filtered Ratio malfunction criteria metric. Generally, a normal system will result in a negative Filtered Ratio while a failing system will result in a positive Filtered			Filtered APC delta between samples Note: first order lag filter coefficient applied to APC = 0.050 Spark Advance Throttle Area (percent of max) Intake Cam Phaser Angle Exhaust Cam Phaser Angle ---------- Electronic Waste Gate (eWG) present If eWG = yes then Waste Gate Position Intrusive eWG Feature If intrusive Waste Gate positin is enabled then the electronic Waste Gate will be commanded to the following range when the other enable conditions have been met. Intrusive Waste Gate Position Min Intrusive Waste Gate Position Max ----------	< 5.00 percent 5 to 55 degrees 0 to 200 percent 0 to 25 degrees 0 to 25 degrees ---------- No 0.0 to 100.0 Disabled 0.0 101.0 ----------	minutes of operation. For RSR or FIR, 8 tests must complete before the diagnostic can report.See P219A info	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Ratio. The range of the Filtered Ratio metric is application specific since both the emissions sensitivity and relationship between imbalance and the Variance metric are application specific. Some applications may need to command a unique cam phaser value before performing the above calculations since cam phasing has been shown to have an impact on overall signal quality. This application Does Not Use this feature. For programs using Active Fuel Management or Multiple Cam profiles a secondary Imbalance Ratio can be calculated while in the secondary operating modes. This secondary ratio is an optional calculation and is labeled as the "Optional Mode Ratio". The Optional Mode Ratio is calculated the same as explained above with the following supporting			Active Fuel Management Firing Fraction if the Optional Mode is enabled (see Malfunction Criteria) Active Fuel Management Firing fraction for Optional Mode calculations Intrusive Firing Fraction during Fast Initial Response or Rapid Step Response If the intrusive Firing Fraction feature is enabled the Active Fuel Management firing fraction will be forced to a value above this threshold when in Fast Initial Response or in Rapid Step Response. ---------- For programs using multi-step cam profiles: High Lift Cam Profile will use: Low Lift Cam Profile will use: Quality Factor (QF) QF calibrations are located in a 17x17 lookup table versus engine speed	0.99 to 1.10 0.99 to 0.01 Disabled >= 0.99 ---------- Standard Mode Filtered Ratio Optional Mode Filtered Ratio >= 0.99		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		tables: **P219B Variance Threshold Bank2 Opt Table** , **P219B Normalizer Bank2 Opt Table** , and **P219B Quality Factor Bank2 Table**			and load (Supporting Table **P219B Quality Factor Bank2 Table**). QF values less than “1” indicate that we don’t have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data. Fuel Control Status Closed Loop and Long Term FT Enabled for: Device Control AIR pump CASE learn EGR EVAP Engine Over Speed Protection Idle speed control PTO Injector base pulse width O2 learned htr resistance Rapid Step Response (RSR): RSR will trigger if the Ratio result from the last test is AND it exceeds the last	 >= 1.2 seconds (Please see "Closed Loop Enable Clarification" and "Long Term FT Enable Criteria" in Supporting Tables) Not active Not on Not active Not intrusive Not intrusive Not Active Normal Not Active Above min pulse limit = Valid (the O2 heater resistance has learned since NVM reset) >= 0.40 >= 0.45		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Filtered ratio by Once triggered, the filtered ratio is reset to: Fast Initial Response (FIR): FIR will trigger when an NVM reset or code clear occurs. Once triggered, the filtered ratio is reset to: No Fault Active for:	 0.20 0.20 EngineMisfireDetected_FA MAP_SensorFA MAF_SensorFA ECT_Sensor_FA TPS_ThrottleAuthorityDefaulted FuelInjectorCircuit_FA AIR System FA EvapExcessPurgePsbl_FA CamSensorAnyLocationFA FuelTrimSystemB2_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_2_FA WRAF_Bank_2_FA		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Performance (naturally aspirated)	P2227	Detects a performance failure in the Barometric Pressure (BARO) sensor, such as when a BARO value is stuck in range. If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The BARO sensor value is checked to see if it is within the normal expected atmospheric pressure range. If it is not, then the BARO performance diagnostic will fail. When the engine is running, there is an estimate of barometric pressure that is determined with the Manifold Pressure (MAP) sensor, throttle position, engine air flow and engine speed. If the BARO value from the sensor is not similar to this barometric pressure estimate, then the BARO performance diagnostic will fail.	**Engine Running:** Difference between Baro Pressure reading and Estimated Baro when distance since last Estimated Baro update OR Difference between Baro Pressure reading and Estimated Baro when distance since last Estimated Baro update	 > 15.0 kPa <= 0.06 miles > 20.0 kPa > 0.06 miles	No Active DTCs: The "Engine Running" case of the P2227 monitor does not execute on applications with LIN MAF. The P10BC monitor is executed instead.	AmbPresSnsrCktFA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips
			Engine Not Rotating: Barometric Pressure OR Barometric Pressure	 < 50.0 kPa > 115.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating If application has a LIN MAF: LIN Communications established with MAF No Active DTCs: No Pending DTCs:	 > 5.0 seconds EngineModeNotRunTimerError MAP_SensorCircuitFA AAP_SnsrCktFA AAP_LIN1_SnsrCktFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP_LIN1_SnsrCktFP	4 failures out of 5 samples 1 sample every 12.5 msec for applications without LIN MAF 1 sample every 25 msec for applications with LIN MAF	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (applications with LIN MAF)	P2228	Detects an eroneously low value being reported over the LIN serial connection from the BARO sensor. The diagnostic monitors the BARO sensor pressure output and fails the diagnostic when the pressure is too low. The BARO sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure. The BARO pressure value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.	BARO Pressure	< 50.0 kPa	LIN Communications established with MAF		160 failures out of 200 samples 1 sample every 25 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (applications with LIN MAF)	P2229	Detects an eroneously high value being reported over the LIN serial connection from the BARO sensor. The diagnostic monitors the BARO sensor pressure output and fails the diagnostic when the pressure is too high. The BARO sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure. The BARO pressure value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.	BARO Pressure	> 115.0 kPa	LIN Communications established with MAF		160 failures out of 200 samples 1 sample every 25 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Intermittent (applications with LIN MAF)	P2230	Detects a noisy or erratic signal in the barometric pressure (BARO) circuit by monitoring the BARO sensor and failing the diagnostic when the BARO signal has a noisier output than is expected. When the value of BARO in kilopascals (kPa) is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of BARO readings. The result of this summation is called a “string length”. Since the BARO signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic BARO signal. The diagnostic will fail if the string length is too high.	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current BARO reading - BARO reading from 25 milliseconds previous)	> 100 kPa 80 consecutive BARO readings	LIN Communications established with MAF		4 failures out of 5 samples Each sample takes 2.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Lean Bank 1 Sensor 2	P2270	The P2270 diagnostic is the first in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, & P013B. This DTC determines if the secondary O2 sensor is stuck in a normal lean voltage range and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow. This fault is set if the secondary O2 sensor does not achieve the required rich voltage before the accumulated mass air flow threshold is reached.	Post O2 sensor signal AND The Accumulated mass air flow monitored during the Stuck Lean Voltage Test	< 825 mvolts > 131 grams	No Active DTC's B1S2 DTC's Not active this key cycle System Voltage Learned heater resistance Green O2S Condition	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_ 1_TFTKO O2S_Bank_ 2_TFTKO P013A, P013B, P013E, P013F, P2270 or P2271 > 11.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow	Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						is above 22.0 grams/sec.		
					Low Fuel Condition	= False		
					Only when FuelLevelDataFault	= False		
					Pedal position	≤ 2.0 %		
					Engine Airflow	4.0 ≤ gps ≤ 20.0		
					Closed loop integral	0.75 ≤ C/L Int ≤ 1.08		
					Closed Loop Active	= TRUE (Please see "**Closed Loop Enable Clarification**" in Supporting Tables).		
					Evap	not in control of purge		
					Ethanol Estimation in Progress	= Not Active (Please see "**Ethanol Estimation in Progress**" in Supporting Tables).		
					Post fuel cell	= Enabled, refer to **Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests** for additional info.		
					Crankshaft Torque	< 125.0 Nm		
					EGR Intrusive diagnostic	= not active		
					All post sensor heater delays	= not active		
					O2S Heater (post sensor) on Time	≥ 60.0 sec		
					Transmission Temp	≥ -40.0 ºC		
					Predicted Catalyst temp	600 ≤ ºC ≤ 900		
					Fuel State	= DFCO possible		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					========== All of the above met for at least 0.0 seconds, and then check the following Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) ========== All of the above met for at least 0.8 seconds, and then the Force Cat Rich intrusive stage is requested. ========== During Stuck Lean test the following must stay TRUE or the test will abort: Commanded Fuel Crankshaft Torque	========== 1,000 ≤ RPM ≤ 2,500 950 ≤ RPM ≤ 2,550 39.8 ≤ MPH ≤ 74.6 37.3 ≤ MPH ≤ 77.7 0.95 ≤ EQR ≤ 1.10 < 125.0 Nm		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Rich Bank 1 Sensor 2	P2271	The P2271 diagnostic is the fourth in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, & P013B. This DTC determines if the secondary O2 sensor is stuck in a normal rich voltage range and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow. This fault is set if the secondary O2 sensor does not achieve the required lean voltage before the accumulated mass air flow threshold is reached.	Post O2 sensor signal AND The Accumulated mass air flow monitored during the Stuck Rich Voltage Test	> 100 mvolts > 10.0 grams	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance Green O2S Condition	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_ 1_TFTKO O2S_Bank_ 2_TFTKO P013A, P013B, P013E, P013F or P2270 > 11.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow	Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						is above 22.0 grams/sec.		
					Low Fuel Condition Only when FuelLevelDataFault	= False = False		
					Fuel State	= DFCO possible		
					DTC's Passed	= P2270 = P013E = P013A		
					========== After above conditions are met: DFCO mode is continued (w/o driver initiated pedal input).	==========		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Lean Bank 2 Sensor 2	P2272	The P2272 diagnostic is the first in a sequence of six intrusive secondary O2 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, & P013D. This DTC determines if the secondary O2 sensor is stuck in a normal lean voltage range and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow. This fault is set if the secondary O2 sensor does not achieve the required rich voltage before the accumulated mass air flow threshold is reached.	Post O2 sensor signal AND The Accumulated mass air flow monitored during the Stuck Lean Voltage Test	< 825 mvolts > 131 grams.	No Active DTC's B2S2 DTC's Not Active this key cycle System Voltage Learned heater resistance Green O2S Condition	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_ 1_TFTKO O2S_Bank_ 2_TFTKO P013C, P013D, P014A, P014B, P2272 or P2273 > 11.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S2, B2S2 in Supporting Tables tab. Airflow accumulation is only enabled when airflow	Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						is above 22.0 grams/sec.		
					Low Fuel Condition	= False		
					Only when FuelLevelDataFault	= False		
					Pedal position	≤ 2.0 %		
					Engine Airflow	4.0 ≤ gps ≤ 20.0		
					Closed loop integral	0.75 ≤ C/L Int ≤ 1.08		
					Closed Loop Active	= TRUE (Please see "**Closed Loop Enable Clarification**" in Supporting Tables).		
					Evap	not in control of purge		
					Ethanol Estimation in Progress	= Not Active (Please see "**Ethanol Estimation in Progress**" in Supporting Tables).		
					Post fuel cell	= Enabled, refer to **Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests** for additional info.		
					Crankshaft Torque	< 125.0 Nm		
					EGR Intrusive diagnostic	= not active		
					All post sensor heater delays	= not active		
					O2S Heater (post sensor) on Time	>= 60.0 sec		
					Transmission Temp	≥ -40.0 ºC		
					Predicted Catalyst temp	600 ≤ ºC ≤ 900		
					Fuel State	= DFCO possible		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					========== All of the above met for at least 0.0 seconds, and then check the following Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) ========== All of the above met for at least 0.8 seconds, and then the Force Cat Rich intrusive stage is requested. ========== During Stuck Lean test the following must stay TRUE or the test will abort: Commanded Fuel Crankshaft Torque	========== 1,000 ≤ RPM ≤ 2,500 950 ≤ RPM ≤ 2,550 39.8 ≤ MPH ≤ 74.6 37.3 ≤ MPH ≤ 77.7 0.95 ≤ EQR ≤ 1.10 < 125.0 Nm		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Rich Bank 2 Sensor 2	P2273	The P2273 diagnostic is the fourth in a sequence of six intrusive secondary O2 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, & P013D. This DTC determines if the secondary O2 sensor is stuck in a normal rich voltage range and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow. This fault is set if the secondary O2 sensor does not achieve the required lean voltage before the accumulated mass air flow threshold is reached.	Post O2 sensor signal AND The Accumulated mass air flow monitored during the Stuck Rich Voltage Test	> 100 mvolts > 10.0 grams.	No Active DTC's B2S2 DTC's Not Active this key cycle System Voltage Learned heater resistance Green O2S Condition	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_ 1_TFTKO O2S_Bank_ 2_TFTKO P013C, P013D, P014A, P014B or P2272 > 11.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S2, B2S2 in Supporting Tables tab. Airflow accumulation is only enabled when airflow	Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						is above 22.0 grams/sec.		
					Low Fuel Condition Only when FuelLevelDataFault Fuel State DTC's Passed ========== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	= False = False = DFCO possible = P2272 = P014A = P013C ==========		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor C Circuit Low (applications with LIN MAF)	P227C	Detects an eroneously low value being reported over the LIN serial connection from the BARO C sensor. The diagnostic monitors the BARO C sensor pressure output and fails the diagnostic when the pressure is too low. The BARO C sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure. The BARO C pressure value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.	BARO C Pressure	< 50.0 kPa	LIN Communications established with MAF		160 failures out of 200 samples 1 sample every 25 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor C Circuit High (applications with LIN MAF)	P227D	Detects an eroneously high value being reported over the LIN serial connection from the BARO C sensor. The diagnostic monitors the BARO C sensor pressure output and fails the diagnostic when the pressure is too high. The BARO C sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure. The BARO C pressure value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.	BARO C Pressure	> 115.0 kPa	LIN Communications established with MAF		160 failures out of 200 samples 1 sample every 25 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor C Circuit Intermittent/ Erratic (applications with LIN MAF)	P227E	Detects a noisy or erratic signal in the barometric pressure (BARO) C circuit by monitoring the BARO C sensor and failing the diagnostic when the BARO C signal has a noisier output than is expected. When the value of BARO C in kilopascals (kPa) is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of BARO C readings. The result of this summation is called a “string length”. Since the BARO C signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic BARO C signal. The diagnostic will fail if the string length is too high.	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current BARO C reading - BARO C reading from 25 milliseconds previous)	> 100 kPa 80 consecutive BARO C readings	LIN Communications established with MAF		4 failures out of 5 samples Each sample takes 2.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump Performance	P228C	This DTC determines if the high pressure pump is not able to maintain target pressure. The fault is set if the measured fuel rail pressure is lower than desired fuel pressure by a value that can impact emission and drivability for a number of pump events.	Fuel Pressure Error (Desired Pressure - Measure Pressure)	>= **P228C P2C1F - High Pressure Pump Control (HPC) fail threshold of pressure too low** Mpa (see supporting tables)	High Pressure Pump Performance Diagnostic Enable Battery Voltage Low Side Fuel Pressure Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) andCam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and	True >= 11 Volts > 0.275 MPa Enabled when a code clear is not active or not exiting device control Engine is not cranking	Positive Pressure Error - 10.00 second failures out of 12.50 second samples	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Engine movement detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active Barometric Pressure Inlet Air Temp Fuel Temp	 >= 70.0 KPA >= -12.0 degC -12 <=Temp degC <= 132		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump Performance	P228D	This DTC determines if the high pressure pump is delivering high pressure that desired pressure. The fault is set if the measured fuel rail pressure is higher than desired fuel pressure by a value that can impact emission and drivability for a number of pump events.	Fuel Pressure Error (Desired Pressure - Measure Pressure)	<= **P228D P2C20 - High Pressure Pump Control (HPC) fail threshold for pressure too high** Mpa (see supporting tables)	High Pressure Pump Performance Diagnostic Enable Battery Voltage Low Side Fuel Pressure Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt	True >= 11 Volts > 0.275 MPa Enabled when a code clear is not active or not exiting device control Engine is not cranking	Negative Pressure Error - 10.00 second failures out of 12.50 second samples	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					enabled on is false and Engine movement detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active Barometric Pressure Inlet Air Temp Fuel Temp	 >= 70.0 KPA >= -12.0 DegC -12 <= Temp degC <= 132		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT LOW	P2300	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 100 Ω impedance between signal and controller ground	Engine running Ignition Voltage	 > 11.0	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT High	P2301	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for a Short to Power fault. Controller specific output driver circuit diagnoses the low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT Low	P2303	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 100 Ω impedance between signal and controller ground	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT High	P2304	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for a Short to Power fault	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT Low	P2306	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 100 Ω impedance between signal and controller ground	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT High	P2307	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for a Short to Power fault	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT Low	P2309	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 100 Ω impedance between signal and controller ground	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT High	P2310	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for a Short to Power fault	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #5 CIRCUIT Low	P2312	Diagnoses Cylinder #5 Ignition Control (EST) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #5 CIRCUIT High	P2313	Diagnoses Cylinder #5 Ignition Control (EST) output driver circuit for a Short to Power fault	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #6 CIRCUIT Low	P2315	Diagnoses Cylinder #6 Ignition Control (EST) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #6 CIRCUIT High	P2316	Diagnoses Cylinder #6 Ignition Control (EST) output driver circuit for a Short to Power fault	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #7 CIRCUIT Low	P2318	Diagnoses Cylinder #7 Ignition Control (EST) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #7 CIRCUIT High	P2319	Diagnoses Cylinder #7 Ignition Control (EST) output driver circuit for a Short to Power fault	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #8 CIRCUIT Low	P2321	Diagnoses Cylinder #8 Ignition Control (EST) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #8 CIRCUIT High	P2322	Diagnoses Cylinder #8 Ignition Control (EST) output driver circuit for a Short to Power fault	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	 > 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Torque Request Circuit	P2544	Determines if the torque request from the TCM is valid	Protect error - Serial Communication message 2's complement not equal ($189/$199)	Message <> two's complement of message	Diagnostic Status	Enabled	>= 16 failures out of 20 samples.	Type B, 2 Trips
					Power Mode	= Run	Performed on every received message	
			OR Rolling count error - Serial Communication message ($189/$199) rolling count index value	Message <> previous message rolling count value + one	Ignition Voltage	> 6.41 volts	>= 6 Rolling count errors out of 10 samples.	
					Engine Running	= True		
			OR		Run/Crank Active	> 0.50 Sec	Performed on every received message	
			Range Error - Serial Communication message - ($189/$199) TCM Requested Torque Increase	> 600 Nm	No Serial communication loss to TCM (U0101)	No loss of communication	>= 6 range errors out of 10 samples.	
							Performed on every received message	
			OR					
			Multi-transition error - Trans torque intervention type request change	Requested torque intervention type toggles from not increasing request to increasing request			>= 3 multi-transitions out of 5 samples. Performed every 200 msec	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Hood Switch Performance	P257D	This DTC monitors the hood switch rationality	Hood Switch position is in an invalid position. Type of Switch: CeHSWR_e_Enumerated With an enumerated type switch the hood switch reading is invalid in these ranges With a discrete type switch the hood switch reading is invalid when With a percentage type switch the hood switch reading is invalid in these ranges With a resistance type switch the hood switch reading is invalid in these ranges	 1281 Ohms to 1404 Ohms Hood Switch 1 and Hood Switch 2 are in the same state (States not equal is proper function) 71.50 % to 67.80 % or 45.70 % to 43.40 % or 17.20 % to 14.60 % 6,775.00 Ohms to 3,367.10 Ohms or 1,585.00 Ohms to 1,352.20 Ohms or 310.40 Ohms to 300.00 Ohms	The diagnostic is enabled Enabled when Run/Crank is active only, otherwise Run/Crank is not used as an enable	= 1 (1 indicates enabled) = 1 (1 indicates Run/ Crank active enabled)	400 failed samples within 500 total samples Diagnostic runs in the 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Hood Switch Short to Ground / Low Voltage	P257E	This DTC monitors the hood switch for a short to ground or low voltage condition	Hood Switch position reading is outside an expected bounds for Type of Switch: CeHSWR_e_Enumerated With an enumerated type switch the bound is hood switch reading With a discrete type switch the bounds are With a percentage type switch the bound is hood switch reading With a resistance type switch the bound is hood switch reading	 <= 325 Ohms Hood Switch 1 and Hood Switch 2 are in the same state (States not equal is proper function) <= 14.60 % <= 300.00 Ohms	The diagnostic is enabled Enabled when Run/Crank is active only, otherwise Run/Crank is not used as an enable	= 1 (1 indicates enabled) = 1 (1 indicates Run/ Crank active enabled)	400 failed samples within 500 total samples Diagnostic runs in the 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Hood Switch Short to Voltage / High Voltage	P257F	This DTC monitors the hood switch for a short to voltage or high voltage condition	Hood Switch position reading is outside an expected bounds for Type of Switch: CeHSWR_e_Enumerated With an enumerated type switch the bound is hood switch reading With a discrete type switch the bounds are With a percentage type switch the bound is hood switch reading With a resistance type switch the bound is hood switch reading	 >= 3620 Ohms Hood Switch 1 and Hood Switch 2 are in the same state (States not equal is proper function) >= 71.50 % >= 6,775.00 Ohms	The diagnostic is enabled Enabled when Run/Crank is active only, otherwise Run/Crank is not used as an enable	= 1 (1 indicates enabled) = 1 (1 indicates Run/ Crank active enabled)	400 failed samples within 500 total samples Diagnostic runs in the 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake System Control Module Requested MIL Illumination	P25A2	Monitors the Brake System Control Module MIL request message to determine when the Brake System Control Module has detected a MIL illuminating fault.	Brake System Control Module Emissions-Related DTC set and module is requesting MIL	Brake System Control Module Emissions-Related DTC set and module is requesting MIL		Time since power-up ≥ 3 seconds	Continuous	Type A, No MIL

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Off Timer Performance	P262B	This DTC determines if the hardware timer does not initialize or count properly. There are two tests to ensure proper functioning of the timer: Count Up Test (CUT) and Range Test (RaTe). Count Up Test (CUT): Verifies that the HWIO timer is counting up with the proper increment. Range Test (RaTe): When the run/crank is not active both the hardware and mirror timers are started. The timers are compared when module shutdown is initiated or run/crank becomes active.	Count Up Test: Time difference between the current read and the previous read of the timer Range Test: The variation of the HWIO timer and mirror timer is	> 1.50 seconds > 0.25 %.			Count Up Test: 8 failures out of 40 samples 1 sec / sample Continuous while run/crank is not active and until controller shutdown is initiated. Range Test: Once per trip when controller shutdown is initiated or run/crank becomes active.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump "A" Low Flow / Performance	P2635	This DTC detects degradation in the performance of the electronically regulated fuel system by calculating the difference between the sensed, filtered system [line] pressure versus the ECM-commanded pressure [error calculation]. The calculated error is then compared to calibrated fault threshold tables for a fault decision.	Sensed Filtered Fuel System [line] pressure error	<= Low Threshold [Supporting Table] **P2635 Threshold Low** OR >= High Threshold [Supporting Table] **P2635 Threshold High**	a) Diagnostic enabled [FDBR_b_FSRD] b) Timer Engine Running [FDBR_t_EngModeRunCoarse] c1) Fuel Flow Rate Valid c2) Ambient Air Pressure Value Defaulted c3) FDB_FuelPresSnsrCktFA c4) Reference Voltage Fault Status [DTC P0641] c5) Exhaust AfterTreatment Fuel Injector A Control Circuit Short Low Fault [HCIR_b_GshtFA DTC P20CD] c6) Fuel Pres Sensor Performance Fault Active [DTC P018B] c7) Use Calculated Flow Performance Fault Thresholds [FDBR_b_UseCalcFSRD_FltThrshs] c8) Engine Speed Status Valid c9) FAB_FuelPmpCktFA c10) Fuel Control Enable	a) == TRUE b) >= 30.00 seconds c1) == TRUE c2) <> TRUE c3) <> TRUE c4) <> TRUE c5) <> TRUE c6) <> TRUE c7) <> TRUE c8] == TRUE c9] <> TRUE c10) <> TRUE	1 sample / 12.5 millisec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Fault Active [DTC P12A6]			
					c11) Fuel Pump Driver Module OverTemp Fault Active [DTC P1255]	c11) <> TRUE		
					c12) Fuel Pump Speed Fault Active [DTC P129F]	c12) <> TRUE		
					c13) CAN Sensor Bus message $0C3 Comm Fault [CFMR_b_FTZM_Info1_UcodeCmFA DTC P165C]	c13) <> TRUE		
					c14) CAN Sensor Bus Fuel Pmp Spd Command ARC and Checksum Comm Fault Code [CFMR_b_FTZM_Cmd1_UcodeCmFA DTC]	c14] <> TRUE		
					c15) Sensor Configuration [FDBR_e_FuelPresSnsrConfig]	c15) == CeFDBR_e_WiredTo_ECM		
					c16) Sensor Bus Relay On	c16) == TRUE		
					d) Emissions Fuel Level Low [Message $3FB]	d) <> TRUE		
					e) Fuel Control Enable	e) == TRUE		
					f) Fuel Pump Control State	f) == NORMAL		
					g) Run_Crank input circuit voltage	g) 11.00 volts <= Run_Crank_V <= 32.00 volts		
					h) High Pres Fuel Pump	h) <> TRUE		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Mode Management Enabled			
					j) High Pres Fuel Pump Control Mode	j) <> Disabled Mode AND a8b) <> ZeroFlow Mode		
					k) Instantaneous Fuel Flow [FCBR_dm_InstFuelFlow]	k) 0.05 grams/sec <= InstFuelFlow <= Max Allowed Flow [Supporting Table] **P2635 Max Fuel Flow**		
					m1) Fuel Pmp Speed Command Alive Rolling Count and Checksum Error [CAN Bus B $0CE] [CFMR_b_FTZM_Cmd1_ ARC_ChkErr DTC]	m1) <> TRUE		
					m2) CAN Sensor Bus message $0C3_Available	m2) == TRUE		
					m3) Fuel Pres Sensor Ref Voltage Status Message Counter Incorrect Alive Rolling Count and Checksum Error [CAN Bus B $0C3] [CFMR_b_FTZM_Info1_A RC_ChkErr DTC]	m3) <> TRUE		
					n) Timer - Diagnostic Enable	n) > 2.00 seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Low	P263A	Detects an inoperative malfunction indicator lamp control circuit. This diagnostic reports the DTC when a short to ground is detected.	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between output and controller ground	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11.00 volts	1 failures out of 1 samples 50 ms / sample	Type B, No MIL NO MIL Note: In certain controllers P0650 may also set (MIL Control Open Circuit)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) High	P263B	Detects an inoperative malfunction indicator lamp control circuit. This diagnostic reports the DTC when a short to power is detected.	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between output and controller power	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11.00 volts	4 failures out of 5 samples 50 ms / sample	Type B, No MIL NO MIL

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Drive Pinion Circuit Open (12VSS)	P26E4	Controller specific output driver circuit diagnoses the Tandem Starter Pinion Relay high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	>= 200 KOhms impedance between signal and controller ground.	Starter relay pinion diag enable Engine speed Run Crank voltage	= 1.00 >= 0.00 RPM >= 11.00 volts	40 failures out of 50 samples 50 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Drive Pinion Circuit Low Voltage (12VSS)	P26E5	Controller specific output driver circuit diagnoses the Tandem Starter Pinion Relay high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 0.5 Ohms impedance between signal and controller ground	Starter control diag enable Engine speed Run Crank voltage	= 1.00 >= 0.00 RPM >= 6.41 volts	8 failures out of 10 samples 50 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Drive Pinion Circuit High Voltage (12VSS)	P26E6	Controller specific output driver circuit diagnoses the Tandem Starter Pinion Relay high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 0.5 Ohms impedance between signal and controller power	Starter control diag enable Engine speed Run Crank voltage	= 1.00 >= 0.00 RPM >= 11.00 volts	40 failures out of 50 samples 50 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transfer Case Control Module Transfer Case Command State Rationality - 4WD high command not 4WD high ratio	P279A	Monitor measured transfer case gear ratio is 4WD low ratio or neutral while the transfer case control module command state is 4WD high. The 4WD measured transfer case ratio is calculated as transmission output shaft speed divided by the transfer case output shaft speed, both speed are measured values based on speed sensors.	transfer case contol module transfer case command state AND measured transfer case ratio is in 4WD low ratio window OR measured transfer case ratio is in neutral window AND measured transfer case ratio is in 4WD low ratio window (measured transfer case ratio = transmission output speed / transfer case output speed) update rate 12.5 milliseconds	= 4WD high 4WD low ratio window ≤ 3.00 ≥ 2.40 neutral ratio window ≥ 1.30 ≤ 0.70 OR ≥ 3.00 ≤ 2.40 4WD low ratio window ≤ 2.90 ≥ 2.50	transmssion gear is forward gear: transmission output shaft speed engine torque engine speed accelerator pedal position brake pedal position transmssion gear is reverse gear: transmission output shaft speed engine torque engine speed accelerator pedal position brake pedal position diagnsotic monitor enable PTO active engine power limited DTCs not fault active	 ≥ 500.0 RPM ≥ 80.0 Nm ≥ 300.0 RPM ≥ 5.0 % ≤ 100.0 % ≥ 500.0 RPM ≥ 80.0 Nm ≥ 300.0 PRM ≥ 5.0 % ≤ 100.0 % = 1 Boolean = FALSE = FALSE CrankSensor_FA VehicleSpeedSensor_FA EngineTorqueEstInaccurate P057B, P057C, P057D, P057E P17D4, P279B, P279C P0502, P0503, P0722, P0723, P2160, P2161	fail time ≥ 7.00 seconds out of sample time ≥ 10.00 seconds update rate 12.5 milliseconds	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transfer Case Control Module Transfer Case Command State Rationality - 4WD low command not 4WD low ratio	P279B	Monitor measures transfer case gear ratio is 4WD high ratio or neutral while the transfer case control module command state is 4WD low. The 4WD measured transfer case ratio is calculated as transmission output shaft speed divided by the transfer case output shaft speed, both speed are measured values based on speed sensors.	transfer case contol module transfer case command state AND measured transfer case ratio is in 4WD high ratio window OR measured transfer case ratio is in neutral window AND measured transfer case ratio is in 4WD high ratio window (measured transfer case ratio = transmission output speed / transfer case output speed) update rate 12.5 milliseconds	= 4WD low 4WD high ratio window ≤ 1.30 ≥ 0.70 neutral ratio window ≥ 1.30 ≤ 0.70 OR ≥ 3.00 ≤ 2.40 4WD high ratio window ≤ 1.20 ≥ 0.80	transmssion gear is forward gear: transmission output shaft speed engine torque engine speed accelerator pedal position brake pedal position transmssion gear is reverse gear: transmission output shaft speed engine torque engine speed accelerator pedal position brake pedal position diagnsotic monitor enable PTO active engine power limited DTCs not fault active	≥ 500.0 RPM ≥ 80.0 Nm ≥ 300.0 RPM ≥ 5.0 % ≤ 100.0 % ≥ 500.0 RPM ≥ 80.0 Nm ≥ 300.0 PRM ≥ 5.0 % ≤ 100.0 % = 1 Boolean = FALSE = FALSE CrankSensor_FA VehicleSpeedSensor_FA EngineTorqueEstInaccurate P057B, P057C, P057D, P057E P17D4, P279A, P279C P0502, P0503, P0722, P0723, P2160, P2161	fail time ≥ 7.00 seconds out of sample time ≥ 10.00 seconds update rate 12.5 milliseconds	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transfer Case Control Module Transfer Case Command State Rationality - 4WD neutral command not 4WD neutral ratio	P279C	Monitor measured transfer case gear ratio is 4WD high ratio or 4WD low ratio while the transfer case control module command state is 4WD neutral. The 4WD measured transfer case ratio is calculated as transmission output shaft speed divided by the transfer case output shaft speed, both speed are measured values based on speed sensors.	transfer case contol module transfer case command state AND measured transfer case ratio is in 4WD low ratio window OR measured transfer case ratio is in 4WD high window AND measured transfer case ratio is in 4WD low ratio window or in 4WD high ratio window (measured transfer case ratio = transmission output speed / transfer case output speed) update rate 12.5 milliseconds	= 4WD neutral 4WD low ratio window ≤ 3.00 ≥ 2.40 4WD high ratio window ≥ 1.30 ≤ 0.70 4WD neutral ratio window ≤ 2.90 ≥ 2.50 OR ≤ 1.20 ≥ 0.80	transmssion gear is forward gear: transmission output shaft speed engine torque engine speed accelerator pedal position brake pedal position transmssion gear is reverse gear: transmission output shaft speed engine torque engine speed accelerator pedal position brake pedal position diagnsotic monitor enable PTO active engine power limited DTCs not fault active	 ≥ 300.0 RPM ≥ -20.0 Nm ≥ 0.0 RPM ≥ 0.0 % ≤ 100.0 % ≥ 500.0 RPM ≥ 80.0 Nm ≥ 300.0 PRM ≥ 5.0 % ≤ 100.0 % = 1 Boolean = FALSE = FALSE CrankSensor_FA VehicleSpeedSensor_FA EngineTorqueEstInaccurate P057B, P057C, P057D, P057E P17D4, P279A, P279B P0502, P0503, P0722, P0723, P2160, P2161	fail time ≥ 10.50 seconds out of sample time ≥ 15.00 seconds update rate 12.5 milliseconds	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module SIDI High Pressure Pump min/ max authority During Catalyst Warm Up	P2C1E	This DTC determines when the high pressure pump control has reached to its max or min authority during Cataylst Warm up	High Pressure Fuel Pump Delivery Angle OR High Pressure Fuel Pump Delivery Angle	>= 130 ° <= 0 °	Catalyst Warm Up High Pressure Pump Performance Diagnostic Enable Battery Voltage Low Side Fuel Pressure Barometric Pressure Inlet Air Temp Fuel Temp Catalyst Warm up enabled (See Definition in Supporting Material below) Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) andCam or	True >= 11 Volts > 0.275 MPa Enabled when a code clear is not active or not exiting device control Engine is not cranking >= 70.0 KPA >= -12.0 degC -12 <= Temp degC <= 132 = True	Windup High/ Low 10.00 seconds failures out of 12.50 Seconds samples	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump Performance During Catalyst Warm Up	P2C1F	This DTC determines if the high pressure pump is not able to maintain target pressure Catalyst Warm Up. The fault is set if the measured fuel rail pressure is lower than desired fuel pressure by a value that can impact emission and drivability for a number of pump events.	Fuel Pressure Error (Desired Pressure - Measure Pressure)	>= **P228C P2C1F - High Pressure Pump Control (HPC) fail threshold of pressure too low** Mpa (see supporting tables)	Catalyst Warm Up High Pressure Pump Performance Diagnostic Enable Battery Voltage Low Side Fuel Pressure Catalyst Warm up enabled (See Definition in Supporting Material below) Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) andCam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and	True >= 11 Volts > 0.275 MPa = True Enabled when a code clear is not active or not exiting device control Engine is not cranking	Positive Pressure Error - 10.00 second failures out of 12.50 second samples	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -12.0 degC -12 <=Temp degC <= 132		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump Performance During Catalyst Warm Up	P2C20	This DTC determines if the high pressure pump is delivering high pressure that desired pressure Catalyst Warm Up. The fault is set if the measured fuel rail pressure is higher than desired fuel pressure by a value that can impact emission and drivability for a number of pump events.	Fuel Pressure Error (Desired Pressure - Measure Pressure)	<= **P228D P2C20 - High Pressure Pump Control (HPC) fail threshold for pressure too high** Mpa (see supporting tables)	Catalyst Warm Up High Pressure Pump Performance Diagnostic Enable Battery Voltage Low Side Fuel Pressure Catalyst Warm up enabled (See Definition in Supporting Material below) Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not	True >= 11 Volts > 0.275 MPa = True Enabled when a code clear is not active or not exiting device control Engine is not cranking	Negative Pressure Error - 10.00 second failures out of 12.50 second samples	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active Barometric Pressure Inlet Air Temp Fuel Temp	 >= 70.0 KPA >= -12.0 DegC -12 <= Temp degC <= 132		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Actuator Voltage Sensor Circuit 1 Low Voltage	P3051	Diagnoses the DC/DC Converter Actuator Voltage Sensor Circuit 1 for short to ground faults.	DC/DC Converter Actuator Voltage Raw Value 1	< 1 Volt	Diagnostic enabled Run/Crank or Accessory Battery Voltage	TRUE TRUE >= 6.60 Volts	640 failed samples out of 800 samples in 6.25 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Actuator Voltage Sensor Circuit 2 Low Voltage	P3052	Diagnoses the DC/DC Converter Actuator Voltage Sensor Circuit 2 for short to ground faults.	DC/DC Converter Actuator Voltage Raw Value 2	< 1 Volt	Diagnostic enabled Run/Crank or Accessory Battery Voltage	TRUE TRUE >= 6.60 Volts	640 failed samples out of 800 samples in 6.25 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Actuator Voltage Sensor Circuit 1 High Voltage	P3053	Diagnoses the DC/DC Converter Actuator Voltage Sensor Circuit 1 for short to battery faults.	DC/DC Converter Actuator Voltage Raw Value 1	> 28 Volt	Diagnostic enabled Run/Crank or Accessory Battery Voltage	TRUE TRUE >= 6.60 Volts	640 failed samples out of 800 samples in 6.25 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Actuator Voltage Sensor Circuit 2 High Voltage	P3054	Diagnoses the DC/DC Converter Actuator Voltage Sensor Circuit 2 for short to battery faults.	DC/DC Converter Actuator Voltage Raw Value 2	> 28 Volt	Diagnostic enabled Run/Crank or Accessory Battery Voltage	TRUE TRUE >= 6.60 Volts	640 failed samples out of 800 samples in 6.25 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Actuator Voltage 1 Performance	P3055	Detects DC/DC Converter Actuator Voltage 1 Performance issues	Bypass Mode: Absolute value of voltage difference between DC/ DC Converter Actuator Voltage Raw Value 1 and ECM Run/Crank	> 1 Volt	Diagnostic enabled Run/Crank or Accessory Engine running OR Engine stopped Battery Voltage	TRUE TRUE for > 160 loops in 6.25 ms loop for > 160 loops in 6.25 ms loop >= 6.60 Volts	640 failed samples out of 800 samples in a 6.25 ms loop	Type B, 2 Trips
			Stabilize Mode- Auto-Cranking: Absolute value of voltage difference between DC/ DC Converter Actuator Voltage Raw Value 1 and ECM Run/Crank	> 1 Volt	Diagnostic enabled Run/Crank or Accessory Engine auto-cranking Battery Voltage	TRUE TRUE for > 0 loops in 6.25 ms loop >= 6.60 Volts	16 failed samples out of 32 samples in a 6.25 ms loop	
			Stablize Mode-Auto-Cranking Events: Number of failed auto-cranking events exceeds threshold	> 2 failed auto-cranking events	Diagnostic enabled Run/Crank or Accessory Engine auto-cranking	TRUE TRUE has occurred	2 failed auto-crank events out of 3 consecutive auto-crank events	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Actuator Voltage 2 Performance	P3056	Detects DC/DC Converter Actuator Voltage 2 Performance issues	Bypass Mode: Absolute value of voltage difference between DC/ DC Converter Actuator Voltage Raw Value 2 and ECM Run/Crank	> 1 Volt	Diagnostic enabled Run/Crank or Accessory Engine running OR Engine stopped Battery Voltage	TRUE TRUE for > 160 loops in 6.25 ms loop for > 160 loops in 6.25 ms loop >= 6.60 Volts	640 failed samples out of 800 samples in a 6.25 ms loop	Type B, 2 Trips
			Stabilize Mode- Auto-Cranking: Absolute value of voltage difference between DC/ DC Converter Actuator Voltage Raw Value 2 and ECM Run/Crank	> 1 Volt	Diagnostic enabled Run/Crank or Accessory Engine auto-cranking Battery Voltage	TRUE TRUE for > 0 loops in 6.25 ms loop >= 6.60 Volts	16 failed samples out of 32 samples in a 6.25 ms loop	
			Stablize Mode-Auto-Cranking Events: Number of failed auto-cranking events exceeds threshold	> 2 failed auto-cranking events	Diagnostic enabled Run/Crank or Accessory Engine auto-cranking	TRUE TRUE has occurred	2 failed auto-crank events out of 3 consecutive auto-crank events	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Ignition Switch Run/ Start Position Ciruit High Voltage	P305B	Diagnoses the DC/DC Converter Ignition Switch Run/Start Position circuit for circuit high faults	DC/DC Converter Ignition Switch Run/Start Position	<> ECM Ignition Switch Run/Start Position	Diagnostic enabled Run/Crank Accessory Battery Voltage	TRUE FALSE TRUE >= 6.60 Volts	320 failed samples out of 400 samples in a 6.25 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Ignition Switch Run/ Start Position Ciruit Low Voltage	P305C	Diagnoses the DC/DC Converter Ignition Switch Run/Start Position circuit for circuit low faults	DC/DC Converter Ignition Switch Run/Start Position	<> ECM Ignition Switch Run/Start Position	Diagnostic enabled Run/Crank Accessory Battery Voltage	TRUE TRUE TRUE >= 6.60 Volts	640 failed samples out of 800 samples in a 6.25 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Crank Control Circuit High Voltage	P305D	Diagnoses the DC/DC Converter Crank Control Circuit for circuit high faults	DC/DC Converter Crank Control	<> ECM Crank Control	Diagnostic enabled Run/Crank ECM Crank Control Battery Voltage	TRUE TRUE FALSE >= 6.60 Volts	640 failed samples out of 800 samples in a 6.25 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Crank Control Circuit Low Voltage	P305E	Diagnoses the DC/DC Converter Crank Control Circuit for circuit low faults	DC/DC Converter Crank Control	<> ECM Crank Control	Diagnostic enabled Run/Crank or Accessory ECM Crank Control Battery Voltage	TRUE TRUE TRUE >= 6.60 Volts	24 failed samples out of 32 samples in a 6.25 ms loop	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 1	P30D6	This DTC detects intermitent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage Run/Crank voltage	>= 6.41 Volts or >= 11.00 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 2	P30D7	This DTC detects intermitent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage Run/Crank voltage	>= 6.41 Volts or >= 11.00 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 3	P30D8	This DTC detects intermitent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage Run/Crank voltage	>= 6.41 Volts or >= 11.00 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 4	P30D9	This DTC detects intermitent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage Run/Crank voltage	>= 6.41 Volts or >= 11.00 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 5	P30DA	This DTC detects intermitent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage Run/Crank voltage	>= 6.41 Volts or >= 11.00 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 6	P30DB	This DTC detects intermitent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage Run/Crank voltage	>= 6.41 Volts or >= 11.00 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 7	P30DC	This DTC detects intermitent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage Run/Crank voltage	>= 6.41 Volts or >= 11.00 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 8	P30DD	This DTC detects intermitent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage Run/Crank voltage	>= 6.41 Volts or >= 11.00 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 1 Deactivation Solenoid Valve High Control Circuit Low Voltage (For Gen IV controller)	P3105	Controller specific output driver circuit diagnoses the Cylinder 1 Deactivation Solenoid high sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3401 may also set (Cylinder 1 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 1 Deactivation Solenoid Valve High Control Circuit High Voltage (For Gen IV controller)	P3106	Controller specific output driver circuit diagnoses the Cylinder 1 Deactivation Solenoid high sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 2 Deactivation Solenoid Valve High Control Circuit Low Voltage (For Gen IV controller)	P3108	Controller specific output driver circuit diagnoses the Cylinder 2 Deactivation Solenoid high sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3409 may also set (Cylinder 2 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 2 Deactivation Solenoid Valve High Control Circuit High Voltage (For Gen IV controller)	P3109	Controller specific output driver circuit diagnoses the Cylinder 2 Deactivation Solenoid high sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 3 Deactivation Solenoid Valve High Control Circuit Low Voltage (For Gen IV controller)	P310B	Controller specific output driver circuit diagnoses the Cylinder 3 Deactivation Solenoid high sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3417 may also set (Cylinder 3 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 3 Deactivation Solenoid Valve High Control Circuit High Voltage (For Gen IV controller)	P310C	Controller specific output driver circuit diagnoses the Cylinder 3 Deactivation Solenoid high sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 4 Deactivation Solenoid Valve High Control Circuit Low Voltage (For Gen IV controller)	P310E	Controller specific output driver circuit diagnoses the Cylinder 4 Deactivation Solenoid high sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Controller specific output driver circuit diagnoses the Cylinder 1 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3425 may also set (Cylinder 4 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 4 Deactivation Solenoid Valve High Control Circuit High Voltage (For Gen IV controller)	P310F	Controller specific output driver circuit diagnoses the Cylinder 4 Deactivation Solenoid high sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.Diagnoses cylinder 4 deactivation solenoid control low side driver circuit for circuit faults	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 5 Deactivation Solenoid Valve High Control Circuit Low Voltage (For Gen IV controller)	P3111	Controller specific output driver circuit diagnoses the Cylinder 5 Deactivation Solenoid high sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Controller specific output driver circuit diagnoses the Cylinder 3 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3433 may also set (Cylinder 5 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 5 Deactivation Solenoid Valve High Control Circuit High Voltage (For Gen IV controller)	P3112	Controller specific output driver circuit diagnoses the Cylinder 5 Deactivation Solenoid high sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 6 Deactivation Solenoid Valve High Control Circuit Low Voltage (For Gen IV controller)	P3114	Controller specific output driver circuit diagnoses the Cylinder 6 Deactivation Solenoid high sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3441 may also set (Cylinder 6 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 6 Deactivation Solenoid Valve High Control Circuit High Voltage (For Gen IV controller)	P3115	Controller specific output driver circuit diagnoses the Cylinder 6 Deactivation Solenoid high sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 7 Deactivation Solenoid Valve High Control Circuit Low Voltage (For Gen IV controller)	P3117	Controller specific output driver circuit diagnoses the Cylinder 7 Deactivation Solenoid high sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage low during driver off state (indicates an short circuit to Ground) Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3449 may also set (Cylinder 7 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 7 Deactivation Solenoid Valve High Control Circuit High Voltage (For Gen IV controller)	P3118	Controller specific output driver circuit diagnoses the Cylinder 7 Deactivation Solenoid high sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 8 Deactivation Solenoid Valve High Control Circuit Low Voltage (For Gen IV controller)	P311A	Controller specific output driver circuit diagnoses the Cylinder 8 Deactivation Solenoid high sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage low during driver off state (indicates an short circuit to Ground) Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3457 may also set (Cylinder 8 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 8 Deactivation Solenoid Valve High Control Circuit High Voltage (For Gen IV controller)	P311B	Controller specific output driver circuit diagnoses the Cylinder 8 Deactivation Solenoid high sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 1 Trapped High Pressure Exhaust Charge	P3189	When conditions are met, continuously monitors to diagnose the cyliner 1 exhaust valve fails to open to release the burned charge. The trapped charge will be re-compressed and produce high cylinder pressure as the piston rises to top dead center and potential damages the intake mechanism during reactivation. Once a fault incidence is detected, the remedial action will be immediately taken to prevent engine hardware damage. This diagnostic monitors crank jerk to detect trapped exhaust charge. This diagnostic is subject to an X/Y maturity criteria.	Filtered crank jerk normalized by engine speed is greater than the threhold value when the cylinder of interest is deactivated	Filtered Crank Jerk > (A*APC^2 + B*APC +C)*RPM A = **HPESFailCoeffA** B = **HPESFailCoeffB** C= **HPESFailCoeffC**	Filtered APC Filtered MAP Firing Fraction Transmission Gear	> 145.00 > 30.00 < 0.95 > CeTGRR_e_TransGr2	66.00 failures out of 100.00 samples Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 2 Trapped High Pressure Exhaust Charge	P318A	When conditions are met, continuously monitors to diagnose the cylinder 2 exhaust valve fails to open to release the burned charge. The trapped charge will be re-compressed and produce high cylinder pressure as the piston rises to top dead center and potential damages the intake mechanism during reactivation. Once a fault incidence is detected, the remedial action will be immediately taken to prevent engine hardware damage. This diagnostic monitors crank jerk to detect trapped exhaust charge. This diagnostic is subject to an X/Y maturity criteria.	Filtered crank jerk normalized by engine speed is greater than the threhold value when the cylinder of interest is deactivated	Filtered Crank Jerk > (A*APC^2 + B*APC +C)*RPM A = **HPESFailCoeffA** B = **HPESFailCoeffB** C= **HPESFailCoeffC**	Filtered APC Filtered MAP Firing Fraction Transmission Gear	> 145.00 > 30.00 < 0.95 > CeTGRR_e_TransGr2	66.00 failures out of 100.00 samples Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 3 Trapped High Pressure Exhaust Charge	P318B	When conditions are met, continuously monitors to diagnose the cylinder 3 exhaust valve fails to open to release the burned charge. The trapped charge will be re-compressed and produce high cylinder pressure as the piston rises to top dead center and potential damages the intake mechanism during reactivation. Once a fault incidence is detected, the remedial action will be immediately taken to prevent engine hardware damage. This diagnostic monitors crank jerk to detect trapped exhaust charge. This diagnostic is subject to an X/Y maturity criteria.	Filtered crank jerk normalized by engine speed is greater than the threhold value when the cylinder of interest is deactivated	Filtered Crank Jerk > (A*APC^2 + B*APC +C)*RPM A = **HPESFailCoeffA** B = **HPESFailCoeffB** C= **HPESFailCoeffC**	Filtered APC Filtered MAP Firing Fraction Transmission Gear	> 145.00 > 30.00 < 0.95 > CeTGRR_e_TransGr2	66.00 failures out of 100.00 samples Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 4 Trapped High Pressure Exhaust Charge	P318C	When conditions are met, continuously monitors to diagnose the cylinder 4 exhaust valve fails to open to release the burned charge. The trapped charge will be re-compressed and produce high cylinder pressure as the piston rises to top dead center and potential damages the intake mechanism during reactivation. Once a fault incidence is detected, the remedial action will be immediately taken to prevent engine hardware damage. This diagnostic monitors crank jerk to detect trapped exhaust charge. This diagnostic is subject to an X/Y maturity criteria.	Filtered crank jerk normalized by engine speed is greater than the threhold value when the cylinder of interest is deactivated	Filtered Crank Jerk > (A*APC^2 + B*APC +C)*RPM A = **HPESFailCoeffA** B = **HPESFailCoeffB** C= **HPESFailCoeffC**	Filtered APC Filtered MAP Firing Fraction Transmission Gear	> 145.00 > 30.00 < 0.95 > CeTGRR_e_TransGr2	66.00 failures out of 100.00 samples Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 5 Trapped High Pressure Exhaust Charge	P318D	When conditions are met, continuously monitors to diagnose the cylinder 5 exhaust valve fails to open to release the burned charge. The trapped charge will be re-compressed and produce high cylinder pressure as the piston rises to top dead center and potential damages the intake mechanism during reactivation. Once a fault incidence is detected, the remedial action will be immediately taken to prevent engine hardware damage. This diagnostic monitors crank jerk to detect trapped exhaust charge. This diagnostic is subject to an X/Y maturity criteria.	Filtered crank jerk normalized by engine speed is greater than the threhold value when the cylinder of interest is deactivated	Filtered Crank Jerk > (A*APC^2 + B*APC +C)*RPM A = **HPESFailCoeffA** B = **HPESFailCoeffB** C= **HPESFailCoeffC**	Filtered APC Filtered MAP Firing Fraction Transmission Gear	> 145.00 > 30.00 < 0.95 > CeTGRR_e_TransGr2	66.00 failures out of 100.00 samples Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 6 Trapped High Pressure Exhaust Charge	P318E	When conditions are met, continuously monitors to diagnose the cylinder 6 exhaust valve fails to open to release the burned charge. The trapped charge will be re-compressed and produce high cylinder pressure as the piston rises to top dead center and potential damages the intake mechanism during reactivation. Once a fault incidence is detected, the remedial action will be immediately taken to prevent engine hardware damage. This diagnostic monitors crank jerk to detect trapped exhaust charge. This diagnostic is subject to an X/Y maturity criteria.	Filtered crank jerk normalized by engine speed is greater than the threhold value when the cylinder of interest is deactivated	Filtered Crank Jerk > (A*APC^2 + B*APC +C)*RPM A = **HPESFailCoeffA** B = **HPESFailCoeffB** C= **HPESFailCoeffC**	Filtered APC Filtered MAP Firing Fraction Transmission Gear	> 145.00 > 30.00 < 0.95 > CeTGRR_e_TransGr2	66.00 failures out of 100.00 samples Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 7 Trapped High Pressure Exhaust Charge	P318F	When conditions are met, continuously monitors to diagnose the cylinder 7 exhaust valve fails to open to release the burned charge. The trapped charge will be re-compressed and produce high cylinder pressure as the piston rises to top dead center and potential damages the intake mechanism during reactivation. Once a fault incidence is detected, the remedial action will be immediately taken to prevent engine hardware damage. This diagnostic monitors crank jerk to detect trapped exhaust charge. This diagnostic is subject to an X/Y maturity criteria.	Filtered crank jerk normalized by engine speed is greater than the threhold value when the cylinder of interest is deactivated	Filtered Crank Jerk > (A*APC^2 + B*APC +C)*RPM A = **HPESFailCoeffA** B = **HPESFailCoeffB** C= **HPESFailCoeffC**	Filtered APC Filtered MAP Firing Fraction Transmission Gear	> 145.00 > 30.00 < 0.95 > CeTGRR_e_TransGr2	66.00 failures out of 100.00 samples Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 8 Trapped High Pressure Exhaust Charge	P3190	When conditions are met, continuously monitors to diagnose the cylinder 8 exhaust valve fails to open to release the burned charge. The trapped charge will be re-compressed and produce high cylinder pressure as the piston rises to top dead center and potential damages the intake mechanism during reactivation. Once a fault incidence is detected, the remedial action will be immediately taken to prevent engine hardware damage. This diagnostic monitors crank jerk to detect trapped exhaust charge. This diagnostic is subject to an X/Y maturity criteria.	Filtered crank jerk normalized by engine speed is greater than the threhold value when the cylinder of interest is deactivated	Filtered Crank Jerk > (A*APC^2 + B*APC +C)*RPM A = **HPESFailCoeffA** B = **HPESFailCoeffB** C= **HPESFailCoeffC**	Filtered APC Filtered MAP Firing Fraction Transmission Gear	> 145.00 > 30.00 < 0.95 > CeTGRR_e_TransGr2	66.00 failures out of 100.00 samples Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 1 Deactivation Solenoid Control Circuit/Open (For Gen IV controller)	P3401	Controller specific output driver circuit diagnoses the Cylinder 1 Deactivation Solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 k Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3403 may also set (Cylinder 1 Deactivation Solenoid Control Circuit/ Low)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 1 Deactivation Solenoid Control Circuit/Low (For Gen IV controller)	P3403	Controller specific output driver circuit diagnoses the Cylinder 1 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3401 may also set (Cylinder 1 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 1 Deactivation Solenoid Control Circuit/High (For Gen IV controller)	P3404	Controller specific output driver circuit diagnoses the Cylinder 1 Deactivation Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 2 Deactivation Solenoid Control Circuit/Open (For Gen IV controller)	P3409	Controller specific output driver circuit diagnoses the Cylinder 2 Deactivation Solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 k Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3411 may also set (Cylinder 2 Deactivation Solenoid Control Circuit/ Low)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 2 Deactivation Solenoid Control Circuit/Low (For Gen IV controller)	P3411	Controller specific output driver circuit diagnoses the Cylinder 2 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3409 may also set (Cylinder 2 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 2 Deactivation Solenoid Control Circuit/High (For Gen IV controller)	P3412	Controller specific output driver circuit diagnoses the Cylinder 2 Deactivation Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 3 Deactivation Solenoid Control Circuit/Open (For Gen IV controller)	P3417	Controller specific output driver circuit diagnoses the Cylinder 3 Deactivation Solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 k Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3419 may also set (Cylinder 3 Deactivation Solenoid Control Circuit/ Low)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 3 Deactivation Solenoid Control Circuit/Low (For Gen IV controller)	P3419	Controller specific output driver circuit diagnoses the Cylinder 3 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3417 may also set (Cylinder 3 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 3 Deactivation Solenoid Control Circuit/High (For Gen IV controller)	P3420	Controller specific output driver circuit diagnoses the Cylinder 3 Deactivation Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 4 Deactivation Solenoid Control Circuit/Open (For Gen IV controller)	P3425	Controller specific output driver circuit diagnoses the Cylinder 4 Deactivation Solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 k Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3427 may also set (Cylinder 4 Deactivation Solenoid Control Circuit/ Low)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 4 Deactivation Solenoid Control Circuit/Low (For Gen IV controller)	P3427	Controller specific output driver circuit diagnoses the Cylinder 4 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Controller specific output driver circuit diagnoses the Cylinder 1 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3425 may also set (Cylinder 4 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 4 Deactivation Solenoid Control Circuit/High (For Gen IV controller)	P3428	Controller specific output driver circuit diagnoses the Cylinder 4 Deactivation Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.Diagnoses cylinder 4 deactivation solenoid control low side driver circuit for circuit faults	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 5 Deactivation Solenoid Control Circuit/Open (For Gen IV controller)	P3433	Controller specific output driver circuit diagnoses the Cylinder 5 Deactivation Solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 k Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3435 may also set (Cylinder 5 Deactivation Solenoid Control Circuit/ Low)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 5 Deactivation Solenoid Control Circuit/Low (For Gen IV controller)	P3435	Controller specific output driver circuit diagnoses the Cylinder 5 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Controller specific output driver circuit diagnoses the Cylinder 3 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3433 may also set (Cylinder 5 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 5 Deactivation Solenoid Control Circuit/High (For Gen IV controller)	P3436	Controller specific output driver circuit diagnoses the Cylinder 5 Deactivation Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 6 Deactivation Solenoid Control Circuit/Open (For Gen IV controller)	P3441	Controller specific output driver circuit diagnoses the Cylinder 6 Deactivation Solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds	Voltage low during driver off state (indicates open circuit)Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 k Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3443 may also set (Cylinder 6 Deactivation Solenoid Control Circuit/ Low)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 6 Deactivation Solenoid Control Circuit/Low (For Gen IV controller)	P3443	Controller specific output driver circuit diagnoses the Cylinder 6 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3441 may also set (Cylinder 6 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 6 Deactivation Solenoid Control Circuit/High (For Gen IV controller)	P3444	Controller specific output driver circuit diagnoses the Cylinder 6 Deactivation Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 7 Deactivation Solenoid Control Circuit/Open (For Gen IV controller)	P3449	Controller specific output driver circuit diagnoses the Cylinder 7 Deactivation Solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 k Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3451 may also set (Cylinder 7 Deactivation Solenoid Control Circuit/ Low)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 7 Deactivation Solenoid Control Circuit/Low (For Gen IV controller)	P3451	Controller specific output driver circuit diagnoses the Cylinder 7 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage low during driver off state (indicates an short circuit to Ground) Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3449 may also set (Cylinder 7 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 7 Deactivation Solenoid Control Circuit/High (For Gen IV controller)	P3452	Controller specific output driver circuit diagnoses the Cylinder 7 Deactivation Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 8 Deactivation Solenoid Control Circuit/Open (For Gen IV controller)	P3457	Controller specific output driver circuit diagnoses the Cylinder 8 Deactivation Solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 k Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3459 may also set (Cylinder 8 Deactivation Solenoid Control Circuit/ Low)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 8 Deactivation Solenoid Control Circuit/Low (For Gen IV controller)	P3459	Controller specific output driver circuit diagnoses the Cylinder 8 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage low during driver off state (indicates an short circuit to Ground) Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3457 may also set (Cylinder 8 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 8 Deactivation Solenoid Control Circuit/High (For Gen IV controller)	P3460	Controller specific output driver circuit diagnoses the Cylinder 7 Deactivation Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	1.00 ≥ 11.00 volts ≥ 425.00 rpm	>= 20.00 errors out of 25.00 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 1 Deactivation Performance	P3498	When conditions are met, this diagnostic continuously monitors to detect valve-train deactivation system's failure to respond to cylinder 1 deactivation commands (both intake and exhaust valves remain activated), preventing the engine from achieving intended skip cycles. This diagnostic monitors filtered Manifold Absolute Pressure(MAP) to detect when a cylinder exhaust valve failed to deactivate when requested. This diagnostic is subject to an X/Y maturity criteria.	Filtered MAP is greated than the threshold when the cylinder of interest is commanded to be deactivated.	Filtered MAP < **Deac MAP Threshold**	Filtered APC Filtered MAP/BARO Filltered MAP/BARO OR Firing Fraction No Firing Fraction Change Transmission Gear Firing Fraction	> 120.00 mg > 0.30 < 0.95 == 0 > CeTGRR_e_TransGr2 <= 0.95	22.00 failures out of 25.00 opportunities Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 2 Deactivation Performance	P3499	When conditions are met, this diagnostic continuously monitors to detect valve-train deactivation system's failure to respond to cylinder 2 deactivation commands (both intake and exhaust valves remain activated), preventing the engine from achieving intended skip cycles. This diagnostic monitors filtered Manifold Absolute Pressure(MAP) to detect when a cylinder exhaust valve failed to deactivate when requested. This diagnostic is subject to an X/Y maturity criteria.	Filtered MAP is greated than the threshold when the cylinder of interest is commanded to be deactivated.	Filtered MAP < **Deac MAP Threshold**	Filtered APC Filtered MAP/BARO Filltered MAP/BARO OR Firing Fraction No Firing Fraction Change Transmission Gear Firing Fraction	> 120.00 mg > 0.30 < 0.95 == 0 > CeTGRR_e_TransGr2 <= 0.95	22.00 failures out of 25.00 opportunities Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 3 Deactivation Performance	P349A	When conditions are met, this diagnostic continuously monitors to detect valve-train deactivation system's failure to respond to cylinder 3 deactivation commands (both intake and exhaust valves remain activated), preventing the engine from achieving intended skip cycles. This diagnostic monitors filtered Manifold Absolute Pressure(MAP) to detect when a cylinder exhaust valve failed to deactivate when requested. This diagnostic is subject to an X/Y maturity criteria.	Filtered MAP is greated than the threshold when the cylinder of interest is commanded to be deactivated.	Filtered MAP < **Deac MAP Threshold**	Filtered APC Filtered MAP/BARO Filltered MAP/BARO OR Firing Fraction No Firing Fraction Change Transmission Gear Firing Fraction	> 120.00 mg > 0.30 < 0.95 == 0 > CeTGRR_e_TransGr2 <= 0.95	22.00 failures out of 25.00 opportunities Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 4 Deactivation Performance	P349B	When conditions are met, this diagnostic continuously monitors to detect valve-train deactivation system's failure to respond to cylinder 4 deactivation commands (both intake and exhaust valves remain activated), preventing the engine from achieving intended skip cycles. This diagnostic monitors filtered Manifold Absolute Pressure(MAP) to detect when a cylinder exhaust valve failed to deactivate when requested. This diagnostic is subject to an X/Y maturity criteria.	Filtered MAP is greated than the threshold when the cylinder of interest is commanded to be deactivated.	Filtered MAP < **Deac MAP Threshold**	Filtered APC Filtered MAP/BARO Filltered MAP/BARO OR Firing Fraction No Firing Fraction Change Transmission Gear Firing Fraction	> 120.00 mg > 0.30 < 0.95 == 0 > CeTGRR_e_TransGr2 <= 0.95	22.00 failures out of 25.00 opportunities Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 5 Deactivation Performance	P349C	When conditions are met, this diagnostic continuously monitors to detect valve-train deactivation system's failure to respond to cylinder 5 deactivation commands (both intake and exhaust valves remain activated), preventing the engine from achieving intended skip cycles. This diagnostic monitors filtered Manifold Absolute Pressure(MAP) to detect when a cylinder exhaust valve failed to deactivate when requested. This diagnostic is subject to an X/Y maturity criteria.	Filtered MAP is greated than the threshold when the cylinder of interest is commanded to be deactivated.	Filtered MAP < **Deac MAP Threshold**	Filtered APC Filtered MAP/BARO Filltered MAP/BARO OR Firing Fraction No Firing Fraction Change Transmission Gear Firing Fraction	> 120.00 mg > 0.30 < 0.95 == 0 > CeTGRR_e_TransGr2 <= 0.95	22.00 failures out of 25.00 opportunities Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 6 Deactivation Performance	P349D	When conditions are met, this diagnostic continuously monitors to detect valve-train deactivation system's failure to respond to cylinder 6 deactivation commands (both intake and exhaust valves remain activated), preventing the engine from achieving intended skip cycles. This diagnostic monitors filtered Manifold Absolute Pressure(MAP) to detect when a cylinder exhaust valve failed to deactivate when requested. This diagnostic is subject to an X/Y maturity criteria.	Filtered MAP is greated than the threshold when the cylinder of interest is commanded to be deactivated.	Filtered MAP < **Deac MAP Threshold**	Filtered APC Filtered MAP/BARO Filltered MAP/BARO OR Firing Fraction No Firing Fraction Change Transmission Gear Firing Fraction	> 120.00 mg > 0.30 < 0.95 == 0 > CeTGRR_e_TransGr2 <= 0.95	22.00 failures out of 25.00 opportunities Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 7 Deactivation Performance	P349E	When conditions are met, this diagnostic continuously monitors to detect valve-train deactivation system's failure to respond to cylinder 7 deactivation commands (both intake and exhaust valves remain activated), preventing the engine from achieving intended skip cycles. This diagnostic monitors filtered Manifold Absolute Pressure(MAP) to detect when a cylinder exhaust valve failed to deactivate when requested. This diagnostic is subject to an X/Y maturity criteria.	Filtered MAP is greated than the threshold when the cylinder of interest is commanded to be deactivated.	Filtered MAP < **Deac MAP Threshold**	Filtered APC Filtered MAP/BARO Filltered MAP/BARO OR Firing Fraction No Firing Fraction Change Transmission Gear Firing Fraction	> 120.00 mg > 0.30 < 0.95 == 0 > CeTGRR_e_TransGr2 <= 0.95	22.00 failures out of 25.00 opportunities Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 8 Deactivation Performance	P349F	When conditions are met, this diagnostic continuously monitors to detect valve-train deactivation system's failure to respond to cylinder 8 deactivation commands (both intake and exhaust valves remain activated), preventing the engine from achieving intended skip cycles. This diagnostic monitors filtered Manifold Absolute Pressure(MAP) to detect when a cylinder exhaust valve failed to deactivate when requested. This diagnostic is subject to an X/Y maturity criteria.	Filtered MAP is greated than the threshold when the cylinder of interest is commanded to be deactivated.	Filtered MAP < **Deac MAP Threshold**	Filtered APC Filtered MAP/BARO Filltered MAP/BARO OR Firing Fraction No Firing Fraction Change Transmission Gear Firing Fraction	> 120.00 mg > 0.30 < 0.95 == 0 > CeTGRR_e_TransGr2 <= 0.95	22.00 failures out of 25.00 opportunities Performed every 90 crank degree	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communication Bus A Off	U0073	This DTC monitors for a BUS A off condition	Bus off failures exceeds before the sample time of is reached	5 counts (equivalent to 0.06 seconds) 812.50 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A CAN hardware is bus OFF for The following criteria have been enabled for Transition from accessory mode to off is pending Battery Voltage Ignition Voltage Criteria: Power Mode Run/Crank Voltage Off Cycle Enable Criteria: KeCMGD_b_OffKeyCycle DiagEnbl KeDFIR_e_OBD_ControllerType is an OBD Controller Controller shutdown impending Power Mode	 Not Active on Current Key Cycle Enabled > 162.5000 seconds >= 3,000.00 milliseconds = False > 11.00 Volts = Run >= 11.00 Volts 0.00 (1 indicates enabled) OBD Controller = False = Not Run/Crank	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communication Bus B Off	U0074	This DTC monitors for a BUS B off condition	Bus off failures exceeds before the sample time of is reached	5 counts (equivalent to 0.06 seconds) 812.50 seconds	General Enable Criteria: U0074 Normal CAN transmission on Bus B CAN hardware is bus OFF for The following criteria have been enabled for Transition from accessory mode to off is pending Battery Voltage Ignition Voltage Criteria: Power Mode Run/Crank Voltage Off Cycle Enable Criteria: KeCMGD_b_OffKeyCycle DiagEnbl KeDFIR_e_OBD_Controll erType is an OBD Controller Controller shutdown impending Power Mode	 Not Active on Current Key Cycle Enabled > 162.5000 seconds >= 3,000.00 milliseconds = False > 11.00 Volts = Run >= 11.00 Volts 0.00 (1 indicates enabled) OBD Controller = False = Not Run/Crank	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With TCM	U0101	This DTC monitors for a loss of communication with the transmission control module	Message is not received from controller for		General Enable Criteria:		Diagnostic runs in 12.5 ms loop	Type A, 1 Trips
			Message $0BD	≥ 10,000.00 milliseconds	U0073	Not Active on Current Key Cycle		
			Message $0C7	≥ 500.00 milliseconds	Normal CAN transmission on Bus A	Enabled		
			Message $0F9	≥ 500.00 milliseconds	The following criteria have been enabled for	>= 3,000.00 milliseconds		
			Message $189	≥ 500.00 milliseconds	Transition from accessory mode to off is pending	= False		
			Message $199	≥ 500.00 milliseconds	Battery Voltage	> 11.00 Volts		
			Message $19D	≥ 500.00 milliseconds	Ignition Voltage Criteria:			
			Message $1AF	≥ 500.00 milliseconds	Power Mode	= Run		
			Message $1F5	≥ 500.00 milliseconds	Run/Crank Voltage	>= 11.00 Volts		
			Message $4C9	≥ 10,000.00 milliseconds	Off Cycle Enable Criteria:			
					KeCMGD_b_OffKeyCycle DiagEnbl	0.00 (1 indicates enabled)		
					KeDFIR_e_OBD_ControllerType is an OBD Controller	OBD Controller		
					Controller shutdown impending	= False		
					Power Mode	= Not Run/Crank		
					U0101	Not Active on Current Key Cycle		
					TCM	is present on the bus		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Transfer Case Control Module	U0102	This DTC monitors for a loss of communication with the transfer case control module	Message is not received from controller for Message $1CB Message $1CC	 ≥ 10,000.00 milliseconds ≥ 500.00 milliseconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A The following criteria have been enabled for Transition from accessory mode to off is pending Battery Voltage Ignition Voltage Criteria: Power Mode Run/Crank Voltage Off Cycle Enable Criteria: KeCMGD_b_OffKeyCycleDiagEnbl KeDFIR_e_OBD_ControllerType is an OBD Controller Controller shutdown impending Power Mode U0102 TCCM	 Not Active on Current Key Cycle Enabled >= 3,000.00 milliseconds = False > 11.00 Volts = Run >= 11.00 Volts 0.00 (1 indicates enabled) OBD Controller = False = Not Run/Crank Not Active on Current Key Cycle is present on the bus	Diagnostic runs in 12.5 ms loop	Type C, No SVS "Emissions Neutral Diagnostics – Type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Brake System Control Module	U0129	This DTC monitors for a loss of communication with the Brake System Control Module (OBD Module ID 7E5).	Message is not received from controller for Message $0C1 Message $0C5 Message $0D1 Message $1C6 Message $1C7 Message $1E9 Message $2F1 Message $2F9	≥ 500.00 milliseconds ≥ 500.00 milliseconds ≥ 500.00 milliseconds ≥ 500.00 milliseconds ≥ 500.00 milliseconds ≥ 10,000.00 milliseconds ≥ 500.00 milliseconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A The following criteria have been enabled for Transition from accessory mode to off is pending Battery Voltage Ignition Voltage Criteria: Power Mode Run/Crank Voltage Off Cycle Enable Criteria: KeCMGD_b_OffKeyCycle DiagEnbl KeDFIR_e_OBD_ControllerType is an OBD Controller Controller shutdown impending Power Mode U0129 Brake System Control Module	Not Active on Current Key Cycle Enabled >= 3,000.00 milliseconds = False > 11.00 Volts = Run >= 11.00 Volts 0.00 (1 indicates enabled) OBD Controller = False = Not Run/Crank Not Active on Current Key Cycle is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Body Control Module	U0140	This DTC monitors for a loss of communication with the Body Control Module.	Message is not received from controller for Message $0F1 Message $12A Message $1E1 Message $1F1 Message $1F3 Message $3C9 Message $3CB Message $3F1 Message $451 Message $4D7 Message $4E1 Message $4E9	≥ 500.00 milliseconds ≥ 10,000.00 milliseconds ≥ 500.00 milliseconds ≥ 500.00 milliseconds ≥ 10,000.00 milliseconds ≥ 10,000.00 milliseconds ≥ 10,000.00 milliseconds ≥ 10,000.00 milliseconds ≥ 500.00 milliseconds ≥ 10,000.00 milliseconds ≥ 10,000.00 milliseconds ≥ 10,000.00 milliseconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A The following criteria have been enabled for Transition from accessory mode to off is pending Battery Voltage Ignition Voltage Criteria: Power Mode Run/Crank Voltage Off Cycle Enable Criteria: KeCMGD_b_OffKeyCycle DiagEnbl KeDFIR_e_OBD_ControllerType is an OBD Controller Controller shutdown impending Power Mode U0140 Body Control Module	 Not Active on Current Key Cycle Enabled >= 3,000.00 milliseconds = False > 11.00 Volts = Run >= 11.00 Volts 0.00 (1 indicates enabled) OBD Controller = False = Not Run/Crank Not Active on Current Key Cycle is present on the bus	Diagnostic runs in 12.5 ms loop	Type C, No SVS "Emissions Neutral Diagnostics – Type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Gateway A	U0146	This DTC monitors for a loss of communication with Gateway A	Message is not received from controller for Message $3CF	≥ 10,000.00 milliseconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A The following criteria have been enabled for Transition from accessory mode to off is pending Battery Voltage Ignition Voltage Criteria: Power Mode Run/Crank Voltage Off Cycle Enable Criteria: KeCMGD_b_OffKeyCycleDiagEnbl KeDFIR_e_OBD_ControllerType is an OBD Controller Controller shutdown impending Power Mode U0146 Gateway Module	 Not Active on Current Key Cycle Enabled >= 3,000.00 milliseconds = False > 11.00 Volts = Run >= 11.00 Volts 0.00 (1 indicates enabled) OBD Controller = False = Not Run/Crank Not Active on Current Key Cycle is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Battery Monitor Module	U01B0	This DTC monitors for a loss of communication with the Battery Monitor Module on LIN bus	Message is not received from controller for		Normal transmission on LIN Bus	Enabled	Between 100ms and 175ms due to rate of LIN communication to Battery Monitor Module.	Type B, 2 Trips
			IBSAmpHourChg_18_C02	>= 0.00 milliseconds	IBS is active	> 3.00 seconds		
			IBSAmpHourDisChrg_19_C02	>= 0.00 milliseconds	LIN channel is enabled	1.00 (1 indicates enabled)		
			IBSCalcData_16_C02	>= 0.00 milliseconds	Diagnostic is enabled	1.00 (1 indicates enabled)		
			IBSCfgDataRtn_1E_C02	>= 0.00 milliseconds	One of the following Battery Saver Mode Diagnostics is Enabled:			
			IBSCurrentFOMData_1A_C02	>= 0.00 milliseconds	Battery Saver Mode Level 4 Diagnosis	1.00 (1 indicates enabled)		
			IBSFOMData_1C_C02	>= 0.00 milliseconds	Battery Saver Mode Level 5 Diagnosis	1.00 (1 indicates enabled)		
			IBSMeasuredTemp_17_C02	>= 0.00 milliseconds	Battery Saver Mode Level 6 Diagnosis	1.00 (1 indicates enabled)		
			IBSMVIData_15_C02	>= 0.00 milliseconds	Battery Saver Mode Level 7 Diagnosis	1.00 (1 indicates enabled)		
			IBSVehStartData_1D_C02	>= 0.00 milliseconds	The following criteria have been enabled for	>= 3,000.00 milliseconds		
			IBSVoltageFOMData_1B_C02	>= 0.00 milliseconds	Transition from accessory mode to off is pending	= False		
					Battery Voltage	> 11.00 Volts		
					Ignition Voltage Criteria:			
					Power Mode	= Run		
					Run/Crank Voltage	>= 11.00 Volts		
					Off Cycle Enable Criteria:			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					KeCMGD_b_OffKeyCycle DiagEnbl KeDFIR_e_OBD_Controll erType is an OBD Controller Controller shutdown impending Power Mode Battery Monitor Module	0.00 (1 indicates enabled) OBD Controller = False = Not Run/Crank is present on the bus and initialized		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication with Active Grill Air Shutter Module A	U0284	This DTC monitors for a loss of communication on the LIN bus with Shutter Module A	Message is not received from controller for		Normal transmission on LIN Bus	Enabled	LIN bus communication executes in 500ms loop	Type B, 2 Trips
			ACM1Rsp_31_C02	>= 0.00 milliseconds	Actuator relay	is powered		
			ACM1Rsp_31_C01	>= 0.00 milliseconds	Or			
					Powertrain Relay and Powertrain Relay state feedback is enabled	is on 1.00 (1 indicates enabled)		
					LIN channel is enabled	1.00 (1 indicates enabled)		
					Diagnostic is enabled	0.00 (1 indicates enabled)		
					The following criteria have been enabled for	>= 3,000.00 milliseconds		
					Transition from accessory mode to off is pending	= False		
					Battery Voltage	> 11.00 Volts		
					Ignition Voltage Criteria:			
					Power Mode	= Run		
					Run/Crank Voltage	>= 11.00 Volts		
					Off Cycle Enable Criteria:			
					KeCMGD_b_OffKeyCycle DiagEnbl	0.00 (1 indicates enabled)		
					KeDFIR_e_OBD_ControllerType is an OBD Controller	OBD Controller		
					Controller shutdown impending	= False		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Mode ACM1	= Not Run/Crank is present on the bus and initialized		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Mass or Volume Air Flow Sensor A	U060F	This DTC monitors for a loss of communication on the LIN bus with Mass or Volume Air Flow Sensor A	Message is not received from MAF for MAF_Rsp_Press_2B_C03 MAF_Rsp_TmpHum_2A_C03	 >= 0.00 milliseconds >= 0.00 milliseconds	Normal transmission on LIN Bus Actuator relay Or Powertrain Relay and Powertrain Relay state feedback is enabled LIN channel is enabled Diagnostic is enabled The following criteria have been enabled for Transition from accessory mode to off is pending Battery Voltage Ignition Voltage Criteria: Power Mode Run/Crank Voltage Off Cycle Enable Criteria: KeCMGD_b_OffKeyCycleDiagEnbl KeDFIR_e_OBD_ControllerType is an OBD Controller Controller shutdown impending	Enabled is powered is on 1.00 (1 indicates enabled) 1.00 (1 indicates enabled) 1.00 (1 indicates enabled) >= 3,000.00 milliseconds = False > 11.00 Volts = Run >= 11.00 Volts 0.00 (1 indicates enabled) OBD Controller = False	LIN bus communication executes in 500ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Mode MAF	= Not Run/Crank is present on the bus and initialized		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Control Module LIN Bus 2	U1346	This DTC monitors for a LIN bus off condition on LIN Bus 2	The total number of diagnostic enabled slave nodes on LIN Bus 2 Or LIN channel wakeup repetition counter	= Total number of slave nodes on LIN Bus 2 that have reported "loss commn with device" >= 10.00 counts	LIN channel is enabled Diagnostic is enabled The following criteria have been enabled for Transition from accessory mode to off is pending Battery Voltage Ignition Voltage Criteria: Power Mode Run/Crank Voltage Off Cycle Enable Criteria: KeCMGD_b_OffKeyCycle DiagEnbl KeDFIR_e_OBD_ControllerType is an OBD Controller Controller shutdown impending Power Mode	1.00 (1 indicates enabled) 1.00 (1 indicates enabled) >= 3,000.00 milliseconds = False > 11.00 Volts = Run >= 11.00 Volts 0.00 (1 indicates enabled) OBD Controller = False = Not Run/Crank	Dependent on bus loading.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Fuel Pump Driver Control Module on Bus S	U18A2	This DTC monitors for a loss of communication with the Fuel Pump Driver Control Module on Bus S	Message is not received from controller for Message $0D5 Message $0D7	 ≥ 10,000.00 milliseconds ≥ 10,000.00 milliseconds	General Enable Criteria: U0074 Normal CAN transmission on Bus B The following criteria have been enabled for Transition from accessory mode to off is pending Battery Voltage Ignition Voltage Criteria: Power Mode Run/Crank Voltage Off Cycle Enable Criteria: KeCMGD_b_OffKeyCycle DiagEnbl KeDFIR_e_OBD_ControllerType is an OBD Controller Controller shutdown impending Power Mode U18A2 Fuel Pump Driver Control	 Not Active on Current Key Cycle Enabled >= 3,000.00 milliseconds = False > 11.00 Volts = Run >= 11.00 Volts 0.00 (1 indicates enabled) OBD Controller = False = Not Run/Crank Not Active on Current Key Cycle is present on the bus	Diagnostic runs in 12.5 ms loop	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Module			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With DC/ DC Converter Control Module on Bus B	U18A7	This DTC monitors for a loss of communication with the DC/DC Converter Control Module on Bus B	Message is not received from controller for Message $0A0 Message $1D2	 ≥ 10,000.00 milliseconds ≥ 10,000.00 milliseconds	General Enable Criteria: U0074 Normal CAN transmission on Bus B The following criteria have been enabled for Transition from accessory mode to off is pending Battery Voltage Ignition Voltage Criteria: Power Mode Run/Crank Voltage Off Cycle Enable Criteria: KeCMGD_b_OffKeyCycle DiagEnbl KeDFIR_e_OBD_ControllerType is an OBD Controller Controller shutdown impending Power Mode U18A7 DC/DC Converter Control Module	 Not Active on Current Key Cycle Enabled >= 3,000.00 milliseconds = False > 11.00 Volts = Run >= 11.00 Volts 0.00 (1 indicates enabled) OBD Controller = False = Not Run/Crank Not Active on Current Key Cycle is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
CGM Lost Communication with ECM	U18D5	This DTC monitors for a CGM Lost Communication with ECM error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame $3CF indicates that the CGM Lost Communication with ECM DTC has set in the CGM.		General Enable Criteria: Message $3CF Central Gateway Module ECM	 is being received is present on the bus is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
CGM Lost Communication with TCM	U18D7	This DTC monitors for a CGM Lost Communication with TCM error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame $3CF indicates that the CGM Lost Communication with TCM DTC has set in the CGM.		General Enable Criteria: Message $3CF Central Gateway Module TCM	 is being received is present on the bus is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
CGM Lost Communication with BSCM1	U18DC	This DTC monitors for a CGM Lost Communication with BSCM1 error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame $3CF indicates that the CGM Lost Communication with BSCM1 DTC has set in the CGM.		General Enable Criteria: Message $3CF Central Gateway Module BSCM1	 is being received is present on the bus is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication with Front Object Detection Control Module	U216A	This DTC monitors for a loss of communication with the Front Object Detection Control Module.	Messages are not received from controller for Message $2CB Message $2CD Message $2CF Message $370	≥ 500.00 milliseconds ≥ 500.00 milliseconds ≥ 500.00 milliseconds ≥ 10,000.00 milliseconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A The following criteria have been enabled for Transition from accessory mode to off is pending Battery Voltage Ignition Voltage Criteria: Power Mode Run/Crank Voltage Off Cycle Enable Criteria: KeCMGD_b_OffKeyCycleDiagEnbl KeDFIR_e_OBD_ControllerType is an OBD Controller Controller shutdown impending Power Mode U216A EOCM, FCM, or RDCM modules (Front Object	 Not Active on Current Key Cycle Enabled >= 3,000.00 milliseconds = False > 11.00 Volts = Run >= 11.00 Volts 0.00 (1 indicates enabled) OBD Controller = False = Not Run/Crank Not Active on Current Key Cycle is present on the bus	Diagnostic runs in 12.5 ms loop	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Detection Modules)			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Central Gateway Module High Speed CAN Bus Off	U2413	This DTC monitors for a Central Gateway Module High Speed CAN Bus Off error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame $3CF indicates that the Central Gateway Module High Speed CAN Bus Off DTC has set in the CGM.		General Enable Criteria: Message $3CF Central Gateway Module	 is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Central Gateway Module High Speed Extension CAN Bus Off	U2414	This DTC monitors for a Central Gateway Module High Speed Extension CAN Bus Off error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame $3CF indicates that the Central Gateway Module High Speed Extension CAN Bus Off DTC has set in the CGM.		General Enable Criteria: Message $3CF Central Gateway Module	 is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Central Gateway Module Chassis Expansion CAN Bus Off	U2415	This DTC monitors for a Central Gateway Module Chassis Expansion CAN Bus Off error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame $3CF indicates that the Central Gateway Module Chassis Expansion CAN Bus Off DTC has set in the CGM.		General Enable Criteria: Message $3CF Central Gateway Module	 is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 1 Deactivation Solenoid Control Circuit/Open	P3401	Controller specific output driver circuit diagnoses the Cylinder 1 Deactivation Solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 k Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	Enabled ≥ 11.00 volts ≥ 400 rpm	>= 20 errors out of 25 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3403 may also set (Cylinder 1 Deactivation Solenoid Control Circuit/ Low)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 1 Deactivation Solenoid Control Circuit/Low	P3403	Controller specific output driver circuit diagnoses the Cylinder 1 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	Enabled ≥ 11.00 volts ≥ 400 rpm	>= 20 errors out of 25 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3401 may also set (Cylinder 1 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 1 Deactivation Solenoid Control Circuit/High	P3404	Controller specific output driver circuit diagnoses the Cylinder 1 Deactivation Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	Enabled ≥ 11.00 volts ≥ 400 rpm	>= 20 errors out of 25 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 4 Deactivation Solenoid Control Circuit/Open	P3425	Controller specific output driver circuit diagnoses the Cylinder 4 Deactivation Solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 k Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	Enabled ≥ 11.00 volts ≥ 400 rpm	>= 20 errors out of 25 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3427 may also set (Cylinder 4 Deactivation Solenoid Control Circuit/ Low)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 4 Deactivation Solenoid Control Circuit/Low	P3427	Controller specific output driver circuit diagnoses the Cylinder 4 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Controller specific output driver circuit diagnoses the Cylinder 1 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	Enabled ≥ 11.00 volts ≥ 400 rpm	>= 20 errors out of 25 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3425 may also set (Cylinder 4 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 4 Deactivation Solenoid Control Circuit/High	P3428	Controller specific output driver circuit diagnoses the Cylinder 4 Deactivation Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.Diagnoses cylinder 4 deactivation solenoid control low side driver circuit for circuit faults	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	Enabled ≥ 11.00 volts ≥ 400 rpm	>= 20 errors out of 25 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 6 Deactivation Solenoid Control Circuit/Open	P3441	Controller specific output driver circuit diagnoses the Cylinder 6 Deactivation Solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds	Voltage low during driver off state (indicates open circuit)Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 k Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	Enabled ≥ 11.00 volts ≥ 400 rpm	>= 20 errors out of 25 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3443 may also set (Cylinder 6 Deactivation Solenoid Control Circuit/ Low)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 6 Deactivation Solenoid Control Circuit/Low	P3443	Controller specific output driver circuit diagnoses the Cylinder 6 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	Enabled ≥ 11.00 volts ≥ 400 rpm	>= 20 errors out of 25 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3441 may also set (Cylinder 6 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 6 Deactivation Solenoid Control Circuit/High	P3444	Controller specific output driver circuit diagnoses the Cylinder 6 Deactivation Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	Enabled ≥ 11.00 volts ≥ 400 rpm	>= 20 errors out of 25 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 7 Deactivation Solenoid Control Circuit/Open	P3449	Controller specific output driver circuit diagnoses the Cylinder 7 Deactivation Solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 k Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	Enabled ≥ 11.00 volts ≥ 400 rpm	>= 20 errors out of 25 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3451 may also set (Cylinder 7 Deactivation Solenoid Control Circuit/ Low)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 7 Deactivation Solenoid Control Circuit/Low	P3451	Controller specific output driver circuit diagnoses the Cylinder 7 Deactivation Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage low during driver off state (indicates an short circuit to Ground) Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Engine RPM	Enabled ≥ 11.00 volts ≥ 400 rpm	>= 20 errors out of 25 samples Performed every 250 msec	Type B, 2 Trips Note: In certain controllers P3449 may also set (Cylinder 7 Deactivation Solenoid Control Circuit/ Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 7 Deactivation Solenoid Control Circuit/High	P3452	Controller specific output driver circuit diagnoses the Cylinder 7 Deactivation Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Engine RPM	Enabled ≥ 11.00 volts ≥ 400 rpm	>= 20 errors out of 25 samples Performed every 250 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Circuit Performance (OAT Wired to IPC)	P0071	Detects an OAT sensor that has stuck in range by comparing to IAT when conditions are appropriate	(IAT - OAT) OR (OAT - IAT)	> 20.0 deg C > 20.0 deg C	Time between current ignition cycle and the last time the engine was running (IAT - Coolant Temp) (Coolant Temp - IAT) (Engine is not running OR Engine run time Ignition Voltage No Active DTCs:	 >= 28,800.0 seconds <= 20.0 deg C <= 20.0 deg C <= 0.1 seconds) >= 11.0 Volts IAT_SensorFA ECT_Sensor_FA EngineModeNotRunTimer Error	5 failures out of 10 samples Executed every 100 msec	Type X, No MIL

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Sensor Performance - Single Sensor	P0191	The DTC Diagnoses a skewed fuel rail sensor via a comparison of measured pressure and commanded/ modeled pressure	Idle test (Low Side Fuel Pressure - High Side Fuel Pressure)	SIDI High Pressure Sensor Performance Diagnostic Enabled and SIDI High Pressure Sensor Performance Idle Test Enabled <= -1.000 MPa OR >= 1.000 MPa	Vehicle Speed Pedal Position = 0 for Battery Voltage Low Pressure Fuel Pump Pressure Engine Run Time Delay counts after pump is turned off	Enabled when a code clear is not active or not exiting device control Engine is not cranking <= 0.62 MPH 200 Counts (12.5ms per count) >= 11 Volts >= 0.250 MPa >= KtFHPD_t_PumpCntrlEngRunThrsh (see supporting tables) Enabled when a code clear is not active or not exiting device control Engine is not cranking >= KtFHPD_Cnt_SnsPrfIdlePumpOffDly (see supporting tables)	Idle Test > = 240 counts (12.5ms per count)	Type A, 1 Trips
			---	---	---	---	---	
			High Drive Test (Relief Pressure - Measured high Pressure)	SIDI High Pressure Sensor Performance Diagnostic Enabled and	Engine Speed Desired High Side Pressure Vehicle Speed	1,000 <= RPM <= 3,000 4 <= MPa <= 6 >= 22 MPH	KtFHPD_Cnt_SnsPrfIdlePumpOffDly runs in 12.5 ms loopHigh Drive Test >= 160	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				SIDI High Pressure Sensor Performance High Drive Test Enabled <= -1.60 MPa	Accelerator Pedal Battery Voltage Low Pressure Fuel Pump Pressure Engine Run Time	>= 10 % >= 11 Volts >= 0.250 MPa >= KtFHPD_t_PumpCntrlEngRunThrsh(see supporting tables) Enabled when a code clear is not active or not exiting device control Engine is not cranking	counts (12.5ms per count)	
			--- Low Drive Test (Commanded high Pressure - Measured high Pressure) AND Modeled Injection Pressure	--- SIDI High Pressure Sensor Performance Diagnostic Enabled and SIDI High Pressure Sensor Performance Low Drive Test Enabled >= 3.000 MPa >= 1.60 MPa	--- Engine Speed Desired High Side Pressure Vehicle Speed Accelerator Pedal Battery Voltage Low Pressure Fuel Pump Pressure Engine Run Time	--- 1,000 <= RPM <= 3,000 4.00 <= MPa <= 6.00 >= 22 MPH >= 10 % >= 11 Volts >= 0.250 MPa >= KtFHPD_t_PumpCntrlEngRunThrsh(see supporting tables) Enabled when a code clear is not active or not	--- LoDrive Test >= 240 counts (12.5ms per count)	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			---------- Sensor Stuck Test Measured High Pressure (max - min)	---------- SIDI High Pressure Sensor Performance Diagnostic Enabled and SIDI High Pressure Sensor Performance Stuck Test Enabled <= 0.100 MPa	---------- Engine Speed Vehicle Speed	exiting device control Engine is not cranking ---------- >= 2,000 RPM >= 18.64 MPH Enabled when a code clear is not active or not exiting device control Engine is not cranking Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and Manufacturers enable counter is 0)Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682)	---------- Stuck Test Engine Run Time >= KtFHPD_t_PumpCntrlEngRunThrsh (See Supporting Tables) or Accumulating engine crank time >= KtFHPD_t_SnsPrfStuckCrankTmout (See Supporting Tables)	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Barometric Pressure Inlet Air Temp Fuel Temp	not active Fuel InjCkt Not (FA or TFTKO) EST Driver Not(FA) Misfire detected Not(FA) MAFR sensor Not (FA) MAPR sensor Not (FA) APSR Pedal sensor Not(FA) TPSR sensor Not (FA) VSPR speed sensor Not(FA) SystemRPM Not (FA) Manual Clutch not engaged or vehicle has automatic transmission All cylinder are fuel enabled and >= 70.0 KPA >= -20.0 DegC -20 <= Temp degC <= 125		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Sensor Out of Range Low	P0192	This DTC Diagnoses High Pressure Sensor Out of Range Low	High Pressure Fuel Sensor	SIDI High Pressure Sensor 1 Out of range Time Based Enabled or SIDI High Pressure Sensor 1 Out of range Engine Synchronous Enabled <= 4 % of 5Vref	Battery Voltage	>= 11 Volts Engine Running	Both Run Continuously Engine Synchronous Mode 800 failures out of 1,000 samples Time Based Mode 400 failures out of 500 samples 6.25 ms Sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Sensor Out of Range High	P0193	This DTC Diagnoses High Pressure Sensor Out of Range High	High Pressure Fuel Sensor	SIDI High Pressure Sensor 1 Out of range Time Based Enabled or SIDI High Pressure Sensor 1 Out of range Engine Synchronous Enabled >= 96 % of 5Vref	Battery Voltage	>= 11 Volts Engine Running	Both Run Continuously Engine Synchronous Mode 800 failures out of 1,000 samples Time Based Mode 400 failures out of 500 samples 6.25 ms Sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Current Monitoring Performance	P058B	This DTC monitors for a battery module current fault	If the absolute value of the difference between the Battery Monitor Module current and Ithe ECM measured reference current is For Failures	>= 22.00 amps >= 160.00 counts	The diagnostic is enabled Power Mode Battery Current Sensor circuit fault active Current has been stable (engine not starting or stopping) for If vehicle speed monitoring is enabled Then Vehicle speed	= 1.00 (1 indicates enabled) = Run/Crank = False > 40.00 counts 0.00 (1 indicates enabled) > 5.00 kph	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Voltage Monitoring Performance	P058D	This DTC monitors for a battery module voltage fault	The absolute value of the difference between the Battery Monitor Module voltage and the ECM measure reference voltage is greater than	> 2.00 Volts	The diagnostic is enabled Power Mode Current has been stable (engine not starting or stopping) for If vehicle speed monitoring is enabled Then Vehicle speed Ignition 1 Switch Circuit 2 Fault Active (P1682)	= 1.00 (1 indicates enabled) = Run/Crank > 40.00 counts 0.00 (1 indicates enabled) > 5.00 kph = False	160.00 failed samples within 200.00 total samples Diagnostic runs in the 250 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Current Sensor A Circuit Low (Battery Monitor Module, non-IBSM)	P118C	Detects a continuous short to ground or open in the Battery Current Sensor A signal.	Battery Current Sensor A is less than threshold.	-400.00 Amp	Diagnostic Enabled Run/Crank or Accessory	TRUE TRUE	160.00 failures out of 200.00 samples 25 ms/sample continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Current Sensor A Circuit High (Battery Monitor Module, non-IBSM)	P118D	Detects a continuous short to power in the Battery Current Sensor A signal.	Battery Current Sensor A is greater than threshold.	150.00 Amp	Diagnostic Enabled Run/Crank or Accessory	TRUE TRUE	160.00 failures out of 200.00 samples 25 ms/sample continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Dual Battery Monitor Module Performance	P305F	This DTC monitors for a dual battery module voltage fault between consecutive auto-start events.	ECM measured battery voltage is less than threshold for present auto-start event.	8.90 Volts	The diagnostic is enabled Hybrid Starter Status (Engine starting time)	= 1 (1 indicates enabled) > 0.00 seconds	5.00 failures out of 10.00 samples taken during auto-start event. 6.25 ms/sample	Type A, 1 Trips
			Exceeded consecutive number of auto-start events where Present Auto-Start Event malfunction criteria was met.	2.00 auto-start events	The diagnostic is enabled	= 1 (1 indicates enabled)	2.00 auto-start events out of 3.00 samples	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Booster Pressure Sensor Performance	P0556	Determines if the Brake Booster Vacuum Sensor is stuck or skewed within the normal operating range by comparing the engine vacuum to the brake booster vacuum when the engine is producing a large amount of vacuum	Engine vs brake booster vacuum sensor values are compared when % throttle < value for a time period. When throttle once again > calibrated value, min and max vacuum sensor values are normalized and subtracted from a 1st order lag filter value of 1. A properly operating vacuum sensor would have a normalized result of 1 or greater. If the normalized result is greater than 1 it is considered 1. The 1st order lag filter value would be 0 in a passing system. 1st order lag fail threshold 1st order lag re-pass threshold	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Booster Pressure Sensor Circuit Low Voltage	P0557	Determines if the Brake Booster Pressure Sensor circuit voltage is too low	(Brake Booster Pressure Sensor Voltage) ÷ 5 Volts *100	< 5.00 percent	Brake booster diagnostic enabled/disabled Brake booster pressure sensor present	Enabled Present	320 failures out of 400 samples Performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Booster Pressure Sensor Circuit High Voltage	P0558	Determines if the Brake Booster Pressure Sensor circuit voltage is too high	(Brake Booster Pressure Sensor Voltage) ÷ 5 Volts *100	> 95.00 percent	Brake booster diagnostic enabled/disabled Brake booster pressure sensor present	Enabled Present	2,000 failures out of 2,400 samples Performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow A Supply Voltage Control Circuit	P121A	Controller specific output driver circuit diagnoses the Mass Air Flow A Supply Voltage Control low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between output and controller ground	Mass Air Flow A Power is commanded on Powertrain Relay Voltage	 >= 11.0 Volts	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips Note: In certain controllers P121B may also set (Mass Air Flow A Supply Voltage Control Circuit Low)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow A Supply Voltage Control Circuit Low	P121B	Controller specific output driver circuit diagnoses the Mass Air Flow A Supply Voltage Control low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between output and controller ground	Mass Air Flow A Power is commanded on Powertrain Relay Voltage	 >= 11.0 Volts	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips Note: In certain controllers P121A may also set (Mass Air Flow A Supply Voltage Control Circuit)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow A Supply Voltage Control Circuit High	P121C	Controller specific output driver circuit diagnoses the Mass Air Flow A Supply Voltage Control low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between output and controller power	Mass Air Flow A Power is commanded off Powertrain Relay Voltage	 >= 11.0 Volts	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Performance Signal Message Counter Incorrect	P155F	This DTC monitors for an error in communication with the DC/DC Converter Internal Health Signal	Communication of the Alive Rolling Count or Protection Value from the DC/DC Converter over CAN bus is incorrect for out of total samples	 >= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 25ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)-Camshaft Position (CMP) Correlation Bank 2 Sensor A (end-park phaser)	P0018	Detects cam to crank misalignment by monitoring if the cam sensor pulse for bank 2 sensor A occurs during the incorrect crank position, diagnostic passes when the cam sensor pulse is in the expected range	2 cam sensor pulses less than or greater than nominal position in one cam revolution..	 -11.0 Crank Degrees 13.0 Crank Degrees	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic Delay diagnostic if Engine RPM and Cam is Enabled for	 CrankSensor_FA P0345, P0346 < 1.0 seconds > 8,200.00 < 3.00	2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table **P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold** . One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft - Sprocket Correlation Diagnostic	P0018 and P0019	On engines with a dual intermediate sprocket between the crankshaft and the camshafts, this diagnostic detects a timing misalignment between the crankshaft, sprocket and camshafts that will cause the bank 2 camshafts to be misaligned.	Bank 2 Cam Sensor A pulses more than -6.1 crank degrees before or 9.9 crank degrees after nominal position in one cam revolution + Bank 2 Cam Sensor B pulses more than -7.3 crank degrees before or 9.9 crank degrees after nominal position in one cam revolution	>= 8	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs:	CrankSensor_FA P0345, P0346 P0390, P0391	2 failures out of 3 tests. A failed test is 1 out of 10 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table **P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold** . One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)-Camshaft Position (CMP) Correlation Bank 2 Sensor B (end-park phaser)	P0019	Detects cam to crank misalignment by monitoring if the cam sensor pulse for bank 2 sensor B occurs during the incorrect crank position, diagnostic passes when the cam sensor pulse is in the expected range	2 cam sensor pulses less than or greater than nominal position in one cam revolution..	 -9.3 Crank Degrees 11.1 Crank Degrees	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic Delay diagnostic if Engine RPM and Cam is Enabled for	 CrankSensor_FA P0390, P0391 < 1.0 seconds > 8,200.00 < 3.00	2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table **P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold** . One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Press Regulator Solenoid Supply Voltage Control High Side Circuit Open	P00C8	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	>= 200 KOhms impedance between signal and controller ground	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit Low (Gen II)	P0107	Detects a continuous short to ground or open circuit in the Manifold Absolute Pressure (MAP) signal circuit by monitoring the MAP sensor output voltage and failing the diagnostic when the MAP voltage is too low. The MAP sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	MAP Voltage	< 3.3 % of 5 Volt Range (This is equal to 7.5 kPa)	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit High (Gen II)	P0108	Detects a continuous short to power in the Manifold Absolute Pressure (MAP) signal circuit by monitoring the MAP sensor output voltage and failing the diagnostic when the MAP voltage is too high. The MAP sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	MAP Voltage	> 68.0 % of 5 Volt Range (This is equal to 291.0 kPa)	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Boost Pressure (TIAP) Sensor Performance (twin turbo)	P0236	Detects a performance failure in the Turbocharger Boost Pressure sensor, such as when a Turbocharger Boost Pressure value is stuck in range. If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The Turbocharger Boost Pressure sensor value is checked to see if it is within the normal expected atmospheric pressure range. If it is not, then the Turbocharger Boost Pressure performance diagnostic will fail. If the Turbocharger Boost Pressure sensor value is within the normal expected atmospheric range, then Manifold Pressure (MAP), Turbocharger Boost Pressure, Barometric Pressure (BARO) and BARO B are compared to see if their values are similar. If the MAP, BARO and BARO B sensor values are similar, but the Turbocharger Boost	**Engine Running:** See table **P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix** for combinations of model failures that can set this DTC. MAF model fails when either MAF1 model fails or MAF2 model fails. MAF1 model fails when ABS(Measured MAF1 Flow – Modeled MAF1 Flow) Filtered MAF2 model fails when ABS(Measured MAF2 Flow – Modeled MAF2 Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP - TIAP Model 1) Filtered	> 25.0 grams/sec > 25.0 grams/sec > 25.0 kPa > 25.0 kPa > 25.0 kPa > 30.0 kPa	Engine Speed Engine Speed (Coolant Temp OR OBD Coolant Enable Criteria Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together) See Residual Weight Factor tables.	>= 400 RPM <= 6,500 RPM >= -9 Deg C = TRUE) <= 150 Deg C >= -20 Deg C <= 125 Deg C >= 0.50 Modeled MAF1 Error multiplied by **P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM** and **P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est** Modeled MAF2 Error multiplied by **P0101, P0106, P010B, P0121, P0236, P1101: MAF2 Residual Weight Factor based on MAF Est** and **P0101, P0106, P010B, P0121, P0236, P1101: MAF2 Residual Weight Factor based on RPM**	Continuous Calculation are performed every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Pressure value is not similar, then a Turbocharger Boost Pressure performance diagnostic will fail. The engine running portion of this diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Mass Air Flow (MAF) sensor, MAF B sensor, Manifold Pressure (MAP) sensor and Throttle Position sensor (TPS). These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the Turbocharger Boost Pressure sensor. In this case, the	TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset** OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset** TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time	> 350 kPa*(g/s) > 30.0 kPa > 30.0 kPa > 1.5 seconds > 1.5 seconds	No Active DTCs:	MAP Model 1 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM** MAP Model 2 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP Model 3 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM** TIAP Model 1 Error multiplied by **P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM** Filtered Throttle Model Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM** MAP_SensorCircuitFA EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Turbocharger Boost Pressure Performance diagnostic will fail.	High Engine Air Flow is TRUE when Mass Air Flow	> a threshold in gm/sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow**	No Pending DTCs:	IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP		
			AND Manifold Pressure	> a threshold in kPa as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP**				
			AND Filtered Mass Air Flow - Mass Air Flow	< 2.0 gm/sec				
			Low Engine Air Flow is TRUE when Mass Air Flow	< a threshold in gm/sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow**				
			AND Manifold Pressure	< a threshold in kPa as a function of engine speed See table				
			-					

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AND Mass Air Flow - Filtered Mass Air Flow	**P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP** < 2.0 gm/sec				
			Engine Not Rotating: Turbocharger Boost Pressure OR Turbocharger Boost Pressure OR ABS(Manifold Pressure - Turbocharger Boost Pressure) AND ABS(Manifold Pressure - Baro Pressure) AND ABS(Manifold Pressure - Baro Pressure B) AND ABS(Turbocharger Boost Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure B) AND ABS(Baro Pressure - Baro Pressure B)	 < 50.0 kPa OR > 115.0 kPa > 10.0 kPa AND <= 10.0 kPa AND <= 10.0 kPa AND > 10.0 kPa AND > 10.0 kPa AND <= 10.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating No Active DTCs: No Pending DTCs:	> 10.0 seconds EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA AAP2_SnsrCktFA AAP3_SnsrCktFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP AAP3_SnsrCktFP	4 failures out of 5 samples 1 sample every 12.5 msec	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Boost Pressure Sensor Circuit Low (Gen II)	P0237	Detects a continuous short to ground or open circuit in the Turbocharger Boost Pressure signal circuit by monitoring the Turbocharger Boost Pressure sensor output voltage and failing the diagnostic when the Turbocharger Boost Pressure voltage is too low. The Turbocharger Boost Pressure sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	Turbocharger Boost Pressure Voltage	< 14.4 % of 5 Volt Range (This is equal to 50.0 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Boost Pressure Sensor Circuit High (Gen II)	P0238	Detects a continuous short to power in the Turbocharger Boost Pressure signal circuit by monitoring the Turbocharger Boost Pressure sensor output voltage and failing the diagnostic when the Turbocharger Boost Pressure voltage is too high. The Turbocharger Boost Pressure sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	Turbocharger Boost Pressure Voltage	> 68.5 % of 5 Volt Range (This is equal to 293.3 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Intercooler Coolant Pump Control Circuit If Intercooler pump are present	P023A	Controller specific output driver circuit diagnoses the 'charged air cooler pump' low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between output and controller ground	Diagnostic enabled ********** Powertrain relay voltage Ignition run crank voltage ********** Engine is not cranking Diagnostic system not disabled	True ********** >= 11.0 Volts > 5.00 Volts **********	20 failures out of 100 samples 100ms / sample	Type A, 1 Trips Note: In certain controllers P023B may also set turbo/ super charger intercooler coolant pump control circuit low

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Intercooler Coolant Pump Control Circuit Low If Intercooler pump are present	P023B	Controller specific output driver circuit diagnoses the 'charged air cooler pump' low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground. In certain controlers this diagnosis runs only when the HWIO-output is driven by the application S/W.	≤ 0.5 Ω impedance between output and controller ground	Diagnostic enabled ********** Powertrain relay voltage Ignition run crank voltage ********** Engine is not cranking Diagnostic system not disabled	True ********** >= 11.0 Volts > 5.00 Volts **********	20 failures out of 100 samples 100ms / sample	Type A, 1 Trips Note: In certain controlle rs P023A may also set turbo/ super charger intercool er coolant pump control circuit

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Intercooler Coolant Pump Control Circuit High If Intercooler pump are present	P023C	Controller specific output driver circuit diagnoses the 'charged air cooler pump' low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power. In certain controlers this diagnosis runs only when the HWIO-output is driven by the application S/W.	≤ 0.5 Ω impedance between output and controller power	Diagnostic enabled ********** Powertrain relay voltage Ignition run crank voltage ********** Engine is not cranking Diagnostic system not disabled	True ********** >= 11.0 Volts > 5.00 Volts **********	20 failures out of 100 samples 100ms / sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Wastegate / Supercharger Boost Solenoid B Control Circuit If two parallel turbos are present.	P0247	Controller specific output driver circuit diagnostic, diagnosing the 'turbocharger boost solenoid 'B' actuator' low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. In series applications, turbocharger 'B' is the second turbocharger in the direction of exhaust flow. In a parallel application, turbocharger 'B'is associated with engine bank 2.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between output and controller ground	Diagnostic enabled ********** Powertrain relay voltage Ignition run crank voltage ********** Engine does not crank Diagnostic system not disabled	True ********** >= 11.0 Volts > 5.00 Volts **********	50 failures out of 63 samples 100ms / sample	Type A, 1 Trips Note: In certain controllers P0249 may also set turbocharger wastegate / supercharger boost solenoid B control circuit low

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Wastegate / Supercharger Boost Solenoid B Control Circuit Low If two parallel turbos are present.	P0249	Controller specific output driver circuit diagnostic, diagnosing the 'turbocharger boost solenoid 'B' actuator' low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. In series applications, turbocharger 'B' is the second turbocharger in the direction of exhaust flow. In a parallel application, turbocharger 'B'is associated with engine bank 2.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground. In certain controllers this diagnosis runs only when the HWIO-output is driven by the application S/W.	≤ 0.5 Ω impedance between output and controller ground	Diagnostic enabled ********** Powertrain relay voltage Ignition run crank voltage ********** Engine does not crank Diagnostic system not disabled	True ********** >= 11.0 Volts > 5.00 Volts **********	50 failures out of 63 samples 100ms / sample	Type A, 1 Trips Note: In certain controllers P0247 may also set turbocharger wastegate / supercharger boost solenoid B control circuit

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Wastegate / Supercharger Boost Solenoid B Control Circuit High If two parallel turbos are present.	P0250	Controller specific output driver circuit diagnostic, diagnosing the 'turbocharger boost solenoid 'B' actuator' low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds. In series applications, turbocharger 'B' is the second turbocharger in the direction of exhaust flow. In a parallel application, turbocharger 'B'is associated with engine bank 2.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power. In certain controllers this diagnosis runs only when the HWIO-output is driven by the application S/W.	≤ 0.5 Ω impedance between output and controller power	Diagnostic enabled ********** Powertrain relay voltage Ignition run crank voltage ********** Engine does not crank Diagnostic system not disabled	True ********** >= 11.0 Volts > 5.00 Volts **********	50 failures out of 63 samples 100ms / sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Charge Air Cooler Efficiency Below Threshold If Intercooler Present	P026A	This DTC indicates a bad efficiency of the Air to Water Charge Air Cooler. The diagnostic is based on the manifold temperature and the time duration boost pressure needs to be limited due to high intake manifold temperatures.	Manifold temperature OR duration of boost pressure limitation caused by elevated intake manifold temperatures	> 110.0 > 10,000	Diagnostic enabled ********** IC Pump enabled ********** Engine run time Coolant temperature ********** No active DTCS:	True ********** Activated via ICP-Control ********** >= 60.0 seconds >= -10.0 deg Celsius ********** ECT_Sensor_FA MnfdTempSensorFA	5 failures out of 10 samples. 100ms / sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Engine Underboost Turbocharger with wastegate. Not supercharger with mechanical compressor	P0299	This DTC indicates an under boost failure. Two failure paths are considered. At steady state engine operating conditions with boost pressure closed loop control being active, a positive boost pressure deviation indicates underboost conditions. During transient conditions, in case the boost pressure increase gradient is below a diagnostic threshold, underboost conditions will be detected.	Desired boost pressure - Actual boost pressure	<refr to **P0299: Underboost pressure deviation limit as a function of engine speed and desired boost pressure** + **P0234 P0299: Ambient pressure correction as a function of engine speed and ambient pressure** in Supporting tables.	Dev. Diagnostic enable ********** Coolant temperature or OBD Coolant Enable Criteria and Coolant temperature Intake air temperature is in range Ambient air pressure is in range Engine speed in range Desired boost pressure in range Desired boost pressure derivative in range ********** All conditions haveto be fullfilled for: ********** No active DTCs: ********** Pressure control has to be in closed loop.	True ********** > -40.0 °C = TRUE) < 127.0 °C > -40.0 °C < 80.0 °C > 60.0 kPa < 120.0 kPa > 1,500 rpm < 6,500 rpm > 70.0 kPa < 245.0 kPa > -40.0 kPa/s < 50.0 kPa/s ********** >refer to **P0234 P0299: Boost deviation diagnostic enable delay as a function of engine speed** in Supporting tables. ********** BSTR_b_PCA_CktFA BSTR_b_TurboBypassCktFA ECT_Sensor_FA IAT_SensorFA BSTR_b_BoostSnsrFA AmbientAirDefault **********	18 failures out of 25 samples 100ms / sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No device control active for WG and compresseor recirculation valve.			
			Actual boost pressure delta the delta is limited by these tables: refer to Max: **P0299: Underboost high rate limit as a function of engine speed** Min: **P0299: Underboost low rate limit as a function of engine speed** in supporting tables.	< 15.00	Rate base diagostic enable and Dev. Diagnostic enable ********** Coolant temperature or OBD Coolant enable criteria and Coolant temperature Intake air temperature is in range Ambient air pressure is in range Desired boost pressure in range Desired boost pressure derivative in hysteresis range Engine speed is in range ********** All conditions have to be fullfilled for: ********** No active DTCs:	False True ********** > -40.0 °C = TRUE) < 127.0 °C > -40.0 °C < 80.0 °C > 60.0 kPa < 120.0 kPa > 70.0 kPa < 245.0 kPa Enable Limit: 20.0 Disable Limit: -5.0 > 1,900 rpm < 6,500 rpm ********** > 0.20 Seconds ********** BSTR_b_PCA_CktFA BSTR_b_TurboBypassCktFA ECT_Sensor_FA IAT_SensorFA BSTR_b_BoostSnsrFA	10 failures out of 20 samples 100ms / sample	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					********** Pressure control has to be in closed loop. No device control active for WG and compresseor recirculation valve.	AmbientAirDefault **********		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Fluid Temperature Sensor Circuit Low Voltage	P0712	Controller specific analog circuit diagnoses the transmission fluid temperature sensor and wiring for a short to ground fault by comparing a voltage measurement to controller specific voltage thresholds, converted to a resistance value.	circuit resistance	≤ 17.88 Ohms (temperature reads greater than 150 °C)	diagnostic monitor enable P0712 fault active OR P0712 test fail this key on vehicle load for non-hybrid only: Engine speed AND Engine speed AND vehicle speed crank diag enable: igntion voltage controller run crank active: ignition voltage	= 1 Boolean = FALSE = FALSE ≥ 200.0 RPM ≤ 7,500.0 RPM ≤ 512.0 KPH ≥ 5.00 volts ≥ 9.0 volts	>= 12.00 seconds for both fail thresholds 250 millisecond update rate ≥ 5.000 seconds ≥ 5.000 seconds ≥ 25 milliseconds	Type C, No SVS Emissions Neutral Diagnostic – When Type C

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Fluid Temperature Sensor Circuit High Voltage	P0713	Controller specific analog circuit diagnoses the transmission fluid temperature sensor and wiring for an open circuit or short to power failure by comparing a voltage measurement to controller specific voltage thresholds, converted to a resistance value.	circuit resistance	≥ 420,000.00 Ohms (temperature reads less than -40 °C)	diagnostic monitor enable P0713 fault active OR P0713 test fail this key on vehicle load for non-hybrid only: Engine speed AND Engine speed AND vehicle speed crank diag enable: igntion voltage controller run crank active: ignition voltage vehicle speed TCC slip speed DTCs not fault active	= 1 Boolean = FALSE = FALSE ≥ 200.0 RPM ≤ 7,500.0 RPM ≤ 512.0 KPH ≥ 5.00 volts ≥ 9.0 volts ≥ 30.0 KPH ≥ -4,096.0 RPM P0502, P0503, P0722, P0723, P077D, P0716, P0717, P07BF, P07C0	>= 80.00 seconds for both fail thresholds 250 millisecond update rate ≥ 5.000 seconds ≥ 5.000 seconds ≥ 25 milliseconds ≥ 200.0 seconds ≥ 200.0 seconds	Type C, No SVS Emissions Neutral Diagnostic – When Type C

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear 6 incorrect ratio (gear shift lever position sensor rationality	P0729	Detects when the N/V gear ratio indicates 6th gear but the Gear (shift lever) Position Sensor does not indicate 6th gear	Shifter Position Sensor	≠ Gear 6	diagnostic calibration enable Gear Position Sensor learn status Ignition voltage run/crank active Engine Torque Inaccurate Engine actual torque Transmission output speed Accelerator pedal position Clutch pedal displacement If four wheel drive low AND Gear box estimated gear ratio Gear box estimated gear ratio If four wheel drive low AND Gear box estimated gear ratio Gear box estimated gear ratio The above conditions are met for DTC's not fault active	= 1 Boolean = Learned ≥ 9.00 volts = TRUE = False ≥ 50.0 Nm ≥ 120 RPM ≥ 8.0 % ≤ 10.0 % = TRUE < 5.500 ≥ 5.000 = FALSE < 0.678 ≥ 0.588 ≥ 1.500 seconds TransmissionOutputRotationalStatusValidity	fail time ≥ 1.000 seconds Once fail time is achieved, increment fail count by 1 ≥ 1 fail counts loop rate 12.5 milliseconds	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EngineTorqueEstInaccurate ClutchPstnSnsr FA ClutchPstnSnsrNotLearned P18C4 P18C5 P18C6 P18C7 P18C8 P2771		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear 1 incorrect ratio (gear shift lever position sensor rationality	P0731	Detects when the N/V gear ratio indicates 1st gear but the Gear (shift lever) Position Sensor does not indicate 1st gear	Shifter Position Sensor	≠ Gear 1	diagnostic calibration enable Gear Position Sensor learn status Ignition voltage run/crank active Engine Torque Inaccurate Engine actual torque Transmission output speed Accelerator pedal position Clutch pedal displacement If four wheel drive low AND Gear box estimated gear ratio Gear box estimated gear ratio If four wheel drive low AND Gear box estimated gear ratio Gear box estimated gear ratio The above conditions are met for DTC's not fault active	= 1 Boolean = Learned ≥ 9.00 volts = TRUE = False ≥ 50.0 Nm ≥ 120 RPM ≥ 8.0 % ≤ 10.0 % = TRUE < 5.500 ≥ 5.000 = FALSE < 2.784 ≥ 2.624 ≥ 1.500 seconds TransmissionOutputRotationalStatusValidity	fail time ≥ 1.000 seconds Once fail time is achieved, increment fail count by 1 ≥ 1 fail counts loop rate 12.5 milliseconds	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EngineTorqueEstInaccurate ClutchPstnSnsr FA ClutchPstnSnsrNotLearned P18C4 P18C5 P18C6 P18C7 P18C8 P2771		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear 2 incorrect ratio (gear shift lever position sensor rationality	P0732	Detects when the N/V gear ratio indicates 2nd gear but the Gear (shift lever) Position Sensor does not indicate 2nd gear	Shifter Position Sensor	≠ Gear 2	diagnostic calibration enable Gear Position Sensor learn status Ignition voltage run/crank active Engine Torque Inaccurate Engine actual torque Transmission output speed Accelerator pedal position Clutch pedal displacement If four wheel drive low AND Gear box estimated gear ratio Gear box estimated gear ratio If four wheel drive low AND Gear box estimated gear ratio Gear box estimated gear ratio The above conditions are met for DTC's not fault active	= 1 Boolean = Learned ≥ 9.00 volts = TRUE = False ≥ 50.0 Nm ≥ 120 RPM ≥ 8.0 % ≤ 10.0 % = TRUE < 5.500 ≥ 5.000 = FALSE < 1.833 ≥ 1.744 ≥ 1.500 seconds TransmissionOutputRotationalStatusValidity	fail time ≥ 1.000 seconds Once fail time is achieved, increment fail count by 1 ≥ 1 fail counts loop rate 12.5 milliseconds	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EngineTorqueEstInaccurate ClutchPstnSnsr FA ClutchPstnSnsrNotLearned P18C4 P18C5 P18C6 P18C7 P18C8 P2771		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear 3 incorrect ratio (gear shift lever position sensor rationality	P0733	Detects when the N/V gear ratio indicates 3rd gear but the Gear (shift lever) Position Sensor does not indicate 3rd gear	Shifter Position Sensor	≠ Gear 3	diagnostic calibration enable Gear Position Sensor learn status Ignition voltage run/crank active Engine Torque Inaccurate Engine actual torque Transmission output speed Accelerator pedal position Clutch pedal displacement If four wheel drive low AND Gear box estimated gear ratio Gear box estimated gear ratio If four wheel drive low AND Gear box estimated gear ratio Gear box estimated gear ratio The above conditions are met for DTC's not fault active	= 1 Boolean = Learned ≥ 9.00 volts = TRUE = False ≥ 50.0 Nm ≥ 120 RPM ≥ 8.0 % ≤ 10.0 % = TRUE < 5.500 ≥ 5.000 = FALSE < 1.352 ≥ 1.262 ≥ 1.500 seconds TransmissionOutputRotationalStatusValidity	fail time ≥ 1.000 seconds Once fail time is achieved, increment fail count by 1 ≥ 1 fail counts loop rate 12.5 milliseconds	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EngineTorqueEstInaccurate ClutchPstnSnsr FA ClutchPstnSnsrNotLearned P18C4 P18C5 P18C6 P18C7 P18C8 P2771		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear 4 incorrect ratio (gear shift lever position sensor rationality	P0734	Detects when the N/V gear ratio indicates 4th gear but the Gear (shift lever) Position Sensor does not indicate 4th gear	Shifter Position Sensor	≠ Gear 4	diagnostic calibration enable Gear Position Sensor learn status Ignition voltage run/crank active Engine Torque Inaccurate Engine actual torque Transmission output speed Accelerator pedal position Clutch pedal displacement If four wheel drive low AND Gear box estimated gear ratio Gear box estimated gear ratio If four wheel drive low AND Gear box estimated gear ratio Gear box estimated gear ratio The above conditions are met for DTC's not fault active	= 1 Boolean = Learned ≥ 9.00 volts = TRUE = False ≥ 50.0 Nm ≥ 120 RPM ≥ 8.0 % ≤ 10.0 % = TRUE < 5.500 ≥ 5.000 = FALSE < 1.050 ≥ 0.960 ≥ 1.500 seconds TransmissionOutputRotationalStatusValidity	fail time ≥ 1.000 seconds Once fail time is achieved, increment fail count by 1 ≥ 1 fail counts loop rate 12.5 milliseconds	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EngineTorqueEstInaccurate ClutchPstnSnsr FA ClutchPstnSnsrNotLearned P18C4 P18C5 P18C6 P18C7 P18C8 P2771		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear 5 incorrect ratio (gear shift lever position sensor rationality	P0735	Detects when the N/V gear ratio indicates 5th gear but the Gear (shift lever) Position Sensor does not indicate 5th gear	Shifter Position Sensor	≠ Gear 5	diagnostic calibration enable Gear Position Sensor learn status Ignition voltage run/crank active Engine Torque Inaccurate Engine actual torque Transmission output speed Accelerator pedal position Clutch pedal displacement If four wheel drive low AND Gear box estimated gear ratio Gear box estimated gear ratio If four wheel drive low AND Gear box estimated gear ratio Gear box estimated gear ratio The above conditions are met for DTC's not fault active	= 1 Boolean = Learned ≥ 9.00 volts = TRUE = False ≥ 50.0 Nm ≥ 120 RPM ≥ 8.0 % ≤ 10.0 % = TRUE < 5.500 ≥ 5.000 = FALSE < 0.846 ≥ 0.756 ≥ 1.500 seconds TransmissionOutputRotationalStatusValidity	fail time ≥ 1.000 seconds Once fail time is achieved, increment fail count by 1 ≥ 1 fail counts loop rate 12.5 milliseconds	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EngineTorqueEstInaccurate ClutchPstnSnsr FA ClutchPstnSnsrNotLearned P18C4 P18C5 P18C6 P18C7 P18C8 P2771		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Reverse Inhibit Control Circuit Open (Manual Transmission Only)	P0801	Detects an open in the reverse inhibit control circuit. This diagnostic reports the DTC when an open circuit is present. Monitoring occurs when the engine speed is above a calibrated value.	Reverse inhibit control open circuit	Controller internal diagnostic	Reverse inhibit control open circuit diagnostic enabled Run/Crank Run/Crank Voltage Engine Speed	= 1.00 = TRUE Voltage ≥ 9 volts > 250 RPM	20 failures out of 25 samples 250 ms / sample	Type C, SVS one trip

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Range / Performance	P0806	A Clutch Pedal position sensor range fault is detected, if Clutch Pedal Position Sensor is in a range indicative of a vehicle NOT in gear, when the vehicle is determined to be in gear. Gear determination is made by verifying that the ratio of engine RPM versus Transmission Output Speed (N/TOS) represents a valid gear. When this occurs a clutch pedal position error is measured and processed by a 1st order lag filter. When this clutch pedal position error exceeds the defined threshold, a this fault code is set.	Filtered Clutch Pedal Position Error when the vehicle is determined to be in gear	> 5 %	N/TOS Ratio: Transfer Case: Vehicle speed: Engine Torque: Clutch Pedal Position: OR No Active DTCs:	Must match actual gear (i.e. vehicle in gear) Not in 4WD Low range > 3.4 MPH > **P0806 EngTorqueThreshold Table** (see Supporting Tables) < **P0806 ResidualErrEnableLow Table** (see Supporting Tables) > **P0806 ResidualErrEnableHigh Table** (see Supporting Tables) ClutchPstnSnsrCktHi FA ClutchPstnSnsrCktLo FA CrankSensor_FA Transmission Output Shaft Angular Velocity Validity VehicleSpeedSensor_FA	12.5 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Low	P0807	A continuous circuit Out-of-Range Low or open fault is detected by monitoring the percent voltage range of the clutch pedal position signal. This sensor by design is dead banded at both the high and low positions. If the voltage from the sensor is below the defined threshold value for the dead banded region, a fail counter increments. When the correct ratio of fail counts to samples occurs the fault code is set.	Clutch Position Sensor Circuit	< 4 % of Vref	Engine Not Cranking System Voltage	 > 11.0 Volts	400 counts out of 500 samples 12.5 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit High	P0808	A continuous circuit Out-of-Range High fault is detected by monitoring the percent voltage range of the clutch pedal position signal. This sensor by design is dead banded at both the high and low positions. If the voltage from the sensor is above the defined threshold value for the dead banded region, a fail counter increments. When the correct ratio of fail counts to samples occurs the fault code is set.	Clutch Position Sensor Circuit	> 96 % of Vref	Engine Not Cranking System Voltage	> 11.0 Volts	400 counts out of 500 samples 12.5 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Not Learned	P080A	During final assembly at the manufacturing facility an initial Clutch Pedal Applied Learn is established. This Learn is used to understand the variation in the clutch fully applied position vs. the clutch pedal position. This position is then adjusted over time based on a learning algorithm in the engine controller to adjust for clutch physical wear with usage. This Diagnostic is used to detect when this Applied Learn value is outside of defined range based on the thresholds set by the diagnostic. If the Applied Learn value is outside of the range of the threshold values this fault code is set. The OBD Manufacturer's enable counter is utilized to prevent the MIL from setting during the vehicle assembly before a Position lean can be completed in the manufacturing facility.	Fully Applied Learn Position OR	< 9.0 % > 36.0 %	OBD Manufacturer's Enable Counter	= 0	250 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Reverse Inhibit Control Circuit Low (Manual Transmission Only)	P088C	Detects a short to ground in the reverse inhibit control circuit. This diagnostic reports the DTC when a short to ground is present. Monitoring occurs when the engine speed is above a calibrated value.	Reverse inhibit control circuit short low	Controller internal diagnostic	Reverse inhibit control open circuit diagnostic enabled Run/Crank Run/Crank Voltage Engine Speed	= 1.00 = TRUE Voltage ≥ 9 volts > 250 RPM	20 failures out of 25 samples 250 ms / sample	Type C, SVS one trip

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Reverse Inhibit Control Circuit High (Manual Transmission Only)	P088D	Detects a short to power in the reverse inhibit control circuit. This diagnostic reports the DTC when a short to power is present. Monitoring occurs when the engine speed is above a calibrated value.	Reverse inhibit control circuit short high	Controller internal diagnostic	Reverse inhibit control open circuit diagnostic enabled Run/Crank Run/Crank Voltage Engine Speed	= 1.00 = TRUE Voltage ≥ 9 volts > 250 RPM	20 failures out of 25 samples 250 ms / sample	Type C, SVS one trip

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Position Sensor Circuit A Low	P18C4	The gear position sensor is a single component containing an X-axis and a Y-axis sensor. The gear position sensor determines the manual transmission shift lever positon based on the PWM output of the X-axis and Y-axis sensors. Controller specific Gear Position Sensor Circuit A Low diagnoses Gear Position Sensor Circuit A and wiring for an out of range low circuit fault by comparing a PWM measurement to controller specific PWM thresholds.	sesnor conditional calibration (direct) gear position sensor B (Y-axis) raw signal sesnor conditional calibration (inverse) gear position sensor B (Y-axis) raw signal	= CeSPMI_e_VoltageDirectProp ≤ 8.9996 % PWM duty cycle = CeSPMI_e_VoltageDirectProp ≥ 8.9996 % PWM duty cycle	sensor available calibration diagnostic monitor enable igntion run/crank active ignition run/crank voltage	= 1 Boolean = 1 Boolean = TRUE ≥ 9.00 volts	≥ 3 fail counts out of ≥ 5 sample counts 12.5 millisecond update rate	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Position Sensor Circuit A High	P18C5	The gear position sensor is a single component containing an X-axis and a Y-axis sensor. The gear position sensor determines the manual transmission shift lever positon based on the PWM output of the X-axis and Y-axis sensors. Controller specific Gear Position Sensor Circuit A High diagnoses Gear Position Sensor Circuit A and wiring for an out of range high circuit fault by comparing a PWM measurement to controller specific PWM thresholds.	sesnor conditional calibration (direct) gear position sensor B (Y-axis) raw signal sesnor conditional calibration (inverse) gear position sensor B (Y-axis) raw signal	= CeSPMI_e_VoltageDirectProp ≥ 89.999 % PWM duty cycle = CeSPMI_e_VoltageDirectProp ≤ 89.999 % PWM duty cycle	sensor available calibration diagnostic monitor enable igntion run/crank active ignition run/crank voltage	= 1 Boolean = 1 Boolean = TRUE ≥ 9.00 volts	≥ 3 fail counts out of ≥ 5 sample counts 12.5 millisecond update rate	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Position Sensor Circuit B Low	P18C6	The gear position sensor is a single component containing an X-axis and a Y-axis sensor. The gear position sensor determines the manual transmission shift lever positon based on the PWM output of the X-axis and Y-axis sensors. Controller specific Gear Position Sensor Circuit B Low diagnoses Gear Position Sensor Circuit B and wiring for an out of range low circuit fault by comparing a PWM measurement to controller specific PWM thresholds.	sesnor conditional calibration (direct) gear position sensor B (Y-axis) raw signal sesnor conditional calibration (inverse) gear position sensor B (Y-axis) raw signal	= CeSPMI_e_VoltageDirectProp ≤ 8.9996 % PWM duty cycle = CeSPMI_e_VoltageDirectProp ≥ 8.9996 % PWM duty cycle	sensor available calibration diagnostic monitor enable igntion run/crank active ignition run/crank voltage	= 1 Boolean = 1 Boolean = TRUE ≥ 9.00 volts	≥ 3 fail counts out of ≥ 5 sample counts 12.5 millisecond update rate	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Position Sensor Circuit B High	P18C7	The gear position sensor is a single component containing an X-axis and a Y-axis sensor. The gear position sensor determines the manual transmission shift lever positon based on the PWM output of the X-axis and Y-axis sensors. Controller specific Gear Position Sensor Circuit B High diagnoses Gear Position Sensor Circuit B and wiring for an out of range high circuit fault by comparing a PWM measurement to controller specific PWM thresholds.	sesnor conditional calibration (direct) gear position sensor B (Y-axis) raw signal sesnor conditional calibration (inverse) gear position sensor B (Y-axis) raw signal	= CeSPMI_e_VoltageDirectProp ≥ 89.999 % PWM duty cycle = CeSPMI_e_VoltageDirectProp ≤ 89.999 % PWM duty cycle	sensor available calibration diagnostic monitor enable igntion run/crank active ignition run/crank voltage	= 1 Boolean = 1 Boolean = TRUE ≥ 9.00 volts	≥ 3 fail counts out of ≥ 5 sample counts 12.5 millisecond update rate	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Position Sensor Indicates Incorrect Gear Ratio (gear shift lever position sensor rationality	P18C9	The gear position sensor is a single component containing an X-axis and a Y-axis sensor. The gear position sensor determines the manual transmission shift lever positon based on the PWM output of the X-axis and Y-axis sensors. Detects when transmission is mechanically in neutral and Gear Position Sensor is not indicating a neutral position.	Gear Position Sensor	= In Gear	Gear Position Sensor learn status Ignition voltage Transmission output speed Clutch pedal displacement Engine speed DTCs not fault active	= Learned ≥ 9.00 volts ≤ 10.00 rpm ≤ 10.00 pct ≥ 450.00 rpm TransmissionOutputRotationalStatusValidity ClutchPstnSnsr FA ClutchPstnSnsrNotLearned P18C4 P18C5 P18C6 P18C7 P18C8	≥ 6.00 seconds Once the above fail time is achieved then increment the fail counter once ≥ 2.00 fail counts	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Position Sensor Not Learned	P18CA	The gear position sensor is a single component containing an X-axis and a Y-axis sensor. The gear position sensor determines the manual transmission shift lever positon based on the PWM output of the X-axis and Y-axis sensors. Detects when the gear position sensor position not learned. Any offset due to hardware variation is captured when the gear position sensor X-axis and Y-axis PWM duty cycle offset is not learned during vehicle assembly or service, with the transmission shift lever in neutral position and the transmission mechanically in neutral. A non-volatile memory status bit is set when the controller service procedure has been executed to successfully learn the gear position variation. The learn values are saved in the controller non-volatile memory with the associated status bit. The status bit is reset every time a controller is	Gear Position Sensor Learn status	= FALSE set to FALSE on a controller NVM initialization after battery connect, set to TRUE when service learn procedure complete	diagnostic monitor enable manufactures enable counter sensor available calibration sensor service learn time	= 1 Boolean = 0 Counts = 1 Boolean = 0.0 seconds	immediate in 500 millisecond loop rate	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		disconnected from the controller battery voltage source. After a controller battery disconnect and reconnect, with the status bit then indicating the learn values have not been learned, the DTC will set fault active.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (boosted applications, Gen II)	P2228	Detects a continuous short to ground or open circuit in the Barometric Pressure (BARO) signal circuit by monitoring the BARO sensor output voltage and failing the diagnostic when the BARO voltage is too low. The BARO sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	BARO Voltage	< 40.0 % of 5 Volt Range (This is equal to 50.9 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (boosted applications, Gen II)	P2229	Detects a continuous short to power in the Barometric Pressure (BARO) signal circuit by monitoring the BARO sensor output voltage and failing the diagnostic when the BARO voltage is too high. The BARO sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	BARO Voltage	> 90.0 % of 5 Volt Range (This is equal to 115.0 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor B Circuit Low (Gen II)	P222C	Detects a continuous short to ground or open circuit in the Barometric Pressure (BARO) B signal circuit by monitoring the BARO B sensor output voltage and failing the diagnostic when the BARO B voltage is too low. The BARO B sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	BARO B Voltage	< 40.0 % of 5 Volt Range (This is equal to 50.9 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor B Circuit High (Gen II)	P222D	Detects a continuous short to power in the Barometric Pressure (BARO) B signal circuit by monitoring the BARO B sensor output voltage and failing the diagnostic when the BARO B voltage is too high. The BARO B sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	BARO B Voltage	> 90.0 % of 5 Volt Range (This is equal to 115.0 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Performance Traction Torque & Speed Request Circuit	P2548	Determines if torque and/or speed request from the EBTCM is valid	Protection error - Serial Communication message ($1C8/$237) 2's complement not equal Torque Request Speed Request OR Rolling count error - Serial Communication message ($1C8/$237) rolling count index value	 Message <> two's complement of message Message <> two's complement of message Message <> previous message rolling count value + one	Diagnostic Status Run/Crank Active Ignition Voltage No Serial communication loss to EBTCM (U0121)	Enabled > 0.50 seconds > 6.41 volts No loss of communication	Fail Threshold: >= 10 failures out of 20 samples Pass Threshold: >= 10 samples during key cycle. OR Fail Threshold >= 3 Rolling count errors out of 10 samples Performed on every received message	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 3 Circuit Performance (applications with humidity sensor and manifold temperature sensor)	P00E9	Detects an Intake Air Temperature 3 (IAT3) sensor value that is stuck in range by comparing the IAT3 sensor value against the IAT and IAT2 sensor values and failing the diagnostic if the IAT3 value is more different than the IAT and IAT2 values than is expected. If the engine has been off for a long enough period of time, the air temperature values in the engine compartment of the vehicle are considered to have equalized, and the diagnostic can be enabled. The diagnostic will fail if the IAT and IAT2 values are similar, and the IAT3 value is not similar to the IAT and IAT2 values. The diagnostic will also fail if none of the three sensor values are similar to each other, and the IAT3 value is furthest from the sensor value that is in the middle of the three sensor values. This diagnostic is executed once per	**Good Correlation Between IAT and IAT2:** ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up IAT - Power Up IAT3) AND ABS(Power Up IAT2 - Power Up IAT3)	<= 25 deg C > 25 deg C > 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.0 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips
			Not Good Correlation, IAT in Middle: Power Up IAT is between Power Up IAT2 and Power Up IAT3 AND ABS(Power Up IAT2 - Power Up IAT3) AND ABS(Power Up IAT - Power Up IAT3) > ABS(Power Up IAT - Power Up IAT2)	 > 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.0 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error	Executes once at the beginning of each ignition cycle if enable conditions are met	
			Not Good Correlation, IAT2 in Middle: Power Up IAT2 is between Power Up IAT and Power Up IAT3		Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time	> 28,800 seconds >= 11.0 Volts >= 0.9 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		ignition cycle if the enable conditions are met.	AND ABS(Power Up IAT - Power Up IAT3) AND ABS(Power Up IAT2 - Power Up IAT3) > ABS(Power Up IAT2 - Power Up IAT)	> 25 deg C	No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 3 Low (applications with manifold temperature and humidity)	P00EA	Detects a continuous short to ground in the Intake Air Temperature 3 (IAT3) signal circuit by monitoring the IAT3 sensor output resistance and failing the diagnostic when the IAT3 resistance is too low. The IAT3 sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. A lower resistance is equivalent to a higher temperature.	Raw IAT 3 Input	< 56.52 Ohms (~150 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 3 High (applications with manifold temperature and humidity)	P00EB	Detects a continuous open circuit in the Intake Air Temperature 3 (IAT3) signal circuit by monitoring the IAT3 sensor output resistance and failing the diagnostic when the IAT3 resistance is too high. The IAT3 sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. A higher resistance is equivalent to a lower temperature.	Raw IAT 3 Input	> 162,529 Ohms (~-60 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 3 Intermittent In-Range	P00EC	Detects a noisy or erratic signal in the Intake Air Temperature 3 (IAT3) circuit by monitoring the IAT3 sensor and failing the diagnostic when the IAT3 signal has a noisier output than is expected. When the value of the IAT3 signal in °C is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of IAT3 readings. The result of this summation is called a “string length”. Since the IAT3 signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic IAT3 signal. The diagnostic will fail if the string length is too high.	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current IAT 3 reading - IAT 3 reading from 100 milliseconds previous)	> 80.00 deg C 10 consecutive IAT 3 readings	Continuous		4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Engine Overboost Turbocharger with wastegate. Not supercharger with mechanical compressor	P0234	This DTC indicates an over boost failure. Two failure paths are considered. When pressure control closed loop control being active, a negative boost pressure deviation indicates overboost conditions at constant driving conditions. In case boost pressure close loop control not being active and with desired boost pressure below basic boost pressure, overboost conditions can be detected when actual boost pressure is higher than basic boost pressure plus a diagnostic offset.	Desired boost pressure - Actual boost pressure	< refer to **P0234: Overboost pressure deviation limit as a function of engine speed and desired boost pressure** - **P0234 P0299: Ambient pressure correction as a function of engine speed and ambient pressure** in Supporting tables.	Dev. diagnostic enable ********** Coolant temperature or OBD Coolant enable criteria and Coolant temperature Intake air temperature is in range Ambient air pressure is in range Engine speed in range Desired boost pressure in range Desired boost pressure derivative in range ********** All conditions have to be fullfilled for: ********** No active DTCs: ********** Pressure control has to be in closed loop.	True ********** > -40.0 °C = TRUE < 126.0 °C > -40.0 °C < 80.0 °C > 60.0 kPa < 120.0 kPa > 2,000 rpm < 6,500 rpm > 100.0 kPa < 280.0 kPa > -70.0 kPa/s < 55.0 kPa/s ********** > refer to **P0234 P0299: Boost deviation diagnostic enable delay as a function of engine speed** in Supporting tables. ********** BSTR_b_PCA_CktFA BSTR_b_TurboBypassCktFA ECT_Sensor_FA IAT_SensorFA BSTR_b_BoostSnsrFA AmbientAirDefault **********	24 failures out of 30 samples 100ms / sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No device control active for WG and compresseor recirculation valve.			
			Actual boost pressure	> refer to **P0234: Overboost pressure limit below basic pressure as a function of engine speed and ambient pressure** in Supporting tables. +Basic Pressure	Basic pressure diag enable and Dev. diagnostic enable ********** Coolant temperature or OBD Coolant enable criteria and Coolant temperature Intake air temperature is in range Ambient air pressure is in range Engine speed in range All conditions haveto be fullfilled for: ********** No active DTCs: ********** Pressure control has to be in open loop.	False True ********** > -40.0 °C = TRUE < 126.0 °C > -40.0 °C < 80.0 °C > 60.0 kPa < 120.0 kPa > 2,000 rpm < 3,500 rpm > 2.00 Seconds ********** BSTR_b_PCA_CktFA BSTR_b_TurboBypassCktFA ECT_Sensor_FA IAT_SensorFA BSTR_b_BoostSnsrFA AmbientAirDefault BSTR_b_PCA_TFTKO **********	20 failures out of 25 samples 100ms / sample	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No device control active for WG and compresseor recirculation valve.			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Boost Pressure (TIAP) Sensor Performance (single turbo)	P0236	Detects a performance failure in the Turbocharger Boost Pressure sensor, such as when a Turbocharger Boost Pressure value is stuck in range. If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The Turbocharger Boost Pressure sensor value is checked to see if it is within the normal expected atmospheric pressure range. If it is not, then the Turbocharger Boost Pressure performance diagnostic will fail. If the Turbocharger Boost Pressure sensor value is within the normal expected atmospheric range, then Manifold Pressure (MAP), Turbocharger Boost Pressure and Barometric Pressure (BARO) are compared to see if their values are similar. If the MAP and BARO sensor values are similar, but the Turbocharger Boost Pressure value is not	**Engine Running:** See table **P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix** for combinations of model failures that can set this DTC. MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP - TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP -	> 20.0 grams/sec > 23.0 kPa > 25.0 kPa > 25.0 kPa > 30.0 kPa > 175 kPa*(g/s)	Engine Speed Engine Speed (Coolant Temp OR OBD Coolant Enable Criteria (Coolant Temp OR OBD Max Coolant Achieved Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together) See Residual Weight Factor tables.	>= 400 RPM <= 6,100 RPM >= -9 Deg C = TRUE) <= 125 Deg C = FALSE) >= -20 Deg C <= 125 Deg C >= 0.50 Modeled Air Flow Error multiplied by **P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM** and **P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est** MAP Model 1 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM** MAP Model 2 Error	Continuous Calculation are performed every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		similar, then a Turbocharger Boost Pressure performance diagnostic will fail. The engine running portion of this diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Mass Air Flow (MAF) sensor, Manifold Pressure (MAP) sensor and Throttle Position sensor (TPS). These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the Turbocharger Boost Pressure sensor. In this case, the Turbocharger Boost Pressure Performance	measured MAP - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset** OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset** TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time High Engine Air Flow is TRUE when Mass Air Flow	> 30.0 kPa > 30.0 kPa > 1.0 seconds > 1.0 seconds > a threshold in gm/sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow**	No Active DTCs: No Pending DTCs:	multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP Model 3 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM** TIAP Model 1 Error multiplied by **P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM** Filtered Throttle Model Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM** MAP_SensorCircuitFA EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		diagnostic will fail.	AND Manifold Pressure AND Filtered Mass Air Flow - Mass Air Flow Low Engine Air Flow is TRUE when Mass Air Flow AND Manifold Pressure AND Mass Air Flow - Filtered Mass Air Flow	> a threshold in kPa as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP** < 1.3 gm/sec < a threshold in gm/sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow** < a threshold in kPa as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP** < 2.0 gm/sec				
			Engine Not Rotating: Turbocharger Boost Pressure OR Turbocharger Boost	< 50.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating	> 10.0 seconds	4 failures out of 5 samples 1 sample every 12.5 msec	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Pressure OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	> 115.0 kPa <= 10.0 kPa > 10.0 kPa > 10.0 kPa	No Active DTCs: No Pending DTCs:	EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA AAP2_SnsrCktFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Boost Pressure Sensor Circuit Low (Gen III)	P0237	Detects a continuous short to ground in the Turbocharger Boost Pressure signal circuit by monitoring the Turbocharger Boost Pressure sensor output voltage and failing the diagnostic when the Turbocharger Boost Pressure voltage is too low. The Turbocharger Boost Pressure sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	Turbocharger Boost Pressure Voltage	< 14.4 % of 5 Volt Range (This is equal to 50.0 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Boost Pressure Sensor Circuit High (Gen III)	P0238	Detects a continuous short to power or open circuit in the Turbocharger Boost Pressure signal circuit by monitoring the Turbocharger Boost Pressure sensor output voltage and failing the diagnostic when the Turbocharger Boost Pressure voltage is too high. The Turbocharger Boost Pressure sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	Turbocharger Boost Pressure Voltage	> 86.0 % of 5 Volt Range (This is equal to 372.0 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Wastegate / Supercharger Boost Solenoid A Control Circuit	P0243	Controller specific output driver circuit diagnostic, diagnosing the 'turbocharger boost solenoid'A' actuator' low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. In series applications, turbocharger 'A' is the first turbocharger in the direction of exhaust flow. In a parallel application, turbocharger 'A' is associated with engine bank 1.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between output and controller ground	Diagnostic enabled ********** Powertrain relay voltage Ignition run crank voltage ********** Engine does not crank Diagnostic system not disabled	True ********** >= 11.0 Volts > 5.00 Volts **********	10 failures out of 20 samples 100ms / sample	Type A, 1 Trips Note: In certain controllers P0245 may also set turbocharger wastegate / supercharger boost solenoid A control circuit low

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Wastegate / Supercharger Boost Solenoid A Control Circuit Low	P0245	Controller specific output driver circuit diagnostic, diagnosing the 'turbocharger boost solenoid 'A' actuator' low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. In series applications, turbocharger 'A' is the first turbocharger in the direction of exhaust flow. In a parallel application, turbocharger 'A'is associated with engine bank 1.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground. In certain controllers this diagnosis runs only when the HWIO-output is driven by the application S/W.	≤ 0.5 Ω impedance between output and controller ground	Diagnostic enabled ********** Powertrain relay voltage Ignition run crank voltage ********** Engine does not crank Diagnostic system not disabled	True ********** >= 11.0 Volts > 5.00 Volts **********	10 failures out of 20 samples 100ms / sample	Type A, 1 Trips Note: In certain controllers P0243 may also set turbocharger wastegate / supercharger boost solenoid A control circuit

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Wastegate / Supercharger Boost Solenoid A Control Circuit High	P0246	Controller specific output driver circuit diagnostic, diagnosing the 'turbocharger boost solenoid 'A' actuator' low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds. In series applications, turbocharger 'A' is the first turbocharger in the direction of exhaust flow. In a parallel application, turbocharger 'A'is associated with engine bank 1.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power. In certain controllers this diagnosis runs only when the HWIO-output is driven by the application S/W.	≤ 0.5 Ω impedance between output and controller power	Diagnostic enabled ********** Powertrain relay voltage Ignition run crank voltage ********** Engine does not crank Diagnostic system not disabled	True ********** >= 11.0 Volts > 5.00 Volts **********	10 failures out of 20 samples 100ms / sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 1 Injector Circuit Range/ Performance	P02EE	Diagnostic to determine if Cylinder 1 injector voltage feedback measured from the analog to digital converter is rational. The measured voltage is checked when the injection pulse width is large enough ensuring the injector pintle has achieved max travel and the injector voltage flux through the coil has reach the max stabilization limit	Injector voltage feedback is not able to detect an opening magnitude OR Measured Voltage feedback converted to Injector Opening Magnitude OR Measured Voltage feedback converted to Injector Opening Magnitude OR Injector voltage feedback is not able to detect a closing time OR Measured Voltage feedback converted to Injector closing time OR Measured Voltage	 = **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Minimum Injector Opening Magnitude** (See supporting table) >= **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Maximum Injector Opening Magnitude** (See supporting table) = **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Minimum Injector Closing Time** (See supporting table) >=	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) Fuel Pulse Voltage Feedback Data Valid (See Definition in Supporting Material below) Injection Pulse Width	= True >= **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Voltage Feedback Rationalities Minimum Pulse Width**	100.00 failures out of 125.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			feedback converted to Injector closing time	**P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Maximum Injector Closing Time** (See supporting table)				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 2 Injector Circuit Range/ Performance	P02EF	Diagnostic to determine if Cylinder 2 injector voltage feedback measured from the analog to digital converter is rational. The measured voltage is checked when the injection pulse width is large enough ensuring the injector pintle has achieved max travel and the injector voltage flux through the coil has reach the max stabilization limit	Injector voltage feedback is not able to detect an opening magnitude OR Measured Voltage feedback converted to Injector Opening Magnitude OR Measured Voltage feedback converted to Injector Opening Magnitude OR Injector voltage feedback is not able to detect a closing time OR Measured Voltage feedback converted to Injector closing time OR Measured Voltage	 =< **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Minimum Injector Opening Magnitude** (See supporting table) >= **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Maximum Injector Opening Magnitude** (See supporting table) =< **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Minimum Injector Closing Time** (See supporting table) >=	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) Fuel Pulse Voltage Feedback Data Valid (See Definition in Supporting Material below) Injection Pulse Width	= True >= **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Voltage Feedback Rationalities Minimum Pulse Width**	100.00 failures out of 125.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			feedback converted to Injector closing time	**P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Maximum Injector Closing Time** (See supporting table)				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 3 Injector Circuit Range/ Performance	P02F0	Diagnostic to determine if Cylinder 3 injector voltage feedback measured from the analog to digital converter is rational. The measured voltage is checked when the injection pulse width is large enough ensuring the injector pintle has achieved max travel and the injector voltage flux through the coil has reach the max stabilization limit	Injector voltage feedback is not able to detect an opening magnitude OR Measured Voltage feedback converted to Injector Opening Magnitude OR Measured Voltage feedback converted to Injector Opening Magnitude OR Injector voltage feedback is not able to detect a closing time OR Measured Voltage feedback converted to Injector closing time OR Measured Voltage	 =< **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Minimum Injector Opening Magnitude** (See supporting table) >= **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Maximum Injector Opening Magnitude** (See supporting table) =< **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Minimum Injector Closing Time** (See supporting table) >=	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) Fuel Pulse Voltage Feedback Data Valid (See Definition in Supporting Material below) Injection Pulse Width	= True >= **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Voltage Feedback Rationalities Minimum Pulse Width**	100.00 failures out of 125.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			feedback converted to Injector closing time	**P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Maximum Injector Closing Time** (See supporting table)				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 4 Injector Circuit Range/ Performance	P02F1	Diagnostic to determine if Cylinder 4 injector voltage feedback measured from the analog to digital converter is rational. The measured voltage is checked when the injection pulse width is large enough ensuring the injector pintle has achieved max travel and the injector voltage flux through the coil has reach the max stabilization limit	Injector voltage feedback is not able to detect an opening magnitude OR Measured Voltage feedback converted to Injector Opening Magnitude OR Measured Voltage feedback converted to Injector Opening Magnitude OR Injector voltage feedback is not able to detect a closing time OR Measured Voltage feedback converted to Injector closing time OR Measured Voltage	 = **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Minimum Injector Opening Magnitude** (See supporting table) >= **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Maximum Injector Opening Magnitude** (See supporting table) = **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Minimum Injector Closing Time** (See supporting table) >=	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) Fuel Pulse Voltage Feedback Data Valid (See Definition in Supporting Material below) Injection Pulse Width	= True >= **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Voltage Feedback Rationalities Minimum Pulse Width**	100.00 failures out of 125.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			feedback converted to Injector closing time	**P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Maximum Injector Closing Time** (See supporting table)				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 1 Injection Pulse Performance	P10A3	Diagnostic to determine if injection pulse total compensation for cylinder 1 is less than the minimum fail limit. The injection pulse total compensation is the sum of the opening magnitude and closing time compensation. Opening Magnitude and closing time compensation are determined using the voltage feedback across the injector enable and command wires.	Total Injection Small Pulse compensation	< **P10A3 P10A5 P10A7 P10A9 P10AB P10AD P10AF P10B1 - Minimum Small Pulse Compensation Limit** (See supporting table)	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) FULR_b_FPV_MeasDiag_TFTKO Uncompensated Injection Pulse Width (Injection is commanded)	= True = True > 0	400.00 failures out of 500.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 1 Injection Pulse Performance	P10A4	Diagnostic to determine if injection pulse total compensation for cylinder 1 is greater than the maximum fail limit. The injection pulse total compensation is the sum of the opening magnitude and closing time compensation. Opening Magnitude and closing time compensation are determined using the voltage feedback across the injector enable and command wires.	Total Injection Small Pulse compensation	> **P10A4 P10A6 P10A8 P10AA P10AC P10AE P10B0 P10B2 - Maximum Small Pulse Compensation Limit** (See supporting table)	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) FULR_b_FPV_MeasDiag_TFTKO Uncompensated Injection Pulse Width (Injection is commanded)	= True = True > 0	400.00 failures out of 500.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 2 Injection Pulse Performance	P10A5	Diagnostic to determine if injection pulse total compensation for cylinder 2 is less than the minimum fail limit. The injection pulse total compensation is the sum of the opening magnitude and closing time compensation. Opening Magnitude and closing time compensation are determined using the voltage feedback across the injector enable and command wires.	Total Injection Small Pulse compensation	< **P10A3 P10A5 P10A7 P10A9 P10AB P10AD P10AF P10B1 - Minimum Small Pulse Compensation Limit** (See supporting table)	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) FULR_b_FPV_MeasDiag_TFTKO Uncompensated Injection Pulse Width (Injection is commanded)	= True = True > 0	400.00 failures out of 500.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 2 Injection Pulse Performance	P10A6	Diagnostic to determine if injection pulse total compensation for cylinder 2 is greater than the maximum fail limit. The injection pulse total compensation is the sum of the opening magnitude and closing time compensation. Opening Magnitude and closing time compensation are determined using the voltage feedback across the injector enable and command wires.	Total Injection Small Pulse compensation	> **P10A4 P10A6 P10A8 P10AA P10AC P10AE P10B0 P10B2 - Maximum Small Pulse Compensation Limit** (See supporting table)	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) FULR_b_FPV_MeasDiag_TFTKO Uncompensated Injection Pulse Width (Injection is commanded)	= True = True > 0	400.00 failures out of 500.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 3 Injection Pulse Performance	P10A7	Diagnostic to determine if injection pulse total compensation for cylinder 3 is less than the minimum fail limit. The injection pulse total compensation is the sum of the opening magnitude and closing time compensation. Opening Magnitude and closing time compensation are determined using the voltage feedback across the injector enable and command wires.	Total Injection Small Pulse compensation	< **P10A3 P10A5 P10A7 P10A9 P10AB P10AD P10AF P10B1 - Minimum Small Pulse Compensation Limit** (See supporting table)	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) FULR_b_FPV_MeasDiag_TFTKO Uncompensated Injection Pulse Width (Injection is commanded)	= True = True > 0	400.00 failures out of 500.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 3 Injection Pulse Performance	P10A8	Diagnostic to determine if injection pulse total compensation for cylinder 3 is greater than the maximum fail limit. The injection pulse total compensation is the sum of the opening magnitude and closing time compensation. Opening Magnitude and closing time compensation are determined using the voltage feedback across the injector enable and command wires.	Total Injection Small Pulse compensation	> **P10A4 P10A6 P10A8 P10AA P10AC P10AE P10B0 P10B2 - Maximum Small Pulse Compensation Limit** (See supporting table)	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) FULR_b_FPV_MeasDiag_TFTKO Uncompensated Injection Pulse Width (Injection is commanded)	= True = True > 0	400.00 failures out of 500.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 4 Injection Pulse Performance	P10A9	Diagnostic to determine if injection pulse total compensation for cylinder 4 is less than the minimum fail limit. The injection pulse total compensation is the sum of the opening magnitude and closing time compensation. Opening Magnitude and closing time compensation are determined using the voltage feedback across the injector enable and command wires.	Total Injection Small Pulse compensation	< **P10A3 P10A5 P10A7 P10A9 P10AB P10AD P10AF P10B1 - Minimum Small Pulse Compensation Limit** (See supporting table)	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) FULR_b_FPV_MeasDiag_TFTKO Uncompensated Injection Pulse Width (Injection is commanded)	= True = True > 0	400.00 failures out of 500.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 4 Injection Pulse Performance	P10AA	Diagnostic to determine if injection pulse total compensation for cylinder 4 is greater than the maximum fail limit. The injection pulse total compensation is the sum of the opening magnitude and closing time compensation. Opening Magnitude and closing time compensation are determined using the voltage feedback across the injector enable and command wires.	Total Injection Small Pulse compensation	> **P10A4 P10A6 P10A8 P10AA P10AC P10AE P10B0 P10B2 - Maximum Small Pulse Compensation Limit** (See supporting table)	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) FULR_b_FPV_MeasDiag_TFTKO Uncompensated Injection Pulse Width (Injection is commanded)	= True = True > 0	400.00 failures out of 500.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve - Mechanical Turbocharger with wastegate. Not supercharger with mechanical compressor	P2261	This DTC indicates the compressor recirculation valve being stuck closed. This diagnostic is active at coast down let off conditions, where an airflow pulsation criteria is used as basis of this diagnostic.	When measuring time accumulated air mass flow derivate boost pressure is high pass filtered with filter frequency ********** A failure is detected when Acc. Filtered Air Mass Flow or Acc.Der.Filtered boost pressure	< 0.80 Second, = 10.00 Hz ********** > 60.00 g/s > 500.00 kPa/s	Diagnostic enabled ********** Engine speed ********** Bypass valve commanded open duty cycle For at least ********** Pressure ratio over the compressor relative limit Condition keep true for x seconds extra ********** Negative transient -> TRUE Relative boost and Pressure derivate Hysteresis negative transient -> FALSE Relative boost or Pressure derivate ********** No Active DTCs:	True ********** >= 1,200 rpm ********** > 6.00 % >= 0.20 s ********** > refer to **P00C4 P2261: Compressor Surge Line** in Supporting Tables 1.50 s ********** TRUE >= 20.00 kPa <= -250.00 kPa/s < 3.00 kPa > 50.00 kPa/s ********** BSTR_b_TurboBypassCktFA BSTR_b_BoostSnsrFA MAF_SensorFA	8 Failed tests out of 10 tests 25ms/ sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 1 Injection Pulse Performance	P2B00	Diagnostic to determine if any of the commanded injection pulses for cylinder 1 was not delivered due to the injector pintle/ armature not moving. The detection is based on the voltage flux feedback that occurs in the injector coil from the pintle/armature movement. The voltage feedback is measured in the ECM across the enable & command wires using an analog to digital converter.	Injector voltage feedback is not able to detect an opening magnitude Or Measured Voltage feedback converted to Injector Opening Magnitude	= **P2B00 P2B01 P2B02 P2B03 P2B04 P2B05 P2B06 P2B07 P2B96 P2B08 P2B09 P2B0A P2B0B P2B0C P2B0D P2B0E P2B0F- Opening Magnitude Misisng Pulse Fail Limit** (See supporting table)	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) Fuel Pulse Voltage Feedback Data Ready (See Definition in Supporting Material below)	= True = True	100.00 failures out of 125.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 2 Injection Pulse Performance	P2B01	Diagnostic to determine if any of the commanded injection pulses for cylinder 2 was not delivered due to the injector pintle/ armature not moving. The detection is based on the voltage flux feedback that occurs in the injector coil from the pintle/armature movement. The voltage feedback is measured in the ECM across the enable & command wires using an analog to digital converter.	Injector voltage feedback is not able to detect an opening magnitude Or Measured Voltage feedback converted to Injector Opening Magnitude	= **P2B00 P2B01 P2B02 P2B03 P2B04 P2B05 P2B06 P2B07 P2B96 P2B08 P2B09 P2B0A P2B0B P2B0C P2B0D P2B0E P2B0F- Opening Magnitude Misisng Pulse Fail Limit** (See supporting table)	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) Fuel Pulse Voltage Feedback Data Ready (See Definition in Supporting Material below)	= True = True	100.00 failures out of 125.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 3 Injection Pulse Performance	P2B02	Diagnostic to determine if any of the commanded injection pulses for cylinder 3 was not delivered due to the injector pintle/ armature not moving. The detection is based on the voltage flux feedback that occurs in the injector coil from the pintle/armature movement. The voltage feedback is measured in the ECM across the enable & command wires using an analog to digital converter.	Injector voltage feedback is not able to detect an opening magnitude Or Measured Voltage feedback converted to Injector Opening Magnitude	=< **P2B00 P2B01 P2B02 P2B03 P2B04 P2B05 P2B06 P2B07 P2B96 P2B08 P2B09 P2B0A P2B0B P2B0C P2B0D P2B0E P2B0F- Opening Magnitude Misisng Pulse Fail Limit** (See supporting table)	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) Fuel Pulse Voltage Feedback Data Ready (See Definition in Supporting Material below)	= True = True	100.00 failures out of 125.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 4 Injection Pulse Performance	P2B03	Diagnostic to determine if any of the commanded injection pulses for cylinder 4 was not delivered due to the injector pintle/ armature not moving. The detection is based on the voltage flux feedback that occurs in the injector coil from the pintle/armature movement. The voltage feedback is measured in the ECM across the enable & command wires using an analog to digital converter.	Injector voltage feedback is not able to detect an opening magnitude Or Measured Voltage feedback converted to Injector Opening Magnitude	= **P2B00 P2B01 P2B02 P2B03 P2B04 P2B05 P2B06 P2B07 P2B96 P2B08 P2B09 P2B0A P2B0B P2B0C P2B0D P2B0E P2B0F- Opening Magnitude Misisng Pulse Fail Limit** (See supporting table)	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) Fuel Pulse Voltage Feedback Data Ready (See Definition in Supporting Material below)	= True = True	100.00 failures out of 125.00 samples Continuous Cylinder event sample rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Injection Pulse Performance	P2B95	Monitors injector pulses when the cold start emission reduction strategy is active by accumulating and determining the percentage of engine cycles that missed a pulse relative to the total number of pulses when multi pulse is active.	Injector voltage feedback is not able to detect an opening magnitude on any pulse for any cylinder Or Measured Voltage feedback converted to Injector Opening Magnitude on any pulse for any cylinder	=< **P2B96 - Opening Magnitude Misisng Pulse Fail Limit** (See supporting table)	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) Fuel Pulse Voltage Feedback Data Ready (See Definition in Supporting Material below) OBD Manufacturer Enable Counter To enable the diagnostic, the Cold Start Emission Reduction Strategy Must Be Active per the following: Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure In addition, Multi Pulse Strategy Is Enabled and Active Per the following: Engine Speed Accel Position Engine Run Time	= True = True = 0 < 350.00 degC > -12.00 degC <= 72.00 degC >= 72.00 KPa >= 450.00 RPM <= 2,500.00 RPM <= 25.00 Pct < 57 seconds	Runs once per trip when the cold start emission reduction strategy is active and Dual Pulse is enabled and active. Frequency: 100ms Test completes after Dual Pulse is no longer active OR The first 500 engine cycles have been reached	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following: Catalyst Temperature AND Engine Run Time OR Engine Run Time OR Barometric Pressure Multi Pulse Strategy will exit per the following: Engine Speed OR Accel Position Engine Run Time	 >= 900.00 degC >= 57.00 seconds > **P050D_P1400_CatalystLightOffExtendedEngineRunTimeExit** This Extended Engine run time exit table is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details. < 72.00 KPa > 2,400.00 RPM > 35.00 Pct >= 57 seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Mulit Pulse Strategy will also exit if the any of the "Additional Dual Pulse Enabling Criteria" is not satisfied:			
					"Additional Multi Pulse Enabling Criteria":			
					Green Engine Enrichment	Not Enabled		
					Misfire Converter Protection strategy	Not being requested		
					Engine Metal Overtemp strategy	Not being requested		
					Fuel control state	Open Loop		
					Output State Control	Not being requested for fuel		
					DOD Or DFCO	Not Active		
					Power Enrichment	Not Active		
					Dynamic Power Enrichment	Not Active		
					Piston Protection	Not Active		
					Hot Coolant Enrichment	Not Active		
					Injector Flow Test	Not Active		
					General Enable			
					DTC's Not Set:	AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFA CrankSensor_FA		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA AnyCamPhaser_TFTKO ClutchPstnSnsr FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA FuelInjectorCircuit_TFTKO FHPR_b_FRP_SnsrCkt_FA FHPR_b_FRP_SnsrCkt_TFTKO FHPR_b_PumpCkt_FA FHPR_b_PumpCkt_TFTKO TransmissionEngagedState_FA EngineTorqueEstInaccurate FuelPumpRlyCktFA		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Secondary Circuit Performance [FTZM Brushed Motor Fuel Pump applications only]	P2BB3	The FPDCM periodically monitors fuel pump duty cycle control error. The diagnostic detects whether the pump output duty cycle [measured] value differs too much compared to the received [commanded] Fuel Pump Control Duty Cycle.	Fuel Pump Duty Cycle Command [Measured]	<> Fuel Pump Duty Cycle Command [Received]	a) Ignition Switch Run_Crank Position Circuit Voltage b) Diagnostic enabled c) CAN serial data available [$0CB] d) CAN serial data faulted status [$0D9] e) Fuel pump control circuit faults [P0231, P0232, P023F] f) No fuel pump driver over-temperature fault [P1255] g) Sensor Bus Relay On h) Duty Cycle diagnostic synchronization delay time [expiration]	a) > 11.00 volts b) == True c) == True d) <> True e) <> True f) <> True g) == True h) > 100 milliseconds	12.5 millisec / sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector Circuit Range/ Performance	P30D4	Diagnostic to determine if any of the voltage feedback measured from the analog to digital converter on any cylinder is rational (total engine based). The measured voltage is checked when the injection pulse width is large enough ensuring the injector pintle has achieved max travel and the injector voltage flux through the coil has reach the max stabilization limit.	Injector voltage feedback is not able to detect an opening magnitude OR Measured Voltage feedback converted to Injector Opening Magnitude OR Measured Voltage feedback converted to Injector Opening Magnitude OR Injector voltage feedback is not able to detect a closing time OR Measured Voltage feedback converted to Injector closing time OR Measured Voltage	=< **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Minimum Injector Opening Magnitude** (See supporting table) >= **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Maximum Injector Opening Magnitude** (See supporting table) =< **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Minimum Injector Closing Time** (See supporting table) >=	Small Pulse General Diagnostic Enable (See Definition in Supporting Material below) Fuel Pulse Voltage Feedback Data Valid (See Definition in Supporting Material below) Injection Pulse Width	= True >= **P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Voltage Feedback Rationalities Minimum Pulse Width**	2.50 Second Fail count out of 10.00 seconds Samples Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			feedback converted to Injector closing time	**P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Maximum Injector Closing Time** (See supporting table)				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Composition Sensor Circuit Low	P0178	A continuous circuit Out-of-Range Low or Open fault is detected by monitoring the signal frequency of the Ethanol composition sensor The ethanol sensor is designed to measure ethanol concentrations from E0 (50Hz) to E100 (150Hz), with a specified accuracy of 5% ethanol (i.e. 5Hz). If the raw frequency value is less than the threshold value a fail counter will increment. When the correct ratio of failure counts vs. sample counts is achieved, the fault code is set.	Flex Fuel Sensor Output Frequency	< 45 Hertz	Powertrain Relay	> 11.0 Volts	50 failures out of 63 samples 100 ms loop Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Composition Sensor Circuit High	P0179	A continuous circuit Out-of-Range High fault is detected by monitoring the signal frequency of the Ethanol composition sensor The ethanol sensor is designed to measure ethanol concentrations from E0 (50Hz) to E100 (150Hz), with a specified accuracy of 5% ethanol (i.e. 5Hz). If the raw frequency value is greater than the threshold value a fail counter will increment. When the correct ratio of failure counts vs. sample counts is achieved, the fault code is set. If the frequency goes higher than the specified high conductivity threshold then a P2269 is set instead (see that monitor for full description)	Flex Fuel Sensor Output Frequency	> 155 Hertz <= 185	Powertrain Relay	> 11.0 Volts	50 failures out of 63 samples 100 ms loop Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 2 Sensor A	P0345	Diagnostic will fail if a cam sensor pulse was not received during a period of time; if cam sensor pulses are received the diagnostic will pass.	Time since last camshaft position sensor pulse received OR Time that starter has been engaged without a camshaft sensor pulse	>= 5.5 seconds >= 4.0 seconds	Starter engaged AND (crank pulses being received OR (MAF_SensorFA AND Engine Air Flow	= FALSE > 3.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged		Continuous every 100 msec	
			No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	CrankSensor_FA	Continuous every MEDRES event	
			The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 2 Sensor A	P0346	Diagnostic will fail if an incorrect number of cam sensor pulses are detected over a number of engine cycles and will pass if the number of cam pulses is correct.	The number of camshaft pulses received during first 12 MEDRES events is OR (There are 12 MEDRES events per engine cycle)	< 4 > 6	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	CrankSensor_FA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor B	P0365	Diagnostic will fail if a cam sensor pulse was not received during a period of time; if cam sensor pulses are received the diagnostic will pass.	Time since last camshaft position sensor pulse received OR Time that starter has been engaged without a camshaft sensor pulse	>= 5.5 seconds >= 4.0 seconds	Starter engaged AND (crank pulses being received OR (MAF_SensorFA AND Engine Air Flow	= FALSE > 3.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged		Continuous every 100 msec	
			No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	CrankSensor_FA	Continuous every MEDRES event	
			The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor B	P0366	Diagnostic will fail if an incorrect number of cam sensor pulses are detected over a number of engine cycles and will pass if the number of cam pulses is correct.	The number of camshaft pulses received during first 12 MEDRES events is OR (There are 12 MEDRES events per engine cycle)	< 4 > 6	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	CrankSensor_FA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 2 Sensor B	P0390	Diagnostic will fail if a cam sensor pulse was not received during a period of time; if cam sensor pulses are received the diagnostic will pass.	Time since last camshaft position sensor pulse received OR Time that starter has been engaged without a camshaft sensor pulse	>= 5.5 seconds >= 4.0 seconds	Starter engaged AND (crank pulses being received OR (MAF_SensorFA AND Engine Air Flow	= FALSE > 3.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged		Continuous every 100 msec	
			No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	CrankSensor_FA	Continuous every MEDRES event	
			The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 2 Sensor B	P0391	Diagnostic will fail if an incorrect number of cam sensor pulses are detected over a number of engine cycles and will pass if the number of cam pulses is correct.	The number of camshaft pulses received during first 12 MEDRES events is OR (There are 12 MEDRES events per engine cycle)	< 4 > 6	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	CrankSensor_FA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Open (ODM)	P0481	Diagnoses the cooling fan 2 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50.00 failures out of 63.00 samples 100 ms / sample	Type B, 2 Trips Note: In certain controllers P0693 may also set (Fan 2 Short to Ground)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft System Cold Start Performance – Bank 1	P05CE	Detects a VVT system error during Cold Starts by comparing the desired and actual cam positions when VVT is activated. This is the same type diagnostic as P0014 except this detects excessive deviations of position while the cold start phaser positions are being commanded.	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	Cam Position Error > 4.00 deg.	**Exhaust Cam Phsr Enable** System Voltage Engine Running Power Take Off (PTO) active **Catalyst Warmup Enabled** Desired cam position Desired AND Measured cam position Desired cam position variation No Active DTCs	= TRUE > 11.00 volts = TRUE = FALSE = TRUE > 0 deg > 4.00 deg AND < 21.00 deg < 4.50 deg for (**P0014_P05CE_StablePositionTimeEc1**) sec P0013 P2090 P2091	40 failures out of 100 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft System Cold Start Performance – Bank 2	P05CF	Detects a VVT system error during Cold Starts by comparing the desired and actual cam positions when VVT is activated. This is the same type diagnostic as P0024 except this detects excessive deviations of position while the cold start phaser positions are being commanded.	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	Cam Position Error > 4.00 deg.	**Exhaust Cam Phsr Enable** System Voltage Engine Running Power Take Off (PTO) active **Catalyst Warmup Enabled** Desired cam position Desired AND Measured cam position Desired cam position variation No Active DTCs	= TRUE > 11.00 Volts = TRUE = FALSE = TRUE > 0 deg > 4.00 deg AND < 21.00 deg < 4.50 deg for (**P0024_P05CF_StablePositionTimeEc2**) seconds P0023 P2094 P2095	40 failures out of 100 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Low Voltage (ODM)	P0693	Diagnoses cooling fan 2 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50.00 failures out of 63.00 samples 100 ms / sample	Type B, 2 Trips Note: In certain controllers P0481 may also set (Fan 2 Open Circuit).

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit High Voltage (ODM)	P0694	Diagnoses the cooling fan 2 relay control low side driver circuit for circuit faults	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50.00 failures out of 63.00 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Low – Bank 1	P2090	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between signal and controller ground	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit High – Bank 1	P2091	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between signal and controller power	System supply voltage Output driver Ignition switch	> 11.00 Volts On Crank or Run	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Low– Bank 2	P2092	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between signal and controller ground	System supply voltage Output driver Ignition switch	> 11.00 Volts On Crank or Run	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit High–Bank 2	P2093	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between signal and controller power	System supply voltage Output driver Ignition switch	> 11.00 Volts On Crank or Run	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Low – Bank 2	P2094	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between signal and controller ground	System supply voltage Output driver Ignition switch	> 11.00 Volts On Crank or Run	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit High – Bank 2	P2095	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between signal and controller power	System supply voltage Output driver Ignition switch	> 11.00 Volts On Crank or Run	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (non-boosted applications)	P2228	Detects a continuous short to low or open in either the signal circuit or the BARO sensor.	BARO Voltage	< 40.0 % of 5 Volt Range (2.0 Volts = 50.9 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (non-boosted applications)	P2229	Detects an open sensor ground or continuous short to high in either the signal circuit or the BARO sensor.	BARO Voltage	> 90.0 % of 5 Volt Range (4.5 Volts = 115.0 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Conductivity Out Of Range (water in fuel)	P2269	Detects the presence of High Conductivity Fuel (e.g. water in fuel) via a specific range of sensor frequency that is higher than the normal out of range high threshold. High conductivity in the fuel causes a significant upward shift in the sensor's output frequency and does not indicate a failure of the sensor or wiring, but instead is a failure of the fuel conditions which requires different repair for the vehicle. If the raw frequency value is greater than the conductivity threshold value a fail counter will increment. When the correct ratio of failure counts vs. sample counts is achieved, the fault code is set.	Flex Fuel Sensor Output Frequency	> 185 Hertz	Powertrain Relay	> 11.0 Volts	50 failures out of 63 samples 100 ms loop Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Door Open Switch Signal - Door Ajar Switch Signal Not Plausible	B2A00	Compares the Door Ajar and Door Open Switch for mismatch	Door Open Switch AND Door Ajar switch	=OPEN = CLOSED	Ignition Not Fault Active	= Run/Crank OR = Accessory U0422	240 failure out of 240 samples 12.5 ms loop	Special Type C No MIL

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Electric Park Brake Availability Status Message Counter Incorrect	C1280	Detects error on ARC & PV reported by CHCM / ECM about signal $22A from EBCM on HS GMLAN	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress for:	within proper operating range for 3,000 msec > 3,000 msec	8 failures out of 10 samples 100 ms loop	DTC Type C No MIL

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Electric Park Brake Application Status Message Counter Incorrect	C1281	Detects error on ARC & PV reported by CHCM / ECM about signal $22A from EBCM on HS GMLAN	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress for:	within proper operating range for 3,000 msec for a time > 3,000 msec	8 failures out of 10 samples 100 ms loop	DTC Type C No MIL

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Open – Bank 1	P0013	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between signal and controller ground.	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft System Performance – Bank 1	P0014	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated.	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive.	(Exhaust cam Bank 1) Cam Position Error > (**P0014_CamPosErrorLimEc1**) deg	**Exhaust Cam Phsr Enable** System Voltage Engine Running Power Take Off (PTO) active Desired cam position Desired AND Measured cam position Desired cam position variation No Active DTCs	= TRUE > 11.00 Volts = TRUE = FALSE > 0 deg > (**P0014_CamPosErrorLimEc1**) deg AND < (**CalculatedPerfMaxEc1**) deg < 4.50 deg for (**P0014_P05CE_StablePositionTimeEc1**) seconds P0013 P2090 P2091	100.00 failures out of 300.00 samples 100 ms /sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)-Camshaft Position (CMP) Correlation Bank 1 Sensor A (mid-park phaser)	P0016	Detects cam to crank misalignment by monitoring if the cam sensor pulse for bank 1 sensor A occurs during the incorrect crank position, diagnostic passes when the cam sensor pulse is in the expected range	2 cam sensor pulses less than or greater than nominal position in one cam revolution.	-6.9 Crank Degrees 12.8 Crank Degrees	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic Delay diagnostic if Engine RPM and Cam is Enabled for	 CrankSensor_FA P0340, P0341 < 1.0 seconds > 2,000.00 Engine Speed < 5.00 seconds	2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. After the first failed test, there is a delay until the camshaft phaser control logic verifies and reports that the camshaft is actually parked. One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft - Sprocket Correlation Diagnostic	P0016 and P0017	On engines with a dual intermediate sprocket between the crankshaft and the camshafts, this diagnostic detects a timing misalignment between the crankshaft, sprocket and camshafts that will cause the bank 1 camshafts to be misaligned.	Bank 1 Cam Sensor A pulses more than -6.9 crank degrees before or 12.8 crank degrees after nominal position in one cam revolution + Bank 1 Cam Sensor B pulses more than -6.9 crank degrees before or 12.8 crank degrees after nominal position in one cam revolution.	>= 8	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs:	CrankSensor_FA P0340, P0341 P0365, P0366	2 failures out of 3 tests. A failed test is 1 out of 10 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table **P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold** . One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)-Camshaft Position (CMP) Correlation Bank 1 Sensor B (mid-park phaser)	P0017	Detects cam to crank misalignment by monitoring if the cam sensor pulse for bank 1 sensor B occurs during the incorrect crank position, diagnostic passes when the cam sensor pulse is in the expected range	. 2 cam sensor pulses less than or greater than nominal position in one cam revolution..	-6.9 Crank Degrees 12.8 Crank Degrees	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic Delay diagnostic if Engine RPM and Cam is Enabled for	 CrankSensor_FA P0365, P0366 < 1.0 seconds > 8,200.00 < 3.00	2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. After the first failed test, there is a delay until the camshaft phaser control logic verifies and reports that the camshaft is actually parked. One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)-Camshaft Position (CMP) Correlation Bank 2 Sensor A (mid-park phaser)	P0018	Detects cam to crank misalignment by monitoring if the cam sensor pulse for bank 2 sensor A occurs during the incorrect crank position, diagnostic passes when the cam sensor pulse is in the expected range	2 cam sensor pulses less than or greater than nominal position in one cam revolution..	-6.9 Crank Degrees 12.8 Crank Degrees	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic Delay diagnostic if Engine RPM and Cam is Enabled for	 CrankSensor_FA P0345, P0346 < 1.0 seconds > 2,000.00 < 5.00	2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. After the first failed test, there is a delay until the camshaft phaser control logic verifies and reports that the camshaft is actually parked. One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft - Sprocket Correlation Diagnostic	P0018 and P0019	On engines with a dual intermediate sprocket between the crankshaft and the camshafts, this diagnostic detects a timing misalignment between the crankshaft, sprocket and camshafts that will cause the bank 2 camshafts to be misaligned.	Bank 2 Cam Sensor A pulses more than -6.9 crank degrees before or 12.8 crank degrees after nominal position in one cam revolution + Bank 2 Cam Sensor B pulses more than -6.9 crank degrees before or 12.8 crank degrees after nominal position in one cam revolution	>= 8	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs:	CrankSensor_FA P0345, P0346 P0390, P0391	2 failures out of 3 tests. A failed test is 1 out of 10 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table **P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold** . One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)-Camshaft Position (CMP) Correlation Bank 2 Sensor B (mid-park phaser)	P0019	Detects cam to crank misalignment by monitoring if the cam sensor pulse for bank 2 sensor B occurs during the incorrect crank position, diagnostic passes when the cam sensor pulse is in the expected range	2 cam sensor pulses less than or greater than nominal position in one cam revolution..	-6.9 Crank Degrees 12.8 Crank Degrees	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic Delay diagnostic if Engine RPM and Cam is Enabled for	 CrankSensor_FA P0390, P0391 < 1.0 seconds > 8,200.00 < 3.00	2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. After the first failed test, there is a delay until the camshaft phaser control logic verifies and reports that the camshaft is actually parked. One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Open – Bank 2	P0020	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between signal and controller ground.	System supply voltage is within limits. Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Performance – Bank 2	P0021	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated.	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive.	(Intake cam Bank 2) Cam Position Error > (**P0021_CamPosErrorLimIc2**) deg	**Intake Cam Phsr Enable** System Voltage Engine Running Power Take Off (PTO) active Desired cam position Desired AND Measured cam position Desired cam position variation No Active DTCs	= TRUE > 11.00 Volts = TRUE = FALSE > 0 deg > (**P0021_CamPosErrorLimIc2**) deg AND < (**CalculatedPerfMaxIc2**) deg < 4.50 deg for (**P0021_P05CD_StablePositionTimeIc2**) seconds P0020 P2092 P2093	100.00 failures out of 300.00 samples 100 ms /sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Open – Bank 2	P0023	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between signal and controller ground.	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft System Performance – Bank 2	P0024	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Exhaust cam Bank 2) Cam Position Error > (**P0024_CamPosErrorLimEc2**) deg	**Exhaust Cam Phsr Enable** System Voltage Engine Running Power Take Off (PTO) active Desired cam position Desired AND Measured cam position Desired cam position variation No Active DTCs	= TRUE > 11.00 volts = TRUE = FALSE > 0 deg > (**P0024_CamPosErrorLimEc2**) deg AND < (**CalculatedPerfMaxEc2**) deg < 4.50 deg for (**P0024_P05CF_StablePositionTimeEc2**) seconds P0023 P2094 P2095	100.00 failures out of 300.00 samples 100 ms /sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger/ Supercharger Bypass Valve B Control Circuit If two parallel turbos are present.	P00C0	Controller specific output driver circuit diagnostic, diagnosing the 'compressor recirculation valve 'B' actuator' low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. In series applications, turbocharger 'B' is the second turbocharger in the direction of exhaust flow. In parallel applications, turbocharger 'B' is associated with engine bank 2.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between output and controller ground.	Diagnostic enabled ********** Powertrain relay Voltage ********** Engine does not crank Diagnostic system not disabled	True ********** >= 11.0 Volts **********	50 failures out of 63 samples 100ms / sample	Type A, 1 Trips Note: In certain controllers P00C1 may also set turbocharger/ supercharger bypass valve B control circuit low

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger/ Supercharger Bypass Valve B Control Circuit Low If two parallel turbos are present.	P00C1	Controller specific output driver circuit diagnostic, diagnosing the 'compressor recirculation valve 'B' actuator' low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. In series applications, turbocharger 'B' is the second turbocharger in the direction of exhaust flow. In parallel applications, turbocharger 'B'is associated with engine bank 2.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground. In certain controllers this diagnosis runs only when the HWIO-output is driven by the application S/W.	≤ 0.5 Ω impedance between output and controller ground	Diagnostic enabled ********** Powertrain relay voltage ********** Engine does not crank Diagnostic system not disabled	True ********** >= 11.0 Volts **********	50 failures out of 63 samples 100ms / sample	Type A, 1 Trips Note: In certain controllers P00C0 may also set turbocharger/ supercharger bypass valve B control circuit

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger/ Supercharger Bypass Valve B Control Circuit High If two parallel turbos are present.	P00C2	Controller specific output driver circuit diagnostic, diagnosing the 'compressor recirculation valve 'B' actuator' low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds. In series applications, turbocharger 'B' is the second turbocharger in the direction of exhaust flow. In parallel applications, turbocharger 'B' is associated with engine bank 2.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power. In certain controllers this diagnosis runs only when the HWIO-output is driven by the application S/W.	≤ 0.5 Ω impedance between output and controller power	Diagnostic enabled ********** Powertrain relay Voltage ********** Engine does not crank Diagnostic system not disabled	True ********** >= 11.0 Volts **********	50 failures out of 63 samples 100ms / sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Pressure Measurement System - Multiple Sensor Correlation (twin turbo)	P00C7	Detects an inconsistency between pressure sensors in the induction system in which a particular sensor cannot be identified as the failed sensor. If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The Manifold Pressure (MAP), Turbocharger Boost Pressure, Barometric Pressure (BARO) and BARO B sensors values are checked to see if they are within the normal expected atmospheric pressure range. If they are, then MAP, Turbocharger Boost Pressure, BARO and BARO B are compared to see if their values are similar. If three of these four sensors are similar, but the fourth is not, then a performance diagnostic for the specific sensor with the dissimilar value will fail. If there is no	See table **P00C7: Twin Turbo Failure Matrix** for the malfunction criteria for this diagnostic. Certain failure combinations in this matrix will set other DTCs if the failures can be correlated to a single sensor. The definition of the column headings is as follows: "MAP & TCBP Diff" = Y if: ABS(Turbocharger Boost Pressure - Manifold Pressure) "MAP & Baro Diff" = Y if: ABS(Baro Pressure - Manifold Pressure) "MAP & Baro B Diff" = Y if: ABS(Baro Pressure B - Manifold Pressure) "TCBP & Baro Diff" = Y if: ABS(Turbocharger Boost Pressure - Baro Pressure) "TCBP & Baro B Diff" = Y if:	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		combination of three of these four sensors that is similar, then the failed sensor cannot be uniquely identified. The Multiple Pressure Sensor Correlation Diagnostic will fail in this case.	ABS(Turbocharger Boost Pressure - Baro Pressure B) "Baro & Baro B Diff" = Y if: ABS(Baro Pressure - Baro Pressure B)	> 10.0 kPa > 10.0 kPa				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (twin turbo)	P0101	Detects a performance failure in the Mass Air Flow (MAF) sensor, such as when a MAF value is stuck in range. This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the MAF B sensor, Manifold Pressure (MAP) sensor, Turbocharger Boost Pressure sensor and Throttle Position sensor (TPS). These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the MAF sensor. In this case, the MAF Performance diagnostic	See table **P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix** for combinations of model failures that can set this DTC. For P0101: MAF model fails when MAF1 model fails. MAF1 model fails when: ABS(Measured MAF1 Flow – Modeled MAF1 Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		will fail.	TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset**	> 30.0 kPa		MAP Model 2 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP Model 3 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM**		
			OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset**	> 30.0 kPa		TIAP Model 1 Error multiplied by **P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM** Filtered Throttle Model Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM**		
			TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time	> 1.5 seconds > 1.5 seconds	No Active DTCs:	MAP_SensorCircuitFA EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault		
			High Engine Air Flow is TRUE when Mass Air Flow	> a threshold in	No Pending DTCs:	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				gm/sec as a function of engine speed. See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow**		MnfdTempSensorCktFP		
			AND Manifold Pressure	> a threshold in kPa as a function of engine speed. See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP**				
			AND Filtered Mass Air Flow - Mass Air Flow	< 2.0 gm/sec				
			Low Engine Air Flow is TRUE when Mass Air Flow	< a threshold in gm/sec as a function of engine speed. See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow**				
			AND Manifold Pressure	< a threshold in kPa as a function of engine speed. See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP**				
			AND Mass Air Flow - Filtered Mass Air Flow	< 2.0 gm/sec				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (twin turbo)	P0106	Detects a performance failure in the Manifold Pressure (MAP) sensor, such as when a MAP value is stuck in range. If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The MAP sensor value is checked to see if it is within the normal expected atmospheric pressure range. If it is not, then the MAP performance diagnostic will fail. If the MAP sensor value is within the normal expected atmospheric range, then MAP, Turbocharger Boost Pressure, Barometric Pressure (BARO) and BARO B are compared to see if their values are similar. If the Turbocharger Boost Pressure, BARO and BARO B sensor values are similar, but the MAP value is not similar, then a MAP performance diagnostic will fail.	**Engine Running:** See table **P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix** for combinations of model failures that can set this DTC. MAF model fails when either MAF1 model fails or MAF2 model fails. MAF1 model fails when: ABS(Measured MAF1 Flow – Modeled MAF1 Flow) Filtered MAF2 model failres when: ABS(Measured MAF2 Flow – Modeled MAF2 Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		The engine running portion of this diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Mass Air Flow (MAF) sensor, MAF B sensor, Turbocharger Boost Pressure sensor and Throttle Position sensor (TPS). These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the MAP sensor. In this case, the MAP Performance diagnostic will fail.	TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset** OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset** TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has	> 300 kPa*(g/s) > 30.0 kPa > 30.0 kPa > 1.5 seconds	No Active DTCs:	**P0101, P0106, P010B, P0121, P0236, P1101: MAF2 Residual Weight Factor based on RPM** MAP Model 1 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM** MAP Model 2 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP Model 3 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM** TIAP Model 1 Error multiplied by **P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM** Filtered Throttle Model Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM** MAP_SensorCircuitFA		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			been TRUE for a period of time High Engine Air Flow is TRUE when Mass Air Flow AND Manifold Pressure AND Filtered Mass Air Flow - Mass Air Flow Low Engine Air Flow is TRUE when Mass Air Flow AND Manifold Pressure	> 1.5 seconds > a threshold in gm/sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow** > a threshold in kPa as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP** < 2.0 gm/sec < a threshold in gm/sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow** < a threshold in kPa as a function of engine speed See table	No Pending DTCs:	EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AND Mass Air Flow - Filtered Mass Air Flow	**P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP** < 2.0 gm/sec				
			Engine Not Rotating: Manifold Pressure OR Manifold Pressure OR ABS(Manifold Pressure - Turbocharger Boost Pressure) AND ABS(Manifold Pressure - Baro Pressure) AND ABS(Manifold Pressure - Baro Pressure B) AND ABS(Turbocharger Boost Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure B) AND ABS(Baro Pressure - Baro Pressure B)	 < 50.0 kPa > 115.0 kPa > 10.0 kPa > 10.0 kPa > 10.0 kPa <= 10.0 kPa <= 10.0 kPa <= 10.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating No Active DTCs: No Pending DTCs:	 > 10.0 seconds EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA AAP2_SnsrCktFA AAP3_SnsrCktFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP AAP3_SnsrCktFP	4 failures out of 5 samples 1 sample every 12.5 msec	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass or Volume Air Flow B Circuit Range/ Performance	P010B	Detects a performance failure in the Mass Air Flow (MAF) B sensor, such as when a MAF B value is stuck in range. This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the MAF sensor, Manifold Pressure (MAP) sensor, Turbocharger Boost Pressure sensor and Throttle Position sensor (TPS). These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the MAF B sensor. In this case, the MAF B Performance diagnostic	See table **Turbocharger P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix** for combinations of model failures that can set this DTC. For P010B: MAF model fails when MAF2 model fails. MAF2 model fails when ABS(Measured MAF2 Flow – Modeled MAF2 Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		will fail.	TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset** OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset**	> 30.0 kPa > 30.0 kPa		MAP Model 2 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP Model 3 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM** TIAP Model 1 Error multiplied by **P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM** Filtered Throttle Model Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM**		
			TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time High Engine Air Flow is TRUE when	> 1.5 seconds > 1.5 seconds	No Active DTCs: No Pending DTCs:	MAP_SensorCircuitFA EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Mass Air Flow	> a threshold in gm/sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow**		MnfdTempSensorCktFP		
			AND Manifold Pressure	> a threshold in kPa TIAP-MAP as a function of engine speed. See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP**				
			AND Filtered Mass Air Flow - Mass Air Flow	< 2.0 gm/sec				
			Low Engine Air Flow is TRUE when Mass Air Flow	< a threshold in gm/sec as a function of engine speed. See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow**				
			AND Manifold Pressure	< a threshold in kPa as a function of engine speed. See table				
			-					

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP				
			AND Mass Air Flow - Filtered Mass Air Flow	< 2.0 gm/sec				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow B Sensor Circuit Low Frequency	P010C	Detects a continuous short to ground in the MAF B sensor circuit or a MAF B sensor that is outputting a frequency that is too low. The diagnostic monitors the MAF B sensor frequency output and fails the diagnostic when the MAF B frequency is too low. The MAF B sensor monitors the temperature of a circuit in the air flow of the engine. The temperature of this circuit is related to the air velocity across the sensor. The MAF B sensor converts this air velocity to a mass air flow value. The mass air flow value is converted by the sensor to a frequency value in Hertz. A digital square wave signal is transmitted by the sensor to the ECM. The ECM calculates the frequency of the square wave signal and converts that frequency to a mass air flow value in grams/second through a transfer function.	MAF B Output	<= 400 Hertz (~ 0.01 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 0.0 seconds >= 300 RPM >= 10.0 Volts >= 1.0 seconds	300 failures out of 375 samples 1 sample every cylinder firing event	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow B Sensor Circuit High Frequency	P010D	Detects a MAF B sensor that is outputting a frequency signal that is too high. The diagnostic monitors the MAF B sensor frequency output and fails the diagnostic when the MAF B frequency is too high. The MAF B sensor monitors the temperature of a circuit in the air flow of the engine. The temperature of this circuit is related to the air velocity across the sensor. The MAF B sensor converts this air velocity to a mass air flow value. The mass air flow value is converted by the sensor to a frequency value in Hertz. A digital square wave signal is transmitted by the sensor to the ECM. The ECM calculates the frequency of the square wave signal and converts that frequency to a mass air flow value in grams/second through a transfer function.	MAF B Output	>= 14,500 Hertz (~ 546.2 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 0.0 seconds >= 300 RPM >= 10.0 Volts >= 1.0 seconds	300 failures out of 375 samples 1 sample every cylinder firing event	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (twin turbo)	P0121	Detects a performance failure in the Throttle Position sensor (TPS) sensor, such as when a TPS value is stuck in range. This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Manifold Pressure (MAP) sensor, Turbocharger Boost Pressure sensor, Mass Air Flow (MAF) sensor and MAF B sensor. These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the TPS sensor. In this case, the TPS	See table **P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix** for combinations of model failures that can set this DTC. MAF model fails when either MAF1 model fails or MAF2 model fails. MAF1 model fails when ABS(Measured MAF1 Flow – Modeled MAF1 Flow) Filtered MAF2 model fails when ABS(Measured MAF2 Flow – Modeled MAF2 Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered	> 20.0 grams/sec > 20.0 grams/sec > 25.0 kPa > 25.0 kPa > 25.0 kPa > 30.0 kPa	Engine Speed Engine Speed (Coolant Temp OR OBD Coolant Enable Criteria (Coolant Temp OR OBD Max Coolant Achieved Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together) See Residual Weight Factor tables.	>= 400 RPM <= 6,100 RPM >= -9 Deg C = TRUE) <= 150 Deg C = FALSE) >= -20 Deg C <= 125 Deg C >= 0.50 Modeled MAF1 Error multiplied by **P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM** and **P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est** Modeled MAF2 Error multiplied by **P0101, P0106, P010B, P0121, P0236, P1101: MAF2 Residual Weight Factor based on MAF Est**	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Performance diagnostic will fail.	TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset** OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset** TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time High Engine Air Flow is	> 300 kPa*(g/s) > 30.0 kPa > 30.0 kPa > 1.5 seconds > 1.5 seconds	No Active DTCs:	and **P0101, P0106, P010B, P0121, P0236, P1101: MAF2 Residual Weight Factor based on RPM** MAP Model 1 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM** MAP Model 2 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP Model 3 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM** TIAP Model 1 Error multiplied by **P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM** Filtered Throttle Model Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM** MAP_SensorCircuitFA		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			TRUE when Mass Air Flow AND Manifold Pressure AND Filtered Mass Air Flow - Mass Air Flow Low Engine Air Flow is TRUE when Mass Air Flow AND Manifold Pressure -	> a threshold in gm sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow** > a threshold in kPa as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP** < 2.0 gm/sec < a threshold in gm sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow** < a threshold in kPa as a function of engine speed See table	No Pending DTCs:	EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AND Mass Air Flow - Filtered Mass Air Flow	**P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP** < 2.0 gm/sec				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 1 (For use with WRAF - E81	P0131	This DTC determines if the WRAF O2 sensor signal circuit is shorted low. This DTC will detect a short to ground fault to the Pump Current, Reference Cell Voltage and Reference Ground circuits. When enabled, the diagnostic monitors the three different failure counters it receives from the WRAF Application-Specific Integrated Circuit (ASIC). The individual diagnostic failure counters are incremented based on the message received from the ASIC. The DTC is set based on any of the three individual fail and sample counters.	B1S1 WRAF ASIC indicates a ground short to any of the following WRAF signals: A) Pump Current - short to ground fail counts are accumulated to determine fault status. B) Reference Cell Voltage - short to ground fail counts are accumulated to determine fault status. C) Reference Ground - short to ground fail counts are accumulated to determine fault status. Note: This ASIC is referred to as ATIC142 (Continental). Note: A ground short on the Pump Current or Reference Voltage signal may also set a P223C DTC.	The ASIC provides a fault indication when the pump current, reference cell or reference ground pin is < 150mV. Note: the faults must exist for previous 100 milli - seconds to qualify for a fail flag. The three fault signals have individual X out of Y calibrations. When the X out of Y is reached in any region this DTC is set.	B1S1 DTC's Not active this key cycle Measure Valid status (ASIC) Controller status (ASIC) Engine Run or Auto stop WRAF Ref cell temperature ********** Heater Warm-up delay Then WRAF circuit diagnostic delay (since heater Warm-up delay is complete) **********	P0135, P0030, P0031 or P0032 = Valid = Ready = True ≥ 628 Deg C = Complete ≥ 20.0 seconds	Signal A: 128 failures out of 160 samples OR Signal B: 128 failures out of 160 samples OR Signal C: 128 failures out of 160 samples Continuous in 25 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 1 (For use with WRAF - E81	P0132	This DTC determines if the WRAF O2 sensor signal circuit is shorted high. This DTC will detect a short to power fault to the Pump Current (and Trim circuit), Reference Cell Voltage and Reference Ground circuit. When enabled, the diagnostic monitors the three different failure counters it receives from the WRAF Application-Specific Integrated Circuit (ASIC). The individual diagnostic failure counters are incremented based on the message received from the ASIC. The DTC is set based on any of the three individual fail and sample counters.	B1S1 WRAF ASIC indicates a short to power on any of the following WRAF signals: A) Pump Current - short to power fail counts are accumulated to determine fault status. B) Reference Cell Voltage - short to power fail counts are accumulated to determine fault status. C) Reference Ground - short to power fail counts are accumulated to determine fault status. <u>Note</u>: This ASIC is referred to as ATIC142 (Continental)..	The ASIC provides a fault indication when the pump current, reference cell or reference ground pin is ≥ 5.2V. Note: the faults must exist for more than 100 msec to qualify for a fail flag. The three fault signals have individual X out of Y calibrations. When the X out of Y is reached in any region this DTC is set.	B1S1 DTC's Not active this key cycle Measure Valid Status (ASIC) Controller status (ASIC) Engine Run or Auto stop WRAF Ref cell temperature ********** Heater Warm-up delay Then WRAF circuit diagnostic delay (since heater Warm-up delay is complete) **********	P0135, P0030, P0031 or P0032 = Valid = Ready = True ≥ 628 Deg C = Complete ≥ 20.0 seconds	Signal A: 128 failures out of 160 samples OR Signal B: 128 failures out of 160 samples OR Signal C: 128 failures out of 160 samples Frequency: Continuous in 25 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 2 Sensor 1 (For use with WRAF - E81	P0151	This DTC determines if the WRAF O2 sensor signal circuit is shorted low. This DTC will detect a short to ground fault to the Pump Current, Reference Cell Voltage and Reference Ground circuits. When enabled, the diagnostic monitors the three different failure counters it receives from the WRAF Application-Specific Integrated Circuit (ASIC). The individual diagnostic failure counters are incremented based on the message received from the ASIC. The DTC is set based on any of the three individual fail and sample counters.	B2S1 WRAF ASIC indicates a ground short to any of the following WRAF signals: A) Pump Current - short to ground fail counts are accumulated to determine fault status. B) Reference Cell Voltage - short to ground fail counts are accumulated to determine fault status. C) Reference Ground - short to ground fail counts are accumulated to determine fault status. Note: This ASIC is referred to as ATIC142 (Continental). Note: A ground short on the Pump Current or Reference Voltage signal may also set a P223D DTC.	The ASIC provides a fault indication when the pump current, reference cell or reference ground pin is < 150mV. Note: the faults must exist for more than 83.3us to qualify for a fail flag. The three fault signals have individual X out of Y calibrations. When the X out of Y is reached in any region this DTC is set.	B2S1 DTC's Not active this key cycle Measure Valid status (ASIC) Controller status (ASIC) Engine Run or Auto stop WRAF Ref cell temperature ********** Heater Warm-up delay Then WRAF circuit diagnostic delay (since heater Warm-up delay is complete) **********	P0155, P0050, P0051 or P0052 = Valid = Ready = True ≥ 628 Deg C = Complete ≥ 20.0 seconds	Signal A: 128 failures out of 160 samples OR Signal B: 128 failures out of 160 samples OR Signal C: 128 failures out of 160 samples Continuous in 25 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 2 Sensor 1 (For use with WRAF - E81	P0152	This DTC determines if the WRAF O2 sensor signal circuit is shorted high. This DTC will detect a short to power fault to the Pump Current (and Trim circuit), Reference Cell Voltage and Reference Ground circuit. When enabled, the diagnostic monitors the three different failure counters it receives from the WRAF Application-Specific Integrated Circuit (ASIC). The individual diagnostic failure counters are incremented based on the message received from the ASIC. The DTC is set based on any of the three individual fail and sample counters.	B2S1 WRAF ASIC indicates a short to power on any of the following WRAF signals: A) Pump Current - short to power fail counts are accumulated to determine fault status. B) Reference Cell Voltage - short to power fail counts are accumulated to determine fault status. C) Reference Ground - short to power fail counts are accumulated to determine fault status. <u>Note</u>: This ASIC is referred to as ATIC142 (Continental).	The ASIC provides a fault indication when the pump current, reference cell or reference ground pin is ≥ 5.2V. Note: the faults must exist for more than 83.3us to qualify for a fail flag. The three fault signals have individual X out of Y calibrations. When the X out of Y is reached in any region this DTC is set.	B2S1 DTC's Not active this key cycle Measure Valid Status (ASIC) Controller status (ASIC) Engine Run or Auto stop WRAF Ref cell temperature ********** Heater Warm-up delay Then WRAF circuit diagnostic delay (since heater Warm-up delay is complete) **********	P0155, P0050, P0051 or P0052 = Valid = Ready = True ≥ 628 Deg C = Complete ≥ 20.0 seconds	Signal A: 128 failures out of 160 samples OR Signal B: 128 failures out of 160 samples OR Signal C: 128 failures out of 160 samples Frequency: Continuous in 25 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 1) (For use with WRAF	P015A	DTC P015A detects that the primary WRAF oxygen sensor for Bank 1 has delayed response when the air fuel ratio transitions from rich to lean condition. This diagnostic runs simultaneously with the intrusive secondary O2 monitor rich to lean tests (P013E / P013A / P2271), which commands fuel cut off. Note: The Primary method is used when the primary WRAF O2 sensor signal transitions from above to below the O2 measured EQR threshold, otherwise the Secondary method is used. <u>Primary method</u>: The P015A diagnostic measures the primary WRAF O2 sensor response time between a rich condition above a starting measured EQR threshold and a lower measured EQR threshold. The response time is then scaled and normalized to mass air flow rate, engine speed, Baro,	Primary method: The EWMA of the Pre O2 sensor normalized R2L time delay value. The EWMA repass limit is The EWMA calculation uses a 0.25 coefficient. This method calculates the result when the WRAF O2 sensor measured EQR is OR Secondary Method: The Accumulated time monitored during the R2L Delayed Response Test. AND Pre WRAF O2 sensor measured EQR is	> 0.55 EWMA (sec) ≤ 0.48 EWMA (sec) < 1.000 EQR ≥ 2.5 Seconds > 0.500 EQR	No Active DTC's System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Only when FuelLevelDataFault Green O2S Condition	TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA WRAF_Bank_1_FA P0131, P0132, P013A, P013B, P013E, P013F, P2270, P2271 > 10.0 Volts = Not active = Not active = Not active = Not active = False = False = Not Valid,	Frequency: Once per trip Note: if NaESPD_b_FastInitRespIsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponseIsActive = TRUE, multiple tests per trip are allowed	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and intake air temperature resulting in a normalized delay value. The normalized delay is fed into a 1st order lag filter to update the final EWMA result. DTC P015A is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value. <u>Secondary method</u>: This fault is set if the primary WRAF O2 sensor does not achieve the required lower measured EQR			O2 Heater (pre sensor) on for Engine Coolant (Or OBD Coolant Enable Criteria IAT Engine run Accum Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) Closed loop integral Closed Loop Active	Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec. ≥ 30 seconds > 55 ºC = TRUE) > -40 ºC > 30 seconds 1,050 ≤ RPM ≤ 2,500 1,000 ≤ RPM ≤ 2,550 3.2 ≤ gps ≤ 11.5 42.3 ≤ MPH ≤ 80.2 38.5 ≤ MPH ≤ 82.0 0.87 ≤ C/L Int ≤ 1.07 = TRUE (Please see "**Closed Loop Enable Clarification**" in Supporting Tables).		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		threshold before a delay time threshold is reached.			Evap Ethanol Estimation in Progress Baro Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State ========== All of the above met for at least 3.0 seconds, and then the Force Cat Rich intrusive stage is requested. ========== Pre O2S EQR B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders ========== After above conditions are met: DFCO Mode is entered (wo driver initiated pedal input).	not in control of purge = Not Active (Please see "**Ethanol Estimation in Progress**" in Supporting Tables). > 70 kpa = enabled = not active = not active ≥ 60.0 sec 500 ≤ ºC ≤ 880 = DFCO possible ========== ========== ≥ 1.100 EQR = DFCO active ≤ 5 cylinders ==========		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 1) (For use with WRAF	P015B	DTC P015B detects that the primary WRAF oxygen sensor for Bank 1 has delayed response when the air fuel ratio transitions from lean to rich condition. This diagnostic runs simultaneously with the intrusive secondary O2 monitor lean to rich tests (P013F / P013B), which commands fuel enrichment. Note: The Primary method is used when the primary WRAF O2 sensor signal transitions from lean condition to above the O2 measured EQR threshold, otherwise the Secondary method is used. <u>Primary method</u>: The P015B diagnostic measures the primary WRAF O2 sensor response time between a lean condition and a higher measured EQR threshold. The response time is then scaled and normalized to mass air flow rate, engine speed, Baro, and intake air temperature resulting in	Primary method: The EWMA of the Pre O2 sensor normalized L2R time delay value. The EWMA repass limit is The EWMA calculation uses a 0.25 coefficient. OR Secondary method: The Accumulated time monitored during the L2R Delayed Response Test. AND Pre WRAF O2 sensor measured EQR is OR At end of Cat Rich stage the Pre WRAF O2 sensor measured EQR is	> 0.60 EWMA (sec) ≤ 0.50 EWMA (sec) ≥ 2.0 Seconds < 1.000 EQR < 1.100 EQR	No Active DTC's P015A test is complete and System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Only when FuelLevelDataFault	TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA WRAF_Bank_1_FA P0131, P0132, P013A, P013B, P013E, P013F, P015A, P2270, P2271 = Passed > 10.0 Volts = Not active = Not active = Not active = Not active = False = False	Frequency: Once per trip Note: if NaESPD_b_FastInitRespIsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponseIsActive = TRUE, multiple tests per trip are allowed	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		a normalized delay value. The normalized delay is fed into a 1st order lag filter to update the final EWMA result. DTC P015B is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value. <u>Secondary method</u>: This fault is set if the primary WRAF O2 sensor does not achieve the required higher measured EQR threshold before a delay time threshold is			Green O2S Condition O2 Heater (pre sensor) on for Engine Coolant (Or OBD Coolant Enable Criteria IAT Engine run Accum Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) Closed loop integral Closed Loop Active	= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec. ≥ 30 seconds > 55 ºC = TRUE) > -40 ºC > 30 seconds 1,050 ≤ RPM ≤ 2,500 1,000 ≤ RPM ≤ 2,550 3.2 ≤ gps ≤ 11.5 42.3 ≤ MPH ≤ 80.2 38.5 ≤ MPH ≤ 82.0 0.87 ≤ C/L Int ≤ 1.07 = TRUE		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		reached.				(Please see "**Closed Loop Enable Clarification**" in Supporting Tables).		
					Evap	not in control of purge		
					Ethanol Estimation in Progress	= Not Active (Please see "**Ethanol Estimation in Progress**" in Supporting Tables).		
					Baro	> 70 kpa		
					Post fuel cell	= enabled		
					EGR Intrusive diagnostic	= not active		
					All post sensor heater delays	= not active		
					O2S Heater (post sensor) on time	≥ 60.0 sec		
					Predicted Catalyst temp	500 ≤ ºC ≤ 880		
					Fuel State	= DFCO inhibit		
					Number of fueled cylinders	≥ 1 cylinders		
					==========	==========		
					When above conditions are met: Fuel Enrich mode is entered.			
					==========	==========		
					During this test: Engine Airflow must stay between:	0 ≤ gps ≤ 13		
					and the delta Engine Airflow over 12.5msec must be :	≤ 0.8 gps		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 2 Sensor 1) (For use with WRAF	P015C	DTC P015C detects that the primary WRAF oxygen sensor for Bank 2 has delayed response when the air fuel ratio transitions from rich to lean condition. This diagnostic runs simultaneously with the intrusive secondary O2 monitor rich to lean tests (P014A / P013C / P2273), which commands fuel cut off. Note: The Primary method is used when the WRAF O2 sensor signal transitions from above to below the O2 measured EQR threshold, otherwise the Secondary method is used. <u>Primary method</u>: The P015C diagnostic measures the primary WRAF O2 sensor response time between a rich condition above a starting measured EQR threshold and a lower measured EQR threshold. The response time is then scaled and normalized to mass air flow rate, engine speed, Baro, and intake air	Primary method: The EWMA of the Pre O2 sensor normalized R2L time delay value. The EWMA repass limit is The EWMA calculation uses a 0.25 coefficient. This method calculates the result when the WRAF O2 sensor measured EQR is OR Secondary method: The Accumulated time monitored during the R2L Delayed Response Test. AND Pre WRAF O2 sensor measured EQR is above	> 0.55 EWMA (sec) ≤ 0.48 EWMA (sec) < 1.0 EQR ≥ 2.5 Seconds > 0.500 EQR	No Active DTC's System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Only when FuelLevelDataFault Green O2S Condition	TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA WRAF_Bank_2_FA P0151, P0152, P013C, P013D, P014A, P014B, P2272, P2273 > 10.0 Volts = Not active = Not active = Not active = Not active = False = False = Not Valid,	Frequency: Once per trip Note: if NaESPD_b_FastInitRespIsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponseIsActive = TRUE, multiple tests per trip are allowed	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		temperature resulting in a normalized delay value. The normalized delay is fed into a 1st order lag filter to update the final EWMA result. DTC P015C is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value. <u>Secondary method</u>: This fault is set if the primary WRAF O2 sensor does not achieve the required lower measured EQR threshold before a			O2 Heater (pre sensor) on for Engine Coolant (Or OBD Coolant Enable Criteria IAT Engine run Accum Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) Closed loop integral Closed Loop Active	Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec. ≥ 30 seconds > 55 ºC = TRUE) > -40 ºC > 30 seconds 1,050 ≤ RPM ≤ 2,500 1,000 ≤ RPM ≤ 2,550 3.2 ≤ gps ≤ 11.5 42.3 ≤ MPH ≤ 80.2 38.5 ≤ MPH ≤ 82.0 0.87 ≤ C/L Int ≤ 1.07 = TRUE (Please see "**Closed Loop Enable Clarification**" in		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		delay time threshold is reached.				Supporting Tables).		
					Evap	not in control of purge		
					Ethanol Estimation in Progress	= Not Active (Please see "**Ethanol Estimation in Progress**" in Supporting Tables).		
					Baro	> 70 kpa		
					Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time	= enabled = not active = not active ≥ 60.0 sec		
					Predicted Catalyst temp Fuel State	500 ≤ ºC ≤ 880 = DFCO possible		
					========== All of the above met for at least 3.0 seconds, and then the Force Cat Rich intrusive stage is requested. ==========	========== ==========		
					Pre O2S EQR B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders ==========	≥ 1.100 EQR = DFCO active ≤ 5 cylinders ==========		
					After above conditions are met: DFCO Mode is entered (wo driver initiated pedal input).			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 2 Sensor 1) (For use with WRAF	P015D	DTC P015D detects that the primary WRAF oxygen sensor for Bank 2 has delayed response when the air fuel ratio transitions from lean to rich condition. This diagnostic runs simultaneously with the intrusive secondary O2 monitor lean to rich tests (P014B / P013D), which commands fuel enrichment. Note: The Primary method is used when the primary WRAF O2 sensor signal transitions from lean condition to above the O2 measured EQR threshold, otherwise the Secondary method is used. <u>Primary method</u>: The P015D diagnostic measures the primary WRAF O2 sensor response time between a lean condition and a higher measured EQR threshold. The response time is then scaled and normalized to mass air flow rate, engine speed, Baro, and intake air temperature resulting in	Primary method: The EWMA of the Pre O2 sensor normalized L2R time delay value. The EWMA repass limit is The EWMA calculation uses a 0.25 coefficient. OR Secondary method: The Accumulated time monitored during the L2R Delayed Response Test. AND Pre WRAF O2 sensor measured EQR is OR At end of Cat Rich stage the Pre WRAF O2 sensor measured EQR is	> 0.60 EWMA (sec) ≤ 0.50 EWMA (sec) ≥ 2.0 Seconds < 1.000 EQR < 1.100 EQR	No Active DTC's

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		a normalized delay value. The normalized delay is fed into a 1st order lag filter to update the final EWMA result. DTC P015D is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value. <u>Secondary method</u>: This fault is set if the primary WRAF O2 sensor does not achieve the required higher measured EQR threshold before a delay time threshold is			Green O2S Condition O2 Heater (pre sensor) on for Engine Coolant (Or OBD Coolant Enable Criteria IAT Engine run Accum Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) Closed loop integral Closed Loop Active	= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than **Multiple DTC Use_Green Sensor Delay Criteria - Limit** for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec. ≥ 30 seconds > 55 ºC = TRUE) > -40 ºC > 30 seconds 1,050 ≤ RPM ≤ 2,500 1,000 ≤ RPM ≤ 2,550 3.2 ≤ gps ≤ 11.5 42.3 ≤ MPH ≤ 80.2 38.5 ≤ MPH ≤ 82.0 0.87 ≤ C/L Int ≤ 1.07 = TRUE (Please see "**Closed**		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		reached.				**Loop Enable Clarification**" in Supporting Tables).		
					Evap	not in control of purge		
					Ethanol Estimation in Progress	= Not Active (Please see "**Ethanol Estimation in Progress**" in Supporting Tables).		
					Baro	> 70 kpa		
					Post fuel cell	= enabled		
					EGR Intrusive diagnostic	= not active		
					All post sensor heater delays	= not active		
					O2S Heater (post sensor) on Time	≥ 60.0 sec		
					Predicted Catalyst temp	500 ≤ ºC ≤ 880		
					Fuel State	= DFCO inhibit		
					Number of fueled cylinders	≥ 1 cylinders		
					========== When above conditions are met: Fuel Enrich mode is entered.	==========		
					========== During this test: Engine Airflow must stay between: and the delta Engine Airflow over 12.5msec must be :	========== 0 ≤ gps ≤ 13 ≤ 0.8 gps		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi-Function Input B Circuit	P0589	Detect when cruise control multi-function switch circuit B (analog) voltage is in an illegal range	Cruise Control analog circuit B voltage must be "between ranges" for greater than a calibratable period of time.	The cruise control analog voltage A/D count ratio is considerred to be "between ranges" when the ratio is measured in the following ranges: 0.28 -0.31, 0.415-0.445, 0.585 - 0.615, 0.78 - 0.81, 1.005 - 1.035	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 0.500 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi-Function Input B Circuit Low	P0592	detects short to ground failure for cruise multi-function switch circuit B	Cruise Control analog circuit B voltage must be in an "Open Short To Ground" range for greater than a calibratable period of time.	The cruise control Circuit B analog voltage A/D count ratio is considered to be "open short to groun"d when the ratio is measured in the following rangs: 0 - 0.185	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	Type C, No SVS ,"Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi-Function Input B Circuit High	P0593	detects short to power failure for cruise multi-function switch circuit B	Cruise Control analog circuit B voltage must be in a "Short To Power" range for greater than a calibratable period of time.	The cruise control Circuit B analog voltage A/D count ratio is considered to be "short to power" when the ratio is measured in the following range: 1.005 - 1.035	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Cold Start Performance – Bank 1	P05CC	Detects a VVT system error during Cold Starts by comparing the desired and actual cam positions when VVT is activated. This is the same type diagnostic as P0011 except this detects excessive deviations of position while the cold start phaser positions are being commanded.	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	Cam Position Error > 4.00 deg.	**Intake Cam Phsr Enable** System Voltage Engine Running Power Take Off (PTO) active **Catalyst Warmup Enabled** Desired cam position Desired AND Measured cam position Desired cam position variation No Active DTCs	= TRUE > 11.00 Volts = TRUE = FALSE = TRUE > 0 deg > 4.00 deg AND < 30.00 deg < 4.50 deg for (**P0011_P05CC_StablePositionTimeIc1**) seconds P0010 P2088 P2089	60 failures out of 100 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Cold Start Performance – Bank 2	P05CD	Detects a VVT system error during Cold Starts by comparing the desired and actual cam positions when VVT is activated. This is the same type diagnostic as P0021 except this detects excessive deviations of position while the cold start phaser positions are being commanded.	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	Cam Position Error > 4.00 deg.	**Intake Cam Phsr Enable** System Voltage Engine Running Power Take Off (PTO) active **Catalyst Warmup Enabled** Desired cam position Desired AND Measured cam position Desired cam position variation No Active DTCs	= TRUE > 11.00 Volts = TRUE = FALSE = TRUE > 0 deg > 4.00 deg AND < 30.00 deg < 4.50 deg for (**P0021_P05CD_StablePositionTimeIc2**) seconds P0020 P2092 P2093	150 failures out of 200 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module O2 Sensor Processor Performance Bank 1) (For use with WRAF	P064D	Diagnoses the WRAF Application-Specific Integrated Circuit (ASIC) for Controller Status and Measure Valid faults. These faults can impact closed loop fuel control. This DTC when enabled, monitors the two different failure counters it receives from the WRAF ASIC. The individual diagnostic failure counters are incremented based on the message received from the ASIC. The DTC is set based on any of the two individual fail and sample counters.	B1S1 WRAF ASIC indicates control module faults	Controller Status fail counts and Measure Valid fail counts are accumulated to determine fault status	Engine Run or Auto stop Heater Warm-up delay WRAF circuit diagnostic delay since power up	= True = Complete ≥ 20.0 sec	128 controller status fail counts out of 160 samples OR 128 measure valid fail counts out of 160 samples 25 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module O2 Sensor Processor Performance Bank 2) (For use with WRAF	P064E	Diagnoses the WRAF Application-Specific Integrated Circuit (ASIC) for Controller Status and Measure Valid faults. These faults can impact closed loop fuel control. This DTC when enabled, monitors the two different failure counters it receives from the WRAF ASIC. The individual diagnostic failure counters are incremented based on the message received from the ASIC. The DTC is set based on any of the two individual fail and sample counters.	B2S1 WRAF ASIC indicates control module faults	Controller Status fail counts and Measure Valid fail counts are accumulated to determine fault status	Engine Run or Auto stop Heater Warm-up delay WRAF circuit diagnostic delay since power up	= True = Complete ≥ 20.0 sec	128 controller status fail counts out of 160 samples OR 128 measure valid fail counts out of 160 samples 25 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Shared High Side Drive #1 Control Circuit Low (STG) - (GEN III Controllers ONLY)	P0658	Controller specific output driver circuit diagnoses the shared high sided driver # 1 for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	- Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. - Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between output and controller ground	Shared high side drive #1 low diag enable Powertrain relay voltage Run Crank voltage Powertrain relay state	= 1.00 >= 11.00 > 5.00 = ON	20 failures out of 25 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Shared High Side Drive #1 Control Circuit High (STP) - (GEN III Controllers ONLY)	P0659	Controller specific output driver circuit diagnoses the shared high sided driver # 1 for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	- Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. - Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between output and controller power	Shared high side drive #1 diag enable Powertrain relay voltage Run Crank voltage Powertrain relay state	= 1.00 >= 11.00 > 5.00 = ON	20 failures out of 25 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Unable to Engage Neutral	P073D	Detects the inability to achieve or remain in Neutral.	Actual Arbitrated Transmission Range	≠Neutral	Actual Transmission Range Commanded Transmission Range AND CodeClearFunction AND ManufacturingModeActive AND: External: Run/Crank OR Accessory/Wakeup Internal: From the time when RunCrankActive until ActualRange AND Accessory/Wakeup	= Good value = Neutral =False =False =True = True =True =Park =False	10,000.00 msec from Park 10,000.00 msec from Reverse 10,000.00 msec from Drive	DTC Type B, Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Unable to Engage Reverse	P073E	Detects the failure to achieve the expected command to Reverse range.	Actual Arbitrated Transmission Range	≠Reverse	Actual Transmission Range Commanded Transmission Range AND CodeClearFunction AND ManufacturingModeActive AND: External: Run/Crank OR Accessory/Wakeup Internal: From the time when RunCrankActive until ActualRange AND Accessory/Wakeup	= Good value = Reverse =False =False =True =True =True =Park =False	10,000.00 msec from Park 3,600,000.00 msec from Neutral* 3,600,000.00 msec from Drive* *Internal does not diagnose from N&D	DTC Type B, Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Park Position Switch A/B Correlation	P07BE	Correlation diagnosic compares the two switches behind the Park pushbutton	Compares Park Switch A and Park Switch B "PRESSED" and "RELEASED" states. Park 1 and Park 2 are both:	=Valid, but not equal continuously = valid states (RELEASED or PRESSED), but disagree.	Not Fault Active Diagnostic System Disable Calibration: Park Comparison Diagnostics Enable Calibration:	P07B3, P07B4, P07B5, P07B9, P07BA, P07BB =FALSE = TRUE	2,400 failures out of 3,000 samples 12.5 ms rate	DTC Type B, One Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Unable to Engage Park	P07E4	Detects the inability to achieve or remain in Park.	Actual Arbitrated Transmission Range	≠Park	Actual Transmission Range Commanded Transmission Range AND CodeClearFunction AND ManufacturingModeActive AND: External: Run/Crank OR Accessory/Wakeup Internal: From the time when RunCrankActive until ActualRange AND Accessory/Wakeup	= Good value = Park =False =False =True = True =True =Park =False	6,000.00 msec from Reverse 6,000.00 msec from Neutral 6,000.00 msec from Drive	DTC Type B, Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Unable to Engage Drive	P07E5	Detects the failure to achieve the expected command to Drive range.	Actual Arbitrated Transmission Range	≠Drive	Actual Transmission Range Commanded Transmission Range AND CodeClearFunction AND ManufacturingModeActive AND: External: Run/Crank OR Accessory/Wakeup Internal: From the time when RunCrankActive until ActualRange AND Accessory/Wakeup	= Good value = Drive =False =False =True = True =True =Park =False	10,000.00 msec from Park 10,000.00 msec from Reverse 10,000.00 msec from Neutral	DTC Type B, Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Lever X Position Sensor 1 Circuit Range/ Performance	P082A	Detects Gear Lever X Position Sensor 1 circuit is reading outside "good" values	Gear Lever Position Sensor 1 Measured Duty Cycle on X OR Gear Lever Position Sensor 1 Frequency error detection flag on X OR Gear Lever Position Sensor 1 Measured Duty Cycle on X and Gear Lever Position Sensor 2 Measured Duty Cycle on X differ by more than	Are outside the shifter path of movement 5.5% to meet 100 Nm force on shifter from nominal path OR = True > 12.00 %	Not Fault Active Controller has been awake for at least	P082B, P082C 0.05 seconds	3.00 failures out of 4.00 samples 25ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Lever X Position Sensor 1 Circuit Low	P082B	Detects Gear Lever X Position Sensor 1 circuit reading low	Gear Lever Position Sensor 1 Measured Duty Cycle on X	< 17.00 %	Controller has been awake for at least	0.05 seconds	3.00 failures out of 4.00 samples 25 ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Detects Gear Lever X Position Sensor 1 circuit reading high	P082C	Gear Lever Position Sensor 1 Measured Duty Cycle on X	Gear Lever Position Sensor 1 Measured Duty Cycle on X	> 88.00 %	Controller has been awake for at least	0.05 seconds	3.00 failures out of 4.00 samples 25 ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Lever Y Position Sensor 1 Circuit Performance	P082D	Detects Gear Lever Y Position Sensor 1 circuit is reading outside "good" values	Gear Lever Position Sensor 1 Measured Duty Cycle on Y OR Gear Lever Position Sensor 1 Frequency error detection flag on Y OR Gear Lever Position Sensor 1 Measured Duty Cycle on Y and Gear Lever Position Sensor 2 Measured Duty Cycle on Y differ by more than	Are outside the shifter path of movement 5.5% to meet 100 Nm force on shifter from nominal path = True > 12.00 %	Not Fault Active Controller has been awake for at least	P082E, P082F 0.05 seconds	3.00 failures out of 4.00 samples 25 ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Lever Y Position Sensor 1 Circuit Low	P082E	Detects Gear Lever Y Position Sensor 1 circuit reading low	Gear Lever Position Sensor 1 Measured Duty Cycle on Y	< 17.00 %	Controller has been awake for at least	0.05 seconds	3.00 failures out of 4.00 samples 25 ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Lever Y Position Sensor 1 Circuit High	P082F	Detects Gear Lever Y Position Sensor 1 circuit reading high	Gear Lever Position Sensor 1 Measured Duty Cycle on Y	> 88.00 %	Controller has been awake for at least	0.05 seconds	3.00 failures out of 4.00 samples 25 ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Lever X Position Sensor 2 Circuit Performance	P089B	Detects Gear Lever X Position Sensor 2 circuit is reading outside "good" values	Gear Lever Position Sensor 2 Measured Duty Cycle on X OR Gear Lever Position Sensor 2 Frequency error detection flag on X OR Gear Lever Position Sensor 2 Measured Duty Cycle on X and Gear Lever Position Sensor 1 Measured Duty Cycle on X differ by more than	Are outside the shifter path of movement 5.5% to meet 100 Nm force on shifter from nominal path = True > 12.00 %	Not Fault Active Controller has been awake for at least	P089C, P089D 0.05 seconds	3.00 failures out of 4.00 samples 25 ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Lever X Position Sensor 2 Circuit Low	P089C	Detects Gear Lever X Position Sensor 2 circuit reading low	Gear Lever Position Sensor 2 Measured Duty Cycle on X	< 17.00 %	Controller has been awake for at least	0.05 seconds	3.00 failures out of 4.00 samples 25 ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Lever X Position Sensor 2 Circuit High	P089D	Detects Gear Lever X Position Sensor 2 circuit reading high	Gear Lever Position Sensor 2 Measured Duty Cycle on X	> 88.00 %	Controller has been awake for at least	0.05 seconds	3.00 failures out of 4.00 samples 25 ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Lever Y Position Sensor 2 Circuit Performance	P08A0	Detects Gear Lever Y Position Sensor 2 circuit is reading outside "good" values	Gear Lever Position Sensor 2 Measured Duty Cycle on Y OR Gear Lever Position Sensor 2 Frequency error detection flag on Y OR Gear Lever Position Sensor 1 Measured Duty Cycle on Y and Gear Lever Position Sensor 2 Measured Duty Cycle on Y differ by more than	Are outside the shifter path of movement 5.5% to meet 100 Nm force on shifter from nominal path = True > 12.00 %	Not Fault Active Controller has been awake for at least	P08A1, P08A2 0.05 seconds	3.00 failures out of 4.00 samples 25 ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Lever Y Position Sensor 2 Circuit Low	P08A1	Detects Gear Lever Y Position Sensor 2 circuit reading low	Gear Lever Position Sensor 2 Measured Duty Cycle on Y	< 17.00 %	Controller has been awake for at least	0.05 seconds	3.00 failures out of 4.00 samples 25 ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Gear Lever Y Position Sensor 2 Circuit High	P08A2	Detects Gear Lever Y Position Sensor 2 circuit reading high	Gear Lever Position Sensor 2 Measured Duty Cycle on Y	> 88.00 %	Controller has been awake for at least	0.05 seconds	3.00 failures out of 4.00 samples 25 ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Heater Supply Voltage Sense Circuit Range/ Performance	P103B	The P103B diagnostic determines if the heater supply circuit is rational by comparing the heater supply voltage to the run crank voltage and calculating the difference. The heater supply voltage input is connected to the O2 heater supply circuit inside the vehicle relay center. It is representative of the voltage supplied to the O2 heaters. The O2 heater voltage is used by the HWIO to calculate the O2 heater resistance on switching type O2 sensors (non-WRAF). With a fault set, the resistance calculation is performed with run crank voltage. The diagnostic failure counter is incremented if the voltage difference is greater than the threshold. This DTC is set based on the fail and sample counters.	The absolute value of Heater Supply Voltage delta from Run Crank voltage	> 3.00 volts	Powertrain relay in range (Relay in range is defined as relay voltage Run Crank signal active	= True > 11.00 volts) = True (Please see "**Run/Crank Active conditiions**" in Supporting Tables)	8 failures out of 10 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Heater Supply Voltage Sense Circuit Low	P103C	The P103C diagnostic determines if the heater supply circuit is low by comparing the heater supply voltage to the threshold. The heater supply voltage input is connected to the O2 heater supply circuit inside the vehicle relay center. It is representative of the voltage supplied to the O2 heaters. The O2 heater voltage is used by the HWIO to calculate the O2 heater resistance on switching type O2 sensors (non-WRAF). With a fault set, the resistance calculation is performed with run crank voltage. The diagnostic failure counter is incremented if the heater supply voltage is less than the threshold. This DTC is set based on the fail and sample counters.	Heater Supply Voltage	< 6.00 volts	Powertrain relay in range (Relay in range is defined as relay voltage Run Crank signal active	= True > 11.00 volts) = True (Please see "**Run/Crank Active conditiions**" in Supporting Tables)	8 failures out of 10 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (twin turbo)	P1101	Detects a performance failure in the Manifold Pressure (MAP) sensor, Turbocharger Boost Pressure sensor, Throttle Position sensor (TPS), Mass Air Flow (MAF) sensor or MAF B sensor that cannot be uniquely identified as a failure in one individual sensor. This diagnostic can set when more than one of these sensors has a performance concern. This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from these five sensors. These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a	See table **P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix** for combinations of model failures that can set this DTC. MAF model fails when either MAF1 model fails or MAF2 model fails. MAF1 model fails when ABS(Measured MAF1 Flow – Modeled MAF1 Flow) Filtered MAF2 model fails when ABS(Measured MAF2 Flow – Modeled MAF2 Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered	> 20.0 grams/sec > 20.0 grams/sec > 25.0 kPa > 25.0 kPa > 25.0 kPa > 30.0 kPa	Engine Speed Engine Speed (Coolant Temp OR OBD Coolant Enable Criteria (Coolant Temp OR OBD Max Coolant Achieved Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together) See Residual Weight Factor tables.	>= 400 RPM <= 6,100 RPM >= -9 Deg C = TRUE) <= 150 Deg C = FALSE) >= -20 Deg C <= 125 Deg C >= 0.50 Modeled MAF1 Error multiplied by **P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM** and **P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est** Modeled MAF2 Error multiplied by **P0101, P0106, P010B, P0121, P0236, P1101: MAF2 Residual Weight Factor based on MAF Est**	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		performance issue with the system, but no single failed sensor can uniquely be identified. In this case, the Inlet Airflow System Performance diagnostic will fail.	TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset** OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset** TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time High Engine Air Flow is	> 300 kPa*(g/s) > 30.0 kPa > 30.0 kPa > 1.5 seconds > 1.5 seconds	No Active DTCs:	and **P0101, P0106, P010B, P0121, P0236, P1101: MAF2 Residual Weight Factor based on RPM** MAP Model 1 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM** MAP Model 2 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP Model 3 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM** TIAP Model 1 Error multiplied by **P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM** Filtered Throttle Model Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM** MAP_SensorCircuitFA		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			TRUE when Mass Air Flow AND Manifold Pressure AND Filtered Mass Air Flow - Mass Air Flow Low Engine Air Flow is TRUE when Mass Air Flow AND Manifold Pressure -	 > a threshold in gm sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow** > a threshold in kPa as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP** < 2.0 gm/sec < a threshold in gm sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow** < a threshold in kPa as a function of engine speed See table	 No Pending DTCs:	EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AND Mass Air Flow - Filtered Mass Air Flow	**P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP** < 2.0 gm/sec				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature Sensor Not Plausible	P111E	This DTC detects either a biased high or low ECT (Engine Coolant temperature) sensor. This is done by comparing the ECT sensor output to two other temperature sensor outputs after a soak condition.	**Sensor usage definitions:** **Sensor1 =** CeECTR_e_ECT_Snsr (Sensor1 is the temp sensor most impacted by the block heater (if equipped)) **Sensor2 =** CeECTR_e_IAT_Snsr **Sensor3 =** CeECTR_e_OAT_Snsr ========== A failure will be reported if any of the following occur: 1) Sensor1 power up absolute temp difference to Sensor2 and Sensor3 is (Sensor1 fast fail) . 2) Sensor1 power up temp is greater than Sensor2 and Sensor3 in this range: (and a block heater has not been detected) 3) Sensor1 power up temp is lower than Sensor2 and Sensor3 by this amount: 4) Sensor1 power up temp is ≥ Sensor2 and	 ≥ 50.0 ºC ≥ 15.0 and < 50.0 ºC ≤ 15.0 Deg ºC	No Active DTC's Engine Off Soak Time Propulsion Off Soak Time Non-volatile memory initization Test complete this trip Test aborted this trip Test disabled this trip Ambient LowFuelCondition Diag ========== Block Heater detection is **enabled** when either of the following occurs: 1) Sensor1 power up temp is greater than Sensor2 and Sensor3 in this range: 2) Cranking time ==========	VehicleSpeedSensor_FA IAT_SensorCircuitFA THMR_RCT_Sensor_Ckt_FA ECT_Sensor_Ckt_FA EngineModeNotRunTimerError EngineModeNotRunTimer_FA OAT_PtEstFiltFA OAT_PtEstRawFA PSAR_PropSysInactveCrs_FA DRER_DiagSystemDsbl > 28,800 seconds > 0 seconds = Not occurred = False = False = False ≥ -9 ºC = False ========== ≥ 15.0 ºC and < 50.0 ºC < 10.0 Seconds ==========	1 failure to set DTC 1 sec/ sample Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Sensor3 by 15.0 ºC and the time spent cranking the engine without starting is ≥ 10.0 seconds with the LowFuelConditionDiag	= False	Block Heater is **detected** and diagnostic is aborted when 1) or 2) occurs. 1a) IAT monitoring is enabled after the following Vehicle drive constraints 1b) Drive time 1c) Vehicle speed 1d) Additional Vehicle drive time is provided to 1b when Vehicle speed is below 1c as follows: 1e) IAT drops from power up IAT 2a) ECT monitoring is enabled after engine start in the following engine run time window 2b) Sensor1 temp derivative during the test is: 2c) Consectutive samples of 2b) being true are: ========== Diagnostic is **aborted** when 3) or 4) occurs: 3) Engine run time with vehicle speed below 1b 4) Engine off time (i.e. auto stop) during Block heater detection	 > 400 Seconds with > 14.9 MPH and 0.50 times the seconds with vehicle speed below 1b ≥ 8.0 ºC 5.0 <= seconds <= 15.0 < -0.10 ºC/sec ≥ 4 samples ========== ≥ 1,800 Seconds ≥ 180.0 Seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT SIDI High Pressure Rail Temperature Sensor Performance	P111F	This DTC Diagnoses Fuel Temperature sensors rationality by comparing Primary sensor (T1) vs. Secondary sensor (T2)	Fuel Temperature Error (Absolute delta between sensor1 and sensor2)	> 20.00 degC	Fuel Temperature Rationality Diagnostic Enabled No Fault Active on No Fault Pending on	True Enabled when a code clear is not active or not exiting device control Temperature sensors 1 out of range Low or High Fault Active (P0182, P0182) Temperature sensors 2 out of range Low or High (P0187, P0188) SENT Communication Fault Active (P16E4, P16E5) SENT Intenal Error Fault Active (P126E, P126F) Fuel Temperature Sensor SENT Message Error Fault Active (P128C, P128D) SENT Communication Fault Pending (P16E4, P16E5) Fuel Temperature Sensor SENT Message Error Fault Pending (P128C, P128D)	100.00 failures out of 125.00 samples 100 ms per Sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Set/ Coast Signal 2 Circuit	P155B	Detects a failure of the cruise set 2 switch in a continously applied state	Cruise Control Set 2 switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 89.000 seconds	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 89.000 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Resume/ Acceleration Signal 2 Circuit	P155C	Detects a failure of the cruise resume 2 switch in a continously applied state	Cruise Control Resume 2 switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 89.000 seconds	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 89.000 seconds	MIL: Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Lane Center Switch Circuit	P1589	Detects failure for cruise lane centering control circuit	Lane Center Control switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 20.00 seconds	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Lane Center Signal Message Counter Incorrect	P158B	Detects rolling count error or protection value error in the frame $2CB.	Rolling count error or protection in frame $2CB (for Lane Center Control) exists for greater than a calibration samples.	Error exists continuously for greater than 8.00 counts.	CAN communication diagnostic in ECM has been enabled, ie. ECM reset process has been complete or diag end of trip tasks have been completed.		been enabled for 3,000.00 ms.	Type C, No SVS "Emissions Neutral Diagnostics – Special Type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Auto Start Stop Select Switch Signal Circuit For start stop conventional hybrid applications	P15A3	BCM to ECM Rolling Count check for CAN frame $1E1. -- Only utilize when calibration variable KeINFG_e_HybridType equals CeINFR_e_StartStopConv.	Rolling count value received from BCM does not match expected value	= TRUE	Engine Speed Engine Speed Engine speed between min/max for Vehicle Speed for Hybrid type	≥ 200 RPM ≤ 7,500 RPM ≥ 5.0 seconds ≤ 318.14 MPH ≥ 5.0 seconds =CeINFR_e_StartStopConv	> 3 error counts for > 10.0 seconds 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Boost Imbalance	P16E7	The DTC indicates that the provided boost pressure of the two parallel turbos can only be balanced with completely different waste gate solenoid duty cycles leading to very different waste gate positions.	Absolut value of (VeBSTR_Pct_TwinBalance = WastegateControl A - WastegateControl B)	> 15.00 %	Diagnostic enabled ********** Engine speed ********** No DTCs active: ********** No boost pressure control failsoft mode active: (VeBSTR_e_FsftAction) ********** Boost pressure closed loop control is active.	True ********** <= 6,800 rpm ********** MAF_SensorFA ********** = CeBSTR_e_NoFsftAction **********	18 Failed tests out of 25 tests 100ms/ sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 1	P16F0	This DTC detects intermitent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor before receiving a valid message.		Run/Crank voltage	> 6.41 Volts	39 / 399 counts continuous; 12.5 ms /count in the ECM main processor	Type A, 1 Trips
			This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor after receiving a valid message.		Run/Crank voltage	> 6.41 Volts	159 / 399 counts continuous; 12.5 ms /count in the ECM main processor	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Transmission Range Control Performance	P16F4	Determines if the Electronic Transmission Range Select control module software incorrectly processes a range request which would result in an unsafe condition	Driver Requested Arbitrated Range Commanded OR: Transmission range control routine Transmission range control routine Transmission range control routine	is issued unexpectedly OR ≠ expected range Does not issue Park or Neutral command quickly enough in response to driver request Issues a request to Drive, Low or Manual without a matching input by the customer within a calibrated time T1. Issues a request to Reverse without a matching input by the customer within a calibrated time limit T2.	TRCR Global Diagnostic Enable CodeClearFunction AND ManufacturingModeActive AND: External: Run/Crank OR Accessory/Wakeup Internal: From the time when RunCrankActive until ActualRange AND Accessory/Wakeup	= True =False =False =True = True =True =Park =False	200 , 200 , 200 , 2,050 , 200 or 200 msec, depending on conditions. T1 = 200 msec T2 = 200 msec	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powerflow Engaged Signal Message Incorrect	P1772	Detects error on ARC & PV reported by CHCM/ ECM about signal $197 from TCM on HS GMLAN	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress for:	within proper operating range for at least 3,000 msec for a time > 3,000 msec	8 failures out of 10 samples 12.5 ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IMS State Signal Message Incorrect	P1773	Detects error on ARC & PV reported by CHCM/ ECM about signal $197 from TCM on HS GMLAN	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress for:	within proper operating range for > 3,000 msec for a time > 3,000 msec	8 failures out of 10 samples 12.5 ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Availability Signal Message Incorrect	P1778	Detects error on ARC & PV reported by CHCM / ECM about signal $3F5 from TCM on HS GMLAN	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress:	within proper operating range for 3,000 msec for a time > 3,000 msec	8 failures out of 10 samples Signal in the 250 ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Unexpected Range Change Detected	P1787	Detects an unexpected change in transmission range.	Actual Arbitrated Transmission Range The internal system only diagnoses range changes in and out of Park.	≠ Previous Value	Actual Tranmission Range Range Change Achievement Diag	= Good value = Not running	1,500 ms	DTC Type B, Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Current Transmission Range Unknown	P1789	Detects the failure of the ETRS system to identify the current transmission range with sufficient confidence.	Actual Transmission Range	= Undefined	Range Indication Source AND CodeClearFunction AND ManufacturingModeActive AND: External: Run/Crank OR Accessory/Wakeup Internal: From the time when RunCrankActive until ActualRange AND Accessory/Wakeup	= Valid =False =False =True = True =True =Park =False	80 failures out of 100 samples 12.5 ms loop	DTC Type B, Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Park Position Switch A/B Circuit Stuck On	P17F3	Checks if both switches have been pressed for a long time	Park Position is PRESSED	≥ 60.00 seconds	Not Fault Active Controller is "on"	P07B3, P07B4, P07B4, P07B9, P07BA, P07BB >~ 100 ms	1.00 failures out of 1.00 samples	DTC Type B Two trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Signal Message Counter Incorrect	P188B	This DTC monitors for an error in communication with the Transmission Range Signal	Communication of the Alive Rolling Count or Protection Value of the Transmission Range Signal Signal over CAN bus is incorrect for out of total samples	 >= 8.00 counts >= 10.00 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is avaialble >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 250ms loop.	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Park Position Switch A/B Circuit Stuck Off	P189D	Compares Park Switch A and Park Switch B "PRESSED" and "RELEASED" states	When either is “PRESSED” for 100 ms then pressed event is entered. Fault is incremented if other switch	 Is not pressed during event.	Not Fault Active Controller is on Park button switches Vehicle Speed	P07B3, P07B4, P07B5, P07B9, P07BA, P07BB >~100 ms =valid <= Park Request Spd	7 synchronized failures in a row. *note: these samples can accumulate over key-cycles	DTC Type B, Two trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O1: Transmission Range Selector Primary Signal Message Counter Incorrect	P189E	Monitor $1EC CAN frame from SIB LS and set a DTC: P189E that indicates an ARC or ChkSum error from the $1EC CAN frame persists long enough to satisfy fail criteria. Linear shifter.	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value Compares Park Switch A and Park Switch B "PRESSED" and "RELEASED" states.	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress for:	within proper operating range for 3,000 msec for a time 3,000 msec	sampled in the 12.5 ms loop 8 failures out of 10 samples	DTC Type B, Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O1: Transmission Range Selector Secondary Signal Message Counter Incorrect	P189F	Monitor $2EC CAN frame from SIB LS and set a DTC: P189F that indicates an ARC or ChkSum error from the $2EC CAN frame persists long enough to satisfy fail criteria. Linear shifter.	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value Compares Park Switch A and Park Switch B "PRESSED" and "RELEASED" states.	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress for:	within proper operating range for 3,000 msec for a time 3,000 msec	sampled in the 12.5 ms loop 8 failures out of 10 samples	DTC Type B, Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Performance (twin turbo)	P2227	Detects a performance failure in the Barometric Pressure (BARO) sensor, such as when a BARO value is stuck in range. If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The BARO sensor value is checked to see if it is within the normal expected atmospheric pressure range. If it is not, then the BARO performance diagnostic will fail. If the BARO sensor value is within the normal expected atmospheric range, then Manifold Pressure (MAP), Turbocharger Boost Pressure, BARO and BARO B are compared to see if their values are similar. If the MAP, Turbocharger Boost Pressure and BARO B sensor values are similar, but the BARO value is not similar, then a BARO performance diagnostic will fail.	**Engine Running:** Difference between Baro Pressure reading and Estimated Baro when distance since last Estimated Baro update OR Difference between Baro Pressure reading and Estimated Baro when distance since last Estimated Baro update	 > 20.0 kPa <= 1.24 miles > 25.0 kPa > 1.24 miles	No Active DTCs:	AmbPresSnsrCktFA IAT_SensorFA MAF_Snsr1_FA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA TC_BoostPresSnsrFA	320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips
			Engine Not Rotating: Barometric Pressure OR Barometric Pressure OR ABS(Manifold Pressure - Turbocharger Boost Pressure) AND ABS(Manifold Pressure - Baro Pressure) AND ABS(Manifold Pressure - Baro Pressure B) AND ABS(Turbocharger Boost Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure B) AND ABS(Baro Pressure -	 < 50.0 kPa > 115.0 kPa <= 10.0 kPa > 10.0 kPa <= 10.0 kPa > 10.0 kPa <= 10.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating No Active DTCs: No Pending DTCs:	 > 10.0 seconds EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA AAP2_SnsrCktFA AAP3_SnsrCktFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP AAP3_SnsrCktFP	4 failures out of 5 samples 1 sample every 12.5 msec	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		When the engine is running, there is an estimate of barometric pressure that is determined with the Turbocharger Boost Pressure sensor, engine air flow and engine speed. If the BARO value from the sensor is not similar to this barometric pressure estimate, then the BARO performance diagnostic will fail.	Baro Pressure B)	> 10.0 kPa				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor B Circuit Range/ Performance	P222B	Detects a performance failure in the Barometric Pressure (BARO) B sensor, such as when a BARO B value is stuck in range. If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The BARO B sensor value is checked to see if it is within the normal expected atmospheric pressure range. If it is not, then the BARO B performance diagnostic will fail. If the BARO B sensor value is within the normal expected atmospheric range, then Manifold Pressure (MAP), Turbocharger Boost Pressure, BARO and BARO B are compared to see if their values are similar. If the MAP, Turbocharger Boost Pressure and BARO sensor values are similar, but the BARO B value is not similar, then a BARO B performance diagnostic will fail.	**Engine Running:** Difference between Baro Pressure B reading and Estimated Baro when distance since last Estimated Baro update OR Difference between Baro Pressure B reading and Estimated Baro when distance since last Estimated Baro update	 > 20.0 kPa <= 1.24 miles > 25.0 kPa > 1.24 miles	No Active DTCs:	AmbPresSnsr2_CktFA IAT_SensorFA MAF_Snsr2_FA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA TC_BoostPresSnsrFA	320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips
			Engine Not Rotating: Barometric Pressure B OR Barometric Pressure B OR ABS(Manifold Pressure - Turbocharger Boost Pressure) AND ABS(Manifold Pressure - Baro Pressure) AND ABS(Manifold Pressure - Baro Pressure B) AND ABS(Turbocharger Boost Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure B) AND ABS(Baro Pressure -	< 50.0 kPa > 115.0 kPa <= 10.0 kPa <= 10.0 kPa > 10.0 kPa <= 10.0 kPa > 10.0 kPa > 10.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating No Active DTCs: No Pending DTCs:	 > 10.0 seconds EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA AAP2_SnsrCktFA AAP3_SnsrCktFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP AAP3_SnsrCktFP	4 failures out of 5 samples 1 sample every 12.5 msec	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		When the engine is running, there is an estimate of barometric pressure that is determined with the Turbocharger Boost Pressure sensor, engine air flow and engine speed. If the BARO B value from the sensor is not similar to this barometric pressure estimate, then the BARO B performance diagnostic will fail.	Baro Pressure B)					

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor B Circuit Low (Gen III)	P222C	Detects a continuous short to ground in the Barometric Pressure (BARO) B signal circuit by monitoring the BARO B sensor output voltage and failing the diagnostic when the BARO B voltage is too low. The BARO B sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	BARO B Voltage	< 40.0 % of 5 Volt Range (This is equal to 50.9 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor B Circuit High (Gen III)	P222D	Detects a continuous short to power or open circuit in the Barometric Pressure (BARO) B signal circuit by monitoring the BARO B sensor output voltage and failing the diagnostic when the BARO B voltage is too high. The BARO B sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	BARO B Voltage	> 90.0 % of 5 Volt Range (This is equal to 115.0 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor B Circuit Intermittent/ Erratic	P222E	Detects a noisy or erratic signal in the barometric pressure (BARO) B circuit by monitoring the BARO B sensor and failing the diagnostic when the BARO B signal has a noisier output than is expected. When the value of BARO B in kilopascals (kPa) is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of BARO B readings. The result of this summation is called a “string length”. Since the BARO B signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic BARO B signal. The diagnostic will fail if the string length is too high.	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current BARO B reading - BARO B reading from 12.5 milliseconds previous)	> 100 kPa 80 consecutive BARO B readings			4 failures out of 5 samples Each sample takes 1.0 seconds	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Pumping Current Performance Bank 1 (For use with WRAF - E81	P223C	This DTC determines if the WRAF O2 sensor pumping current has an incorrect or out of range value. This DTC will detect open circuit faults to the Pump current, Ref Cell voltage, Ref Ground circuits. When enabled, the diagnostic monitors the pumping current in three different fault regions during DFCO. The individual diagnostic failure counters are incremented based on the diagnostic results in each region. The DTC is set based on any of the three individual fail and sample counters.	Fault condition present when the pump current is in any of the fault regions when this test is enabled during DFCO. Note: This ASIC is referred to as ATIC142 (Continental).	The three pump current fault regions are: A) Pump current > 5.00 ma B) Pump current ≤ 0.30 ma and ≥ - 0.30 ma C) Pump current < -0.10 ma The three fault regions have individual X out of Y calibrations. When the X out of Y is reached in any region this DTC is set.	DTC's Not active this key cycle Measure Valid status (ASIC) Controller status (ASIC) Engine Run or Auto stop WRAF Ref cell temperature ********** Heater Warm-up delay Then WRAF circuit diagnostic delay (since heater Warm-up delay is complete) ********** Test starts when time in DFCO Test stops when time in DFCO	WRAF_Bank_1_FA P0135, P0030, P0031, P0032 = Valid = Ready = True ≥ 628 Deg C = Complete ≥ 20.0 seconds ≥ 5.0 seconds > 12.0 seconds	Region A: 40 failures out of 160 samples OR Region B: 40 failures out of 160 samples OR Region C: 40 failures out of 160 samples Sample rate is 25 msec. Test enabled during DFCO.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Pumping Current Performance Bank 2 (For use with WRAF - E81	P223D	This DTC determines if the WRAF O2 sensor pumping current has an incorrect or out of range value. This DTC will detect open circuit faults to the Pump current, Ref Cell voltage, Ref Ground circuits. When enabled, the diagnostic monitors the pumping current in three different fault regions during DFCO. The individual diagnostic failure counters are incremented based on the diagnostic results in each region. The DTC is set based on any of the three individual fail and sample counters.	Fault condition present when the pump current is in any of the fault regions when this test is enabled during DFCO. Note: This ASIC is referred to as ATIC142 (Continental).	The three pump current fault regions are: A) Pump current > 5.00 ma B) Pump current ≤ 0.30 ma and ≥ - 0.30 ma C) Pump current < -0.10 ma The three fault regions have individual X out of Y calibrations. When the X out of Y is reached in any region this DTC is set.	DTC's Not active this key cycle Measure Valid status (ASIC) Controller status (ASIC) Engine Run or Auto stop WRAF Ref cell temperature ********** Heater Warm-up delay Then WRAF circuit diagnostic delay (since heater Warm-up delay is complete) ********** Test starts when time in DFCO Test stops when time in DFCO	WRAF_Bank_2_FA P0155, P0050, P0051, P0052 = Valid = Ready = True ≥ 628 Deg C = Complete ≥ 20.0 seconds ≥ 5.0 seconds > 12.0 seconds	Region A: 40 failures out of 160 samples OR Region B: 40 failures out of 160 samples OR Region C: 40 failures out of 160 samples Sample rate is 25 msec. Test enabled during DFCO.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Reference Resistance Out Of Range Bank 1	P223E	This DTC determines if the WRAF O2 sensor reference cell has an incorrect or out of range resistance value. This test compares the element's resistance (from the WRAF sensor Application-Specific Integrated Circuit (ASIC)) to the expected values for the enabled condition. The element temperature is directly related to the element resistance based on the released sensor element specifications. The diagnostic failure counter is incremented if the element temperature is outside the expected range. This DTC is set based on the fail and sample counters.	Measured Reference cell temperature	< 700 Deg C OR > 1,000.0 Deg C	DTC's Not active this key cycle Measure Valid status (ASIC) Controller status (ASIC) Engine Run or Auto stop ********** Heater Warm-up delay Then Delay after WRAF circuit diagnostic delay **********	WRAF_Bank_1_FA P0135, P0030, P0031, P0032 = Valid = Ready = True = Complete ≥ 20.0 seconds	64 failures out of 80 samples Sample rate is 25 msec Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Reference Resistance Out Of Range Bank 2	P223F	This DTC determines if the WRAF O2 sensor reference cell has an incorrect or out of range resistance value. This test compares the element's resistance (from the WRAF sensor Application-Specific Integrated Circuit (ASIC)) to the expected values for the enabled condition. The element temperature is directly related to the element resistance based on the released sensor element specifications. The diagnostic failure counter is incremented if the element temperature is outside the expected range. This DTC is set based on the fail and sample counters.	Measured Reference cell temperature	< 700 Deg C OR > 1,000.0 Deg C	DTC's Not active this key cycle Measure Valid status (ASIC) Controller status (ASIC) Engine Run or Auto stop ********** Heater Warm-up delay Then Delay after WRAF circuit diagnostic delay **********	WRAF_Bank_2_FA P0155, P0050, P0051 or P0052 = Valid = Ready = True = Complete ≥ 20.0 seconds	64 failures out of 80 samples Sample rate is 25 msec Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Pumping Current Trim Circuit/Open Bank 1 Sensor 1 (For use with WRAF - E81	P2626	This DTC determines if the WRAF O2S trim circuit is open. The trim circuit fine tunes the WRAF O2S pump current signal. The diagnostic is an Application-Specific Integrated Circuit (ASIC) intrusive test which runs when the Run/Crank signal changes from False to True. The diagnostic failure counter is incremented if the ASIC test fails and the enable conditions are met. This DTC is set based on the fail and sample counters.	B1S1 Trim circuit Open test. This application uses the following type of WRAF sensor: The ASIC Open trim test detects a fault if the trim circuit resistance is: For NGK_ZFAS_U2 For Bosch_LSU_4p9 Note: This ASIC is referred to as ATIC142 (Continental).	 CeWRSG_e_NGK_ZFAS_U2 > 4,644 ohms > 379.5 ohms	DTC's Not active this key cycle Run/Crank Signal WRAF Ref cell temperature WRAF circuit diagnostic delay (since heater Warm-up delay is complete) Fuel Control State Off Stoich Closed Loop DFCO WRAF Pump current	WRAF_Bank_1_FA P0135, P0030, P0031, P0032 changes from false to true ≥ 628 Deg C ≥ 20.0 seconds = Closed Loop = Not active = Not active ≤ 1.0 ma	128 fail counts out of 160 samples 25 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Pumping Current Trim Circuit/Open Bank 2 Sensor 1 (For use with WRAF - E81	P2629	This DTC determines if the WRAF O2S trim circuit is open. The trim circuit fine tunes the WRAF O2S pump current signal. The diagnostic is an Application-Specific Integrated Circuit (ASIC) intrusive test which runs when the Run/Crank signal changes from False to True. The diagnostic failure counter is incremented if the ASIC test fails and the enable conditions are met. This DTC is set based on the fail and sample counters.	B2S1 Trim circuit Open test. This application uses the following type of WRAF sensor: The ASIC Open trim test detects a fault if the trim circuit resistance is: For NGK_ZFAS_U2 For Bosch_LSU_4p9 Note: This ASIC is referred to as ATIC142 (Continental).	 CeWRSG_e_NGK_ZFAS_U2 > 4,644 ohms > 379.5 ohms	DTC's Not active this key cycle Run/Crank Signal WRAF Ref cell temperature WRAF circuit diagnostic delay (since heater Warm-up delay is complete) Fuel Control State Off Stoich Closed Loop DFCO WRAF Pump current	WRAF_Bank_2_FA P0155, P0050, P0051, P0052 changes from false to true ≥ 628 Deg C ≥ 20.0 seconds = Closed Loop = Not active = Not active ≤ 1.0 ma	128 fail counts out of 160 samples 25 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Shared High Side Drive #2 Control Circuit Low (STG) - (GEN III Controllers ONLY)	P2670	Controller specific output driver circuit diagnoses the shared high sided driver # 2 for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	- Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. - Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between output and controller ground	Shared high side drive #2 low diag enable Powertrain relay voltage Run Crank voltage Powertrain relay state	= 1.00 >= 11.00 > 5.00 = ON	20 failures out of 25 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Shared High Side Drive #2 Control Circuit High (STP) - (GEN III Controllers ONLY)	P2671	Controller specific output driver circuit diagnoses the shared high sided driver # 2 for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	- Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. - Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between output and controller power	Shared high side drive #2 diag enable Powertrain relay voltage Run Crank voltage Powertrain relay state	= 1.00 >= 11.00 > 5.00 = ON	20 failures out of 25 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Invalid Data Received From Body Control Module	U0422	Signal between the BCM and door switches is unreliable	Driver Door Ajar Switch Virtual Device Availability OR Driver Door Open Switch Virtual Device Availability	= INVALID = INVALID	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress for	within proper operating range for 3,000 msec. for a time 3,000 msec.	12.5 ms loop 8 failures out of 10 samples.	Special Type C No MIL

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication with Transmission Control Module on Engine Control Module LIN Bus 1	U135E	Detects that LIN serial data communication has been lost with the LIN Bus	TCM to ECM: Message $01 Bus Status	= Undetected	Controller On Ignition	> 3,000 ms = Run/Crank OR = Accessory	1.0 second	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication with Transmission Range Selector Control Module on Powertrain Sensor CAN Bus	U18D2	Detects that CAN serial data communication has been lost with the TRS PT Sensor Bus	TRS Buttons Message: $2F3, $4C4, $1E4, TRS Linear Shifter Messages: $2F3, $4C4, $1EC	=Undetected	Controller On Ignition	> 3,000 ms = Run/Crank OR = Accessory	1.0 second	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication with Transmission Range Selector Control Module on Powertrain Expansion CAN Bus	U18D3	Detects that CAN serial data communication has been lost with the SIB PT Exp Bus	TRS Buttons Message: $2C2 TRS Linear Shifter Message: $2EC	=Undetected	Controller On Ignition	> 3,000 ms = Run/Crank OR = Accessory	1.0 second	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Invalid Data Received From Transmission Control Module on Chassis Control Module LIN Bus 2	U250D	Detects if Range Command Echo from TCM matches current Range Command (For Internal ETRS only)	Check Range Command Echo vs Range Command when Range Command Poke is called	Range Command Echo ≠ Range Command	Diagnostic Enable Calibration Recent Range Command Transition TCM LIN Node or Bus Fault Active	= TRUE = FALSE = FALSE	80 failures out of 100 samples 50 ms loop	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature Below Stat Regulating Temperature	P0128	This DTC detects if the ECT (EngineCoolant temperature) does not achieve the required target temperature after an allowed energy accumulation by the engine. This can be caused by an ECT sensor biased low or a cooling system that is not warming up correctly because of a stuck open thermostat or other fault.	Energy is accumulated after the first conbustion event using Range #1 or #2 below: Thermostat type is divided into normal (non-heated) and electrically heated. For this application the "type" cal (KeTHMG_b_TMS_ElecThstEquipped) = 0 If the type cal is equal to one, the application has an electrically heated t-stat, if equal to zero the the application has an non heated t-stat. See appropiate section below. ********** Type cal above = 1 (Electrically heated t-stat) == == == == Range #1 (Primary) ECT reaches Commanded temperature minus 11 °C when Ambient min is ≤ 52 °C and > 10 °C. Note: Warm up target for range #1 will be at least 80 °C == == == == Range #2 (Alternate) ECT reaches Commanded temperature minus 31 °C when Ambient min is ≤ 10 °C and > -9 °C. Note: Warm up target for range #2 will be at least	See the two tables named: **P0128_Maximum Accumulated Energy for Start-up ECT conditions - Primary** and **P0128_Maximum Accumulated Energy for Start-up ECT conditions - Alternate** in the Supporting tables section. This diagnostic models the net energy into and out of the cooling	No Active DTC's Engine not run time (soaking time before current trip) Engine run time Fuel Condition Distance traveled ********** If Engine RPM is continuously greater than for this time period The diagnostic test for this key cycle will abort ********** ********** If T-Stat Heater commanded duty cycle for this time period	ECT_Sensor_Ckt_FA ECT_Sensor_Perf_FA VehicleSpeedSensor_FA OAT_PtEstFiltFA IAT_SensorCircuitFA MAF_SensorFA THMR_AWP_AuxPumpFA THMR_AHV_FA THMR_SWP_Control_FA THMR_SWP_NoFlow_FA THMR_SWP_FlowStuckOn_FA EngineTorqueEstInaccurate ≥ 1,800 seconds 30 ≤ Eng Run Tme ≤ 1,450 seconds Ethanol ≤ 87 % ≥ 1.49 miles ********** 9,999 rpm 5.0 seconds ********** ********** > 20.0 % duty cycle > 5.0 seconds	1 failure to set DTC 1 sec/ sample Once per ignition key cycle	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			55 °C ********** Type cal above = 0 (non - heated t-stat) == == == == Range #1 (Primary) ECT reaches 80 °C when Ambient min is ≤ 52 °C and > 10 °C. == == == == Range #2 (Alternate) ECT reaches 55 °C when Ambient min is ≤ 10 °C and > -9 °C. **********	system during the warm-up process. The five energy terms are: heat from combustion (with AFM correction), heat from after-run, heat loss to enviroment, heat loss to cabin and heat loss to DFCO.	The diagnostic test for this key cycle will abort ********** ECT at start run	********** -60 ≤ ECT ≤ 75 °C		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Secondary Circuit Low [FTZM Brushed Motor Fuel Pump applications only]	P0231	This DTC detects if the fuel pump control circuit is shorted to low. Per "smart device" design guidelines, Fuel Pump Power Driver device reports a Faulted state enumeration if current >= 18A [25A for high performance variants. FPDCM reports Not Faulted enumeration if current < 18A FPDCM reports Indeterminate state enumeration if the circuit is not being evaluated during current decision loop due to other conditions.	Power driver output current (Fuel Pump Power Module Driver Circuit Ground Short enumeration)	Current >= 18.0 A	a) Chassis Fuel Pres Sys Type configuration selection [FCBR] b) Arbitrated Fuel Pump Duty Cycle (%) c) Diagnostic Enabled d) Control serial data available [$3EC] e) Sensor Bus Relay On state f] FPDCM Driver Status Alive Rolling Count Sample Faulted g) Fuel Pump Control Enable time [FABR GshtCktDiagInvFail]	a) == FCBR Gas ECM FTZM BDC Sys b1) > 10.00 % AND b2) < 100.00 % c) == TRUE d) == TRUE e) == TRUE f] <> True g) >= 31,536,000.00 seconds	7 failures / 14 samples 1 sample/12.5 millisec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Secondary Circuit High [FTZM Brushed Motor Fuel Pump applications only]	P0232	This DTC detects if the fuel pump control circuit is shorted to high voltage by measuring voltage offset relative to low state level of duty cycle pulse. Per "smart device" design guidelines, Fuel Pump Power device reports a Faulted state enumeration if circuit voltage >= 4V. FPPM reports Not Faulted enumeration if circuit voltage < 4V. FPPM reports Indeterminate state enumeration if the circuit is not being evaluated during current decision loop due to other conditions.	Voltage offset relative to low state level of duty cycle pulse measured at fuel pump circuit	> 4.0 V	a) Chassis Fuel Pres Sys Type configuration selection [FCBR] b) Arbitrated Fuel Pump Duty Cycle (%) c) Diagnostic Enabled d) Diagnostic serial data available [$3EC] e) Sensor Bus Relay On f] FPPM Driver Status Alive Rolling Count Sample Faulted	a) == FCBR Gas ECM FTZM BDC Sys b1) > 5.00 % AND b2) < 95.00 % c) == TRUE d) == TRUE e) == TRUE f] <> True	40 failures / 80 samples 1 sample / 12.5 millisec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Secondary Circuit Open [FTZM Brushed Motor Fuel Pump applications only]	P023F	This DTC detects if the fuel pump control circuit is open Per "smart device" design guidelines, Fuel Pump Power device reports a Faulted state enumeration if current <= 1A . FPPM reports Not Faulted enumeration if current > 1A. FPPM reports Indeterminate state enumeration if the circuit is not being evaluated during current decision loop due to other conditions.	Output driver current [Fuel Pump Power Driver Circuit Open enumeration]	Current <= 1.0 A	a) Chassis Fuel Pres Sys Type configuration selection [FCBR] b) Diagnostic Enabled c) Arbitrated Fuel Pump Duty Cycle (%) d] FPDCM Driver Status Alive Rolling Count Sample Faulted	a) == FCBR Gas ECM FTZM BDC Sys b) == TRUE c1) > 20.00 % AND c2) < 100.00 % d] <> TRUE	40 failures / 80 samples; 1 sample/12.5ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Performance (For use on vehicles with dual fuel tanks and mechanical transfer pump)	P0461	This DTC will detect a primary fuel tank level sensor stuck in-range.	1) ********** Fuel Level in Primary and Secondary Tanks Remain in an Unreadable Range too Long ********** 1a) If Deadband diagnostic subtest enabled 1b) If fuel volume in primary tank is 1c) and if fuel volume in secondary tank is 1d) and if 1b and 1c indications do not change while fuel volume consumed by engine is OR 2) ********** After Refuel Event ********** 2a) If primary tank volume change from Engine Off to next Engine On condition is 2b)then secondary tank volume change must be OR 3) ********** Fuel consumed without a Primary Fuel Level Change ********** 3a) If indicated fuel	 1a) == Enabled status 1b) ≥ 27.5 liters 1c) < 5.0 liters 1d) >= 16.2 liters 2a) >= 35.50 liters 2b) >= 3.00 liters	1a) Diagnostic Enabled 1b) Engine Operational State 2) Primary tank indicated volume @ shutdown plus 3.0 liters	1a) == True 1b) == Running 2) < 27.5 liters	250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			volume change is 3b) while fuel consumed by the engine is	< 3 liters >= 14.8 liters				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Assist Vacuum Too Low	P050F	Monitors for a brake booster vacuum leak	Brake booster vacuum drift ratio (EWMA) reaches the fail threshold (based on engine running condition) before the sample count threshold is reached, a failure is reported. Engine Running Fail Threshold based on prior diagnostic state (description below) Diagnostic failed prior loop Diagnostic passed prior loop Before the sample counts Engine Stopped Fail Threshold based on prior diagnostic state (description below) Diagnostic failed prior loop Diagnostic passed prior loop Before the sample counts	 >= 0.60 >= 0.65 > 0.00 counts >= 0.55 >= 0.65 > 0.00 counts	Diagnostic is enabled and the following conditions are met for engine run conditions: No brake booster vacuum sensor faults active No brake pedal position sensor faults active Brake pedal travel is No mass air flow faults No manifold air pressure faults Mass air flow estimate Manifold air pressure Engine vacuum stability time has reached Difference between brake booster vacuum and manifold air pressure is OR Diagnostic is enabled for the following engine auto off conditions:	Enabled < 8.00 percent - 5.00 percent offset >= 6.00 grams / second <= 20.00 kPa >= 0.70 seconds > 10.00 kPa Enabled	Performed every 100 msecond Minimum time to pass: Engine Running 0.00 second Engine Stopped 0.00 second	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No brake booster vacuum sensor faults active No brake pedal position sensor faults active Brake pedal travel is No engine movement detected Engine is in AutoStop mode OR Diagnostic is enabled for the following key off conditions: No brake booster vacuum sensor faults active No brake pedal position sensor faults active Brake pedal travel is No engine movement detected Engine is in KeyStop mode	< 8.00 percent - 5.00 percent offset Disabled < 8.00 percent - 5.00 percent offset		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Signal Message Counter Incorrect	P1100	This DTC monitors for an error in communication with the Fuel Pump Control Module (FTZM) Fuel Level Sensor 2 Signal Message Counter	Communication of the Fuel Level Sensor 2 Signal Message Counter from the Fuel Pump Control Module (FTZM) over CAN bus is incorrect for out of total samples	>= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage Sensor Bus Relay	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Fuel Level Sensor 2 Internal Supply Circuit	P1179	This DTC monitors for an error in the Fuel Pump Driver Control Module Fuel Level Sensor 2 Internal Supply Circuit	Raw Fuel Pump Driver Control Module Fuel Level Sensor 2 Internal Supply Circuit is or Raw Fuel Pump Driver Control Module Fuel Level Sensor 2 Internal Supply Circuit is or Absolute difference of the filtered Fuel Pump Driver Control Module Fuel Level Sensor 2 Internal Supply Circuit and Raw Fuel Pump Driver Control Module Fuel Level Sensor 2 Internal Supply Circuit is For a non-continuous failure of out of For a continuous failure of	> 92.25 Percent < 87.75 Percent > 0.90 Percent 40.00 counts 80.00 counts 0.20 seconds	Diagnostic is enabled Run/Crank Ignition Voltage U0076 PT Sensor Bus Relay Communication with the Fuel Tank Zone Module is not lost	1.00 (1 indicates enabled) >= 11.00 Volts Is not active Commanded on	Executes in 50.0ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor B Reference Feedback Range/ Performance	P143E	This DTC monitors for an error with the FTZM Fuel Level Sensor B Reference Feedback Range/Performance Circuit	The difference between the actual and commanded FTZM reference voltage period or The difference between the actual and commanded FTZM reference voltage pulse width error	> 25.00 ms > 1.50 ms	Diagnostic is enabled Message $2D7 is being received Reference Voltage Pulse Width Signal has been available for Reference Voltage Period Signal has been available for System Diagnostics Disabled Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	1.00 True >= 1.25 seconds >= 0.75 seconds False = Run >= 11.00 Volts >= 11.00 Volts	16 failed samples within 20 total samples Executes in 250ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Performance (For use on vehicles with dual fuel tanks and mechanical transfer pump)	P2066	This DTC will detect a secondary fuel tank level sensor stuck in-range.	1) If Deadband diagnostic subtest Enabled AND 2a) If fuel volume in primary tank is and 2b) if fuel volume in secondary tank is and 2c) and if 2a and 2b indications do not change while fuel volume consumed by engine is	1) == Enabled status 2a) ≥ 27.5 liters 2b) < 5.0 liters 2c) >= 16.2 liters	1a) Diagnostic Enabled 1b) Engine Operational Status	1a) == True 1b) == Running	250 ms / sample	Type B, 2 Trips
			1) If Secondary sensor rationality diagnostic subtest enabled AND 2a) Volume in primary tank is 2b) and volume in secondary tank is 2c) and remains in this condition for	1) == Disabled status 2a) < 28 liters 2b) > 5 liters 2c) >= 1,800 seconds	1a) Diagnostic Enabled 1b) Engine Operational StatusEngine Running	1a) == True 1b) == Running	250 ms / sample	
			a) If indicated fuel volume change is b) while fuel consumed by the engine is	a) <= 3.00 liters b) >= 16 liters	1a) Diagnostic Enabled 1b) Engine Operational StatusEngine Running 2) Secondary tank volume [Not Empty] is	1a) == True 1b) == Running 2) ≥ 5.0 liters	250 ms / sample	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Circuit Low Voltage (For use on vehicles with dual fuel tanks)	P2067	This DTC will detect a fuel sender stuck out-of-range low in the secondary fuel tank.	Fuel level Sender % of 5V range	< 10 % or 26.72 liters	a) Diagnostic enabled status b) Fuel Level Sensor Initialized status c) Fuel Level Sensor Data Available Status d) Communication faults status	a) == True b) == True c) == True d) <> True	100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Circuit High Voltage (For use on vehicles with dual fuel tanks)	P2068	This DTC will detect a fuel level sensor stuck out-of-range high in the secondary fuel tank.	Fuel level Sender % of 5V range	> 60 % or 2.77 liters	a) Diagnostic enabled status b) Fuel Level Sensor Initialized status c) Fuel Level Sensor Data Available Status d) Communication faults status	a) == True b) == True c) == True d) <> True	100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VVT Lock Control Open Ckt Bnk1	P25CA	Controller specific output driver circuit diagnoses the VVL park pin system high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between signal and controller ground.	System supply voltage Output driver Ignition switch	> 11.00 Volts On Crank or Run	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VVT Lock Control Low Ckt Bnk1	P25CB	Controller specific output driver circuit diagnoses the VVL park pin system high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between signal and controller ground	System supply voltage Output driver Ignition switch	> 11.00 Volts On Crank or Run	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VVT Lock Control Hi Ckt Bnk1	P25CC	Controller specific output driver circuit diagnoses the VVL park pin system high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between signal and controller power	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VVT Lock Control Open Ckt Bnk2	P25CD	Controller specific output driver circuit diagnoses the VVL park pin system high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between signal and controller ground.	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VVT Lock Control Low Ckt Bnk2	P25CE	Controller specific output driver circuit diagnoses the VVL park pin system high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between signal and controller ground	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VVT Lock Control Hi Ckt Bnk2	P25CF	Controller specific output driver circuit diagnoses the VVL park pin system high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between signal and controller power	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Sensor B Circuit Low	P2802	Controller specific PWM circuit diagnoses the internal range sensor (IRS) B for a short to ground failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates short to ground failure Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to ground	≤ 0.5 Ω impedance between signal and controller ground	diagnostic monitor enable battery voltage update battery voltage timer PWM % duty cycle when voltage directly proportional OR PWM % duty cycle when voltage inversly proportional circuit sensor type	= 1 Boolean ≥ 9.00 volts ≤ 8.79 % ≥ 8.79 % CeTRGD_e_VoltDirctProp	fail time ≥ 0.50 seconds out of sample time ≥ 1.00 seconds battery voltage timer ≥ 1.00 seconds	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Sensor B Circuit High	P2803	Controller specific PWM circuit diagnoses the internal range sensor (IRS) B for a power short or open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates an open circuit or power short failure Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit or power short	≤ 0.5 Ω impedance between signal and controller voltage source OR ≥ 200 K Ω impedance between signal and controller ground	diagnostic monitor enable battery voltage update battery voltage timer PWM % duty cycle when voltage directly proportional OR PWM % duty cycle when voltage inversly proportional circuit sensor type	= 1 Boolean ≥ 9.00 volts ≥ 91.21 % ≤ 91.21 % CeTRGD_e_VoltDirctProp	fail time ≥ 0.50 seconds out of sample time ≥ 1.00 seconds battery voltage timer ≥ 1.00 seconds	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Two Stage Oil Pump Control Circuit Performance - One Sided	P06DD	Diagnoses the two stage oil pump is stuck. This diagnostic includes an intrusive test and a passive test. Intrusive test: The oil pump control is cycled off (high pressure) and on (low pressure) Y = 15 times at calibratable intervals. If a change in oil pressure above a calibration is not detected then the oil pressure is checked to determine if it is stuck. It takes X-out-of-Y failures to fail and set the appropriate code. Passive test: After the intrusive test passes, then a passive test will begin to run. The passive test will monitor the oil pressure changes associated with oil pump control state changes. If the passive test determines that the oil pressure change was less then desired then the intrusive test is retriggered.	<u>Fail from passing state:</u> Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is above a threshold	Oil Pressure delta = ABS [Filtered Oil Pressure at beginning of state change - filtered oil pressure after 1.3 seconds] Oil Pressure delta < **P06DD_P06DE_OP_StateChangeMin** AND Filtered Oil Pressure ≥ **P06DD_P06DE_MinOilPressThresh** (see P06DD details on Supporting Tables Tab **P06DD_P06DE_OP_StateChangeMin P06DD_P06DE_MinOilPressThresh**)	<u>Common Criteria:</u> Two Stage Oil Pump is Present Engine Running Ambient Air Pressure Oil Aeration (= TRUE if engine speed > 10,000 RPM for longer than 30.0 seconds) No active DTC's for diagnsotic enable: Check oil pump TFTKO as a diagnostic enable when Enabled. No active DTC's for control enable: <u>Active Criteria:</u> One Sided Performance Test = Enabled	TRUE ≥ 30.0 seconds ≥ 70.0 kPa FALSE Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensor_FA EngOilPressureSensorCktFA AmbientAirDefault EngOilTempFA Enabled : OilPmpTFTKO Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccurate EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA Enabled	≥ 12 errors out of 15 samples. Run once per trip or activiated by the Passive Test	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Oil Pump in Low State	> 1.3 seconds		
					Modelled Oil Temperature within range	40.0 deg C ≤ Oil Temp ≤ 110.0 deg C		
					Filtered Engine Speed within range	1,400 RPM ≤ Filtered Engine Speed ≤ 2,500 RPM		
					Engine Torque within range	**P06DD_P06DE_MinEnableTorque_OP** ≤ Indicated Requested Engine Torque ≤ **P06DD_P06DE_MaxEnableTorque_OP** (see P06DD details on Supporting Tables Tab **P06DD_P06DE_MinEnableTorque_OP** **P06DD_P06DE_MaxEnableTorque_OP**)		
					Delta Filtered Engine Speed within a range	ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds] ≤ 100 RPM		
					Filtered Oil Pressure within range	Filtered Engine Oil Pressure > **P06DD_P06DE_MinOilPressThresh** (see P06DD details on Supporting Tables Tab **P06DD_P06DE_MinOilPressThresh**)		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Expected Oil Pressure Delta within range

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			change and the measured filtered oil pressure is above a threshold	of state change - filtered oil pressure after 1.3 seconds] Oil Pressure delta < **P06DD_P06DE_OP_StateChangeMin** AND Filtered Oil Pressure ≥ **P06DD_P06DE_MinOilPressThresh** (see P06DD details on Supporting Tables Tab **P06DD_P06DE_OP_StateChangeMin** **P06DD_P06DE_MinOilPressThresh**)	Engine Running Ambient Air Pressure Oil Aeration (= TRUE if engine speed > 10,000 RPM for longer than 30.0 seconds) No active DTC's for diagnsotic enable: Check oil pump TFTKO as a diagnostic enable when Enabled. No active DTC's for control enable: <u>Active Criteria:</u> One Sided Performance Test = Enabled Oil Pump in Low State Modelled Oil Temperature within range	≥ 30.0 seconds ≥ 70.0 kPa FALSE Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensor_FA EngOilPressureSensorCktFA AmbientAirDefault EngOilTempFA Enabled : OilPmpTFTKO Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccurate EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA Enabled > 1.3 seconds 40.0 deg C ≤ Oil Temp ≤ 110.0 deg C	or activiated by the Passive Test	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Filtered Engine Speed within range	1,400 RPM ≤ Filtered Engine Speed ≤ 2,500 RPM		
					Engine Torque within range	**P06DD_P06DE_MinEnableTorque_OP** ≤ Indicated Requested Engine Torque ≤ **P06DD_P06DE_MaxEnableTorque_OP** (see P06DD details on Supporting Tables Tab **P06DD_P06DE_MinEnableTorque_OP** **P06DD_P06DE_MaxEnableTorque_OP**)		
					Expected Oil Pressure Delta within range	150.0 kPa < ABS[**P0521_P06DD_P06DE_OP_HiStatePressure** - **P0521_P06DD_P06DE_OP_LoStatePressure**] < 425.0 kPa		
					Delta Filtered Engine Speed within a range	ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds] ≤ 100 RPM		
					Filtered Oil Pressure within range	Filtered Engine Oil Pressure > **P06DD_P06DE_MinOilPressThresh** (see P06DD details on Supporting Tables Tab **P06DD_P06DE_MinOilPressThresh**)		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Metal Over temperature Active	P1258	The objective of the algorithm is to protect the engine in the event of engine metal overtemperature, mainly due to loss of coolant	Engine Coolant For a period	>= 132 °C >= 2 seconds	Engine Run Time If feature was active and it set the coolant sensor fault then feature will be enabled on coolant sensor fault pending on the next trip.	>= 30 Seconds	Fault present for >= 0 seconds	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Temperature Sensor 1 Internal Fault - Error Code	P126E	This DTC Diagnoses the SENT Fuel Temperature Sensor 1 internal failure	Fuel Temperature Sensor 1 SENT digital read value	>= 4,089.00	No Fault Active on No Fault Pending on	Enabled when a code clear is not active or not exiting device control SENT Communication Fault Active (P16E4, P16E5) Fuel Temperature Sensor SENT Message Error Fault Active (P128C) Fuel Temperature Sensor SENT Message Error Fault Pending (P128C)	50.00 failures out of 62.00 samples 100 ms per Sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Temperature Sensor 2 Internal Fault - Error Code	P126F	This DTC Diagnoses the SENT Fuel Temperature Sensor 2 internal failure	Fuel Temperature Sensor 2 SENT digital read value	>= 4,089.00	No Fault Active on No Fault Pending on	Enabled when a code clear is not active or not exiting device control SENT Communication Fault Active (P16E4, P16E5) Fuel Temperature Sensor SENT Message Error (P128D) Fuel Temperature Sensor SENT Message Error Fault Pending (P128D)	50.00 failures out of 62.00 samples 100 ms per Sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Mode Switch Signal Circuit Include for programs that are NOT hybrid start stop conventional	P1762	Vehicles that are not hybrid start stop conventional applications, this diagnoses the transmission mode switch signal circuit (BCM to ECM Rolling Count check)	Rolling count value received from BCM does not match expected value	= TRUE	Engine Speed Engine Speed Engine speed between min/max for Vehicle Speed for	≥ 200 RPM ≤ 7,500 RPM ≥ 5.0 seconds ≤ 318.14 MPH ≥ 5.0 seconds	> 3 error counts for > 10.0 seconds 100 ms / sample	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transfer Case Speed Sensor Output (TCSS)	P2160	The diagnostic monitor detects no activity in the TCSS circuit due to an electrical fault, wiring fault or sensor fault. The TCSS signal is rationalized against operating conditions of the vehicle. If the vehicle is in motion, accelerator pedal, engine torque, transmission in gear, and no vehicle braking, and the TCSS signal registers below a threshold, the DTC will set.	transfer case output shaft speed sesnor raw speed	≤ 25.0 RPM	diagnotic monitor enable calibration transmission gear selector position AND engine torque AND engine torque NOT AND accelerator pedal position AND accelerator pedal position NOT transmission gear selector position AND engine torque AND engine torque NOT AND accelerator pedal position AND accelerator pedal position NOT run/crank voltage run/crank voltage engine power limited PTO active engine speed transmission output shaft speed update range change delay time when condition A or condition B or condition C (25 millisecond update rate):	= 1 Boolean = PARK OR NEUTRAL ≥ 8,191.75 Nm ≤ 8,191.75 Nm ≥ 100.00 % ≤ 8.00 % ≠ PARK AND ≠ NEUTRAL ≥ 80.00 Nm ≤ 35.00 ≥ 5.00 % ≤ 3.00 % ≥ 5.0 volts for 25 milliseconds ≥ 9.0 volts = FALSE Boolean = FALSE Boolean ≥ 300.0 RPM ≥ 181.0 RPM	fail time ≥ 4.50 seconds 25 millisecond update rate range change delay time ≥	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					condition A: transmission range state transmission range state previous loop (25 millisecond) condition B: test when transmission range state is reverse enable calibration AND transmission range state transmission range state previous loop (25 millisecond) condition C: test when transmission range state is neutral enable calibration AND transmission range state transmission range state previous loop (25 millisecond) P2161 test fail this key on P2160 test fail this key on P2160 fault active DTCs not fault active	 = drive8 or less = drive8 or less = 0 Boolean = REVERSE = REVERSE = 0 Boolean = NEUTRAL = NEUTRAL = FALSE Boolean = FALSE Boolean = FALSE Boolean Transmission Output Shaft Angular Velocity Validity CrankSensor_FA EngineTorqueEstInaccurate	**P2160 range change delay time** seconds Refer to "Transmission Supporting Tables" for details	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transfer Case Speed Sensor Output (TCSS)	P2161	The diagnostic monitor detects an unrealistic drop in the TCSS signal due to a sudden electrical fault, wiring fault or sensor fault. The TCSS signal is rationalized against operating conditions of the vehicle. If the vehicle is in motion, accelerator pedal, engine torque, transmission in gear, and no vehicle braking, and the TCSS signal drops above a delta threshold, a fail timer is enabled. When a TCSS drop occurs it is possible to enable the P2160 fail time as well as the PP2161 fail time. With both P2160 and P2161 fail timers active it is a race condition to either DTC.	transfer case speed sesnor raw speed delta, 25 millisecond update rate	≥ 650.0 RPM	diagnotic monitor enable calibration update range change delay time when condition A or condition B or condition C (25 millisecond update rate): condition A: transmission range state transmission range state previous loop (25 millisecond) condition B: test when transmission range state is reverse enable calibration AND transmission range state transmission range state previous loop (25 millisecond) condition C: test when transmission range state is neutral enable calibration AND transmission range state transmission range state previous loop (25 millisecond)	= 1 Boolean = drive8 or less = drive8 or less = 0 Boolean = REVERSE = REVERSE = 0 Boolean = NEUTRAL = NEUTRAL	fail time ≥ 3.00 seconds, 25 millisecond update rate, increment fail count fail count ≥ 5 counts, 25 millisecond update rate range change delay time ≥ **P2161 range change delay time** seconds Refer to "Transmission Supporting Tables" for details	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					run/crank voltage	≥ 5.0 volts for 25 milliseconds		
					run/crank voltage	≥ 9.0 volts		
					PTO active	= FALSE Boolean		
					transfer case mode	≠ transfer case mode previos loop (25 millisecond) update 4WD range change time		
					4WD range change time	≥ 5.00 seconds		
					engine speed	≥ 500.0 RPM		
					transmission output shaft speed loop to loop delta (25 millisecond)	≤ 4,095.0 RPM		
					AND			
					transmission output shaft speed	≥ 350.0 RPM		
					update stability time	≥ 0.00 seconds		
					stability time			
					transfer case raw output speed	> 150.0 RPM		
					AND			
					transfer case raw output speed last loop (25 millisecond)	> 150.0 RPM		
					update stability time			
					stability time	≥ 6.00 seconds		
					P2160 test fail this key on	= FALSE		
					P2160 fault active	= FALSE		
					DTCs not fault active	CrankSensor_FA TransmissionEngagedState_FA Transmission Output Shaft Angular Velocity Validity		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Temperature Sensor 1 Circuit Low Fault	P0182	This DTC diagnose SENT fuel rail temperature sensor 1 that is too low out of range. If the sensor digital value (represnting the refernce voltage) is below the lower digital threshold, the low fail counter then increments. If the low fail counter reaches its threshold then a fail is reported. A pass is reported for this DTC if the low sample counter reaches its threshold.	Fuel Temperature Sensor 1 SENT digital read value	< 219	Fuel Temperature Out of Range Diagnoistic Enabled No Fault Active on No Fault Pending on	True Enabled when a code clear is not active or not exiting device control SENT Communication Fault Active (P16E4, P16E5) SENT Intenal Error Fault Active (P126E) Fuel Temperature Sensor SENT Message Error Fault Active (P128C) SENT Intenal Error Fault Pending (P126E) Fuel Temperature Sensor SENT Message Error Fault Pending (P128C)	50.00 failures out of 62.00 samples 100 ms per Sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Temperature Sensor 1 Circuit High Fault	P0183	This DTC diagnose SENT fuel rail temperature sensor 1 that is too high out of range. If the sensor digital value (represnting the refernce voltage) is above the upper digital threshold, the high fail counter then increments. If the high fail counter reaches its threshold then a fail is reported. A pass is reported for this DTC if the high sample counter reaches its threshold.	Fuel Temperature Sensor 1 SENT digital read value	> 2,049	Fuel Temperature Out of Range Diagnoistic Enabled No Fault Active on No Fault Pending	True Enabled when a code clear is not active or not exiting device control SENT Communication Fault Active (P16E4, P16E5) SENT Intenal Error Fault Active (P126E) Fuel Temperature Sensor SENT Message Error Fault Active (P128C) SENT Intenal Error Fault Pending (P126E) Fuel Temperature Sensor SENT Message Error Fault Pending (P128C)	50.00 failures out of 62.00 samples 100 ms per Sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Temperature Sensor 2 Circuit Low Fault	P0187	This DTC diagnose SENT fuel rail temperature sensor 2 that is too low out of range. If the sensor digital value (represnting the refernce voltage) is below the lower digital read threshold, the low fail counter then increments. If the low fail counter reaches its threshold then a fail is reported. A pass is reported for this DTC if the low sample counter reaches its threshold.	Fuel Temperature Sensor 1 SENT digital read value	< 219.00	Fuel Temperature Out of Range Diagnoistic Enabled No Fault Active on No Fault Pending	True Enabled when a code clear is not active or not exiting device control SENT Communication Fault Active (P16E4, P16E5) SENT Intenal Error Fault Active (P126F) Fuel Temperature Sensor SENT Message Error Fault Active (P128D) SENT Intenal Error Fault Pending (P126F) Fuel Temperature Sensor SENT Message Error Fault Pending (P128D)	50.00 failures out of 62.00 samples 100 ms per Sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Temperature Sensor 2 Circuit High Fault	P0188	This DTC diagnose SENT fuel rail temperature sensor 2 that is too high out of range. If the sensor digital value (represnting the refernce voltage) is above the upper digital read threshold, the high fail counter then increments. If the high fail counter reaches its threshold then a fail is reported. A pass is reported for this DTC if the high sample counter reaches its threshold.	Fuel Temperature Sensor 1 SENT digital read value	> 2,049.00	Fuel Temperature Out of Range Diagnoistic Enabled No Fault Active on No Fault Pending	True Enabled when a code clear is not active or not exiting device control SENT Communication Fault Active (P16E4, P16E5) SENT Intenal Error Fault Active (P126F) Fuel Temperature Sensor SENT Message Error Fault Active (P128D) SENT Intenal Error Fault Pending (P126F) Fuel Temperature Sensor SENT Message Error Fault Pending (P128D)	50.00 failures out of 62.00 samples 100 ms per Sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Active Grill Air Shutter B Performance /Stuck OFF	P05AE	A 2-part diagnostic. Part 1 continuously monitors for failure to achieve a commanded shutter actuator position [Suspect Stuck Condtion] when X failures occur in Y samples after an electronic command latency delay. Part 1 failure enables Part 2 which makes a fixed number of repeat attempts to reach the commanded postion [ReTry to clear obstruction]. The DTC is set when the calibrated fault threshold count of repeat attempts is reached without achieving the original commanded shutter position.	Smart Shutter Actuator 2 Position Response AND Shutter 2 Diagnostic Delay Threshold count	<> Smart Shutter Actuator 2 Commanded Position percent AND Counter > 129.00 counts	a. Ignition Run_Crank Active, b. Ignition Run_Crank AND Ignition Accessory AND ECU Awake, c. Command Shutter2 Enable	a. = TRUE, b. = FALSE AND = FALSE AND = TRUE, c. = 1.00	1.00 failures out of 1.00 samples 1 sample / 100 milliseconds	Type B, 2 Trips
			Shutter 2 Performance Test count	= 5.00 counts	a. Ignition Run_Crank Active, b. Ignition Run_Crank AND Ignition Accessory AND ECU Awake, c. Command Shutter2 Enable	a. = TRUE, b. = FALSE AND = FALSE AND = TRUE, c. = 1.00	1-5 actuator cycles [1 cycle typically requires 10-25 seconds]	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit Open	P0627	Controller specific output driver circuit diagnoses the Feed Fuel Pump Relay high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	>= 200 KOhms impedance between signal and controller ground.	Run/Crank Voltage Engine Speed	Voltage 11.00 volts 0 RPM	8 failures out of 10 samples 250 ms / sample	Type A, 1 Trips Note: In certain controllers P0629 may also set (Fuel Pump Relay Control Short to Power)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit Low Voltage	P0628	Controller specific output driver circuit diagnoses the Feed Fuel Pump Relay high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 0.5 Ohms impedance between signal and controller ground	Run/Crank Voltage Engine Speed	Voltage 11.00 volts 0 RPM	8 failures out of 10 samples 250 ms / sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit High Voltage	P0629	Controller specific output driver circuit diagnoses the Feed Fuel Pump Relay high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 0.5 Ohms impedance between signal and controller power	Run/Crank Voltage Engine Speed	Voltage 11.00 volts 0 RPM	8 failures out of 10 samples 250 ms / sample	Type A, 1 Trips Note: In certain controllers P0627 may also set (Fuel Pump Relay Control Open Circuit)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Two Stage Oil Pump Control Circuit Open	P06DA	Controller specific output driver circuit diagnoses the two stage oil pump low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit ≥ 200 k Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Run/Crank Active Cranking State	Enabled ≥ 11.00 = True = False	>= 40 errors out of 50 samples. Performed every 100 msec	Type B, 2 Trips Note: In certain controllers P06DB may also set (Two Stage Oil Pump Control Circuit Short To Ground)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Two Stage Oil Pump Control Circuit Short To Ground	P06DB	Controller specific output driver circuit diagnoses the two stage oil pump low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	Diagnostic Status Powertrain Relay Voltage Run/Crank Active Cranking State	Enabled ≥ 11.00 = True = False	>= 40 errors out of 50 samples. Performed every 100 msec	Type A, 1 Trips Note: In certain controllers P06DA may also set (Two Stage Oil Pump Control Circuit Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Two Stage Oil Pump Control Circuit Short To Power	P06DC	Controller specific output driver circuit diagnoses the two stage oil pump low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power ≤ 0.5 Ω impedance between output and controller power	Diagnostic Status Powertrain Relay Voltage Run/Crank Active Cranking State	Enabled ≥ 11.00 = True = False	>= 40 errors out of 50 samples. Performed every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Two Stage Oil Pump Control Circuit Performance - Two Sided	P06DD	Diagnoses the two stage oil pump is stuck in the high pressure state. This diagnostic includes an intrusive test and a passive test. Intrusive test: The oil pump control is cycled off (high pressure) and on (low pressure) Y = 15 times at calibratable intervals. If a change in oil pressure above a calibration is not detected then the oil pressure is checked to determine if it is stuck. It takes X-out-of-Y failures to fail and set the appropriate code. Passive test: After the intrusive test passes, then a passive test will begin to run. The passive test will monitor the oil pressure changes associated with oil pump control state changes. If the passive test determines that the oil pressure change was less then desired then the intrusive test is retriggered.	<u>Fail from passing state:</u> Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is above a threshold	Oil Pressure delta = ABS [Filtered Oil Pressure at beginning of state change - filtered oil pressure after 1.5 seconds] Oil Pressure delta < **P06DD_P06DE_OP_StateChangeMin** AND Filtered Oil Pressure ≥ (**P0521_P06DD_P06DE_OP_HiStatePressure** + **P0521_P06DD_P06DE_OP_LoStatePressure**) ÷ 2 (see P06DD details on Supporting Tables Tab **P06DD_P06DE_OP_StateChangeMin** **P0521_P06DD_P06DE_OP_HiStatePressure** **P0521_P06DD_P06DE_OP_LoStatePressure**)	<u>Common Criteria:</u> Two Stage Oil Pump is Present Engine Running Ambient Air Pressure Oil Aeration (= TRUE if engine speed > 5,000 RPM for longer than 30.0 seconds) No active DTC's for diagnsotic enable: Check oil pump TFTKO as a diagnostic enable when Enabled. No active DTC's for control enable: <u>Active Criteria:</u> One Sided Performance Test = Disabled	TRUE ≥ 5.5 seconds ≥ 70.0 kPa FALSE Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensor_FA EngOilPressureSensorCktFA AmbientAirDefault EngOilTempFA OilPmpTFTKO Enabled : OilPmpTFTKO Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccurate EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA Disabled	≥ 12 errors out of 15 samples. Run once per trip or activiated by the Passive Test	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Oil Pump in Low State	> 1.5 seconds		
					Modelled Oil Temperature within range	60.0 deg C ≤ Oil Temp ≤ 115.0 deg C		
					Filtered Engine Speed within range	1,500 RPM ≤ Filtered Engine Speed ≤ 3,500 RPM		
					Delta Filtered Engine Speed within a range	ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds] ≤ 150 RPM		
					Engine Torque within range	**P06DD_P06DE_MinEnableTorque_OP** ≤ Indicated Requested Engine Torque ≤ **P06DD_P06DE_MaxEnableTorque_OP** (see P06DD details on Supporting Tables Tab **P06DD_P06DE_MinEnableTorque_OP** **P06DD_P06DE_MaxEnableTorque_OP**)		
					Filtered Oil Pressure within range	Filtered Engine Oil Pressure > **P06DD_P06DE_MinOilPressThresh** (see P06DD details on Supporting Tables Tab **P06DD_P06DE_MinOilPressThresh**)		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Expected Oil Pressure Delta within range	111.0 kPa < ABS [**P0521_P06DD_P06DE_OP_HiStatePressure** - **P0521_P06DD_P06DE_OP_LoStatePressure**] < 200.0 kPa		
					<u>Passive Criteria:</u>			
					Active Test Passed	TRUE		
					Filtered Engine Speed within range	1,800 RPM ≤ Filtered Engine Speed ≤ 4,500 RPM		
					Modelled Oil Temperature within range	50.0 deg C ≤ Oil Temp ≤ 105.0 deg C		
					Delta Filtered Engine Speed within a range	ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.50 seconds] ≤ 450 RPM		
					Oil Pressure Delta within a range	Oil Pressure Delta < **P06DD_P06DE_OP_StateChangeMin** (see P06DD details on Supporting Tables Tab **P06DD_P06DE_OP_StateChangeMin**)		
			<u>Fast Pass Condition</u> Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is	Oil Pressure delta = ABS [Filtered Oil Pressure at beginning of state change -	<u>Common Criteria:</u> Two Stage Oil Pump is Present Engine Running	 TRUE ≥ 5.5 seconds	0 errors out of 5 samples. Run once per trip or activiated by the Passive Test	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			above a threshold	filtered oil pressure after 1.5 seconds] Oil Pressure delta < **P06DD_P06DE_OP_StateChangeMin** AND Filtered Oil Pressure ≥ (**P0521_P06DD_P06DE_OP_HiStatePressure** - **P0521_P06DD_P06DE_OP_LoStatePressure**) ÷ 2 (see P06DD details on Supporting Tables Tab **P06DD_P06DE_OP_StateChangeMin** **P0521_P06DD_P06DE_OP_HiStatePressure** **P0521_P06DD_P06DE_OP_LoStatePressure**)	Ambient Air Pressure Oil Aeration (= TRUE if engine speed > 5,000 RPM for longer than 30.0 seconds) No active DTC's for diagnsotic enable: Check oil pump TFTKO as a diagnostic enable when Enabled. No active DTC's for control enable: <u>Active Criteria:</u> One Sided Performance Test = Disabled Oil Pump in Low State Modelled Oil Temperature within range Filtered Engine Speed within range	≥ 70.0 kPa FALSE Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA EngOilPressureSensorCktFA AmbientAirDefault EngOilTempFA OilPmpTFTKO CrankSensor_FA Enabled : OilPmpTFTKO Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccurate EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA Disabled > 1.5 seconds 60.0 deg C ≤ Oil Temp ≤ 115.0 deg C 1,500 RPM ≤ Filtered Engine Speed ≤ 3,500		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						RPM		
					Engine Torque within range	**P06DD_P06DE_MinEnableTorque_OP** ≤ Indicated Requested Engine Torque ≤ **P06DD_P06DE_MaxEnableTorque_OP** (see P06DD details on Supporting Tables Tab **P06DD_P06DE_MinEnableTorque_OP** **P06DD_P06DE_MaxEnableTorque_OP**)		
					Delta Filtered Engine Speed within a range	ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds] ≤ 150 RPM		
					Filtered Oil Pressure within range	Filtered Engine Oil Pressure > **P06DD_P06DE_MinOilPressThresh** (see P06DD details on Supporting Tables Tab **P06DD_P06DE_MinOilPressThresh**)		
					Expected Oil Pressure Delta within range	111.0 kPa < ABS [**P0521_P06DD_P06DE_OP_HiStatePressure** - **P0521_P06DD_P06DE_OP_LoStatePressure**] < 200.0 kPa		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Two Stage Oil Pump Control Circuit StuckOn - Two Sided	P06DE	Diagnoses the two stage oil pump is stuck in the low pressure state. This diagnostic includes an intrusive test and a passive test. Intrusive test: The oil pump control is cycled off (high pressure) and on (low pressure) Y times at calibratable intervals. If a change in oil pressure above a calibration is not detected then the oil pressure is checked to determine if it is stuck. It takes X-out-of-Y failures to fail and set the appropriate code. Passive test: After the intrusive test passes, then a passive test will begin to run. The passive test will monitor the oil pressure changes associated with oil pump control state changes. If the passive test determines that the oil pressure change was less then desired then the intrusive test is retriggered.	<u>Fail from a passing state:</u> Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is below a threshold	Oil Pressure delta = ABS [Filtered Oil Pressure at beginning of state change - filtered oil pressure after 1.5 seconds] Oil Pressure delta < **P06DD_P06DE_OP_StateChangeMin** (see P06DE details on Supporting Tables Tab) Filtered Oil Pressure ≤ **P0521_P06DD_P06DE_OP_HiStatePressu** (**re - P0521_P06DD_P06DE_OP_LoStatePressure**) **÷ 2** (see P06DE details on Supporting Tables Tab)	<u>Common Criteria</u>: Two Stage Oil Pump is Present Engine Running Ambient Air Pressure Oil Aeration (= TRUE if engine speed > 5,000 RPM for longer than 30.0 seconds) No active DTC's for diagnsotic enable: Check oil pump TFTKO as a diagnostic enable when Enabled. No active DTC's for control enable: <u>Active Criteria</u>: One Sided Performance	TRUE ≥ 5.5 seconds ≥ 70.0 kPa FALSE Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensor_FA EngOilPressureSensorCktFA AmbientAirDefault EngOilTempFA Enabled : OilPmpTFTKO Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccurate EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA Disabled	≥ 12 errors out of 15 samples. Run once per trip or activiated by the Passive Test	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Test = Disabled			
					Oil Pump in Low State	> 1.5 seconds		
					Modelled Oil Temperature within range	60.0 deg C ≤ Oil Temp ≤ 115.0 deg C		
					Filtered Engine Speed within range	1,500 RPM ≤ Filtered Engine Speed ≤ 3,500 RPM		
					Engine Torque within range	**P06DD_P06DE_MinEnableTorque_OP** ≤ Indicated Requested Engine Torque ≤ **P06DD_P06DE_MaxEnableTorque_OP** (see P06DE details on Supporting Tables Tab)		
					Delta Filtered Engine Speed within a range	ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds] ≤ 150 RPM		
					Filtered Oil Pressure within range	Filtered Engine Oil Pressure > **P06DD_P06DE_MinOilPressThresh** (see P06DD details on Supporting Tables Tab)		
					Expected Oil Pressure Delta within range	111.0 kPa < ABS [**P0521_P06DD_P06DE_OP_HiStatePressure** - **P0521_P06DD_P06DE_OP_LoStatePressure**] < 200.0 kPa		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Passive Criteria:			
					Active Test Passed	TRUE		
					Filtered Engine Speed within range	1,800 RPM ≤ Filtered Engine Speed ≤ 4,500 RPM		
					Modelled Oil Temperature within range	50.0 deg C ≤ Oil Temp ≤ 105.0 deg C		
					Delta Filtered Engine Speed within a range	ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.50 seconds] ≤ 450 RPM		
					Oil Pressure Delta < **P06DD_P06DE_OP_StateChangeMin** (see P06DE details on Supporting Tables Tab)	TRUE		
			Fast Pass Condition Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is below a threshold	Oil Pressure delta = ABS [Filtered Oil Pressure at beginning of state change - filtered oil pressure after 1.5 seconds] Oil Pressure delta <	Common Criteria: Two Stage Oil Pump is Present Engine Running Ambient Air Pressure Oil Aeration (= TRUE if engine speed	 TRUE ≥ 5.5 seconds ≥ 70.0 kPa FALSE	0 errors out of 5 samples. Run once per trip or activiated by the Passive Test	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				P06DD_P06DE_OP_StateChangeMin (P06DD Performance Test Details on Supporting Tables Tab) Filtered Oil Pressure ≤ **P0521_P06DD_P06DE_OP_HiStatePressure** - **P0521_P06DD_P06DE_OP_LoStatePressure**) / 2 (P06DD Performance Test Details on Supporting Tables Tab)	> 5,000 RPM for longer than 30.0 seconds) No active DTC's for diagnsotic enable: Check oil pump TFTKO as a diagnostic enable when Enabled. No active DTC's for control : <u>Active Criteria:</u> One Sided Performance Test = Disabled Oil Pump in Low State Modelled Oil Temperature within range Filtered Engine Speed within range Engine Torque within range	Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensor_FA EngOilPressureSensorCktFA AmbientAirDefault EngOilTempFA Enabled : OilPmpTFTKO Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccurate EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA Disabled > 1.5 seconds 60.0 deg C ≤ Oil Temp ≤ 115.0 deg C 1,500 RPM ≤ Filtered Engine Speed ≤ 3,500 RPM **P06DD_P06DE_MinEnableTorque_OP** ≤		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						Indicated Requested Engine Torque ≤ **P06DD_P06DE_MaxEnableTorque_OP** (P06DD Performance Test Details on Supporting Tables Tab)		
					Delta Filtered Engine Speed within a range	ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds] ≤ 150 RPM		
					Filtered Oil Pressure within range	Filtered Engine Oil Pressure > **P06DD_P06DE_MinOilPressThresh** (see P06DD details on Supporting Tables Tab)		
					Expected Oil Pressure Delta within range	111.0 kPa < ABS [**P0521_P06DD_P06DE_OP_HiStatePressure** - **P0521_P06DD_P06DE_OP_LoStatePressure**] < 200.0 kPa		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Powertrain Control Module (HPC) Requested MIL Illumination	P0AC4	Monitors the HPC MIL request message to determine when the HPC has detected a MIL illuminating fault.	HPC Module Emissions-Related DTC set and module is requesting MIL	HPC Module Emissions-Related DTC set and module is requesting MIL		Time since power-up ≥ 3 seconds	Continuous	Type A, No MIL

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temperature Sensor Not Plausible	P112F	This DTC detects either a biased high or low RCT (Radiator Coolant Temperature) sensor. This is done by comparing the RCT sensor output to two other temperature sensor outputs after a soak condition.	**Sensor usage definitions:** **Sensor1 =** CeECTR_e_ECT_Snsr (Sensor1 is the temp sensor most impacted by the block heater (if equipped)) **Sensor2 =** CeECTR_e_RCT_Snsr **Sensor3 =** CeECTR_e_IAT_Snsr ========== A failure will be reported if (based on the above calibrations): 1) Sensor2 (if RCT is Sensor2)power up absolute temp difference to Sensor1 and Sensor3 is: OR (based on usage) 2) Sensor3 (if RCT is Sensor3) power up absolute temp difference to Sensor1 and Sensor2 is:	 ≥ 15.8 ºC ≥ 15.8 ºC	No Active DTC's Engine Off Soak Time Propulsion Off Soak Time Non-volatile memory initization Test complete this trip Test aborted this trip Test disabled this trip Ambient LowFuelCondition Diag	VehicleSpeedSensor_FA IAT_SensorCircuitFA THMR_RCT_Sensor_Ckt_FA ECT_Sensor_Ckt_FA EngineModeNotRunTimerError EngineModeNotRunTimer_FA OAT_PtEstFiltFA OAT_PtEstRawFA PSAR_PropSysInactveCrs_FA DRER_DiagSystemDsbl > 25,200 seconds > 0 seconds = Not occurred = False = False = False ≥ -9 ºC = False	1 failure to set DTC 1 sec/ sample Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure &Temperature Sensor Temperature 1 Message Incorrect	P128C	This DTC diagnoses the the communication errors on the temperature 1 serial data channel	Serial Message 1 Age	>= 0.04 ms	SENT signal Serial waveform diagnostics enable SENT power up delay No Fault Active	True >= 0.00 seconds P16E4 P16E5	114 failures out of 142 samples 6.25 ms per sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure & Temperature Sensor Temperature 2 Message Incorrect	P128D	This DTC diagnoses the the communication errors on the temperature 2 serial data channel	Serial Message 2 Age	>= 0.04 ms	SENT signal Serial waveform diagnostics enable SENT power up delay No Fault Active	True >= 0.00 seconds P16E4 P16E5	114 failures out of 142 samples 6.25 ms per sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Module-System Voltage Low [FPPM applications only]	P129B	Detects low voltage condition of the fuel pump power module. This diagnostic reports the DTC when the fuel pump power module input voltage drops below a calibrated value.	Input Voltage	< 7.00 volts	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType b) Diagnostic Enabled KeFRPR_b_FPPM_ BatVoltLoDiagEnbl c] Diagnostic System Disabled d] Engine Running e] FPPM Power Alive Rolling Counter Fault f] FPPM Diagnostic Info1 Received message $0D5 g] Sensed Battery Voltage [message $D5]	a) == CeFRPR_e_ECM _FPPM_Sys b) == TRUE c] <> TRUE d] == TRUE e] <> TRUE f] == TRUE g] >= 7.00 volts	64.00 failures / 80.00 samples [12.5 miilisec / sample]	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Module-System Voltage High [FPPM applications only]	P129C	Detects high voltage condition of the fuel pump power module. This diagnostic reports the DTC when the fuel pump power module input voltage exceeds a calibrated value.	Input Voltage	> 18.00 volts	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType b) Diagnostic Enabled KeFRPR_b_FPPM_ BatVoltLoDiagEnbl c] Diagnostic System Disabled d] FPPM Power Alive Rolling Counter Fault e] FPPM Diagnostic Info1 Received message $0D5 f] Sensed Battery Voltage [message $D5]	a) == CeFRPR_e_ECM _FPPM_Sys b) == TRUE c] <> TRUE d] <> TRUE e] == TRUE f] >= 7.00 volts	64.00 failures / 80.00 samples [12.5 miilisec / sample]	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Module-Ignition Switch Run/ Start Position Circuit Low [FPPM applications only]	P129D	To detect if the Run/ Start position circuit voltage is short to low / open	FPPM Run_Crank Active status	<> ECM Run_Crank Active status	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType b) Diagnostic KeFRPR_b_FPPM_RunC rnkRatlEnbld c) FPPM Control Status Alive Rolling Count result d) Diagnostic feedback received e) System Voltage	a) == CeFRPR_e_ECM_FPPM _Sys b) == TRUE c) == Valid d) == TRUE e) >= 0.0 v	64 failures / 80 samples 1 sample / 12.5 millisec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Signal Message Counter Incorrect [FPPM applications only]	P129E	To detect if the command message received as serial data from the engine control module is valid The "rolling count check" value is created by adding an appended hexadecimal calculation to the pump duty cycle command value. In order to achieve a desired fuel pressure, a hexadecimal equivalent value representing the necessary fuel pump current pulse "On" time (duty cycle as a percent value) is transmitted to the FPPM. The corresponding "check" value is transmitted as well. At the FPPM, the received duty cycle command value is used to create an expected "rolling count" value using the same calculation method as the ECM. The expected "rolling count" value calculated at the receiving power module (smart device) is compared to the transmitted "rolling count" value. If these do not match, a fault condition is reported	FPPM Received Duty Cycle Rolling Count	<> Transmitted Duty Cycle Rolling Count (ECM) (Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate test state)	a) Chassis Fuel Pres Sys Type configuration selection b) Diagnostic Enabled c) FPPM Control Rolling Count Faulted d) FPPM Diagnostic data received [$0CE] e) FPPM Diagnostic Data Validity Enabled f) Diagnostic System Disabled g) Communication Faulted h) Run_Crank Ignition Switch Position Circuit Voltage j) Run_Crank Ignition Status k) Sensor Bus Relay On	a) == FCBR ECM FPPM Sys b) == TRUE c) <> True d) == TRUE e) == TRUE f) <> True g) <> True h) > 7.00 Volts j) == TRUE k) == TRUE	64 failures / 80 samples 1 sample / 12.5 millisec	Type B, 2 Trips
			FPPM Received Duty Cycle Protection Value	<> Transmitted Duty Cycle Protection Value (ECM) (Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate test state)	a) Chassis Fuel Pres Sys Type configuration selection b) Diagnostic Enabled c) FPPM Control Rolling Count Faulted d) FPPM Diagnostic data received [$0CE] e) FPPM Diagnostic Data Validity Enabled f) Diagnostic System Disabled g) Communication Faulted h) Run_Crank Ignition Switch Position Circuit	a) == FCBR ECM FPPM Sys b) == TRUE c) <> True d) == TRUE e) == TRUE f) <> True g) <> True h) > 7.00 Volts	64 failures / 80 samples 1 sample / 12.5 millisec	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		forward to the ECM where X/Y diagnostic counting is performed.			Voltage j) Run_Crank Ignition Status k) Sensor Bus Relay On	 j) == TRUE k) == TRUE		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Control Status Signal Message Counter Incorrect [FPPM applications only]	P12A8	To detect if the control status message transmitted as serial data from the driver control module is valid. The "rolling count check" value is created by adding an appended hexadecimal calculation to each control command value. The corresponding "check" value is transmitted to the FPPM as well as the actual command. At the FPPM, the received command value is used to create an expected "rolling count" value using the same calculation method as the ECM. The expected "rolling count" value calculated at the receiving power module (smart device) is compared to the transmitted "rolling count" value. If these do not match, a fault condition is reported forward to the ECM where X/Y diagnostic counting is performed.	FPPM Control Status Alive Rolling Count	<> ECM Control Status Alive Rolling Count (Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate test state)	a) Chassis Fuel Pres Sys Type configuration selection b) Diagnostic Enabled c) FPPM Diagnostic serial data received d) Run_Crank Ignition Switch Position Circuit Voltage	a) == FCBR ECM FPPM Sys b) == TRUE c) == TRUE d) > 0.00 Volts	64 failures / 80 samples 1 sample / 12.5 millisec	Type B, 2 Trips
			FPPM Power Consumption Alive Rolling Count	<> ECM Power Consumption Alive Rolling Count (Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate test state)	a) Chassis Fuel Pres Sys Type configuration selection b) Diagnostic Enabled c) FPPM Diagnostic serial data received d) Run_Crank Ignition Switch Position Circuit Voltage	a) == FCBR ECM FPPM Sys b) == TRUE c) == TRUE d) > 0.00 Volts	64 failures / 80 samples 1 sample / 12.5 millisec	
			FPPM Driver Status Alive Rolling Count	<> ECM Driver Status Alive Rolling Count (Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate test state)	a) Chassis Fuel Pres Sys Type configuration selection b) Diagnostic Enabled c) FPPM Diagnostic serial data received d) Run_Crank Ignition Switch Position Circuit Voltage	a) == FCBR ECM FPPM Sys b) == TRUE c) == TRUE d) > 0.00 Volts	64 failures / 80 samples 1 sample / 12.5 millisec	
			FPPM Hardware Status Alive Rolling Count	<> ECM Hardware Status Alive Rolling Count (Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate test state)	a) Chassis Fuel Pres Sys Type configuration selection b) Diagnostic Enabled c) FPPM Diagnostic serial data received d) Run_Crank Ignition Switch Position Circuit Voltage	a) == FCBR ECM FPPM Sys b) == TRUE c) == TRUE d) > 0.00 Volts	64 failures / 80 samples 1 sample / 12.5 millisec	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Communication Error with Active Grill Air Shutter Module “B”	P151F	This DTC monitors for an internal error or error in communication with the Active Grill Air Shutter Module B	Communication of the Alive Rolling Count from the Shutter Module B over LIN bus is incorrect or the Shutter Module B signals has an internal error for out of total samples	 >= 8.00 counts >= 10.00 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	LIN bus communication executes in 500ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Adaptive Cruise Control Signal Circuit	P1553	Detects rolling count or protection value errors in Adaptive Cruise Control Axle Torque Command serial data signal	If x of y rolling count / protection value faults occur, disable adaptive cruise control for duration of fault		Adaptive Cruise Control Command Serial Data Error Diagnostic Enable	1.00	9 / 17 counts	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Torque Command Circuit	P15F2	This DTC monitors for an error in communication with the Hybrid Commanded Engine Torque Signal	Communication of the Alive Rolling Count or Protection Value for the the Hybrid Commanded Engine Torque Signal over CAN bus is incorrect for out of total samples	>= 8.00 counts >= 10.00 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 10ms loop.	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Drive Motor Torque Delivered Circuit	P15F4	This DTC monitors for an error in communication with the Drive Motor Torque Delivered Signal	Communication of the Alive Rolling Count or Protection Value of the Drive Motor Torque Delivered Signal over CAN bus is incorrect for out of total samples	>= 10.00 counts >= 16.00 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 10ms loop.	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Control Speed Request Circuit Signal Message Counter Incorrect	P15F9	This DTC monitors for an error in communication with the Speed Request signal in $281	Communication of the Alive Rolling Count or Protection Value in the Speed Request signal over CAN bus is incorrect for out of total samples	>= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 25ms loop.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Signal Message Counter Incorrect	P15FB	Detects rolling count or protection value errors in Chassis Brake Pedal Position Emissions Related serial data signal	If x of y rolling count / protection value faults occur, default brake pedal positiion to zero for duration of fault		Chassis Brake Pedal Position Emissions Related Serial Data Error Diagnostic Enable	1.00	9.00 / 17.00 counts	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Powertrain Control Module (HPC) 2 Requested MIL Illumination	P1E00	Monitors the HPC 2 MIL request message to determine when the HPC has detected a MIL illuminating fault.	HPC 2 Module Emissions-Related DTC set and module is requesting MIL	HPC 2 Module Emissions-Related DTC set and module is requesting MIL		Time since power-up ≥ 3 seconds	Continuous	Type A, No MIL

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Chassis Control Module 1 Requested MIL Illumination	P26C8	Monitors the Chassis Contol Module 1 MIL request message to determine when the Chassis Control Module 1 has detected a MIL illuminating fault.	Chassis Control Module 1 Emissions-Related DTC set and module is requesting MIL	Chassis Control Module 1 Emissions-Related DTC set and module is requesting MIL		Time since power-up ≥ 3 seconds	Continuous	Type A, No MIL

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Chassis Control Module A	U012A	This DTC monitors for a loss of communication with the Chassis Control Module A.	Message is not received from controller for Message $4DB	≥ 10.0 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Run/Crank Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 5.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for	 Not Active on Current Key Cycle Enabled Not Active Not Active > 6.41 Volts = run = 1 (1 indicates enabled) = Active > 11.00 Volts > 0.4000 seconds	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					U012A CHCM A	Not Active on Current Key Cycle is present on the bus		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Power Steering Control Module	U0131	This DTC monitors for a loss of communication with the Power Steering Control Module	Message is not received from controller for Message $1E5	 ≥ 10.0 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Run/Crank Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 5.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for	 Not Active on Current Key Cycle Enabled Not Active Not Active > 6.41 Volts = run = 1 (1 indicates enabled) = Active > 11.00 Volts > 0.4000 seconds	Diagnostic runs in 12.5 ms loop	Type C, No SVS "Safety Emissions Neutral Diagnostic"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					U0131 Power Steering Control Module	Not Active on Current Key Cycle is present on the bus		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication with Active Grill Air Shutter Module B	U0285	This DTC monitors for a loss of communication on the LIN bus with Shutter Module B	ECM has lost communication over the LIN bus with Device 1 / Shutter 2 for	>= 3.00 counts	The following criteria have been enabled for Power Mode Run/Crank Voltage	>= 400.00 milliseconds =Run >= 11.00 Volts	LIN bus communication executes in 500ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Hybrid Powertrain Control Module	U0293	This DTC monitors for a loss of communication with the Hybrid Powertrain Control Module.	Message is not received from controller for Message $0B4 Message $0D3 Message $186 Message $1DF Message $3C1	 ≥ 10.0 seconds ≥ 0.5 seconds ≥ 0.5 seconds ≥ 10.0 seconds ≥ 10.0 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Run/Crank Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 5.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for	 Not Active on Current Key Cycle Enabled Not Active Not Active > 6.41 Volts = run = 1 (1 indicates enabled) = Active > 11.00 Volts > 0.4000 seconds	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					U0293 Hybrid Powertrain Control Module	Not Active on Current Key Cycle is present on the bus		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Hybrid Powertrain Control Module B	U179A	This DTC monitors for a loss of communication with the Hybrid Powertrain Control Module B	Message is not received from controller for	≥ 10.0 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Run/Crank Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 5.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is	 Not Active on Current Key Cycle Enabled Not Active Not Active > 6.41 Volts = run = 1 (1 indicates enabled) = Active > 11.00 Volts	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					not active for U179A Hybrid Powertrain Control Module B	> 0.4000 seconds Not Active on Current Key Cycle is present on the bus		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Hybrid Powertrain Control Module on Bus B	U1817	This DTC monitors for a loss of communication with the Hybrid Powertrain Control Module on Bus B	Message is not received from controller for Message $0A7 Message $1E3 Message $281	 ≥ 10.0 seconds ≥ 10.0 seconds ≥ 0.5 seconds	General Enable Criteria: U0074 Normal CAN transmission on Bus B Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Run/Crank Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 5.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for	 Not Active on Current Key Cycle Enabled Not Active Not Active > 6.41 Volts = run = 1 (1 indicates enabled) = Active > 11.00 Volts > 0.4000 seconds	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					U1817 Hybrid Powertrain Control Module	Not Active on Current Key Cycle is present on the bus		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Hybrid Powertrain Control Module B on Bus B	U182D	This DTC monitors for a loss of communication with the Hybrid Powertrain Control Module B on Bus B	Message is not received from controller for Message $1D8 Message $3C5 Message $3DA Message $3FF Message $4C2	 ≥ 0.5 seconds ≥ 10.0 seconds ≥ 10.0 seconds ≥ 10.0 seconds ≥ 10.0 seconds	General Enable Criteria: U0074 Normal CAN transmission on Bus B Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Run/Crank Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 5.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for	 Not Active on Current Key Cycle Enabled Not Active Not Active > 6.41 Volts = run = 1 (1 indicates enabled) = Active > 11.00 Volts > 0.4000 seconds	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					U182D Hybrid Powertrain Control Module B (VICM)	Not Active on Current Key Cycle is present on the bus		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Lost Communication with ECM [FPPM applications only]	U2616	To detect lost serial data communication from the power driver controller to the ECM	Timer - Fuel System Control message not received (FPPM Received Data Communication Status)	t > 10 s (Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate)	a) Chassis Fuel Pres Sys Type configuration selection b) Diagnostic Enabled c) Diagnostic System Disabled condition d) FPPM Control Alive Rolling Count Faulted e) FPPM serial data received [$0CE] f) Run_Crank Input Circuit Voltage g) Run_Crank Ignition Switch Position status h) Sensor Bus Relay On	a) == FCBR ECM FPPM Sys b) == TRUE c) <> True d) <> True e) == TRUE f) > 7.00 volts g) == TRUE h) == TRUE	64.00 failures / 80.00 samples 1 sample / 12.5 millisec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)-Camshaft Position (CMP) Correlation Bank 1 Sensor B (end-park phaser)	P0017	Detects cam to crank misalignment by monitoring if the cam sensor pulse for bank 1 sensor B occurs during the incorrect crank position, diagnostic passes when the cam sensor pulse is in the expected range	4 cam sensor pulses less than or greater than nominal position in one cam revolution..	-7.9 Crank Degrees 12.1 Crank Degrees	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic Delay diagnostic if Engine RPM and Cam is Enabled for	 CrankSensor_FA P0365, P0366 < 1.0 seconds > 8,200.00 < 3.00	2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table **P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold** . One sample per cam rotation	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve A Control Circuit	P0033	Controller specific output driver circuit diagnostic, diagnosing the 'compressor recirculation valve 'A' actuator' low sided driver for an open circuit failure, when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. In series applications, turbocharger 'A' is the first turbocharger in the direction of exhaust flow. In parallel applications, turbocharger 'A' is associated with engine bank 1.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between output and controller ground	Diagnostic enabled ********** Powertrain relay voltage ********** Engine does not crank Diagnostic system not disabled	True ********** >= 11.0 Volts **********	80 failures out of 100 samples PWM CRV: 100ms / sample eCRV: 12.5ms / sample	Type A, 1 Trips Note: In certain controllers P0034 may also set turbo/ super charger bypass valve control circuit low

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve A Control Circuit Low	P0034	Controller specific output driver circuit diagnostic, diagnosing the 'compressor recirculation valve 'A' actuator' low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. In series application, turbocharger 'A' is the first turbocharger in the direction of exhaust flow. In parallel applications, turbocharger 'A' is associated with engine bank 1.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground. In certain controllers this diagnosis runs only when the HWIO-output is driven by the application S/W.	≤ 0.5 Ω impedance between output and controller ground	Diagnostic Enabled ********** Powertrain relay voltage ********** Engine does not crank Diagnostic system not disabled	True ********** >= 11.0 Volts **********	80 failures out of 100 samples PWM CRV: 100ms / sample eCRV: 12.5ms / sample	Type A, 1 Trips Note: In certain controllers P0033 may also set turbo/ super charger bypass balve control circuit

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve A Control Circuit High	P0035	Controller specific output driver circuit diagnostic, diagnosing the 'compressor recirculation valve 'A' actuator' low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds. In series application, turbocharger 'A' is the first turbocharger in the direction of exhaust flow. In parallel applications, turbocharger 'A' is associated with engine bank 1.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power. In certain controllers this diagnosis runs only when the HWIO-output is driven by the application S/W.	≤ 0.5 Ω impedance between output and controller power.	Diagnostic enabled ********** Powertrain relay voltage ********** Engine does not crank Diagnostic system not disabled	True ********** >= 11.0 Volts **********	80 failures out of 100 samples PWM CRV: 100ms / sample eCRV: 12.5ms / sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Circuit Performance (applications with humidity sensor and manifold temperature sensor)	P0096	Detects an Intake Air Temperature 2 (IAT2) sensor value that is stuck in range by comparing the IAT2 sensor value against the IAT and IAT3 sensor values and failing the diagnostic if the IAT2 value is more different than the IAT and IAT3 values than is expected. If the engine has been off for a long enough period of time, the air temperature values in the engine compartment of the vehicle are considered to have equalized, and the diagnostic can be enabled. The diagnostic will fail if the IAT and IAT3 values are similar, and the IAT2 value is not similar to the IAT and IAT3 values. The diagnostic will also fail if none of the three sensor values are similar to each other, and the IAT2 value is furthest from the sensor value that is in the middle of the three sensor values. This diagnostic is executed once per	**Good Correlation Between IAT and IAT3:** ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up IAT - Power Up IAT3) AND ABS(Power Up IAT2 - Power Up IAT3)	 > 30 deg C <= 25 deg C > 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	 > 28,800 seconds >= 11.0 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips
			Not Good Correlation, IAT in middle: Power Up IAT is between Power Up IAT2 and Power Up IAT3 AND ABS(Power Up IAT2 - Power Up IAT3) AND ABS(Power Up IAT - Power Up IAT2) > ABS(Power Up IAT - Power Up IAT3)	 > 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	 > 28,800 seconds >= 11.0 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error	Executes once at the beginning of each ignition cycle if enable conditions are met	
			Not Good Correlation, IAT3 in middle: Power Up IAT3 is between Power Up IAT and Power Up IAT2		Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time	 > 28,800 seconds >= 11.0 Volts >= 0.9 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		ignition cycle if the enable conditions are met.	AND ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up IAT3 - Power Up IAT2) > ABS(Power Up IAT3 - Power Up IAT)	> 30 deg C	No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Pressure Measurement System - Multiple Sensor Correlation (single turbo)	P00C7	Detects an inconsistency between pressure sensors in the induction system in which a particular sensor cannot be identified as the failed sensor. If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The Manifold Pressure (MAP), Turbocharger Boost Pressure and Barometric Pressure (BARO) sensors values are checked to see if they are within the normal expected atmospheric pressure range. If they are, then MAP, Turbocharger Boost Pressure and BARO are compared to see if their values are similar. If two of these three sensors are similar, but the third is not, then a performance diagnostic for the specific sensor with the dissimilar value will fail. If there is no combination of two of	ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure) OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure) OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure) OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold	> 10.0 kPa <= 10.0 kPa <= 10.0 kPa <= 10.0 kPa > 10.0 kPa <= 10.0 kPa <= 10.0 kPa <= 10.0 kPa > 10.0 kPa > 10.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating Manifold Pressure Manifold Pressure Baro Pressure Baro Pressure Turbocharger Boost Pressure Turbocharger Boost Pressure No Active DTCs: No Pending DTCs:	> 10.0 seconds >= 50.0 kPa <= 115.0 kPa >= 50.0 kPa <= 115.0 kPa >= 50.0 kPa <= 115.0 kPa EngineModeNotRunTimer Error MAP_SensorFA AAP_SnsrFA AAP2_SnsrFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP	4 failures out of 5 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		these three sensors that is similar, then the failed sensor cannot be uniquely identified. The Multiple Pressure Sensor Correlation Diagnostic will fail in this case.	Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	> 10.0 kPa > 10.0 kPa				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (single turbo)	P0101	Detects a performance failure in the Mass Air Flow (MAF) sensor, such as when a MAF value is stuck in range. This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Manifold Pressure (MAP) sensor, Turbocharger Boost Pressure sensor and Throttle Position sensor (TPS). These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the MAF sensor. In this case, the MAF Performance diagnostic	See table **P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix** for combinations of model failures that can set this DTC. MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		will fail.	Measured TIAP - measured MAP - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset** OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset** TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time High Engine Air Flow is TRUE when Mass Air Flow -	> 24.0 kPa > 24.0 kPa > 1.0 seconds > 1.0 seconds > a threshold in gm/sec as a function of engine speed. See table	No Active DTCs: No Pending DTCs:	MAP Model 2 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP Model 3 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM** TIAP Model 1 Error multiplied by **P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM** Filtered Throttle Model Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM** MAP_SensorCircuitFA EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow		MnfdTempSensorCktFP		
			AND Manifold Pressure	> a threshold in kPa as a function of engine speed. See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP**				
			AND Filtered Mass Air Flow - Mass Air Flow	< 3.0 gm/sec				
			Low Engine Air Flow is TRUE when Mass Air Flow	< a threshold in gm/sec as a function of engine speed. See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow**				
			AND Manifold Pressure	< a threshold in kPa as a function of engine speed. See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP**				
			AND Mass Air Flow - Filtered Mass Air Flow	< 2.0 gm/sec				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (single turbo)	P0106	Detects a performance failure in the Manifold Pressure (MAP) sensor, such as when a MAP value is stuck in range. If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The MAP sensor value is checked to see if it is within the normal expected atmospheric pressure range. If it is not, then the MAP performance diagnostic will fail. If the MAP sensor value is within the normal expected atmospheric range, then MAP, Turbocharger Boost Pressure, and Barometric Pressure (BARO) are compared to see if their values are similar. If the Turbocharger Boost Pressure and BARO sensor values are similar, but the MAP value is not similar, then a MAP performance diagnostic will fail.	**Engine Running:** See table **P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix** for combinations of model failures that can set this DTC. MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		The engine running portion of this diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Mass Air Flow (MAF) sensor, Turbocharger Boost Pressure sensor and Throttle Position sensor (TPS). These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the MAP sensor. In this case, the MAP Performance diagnostic will fail.	AND Measured TIAP - measured MAP - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset** OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset** TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time High Engine Air Flow is TRUE when Mass Air Flow -	> 24.0 kPa > 24.0 kPa > 1.0 seconds > 1.0 seconds > a threshold in gm/sec as a function of engine speed See table	No Active DTCs: No Pending DTCs:	multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP Model 3 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM** TIAP Model 1 Error multiplied by **P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM** Filtered Throttle Model Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM** MAP_SensorCircuitFA EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow		MnfdTempSensorCktFP		
			AND Manifold Pressure	> a threshold in kPa as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP**				
			AND Filtered Mass Air Flow - Mass Air Flow	< 3.0 gm/sec				
			Low Engine Air Flow is TRUE when Mass Air Flow	< a threshold in gm/sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow**				
			AND Manifold Pressure	< a threshold in kPa as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP**				
			AND Mass Air Flow - Filtered Mass Air Flow	< 2.0 gm/sec				
			Engine Not Rotating: Manifold Pressure	< 50.0 kPa	Time between current ignition cycle and the last time the engine was		4 failures out of 5 samples	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR Manifold Pressure OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	 > 115.0 kPa > 10.0 kPa > 10.0 kPa <= 10.0 kPa	running Engine is not rotating No Active DTCs: No Pending DTCs:	> 10.0 seconds EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA AAP2_SnsrCktFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP	1 sample every 12.5 msec	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Performance (applications with humidity sensor and manifold temperature sensor)	P0111	Detects an Intake Air Temperature (IAT) sensor value that is stuck in range by comparing the IAT sensor value against the IAT2 and IAT3 sensor values and failing the diagnostic if the IAT value is more different than the IAT2 and IAT3 values than is expected. If the engine has been off for a long enough period of time, the air temperature values in the engine compartment of the vehicle are considered to have equalized, and the diagnostic can be enabled. The diagnostic will fail if the IAT2 and IAT3 values are similar, and the IAT value is not similar to the IAT2 and IAT3 values. The diagnostic will also fail if none of the three sensor values are similar to each other, and the IAT value is furthest from the sensor value that is in the middle of the three sensor values. This diagnostic is executed once per	**Good Correlation Between IAT2 and IAT3** ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up IAT - Power Up IAT3) AND ABS(Power Up IAT2 - Power Up IAT3)	 > 30 deg C > 25 deg C <= 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	 > 28,800 seconds >= 11.0 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips
			Not Good Correlation, IAT2 in Middle: Power Up IAT2 is between Power Up IAT and Power Up IAT3 AND ABS(Power Up IAT - Power Up IAT3) AND ABS(Power Up IAT2 - Power Up IAT) > ABS(Power Up IAT2 - Power Up IAT3)	 > 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	 > 28,800 seconds >= 11.0 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error	Executes once at the beginning of each ignition cycle if enable conditions are met	
			Not Good Correlation, IAT3 in Middle: Power Up IAT3 is between Power Up IAT and Power Up IAT2		Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time	 > 28,800 seconds >= 11.0 Volts >= 0.9 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		ignition cycle if the enable conditions are met.	AND ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up IAT3 - Power Up IAT) > ABS(Power Up IAT3 - Power Up IAT2)	> 30 deg C	No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (single turbo)	P0121	Detects a performance failure in the Throttle Position sensor (TPS) sensor, such as when a TPS value is stuck in range. This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Manifold Pressure (MAP) sensor, Turbocharger Boost Pressure sensor and Mass Air Flow (MAF) sensor. These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the TPS sensor. In this case, the TPS	See table **P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix** for combinations of model failures that can set this DTC. MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP -	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Performance diagnostic will fail.	measured MAP - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset** OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset** TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time High Engine Air Flow is TRUE when Mass Air Flow AND	> 24.0 kPa > 24.0 kPa > 1.0 seconds > 1.0 seconds > a threshold in gm sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow**	No Active DTCs: No Pending DTCs:	MAP Model 2 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP Model 3 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM** TIAP Model 1 Error multiplied by **P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM** Filtered Throttle Model Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM** MAP_SensorCircuitFA EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Manifold Pressure AND Filtered Mass Air Flow - Mass Air Flow Low Engine Air Flow is TRUE when Mass Air Flow AND Manifold Pressure AND Mass Air Flow - Filtered Mass Air Flow	> a threshold in kPa as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP** < 3.0 gm/sec < a threshold in gm sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow** < a threshold in kPa as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP** < 2.0 gm/sec		MnfdTempSensorCktFP		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 1 (For use with WRAF - E80	P0131	This DTC determines if the WRAF O2 sensor signal circuit is shorted low. This DTC will detect a short to ground fault to the Pump Current, Reference Cell Voltage and Reference Ground circuits. When enabled, the diagnostic monitors the three different failure counters it receives from the WRAF Application-Specific Integrated Circuit (ASIC). The individual diagnostic failure counters are incremented based on the message received from the ASIC. The DTC is set based on any of the three individual fail and sample counters.	B1S1 WRAF ASIC indicates a ground short to any of the following WRAF signals: A) Pump Current - short to ground fail counts are accumulated to determine fault status. B) Reference Cell Voltage - short to ground fail counts are accumulated to determine fault status. C) Reference Ground - short to ground fail counts are accumulated to determine fault status. <u>Note</u>: This ASIC is referred to as C2WRAF (Delphi). <u>Note</u>: A ground short on the Pump Current or Reference Voltage signal may also set a P223C DTC.	The ASIC provides a fault indication when the pump current pin is between -150 mV and +175 mV. The ASIC provides a fault indication when the Refernce Cell Voltage pin < 225 mV. The ASIC provides a fault indication when during the intrusive test the Reference Cell impedance change is ≤ 90 ohms. <u>Note</u>: Signal A & B faults must exist for 24 ASIC clock cycles to qualify for a fail flag. The three fault signals have individual X out of Y calibrations. When the X out of Y is reached in any region this DTC is set.	B1S1 DTC's Not active this key cycle Measure Valid status (ASIC) Controller status (ASIC) Engine Run or Auto stop WRAF Ref cell temperature ********** Heater Warm-up delay Then WRAF circuit diagnostic delay (since heater Warm-up delay is complete) **********	P0135, P0030, P0031 or P0032 = Valid = Ready = True ≥ 628 Deg C = Complete ≥ 20.0 seconds	Signal A: 128 failures out of 160 samples OR Signal B: 128 failures out of 160 samples OR Signal C: 3 failures out of 1 samples Frequency for Signal A & B: Continuous in 25 milli - second loop Frequency for Signal C: Tested during an intrusive event performed every 60 seconds. During each event the impedance is measured 3 times once every 12.5 msec. Note: If the fail count value is greater than the sample count value that individual	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							monitor is disabled.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 1 (For use with WRAF - E80	P0132	This DTC determines if the WRAF O2 sensor signal circuit is shorted high. This DTC will detect a short to power fault to the Pump Current (and Trim circuit), Reference Cell Voltage and Reference Ground circuit. When enabled, the diagnostic monitors the three different failure counters it receives from the WRAF Application-Specific Integrated Circuit (ASIC). The individual diagnostic failure counters are incremented based on the message received from the ASIC. The DTC is set based on any of the three individual fail and sample counters.	B1S1 WRAF ASIC indicates a short to power on any of the following WRAF signals: A) Pump Current - short to power fail counts are accumulated to determine fault status. B) Reference Cell Voltage - short to power fail counts are accumulated to determine fault status. C) Reference Ground - short to power fail counts are accumulated to determine fault status. Note: This ASIC is referred to as C2WRAF (Delphi).	The ASIC provides a fault indication when the pump current pin > 2.8 V. The ASIC provides a fault indication when the Reference Cell Voltage pin > 3.3 V. The ASIC provides a fault indication when the Reference Ground pin > 225 mV. Note: The above faults must exist for 21 ASIC clock cycles to qualify for a fail flag. The three fault signals have individual X out of Y calibrations. When the X out of Y is reached in any region this DTC is set.	B1S1 DTC's Not active this key cycle Measure Valid Status (ASIC) Controller status (ASIC) Engine Run or Auto stop WRAF Ref cell temperature ********** Heater Warm-up delay Then WRAF circuit diagnostic delay (since heater Warm-up delay is complete) **********	P0135, P0030, P0031 or P0032 = Valid = Ready = True ≥ 628 Deg C = Complete ≥ 20.0 seconds	Signal A: 128 failures out of 160 samples OR Signal B: 128 failures out of 160 samples OR Signal C: 128 failures out of 160 samples Frequency: Continuous in 25 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0137	This DTC determines if the O2 sensor signal circuit is shorted low. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold. The diagnostic failure counter is incremented if the O2S signal is below the threshold value. This DTC is set based on the fail and sample counters.	Oxygen Sensor Signal	< 50 mvolts	No Active DTC's

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All Fuel Injectors for active Cylinders Fuel Condition Ethanol Estimation in Progress Fuel State All of the above met for	Enabled (On) Ethanol ≤ 87 % = Not Active (Please see "**Ethanol Estimation in Progress**" in Supporting Tables). DFCO not active > 5.0 seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0138	This DTC determines if the O2 sensor signal circuit is shorted high or open. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold. The diagnostic failure counter is incremented if the O2S signal is above the threshold value. This DTC is set based on the fail and sample counters.	Oxygen Sensor Signal	> 1,050 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Low Fuel Condition Only when FuelLevelDataFault ********** Secondary delay after above conditions are complete (cold start condition) Secondary delay after above conditions are complete (not cold start condition) Commanded Equivalence Ratio ********** All of the above met for	TPS_ThrottleAuthorityDefaulted MAF_SensorFA MAP_SensorFA EvapExcessPurgePsbl_FA FuelInjectorCircuit_FA Ethanol Composition Sensor FA AIR System FA 10.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds = False = False ********** > 175.0 seconds when engine soak time > 28,800 seconds > 175.0 seconds when engine soak time ≤ 28,800 seconds ≤ 1.040 EQR ********** > 5.0 seconds	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0141	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit. This test compares the measured heater current (monitored thru the low side driver) and compares it to the expected values (over the voltage range provided) for the released sensor. The diagnostic failure counter is incremented if the heater current is outside the expected range. This DTC is set based on the fail and sample counters.	Heater Current outside of the expected range of	0.3 > amps > 2.5	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA > 10.0 Volts = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 3 tests per trip 30 seconds delay between tests and 1 second execution rate.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Control Module (FPCM) Requested MIL Illumination	P069E	Monitors the FPCM MIL request message to determine when the FPCM has detected a MIL illuminating fault.	Fuel Pump Control Module Emissions-Related DTC set and module is requesting MIL	Fuel Pump Control Module Emissions-Related DTC set and module is requesting MIL		Time since power-up ≥ 3 seconds	Continuous	Type A, No MIL

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #5 Circuit	P06D2	Detects a continuous or intermittent short on the 5 volt reference circuit #5 by monitoring the reference percent Vref5 and failing the diagnostic when the percent Vref5 is too low or too high or if the delta between the filtered percent Vref5 and non-filtered percent Vref5 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref5 < or ECM percent Vref5 > or the difference between ECM filtered percent Vref5 and percent Vref5 >	4.875 % Vref5 5.125 % Vref5 0.0495 % Vref5	Diagnostic enabled AND [(Run/Crank voltage for Time period AND Starter engaged) OR (Run/Crank voltage AND Starter engaged)]	= 1 > 6.41 Volts = 0.02 Seconds = FALSE > 8.41 Volts = TRUE	19 / 39 counts; or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Temperature Sensor Circuit High	P105B	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P105B diagnoses the ESC temperature sensor for out of range high circuit faults. The diagnostic failure counter is incremented if the ESC temperature information is below the threshold value. This DTC is set based on the fail and sample counters.	Stop-Start capacitor temperature value	< -60.0 ºC	No active DTCs Diagnostic reporting is enabled when the following two steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Afterwards, this diagnostic runs continuously.	U135C, U1347, P1066 = TRUE > 0.50 sec	10 failure out of 14 samples 500ms cycle time continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Temperature Sensor Circuit Low	P105C	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P105C diagnoses the ESC temperature sensor for out of range low circuit faults. The diagnostic failure counter is incremented if the ESC temperature information is above the threshold value. This DTC is set based on the fail and sample counters.	Stop-Start capacitor temperature value	> 180.0 ºC	No active DTCs Diagnostic reporting is enabled when the following two steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Afterwards, this diagnostic runs continuously.	U135C, U1347, P1066 = TRUE > 0.50 sec	10 failure out of 14 samples 500ms cycle time Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Temperature Sensor Not Plausible	P105D	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P105D diagnoses the ESC temperature sensor for rationality faults by comparing it to other temperature sensors after a soak time (to allow all sensors to reach ambient condition). The diagnostic fails if the absolute ESC temperature difference when compared to the other temperature sensors is above the threshold value.	Absolute value of temperature difference between capacitor and DCDC converter AND Absolute value of temperature difference between capacitor and capacitor switch (K2)	> 20.0 ºC > 20.0 ºC	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) ECM off time Then, (B) LIN bus wake up Then, (C) ESCM wake up delay Note: This is not a continuous diagnositc. It runs once at LIN bus wake up, after ECM off time is large enough.	U135C, U1347, P1066 > 28,800 sec = TRUE > 0.50 sec	Wake up test only. Fault is set at first detection.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module DCDC Converter Temperature Sensor Circuit High	P105E	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P105E diagnoses the DCDC Converter (inside the ESCM) temperature sensor for out of range high circuit faults. The diagnostic failure counter is incremented if the DCDC temperature information is below the threshold value. This DTC is set based on the fail and sample counters.	DCDC converter temperature	< -50.0 ºC	No active DTCs Diagnostic reporting is enabled when the following two steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Afterwards, this diagnostic runs continuously.	U135C, U1347, P1066 = TRUE > 0.50 sec	10 failure out of 14 samples 500ms cycle time continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module DC/ DC Converter Temperature Sensor Circuit Low	P105F	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P105F diagnoses the DCDC Converter (inside the ESCM) temperature sensor for out of range low circuit faults. The diagnostic failure counter is incremented if the DCDC temperature information is above the threshold value. This DTC is set based on the fail and sample counters.	DCDC converter temperature	> 160.0 ºC	No active DTCs Diagnostic reporting is enabled when the following two steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Afterwards, this diagnostic runs continuously.	U135C, U1347, P1066 = TRUE > 0.50 sec	10 failure out of 14 samples 500ms cycle time continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module DC/ DC Converter Temperature Sensor Not Plausible	P1060	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1060 diagnoses the DCDC Converter (inside the ESCM) temperature sensor for rationality faults by comparing it to other temperature sensors after a soak time (to allow all sensors to reach ambient condition). The diagnostic fails if the absolute DCDC Converter temperature difference when compared to the other temperature sensors is above the threshold value.	The absolute value of temperature difference between DCDC converter and capacitor. AND The absolute value of temperature difference between DCDC converter and capacitor switch (K2).	> 20.0 ºC > 20.0 ºC	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) ECM off time Then, (B) LIN bus wake up Then, (C) ESCM wake up delay Note: This is not a continuous diagnositc. It runs once at LIN bus wake up, after ECM off time is large enough.	U135C, U1347, P1066 > 28,800 sec = TRUE > 0.50 sec	Wake up test only. Fault is set at first detection.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Secondary Switch Temperature Sensor Circuit High	P1061	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1061 diagnoses the Secondary Switch (K2) (inside the ESCM) temperature sensor for out of range high circuit faults. The diagnostic failure counter is incremented if the Secondary Switch temperature information is below the threshold value. This DTC is set based on the fail and sample counters.	Capacitor switch (K2) temperature	< -50.0 ºC	No active DTCs Diagnostic reporting is enabled when the following two steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Afterwards, this diagnostic runs continuously.	U135C, U1347, P1066 = TRUE > 0.50 sec	10 failure out of 14 samples 500ms cycle time continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Secondary Switch Temperature Sensor Circuit Low	P1062	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1062 diagnoses the Secondary Switch (K2) (inside the ESCM) temperature sensor for out of range low circuit faults. The diagnostic failure counter is incremented if the Secondary Switch temperature information is above the threshold value. This DTC is set based on the fail and sample counters.	The capacitor switch (K2) temperature	> 160.0 ºC	No active DTCs Diagnostic reporting is enabled when the following two steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Afterwards, this diagnostic runs continuously.	U135C, U1347, P1066 = TRUE > 0.50 sec	10 failure counts out of 14 samples 500ms cycle time continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Secondary Switch Temperature Sensor Not Plausible	P1063	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1063 diagnoses the Secondary Switch (K2) (inside the ESCM) temperature sensor for rationality faults by comparing it to other temperature sensors after a soak time (to allow all sensors to reach ambient condition). The diagnostic fails if the absolute Secondary Switch (K2) temperature difference when compared to the other temperature sensors is above the threshold value.	The absolute value of temperature difference between the capacitor switch (K2) and the capacitor. AND The absolute value of tempeature difference between the capacitor switch (K2) and DCDC converter.	> 20.0 ºC > 20.0 ºC	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) ECM off time Then, (B) LIN bus wake up Then, (C) ESCM wake up delay Note: This is not a continuous diagnositc. It runs once at LIN bus wake up, after ECM off time is large enough.	U135C, U1347, P1066 > 28,800 sec = TRUE > 0.50 sec	Wake up test only. Fault is set at first detection.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System Voltage Low During Start Assist	P1064	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1064 diagnoses the assist system by monitoring the system voltage during an auto start event. Note: in some cases it averages over multiple auto start events for improved robustness. The diagnostic fails if the calibrated diagnostic method does not satisfy the corresponding threshold value.	The diagnostic method is selected from method (A) or (B) below. The two methods are: Method (A) = CeUCCD_e_UseGrd OR Method (B) = CeUCCD_e_UseDeltaVlt The method used on this application is ********** Method (A) - The average system voltage during an assisted auto start is Method (B) - The average system voltage delta during an assisted auto start is	 = CeUCCD_e_UseDeltaVlt ********** ≤ 9.00 V > 1.50 V	No active DTCs Low Fuel Condition Diag Fuel Level Data Fault ECT (Or OBD Coolant Enable Criteria Auto start is commanded from an auto stop state	U135C, U1347, P1066, UCAP_RmdlActFltFA UCAP_TempOOR_FA UCAP_TempRatFA ECT_Sensor_Ckt_FA ECT_Sensor_Perf_FA = FALSE = FALSE > 30.0 ºC = TRUE) = TRUE	Diagnostic runs when auto start is commaned from an auto stop state. Minimum auto stop time > 1.00 sec The test result average is calculated using data from 3 auto start events.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Charging Current Performance	P1065	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1065 diagnoses the ESS charging system by monitoring the capacitor voltage while the engine is running and comparing it to the expected voltage target value. The diagnostic failure counter is incremented if the ESC voltage is below the threshold value based on the temperature derating level. This DTC is set based on the fail and sample counters.	The diagnostic measures the capacitor voltage and compares it to a calibration value that is specific to the temperature derating level . ********** Derating level 0 Capacitor temperature Capacitor voltage threshold to arm the auto start ********** Derating level 1 Capacitor temperature Capacitor voltage threshold ********** Derating level 2 Capacitor temperature Capacitor voltage threshold **********	********** -40.0 ºC < capacitor temperature < 55.0 ºC ≤ Refer to **P1065_UCAP_Arm_Autostart_Thresh_Derating_Zero** in the Supporting Tables tab. ********** 55.0 ºC ≤ capacitor temperature < 61.0 ºC ≤ 2.70 V ********** 61.0 ºC ≤ capacitor temperature < 73.0 ºC ≤ 2.20 V **********	No active DTCs ECT (Or OBD Coolant Enable Criteria Engine run No change of the capacitor derating level during the test Capacitor temperature Delay period before accumulating fails (allows time for caps to charge)	U135C, U1347, P1066, UCAP_RmdlActFltFA UCAP_TempOOR_FA UCAP_TempRatFA ECT_Sensor_Ckt_FA ECT_Sensor_Perf_FA > 30.0 ºC = TRUE) = TRUE = TRUE -40.0 ºC < capacitor temperature < 73.0 ºC = 20.0 seconds	320 failures out of 400 samples 500ms cycle time Continuously runs when enable conditions are met.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Status Message Counter Incorrect (UltraCap)	P1066	This DTC monitors for an error in communication with the Stop-Start Capacitor Control Module Status Signals	Communication of the Alive Rolling Count or Protection Value of the Current Status from the UltraCap over LIN bus is incorrect for out of total samples Or Communication of the Alive Rolling Count or Protection Value of the Part Number from the UltraCap over LIN bus is incorrect for out of total samples Or Communication of the Alive Rolling Count or Protection Value of the Temperature Fault from the UltraCap over LIN bus is incorrect for out of total samples Or Communication of the Alive Rolling Count or Protection Value of the Temperature Status Fault from the UltraCap over	 >= 8.00 counts >= 10.00 counts >= 8.00 counts >= 10.00 counts >= 8.00 counts >= 10.00 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 10ms loop.	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			LIN bus is incorrect for out of total samples	>= 8.00 counts >= 10.00 counts				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Performance	P1067	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1067 diagnoses the ESCM performance by monitoring five specific fault cases. P1067 Indicates one or more of the following faults have occured: Case 1: The ground switch (K1) current sensor is faulty. Case 2: The capacitor switch (K2) current sensor is faulty. Case 3: The onboard voltages indicate a faulty voltage regulator. Case 4: The analog input circuits are faulty. Case 5: The capacitor voltage sensor is stuck at maximum. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	Case 1: The ground switch (K1) current is out of range	< -1330 amps OR > 1330 amps	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs continuously.	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.51 sec	Test cycle time is 5ms Error count increases by 10 if an error is detected, up to a maximum value of 200. Error count decreases by 1 if no error is detected, minimum value 0. Fault is set when error count = 200 (100ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type B, 2 Trips
			Case 2: The ground switch (K2) current is out of range	< -1330 amps OR > 1330 amps	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then,	U135C, U1347, P1066 = TRUE	Test cycle time is 5ms Error count increases by 10 if an error is detected, up to a maximum value of 200. Error count	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs continuously.	> 0.50 sec > 0.51 sec	decreases by 1 if no error is detected, minimum value 0. Fault is set when error count = 200 (100ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	
			Case 3: Internal Power Supplies 2.5 V Reference 5.0 V Linear regulator 15.0 V Boost regulator are not functional or out of range.	Correct range is: 2.5 V +/- 0.1% 5.0 V +/- 0.2 V 15.0 V +/- 1.0 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; ; or whenever fault state from ESCM changes its value	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.51 sec	Test cycle time is 5ms Error count increases by 100 if an error is detected, up to a maximum value of 200. Error count decreases by 1 if no error is detected, minimum value 0. Fault is set when error count = 200 (10 ms fault maturity) Fault is removed	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Afterwards, this diagnostic runs continuously.		when error count = 0. (1 sec healing time)	
			Case 4: The analog input circuits are faulty: Measured 2.5V Reference voltage of out of range, which is a indicator that the analog inputs to A/D converter are faulty	< 2.23 V OR > 2.78 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met: Internal Power Supplies DCDC	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.51 sec = OK = Not active	Test cycle time is 5ms Error count increases by 20 if an error is detected, up to a maximum value of 200. Error count decreases by 1 if no error is detected, minimum value 0. Fault is set when error count = 200 (50ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	
			Case 5: The measured capacitor voltage	≥ 5.86 V	No active DTCs Diagnostic reporting is enabled when the following three steps	U135C, U1347, P1066	Test cycle time is 10ms Error count increases by 10 if an error is	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs continuously.	 = TRUE > 0.50 sec > 0.51 sec	detected, up to a maximum value of 100. Error count decreases by 1 if no error is detected, minimum value 0. Fault is set when error count = 100 (100ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Deteriorated	P1068	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1068 diagnoses the ESC deteriation (end of life) by monitoring three specific fault cases. This DTC is set any of the three criteria met their respective thresholds.	Capacitance OR Equivalent serial resistance (ESR) OR Number of consecutive cycles in which one of the capacitor cells has a voltage 0.6V lower than the other.	< 480 Farads > 3.6 milliion Ohms = 10 times	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Note: This is not continuous diagnostic.	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.10 sec	The capacitance and ESR are calculated during state of health determination. Fault is set after first detection. Cell voltage difference is calculated after ESCM wake up. Fault is set after 10 consecutive detections. This is a persistent fault that can only be removed by service.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Voltage High	P1069	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1069 diagnoses the ESC voltage for out of range high faults. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	capacitor voltage	> 5.8 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs continuously.	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.51 sec	Test cycle time 10ms Error count increases by 2 if an error is detected, up to a maximum value of 100. Error count decreases by 1 if no error is detected, minimum value 0. Fault is set when error count = 100 (500ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Battery Negative Circuit Driver "A" and "B" Stuck Open	P106A	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P106A indicates that the ground switch (K1) is in a high impedance state. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	Voltage drop across the ground switch (K1) when current > 550 amps OR Voltage drop across the ground switch (K1) when current > 550 amps OR Voltage drop across the ground switch (K1) when current ≤ 550 amps OR Voltage drop across the ground switch (K1) when current ≤ 550 amps	< -0.8 V > 0.8 V < -0.4 V > 0.4 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the folloiwng conditions are met: Capacitor switch (K2) open Ground switch (K1) close is commanded	U135C, U1347, P1066 = TRUE > 0.50 sec > 1.01 sec = TRUE = TRUE	Test cycle time is 10ms. Error count increases by 1 if an error is detected, up to a maximum of 100. Error count decreases by 1 if no error is detected, up to a minimum of 0. Fault is set when error count = 100. (1 sec fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Ground Switches "A" or "B" Stuck Open	P106B	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P106B indicates that both banks of ground switch (K1) stuck open, cannot be closed. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	The ground switch (K1) flip-flop state. Note: flip-flop is a basic hardware component used by software to command the switch to open or close. K1 driver voltage bank A K1 driver voltage bank B	= stuck open < 10.46 V < 10.46 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met: Ground switch is commanded to close	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.05 sec = TRUE	Test cycle time is 5ms. Error count increases by 20 if an error is detected, up to a maximum of 200. Error count decreases by 1 if no error is detected, up to a minimum of 0. Fault is set when error count = 200. (50ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Charge Pump Performance	P106D	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P106D indicates that the charge pump (internal safety supply voltage) does not work correctly. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	The Internal safety supply voltage	< 11.23 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met, once per drive cyle: Capacitor voltage Authorization to support start	U135C, U1347, P1066 = TRUE > 0.50 sec > 1.10 sec ≥ 4.7 V = FALSE	Tested once per driving cycle. Needs enabling from SW: enable - wait 500ms - diagnose during 500 ms - disable. Test cycle time 10 ms. Error count increases by 10 if an error detection occurs up to a maximum of 100. Error count decreases by 1 if no error detection occurs up to a minimum of 0. Fault is set when error count = 100. (100ms fault maturity) Fault can only be removed in the next wake up, or by LIN message.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module State of Health Unkown	P106E	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P106E indicates that the ESCM has determined the ESC state of health as unknown. The DTC is set when enabled and the ESC state of health is not determined.	ESC state of health	= not determined.	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Note: This diagnostic runs once per trip.	U135C, U1347, P1066 = TRUE > 0.50 sec > 10.00 sec	Once per trip.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Self Test Incomplete	P106F	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P106F indicates that the ESCM self test has not been performed / completed for multiple consecutive trip cycles. The self test is performed during powerdown after trip completion. The DTC is set when the not performed / completed trip cycle counter is greater than the threshold.	Consecutive trip cycles in which the self-test has not been performed / completed	> 10 drive cycles	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Note: This diagnostic runs at wake up using information from previous power down.	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.03 sec	Wake up test only. Fault is set after first detection. Fault can be healed if the self test is performed / completed without errors in the last trip cycle.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Output Circuit	P1070	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1070 indicates that the ESC voltage output line is disconnected or the DCDC converter is defective. The DTC is set when: 1) The malfunction criteria mets the threshold value (Case 1 & 3) or, 2) The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value (Case 2).	Case 1: The capacitor voltage increase rate after 5s of charge	< 20 mV / s	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Note: This diagnostic runs at every charge when the following conditions are met: DCDC charging Capacitor voltage	U135C, U1347, P1066 = TRUE > 0.50 sec > 5.00 sec = Active > 0.5 V	First 5 seconds of each charge. Fault is set after first detetion. Once Fault is set, it will persist in the same driving cycle, and inhibit use of DCDC. Fault will be removed in the next wake up or by LIN message.	Type A, 1 Trips
			Case 2: Capacitor output voltage Capacitor (dual cell) mid point voltage	< 0.5 V > 0.8 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up	U135C, U1347, P1066 = TRUE	Test cycle time is 5ms. Error count increases by 10 if an error detection occurs up to a maximum	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs continuously.	 > 0.50 sec > 5.00 sec	of 100. Error count decreases by 1 if no error detection occurs up to a minimum of 0. Fault is set when error count = 100. (50ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	
			Case 3: The difference between the following items (A) and (B) (A) the sum of 3 Capacitor voltage samples (sampled with a 10ms reccurence after DCDC starts charging) (B) the Capacitor voltage sampled before starting the charge multiplied by 3	> 2.7 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM	U135C, U1347, P1066 = TRUE > 0.50 sec > 5.00 sec	First 30ms every time DCDC charging is active. Fault is set after first detetion. Once Fault is set, it will persist in the same driving cycle, and inhibit use of DCDC. Fault will be removed in the next wake up or by LIN message	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					changes its value Note: This diagnostic runs at every charge, when the following conditions met: DCDC charging	 = Active		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Read Only Memory Performance	P1071	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1071 indicates a failure of the ESCM ROM (flash program memory). The DTC is set when enabled and the ESCM ROM memory checksum does not match.	The calculated checksum across the ROM memory doesn't match the stored checksum computed during the build of the software.	checksum does not match.	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs continuously.	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.01 sec	10ms cycle time to scan a portion of ROM. The whole memory is scanned in less than 2.6 seconds. If fault is detected, perform a reset up to a predefined number of times (5 times). if this number has expired go to a Fail Safe State that can only be left by ECU powerdown Note: in Fail Safe State, LIN communication is on, K1 is closed, DCDC is off. Fault can only be removed in next wake up or by LIN message.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Random Access Memory Performance	P1072	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1072 indicates a failure of the ESCM RAM. The DTC is set when enabled and the ESCM RAM memory cell is stuck high or low.	An error is detected while testing the RAM.	RAM memory cell is stuck at high or low	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received. or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs continuously.	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.01 sec	10ms cycle time to scan a portion of RAM. The whole memory is scanned in less than 2.6 seconds. Fault is detected when one of the cells is not functioning correctly. If fault is detected, perform a reset up to a predefined number of times (5 times). If this number has expired go to a Fail Safe State that can only be left by ECU Powerdown Note: in Fail Safe State, LIN communication is on, K1 is closed, DCDC is off. Fault can only removed in next wake up or by	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							LIN message.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Long Term Memory Performance	P1073	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1073 indicates a failure of the ESCM EPROM. The DTC is set when enabled and the ESCM EPROM memory checksum does not match the stored value.	CRC checksum calculation of the non volatile memory blocks	The calculated CRC doesn't match the stored CRC	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Note: diagnostic runs at control module wake up.	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.10 sec	EEPROM is scanned at control module wake up. Fault is set at first detection. Fault can only be removed in next wake up, or by LIN message.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Long Term Memory Reset	P1074	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1074 indicates a failure of the ESCM long term mermory. The DTC is set when enabled and the ESCM reset counter mets / exceeds the threshold value.	unexpected reset counter	≥ 15 counts	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Note: diagnostic runs at capacitor control module wake up.	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.10 sec	Capacitor control module wake up test only. Each unexpected reset increments the Unexpected Resets counter by 3 up to a maximum of 15. Each expected reset decrements the conter by 1 up to a minimum of 0. Fault is set when the counter reaches 15. Fault can only by removed in next wake up, or by LIN message.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Start-Stop Capacitor Sense Circuit Low	P1075	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1075 indicates that the ESC middle point voltage sense line is in an open circuit / short to GND faulted state or that the ESC is defective. The DTC is set when the malfunction criteria mets the threshold value for Case 1 or Case 2.	Case 1: Voltage increase rate of the capacitor after 5 seconds of charge	< 10 mV / s	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met: DCDC charging Charging current	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.03 sec = active > 40 Amps	Detection is done in the first 5 seconds at each charge. Fault is set at first detection. Fault can only be removed at next wake up, or by LIN message.	Type A, 1 Trips
			Case 2: The capacitor (dual cell) mid point voltage before starting balance The capacitor (dual cell) mid point voltage after starting balance.	< 0.1 V > 0.8 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up	U135C, U1347, P1066 = TRUE	Detect after each balance of capacitor cells. Fault is set at first detection. Once set, this fault will inhibit	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Note: balance is used to make the capacitor voltage equally distributed between the two cells.		Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Then, this diagnostic runs after each balance.	 > 0.50 sec > 0.03 sec	further cells balancing. Fault can only be removed in the next wake up or by LIN message.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Start-Stop Capacitor Sense Circuit High	P1076	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1076 indicates that the ESC middle point voltage sense line has a short to power fault. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	Capacitor mid point line voltage	> 4.8 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs continuously.	U135C, U1347, P1066 = TRUE > 0.50 sec > 2.10 sec	Test cycle time is 100ms. Error count increases by 1 if an error is detected, up to a maximum of 20. Error count decreases by 1 if no error is detected, up to a minimum of 0. Fault is set when error count = 20. (2 sec fault maturity) Fault is removed when error count = 0. (2 sec healing time)	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module LIN System Voltage Low	P1077	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1077 indicates that the LIN supply voltage is too low. The LIN supply voltage input is monitored and compared to the threshold value. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	LIN supply voltage	< 9.12 V	No active DTCs Diagnostic reporting is enabled when the following steps (A)~(D) finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Engine run time Then, (D) Fault maturity delay time expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions met: Ground switch (K1) Capactor switch (K2) Engine run time after each auto stop event	U135C, U1347, P1066 = TRUE > 0.50 sec > 3.0 sec > 5.00 sec = Closed = Open > 3.0 sec	Test cycle time is 10ms. Error count increases by 2 if an error is detected, up to a maximum of 100. Error count decreases by 1 if no error is detected up to a minimum of 0. Fault is set when error count = 100. (500ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module LIN System Voltage High	P1078	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1078 indicates that the LIN supply voltage is too high. The LIN supply voltage input is monitored and compared to the threshold value. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	LIN supply voltage	> 17.16 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met: Ground switch (K1) Capactor switch (K2)	U135C, U1347, P1066 = TRUE > 0.50 sec > 5.00 sec = Closed = Open	Test cycle time is 10ms. Error count increases by 2 if an error is detected up to a maximum of 100. Error count decreases by 1 if no error is detected up to a minimum of 0. Fault is set when error count = 100. (500ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module LIN System Voltage Performance	P1079	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1079 indicates that the difference between the received reference voltage and the measured LIN supply votlage is too high. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	The absolute value of difference of the following two items (A) and (B): (A) measured LIN supply voltage (B) received engine run crank voltage from LIN message	> 2.5 V	No active DTCs Diagnostic reporting is enabled when the following steps (A)~(D) finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Engine Mode Run Then, (D) Fault maturity delay time expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met: Ground switch (K1) Capactor switch (K2) Engine run time after each auto stop event	U135C, U1347, P1066 = TRUE > 0.50 sec > 3.0 sec > 5.00 sec = Closed = Open > 3.0 sec	Test cycle time is 100ms. Error count increases by 2 if an error is detected, up to a maximum of 10. Error count decreases by 1 if no error is detected up to a minimum of 0. Fault is set when error count = 10. (500ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module DC/ DC Converter System Voltage Low	P107A	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P107A indicates that the measured battery (input to the DC/DC Converter system) is too low. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	Measured battery voltage	< 6.34 V	No active DTCs Diagnostic reporting is enabled when the following steps (A)~(D) finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Engine run time Then, (D) Fault maturity delay time expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs continuously when the following conditions are met: Measured LIN supply voltage Engine run time after each auto stop event	U135C, U1347, P1066 = TRUE > 0.50 sec > 3.0 sec > 0.11 sec > 6.5V + 380 mv hysteresis > 3.0 sec	Test cycle time is 10ms. Error count increases by 10 if an error is detected, up to a maximum of 100. Error count decreases by 1 if no error is detected up to a minimum of 0. Fault is set when error count = 100. (100ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module DC/ DC Converter System Voltage High	P107B	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P107B indicates that the measured battery (input to the DC/DC Converter system) is too high. The measured battery (input to the DC/DC Converter system) input is monitored and compared to the threshold value. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	Measured battery voltage	> 17.06 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs continuously when the following conditions are met: Measured LIN supply voltage	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.11 sec > 6.5 V + 380 mv hysteresis	Test cycle time is 10ms. Error count increases by 10 if an error detection occurs up to a maximum of 100. Error count decreases by 1 if no error detection occurs up to a minimum of 0. Fault is set when error count = 100. (100ms fault maturity) Fault is removed when error count = 0. (1 sec healing time).	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module DC/ DC Converter Supply Voltage Circuit Performance	P107C	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P107C indicates that the difference between the received reference voltage and the measured battery (input to the DC/DC Converter system) voltage is too high. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	The absolute value of difference between the following two items (A) and (B): (A) Mesured battery voltage (B) Received engine run crank voltage	> 2.5 V	No active DTCs Diagnostic reporting is enabled when the following steps (A)~(D) finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Engine run time Then, (D) Fault maturity delay time expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met: Ground swith (K1) Capacitor switch (K2) Engine run time after each auto stop event	U135C, U1347, P1066 = TRUE > 0.50 sec > 3.0 sec > 5.00 sec = Closed = Open > 3.0 sec	Test cycle time is 100ms. Error count increases by 2 if an error is detected up to a maximum of 10. Error count decreases by 1 if no error is detected up to a minimum of 0. Fault is set when error count = 10. (500ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Control Module Backup System Voltage Low	P107D	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P107D indicates that the measured external safe supply (input to the ESCM) voltage is too low. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	Measured external safe supply voltage	< 62 % of the measured battery voltage	No active DTCs Diagnostic reporting is enabled when the following steps (A)~(D) finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Engine run time Then, (D) Fault maturity delay time expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs continuously when the following conditions are met: Measured LIN supply voltage Engine run time after each auto stop event	U135C, U1347, P1066 = TRUE > 0.50 sec > 3.0 sec > 0.60 sec > 6.5 V + 380 mv hysteresis > 3.0 sec	Test cycle time is 100ms. Error count increases by 2 if an error is detected, up to a maximum of 10. Error count decreases by 1 if no error is detected, up to a minimum of 0. Fault is set when error count = 10. (500ms fault maturity) Fault is removed when error count = 0. (1sec healing time)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Control Module Backup System Voltage High	P107E	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P107E indicates that the measured external safe supply (input to the ESCM) voltage is too high. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	Measured external safe supply voltage	> 17.16 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Aftterwards, this diagnostic runs when the following conditions are met: Ground switch (K1) Capacitor switch (K2)	U135C, U1347, P1066 = TRUE > 0.50 sec > 5.00 sec = Closed = Open	Test cycle time is 100ms. Error count increases by 2 if an error is detected, up to a maximum of 10. Error count decreases by 1 if no error is detected, up to a minimum of 0. Fault is set when error count = 10. (500ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Control Module Backup System Voltage Performance	P107F	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P107F indicates that the difference between the received reference voltage and the measured external safe supply (input to the ESCM) voltage is too high. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	Absolute value of difference of the following two items (A) and (B): (A) measured extrnal safe supply voltage (B) received engine run crank voltage	> 2.5 V	No active DTCs Diagnostic reporting is enabled when the following steps (A)~(D) finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Engine run time Then, (D) Fault maturity delay time expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met: Ground switch (K1) Capacitor switch (K2) Engine run time after each auto stop event	U135C, U1347, P1066 = TRUE > 0.50 sec > 3.0 sec > 5.00 sec = Closed = Open > 3.0 sec	Test cycle time is 100ms. Error count increases by 2 if an error is detected, up to a maximum of 10. Error count decreases by 1 if no error is detected, up to a minimum of 0. Fault is set when error count = 10. (500ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Battery Negative Circuit Driver "A" Low	P1080	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1080 indicates that the ground switch (K1) bank A driver is stuck at open when should be closed. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	Gound switch (K1) bank A gate voltage is low. Note: the gate voltage is to assure that the switch stays closed when commanded.	< 10.5V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met: Measured LIN supply voltage Ground switch (K1) is commanded to close according to flip-flop output	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.50 sec > 6.5 V + 380 mv hysteresis = TRUE	Test cycle time is 5ms. Error count increases by 2 if an error detection occurs up to a maximum of 200. Error count decreases by 1 if no error detection occurs up to a minimum of 0. Fault is set when error count = 200. (500ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Battery Negative Circuit Driver "A" High	P1081	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1081 indicates that the ground switch (K1) bank A driver is stuck at closed when should be open. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value	Ground switch (K1) bank A gate voltage	> 2.0 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met: Ground switch (K1) is commaned to open according to flip-flop output And, Measured LIN supply voltage	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.05 sec = TRUE > 6.5 V + 380 mv hysteresis	Test cycle time is 5ms. Error count increases by 29 if an error detection occurs up to a maximum of 203. Error count decreases by 1 if no error detection occurs up to a minimum of 0. Fault is set when error count = 203. (50ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Battery Negative Circuit Driver "A"-"B" Not Plausible	P108A	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P108A indicates that the difference between the ESCM ground switch (K1) bank A gate voltage and bank B gate voltage is too high. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	The absolute value of difference between the following two items (A) and (B) (A) K1A gate voltage (B) K1B gate voltage	> 2.0 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs continuously	U135C, U1347, P1066 = TRUE > 0.50 sec > 5.00 sec	Test cycle time is 100ms. Error count increases by 2 if an error detection occurs up to a maximum of 10. Error count decreases by 1 if no error detection occurs up to a minimum of 0. Fault is set when error count = 10. (500ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Battery Negative Circuit Driver "B" Low	P108B	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P108B indicates that the ground switch (K1) bank B driver is stuck at open when should be closed. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	Gound switch (K1) bank B gate voltage	< 10.5 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received. Afterwards, this diagnostic runs when the following conditions are met: Measured LIN supply voltage Ground switch (K1) is commanded to close according to flip-flop output	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.50 sec > 6.5 V + 380mv hysteresis = TRUE	Test cycle time is 5ms. Error count increases by 2 if an error detection occurs up to a maximum of 200. Error count decreases by 1 if no error detection occurs up to a minimum of 0. Fault is set when error count = 200. (500ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Battery Negative Circuit Driver "B" High	P108C	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P108C indicates that the ground switch (K1) bank B is stuck at closed when should be open. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	Ground switch (K1) bank B gate voltage	> 2.0 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received. Afterwards, this diagnostic runs when the following conditions are met: Ground switch (K1) is commanded to close according to flip-flop output And, Measured LIN supply voltage	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.05 sec = TRUE > 6.5 V + 380 mv hysteresis	Test cycle time is 5ms. Error count increases by 29 if an error detection occurs up to a maximum of 203. Error count decreases by 1 if no error detection occurs up to a minimum of 0. Fault is set when error count = 203. (50ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module DC/ DC Converter Discharging Performance	P108D	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P108D indicates that one or more of the following two ESCM DC/DC Converter discharging faults have occurred: Case 1) DCDC does not stop charging when requested; Case 2) DCDC is unable to discharge the capacitor The DTC is set when: 1) The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the	Case 1: DCDC does not stop charging when requsted Charging current	 > 10 Amps	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met: DCDC disabled OR DCDC discharging	U135C, U1347, P1066 = TRUE > 0.50 sec > 15.00 sec = TRUE = TRUE	Test cycle time is 10ms. Error count increases by 1 if an error detection occurs up to a maximum of 200. Error count decreases by 2 if no error detection occurs up to a minimum of 0. Fault is set when error count = 200. (500ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		error count maximum value (Case 1) or, 2) The malfunction criteria mets the threshold value (Case 2)	Case 2: DCDC is unable to discharge the capacitor: Capacitor voltage decrease rate	< 6 mv / second in first 15 sec discharging time	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met: DCDC discharging Capacitor voltage	U135C, U1347, P1066 = TRUE > 0.50 sec > 15.00 sec = TRUE > 0.5 V	Detect during first 15 seconds ot discharging. Fault is set after first detection. Fault can only be removed in the next wake up, or by LIN message.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capcitor Control Module DC/ DC Converter Charging Performance	P108E	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P108E indicates that one or more of the following two ESCM DC/DC Converter Charging faults have occurred: Case 1) Charge current is too high Case 2) DCDC does not charge when requested The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	Case 1: Charge current is too high Phase 1 charge current OR Phase 2 charge current	 > 36.75 Amps > 68.25 Amps	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met: DCDC charging	U135C, U1347, P1066 = TRUE > 0.50 sec > 2.10 sec = TRUE	Test cycle time is 10 ms. Error count increases by 10 if an error detection occurs up to a maximum of 100. Error count decreases by 1 if no error detection occurs up to a minimum of 0. Fault is set when error count = 100. (100 ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type A, 1 Trips
			Case 2: DCDC does not charge when requested: ********** Condition (I) if DCDC is charging with half current OR capacitor voltage > 4V ********** Charge current	 < 15 Amps	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay	U135C, U1347, P1066 = TRUE > 0.50 sec	Detection starts after 500 ms charge. Test cycle time is 10 ms. Error count increases by 1 if an error detection occurs up to a maximum of 200.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			********** Condtion (II) if DCDC is charging with full current AND capacitor voltage ≤ 4 V ********** Charge current	 < 30 Amps	Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received. Note: After intial time delay, diagnostic runs if the following conditions satisfy: DCDC charging DCDC charging time	 > 2.10 sec = TRUE ≥ 500 ms	Error count decreases by 1 if no error detection occurs up to a minimum of 0. Fault is set when error count = 200. Fault is removed when error count = 0.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Self Test Failed	P108F	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P108F indicates that one ore more of the following three faults have occurred: Case 1) Unable to switch over to capacitor switch (K2) during self test, Case 2) An unintended switchover to capacitor switch (K2) during self test, Case 3) Capacitor switch (K2) is in a high impedance state or diode mode during self test The DTC is set when the malfunction criteria mets the threshold values in any of the three cases.	Case 1: Unable to switch over to capacitor switch (K2) during self test if either (A) or (B) is TRUE: (A) Hardware current comparator output stuck at passive. And, the measured battery voltage Note: hardware current comparator is used to automatically provoke a switch if the current flowing through the ground switch (K2) is greater than a threshold. (B) Hardware voltage comparator is stuck at passive. And, the measured battery voltage Note: hardware voltage comparator is used to automatically provoke a switch if the battery voltage is less than a threshold.	< 13.3 V ≥ 13.3 V	No active DTCs Diagnostic reporting is enabled when the following steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value And, (D) Fault is deteced following previous drive cycle during powerdown self test. Note: This is not continuous diagnostic.	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.10 sec	Detect during part two of the self test procedure only if there was no switch (K1-K2-K1) in the drving cycle. Self test procedure is performed at the end of the drive cycle after ESCM is not in working state, i.e. no LIN commnication, and further delay by 120 seconds. Fault is set after first detection. Fault can only be removed in the following driving cycle when self test runs again.	Type A, 1 Trips
			Case 2: Unintended switchover to capacitor switch (K2) during self test if either (A) or (B) is TRUE: (A) Hardware current comparator output is		No active DTCs Diagnostic reporting is enabled when the following steps finish: (A) LIN bus wake up	U135C, U1347, P1066	Detect during part one of the self test procedure. Self test procedure is performed at the	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			always triggerred. And, the measured battery voltage Note: hardware current comparator is used to automatically provoke a switch if the current flowing through the ground switch (K2) is greater than a threshold. (B) Hardware voltage comparator output is always triggerred. And, the measured battery voltage Note: hardware voltage comparator is used to automatically provoke a switch if the battery voltage is less than a threshold (9.5V)	< 3.3 V OR > 7.5 V ≥ 3.3 V AND ≤ 7.5 V	Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value And, (D) Fault is deteced following previous drive cycle during powerdown self test. Note: This is not continuous diagnostic.	= TRUE > 0.50 sec > 0.10 sec	end of the drive cycle after ESCM is not in working state, i.e. no LIN commnication, and further delay by 120 seconds. Fault can only be removed in the following driving cycle when self test runs again.	
			Case 3: Capacitor switch (K2) is in a high impedance state or diode mode during self test; Measured battery voltage jumps immediately after the switch, i.e. ground switch (K1) changes from close to open, meanwhile capacitor switch (K2) changes from open to close.	< 1.0 V	No active DTCs Diagnostic reporting is enabled when the following steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.10 sec	Detect during part two of the self test procedure. Self test procedure is performed at the end of the drive cycle after ESCM is not in working state, i.e. no LIN commnication,	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Note: this test requires that measured capacitor voltage	> 2.0 V	expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value And, (D) Fault is deteced following previous drive cycle during powerdown self test.		and further delay by 120 seconds. Fault can only be removed in the following driving cycle when self test runs again.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Internal Circuitry Performance	P1090	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1090 indicates a ESCM power interconnection defect on control board / power board. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the counter reaches the error count maximum value.	Measured 2.5V reference voltage	< 2.18 V OR > 2.83 V	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met: Internal power supply DCDC charging OR discharging	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.51 sec = OK = TRUE	Test cycle time is 10ms. Error count increases by 2 if an error detection occurs up to a maximum of 100. Error count decreases by 1 if no error detection occurs up to a minimum of 0. Fault is set when error count = 100. (500ms fault maturity) Fault is removed when error count = 0. (1 sec healing time)	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Stop-Start Capacitor Control Module Switch Deteriorated	P1091	The Energy Storage Capacitor (ESC) and Energy Storage Control Module (ESCM) are used on certain 12 volt start stop applications to improve the vehicle system voltage during engine start events. P1091 diagnoses the ESCM switch degridation by monitoring four specific fault cases. P1091 Indicates one or more of the following faults have occured: Case 1) Ground switch (K1) is in short circuit when it should be open Case 2) Capacitor switch (K2) is in a high impedance or in diode mode when it should be closed. Case 3) Capacitor switch (K2) close command does not close K2 when required. Case 4) Capacitor control module has reached its end of life. The diagnostic failure counters are incremented and decremented based on error detection, the DTC is set when the	Case 1: Ground switch (K1) current measurement AND Capcitor switch current measurement	< -120 Amps > 60 Amps	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value. Afterwards, this diagnostic runs when the following conditions are met: Capacitor switch (K2) closed	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.03 sec = TRUE	Test cycle time is 1ms. Error count increases by 10 if an error detection occurs up to a maximum of 100. Error count decreases by 1 if no error detection occurs up to a minimum of 0. Fault is set when error count = 100. (10ms fault maturity) Fault is removed when error count = 0. (100ms healing time)	Type A, 1 Trips
			Case 2: Measured ground switch (K1) current AND Measured capacitor switch (K2) current	> 40A < 30A	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay	U135C, U1347, P1066 = TRUE > 0.50 sec	Test cycle time is 1ms. Error count increases by 10 if an error detection occurs up to a maximum of 100. Error count decreases by 1 if no error	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		counter reaches the error count maximum value.			Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met: Capacitor switch (K2)	> 0.03 sec = Closed	detection occurs up to a minimum of 0. Fault is set when error count = 100. (10 ms fault maturity) Fault is removed when error count = 0. (100ms healing time)	
			Case 3: Capacitor switch (K2) stuck at open when it should be closed	n.a.	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) Diagnostic delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs when the following conditions are met:	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.03 sec	Test cycle time is 10ms. Error count increases by 34 if an error detection occurs up to a maximum of 102. Error count decreases by 1 if no error detection occurs up to a minimum of 0. Fault is set when error count = 102. (30ms fault maturity) Fault is removed when error count	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Capacitor switch (K2) is commanded to close, according to flip-flop output	= TRUE	= 0. (1.2 sec healing time)	
			Case 4: Number of switchbacks between ground switch (K1) and capacitor switch (K2)	> 2 million times	No active DTCs Diagnostic reporting is enabled when the following three steps finish: (A) LIN bus wake up Then, (B) ESCM wake up delay Then, (C) Fault maturity delay expires, and the next valid LIN frame has been received; or whenever fault state from ESCM changes its value Afterwards, this diagnostic runs continuously.	U135C, U1347, P1066 = TRUE > 0.50 sec > 0.03 sec	Detect after every switch-back. Fault is set after first detection. This fault is permament, can only be removed by service tool.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (single turbo)	P1101	Detects a performance failure in the Manifold Pressure (MAP) sensor, Turbocharger Boost Pressure sensor, Throttle Position sensor (TPS) or Mass Air Flow (MAF) sensor that cannot be uniquely identified as a failure in one individual sensor. This diagnostic can set when more than one of these sensors has a performance concern. This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from these four sensors. These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with	See table **P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix** for combinations of model failures that can set this DTC. MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP -	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		the system, but no single failed sensor can uniquely be identified. In this case, the Inlet Airflow System Performance diagnostic will fail.	measured MAP - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset** OR Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset** TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time High Engine Air Flow is TRUE when Mass Air Flow	> 24.0 kPa > 24.0 kPa > 1.0 seconds > 1.0 seconds > a threshold in gm sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow**	No Active DTCs: No Pending DTCs:	MAP Model 2 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP Model 3 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM** TIAP Model 1 Error multiplied by **P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM** Filtered Throttle Model Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM** MAP_SensorCircuitFA EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AND Manifold Pressure	> a threshold in kPa as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP**		MnfdTempSensorCktFP		
			AND Filtered Mass Air Flow - Mass Air Flow	< 3.0 gm/sec				
			Low Engine Air Flow is TRUE when Mass Air Flow	< a threshold in gm sec as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow**				
			AND Manifold Pressure	< a threshold in kPa as a function of engine speed See table **P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP**				
			AND Mass Air Flow - Filtered Mass Air Flow	< 2.0 gm/sec				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Surge Solenoid Circuit Open	P171A	Controller specific transmission surge accumulator control circuit diagnoses the transmission surge accumulator and wiring for an open circuit fault by comparing a voltage measurement to controller specific voltage thresholds.	transmission surge accumulator control circuit impedance	≥ 200 K Ω impedance between signal and controller ground	battery voltage AND battery voltage update battery enable time run/crank voltage diagnostic monitor enable	≥ 7.00 volts ≤ 32.00 volts ≥ 5.00 volts = 1 Boolean	fail time ≥ 0.188 seconds out of sample time ≥ 0.250 seconds 25 milliseconds update rate battery enable time ≥ 5.00 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Surge Solenoid Circuit Low	P171B	Controller specific transmission surge accumulator control circuit diagnoses the transmission surge accumulator and wiring for a ground short circuit fault by comparing a voltage measurement to controller specific voltage thresholds.	transmission surge accumulator control circuit impedance	≤ 0.5 Ω impedance between signal and controller ground	battery voltage AND battery voltage update battery enable time run/crank voltage diagnostic monitor enable	≥ 7.00 volts ≤ 32.00 volts ≥ 5.00 volts = 1 Boolean	fail time ≥ 0.188 seconds out of sample time ≥ 0.250 seconds 25 milliseconds update rate battery enable time ≥ 5.00 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Surge Solenoid Circuit High	P171C	Controller specific transmission surge accumulator control circuit diagnoses the transmission surge accumulator and wiring for a short to power circuit fault by comparing a voltage measurement to controller specific voltage thresholds.	transmission surge accumulator control circuit impedance	≤ 0.5 Ω impedance between signal and controller voltage source	battery voltage AND battery voltage update battery enable time run/crank voltage diagnostic monitor enable	≥ 7.00 volts ≤ 32.00 volts ≥ 5.00 volts = 1 Boolean	fail time ≥ 0.069 seconds out of sample time ≥ 0.081 seconds 25 milliseconds update rate battery enable time ≥ 5.00 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Surge Accumulator System Performance	P171D	Detects when the surge accumulator system, used to provide transmission hydraulic pressure, is not capable of supplying adequate hydraulic pressure during an engine auto-start. The transmission holding clutch pressures are commanded to meet the engine crank shaft torque output, to prevent clutch slip to those holding clutches, during the engine auto-start. The diagnostic monitors transmission input shaft speed during the auto-start event as the primary malfunction criteria. Measured input shaft speed that is excessive is an indication the holding clutches are slipping due to inadequate hydraulic pressure, as a result of a failed surge accumulator system.	Transmission turbine speed is greater than predicted turbine speed during autostart event, update initial fail count	≥ **P171D predicted turbine speed error** Refer to "Transmission Supporting Tables" for details	PRNDL state defaulted Transmission shift lever position Propulsion system active Ignition voltage Ignition voltage Transmission fluid temp Transmission fluid temp Hybrid state AutoStop duration min During autostop Engine speed was ********** If above conditions are met then the following must occur: Turbine speed Engine speed Hydraulic pressure delay time If above conditions are met then increment time-out timer. Time-out timer Note: The initial fail	= False = Forward range A = True > 9.00 volts < 31.99 volts > 0.00 °C < 110.00 °C = Engine off ≥ 1.200 seconds < 5.0 RPM ≥ 80.0 RPM ≥ 450.0 RPM ≥ **P171D hydraulic pressure delay** Refer to "Transmission Supporting Tables" for details ≤ 0.38 seconds	≥ 12 counts (initial fail count) Frequency =12.5ms Once the above counts are achieved then increment the final fail counter once. The final fail counter can only increment once per autostart event ≥ 3 counts (final fail counter) If above counter is greater than threshold then report DTC failed. Frequency = 12.5ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					counter must achieve it's fail threshold in less than the time-out time. ********** If vehicle is launched then: Transmission gear ratio Trans 1st gear ratio high Trans 1st gear ratio low Trans gear ratio not 1st gear high Trans gear ratio not 1st gear low Valid transmission gear ratio achieved time OR If vehicle is not launched but autostart occurs then: Turbine speed Turbine speed less then above threshold for Note: During an autostart event the lack of hydraulic pressure will result in momentary clutch slip in	 = 4.5600 1st gear ratio = 2.9700 2nd gear ratio = 2.0700 3rd gear ratio = 1.6800 4th gear ratio = 1.2700 5th gear ratio = 1.0000 6th gear ratio ≤ 1.120 times 1st gear ratio ≥ 0.880 times 1st gear ratio ≤ 1.070 times gear ratio ≥ 0.930 times gear ratio ≥ 0.500 seconds ≤ 5.00 RPM ≥ 0.500 seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					the C1234 clutch. After the clutch slip event, the main transmission pump and clutch will gain capacity, clutch slip will go to zero. If the vehicle is launching (moving) then a valid transmission ratio can be achieved. Or if the brake is continually applied and an autostart occurs naturally, then no ratio can be measured. In this case turbine speed will return to near zero rpm. ********** DTCs not fault active	CrankSensor_FA Transmission Output Shaft Angular Velocity Validity Transmission Turbine Angular Velocity Validity Transmission Oil Temperature Validity P171A P171B P171C U0101 P182E P1915		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Performance (single turbo)	P2227	Detects a performance failure in the Barometric Pressure (BARO) sensor, such as when a BARO value is stuck in range. If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The BARO sensor value is checked to see if it is within the normal expected atmospheric pressure range. If it is not, then the BARO performance diagnostic will fail. If the BARO sensor value is within the normal expected atmospheric range, then Manifold Pressure (MAP), Turbocharger Boost Pressure and BARO are compared to see if their values are similar. If the MAP and Turbocharger Boost Pressure sensor values are similar, but the BARO value is not similar, then a BARO performance diagnostic will fail. When the engine is	**Engine Running:** Difference between Baro Pressure reading and Estimated Baro when distance since last Estimated Baro update OR Difference between Baro Pressure reading and Estimated Baro when distance since last Estimated Baro update	 > 15.0 kPa <= 0.06 miles > 20.0 kPa > 0.06 miles	No Active DTCs:	AmbPresSnsrCktFA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA TC_BoostPresSnsrFA	320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips
			Engine Not Rotating: Barometric Pressure OR Barometric Pressure OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	 < 50.0 kPa > 115.0 kPa > 10.0 kPa <= 10.0 kPa > 10.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating No Active DTCs: No Pending DTCs:	 > 10.0 seconds EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA AAP2_SnsrCktFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP	4 failures out of 5 samples 1 sample every 12.5 msec	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		running, there is an estimate of barometric pressure that is determined with the Turbocharger Boost Pressure sensor, engine air flow and engine speed. If the BARO value from the sensor is not similar to this barometric pressure estimate, then the BARO performance diagnostic will fail.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (boosted applications, Gen III)	P2228	Detects a continuous short to ground in the Barometric Pressure (BARO) signal circuit by monitoring the BARO sensor output voltage and failing the diagnostic when the BARO voltage is too low. The BARO sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	BARO Voltage	< 39.3 % of 5 Volt Range (This is equal to 50.0 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (boosted applications, Gen III)	P2229	Detects a continuous short to power or open circuit in the Barometric Pressure (BARO) signal circuit by monitoring the BARO sensor output voltage and failing the diagnostic when the BARO voltage is too high. The BARO sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	BARO Voltage	> 90.0 % of 5 Volt Range (This is equal to 115.0 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Pumping Current Performance Bank 1 (For use with WRAF - E80	P223C	This DTC determines if the WRAF O2 sensor pumping current has an incorrect or out of range value. This DTC will detect open circuit faults to the Pump current, Ref Cell voltage, Ref Ground and Trim circuits. When enabled, the diagnostic monitors the pumping current in three different fault regions during DFCO. The individual diagnostic failure counters are incremented based on the diagnostic results in each region. The DTC is set based on any of the three individual fail and sample counters.	Fault condition present when the pump current is in any of the fault regions when this test is enabled during DFCO. Note: This ASIC is referred to as C2WRAF (Delphi).	The three pump current fault regions are: A) Pump current > 4.18 ma B) Pump current ≤ 0.10 ma and ≥ - 0.10 ma C) Pump current < -0.10 ma The three fault regions have individual X out of Y calibrations. When the X out of Y is reached in any region this DTC is set. Note: A open circuit on the Pump current signal may also set a P0131 DTC. Note: A short to ground on the trim circuit can set P223C.	DTC's Not active this key cycle Measure Valid status (ASIC) Controller status (ASIC) Engine Run or Auto stop WRAF Ref cell temperature ********** Heater Warm-up delay Then WRAF circuit diagnostic delay (since heater Warm-up delay is complete) ********** Test starts when time in DFCO Test stops when time in DFCO	WRAF_Bank_1_FA P0135, P0030, P0031, P0032 = Valid = Ready = True ≥ 628 Deg C = Complete ≥ 20.0 seconds ≥ 5.0 seconds > 12.0 seconds	Region A: 224 failures out of 280 samples OR Region B: 224 failures out of 280 samples OR Region C: 224 failures out of 280 samples Sample rate is 25 msec. Test enabled during DFCO.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Auxiliary Coolant Pump Relay Control Circuit	P2600	Controller specific output driver circuit diagnoses the Auxillary Coolant Pump Relay Control Circuit low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between signal and controller ground.	Run Crank Ignition in Range Engine not cranking == Above is true and == Last Open Circuit Test	= True = True ========== not Indeterminate	5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips Note: In certian controllers P2602 may also set

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Auxiliary Coolant Pump Relay Control Circuit Low Voltage	P2602	Controller specific output driver circuit diagnoses the Auxiliary Coolant Pump Relay Control Circuit low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between signal and controller ground	Run Crank Ignition in Range Engine not cranking == Above is true and == Last Open Circuit Test	= True = True ========== not Indeterminate	5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips Note: In certian controllers P2600 may also set

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Auxiliary Coolant Pump Relay Control Circuit High Voltage	P2603	Controller specific output driver circuit diagnoses the Auxiliary Coolant Pump Relay Control Circuit low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between signal and controller power.	Run Crank Ignition in Range Engine not cranking == Above is true and == Last Open Circuit Test	 = True = True ========== not Indeterminate	5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position Signal Output Circuit Low	P2615	Controller specific output driver circuit diagnoses the camshaft output low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.	Short to ground: <= 0.5 Ohms impedance between signal and controller ground Open Circuit: >= 200 K Ohms impedance between signal and controller ground	Powertrain Relay Voltage Engine is not cranking Camshaft Position Output is commanded high	>= 11.0 Volts	40 failures out of 50 samples 1 sample every 100 msec	Type C, No SVS Note: In certain controllers P2614 may also set (Camshaft Position Signal Output Circuit / Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position Signal Output Circuit High	P2616	Controller specific output driver circuit diagnoses the camshaft position output low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.	Short to power: <= 0.5 Ohms impedance between signal and controller power	Powertrain Relay Voltage Engine is not cranking Camshaft Position Output is commanded low	>= 11.0 Volts	40 failures out of 50 samples 1 sample every 100 msec	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position Signal Output Circuit Low	P2618	Controller specific output driver circuit diagnoses the crankshaft position output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.	Short to ground: <= 0.5 Ohms impedance between signal and controller ground Open Circuit: >= 200 K Ohms impedance between signal and controller ground	Powertrain Relay Voltage Engine is not cranking Crankshaft Position Output is commanded high	>= 11.0 Volts	40 failures out of 50 samples 1 sample every 100 msec	Type C, No SVS Note: In certain controllers P2617 may also set (Crankshaft Position Signal Output Circuit / Open)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Cruise Control Module	U0104	This DTC monitors for a loss of communication with the Cruise Control Module.	Message is not received from controller for Message $2CB Message $2CD	 ≥ 0.5 seconds ≥ 0.5 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Run/Crank Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 5.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for	 Not Active on Current Key Cycle Enabled Not Active Not Active > 6.41 Volts = run = 1 (1 indicates enabled) = Active > 11.00 Volts > 0.4000 seconds	Diagnostic runs in 12.5 ms loop	Type C, No SVS "Emissions Neutral Diagnostics – Type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					U0104 Cruise Control Module	Not Active on Current Key Cycle is present on the bus		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Fuel Pump Control Module	U0109	This DTC monitors for a loss of communication with the fuel pump control module	Message is not received from controller for Message $1EB Message $4D9	 ≥ 10.0 seconds ≥ 10.0 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Run/Crank Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 5.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for	 Not Active on Current Key Cycle Enabled Not Active Not Active > 6.41 Volts = run = 1 (1 indicates enabled) = Active > 11.00 Volts > 0.4000 seconds	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					U0109 Fuel Pump Control Module	Not Active on Current Key Cycle is present on the bus		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Anti-Lock Brake System (ABS) Control Module	U0121	This DTC monitors for a loss of communication with the Anti-Lock Brake System (ABS) Control Module (Non-OBD Module ID 243).	Message is not received from controller for Message $0C1 Message $0C5 Message $1C7 Message $1E9 Message $2F1 Message $2F9	 ≥ 0.5 seconds ≥ 0.5 seconds ≥ 0.5 seconds ≥ 0.5 seconds ≥ 10.0 seconds ≥ 0.5 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Run/Crank Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 5.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for	 Not Active on Current Key Cycle Enabled Not Active Not Active > 6.41 Volts = run = 1 (1 indicates enabled) = Active > 11.00 Volts > 0.4000 seconds	Diagnostic runs in 12.5 ms loop	Type C, No SVS "Emissions Neutral Diagnostics – Type C"

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					U0121 Anti-Lock Brake System Control Module	Not Active on Current Key Cycle is present on the bus		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communication LIN Bus 3 Off	U1347	This DTC monitors for a LIN bus 3 off condition	LIN bus off failures	>= 3.00 counts	The following criteria have been enabled for Power Mode Run/Crank Voltage	>= 400.00 milliseconds =Run >= 11.00 Volts	Dependent on bus loading.	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
LIN Bus 3 Loss of Communication with Stop-Start Control Module (UltraCap)	U135C	This DTC monitors for a loss of communication on the LIN bus 3 with UltraCap Module	ECM has lost communication over the LIN bus 3 with the UltraCap Module for	>= 3.00 counts	The following criteria have been enabled for Power Mode Run/Crank Voltage	>= 400.00 milliseconds =Run >= 11.00 Volts	LIN bus communication executes in 500ms loop	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp Sensor Circuit Low Voltage	P00B3	Circuit Continuity This DTC detects a short to ground in the RCT (Radiator Coolant temperature) signal circuit or the RCT sensor. This is accomplished by monitoring the resitance of the circuit. If the resistance goes out of the expected range the DTC is set.	RCT Resistance (@ 150ºC)	< 34 Ohms	Engine run time OR IAT min	> 10.0 seconds ≤ 70.3 °C	5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp Sensor Circuit High Voltage	P00B4	Circuit Continuity This DTC detects a short to high or open in the RCT (Radiator Coolant temperature) signal circuit or the RCT sensor. This is accomplished by monitoring the resistance of the circuit. If the resistance goes out of the expected range the DTC is set.	RCT Resistance (@ -60ºC)	> 260,000 Ohms	Engine run time OR IAT min	> 60.0 seconds ≥ -7.0 °C	5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Switch	P0520	When criteria are met that assure no oil pressure should be present, read state of oil pressure switch circuit	State of Engine Oil Pressure (EOP) switch circuit	Detecting.a.ground.will.set.a.fault	Run/Crank powermode active Engine movement detected Key in crank position Power down engine coolant Powertrain relay voltage Run/Crank Ignition voltage AND Time since engine last running Timer for time since engine last running validity OR Engine coolant at power up Diagnostic enabled/ disabled No active DTC's	= True = False = False > 70 Deg C >= 11.00 volts >= 11.00 volts > 3,600 Seconds = True < (Power down engine coolant) minus an additional 10 Deg C Disabled Fault bundles: ECT_Sensor_Ckt_FA	Fail detected for >= 5.00 Sec. 250 msec loop Continuous	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control Open Circuit	P0597	Controller specific output driver circuit diagnoses the Thermostat Heater Control sided driver for an open circuit failure. When the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Run Crank Ignition in Range Engine not cranking Run Crank active == Above is true and == Last Open Circuit Test	 = True = True = True ========== = not Indeterminate	15 failures out of 30 samples 1 sec/ sample Continuous	Type B, 2 Trips Note: In certian controllers P0598 may also set

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control Circuit Low	P0598	Controller specific output driver circuit diagnoses the Thermostat Heater low sided driver for a short to ground failure. A DTC is set when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run Crank Ignition in Range Engine not cranking Run Crank active == Above is true and == Last Ground Short Circuit Test	 = True = True = True ========== = not Indeterminate	15 failures out of 30 samples 1 sec/ sample Continuous	Type B, 2 Trips Note: In certian controllers P0597 may also set

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control Circuit High	P0599	Controller specific output driver circuit diagnoses the Thermostat Heater low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Run Crank Ignition in Range Engine not cranking Run Crank active == Above is true and == Last Power Short Circuit Test	 = True = True = True ========== = not Indeterminate	15 failures out of 30 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling System Performance	P2181	This DTC detects a stuck open thermostat by comparing the ECT sensor reading with the Radiator Coolant Temperature (RCT) sensor reading while the thermostat is expected to be closed (ie: during warm up). If the sensors follow each other the DTC is set.	This diagnostic can be calibrated to fail in <u>one</u> of two methods based on the following calibration. This application has been calibrated as a Type 0 . <u>Type 0 - Airflow Method:</u> Engine Coolant Temp (ECT) is ≤ commanded temperature minus 11 Deg C and normalized ratio is ≤ When above is present for more than 0 seconds, fail counts start. == Ratio Definition:=== Current temp difference between ECT and RCT minus PwrUp difference divided by total airgrams. Note: Minimum total airgrams is 300.0 grams. <u>Type 1 - Energy Method:</u> Engine Coolant Temp (ECT) is ≤ commanded temperature minus 11 Deg C and normalized ratio is ≤ When above is present for more than 0 seconds, fail counts start. == Ratio Definition:=== Current temp difference between ECT and RCT minus PwrUp difference divided by predicted energy.	 2.20

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor A Signal Message Counter Incorrect	P14B6	This DTC monitors for an error in communication with the Mass Air Flow Sensor A	Communication of the Alive Rolling Count Press_2B_C03 from the Mass Air Flow Sensor A over LIN bus is incorrect for out of total samples Or Communication of the Alive Rolling Count TmpHum_2A_C03 from the Mass Air Flow Sensor A over LIN bus is incorrect for out of total samples	>= 8 counts >= 10 counts >= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	LIN bus communication executes in 500ms loop	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder Deactivation System Performance	P3400	Detects a performance failure in the cylinder deactivation system. This diagnostic will fail if one or more cylinders that has been commanded to deactivate does not deactivate. This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates a modeled values of the Manifold Pressure (MAP) sensor using the Mass Air Flow (MAF) sensor. This is called the MAP2 Model. The MAP2 modeled value is compared against the actual MAP sensor values when all cylinders are active. An “all cylinder” MAP2 Model error is established with this comparison. When cylinders are deactivated, a “cylinder deactivation” MAP2 Model error is similarly established. If the “all cylinder” and “cylinder deactivation” MAP2 Model errors are similar, then air flow through the system	Current MAP Model 2 Error AND (All Cylinder MAP Model 2 Error) - (Current MAP Model 2 Error) Where: Current MAP Model 2 Error = (Measured MAP – MAP Model 2) Filtered Where: All Cylinder MAP Model 2 Error = (Measured MAP – MAP Model 2) Filtered stored the last time that all cylinders were active for a time greater than	< -8 kPa > -8 kPa > 2.0 seconds	**ReducedEngineCapacityMode_Enable** = TRUE for a time Engine Speed Engine Speed (Coolant Temp OR OBD Coolant Enable Criteria (Coolant Temp OR OBD Max Coolant Achieved Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together) See Residual Weight Factor tables. No Active DTCs: No Pending DTCs:	> 2.0 seconds >= 9,999 RPM <= 5,600 RPM >= -7 Deg C = TRUE) <= 129 Deg C = FALSE) >= -20 Deg C <= 129 Deg C >= 0.50 MAP Model 2 Error multiplied by **P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM** MAP_SensorCircuitFA EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA EGRValve_FP ECT_Sensor_Ckt_FP	100 failures out of 200 samples Performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		when cylinders are deactivated is the expected value. All cylinders are properly deactivated. If these two MAP2 Model errors are not similar, then air flow through the system when cylinders are deactivated is different than the expected value. This indicates that a cylinder is pumping air when it should not. This cylinder is not properly deactivated. In this case, the Deactivation System Performance diagnostic will fail.				IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Open Circuit - (PFI)	P0201	Controller specific output driver circuit diagnoses Injector 1 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	>= 200 KOhms impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11.00 Volts >= 5 Seconds >= 0 Seconds	50.00 failures out of 63.00 samples 100 ms /sample Continuous	Type A, 1 Trips Note: In certain controllers P0261 may also set (Injector 1 Short to Ground)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Open Circuit - (PFI)	P0202	Controller specific output driver circuit diagnoses Injector 2 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	 >= 200 KOhms impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11.00 Volts >= 5 Seconds >= 0 Seconds	50.00 failures out of 63.00 samples 100 ms /sample Continuous	Type A, 1 Trips Note: In certain controllers P0264 may also set (Injector 2 Short to Ground)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Open Circuit - (PFI)	P0203	Controller specific output driver circuit diagnoses Injector 3 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	 >= 200 KOhms impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11.00 Volts >= 5 Seconds >= 0 Seconds	50.00 failures out of 63.00 samples 100 ms /sample Continuous	Type A, 1 Trips Note: In certain controllers P0267 may also set (Injector 3 Short to Ground)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Open Circuit - (PFI)	P0204	Controller specific output driver circuit diagnoses Injector 4 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	 >= 200 KOhms impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11.00 Volts >= 5 Seconds >= 0 Seconds	50.00 failures out of 63.00 samples 100 ms /sample Continuous	Type A, 1 Trips Note: In certain controllers P0270 may also set (Injector 4 Short to Ground)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to ground (PFI)	P0261	Controller specific output driver circuit diagnoses Injector 1 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 0.5 Ohms impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11.00 Volts >= 5 Seconds >= 0 Seconds	50.00 failures out of 63.00 samples 100 ms /sample Continuous	Type A, 1 Trips Note: In certain controllers P0201 may also set (Injector 1 Open Circuit)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to power (PFI)	P0262	Controller specific output driver circuit diagnoses Injector 1 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 0.5 Ohms impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running	>= 11.00 Volts >= 5 Seconds >= 0 Seconds	50.00 failures out of 63.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to ground (PFI)	P0264	Controller specific output driver circuit diagnoses Injector 2 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 0.5 Ohms impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11.00 Volts >= 5 Seconds >= 0 Seconds	50.00 failures out of 63.00 samples 100 ms /sample Continuous	Type A, 1 Trips Note: In certain controllers P0202 may also set (Injector 2 Open Circuit)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to power (PFI)	P0265	Controller specific output driver circuit diagnoses Injector 2 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 0.5 Ohms impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running	>= 11.00 Volts >= 5 Seconds >= 0 Seconds	50.00 failures out of 63.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to ground (PFI)	P0267	Controller specific output driver circuit diagnoses Injector 3 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	 <= 0.5 Ohms impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11.00 Volts >= 5 Seconds >= 0 Seconds	50.00 failures out of 63.00 samples 100 ms /sample Continuous	Type A, 1 Trips Note: In certain controllers P0203 may also set (Injector 3 Open Circuit)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to power (PFI)	P0268	Controller specific output driver circuit diagnoses Injector 3 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 0.5 Ohms impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running	>= 11.00 Volts >= 5 Seconds >= 0 Seconds	50.00 failures out of 63.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to ground (PFI)	P0270	Controller specific output driver circuit diagnoses Injector 4 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	 <= 0.5 Ohms impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11.00 Volts >= 5 Seconds >= 0 Seconds	50.00 failures out of 63.00 samples 100 ms /sample Continuous	Type A, 1 Trips Note: In certain controllers P0204 may also set (Injector 4 Open Circuit)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to power (PFI)	P0271	Controller specific output driver circuit diagnoses Injector 4 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 0.5 Ohms impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running	>= 11.00 Volts >= 5 Seconds >= 0 Seconds	50.00 failures out of 63.00 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Output Speed Sensor (TOSS)	P0502	The diagnostic monitor detects no activity in the TOSS circuit due to an electrical fault, wiring fault or sensor fault. The TOSS signal is rationalized against operating conditions of the vehicle. If the vehicle is in motion, accelerator pedal, engine torque, transmission in gear, and no vehicle braking, and the TOSS signal registers below a threshold, the DTC will set.	transmission output speed raw	≤ 20 RPM	service mode $04 active diagnostic monitor enable PTO active ignition voltage (controller run crank ignition in range) engine load enable occurs when: (accelerator pedal position engine torque) engine load disable occurs when: (accelerator pedal position engine torque OR accelerator pedal position engine torque) brake pedal position brake pedal position engine speed engine speed P0503 test fail this key on if clutch pedal is enabled clutch pedal position clutch pedal position P0502 test fail this key on OR P0502 fault active DTCs not fault active	= FALSE = 1 Boolean = FALSE ≥ 11.00 volts ≥ 15.0 % ≥ 90.0 Nm ≤ 6.0 % ≤ 65.0 Nm > 6.0 % ≤ 65.0 Nm ≤ 1.9 % < 80.0 % ≥ 6,500.0 RPM ≤ 1,500.0 RPM = FALSE = 1 Boolean ≥ 89.0 % > 84.0 % = FALSE = FALSE AcceleratorPedalFailure EngineTorqueEstInaccurate	fail time ≥ 0.5 seconds 100 millisecond update rate	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Output Speed Sensor (TOSS)	P0503	The diagnostic monitor detects an unrealistic drop in the TOSS signal due to a sudden electrical fault, wiring fault or sensor fault. The TOSS signal is rationalized against operating conditions of the vehicle. If the vehicle is in motion, accelerator pedal, engine torque, transmission in gear, and no vehicle braking, and the TOSS signal drops above a delta threshold, a fail timer is enabled. When a TOSS drop occurs it is possible to enable the P0502 fail time as well as the P0503 fail time. With both P0502 and P0503 fail timers active it is a race condition to either DTC.	ABS(raw transmssion output speed current loop - raw transmssion output speed previous loop), 25 millisecond update rate	≥ delta fail threshold RPM	service mode $04 active diagnostic monitor enable PTO active ignition voltage (controller run crank ignition in range)	= FALSE = 1 Boolean = FALSE ≥ 11.00 volts	fail time ≥ 3.250 seconds, increment fail count, fail count ≥ 5 counts, 25 millisecond update rate	Type A, 1 Trips
					4WD range current loop, update 4WD range time, reset 4WD range time when	≠ 4WD range previous loop	4wd range time ≥ 6.00 seconds	
					4WD range current loop	≠ 4WD range previous loop		
					raw transmission output speed OR	≥ 300.0 RPM	transmission output speed active time ≥ 2.00 seconds	
					last valid transmision output speed before delta drop, update transmission output speed active time	≥ 300.0 RPM		
					25 millisecond loop to loop transmision output speed positive delta, update transmission output speed stable time	≤ 150.0 RPM	transmission output speed stable time ≤ 2.000 seconds	
					P0503 fault active OR P0503 test fail this key on	= FALSE = FALSE		
					if shift lever position is enable: (shift lever position previous loop AND shift lever position current loop) OR shift lever position current	= 0 Boolean = NEUTRAL = IN GEAR = IN GEAR	shift lever position stablity time ≥ 0.500 seconds	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					loop, update shift lever position stablity time P0503 fault pending delta fail threshold P0503 fault pending clutch pedal position select delta fail threshold where mesaured ratio = TISS/TOSS: 1st gear mesaured ratio mesaured ratio delta fail threshold, mesaured ratio mesaured ratio delta fail threshold, 2nd gear mesaured ratio mesaured ratio delta fail threshold, mesaured ratio mesaured ratio delta fail threshold, 3rd gear mesaured ratio mesaured ratio delta fail threshold, mesaured ratio mesaured ratio delta fail threshold, 4th gear mesaured ratio mesaured ratio delta fail threshold, mesaured ratio mesaured ratio delta fail threshold, 5th gear mesaured ratio	 = TRUE = 300.0 RPM = FALSE ≥ 89.00 % ≥ 14.000 ≤ 15.179 = 300.0 RPM ≤ 14.000 ≥ 7.871 = 300.0 RPM ≥ 7.200 ≤ 7.871 = 300.0 RPM ≤ 7.200 ≥ 5.070 = 300.0 RPM ≥ 4.600 ≤ 5.070 = 300.0 RPM ≤ 4.600 ≥ 4.087 = 300.0 RPM ≥ 3.600 ≤ 4.087 = 300.0 RPM ≤ 3.600 ≥ 3.310 = 300.0 RPM ≥ 2.900		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					mesaured ratio delta fail threshold, mesaured ratio mesaured ratio delta fail threshold, 6th gear mesaured ratio mesaured ratio delta fail threshold, mesaured ratio mesaured ratio delta fail threshold, 7th gear mesaured ratio mesaured ratio delta fail threshold, otherwise delta fail threshold P0503 fault pending clutch pedal position delta fail threshold	≤ 3.310 = 300.0 RPM ≤ 2.900 ≥ 3.310 = 300.0 RPM ≥ 2.900 ≤ 3.310 = 300.0 RPM ≤ 2.900 ≥ 13.990 = 300.0 RPM ≥ 12.900 ≤ 13.990 = 300.0 RPM = 300.0 RPM = FALSE ≤ 84.00 % = 300.0 RPM		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Range / Performance	P08A8	A Clutch Pedal position sensor range fault is detected, if Clutch Pedal Position Sensor is in a range indicative of a vehicle NOT in gear, when the vehicle is determined to be in gear. Gear determination is made by verifying that the ratio of engine RPM versus Transmission Output Speed (N/TOS) represents a valid gear. When this occurs a clutch pedal position error is measured and processed by a 1st order lag filter. When this clutch pedal position error exceeds the defined threshold, this fault code is set.	Filtered Clutch Pedal Position Error when the vehicle is determined to be in gear	> 4 %	N/TOS Ratio: Transfer Case: Vehicle speed: Engine Torque: Clutch Pedal Position: OR No Active DTCs:	Must match actual gear (i.e. vehicle in gear) Not in 4WD Low range > 4.3 MPH > **P08A8 EngTorqueThreshold Table** (see Supporting Tables) < **P08A8 ResidualErrEnableLow Table** (see Supporting Tables) > **P08A8 ResidualErrEnableHigh Table** (see Supporting Tables) ClutchPstnSnsrCktHi FA ClutchPstnSnsrCktLo FA CrankSensor_FA Transmission Output Shaft Angular Velocity Validity VehicleSpeedSensor_FA	12.5 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Low	P08A9	A continuous circuit Out-of-Range Low or open fault is detected by monitoring the percent voltage range of the clutch pedal position signal. This sensor by design is dead banded at both the high and low positions. If the voltage from the sensor is below the defined threshold value for the dead banded region, a fail counter increments. When the correct ratio of fail counts to samples occurs the fault code is set.	Clutch Position Sensor Circuit	< 4 % of Vref	Engine Not Cranking System Voltage	> 9.0 Volts	400 counts out of 500 samples 12.5 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit High	P08AA	A continuous circuit Out-of-Range High fault is detected by monitoring the percent voltage range of the clutch pedal position signal. This sensor by design is dead banded at both the high and low positions. If the voltage from the sensor is above the defined threshold value for the dead banded region, a fail counter increments. When the correct ratio of fail counts to samples occurs the fault code is set.	Clutch Position Sensor Circuit	> 96 % of Vref	Engine Not Cranking System Voltage	> 9.0 Volts	400 counts out of 500 samples 12.5 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Not Learned	P08AC	During final assembly at the manufacturing facility an initial Clutch Pedal Applied Learn is established. This Learn is used to understand the variation in the clutch fully applied position vs. the clutch pedal position. This position is then adjusted over time based on a learning algorithm in the engine controller to adjust for clutch physical wear with usage. This Diagnostic is used to detect when this Applied Learn value is outside of defined range based on the thresholds set by the diagnostic. If the Applied Learn value is outside of the range of the threshold values this fault code is set. The OBD Manufacturer's enable counter is utilized to prevent the MIL from setting during the vehicle assembly before a Position lean can be completed in the manufacturing facility.	Fully Applied Learn Position OR	< 7.0 % > 33.0 %	OBD Manufacturer's Enable Counter	= 0	250 ms loop Continuous	Type A, 1 Trips

Initial Supporting table - Deac MAP Threshold

Description: Deac MAP Threshold Calibration

Value Units: kPa
X Unit: MAP Filtered (kPa)
Y Units: Cyl Deac Count (counts)

y/x	1.00	2.00	3.00	4.00	5.00	6.00
0.20	0.20	-0.20	-0.60	-0.60	-0.60	-0.80
0.80	0.20	-0.20	-0.60	-0.60	-0.60	-0.80
0.85	0.00	-0.20	-0.60	-0.60	-0.60	-0.80
0.90	-0.20	-0.40	-0.60	-0.60	-0.60	-0.80
0.95	-0.60	-0.60	-0.60	-0.60	-0.60	-1.00
1.00	-0.80	-0.80	-0.80	-0.80	-0.80	-1.00

Initial Supporting table - HPESFailCoeffA

Description: Cofficient A for HPES diagnostic failure threshold.

Value Units: None
X Unit: Fire skip status (none)

y/x	0	1	2	3	4	5	6	7
1	0	2	0	-26	4	0	-20	-17

Initial Supporting table - HPESFailCoeffB

Description: Cofficient B for HPES diagnostic failure threshold.

Value Units: None
X Unit: Fire skip status (none)

y/x	0	1	2	3	4	5	6	7
1	14	35	52	51	27	21	42	41

Initial Supporting table - HPESFailCoeffC

Description: Cofficient B for HPES diagnostic failure threshold.

Value Units: None
X Unit: Fire skip status (none)

y/x	0	1	2	3	4	5	6	7
1	1,250	-1,000	0	0	-1,000	0	0	0

Initial Supporting table - P01F0 - Heat To Coolant Min

Description: KtETHD_P_CDD_HeatToCoolantMin

Value Units: Indicated Power (kW)
X Unit: Ambient temperature (°C)

y/x	0	20	50	80	100
1	0	20	50	80	100

Initial Supporting table - P129F Threshold High

Description: P129F Filtered Fuel Pump Speed Error High Threshold [over-performing motor]
Instantaneously calculated filtered pump speed error measured is higher than commanded

Value Units: revs / min
X Unit: revs / min [commanded pump speed]
Y Units: kiloPascals [requested fuel pressure]

y/x	200.0	300.0	400.0	500.0	600.0
1,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
2,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
3,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
4,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
5,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
6,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
7,000.0	-1,200.0	-1,200.0	-1,200.0	-1,200.0	-1,200.0

Initial Supporting table - P129F Threshold Low

Description: P129F Filtered Fuel Pump Speed Error Low Threshold [under-performing motor]
Instantaneously calculated filtered pump speed error measured is lower than commanded

Value Units: revs / min
X Unit: revs / min [commanded pump speed]
Y Units: kiloPascals [requested fuel pressure]

y/x	200.0	300.0	400.0	500.0	600.0
1,000.0	675.0	675.0	675.0	675.0	675.0
2,000.0	675.0	675.0	675.0	675.0	675.0
3,000.0	675.0	675.0	675.0	675.0	675.0
4,000.0	675.0	675.0	675.0	675.0	675.0
5,000.0	675.0	675.0	675.0	675.0	675.0
6,000.0	675.0	675.0	675.0	675.0	675.0
7,000.0	1,200.0	1,200.0	1,200.0	1,200.0	1,200.0

Initial Supporting table - P219A Quality Factor Bank1 Table

Description: Bank 1 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

Value Units: Unitless Scalar
X Unit: Engine Speed (RPM)
Y Units: Air Per Cylinder (APC) (mg/cylinder)

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,500	4,000	4,500	5,000	6,000
40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
80	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
120	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
160	0.00	1.00	0.00	0.00	0.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
200	0.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
240	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
280	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
320	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
360	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
400	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
440	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
480	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
520	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
560	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
640	0.00	0.00	1.00	1.00	1.00	0.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
720	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
800	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

Initial Supporting table - P219B Quality Factor Bank2 Table

Description: Bank 2 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

Value Units: Unitless Scalar
X Unit: Engine Speed (RPM)
Y Units: Air Per Cylinder (APC) (mg/cylinder)

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,500	4,000	4,500	5,000	6,000
40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
80	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
120	0.00	1.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
160	0.00	1.00	0.00	0.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
200	0.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
240	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
280	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
320	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
360	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
400	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
440	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
480	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
520	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
560	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
640	0.00	0.00	1.00	1.00	0.00	0.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
720	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
800	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

Initial Supporting table - P2635 Max Fuel Flow

Description: P2635 Maximum Fuel Flow Disable Criteria
Maximum allowed fuel flow values above which the diagnostic is disabled

Value Units: grams / second
X Unit: kilopascals [commanded fuel pressure]
Y Units: volts [device supply]

y/x	200	250	300	350	400	450	500	550	600
5	512	512	512	512	512	512	512	512	512
6	512	512	512	512	512	512	512	512	512
8	512	512	512	512	512	512	512	512	512
9	512	512	512	512	512	512	512	512	512
11	512	512	512	512	512	512	512	512	512
12	512	512	512	512	512	512	512	512	512
14	512	512	512	512	512	512	512	512	512
15	512	512	512	512	512	512	512	512	512
17	512	512	512	512	512	512	512	512	512
18	512	512	512	512	512	512	512	512	512
20	512	512	512	512	512	512	512	512	512
21	512	512	512	512	512	512	512	512	512
23	512	512	512	512	512	512	512	512	512
24	512	512	512	512	512	512	512	512	512
26	512	512	512	512	512	512	512	512	512
27	512	512	512	512	512	512	512	512	512
29	512	512	512	512	512	512	512	512	512

Initial Supporting table - P2635 Threshold High

Description: P2635 Filtered Fuel Pressure Error High Threshold [under-performing pump]
Instantaneously calculated filtered fuel pressure error

Value Units: kilopascals
X Unit: kilopascals [commanded fuel pressure]
Y Units: grams / sec [fuel flow]

y/x	200	250	300	350	400	450	500	550	600
0	30	38	45	53	60	68	75	83	90
2	30	38	45	53	60	68	75	83	90
3	30	38	45	53	60	68	75	83	90
5	30	38	45	53	60	68	75	83	90
6	30	38	45	53	60	68	75	83	90
8	30	38	45	53	60	68	75	83	90
9	30	38	45	53	60	68	75	83	90
11	30	38	45	53	60	68	75	83	90
12	30	38	45	53	60	68	75	83	90
14	30	38	45	53	60	68	75	83	90
15	30	38	45	53	60	68	75	83	90
17	30	38	45	53	60	68	75	83	90
18	30	38	45	53	60	68	75	83	90
20	30	38	45	53	60	68	75	83	90
21	30	38	45	53	60	68	75	83	90
23	30	38	45	53	60	68	75	83	90
24	30	38	45	53	60	68	75	83	90
26	30	38	45	53	60	68	75	83	90
27	30	38	45	53	60	68	75	83	90
29	30	38	45	53	60	68	75	83	90
30	30	38	45	53	60	68	75	83	90
32	30	38	45	53	60	68	75	83	90
33	30	38	45	53	60	68	75	83	90
35	30	38	45	53	60	68	75	83	90
36	30	38	45	53	60	68	75	83	90
38	30	38	45	53	60	68	75	83	90
39	30	38	45	53	60	68	75	83	90
41	30	38	45	53	60	68	75	83	90
42	30	38	45	53	60	68	75	83	90
44	30	38	45	53	60	68	75	83	90
45	30	38	45	53	60	68	75	83	90

Initial Supporting table - P2635 Threshold High

47	30	38	45	53	60	68	75	83	90
48	30	38	45	53	60	68	75	83	90

Initial Supporting table - P2635 Threshold Low

Description: P2635 Filtered Pressure Error Low Threshold [over-performing pump]
Instantaneously calculated filtered fuel pressure error

Value Units: kilopascals
X Unit: kilopascals [commanded fuel pressure]
Y Units: grams / second [fuel flow]

y/x	200	250	300	350	400	450	500	550	600
0	-260	-210	-160	-110	-60	-68	-75	-83	-90
2	-145	-125	-103	-81	-60	-68	-75	-83	-90
3	-30	-38	-45	-53	-60	-68	-75	-83	-90
5	-30	-38	-45	-53	-60	-68	-75	-83	-90
6	-30	-38	-45	-53	-60	-68	-75	-83	-90
8	-30	-38	-45	-53	-60	-68	-75	-83	-90
9	-30	-38	-45	-53	-60	-68	-75	-83	-90
11	-30	-38	-45	-53	-60	-68	-75	-83	-90
12	-30	-38	-45	-53	-60	-68	-75	-83	-90
14	-30	-38	-45	-53	-60	-68	-75	-83	-90
15	-30	-38	-45	-53	-60	-68	-75	-83	-90
17	-30	-38	-45	-53	-60	-68	-75	-83	-90
18	-30	-38	-45	-53	-60	-68	-75	-83	-90
20	-30	-38	-45	-53	-60	-68	-75	-83	-90
21	-30	-38	-45	-53	-60	-68	-75	-83	-90
23	-30	-38	-45	-53	-60	-68	-75	-83	-90
24	-30	-38	-45	-53	-60	-68	-75	-83	-90
26	-30	-38	-45	-53	-60	-68	-75	-83	-90
27	-30	-38	-45	-53	-60	-68	-75	-83	-90
29	-30	-38	-45	-53	-60	-68	-75	-83	-90
30	-30	-38	-45	-53	-60	-68	-75	-83	-90
32	-30	-38	-45	-53	-60	-68	-75	-83	-90
33	-30	-38	-45	-53	-60	-68	-75	-83	-90
35	-30	-38	-45	-53	-60	-68	-75	-83	-90
36	-30	-38	-45	-53	-60	-68	-75	-83	-90
38	-30	-38	-45	-53	-60	-68	-75	-83	-90
39	-30	-38	-45	-53	-60	-68	-75	-83	-90
41	-30	-38	-45	-53	-60	-68	-75	-83	-90
42	-30	-38	-45	-53	-60	-68	-75	-83	-90
44	-30	-38	-45	-53	-60	-68	-75	-83	-90
45	-30	-38	-45	-53	-60	-68	-75	-83	-90

Initial Supporting table - P2635 Threshold Low

47	-30	-38	-45	-53	-60	-68	-75	-83	-90
48	-30	-38	-45	-53	-60	-68	-75	-83	-90

Initial Supporting table - Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests

Description: This table describes the adaptive (Block Learn) cells in which to enable the Post (Secondary) Oxygen sensor response tests.
Note: When the table column heading matches the calibration value below it, that individual cell is enabled.

The cell numbers in the table are defined as:
CeFADR_e_Cell00_PurgOnAirMode5 = 0,
CeFADR_e_Cell01_PurgOnAirMode4 = 1,
CeFADR_e_Cell02_PurgOnAirMode3 = 2,
CeFADR_e_Cell03_PurgOnAirMode2 = 3,
CeFADR_e_Cell04_PurgOnAirMode1 = 4,
CeFADR_e_Cell05_PurgOnAirMode0 = 5,
CeFADR_e_Cell06_PurgOnIdle = 6,
CeFADR_e_Cell07_PurgOnDecel = 7,
CeFADR_e_Cell08_PurgOffAirMode5 = 8,
CeFADR_e_Cell09_PurgOffAirMode4 = 9,
CeFADR_e_Cell10_PurgOffAirMode3 = 10,
CeFADR_e_Cell11_PurgOffAirMode2 = 11,
CeFADR_e_Cell12_PurgOffAirMode1 = 12,
CeFADR_e_Cell13_PurgOffAirMode0 = 13,
CeFADR_e_Cell14_PurgOffIdle = 14,
CeFADR_e_Cell15_PurgOffDecel = 15

Value Units: Block Learn cell number
X Unit: Block Learn cell number

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	7	7	7	7	7	7	7	7	15	15	15	15	15	15	15	15

Initial Supporting table - Multiple DTC Use - Response Cell Enable Table

Description: This table describes the Block learn cells which enable the Pre (Primary) Oxygen sensor response tests.
Note: When the table column heading matches the calibration value below it, that individual cell is enabled.

Value Units: Block Learn cell name and number
X Unit: Block Learn cell name and number

Multiple DTC Use - Response Cell Enable Table - Part 1				
y/x	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR_e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2
1	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR_e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2
Multiple DTC Use - Response Cell Enable Table - Part 2				
y/x	CeFADR_e_Cell04_PurgOnAirMode 1	CeFADR_e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
1	CeFADR_e_Cell04_PurgOnAirMode 1	CeFADR_e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
Multiple DTC Use - Response Cell Enable Table - Part 3				
y/x	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR_e_Cell10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2
1	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR_e_Cell10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2
Multiple DTC Use - Response Cell Enable Table - Part 4				
y/x	CeFADR_e_Cell12_PurgOffAirMode 1	CeFADR_e_Cell13_PurgOffAirMode 0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel
1	CeFADR_e_Cell12_PurgOffAirMode 1	CeFADR_e_Cell13_PurgOffAirMode 0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel

Initial Supporting table - Multiple DTC Use_Green Sensor Delay Criteria - Limit

Description: This Calibration is the acculmulated airflow limit above which the Green condition is expired
Used for: P0133, P013A, P013B, P013C, P013D, P013E, P013F, P014A, P014B, P0153, P015A, P015B, P015C, P015D, P1133, P1153, P2270, P2271, P2272 and P2273.
Note: This feature is only enabled when the vehicle is new and cannot be enabled in service.

Value Units: Grams
X Unit: Acculmulated Engine Airflow

y/x	CiOXYR_O2_Bank1_Sensor1	CiOXYR_O2_Bank1_Sensor2	CiOXYR_O2_Bank2_Sensor1	CiOXYR_O2_Bank2_Sensor2
1	120,000	120,000	120,000	120,000

Initial Supporting table - P0011_CamPosErrorLimIc1

Description: Maximum Intake Cam 1 phase error as a function of engine speed and engine oil temperature.

Value Units: Maximum Intake Cam 1 phase error (degCAM)
X Unit: Engine Oil Temperature (degC)
Y Units: Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
1,200	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
1,600	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
2,000	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
2,400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
2,800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
3,200	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
3,600	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
4,000	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
4,400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
4,800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
5,200	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
5,600	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
6,000	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
6,400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
6,800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0

Initial Supporting table - P0011_P0021_P05CC_P05CD_EngOilPressEnblIc

Description: Delay time before the oil pressure enable flag is set assuming all the oil pressure enable criteria are met

Value Units: Time (sec)
X Unit: Engine Coolant Temperature (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	8	8	8	6	4	3	2	1	1	1	1	1	1	1	1	2	3

Initial Supporting table - P0011_P0021_P05CC_P05CD_HiEngSpdHiDsbllc

Description: Minimum engine speed to disable Intake cam

Value Units: Engine Speed (rpm)
X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000

Initial Supporting table - P0011_P0021_P05CC_P05CD_HiEngSpdLoEnbllc

Description: Maximum engine speed to enable Intake cam - works as hysteresis.

Value Units: Engine Speed (rpm)
X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800

Initial Supporting table - P0011_P0021_P05CC_P05CD_LoPresHiEnblIc

Description: Intake cam is enabled when oil pressure exceeds this value

Value Units: Engine Speed (rpm)
X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180

Initial Supporting table - P0011_P0021_P05CC_P05CD_LoPresLoDsbllc

Description: Intake cam is disabled when oil pressure falls below this value

Value Units: Engine Oil Pressure (kPa)
X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	145	145	145	145	135	125	125	125	125	125	125	125	125	125	135	145	145

Initial Supporting table - P0011_P0021_P05CC_P05CD_LoRpmHiEnblIc

Description: Intake cam is enabled when engine speed exceeds this value.

Value Units: Engine Speed (rpm)
X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	900	900	800	800	700	700	700	700	700	700	700	700	700	700	800	800	800

Initial Supporting table - P0011_P0021_P05CC_P05CD_LoRpmLoDsbllc

Description: Intake cam is disabled when engine speed is below this value.

Value Units: Engine Speed (rpm)
X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	750	750	700	700	650	650	650	650	650	650	650	650	650	650	700	700	700

Initial Supporting table - P0011_P0021_P05CC_P05CD_P0014_P0024_P05CE_P05CF_ColdStartEngRunning

Description: Engine running time must be greater than this threshold during a cold start to enable cam phasing

Value Units: Time (sec)
X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	15	15	14	13	12	11	10	9	8	7	6	5	4	4	4	4	4

Initial Supporting table - P0011_P05CC_StablePositionTimeIc1

Description: Minimum time for Intake Cam 1 phase position to be stable to enable performance diagnostic.

Value Units: Minimum time (sec)
X Unit: Engine Oil Temperature (degC)
Y Units: Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
1,200	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
1,600	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
2,000	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
2,400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
2,800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
3,200	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
3,600	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
4,000	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
4,400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
4,800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
5,200	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
5,600	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
6,000	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
6,400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
6,800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4

Initial Supporting table - P0014_P0024_P05CE_P05CF_EngOilPressEnblEc

Description: Delay time before the oil pressure enable flag is set assuming all the oil pressure enable criteria are met

Value Units: Time (sec)
X Unit: Engine Coolant Temperature (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3

Initial Supporting table - P0014_P0024_P05CE_P05CF_HiEngSpdHiDsblEc

Description: Exhaust cam is disabled when engine speed exceeds this value

Value Units: Engine Speed (rpm)
X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Initial Supporting table - P0014_P0024_P05CE_P05CF_HiEngSpdLoEnblEc

Description: Exhaust cam is enabled when engine speed remains below this value

Value Units: Engine Speed (rpm)
X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Initial Supporting table - P0014_P0024_P05CE_P05CF_LoPresHiEnblEc

Description: Exhaust cam is enabled when oil pressure exceeds this value

Value Units: Engine Oil Pressure (kPa)
X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180

Initial Supporting table - P0014_P0024_P05CE_P05CF_LoPresLoDsblEc

Description: Exhaust cam is disabled when oil pressure falls below this value

Value Units: Engine Oil Pressure (kPa)
X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	125	125	125	125	125	125	125	125	125	125	125	125	125	125	125	125	125

Initial Supporting table - P0014_P0024_P05CE_P05CF_LoRpmHiEnblEc

Description: Exhaust cam is enabled when engine speed exceeds this value.

Value Units: Engine Speed (rpm)
X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	900	900	800	800	700	700	700	700	700	700	700	700	700	700	800	800	800

Initial Supporting table - P0014_P0024_P05CE_P05CF_LoRpmLoDsblEc

Description: Exhaust cam is disabled when engine speed is below this value.

Value Units: Engine Speed (rpm)
X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	750	750	750	750	750	750	750	750	750	750	750	750	750	750	750	750	750

Initial Supporting table - P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold

Description: P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold

Value Units: Engine Run Time- Seconds
X Unit: Oil Temperature- C

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	300	300	160	18	18	18	18	10	3	3	3	3	3	3	3	3	3

Initial Supporting table - P0071: OAT Performance Drive Equilibrium Engine Off

Description: OAT Performance Diagnostic counter increment for determining OAT-IAT equilibrium for engine off (for hybrid applications)

Value Units: Counter Increment Value (Unitless)
X Unit: Vehicle Speed (KPH)

y/x	0.0	20.0	30.0	45.0	60.0	75.0	90.0	105.0	120.0
1.0	0.0	4.0	6.0	6.8	7.8	7.8	8.0	8.0	8.0

Initial Supporting table - P0071: OAT Performance Drive Equilibrium Engine Running

Description: OAT Performance Diagnostic counter increment for determining OAT-IAT equilibrium for engine running

Value Units: Counter Increment Value (Unitless)
X Unit: Vehicle Speed (KPH)
Y Units: Engine Air Flow (Grams/Second)

y/x	0.0	20.0	30.0	45.0	60.0	75.0	90.0	105.0	120.0
0.0	1.0	5.0	7.0	7.5	8.0	9.0	9.0	9.0	9.0
15.0	-5.0	1.0	2.0	2.5	3.0	3.5	4.0	4.5	5.0
25.0	-4.0	1.0	2.0	2.5	3.0	3.5	4.0	4.5	5.0
35.0	-2.0	1.0	2.0	2.5	3.0	3.5	4.0	4.5	5.0
45.0	-1.0	2.0	3.0	3.5	4.0	4.5	5.0	5.5	6.0
55.0	0.0	2.0	3.0	3.5	4.0	4.5	5.0	5.5	6.0
65.0	0.0	3.0	4.0	4.5	5.0	5.5	6.0	6.5	7.0
75.0	0.0	4.0	5.0	5.5	6.0	6.5	7.0	7.5	8.0
85.0	1.0	5.0	6.0	6.5	7.0	7.5	8.0	8.5	9.0

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP1 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.000

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP2 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.000

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 TPS Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	0.500	0.670	0.750	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.000

Initial Supporting table - P0133_KnEOSD_t_ST_LRC_LimRS1

Description: X Table Axis for P0133

Value Units: Seconds
X Unit: X Table Axis for P0133, L2R Response time breakpoints for table

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.030	0.045	0.060	0.075	0.090	0.105	0.120	0.135	0.150	0.165	0.180	0.195	0.210	0.225	0.240	1.000

Initial Supporting table - P0133_KnEOSD_t_ST_RLC_LimRS1

Description: Y Table Axis for P0133

Value Units: Seconds
Y Units: Y Table Axis for P0133, R2L Response time breakpoints for table

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.045	0.060	0.075	0.090	0.105	0.120	0.135	0.150	0.165	0.180	0.195	0.210	0.225	0.240	0.255	1.000

Initial Supporting table - P0133_O2S Slow Response Bank 1 Sensor 1 Pass/Fail Threshold table

Description: This table discribes the Pass and Fail regions based on the diagnostic test result

Value Units: If the cell contains a "0" then the fault is indicated, if it contains a "1" a fault is not indicated.
X Unit: X axis is Lean to Rich response time (in sec), Please see the table below named "KnEOSD_t_ST_LRC_LimRS1" for the 17 X axis table breakpoints.
Y Units: Y axis is Rich to Lean response time (in sec), Please see the table below named "KnEOSD_t_ST_RLC_LimRS1" for the 17 Y axis table breakpoints.

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0	0
1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
2	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
3	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0
4	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
5	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
6	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
7	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
8	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
9	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
10	0	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
11	0	0	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
12	0	0	0	1	1	1	1	1	1	1	1	1	1	0	0	0	0
13	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
15	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Initial Supporting table - P0153_KnEOSD_t_ST_LRC_LimRS2

Description: X Table Axis for P0153

Value Units: Seconds
X Unit: X Table Axis for P0153, L2R Response time breakpoints for table

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.030	0.045	0.060	0.075	0.090	0.105	0.120	0.135	0.150	0.165	0.180	0.195	0.210	0.225	0.240	1.000

Initial Supporting table - P0153_KnEOSD_t_ST_RLC_LimRS2

Description: Y Table Axis for P0153

Value Units: Seconds
Y Units: Y Table Axis for P0153, R2L Response time breakpoints for table

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.045	0.060	0.075	0.090	0.105	0.120	0.135	0.150	0.165	0.180	0.195	0.210	0.225	0.240	0.255	1.000

Initial Supporting table - P0153_O2S Slow Response Bank 2 Sensor 1 Pass/Fail Threshold table

Description: This table discribes the Pass and Fail regions based on the diagnostic test result

Value Units: If the cell contains a "0" then the fault is indicated, if it contains a "1" a fault is not indicated.
X Unit: X axis is Lean to Rich response time (in sec), Please see the table below named "KnEOSD_t_ST_LRC_LimRS2" for the 17 X axis table breakpoints.
Y Units: Y axis is Rich to Lean response time (in sec), Please see the table below named "KnEOSD_t_ST_RLC_LimRS2" for the 17 Y axis table breakpoints.

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0	0
1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
2	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
3	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0
4	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
5	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
6	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
7	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
8	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
9	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
10	0	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
11	0	0	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
12	0	0	0	1	1	1	1	1	1	1	1	1	1	0	0	0	0
13	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
15	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Initial Supporting table - P050D_P1400_CatalystLightOffExtendedEngineRunTimeExit

Description: Exit Catalyst Warm-up mode if Engine Run Time is greater than this value. This table is based on percent ethanol (x-axis) and catmon's NormRatio_EWMA value (y-axis). The NormRatio_EWMA value determines the state of the catalyst. Typically, NormRatio_EWMA values below 0.35 (0 is bad and 1 is good) represent catalysts that have degraded. The emission performance of these degraded catalysts can be improved by extending catalyst light off of GetE85R_Pct_FFS_CompAtEngFloat.

y/x	0	25	50	75	100
0.000	30	30	30	30	30
0.125	30	30	30	30	30
0.250	30	30	30	30	30
0.375	30	30	30	30	30
0.500	20	20	20	20	20
0.625	20	20	20	20	20
0.750	20	20	20	20	20
0.875	20	20	20	20	20
1.000	20	20	20	20	20

Initial Supporting table - P1400_ColdStartDiagnosticDelayBasedOnEngineRunTime

Description: Quality weight-based on engine run time. This allows adjustment of the weighting factors at various engine run times in order to prevent the updating of the cumulative quality timer or to change the value of the average qualified residual energy calculation to prevent false Fails of the diagnostic under circumstances inappropriate to update the calculation of the average qualified residual value.

y/x	0	2	2	4	5	10	15	20	30
1	0	0	1	1	1	1	1	1	1

Initial Supporting table - P1400_ColdStartDiagnosticDelayBasedOnEngineRunTimeCalAxis

Description: This is the x-axis for the KtCSED_K_TimeWght calibration table. Refer to the description for KtCSED_K_TimeWght for details.

y/x	1	2	3	4	5	6	7	8	9
1	0	2	2	4	5	10	15	20	30

Initial Supporting table - P1400_EngineSpeedResidual_Table

Description: This 1x17 table of engine exhaust flow values is used to calculate both the desired and the actual engine exhaust flow based on desired and actual engine speed. The desired engine exhaust flow is gathered from the desired engine speed (VeSPDR_n_EngDsrd). The value used for the actual engine exhaust flow is based on the actual engine RPM value.

y/x	600	750	800	830	850	900	950	1,000	1,030	1,060	1,080	1,100	1,130	1,135	1,150	1,300	1,500
1	1	1	5	5	5	5	8	8	8	8	8	11	11	12	12	12	12

Initial Supporting table - P1400_SparkResidual_Table

Description: Predicted engine-out energy potential based on either the desired cold start spark advance value or the actual spark advance value. ExhEngyPerUnitMass calibration is used to calculate both desired exhaust energy and actual energy. The desired and actual exhaust energy per unit mass values are used in part to calculate the desired exhaust energy per unit time and actual exhaust energy per unit time. Both desired and actual go into the residual exhaust energy per unit time calculation.

y/x	-12	-10	-8	-6	-5	-3	0	10	15
1	1.13	1.13	1.13	1.13	1.06	1.00	0.94	0.75	0.63

Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est

Description: P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on MAF Est

Value Units: Weight Factor (Unitless)
X Unit: Estimated Engine Air Flow (Grams/Second)

y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM

Description: P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.900	0.800	0.800	0.800	0.750	0.700	0.000

Initial Supporting table - P0116_Fail if power up ECT exceeds IAT by these values

Description: KtECTD_T_HSC_FastFailTempDiff

Value Units: Fast Failure temp difference (°C)
X Unit: IAT Temperature at Power up (°C)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	80	80	80	60	60	40	40	30	30	30	30	30	30	30	30	30	30

Initial Supporting table - P0128_Maximum Accumulated Energy for Start-up ECT conditions - Alternate

Description: KtECTR_E_CTR_WrmUpEnrgyLimTest1

Value Units: Cooling system energy failure threshold (kJ)
X Unit: Minimum ECT for the key cycle (°C)

y/x	-20	-7	10	30	45	60	85
1	25,192	22,792	19,654	15,962	13,193	10,424	5,809

Initial Supporting table - P0128_Maximum Accumulated Energy for Start-up ECT conditions - Primary

Description: KtECTR_E_CTR_WrmUpEnrgyLimTest0

Value Units: Cooling system energy failure threshold (kJ)
X Unit: Minimum ECT for the key cycle (°C)

y/x	-20	-7	10	30	45	60	85
1	26,291	23,827	20,605	16,814	13,971	11,128	6,389

Initial Supporting table - P0606_Last Seed Timeout f(Loop Time)

Description: The max time for the Last Seed Timeout as a function of operating loop time sequence.

P0606_Last Seed Timeout f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000	200.000

P0606_Last Seed Timeout f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	200.000	500.000	500.000	1,000.000	1,000.000	8,191.875	8,191.875	8,191.875

Initial Supporting table - P0606_PSW Sequence Fail f(Loop Time)

Description: Fail threshold for PSW per operating loop.

P0606_PSW Sequence Fail f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	5	3	5	3	5	3	5	3

P0606_PSW Sequence Fail f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	5	3	5	5	5	3	5	5

Initial Supporting table - P0606_PSW Sequence Sample f(Loop Time)

Description: Sample threshold for PSW per operating loop.

P0606_PSW Sequence Sample f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	4	4	4	4	4	4	4	4

P0606_PSW Sequence Sample f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	4	4	4	4	4	4	4	4

Initial Supporting table - P16F3_Delta MAP Threshold f(Desired Engine Torque)

Description: Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	17.30	17.30	17.30	17.30	17.30	17.30

Initial Supporting table - P16F3_Speed Control External Load f(Oil Temp, RPM)

Description: Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

y/x	-40.00	-20.00	-10.00	0.00	50.00	90.00
300.00	500.00	500.00	500.00	500.00	500.00	500.00
370.00	500.00	500.00	500.00	500.00	500.00	500.00
435.00	500.00	500.00	500.00	500.00	500.00	500.00
550.00	500.00	500.00	500.00	350.00	200.00	150.00
600.00	500.00	500.00	350.00	200.00	81.83	60.94
660.00	500.00	500.00	200.00	134.34	79.97	58.01
800.00	350.00	350.00	141.23	143.49	83.57	53.00
1,000.00	235.66	176.73	140.24	147.42	97.69	70.25
1,300.00	187.35	140.64	111.53	113.52	71.48	33.72
1,600.00	135.96	92.26	64.60	67.72	30.02	-3.96
2,000.00	64.44	24.98	0.65	2.19	-31.02	-34.66
2,500.00	61.31	22.67	-0.80	-0.68	-34.98	-36.01
3,200.00	55.77	16.62	-7.31	-6.38	-40.01	-43.35
4,000.00	44.94	5.66	-18.44	-17.25	-50.70	-55.10
5,000.00	28.88	-10.39	-34.48	-33.30	-66.77	-71.09
6,100.00	9.48	-29.90	-54.12	-52.74	-86.07	-91.22
6,600.00	-0.11	-39.40	-62.94	-62.33	-95.67	-97.48

Initial Supporting table - P00C6 - High Pressure Pump Control Mode timeout

Description: High Pressure Pump Control Mode timeout

Value Units: Time (Seconds)
X Unit: Coolant Temperature (Deg C)

y/x	-40	-35	-30	-25	-20	-10	0	8	16	20	24	32	40	60	80	90	112
1	10.0	10.0	10.0	10.0	10.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

upporting table - P00C6 - maximum acceptable counts of fuel rail pressure below KtFHPD_p_HPS_PressFallLoThrsh after High Pressure Sta

Description: The maximum acceptable counts of fuel rail pressure below KtFHPD_p_HPS_PressFallLoThrsh after High Pressure Start (HPS) is executed but before engine is in run mode.

Value Units: maximum acceptable counts of fuel rail pressure below KtFHPD_p_HPS_PressFallLoThrsh after High Pressure Start (Count)
X Unit: Ethanol Precent (%)
Y Units: Coolant Temperature (Deg C)

y/x	-40	-35	-30	-25	-20	-10	0	8	16	20	24	32	40	60	80	90	112
0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
13	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
25	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
38	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
50	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
63	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
75	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
88	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
100	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

Initial Supporting table - P00C6 - Minimum acceptable value of fuel rail pressure after High Pressure Start

Description: The minimum acceptable value of fuel rail pressure after High Pressure Start (HPS) is executed. This ensures the pressure does not fall off drastically after High Pressure Start (HPS) is executed, but before engine is in run mode.

Value Units: Minimum acceptable value of fuel rail pressure after High Pressure Start (Mpa)
X Unit: Ethanol Precent (%)
Y Units: Coolant Temperature (Deg C)

y/x	-40	-35	-30	-25	-20	-10	0	8	16	20	24	32	40	60	80	90	112
0	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
13	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
25	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
38	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
50	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
63	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
75	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
88	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
100	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6

Initial Supporting table - P00C6 - Minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery

Description: This calibration is the minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery

Value Units: Minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery
X Unit: Ethanol Precent (%)
Y Units: Coolant Temperature (Deg C)

y/x	-40	-35	-30	-25	-20	-10	0	8	16	20	24	32	40	60	80	90	112
0	11.0	12.0	10.0	10.0	8.0	3.0	2.0	1.5	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
13	11.0	12.0	10.0	10.0	8.0	3.0	2.0	1.5	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
25	12.0	12.0	12.0	12.0	8.0	4.0	3.0	2.5	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
38	13.0	13.0	13.0	13.0	10.0	8.6	4.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
50	13.0	13.0	13.0	13.0	10.0	8.6	4.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
63	13.0	13.0	13.0	13.0	10.0	8.6	6.0	5.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
75	13.0	13.0	13.0	13.0	10.0	8.6	6.0	5.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
88	13.0	13.0	13.0	13.0	10.0	8.6	7.0	6.0	5.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
100	13.0	13.0	13.0	13.0	10.0	8.6	7.5	7.0	6.0	5.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0

Initial Supporting table - P0191 - High fail limit of fuel control due to high pressure sensor skewed High

Description: High fail limit of fuel control due to high pressure sensor skewed High error as Function of desired pressure

Value Units: Ratio
X Unit: Desired Pressure (Mpa)

y/x	1.50	3.00	4.00	15.00	20.00	25.00	27.50	32.00	36.00
1.00	1.20	1.20	1.20	1.20	1.20	1.20	1.20	1.09	1.05

Initial Supporting table - P0191 - Low fail limit of fuel control due to pressure sensor skewed low

Description: Low fail limit of fuel control due to pressure sensor skewed low error as Function of desired pressure

Value Units: Ratio
X Unit: Desired Pressure (Mpa)

y/x	1.50	3.00	4.00	15.00	20.00	25.00	27.50	32.00	36.00
1.00	0.86	0.86	0.86	0.86	0.86	0.86	0.86	0.92	0.95

Initial Supporting table - P0420_BestFailingOSCTableB1

Description: This table is a 9x17 table of baseline Best Failing (e.g. threshold converter) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow,the BestFailing OSC value is found within this table for the measured temp and airflow and is used along with the OSC_TimeRaw (and the WorstPassing value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the identified BPU converter that is used for MIL illumination across the specific temp and airflow range for a given program.

y/x	6.24	6.77	7.30	7.83	8.36	8.88	9.41	9.94	10.47	11.00	11.53	12.05	12.58	13.11	13.64	14.17	14.70
610.00	1.13	1.07	1.01	0.92	0.85	0.80	0.74	0.68	0.65	0.60	0.59	0.58	0.56	0.55	0.53	0.52	0.50
645.00	1.17	1.14	1.07	0.98	0.92	0.85	0.82	0.75	0.71	0.66	0.63	0.62	0.60	0.58	0.55	0.54	0.52
681.00	1.23	1.19	1.14	1.02	0.98	0.95	0.90	0.79	0.75	0.70	0.67	0.66	0.64	0.61	0.58	0.55	0.53
717.00	1.27	1.24	1.20	1.08	1.00	0.99	0.96	0.84	0.81	0.74	0.70	0.69	0.67	0.63	0.61	0.57	0.55
753.00	1.31	1.27	1.23	1.12	1.03	0.99	0.97	0.89	0.87	0.82	0.77	0.72	0.71	0.66	0.64	0.59	0.56
789.00	1.32	1.29	1.25	1.14	1.04	1.01	0.97	0.89	0.88	0.86	0.80	0.75	0.74	0.68	0.66	0.62	0.57
824.00	1.35	1.32	1.29	1.16	1.05	1.01	0.97	0.89	0.87	0.85	0.80	0.75	0.73	0.69	0.66	0.63	0.58
860.00	1.36	1.34	1.31	1.16	1.06	1.01	0.96	0.90	0.86	0.85	0.80	0.76	0.74	0.69	0.67	0.63	0.59
896.00	1.39	1.35	1.32	1.18	1.06	1.02	0.96	0.91	0.86	0.86	0.80	0.76	0.74	0.69	0.66	0.64	0.59

Initial Supporting table - P0420_WorstPassingOSCTableB1

Description: This table is a 9x17 table of WorstPassing (e.g. 120k) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the WorstPassing OSC value is found within this table for the measured temp and airflow and is used along with the OSC_TimeRaw (and the BestFailing OSC value) to calculate the Normalized Ratio for that specific test.The values in this table are based on the measured OSC for the WPA part across the temp and airflow range.

y/x	6.24	6.77	7.30	7.83	8.36	8.88	9.41	9.94	10.47	11.00	11.53	12.05	12.58	13.11	13.64	14.17	14.70
610.00	1.55	1.50	1.35	1.26	1.18	1.08	1.00	0.93	0.88	0.86	0.83	0.77	0.75	0.73	0.71	0.70	0.66
645.00	1.65	1.57	1.42	1.32	1.24	1.14	1.08	1.02	0.97	0.93	0.90	0.82	0.80	0.79	0.77	0.76	0.70
681.00	1.73	1.64	1.46	1.35	1.28	1.20	1.15	1.09	1.04	1.00	0.95	0.85	0.84	0.81	0.79	0.78	0.74
717.00	1.79	1.69	1.47	1.37	1.32	1.23	1.18	1.12	1.09	1.06	0.99	0.86	0.85	0.83	0.81	0.79	0.75
753.00	1.84	1.74	1.54	1.41	1.34	1.25	1.20	1.15	1.11	1.08	1.01	0.87	0.86	0.84	0.82	0.80	0.77
789.00	1.87	1.77	1.56	1.45	1.37	1.27	1.22	1.17	1.14	1.10	1.03	0.88	0.87	0.85	0.83	0.81	0.78
824.00	1.90	1.79	1.59	1.49	1.39	1.30	1.24	1.18	1.16	1.12	1.04	0.90	0.88	0.86	0.83	0.82	0.79
860.00	1.91	1.82	1.61	1.52	1.41	1.32	1.25	1.19	1.17	1.14	1.05	0.91	0.90	0.87	0.84	0.82	0.80
896.00	1.92	1.83	1.63	1.54	1.42	1.34	1.27	1.20	1.19	1.15	1.06	0.92	0.91	0.88	0.85	0.83	0.80

Initial Supporting table - P0430_BestFailingOSCTableB2

Description: This table is a 9x17 table of baseline Best Failing (e.g. threshold converter) OSC times for catalyst Bank 2. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow,the BestFailing OSC value is found within this table for the measured temp and airflow and is used along with the OSC_TimeRaw (and the WorstPassing value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the identified BPU converter that is used for MIL illumination across the specific temp and airflow range for a given program.

y/x	6.24	6.77	7.30	7.83	8.36	8.88	9.41	9.94	10.47	11.00	11.53	12.05	12.58	13.11	13.64	14.17	14.70
610.00	0.92	0.94	0.90	0.88	0.86	0.78	0.75	0.67	0.65	0.62	0.59	0.57	0.55	0.52	0.50	0.47	0.44
645.00	1.19	1.19	1.17	1.05	1.03	0.96	0.94	0.78	0.73	0.71	0.66	0.62	0.60	0.58	0.56	0.52	0.45
681.00	1.28	1.27	1.26	1.14	1.07	1.03	0.97	0.90	0.85	0.78	0.72	0.67	0.65	0.61	0.60	0.54	0.47
717.00	1.36	1.31	1.28	1.19	1.09	1.05	0.97	0.93	0.89	0.85	0.81	0.74	0.73	0.67	0.66	0.59	0.48
753.00	1.40	1.38	1.36	1.22	1.11	1.04	0.98	0.92	0.90	0.84	0.82	0.78	0.77	0.69	0.68	0.64	0.50
789.00	1.42	1.39	1.37	1.22	1.11	1.06	0.98	0.92	0.88	0.85	0.81	0.79	0.77	0.70	0.68	0.64	0.52
824.00	1.43	1.39	1.36	1.22	1.12	1.07	0.97	0.92	0.88	0.85	0.82	0.79	0.77	0.71	0.69	0.65	0.53
860.00	1.45	1.42	1.39	1.23	1.13	1.09	0.99	0.93	0.90	0.86	0.82	0.80	0.78	0.72	0.69	0.66	0.54
896.00	1.47	1.45	1.43	1.25	1.14	1.11	1.01	0.95	0.92	0.88	0.84	0.82	0.79	0.73	0.69	0.67	0.55

Initial Supporting table - P0430_WorstPassingOSCTableB2

Description: This table is a 9x17 table of WorstPassing (e.g. 120k) OSC times for catalyst Bank 2. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the WorstPassing OSC value is found within this table for the measured temp and airflow and is used along with the OSC_TimeRaw (and the BestFailing OSC value) to calculate the Normalized Ratio for that specific test.The values in this table are based on the measured OSC for the WPA part across the temp and airflow range.

y/x	6.24	6.77	7.30	7.83	8.36	8.88	9.41	9.94	10.47	11.00	11.53	12.05	12.58	13.11	13.64	14.17	14.70
610.00	1.39	1.37	1.41	1.32	1.22	1.10	0.98	0.95	0.93	0.91	0.86	0.82	0.80	0.78	0.76	0.67	0.64
645.00	1.52	1.52	1.56	1.46	1.34	1.20	1.11	1.05	1.03	1.01	0.96	0.92	0.88	0.82	0.79	0.72	0.68
681.00	1.60	1.61	1.67	1.57	1.43	1.29	1.19	1.13	1.09	1.06	1.01	0.96	0.93	0.85	0.81	0.75	0.71
717.00	1.68	1.69	1.75	1.64	1.49	1.33	1.25	1.17	1.15	1.10	1.06	0.99	0.95	0.88	0.83	0.79	0.73
753.00	1.75	1.75	1.81	1.67	1.53	1.36	1.31	1.21	1.17	1.12	1.09	1.01	0.97	0.89	0.85	0.81	0.76
789.00	1.81	1.82	1.87	1.69	1.56	1.40	1.34	1.22	1.20	1.14	1.10	1.03	0.98	0.91	0.87	0.82	0.78
824.00	1.84	1.89	1.89	1.72	1.59	1.43	1.36	1.25	1.23	1.17	1.11	1.05	1.00	0.93	0.89	0.84	0.79
860.00	1.84	1.90	1.92	1.74	1.61	1.45	1.39	1.26	1.25	1.20	1.13	1.07	1.02	0.95	0.91	0.86	0.82
896.00	1.87	1.92	1.94	1.77	1.64	1.46	1.41	1.28	1.28	1.22	1.16	1.11	1.05	0.97	0.93	0.88	0.85

Initial Supporting table - P228C P2C1F - High Pressure Pump Control (HPC) fail threshold of pressure too low

Description: The High Pressure Pump Control (HPC) fail threshold of pressure too low test as a function of desired fuel pressure.

Value Units: Pressure Error - Desired pressure - Actual Pressure (Mpa)
X Unit: Desired Pressure (Mpa)

y/x	2	3	4	15	20	25	28	32	36
1	0	2	3	3	3	3	3	3	3

Initial Supporting table - P228D P2C20 - High Pressure Pump Control (HPC) fail threshold for pressure too high

Description: The High Pressure Pump Control (HPC) fail threshold for pressure too high test as a function of desired fuel pressure.

Value Units: Pressure Error - Desired pressure - Actual Pressure (Mpa)
X Unit: Desired Pressure (Mpa)

y/x	1.50	3.00	4.00	15.00	20.00	25.00	27.50	32.00	36.00
1	-3.00	-3.00	-3.00	-3.00	-3.00	-3.00	-3.00	-3.00	-3.00

- P2B00 P2B01 P2B02 P2B03 P2B04 P2B05 P2B06 P2B07 P2B96 P2B08 P2B09 P2B0A P2B0B P2B0C P2B0D P2B0E P2B0F - kaFULO_n_RP

Description: Max Engine Speed to allow Multipulse function of injector energy profile

Value Units: Max Engine Speed to allow Multipulse
X Unit: Injector Energy Profile
Y Units: Multipulse Mode (0 = Double Pulse, 1 = Triple Pulse)

y/x	0	1	2	3
0	3,600	3,600	3,600	3,600
1	3,000	3,000	3,000	3,000

Initial Supporting table - Closed Loop Enable Clarification - KaFCLP_U_SlphrIntglOfst_Thrsh

Description: Integral Offset voltage thresholds (bank and cell specific cals) used with KeFCLP_Pct_CatAccuSlphrPostDsbl to check for sulphur poisoning.

Value Units: millivolts
X Unit: Post Catalyst Number

y/x	CiOXYR_O2_PostCat1	CiOXYR_O2_PostCat2
CiFCLP_Decel	1,000	1,000
CiFCLP_Idle	1,000	1,000
CiFCLP_Cruise	1,000	1,000
CiFCLP_LightAccel	1,000	1,000
CiFCLP_HeavyAccel	1,000	1,000

Initial Supporting table - Closed Loop Enable Clarification - KcFCLP_Cnt_O2RdyCyclesThrsh

Description: Number of times a post oxygen sensor value must be in range before declaring it ready

Value Units: Time (events * 12.5 milliseconds)

y/x	1
1	10

Initial Supporting table - Closed Loop Enable Clarification - KcFULC_O2_SensorReadyEvents

Description: Number of times a pre oxygen sensor value must be in range before declaring it ready

Value Units: Time (events * 12.5 milliseconds)

y/x	1
1	10

Initial Supporting table - Closed Loop Enable Clarification - KeEOSD_U_RichThrsh

Description: The oxygen sensor voltage above which a sensor will be considered failing during a Rich Test.

Value Units: Volts

y/x	1
1	1,050

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_dm_IntegrationAirflowMax

Description: Maximum allowed estimated airflow for post O2 integral terms to be updated.

Value Units: Grams per Second

y/x	1
1	512

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_Pct_CatAccuSlphrPostDsbl

Description: Sulphur percent threshold above which post integral learning is disabled if the threshold criteria KaFCLP_U_SlphrIntglOfst_Thrsh is also met.

Value Units: Percent

y/x	1
1	75

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_T_IntegrationCatalystMax

Description: Maximum allowed estimated catalytic converter temperature for post O2 integral terms to be updated.

Value Units: Celcius

y/x	1
1	950

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_T_IntegrationCatalystMin

Description: Minimum allowed estimated catalytic converter temperature to begin using post O2 integration correction terms. Converter temperature must remain above this threshold to ramp-in the post O2 integration adjustments. Once the ramp-in has started, a converter temperature below this threshold will freeze the ramp-in multiplier. Post O2 integration will not be allowed below this converter temperature

Value Units: Celcius

y/x	1
1	500

Initial Supporting table - Closed Loop Enable Clarification - KeFULC_T_WRAF_SensorReadyThrsh

Description: Pumping cell temperature threshold above which the wideband oxygen sensor will be considered ready for use

Value Units: Degrees Celcius

y/x	1
1	700

Initial Supporting table - Closed Loop Enable Clarification - KeWRSC_T_HtrCntrlCL

Description: WRAF heater temperature enabling threshold for transition from Open Loop to Closed Loop

Value Units: Degrees Celcius

y/x	1
1	628

Initial Supporting table - Closed Loop Enable Clarification - KeWRSI_T_PumpCurrentEnable

Description: WRAF heater temperature threshold for enabling the sensor pump current

Value Units: Degrees Celcius

y/x	1
1	628

Initial Supporting table - Closed Loop Enable Clarification - KfFCLL_T_AdaptiveLoCoolant

Description: LTM learning is inhibited if the engine coolant temperature is below this calibration.

Value Units: Degrees Celcius

y/x	1
1	39

Initial Supporting table - Closed Loop Enable Clarification - KfFCLP_U_O2ReadyThrshLo

Description: Voltage limit checked against when determining if a post converter oxygen sensor is in range

Value Units: millivolts

y/x	1
1	1,100

Initial Supporting table - Closed Loop Enable Clarification - KfFULC_U_O2_SensorReadyThrshLo

Description: Voltage limit checked against when determining if a pre converter oxygen sensor is in range

Value Units: millivolts

y/x	1
1	1,795

Initial Supporting table - Closed Loop Enable Clarification - KtFCLL_p_AdaptiveLowMAP_Limit

Description: Long term fuel learning is disabled below this MAP limit as a function of barometric pressure.

Value Units: KPa
X Unit: KPa

y/x	65	70	75	80	85	90	95	100	105
1	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

Initial Supporting table - Closed Loop Enable Clarification - KtFCLP_t_PostIntglDisableTime

Description: Disable integral offset after engine start for this amount of time as a function of start up coolant temperature.

Value Units: Time in seconds
X Unit: Degrees Celcius

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	220.0	220.0	220.0	196.0	120.0	72.0	60.0	60.0	52.0	41.0	35.0	32.0	36.0	40.0	44.0	60.0	60.0

Initial Supporting table - Closed Loop Enable Clarification - KtFCLP_t_PostIntglRampInTime

Description: Time required to ramp integral offset to desired value as a function of start up coolant temperature.

Value Units: Time in seconds
X Unit: Degrees Celcius

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	60.0	60.0	60.0	60.0	60.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0

Initial Supporting table - Closed Loop Enable Clarification - KtFSTA_t_ClosedLoopAutostart

Description: Engine run time following an autostart, as a function of begin run coolant, which must be exceeded to enable CLOSED LOOP.

Value Units: Time in seconds
X Unit: Degrees Celcius

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	360.0	300.0	240.0	180.0	130.0	55.0	45.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Initial Supporting table - Closed Loop Enable Clarification - KtFSTA_t_ClosedLoopTime

Description: Engine run time, as a function of startup coolant temperature, which must be exceeded to enable CLOSED LOOP.

Value Units: Time in seconds
X Unit: Degrees Celcius

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	360.0	300.0	240.0	180.0	130.0	55.0	45.0	35.0	20.0	10.0	5.0	3.0	3.0	8.0	8.0	8.0	8.0

Initial Supporting table - P0442 Volatility Time as a Function of Estimate of Ambient Temperature

Description: EONV volatility time as a function of estimated ambient temperature

Value Units: Volatility time (seconds)
X Unit: Estimated Ambient Temperature (Deg C)

y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	45	45	45	45	49	57	105	173	340	500	500	500	500	500	500	500	500

Initial Supporting table - P0442 Engine Off Time Before Vehicle Off Maximum as a Function of Estimated Ambient Temperature

Description: Maximum engine off time before vehicle off time as a function of estimated ambient temperature (EAT)

Value Units: Maximum Engine Off Time Before Vehicle Off Time (seconds)
X Unit: Estimated Ambient Temperature (Deg C)

y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30

Initial Supporting table - P0442 EONV Pressure Threshold (Pascals)

Description: EONV pressure threshold as a function of fuel level and estimated ambient temperature (EAT)

Value Units: EONV Pressure Threshold (Pascals)
X Unit: Fuel Level (percent) from 0 to 100 with step size 6.25
Y Units: Estimated Ambient Temperature (deg C) from -10 to 80 with step size 5.625

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
2	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
3	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
4	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
5	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
6	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
7	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
8	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
9	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
10	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
11	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
12	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
13	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
14	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
15	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
16	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5
17	-311.4	-299.7	-288.0	-276.3	-264.7	-253.0	-241.3	-229.6	-218.0	-206.3	-194.6	-182.9	-171.2	-159.6	-147.9	-136.2	-124.5

Initial Supporting table - P0496 Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level

Description: Purge valve leak test engine vacuum test time as a function of fuel level

Value Units: Purge Valve Leak Test Engine Vacuum Test Time (seconds)
X Unit: Fuel Level (percent)

y/x	0	6	12	19	25	31	37	44	50	56	62	69	75	81	87	94	100
1	48	47	46	44	43	42	40	39	37	36	35	33	32	31	29	28	26

Initial Supporting table - P057B KtBRKI_K_CmpltTestPointWeight

Description:

y/x	0.000	0.010	0.025	0.032	0.050	0.250	0.500	0.750	1.000
1	0	0	0	1	1	1	1	1	1

Initial Supporting table - P057B KtBRKI_K_FastTestPointWeight

Description:

y/x	0.000	0.010	0.025	0.032	0.050	0.250	0.500	0.750	1.000
1	0	0	0	1	1	1	1	1	1

Initial Supporting table - DFCO_CoolEnblHi_Temp

Description:			
y/x	-40	0	25
1	30.0	30.0	45.0

Initial Supporting table - DFCO_DelayAfterStart_Time

Description:

y/x	-30	-10	20	60	90
1	30.0	30.0	30.0	30.0	30.0

Initial Supporting table - DFCO_DsblLo_Vehicle_Speed

Description:

y/x	CeTCOR_e_NonEcoMode	CeTCOR_e_EcoMode
CeTGRR_e_TransGr1	0	0
CeTGRR_e_TransGr2	0	0
CeTGRR_e_TransGr3	0	0
CeTGRR_e_TransGr4	0	0
CeTGRR_e_TransGr5	0	0
CeTGRR_e_TransGr6	0	0
CeTGRR_e_TransGr9	0	0
CeTGRR_e_TransGr10	0	0
CeTGRR_e_TransGrNeut	0	0
CeTGRR_e_TransGrRvrs	0	0
CeTGRR_e_TransGrPark	0	0
CeTGRR_e_TransGr7	0	0
CeTGRR_e_TransGr8	0	0

Initial Supporting table - DFCO_EnblHi_Vehicle_Speed

Description:

y/x	CeTCOR_e_NonEcoMode	CeTCOR_e_EcoMode
CeTGRR_e_TransGr1	21.0	21.0
CeTGRR_e_TransGr2	32.0	32.0
CeTGRR_e_TransGr3	45.0	45.0
CeTGRR_e_TransGr4	0.0	0.0
CeTGRR_e_TransGr5	0.0	0.0
CeTGRR_e_TransGr6	0.0	0.0
CeTGRR_e_TransGr9	0.0	0.0
CeTGRR_e_TransGr10	0.0	0.0
CeTGRR_e_TransGrNeut	0.0	0.0
CeTGRR_e_TransGrRvrs	510.0	510.0
CeTGRR_e_TransGrPark	0.0	0.0
CeTGRR_e_TransGr7	0.0	0.0
CeTGRR_e_TransGr8	0.0	0.0

Initial Supporting table - DFCO_EngSpdEnblOfst

Description:

y/x	-1,750	-1,500	-1,250	-800	-500	-450	-300	-100	0
1	100	100	100	100	100	75	25	0	0

Initial Supporting table - CalculatedPerfMaxIc1

Description: Maximum desired camshaft position for Intake CAM - Bank1

Value Units: Maximum desired camshaft position (degCam)
X Unit: Engine Oil Temperature (degC)
[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]
[-40 -28 -16 -4 8 20 32 44 56 68 80 92 104 116 128 140 152]
Y Units: Engine Speed (rpm)
[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]
[400 800 1200 1600 2000 2400 2800 3200 3600 4000 4400 4800 5200 5600 6000 6400 6800]

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
2	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
3	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
4	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
5	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
6	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
7	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
8	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
9	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
10	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
11	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
12	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
13	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
14	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
15	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
16	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
17	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0

Initial Supporting table - P0196_FastFailTempDiff

Description: EOT Sensor Cold Start Fast Fail Threshold

Value Units: Threshold between power-up engine oil temperature and power-up engine coolant temperature (Deg C)
X Unit: PowerUp coolant temperature (deg C)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	80.0	80.0	80.0	60.0	60.0	40.0	40.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0

Initial Supporting table - P0196_TotalAccumulatedFlow

Description: Total accumulated air consumed by engine since engine start as a function of powerup undefaulted Oil Temperature

Value Units: Minimum accumulated (total) air grams consumed by engine (gram)
X Unit: PowerUp coolant temperature (deg C)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	15,000	14,000	13,000	12,000	11,000	10,000	9,000	8,000	7,000	6,000	5,000	4,000	5,000	4,000	3,000	3,000	3,000

Initial Supporting table - P0521_Eng_Load_Stability_Weighting_Factor - Single Stage Oil Pump

Description: Engine Load Stability Weighting Factor - Single Stage Oil Pump

Value Units: Weight factor for engine load stability (none)
X Unit: Engine load stability (milligram)

y/x	0	5	10	20	30	50	100	200	399
1	1.00	1.00	0.50	0.30	0.10	0.00	0.00	0.00	0.00

Initial Supporting table - P0521_Eng_Oil_Pred_Weighting_Factor - Single Stage Oil Pump

Description: Oil Pressure Predicted Weighting Factor - Single Stage Oil Pump

Value Units: Weight factor for engine oil pressure prediction (none)
X Unit: Predicted oil pressure (kPa)

y/x	0	170	250	275	360	375	400	500	600
1	0.00	0.00	0.10	1.00	1.00	1.00	1.00	0.86	0.00

Initial Supporting table - P0521_Oil_Temp_Weighting_Factor - Single Stage Oil Pump

Description: Oil Temperature Weighting Factor - Single Stage Oil Pump

Value Units: Weight factor for the engine oil temperature (none)
X Unit: Filtered oil temperature (deg C)

y/x	-40	40	60	80	90	100	120	130	140
1	0.58	0.70	0.70	0.70	0.70	0.70	0.70	0.70	0.00

Initial Supporting table - P0521_RPM_Weighting_Factor - Single Stage Oil Pump

Description: Engine RPM Weighting Factor - Single Stage Oil Pump

Value Units: Weight factor for the given engine speed (none)
X Unit: Filtered engine speed (RPM)

y/x	0	500	900	1,000	2,000	3,000	4,000	5,000	6,000
1	0.00	0.00	0.00	0.45	0.45	0.45	0.46	0.44	0.00

Initial Supporting table - Minimum Non-Purge Samples for Purge Vapor Fuel

Description: Number of Fuel Trim Monitor sample counts required to allow the Purge Vapor Fuel value to inhibit the Intrusive Rich test

Value Units: Sample Counts per loop rate of 100ms (divide by 10 to get seconds)
X Unit: Long Term Fuel Trim Cell I.D. (no units) (Only PurgeOff cells are used)

Minimum Non-Purge Samples for Purge Vapor Fuel - Part 1				
y/x	CeFADR_e_Cell00_PurgOnAirMode5	CeFADR_e_Cell01_PurgOnAirMode4	CeFADR_e_Cell02_PurgOnAirMode3	CeFADR_e_Cell03_PurgOnAirMode2
1	65,535	65,535	65,535	65,535
Minimum Non-Purge Samples for Purge Vapor Fuel - Part 2				
y/x	CeFADR_e_Cell04_PurgOnAirMode1	CeFADR_e_Cell05_PurgOnAirMode0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
1	65,535	65,535	65,535	65,535
Minimum Non-Purge Samples for Purge Vapor Fuel - Part 3				
y/x	CeFADR_e_Cell08_PurgOffAirMode5	CeFADR_e_Cell09_PurgOffAirMode4	CeFADR_e_Cell10_PurgOffAirMode3	CeFADR_e_Cell11_PurgOffAirMode2
1	65,535	65,535	65,535	65,535
Minimum Non-Purge Samples for Purge Vapor Fuel - Part 4				
y/x	CeFADR_e_Cell12_PurgOffAirMode1	CeFADR_e_Cell13_PurgOffAirMode0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel
1	65,535	65,535	65,535	65,535

Initial Supporting table - P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage

Description: Identifies which Long Term Fuel Trim Cell I.D.s are used for diagnosis. Only cells identified as "CeFADD_e_NonSelectedCell" are not used for diagnosis.

P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 1				
y/x	CeFADR_e_Cell00_PurgOnAirMode5	CeFADR_e_Cell01_PurgOnAirMode4	CeFADR_e_Cell02_PurgOnAirMode3	CeFADR_e_Cell03_PurgOnAirMode2
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell
P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 2				
y/x	CeFADR_e_Cell04_PurgOnAirMode1	CeFADR_e_Cell05_PurgOnAirMode0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell
P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 3				
y/x	CeFADR_e_Cell08_PurgOffAirMode5	CeFADR_e_Cell09_PurgOffAirMode4	CeFADR_e_Cell10_PurgOffAirMode3	CeFADR_e_Cell11_PurgOffAirMode2
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell
P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 4				
y/x	CeFADR_e_Cell12_PurgOffAirMode1	CeFADR_e_Cell13_PurgOffAirMode0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell

Initial Supporting table - Startup Engine Coolant adjusment to Minimum accumulation time

Description: Time offset added to the minimum accumulation time based on Startup Coolant.

Value Units: Counts (10 counts equals 1 second)
X Unit: Degree C

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	500	500	500	500	300	0	0	0	0	0	0	0	0	0	0	0	0

Initial Supporting table - P0068_Delta MAF Threshold f(TPS)

Description: Table of delta MAF values as a function of desired throttle position. The output of this table provides a delta MAF that if the measured minus the estimated MAF exceeds, is considered a fail.

Value Units: Delta MAF Values (dm)
X Unit: Desired Throttle Position (Pct)

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	19.49	26.27	31.22	37.95	40.99	48.13	255.00	255.00	255.00

Initial Supporting table - P0068_Delta MAP Threshold f(TPS)

Description: Table of delta MAP values as a function of desired throttle position. The output of this table provides a delta MAP that if the measured minus the estimated MAP exceeds, is considered a fail.

Value Units: Delta MAP Values (kPa)
X Unit: Desired Throttle Position (Pct)

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	24.95	28.45	26.12	25.02	19.11	17.30	255.00	255.00	255.00

Initial Supporting table - P0068_Maximum MAF f(RPM)

Description: Table of maximum MAF values vs. engine speed. This is the maximum MAF the engine can see under all ambient conditions.

Value Units: Delta MAF Values (dm)
X Unit: Engine Speed (RPM)

y/x	600.00	1,400.00	2,200.00	3,000.00	3,800.00	4,600.00	5,400.00	6,200.00	7,000.00
1.00	25.00	57.00	93.00	135.00	188.00	236.00	265.00	275.00	275.00

Initial Supporting table - P0068_Maximum MAF f(Volts)

Description: Table of maximum MAF values vs. system voltage. The output of the air meter is clamped to lower values as system voltage drops off.

Value Units: Delta MAF Values (dm)
X Unit: System Voltage (V)

y/x	6.00	7.00	8.00	9.00	10.00	11.00	12.00	13.00	14.00
1.00	69.70	180.36	376.20	511.99	511.99	511.99	511.99	511.99	511.99

Initial Supporting table - P0326_P0331_AbnormalNoise_Thresh_AFM

Description: Fail threshold for the Knock Performance Abnormal Noise Diagnostic when engine IS in AFM mode

Value Units: Filtered background engine noise. Unit-less term from the Knock Detection Fast Fourier Transform (FFT) for a selected frequency range.
X Unit: Engine Speed (RPM)
Y Units: N/A

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.412	0.417	0.409	0.431	0.484	0.475	0.525	0.527	0.561	0.676	0.730	0.730	0.730	0.730	0.730	0.730	0.730

Initial Supporting table - P0606_Last Seed Timeout f(Loop Time)

Description: The max time for the Last Seed Timeout as a function of operating loop time sequence.

Value Units: Max Time for Last Seed Timeout (ms)
X Unit: Operating Loop Sequence (enum)

P0606_Last Seed Timeout f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000	200.000

P0606_Last Seed Timeout f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	200.000	500.000	500.000	1,000.000	1,000.000	8,191.875	8,191.875	8,191.875

Initial Supporting table - P0606_Program Sequence Watch Enable f(Core, Loop Time)

Description: The enabling flags for the program sequence watch as a function of processor core and operating loop time sequence.

Value Units: PSW enable flag (boolean)
X Unit: Processor Core (enum)
Y Units: Operating Loop Time Sequence (enum)

y/x	CeTSKR_e_CPU	CeTSKR_e_CPU2	CeTSKR_e_CPU3	CeTSKR_e_CPU4
CePISR_e_2p5msSeq	0	0	0	0
CePISR_e_3p125msSeq	0	0	0	0
CePISR_e_5msSeq	0	0	0	0
CePISR_e_6p25msSeq	1	1	0	0
CePISR_e_10msSeq	0	0	0	0
CePISR_e_12p5msSeq	1	1	0	0
CePISR_e_20msSeq	0	0	0	0
CePISR_e_25msSeq	1	1	0	0
CePISR_e_40msSeq	0	0	0	0
CePISR_e_50msSeq	1	1	0	0
CePISR_e_80msSeq	0	0	0	0
CePISR_e_100msSeq	1	1	0	0
CePISR_e_250msSeq	0	0	0	0
CePISR_e_EventA_Seq	0	0	0	0
CePISR_e_EventB_Seq	0	0	0	0
CePISR_e_EventC_Seq	0	0	0	0

Initial Supporting table - P0606_PSW Sequence Fail f(Loop Time)

Description: Fail threshold for PS□ per operating loop.

Value Units: Fail threshold for PS□ (count)
X Unit: Operating □oop (enum)

P0606_PSW Sequence Fail f(Loop Time) - Part 1

y□□	CePISR□e□2p5msSe□	CePISR□e□□p125msSe□	CePISR□e□5msSe□	CePISR□e□6p25msSe□	CePISR□e□10msSe□	CePISR□e□12p5msSe□	CePISR□e□20msSe□	CePISR□e□25msSe□
1	5	□	5	□	5	□	5	□

P0606_PSW Sequence Fail f(Loop Time) - Part 2

y□□	CePISR□e□40msSe□	CePISR□e□50msSe□	CePISR□e□□0msSe□	CePISR□e□100msSe□	CePISR□e□250msSe□	CePISR□e□EventA□Se□	CePISR□e□EventB□Se□	CePISR□e□EventC□Se□
1	5	□	5	5	5	□	5	5

Initial Supporting table - P0606_PSW Sequence Sample f(Loop Time)

Description: Sample threshold for PSW per operating loop.

Value Units: Sample threshold for PSW (count)
X Unit: Operating Loop (enum)

P0606_PSW Sequence Sample f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	4	4	4	4	4	4	4	4

P0606_PSW Sequence Sample f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	4	4	4	4	4	4	4	4

Initial Supporting table - P1682_PT Relay Pull-in Run/Crank Voltage f(IAT)

Description: The Run/Crank voltages required to pull in the PT relay as a function of induction air temperature.

Value Units: Run/Crank Voltages required to pull in PT Relay (V)
X Unit: Induction Air Temperature (deg C)

y/x	23.0	85.0	95.0	105.0	125.0
1	7.000	8.699	9.000	9.199	10.000

Initial Supporting table - P16F3_Delta MAP Threshold f(Desired Engine Torque)

Description: Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

Value Units: Torque Security Threshold for Engine Sync and Time Based Delta Pressure (kPa)
X Unit: Desired Engine Torque (Nm)

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	17.30	17.30	17.30	17.30	17.30	17.30

Initial Supporting table - P16F3_Speed Control External Load f(Oil Temp, RPM)

Description: Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

Value Units: External Load Table for SPDR (Nm)
X Unit: Engine Oil Temperature (deg C)
Y Units: Engine Speed (RPM)

y/x	-40.00	-20.00	-10.00	0.00	50.00	90.00
300.00	500.00	500.00	500.00	500.00	500.00	500.00
370.00	500.00	500.00	500.00	500.00	500.00	500.00
435.00	500.00	500.00	500.00	500.00	500.00	500.00
550.00	500.00	500.00	500.00	350.00	200.00	150.00
600.00	500.00	500.00	350.00	200.00	81.83	60.94
660.00	500.00	500.00	200.00	134.34	79.97	58.01
800.00	350.00	350.00	141.23	143.49	83.57	53.00
1,000.00	235.66	176.73	140.24	147.42	97.69	70.25
1,300.00	187.35	140.64	111.53	113.52	71.48	33.72
1,600.00	135.96	92.26	64.60	67.72	30.02	-3.96
2,000.00	64.44	24.98	0.65	2.19	-31.02	-34.66
2,500.00	61.31	22.67	-0.80	-0.68	-34.98	-36.01
3,200.00	55.77	16.62	-7.31	-6.38	-40.01	-43.35
4,000.00	44.94	5.66	-18.44	-17.25	-50.70	-55.10
5,000.00	28.88	-10.39	-34.48	-33.30	-66.77	-71.09
6,100.00	9.48	-29.90	-54.12	-52.74	-86.07	-91.22
6,600.00	-0.11	-39.40	-62.94	-62.33	-95.67	-97.48

Initial Supporting table - P0324_PerCyl_ExcessiveKnock_Threshold

Description: Fail threshold for the Knock Performance per-cylinder Excessive Knock Diagnostic

Value Units: Filtered Knock Intensity. Unit-less term scaled from 0.0 (no knock) to 5.0 (maximum/large knock)
X Unit: Engine Speed (RPM)
Y Units: N/A

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	1.50	1.50	1.50	1.50	1.50	1.50	1.50	1.50	1.50	1.50	1.50	1.50	1.50	1.50	1.50	1.50	1.50

Initial Supporting table - P0325_P0330_OpenCktThrshMax (20 kHz)

Description: Knock Open Circuit Diagnostic Maximum Threshold when using the 20 kHz method (see "OpenMethod" description)

Value Units: Unit-less, filtered term from the Knock Detection Fast Fourier Transform (FFT) for the 20 kHz frequency range.
X Unit: Engine Speed (RPM).
Y Units: N/A

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	12.7383	11.6152	11.4727	11.1523	11.1816	11.2500	11.1133	10.0977	9.0000	7.9023	7.9023	7.9023	7.9023	7.9023	7.9023	7.9023	7.9023

Initial Supporting table - P0325_P0330_OpenCktThrshMax (Normal Noise)

Description: Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

Value Units: Filtered background engine noise. Unit-less term from the Knock Detection Fast Fourier Transform (FFT) for a selected frequency range.
X Unit: Engine Speed (RPM)
Y Units: N/A

y/x	2,700	2,900	3,000	3,250	3,500	3,750	4,000	4,250	4,500	4,750	5,000	5,500	6,000	6,500	7,000	7,500	8,500
1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000

Initial Supporting table - P0325_P0330_OpenCktThrshMin (20 kHz)

Description: Knock Open Circuit Diagnostic Minimum Threshold when using the 20 kHz method (see "OpenMethod" description)

Value Units: Unit-less, filtered term from the Knock Detection Fast Fourier Transform (FFT) for the 20 kHz frequency range.
X Unit: Engine (RPM)
Y Units: N/A

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	5.2344	5.1875	5.1387	5.1641	4.9824	4.9941	5.0020	4.9277	4.7715	4.6172	4.2988	4.2988	4.2988	4.2988	4.2988	4.2988	4.2988

Initial Supporting table - P0325_P0330_OpenCktThrshMin (Normal Noise)

Description: Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

Value Units: Filtered background engine noise. Unit-less term from the Knock Detection Fast Fourier Transform (FFT) for a selected frequency range.
X Unit: Engine Speed (RPM)
Y Units: N/A

y/x	2,700	2,900	3,000	3,250	3,500	3,750	4,000	4,250	4,500	4,750	5,000	5,500	6,000	6,500	7,000	7,500	8,500
1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000

Initial Supporting table - P0325_P0330_OpenMethod_2

Description: Defines which Knock Open Circuit Diagnostic method to use.

Value Units: Identifies one of two diagnostic methods (either 20 kHz or Normal Noise) used (as a function of engine speed) for Open Circuit detection
X Unit: Engine Speed Index, 500 to 8500 (RPM) by 500 rpm increments (Index 0, 1, 2.... 16 = 500, 1000, 1500.... 8500 RPM)
Y Units: N/A

P0325_P0330_OpenMethod_2 - Part 1					
y/x	0	1	2	3	4
1	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz
P0325_P0330_OpenMethod_2 - Part 2					
y/x	5	6	7	8	9
1	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz
P0325_P0330_OpenMethod_2 - Part 3					
y/x	10	11	12	13	14
1	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_None	CeKNKD_e_Open_None	CeKNKD_e_Open_None	CeKNKD_e_Open_None
P0325_P0330_OpenMethod_2 - Part 4					
y/x	15	16			
1	CeKNKD_e_Open_None	CeKNKD_e_Open_None			

Initial Supporting table - P0326_P0331_AbnormalNoise_CylsEnabled

Description: Specifies which cylinders will be used for the Abnormal Noise portion of the performance diagnostics (1 = cylinder used, 0 = cylinder not used)

Value Units: Boolean that indicates which engine cylinders are being used for the per-sensor Knock Performance diagnostic (0 = not used, 1 = used)
X Unit: Cylinder number in firing order (i.e. Cyl 0 = first cylinder in firing order, Cyl 1 = second cylinder in firing order....)
Y Units: N/A

y/x	0	1	2	3	4	5	6	7
1	1	1	1	1	1	1	1	1

Initial Supporting table - P0326_P0331_AbnormalNoise_Threshold

Description: Fail threshold for the Knock Performance Abnormal Noise Diagnostic when engine is NOT in AFM mode

Value Units: Filtered background engine noise. Unit-less term from the Knock Detection Fast Fourier Transform (FFT) for a selected frequency range.
X Unit: Engine Speed (RPM)
Y Units: N/A

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	1.609	1.609	1.609	1.645	1.546	1.560	1.459	1.517	1.519	1.410	1.459	1.459	1.459	1.459	1.459	1.459	1.459

Initial Supporting table - P06B6_P06B7_OpenTestCktThrshMax

Description: Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

Value Units: Unit-less, filtered term from the Knock Detection Fast Fourier Transform (FFT) for the 20 kHz frequency range.
X Unit: Engine Speed (RPM)
Y Units: N/A

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.523	0.523	0.518	0.547	0.549	0.648	0.723	0.756	0.908	1.063	2.094	3.123	3.123	3.123	3.123	3.123	3.123

Initial Supporting table - P06B6_P06B7_OpenTestCktThrshMin

Description: Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

Value Units: Unit-less, filtered term from the Knock Detection Fast Fourier Transform (FFT) for the 20 kHz frequency range.
X Unit: Engine Speed (RPM).
Y Units: N/A

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.240	0.240	0.240	0.252	0.252	0.287	0.334	0.385	0.463	0.541	1.055	1.055	1.055	1.055	1.055	1.055	1.055

Initial Supporting table - P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold

Description: P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold

Value Units: Engine Run Time- Seconds
X Unit: Oil Temperature- C

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	300	300	160	18	18	18	18	10	3	3	3	3	3	3	3	3	3

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

Description: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix - This table describes combinations of individual model failures that will set P0101, P0106, P010B, P0121, P0236 and P1101 on turbocharged applications.

Value Units: Boolean
X Unit: Unitless (See top line for heading information)
Y Units: Unitless

y/x	1	2	3	4	5	6	7	8	9
1	MAF Model	MAP1 Model	MAP2 Model	MAP3 Model	TIAP1 Model	TPS Model	TIAP Correlation	TIAP Correlation	DTC Set
2	Failed	Failed	Failed	Failed	Failed	Failed	Failed	Valid	
3	F	F	F	F	F	F	F	F	No DTC
4	F	F	F	F	F	F	F	T	No DTC
5	F	F	F	F	F	F	T	F	No DTC
6	F	F	F	F	F	F	T	T	No DTC
7	F	F	F	F	F	T	F	F	No DTC
8	F	F	F	F	F	T	F	T	No DTC
9	F	F	F	F	F	T	T	F	No DTC
10	F	F	F	F	F	T	T	T	No DTC
11	F	F	F	F	T	F	F	F	No DTC
12	F	F	F	F	T	F	F	T	No DTC
13	F	F	F	F	T	F	T	F	No DTC
14	F	F	F	F	T	F	T	T	No DTC
15	F	F	F	F	T	T	F	F	P1101
16	F	F	F	F	T	T	F	T	P0121
17	F	F	F	F	T	T	T	F	P1101
18	F	F	F	F	T	T	T	T	P0236
19	F	F	F	T	F	F	F	F	No DTC
20	F	F	F	T	F	F	F	T	P1101
21	F	F	F	T	F	F	T	F	P1101
22	F	F	F	T	F	F	T	T	P1101
23	F	F	F	T	F	T	F	F	P1101
24	F	F	F	T	F	T	F	T	P1101
25	F	F	F	T	F	T	T	F	P1101
26	F	F	F	T	F	T	T	T	P1101
27	F	F	F	T	T	F	F	F	P1101
28	F	F	F	T	T	F	F	T	P1101
29	F	F	F	T	T	F	T	F	P1101
30	F	F	F	T	T	F	T	T	P1101
31	F	F	F	T	T	T	F	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

32	F	F	F	T	T	T	F	T	P1101
33	F	F	F	T	T	T	T	F	P1101
34	F	F	F	T	T	T	T	T	P1101
35	F	F	T	F	F	F	F	F	No DTC
36	F	F	T	F	F	F	F	T	P1101
37	F	F	T	F	F	F	T	F	P1101
38	F	F	T	F	F	F	T	T	P1101
39	F	F	T	F	F	T	F	F	P1101
40	F	F	T	F	F	T	F	T	P1101
41	F	F	T	F	F	T	T	F	P1101
42	F	F	T	F	F	T	T	T	P1101
43	F	F	T	F	T	F	F	F	P1101
44	F	F	T	F	T	F	F	T	P1101
45	F	F	T	F	T	F	T	F	P1101
46	F	F	T	F	T	F	T	T	P1101
47	F	F	T	F	T	T	F	F	P1101
48	F	F	T	F	T	T	F	T	P1101
49	F	F	T	F	T	T	T	F	P1101
50	F	F	T	F	T	T	T	T	P1101
51	F	F	T	T	F	F	F	F	P1101
52	F	F	T	T	F	F	F	T	P1101
53	F	F	T	T	F	F	T	F	P1101
54	F	F	T	T	F	F	T	T	P1101
55	F	F	T	T	F	T	F	F	P1101
56	F	F	T	T	F	T	F	T	P1101
57	F	F	T	T	F	T	T	F	P1101
58	F	F	T	T	F	T	T	T	P1101
59	F	F	T	T	T	F	F	F	No DTC
60	F	F	T	T	T	F	F	T	No DTC
61	F	F	T	T	T	F	T	F	No DTC
62	F	F	T	T	T	F	T	T	No DTC
63	F	F	T	T	T	T	F	F	P1101
64	F	F	T	T	T	T	F	T	P1101
65	F	F	T	T	T	T	T	F	P1101
66	F	F	T	T	T	T	T	T	P1101
67	F	T	F	F	F	F	F	F	No DTC
68	F	T	F	F	F	F	F	T	P1101
69	F	T	F	F	F	F	T	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

70	F	T	F	F	F	F	T	T	P0236
71	F	T	F	F	F	T	F	F	P1101
72	F	T	F	F	F	T	F	T	P0121
73	F	T	F	F	F	T	T	F	P1101
74	F	T	F	F	F	T	T	T	P0236
75	F	T	F	F	T	F	F	F	P1101
76	F	T	F	F	T	F	F	T	P1101
77	F	T	F	F	T	F	T	F	P1101
78	F	T	F	F	T	F	T	T	P0236
79	F	T	F	F	T	T	F	F	P1101
80	F	T	F	F	T	T	F	T	P0121
81	F	T	F	F	T	T	T	F	P1101
82	F	T	F	F	T	T	T	T	P0236
83	F	T	F	T	F	F	F	F	P1101
84	F	T	F	T	F	F	F	T	P1101
85	F	T	F	T	F	F	T	F	P1101
86	F	T	F	T	F	F	T	T	P1101
87	F	T	F	T	F	T	F	F	P1101
88	F	T	F	T	F	T	F	T	P1101
89	F	T	F	T	F	T	T	F	P1101
90	F	T	F	T	F	T	T	T	P1101
91	F	T	F	T	T	F	F	F	P1101
92	F	T	F	T	T	F	F	T	P1101
93	F	T	F	T	T	F	T	F	P1101
94	F	T	F	T	T	F	T	T	P1101
95	F	T	F	T	T	T	F	F	P1101
96	F	T	F	T	T	T	F	T	P1101
97	F	T	F	T	T	T	T	F	P1101
98	F	T	F	T	T	T	T	T	P1101
99	F	T	T	F	F	F	F	F	P1101
100	F	T	T	F	F	F	F	T	P1101
101	F	T	T	F	F	F	T	F	P1101
102	F	T	T	F	F	F	T	T	P1101
103	F	T	T	F	F	T	F	F	P1101
104	F	T	T	F	F	T	F	T	P1101
105	F	T	T	F	F	T	T	F	P1101
106	F	T	T	F	F	T	T	T	P1101
107	F	T	T	F	T	F	F	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

108	F	T	T	F	T	F	F	T	P1101
109	F	T	T	F	T	F	T	F	P1101
110	F	T	T	F	T	F	T	T	P1101
111	F	T	T	F	T	T	F	F	P1101
112	F	T	T	F	T	T	F	T	P1101
113	F	T	T	F	T	T	T	F	P1101
114	F	T	T	F	T	T	T	T	P1101
115	F	T	T	T	F	F	F	F	P0106
116	F	T	T	T	F	F	F	T	P0106
117	F	T	T	T	F	F	T	F	P0106
118	F	T	T	T	F	F	T	T	P0106
119	F	T	T	T	F	T	F	F	P1101
120	F	T	T	T	F	T	F	T	P1101
121	F	T	T	T	F	T	T	F	P1101
122	F	T	T	T	F	T	T	T	P1101
123	F	T	T	T	T	F	F	F	P1101
124	F	T	T	T	T	F	F	T	P1101
125	F	T	T	T	T	F	T	F	P1101
126	F	T	T	T	T	F	T	T	P1101
127	F	T	T	T	T	T	F	F	P1101
128	F	T	T	T	T	T	F	T	P1101
129	F	T	T	T	T	T	T	F	P1101
130	F	T	T	T	T	T	T	T	P1101
131	T	F	F	F	F	F	F	F	No DTC
132	T	F	F	F	F	F	F	T	P1101
133	T	F	F	F	F	F	T	F	P1101
134	T	F	F	F	F	F	T	T	P0236
135	T	F	F	F	F	T	F	F	P1101
136	T	F	F	F	F	T	F	T	P0121
137	T	F	F	F	F	T	T	F	P1101
138	T	F	F	F	F	T	T	T	P0236
139	T	F	F	F	T	F	F	F	P1101
140	T	F	F	F	T	F	F	T	P1101
141	T	F	F	F	T	F	T	F	P1101
142	T	F	F	F	T	F	T	T	P0236
143	T	F	F	F	T	T	F	F	P1101
144	T	F	F	F	T	T	F	T	P0121
145	T	F	F	F	T	T	T	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

146	T	F	F	F	T	T	T	T	P0236
147	T	F	F	T	F	F	F	F	P1101
148	T	F	F	T	F	F	F	T	P1101
149	T	F	F	T	F	F	T	F	P1101
150	T	F	F	T	F	F	T	T	P1101
151	T	F	F	T	F	T	F	F	P1101
152	T	F	F	T	F	T	F	T	P1101
153	T	F	F	T	F	T	T	F	P1101
154	T	F	F	T	F	T	T	T	P1101
155	T	F	F	T	T	F	F	F	P1101
156	T	F	F	T	T	F	F	T	P1101
157	T	F	F	T	T	F	T	F	P1101
158	T	F	F	T	T	F	T	T	P1101
159	T	F	F	T	T	T	F	F	P1101
160	T	F	F	T	T	T	F	T	P1101
161	T	F	F	T	T	T	T	F	P1101
162	T	F	F	T	T	T	T	T	P1101
163	T	F	T	F	F	F	F	F	P1101
164	T	F	T	F	F	F	F	T	P1101
165	T	F	T	F	F	F	T	F	P1101
166	T	F	T	F	F	F	T	T	P1101
167	T	F	T	F	F	T	F	F	P1101
168	T	F	T	F	F	T	F	T	P1101
169	T	F	T	F	F	T	T	F	P1101
170	T	F	T	F	F	T	T	T	P1101
171	T	F	T	F	T	F	F	F	P1101
172	T	F	T	F	T	F	F	T	P1101
173	T	F	T	F	T	F	T	F	P1101
174	T	F	T	F	T	F	T	T	P1101
175	T	F	T	F	T	T	F	F	P1101
176	T	F	T	F	T	T	F	T	P1101
177	T	F	T	F	T	T	T	F	P1101
178	T	F	T	F	T	T	T	T	P1101
179	T	F	T	T	F	F	F	F	P1101
180	T	F	T	T	F	F	F	T	P1101
181	T	F	T	T	F	F	T	F	P1101
182	T	F	T	T	F	F	T	T	P1101
183	T	F	T	T	F	T	F	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

184	T	F	T	T	F	T	F	T	P1101
185	T	F	T	T	F	T	T	F	P1101
186	T	F	T	T	F	T	T	T	P1101
187	T	F	T	T	T	F	F	F	P0101 or P010B
188	T	F	T	T	T	F	F	T	P0101 or P010B
189	T	F	T	T	T	F	T	F	P0101 or P010B
190	T	F	T	T	T	F	T	T	P0101 or P010B
191	T	F	T	T	T	T	F	F	P1101
192	T	F	T	T	T	T	F	T	P1101
193	T	F	T	T	T	T	T	F	P1101
194	T	F	T	T	T	T	T	T	P1101
195	T	T	F	F	F	F	F	F	P1101
196	T	T	F	F	F	F	F	T	P1101
197	T	T	F	F	F	F	T	F	P1101
198	T	T	F	F	F	F	T	T	P0236
199	T	T	F	F	F	T	F	F	P1101
200	T	T	F	F	F	T	F	T	P0121
201	T	T	F	F	F	T	T	F	P1101
202	T	T	F	F	F	T	T	T	P0236
203	T	T	F	F	T	F	F	F	P1101
204	T	T	F	F	T	F	F	T	P1101
205	T	T	F	F	T	F	T	F	P1101
206	T	T	F	F	T	F	T	T	P0236
207	T	T	F	F	T	T	F	F	P1101
208	T	T	F	F	T	T	F	T	P0121
209	T	T	F	F	T	T	T	F	P1101
210	T	T	F	F	T	T	T	T	P0236
211	T	T	F	T	F	F	F	F	P1101
212	T	T	F	T	F	F	F	T	P1101
213	T	T	F	T	F	F	T	F	P1101
214	T	T	F	T	F	F	T	T	P1101
215	T	T	F	T	F	T	F	F	P1101
216	T	T	F	T	F	T	F	T	P1101
217	T	T	F	T	F	T	T	F	P1101
218	T	T	F	T	F	T	T	T	P1101
219	T	T	F	T	T	F	F	F	P1101
220	T	T	F	T	T	F	F	T	P1101
221	T	T	F	T	T	F	T	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

222	T	T	F	T	T	F	T	T	P1101
223	T	T	F	T	T	T	F	F	P1101
224	T	T	F	T	T	T	F	T	P1101
225	T	T	F	T	T	T	T	F	P1101
226	T	T	F	T	T	T	T	T	P1101
227	T	T	T	F	F	F	F	F	P1101
228	T	T	T	F	F	F	F	T	P1101
229	T	T	T	F	F	F	T	F	P1101
230	T	T	T	F	F	F	T	T	P1101
231	T	T	T	F	F	T	F	F	P1101
232	T	T	T	F	F	T	F	T	P1101
233	T	T	T	F	F	T	T	F	P1101
234	T	T	T	F	F	T	T	T	P1101
235	T	T	T	F	T	F	F	F	P1101
236	T	T	T	F	T	F	F	T	P1101
237	T	T	T	F	T	F	T	F	P1101
238	T	T	T	F	T	F	T	T	P1101
239	T	T	T	F	T	T	F	F	P1101
240	T	T	T	F	T	T	F	T	P1101
241	T	T	T	F	T	T	T	F	P1101
242	T	T	T	F	T	T	T	T	P1101
243	T	T	T	T	F	F	F	F	P1101
244	T	T	T	T	F	F	F	T	P1101
245	T	T	T	T	F	F	T	F	P1101
246	T	T	T	T	F	F	T	T	P1101
247	T	T	T	T	F	T	F	F	P1101
248	T	T	T	T	F	T	F	T	P1101
249	T	T	T	T	F	T	T	F	P1101
250	T	T	T	T	F	T	T	T	P1101
251	T	T	T	T	T	F	F	F	P1101
252	T	T	T	T	T	F	F	T	P1101
253	T	T	T	T	T	F	T	F	P1101
254	T	T	T	T	T	F	T	T	P1101
255	T	T	T	T	T	T	F	F	P1101
256	T	T	T	T	T	T	F	T	P1101
257	T	T	T	T	T	T	T	F	P1101
258	T	T	T	T	T	T	T	T	P1101

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP1 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	600	950	1,300	1,650	2,000	2,350	2,700	3,050	3,400	3,750	4,100	4,450	4,800	5,150	5,500	6,000	6,500
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.698

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP2 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	600	950	1,300	1,650	2,000	2,350	2,700	3,050	3,400	3,750	4,100	4,450	4,800	5,150	5,500	6,000	6,500
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.864	1.000	1.000	1.000	1.000	1.000	1.000	0.662

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP3 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	600	950	1,300	1,650	2,000	2,350	2,700	3,050	3,400	3,750	4,100	4,450	4,800	5,150	5,500	6,000	6,500
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.814	0.974	1.000	0.925	1.000	0.971	0.600	1.000

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 TPS Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	600	950	1,300	1,650	2,000	2,350	2,700	3,050	3,400	3,750	4,100	4,450	4,800	5,150	5,500	6,000	6,500
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.905	1.000	1.000	1.000	0.909	1.000	1.000	0.750	0.540

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P0236_P1101 TIAP Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	600	950	1,300	1,650	2,000	2,350	2,700	3,050	3,400	3,750	4,100	4,450	4,800	5,150	5,500	6,000	6,500
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Max Air Flow

Value Units: Engine Air Flow (Grams/Second)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	20.0	25.0	28.0	30.0	32.0	31.0	30.0	30.0	30.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Max MAP

Value Units: Manifold Pressure (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	95.0	80.0	70.0	45.0	38.0	35.0	30.0	30.0	30.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Offset

Value Units: Pressure Difference (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	0.3	0.5	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min Air Flow

Value Units: Engine Air Flow (Grams/Second)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	18.0	65.0	115.0	130.0	150.0	165.0	175.0	175.0	175.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min MAP

Value Units: Manifold Pressure (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	95.0	120.0	130.0	155.0	170.0	160.0	160.0	162.0	170.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Offset

Value Units: Pressure Difference (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	1.0	1.0	1.0	1.0	2.0	2.4	4.0	5.0	5.0

Initial Supporting table - P0234 P0299: Ambient pressure correction as a function of engine speed and ambient pressure

Description: Additative offset on boost pressure control deviation fail limit.

Value Units: [kPa] Control Deviation - Ambient correction.
X Unit: [kPa] KnBSTD_p_CntrlDevDiagAmbCorrBP - Ambient Air Pressure
Y Units: [rpm] KnBSTD_n_CntrlDevDiagAmbCorrBP - Engine Speed

y/x	60.00	70.00	80.00	90.00	95.00	110.00
1,500	50.00	42.00	18.00	8.00	3.00	0.00
2,500	45.00	37.00	13.00	6.33	3.00	0.00
3,000	35.86	27.57	15.43	7.14	3.00	0.00
4,000	40.57	31.71	20.29	8.76	3.00	0.00
5,000	44.29	34.86	25.14	10.38	3.00	0.00
6,000	50.00	40.00	30.00	12.00	3.00	0.00

Initial Supporting table - P0234 P0299: Boost deviation diagnostic enable delay as a function of engine speed

Description: Timer to stabilize enable conditions for over and underboost diagnosis.

Value Units: [sec] Pressure control deviation diagnosis enable delay.
X Unit: [rpm] KnBSTD_n_CntrlDevDiagEngSpdBP - Engine Speed

y/x	1,000	1,500	1,900	2,500	3,000	3,500	4,000	4,500	5,500	6,500
1	3.0000	2.2500	1.8750	1.5000	1.3750	1.2500	1.1250	1.0000	0.7500	0.6250

Initial Supporting table - P0299: Underboost pressure deviation limit as a function of engine speed and desired boost pressure

Description: Positive boost pressure control deviation fail limit.

Value Units: [kPa] Positive boost pressure deviation limit.
X Unit: [kPa] KnBSTD_p_CntrlDevDiagDsrdBP - Boost pressure
Y Units: [rpm] KnBSTD_n_CntrlDevDiagEngSpdBP - Engine speed

y/x	105.00	114.00	120.00	130.00	140.00	150.00	160.00	170.00	180.00	220.00
1,000	4.00	9.00	16.60	20.00	31.00	36.00	41.00	46.00	53.50	85.00
1,500	4.00	9.00	16.60	20.00	31.00	36.00	41.00	46.00	53.50	85.00
1,900	4.00	9.00	16.10	21.00	29.00	34.00	39.00	44.00	51.50	85.00
2,500	4.00	8.00	13.10	18.00	26.00	26.00	26.00	31.00	38.50	85.00
3,000	4.00	6.00	14.87	18.00	24.75	24.50	23.50	28.50	37.25	70.00
3,500	4.00	6.00	10.15	12.00	16.00	20.00	23.75	25.00	65.00	70.00
4,000	4.00	6.00	8.11	10.00	15.00	20.00	20.00	25.00	65.00	70.00
4,500	4.00	6.00	8.11	10.00	15.00	20.00	20.00	25.00	65.00	70.00
5,500	4.00	6.00	8.11	10.00	15.00	20.00	20.00	25.00	65.00	70.00
6,500	4.00	6.00	8.11	10.00	15.00	20.00	20.00	25.00	65.00	70.00

Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est

Description: P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on MAF Est

Value Units: Weight Factor (Unitless)
X Unit: Estimated Engine Air Flow (Grams/Second)

y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.910	0.945	1.000	0.775	0.962	0.741	0.895	1.000

Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM

Description: P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	600	950	1,300	1,650	2,000	2,350	2,700	3,050	3,400	3,750	4,100	4,450	4,800	5,150	5,500	6,000	6,500
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: MAF2 Residual Weight Factor based on MAF Est

Description: P0101_P0106_P010B_P0121_P0236_P1101 MAF2 Residual Weight Factor based on MAF Est

Value Units: Weight Factor (Unitless)
X Unit: Estimated Engine Air Flow (Grams/Second)

y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.952	0.790	0.785	0.908	0.796	0.940	0.763	0.821	0.653

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: MAF2 Residual Weight Factor based on RPM

Description: P0101_P0106_P010B_P0121_P0236_P1101 MAF2 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Air Flow (Grams/Second)

y/x	600	950	1,300	1,650	2,000	2,350	2,700	3,050	3,400	3,750	4,100	4,450	4,800	5,150	5,500	6,000	6,500
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P0806 EngTorqueThreshold Table

Description: The diagnostic is inhibited if torque (NM) is less than this value. Prevents false fails in regions where false in-gear N/TOS ratios are possible due to low torque, where high torque would otherwise cause slip and prevent a valid in-gear state.

Value Units: Torque (NM)
X Unit: Percent Clutch Pedal Position (%)

y/x	0.00	6.25	12.50	18.75	25.00	31.25	37.50	43.75	50.00	56.25	62.50	68.75	75.00	81.25	87.50	93.75	100.00
1	10.0	10.0	10.0	10.0	10.0	32.5	65.0	82.5	100.0	100.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

Initial Supporting table - P0806 ResidualErrEnableHigh Table

Description: Represents the upper threshold of a deadband where the diagnostic will be inhibited to prevent false fails due to clutch slip that can falsely indicate a valid in-gear N/TOS ratio. The lower threshold of the deadband is represented by the table "P0806 ResidualErrEnableLow Table". A lower threshold value that is greater than or equal to the upper threshold for the same gear is an indication that this portion of the diagnostic's enable critera is ignored in that gear. Conversely if the lower threshold value is at or near 0% and the upper threshold for the same gear is at or near 100%, then diagnosis is not enabled in that gear.

Value Units: Percent Clutch Pedal Position (%)
X Unit: Gear, where "0" - "6" is gear 1 - 7, respectively; "7" is reverse

y/x	CeMTCl_e_Gear1	CeMTCl_e_Gear2	CeMTCl_e_Gear3	CeMTCl_e_Gear4	CeMTCl_e_Gear5	CeMTCl_e_Gear6	CeMTCl_e_Gear7	CeMTCl_e_Reverse
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Initial Supporting table - P0806 ResidualErrEnableLow Table

Description: Represents the lower threshold of a deadband where the diagnostic will be inhibited to prevent false fails due to clutch slip that can falsely indicate a valid in-gear N/TOS ratio. The upper threshold of the deadband is represented by the table "P0806 ResidualErrEnableHigh Table". An upper threshold value that is less than or equal to the lower threshold for the same gear is an indication that this portion of the diagnostic's enable critera is ignored in that gear. Conversely if the lower threshold value is at or near 0% and the upper threshold for the same gear is at or near 100%, then diagnosis is not enabled in that gear.

Value Units: Percent Clutch Pedal Position (%)
X Unit: Gear, where "0" - "6" is gear 1 - 7, respectively; "7" is reverse

y/x	CeMTCl_e_Gear1	CeMTCl_e_Gear2	CeMTCl_e_Gear3	CeMTCl_e_Gear4	CeMTCl_e_Gear5	CeMTCl_e_Gear6	CeMTCl_e_Gear7	CeMTCl_e_Reverse
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Initial Supporting table - P0299: Underboost high rate limit as a function of engine speed

Description: Allowed positive rate limit on desired boost pressure. In allowed kPa per 100 ms.

Value Units: [kPa] Allowed positive rate limit
X Unit: [rpm] KnBSTD_n_CntrlDevDiagEngSpdBP - Engine Speed

y/x	1,000	1,500	1,900	2,500	3,000	3,500	4,000	4,500	5,500	6,500
1	0.195	0.265	0.449	1.560	1.976	2.080	2.080	2.080	2.080	2.080

Initial Supporting table - P0299: Underboost low rate limit as a function of engine speed

Description: Allowed negative rate limit on desired boost pressure. In allowed kPa per 100 ms.

Value Units: [kPa] Allowed negative rate limit.
X Unit: [rpm] KnBSTD_n_CntrlDevDiagEngSpdBP - Engine Speed

y/x	1,000	1,500	1,900	2,500	3,000	3,500	4,000	4,500	5,500	6,500
1	-200.00	-200.00	-200.00	-200.00	-200.00	-200.00	-200.00	-200.00	-200.00	-200.00

Small Pulse General Enable (General Enable Missing Pulse, Min Learn limit, Max Learn Limit and Voltage Feedback Rationalities)

A) ignition state in Run or Crank

B) No Low Fuel condition (

C) InjCkt Fault Active

D) InjCkt TFTKO

E) Run time

F) PTRelayInRange OR PTRelayVoltage

I) Injector Circuit Fault Pending For Current Cylinder

J) Pulse under consideration was delivered at a pressure

K) Collision OR Process Pulse OR Invalid pulse data

" "A) == TRUE

B) == FALSE

C) == FALSE

D) == FALSE

E) >= KeFULO_t_PulseDiagRunTmDly

F) ≥ KeFULO_U_PulseDiagEnblThrsh

I) FALSE

J) >= KeFULO_p_SmallPulseCompMinThrsh

K) == TRUE"

Small Pulse General Enable (General Enable Missing Pulse, Min Learn limit, Max Learn Limit and Voltage Feedback Rationalities)
Run Crank Active

Initial Supporting table - P00C4 P2261: Compressor Surge Line

Description: Turbo compressor recirculation valve diagnosis surge area limit.

Value Units: [ratio] CRV diagnosis surge area limit.
X Unit: [g/sec[] KnBSTD_dm_AirFlowBP - Air FLow

y/x	11.94	23.08	40.02	55.08	71.72	99.66
1	1.020	1.230	1.900	2.300	2.700	3.218

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

Description: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix - This table describes combinations of individual model failures that will set P0101, P0106, P010B, P0121, P0236 and P1101 on turbocharged applications.

Value Units: Boolean
X Unit: Unitless (See top line for heading information)
Y Units: Unitless

y/x	1	2	3	4	5	6	7	8	9
1	MAF Model	MAP1 Model	MAP2 Model	MAP3 Model	TIAP1 Model	TPS Model	TIAP Correlation	TIAP Correlation	DTC Set
2	Failed	Failed	Failed	Failed	Failed	Failed	Failed	Valid	
3	F	F	F	F	F	F	F	F	No DTC
4	F	F	F	F	F	F	F	T	No DTC
5	F	F	F	F	F	F	T	F	No DTC
6	F	F	F	F	F	F	T	T	No DTC
7	F	F	F	F	F	T	F	F	No DTC
8	F	F	F	F	F	T	F	T	No DTC
9	F	F	F	F	F	T	T	F	No DTC
10	F	F	F	F	F	T	T	T	No DTC
11	F	F	F	F	T	F	F	F	No DTC
12	F	F	F	F	T	F	F	T	No DTC
13	F	F	F	F	T	F	T	F	No DTC
14	F	F	F	F	T	F	T	T	No DTC
15	F	F	F	F	T	T	F	F	P1101
16	F	F	F	F	T	T	F	T	P0121
17	F	F	F	F	T	T	T	F	P1101
18	F	F	F	F	T	T	T	T	P0236
19	F	F	F	T	F	F	F	F	No DTC
20	F	F	F	T	F	F	F	T	P1101
21	F	F	F	T	F	F	T	F	P1101
22	F	F	F	T	F	F	T	T	P1101
23	F	F	F	T	F	T	F	F	P1101
24	F	F	F	T	F	T	F	T	P1101
25	F	F	F	T	F	T	T	F	P1101
26	F	F	F	T	F	T	T	T	P1101
27	F	F	F	T	T	F	F	F	P1101
28	F	F	F	T	T	F	F	T	P1101
29	F	F	F	T	T	F	T	F	P1101
30	F	F	F	T	T	F	T	T	P1101
31	F	F	F	T	T	T	F	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

32	F	F	F	T	T	T	F	T	P1101
33	F	F	F	T	T	T	T	F	P1101
34	F	F	F	T	T	T	T	T	P1101
35	F	F	T	F	F	F	F	F	No DTC
36	F	F	T	F	F	F	F	T	P1101
37	F	F	T	F	F	F	T	F	P1101
38	F	F	T	F	F	F	T	T	P1101
39	F	F	T	F	F	T	F	F	P1101
40	F	F	T	F	F	T	F	T	P1101
41	F	F	T	F	F	T	T	F	P1101
42	F	F	T	F	F	T	T	T	P1101
43	F	F	T	F	T	F	F	F	P1101
44	F	F	T	F	T	F	F	T	P1101
45	F	F	T	F	T	F	T	F	P1101
46	F	F	T	F	T	F	T	T	P1101
47	F	F	T	F	T	T	F	F	P1101
48	F	F	T	F	T	T	F	T	P1101
49	F	F	T	F	T	T	T	F	P1101
50	F	F	T	F	T	T	T	T	P1101
51	F	F	T	T	F	F	F	F	P1101
52	F	F	T	T	F	F	F	T	P1101
53	F	F	T	T	F	F	T	F	P1101
54	F	F	T	T	F	F	T	T	P1101
55	F	F	T	T	F	T	F	F	P1101
56	F	F	T	T	F	T	F	T	P1101
57	F	F	T	T	F	T	T	F	P1101
58	F	F	T	T	F	T	T	T	P1101
59	F	F	T	T	T	F	F	F	No DTC
60	F	F	T	T	T	F	F	T	No DTC
61	F	F	T	T	T	F	T	F	No DTC
62	F	F	T	T	T	F	T	T	No DTC
63	F	F	T	T	T	T	F	F	P1101
64	F	F	T	T	T	T	F	T	P1101
65	F	F	T	T	T	T	T	F	P1101
66	F	F	T	T	T	T	T	T	P1101
67	F	T	F	F	F	F	F	F	No DTC
68	F	T	F	F	F	F	F	T	P1101
69	F	T	F	F	F	F	T	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

70	F	T	F	F	F	F	T	T	P0236
71	F	T	F	F	F	T	F	F	P1101
72	F	T	F	F	F	T	F	T	P0121
73	F	T	F	F	F	T	T	F	P1101
74	F	T	F	F	F	T	T	T	P0236
75	F	T	F	F	T	F	F	F	P1101
76	F	T	F	F	T	F	F	T	P1101
77	F	T	F	F	T	F	T	F	P1101
78	F	T	F	F	T	F	T	T	P0236
79	F	T	F	F	T	T	F	F	P1101
80	F	T	F	F	T	T	F	T	P0121
81	F	T	F	F	T	T	T	F	P1101
82	F	T	F	F	T	T	T	T	P0236
83	F	T	F	T	F	F	F	F	P1101
84	F	T	F	T	F	F	F	T	P1101
85	F	T	F	T	F	F	T	F	P1101
86	F	T	F	T	F	F	T	T	P1101
87	F	T	F	T	F	T	F	F	P1101
88	F	T	F	T	F	T	F	T	P1101
89	F	T	F	T	F	T	T	F	P1101
90	F	T	F	T	F	T	T	T	P1101
91	F	T	F	T	T	F	F	F	P1101
92	F	T	F	T	T	F	F	T	P1101
93	F	T	F	T	T	F	T	F	P1101
94	F	T	F	T	T	F	T	T	P1101
95	F	T	F	T	T	T	F	F	P1101
96	F	T	F	T	T	T	F	T	P1101
97	F	T	F	T	T	T	T	F	P1101
98	F	T	F	T	T	T	T	T	P1101
99	F	T	T	F	F	F	F	F	P1101
100	F	T	T	F	F	F	F	T	P1101
101	F	T	T	F	F	F	T	F	P1101
102	F	T	T	F	F	F	T	T	P1101
103	F	T	T	F	F	T	F	F	P1101
104	F	T	T	F	F	T	F	T	P1101
105	F	T	T	F	F	T	T	F	P1101
106	F	T	T	F	F	T	T	T	P1101
107	F	T	T	F	T	F	F	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

108	F	T	T	F	T	F	F	T	P1101
109	F	T	T	F	T	F	T	F	P1101
110	F	T	T	F	T	F	T	T	P1101
111	F	T	T	F	T	T	F	F	P1101
112	F	T	T	F	T	T	F	T	P1101
113	F	T	T	F	T	T	T	F	P1101
114	F	T	T	F	T	T	T	T	P1101
115	F	T	T	T	F	F	F	F	P0106
116	F	T	T	T	F	F	F	T	P0106
117	F	T	T	T	F	F	T	F	P0106
118	F	T	T	T	F	F	T	T	P0106
119	F	T	T	T	F	T	F	F	P1101
120	F	T	T	T	F	T	F	T	P1101
121	F	T	T	T	F	T	T	F	P1101
122	F	T	T	T	F	T	T	T	P1101
123	F	T	T	T	T	F	F	F	P1101
124	F	T	T	T	T	F	F	T	P1101
125	F	T	T	T	T	F	T	F	P1101
126	F	T	T	T	T	F	T	T	P1101
127	F	T	T	T	T	T	F	F	P1101
128	F	T	T	T	T	T	F	T	P1101
129	F	T	T	T	T	T	T	F	P1101
130	F	T	T	T	T	T	T	T	P1101
131	T	F	F	F	F	F	F	F	No DTC
132	T	F	F	F	F	F	F	T	P1101
133	T	F	F	F	F	F	T	F	P1101
134	T	F	F	F	F	F	T	T	P0236
135	T	F	F	F	F	T	F	F	P1101
136	T	F	F	F	F	T	F	T	P0121
137	T	F	F	F	F	T	T	F	P1101
138	T	F	F	F	F	T	T	T	P0236
139	T	F	F	F	T	F	F	F	P1101
140	T	F	F	F	T	F	F	T	P1101
141	T	F	F	F	T	F	T	F	P1101
142	T	F	F	F	T	F	T	T	P0236
143	T	F	F	F	T	T	F	F	P1101
144	T	F	F	F	T	T	F	T	P0121
145	T	F	F	F	T	T	T	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

146	T	F	F	F	T	T	T	T	P0236
147	T	F	F	T	F	F	F	F	P1101
148	T	F	F	T	F	F	F	T	P1101
149	T	F	F	T	F	F	T	F	P1101
150	T	F	F	T	F	F	T	T	P1101
151	T	F	F	T	F	T	F	F	P1101
152	T	F	F	T	F	T	F	T	P1101
153	T	F	F	T	F	T	T	F	P1101
154	T	F	F	T	F	T	T	T	P1101
155	T	F	F	T	T	F	F	F	P1101
156	T	F	F	T	T	F	F	T	P1101
157	T	F	F	T	T	F	T	F	P1101
158	T	F	F	T	T	F	T	T	P1101
159	T	F	F	T	T	T	F	F	P1101
160	T	F	F	T	T	T	F	T	P1101
161	T	F	F	T	T	T	T	F	P1101
162	T	F	F	T	T	T	T	T	P1101
163	T	F	T	F	F	F	F	F	P1101
164	T	F	T	F	F	F	F	T	P1101
165	T	F	T	F	F	F	T	F	P1101
166	T	F	T	F	F	F	T	T	P1101
167	T	F	T	F	F	T	F	F	P1101
168	T	F	T	F	F	T	F	T	P1101
169	T	F	T	F	F	T	T	F	P1101
170	T	F	T	F	F	T	T	T	P1101
171	T	F	T	F	T	F	F	F	P1101
172	T	F	T	F	T	F	F	T	P1101
173	T	F	T	F	T	F	T	F	P1101
174	T	F	T	F	T	F	T	T	P1101
175	T	F	T	F	T	T	F	F	P1101
176	T	F	T	F	T	T	F	T	P1101
177	T	F	T	F	T	T	T	F	P1101
178	T	F	T	F	T	T	T	T	P1101
179	T	F	T	T	F	F	F	F	P1101
180	T	F	T	T	F	F	F	T	P1101
181	T	F	T	T	F	F	T	F	P1101
182	T	F	T	T	F	F	T	T	P1101
183	T	F	T	T	F	T	F	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

184	T	F	T	T	F	T	F	T	P1101
185	T	F	T	T	F	T	T	F	P1101
186	T	F	T	T	F	T	T	T	P1101
187	T	F	T	T	T	F	F	F	P0101 or P010B
188	T	F	T	T	T	F	F	T	P0101 or P010B
189	T	F	T	T	T	F	T	F	P0101 or P010B
190	T	F	T	T	T	F	T	T	P0101 or P010B
191	T	F	T	T	T	T	F	F	P1101
192	T	F	T	T	T	T	F	T	P1101
193	T	F	T	T	T	T	T	F	P1101
194	T	F	T	T	T	T	T	T	P1101
195	T	T	F	F	F	F	F	F	P1101
196	T	T	F	F	F	F	F	T	P1101
197	T	T	F	F	F	F	T	F	P1101
198	T	T	F	F	F	F	T	T	P0236
199	T	T	F	F	F	T	F	F	P1101
200	T	T	F	F	F	T	F	T	P0121
201	T	T	F	F	F	T	T	F	P1101
202	T	T	F	F	F	T	T	T	P0236
203	T	T	F	F	T	F	F	F	P1101
204	T	T	F	F	T	F	F	T	P1101
205	T	T	F	F	T	F	T	F	P1101
206	T	T	F	F	T	F	T	T	P0236
207	T	T	F	F	T	T	F	F	P1101
208	T	T	F	F	T	T	F	T	P0121
209	T	T	F	F	T	T	T	F	P1101
210	T	T	F	F	T	T	T	T	P0236
211	T	T	F	T	F	F	F	F	P1101
212	T	T	F	T	F	F	F	T	P1101
213	T	T	F	T	F	F	T	F	P1101
214	T	T	F	T	F	F	T	T	P1101
215	T	T	F	T	F	T	F	F	P1101
216	T	T	F	T	F	T	F	T	P1101
217	T	T	F	T	F	T	T	F	P1101
218	T	T	F	T	F	T	T	T	P1101
219	T	T	F	T	T	F	F	F	P1101
220	T	T	F	T	T	F	F	T	P1101
221	T	T	F	T	T	F	T	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

222	T	T	F	T	T	F	T	T	P1101
223	T	T	F	T	T	T	F	F	P1101
224	T	T	F	T	T	T	F	T	P1101
225	T	T	F	T	T	T	T	F	P1101
226	T	T	F	T	T	T	T	T	P1101
227	T	T	T	F	F	F	F	F	P1101
228	T	T	T	F	F	F	F	T	P1101
229	T	T	T	F	F	F	T	F	P1101
230	T	T	T	F	F	F	T	T	P1101
231	T	T	T	F	F	T	F	F	P1101
232	T	T	T	F	F	T	F	T	P1101
233	T	T	T	F	F	T	T	F	P1101
234	T	T	T	F	F	T	T	T	P1101
235	T	T	T	F	T	F	F	F	P1101
236	T	T	T	F	T	F	F	T	P1101
237	T	T	T	F	T	F	T	F	P1101
238	T	T	T	F	T	F	T	T	P1101
239	T	T	T	F	T	T	F	F	P1101
240	T	T	T	F	T	T	F	T	P1101
241	T	T	T	F	T	T	T	F	P1101
242	T	T	T	F	T	T	T	T	P1101
243	T	T	T	T	F	F	F	F	P1101
244	T	T	T	T	F	F	F	T	P1101
245	T	T	T	T	F	F	T	F	P1101
246	T	T	T	T	F	F	T	T	P1101
247	T	T	T	T	F	T	F	F	P1101
248	T	T	T	T	F	T	F	T	P1101
249	T	T	T	T	F	T	T	F	P1101
250	T	T	T	T	F	T	T	T	P1101
251	T	T	T	T	T	F	F	F	P1101
252	T	T	T	T	T	F	F	T	P1101
253	T	T	T	T	T	F	T	F	P1101
254	T	T	T	T	T	F	T	T	P1101
255	T	T	T	T	T	T	F	F	P1101
256	T	T	T	T	T	T	F	T	P1101
257	T	T	T	T	T	T	T	F	P1101
258	T	T	T	T	T	T	T	T	P1101

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP1 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,600
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP2 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,600
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP3 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,600
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 TPS Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,600
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P0236_P1101 TIAP Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,600
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.982	0.920	0.837	0.865	0.819	0.819

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Max Air Flow

Value Units: Engine Air Flow (Grams/Second)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	10.0	14.0	23.0	26.0	27.0	20.0	20.0	20.0	20.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Max MAP

Value Units: Manifold Pressure (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	95.0	80.0	60.0	50.0	50.0	40.0	30.0	30.0	30.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Offset

Value Units: Pressure Difference (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	3.5	7.0	7.0	10.0	10.0	10.0	10.0	10.0	10.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min Air Flow

Value Units: Engine Air Flow (Grams/Second)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	13.0	36.0	70.0	82.0	104.0	115.0	120.0	120.0	120.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min MAP

Value Units: Manifold Pressure (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	115.0	150.0	180.0	180.0	180.0	180.0	180.0	165.0	165.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Offset

Value Units: Pressure Difference (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	1.5	1.5	2.5	3.5	3.8	5.0	6.0	6.0	6.0

Initial Supporting table - P0234 P0299: Ambient pressure correction as a function of engine speed and ambient pressure

Description: Additative offset on boost pressure control deviation fail limit.

Value Units: [kPa] Control Deviation - Ambient correction.
X Unit: [kPa] KnBSTD_p_CntrlDevDiagAmbCorrBP - Ambient Air Pressure
Y Units: [rpm] KnBSTD_n_CntrlDevDiagAmbCorrBP - Engine Speed

y/x	60.00	70.00	80.00	90.00	100.00	110.00
2,000	80.00	60.00	40.00	20.00	0.00	0.00
2,500	40.00	30.00	20.00	10.00	0.00	0.00
3,000	15.00	10.00	10.00	0.00	0.00	0.00
4,000	15.00	10.00	10.00	0.00	0.00	0.00
5,000	15.00	10.00	5.00	0.00	0.00	0.00
6,000	15.00	5.00	5.00	0.00	0.00	0.00

Initial Supporting table - P0234 P0299: Boost deviation diagnostic enable delay as a function of engine speed

Description: Timer to stabilize enable conditions for over and underboost diagnosis.

Value Units: [sec] Pressure control deviation diagnosis enable delay.
X Unit: [rpm] KnBSTD_n_CntrlDevDiagEngSpdBP - Engine Speed

y/x	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	6,000
1	8.0000	6.5000	5.0000	3.0000	2.0000	1.0000	1.0000	1.0000	1.0000	1.0000

Initial Supporting table - P0234: Overboost pressure deviation limit as a function of engine speed and desired boost pressure

Description: Negative boost pressure control deviation fail limit.

Value Units: [kPa] Negative boost pressure deviation limit.
X Unit: [kPa] KnBSTD_p_CntrlDevDiagDsrdBP - Boost pressure
Y Units: [rpm] KnBSTD_n_CntrlDevDiagEngSpdBP - Engine speed

y/x	100.00	120.00	140.00	160.00	170.00	180.00	190.00	200.00	210.00	220.00
1,000	-20.00	-20.00	-20.00	-20.00	-20.00	-20.00	-20.00	-20.00	-20.00	-20.00
1,500	-20.00	-20.00	-20.00	-20.00	-20.00	-20.00	-20.00	-20.00	-20.00	-20.00
2,000	-20.00	-20.00	-20.00	-20.00	-20.00	-20.00	-20.00	-20.00	-20.00	-20.00
2,500	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00
3,000	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00
3,500	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00
4,000	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00
4,500	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00
5,000	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00
6,000	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00	-35.00

Initial Supporting table - P050D_P1400_CatalystLightOffExtendedEngineRunTimeExit

Description: Exit Catalyst Warm-up mode if Engine Run Time is greater than this value. This table is based on percent ethanol (x-axis) and catmon's NormRatio_EWMA value (y-axis). The NormRatio_EWMA value determines the state of the catalyst. Typically, NormRatio_EWMA values below 0.35 (0 is bad and 1 is good) represent catalysts that have degraded. The emission performance of these degraded catalysts can be improved by extending catalyst light off of GetE85R_Pct_FFS_CompAtEngFloat.

y/x	0	25	50	75	100
0.000	57	57	57	57	57
0.125	57	57	57	57	57
0.250	57	57	57	57	57
0.375	57	57	57	57	57
0.500	32	32	32	32	32
0.625	32	32	32	32	32
0.750	32	32	32	32	32
0.875	32	32	32	32	32
1.000	32	32	32	32	32

Initial Supporting table - P2B96 - Opening Magnitude Misisng Pulse Fail Limit

Description: Opening Magnitude threshold to detect missing injection pulse

Value Units: Opening Magnitude Voltage
X Unit: Measured Fuel Rail Pressure

y/x	0	1	2	3	4	5	6	8	10	11	12	14	16	18	20	21	24
1	0	0	0	0	0	0	0	0	515	515	515	515	515	515	515	515	515

Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est

Description: P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on MAF Est

Value Units: Weight Factor (Unitless)
X Unit: Estimated Engine Air Flow (Grams/Second)

y/x	0	50	70	73	76	79	82	85	89	95	100	110	150	170	200	230	350
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM

Description: P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,600
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Maximum Injector Closing Time

Description: Maximum injector closing time function of measured fuel rail pressure

Value Units: Injector Closing Time (us)
X Unit: Measrured Fuel Rail Pressure (MPa)

y/x	0.40	1.00	2.00	3.00	4.00	5.00	6.00	8.00	10.00	11.00	12.00	14.00	16.00	18.00	20.00	21.00	24.00
1.00	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Initial Supporting table - P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Maximum Injector Opening Magnitude

Description: Maximum injector opening Magnitude voltage function of measured fuel rail pressure

Value Units: Opening Magnitude Voltage
X Unit: Measrured Fuel Rail Pressure (MPa)

y/x	0.40	1.00	2.00	3.00	4.00	5.00	6.00	8.00	10.00	11.00	12.00	14.00	16.00	18.00	20.00	21.00	24.00
1.00	996	990	993	996	994	991	992	991	989	983	988	986	985	985	990	982	982

Initial Supporting table - P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Minimum Injector Closing Time

Description: Minimum injector closing time function of measured fuel rail pressure

Value Units: Injector Closing Time (us)
X Unit: Measrured Fuel Rail Pressure (MPa)

y/x	0.40	1.00	2.00	3.00	4.00	5.00	6.00	8.00	10.00	11.00	12.00	14.00	16.00	18.00	20.00	21.00	24.00
1.00	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Initial Supporting table - P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Minimum Injector Opening Magnitude

Description: Minimum injector opening Magnitude voltage function of measured fuel rail pressure

Value Units: Opening Magnitude Voltage
X Unit: Measrured Fuel Rail Pressure (MPa)

y/x	0.40	1.00	2.00	3.00	4.00	5.00	6.00	8.00	10.00	11.00	12.00	14.00	16.00	18.00	20.00	21.00	24.00
1.00	460	460	460	460	460	460	460	460	460	460	460	460	460	460	460	460	460

al Supporting table - P02EE P02EF P02F0 P02F1 P02F2 P02F3 P02F4 P02F5 P30D4 - Voltage Feedback Rationalities Minimum Pulse Width

Description: Minimum injection pulse width function of measured fuel rail pressure where the voltage feedback measured from the analog to digital converter is rationalized

Value Units: Pulse Width (ms)
X Unit: Measrured Fuel Rail Pressure (MPa)

y/x	0.40	1.00	2.00	3.00	4.00	5.00	6.00	8.00	10.00	11.00	12.00	14.00	16.00	18.00	20.00	21.00	24.00
1.00	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2

Initial Supporting table - P10A3 P10A5 P10A7 P10A9 P10AB P10AD P10AF P10B1 - Minimum Small Pulse Compensation Limit

Description: Minimum Small Pulse Compensation Fail Limit function of Pulse Width and Pressure

Value Units: Minimum Small Pulse Compensation Fail Limit (ms)
X Unit: Measrured Fuel Rail Pressure (MPa)
Y Units: Injection Pulse With (ms)

P10A3 P10A5 P10A7 P10A9 P10AB P10AD P10AF P10B1 - Minimum Small Pulse Compensation Limit - Part 1

y/x	0.00	0.00	0.01	0.01	0.02	0.02	0.02	0.03	0.03	0.04	0.04
0.40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
2.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
3.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
4.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
5.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
6.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
8.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
10.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
11.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
12.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
14.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
16.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
18.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
20.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
21.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
24.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

P10A3 P10A5 P10A7 P10A9 P10AB P10AD P10AF P10B1 - Minimum Small Pulse Compensation Limit - Part 2

y/x	0.04	0.05	0.05	0.06	0.06	0.06	0.07	0.07	0.08	0.08	0.10
0.40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
2.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
3.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
4.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
5.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
6.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
8.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
10.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
11.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
12.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

Initial Supporting table - P10A3 P10A5 P10A7 P10A9 P10AB P10AD P10AF P10B1 - Minimum Small Pulse Compensation Limit

14.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
16.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
18.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
20.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
21.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
24.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

P10A3 P10A5 P10A7 P10A9 P10AB P10AD P10AF P10B1 - Minimum Small Pulse Compensation Limit - Part 3

y/x	0.15	0.20	0.25	0.30	0.35	0.40	0.45	0.50	0.55	1.00	1.50
0.40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
2.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
3.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
4.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
5.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
6.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
8.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
10.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
11.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
12.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
14.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
16.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
18.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
20.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
21.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
24.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

Initial Supporting table - P10A4 P10A6 P10A8 P10AA P10AC P10AE P10B0 P10B2 - Maximum Small Pulse Compensation Limit

Description: Maximum Small Pulse Compensation Fail Limit function of Pulse Width and Pressure

Value Units: Maximum Small Pulse Compensation Fail Limit (ms)
X Unit: Measrured Fuel Rail Pressure (MPa)
Y Units: Injection Pulse With (ms)

P10A4 P10A6 P10A8 P10AA P10AC P10AE P10B0 P10B2 - Maximum Small Pulse Compensation Limit - Part 1

y/x	0.00	0.00	0.01	0.01	0.02	0.02	0.02	0.03	0.03	0.04	0.04
0.40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
2.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
3.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
4.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
5.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
6.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
8.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
10.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
11.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
12.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
14.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
16.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
18.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
20.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
21.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
24.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

P10A4 P10A6 P10A8 P10AA P10AC P10AE P10B0 P10B2 - Maximum Small Pulse Compensation Limit - Part 2

y/x	0.04	0.05	0.05	0.06	0.06	0.06	0.07	0.07	0.08	0.08	0.10
0.40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
2.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
3.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
4.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
5.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
6.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
8.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
10.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
11.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
12.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

Initial Supporting table - P10A4 P10A6 P10A8 P10AA P10AC P10AE P10B0 P10B2 - Maximum Small Pulse Compensation Limit

14.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
16.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
18.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
20.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
21.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
24.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

P10A4 P10A6 P10A8 P10AA P10AC P10AE P10B0 P10B2 - Maximum Small Pulse Compensation Limit - Part 3

y/x	0.15	0.20	0.25	0.30	0.35	0.40	0.45	0.50	0.55	1.00	1.50
0.40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
2.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
3.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
4.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
5.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
6.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
8.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
10.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
11.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
12.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
14.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
16.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
18.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
20.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
21.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
24.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

00 P2B01 P2B02 P2B03 P2B04 P2B05 P2B06 P2B07 P2B96 P2B08 P2B09 P2B0A P2B0B P2B0C P2B0D P2B0E P2B0F- Opening Magnitude M

Description: Opening Magnitude threshold to detect missing injection pulse

Value Units: Opening Magnitude Voltage
X Unit: Measured Fuel Rail Pressure

y/x	0.40	1.00	2.00	3.00	4.00	5.00	6.00	8.00	10.00	11.00	12.00	14.00	16.00	18.00	20.00	21.00	24.00
1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	515.00	515.00	515.00	515.00	515.00	515.00	515.00	515.00	515.00

Initial Supporting table - P0234: Overboost pressure limit below basic pressure as a function of engine speed and ambient pressure

Description: Overboost under basic pressure (open loop pressure control) diagnose failure limit.

Value Units: [kPa] Overboost under basic pressure fail limit.
X Unit: [kPa] KnBSTD_p_CntrlDevDiagAmbCorrBP - Ambient Air Pressure
Y Units: [rpm] KnBSTD_n_CntrlDevDiagAmbCorrBP - Engine Speed

y/x	60.00	70.00	80.00	90.00	100.00	110.00
2,000.00	62.000	52.000	32.000	30.000	30.000	30.000
2,500.00	62.000	38.500	20.000	20.000	20.000	20.000
3,000.00	42.000	25.000	10.000	10.000	10.000	10.000
4,000.00	30.000	10.000	10.000	10.000	10.000	10.000
5,000.00	30.000	10.000	10.000	10.000	10.000	10.000
6,000.00	30.000	10.000	10.000	10.000	10.000	10.000

Initial Supporting table - Multiple DTC Use_Green Sensor Delay Criteria - Limit

Description: This Calibration is the acculmulated airflow limit above which the Green condition is expired
Used for: P0133, P013A, P013B, P013C, P013D, P013E, P013F, P014A, P014B, P0153, P015A, P015B, P015C, P015D, P1133, P1153, P2270, P2271, P2272 and P2273.
Note: This feature is only enabled when the vehicle is new and cannot be enabled in service.

Value Units: Grams
X Unit: Acculmulated Engine Airflow

y/x	CiOXYR_O2_Bank1_Sensor1	CiOXYR_O2_Bank1_Sensor2	CiOXYR_O2_Bank2_Sensor1	CiOXYR_O2_Bank2_Sensor2
1	120,000	120,000	120,000	120,000

Initial Supporting table - P0011_P05CC_StablePositionTimeIc1

Description: Minimum time for Intake Cam 1 phase position to be stable to enable performance diagnostic.

Value Units: Minimum time (sec)
X Unit: Engine Oil Temperature (degC)
Y Units: Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0

Initial Supporting table - P0014_CamPosErrorLimEc1

Description: Maximum Exhaust Cam 1 phase error as a function of engine speed and engine oil temperature.

Value Units: Maximum Exhaust Cam 1 phase error (degCAM)
X Unit: Engine Oil Temperature (degC)
Y Units: Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

Initial Supporting table - P0014_P05CE_StablePositionTimeEc1

Description: Minimum time for Exhaust Cam 1 phase position to be stable to enable performance diagnostic.

Value Units: Minimum time (sec)
X Unit: Engine Oil Temperature (degC)
Y Units: Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0

Initial Supporting table - P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold

Description: P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold

Value Units: Engine Run Time- Seconds
X Unit: Oil Temperature- C

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	300	7	5	2	1	1	1	1	1	1	1	1	1	1	1	1	1

Initial Supporting table - P0021_CamPosErrorLimIc2

Description: Maximum Intake Cam 2 phase error as a function of engine speed and engine oil temperature.

Value Units: Maximum Intake Cam 2 phase error (degCAM)
X Unit: Engine Oil Temperature (degC)
Y Units: Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

Initial Supporting table - P0021_P05CD_StablePositionTimeIc2

Description: Minimum time for Intake Cam 2 phase position to be stable to enable performance diagnostic.

Value Units: Minimum time (sec)
X Unit: Engine Oil Temperature (degC)
Y Units: Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0

Initial Supporting table - P0024_CamPosErrorLimEc2

Description: Maximum Exhaust Cam 2 phase error as a function of engine speed and engine oil temperature.

Value Units: Maximum Exhaust Cam 2 phase error (degCAM)
X Unit: Engine Oil Temperature (degC)
Y Units: Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

Initial Supporting table - P0024_P05CF_StablePositionTimeEc2

Description: Minimum time for Exhaust Cam 2 phase position to be stable to enable performance diagnostic.

Value Units: Minimum time (sec)
X Unit: Engine Oil Temperature (degC)
Y Units: Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

Description: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix - This table describes combinations of individual model failures that will set P0101, P0106, P010B, P0121, P0236 and P1101 on turbocharged applications.

Value Units: Boolean
X Unit: Unitless (See top line for heading information)
Y Units: Unitless

y/x	1	2	3	4	5	6	7	8	9
1	MAF Model	MAP1 Model	MAP2 Model	MAP3 Model	TIAP1 Model	TPS Model	TIAP Correlation	TIAP Correlation	DTC Set
2	Failed	Failed	Failed	Failed	Failed	Failed	Failed	Valid	
3	F	F	F	F	F	F	F	F	No DTC
4	F	F	F	F	F	F	F	T	No DTC
5	F	F	F	F	F	F	T	F	No DTC
6	F	F	F	F	F	F	T	T	No DTC
7	F	F	F	F	F	T	F	F	No DTC
8	F	F	F	F	F	T	F	T	No DTC
9	F	F	F	F	F	T	T	F	No DTC
10	F	F	F	F	F	T	T	T	No DTC
11	F	F	F	F	T	F	F	F	No DTC
12	F	F	F	F	T	F	F	T	No DTC
13	F	F	F	F	T	F	T	F	No DTC
14	F	F	F	F	T	F	T	T	No DTC
15	F	F	F	F	T	T	F	F	P1101
16	F	F	F	F	T	T	F	T	P0121
17	F	F	F	F	T	T	T	F	P1101
18	F	F	F	F	T	T	T	T	P0236
19	F	F	F	T	F	F	F	F	No DTC
20	F	F	F	T	F	F	F	T	P1101
21	F	F	F	T	F	F	T	F	P1101
22	F	F	F	T	F	F	T	T	P1101
23	F	F	F	T	F	T	F	F	P1101
24	F	F	F	T	F	T	F	T	P1101
25	F	F	F	T	F	T	T	F	P1101
26	F	F	F	T	F	T	T	T	P1101
27	F	F	F	T	T	F	F	F	P1101
28	F	F	F	T	T	F	F	T	P1101
29	F	F	F	T	T	F	T	F	P1101
30	F	F	F	T	T	F	T	T	P1101
31	F	F	F	T	T	T	F	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix									
32	F	F	F	T	T	T	F	T	P1101
33	F	F	F	T	T	T	T	F	P1101
34	F	F	F	T	T	T	T	T	P1101
35	F	F	T	F	F	F	F	F	No DTC
36	F	F	T	F	F	F	F	T	P1101
37	F	F	T	F	F	F	T	F	P1101
38	F	F	T	F	F	F	T	T	P1101
39	F	F	T	F	F	T	F	F	P1101
40	F	F	T	F	F	T	F	T	P1101
41	F	F	T	F	F	T	T	F	P1101
42	F	F	T	F	F	T	T	T	P1101
43	F	F	T	F	T	F	F	F	P1101
44	F	F	T	F	T	F	F	T	P1101
45	F	F	T	F	T	F	T	F	P1101
46	F	F	T	F	T	F	T	T	P1101
47	F	F	T	F	T	T	F	F	P1101
48	F	F	T	F	T	T	F	T	P1101
49	F	F	T	F	T	T	T	F	P1101
50	F	F	T	F	T	T	T	T	P1101
51	F	F	T	T	F	F	F	F	P1101
52	F	F	T	T	F	F	F	T	P1101
53	F	F	T	T	F	F	T	F	P1101
54	F	F	T	T	F	F	T	T	P1101
55	F	F	T	T	F	T	F	F	P1101
56	F	F	T	T	F	T	F	T	P1101
57	F	F	T	T	F	T	T	F	P1101
58	F	F	T	T	F	T	T	T	P1101
59	F	F	T	T	T	F	F	F	No DTC
60	F	F	T	T	T	F	F	T	No DTC
61	F	F	T	T	T	F	T	F	No DTC
62	F	F	T	T	T	F	T	T	No DTC
63	F	F	T	T	T	T	F	F	P1101
64	F	F	T	T	T	T	F	T	P1101
65	F	F	T	T	T	T	T	F	P1101
66	F	F	T	T	T	T	T	T	P1101
67	F	T	F	F	F	F	F	F	No DTC
68	F	T	F	F	F	F	F	T	P1101
69	F	T	F	F	F	F	T	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

70	F	T	F	F	F	F	T	T	P0236
71	F	T	F	F	F	T	F	F	P1101
72	F	T	F	F	F	T	F	T	P0121
73	F	T	F	F	F	T	T	F	P1101
74	F	T	F	F	F	T	T	T	P0236
75	F	T	F	F	T	F	F	F	P1101
76	F	T	F	F	T	F	F	T	P1101
77	F	T	F	F	T	F	T	F	P1101
78	F	T	F	F	T	F	T	T	P0236
79	F	T	F	F	T	T	F	F	P1101
80	F	T	F	F	T	T	F	T	P0121
81	F	T	F	F	T	T	T	F	P1101
82	F	T	F	F	T	T	T	T	P0236
83	F	T	F	T	F	F	F	F	P1101
84	F	T	F	T	F	F	F	T	P1101
85	F	T	F	T	F	F	T	F	P1101
86	F	T	F	T	F	F	T	T	P1101
87	F	T	F	T	F	T	F	F	P1101
88	F	T	F	T	F	T	F	T	P1101
89	F	T	F	T	F	T	T	F	P1101
90	F	T	F	T	F	T	T	T	P1101
91	F	T	F	T	T	F	F	F	P1101
92	F	T	F	T	T	F	F	T	P1101
93	F	T	F	T	T	F	T	F	P1101
94	F	T	F	T	T	F	T	T	P1101
95	F	T	F	T	T	T	F	F	P1101
96	F	T	F	T	T	T	F	T	P1101
97	F	T	F	T	T	T	T	F	P1101
98	F	T	F	T	T	T	T	T	P1101
99	F	T	T	F	F	F	F	F	P1101
100	F	T	T	F	F	F	F	T	P1101
101	F	T	T	F	F	F	T	F	P1101
102	F	T	T	F	F	F	T	T	P1101
103	F	T	T	F	F	T	F	F	P1101
104	F	T	T	F	F	T	F	T	P1101
105	F	T	T	F	F	T	T	F	P1101
106	F	T	T	F	F	T	T	T	P1101
107	F	T	T	F	T	F	F	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

108	F	T	T	F	T	F	F	T	P1101
109	F	T	T	F	T	F	T	F	P1101
110	F	T	T	F	T	F	T	T	P1101
111	F	T	T	F	T	T	F	F	P1101
112	F	T	T	F	T	T	F	T	P1101
113	F	T	T	F	T	T	T	F	P1101
114	F	T	T	F	T	T	T	T	P1101
115	F	T	T	T	F	F	F	F	P0106
116	F	T	T	T	F	F	F	T	P0106
117	F	T	T	T	F	F	T	F	P0106
118	F	T	T	T	F	F	T	T	P0106
119	F	T	T	T	F	T	F	F	P1101
120	F	T	T	T	F	T	F	T	P1101
121	F	T	T	T	F	T	T	F	P1101
122	F	T	T	T	F	T	T	T	P1101
123	F	T	T	T	T	F	F	F	P1101
124	F	T	T	T	T	F	F	T	P1101
125	F	T	T	T	T	F	T	F	P1101
126	F	T	T	T	T	F	T	T	P1101
127	F	T	T	T	T	T	F	F	P1101
128	F	T	T	T	T	T	F	T	P1101
129	F	T	T	T	T	T	T	F	P1101
130	F	T	T	T	T	T	T	T	P1101
131	T	F	F	F	F	F	F	F	No DTC
132	T	F	F	F	F	F	F	T	P1101
133	T	F	F	F	F	F	T	F	P1101
134	T	F	F	F	F	F	T	T	P0236
135	T	F	F	F	F	T	F	F	P1101
136	T	F	F	F	F	T	F	T	P0121
137	T	F	F	F	F	T	T	F	P1101
138	T	F	F	F	F	T	T	T	P0236
139	T	F	F	F	T	F	F	F	P1101
140	T	F	F	F	T	F	F	T	P1101
141	T	F	F	F	T	F	T	F	P1101
142	T	F	F	F	T	F	T	T	P0236
143	T	F	F	F	T	T	F	F	P1101
144	T	F	F	F	T	T	F	T	P0121
145	T	F	F	F	T	T	T	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

146	T	F	F	F	T	T	T	T	P0236
147	T	F	F	T	F	F	F	F	P1101
148	T	F	F	T	F	F	F	T	P1101
149	T	F	F	T	F	F	T	F	P1101
150	T	F	F	T	F	F	T	T	P1101
151	T	F	F	T	F	T	F	F	P1101
152	T	F	F	T	F	T	F	T	P1101
153	T	F	F	T	F	T	T	F	P1101
154	T	F	F	T	F	T	T	T	P1101
155	T	F	F	T	T	F	F	F	P1101
156	T	F	F	T	T	F	F	T	P1101
157	T	F	F	T	T	F	T	F	P1101
158	T	F	F	T	T	F	T	T	P1101
159	T	F	F	T	T	T	F	F	P1101
160	T	F	F	T	T	T	F	T	P1101
161	T	F	F	T	T	T	T	F	P1101
162	T	F	F	T	T	T	T	T	P1101
163	T	F	T	F	F	F	F	F	P1101
164	T	F	T	F	F	F	F	T	P1101
165	T	F	T	F	F	F	T	F	P1101
166	T	F	T	F	F	F	T	T	P1101
167	T	F	T	F	F	T	F	F	P1101
168	T	F	T	F	F	T	F	T	P1101
169	T	F	T	F	F	T	T	F	P1101
170	T	F	T	F	F	T	T	T	P1101
171	T	F	T	F	T	F	F	F	P1101
172	T	F	T	F	T	F	F	T	P1101
173	T	F	T	F	T	F	T	F	P1101
174	T	F	T	F	T	F	T	T	P1101
175	T	F	T	F	T	T	F	F	P1101
176	T	F	T	F	T	T	F	T	P1101
177	T	F	T	F	T	T	T	F	P1101
178	T	F	T	F	T	T	T	T	P1101
179	T	F	T	T	F	F	F	F	P1101
180	T	F	T	T	F	F	F	T	P1101
181	T	F	T	T	F	F	T	F	P1101
182	T	F	T	T	F	F	T	T	P1101
183	T	F	T	T	F	T	F	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

184	T	F	T	T	F	T	F	T	P1101
185	T	F	T	T	F	T	T	F	P1101
186	T	F	T	T	F	T	T	T	P1101
187	T	F	T	T	T	F	F	F	P0101 or P010B
188	T	F	T	T	T	F	F	T	P0101 or P010B
189	T	F	T	T	T	F	T	F	P0101 or P010B
190	T	F	T	T	T	F	T	T	P0101 or P010B
191	T	F	T	T	T	T	F	F	P1101
192	T	F	T	T	T	T	F	T	P1101
193	T	F	T	T	T	T	T	F	P1101
194	T	F	T	T	T	T	T	T	P1101
195	T	T	F	F	F	F	F	F	P1101
196	T	T	F	F	F	F	F	T	P1101
197	T	T	F	F	F	F	T	F	P1101
198	T	T	F	F	F	F	T	T	P0236
199	T	T	F	F	F	T	F	F	P1101
200	T	T	F	F	F	T	F	T	P0121
201	T	T	F	F	F	T	T	F	P1101
202	T	T	F	F	F	T	T	T	P0236
203	T	T	F	F	T	F	F	F	P1101
204	T	T	F	F	T	F	F	T	P1101
205	T	T	F	F	T	F	T	F	P1101
206	T	T	F	F	T	F	T	T	P0236
207	T	T	F	F	T	T	F	F	P1101
208	T	T	F	F	T	T	F	T	P0121
209	T	T	F	F	T	T	T	F	P1101
210	T	T	F	F	T	T	T	T	P0236
211	T	T	F	T	F	F	F	F	P1101
212	T	T	F	T	F	F	F	T	P1101
213	T	T	F	T	F	F	T	F	P1101
214	T	T	F	T	F	F	T	T	P1101
215	T	T	F	T	F	T	F	F	P1101
216	T	T	F	T	F	T	F	T	P1101
217	T	T	F	T	F	T	T	F	P1101
218	T	T	F	T	F	T	T	T	P1101
219	T	T	F	T	T	F	F	F	P1101
220	T	T	F	T	T	F	F	T	P1101
221	T	T	F	T	T	F	T	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

222	T	T	F	T	T	F	T	T	P1101
223	T	T	F	T	T	T	F	F	P1101
224	T	T	F	T	T	T	F	T	P1101
225	T	T	F	T	T	T	T	F	P1101
226	T	T	F	T	T	T	T	T	P1101
227	T	T	T	F	F	F	F	F	P1101
228	T	T	T	F	F	F	F	T	P1101
229	T	T	T	F	F	F	T	F	P1101
230	T	T	T	F	F	F	T	T	P1101
231	T	T	T	F	F	T	F	F	P1101
232	T	T	T	F	F	T	F	T	P1101
233	T	T	T	F	F	T	T	F	P1101
234	T	T	T	F	F	T	T	T	P1101
235	T	T	T	F	T	F	F	F	P1101
236	T	T	T	F	T	F	F	T	P1101
237	T	T	T	F	T	F	T	F	P1101
238	T	T	T	F	T	F	T	T	P1101
239	T	T	T	F	T	T	F	F	P1101
240	T	T	T	F	T	T	F	T	P1101
241	T	T	T	F	T	T	T	F	P1101
242	T	T	T	F	T	T	T	T	P1101
243	T	T	T	T	F	F	F	F	P1101
244	T	T	T	T	F	F	F	T	P1101
245	T	T	T	T	F	F	T	F	P1101
246	T	T	T	T	F	F	T	T	P1101
247	T	T	T	T	F	T	F	F	P1101
248	T	T	T	T	F	T	F	T	P1101
249	T	T	T	T	F	T	T	F	P1101
250	T	T	T	T	F	T	T	T	P1101
251	T	T	T	T	T	F	F	F	P1101
252	T	T	T	T	T	F	F	T	P1101
253	T	T	T	T	T	F	T	F	P1101
254	T	T	T	T	T	F	T	T	P1101
255	T	T	T	T	T	T	F	F	P1101
256	T	T	T	T	T	T	F	T	P1101
257	T	T	T	T	T	T	T	F	P1101
258	T	T	T	T	T	T	T	T	P1101

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP1 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	600	950	1,300	1,650	2,000	2,350	2,700	3,050	3,400	3,750	4,100	4,450	4,800	5,150	5,500	6,000	6,500
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.939	1.000	1.000	1.000	1.000	1.000	1.000	0.835	0.840	0.621

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP2 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	600	950	1,300	1,650	2,000	2,350	2,700	3,050	3,400	3,750	4,100	4,450	4,800	5,150	5,500	6,000	6,500
1	1.000	1.000	1.000	1.000	0.923	0.739	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP3 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	600	950	1,300	1,650	2,000	2,350	2,700	3,050	3,400	3,750	4,100	4,450	4,800	5,150	5,500	6,000	6,500
1	1.000	1.000	1.000	1.000	1.000	0.630	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.643

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 TPS Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	600	950	1,300	1,650	2,000	2,350	2,700	3,050	3,400	3,750	4,100	4,450	4,800	5,150	5,500	6,000	6,500
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.643	0.293

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P0236_P1101 TIAP Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	600	950	1,300	1,650	2,000	2,350	2,700	3,050	3,400	3,750	4,100	4,450	4,800	5,150	5,500	6,000	6,500
1	0.600	0.600	0.800	0.800	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.624	0.440

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Max Air Flow

Value Units: Engine Air Flow (Grams/Second)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	6.5	8.5	10.0	15.0	18.0	22.0	12.0	13.0	13.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Max MAP

Value Units: Manifold Pressure (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	40.0	37.0	33.0	31.0	28.0	28.0	30.0	30.0	30.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Offset

Value Units: Pressure Difference (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	0.7	0.5	0.5	0.7	1.0	1.5	2.0	2.5	3.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min Air Flow

Value Units: Engine Air Flow (Grams/Second)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	24.0	36.0	55.0	85.0	100.0	140.0	150.0	150.0	150.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min MAP

Value Units: Manifold Pressure (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	105.0	108.0	115.0	130.0	140.0	150.0	150.0	150.0	150.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Offset

Value Units: Pressure Difference (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	1.5	1.0	1.0	1.3	2.5	3.0	3.3	4.0	5.0

Initial Supporting table - P00C7: Twin Turbo Failure Matrix

Description: Intake Air Pressure System Performance Failure Matrix for Twin Turbo Applications. This table describes the combination of intake system pressure sensor difference combinations that will set P00C7 on twin turbocharged applications

Value Units: Yes or No
X Unit: Unitless (See top line for heading information)
Y Units: Unitless

y/x	1	2	3	4	5	6	7
1	DTC	MAP & TCBP Diff	MAP & Baro Diff	MAP & Baro B Diff	TCBP & Baro Diff	TCBP & Baro B Diff	Baro & Baro B Diff
2	No DTC	N	N	N	N	N	N
3	P00C7	Y	N	N	N	N	N
4	P00C7	N	Y	N	N	N	N
5	P00C7	Y	Y	N	N	N	N
6	P00C7	N	N	Y	N	N	N
7	P00C7	Y	N	Y	N	N	N
8	P00C7	N	Y	Y	N	N	N
9	P0106	Y	Y	Y	N	N	N
10	P00C7	N	N	N	Y	N	N
11	P00C7	Y	N	N	Y	N	N
12	P00C7	N	Y	N	Y	N	N
13	P00C7	Y	Y	N	Y	N	N
14	P00C7	N	N	Y	Y	N	N
15	P00C7	Y	N	Y	Y	N	N
16	P00C7	N	Y	Y	Y	N	N
17	P00C7	Y	Y	Y	Y	N	N
18	P00C7	N	N	N	N	Y	N
19	P00C7	Y	N	N	N	Y	N
20	P00C7	N	Y	N	N	Y	N
21	P00C7	Y	Y	N	N	Y	N
22	P00C7	N	N	Y	N	Y	N
23	P00C7	Y	N	Y	N	Y	N
24	P00C7	N	Y	Y	N	Y	N
25	P00C7	Y	Y	Y	N	Y	N
26	P00C7	N	N	N	Y	Y	N
27	P0236	Y	N	N	Y	Y	N
28	P00C7	N	Y	N	Y	Y	N
29	P00C7	Y	Y	N	Y	Y	N
30	P00C7	N	N	Y	Y	Y	N
31	P00C7	Y	N	Y	Y	Y	N

Initial Supporting table - P00C7: Twin Turbo Failure Matrix

32	P00C7	N	Y	Y	Y	Y	N
33	P00C7	Y	Y	Y	Y	Y	N
34	P00C7	N	N	N	N	N	Y
35	P00C7	Y	N	N	N	N	Y
36	P00C7	N	Y	N	N	N	Y
37	P00C7	Y	Y	N	N	N	Y
38	P00C7	N	N	Y	N	N	Y
39	P00C7	Y	N	Y	N	N	Y
40	P00C7	N	Y	Y	N	N	Y
41	P00C7	Y	Y	Y	N	N	Y
42	P00C7	N	N	N	Y	N	Y
43	P00C7	Y	N	N	Y	N	Y
44	P2227	N	Y	N	Y	N	Y
45	P00C7	Y	Y	N	Y	N	Y
46	P00C7	N	N	Y	Y	N	Y
47	P00C7	Y	N	Y	Y	N	Y
48	P00C7	N	Y	Y	Y	N	Y
49	P00C7	Y	Y	Y	Y	N	Y
50	P00C7	N	N	N	N	Y	Y
51	P00C7	Y	N	N	N	Y	Y
52	P00C7	N	Y	N	N	Y	Y
53	P00C7	Y	Y	N	N	Y	Y
54	P222B	N	N	Y	N	Y	Y
55	P00C7	Y	N	Y	N	Y	Y
56	P00C7	N	Y	Y	N	Y	Y
57	P00C7	Y	Y	Y	N	Y	Y
58	P00C7	N	N	N	Y	Y	Y
59	P00C7	Y	N	N	Y	Y	Y
60	P00C7	N	Y	N	Y	Y	Y
61	P00C7	Y	Y	N	Y	Y	Y
62	P00C7	N	N	Y	Y	Y	Y
63	P00C7	Y	N	Y	Y	Y	Y
64	P00C7	N	Y	Y	Y	Y	Y
65	P00C7	Y	Y	Y	Y	Y	Y

Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est

Description: P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on MAF Est

Value Units: Weight Factor (Unitless)
X Unit: Estimated Engine Air Flow (Grams/Second)

y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM

Description: P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	600	950	1,300	1,650	2,000	2,350	2,700	3,050	3,400	3,750	4,100	4,450	4,800	5,150	5,500	6,000	6,500
1	1.000	1.000	1.000	0.955	1.000	0.733	0.941	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.848	0.665	0.430

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: MAF2 Residual Weight Factor based on MAF Est

Description: P0101_P0106_P010B_P0121_P0236_P1101 MAF2 Residual Weight Factor based on MAF Est

Value Units: Weight Factor (Unitless)
X Unit: Estimated Engine Air Flow (Grams/Second)

y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: MAF2 Residual Weight Factor based on RPM

Description: P0101_P0106_P010B_P0121_P0236_P1101 MAF2 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Air Flow (Grams/Second)

y/x	600	950	1,300	1,650	2,000	2,350	2,700	3,050	3,400	3,750	4,100	4,450	4,800	5,150	5,500	6,000	6,500
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.944	1.000	1.000	1.000	1.000	1.000	0.789	0.566	0.296

Initial Supporting table - Closed Loop Enable Clarification - KaFCLP_U_SlphrIntglOfst_Thrsh

Description: Integral Offset voltage thresholds (bank and cell specific cals) used with KeFCLP_Pct_CatAccuSlphrPostDsbl to check for sulphur poisoning.

Value Units: millivolts
X Unit: Post Catalyst Number

y/x	CiOXYR_O2_PostCat1	CiOXYR_O2_PostCat2
CiFCLP_Decel	2,048	2,048
CiFCLP_Idle	2,048	2,048
CiFCLP_Cruise	2,048	2,048
CiFCLP_LightAccel	2,048	2,048
CiFCLP_HeavyAccel	2,048	2,048

Initial Supporting table - Closed Loop Enable Clarification - KcFCLP_Cnt_O2RdyCyclesThrsh

Description: Number of times a post oxygen sensor value must be in range before declaring it ready

Value Units: Time (events * 12.5 milliseconds)

y/x	1
1	10

Initial Supporting table - Closed Loop Enable Clarification - KcFULC_O2_SensorReadyEvents

Description: Number of times a pre oxygen sensor value must be in range before declaring it ready

Value Units: Time (events * 12.5 milliseconds)

y/x	1
1	10

Initial Supporting table - Closed Loop Enable Clarification - KeEOSD_U_RichThrsh

Description: The oxygen sensor voltage above which a sensor will be considered failing during a Rich Test.

Value Units: Volts

y/x	1
1	1,050

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_dm_IntegrationAirflowMax

Description: Maximum allowed estimated airflow for post O2 integral terms to be updated.

Value Units: Grams per Second

y/x	1
1	512

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_Pct_CatAccuSlphrPostDsbl

Description: Sulphur percent threshold above which post integral learning is disabled if the threshold criteria KaFCLP_U_SlphrIntglOfst_Thrsh is also met.

Value Units: Percent

y/x	1
1	255

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_T_IntegrationCatalystMax

Description: Maximum allowed estimated catalytic converter temperature for post O2 integral terms to be updated.

Value Units: Celcius

y/x	1
1	900

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_T_IntegrationCatalystMin

Description: Minimum allowed estimated catalytic converter temperature to begin using post O2 integration correction terms. Converter temperature must remain above this threshold to ramp-in the post O2 integration adjustments. Once the ramp-in has started, a converter temperature below this threshold will freeze the ramp-in multiplier. Post O2 integration will not be allowed below this converter temperature

Value Units: Celcius

y/x	1
1	450

Initial Supporting table - Closed Loop Enable Clarification - KeFULC_T_WRAF_SensorReadyThrsh

Description: Pumping cell temperature threshold above which the wideband oxygen sensor will be considered ready for use

Value Units: Degrees Celcius

y/x	1
1	700

Initial Supporting table - Closed Loop Enable Clarification - KeWRSC_T_HtrCntrlCL

Description: WRAF heater temperature enabling threshold for transition from Open Loop to Closed Loop

Value Units: Degrees Celcius

y/x	1
1	628

Initial Supporting table - Closed Loop Enable Clarification - KeWRSI_T_PumpCurrentEnable

Description: WRAF heater temperature threshold for enabling the sensor pump current

Value Units: Degrees Celcius

y/x	1
1	628

Initial Supporting table - Closed Loop Enable Clarification - KfFCLL_T_AdaptiveLoCoolant

Description: LTM learning is inhibited if the engine coolant temperature is below this calibration.

Value Units: Degrees Celcius

y/x	1
1	40

Initial Supporting table - Closed Loop Enable Clarification - KfFCLP_U_O2ReadyThrshLo

Description: Voltage limit checked against when determining if a post converter oxygen sensor is in range

Value Units: millivolts

y/x	1
1	1,100

Initial Supporting table - Closed Loop Enable Clarification - KfFULC_U_O2_SensorReadyThrshLo

Description: Voltage limit checked against when determining if a pre converter oxygen sensor is in range

Value Units: millivolts

y/x	1
1	1,150

Initial Supporting table - Closed Loop Enable Clarification - KtFCLL_p_AdaptiveLowMAP_Limit

Description: Long term fuel learning is disabled below this MAP limit as a function of barometric pressure.

Value Units: KPa
X Unit: KPa

y/x	65	70	75	80	85	90	95	100	105
1	20.0	20.0	20.0	21.0	23.0	24.0	25.0	25.0	25.0

Initial Supporting table - Closed Loop Enable Clarification - KtFCLP_t_PostIntglDisableTime

Description: Disable integral offset after engine start for this amount of time as a function of start up coolant temperature.

Value Units: Time in seconds
X Unit: Degrees Celcius

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	600.0	600.0	600.0	480.0	400.0	240.0	240.0	240.0	40.0	40.0	40.0	40.0	40.0	20.0	20.0	20.0	20.0

Initial Supporting table - Closed Loop Enable Clarification - KtFCLP_t_PostIntglRampInTime

Description: Time required to ramp integral offset to desired value as a function of start up coolant temperature.

Value Units: Time in seconds
X Unit: Degrees Celcius

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	50.0	50.0	50.0	45.0	40.0	40.0	40.0	40.0	30.0	25.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

Initial Supporting table - Closed Loop Enable Clarification - KtFSTA_t_ClosedLoopAutostart

Description: Engine run time following an autostart, as a function of begin run coolant, which must be exceeded to enable CLOSED LOOP.

Value Units: Time in seconds
X Unit: Degrees Celcius

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	100.0	100.0	100.0	55.0	19.0	18.0	18.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Initial Supporting table - Closed Loop Enable Clarification - KtFSTA_t_ClosedLoopTime

Description: Engine run time, as a function of startup coolant temperature, which must be exceeded to enable CLOSED LOOP.

Value Units: Time in seconds
X Unit: Degrees Celcius

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	600.0	600.0	600.0	480.0	280.0	85.0	85.0	75.0	75.0	75.0	75.0	25.0	35.0	40.0	45.0	45.0	45.0

Initial Supporting table - CalculatedPerfMaxEc1

Description: Maximum desired camshaft position for Exhaust CAM - Bank1

Value Units: Maximum desired camshaft position (degCam)
X Unit: Engine Oil Temperature (degC)
[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]
[-40 -28 -16 -4 8 20 32 44 56 68 80 92 104 116 128 140 152]

Y Units: Engine Speed (rpm)
[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]
[400 800 1200 1600 2000 2400 2800 3200 3600 4000 4400 4800 5200 5600 6000 6400 6800]

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
2	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
3	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
4	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
6	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
7	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
8	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
9	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
10	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
11	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
12	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
13	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
14	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
15	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
16	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
17	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5

Initial Supporting table - CalculatedPerfMaxEc2

Description: Maximum desired camshaft position for Exhaust CAM - Bank2

Value Units: Maximum desired camshaft position (degCam)
X Unit: Engine Oil Temperature (degC)
[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]
[-40 -28 -16 -4 8 20 32 44 56 68 80 92 104 116 128 140 152]
Y Units: Engine Speed (rpm)
[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]
[400 800 1200 1600 2000 2400 2800 3200 3600 4000 4400 4800 5200 5600 6000 6400 6800]

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
2	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
3	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
4	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
6	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
7	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
8	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
9	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
10	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
11	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
12	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
13	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
14	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
15	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
16	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
17	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5

Initial Supporting table - CalculatedPerfMaxIc2

Description: Maximum desired camshaft position for Intake CAM - Bank2

Value Units: Maximum desired camshaft position (degCam)
X Unit: Engine Oil Temperature (degC)
[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]
[-40 -28 -16 -4 8 20 32 44 56 68 80 92 104 116 128 140 152]
Y Units: Engine Speed (rpm)
[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]
[400 800 1200 1600 2000 2400 2800 3200 3600 4000 4400 4800 5200 5600 6000 6400 6800]

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
2	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
3	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
4	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
5	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
6	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
7	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
8	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
9	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
10	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
11	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
12	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
13	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
14	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
15	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
16	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29
17	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29	29

Initial Supporting table - P0521_P06DD_P06DE_OP_HiStatePressure

Description: Two Stage Oil Pump Oil Pressure in High State

Value Units: Nominal high state oil pressure (kPa)
X Unit: Engine oil temperature (deg C)

y/x	-7.0	0.0	20.0	40.0	60.0	80.0	100.0	110.0	120.0
1,400.0	636.0	636.0	636.0	636.0	585.0	533.1	464.9	405.9	346.9
1,500.0	648.7	648.7	648.7	648.7	595.4	545.6	484.3	433.3	382.3
2,000.0	700.6	700.6	700.6	700.6	646.7	605.0	545.5	503.9	462.3
2,500.0	752.6	752.6	752.6	752.6	699.5	662.4	604.2	559.6	514.9
3,000.0	765.6	765.6	765.6	765.6	742.8	705.5	643.9	596.3	548.8
3,500.0	783.4	783.4	783.4	783.4	758.8	725.1	685.5	631.7	577.8
4,000.0	754.9	754.9	754.9	754.9	785.1	755.2	700.6	640.8	580.9
4,500.0	753.7	753.7	753.7	753.7	751.1	759.1	709.1	646.9	584.8
5,000.0	762.3	762.3	762.3	762.3	751.6	753.3	732.6	677.6	622.6

Initial Supporting table - P0521_P06DD_P06DE_OP_LoStatePressure

Description: Two Stage Oil Pump Oil Pressure in Low State

Value Units: Nominal low state oil pressure (kPa)
X Unit: Engine oil temperature (deg C)

y/x	-7	0	20	40	60	80	100	110	120
1,400	325	325	325	325	301	290	281	269	257
1,500	327	327	327	327	300	288	282	271	260
2,000	326	326	326	326	311	299	289	284	280
2,500	333	333	333	333	318	300	290	287	284
3,000	331	331	331	331	326	306	293	287	282
3,500	336	336	336	336	326	314	302	296	290
4,000	344	344	344	344	335	322	306	305	303
4,500	352	352	352	352	329	294	292	294	296
5,000	355	355	355	355	318	272	285	287	289

Initial Supporting table - P06DD_P06DE_MaxEnableTorque_OP

Description: Two Stage Oil Pump Rationality Test Torque Max Enable Threshold

Value Units: Maximum engine torque (Nm)
X Unit: Engine speed (RPM)

y/x	1,300.0	1,462.5	1,625.0	1,787.5	1,925.0	1,926.0	2,088.5	2,296.0	2,600.0
1.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0

Initial Supporting table - P06DD_P06DE_MinEnableTorque_OP

Description: Two Stage Oil Pump Rationality Test Torque Min Enable Threshold

Value Units: Min engine torque (Nm)
X Unit: Engine speed (RPM)

y/x	1,300.0	1,462.5	1,625.0	1,787.5	1,925.0	1,926.0	2,088.5	2,296.0	2,600.0
1.0	158.5	175.0	183.8	199.0	195.0	195.0	175.0	175.0	225.0

Initial Supporting table - P06DD_P06DE_MinOilPressThresh

Description: Intrusive diagnostic minimum pressure limit that is a function of Engine Speed and Oil Temperature

Value Units: Minimum engine oil pressure threshold (kPa)
X Unit: Engine oil temperature (deg C)

y/x	-7	0	20	40	60	80	100	110	120
1,400	108	108	108	108	108	108	108	108	108
1,500	115	115	115	115	115	115	115	115	115
2,000	136	136	136	136	136	136	136	136	136
2,500	153	153	153	153	153	153	153	153	153
3,000	167	167	167	167	167	167	167	167	167
3,500	183	183	183	183	183	183	183	183	183
4,000	199	199	199	199	199	199	199	199	199
4,500	233	233	233	233	233	233	233	233	233
5,000	310	310	310	310	310	310	310	310	310

Initial Supporting table - P06DD_P06DE_OP_StateChangeMin

Description: Minimum allowed pressure change on a Two Stage Oil Pump state change

Value Units: Min pressure change (kPa)
X Unit: Engine oil temperature (deg C)

y/x	-7.0	0.0	20.0	40.0	60.0	80.0	100.0	110.0	120.0
1,400.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0
1,500.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0
2,000.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0
2,500.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0
3,000.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0
3,500.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0
4,000.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0
4,500.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0
5,000.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0	60.0

Initial Supporting table - P2160 range change delay time

Description: If the transmission range state changes, the transmission range state must be stable for this amount of time as part of the P2160 enable conditions.

X Unit: transmission fluid temperature DegC
Y Units: delay time seconds

y/x	-40.00	0.00	40.00
1	5.000	5.000	5.000

Initial Supporting table - P2161 range change delay time

Description: If the transmission range state changes, the transmission range state must be stable for this amount of time as part of the P2161 enable conditions.

X Unit: transmission fluid temperature DegC
Y Units: delay time seconds

y/x	-40.00	-20.00	40.00
1	5.000	5.000	5.000

Initial Supporting table - P0521_P06DD_P06DE_OP_HiStatePressure

Description: Two Stage Oil Pump Oil Pressure in High State

Value Units: Nominal high state oil pressure (kPa)
X Unit: Engine oil temperature (deg C)

y/x	40.0	50.0	60.0	70.0	80.0	90.0	100.0	110.0	120.0
1,000.0	528.5	495.4	459.1	419.7	376.9	330.4	280.3	226.3	168.1
1,500.0	579.8	552.8	522.6	489.4	452.9	413.0	369.4	322.0	270.6
2,000.0	605.4	583.4	558.6	530.6	499.6	465.1	427.1	385.4	339.8
2,500.0	612.1	594.2	573.6	550.1	523.4	493.5	460.2	423.2	382.4
3,000.0	606.6	591.9	574.6	554.5	531.4	505.1	475.4	442.3	405.4
3,500.0	595.8	583.4	568.5	550.8	530.3	506.6	479.8	449.5	415.6
4,000.0	586.4	575.4	561.9	545.8	526.8	504.9	479.9	451.5	419.6
4,500.0	585.4	574.7	561.7	546.1	527.9	506.8	482.6	455.2	424.4
5,000.0	599.3	588.1	574.6	558.7	540.2	518.9	494.6	467.3	436.6

Initial Supporting table - P0521_P06DD_P06DE_OP_LoStatePressure

Description: Two Stage Oil Pump Oil Pressure in Low State

Value Units: Nominal low state oil pressure (kPa)
X Unit: Engine oil temperature (deg C)

y/x	40	50	60	70	80	90	100	110	120
1,000	346	332	317	301	283	264	242	218	192
1,500	370	358	345	331	315	298	279	257	232
2,000	382	372	361	349	335	320	302	283	260
2,500	386	377	368	357	345	332	316	298	277
3,000	384	376	368	359	349	336	322	306	287
3,500	378	372	365	357	348	337	324	309	291
4,000	372	367	361	354	346	336	324	311	294
4,500	368	364	359	353	345	337	326	313	297
5,000	370	366	361	356	349	341	331	319	304

Initial Supporting table - P06DD_P06DE_MaxEnableTorque_OP

Description: Two Stage Oil Pump Rationality Test Torque Max Enable Threshold

Value Units: Maximum engine torque (Nm)
X Unit: Engine speed (RPM)

y/x	1,000.0	1,250.0	1,500.0	1,750.0	2,000.0	2,250.0	2,500.0	2,750.0	3,000.0
1.0	0.0	0.0	180.0	180.0	180.0	180.0	180.0	0.0	0.0

Initial Supporting table - P06DD_P06DE_MinEnableTorque_OP

Description: Two Stage Oil Pump Rationality Test Torque Min Enable Threshold

Value Units: Min engine torque (Nm)
X Unit: Engine speed (RPM)

y/x	1,000.0	1,250.0	1,500.0	1,750.0	2,000.0	2,250.0	2,500.0	2,750.0	3,000.0
1.0	0.0	0.0	20.0	20.0	20.0	20.0	20.0	0.0	0.0

Initial Supporting table - P06DD_P06DE_MinOilPressThresh

Description: Intrusive diagnostic minimum pressure limit that is a function of Engine Speed and Oil Temperature

Value Units: Minimum engine oil pressure threshold (kPa)
X Unit: Engine oil temperature (deg C)

y/x	40	50	60	70	80	90	100	110	120
1,000	160	160	160	160	160	160	160	160	160
1,500	160	160	160	160	160	160	160	160	160
2,000	187	187	187	187	187	187	187	187	187
2,500	200	200	200	200	200	200	200	200	200
3,000	200	200	200	200	200	200	200	200	200
3,500	200	200	200	200	200	200	200	200	200
4,000	200	200	200	200	200	200	200	200	200
4,500	200	200	200	200	200	200	200	200	200
5,000	1,133	1,133	1,133	1,133	1,133	1,133	1,133	1,133	1,133

Initial Supporting table - P06DD_P06DE_OP_StateChangeMin

Description: Minimum allowed pressure change on a Two Stage Oil Pump state change

Value Units: Min pressure change (kPa)
X Unit: Engine oil temperature (deg C)

y/x	40.0	50.0	60.0	70.0	80.0	90.0	100.0	110.0	120.0
1,000.0	73.1	65.5	57.0	47.7	37.6	26.7	15.3	3.2	0.4
1,500.0	84.0	78.1	71.2	63.5	55.1	46.0	36.3	26.0	15.3
2,000.0	89.3	84.6	79.1	72.8	65.8	58.1	49.9	41.1	31.9
2,500.0	90.5	86.9	82.4	77.2	71.3	64.8	57.7	50.1	42.1
3,000.0	89.3	86.4	82.7	78.3	73.2	67.5	61.3	54.6	47.5
3,500.0	87.2	84.8	81.5	77.6	73.0	67.9	62.3	56.1	49.7
4,000.0	85.9	83.6	80.5	76.8	72.4	67.6	62.2	56.4	50.3
4,500.0	86.9	84.4	81.3	77.4	73.0	68.1	62.7	56.9	50.9
5,000.0	91.9	89.0	85.4	81.2	76.4	71.1	65.4	59.4	53.1

Initial Supporting table - P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold

Description: P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold

Value Units: Engine Run Time- Seconds
X Unit: Oil Temperature- C

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	3	3	3	2	1	1	1	1	1	1	1	1	1	1	1	1	1

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

Description: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix - This table describes combinations of individual model failures that will set P0101, P0106, P010B, P0121, P0236 and P1101 on turbocharged applications.

Value Units: Boolean
X Unit: Unitless (See top line for heading information)
Y Units: Unitless

y/x	1	2	3	4	5	6	7	8	9
1	MAF Model	MAP1 Model	MAP2 Model	MAP3 Model	TIAP1 Model	TPS Model	TIAP Correlation	TIAP Correlation	DTC Set
2	Failed	Failed	Failed	Failed	Failed	Failed	Failed	Valid	
3	F	F	F	F	F	F	F	F	No DTC
4	F	F	F	F	F	F	F	T	No DTC
5	F	F	F	F	F	F	T	F	No DTC
6	F	F	F	F	F	F	T	T	No DTC
7	F	F	F	F	F	T	F	F	No DTC
8	F	F	F	F	F	T	F	T	No DTC
9	F	F	F	F	F	T	T	F	No DTC
10	F	F	F	F	F	T	T	T	No DTC
11	F	F	F	F	T	F	F	F	No DTC
12	F	F	F	F	T	F	F	T	No DTC
13	F	F	F	F	T	F	T	F	No DTC
14	F	F	F	F	T	F	T	T	No DTC
15	F	F	F	F	T	T	F	F	P1101
16	F	F	F	F	T	T	F	T	P0121
17	F	F	F	F	T	T	T	F	P1101
18	F	F	F	F	T	T	T	T	P0236
19	F	F	F	T	F	F	F	F	No DTC
20	F	F	F	T	F	F	F	T	P1101
21	F	F	F	T	F	F	T	F	P1101
22	F	F	F	T	F	F	T	T	P1101
23	F	F	F	T	F	T	F	F	P1101
24	F	F	F	T	F	T	F	T	P1101
25	F	F	F	T	F	T	T	F	P1101
26	F	F	F	T	F	T	T	T	P1101
27	F	F	F	T	T	F	F	F	P1101
28	F	F	F	T	T	F	F	T	P1101
29	F	F	F	T	T	F	T	F	P1101
30	F	F	F	T	T	F	T	T	P1101
31	F	F	F	T	T	T	F	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

32	F	F	F	T	T	T	F	T	P1101
33	F	F	F	T	T	T	T	F	P1101
34	F	F	F	T	T	T	T	T	P1101
35	F	F	T	F	F	F	F	F	No DTC
36	F	F	T	F	F	F	F	T	P1101
37	F	F	T	F	F	F	T	F	P1101
38	F	F	T	F	F	F	T	T	P1101
39	F	F	T	F	F	T	F	F	P1101
40	F	F	T	F	F	T	F	T	P1101
41	F	F	T	F	F	T	T	F	P1101
42	F	F	T	F	F	T	T	T	P1101
43	F	F	T	F	T	F	F	F	P1101
44	F	F	T	F	T	F	F	T	P1101
45	F	F	T	F	T	F	T	F	P1101
46	F	F	T	F	T	F	T	T	P1101
47	F	F	T	F	T	T	F	F	P1101
48	F	F	T	F	T	T	F	T	P1101
49	F	F	T	F	T	T	T	F	P1101
50	F	F	T	F	T	T	T	T	P1101
51	F	F	T	T	F	F	F	F	P1101
52	F	F	T	T	F	F	F	T	P1101
53	F	F	T	T	F	F	T	F	P1101
54	F	F	T	T	F	F	T	T	P1101
55	F	F	T	T	F	T	F	F	P1101
56	F	F	T	T	F	T	F	T	P1101
57	F	F	T	T	F	T	T	F	P1101
58	F	F	T	T	F	T	T	T	P1101
59	F	F	T	T	T	F	F	F	No DTC
60	F	F	T	T	T	F	F	T	No DTC
61	F	F	T	T	T	F	T	F	No DTC
62	F	F	T	T	T	F	T	T	No DTC
63	F	F	T	T	T	T	F	F	P1101
64	F	F	T	T	T	T	F	T	P1101
65	F	F	T	T	T	T	T	F	P1101
66	F	F	T	T	T	T	T	T	P1101
67	F	T	F	F	F	F	F	F	No DTC
68	F	T	F	F	F	F	F	T	P1101
69	F	T	F	F	F	F	T	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

70	F	T	F	F	F	F	T	T	P0236
71	F	T	F	F	F	T	F	F	P1101
72	F	T	F	F	F	T	F	T	P0121
73	F	T	F	F	F	T	T	F	P1101
74	F	T	F	F	F	T	T	T	P0236
75	F	T	F	F	T	F	F	F	P1101
76	F	T	F	F	T	F	F	T	P1101
77	F	T	F	F	T	F	T	F	P1101
78	F	T	F	F	T	F	T	T	P0236
79	F	T	F	F	T	T	F	F	P1101
80	F	T	F	F	T	T	F	T	P0121
81	F	T	F	F	T	T	T	F	P1101
82	F	T	F	F	T	T	T	T	P0236
83	F	T	F	T	F	F	F	F	P1101
84	F	T	F	T	F	F	F	T	P1101
85	F	T	F	T	F	F	T	F	P1101
86	F	T	F	T	F	F	T	T	P1101
87	F	T	F	T	F	T	F	F	P1101
88	F	T	F	T	F	T	F	T	P1101
89	F	T	F	T	F	T	T	F	P1101
90	F	T	F	T	F	T	T	T	P1101
91	F	T	F	T	T	F	F	F	P1101
92	F	T	F	T	T	F	F	T	P1101
93	F	T	F	T	T	F	T	F	P1101
94	F	T	F	T	T	F	T	T	P1101
95	F	T	F	T	T	T	F	F	P1101
96	F	T	F	T	T	T	F	T	P1101
97	F	T	F	T	T	T	T	F	P1101
98	F	T	F	T	T	T	T	T	P1101
99	F	T	T	F	F	F	F	F	P1101
100	F	T	T	F	F	F	F	T	P1101
101	F	T	T	F	F	F	T	F	P1101
102	F	T	T	F	F	F	T	T	P1101
103	F	T	T	F	F	T	F	F	P1101
104	F	T	T	F	F	T	F	T	P1101
105	F	T	T	F	F	T	T	F	P1101
106	F	T	T	F	F	T	T	T	P1101
107	F	T	T	F	T	F	F	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

108	F	T	T	F	T	F	F	T	P1101
109	F	T	T	F	T	F	T	F	P1101
110	F	T	T	F	T	F	T	T	P1101
111	F	T	T	F	T	T	F	F	P1101
112	F	T	T	F	T	T	F	T	P1101
113	F	T	T	F	T	T	T	F	P1101
114	F	T	T	F	T	T	T	T	P1101
115	F	T	T	T	F	F	F	F	P0106
116	F	T	T	T	F	F	F	T	P0106
117	F	T	T	T	F	F	T	F	P0106
118	F	T	T	T	F	F	T	T	P0106
119	F	T	T	T	F	T	F	F	P1101
120	F	T	T	T	F	T	F	T	P1101
121	F	T	T	T	F	T	T	F	P1101
122	F	T	T	T	F	T	T	T	P1101
123	F	T	T	T	T	F	F	F	P1101
124	F	T	T	T	T	F	F	T	P1101
125	F	T	T	T	T	F	T	F	P1101
126	F	T	T	T	T	F	T	T	P1101
127	F	T	T	T	T	T	F	F	P1101
128	F	T	T	T	T	T	F	T	P1101
129	F	T	T	T	T	T	T	F	P1101
130	F	T	T	T	T	T	T	T	P1101
131	T	F	F	F	F	F	F	F	No DTC
132	T	F	F	F	F	F	F	T	P1101
133	T	F	F	F	F	F	T	F	P1101
134	T	F	F	F	F	F	T	T	P0236
135	T	F	F	F	F	T	F	F	P1101
136	T	F	F	F	F	T	F	T	P0121
137	T	F	F	F	F	T	T	F	P1101
138	T	F	F	F	F	T	T	T	P0236
139	T	F	F	F	T	F	F	F	P1101
140	T	F	F	F	T	F	F	T	P1101
141	T	F	F	F	T	F	T	F	P1101
142	T	F	F	F	T	F	T	T	P0236
143	T	F	F	F	T	T	F	F	P1101
144	T	F	F	F	T	T	F	T	P0121
145	T	F	F	F	T	T	T	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

146	T	F	F	F	T	T	T	T	P0236
147	T	F	F	T	F	F	F	F	P1101
148	T	F	F	T	F	F	F	T	P1101
149	T	F	F	T	F	F	T	F	P1101
150	T	F	F	T	F	F	T	T	P1101
151	T	F	F	T	F	T	F	F	P1101
152	T	F	F	T	F	T	F	T	P1101
153	T	F	F	T	F	T	T	F	P1101
154	T	F	F	T	F	T	T	T	P1101
155	T	F	F	T	T	F	F	F	P1101
156	T	F	F	T	T	F	F	T	P1101
157	T	F	F	T	T	F	T	F	P1101
158	T	F	F	T	T	F	T	T	P1101
159	T	F	F	T	T	T	F	F	P1101
160	T	F	F	T	T	T	F	T	P1101
161	T	F	F	T	T	T	T	F	P1101
162	T	F	F	T	T	T	T	T	P1101
163	T	F	T	F	F	F	F	F	P1101
164	T	F	T	F	F	F	F	T	P1101
165	T	F	T	F	F	F	T	F	P1101
166	T	F	T	F	F	F	T	T	P1101
167	T	F	T	F	F	T	F	F	P1101
168	T	F	T	F	F	T	F	T	P1101
169	T	F	T	F	F	T	T	F	P1101
170	T	F	T	F	F	T	T	T	P1101
171	T	F	T	F	T	F	F	F	P1101
172	T	F	T	F	T	F	F	T	P1101
173	T	F	T	F	T	F	T	F	P1101
174	T	F	T	F	T	F	T	T	P1101
175	T	F	T	F	T	T	F	F	P1101
176	T	F	T	F	T	T	F	T	P1101
177	T	F	T	F	T	T	T	F	P1101
178	T	F	T	F	T	T	T	T	P1101
179	T	F	T	T	F	F	F	F	P1101
180	T	F	T	T	F	F	F	T	P1101
181	T	F	T	T	F	F	T	F	P1101
182	T	F	T	T	F	F	T	T	P1101
183	T	F	T	T	F	T	F	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

184	T	F	T	T	F	T	F	T	P1101
185	T	F	T	T	F	T	T	F	P1101
186	T	F	T	T	F	T	T	T	P1101
187	T	F	T	T	T	F	F	F	P0101 or P010B
188	T	F	T	T	T	F	F	T	P0101 or P010B
189	T	F	T	T	T	F	T	F	P0101 or P010B
190	T	F	T	T	T	F	T	T	P0101 or P010B
191	T	F	T	T	T	T	F	F	P1101
192	T	F	T	T	T	T	F	T	P1101
193	T	F	T	T	T	T	T	F	P1101
194	T	F	T	T	T	T	T	T	P1101
195	T	T	F	F	F	F	F	F	P1101
196	T	T	F	F	F	F	F	T	P1101
197	T	T	F	F	F	F	T	F	P1101
198	T	T	F	F	F	F	T	T	P0236
199	T	T	F	F	F	T	F	F	P1101
200	T	T	F	F	F	T	F	T	P0121
201	T	T	F	F	F	T	T	F	P1101
202	T	T	F	F	F	T	T	T	P0236
203	T	T	F	F	T	F	F	F	P1101
204	T	T	F	F	T	F	F	T	P1101
205	T	T	F	F	T	F	T	F	P1101
206	T	T	F	F	T	F	T	T	P0236
207	T	T	F	F	T	T	F	F	P1101
208	T	T	F	F	T	T	F	T	P0121
209	T	T	F	F	T	T	T	F	P1101
210	T	T	F	F	T	T	T	T	P0236
211	T	T	F	T	F	F	F	F	P1101
212	T	T	F	T	F	F	F	T	P1101
213	T	T	F	T	F	F	T	F	P1101
214	T	T	F	T	F	F	T	T	P1101
215	T	T	F	T	F	T	F	F	P1101
216	T	T	F	T	F	T	F	T	P1101
217	T	T	F	T	F	T	T	F	P1101
218	T	T	F	T	F	T	T	T	P1101
219	T	T	F	T	T	F	F	F	P1101
220	T	T	F	T	T	F	F	T	P1101
221	T	T	F	T	T	F	T	F	P1101

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

222	T	T	F	T	T	F	T	T	P1101
223	T	T	F	T	T	T	F	F	P1101
224	T	T	F	T	T	T	F	T	P1101
225	T	T	F	T	T	T	T	F	P1101
226	T	T	F	T	T	T	T	T	P1101
227	T	T	T	F	F	F	F	F	P1101
228	T	T	T	F	F	F	F	T	P1101
229	T	T	T	F	F	F	T	F	P1101
230	T	T	T	F	F	F	T	T	P1101
231	T	T	T	F	F	T	F	F	P1101
232	T	T	T	F	F	T	F	T	P1101
233	T	T	T	F	F	T	T	F	P1101
234	T	T	T	F	F	T	T	T	P1101
235	T	T	T	F	T	F	F	F	P1101
236	T	T	T	F	T	F	F	T	P1101
237	T	T	T	F	T	F	T	F	P1101
238	T	T	T	F	T	F	T	T	P1101
239	T	T	T	F	T	T	F	F	P1101
240	T	T	T	F	T	T	F	T	P1101
241	T	T	T	F	T	T	T	F	P1101
242	T	T	T	F	T	T	T	T	P1101
243	T	T	T	T	F	F	F	F	P1101
244	T	T	T	T	F	F	F	T	P1101
245	T	T	T	T	F	F	T	F	P1101
246	T	T	T	T	F	F	T	T	P1101
247	T	T	T	T	F	T	F	F	P1101
248	T	T	T	T	F	T	F	T	P1101
249	T	T	T	T	F	T	T	F	P1101
250	T	T	T	T	F	T	T	T	P1101
251	T	T	T	T	T	F	F	F	P1101
252	T	T	T	T	T	F	F	T	P1101
253	T	T	T	T	T	F	T	F	P1101
254	T	T	T	T	T	F	T	T	P1101
255	T	T	T	T	T	T	F	F	P1101
256	T	T	T	T	T	T	F	T	P1101
257	T	T	T	T	T	T	T	F	P1101
258	T	T	T	T	T	T	T	T	P1101

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP1 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,200
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP2 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,200
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.950	0.950	1.000	0.950	0.950	0.950	0.950	1.000

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP3 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,200
1	1.000	1.000	1.000	1.000	1.000	0.900	1.000	1.000	1.000	0.850	0.850	1.000	0.900	0.950	0.950	0.950	0.987

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 TPS Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,200
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P0236_P1101 TIAP Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,200
1	1.000	0.700	0.700	1.000	1.000	1.000	1.000	1.000	0.850	0.850	0.850	0.850	0.850	0.850	0.850	0.880	0.900

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Max Air Flow

Value Units: Engine Air Flow (Grams/Second)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	13.0	13.0	13.0	16.0	20.0	24.0	28.0	31.0	32.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Max MAP

Value Units: Manifold Pressure (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	70.0	70.0	70.0	70.0	70.0	70.0	70.0	70.0	70.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Offset

Value Units: Pressure Difference (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	0.0	1.5	3.5	6.0	9.0	12.0	16.0	20.0	25.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min Air Flow

Value Units: Engine Air Flow (Grams/Second)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	17.0	47.0	85.0	124.0	162.0	184.0	206.0	206.0	206.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min MAP

Value Units: Manifold Pressure (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	110.0	158.0	192.0	203.0	214.0	207.0	200.0	182.0	182.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Offset

Value Units: Pressure Difference (kPa)
X Unit: Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est

Description: P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on MAF Est

Value Units: Weight Factor (Unitless)
X Unit: Estimated Engine Air Flow (Grams/Second)

y/x	0	15	30	45	60	75	90	105	120	135	150	165	180	195	210	230	250
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM

Description: P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,200
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.950	0.900	0.900	0.850	0.900	0.900	0.900	0.900	0.900

Initial Supporting table - P171D hydraulic pressure delay

Description: Time to delay the initial x of y counter due to hydraulic transients. Thresholds are a function of transmission fluid temperature. Horizontal axis is transmission fluid temperature (DegC) and table output is delay time (seconds).

Value Units: delay time seconds
X Unit: transmission fluid temperature DegC

y/x	-40	0	20	30	40	50	60
1	0.090	0.090	0.080	0.075	0.075	0.075	0.075

Initial Supporting table - P171D predicted turbine speed error

Description: Predicted turbine speed vs actual turbine speed error. Thresholds are a function of engine speed and transmission fliud temperature. Diagnostic is considered failing above these values. Table vertical axis is engine speed (RPM), horizontal axis is transmission fluid temperature (DegC) and table output is predicted turbine speed error (RPM).

Value Units: turbine speed RPM error
X Unit: transmission fluid temperature DegC
Y Units: engine speed RPM

y/x	-40	0	10	20	40
0	350	350	350	350	350
500	350	350	350	350	350
1,100	350	350	350	350	350
1,500	350	350	350	350	350
2,500	350	350	350	350	350

Initial Supporting table - P1065_UCAP_Arm_Autostart_Thresh_Derating_Zero

Description: This is the minimum Cap voltage to arm an AutoStop-Start. When the charging diagnostic is enabled, and the Cap voltage is less than the table value a failure counter is incrementated.

Value Units: Volts
X Unit: The axis of this table is ESC capacitor state of health level (0 to 100%)

y/x	0	13	25	38	50	63	75	88	100
1	3.90	3.80	3.80	3.70	3.70	3.70	3.70	3.70	3.70

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP2 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	5,650	6,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Initial Supporting table - P08A8 EngTorqueThreshold Table

Description: The diagnostic is inhibited if torque (NM) is less than this value. Prevents false fails in regions where false in-gear N/TOS ratios are possible due to low torque, where high torque would otherwise cause slip and prevent a valid in-gear state.

Value Units: Torque (NM)
X Unit: Percent Clutch Pedal Position (%)

y/x	0.00	6.25	12.50	18.75	25.00	31.25	37.50	43.75	50.00	56.25	62.50	68.75	75.00	81.25	87.50	93.75	100.00
1	10.0	10.0	10.0	10.0	10.0	20.0	35.0	35.0	40.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

Initial Supporting table - P08A8 ResidualErrEnableHigh Table

Description: Represents the upper threshold of a deadband where the diagnostic will be inhibited to prevent false fails due to clutch slip that can falsely indicate a valid in-gear N/TOS ratio. The lower threshold of the deadband is represented by the table "P08A8 ResidualErrEnableLow Table". A lower threshold value that is greater than or equal to the upper threshold for the same gear is an indication that this portion of the diagnostic's enable critera is ignored in that gear. Conversely if the lower threshold value is at or near 0% and the upper threshold for the same gear is at or near 100%, then diagnosis is not enabled in that gear.

Value Units: Percent Clutch Pedal Position (%)
X Unit: Gear, where "0" - "6" is gear 1 - 7, respectively; "7" is reverse

y/x	CeMTCI_e_Gear1	CeMTCI_e_Gear2	CeMTCI_e_Gear3	CeMTCI_e_Gear4	CeMTCI_e_Gear5	CeMTCI_e_Gear6	CeMTCI_e_Gear7	CeMTCI_e_Reverse
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Initial Supporting table - P08A8 ResidualErrEnableLow Table

Description: Represents the lower threshold of a deadband where the diagnostic will be inhibited to prevent false fails due to clutch slip that can falsely indicate a valid in-gear N/TOS ratio. The upper threshold of the deadband is represented by the table "P08A8 ResidualErrEnableHigh Table". An upper threshold value that is less than or equal to the lower threshold for the same gear is an indication that this portion of the diagnostic's enable critera is ignored in that gear. Conversely if the lower threshold value is at or near 0% and the upper threshold for the same gear is at or near 100%, then diagnosis is not enabled in that gear.

Value Units: Percent Clutch Pedal Position (%)
X Unit: Gear, where "0" - "6" is gear 1 - 7, respectively; "7" is reverse

y/x	CeMTCI_e_Gear1	CeMTCI_e_Gear2	CeMTCI_e_Gear3	CeMTCI_e_Gear4	CeMTCI_e_Gear5	CeMTCI_e_Gear6	CeMTCI_e_Gear7	CeMTCI_e_Reverse
1	100.0	100.0	100.0	100.0	100.0	100.0	100.0	100.0

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
Transmission Control Module (TCM)	C1252	The longitudinal accleration sensor signal failed at a low voltge	hardware configuration longitudinal accleration sensor raw signal hardware configuration longitudinal accleration sensor raw signal	= CeLATR_e_VoltageDirectPrOp <= -3.849999905 g's = CeLATR_e_VoltageDirectPrOp >= -3.849999905 g's	transient delay timer	>= 30 Sec	>= 75 Sec out of 120 Sec	Special No MIL
					longitudinal acceleration low voltage diagnostic enable calibration Battery Voltage Battery Voltage Battery voltage is within the allowable limits for Ignition Voltage Ignition Voltage Service Fast Learn (SFL) Mode VBS Failsafe Ignition voltage and SFL conditions met for	= 1 <= 31.999023 Volts >= 9 Volts >= 0.1 Sec <= 31.999023 Volts >= 9 Volts = FALSE Boolean >= 0.1 Sec	
			Disable Conditions:		MIL not Illuminated for DTC's:	TCM: U0073 ECM: None		
Transmission Control Module (TCM)	C1253	The longitudinal accleration sensor signal failed at a high voltge	hardware configuration longitudinal accleration sensor raw signal hardware configuration longitudinal accleration sensor raw signal	= CeLATR_e_VoltageDirectPrOp >= 3.849999905 g's = CeLATR_e_VoltageDirectPrOp <= 3.849999905 g's	transient delay timer	>= 30 Sec	>= 75 Sec out of 120 Sec	Special No MIL
					longitudinal acceleration high voltage diagnostic enable calibration Battery Voltage Battery Voltage Battery voltage is within the allowable limits for Ignition Voltage Ignition Voltage Service Fast Learn (SFL) Mode VBS Failsafe Ignition voltage and SFL conditions met for	= 1 <= 31.999023 Volts >= 9 Volts >= 0.1 Sec <= 31.999023 Volts >= 9 Volts = FALSE Boolean >= 0.1 Sec	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: U0073 ECM: None		
Transmission Control Module (TCM)	C1254	The longitudinal accleration signal is stuck at a high magnitude in range	absolute value (longitudinal accleration) absolute value (longitudinal accleration)	>= 0.529999971 g's <= 3.849999905 g's	absolute value (longitudinal accleration) for stablity absolute value (longitudinal accleration) for stablity stability time	>= 0.53 g's <= 3.8499999 g's >= 30 Sec	>= 75 Sec out of 120 Sec	Special No MIL
					Diagnostic shifting override command Attained Gear State Attained Gear Slip Transmission Type High Side Drivers enabled transmssion output speed acceleration Vehicle Speed longitudinal acceleration stuck in range diagnostic enable calibration Battery Voltage Battery Voltage Battery voltage is within the allowable limits for Ignition Voltage Ignition Voltage Service Fast Learn (SFL) Mode VBS Failsafe Ignition voltage and SFL conditions met for	= FALSE Boolean = 1st through 8th <= 100 RPM = Clutch to Clutch Transmission = TRUE Boolean >= 0.53 meter/second/second >= 15 kph = 1 <= 31.999023 Volts >= 9 Volts >= 0.1 Sec <= 31.999023 Volts >= 9 Volts = FALSE Boolean >= 0.1 Sec	
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0721, P0722, P0723, P07BF, P07C0, P077B, P077C, P077D, P215C, U0073 ECM: None		
Transmission Control Module (TCM)	P0561	Battery to ignition voltage performance error at the TCM for an extended period of time.	delta = ABS(TCM battery voltage - TCM ignition voltage)	>= 3 Volts			= 40 Fail counts (100ms loop) Out of 50 Sample Counts (100ms loop)	Type A, One Trip
					battery to ignition voltage performance diagnostic enable calibration TCM has battery voltage circuit	= 1 = 1 Boolean		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Service mode $04 active and end of trip pocessing active	= FALSE Boolean		
					Ignition Voltage Hyst Hi (enabled above this value)	> 5 Volts		
					Ignition Voltage Hyst Lo disabled below this value)	<= 2 Volts		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Transmission Control Module (TCM)	P0601	Transmission Electro-Hydraulic Control Module Read Only Memory	Incorrect program/calibrations checksum	= TRUE Boolean			>= 5 Fail Counts (background task continuous)	Type A, One Trip
					NVM write error diagnotic enable	= 1 Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0601 ECM: None		
Transmission Control Module (TCM)	P0603	Transmission Electro-Hydraulic Control Module Long-Term Memory Reset	Non-volatile memory (static or dynamic) checksum failure at controller initialization	= TRUE Boolean			Runs Continously	Type A, One Trip
					not programmed diagnotic enable	= 1 Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0603 ECM: None		
Transmission Control Module (TCM)	P0604	Transmission Electro-Hydraulic Control Module Random Access Memory	secondary micro processor RAM error	= TRUE Boolean			1000 ms cont.	Type A, One Trip
			OR					
			dual store RAM write time out error	= TRUE Boolean			> 175 seconds (interrupt driven based on calling functions)	
			OR					
			system RAM fault	= TRUE Boolean			>= 3 counts (controller initialization and background task continuous)	
			OR					

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			cashe RAM fault	= TRUE Boolean			>= 3 counts (controller initialization and background task continuous)	
			OR					
			secondary micro processor micro code error	= TRUE Boolean			>= 3 counts (controller initialization and background task continuous)	
			OR					
					Service mode $04 active or end of trip processing active	= FALSE Boolean		
			write attempt occurred during RAM lock	= TRUE Boolean			> 65534 counts (background task continuous)	
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal TCM Processor Integrity Fault	P0606	Transmission Electro-Hydraulic Control Module Processor Integrity	main processor RAM circuit hardware failure	= TRUE Boolean	RAM diagnotic test enable	= 1 Boolean	>= 5 counts (controller initialization)	Type A, One Trip
					hardware reset source is controller power up reset	= TRUE Boolean		
			OR					
			main processor flash EPROM circuit hardware failure	= TRUE Boolean	flash EPROM diagnotic test enable	= 1 Boolean	>= 5 counts (controller initialization)	
					hardware reset source is controller power up reset	= TRUE Boolean		
			OR					
			main processor memory stack failure	= TRUE Boolean	Service mode $04 active and end of trip pocessing active	= FALSE Boolean	>= 5 counts (100 msec continuous)	
					main processor memory stack test enable	= 1 Boolean		
			OR					
			secondary processor memory stack failure	= TRUE Boolean	secondary processor memory stack test enable	= 1 Boolean	>= 5 counts (12.5 msec continuous)	
			OR					
			secondary micro processor remedial action active on request	= FALSE Boolean			>= 1 counts (controller power up, 12.5 ms continuous)	
			OR					
			main processor ROM first test complete	= FALSE Boolean			>= 35 counts (12.5 msec continuous)	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			OR					
			secondary processor to main processor seed sequence fault	= TRUE Boolean			>= 0.5 seconds	
			OR					
			seed sequence error	≠ FALSE Boolean	program sequence watch communication fault	= FALSE Boolean	>= 3 counts (12.5 msec continuous)	
					main processor to secondary processor serial peripheral interface error	= FALSE Boolean	>= 17 counts (12.5 msec continuous)	
					seed sequence test enable	= see table 50 in supporting documents Boolean		
					battery voltage	> 11 Volts		
					ignition voltage	>= 11 volts		
			OR					
			seed key fault current loop	= TRUE Boolean	seed key test enable	= see table 50 in supporting documents Boolean		
					seed key fault previous loop	= TRUE Boolean		
					Service mode $04 active and end of trip processing active	= FALSE Boolean		
			OR					
			normalize 0-5 volt (absolute value (analog to digital test voltage commanded - actual analog to digital voltage feedback))	> 3.298950195 percent	analog to digital voltage test enabled	= 1 Boolean	>= 3 counts (50 msec continuous)	
					ignition voltage	>= 7 Volts	>= 8 counts (50 msec continuous)	
					analog to digital voltage channel enabled	= see Table 46 in supporting documents Boolean		
					analog to digital test voltage command	= see Table 47 in supporting documents Volts	>= 0.2 seconds	
					Service mode $04 active and end of trip processing active	= FALSE Boolean		
			OR					
			arithmatic logic unit 1 test pass	= FALSE Boolean	arithmatic logic unit test enable	= 1 Boolean	at controller initialization, then 12.5 ms cont.	
					arithmatic logic unit 1 test pass previous loop	= FALSE Boolean		
					Service mode $04 active and end of trip processing active A and B and C must occur	= FALSE Boolean		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					A: starter motor engaged = TRUE Boolean B: ignition voltage <= 11 Volts C: starter motor engaged time < 0.025 sec A and B must occur A: ignition voltage <= 6.4091797 Volts B: ignition low voltage time >= 2.50E-02 sec		
			arithmatic logic unit 2 test pass	= FALSE Boolean	arithmatic logic unit test enable	= 1 Boolean	at controller initialization, then 12.5 ms cont.	
					arithmatic logic unit 1 test pass previous loop = FALSE Boolean Service mode $04 active and end of trip processing active = FALSE Boolean A and B and C must occur A: starter motor engaged = TRUE Boolean B: ignition voltage <= 11 Volts C: starter motor engaged time < 0.025 sec		
			OR secondary processor arithmatic logic unit fault	= TRUE Boolean				
			OR clock test fail current loop	= TRUE Boolean	clock test enable	= 1 Boolean	at controller initialization, then 12.5 ms cont.	
					clock test fail previous loop = TRUE Boolean Service mode $04 active and end of trip processing active = FALSE Boolean A and B and C must occur A: starter motor engaged = TRUE Boolean B: ignition voltage <= 11 Volts C: starter motor engaged time < 0.025 sec A and B must occur A: ignition voltage <= 6.4091797 Volts B: ignition low voltage time >= 2.50E-02 sec		
			OR configuration register test fail current loop	= TRUE Boolean	configuration register test enable	= 1 Boolean	at controller initialization, then 12.5 ms cont.	
					configuration register test fail previous loop = TRUE Boolean Service mode $04 active and end of trip processing active = FALSE Boolean A and B and C must occur A: starter motor engaged = TRUE Boolean B: ignition voltage <= 11 Volts C: starter motor engaged time < 0.025 sec A and B must occur A: ignition voltage <= 6.4091797 Volts B: ignition low voltage time >= 2.50E-02 sec		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			OR					
			secondary processor configuration register fault	= TRUE Boolean				
			OR					
			A or B occur					
			A: direct memeory access (DMA) read/write test result	≠ FALSE Boolean	flash data transfer test enable	= 1 Boolean	normal controller initialization	
			B: direct memeory access (DMA) read/write value	≠ $5AA5A55A hexadecimal value	flash data transfer test enable	= 1 Boolean	normal controller initialization	
			software uses DMA peripheral function to write and read $5AA5A55A to flash memory locations to verify each flash memory location		running reset	= FALSE Boolean		
					normal power up reset	= TRUE Boolean		
			OR					
			secondary micro processor detects main micor processor SPI fault	= TRUE Boolean				
			OR					
			A or B or C or D occur		seed and key store fault test enable	= 0 Boolean		
			A: last 6.25 msec seed and key time	> see Table 48 in supporting documents sec				
			B: last 12.5 msec seed and key time	> see Table 48 in supporting documents sec				
			C: last 50 msec seed and key time	> see Table 48 in supporting documents sec				
			D: last lores engine interrupt seed and key time	> see Table 48 in supporting documents sec				
			OR					
			A or B or C or D occur		prgram sequence watch test enable	= see 3D_Table 1 in supporting documents Boolean		
			A: 6.25 msec program sequence fault fail count	>= see Table 49 in supporting documents counts (50 msec continuous on 6.25 msec time interrupt)				
			B: 12.5 msec program sequence fault fail count	>= see Table 49 in supporting documents counts (50 msec continuous on 12.5 msec time interrupt)				
			C: 50 msec program sequence fault fail count	>= see Table 49 in supporting documents counts (50 msec continuous)				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			D: engine lores interrupt program sequence fault fail count	>= see Table 49 in supporting documents counts (on execution of engine lores interrupts ECM only)				
					Service mode $04 active and end of trip processing active	= FALSE Boolean		
					secondary processor reports SPI communication fault previous loop	= TRUE Boolean		
					A and B and C must occur			
					A: starter motor engaged	= TRUE Boolean		
					B: ignition voltage	<= 11 Volts		
					C: starter motor engaged time	< 0.025 sec		
					SPI message checksum fault	≠ FASLE Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Indicates that the TCM has detected an internal processor integrity fault	P062F	Transmission Electro-Hydraulic Control Module Long Term Memory Performance	TCM Non-Volatile Memory read or write error	= TRUE Boolean			every controller initialization	Type A, One Trip
					NVM write error diagnotic enable	= 1 Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P062F ECM: None		
High Side Driver 1	P0658	Actuator Supply Voltage Circuit Low	The HWIO reports a low voltage (ground short) error flag	= TRUE Boolean			>= 6 Fail Counts (6.25 msec continuous) out of 2395 Sample Counts (6.25 msec continuous)	Type A, One Trip
					actuator supply voltage circuit low enable calibration	= 1		
					Service mode $04 active and end of trip pocessing active	= FALSE Boolean		
					P0658 Status is not	= Test Failed This Key On or Fault Active		
					P0658 Status is not	= Test Failed This Key On or Fault Active		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE	Boolean		
					High Side Driver 1 On	=	True	Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None				
Transmission Fluid Temperature Sensor (TFT)	P0711	transmission fluid temperature sensor rationality	Fail Case 1 transmission fluid temperature warm up test transmission fluid temperature raw	<= 15 ºC					>= see Table 26 in supporting documents seconds	Type B, Two Trips
					transmission fluid temperature sensor performance diagnsotic enable calibration	=	1	Boolean		
					P0712 and P0713	≠	Fault Active			
					Battery Voltage	<=	31.999023	Volts		
					Battery Voltage	>=	9	Volts		
					Battery voltage is within the allowable limits for	>=	0.1	Sec		
					Ignition Voltage	<=	31.999023	Volts		
					Ignition Voltage	>=	9	Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE	Boolean		
					Ignition voltage and SFL conditions met for	>=	0.1	Sec		
					transmission fluid temperature warm up test calibration enable	=	1	Boolean		
					driver accelerator pedal position valid	=	TRUE	Boolean		
					driver accelerator pedal position	>=	5	%		
					engine torque valid	=	TRUE	Boolean		
					engine torque steady state raw	>=	50	N*m		
					engine speed valid	=	TRUE	Boolean		
					engine speed	>=	500	RPM		
					P0722, P0723, P077C, P077D	≠	Fault Active			
					Vehicle Speed	>=	10	KPH		
					P2809 TCC stuck on fault fault status	≠	Test Failed This Key On or Fault Active			
					transmission fluid temperature	>=	-40	ºC		
					transmission fluid temperature	<=	150	ºC		
					engine coolant temperature valid	=	TRUE	Boolean		
					engine coolant temperature	>=	-40	ºC		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					engine coolant temperature	<= 150 ºC		
			Fail Case 2 transmission fluid temperature intermittent delta temperature test transmission fluid temperature delta (100 ms loop to loop)	>= 10 ºC			>= 8 seconds (100 ms cont.)	
							>= 12 seconds (100 ms cont.)	
					transmission fluid temperature sensor performance diagnsotic enable calibration	= 1 Boolean		
					P0712 and P0713	≠ Fault Active		
					Battery Voltage	<= 31.999023 Volts		
					Battery Voltage	>= 9 Volts		
					Battery voltage is within the allowable limits for	>= 0.1 Sec		
					Ignition Voltage	<= 31.999023 Volts		
					Ignition Voltage	>= 9 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Ignition voltage and SFL conditions met for	>= 0.1 Sec		
					transmission fluid temperature intermittent delta temperature test calibration enable	= 1 Boolean		
					propulsion system active	= TRUE Boolean		
			Fail Case 3 transmission fluid temperature stuck in range test transmission fluid temperature delta (100 ms loop to loop)	<= 0 ºC			>= 300 seconds (100 ms cont.)	
					transmission fluid temperature sensor performance diagnsotic enable calibration	= 1 Boolean		
					P0712 and P0713	≠ Fault Active		
					Battery Voltage	<= 31.999023 Volts		
					Battery Voltage	>= 9 Volts		
					Battery voltage is within the allowable limits for	>= 0.1 Sec		
					Ignition Voltage	<= 31.999023 Volts		
					Ignition Voltage	>= 9 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Ignition voltage and SFL conditions met for	>= 0.1 Sec		
					transmission fluid temperature stuck in range test calibration enable	= 1 Boolean		
					propulsion system active	= TRUE Boolean		
					transmission fluid temperature	<= 150 ºC		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					transmission fluid temperature	>= -40 ºC		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0712, P0713, P0717, P0722, P0723, P077C, P077D, P02809 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Transmission Fluid Temperature Sensor (TFT)	P0712	Transmission fluid temperature sensor failed at a low voltage	If Transmission Fluid Temperature Sensor Raw Resistance	<= 47.45000076 Ohms			>= 4 Fail Time (Sec) out of 5 Sample Time (Sec)	Type B, Two Trips
					trans fluid temp sensor low voltage diagnostic enable	= 1 Boolean		
					Battery Voltage	<= 31.999023 Volts		
					Battery Voltage	>= 9 Volts		
					Battery voltage is within the allowable limits for	>= 0.1 Sec		
					Ignition Voltage	<= 31.999023 Volts		
					Ignition Voltage	>= 9 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Ignition voltage and SFL conditions met for	>= 0.1 Sec		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Transmission Fluid Temperature Sensor (TFT)	P0713	Transmission fluid temperature sensor failed at a high voltage	If Transmission Fluid Temperature Sensor Raw Resistance	>= 105445 Ohms			>= 10 Fail Time (Sec) out of 12 Sample Time (Sec)	Type B, Two Trips
					trans fluid temp sensor high voltage diagnostic enable	= 1 Boolean		
					Battery Voltage	<= 31.999023 Volts		
					Battery Voltage	>= 9 Volts		
					Battery voltage is within the allowable limits for	>= 0.1 Sec		
					Ignition Voltage	<= 31.999023 Volts		
					Ignition Voltage	>= 9 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Ignition voltage and SFL conditions met for	>= 0.1 Sec		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Transmission Input Speed Sensor (TISS)	P0716	Input Speed Sensor Performance	Abolute Value Of Transmission Input Speed Sensor Delta (loop to loop)	>= 850 RPM			>= 1.5 seconds >= 5 fail events	Type A, One Trip
					speed sensor processing	= time based		
					Service mode $04 active and end of trip pocessing active	= FALSE Boolean		
					transmission input speed sensor performance diagnostic enable	= 1 Boolean		
					Ignition Voltage Hyst Hi (enabled above this value)	> 5 Volts		
					Ignition Voltage Hyst Lo disabled below this value)	<= 2 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Ignition Voltage Max (disabled above this value)	<= 31.999023 Volts		
					Ignition Voltage Min (enabled above this value)	>= 9 Volts		
					P0717 Status is not	= Test Failed This Key On		
					P07BF Status is not	= Test Failed This Key On		
					P07C0 Status is not	= Test Failed This Key On		
					last valid transmission input speed	> 148 RPM		
					OR transmission input speed raw	>= 148 RPM		
					transmssion input speed last valid or raw timer	>= 2 Seconds		
					transmission input speed sensor performance test complete (initialized to FALSE set to TRUE when P0716 fails)	= FALSE Boolean		
					transmission hydraulic system pressurized	= TRUE Boolean		
					driver accelerator pedal position available	= TRUE Boolean		
					engine torque inaccurate	= FALSE Boolean		
					Transmission Output Speed Sensor Raw Speed	>= 230 RPM		
					driver accelerator pedal position	>= 5.0003052 Pct		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					engine actual torque steady state raw	<= 8191.875 N*m		
					engine actual torque steady state raw	>= 30 N*m		
					P0716 Status is not	= Test Failed This Key On or Fault Active		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: P0716, P0717, P07BF, P07C0 ECM: P0101, P0102, P0103, P0121, P0122, P0123		
Transmission Input Speed Sensor (TISS)	P0717	Input Speed Sensor Circuit Low Voltage	Fail Case 1 Transmission Input Speed is	< 100 RPM			>= 4 Fail Time (Sec)	Type A, One Trip
			OR					
			Fail Case 2 P0722 DTC Status is Test Failed This Key On and and controller uses single power feed Transmission Input Speed is	< 175 RPM				
					Controller uses a single power supply for the speed sensors	= 0 Boolean		
					speed sensor processing	= time based		
					Service mode $04 active and end of trip pocessing active	= FALSE Boolean		
					transmission input speed sensor low diagnostic enable	= 1 Boolean		
					transmission hydraulic system pressurized	= TRUE Boolean		
					Ignition Voltage Hyst Hi (enabled above this value)	> 5 Volts		
					Ignition Voltage Hyst Lo disabled below this value)	<= 2 Volts		
					speed sensor connected to controller	= 1 Boolean		
					P0722 Status is not	= fault active		
					P0723 Status is not	= fault active		
					P077C Status is not	= fault active		
					P077D Status is not	= fault active		
					brake pedal position is not	>= 69.999695 Pct		
					engine torque inaccurate	= FALSE Boolean		
					P0716 Status is not	= Test Failed This Key On		
					P07BF Status is not	= Test Failed This Key On		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required			Mil Illum.
					P07C0 Status is not	=	Test Failed This Key On					
					driver accelerator pedal position	>=	5	Pct				
					engine actual torque steady state raw	<=	8191.875	N*m				
					engine actual torque steady state raw	>=	30	N*m				
					attained gear low	<	CeCGSR_e_CR_Sixth					
					Transmission Output Speed Sensor Raw Speed when attained gear low	>=	72	RPM				
					attained gear high	>=	CeCGSR_e_CR_Sixth					
					Transmission Output Speed Sensor Raw Speed when attained gear high	>=	230	RPM				
					P0717 Status is not	=	Test Failed This Key On or Fault Active					
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0722, P0723, P077C, P077D, P07BF, P07C0 ECM: P0101, P0102, P0103						
Transmission Output Speed Sensor (TOSS)	P0722	Output Speed Sensor Circuit Low Voltage	Transmission Output Speed Sensor Raw Speed	<= 30 RPM	attained gear high	>	CeCGSR_e_CR_Fourth	ENUM	>=	5	Fail Time (Sec)	Type A, One Trip
					attained gear low	<=	CeCGSR_e_CR_Fourth	ENUM	>=	3.5	Fail Time (Sec)	
					P0722 Status is not	=	Test Failed This Key On or Fault Active					
					Service mode $04 active and end of trip pocessing active ----------	=	FALSE	Boolean				
					transmission output speed sensor low diagnostic enable	=	1	Boolean				
					power flow not active (garage shift not complete, PRNDL = P or PRNDL = N, transmission range control in progress)	=	TRUE	Boolean				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					engine actual torque steady state raw power flow not active	>=	8192	N*m		
					driver accelerator position	>=	99.998474	Pct		
					---					
					power flow not active (garage shift not complete, PRNDL = P or PRNDL = N, transmission range control in progress)	=	FALSE	Boolean		
					attained gear high	>	CeCGSR_e_CR_Fourth	ENUM		
					high gear engine actual torque steady state raw power flow active hysteresis high	>=	50	N*m		
					high gear engine actual torque steady state raw power flow active hysteresis low not	<=	30	N*m		
					high gear accelerator pedal position power flow active hysteresis high	>=	4.9987793	Pct		
					high gear accelerator pedal position power flow active hysteresis low not	<=	2.9998779	Pct		
					attained gear low	<=	CeCGSR_e_CR_Fourth	ENUM		
					low gear engine actual torque steady state raw power flow active hysteresis high	>=	80	N*m		
					low gear engine actual torque steady state raw power flow active hysteresis low not	<=	50	N*m		
					low gear accelerator pedal position power flow active hysteresis high	>=	7.9986572	Pct		
					low gear accelerator pedal position power flow active hysteresis low not	<=	4.9987793	Pct		
					---					
					use transmission input speed sensor	=	TRUE	Boolean		
					speed sensors have single power feed	=	0	Boolean		
					transmission input speed sensor signal raw	<=	8191.875	RPM		
					transmission input speed sensor signal raw	>=	175	RPM		
					---					
					use transmission input speed sensor	=	FALSE	Boolean		
					speed sensors have single power feed	=	0	Boolean		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required			Mil Illum.
					engine speed sensor signal	<=	8191.875	RPM				
					engine speed sensor signal	>=	3500	RPM				

					P0716 Status is not	=	Fault Active					
					P0717 Status is not	=	Fault Active					
					P07BF Status is not	=	Fault Active					
					P07C0 Status is not	=	Fault Active					
					PTO disable	=	1	Boolean				
					PTO engaged	=	FALSE	Boolean				
					driver accelerator pedal position available	=	TRUE	Boolean				
					engine torque inaccurate	=	FALSE	Boolean				
					transmission hydraulic system pressurized	=	TRUE	Boolean				
					Ignition Voltage Hyst Hi (enabled above this value)	>	5	Volts				
					Ignition Voltage Hyst Lo disabled below this value)	<=	2	Volts				
					Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE	Boolean				
					Ignition Voltage Max (disabled above this value)	<=	31.999023	Volts				
					Ignition Voltage Min (enabled above this value)	>=	9	Volts				
					transmssion fluid temperature sensor	>=	-40	ºC				
					P0723 Status is not	=	Test Failed This Key On					
					P077C Status is not	=	Test Failed This Key On					
					P077D Status is not	=	Test Failed This Key On					
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0723 ECM: P0101, P0102, P0103, P0121, P0122, P0123						
Transmission Output Speed Sensor (TOSS)	P0723	Output Speed Sensor Circuit Intermittent	transmission output speed delta	>= see "set fail RPM threshold" RPM					>= 1.5		Fail Time (Sec)	Type A, One Trip
					transmission output speed OR	>=	36	RPM	>= 5		fail events	
					transmission output speed last valid output speed before drop	>=	36	RPM				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					for TOSS output speed raw, TOSS last valid output speed, time	>=	2	seconds		
					set fail RPM threshold					
					4WD low state valid	=	TRUE	Boolean		
					4WD low state	=	TRUE	Boolean		
					2WD delta transmission output speed fail threshold	=	500	RPM		
					4WD gear ratio	=	2.71			
					final delta transmission output speed fail threshold	=	1355	RPM		
					OR					
					4WD low state valid	=	TRUE	Boolean		
					4WD low state	=	FALSE	Boolean		
					OR					
					4WD low state valid	=	FALSE	Boolean		
					2WD delta transmission output speed fail threshold	=	500	RPM		
					final delta transmission output speed fail threshold	=	500	RPM		

					Range_Disable	=	FALSE	See Below		
					OR					

					Neutral_Range_Enable	=	TRUE	See Below		
					And					
					Neutral_Speed_Enable	=	TRUE	See Below		
					are TRUE concurrently					

					Transmission_Range_Enable	=	TRUE	See Below		
					Transmission_Input_Speed_Enable	=	TRUE	See Below		
					transmission output speed sensor performance diagnostic enable	=	1	Boolean		
					Service mode $04 active and end of trip pocessing active	=	FALSE	Boolean		
					No Change in Transfer Case Range (High <-> Low) for	>=	5	Seconds		
					P0723 Status is not	=	Test Failed This Key On or Fault Active			
					Disable this DTC if the PTO is active	=	1	Boolean		
					Ignition Voltage Hyst Hi (enabled above this value)	>	5	Volts		
					Ignition Voltage Hyst Lo disabled below this value)	<=	2	Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE	Boolean		
					Ignition Voltage Max (disabled above this value)	<=	31.999023	Volts		
					Ignition Voltage Min (enabled above this value)	>=	9	Volts		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					P077C Status is not	=	Test Failed This Key On			
					P077D Status is not	=	Test Failed This Key On			
					Enable_Flags Defined Below					
					Transmission_Input_Speed_Enable is TRUE when either TIS Condition 1 or TIS Condition 2 is TRUE:					
					TIS Condition 1 is TRUE when both of the following conditions are satsified for	>=	2	Enable Time (Sec)		
					Input Speed Delta	<=	4095.875	RPM		
					Raw Input Speed	>=	148	RPM		
					TIS Condition 2 is TRUE when ALL of the next two conditions are satisfied					
					Input Speed	=	0	RPM		
					A Single Power Supply is used for all speed sensors	=	TRUE	Boolean		

					Neutral_Range_Enable is TRUE when any of the next 3 conditions are TRUE					
					Transmission Range is	=	Neutral	ENUM		
					Transmission Range is	=	Reverse/Neutral Transitonal	ENUM		
					Transmission Range is	=	Neutral/Drive Transitional	ENUM		
					KeTOSl_n_OutSpdInNeutNoiseMaxLim	<	50	RPM		
					and when Loop to Loop Drop of Transmission Output Speed is	>	500	RPM		

					Range_Disable is TRUE when any of the next three conditions are TRUE					
					Transmission Range is	=	Park	ENUM		
					Transmission Range is	=	Park/Reverse Transitonal	ENUM		
					Input Clutch is not	=	ON (Fully Applied)	ENUM		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required			Mil Illum.
					Neutral_Speed_Enable is TRUE when All of the next three conditions are satsified for	>	2	Seconds				
					Transmission Output Speed	>=	50	RPM				
					The loop to loop change of the Transmission Output Speed is	<	20	RPM				
					The loop to loop change of the Transmission Output Speed is	>	-140	RPM				

					Transmission_Range_Enable is TRUE when one of the next six conditions is TRUE							
					Transmission Range is	=	Neutral	ENUM				
					Transmission Range is	=	Reverse/Neutral Transitional	ENUM				
					Transmission Range is	=	Neutral/Drive Transitional	ENUM				
					Time since a driven range (R,D) has been selected	>=	see Table 21 in supporting documents	Sec				
					Transmission Output Speed Sensor Raw Speed	>=	250	RPM				
					Output Speed when a fault was detected	>=	250	RPM				
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P077C, P077D ECM: P2771, P279A, P279B, P279C						
Variable Force Solenoid (VFS)	P0746	Pressure Control Solenoid A Stuck Off (clutch1/CB1278R)	absolute value (attained gear slip)	>= 400 RPM					>= 1.5 seconds when fail time reaches fail limit increment fail event count >= 3 event counts			Type A, One Trip
					clutch solenoid stuck on performance diagnostic monitor test deceleration limit not	=	TRUE	boolean				
					clutch solenoid stuck on performance diagnostic monitor test return to previous range not	=	TRUE	boolean				
					PRNDL State not	=	park	enumeration				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					PRNDL State not	=	neutral	enumeration		
					while conditinos A and B and C are met, time down delay from clibration to 0.0 seconds					
					delay time calibration	=	0.5	seconds		
					A) neutral condition fault pending	=	FALSE	boolean		
					B) intrusive shift active	=	FALSE	boolean		
					C) range shift state	=	shift complete	enumeration		
					intrusive shift allowed	=	TRUE	boolean		
					intrusive shift active	=	FALSE	boolean		
					steady state pressure adapt in progress	=	FALSE	boolean		
					transmission output speed	>=	100	RPM		
					accelerator pedal position	>=	0.5004883	%		
					accelerator pedal position valid	=	TRUE	Boolean		
					engine speed valid	=	TRUE	Boolean		
					D or E					
					D) select battery voltage to enable diagnsotic monitor	=	0	Boolean		
					E) battery voltage	<=	31.999023	volts		
					E) battery voltage	>=	9	volts		
					E) battery voltage time	>=	0.1	sec		
					F or G					
					F) select ignition voltage to enable diagnsotic monitor	=	0	Boolean		
					G) Ignition Voltage	<=	31.999023	Volts		
					G) Ignition Voltage	>=	9	Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE	Boolean		
					Ignition voltage and SFL conditions met for	>=	0.1	Sec		
					Hydraulic System Pressurized	=	TRUE	Boolean		
					high side driver 1 enabled	=	TRUE	Boolean		
					high side driver 2 enabled	=	TRUE	Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P1824, P182A, P182B, P182C, P182D, P182E, P182F, P1838, P1839, P1840, P1841, P18B5, P18B6, P18B7, P18B8, P18B9, P18BA, P18BB, P18BC, P18BD, P18BE, P18BF, P18C0, P18C1, P18C2, P18C3, P1915, P2534 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E					

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
Variable Force Solenoid (VFS)	P0747	Pressure Control Solenoid A Stuck On (clutch1/CB1278R)	automatic transmission shift torque phase test (A) or inertia phase test (B) fail event count deceleration limited	>= see Table 32 in supporting documents fail event counts				Type A, One Trip
			automatic transmission shift torque phase test (A) or inertia phase test (B) fail event count no deceleration	>= see Table 33 in supporting documents fail event counts				
			A) absolute value (attained gear slip), fail during post torque phase of transmission automatic shift, before engine speed change, pull up or pull down occurs	<= 40 RPM				
			increment fail time when slip criteria met, fail time for power down shift				>= see Table 29 in supporting documents seconds	
			increment fail time when slip criteria met, fail time for up shift or closed throttle down shift deceleration limited				>= see Table 30 in supporting documents seconds	
			increment fail time when slip criteria met, fail time for up shift or closed throttle down shift no deceleration				>= see Table 31 in supporting documents seconds	
							when fail time reaches fail limit increment fail event count above	
			B) absolute value (command gear slip), fail during inertia phase of transmission automatic shift, engine speed change begins, pull up or pull down	>= 70 RPM				
			increment fail time when slip criteria met, fail time during shift deceleration limited				>= see Table 35 in supporting documents seconds	
			increment fail time when slip criteria met, fail time during shift no deceleration				>= see Table 36 in supporting documents seconds	
							when fail time reaches fail limit increment fail event count above	
					inertia phase test measured gear ratio	>= 0.558		
					inertia phase test measured gear ratio	<= 4.7150002		
					inertia phase test measured gear ratio time	>= 0.15 seconds		
					clutch test enabled	= see Table 10 in supporting documents boolean		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					post torque phase test engine torque hysteresis high enable for upshift or power on down shift	>=	see Table 11 in supporting documents	N*m		
					post torque phase test engine torque hysteresis low disable for upshift or power on down shift	>	see Table 12 in supporting documents	N*m		
					post torque phase test engine torque hysteresis high enable for closed throttle down shift	>=	see Table 13 in supporting documents	N*m		
					post torque phase test engine torque hysteresis low disable for closed throttle down shift	>	see Table 14 in supporting documents	N*m		
					inertia phase test engine torque hysteresis high enable for upshift or power on down shift	>=	see Table 15 in supporting documents	N*m		
					inertia phase test engine torque hysteresis low disable for upshift or power on down shift	>	see Table 16 in supporting documents	N*m		
					inertia phase test engine torque hysteresis high enable for closed throttle down shift	>=	see Table 17 in supporting documents	N*m		
					inertia phase test engine torque hysteresis low disable for closed throttle down shift	>	see Table 18 in supporting documents	N*m		
					off going clutch pressure	<=	see Table 37 in supporting documents	kPa		
					off going clutch pressure closed throttle down shift delay time	>=	see Table 2 in supporting documents	seconds		
					off going clutch pressure closed power down shift delay time	>=	see Table 38 in supporting documents	seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					off going clutch pressure up shift delay time	>=	see Table 59 in supporting documents	seconds		
					on coming clutch pressure for up shift	>=	see Table 8 in supporting documents	kPa		
					on coming clutch pressure for down shift	>=	see Table 7 in supporting documents	kPa		
					brake pedal position hysteresis high disable	>=	27.000427	%		
					brake pedal position hysteresis low enable	<=	25	%		
					absolute value (attained gear slip)	<=	40	RPM		
					shift type enable	=	see Table 45 in supporting documents	boolean		
					clucth solenoid stuck off intrusive shift request not	=	TRUE	boolean		
					traction control event test suspend not	=	TRUE	boolean		
					transmission output speed	>=	100	RPM		
					accelerator pedal position valid	=	TRUE	Boolean		
					engine speed valid D or E	=	TRUE	Boolean		
					D) select battery voltage to enable diagnsotic monitor	=	0	Boolean		
					E) battery voltage	<=	31.999023	volts		
					E) battery voltage	>=	9	volts		
					E) battery voltage time F or G	>=	0.1	sec		
					F) select ignition voltage to enable diagnsotic monitor	=	0	Boolean		
					G) Ignition Voltage	<=	31.999023	Volts		
					G) Ignition Voltage	>=	9	Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE	Boolean		
					Ignition voltage and SFL conditions met for	>=	0.1	Sec		
					Hydraulic System Pressurized	=	TRUE	Boolean		
					high side driver 1 enabled	=	TRUE	Boolean		
					high side driver 2 enabled	=	TRUE	Boolean		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P1824, P182A, P182B, P182C, P182D, P182E, P182F, P1838, P1839, P1840, P1841, P18B5, P18B6, P18B7, P18B8, P18B9, P18BA, P18BB, P18BC, P18BD, P18BE, P18BF, P18C0, P18C1, P18C2, P18C3, P1915, P2534 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Force Solenoid (VFS)	P0776	Pressure Control Solenoid B Stuck Off (clutch2/CB12345R)	absolute value (attained gear slip)	>= 400 RPM			>= 1.5 seconds when fail time reaches fail limit increment fail event count >= 3 event counts	Type A, One Trip
					clutch solenoid stuck on performance diagnostic monitor test deceleration limit not	= TRUE boolean		
					clutch solenoid stuck on performance diagnostic monitor test return to previous range not	= TRUE boolean		
					PRNDL State not	= park enumeration		
					PRNDL State not	= neutral enumeration		
					while conditinos A and B and C are met, time down delay from clibration to 0.0 seconds			
					delay time calibration	= 0.5 seconds		
					A) neutral condition fault pending	= FALSE boolean		
					B) intrusive shift active	= FALSE boolean		
					C) range shift state	= shift complete enumeration		
					intrusive shift allowed	= TRUE boolean		
					intrusive shift active	= FALSE boolean		
					steady state pressure adapt in progress	= FALSE boolean		
					transmission output speed	>= 100 RPM		
					accelerator pedal position	>= 0.5004883 %		
					accelerator pedal position valid	= TRUE Boolean		
					engine speed valid D or E	= TRUE Boolean		
					D) select battery voltage to enable diagnsotic monitor	= 0 Boolean		
					E) battery voltage	<= 31.999023 volts		
					E) battery voltage	>= 9 volts		
					E) battery voltage time	>= 0.1 sec		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					F or G F) select ignition voltage to enable diagnsotic monitor = 0 Boolean G) Ignition Voltage <= 31.999023 Volts G) Ignition Voltage >= 9 Volts Service Fast Learn (SFL) Mode VBS Failsafe = FALSE Boolean Ignition voltage and SFL conditions met for >= 0.1 Sec Hydraulic System Pressurized = TRUE Boolean high side driver 1 enabled = TRUE Boolean high side driver 2 enabled = TRUE Boolean		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P1824, P182A, P182B, P182C, P182D, P182E, P182F, P1838, P1839, P1840, P1841, P18B5, P18B6, P18B7, P18B8, P18B9, P18BA, P18BB, P18BC, P18BD, P18BE, P18BF, P18C0, P18C1, P18C2, P18C3, P1915, P2534 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Force Solenoid (VFS)	P0777	Pressure Control Solenoid B Stuck On (clutch2/CB12345R)	automatic transmission shift torque phase test (A) or inertia phase test (B) fail event count deceleration limited	>= see Table 32 in supporting documents fail event counts				Type A, One Trip
			automatic transmission shift torque phase test (A) or inertia phase test (B) fail event count no deceleration	>= see Table 33 in supporting documents fail event counts				
			A) absolute value (attained gear slip), fail during post torque phase of transmission automatic shift, before engine speed change, pull up or pull down occurs	<= 40 RPM				
			increment fail time when slip criteria met, fail time for power down shift				>= see Table 29 in supporting documents seconds	
			increment fail time when slip criteria met, fail time for up shift or closed throttle down shift deceleration limited				>= see Table 30 in supporting documents seconds	
			increment fail time when slip criteria met, fail time for up shift or closed throttle down shift no deceleration				>= see Table 31 in supporting documents seconds	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
							when fail time reaches fail limit increment fail event count above	
			B) absolute value (command gear slip), fail during inertia phase of transmission automatic shift, engine speed change begins, pull up or pull down	>= 70 RPM				
			increment fail time when slip criteria met, fail time during shift deceleration limited				>= see Table 35 in supporting documents seconds	
			increment fail time when slip criteria met, fail time during shift no deceleration				>= see Table 36 in supporting documents seconds	
							when fail time reaches fail limit increment fail event count above	
					inertia phase test measured gear ratio	>= 0.558		
					inertia phase test measured gear ratio	<= 4.7150002		
					inertia phase test measured gear ratio time	>= 0.15 seconds		
					clutch test enabled	= see Table 10 in supporting documents boolean		
					post torque phase test engine torque hysteresis high enable for upshift or power on down shift	>= see Table 11 in supporting documents N*m		
					post torque phase test engine torque hysteresis low disable for upshift or power on down shift	> see Table 12 in supporting documents N*m		
					post torque phase test engine torque hysteresis high enable for closed throttle down shift	>= see Table 13 in supporting documents N*m		
					post torque phase test engine torque hysteresis low disable for closed throttle down shift	> see Table 14 in supporting documents N*m		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					inertia phase test engine torque hysteresis high enable for upshift or power on down shift	>=	see Table 15 in supporting documents	N*m		
					inertia phase test engine torque hysteresis low disable for upshift or power on down shift	>	see Table 16 in supporting documents	N*m		
					inertia phase test engine torque hysteresis high enable for closed throttle down shift	>=	see Table 17 in supporting documents	N*m		
					inertia phase test engine torque hysteresis low disable for closed throttle down shift	>	see Table 18 in supporting documents	N*m		
					off going clutch pressure	<=	see Table 37 in supporting documents	kPa		
					off going clutch pressure closed throttle down shift delay time	>=	see Table 3 in supporting documents	seconds		
					off going clutch pressure closed power down shift delay time	>=	see Table 39 in supporting documents	seconds		
					off going clutch pressure up shift delay time	>=	see Table 60 in supporting documents	seconds		
					on coming clutch pressure for up shift	>=	see Table 8 in supporting documents	kPa		
					on coming clutch pressure for down shift	>=	see Table 7 in supporting documents	kPa		
					brake pedal position hysteresis high disable	>=	27.000427	%		
					brake pedal position hysteresis low enable	<=	25	%		
					absolute value (attained gear slip)	<=	40	RPM		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required		Mil Illum.
					shift type enable	=	see Table 45 in supporting documents	boolean			
					clucth solenoid stuck off intrusive shift request not	=	TRUE	boolean			
					traction control event test suspend not	=	TRUE	boolean			
					transmission output speed	>=	100	RPM			
					accelerator pedal position valid	=	TRUE	Boolean			
					engine speed valid	=	TRUE	Boolean			
					D or E						
					D) select battery voltage to enable diagnsotic monitor	=	0	Boolean			
					E) battery voltage	<=	31.999023	volts			
					E) battery voltage	>=	9	volts			
					E) battery voltage time	>=	0.1	sec			
					F or G						
					F) select ignition voltage to enable diagnsotic monitor	=	0	Boolean			
					G) Ignition Voltage	<=	31.999023	Volts			
					G) Ignition Voltage	>=	9	Volts			
					Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE	Boolean			
					Ignition voltage and SFL conditions met for	>=	0.1	Sec			
					Hydraulic System Pressurized	=	TRUE	Boolean			
					high side driver 1 enabled	=	TRUE	Boolean			
					high side driver 2 enabled	=	TRUE	Boolean			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P1824, P182A, P182B, P182C, P182D, P182E, P182F, P1838, P1839, P1840, P1841, P18B5, P18B6, P18B7, P18B8, P18B9, P18BA, P18BB, P18BC, P18BD, P18BE, P18BF, P18C0, P18C1, P18C2, P18C3, P1915, P2534 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E					
Transmission Output Speed Sensor (TOSS)	P077C	Output Speed Sensor Circuit Low	TOSS Analog Signal Voltage	<= 0.25 Volts					>= 5.00E-02	sec	Type A, One Trip
			P077C Status is not	= Test Failed This Key On or Fault Active							

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			If the above conditons have been met, increment the P077C Fail Counter					
			DTC P077C Sets when the Fail Counter	>= 16 Counts (6.25 msec continuous)				
					P077C Enable Calibration	= 1		
					Service mode $04 active and end of trip pocessing active	= FALSE Boolean		
					Ignition Voltage Hyst Hi (enabled above this value)	> 5 Volts		
					Ignition Voltage Hyst Lo disabled below this value)	<= 2 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Battery Voltage Max (disabled above this value)	<= 31.999023 Volts		
					Battery Voltage Min (disabled below this value)	<= 10 Volts		
					Ignition Voltage Min (disabled below this value)	>= 10 Volts		
					for voltage stablity time	>= 5 seconds		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P077D		
Transmission Output Speed Sensor (TOSS)	P077D	Output Speed Sensor Circuit High	TOSS Analog Signal Voltage	>= 4.75 Volts			>= 5.00E-02 sec	Type A, One Trip
			P077D Status is not	= Test Failed This Key On or Fault Active				
			If the above conditons have been met, increment the P077D Fail Counter					
			DTC P077D Sets when the Fail Counter	>= 16 Counts (12.5 msec continuous)				
					P077D Enable Calibration	= 1		
					Service mode $04 active and end of trip pocessing active	= FALSE Boolean		
					Ignition Voltage Hyst Hi (enabled above this value)	> 5 Volts		
					Ignition Voltage Hyst Lo disabled below this value)	<= 2 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Battery Voltage Max (disabled above this value)	<= 31.999023 Volts		
					Battery Voltage Min (disabled below this value)	<= 10 Volts		
					Ignition Voltage Min (disabled below this value)	>= 10 Volts		
					for voltage stablity time	>= 5 seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P077C		
Variable Force Solenoid (VFS)	P0796	Pressure Control Solenoid C Stuck Off (clutch3/C13567)	absolute value (attained gear slip)	>= 400 RPM			>= 1.5 seconds when fail time reaches fail limit increment fail event count >= 3 event counts	Type A, One Trip
					clutch solenoid stuck on performance diagnostic monitor test deceleration limit not	= TRUE boolean		
					clutch solenoid stuck on performance diagnostic monitor test return to previous range not	= TRUE boolean		
					PRNDL State not	= park enumeration		
					PRNDL State not	= neutral enumeration		
					while conditinos A and B and C are met, time down delay from clibration to 0.0 seconds			
					delay time calibration	= 0.5 seconds		
					A) neutral condition fault pending	= FALSE boolean		
					B) intrusive shift active	= FALSE boolean		
					C) range shift state	= shift complete enumeration		
					intrusive shift allowed	= TRUE boolean		
					intrusive shift active	= FALSE boolean		
					steady state pressure adapt in progress	= FALSE boolean		
					transmission output speed	>= 100 RPM		
					accelerator pedal position	>= 0.5004883 %		
					accelerator pedal position valid	= TRUE Boolean		
					engine speed valid D or E	= TRUE Boolean		
					D) select battery voltage to enable diagnsotic monitor	= 0 Boolean		
					E) battery voltage	<= 31.999023 volts		
					E) battery voltage	>= 9 volts		
					E) battery voltage time F or G	>= 0.1 sec		
					F) select ignition voltage to enable diagnsotic monitor	= 0 Boolean		
					G) Ignition Voltage	<= 31.999023 Volts		
					G) Ignition Voltage	>= 9 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Ignition voltage and SFL conditions met for	>= 0.1 Sec		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Hydraulic System Pressurized high side driver 1 enabled high side driver 2 enabled	= TRUE Boolean = TRUE Boolean = TRUE Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P1824, P182A, P182B, P182C, P182D, P182E, P182F, P1838, P1839, P1840, P1841, P18B5, P18B6, P18B7, P18B8, P18B9, P18BA, P18BB, P18BC, P18BD, P18BE, P18BF, P18C0, P18C1, P18C2, P18C3, P1915, P2534 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Force Solenoid (VFS)	P0797	Pressure Control Solenoid C Stuck On (clutch3/C13567)	automatic transmission shift torque phase test (A) or inertia phase test (B) fail event count deceleration limited	>= see Table 32 in supporting documents fail event counts				Type A, One Trip
			automatic transmission shift torque phase test (A) or inertia phase test (B) fail event count no deceleration	>= see Table 33 in supporting documents fail event counts				
			A) absolute value (attained gear slip), fail during post torque phase of transmission automatic shift, before engine speed change, pull up or pull down occurs	<= 40 RPM				
			increment fail time when slip criteria met, fail time for power down shift				>= see Table 29 in supporting documents seconds	
			increment fail time when slip criteria met, fail time for up shift or closed throttle down shift deceleration limited				>= see Table 30 in supporting documents seconds	
			increment fail time when slip criteria met, fail time for up shift or closed throttle down shift no deceleration				>= see Table 31 in supporting documents seconds	
							when fail time reaches fail limit increment fail event count above	
			B) absolute value (command gear slip), fail during inertia phase of transmission automatic shift, engine speed change begins, pull up or pull down	>= 70 RPM				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required		Mil Illum.
			increment fail time when slip criteria met, fail time during shift deceleration limited increment fail time when slip criteria met, fail time during shift no deceleration						>= see Table 35 in supporting documents >= see Table 36 in supporting documents	seconds seconds when fail time reaches fail limit increment fail event count above	
					inertia phase test measured gear ratio	>=	0.558				
					inertia phase test measured gear ratio	<=	4.7150002				
					inertia phase test measured gear ratio time	>=	0.15	seconds			
					clutch test enabled	=	see Table 10 in supporting documents	boolean			
					post torque phase test engine torque hysteresis high enable for upshift or power on down shift	>=	see Table 11 in supporting documents	N*m			
					post torque phase test engine torque hysteresis low disable for upshift or power on down shift	>	see Table 12 in supporting documents	N*m			
					post torque phase test engine torque hysteresis high enable for closed throttle down shift	>=	see Table 13 in supporting documents	N*m			
					post torque phase test engine torque hysteresis low disable for closed throttle down shift	>	see Table 14 in supporting documents	N*m			
					inertia phase test engine torque hysteresis high enable for upshift or power on down shift	>=	see Table 15 in supporting documents	N*m			
					inertia phase test engine torque hysteresis low disable for upshift or power on down shift	>	see Table 16 in supporting documents	N*m			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					inertia phase test engine torque hysteresis high enable for closed throttle down shift	>=	see Table 17 in supporting documents	N*m		
					inertia phase test engine torque hysteresis low disable for closed throttle down shift	>	see Table 18 in supporting documents	N*m		
					off going clutch pressure	<=	see Table 37 in supporting documents	kPa		
					off going clutch pressure closed throttle down shift delay time	>=	see Table 4 in supporting documents	seconds		
					off going clutch pressure closed power down shift delay time	>=	see Table 40 in supporting documents	seconds		
					off going clutch pressure up shift delay time	>=	see Table 61 in supporting documents	seconds		
					on coming clutch pressure for up shift	>=	see Table 8 in supporting documents	kPa		
					on coming clutch pressure for down shift	>=	see Table 7 in supporting documents	kPa		
					brake pedal position hysteresis high disable	>=	27.000427	%		
					brake pedal position hysteresis low enable	<=	25	%		
					absolute value (attained gear slip)	<=	40	RPM		
					shift type enable	=	see Table 45 in supporting documents	boolean		
					clucth solenoid stuck off intrusive shift request not	=	TRUE	boolean		
					traction control event test suspend not	=	TRUE	boolean		
					transmission output speed	>=	100	RPM		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					accelerator pedal position valid = TRUE Boolean engine speed valid = TRUE Boolean D or E D) select battery voltage to enable diagnsotic monitor = 0 Boolean E) battery voltage <= 31.999023 volts E) battery voltage >= 9 volts E) battery voltage time >= 0.1 sec F or G F) select ignition voltage to enable diagnsotic monitor = 0 Boolean G) Ignition Voltage <= 31.999023 Volts G) Ignition Voltage >= 9 Volts Service Fast Learn (SFL) Mode VBS Failsafe = FALSE Boolean Ignition voltage and SFL conditions met for >= 0.1 Sec Hydraulic System Pressurized = TRUE Boolean high side driver 1 enabled = TRUE Boolean high side driver 2 enabled = TRUE Boolean			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P1824, P182A, P182B, P182C, P182D, P182E, P182F, P1838, P1839, P1840, P1841, P18B5, P18B6, P18B7, P18B8, P18B9, P18BA, P18BB, P18BC, P18BD, P18BE, P18BF, P18C0, P18C1, P18C2, P18C3, P1915, P2534 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Transmission Input Speed Sensor (TISS)	P07BF	Input/Turbine Speed Sensor A Circuit Low	TISS Analog Signal Voltage P07BF Status is not If the above conditons have been met, increment the P07BF Fail Counter	<= 0.25 Volts = Test Failed This Key On or Fault Active			>= 5.00E-02 sec	Type A, One Trip
			DTC P07BF Sets when the Fail Counter	>= 16 Counts (12.5 msec continuous)				
					speed sensor processing = time based P07BF Enable Calibration = 1 Service mode $04 active and end of trip pocessing active = FALSE Boolean			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Ignition Voltage Hyst Hi (enabled above this value)	> 5 Volts		
					Ignition Voltage Hyst Lo disabled below this value)	<= 2 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Battery Voltage Max (disabled above this value)	<= 31.999023 Volts		
					Battery Voltage Min (disabled below this value)	<= 10 Volts		
					Ignition Voltage Min (disabled below this value)	>= 10 Volts		
					for voltage stablity time	>= 5 seconds		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P07C0		
Transmission Input Speed Sensor (TISS)	P07C0	Input/Turbine Speed Sensor A Circuit High	TISS Analog Signal Voltage	>= 4.75 Volts			>= 5.00E-02 sec	Type A, One Trip
			P07C0 Status is not	= Test Failed This Key On or Fault Active				
			If the above conditons have been met, increment the P07C0 Fail Counter					
			DTC P07C0 Sets when the Fail Counter	>= 16 Counts (12.5 msec continuous)				
					speed sensor processing	= time based		
					P07C0 Enable Calibration	= 1		
					Service mode $04 active and end of trip pocessing active	= FALSE Boolean		
					Ignition Voltage Hyst Hi (enabled above this value)	> 5 Volts		
					Ignition Voltage Hyst Lo disabled below this value)	<= 2 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Battery Voltage Max (disabled above this value)	<= 31.999023 Volts		
					Battery Voltage Min (disabled below this value)	<= 10 Volts		
					Ignition Voltage Min (disabled below this value)	>= 10 Volts		
					for voltage stablity time	>= 5 seconds		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P07BF		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria		Threshold Value			Secondary Malfunction	Enable Conditions	Time Required			Mil Illum.
Tap Up Tap Down Switch (TUTD)	P0815	Upshift Switch Circuit	Fail Case 1	Tap Up Switch Stuck in the Up Position in Range 1 Enabled	=	1	Boolean						Special No MIL
				Tap Up Switch Stuck in the Up Position in Range 2 Enabled	=	1	Boolean						
				Tap Up Switch Stuck in the Up Position in Range 3 Enabled	=	1	Boolean						
				Tap Up Switch Stuck in the Up Position in Range 4 Enabled	=	1	Boolean						
				Tap Up Switch Stuck in the Up Position in Range 5 Enabled	=	1	Boolean						
				Tap Up Switch Stuck in the Up Position in Range 6 Enabled	=	1	Boolean						
				Tap Up Switch Stuck in the Up Position in Range 7 Enabled	=	1	Boolean						
				Tap Up Switch Stuck in the Up Position in Range 8 Enabled	=	1	Boolean						
				Tap Up Switch Stuck in the Up Position in Neutral Enabled	=	0	Boolean						
				Tap Up Switch Stuck in the Up Position in Park Enabled	=	0	Boolean						
				Tap Up Switch Stuck in the Up Position in Reverse Enabled	=	0	Boolean						
				Tap Up Switch ON	=	TRUE	Boolean			>=	1	Fail Time (Sec)	
			Fail Case 2	Tap Up Switch Stuck in the Up Position in Range 1 Enabled	=	1	Boolean						
				Tap Up Switch Stuck in the Up Position in Range 2 Enabled	=	1	Boolean						
				Tap Up Switch Stuck in the Up Position in Range 3 Enabled	=	1	Boolean						
				Tap Up Switch Stuck in the Up Position in Range 4 Enabled	=	1	Boolean						
				Tap Up Switch Stuck in the Up Position in Range 5 Enabled	=	1	Boolean						
				Tap Up Switch Stuck in the Up Position in Range 6 Enabled	=	1	Boolean						
				Tap Up Switch Stuck in the Up Position in Range 7 Enabled	=	1	Boolean						
				Tap Up Switch Stuck in the Up Position in Range 8 Enabled	=	1	Boolean						
				Tap Up Switch Stuck in the Up Position in Neutral Enabled	=	0	Boolean						
				Tap Up Switch Stuck in the Up Position in Park Enabled	=	0	Boolean						
				Tap Up Switch Stuck in the Up Position in Reverse Enabled	=	0	Boolean						
				Tap Up Switch ON	=	TRUE	Boolean						
				NOTE: Both Failcase1 and Failcase 2 Must Be Met						>=	120	Fail Time (Sec)	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					upshift switch diagnostic monitor enable calibration = 1 Service mode $04 active and end of trip processing active = FALSE Boolean Ignition Voltage Hyst Hi (enabled above this value) > 5 Volts Ignition Voltage Hyst Lo disabled below this value) <= 2 Volts Service Fast Learn (SFL) Mode VBS Failsafe = FALSE Boolean Ignition Voltage Max (disabled above this value) <= 31.999023 Volts Ignition Voltage Min (enabled above this value) >= 9 Volts Time Since Last Range Change >= 1 Enable Time (Sec) P0815 Status is ≠ Test Failed This Key On or Fault Active		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0826, P1824, P182A, P182B, P182C, P182D, P182E, P182F, P1838, P1839, P1840, P1841, P18B5, P18B6, P18B7, P18B8, P18B9, P18BA, P18BB, P18BC, P18BD, P18BE, P18BF, P18C0, P18C1, P18C2, P18C3, P1915, P1761 ECM: None		
Tap Up Tap Down Switch (TUTD)	P0816	Downshift Switch Circuit	Fail Case 1 Tap Down Switch Stuck in the Down Position in Range 1 Enabled = 1 Boolean Tap Down Switch Stuck in the Down Position in Range 2 Enabled = 1 Boolean Tap Down Switch Stuck in the Down Position in Range 3 Enabled = 1 Boolean Tap Down Switch Stuck in the Down Position in Range 4 Enabled = 1 Boolean Tap Down Switch Stuck in the Down Position in Range 5 Enabled = 1 Boolean Tap Down Switch Stuck in the Down Position in Range 6 Enabled = 1 Boolean					Special No MIL

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria		Threshold Value		Secondary Malfunction	Enable Conditions	Time Required			Mil Illum.
			Tap Down Switch Stuck in the Down Position in Range 7 Enabled	=	1	Boolean						
			Tap Down Switch Stuck in the Down Position in Range 8 Enabled	=	1	Boolean						
			Tap Down Switch Stuck in the Down Position in Range Neutral Enabled	=	0	Boolean						
			Tap Down Switch Stuck in the Down Position in Range Park Enabled	=	0	Boolean						
			Tap Down Switch Stuck in the Down Position in Range Reverse Enabled	=	0	Boolean						
			Tap Down Switch ON	=	TRUE	Boolean			>=	1	sec	
			Fail Case 2 Tap Down Switch Stuck in the Down Position in Range 1 Enabled	=	1	Boolean						
			Tap Down Switch Stuck in the Down Position in Range 2 Enabled	=	1	Boolean						
			Tap Down Switch Stuck in the Down Position in Range 3 Enabled	=	1	Boolean						
			Tap Down Switch Stuck in the Down Position in Range 4 Enabled	=	1	Boolean						
			Tap Down Switch Stuck in the Down Position in Range 5 Enabled	=	1	Boolean						
			Tap Down Switch Stuck in the Down Position in Range 6 Enabled	=	1	Boolean						
			Tap Down Switch Stuck in the Down Position in Range 7 Enabled	=	1	Boolean						
			Tap Down Switch Stuck in the Down Position in Range 8 Enabled	=	1	Boolean						
			Tap Down Switch Stuck in the Down Position in Neutral Enabled	=	0	Boolean						
			Tap Down Switch Stuck in the Down Position in Park Enabled	=	0	Boolean						
			Tap Down Switch Stuck in the Down Position in Reverse Enabled	=	0	Boolean						
			Tap Down Switch ON NOTE: Both Failcase1 and Failcase 2 Must Be Met	=	TRUE	Boolean			>=	120	sec	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					downshift switch diagnostic monitor enable calibration = 1 Service mode $04 active and end of trip pocessing active = FALSE Boolean Ignition Voltage Hyst Hi (enabled above this value) > 5 Volts Ignition Voltage Hyst Lo disabled below this value) <= 2 Volts Service Fast Learn (SFL) Mode VBS Failsafe = FALSE Boolean Ignition Voltage Max (disabled above this value) <= 31.999023 Volts Ignition Voltage Min (enabled above this value) >= 9 Volts Time Since Last Range Change >= 1 Enable Time (Sec) P0816 Status is ≠ Test Failed This Key On or Fault Active		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: P0826, P1824, P182A, P182B, P182C, P182D, P182E, P182F, P1838, P1839, P1840, P1841, P18B5, P18B6, P18B7, P18B8, P18B9, P18BA, P18BB, P18BC, P18BD, P18BE, P18BF, P18C0, P18C1, P18C2, P18C3, P1915, P1761 ECM: None		
Tap Up Tap Down Switch (TUTD)	P0826	Up and Down Shift Switch Circuit	TUTD Circuit Reads Invalid Voltage	= TRUE Boolean			>= 60 Fail Time (Sec)	Special No MIL
					Service mode $04 active and end of trip pocessing active = FALSE Boolean upshift downshift switch circuit diagnostic monitor enable calibration = 1 Ignition Voltage Hyst Hi (enabled above this value) > 5 Volts Ignition Voltage Hyst Lo disabled below this value) <= 2 Volts Service Fast Learn (SFL) Mode VBS Failsafe = FALSE Boolean Ignition Voltage Max (disabled above this value) <= 31.999023 Volts Ignition Voltage Min (enabled above this value) >= 9 Volts		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					P0826 Status is	≠ Test Failed This Key On or Fault Active		
					Disable Conditions: MIL not Illuminated for DTC's:			
Variable Force Solenoid (VFS)	P0960	Pressure Control Solenoid A Control Circuit Open (clutch1/CB1278R VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration	= TRUE Boolean		
					VFS source must be high side driver 1 or 2 or 3			
					high side driver VFS source is	= CeTSCR_e_HSD2 enumeration		
					high side driver VFS source enabled	= TRUE Boolean		
					controller power mode state is ignition or accessory	= TRUE Boolean		
					battery voltage in range for stability time			
					battery voltage stability time	>= 1 seconds		
					battery voltage	>= 8 volts		
					battery voltage	<= 32 Volts		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P0962	Pressure Control Solenoid A Control Circuit Low (clutch1/CB1278R VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration	= TRUE Boolean		
					VFS source must be high side driver 1 or 2 or 3			
					high side driver VFS source is	= CeTSCR_e_HSD2 enumeration		
					high side driver VFS source enabled	= TRUE Boolean		
					controller power mode state is ignition or accessory	= TRUE Boolean		
					battery voltage in range for stability time			
					battery voltage stability time	>= 1 seconds		
					battery voltage	>= 8 volts		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					battery voltage	<= 32 Volts		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P0963	Pressure Control Solenoid A Control Circuit High (clutch1/CB1278R VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration	= TRUE Boolean		
					VFS source must be high side driver 1 or 2 or 3			
					high side driver VFS source is	= CeTSCR_e_HSD2 enumeration		
					high side driver VFS source enabled	= TRUE Boolean		
					controller power mode state is ignition or accessory	= TRUE Boolean		
					battery voltage in range for stability time			
					battery voltage stability time	>= 1 seconds		
					battery voltage	>= 8 volts		
					battery voltage	<= 32 Volts		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P0964	Pressure Control Solenoid B Control Circuit Open (clutch2/CB12345R VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration	= TRUE Boolean		
					VFS source must be high side driver 1 or 2 or 3			
					high side driver VFS source is	= CeTSCR_e_HSD2 enumeration		
					high side driver VFS source enabled	= TRUE Boolean		
					controller power mode state is ignition or accessory	= TRUE Boolean		
					battery voltage in range for stability time			
					battery voltage stability time	>= 1 seconds		
					battery voltage	>= 8 volts		
					battery voltage	<= 32 Volts		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P0966	Pressure Control Solenoid B Control Circuit Low (clutch2/CB12345R VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration = TRUE Boolean VFS source must be high side driver 1 or 2 or 3 high side driver VFS source is = CeTSCR_e_HSD2 enumeration high side driver VFS source enabled = TRUE Boolean controller power mode state is ignition or accessory = TRUE Boolean battery voltage in range for stability time battery voltage stability time >= 1 seconds battery voltage >= 8 volts battery voltage <= 32 Volts			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P0967	Pressure Control Solenoid B Control Circuit High (clutch2/CB12345R VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration = TRUE Boolean VFS source must be high side driver 1 or 2 or 3 high side driver VFS source is = CeTSCR_e_HSD2 enumeration high side driver VFS source enabled = TRUE Boolean controller power mode state is ignition or accessory = TRUE Boolean battery voltage in range for stability time battery voltage stability time >= 1 seconds battery voltage >= 8 volts battery voltage <= 32 Volts			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
Variable Force Solenoid (VFS)	P0968	Pressure Control Solenoid C Control Circuit Open (clutch3/C13567 VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration	= TRUE Boolean		
					VFS source must be high side driver 1 or 2 or 3			
					high side driver VFS source is	= CeTSCR_e_HSD2 enumeration		
					high side driver VFS source enabled	= TRUE Boolean		
					controller power mode state is ignition or accessory	= TRUE Boolean		
					battery voltage in range for stability time			
					battery voltage stability time	>= 1 seconds		
					battery voltage	>= 8 volts		
					battery voltage	<= 32 Volts		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P0970	Pressure Control Solenoid C Control Circuit Low (clutch3/C13567 VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration	= TRUE Boolean		
					VFS source must be high side driver 1 or 2 or 3			
					high side driver VFS source is	= CeTSCR_e_HSD2 enumeration		
					high side driver VFS source enabled	= TRUE Boolean		
					controller power mode state is ignition or accessory	= TRUE Boolean		
					battery voltage in range for stability time			
					battery voltage stability time	>= 1 seconds		
					battery voltage	>= 8 volts		
					battery voltage	<= 32 Volts		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P0971	Pressure Control Solenoid C Control Circuit High (clutch3/C13567 VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec)	Type A, One Trip

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
							out of 0.5 Sample Time (Sec)	
					diagnostic monitor enable calibration = TRUE Boolean VFS source must be high side driver 1 or 2 or 3 high side driver VFS source is = CeTSCR_e_HSD2 enumeration high side driver VFS source enabled = TRUE Boolean controller power mode state is ignition or accessory = TRUE Boolean battery voltage in range for stability time battery voltage stability time >= 1 seconds battery voltage >= 8 volts battery voltage <= 32 Volts		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Transmission Control Module (TCM)	P16E9	Transmission Control Module	secondary micro processor hardware serial peripheral device fault active = TRUE Boolean secondary micro processor hardware serial peripheral device fault active previous loop = TRUE Boolean					Type A, One Trip
					Service mode $04 active and end of trip pocessing active = FALSE Boolean			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Transmission Control Module (TCM)	P16F0	Transmission Control Module	secondary micro processor serial peripheral device message valid detected by primary micro processor since controller initialization = FALSE Boolean				>= 5 counts (12.5 ms) cont	Type A, One Trip
			OR secondary micro processor serial peripheral device message valid detected by primary micro processor after controller initialization = FALSE Boolean				>= 8 counts (12.5 ms) cont >= 5 counts (12.5 ms) cont	
			OR				>= 8 counts (12.5 ms) cont	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			secondary micro processor serial peripheral device message valid detected by primary micro processor after controller initialization	= FALSE Boolean			>= 5 counts (12.5 ms) NON continuous >= 8 counts (12.5 ms) NON continuous	
					NOT in low voltage engine crank condition defined by A or B below during, for low voltage mode time low voltage mode time A) low voltage mode hysteresis time B) ignition voltage, set low voltage mode	>= 2.50E-02 seconds <= 0.1 seconds <= 6.4091797 volts		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Transmission Control Module (TCM)	P16F3	Transmission Control Module	diagnostic monitor fails when any of the following conditions occur A or B or C					Type A, One Trip
			A) command pressure and its dual store do not equal OR	= TRUE Boolean	redundent memory command pressure disable calibration not OR redundent memory command pressure enable calibration	= TRUE Boolean = TRUE Boolean		
			B) command shift and its dual store do not equal OR	= TRUE Boolean	redundent memory command shift disable calibration not OR redundent memory command shift enable calibration	= FALSE Boolean Boolean = TRUE Boolean		
			C) rate limited vehicle speed and its dual store do not equal	= TRUE Boolean	rate limited vehicle speed dual store enable calibration	= TRUE Boolean	>= 10 counts (25 msec continuous) >= 20 counts (25 msec continuous)	
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
Transmission Control Module (TCM)	P16F4	Transmission Control Module	redundent path calculation of driver selected transmission range error	= TRUE Boolean			>= 6 counts (25 msec continuous) >= 8 counts (25 msec continuous)	Type A, One Trip
					secureed controller or emission critical ignition voltage	>= 11 volts		
					P16F4 status is not	= test pass this key on Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Transmission Control Module (TCM)	P16FB	Transmission Control Module	transmission output speed raw (25 ms loop value) - transmission output speed raw (6.25 ms loop value)	>= 60 RPM			>= 8 seconds >= 10 seconds	Type A, One Trip
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Battery Voltage Max (disabled above this value)	<= 31.999023 Volts		
					Battery Voltage Min (disabled below this value)	<= 10 Volts		
					Ignition Voltage Min (disabled below this value)	>= 10 Volts		
					for voltage stablity time	>= 5 seconds		
					transmission output speed raw (6.25 ms loop value)	>= 150 RPM		
					transmission output speed raw (25 ms loop value)	>= 150 RPM		
					Service mode $04 active and end of trip pocessing active	= FALSE Boolean		
					diagnostic monitor enable calibration	= 1 Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Lateral acceleration signal	P175F	Lateral acceleration signal circuit (rolling count or checksum)	P175F will fail when A: message alive rolling count erroror or B: message checksum error					Special No MIL
			A: Rolling count value received from EBCM and expected TCM calculated value not	= TRUE Boolean			>= 9 Fail Counter (50 msec continuous) > 54 Fail Timer (Sec)	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Lateral acceleration message health (message receive occur)	= TRUE Boolean		
					Lateral acceleration signal circuit rolling count diagnostic monitor enable calibration	= 1 Boolean		
					battery voltage	<= 31.999023 volts		
					battery voltage	>= 9 volts		
					battery voltage time	>= 0.1 sec		
					Ignition Voltage	<= 31.999023 Volts		
					Ignition Voltage	>= 9 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Ignition voltage and SFL conditions met for	>= 0.1 Sec		
			B: checksum of lateral acceleration message value error	= TRUE Boolean			>= 54 Fail Timer (Sec)	
					Lateral acceleration message health (message receive occur)	= TRUE Boolean		
					Lateral acceleration signal circuit checksum diagnostic monitor enable calibration	= 1 Boolean		
					battery voltage	<= 31.999023 volts		
					battery voltage	>= 9 volts		
					battery voltage time	>= 0.1 sec		
					Ignition Voltage	<= 31.999023 Volts		
					Ignition Voltage	>= 9 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Ignition voltage and SFL conditions met for	>= 0.1 Sec		
					normal serial data communication enabled	= TRUE Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: U0073 ECM: None		
Tap Up Tap Down Switch (TUTD)	P1761	Tap Up and Down switch signal circuit (rolling count)	Rolling count value received from BCM and expected TCM calculated value not	= TRUE Boolean			>= 3 Fail Counter (100 msec continuous) > 10 Fail Timer (Sec)	Special No MIL
					Tap up/down message health (message receive occur)	= TRUE Boolean		
					Tap up/downswitch signal circuit (rolling count) diagnostic monitor enable calibration	= 1 Boolean		
					Ignition Voltage	<= 31.999023 Volts		
					Ignition Voltage	>= 9 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Ignition voltage and SFL conditions met for	>= 0.1 Sec		
					Service mode $04 active and end of trip pocessing active	= FALSE Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:			
Transmission Intermediate Speed Sensor	P176B	Transmission Intermediate Speed Sensor Performance	attained gear is Reverse or 1st or 2nd		fail time	>= 4 seconds	>= 4 counts (25 msec continuous)	Type B, Two Trips
			transmssion intermediate speed attained gear is 3rd or 4th or 5th or 6th or 7th or 8th	> 60 PRM				
			calculated intermediate gear slip = absolute value (transmission input speed - (transmission intermediate speed * command gear intermediate ratio))	> 60 PRM				
					calculated gear slip = absolute value (transmission input speed - (transmission output speed * command gear ratio))	<= 60 RPM		
					calculated gear slip stablity time when all of the conditions below are met	>= 1 seconds		
					diagnostic monitor enable calibration	= 1 Boolean		
					transmission output speed	>= 190 RPM		
					transmission input speed	>= 395 RPM		
					neutral idle mode requesting holding clutch disable	= FALSE Boolean		
					range shift state is	= shift complete		
					Hydraulic System Pressurized	= TRUE Boolean		
					battery voltage	<= 31.999023 volts		
					battery voltage	>= 9 volts		
					battery voltage time	>= 0.1 sec		
					Ignition Voltage	<= 31.999023 Volts		
					Ignition Voltage	>= 9 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Ignition voltage and SFL conditions met for	>= 0.1 Sec		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P07BF, P07C0, P0722, P0723, P077C, P077D		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria		Threshold Value	Secondary Malfunction		Enable Conditions		Time Required		Mil Illum.
Transmission Intermediate Speed Sensor	P176C	Intermediate Speed Sensor Circuit Low	speed sensor1 voltage	<=	see Table 51 in supporting documents volts	speed sensor1 fail time	>=	see Table 53 in supporting documents seconds		>= see Table 52 in supporting documents	counts (12.5 msec continuous)	Type B, Two Trips
						speed sensor1 circuit low diagnostic monitor enable calibration	=	see Table 54 in supporting documents Boolean				
						Service mode $04 active and end of trip pocessing active	=	FALSE Boolean				
						Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE Boolean				
						Battery Voltage Max (disabled above this value)	<=	31.999023 Volts				
						Battery Voltage Min (disabled below this value)	<=	10 Volts				
						Ignition Voltage Min (disabled below this value)	>=	10 Volts				
						for voltage stablity time	>=	5 seconds				
						P176C Status is not	=	Test Failed This Key On or Fault Active				
			Disable Conditions:			MIL not Illuminated for DTC's:	TCM: P176D					
Transmission Intermediate Speed Sensor	P176D	Intermediate Speed Sensor Circuit High	speed sensor1 voltage	>=	see Table 55 in supporting documents volts	speed sensor1 fail time	>=	see Table 57 in supporting documents seconds		>= see Table 56 in supporting documents	counts (12.5 msec continuous)	Type B, Two Trips
						speed sensor1 circuit high diagnostic monitor enable calibration	=	see Table 58 in supporting documents Boolean				
						Service mode $04 active and end of trip pocessing active	=	FALSE Boolean				
						Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE Boolean				
						Battery Voltage Max (disabled above this value)	<=	31.999023 Volts				
						Battery Voltage Min (disabled below this value)	<=	10 Volts				
						Ignition Voltage Min (disabled below this value)	>=	10 Volts				
						for voltage stablity time	>=	5 seconds				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required			Mil Illum.
					P176D Status is not	=	Test Failed This Key On or Fault Active					
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P176C						
Internal Mode Switch (IMS)	P1824	Internal Mode Switch P Circuit High Voltage	IMS switch P voltage	> 2.380000114 volts					>=	70	Fail Counts (25ms loop)	Type B, Two Trips
									out of	80	Sample Counts (25ms loop)	
					Diagnostic monitor enable calibration	=	1	Boolean				
					Ignition Voltage Lo	>=	9	Volts				
					Ignition Voltage Hi	<=	31.999023	Volts				
					If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event							
					Ignition Voltage Lo	>=	7	Volts				
					Ignition Voltage Hi	<	9	Volts				
					Ignition Voltage within the above low / high thresholds for	<=	7.50E-02	seconds				
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None						
Internal Mode Switch (IMS)	P182A	Internal Mode Switch A Circuit Low Voltage	IMS switch A voltage	< 0.699999988 volts					>=	70	Fail Counts (25ms loop)	Type B, Two Trips
									out of	80	Sample Counts (25ms loop)	
					Diagnostic monitor enable calibration	=	1	Boolean				
					Ignition Voltage Lo	>=	9	Volts				
					Ignition Voltage Hi	<=	31.999023	Volts				
					If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event							
					Ignition Voltage Lo	>=	7	Volts				
					Ignition Voltage Hi	<	9	Volts				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Ignition Voltage within the above low / high thresholds for	<= 7.50E-02 seconds		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P182B	Internal Mode Switch B Circuit Low Voltage	IMS switch B voltage	< 0.699999988 volts			>= 70 Fail Counts (25ms loop) out of 80 Sample Counts (25ms loop)	Type B, Two Trips
					Diagnostic monitor enable calibration Ignition Voltage Lo Ignition Voltage Hi If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event Ignition Voltage Lo Ignition Voltage Hi Ignition Voltage within the above low / high thresholds for	= 1 Boolean >= 9 Volts <= 31.999023 Volts >= 7 Volts < 9 Volts <= 7.50E-02 seconds		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P182C	Internal Mode Switch B Circuit High Voltage	IMS switch B voltage	> 2.380000114 volts			>= 70 Fail Counts (25ms loop) out of 80 Sample Counts (25ms loop)	Type B, Two Trips
					Diagnostic monitor enable calibration Ignition Voltage Lo Ignition Voltage Hi If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event Ignition Voltage Lo Ignition Voltage Hi Ignition Voltage within the above low / high thresholds for	= 1 Boolean >= 9 Volts <= 31.999023 Volts >= 7 Volts < 9 Volts <= 7.50E-02 seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P182D	Internal Mode Switch P Circuit Low Voltage	IMS switch P voltage	< 0.699999988 volts			>= 70 Fail Counts (25ms loop) out of 80 Sample Counts (25ms loop)	Type B, Two Trips
					Diagnostic monitor enable calibration	= 1 Boolean		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event			
					Ignition Voltage Lo	>= 7 Volts		
					Ignition Voltage Hi	< 9 Volts		
					Ignition Voltage within the above low / high thresholds for	<= 7.50E-02 seconds		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P182E	Internal Mode Switch Illegal Range	Range	= Illegal (SABCP= 00000 or SABCP= 10000) enumeration			>= 108 Fail Counts (25ms loop) out of 125 Sample Counts (25ms loop)	Type B, Two Trips
					Diagnostic monitor enable calibration	= 1 Boolean		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event			
					Ignition Voltage Lo	>= 7 Volts		
					Ignition Voltage Hi	< 9 Volts		
					Ignition Voltage within the above low / high thresholds for	<= 7.50E-02 seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P182F	Internal Mode Switch C Circuit High Voltage	IMS switch C voltage	> 2.380000114 volts			>= 70 Fail Counts (25ms loop) out of 80 Sample Counts (25ms loop)	Type B, Two Trips
					Diagnostic monitor enable calibration	= 1 Boolean		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event			
					Ignition Voltage Lo	>= 7 Volts		
					Ignition Voltage Hi	< 9 Volts		
					Ignition Voltage within the above low / high thresholds for	<= 7.50E-02 seconds		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P1838	Internal Mode Switch A Circuit High Voltage	IMS switch A voltage	> 2.380000114 volts			>= 70 Fail Counts (25ms loop) out of 80 Sample Counts (25ms loop)	Type B, Two Trips
					Diagnostic monitor enable calibration	= 1 Boolean		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event			
					Ignition Voltage Lo	>= 7 Volts		
					Ignition Voltage Hi	< 9 Volts		
					Ignition Voltage within the above low / high thresholds for	<= 7.50E-02 seconds		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required			Mil Illum.
Internal Mode Switch (IMS)	P1839	Internal Mode Switch C Circuit Low Voltage	IMS switch C voltage	< 0.699999988 volts					>=	70	Fail Counts (25ms loop)	Type B, Two Trips
									out of	80	Sample Counts (25ms loop)	
					Diagnostic monitor enable calibration	=	1	Boolean				
					Ignition Voltage Lo	>=	9	Volts				
					Ignition Voltage Hi	<=	31.999023	Volts				
					If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event							
					Ignition Voltage Lo	>=	7	Volts				
					Ignition Voltage Hi	<	9	Volts				
					Ignition Voltage within the above low / high thresholds for	<=	7.50E-02	seconds				
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None						
						ECM: None						
Internal Mode Switch (IMS)	P1840	Internal Mode Switch S Circuit Low Voltage	IMS switch S voltage	< 0.699999988 volts					>=	70	Fail Counts (25ms loop)	Type B, Two Trips
									out of	80	Sample Counts (25ms loop)	
					Diagnostic monitor enable calibration	=	1	Boolean				
					Ignition Voltage Lo	>=	9	Volts				
					Ignition Voltage Hi	<=	31.999023	Volts				
					If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event							
					Ignition Voltage Lo	>=	7	Volts				
					Ignition Voltage Hi	<	9	Volts				
					Ignition Voltage within the above low / high thresholds for	<=	7.50E-02	seconds				
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None						
						ECM: None						
Internal Mode Switch (IMS)	P1841	Internal Mode Switch S Circuit High Voltage	IMS switch S voltage	> 2.380000114 volts					>=	70	Fail Counts (25ms loop)	Type B, Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
							out of 80 Sample Counts (25ms loop)	
					Diagnostic monitor enable calibration = 1 Boolean Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.999023 Volts If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event Ignition Voltage Lo >= 7 Volts Ignition Voltage Hi < 9 Volts Ignition Voltage within the above low / high thresholds for <= 7.50E-02 seconds		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P18B5	Internal Mode Switch A Circuit Shorted	IMS switch A voltage	< 1.679999948 volts			>= 70 Fail Counts (25ms loop)	Type B, Two Trips
			IMS switch A voltage	> 0.966000021 volts			out of 80 Sample Counts (25ms loop)	
					Diagnostic monitor enable calibration = 1 Boolean Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.999023 Volts If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event Ignition Voltage Lo >= 7 Volts Ignition Voltage Hi < 9 Volts Ignition Voltage within the above low / high thresholds for <= 7.50E-02 seconds		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P18B6	Internal Mode Switch B Circuit Shorted	IMS switch B voltage	< 1.679999948 volts			>= 70 Fail Counts (25ms loop)	Type B, Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			IMS switch B voltage	> 0.966000021 volts			out of 80 Sample Counts (25ms loop)	
					Diagnostic monitor enable calibration	= 1 Boolean		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event			
					Ignition Voltage Lo	>= 7 Volts		
					Ignition Voltage Hi	< 9 Volts		
					Ignition Voltage within the above low / high thresholds for	<= 7.50E-02 seconds		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P18B7	Internal Mode Switch C Circuit Shorted	IMS switch C voltage	< 1.679999948 volts			>= 70 Fail Counts (25ms loop)	Type B, Two Trips
			IMS switch C voltage	> 0.966000021 volts			out of 80 Sample Counts (25ms loop)	
					Diagnostic monitor enable calibration	= 1 Boolean		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event			
					Ignition Voltage Lo	>= 7 Volts		
					Ignition Voltage Hi	< 9 Volts		
					Ignition Voltage within the above low / high thresholds for	<= 7.50E-02 seconds		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P18B8	Internal Mode Switch P Circuit Shorted	IMS switch P voltage	< 1.679999948 volts			>= 70 Fail Counts (25ms loop)	Type B, Two Trips
			IMS switch P voltage	> 0.966000021 volts			out of 80 Sample Counts (25ms loop)	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Diagnostic monitor enable calibration = 1 Boolean Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.999023 Volts If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event Ignition Voltage Lo >= 7 Volts Ignition Voltage Hi < 9 Volts Ignition Voltage within the above low / high thresholds for <= 7.50E-02 seconds		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P18B9	Internal Mode Switch S Circuit Shorted	IMS switch S voltage	< 1.679999948 volts			>= 70 Fail Counts (25ms loop)	Type B, Two Trips
			IMS switch S voltage	> 0.966000021 volts			out of 80 Sample Counts (25ms loop)	
					Diagnostic monitor enable calibration = 1 Boolean Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.999023 Volts If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event Ignition Voltage Lo >= 7 Volts Ignition Voltage Hi < 9 Volts Ignition Voltage within the above low / high thresholds for <= 7.50E-02 seconds		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P18BA	Internal Mode Switch A Stuck Off	Range	= Transition 30 (SABCP= 00001) enumeration			>= 108 Fail Counts (25ms loop)	Type B, Two Trips
			Switch A	≠ True (this key cycle) boolean			out of 125 Sample Counts (25ms loop)	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Diagnostic monitor enable calibration = 1 Boolean Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.999023 Volts If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event Ignition Voltage Lo >= 7 Volts Ignition Voltage Hi < 9 Volts Ignition Voltage within the above low / high thresholds for <= 7.50E-02 seconds Disable Conditions: MIL not Illuminated for DTC's: TCM: None ECM: None		
Internal Mode Switch (IMS)	P18BB	Internal Mode Switch B Stuck Off	Range = Transition 29 (SABCP= 00010) enumeration Prev Range = Transition 14 (SABCP= 10001)				>= 108 Fail Counts (25ms loop) out of 125 Sample Counts (25ms loop)	Type B, Two Trips
					Diagnostic monitor enable calibration = 1 Boolean Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.999023 Volts If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event Ignition Voltage Lo >= 7 Volts Ignition Voltage Hi < 9 Volts Ignition Voltage within the above low / high thresholds for <= 7.50E-02 seconds Disable Conditions: MIL not Illuminated for DTC's: TCM: None ECM: None		
Internal Mode Switch (IMS)	P18BC	Internal Mode Switch C Stuck Off	Range = Transition 27 (SABCP= 00100) enumeration				>= 108 Fail Counts (25ms loop) out of 125 Sample Counts (25ms loop)	Type B, Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Diagnostic monitor enable calibration = 1 Boolean Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.999023 Volts If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event Ignition Voltage Lo >= 7 Volts Ignition Voltage Hi < 9 Volts Ignition Voltage within the above low / high thresholds for <= 7.50E-02 seconds Disable Conditions: MIL not Illuminated for DTC's: TCM: None ECM: None		
Internal Mode Switch (IMS)	P18BD	Internal Mode Switch P Stuck Off	Range = Transition 23 (SABCP= 01000) enumeration Prev Range = Transition 11 (SABCP= 10100)				>= 108 Fail Counts (25ms loop) out of 125 Sample Counts (25ms loop)	Type B, Two Trips
					Diagnostic monitor enable calibration = 1 Boolean Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.999023 Volts If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event Ignition Voltage Lo >= 7 Volts Ignition Voltage Hi < 9 Volts Ignition Voltage within the above low / high thresholds for <= 7.50E-02 seconds Disable Conditions: MIL not Illuminated for DTC's: TCM: None ECM: None		
Internal Mode Switch (IMS)	P18BE	Internal Mode Switch S Stuck Off	Range = Drive 8 enumeration Prev Range = Transition 26 (SABCP= 00101)				>= 108 Fail Counts (25ms loop) out of 125 Sample Counts (25ms loop)	Type B, Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Switch A =	True (this key cycle) boolean				
			Switch S ≠	True (this key cycle) boolean				
					Diagnostic monitor enable calibration	= 1 Boolean		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event			
					Ignition Voltage Lo	>= 7 Volts		
					Ignition Voltage Hi	< 9 Volts		
					Ignition Voltage within the above low / high thresholds for	<= 7.50E-02 seconds		
			Disable Conditions:		MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P18C0	Internal Mode Switch B Stuck On	Range =	Drive 8 enumeration			>= 108 Fail Counts (25ms loop)	Type B, Two Trips
			Prev Range = Park for	>= 80 counts (25ms loop)			out of 125 Sample Counts (25ms loop)	
			Switch B ≠	False (this key cycle) boolean				
					Diagnostic monitor enable calibration	= 1 Boolean		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event			
					Ignition Voltage Lo	>= 7 Volts		
					Ignition Voltage Hi	< 9 Volts		
					Ignition Voltage within the above low / high thresholds for	<= 7.50E-02 seconds		
			Disable Conditions:		MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P18C1	Internal Mode Switch C Stuck On	Range =	Transition 20 (SABCP= 01011) enumeration			>= 108 Fail Counts (25ms loop)	Type B, Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Switch C	≠ False (this key cycle) boolean			out of 125 Sample Counts (25ms loop)	
					Diagnostic monitor enable calibration	= 1 Boolean		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event			
					Ignition Voltage Lo	>= 7 Volts		
					Ignition Voltage Hi	< 9 Volts		
					Ignition Voltage within the above low / high thresholds for	<= 7.50E-02 seconds		
					Disable Conditions:	MIL not Illuminated for DTC's: TCM: None ECM: None		
Internal Mode Switch (IMS)	P18C2	Internal Mode Switch P Stuck On	Range	= Transition 24 (SABCP= 00111) enumeration			>= 108 Fail Counts (25ms loop) out of 125 Sample Counts (25ms loop)	Type B, Two Trips
					Diagnostic monitor enable calibration	= 1 Boolean		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event			
					Ignition Voltage Lo	>= 7 Volts		
					Ignition Voltage Hi	< 9 Volts		
					Ignition Voltage within the above low / high thresholds for	<= 7.50E-02 seconds		
					Disable Conditions:	MIL not Illuminated for DTC's: TCM: None ECM: None		
Internal Mode Switch (IMS)	P18C3	Internal Mode Switch S Stuck On	Range	= Drive 7 enumeration			>= 108 Fail Counts (25ms loop)	Type B, Two Trips
			Prev Range = Park for	>= 80 counts (25ms loop)			out of 125 Sample Counts (25ms loop)	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Switch S	≠ False (this key cycle) boolean				
					Diagnostic monitor enable calibration = 1 Boolean Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.999023 Volts If ignition voltage was previously between the above low / high thresholds, then the following conditions apply once per auto start event Ignition Voltage Lo >= 7 Volts Ignition Voltage Hi < 9 Volts Ignition Voltage within the above low / high thresholds for <= 7.50E-02 seconds			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P1915	Internal Mode Switch Does Not Indicate Park/Neutral (P/N) During Start	Range	≠ Park Neutral Transition 1 (SABCP= 11110) Transition 2 (SABCP= 11101) Transition 4 (SABCP= 11011) Transition 17 (SABCP= 01110) Transition 18 (SABCP= 01101) Transition 21 (SABCP= 01010) Enumeration				Type B, Two Trips
			The following events must occur Sequentially Initial Engine speed	<= 50 RPM			>= 0.1 Enable Time (Sec)	
			Then Engine Speed Between Following Cals Engine Speed Lo Hist Engine Speed Hi Hist	>= 50 RPM <= 480 RPM			>= 0.06875 Enable Time (Sec)	
			Then Final Engine Speed Final Transmission Input Speed	>= 550 RPM >= 100 RPM			>= 1.25 Fail Time (Sec)	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					DTC has Ran this Key Cycle = FALSE Boolean Ignition Voltage Lo >= 6 V Ignition Voltage Hi <= 31.900391 V Ignition Voltage Hyst High (enables above this value) >= 5 V Ignition Voltage Hyst Low (disabled below this value) <= 2 V Transmission Output Speed <= 90 rpm P1915 Status is ≠ Test Failed This Key On or Fault Active		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0722, P0723 ECM: None		
Transmission Control Module (TCM)	P2534	Ignition Switch Run/Start Position Circuit Low	TCM Run crank active (based on voltage thresholds below) = FALSE Boolean Ignition Voltage High Hyst (run crank goes true when above this value) > 5 Volts Ignition Voltage Low Hyst (run crank goes false when below this value) < 2 Volts				>= 280 one fail count per 25 ms loop Out of 280 one sample count per 25 ms loop	Type A, One Trip
					Ignition Switch Run/Start Position Circuit Low diagnaotic enable calibration = 1 Boolean ECM run/crank active status available from serial data = TRUE Boolean ECM run/crank active status = TRUE Boolean Service mode $04 active and end of trip pocessing active = FALSE Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Transmission Control Module (TCM)	P2535	Ignition Switch Run/Start Position Circuit High	TCM Run crank active (based on voltage thresholds below) = TRUE Boolean Ignition Voltage High Hyst (run crank goes true when above this value) > 5 Volts Ignition Voltage Low Hyst (run crank goes false when below this value) < 2 Volts				>= 280 one fail count per 25 ms loop Out of 280 one sample count per 25 ms loop	Type A, One Trip
					Ignition Switch Run/Start Position Circuit High diagnaotic enable calibration = 1 Boolean ECM run/crank active status available from serial data = TRUE Boolean ECM run/crank active status = FALSE Boolean		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Service mode $04 active and end of trip pocessing active = FALSE Boolean			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
High Side Driver 2	P2670	Actuator Supply Voltage B Circuit Low	The HWIO reports a low voltage (ground short) error flag	= TRUE Boolean			>= 6 Fail Counts (6.25 msec continuous) out of 2395 Sample Counts (6.25 msec continuous)	Type A, One Trip
					actuator supply voltage circuit low enable calibration = 1 Service mode $04 active and end of trip pocessing active = FALSE Boolean P2670 Status is not = Test Failed This Key On or Fault Active P2670 Status is not = Test Failed This Key On or Fault Active Service Fast Learn (SFL) Mode = FALSE Boolean VBS Failsafe = True Boolean High Side Driver 2 On = True Boolean			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P2714	Pressure Control Solenoid D Stuck Off (clutch4/C23468)	absolute value (attained gear slip)	>= 400 RPM			>= 1.5 seconds when fail time reaches fail limit increment fail event count >= 3 event counts	Type A, One Trip
					clutch solenoid stuck on performance diagnostic monitor test deceleration limit not = TRUE boolean clutch solenoid stuck on performance diagnostic monitor test return to previous range not = TRUE boolean PRNDL State not = park enumeration PRNDL State not = neutral enumeration			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					while conditinos A and B and C are met, time down delay from clibration to 0.0 seconds					
					delay time calibration	=	0.5	seconds		
					A) neutral condition fault pending	=	FALSE	boolean		
					B) intrusive shift active	=	FALSE	boolean		
					C) range shift state	=	shift complete	enumeration		
					intrusive shift allowed	=	TRUE	boolean		
					intrusive shift active	=	FALSE	boolean		
					steady state pressure adapt in progress	=	FALSE	boolean		
					transmission output speed	>=	100	RPM		
					accelerator pedal position	>=	0.5004883	%		
					accelerator pedal position valid	=	TRUE	Boolean		
					engine speed valid	=	TRUE	Boolean		
					D or E					
					D) select battery voltage to enable diagnsotic monitor	=	0	Boolean		
					E) battery voltage	<=	31.999023	volts		
					E) battery voltage	>=	9	volts		
					E) battery voltage time	>=	0.1	sec		
					F or G					
					F) select ignition voltage to enable diagnsotic monitor	=	0	Boolean		
					G) Ignition Voltage	<=	31.999023	Volts		
					G) Ignition Voltage	>=	9	Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE	Boolean		
					Ignition voltage and SFL conditions met for	>=	0.1	Sec		
					Hydraulic System Pressurized	=	TRUE	Boolean		
					high side driver 1 enabled	=	TRUE	Boolean		
					high side driver 2 enabled	=	TRUE	Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P1824, P182A, P182B, P182C, P182D, P182E, P182F, P1838, P1839, P1840, P1841, P18B5, P18B6, P18B7, P18B8, P18B9, P18BA, P18BB, P18BC, P18BD, P18BE, P18BF, P18C0, P18C1, P18C2, P18C3, P1915, P2534 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E					

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
Variable Force Solenoid (VFS)	P2715	Pressure Control Solenoid D Stuck On (clutch4/C23468)	automatic transmission shift torque phase test (A) or inertia phase test (B) fail event count deceleration limited	>= see Table 32 in supporting documents fail event counts				Type A, One Trip
			automatic transmission shift torque phase test (A) or inertia phase test (B) fail event count no deceleration	>= see Table 33 in supporting documents fail event counts				
			A) absolute value (attained gear slip), fail during post torque phase of transmission automatic shift, before engine speed change, pull up or pull down occurs	<= 40 RPM				
			increment fail time when slip criteria met, fail time for power down shift				>= see Table 29 in supporting documents seconds	
			increment fail time when slip criteria met, fail time for up shift or closed throttle down shift deceleration limited				>= see Table 30 in supporting documents seconds	
			increment fail time when slip criteria met, fail time for up shift or closed throttle down shift no deceleration				>= see Table 31 in supporting documents seconds	
							when fail time reaches fail limit increment fail event count above	
			B) absolute value (command gear slip), fail during inertia phase of transmission automatic shift, engine speed change begins, pull up or pull down	>= 70 RPM				
			increment fail time when slip criteria met, fail time during shift deceleration limited				>= see Table 35 in supporting documents seconds	
			increment fail time when slip criteria met, fail time during shift no deceleration				>= see Table 36 in supporting documents seconds	
							when fail time reaches fail limit increment fail event count above	
					inertia phase test measured gear ratio	>= 0.558		
					inertia phase test measured gear ratio	<= 4.7150002		
					inertia phase test measured gear ratio time	>= 0.15 seconds		
					clutch test enabled	= see Table 10 in supporting documents boolean		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					post torque phase test engine torque hysteresis high enable for upshift or power on down shift	>=	see Table 11 in supporting documents	N*m		
					post torque phase test engine torque hysteresis low disable for upshift or power on down shift	>	see Table 12 in supporting documents	N*m		
					post torque phase test engine torque hysteresis high enable for closed throttle down shift	>=	see Table 13 in supporting documents	N*m		
					post torque phase test engine torque hysteresis low disable for closed throttle down shift	>	see Table 14 in supporting documents	N*m		
					inertia phase test engine torque hysteresis high enable for upshift or power on down shift	>=	see Table 15 in supporting documents	N*m		
					inertia phase test engine torque hysteresis low disable for upshift or power on down shift	>	see Table 16 in supporting documents	N*m		
					inertia phase test engine torque hysteresis high enable for closed throttle down shift	>=	see Table 17 in supporting documents	N*m		
					inertia phase test engine torque hysteresis low disable for closed throttle down shift	>	see Table 18 in supporting documents	N*m		
					off going clutch pressure	<=	see Table 37 in supporting documents	kPa		
					off going clutch pressure closed throttle down shift delay time	>=	see Table 5 in supporting documents	seconds		
					off going clutch pressure closed power down shift delay time	>=	see Table 41 in supporting documents	seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					off going clutch pressure up shift delay time	>=	see Table 62 in supporting documents	seconds		
					on coming clutch pressure for up shift	>=	see Table 8 in supporting documents	kPa		
					on coming clutch pressure for down shift	>=	see Table 7 in supporting documents	kPa		
					brake pedal position hysteresis high disable	>=	27.000427	%		
					brake pedal position hysteresis low enable	<=	25	%		
					absolute value (attained gear slip)	<=	40	RPM		
					shift type enable	=	see Table 45 in supporting documents	boolean		
					clucth solenoid stuck off intrusive shift request not	=	TRUE	boolean		
					traction control event test suspend not	=	TRUE	boolean		
					transmission output speed	>=	100	RPM		
					accelerator pedal position valid	=	TRUE	Boolean		
					engine speed valid D or E	=	TRUE	Boolean		
					D) select battery voltage to enable diagnsotic monitor	=	0	Boolean		
					E) battery voltage	<=	31.999023	volts		
					E) battery voltage	>=	9	volts		
					E) battery voltage time F or G	>=	0.1	sec		
					F) select ignition voltage to enable diagnsotic monitor	=	0	Boolean		
					G) Ignition Voltage	<=	31.999023	Volts		
					G) Ignition Voltage	>=	9	Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE	Boolean		
					Ignition voltage and SFL conditions met for	>=	0.1	Sec		
					Hydraulic System Pressurized	=	TRUE	Boolean		
					high side driver 1 enabled	=	TRUE	Boolean		
					high side driver 2 enabled	=	TRUE	Boolean		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P1824, P182A, P182B, P182C, P182D, P182E, P182F, P1838, P1839, P1840, P1841, P18B5, P18B6, P18B7, P18B8, P18B9, P18BA, P18BB, P18BC, P18BD, P18BE, P18BF, P18C0, P18C1, P18C2, P18C3, P1915, P2534 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Force Solenoid (VFS)	P2718	Pressure Control Solenoid D Control Circuit Open (clutch4/C23468 VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration	= TRUE Boolean		
					VFS source must be high side driver 1 or 2 or 3			
					high side driver VFS source is	= CeTSCR_e_HSD1 enumeration		
					high side driver VFS source enabled	= TRUE Boolean		
					controller power mode state is ignition or accessory	= TRUE Boolean		
					battery voltage in range for stability time			
					battery voltage stability time	>= 1 seconds		
					battery voltage	>= 8 volts		
					battery voltage	<= 32 Volts		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P2720	Pressure Control Solenoid D Control Circuit Low (clutch4/C23468 VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration	= TRUE Boolean		
					VFS source must be high side driver 1 or 2 or 3			
					high side driver VFS source is	= CeTSCR_e_HSD1 enumeration		
					high side driver VFS source enabled	= TRUE Boolean		
					controller power mode state is ignition or accessory	= TRUE Boolean		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					battery voltage in range for stability time battery voltage stability time >= 1 seconds battery voltage >= 8 volts battery voltage <= 32 Volts			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P2721	Pressure Control Solenoid D Control Circuit High (clutch4/C23468 VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration = TRUE Boolean VFS source must be high side driver 1 or 2 or 3 high side driver VFS source is = CeTSCR_e_HSD1 enumeration high side driver VFS source enabled = TRUE Boolean controller power mode state is ignition or accessory = TRUE Boolean battery voltage in range for stability time battery voltage stability time >= 1 seconds battery voltage >= 8 volts battery voltage <= 32 Volts			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P2723	Pressure Control Solenoid E Stuck Off (clutch5/C45678R)	absolute value (attained gear slip)	>= 400 RPM			>= 1.5 seconds when fail time reaches fail limit increment fail event count >= 3 event counts	Type A, One Trip
					clutch solenoid stuck on performance diagnostic monitor test deceleration limit not = TRUE boolean clutch solenoid stuck on performance diagnostic monitor test return to previous range not = TRUE boolean PRNDL State not = park enumeration PRNDL State not = neutral enumeration			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					while conditinos A and B and C are met, time down delay from clibration to 0.0 seconds					
					delay time calibration	=	0.5	seconds		
					A) neutral condition fault pending	=	FALSE	boolean		
					B) intrusive shift active	=	FALSE	boolean		
					C) range shift state	=	shift complete	enumeration		
					intrusive shift allowed	=	TRUE	boolean		
					intrusive shift active	=	FALSE	boolean		
					steady state pressure adapt in progress	=	FALSE	boolean		
					transmission output speed	>=	100	RPM		
					accelerator pedal position	>=	0.5004883	%		
					accelerator pedal position valid	=	TRUE	Boolean		
					engine speed valid	=	TRUE	Boolean		
					D or E					
					D) select battery voltage to enable diagnsotic monitor	=	0	Boolean		
					E) battery voltage	<=	31.999023	volts		
					E) battery voltage	>=	9	volts		
					E) battery voltage time	>=	0.1	sec		
					F or G					
					F) select ignition voltage to enable diagnsotic monitor	=	0	Boolean		
					G) Ignition Voltage	<=	31.999023	Volts		
					G) Ignition Voltage	>=	9	Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE	Boolean		
					Ignition voltage and SFL conditions met for	>=	0.1	Sec		
					Hydraulic System Pressurized	=	TRUE	Boolean		
					high side driver 1 enabled	=	TRUE	Boolean		
					high side driver 2 enabled	=	TRUE	Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P1824, P182A, P182B, P182C, P182D, P182E, P182F, P1838, P1839, P1840, P1841, P18B5, P18B6, P18B7, P18B8, P18B9, P18BA, P18BB, P18BC, P18BD, P18BE, P18BF, P18C0, P18C1, P18C2, P18C3, P1915, P2534 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E					

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
Variable Force Solenoid (VFS)	P2724	Pressure Control Solenoid E Stuck On (clutch5/C45678R)	automatic transmission shift torque phase test (A) or inertia phase test (B) fail event count deceleration limited	>= see Table 32 in supporting documents fail event counts				Type A, One Trip
			automatic transmission shift torque phase test (A) or inertia phase test (B) fail event count no deceleration	>= see Table 33 in supporting documents fail event counts				
			A) absolute value (attained gear slip), fail during post torque phase of transmission automatic shift, before engine speed change, pull up or pull down occurs	<= 40 RPM				
			increment fail time when slip criteria met, fail time for power down shift				>= see Table 29 in supporting documents seconds	
			increment fail time when slip criteria met, fail time for up shift or closed throttle down shift deceleration limited				>= see Table 30 in supporting documents seconds	
			increment fail time when slip criteria met, fail time for up shift or closed throttle down shift no deceleration				>= see Table 31 in supporting documents seconds	
							when fail time reaches fail limit increment fail event count above	
			B) absolute value (command gear slip), fail during inertia phase of transmission automatic shift, engine speed change begins, pull up or pull down	>= 70 RPM				
			increment fail time when slip criteria met, fail time during shift deceleration limited				>= see Table 35 in supporting documents seconds	
			increment fail time when slip criteria met, fail time during shift no deceleration				>= see Table 36 in supporting documents seconds	
							when fail time reaches fail limit increment fail event count above	
					inertia phase test measured gear ratio	>= 0.558		
					inertia phase test measured gear ratio	<= 4.7150002		
					inertia phase test measured gear ratio time	>= 0.15 seconds		
					clutch test enabled	= see Table 10 in supporting documents boolean		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					post torque phase test engine torque hysteresis high enable for upshift or power on down shift	>=	see Table 11 in supporting documents	N*m		
					post torque phase test engine torque hysteresis low disable for upshift or power on down shift	>	see Table 12 in supporting documents	N*m		
					post torque phase test engine torque hysteresis high enable for closed throttle down shift	>=	see Table 13 in supporting documents	N*m		
					post torque phase test engine torque hysteresis low disable for closed throttle down shift	>	see Table 14 in supporting documents	N*m		
					inertia phase test engine torque hysteresis high enable for upshift or power on down shift	>=	see Table 15 in supporting documents	N*m		
					inertia phase test engine torque hysteresis low disable for upshift or power on down shift	>	see Table 16 in supporting documents	N*m		
					inertia phase test engine torque hysteresis high enable for closed throttle down shift	>=	see Table 17 in supporting documents	N*m		
					inertia phase test engine torque hysteresis low disable for closed throttle down shift	>	see Table 18 in supporting documents	N*m		
					off going clutch pressure	<=	see Table 37 in supporting documents	kPa		
					off going clutch pressure closed throttle down shift delay time	>=	see Table 6 in supporting documents	seconds		
					off going clutch pressure closed power down shift delay time	>=	see Table 42 in supporting documents	seconds		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					off going clutch pressure up shift delay time	>=	see Table 63 in supporting documents	seconds		
					on coming clutch pressure for up shift	>=	see Table 8 in supporting documents	kPa		
					on coming clutch pressure for down shift	>=	see Table 7 in supporting documents	kPa		
					brake pedal position hysteresis high disable	>=	27.000427	%		
					brake pedal position hysteresis low enable	<=	25	%		
					absolute value (attained gear slip)	<=	40	RPM		
					shift type enable	=	see Table 45 in supporting documents	boolean		
					clucth solenoid stuck off intrusive shift request not	=	TRUE	boolean		
					traction control event test suspend not	=	TRUE	boolean		
					transmission output speed	>=	100	RPM		
					accelerator pedal position valid	=	TRUE	Boolean		
					engine speed valid D or E	=	TRUE	Boolean		
					D) select battery voltage to enable diagnsotic monitor	=	0	Boolean		
					E) battery voltage	<=	31.999023	volts		
					E) battery voltage	>=	9	volts		
					E) battery voltage time F or G	>=	0.1	sec		
					F) select ignition voltage to enable diagnsotic monitor	=	0	Boolean		
					G) Ignition Voltage	<=	31.999023	Volts		
					G) Ignition Voltage	>=	9	Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE	Boolean		
					Ignition voltage and SFL conditions met for	>=	0.1	Sec		
					Hydraulic System Pressurized	=	TRUE	Boolean		
					high side driver 1 enabled	=	TRUE	Boolean		
					high side driver 2 enabled	=	TRUE	Boolean		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P1824, P182A, P182B, P182C, P182D, P182E, P182F, P1838, P1839, P1840, P1841, P18B5, P18B6, P18B7, P18B8, P18B9, P18BA, P18BB, P18BC, P18BD, P18BE, P18BF, P18C0, P18C1, P18C2, P18C3, P1915, P2534 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Force Solenoid (VFS)	P2727	Pressure Control Solenoid E Control Circuit Open (clutch5/C45678 VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration	= TRUE Boolean		
					VFS source must be high side driver 1 or 2 or 3			
					high side driver VFS source is	= CeTSCR_e_HSD1 enumeration		
					high side driver VFS source enabled	= TRUE Boolean		
					controller power mode state is ignition or accessory	= TRUE Boolean		
					battery voltage in range for stability time			
					battery voltage stability time	>= 1 seconds		
					battery voltage	>= 8 volts		
					battery voltage	<= 32 Volts		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P2729	Pressure Control Solenoid E Control Circuit Low (clutch5/C45678 VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration	= TRUE Boolean		
					VFS source must be high side driver 1 or 2 or 3			
					high side driver VFS source is	= CeTSCR_e_HSD1 enumeration		
					high side driver VFS source enabled	= TRUE Boolean		
					controller power mode state is ignition or accessory	= TRUE Boolean		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					battery voltage in range for stability time battery voltage stability time >= 1 seconds battery voltage >= 8 volts battery voltage <= 32 Volts			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P2730	Pressure Control Solenoid E Control Circuit High (clutch5/C45678 VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration = TRUE Boolean VFS source must be high side driver 1 or 2 or 3 high side driver VFS source is = CeTSCR_e_HSD1 enumeration high side driver VFS source enabled = TRUE Boolean controller power mode state is ignition or accessory = TRUE Boolean battery voltage in range for stability time battery voltage stability time >= 1 seconds battery voltage >= 8 volts battery voltage <= 32 Volts			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P2736	Pressure Control Solenoid F Control Circuit Open (line pressure VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration = TRUE Boolean VFS source must be high side driver 1 or 2 or 3 high side driver VFS source is = CeTSCR_e_HSD2 enumeration high side driver VFS source enabled = TRUE Boolean controller power mode state is ignition or accessory = TRUE Boolean battery voltage in range for stability time battery voltage stability time >= 1 seconds battery voltage >= 8 volts			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					battery voltage	<= 32 Volts		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P2738	Pressure Control Solenoid F Control Circuit Low (line pressure VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration	= TRUE Boolean		
					VFS source must be high side driver 1 or 2 or 3			
					high side driver VFS source is	= CeTSCR_e_HSD2 enumeration		
					high side driver VFS source enabled	= TRUE Boolean		
					controller power mode state is ignition or accessory	= TRUE Boolean		
					battery voltage in range for stability time			
					battery voltage stability time	>= 1 seconds		
					battery voltage	>= 8 volts		
					battery voltage	<= 32 Volts		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P2739	Pressure Control Solenoid F Control Circuit High (line pressure VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration	= TRUE Boolean		
					VFS source must be high side driver 1 or 2 or 3			
					high side driver VFS source is	= CeTSCR_e_HSD2 enumeration		
					high side driver VFS source enabled	= TRUE Boolean		
					controller power mode state is ignition or accessory	= TRUE Boolean		
					battery voltage in range for stability time			
					battery voltage stability time	>= 1 seconds		
					battery voltage	>= 8 volts		
					battery voltage	<= 32 Volts		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
VFS characterization	P27A7	VFS characterization	clutch1/CB1278R pressure control solenoid characterization not programmed	= TRUE Boolean				Type A, One Trip
					manufacture enable counter	= 0 counts		
					memory type updated	= non-volatile memory		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
VFS characterization	P27A8	VFS characterization	clutch2/CB12345R pressure control solenoid characterization not programmed	= TRUE Boolean				Type A, One Trip
					manufacture enable counter	= 0 counts		
					memory type updated	= non-volatile memory		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
VFS characterization	P27A9	VFS characterization	clutch3/C13567 pressure control solenoid characterization not programmed	= TRUE Boolean				Type A, One Trip
					manufacture enable counter	= 0 counts		
					memory type updated	= non-volatile memory		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
VFS characterization	P27AA	VFS characterization	clutch4/C23468 pressure control solenoid characterization not programmed	= TRUE Boolean				Type A, One Trip
					manufacture enable counter	= 0 counts		
					memory type updated	= non-volatile memory		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
VFS characterization	P27AB	VFS characterization	clutch5/C45678R pressure control solenoid characterization not programmed	= TRUE Boolean				Type A, One Trip
					manufacture enable counter	= 0 counts		
					memory type updated	= non-volatile memory		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: None ECM: None		
VFS characterization	P27AC	VFS characterization	line pressure control solenoid characterization not programmed	= TRUE Boolean				Type A, One Trip
					manufacture enable counter	= 0 counts		
					memory type updated	= non-volatile memory		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: None ECM: None		
VFS characterization	P27AD	VFS characterization	TCC pressure control solenoid characterization not programmed	= TRUE Boolean				Type A, One Trip
					manufacture enable counter	= 0 counts		
					memory type updated	= non-volatile memory		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: None ECM: None		
Torque Converter Clutch (TCC)	P2808	TCC System Stuck OFF	TCC Pressure	>= 750 Kpa			>= 2 Enable Time (Sec)	Type B, Two Trips
			TCC capacity	>= 0 %			>= 0 Enable Time (Sec)	
			Either Condition (A) or (B) Must be Met					
			(A) TCC Slip Error @ TCC On Mode	>= see Table 1 in Supporting Documents RPM			>= 4 Fail Time (Sec)	
			(B) TCC Slip @ Lock On Mode	>= 130 RPM			>= 4 Fail Time (Sec)	
			If Above Conditions Have been Met, and Fail Timer Expired, Increment Fail Counter				>= 3 TCC Stuck Off Fail Counter	
					TCC Mode	= On or Lock		
					TCC system stuck off diagnostic monitor enable c	= 1		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					default valve state = high (active)			
					absolute value of attained gear slip >= 25 RPM			
					attained gear >= CeCGSR_e_CR_Fourth			
					range shift state = shift complete			
					Hydraulic System Pressurized = TRUE Boolean			
					battery voltage <= 31.999023 volts			
					battery voltage >= 9 volts			
					battery voltage time >= 0.1 sec			
					Ignition Voltage <= 31.999023 Volts			
					Ignition Voltage >= 9 Volts			
					Service Fast Learn (SFL) Mode VBS Failsafe = FALSE Boolean			
					Ignition voltage and SFL conditions met for >= 0.1 Sec			
					Engine Torque >= 50 N*m			
					Engine Torque <= 8191.75 N*m			
					Throttle Position >= 8.0001831 Pct			
					Throttle Position <= 99.998474 Pct			
					Transmission Fluid Temperature >= -6.65625 ºC			
					Transmission Fluid Temperature <= 130 ºC			
					PTO Not Active = TRUE Boolean			
					Engine Torque Signal Valid = TRUE Boolean			
					Accelerator Pedal Position Signal Valid = TRUE Boolean			
					P2808 Status is ≠ Test Failed This Key On			
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: P0716, P0717, P07BF, P07C0, P0722, P0723, P077C, P077D, P2808, P2812, P2814, P2815 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Torque Converter Clutch (TCC)	P2809	TCC System Stuck ON	TCC Slip Speed	>= -50 RPM				Type A, One Trip
			TCC Slip Speed	<= 30 RPM				
			If Above Conditions Have been Met, and Fail Timer Expired, Increment Fail Counter				>= 1.5 Fail Time (Sec) >= 6 Fail Counter	
					TCC Mode	= Off		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					default valve state	=	high (active)			
					default valve state previous	=	low to high			
					set default valve state timer	=	see Table 24 in Supporting Documents	seconds		
					default valve state timer times down to zero (0.0) when default valve state not	=	high (active)			
					default valve state timer times down to zero (0.0) when default valve state previous not	=	low to high			
					either A or B ro C must be met					
					A) default valve state	=	low to high			
					B) default valve state timer	>	0	seconds		
					C) low TCC slip fail timer	>	0	seconds		
					clutch solenoid stuck off performance (neutral) test active	=	FALSE	Boolean		
					clutch solenoid stuck on performance (tie-up) test active	=	FALSE	Boolean		
					TCC Slip Speed	<=	85	RPM		
					derivative TCC slip speed	<=	see Table 25 in Supporting Documents	RPM/sec		
					TCC system stuck on diagnostic monitor enable c	=	1			
					Engine Speed	<=	5500	RPM		
					Engine Speed	>=	400	RPM		
					Vehicle Speed HI	<=	45	KPH		
					Engine Torque	<=	800	Nm		
					Engine Torque	>=	55	Nm		
					Current Range	≠	Neutral	Range		
					Current Range	≠	Reverse	Range		
					Transmission Fluid Temperature	<=	130	ºC		
					Transmission Fluid Temperature	>=	-6.65625	ºC		
					Throttle Position Hyst High AND	>=	3.9993286	Pct		
					Max Vehicle Speed to Meet Throttle Enable	<=	8	KPH		
					Once Hyst High has been met, the enable will remain while Throttle Position	>=	0.9994507	Pct		
					Disable for Throttle Position	>=	94.999695	Pct		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required			Mil Illum.
					Disable if PTO active and value true	=	1					
					enable if tap up/down mode is false or tap up/down TCC calibration value is false	=	0	Boolean				
					enable if manual up/down mode is false or manual up/down TCC calibration value is false	=	0	Boolean				
					enable if misfire disengage TCC is false or value TCC misfire calibration value is false	=	0	Boolean				
					4 Wheel Drive Low Active	=	FALSE	Boolean				
					battery voltage	<=	31.999023	volts				
					battery voltage	>=	9	volts				
					battery voltage time	>=	0.1	sec				
					Ignition Voltage	<=	31.999023	Volts				
					Ignition Voltage	>=	9	Volts				
					Service Fast Learn (SFL) Mode	=	FALSE	Boolean				
					VBS Failsafe Ignition voltage and SFL conditions met for	>=	0.1	Sec				
					Engine Torque Signal Valid	=	TRUE	Boolean				
					Throttle Position Signal Valid	=	TRUE	Boolean				
					P0742 Status is	≠	Test Failed This Key On					
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P07BF, P07C0, P0722, P0723, P077C, P077D, P2809, P2812, P2814, P2815 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E							
Variable Force Solenoid (VFS)	P2812	Pressure Control Solenoid G Control Circuit Open (TCC pressure VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean					>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)			Type A, One Trip
					diagnostic monitor enable calibration	=	TRUE	Boolean				
					VFS source must be high side driver 1 or 2 or 3 high side driver VFS source is	=	CeTSCR_e_HSD2	enumeration				
					high side driver VFS source enabled	=	TRUE	Boolean				
					controller power mode state is ignition or accessory	=	TRUE	Boolean				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					battery voltage in range for stability time battery voltage stability time >= 1 seconds battery voltage >= 8 volts battery voltage <= 32 Volts			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P2814	Pressure Control Solenoid G Control Circuit Low (TCC pressure VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration = TRUE Boolean VFS source must be high side driver 1 or 2 or 3 high side driver VFS source is = CeTSCR_e_HSD2 enumeration high side driver VFS source enabled = TRUE Boolean controller power mode state is ignition or accessory = TRUE Boolean battery voltage in range for stability time battery voltage stability time >= 1 seconds battery voltage >= 8 volts battery voltage <= 32 Volts			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Force Solenoid (VFS)	P2815	Pressure Control Solenoid G Control Circuit High (TCC pressure VFS)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration = TRUE Boolean VFS source must be high side driver 1 or 2 or 3 high side driver VFS source is = CeTSCR_e_HSD2 enumeration high side driver VFS source enabled = TRUE Boolean controller power mode state is ignition or accessory = TRUE Boolean battery voltage in range for stability time battery voltage stability time >= 1 seconds battery voltage >= 8 volts			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required			Mil Illum.
					battery voltage	<=	32	Volts				
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None						
default valve on/off valve solenoid	P2817	Hydraulic on/off Control Solenoid H Stuck Off (default valve on/off solenoid)	absolute value (attained gear slip) 4th gear commanded	>= 400 RPM	6th gear intrusive shift command when fail time reaches fail limit				>=	1.5	seconds	Type A, One Trip
					attained gear when intrusive 6th gear command	=	3rd					
					attained gear slip 3rd gear	<=	75	RPM				
					3rd gear attained time	>=	0.25	seconds				
					intrusive 6th gear commanded event count	>=	2	counts				
									>=	2	counts	
					clutch solenoid stuck on performance diagnostic monitor test deceleration limit not	=	TRUE	boolean				
					clutch solenoid stuck on performance diagnostic monitor test return to previous range not	=	TRUE	boolean				
					PRNDL State not	=	park	enumeration				
					PRNDL State not	=	neutral	enumeration				
					while conditinos A and B and C are met, time down delay from clibration to 0.0 seconds							
					delay time calibration	=	0.5	seconds				
					A) neutral condition fault pending	=	FALSE	boolean				
					B) intrusive shift active	=	FALSE	boolean				
					C) range shift state	=	shift complete	enumeration				
					intrusive shift allowed	=	TRUE	boolean				
					intrusive shift active	=	FALSE	boolean				
					steady state pressure adapt in progress	=	FALSE	boolean				
					transmission output speed	>=	100	RPM				
					accelerator pedal position	>=	0.5004883	%				
					accelerator pedal position valid	=	TRUE	Boolean				
					engine speed valid D or E	=	TRUE	Boolean				
					D) select battery voltage to enable diagnsotic monitor	=	0	Boolean				
					E) battery voltage	<=	31.999023	volts				
					E) battery voltage	>=	9	volts				
					E) battery voltage time F or G	>=	0.1	sec				
					F) select ignition voltage to enable diagnsotic monitor	=	0	Boolean				
					G) Ignition Voltage	<=	31.999023	Volts				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required			Mil Illum.
					G) Ignition Voltage	>=	9	Volts				
					Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE	Boolean				
					Ignition voltage and SFL conditions met for	>=	0.1	Sec				
					Hydraulic System Pressurized	=	TRUE	Boolean				
					high side driver 1 enabled	=	TRUE	Boolean				
					high side driver 2 enabled	=	TRUE	Boolean				
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P1824, P182A, P182B, P182C, P182D, P182E, P182F, P1838, P1839, P1840, P1841, P18B5, P18B6, P18B7, P18B8, P18B9, P18BA, P18BB, P18BC, P18BD, P18BE, P18BF, P18C0, P18C1, P18C2, P18C3, P1915, P2534 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E							
default valve on/off valve solenoid	P2818	Hydraulic on/off Control Solenoid H Stuck On (default valve on/off solenoid)	TCC slip speed	<= 6 RPM					>= 0.5 seconds			Type B, Two Trips
									>= 3 counts			
									>= 5 counts			
					delay time after TCC intrusive command pressure reaches intrusive value	>=	see Table 28 in supporting documents	seconds				
					TCC intrusive command pressure	>=	600	kPa				
					test delay timer calibration test delay timer times down from calibration to zero (0.0) when all of the following conditinos are met	=	0.5	seconds				
					engine speed	>=	400	RPM				
					engine speed	<=	900	RPM				
					transmission temperature	>=	0	ºC				
					transmission temperature	<=	40	ºC				
					PRNDL state	=	park	enumeration				
					Hydraulic System Pressurized	=	TRUE	Boolean				
					battery voltage	<=	31.999023	volts				
					battery voltage	>=	9	volts				
					battery voltage time	>=	0.1	sec				
					Ignition Voltage	<=	31.999023	Volts				
					Ignition Voltage	>=	9	Volts				
					Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE	Boolean				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Ignition voltage and SFL conditions met for	>= 0.1 Sec		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P07BF, P07C0, P2812, P2814, P2815 ECM: none		
default valve on/off solenoid	P281D	Pressure Control Solenoid H Control Circuit Low (default valve on/off solenoid)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration	= TRUE Boolean		
					VFS source must be high side driver 1 or 2 or 3			
					high side driver VFS source is	= CeTSCR_e_HSD1 enumeration		
					high side driver VFS source enabled	= TRUE Boolean		
					controller power mode state is ignition or accessory	= TRUE Boolean		
					battery voltage in range for stability time			
					battery voltage stability time	>= 1 seconds		
					battery voltage	>= 8 volts		
					battery voltage	<= 32 Volts		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
default valve on/off solenoid	P281E	Pressure Control Solenoid H Control Circuit High (default valve on/off solenoid)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration	= TRUE Boolean		
					VFS source must be high side driver 1 or 2 or 3			
					high side driver VFS source is	= CeTSCR_e_HSD1 enumeration		
					high side driver VFS source enabled	= TRUE Boolean		
					controller power mode state is ignition or accessory	= TRUE Boolean		
					battery voltage in range for stability time			
					battery voltage stability time	>= 1 seconds		
					battery voltage	>= 8 volts		
					battery voltage	<= 32 Volts		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
clutch2/CB12345R boost valve on/off solenoid	P2824	Pressure Control Solenoid J Control Circuit High (clutch2/CB12345R boost valve on/off solenoid)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration VFS source must be high side driver 1 or 2 or 3 high side driver VFS source is high side driver VFS source enabled controller power mode state is ignition or accessory battery voltage in range for stability time battery voltage stability time battery voltage battery voltage	= TRUE Boolean = CeTSCR_e_HSD1 enumeration = TRUE Boolean = TRUE Boolean >= 1 seconds >= 8 volts <= 32 Volts		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
clutch2/CB12345R boost valve on/off solenoid	P2826	Pressure Control Solenoid J Control Circuit Low (clutch2/CB12345R boost valve on/off solenoid)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration VFS source must be high side driver 1 or 2 or 3 high side driver VFS source is high side driver VFS source enabled controller power mode state is ignition or accessory battery voltage in range for stability time battery voltage stability time battery voltage battery voltage	= TRUE Boolean = CeTSCR_e_HSD2 enumeration = TRUE Boolean = TRUE Boolean >= 1 seconds >= 8 volts <= 32 Volts		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
clutch2/CB12345R boost valve on/off solenoid	P2827	Pressure Control Solenoid J Control Circuit High (clutch2/CB12345R boost valve on/off solenoid)	The HWIO reports open crcuit error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.5 Sample Time (Sec)	Type A, One Trip
					diagnostic monitor enable calibration	= TRUE Boolean		
					VFS source must be high side driver 1 or 2 or 3			
					high side driver VFS source is	= CeTSCR_e_HSD2 enumeration		
					high side driver VFS source enabled	= TRUE Boolean		
					controller power mode state is ignition or accessory	= TRUE Boolean		
					battery voltage in range for stability time			
					battery voltage stability time	>= 1 seconds		
					battery voltage	>= 8 volts		
					battery voltage	<= 32 Volts		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Communication	U0073	Controller Area Network Bus Communication Error	CAN Hardware Circuitry Detects a Bus Voltage Error (CAN bus off)	= TRUE Boolean			>= 62 counts	Type A, One Trip
			Bus off delay time	>= 0.1125 sec			>= 70 counts	
					all conditions A and B and C below must occur for stabilization time			
					Bus Stabilization time	>= 3 seconds		
					A) Service mode $04 active and end of trip pocessing active	= FALSE Boolean		
					A) normal serial data communication enabled	= TRUE Boolean		
					A) P0073 status not	= fault active		
					B) secured controller or emission critical then use ignition voltage	= CeCANR_e_OBDII_Dsbl Boolean		
					B) secureed controller or emission critical Ignition Voltage	>= 11 volts		
					B) Power Mode	= Run		
					B) secured controller or emission critical then use controller power mode	= CeCANR_e_OBDII_Dsbl Boolean		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required		Mil Illum.
					B) Power Mode	=	Run				
					C) ignition off enable	=	1	Boolean			
					C) Power Mode	=	accessory				
					C) battery voltage	>=	11	volts			
					all conditions A and B below must occur						
					A) post clear code timer	>=	0.15	seconds			
					B) when Propulsion System Active use low voltage check	=	FALSE	Boolean			
					NOT in low voltage engine crank condition defined by A or B below during, for low voltage mode time						
					low voltage mode time	>=	2.50E-02	seconds			
					A) low voltage mode hysteresis time	<=	0.1	seconds			
					B) ignition voltage, set low voltage mode	<=	6.4091797	volts			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None					
Communication	U0100	Lost Communications with ECM (Engine Control Module)	TCM Rx message missed frame		fail times are caculated based on Rx message enable calibration set to CeCANR_e_BusA_ECM		Tx controller				Type A, One Trip
			TCM Rx frame message missed frame	= TRUE Boolean	TCM Rx frame calibration enabled	≠	see Table 64 in supporting documents	enumeration	>= see Table 65 in supporting documents	seconds	
					Frame recovery stabilization delay	>=	0.5	seconds			
					all conditions A and B and C below must occur for stabilization time						
					Bus Stabilization time	>=	3	seconds			
					A) Service mode $04 active and end of trip pocessing active	=	FALSE	Boolean			
					A) normal serial data communication enabled	=	TRUE	Boolean			
					A) P0073 status not	=	fault active				
					B) secured controller or emission critical then use ignition voltage	=	CeCANR_e_OBDII_Dsbl	Boolean			
					B) secureed controller or emission critical Ignition Voltage	>=	11	volts			
					B) Power Mode	=	Run				
					B) secured controller or emission critical then use controller power mode	=	CeCANR_e_OBDII_Dsbl	Boolean			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required		Mil Illum.
					B) Power Mode	=	Run				
					C) ignition off enable	=	1	Boolean			
					C) Power Mode	=	accessory				
					C) battery voltage	>=	11	volts			
					all conditions A and B below must occur						
					A) post clear code timer	>=	0.15	seconds			
					B) when Propulsion System Active use low voltage check	=	FALSE	Boolean			
					NOT in low voltage engine crank condition defined by A or B below during, for low voltage mode time						
					low voltage mode time	>=	2.50E-02	seconds			
					A) low voltage mode hysteresis time	<=	0.1	seconds			
					B) ignition voltage, set low voltage mode	<=	6.4091797	volts			
					U0100 fault status is not	=	fault active				
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: U0073 ECM: None					
Communication	U0121	Loss Communications with ABS (Anti-lock Brake System)	TCM Rx message missed frame		fail times are caculated based on the following Rx messages enable calibration set to CeCANR_e_BusA_ABS		Tx controller				Special No MIL
			TCM Rx frame message missed frame	= TRUE Boolean	TCM Rx frame calibration enabled	≠	see Table 64 in supporting documents	enumeration	>= see Table 65 in supporting documents	seconds	
					Frame recovery stabilization delay	>=	0.5	seconds			
					all conditions A and B and C below must occur for stabilization time						
					Bus Stabilization time	>=	3	seconds			
					A) Service mode $04 active and end of trip pocessing active	=	FALSE	Boolean			
					A) normal serial data communication enabled	=	TRUE	Boolean			
					A) P0073 status not	=	fault active				
					B) secured controller or emission critical then use ignition voltage	=	CeCANR_e_OBDII_Dsbl	Boolean			
					B) secureed controller or emission critical Ignition Voltage	>=	11	volts			
					B) Power Mode	=	Run				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required			Mil Illum.
					B) secured controller or emission critical then use controller power mode	=	CeCANR_e_OBDII_Dsbl	Boolean				
					B) Power Mode	=	Run					
					C) ignition off enable	=	1	Boolean				
					C) Power Mode	=	accessory					
					C) battery voltage	>=	11	volts				
					all conditions A and B below must occur							
					A) post clear code timer	>=	0.15	seconds				
					B) when Propulsion System Active use low voltage check	=	FALSE	Boolean				
					NOT in low voltage engine crank condition defined by A or B below during, for low voltage mode time							
					low voltage mode time	>=	2.50E-02	seconds				
					A) low voltage mode hysteresis time	<=	0.1	seconds				
					B) ignition voltage, set low voltage mode	<=	6.4091797	volts				
					U0121 fault status is not	=	fault active					
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: U0073 ECM: None						
Communication	U0140	Loss Communications with BCM (Body Control Module)	TCM Rx message missed frame		fail times are caculated based on the following Rx messages enable calibration set to CeCANR_e_BusA_BCM		Tx controller					Special No MIL
			TCM Rx frame message missed frame	= TRUE Boolean	TCM Rx frame calibration enabled	≠	see Table 64 in supporting documents	enumeration	>=	see Table 65 in supporting documents	seconds	
					Frame recovery stabilization delay	>=	0.5	seconds				
					all conditions A and B and C below must occur for stabilization time							
					Bus Stabilization time	>=	3	seconds				
					A) Service mode $04 active and end of trip pocessing active	=	FALSE	Boolean				
					A) normal serial data communication enabled	=	TRUE	Boolean				
					A) P0073 status not	=	fault active					
					B) secured controller or emission critical then use ignition voltage	=	CeCANR_e_OBDII_Dsbl	Boolean				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					B) secureed controller or emission critical Ignition Voltage	>=	11	volts		
					B) Power Mode	=	Run			
					B) secured controller or emission critical then use controller power mode	=	CeCANR_ e_OBDII_D sbl	Boolean		
					B) Power Mode	=	Run			
					C) ignition off enable	=	1	Boolean		
					C) Power Mode	=	accessory			
					C) battery voltage	>=	11	volts		
					all conditions A and B below must occur					
					A) post clear code timer	>=	0.15	seconds		
					B) when Propulsion System Active use low voltage check	=	FALSE	Boolean		
					NOT in low voltage engine crank condition defined by A or B below during, for low voltage mode time					
					low voltage mode time	>=	2.50E-02	seconds		
					A) low voltage mode hysteresis time	<=	0.1	seconds		
					B) ignition voltage, set low voltage mode	<=	6.4091797	volts		
					U0140 fault status is not	=	fault active			

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
Transmission Control Module (TCM)	C124F	The lateral accleration sensor signal failed at a low voltge	hardware configuration Lateral accleration sensor raw signal hardware configuration Lateral accleration magnitude	= CeLATR_e_VoltageDirectPrOp <= -3.849999905 g's = CeLATR_e_VoltageDirectPrOp >= -3.849999905 g's	transient delay timer	>= 30 Sec	>= 75 Sec out of 120 Sec	Special No MIL
					Lateral acceleration low voltage diagnostic enable calibration	= 1		
					Battery Voltage	<= 31.999023 Volts		
					Battery Voltage	>= 9 Volts		
					Battery voltage is within the allowable limits for	>= 0.1 Sec		
					Ignition Voltage	<= 31.999023 Volts		
					Ignition Voltage	>= 9 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Ignition voltage and SFL conditions met for	>= 0.1 Sec		
			Disable Conditions:	MIL not Illuminated for DTC's:		TCM: U0073 ECM: None		
Transmission Control Module (TCM)	C1250	The lateral accleration sensor signal failed at a high voltge	hardware configuration Lateral accleration sensor raw signal hardware configuration Lateral accleration magnitude	= CeLATR_e_VoltageDirectPrOp >= 3.849999905 g's = CeLATR_e_VoltageDirectPrOp <= 3.849999905 g's	transient delay timer	>= 30 Sec	>= 75 Sec out of 120 Sec	Special No MIL
					Lateral acceleration high voltage diagnostic enable calibration	= 1		
					Battery Voltage	<= 31.999023 Volts		
					Battery Voltage	>= 9 Volts		
					Battery voltage is within the allowable limits for	>= 0.1 Sec		
					Ignition Voltage	<= 31.999023 Volts		
					Ignition Voltage	>= 9 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Ignition voltage and SFL conditions met for	>= 0.1 Sec		
			Disable Conditions:	MIL not Illuminated for DTC's:		TCM: U0073 ECM: None		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
Transmission Control Module (TCM)	C1251	The lateral accleration signal is stuck at a high magnitude in range	absolute value (lateral accleration)	>= 0.529999971 g's	absolute value (lateral accleration) for stablity	>= 0.53 g's	>= 75 Sec	Special No MIL
			absolute value (lateral accleration)	<= 3.849999905 g's	absolute value (lateral accleration) for stablity	<= 3.8499999 g's		
					stability time	>= 30 Sec		
					Diagnostic shifting override command	= FALSE Boolean		
					Attained Gear State	= 1st through 8th		
					Attained Gear Slip	<= 100 RPM		
					Transmission Type	= Clutch to Clutch Transmission		
					High Side Drivers enabled	= TRUE Boolean		
					Vehicle Speed	>= 15 kph		
					Lateral acceleration stuck in range diagnostic enable calibration	= 1		
					Battery Voltage	<= 31.999023 Volts		
					Battery Voltage	>= 9 Volts		
					Battery voltage is within the allowable limits for	>= 0.1 Sec		
					Ignition Voltage	<= 31.999023 Volts		
					Ignition Voltage	>= 9 Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	= FALSE Boolean		
					Ignition voltage and SFL conditions met for	>= 0.1 Sec		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0721, P0722, P0723, P07BF, P07C0, P077B, P077C, P077D, P215C, U0073 ECM: None		
Transmission Cooling Fan Performance	P184F	Transmission Cooling Fan Performance	delta transmission fluid temperature fail = transmission fluid temperature start of test - current value transmission fluid temperature transmission fluid temperature start of test is latched to the current value of transmission fluid temperature when transmission cooling fan run time is not zero (0.0)	<= Table Based Time Please see Table 27 ºC in Supporting Documents			>= 2 counts (100 msec continuous)	Type B, Two Trips
					use outside air temperature (emission system) calibration OR	= 0		
					outside air temperature available (emission system) and all of the following	= TRUE Boolean		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions			Time Required	Mil Illum.
					outside ait temperature (emission system)	>=	-8192	ºC		
					outside ait temperature (emission system)	<=	58	ºC		
					transmission fluid temperature	<=	255.99219			
					transmission fluid temperature	>=	110			
					transmission fluid temperature valid	=	TRUE	Boolean		
					transmission cooling fan state command	=	ON			
					transmission cooling fan command capacity	>=	18.499756	%		
					transmission cooling fan run time	>=	300	seconds		
					diagnotic monitor enable calibration	=	1			
					outside air temperature valid	=	TRUE	Boolean		
					battery voltage	<=	31.999023	volts		
					battery voltage	>=	9	volts		
					battery voltage time	>=	0.1	sec		
					Ignition Voltage	<=	31.999023	Volts		
					Ignition Voltage	>=	9	Volts		
					Service Fast Learn (SFL) Mode VBS Failsafe	=	FALSE	Boolean		
					Ignition voltage and SFL conditions met for	>=	0.1	Sec		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0711, P0712, P0713 ECM: P0072, P073, P074				

19 OBDG03B TCM Summary Tables

2D Supporting Tables TCM

Table 1

Axis	0.00	64.00	128.00	192.00	256.00	320.00	384.00	448.00	512.00	N*m
Curve	50.00	50.00	50.00	50.00	50.00	50.00	50.00	50.00	50.00	RPM

Table 2

Axis	-40.00	-20.00	0.00	30.00	110.00	ºC
Curve	1.6000	1.1000	0.9500	0.8500	0.8500	seconds

Table 3

Axis	-40.00	-20.00	0.00	30.00	110.00	ºC
Curve	1.5500	1.0500	0.9000	0.8000	0.8000	seconds

Table 4

Axis	-40.00	-20.00	0.00	30.00	110.00	ºC
Curve	1.4000	0.9000	0.7500	0.6500	0.6500	seconds

Table 5

Axis	-40.00	-20.00	0.00	30.00	110.00	ºC
Curve	1.5500	1.0500	1.0000	1.0000	1.0000	seconds

Table 6

Axis	-40.00	-20.00	0.00	30.00	110.00	ºC
Curve	1.5500	1.0500	0.9000	0.8000	0.8000	seconds

Table 7

Axis	_e_CD_21	R_e_CD_31	_e_CD_32	_e_CD_42	_e_CD_43	_e_CD_51	_e_CD_53	_e_CD_54	_e_CD_63	closed throttle down shift type: 2-1, 3-1, 3-2, 4-2, 4-3, 5-1, 5-3, 5-4, 6-3, 6-4, 6-5, 7-1, 7-,5 7-6, 8-2, 8-4, 8-6, 8-7
Curve	750.0	750.0	750.0	750.0	750.0	750.0	750.0	750.0	750.0	kPa
Axis	_e_CD_64	R_e_CD_65	_e_CD_71	_e_CD_75	_e_CD_76	_e_CD_82	_e_CD_84	_e_CD_86	_e_CD_87	closed throttle down shift type: 2-1, 3-1, 3-2, 4-2, 4-3, 5-1, 5-3, 5-4, 6-3, 6-4, 6-5, 7-1, 7-,5 7-6, 8-2, 8-4, 8-6, 8-7
Curve	750.0	750.0	750.0	750.0	750.0	750.0	750.0	750.0	750.0	kPa

Table 8

Axis	_e_US_12	R_e_US_23	_e_US_34	_e_US_45	_e_US_56	_e_US_67	_e_US_78	_e_US_13	_e_US_24	up shift type: 1-2, 2-3, 3-4, 4-5, 5-6, 6-7, 7-8, 1-3, 2-4, 3-5, 4-6, 5-7, 6-8
Curve	750.0	750.0	750.0	750.0	750.0	750.0	750.0	750.0	750.0	kPa
Axis	_e_US_35	R_e_US_46	_e_US_57	_e_US_68	up shift type: 1-2, 2-3, 3-4, 4-5, 5-6, 6-7, 7-8, 1-3, 2-4, 3-5, 4-6, 5-7, 6-8					
Curve	750.0	750.0	750.0	750.0	kPa					

Table 9

Axis	-6.67	-6.66	40.00	80.00	120.00	ºC
Curve	409.00	3.30	1.30	1.20	1.10	Sec

Table 10

Axis	C1_Clutch	e_C2_Clutch	_C3_Clutch	_C4_Clutch	_C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Curve	1	1	1	1	1	BOOLEAN

2D Supporting Tables TCM

Table 11

	C1_Clutch	e_C2_Clutch	C3_Clutch	C4_Clutch	C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Axis						
Curve	180.0	180.0	180.0	180.0	180.0	N*m

Table 12

	C1_Clutch	e_C2_Clutch	C3_Clutch	C4_Clutch	C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Axis						
Curve	60.0	60.0	60.0	60.0	60.0	N*m

Table 13

	C1_Clutch	e_C2_Clutch	C3_Clutch	C4_Clutch	C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Axis						
Curve	10.0	10.0	10.0	10.0	10.0	N*m

Table 14

	C1_Clutch	e_C2_Clutch	C3_Clutch	C4_Clutch	C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Axis						
Curve	-30.0	-30.0	-30.0	-30.0	-30.0	N*m

Table 15

	C1_Clutch	e_C2_Clutch	C3_Clutch	C4_Clutch	C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Axis						
Curve	100.0	100.0	100.0	100.0	100.0	N*m

Table 16

	C1_Clutch	e_C2_Clutch	C3_Clutch	C4_Clutch	C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Axis						
Curve	60.0	60.0	60.0	60.0	60.0	N*m

Table 17

	C1_Clutch	e_C2_Clutch	C3_Clutch	C4_Clutch	C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Axis						
Curve	10.0	10.0	10.0	10.0	10.0	N*m

Table 18

	C1_Clutch	e_C2_Clutch	C3_Clutch	C4_Clutch	C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Axis						
Curve	-30.0	-30.0	-30.0	-30.0	-30.0	N*m

Table 19

Axis	-40.10	-40.00	-20.00	0.00	30.00	60.00	100.00	149.00	149.10	ºC
Curve	256.00	50.00	45.00	40.00	34.00	25.00	20.00	20.00	256.00	ºC

Table 20

Axis	-40.10	-40.00	-20.00	0.00	30.00	60.00	100.00	149.00	149.10	ºC
Curve	256.00	10.00	8.00	8.00	8.00	8.00	8.00	8.00	256.00	ºC

2D Supporting Tables TCM

Table 21

Axis	-40.00	0.00	40.00	ºC
Curve	5.00	5.00	5.00	Sec

Table 22

Axis	-6.67	-6.66	40.00	ºC
Curve	8191.75	8191.75	8191.75	RPM/Sec

Table 23

Axis	-6.67	-6.66	40.00	ºC
Curve	8191.75	8191.75	8191.75	RPM/Sec

Table 24

Axis	-7.00	10.00	40.00	ºC
Curve	1.50	1.25	1.00	Sec

Table 25

Axis	-7.00	10.00	40.00	ºC
Curve	-2000.00	-2000.00	-2000.00	RPM/Sec

Table 26

Axis	-40.00	-30.00	-20.00	0.00	20.00	ºC
Curve	1800.00	1500.00	1200.00	600.00	60.00	Sec

Table 27

Axis	0.00	20.00	60.00	100.00	120.00	Kph
Curve	-8.00	-8.00	-8.00	-8.00	-8.00	ºC

Table 28

Axis	-40.00	-20.00	0.00	30.00	110.00	ºC
Curve	5.00	3.00	2.00	1.75	1.00	Sec

Table 29

Axis	_C1_Clutch	e_C2_Clutch	_C3_Clutch	_C4_Clutch	_C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Curve	0.9000	0.9000	0.9000	0.9000	0.9000	seconds

Table 30

Axis	_C1_Clutch	e_C2_Clutch	_C3_Clutch	_C4_Clutch	_C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Curve	0.9000	0.9000	0.9000	0.9000	0.9000	seconds

2D Supporting Tables TCM

Table 31

	C1_Clutch	e_C2_Clutch	C3_Clutch	C4_Clutch	C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Axis						
Curve	0.9000	0.9000	0.9000	0.9000	0.9000	seconds

Table 32

	C1_Clutch	e_C2_Clutch	C3_Clutch	C4_Clutch	C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Axis						
Curve	4	4	4	4	4	counts

Table 33

	C1_Clutch	e_C2_Clutch	C3_Clutch	C4_Clutch	C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Axis						
Curve	4	4	4	4	4	counts

Table 34

NOT USED
NOT USED

Table 35

	C1_Clutch	e_C2_Clutch	C3_Clutch	C4_Clutch	C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Axis						
Curve	0.5000	0.5000	0.5000	0.5000	0.5000	seconds

Table 36

	C1_Clutch	e_C2_Clutch	C3_Clutch	C4_Clutch	C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Axis						
Curve	0.5000	0.5000	0.5000	0.5000	0.5000	seconds

Table 37

	C1_Clutch	e_C2_Clutch	C3_Clutch	C4_Clutch	C5_Clutch	clutch1 CB1278R, clutch 2 CB12345R, clutch3 C13567, clutch4 C23468, clutch5 C45678R
Axis						
Curve	300.0	300.0	300.0	300.0	300.0	kPa

Table 38

Axis	-40.00	-20.00	0.00	30.00	110.00	ºC
Curve	0.9500	0.4500	0.3000	0.3000	0.3000	seconds

Table 39

Axis	-40.00	-20.00	0.00	30.00	110.00	ºC
Curve	0.9500	0.4500	0.3000	0.2000	0.2000	seconds

Table 40

Axis	-40.00	-20.00	0.00	30.00	110.00	ºC
Curve	0.9500	0.4500	0.3000	0.2000	0.2000	seconds

2D Supporting Tables TCM

Table 41

Axis	-40.00	-20.00	0.00	30.00	110.00	ºC
Curve	1.1000	0.6000	0.5500	0.5500	0.5500	seconds

Table 42

Axis	-40.00	-20.00	0.00	30.00	110.00	ºC
Curve	0.9500	0.4500	0.3000	0.2000	0.2000	seconds

Table 43

NOT USED
NOT USED

Table 44

NOT USED
NOT USED

Table 45

Axis	_e_CC_US	R_e_CC_CD	_e_CC_PD	_e_CC_GS	up shift, closed throttle down shift, power down shift, garage shift
Curve	1	1	1	0	BOOLEAN

Table 46

Axis	0	1	2	3	1 ADchannel, 2 AD channels, 3 AD channels, 4 AD channels
Curve	1	0	0	0	BOOLEAN

Table 47

Axis	stVoltage1	TestVoltage2	stVoltage3	stVoltage4	1 ADchannel, 2 AD channels, 3 AD channels, 4 AD channels
Curve	5.0000	25.0000	75.0000	95.0000	volts

Table 48

Axis	p25msSeq	_12.5msSeq	_25msSeq	_LORES_C	6.25 msec loop, 12.5 msec loop, 25 msec loop, low res engine
Curve	0.2000	0.2000	0.2000	409.5938	seconds

Table 49

Axis	p25msSeq	_12.5msSeq	_25msSeq	_LORES_C	6.25 msec loop, 12.5 msec loop, 25 msec loop, low res engine
Curve	16	8	4	16	counts

Table 50

Axis	R_i_MontrA	MR_i_MontrB	R_i_MontrC	seed key test enable, seed sequence test enable, seed timeout test enable
Curve	1	0	0	BOOLEAN

Table 51

Axis	0	1	speed sensor1, speed sensor2
Curve	0.2500	0.0000	volts

Table 52

Axis	0	1	speed sensor1, speed sensor2
Curve	40	65535	counts

2D Supporting Tables TCM

Table 53

Axis	0	1	speed sensor1, speed sensor2
Curve	0.0500	409.5938	seconds

Table 54

Axis	0	1	speed sensor1, speed sensor2
Curve	1	0	BOOLEAN

Table 55

Axis	0	1	speed sensor1, speed sensor2
Curve	4.7500	12.0000	volts

Table 56

Axis	0	1	speed sensor1, speed sensor2
Curve	40	65535	counts

Table 57

Axis	0	1	speed sensor1, speed sensor2
Curve	0.0500	409.5938	seconds

Table 58

Axis	0	1	speed sensor circuit low, speed sensor circuit high
Curve	1	0	BOOLEAN

Table 59

Axis	-40.00	-20.00	0.00	30.00	110.00	°C
Curve	1.2000	0.9000	0.8500	0.7500	0.7500	seconds

Table 60

Axis	-40.00	-20.00	0.00	30.00	110.00	°C
Curve	1.2500	0.7500	0.6000	0.6000	0.6000	seconds

Table 61

Axis	-40.00	-20.00	0.00	30.00	110.00	°C
Curve	1.2000	0.7000	0.5500	0.4500	0.4500	seconds

Table 62

Axis	-40.00	-20.00	0.00	30.00	110.00	°C
Curve	1.2000	0.7000	0.5500	0.5500	0.5500	seconds

Table 63

Axis	-40.00	-20.00	0.00	30.00	110.00	°C
Curve	1.2000	0.7000	0.5500	0.4500	0.4500	seconds

2D Supporting Tables TCM

Table 64

Axis	0BE_BusA	GACY_BusA	0C1_BusA	0C5_BusA	0C9_BusA	0F1_BusA	_CA_BusA	12A_BusA	_185_BusA	frame
Curve	BusA_ECM	alidRxDevice	BusA_ABS	BusA_ABS	BusA_ECM	BusA_BCM	dRxDevice	BusA_BCM	dRxDevice	enable or invalid
Axis	18E_BusA	GACY_BusA	_191_BusA	1A1_BusA	1A3_BusA	1A5_BusA	1AA_BusA	ACY_BusA	1BA_BusA	frame
Curve	BusA_ECM	alidRxDevice	dRxDevice	BusA_ECM	BusA_ECM	dRxDevice	BusA_ECM	dRxDevice	BusA_ECM	enable or invalid
Axis	1CB_BusA	g_1DF_BusA	1E9_BusA	_1F1_BusA	1F3_BusA	1F9_BusA	1FC_BusA	_287_BusA	2D1_BusA	frame
Curve	dRxDevice	alidRxDevice	BusA_ABS	BusA_BCM	BusA_BCM	dRxDevice	BusA_ABS	BusA_ECM	dRxDevice	enable or invalid
Axis	2F9_BusA	g_3D1_BusA	3E9_BusA	3FC_BusA	4A3_BusA	4C1_BusA	4C7_BusA	4DF_BusA	4E1_BusA	frame
Curve	dRxDevice	_BusA_ECM	BusA_ECM	dRxDevice	dRxDevice	BusA_ECM	dRxDevice	_CHCM_A	BusA_BCM	enable or invalid
Axis	4E9_BusA	g_4F1_BusA	_589_BusA	frame						
Curve	BusA_BCM	_BusA_ECM	BusA_ECM	enable or invalid						

Table 65

Axis	0BE_BusA	GACY_BusA	0C1_BusA	0C5_BusA	0C9_BusA	0F1_BusA	_CA_BusA	12A_BusA	_185_BusA	frame
Curve	12.000	12.000	12.000	12.000	0.500	12.000	12.000	12.000	12.000	seconds
Axis	18E_BusA	GACY_BusA	_191_BusA	1A1_BusA	1A3_BusA	1A5_BusA	1AA_BusA	ACY_BusA	1BA_BusA	frame
Curve	0.500	12.000	12.000	12.000	12.000	12.000	0.500	12.000	0.500	seconds
Axis	1CB_BusA	g_1DF_BusA	1E9_BusA	_1F1_BusA	1F3_BusA	1F9_BusA	1FC_BusA	_287_BusA	2D1_BusA	frame
Curve	12.000	12.000	12.000	12.000	12.000	12.000	12.000	12.000	12.000	seconds
Axis	2F9_BusA	g_3D1_BusA	3E9_BusA	3FC_BusA	4A3_BusA	4C1_BusA	4C7_BusA	4DF_BusA	4E1_BusA	frame
Curve	12.000	12.000	12.000	12.000	12.000	12.000	12.000	12.000	12.000	seconds
Axis	4E9_BusA	g_4F1_BusA	_589_BusA	frame						
Curve	12.000	12.000	0.500	seconds						

Supporting Documents - 3D Tables TCM

3D_Table 1

CeTSKR_Cnt_MaxCPUs
CePISR_e_NumOfSeqTasks
KaPISD_b_ProgSeqWatchEnbl

	CeTSKR_e_CPU				
X-Axis Calibration					CPU
Y-Axis Calibration	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C	loop test type
Table Calibration	1	1	1	0	BOOLEAN

	CeTSKR_e_CPU2				
X-Axis Calibration					CPU
Y-Axis Calibration	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C	loop test type
Table Calibration	0	0	0	0	BOOLEAN

19 OBDG03B Electronic Transmission Range Selector - ICCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Remote PRNDL Display Internal Electronic Failure	B071F	Indicates error on Transmission Range Indicator Bezel	Fault Flag	=True	Ignition	Run/Crank	120 failures out of 200 samples, 100 msec loop.	DTC Type C No MIL
Door Open Switch Signal - Door Ajar Switch Signal Not Plausible	B2A00	Compares the Door Ajar and Door Open Switch for mismatch	Door Open Switch AND Door Ajar switch	= OPEN = CLOSED	Controller Status Not Fault Active	= On U0422	240 failure out of 240 samples 12.5 msec loop	Emissions Neutral, Type C No MIL
Electric Park Brake **Availability** Status Message Counter Incorrect	C1280	Detects error on ARC & PV reported by CHCM about signal $22A from EBCM on HS GMLAN □	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress	within proper operating range for at least 3 seconds. For at least 3 seconds.	10 failures out of 16 samples. Executed at 100 msec loop	DTC Type C No MIL
Electric Park Brake **Application** Status Message Counter Incorrect	C1281	Detects error on ARC & PV reported by CHCM about signal $22A from EBCM on HS GMLAN	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress, as indicated by: VeDRER_b_DiagSystemDsbl	within proper operating range for at least 3 seconds. =False, for at least 3 seconds.	10 failures out of 16 samples. Executed at 100 msec	DTC Type C No MIL
System Voltage Performance	P0561	Sets when voltage system voltage signal is erratic.	Battery Voltage Measured Delta Over 12.5ms (Loop to Loop)	>3 Volts	Ignition Key Status Engine Speed	RUN/CRANK >= 400 RPM	62.5 ms out of a 250ms window = 5 failures out of 20 trials. Executed at 12.5 msec.	Type C
System Voltage Low	P0562	Sets when the low voltage system voltage is below a threshold	Battery Voltage	Ignition Voltage <= 9 Volts	Ignition Key Status Engine Speed	RUN/CRANK >=400 RPM	5 seconds in a 6 second window	Type C
System Voltage High	P0563	Sets when the low voltage system voltage is above a threshold	Battery Voltage	> 18 Volts	Hardwire Ignition Engine Speed	RUN/CRANK >= 400 RPM	5 seconds in a 6 second window	Type C
Sensor Reference Voltage A Circuit/Open	P0641	This diagnostic monitors the buffered 5V supply circuit 1/A	5V supply circuit measured percentage	X < 87.75% OR X > 92.25%	Run/Crank Voltage	> 10 volts	2 seconds	DTC Type B Two trips
		DTC Pass	5V supply circuit measured percentage	Within acceptable values				
Sensor Reference Voltage C Circuit/Open	P0697	This diagnostic monitors the buffered 5V supply circuit 3/C	5V supply circuit measured percentage	X < 87.75% OR X > 92.25%	Run/Crank Voltage	> 10 volts	2 seconds	DTC Type B Two trips
		DTC Pass	5V supply circuit measured percentage	Within acceptable values				

19 OBDG03B Electronic Transmission Range Selector - ICCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Unable to Engage Neutral	P073D	Detects the inability to achieve or remain in Neutral.	Actual Arbitrated Transmission Range	≠Neutral	Actual Transmission Range Commanded Transmission Range Global diagnostic Enabler calibration: Range Achieved Diagnostics Enabling calibration: Range Position Sensor / Internal Mode Switch (IMS) from TCM on CAN bus: Actual Transmission Range = AND CodeClearFunction AND ManufacturingModeActive AND: <u>External:</u> Run/Crank OR Accessory/Wakeup <u>Internal:</u> From the time when RunCrankActive until ActualRange AND Accessory/Wakeup	= Good value = valid, Neutral =TRUE =TRUE =valid =Good value =False =False =True = True =True =Park =False	Park to Neutral: 2000 msec Reverse to Neutral: 2000 msec Neutral to Neutral: 1800 msec Drive to Neutral: 2000 msec	DTC Type B, Two Trips
		DTC Pass	Actual Transmission Range	=Neutral				
Unable to Engage Reverse	P073E	Detects the failure to achieve the expected command to Reverse range.	Actual Arbitrated Transmission Range	≠Reverse	Actual Transmission Range Commanded Transmission Range Global diagnostic Enabler calibration: Range Achieved Diagnostics Enabling calibration: Range Position Sensor / Internal Mode Switch (IMS) from TCM on CAN bus: Actual Transmission Range = AND CodeClearFunction AND ManufacturingModeActive AND: <u>External:</u> Run/Crank OR Accessory/Wakeup <u>Internal:</u> From the time when RunCrankActive until ActualRange AND Accessory/Wakeup	= Good value = valid, Reverse =TRUE =TRUE =valid =Good value =False =False =True = True =True =Park =False	Park to Reverse: 2000 msec Reverse to Reverse: 1800 msec Neutral to Reverse: 2000 msec Drive to Reverse: 2000 msec	DTC Type B, Two Trips
		DTC Pass	Actual Transmission Range	= Reverse				
Transmission Park Position Switch A Circuit Low	P07B3	Detects Park Position Switch A circuit reading low	Park Position Measured Voltage Percent	< 35 % 35% percent of 5 Volts = ~ 1.75Volts	Enabling calibration of this particular diagnostic Diagnostics enabling calibration Controller is "On" for	=TRUE =TRUE > 0.05 sec	7 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
		DTC Pass	Park Position Measured Voltage Percent	Within acceptable Voltage Percent				

19 OBDG03B Electronic Transmission Range Selector - ICCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Transmission Park Position Switch A Circuit High	P07B4	Detects Park Position Switch A circuit reading high	Park Position Measured Voltage Percent	> 70%	Enabling calibration of this particular diagnostic Diagnostics enabling calibration Controller is "On" for	=TRUE =TRUE > 0.05 sec	7 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
		DTC Pass	Park Position Measured Voltage Percent	Within acceptable Voltage Percent				
Transmission Park Position Switch A Circuit Performance	P07B5	Detects Park Position Switch A circuit reading outside "Released" or "Pressed" values	Park Position Measured Voltage Percent	45% < X < 58%	Not Fault Active Enabling calibration of this particular diagnostic Diagnostics enabling calibration Controller is "On" for	P07B3, P07B4 =TRUE =TRUE > 0.05 sec	40 failures out of 50 samples, executed at 12.5 msec	DTC Type B, Two Trips
		DTC Pass	Park Position Measured Voltage Percent	Within acceptable Voltage Percent				
Transmission Park Position Switch B Circuit Low	P07B9	Detects Park Position Switch B circuit reading low	Park Position Measured Voltage Percent	<35 %	Enabling calibration of this particular diagnostic Diagnostics enabling calibration Controller is "On" for	=TRUE =TRUE > 0.05 sec	7 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
		DTC Pass	Park Position Measured Voltage Percent	Within acceptable Voltage Percent				
Transmission Park Position Switch B Circuit High	P07BA	Detects Park Position Switch B circuit reading high	Park Position Measured Voltage Percent	> 70%	Enabling calibration of this particular diagnostic Diagnostics enabling calibration Controller is "On" for	=TRUE =TRUE > 0.05 sec	7 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
		DTC Pass	Park Position Measured Voltage Percent	Within acceptable Voltage Percent				
Transmission Park Position Switch B Circuit Performance	P07BB	Detects Park Position Switch B circuit reading outside "Released" or "Pressed" values	Park Position Measured Voltage Percent	45% < X < 58%	Not Fault Active Enabling calibration of this particular diagnostic Diagnostics enabling calibration Controller is "On" for	P07BA, P07B9 =TRUE =TRUE > 0.05 sec	40 failures out of 50 samples, executed in a 12.5 msec loop	DTC Type B, Two Trips
		DTC Pass	Park Position Measured Voltage Percent	Within acceptable Voltage Percent				
Transmission Park Position Switch A/B Correlation	P07BE	Correlation diagnosic compares both switches	Compares Park Switch A and Park Switch B "PRESSED" and "RELEASED" states.	One Switch Stuck On: The states are valid, but not equal continuously	Not Fault Active Controller has been active for at least: DTC enabling calibrations = Vehicle Speed is low enough to honor Park request. Vehilce speed:	P07B3, P07B4, P07B4, P07B9, P07BA, P07BB 100 msec = TRUE <= Calibrated limit. The calibration name for the vehicle speed for checking for the Park button correlation diagnostics DTC: 10.5 and 10. (Hysteresis)	4800 failures out of 6000 samples at 12.5 msec rate	DTC Type B, two trips.

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Unable to Engage Park	P07E4	Detects the inability to achieve or remain in Park.	Actual Arbitrated Transmission Range	≠Park	Actual Transmission Range Commanded Transmission Range Global diagnostic Enabler calibration: Range Achieved Diagnostics Enabling calibration: Range Position Sensor / Internal Mode Switch (IMS) from TCM on CAN bus: Actual Transmission Range = AND CodeClearFunction AND ManufacturingModeActive AND: <u>External:</u> Run/Crank OR Accessory/Wakeup	= Good value = valid, Park =TRUE =TRUE =valid =Good value =False =False =True = True	From an undefined range to Park: 2000 msec From Park to Park: 1800 msec From Reverse to Park: 2000 msec From Neutral to Park: 2000 msec From Drive to Park: 2000 msec	DTC Type B, Two Trips
		DTC Pass	Commanded Trans Range Actual Transmission Range	= Park AND = Park	<u>Internal:</u> From the time when RunCrankActive until ActualRange AND Accessory/Wakeup	=True =Park =False		
Unable to Engage Drive	P07E5	Detects the failure to achieve the expected command to Drive range.	Actual Arbitrated Transmission Range	≠Drive	Actual Transmission Range AND Commanded Transmission Range Global diagnostic Enabler calibration: Range Achieved Diagnostics Enabling calibration: Range Position Sensor / Internal Mode Switch (IMS) from TCM on CAN bus: Actual Transmission Range = AND CodeClearFunction AND ManufacturingModeActive AND: <u>External:</u> Run/Crank OR Accessory/Wakeup	= Good value = valid, Drive =TRUE =TRUE =valid =Good value =False =False =True = True	From an Undetermined range to Drive: 2000 msec From Park to Drive: 2000 msec From Reverse to Drive: 2000 msec From Neutral to Drive: 2000 msec From Drive to Drive: 1800 msec	DTC Type B, Two Trips
		DTC Pass	Actual Transmission Range	= Drive	<u>Internal:</u> From the time when RunCrankActive until ActualRange AND Accessory/Wakeup	=True =Park =False		
Gear Lever X Position Sensor 1 Circuit Performance	P082A	Detects Gear Lever X Position Sensor 1 circuit is reading outside "good" values	Gear Lever Position Sensor 1 Measured Duty Cycle on X	Are outside the shifter path of movement (6 to 11% to meet 100 Nm force on shifter from nominal path) OR:	Not Fault Active Diagnostic Enable Calibration= Controller has been awake for at least:	P082B, P082C TRUE 0.05 seconds	4 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
			Gear Lever Position Sensor 1 Measured Frequency on X	≠(89<X<111Hz) OR:				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
			Gear Lever Position Sensor 1 Measured Duty Cycle on X and Gear Lever Position Sensor 2 Measured Duty Cycle on X differ by more than	> 12 %				
		DTC Pass	Gear Lever Position Sensor 1 Measured Duty Cycle and Frequency on X	Within acceptable values				
Gear Lever X Position Sensor 1 Circuit Low	P082B	Detects Gear Lever X Position Sensor 1 circuit reading low	Gear Lever Position Sensor 1 Measured Duty Cycle on X	< 17 %	Diagnostic Enable Calibration= Controller has been awake for at least:	TRUE 0.05 seconds	4 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
		DTC Pass	Gear Lever Position Sensor 1 Measured Duty Cycle on X	Within acceptable Duty Cycle				
Gear Lever X Position Sensor 1 Circuit High	P082C	Detects Gear Lever X Position Sensor 1 circuit reading high	Gear Lever Position Sensor 1 Measured Duty Cycle on X	> 88 %	Diagnostic Enable Calibration= Controller has been awake for at least:	TRUE 0.05 seconds	4 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
		DTC Pass	Gear Lever Position Sensor 1 Measured Duty Cycle on X	Within acceptable Duty Cycle				
Gear Lever Y Position Sensor 1 Circuit Performance	P082D	Detects Gear Lever Y Position Sensor 1 circuit is reading outside "good" values	Gear Lever Position Sensor 1 Measured Duty Cycle on Y	Are outside the shifter path of movement (6 to 11% to meet 100 Nm force on shifter from nominal path) OR:	Not Fault Active Diagnostic Enable Calibration= Controller has been awake for at least:	P082E, P082F TRUE 0.05 seconds	4 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
			Gear Lever Position Sensor 1 Measured Frequency on Y	≠(89<X<111Hz) OR:				
			Gear Lever Position Sensor 1 Measured Duty Cycle on Y and Gear Lever Position Sensor 2 Measured Duty Cycle on Y differ by more than	> 12 %				
		DTC Pass	Gear Lever Position Sensor 1 Measured Duty Cycle and Frequency on Y	Within acceptable values				
Gear Lever Y Position Sensor 1 Circuit Low	P082E	Detects Gear Lever Y Position Sensor 1 circuit reading low	Gear Lever Position Sensor 1 Measured Duty Cycle on Y	< 17 %	Diagnostic Enable Calibration= Controller has been awake for at least:	TRUE 0.05 seconds	4 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
		DTC Pass	Gear Lever Position Sensor 1 Measured Duty Cycle on Y	Within acceptable Duty Cycle				
Gear Lever Y Position Sensor 1 Circuit High	P082F	Detects Gear Lever Y Position Sensor 1 circuit reading high	Gear Lever Position Sensor 1 Measured Duty Cycle on Y	> 88 %	Diagnostic Enable Calibration= Controller has been awake for at least:	TRUE 0.05 seconds	4 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
		DTC Pass	Gear Lever Position Sensor 1 Measured Duty Cycle on Y	Within acceptable Duty Cycle				
Gear Lever X Position Sensor 2 Circuit Performance	P089B	Detects Gear Lever X Position Sensor 2 circuit is reading outside "good" values	Gear Lever Position Sensor 2 Measured Duty Cycle on X	Are outside the shifter path of movement (6 to 11% to meet 100 Nm force on shifter from nominal path) OR:	Not Fault Active Diagnostic Enable Calibration= Controller has been awake for at least:	P089C, P089D TRUE 0.05 seconds	4 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
			Gear Lever Position Sensor 2 Measured Frequency on X	≠(89<X<111Hz) OR:				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
			Gear Lever Position Sensor 2 Measured Duty Cycle on X and Gear Lever Position Sensor 1 Measured Duty Cycle on X differ by more than	> 12 %				
		DTC Pass	Gear Lever Position Sensor 2 Measured Duty Cycle and Frequency on X	Within acceptable values				
Gear Lever X Position Sensor 2 Circuit Low	P089C	Detects Gear Lever X Position Sensor 2 circuit reading low	Gear Lever Position Sensor 2 Measured Duty Cycle on X	<17%	Diagnostic Enable Calibration= Controller has been awake for at least:	TRUE 0.05 seconds	4 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
		DTC Pass	Gear Lever Position Sensor 2 Measured Duty Cycle on X	Within acceptable Duty Cycle				
Gear Lever X Position Sensor 2 Circuit High	P089D	Detects Gear Lever X Position Sensor 2 circuit reading high	Gear Lever Position Sensor 2 Measured Duty Cycle on X	>88%	Diagnostic Enable Calibration= Controller has been awake for at least:	TRUE 0.05 seconds	4 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
		DTC Pass	Gear Lever Position Sensor 2 Measured Duty Cycle on X	Within acceptable Duty Cycle				
Gear Lever Y Position Sensor 2 Circuit Performance	P08A0	Detects Gear Lever Y Position Sensor 2 circuit is reading outside "good" values	Gear Lever Position Sensor 2 Measured Duty Cycle on Y	Are outside the shifter path of movement (6 to 11% to meet 100 Nm force on shifter from nominal path)	Not Fault Active Diagnostic Enable Calibration= Controller has been awake for at least:	P08A1, P08A2 TRUE 0.05 seconds	4 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
			Gear Lever Position Sensor 2 Measured Frequency on Y	≠(89<X<111Hz)				
			Gear Lever Position Sensor 1 Measured Duty Cycle on Y and Gear Lever Position Sensor 2 Measured Duty Cycle on Y differ by more than	> 12 %				
		DTC Pass	Gear Lever Position Sensor 2 Measured Duty Cycle and Frequency on Y	Within acceptable values				
Gear Lever Y Position Sensor 2 Circuit Low	P08A1	Detects Gear Lever Y Position Sensor 2 circuit reading low	Gear Lever Position Sensor 2 Measured Duty Cycle on Y	<17%	Diagnostic Enable Calibration= Controller has been awake for at least:	TRUE 0.05 seconds	4 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
		DTC Pass	Gear Lever Position Sensor 2 Measured Duty Cycle on Y	Within acceptable Duty Cycle				
Gear Lever Y Position Sensor 2 Circuit High	P08A2	Detects Gear Lever Y Position Sensor 2 circuit reading high	Gear Lever Position Sensor 2 Measured Duty Cycle on Y	>88%	Diagnostic Enable Calibration= Controller has been awake for at least:	TRUE 0.05 seconds	4 failures out of 9 samples 12.5 msec loop	DTC Type B, Two Trips
		DTC Pass	Gear Lever Position Sensor 2 Measured Duty Cycle on Y	Within acceptable Duty Cycle				
Wheel Speed Sensor Sequence Number Incorrect	P15FD	Detects error on ARC reported by the CHCM about signal $0C1 from EBCM on HS GMLAN	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1	Current ARC ≠ Previous ARC +1 ☐	Run Crank Active DTC enabling calibration:	True for > 0.5 seconds TRUE	1 second	DTC Type C No MIL
		DTC Pass: The diagnostic will pass once valid data is received for 0.5sec.						

19 OBDG03B Electronic Transmission Range Selector - ICCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
ECM/PCM Power Relay Signal Message Counter Incorrect	P16E8	Detects error on ARC & PV reported by CHCM about signal $3C7 from ECM on HS GMLAN	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value □	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress	within proper operating range for at least 3 seconds. for at least 3 seconds.	sampled at 12.5 msec rate 10 failures within 16 samples	DTC Type B Two Trips
Internal Control Module Transmission Range Control Performance	P16F4	Determines if the Electronic Transmission Range Select control module software incorrectly processes a range request which would result in an unsafe condition	Driver Requested Arbitrated Range Commanded OR: Transmission range control routine Transmission range control routine Transmission range control routine	is issued unexpectedly OR ≠ expected range Does not issue Park or Neutral command quickly enough in response to driver request Issues a request to Drive, Low or Manual without a matching input by the customer within a calibrated time 200 msec. Issues a request to Reverse without a matching input by the customer within a calibrated time limit 200 msec.	Global Diagnostic Enable CodeClearFunction AND ManufacturingModeActive AND: External: Run/Crank OR Accessory/Wakeup Internal: From the time when RunCrankActive until ActualRange AND Accessory/Wakeup DTC enabling calibrations for each type of range request:	= True =False =False =True = True =True =Park =False =True	Drive Request Acknowledgment Time Limit = 200 msec Reverse Request Acknowledgment Time Limit = 200 msec Neutral Request Acknowledgment Time Limit = 200 msec Park Request Acknowledgment Time Limit = 200 msec Park Exit Acknowledgment Time Limit = 200 msec Park Exit Correlation Time Limit = 2050 msec	DTC Type B Two Trips
		DTC Pass	Driver Requested Arbitrated Range Commanded	= expected, for a minimum of 120 seconds in 5 consecutive key cycles				
Transmission Range Sensor - Transmission Range Control Module Correlation	P1769	Detects misalignment between the Transmission Mode Position and the TRCM Position sensors.	TCM Transmission Mode Position is compared to the TRCM Rotary Sensor Range Position	TCM Mode Position ≠ TRCM Position	CodeClearFunction AND ManufacturingModeActive AND Run/Crank active: AND Position Sensor/Internal Mode Switch (IMS) from TCM on CAN is AND: External: DTC enabling calibration AND: Run/Crank OR Accessory/Wakeup Internal: From the time when RunCrankActive until ActualRange AND Accessory/Wakeup	'=False =False =True =valid =True =True = True =True =Park =False	650 msec is the allowable amount of time that a mismatch between the transmission and TRCM range feedback can persist before logging the failure time. After this time has expired, if the failure conditions continue for 278 failures out of 348 samples, the corresponding diagnostic will be set. 12.5 msec loop	DTC Type B, Two Trips
		DTC Pass	TCM Transmission Mode Position	= TRCM Rotary Sensor Range Position				
Powerflow Engaged Signal Message Incorrect	P1772	Detects error on ARC & PV reported by CHCM or ECM about signal $197 from TCM on HS GMLAN	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value □	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress	within proper operating range for at least 3 seconds. For at least 3 seconds	This DTC trips after 10 failures are observed within 16 samples. Executed at 12.5 msec	DTC Type B Two Trips

19 OBDG03B Electronic Transmission Range Selector - ICCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
IMS State Signal Message Incorrect	P1773	Detects error on ARC & PV reported by CHCM about signal $197 from TCM on HS GMLAN	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value □	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress	within proper operating range for at least 3 seconds. For at least 3 seconds	This DTC trips after 10 failures are observed within 16 samples. Executed at 12.5 msec	DTC Type B Two Trips
Chassis Control Module ETRS General Status Message Incorrect	P1774	Detects error on ARC & PV reported by CHCM/ECM about signal $209 from TRCM on CE Bus	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value □	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress	within proper operating range for at least 3 seconds. For at least 3 seconds	This DTC trips after 10 failures are observed within 16 samples. Sampled at 25 msec rate	DTC Type B Two Trips
Transmission Range Availability Signal Message Incorrect	P1778	Detects error on ARC & PV reported by CHCM about signal $3F5 from TCM on HS GMLAN	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress	within proper operating range for at least 3 seconds. For at least 3 seconds	This DTC trips after 10 failures are observed within 16 samples. 250 msec loop.	DTC Type B Two Trips
Default To Park Status Signal Message Incorrect	P177A	Detects when an error is reported by CHCM/ECM as receivers of a message sent by Default to Park on LIN	Gen 1 ETRS: DTP to CHCM, Message $21 Gen 2 ETRS: DTP to ECM, Message $05	Indicates an Error OR ARC Error	Controller On Ignition Diagnostics enabling □	= True = Run/Crank OR = Accessory =True	This DTC trips after 10 failures are observed within 16 samples. 50 msec loop.	DTC Type B Two Trips
Unexpected Range Change Detected	P1787	Detects an unexpected change in transmission range.	Actual Arbitrated Transmission Range	≠ Previous Value, without the driver requesting range change.	Actual Tranmission Range Range Command: None of the Unable to Engage Range Change diagnostics are running: DTC enabling calibration: Range Position Sensor/Internal Mode Switch (IMS) from TCM on CAN □	= Good value =valid =P073D, P073E, P07E4, P07E5 are inactive = TRUE = valid	0 - 2000 msec (depends on conditions)	DTC Type B, Two Trips
		DTC Pass If fail is from P, R, D then spend 5 sec time in each range (P, R & D) to rePass the DTC. If you fail from neutral then 5 sec time in each range (P, R, N & D) to repass the DTC.	If failure is from P, R or D then, Range Commanded=P and Actual Range= Range Commanded=R and Actual Range= Range Commanded=D and Actual Range= If failure is from N then, Range Commanded=P and Actual Range= Range Commanded=R and Actual Range= Range Commanded=N and Actual Range= Range Commanded=D and Actual Range=	=P for 5 sec AND =R for 5 sec AND =D for 5 sec =P for 5 sec AND =R for 5 sec AND =N for 5 sec AND =D for 5 sec				

19 OBDG03B Electronic Transmission Range Selector - ICCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Current Transmission Range Unknown	P1789	Detects the failure of the ETRS system to identify the current transmission range with sufficient confidence.	Actual Transmission Range	≠ Undefined	Range Indication Source AND Global diagnostic enabling criteria AND DTC enabling calibrationl AND CodeClearFunction AND ManufacturingModeActive AND: External: Run/Crank OR Accessory/Wakeup Internal: From the time when RunCrankActive until ActualRange AND Accessory/Wakeup	= Valid =met =True =False =False =True = True =True =Park =False	80 failures out of 100 samples 12.5 msec loop	DTC Type B, Two Trips
		DTC Pass	Actual Transmission Range					
Transmission Range Position not Plausible	P178A	Compares Commanded Range in CHCM/ECM to IMS. The diagnostic shall be deemed failing if neither the TRCM NOR IMS position sensors align with the commanded range within a calibrateable amount of time. The diagnostic shall be deemed passing if either the TRCM NOR IMS position sensors align with the commanded range within a calibrateable amount of time.	Commmanded Range □	≠ Actual Transmission Range IMS 250 msec	Diagnostic Enable Calibration TRCM Achievement diagnostic Global diagnostic criteria: IMS signal: AND CodeClearFunction AND ManufacturingModeActive AND: External: Run/Crank OR Accessory/Wakeup Internal: From the time when RunCrankActive until ActualRange AND Accessory/Wakeup	=TRUE = Enabled =Enabled =Valid =False AND =False =True = True =True =Park =False	This DTC trips after 269 failures are observed within 336 samples. 12.5 msec loop	DTC Type B Two trips
Default to Park Supplemental Power Supply Life	P178B	Detects the Supplemental Power Capacitors fail to have enough energy to supply the DTP when power has been lost.	Capacitor not charged at start of test such that Capacitor voltage OR: (below)	< 8 volts	Test does not start unless on key-up the capacitors had at least this much time to charge: Vehicle is in key down when Ignition transitions DTC enabling calibration = The shutdown of CHCM / ECM. System diagnostics enabling: Temperature measurement faults: Default To Park Arming Fault: □	 > 5 seconds from On to Off True Not enabled by the software yet True Inactive Inactive	1 test failure	DTC Type B 2 trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
		The diagnostic test is done during vehicle key off. The diagnostic test is reported as “failed” immediately after the DTP SOH (=State Of Health) Test failure is detected. Diagnostic test is reported as “passed” if only if the DTP SOH Test passes.	Capacitor does not discharge at end of test such that Capacitor voltage decay ratio OR: (below)	> 1.1 ratio	Test does not start unless on key-up the capacitors had at least this much time to charge: Vehicle is in key down when Ignition transitions Calculated Capacitor time constant is calculated when capacitor voltage is: If voltage is not reached then calculated (?) when time from start of test is: DTC enabling calibration = The shutdown of CHCM / ECM System diagnostics enabling: Temperature measurement faults: Default To Park Arming Fault: □	> 5 seconds from On to Off <= 8 Volts. >= 60 sec True Not enabled by the software yet True Inactive Inactive	1 test failure	
			Calculated Capacitor Time Constant (K) is outside of the expected Capacitor time constant range	K < range [29.89 to 38.74] based on temperature. OR K> range [59.89 to 68.74] based on temperature	Test does not start unless on key-up the capacitors had at least this much time to charge: Vehicle is in key down when Ignition transitions Calculated Capacitor time constant is calculated when capacitor voltage is: DTC enabling calibration = The shutdown of CHCM / ECM. System diagnostics enabling: Battery Voltage: Temperature measurement faults: Default To Park Arming Fault: □	> 5 secs from On to Off <= 8 Volts. True Not enabled by the software yet True Within operating range Inactive Inactive	1 test failure	
		DTC Pass	Test is run at each key down and depending on threshold value it will Pass or Fail					
Transmission Backup Park Performance	P178C	CASE 1: Detects when the DTP is activated and Park not reached CASE 2: Detects when an intrusive DTP Test is activated, and fails to engage Park	When DTP is activated and Transmission Range When DTP is activated due to an intrusive test and Transmission Range	≠ Park ≠ Park	CASE 1 & 2: This diagnostic shall be enabled when all the following conditions are met: 1. DTC enabling calibration 2. System diagnostics 3. System Voltage Low fault 4. Battery voltage is 5. TRCM CAN faults: 6. DTP Arming fault 7. TRCM detected position 8. GMLAN messages from TRCM 9. GMLAN messages from TRCM Not Fault Active CASE 1: The shutdown of CHCM / ECM: Temperature measurement faults: CASE 2: An intrusive test shall be run when: Key cycles since last test Time since last test: Percent Grade Commanded Range OR:	 = True = Enabled = not active = in operating range =inactive = inactive =has been valid, defined and usable for a calibrated period. =has been available for a calibrated time = did not have a protection value error or rolling count error for a calibrated period. P0562, P17AE, U18AC, P1774, P177A, U1343, U0077 Not enabled yet. =Inactive > 140 > 360,000 sec < DTPGrade = From Drive	1.95 seconds	DTC Type B Two Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
		DTC Pass	After the Intrusive Test and Trans Range	= Park	OR: Key cycles since last test Time since last test: Percent Grade Commanded Range OR: Key cycles since last test Time since last test: Commanded Range Percent Grade:	 > 160 > 446400 sec < DTPGrade = From Any > 180 > 532800 sec = From Any No restriction		
Default to Park Performance	P178D	Detects the relatching of DTP release spring	After a DTP activation and DTP Gear = Armed, then over-travel is requested and new Range commanded and after >0 seconds the transmission	Does not stay in commanded range	Not Fault Active Battery Voltage This diagnostic shall be enabled when all the following conditions are met: 1. DTC enabling calibration: 2. A TRCM CAN 3. Battery voltage: 4. System diagnostics: 5. System voltage low: 6. Power mode: 7. DTP Gear Diagnostic shall be disabled for 3.1 seconds after the over-travel flag is asserted for changing the range. □	P0562, P17AE, U18AC, P1774, P177A, U1343, U0077 is in operating range =True = Not fault active =in operating range =enabled =not fault active =RUN or CRANK =armed	1.9 seconds.	DTC Type B Two Trips
		DTC Pass	After a DTP activation and DTP Gear = Armed And Spring is relatched					
Backup Park Actuator Arming Performance	P178E	Detects errors in the Default to Park Gear status	1) DTP Gear & DTP Command Issue with DTP gear armed when DTP has been activated. OR 2) DTP Gear & DTP Command Issue when DTP gear is unarmed when commanded to be armed.	1) = Armed = Activate DTP 2) = Unarmed = Arm	This diagnostic shall be enabled when all the following conditions are met: 1. DTC enabling calibrations 2. A DTP LIN bus 3. Battery voltage: 4. System Voltage Low fault: 5. System diagnostics Diagnostic shall be disabled for Ke_t_DTPArmingEr_Disable after the Rearm DTP Gear or Activate DTP command is asserted. Not Fault Active 1) DTP Command = Activate DTP for:	 =True =Not faulted =in operational range =not active =enabled P0562, P17AE, U18AC, P1774, P177A, U1343, U0077 > 1 sec	80 failures out of 100 samples 12.5 msec loop	DTC Type B Two Trips
		DTC Pass	1) DTP Gear & DTP Command AND 2) DTP Gear & DTP Command	1) = Armed = Arm 2) = UnArmed = Activate DTP				
Transmission Range Selector Enable Switch A Circuit Low	P17A3	Detects Selector Enable Switch A circuit reading low	Shift Enable Switch Measured Voltage Percent	<49 %	DTC enabling calibration: The controller has been awake for at least	=True =0.05 sec	7 failures out of 9 samples 12.5 msec loop	Emissions Neutral, Type C No MIL
		DTC Pass	Selector Enable Switch Measured Voltage Percent	Within acceptable Voltage Percent				
Transmission Range Selector Enable Switch A Circuit High	P17A4	Detects Selector Enable Switch A circuit reading high	Selector Enable Switch Measured Voltage Percent	> 82% 82% of 5 Volts = 4.1 Volts	DTC enabling calibration: The controller has been awake for at least:	=True =0.05 sec	7 failures out of 9 samples 12.5 msec loop	Emissions Neutral, Type C No MIL
		DTC Pass	Selector Enable Switch Measured Voltage Percent	Within acceptable Voltage Percent				

19 OBDG03B Electronic Transmission Range Selector - ICCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Transmission Range Selector Enable Switch A Circuit Performance	P17A5	Detects Selector Enable Switch A circuit reading outside "Released" or "Pressed" values	Selector Enable Switch Measured Voltage Percent	In-between the band created by 61% < X < 70%	Not Fault Active DTC enabling calibration: The controller has been awake for at least	P17A4, P17A3 =True = 0.05 seconds	40 failures out of 50 samples 12.5 msec loop	Emissions Neutral, Type C No MIL
		DTC Pass	Selector Enable Switch Measured Voltage Percent	Within acceptable Voltage Percent				
Transmission Range Selector Enable Switch A/B Correlation	P17A6	Correlation diagnosic compares both switches	Measured Voltage Percent of Selector Enable Switch A and Switch B	Are both VALID, (Release or Pressed), but disagree.	DTC enabling calibration = The controller has been awake for at least	True =0.05 seconds	12.5 msec rate. 48000 failures out of 48000 samples	Emissions Neutral, Type C No MIL
Transmission Range Selector Enable Switch B Circuit Low	P17A7	Detects Selector Enable Switch B circuit reading low	Selector Enable Switch Measured Voltage Percent	<49 %	DTC enabling calibration: The controller has been awake for at least	=True =0.05 sec	7 failures out of 9 samples 12.5 msec loop	Emissions Neutral, Type C No MIL
		DTC Pass	Selector Enable Switch Measured Voltage Percent	Within acceptable Voltage Percent				
Transmission Range Selector Enable Switch B Circuit High	P17A8	Detects Selector Enable Switch B circuit reading high	Selector Enable Switch Measured Voltage Percent	> 82%	DTC enabling calibration: The controller has been awake for at least	=True =0.05 sec	7 failures out of 9 samples 12.5 msec loop	Emissions Neutral, Type C No MIL
		DTC Pass	Selector Enable Switch Measured Voltage Percent	Within acceptable Voltage Percent				
Transmission Range Selector Enable Switch B Circuit Performance	P17A9	Detects Selector Enable Switch B circuit reading outside "Released" or "Pressed" values	Selector Enable Switch Measured Voltage Percent	61% < X < 70%	Not Fault Active DTC enabling calibration: The controller has been awake for at least	P17A8, P17A7 =True = 0.05 seconds	40 failures out of 50 samples 12.5 msec loop	Emissions Neutral, Type C No MIL
		DTC Pass	Selector Enable Switch Measured Voltage Percent	Within acceptable Voltage Percent				
Backup Park Lock Actuator Supply Voltage Circuit Low	P17CF	Determines if the Power Train Relay that supplies power to the DTP has been incorrectly switched off	Run Crank Switched Battery OR PowerTrain Relay Switched Battery OR Run Crank DTP Power on LIN Lost	=Active =Off =On = Off =Active =True	Not Fault Active Battery Voltage DTC enabling calibration System diagnostics System Voltage Low fault:	P0562, P17AE, U18AC, P1774, P177A, U1343, U0077 is in operating range =True Enabled Not active	80 failures out of 100 samples 12.5 msec loop	Type C No MIL
Transmission Range Control Slow Response	P17D5	The TRCM Slow Response Fault diagnostic test determines if the TRCM takes a long time to shift to the required range.	Time taken to achieve the requested range	> calibrated time specific to the range change	TRCM Wakeup time This diagnostic shall be enabled when all the following conditions are met: 1. DTC enabling calibration: 2. System diagnostics 3. TRCM detected position 4. TRCM Detected position message	> 3 sec =True =enabled =is available, valid, usable and not undefined =does not have a rolling count (ARC) or protection value (PV) error.	P -> R: 0.4 sec P -> N: 0.6 sec P -> D: 0.8 sec R -> P: 0.4 sec R -> N: 0.4 sec R -> D: 0.6 sec N -> P: 0.6 sec N -> R: 0.4 sec N -> D: 0.4 sec D -> P: 0.8 sec D -> R: 0.6 sec D -> N: 0.4 sec	Type C No MIL
		DTC Pass	Time taken to achieve the requested range AND A subset of the shift that failed the	< calibrated time specific to the range change				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Transmission Park Position Switch A/B Circuit Stuck On	P17F3	Checks if switch has been pressed for a long time Both switches have to be pressed at the same time, for a long time, for this DTC to set.	Both Park switches indicate PRESSED	for 60 seconds	DTC enabling calibration Controller: None of the corresponding circuit diagnostics are set. Both Park Switch signals:	= True is “On” for > 100 ms are valid for > 100 ms	60 seconds Additionally, in order to pass the diagnostic, both Park switches must read "released" for 1 sec.	DTC Type B, Two Trips
Transmission Range Selector Enable Switch A/B Circuit Stuck On	P17F4	Checks if switch has been pressed for a long time	Enable Switch A or B are PRESSED	For 600 seconds	DTC_enabling calibration = Controller:	True On	If both of the Park switches are detected to be in the pressed state for more than 600 seconds, then the DTC will be set. Additionally, in order to pass the diagnostic, both Park switches must read released for 1 second.	Emissions Neutral, Type C No MIL
P189D: Transmission Park Position Switch A/B Circuit Stuck Off	P189D	Correlation diagnosic compares Park Switch A and Park Switch B "PRESSED" and "RELEASED" states.	When either switch is “PRESSED” for 100 ms then "pressed event" is entered. Fault is incremented if other switch	At the 7th Park Request: one switch has been pressed <= 0.08 * total number of Park request presses, while the other switch has been pressed >= 0.8 * the total number of Park request presses.	Not Fault Active Current vehicle range = Comprehensive Correlation Diagnostics enabling cal: DTC enabling calibration: Controller is on Both park button switch signals: Vehicle Speed is low enough to honor Park request. Vehilce speed:	P07B3, P07B4, P07B5, P07B9, P07BA, P07BB NOT Park =True =True >~100 ms =valid <= Calibrated limit. The calibration name for the vehicle speed for checking for the Park button correlation diagnostics DTC: 10.5 and 10 (Hysteresis)	20 failures of 25 consecutive samples of button presses from non-park. The Park button is usually only pressed one time during a trip, so button presses are counted over key cycles. In one Park Request the two Park switch states are compared and when they are not equal for 3 consecutive software update cycles (each cycle takes 12.5 msec) then the x is incremented for one non-matching Park Button Press. In order to set the corresponding diagnostic, there must be at least 20 failed button presses out of 25 consecutive presses (the x/y counter).	DTC Type B, Two Trips MIL is set on the second occurrence of the fault.
Ignition 1 Switch Circuit Low Voltage	P2534	Detects if the Ignition1 Switch circuit is shorted to low or open	Ignition 1 voltage	<= 6 V	Engine	Running	180 failures out of 200 samples 25.0 msec loop	DTC Type B Two trips
Ignition 1 Switch Circuit High Voltage	P2535	Detects if the Ignition1 Switch circuit is shorted to vehicle supply voltage	Ignition 1 voltage	> 11.7 V	Hardwire Ignition	Off	180 failures out of 200 samples 25.0 msec loop	DTC Type B Two trips
Ignition Switch Accessory Position Circuit Low	P2537	Detects if the Accessory Position circuit is shorted to low or open	Accessory voltage	<= 6 V	Hardwire ignition	RUN/CRANK	180 failures out of 200 samples 25.0 ms loop	DTC Type B Two trips
Control Module Communication Bus A Off	U0073	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off state	Bus Status	= Off	Controller On Ignition U0073_00_ENABLE □	= True = Run/Crank OR = Accessory =True	0.5 second	DTC Type B Two Trips
Control Module Communication Bus E Off	U0077	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off state	Bus Status	= Off	Controller On Ignition	= True = Run/Crank OR = Accessory	0.5 second Monitoring runs continuously while GM LAN frames are being transmitted on the Chassis Expansion CAN bus.	DTC Type B Two Trips

19 OBDG03B Electronic Transmission Range Selector - ICCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Lost Communication With ECM/PCM A	U0100	Detects that CAN serial data communication has been lost with the ECM on HS GMLAN	Message $0BE, $0C9, $1A1, $1DF, $3C7, $4C1, $4F1	=Undetected	Controller On Ignition No Fault Active	= True = Run/Crank OR = Accessory U0073	Depends on CAN frame: 1.0 sec or 10 seconds. Monitored continuously while GMLAN frames are being transmitted.	DTC Type B Two Trips
Lost Communication With TCM	U0101	Detects that CAN serial data communication has been lost with the TCM Transmission Control Module on HS GMLAN	Message $0C1, $197, $1F5, 3F5	=Undetected	Controller On Ignition Non OBD Control Modules: Vehicle Power Mode condition: OBD Control Modules: Accessory Wake Up: U0101_00_ENABLE	= True = Run/Crank OR = Accessory RUN Active =True	1.0 second	DTC Type B Two Trips
Lost Communication With Anti-Lock Brake System (ABS) Control Module	U0121	Detects when CHCM or ECM loses Communication with Electronic Brake Control Module on HS GMLAN	Message $0C1, $214, $22A $500	=Undetected	Controller On Ignition Non OBD Control Modules: Vehicle Power Mode condition: OBD Control Modules: Accessory Wake Up: Virtual Network condition: U0121_00_ENABLE =	= True = Run/Crank OR = Accessory RUN Active Any Virtual Network that the module participates in is active True	$0C1: 1 second $214: 10 seconds $22A: 1 second $500: 10 seconds Monitored continuously while GMLAN frames are being transmitted.	DTC Type C No MIL
Lost Communication With Electric Park Brake Control Module (Starting with MY18 this content was merged into the U0121 DTC.) This DTC is shown here for reference.	U0128	Detects when CHCM loses Communication with Electronic Park Brake on HS GMLAN	Message $22A	=Undetected	Controller On Ignition	= True = Run/Crank OR = Accessory	1.0 second	DTC Type C No MIL
Lost Communication With Brake System Control Module	U0129	Detects that CAN serial data communication has been lost with the EBCM Transmission Control Module on GMLAN.	CAN messages are monitored continuously while GMLAN frames are being transmitted. Messages $0C1, $214, $22A, $500	=Undetected.	Controller On: Ignition: Non OBD Control Modules: Vehicle Power Mode condition: OBD Control Modules, e.g. ECM: Accessory Wake Up: Virtual Network condition: Bus off DTC U0073 U0129_00_ENABLE=	=TRUE = Run / Crank or Accessory Run Active	$0C1: 1 second $214: 10 seconds $22A: 1 second $500: 10 seconds Monitored continuously while GMLAN frames are being transmitted. □	Depends on the node. Typically Type B, two trips.

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Lost Communication With Body Control Module	U0140	Detects that CAN serial data communication has been lost with the BCM Body Control Module on HS GMLAN	Message $0F1, $12A, $139, $140, $142, $160, $1F1, $21D, $3F1	=Undetected	Controller On: Ignition: Non OBD Control Modules: Vehicle Power Mode condition: OBD Control Modules, e.g. ECM: Accessory Wake Up: Virtual Network condition: Bus off DTC U0073 U0140_00_ENABLE=	=TRUE = Run / Crank or Accessory Run Active	$0F1, $12A, $139, $160, $1F1: 1.0 second $140, $3F1: 10 seconds Monitored continuously while GMLAN frames are being transmitted.	DTC Type C
Lost Communication With Hybrid Powertrain Control Module	U0293	Monitored continuously while GMLAN frames are being transmitted.	The DTC sets upon notification of supervision timeout (passed up to the application from the handler). The DTC is set upon notification by the handler that associated supervised signal: A calibrateable debounce time, i.e. X of Y strategy, is permitted at the time that notification of failed supervision has been received by the application to delay storing of DTC.	has failed supervision.	Non OBD Control Modules: Vehicle Power Mode condition: OBD Control Modules: Accessory Wake Up: Virtual Network condition: Any Virtual Network that the module participates in is: DTC setting for that DTC # shall be disabled if its flag, U0293_00_ENABLE = however, failsoft actions shall still be taken if failure conditions are met. When a bus off condition (U0073) is= these Lost Communications DTCs shall not set but the failsoft action shall occur if conditions to set the DTC are met The conditions of "Lost Communication" DTCs are = □	RUN Active Active Disabled current not active	1 second	Type C No MIL
Invalid Data Received From Body Control Module	U0422	Signal between the BCM and door switches is unreliable	Driver Door Ajar Switch Virtual Device Availability OR Driver Door Open Switch Virtual Device Availability	= INVALID = INVALID	Battery voltage A diagnostic code clear event or diagnostic re-enable event is not in progress	within proper operating range for at least 3 seconds. For at least 3 seconds	12.5 msec loop Both the door ajar and the door open conditions will trigger a DTC if there are 10 failures out of 16 samples.	Emissions Neutral, Type C No MIL
Chassis Control Module LIN Bus 1	U1343	Detects that LIN serial data communication has been lost with the LIN Bus.	Bus Status	= Off	Controller On Ignition	= True = Run/Crank OR = Accessory	1.0 second	DTC Type B Two Trips
Loss of communication with Default to Park Actuator	U135A	Gen 1 ETRS: Detects when the CHCM Loses Communication with Default to Park through LIN bus.	Message $34 □	=Undetected for 500 msec	Controller On Ignition	= True for 3000 msec = Run/Crank OR = Accessory	500 msec	DTC Type B Two Trips
Lost Communication with Device D on Sub-Bus 6	U156D	Detects when the CHCM Loses Communication with Transmission Range Indicator Bezel	Message $21 on LIN	=Undetected	Controller On Ignition The DTC: U1505_00- Inter-Device Dedicated Bus 5	= True = Run/Crank OR Accessory =NOT active	This diagnostic will detect a loss of communication with the ETRS shifter. In order to set the corresponding U-code, the ETRS master must not receive an RPD response for 250 msec.	DTC Type C No MIL

19 OBDG03B Electronic Transmission Range Selector - ICCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Lost Communication With Transmission Range Control Module on Chassis Expansion CAN Bus	U18AC	Detects that CAN serial data communication has been lost with the TRCM on the Chassis Expansion Bus	Message $202, $204, $209	=Undetected	Controller On Ignition	= True for at least 500 msec = Run/Crank OR = Accessory	$202 frame: 1.0 second $204 frame: 10 second $209 frame: 0.5 second	DTC Type B Two Trips

Diagnostic Name	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Interlock Button Diagnostics								
Transmission Range Selector Enable Switch A Circuit High	P17A4	Detects Selector Enable Switch A circuit reading high	Selector Enable Switch Measured Voltage	> High 853 counts (1023 Cnts = 5 Volts)			16 Failures out of 20 Samples (SIB is 5 msec loop)	Emissions Neutral Type C No MIL
Transmission Range Selector Enable Switch A Circuit Low	P17A3	Detects Selector Enable Switch A circuit reading low	Shift Enable Switch Measured Voltage	< Low 446 counts (1023 Cnts = 5 Volts)			16 Failures out of 20 Samples (SIB is 5 msec loop)	Emissions Neutral Type C No MIL
Transmission Range Selector Enable Switch A Circuit Performance	P17A5	Detects Selector Enable Switch A circuit reading outside "Released" or "Pressed" values	Selector Enable Switch Measured Voltage	544 < X < 753 counts (1023 Cnts = 5 Volts)	Not Fault Active	P17A4, P17A3	100 Failures out of 120 Samples (SIB is 5 msec loop)	Emissions Neutral Type C No MIL
Transmission Range Selector Enable Switch B Circuit High	P17A8	Detects Selector Enable Switch B circuit reading high	Selector Enable Switch Measured Voltage	> High 853 counts (1023 Cnts = 5 Volts)			16 Failures out of 20 Samples (SIB is 5 msec loop)	Emissions Neutral Type C No MIL
Transmission Range Selector Enable Switch B Circuit Low	P17A7	Detects Selector Enable Switch B circuit reading low	Selector Enable Switch Measured Voltage	< Low 446 counts (1023 Cnts = 5 Volts)			16 Failures out of 20 Samples (SIB is 5 msec loop)	Emissions Neutral Type C No MIL
Transmission Range Selector Enable Switch B Circuit Performance	P17A9	Detects Selector Enable Switch B circuit reading outside "Released" or "Pressed" values	Selector Enable Switch Measured Voltage	544 < X < 753 counts (1023 Cnts = 5 Volts)	Not Fault Active	P17A8, P17A7	100 Failures out of 120 Samples (SIB is 5 msec loop)	Emissions Neutral Type C No MIL
Park Button Diagnostics								
Transmission Park Position Sensor/Switch A Circuit High	P07B4	The Park Button Circuit Diagnostic detects a reading High	Park Position Measured Voltage	> High 853 counts (1023 Cnts = 5 Volts)			16 Failures out of 20 Samples (SIB is 5 msec loop)	DTC Type B, Two Trips
Transmission Park Position Sensor/Switch A Circuit Low	P07B3	The Park Button Circuit Diagnostic detects a reading Low	Park Position Measured Voltage	< Low 446 counts (1023 Cnts = 5 Volts)			16 Failures out of 20 Samples (SIB is 5 msec	DTC Type B, Two

Diagnostic Name	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
							loop)	Trips
Transmission Park Position Sensor/Switch A Circuit Performance	P07B5	The Park Button Circuit Diagnostic detects a reading that is outside of the PRESSED and RELEASED zones.	Park Position Measured Voltage	544 < X < 753 counts (1023 Cnts = 5 Volts)	DTC not set	P07B3 OR P07B4	100 Failures out of 120 Samples (SIB is 5 msec loop)	DTC Type B, Two Trips
Transmission Park Position Sensor/Switch B Circuit High	P07BA	The Park Button Circuit Diagnostic detects a reading High	Park Position Measured Voltage	> High 853 counts (1023 Cnts = 5 Volts)			16 Failures out of 20 Samples (SIB is 5 msec loop)	DTC Type B, Two Trips
Transmission Park Position Sensor/Switch B Circuit Low	P07B9	The Park Button Circuit Diagnostic detects a reading Low	Park Position Measured Voltage	< Low 446 counts (1023 Cnts = 5 Volts)			16 Failures out of 20 Samples (SIB is 5 msec loop)	DTC Type B, Two Trips
Transmission Park Position Sensor/Switch B Circuit Performance	P07BB	The Park Button Circuit Diagnostic detects a reading that is outside of the PRESSED and RELEASED zones.	Park Position Measured Voltage	544 < X < 753 counts (1023 Cnts = 5 Volts)	DTC not set	P07BA P07B9	100 Failures out of 120 Samples (SIB is 5 msec loop)	DTC Type B, Two Trips
SIB Controller Fault Diagnostics								
Transmission Range Selector Control Module Memory Checksum Error	P17D8	This DTC will be stored if any software or calibration check sum is incorrect. Modeled after GMs DTC P0601	Calculated Checksum	≠ stored checksum for any of the parts (boot, software, application calibration, system calibration)	Ignition OR Accessory	Run or Run/Crank ON	1 failure if it occurs during the first ROM test of the ignition cycle, otherwise 5 failures Frequency: Runs continuously in the background	DTC Type A 1 trip
		Circuit Monitor mismatch occurs	Switch circuit calculated values	≠ switch circuit monitor values	Ignition OR Accessory	Run or Run/Crank ON	Test runs during calculation of switch circuit	

Diagnostic Name	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
							values	
Transmission Range Selector Control Module Read Only Memory (ROM) Error	P17D9	Reports a failure if the Built in self test for ROM checksum or the ROM Error correcting code (ECC) check fails.	Checksum at power up	≠ checksum at power-down	Ignition OR Accessory	Run or Run/Crank ON	1 failure Frequency: Once at power-up	DTC Type A 1 trip
			ROM ECC	= fault	Ignition OR Accessory	Run or Run/Crank ON	1 failure Frequency: Runs continuously in the background	
Transmission Range Selector Control Module Internal Random Access Memory (RAM) Error	P17DA	Indicates that control module is unable to correctly write and read data to and from RAM. Modeled after GMs DTC P0604	Data read	≠ Data written	Ignition OR Accessory	Run or Run/Crank ON	1 failure if it occurs during the first RAM test of the ignition cycle, otherwise 5 failures Frequency: Runs continuously in the background	DTC Type A 1 trip
Transmission Range Selector Control Module Processor	P17DB	Indicates the ECU has detected an internal processor fault. This DTC is dependent on the microprocessor and includes self testing not listed. Modeled after GMs DTC P0606			Ignition Accessory	Run or Run/Crank OR ON		DTC Type A 1 trip

Diagnostic Name	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
		1. Microprocessor ALU Integrity Diagnostic Monitor Algorithm	Calculated key from rolling seed	≠ expected key			1 failure Test runs continuously (20ms loop or less)	
		2. Main Processor Configuration Register Test	Processor register	≠ expected processor register value			1 failure Test runs continuously (20ms loop or less)	
		3: Seed and Key fault (Set by ECM when seeds and keys do not match)					1 failure Test runs continuously (25ms loop or less)	
		4. Stack overflow	Unused stack memory above maximum stack used	≠ initialized special pattern			1 failure Test run by OS on task switches	
		5. Program Counter exception error	Illegal instruction loaded into program counter				1 failure	
		6. Watchdog Fails to reset	If a fault that should cause a reset fails to cause a reset.				1 failure	
Power Moding Diagnostics								
Transmission Range Selector Control Module System Voltage Low	P17DD	Sets when the low voltage system voltage is below a threshold	Battery Voltage	<= 10 Volts	Engine Controller Run Crank Terminal Status - CAN Message	= 1 indicating RUN/CRANK	5 seconds in a 6 second window	Type C
Transmission Range Selector Control Module System Voltage Performance	P17DF	Sets when voltage system voltage signal is erratic.	Battery Voltage Measured Delta Over 10 ms	> 3 Volts	Engine Controller Run Crank Terminal Status - CAN Message	= 1 indicating RUN/CRANK	16 failures out of 40 Samples (SIB is 5 msec loop)	Type C
Transmission Range Selector Control Module System Voltage High	P17DE	Sets when the low voltage system voltage is above a threshold	Battery Voltage	> 16 Volts	Engine Controller Run Crank Terminal Status - CAN Message	= 1 indicating RUN/CRANK	5 seconds in a 6 second window	Type C

Diagnostic Name	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Transmission Range Selector Control Module Ignition On/Start Switch Circuit Low	P17E0	Detects if the Ignition1 Switch circuit is shorted to low or open	Ignition 1 voltage	<= 6 V	Engine Controller Run Crank Terminal Status - CAN Message	= 1 indicating RUN/CRANK	4.5 sec in 5.5 second window	Type B 2 trips
Transmission Range Selector Control Module Ignition On/Start Switch Circuit High	P17E1	Detects if the Ignition1 Switch circuit is shorted to vehicle supply voltage	Ignition 1 voltage	> 11.7 V	Engine Controller Run Crank Terminal Status - CAN Message	= 0 indicating NOT RUN/CRANK	4.5 sec in 5.5 second window	Type B 2 trips
Transmission Range Selector Control Module Ignition Accessory Circuit Low	P17E2	Detects if the Accessory Position circuit is shorted to low or open	Accessory voltage	<= 6 V	-	-	4.5 sec in 5.5 second window	DTC Type C
Communication Diagnostics								
Transmission Range Selection Signal Message Counter Incorrect	P17D7	ARC & PV reported SIB for $1E8 signal from the ECM on Powertrain Sensor CAN Bus	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Ignition	Run or Run/Crank	1 second	DTC Type B 2 trips
Transmission Range Selector Control Module Powertrain Sensor CAN Bus Off	U240E	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off state	Powertrain Sensor Bus Status	Off	Ignition	Run or Run/Crank	1 second	DTC Type B 2 trips
Transmission Range Selector Control Module Powertrain Expansion CAN Bus Off	U240D	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off state	Powertrain Expansion Bus Status	Off	Ignition	Run or Run/Crank	1 second	DTC Type B 2 trips

Diagnostic Name	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Transmission Range Selector Control Module Lost Communication with Engine Control Module on Powertrain Sensor CAN Bus	U18C6	Detects that CAN serial data communication has been lost with the ECM.	Powertrain Sensor Bus Message $1E2 OR $1E8	Undetected	Ignition 2. Ignition Run/Crank Voltage	Run or Run/Crank 11V<RCVolt <32V	1 second	DTC Type B 2 trips
LED Diagnostics								
Shifter Interface Board Range Indicator Failed OR Remote PRNDL Display Internal Electronic Failure	B071F	Detects an indicator LED circuit with a latent fault where an indicator LED could light with a single fault	When sequencing transitors Circuit Feedback Current	> 520 uA (worst case)	Ignition	Run or Run/Crank	detected within 50 ms at first key up	DTC Type C

Diagnostic Name	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Transmission Range Control Module Read Only Memory (ROM)	P17AA	This DTC will be stored if any software or calibration check sum is incorrect.	Calculated Checksum	≠ stored checksum for any of the parts (boot, software, application calibration, system calibration) Note: ROM start & end are calibratable.	Hardwire Powermode	= Run/Crank OR =Accessory	1 failure if it occurs during the first ROM test of the ignition cycle, otherwise 5 failures Runs continuously in the background and takes 300 ms to complete ROM check	DTC Type A One Trip
Transmission Range Control Module Not Programmed	P17AB	Indicates that the ECU needs to be programmed	No Start Calibration Or Calibration	= TRUE ≠ VALID	Hardwire Powermode	= Run/Crank OR =Accessory	Runs at power up And continously	DTC Type A One Trip
Transmission Range Control Module Long Term Memory Reset	P17AC	Non-volatile memory checksum error at controller power-up.	Checksum at power-up	≠ checksum at power-down	Hardwire Powermode	= Run/Crank OR =Accessory	1 failure Frequency: Once at power-up	DTC Type A One Trip
Transmission Range Control Module Random Access Memory (RAM)	P17AD	Indicates that control module is unable to correctly write and read data to and from RAM.	Data read OR ECC	≠ Data written Has ERROR	Hardwire Powermode	= Run/Crank OR =Accessory	1 failure if it occurs during the first RAM test of the ignition cycle, otherwise 5 failures Runs continuously in the background and takes 500 ms to complete RAM block check	DTC Type A One Trip
Transmission Range Control Module Internal Performance	P17AE	Indicates the ECU has detected an internal processor fault or external watchdog fault			Hardwire Powermode	= Run/Crank OR =Accessory		DTC Type A One Trip
		Micro data update check Micro data sequence check	Rolling Count OR Maximum Flow Count	=ERROR OR =ERROR			Error set A=10 times	
		Main Processor Configuration Register	I/O configuration register faults	=Incorrect value			3 failures during run crank cycle	
		Processor clock test	Processor Clock	=Faulted			1 failure Runs continuously	
		External watchdog test	External Watchdog	=Faulted			1 failure during power up	
		Internal watchdog test	Internal Watchdog	=Faulted			57 failures out of 71 samples	
		PWM pin status during	PWM pin status at power up	=INCORRECT VALUE (1)			1 failures during power up	
		Microcontroller configuration register test and interrupt performance monitor test	Configuration register value Number of interrupt calls	=INCORRECT VALUE =INCORRECT VALUE			5 out failures out of 5 samples for register test and 10 out of 10 for interrupt performance	
		ALU test	ALU result	=INCORRECT VALUE			3 failures during run crank cycle	
		Memory stack over flow	Memory stack usage	>75% stack memory			3 failures during run crank cycle	
		ADC internal error	ADC internal reference ADC external reference does not run below 6Volts	=INCORRECT VALUE =INCORRECT VALUE			3 failures during run crank cycle	
Transmission Range Control Module System Voltage Low	P17B0	Sets when the battery system voltage is below a threshold	Battery Voltage	<= 9 Volts	U18AA AND CAN message OR Hardwire Powermode OR PT Crank Active	=Not Faulted =RUN/CRANK =Accessory =false (min time & max time enabled)	5 seconds in a 6 second window	DTC Type C No MIL

Diagnostic Name	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Transmission Range Control Module System Voltage Performance	P17B1	Sets when battery system voltage signal is erratic.	Battery Voltage Measured Delta Over 15ms	> 3 Volts	CAN message OR Hardwire Powermode PT Crank Active	=RUN/CRANK =Accessory =false (min time & max time enabled)	40 out of 50 counts 25ms sample	DTC Type C No MIL
Transmission Range Control Module System Voltage High	P17B2	Sets when the battery voltage is above a threshold	Battery Voltage	> 16 Volts	U18AA AND CAN message OR Hardwire Powermode PT Crank Active	=Not Faulted =RUN/CRANK =ACC =false (min time & max time enabled)	5 seconds in a 6 second window	DTC Type C No MIL
Transmission Range Control Module Ignition 1 Switch Circuit Low Voltage	P17B3	Detects if the Ignition1 Switch circuit is shorted to low or open	Ignition 1 voltage	<= 8 V	U18AA AND CAN message OR Hardwire Powermode PT Crank Active	=Not Faulted =RUN/CRANK =ACC =false (min time & max time enabled)	180 failures out of 200 samples 25ms sample	Type B Two Trips
Transmission Range Control Module Ignition 1 Switch Circuit High Voltage	P17B4	Detects if the Ignition1 Switch circuit is shorted to vehicle supply voltage	Ignition 1 voltage	> 11.7 V	U18AA AND CAN message OR Hardwire Powermode PT Crank Active	=Not Faulted = NOT RUN/CRANK =Accessory =false (min time & max time enabled)	180 failures out of 200 samples 25ms sample	DTC Type B Two Trips
Transmission Range Control Module Ignition Switch Accessory Position Circuit Low	P17B5	Detects if the Accessory Position circuit is shorted to low or open	Accessory voltage	<= 6 V	U18AA AND CAN message OR Hardwire Powermode PT Crank Active	=Not Faulted =RUN/CRANK =ACC =false (min time & max time enabled)	180 failures out of 200 samples 25ms sample	DTC Type C No MIL
Transmission Range Control Module Sensor Reference A Circuit Low	P173A	This diagnostic monitors the buffered 5V supply circuit A	5V supply circuit measured percentage	X < 95%	Battery Voltage Hardwire Powermode	> 9 volts =Run/Crank OR =Accessory	4 seconds	DTC Type B Two Trips
		DTC Pass	5V supply circuit measured	95% < X < 115%			1 second	
Transmission Range Control Module Sensor Reference A Circuit High	P173B	This diagnostic monitors the buffered 5V supply circuit A	5V supply circuit measured percentage	X > 115%	Battery Voltage Hardwire Powermode	> 9 volts =Run/Crank OR =Accessory	4 seconds	DTC Type B Two Trips
		DTC Pass	5V supply circuit measured percentage	95% < X < 115%			1 second	
Transmission Range Control Module Sensor Reference A Circuit Intermittent/Erratic	P173C	For Safety: This diagnostic monitors the 5V Reference A Circuit for a noisy/erratic failure	5V Reference A Voltage Measured Delta Over 15ms	> 0.325 Volts	Battery Voltage Hardwire Powermode	> 9 volts =Run/Crank OR =Accessory	75 ms out of a 300 ms window	DTC Type B Two Trips
Transmission Range Control Module Sensor Reference B Circuit Low	P173D	This diagnostic monitors the buffered 5V supply circuit B	5V supply circuit measured percentage	X < 95%	Battery Voltage Hardwire Powermode	> 9 volts =Run/Crank OR =Accessory	4 seconds	DTC Type B Two Trips
		DTC Pass	5V supply circuit measured percentage	95% < X < 115%			1 second	

Diagnostic Name	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Transmission Range Control Module Sensor Reference B Circuit High	P173E	This diagnostic monitors the buffered 5V supply circuit B	5V supply circuit measured percentage	X > 115%	Battery Voltage Hardwire Powermode	> 9 volts =Run/Crank OR =Accessory	4 seconds	DTC Type B Two Trips
		DTC Pass	5V supply circuit measured percentage	95% < X < 115%			1 second	
Transmission Range Control Module Sensor Reference B Circuit Intermittent/Erratic	P173F	For Safety: This diagnostic monitors the 5V Reference B Circuit for a noisy/erratic failure	5V Reference B Voltage Measured Delta Over 15ms	> 0.325 Volts	Battery Voltage Hardwire Powermode	> 9 volts =Run/Crank OR =Accessory	75 ms out of a 300 ms window	DTC Type B Two Trips
Transmission Range Control Module Rotary Shaft Postion Loss of Signal	P17B6	Sets when the TRCM detects the signal from the Rotary Shaft Position is Lost			Hardwire Powermode	= Run/Crank OR =Accessory	57 failures out of 71 samples 5 ms loop	DTC Type A One Trip
Transmission Range Control Module Rotary Shaft Postion Signal Low	P17B7	Sets when the TRCM detects the signal from the Rotary Shaft Position is Low.	Measured counts <	300 counts (6.6 deg)	Hardwire Powermode	= Run/Crank OR =Accessory	57 failures out of 71 samples 5 ms loop	DTC Type A One Trip
Transmission Range Control Module Rotary Shaft Postion Signal High	P17B8	Sets when the TRCM detects the signal from the Rotary Shaft Position is High.	Measured counts >	3500 count (76.9 deg)	Hardwire Powermode	= Run/Crank OR =Accessory	57 failures out of 71 samples 5 ms loop	DTC Type A One Trip
Transmission Range Control Module Rotary Shaft Postion Perfomance	P17B9	Set when the TRCM detects the diagnostic data from the Rotary Sensor indicates an internal failure.	Micro Fault	= ADC failure, ADC saturation, Analog Gain too Low, Magnetic Field too Weak, Magnetic Field too Strong, Analog Gain too High, Offset too High OR Device Vdd > 7V	Hardwire Powermode	= Run/Crank OR =Accessory	57 failures out of 71 samples 5 ms loop	DTC Type A One Trip
Transmission Range Control Module Motor Enable Circuit Low	P17BA	Transmission Range Control Module Motor Enable Circuit Low Diagnostic detects when the TRCM MOSFET enable circuit is low	Measured Voltage Percent (hardware fault)	<2 %	Hardwire Powermode MOSFET Status DTP Status (CE) U18A9 PT Crank Active	= Run/Crank OR =Accessory =On = Not Active =Not Faulted =false (min time & max time enabled)	60 Failures out of 60 Samples 5 ms loop	DTC Type A One Trip
Transmission Range Control Module Motor Enable Circuit High	P17BB	Transmission Range Control Module Motor Enable Circuit High Diagnostic detects when the TRCM MOSFET enable circuit is shorted	Measured Voltage	Less than 0.4 volts OR greater than 1.1 volts	Hardwire Powermode PT Crank Active	=Run or Crank OR =Accessory =false (min time & max time enabled)	60 Failures out of 60 Samples 5 ms loop	DTC Type B, Two Trips
Transmission Range Control Module Range Motor Voltage Low	P17BC	Transmission Range Control Module Range Motor Voltage Low Diagnostic detects when any of the TRCM Motor Control MOSFETS are open	Measured Voltage Percent (spread sheet depending on on & off & overall voltage done in background)	<2 %	Hardwire Powermode MOSFET Status DTP Status (CE) U18A9 PT Crank Active	= Run/Crank OR =Accessory =On = Not Active =Not Faulted =false (min time & max time enabled)	60 Failures out of 60 Samples 5 ms loop	DTC Type A One Trip

Diagnostic Name	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Transmission Range Control Module Range Motor Voltage High	P17BD	Transmission Range Control Module Range Motor Voltage High Diagnostic detects when any of the TRCM Motor Control MOSFETS are shorted	Measured Voltage Percent (spread sheet depending on on & off & overall voltage done in background)	> 98%	Hardwire Powermode MOSFET Status DTP Status (CE) U18A9 PT Crank Active	= Run/Crank OR =Accessory =On = Not Active =Not Faulted =false (min time & max time enabled)	60 Failures out of 60 Samples 5 ms loop	DTC Type A One Trip
Transmission Range Select Motor Control Circuit Current Too High	P17BF	Detects when the TRCM Motor Control Circuit has high current	Uses comparitor	> hardware set value 34 amps	Hardwire Powermode	= Run/Crank OR =Accessory	Retry algorithm such that diagnostic sets with 6 failures within 400 msec OR sets if it does not reach the commanded range with 1 or more failures >= 400 msec	DTC Type A One Trip
Transmission Range Control Module High Speed CAN Bus Off	U2409	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off state	Bus Status	= Off	Hardwire Powermode	= Run/Crank OR =Accessory	1 second	DTC Type B Two Trips
TRCM Lost Communication With ECM on HS GMLAN CAN Bus	U18AA	Detects that CAN serial data communication has been lost with the ECM	Message $4C1, $0C9, $1DF, $4F1, Plus $1F7 on Gen2	Undetected	Hardwire Powermode	= Run/Crank OR =Accessory	25 failures out of 25 samples 40 ms loop (1 sec)	DTC Type B Two Trips
Lost Communication With CHCM on HS GMLAN CAN Bus	U18AB	Detects when the TRCM Loses Communication with CHCM on HS GMLAN Bus "A"	Message $1F7	Undetected	Hardwire Powermode	= Run/Crank OR =Accessory	1 second	DTC Type B Two Trips
Transmission Range Control Module Range Command Signal Message Counter Incorrect	P174B	ARC & PV report by TRCM about signal $1F7 from CHCM or ECM on GMLAN Bus "A"	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Hardwire Powermode	= Run/Crank OR =Accessory	4 seconds (160 messages)	DTC Type B Two Trips
Lost Communication With CHCM on Chassis Expansion CAN Bus "B"	U18A9	Detects when the TRCM Loses Communication with the CHCM on the CE Bus "B"	Message $207	Undetected	Hardwire Powermode	= Run/Crank OR =Accessory	1 second	DTC Type B Two Trips
Lost Communication With EBCM on Chassis Expansion CAN Bus "B"	U18AD	Detects when the TRCM Loses Communication with the EBCM on the CE Bus "B"	Message $0C1, $500	Undetected	Hardwire Powermode	= Run/Crank OR =Accessory	1 second	DTC Type C No MIL
Transmission Range Control Module Wheel Speed Signal Message Counter Incorrect	P174C	Sets if wheel speed CAN data $0C1 is invalid or error on CAN sequence number data.	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR Validity	Current ARC ≠ Previous ARC +1 not Valid	Hardwire Powermode	= Run/Crank OR =Accessory	1.1 seconds (110 messages)	DTC Type C No MIL

Diagnostic Name	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
TRCM ETRS General Status Signal Message Incorrect	P1771	GEN1: ARC & PV reported TRCM for $207 signal from the CHCM GEN2: ARC & PV reported TRCM for $1D7 signal from the ECM	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1 OR The primary signal value does not equal the protection value	Current ARC ≠ Previous ARC +1 Primary Value ≠ Protection Value	Hardwire Powermode	= Run/Crank OR =Accessory	4 seconds (160 messages)	DTC Type B Two Trips
Transmission Range Control Module Chassis Expansion CAN Bus Off	U240A	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off state	Bus Status	= Off	Hardwire Powermode	= Run/Crank OR =Accessory	1 second	DTC Type B Two Trips
Transmission Range Control Module Range Not Learned	P174D	If the values are not populated with values during the learn process, then this DTC is set			Hardwire Powermode	= Run/Crank OR =Accessory		DTC Type A One Trip
Transmission Range Control Module Range Motor Protection Mode Active	P17C8	Detects and reports fault when the motors are shut off for protection and the actual range is not achieved	Motors are shut off for motor/circuit protection.	This can happen in as short as 500 ms. Record commanded range at motor shut down	Not Fault Active	P17B6, P17B7, P17B8, P17B9	500 msec	DTC Type B One Trip
		DTC Pass	On a new command from CHCM and Range Commanded (range that it failed in) Motor Status	=Actual Range Achieved ≠ Protection Shutdown				
Lost Communication With ECM on Powertrain Expansion Bus	U18CC	Detects when the TRCM Loses Communication with the ECM on the PT EXP Bus	Message $1D7	Undetected	Hardwire OR (Enable Cal AND Hardwire	=Run or Crank OR = ok to run in ACC =Accessory)	1 second	DTC Type B 2 trips
Lost Communication With EBCM on HS GMLAN	U240F	Detects when the TRCM Loses Communication with the EBCM on HS GMLAN	Message $0C1, $500	Undetected	Hardwire OR (Enable Cal AND Hardwire	=Run or Crank OR = ok to run in ACC =Accessory)	1 second	DTC Type C
Lost Communication With BCM on HS GMLAN	U2410	Detects when the TRCM Loses Communication with the BCM on HS GMLAN	Message $1F1	Undetected	Hardwire OR (Enable Cal AND Hardwire	=Run or Crank OR = ok to run in ACC =Accessory)	4 seconds	DTC Type C

Diagnostic Name	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Transmission Range Control Module Powertrain Expansion Bus Off	U2411	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off state	Bus Status	Off	Hardwire OR (Enable Cal AND Hardwire	=Run or Crank OR = ok to run in ACC =Accessory)	1 second	DTC Type B 2 trips
Lost Communication With EBCM on Chassis Expansion CAN Bus "B"	U18AD	Detects when the TRCM Loses Communication with the EBCM on the CE Bus "B"	CAN frames $0C1, $500	Undetected	Hardwire Powermode	= Run/Crank OR =Accessory	1 second	Emissions Neutral, Type C No MIL Controller "Action" in case this DTC sets: If this CAN bus is lost then wheel speed information is not available. Therefore assume zero vehicle speed.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
Group 1 - Wheel Speed Sensor							
WSS_OPEN_FRONT_LEFT	C0502	• Polaris ASIC sets FL Open Sensor bit = TRUE when High side current < 3.5mA	• Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	Polaris ASIC Open Sensor Bit= True	• Wheel speed sensor supply is enabled	100 ms	Type A. MIL Illumination.
WSS_OPEN_FRONT_RIGHT	C0508	• Polaris ASIC sets FR Open Sensor bit = TRUE when High side current < 3.5mA	• Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	Polaris ASIC Open Sensor Bit= True	• Wheel speed sensor supply is enabled	100 ms	Type A. MIL Illumination.
WSS_OPEN_REAR_LEFT	C050E	• Polaris ASIC sets RL Open Sensor bit = TRUE when High side current < 3.5mA	• Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	Polaris ASIC Open Sensor Bit= True	• Wheel speed sensor supply is enabled	100 ms	Type A. MIL Illumination.
WSS_OPEN_REAR_RIGHT	C0514	• Polaris ASIC sets RR Open Sensor bit = TRUE when High side current < 3.5mA	• Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	Polaris ASIC Open Sensor Bit= True	• Wheel speed sensor supply is enabled	100 ms	Type A. MIL Illumination.
WSS_SHORT_FRONT_LEFT	C0503	• Polaris Asic sets XX HS OC = TRUE when High side current > 40mA	• HS Shorted to Battery • LS Shorted to Battery • Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	High side over current bit= True OR High side short to battery bit= True OR Low side over current bit= True OR Low side short to ground bit= True	• Wheel speed sensor supply is enabled	100 ms	Type A. MIL Illumination.
WSS_SHORT_FRONT_RIGHT	C0509	• Polaris Asic sets XX HS OC = TRUE when High side current > 40mA	• HS Shorted to Battery • LS Shorted to Battery • Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	High side over current bit= True OR High side short to battery bit= True OR Low side over current bit= True OR Low side short to ground bit= True	• Wheel speed sensor supply is enabled	100 ms	Type A. MIL Illumination.
WSS_SHORT_REAR_LEFT	C050F	• Polaris Asic sets XX HS OC = TRUE when High side current > 40mA	• HS Shorted to Battery • LS Shorted to Battery • Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	High side over current bit= True OR High side short to battery bit= True OR Low side over current bit= True OR Low side short to ground bit= True	• Wheel speed sensor supply is enabled	100 ms	Type A. MIL Illumination.
WSS_SHORT_REAR_RIGHT	C0515	• Polaris Asic sets XX HS OC = TRUE when High side current > 40mA	• HS Shorted to Battery • LS Shorted to Battery • Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	High side over current bit= True OR High side short to battery bit= True OR Low side over current bit= True OR Low side short to ground bit= True	• Wheel speed sensor supply is enabled	100 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_LS_SHORT_TO_GND_FRONT_LEFT	C0502	• Polaris Asic sets XX LS SHORT TO GROUND spi bit= TRUE	• LS Shorted to Ground • Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC		• Wheel speed sensor supply is enabled	100 ms	Type A. MIL Illumination.
WSS_LS_SHORT_TO_GND_FRONT_RIGHT	C0508	• Polaris Asic sets XX LS SHORT TO GROUND spi bit= TRUE	• LS Shorted to Battery • Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC		• Wheel speed sensor supply is enabled	100 ms	Type A. MIL Illumination.
WSS_LS_SHORT_TO_GND_REAR_LEFT	C050E	• Polaris Asic sets XX LS SHORT TO GROUND spi bit= TRUE	• LS Shorted to Battery • Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC		• Wheel speed sensor supply is enabled	100 ms	Type A. MIL Illumination.
WSS_LS_SHORT_TO_GND_REAR_RIGHT	C0514	• Polaris Asic sets XX LS SHORT TO GROUND spi bit= TRUE	• LS Shorted to Battery • Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC		• Wheel speed sensor supply is enabled	100 ms	Type A. MIL Illumination.
WSS_MISSING_FRONT_LEFT	C0505	Missing Wheel Speed Sensor If one sensor shows a speed of less than 1.5 km/h (standstill detection threshold) while the other sensors indicate a speed greater than 6 km/h, then a missing sensor signal fault occurs. The detection is dependant on the speed of the wheels showing a valid signal. If the average speed of moving wheel (6km/h) is greater than 50 km/h and/or any undroven wheel speed is greater than 6km/h, the fault detection time is faster. The entire test sequence is bypassed whenever unexpected wheel acceleration is detected to induce ABS (DRP) activation. The purpose of this handling is to avoid erroneous fault detection. Special case is during ABS, only if the wheel is in pressure dump state, then the detection is run and the detection time is increased.	• Wheel speed sensor not mounted correctly. • Wheel speed sensor to tone-ring gap out of tolerance. • Demagnetized tone-ring.	If one sensor shows a speed of less than 1.5 km/h (standstill detection threshold) while the other sensors indicate a speed greater than 6 km/h, then a missing sensor signal fault occurs. The detection is dependant on the speed of the wheels showing a valid signal. If the average speed of moving wheel (6km/h) is greater than 50 km/h and/or any undriven wheel speed is greater than 6km/h the fault detection time is faster. The entire test sequence is bypassed whenever unexpected wheel acceleration is detected to induce ABS (DRP) activation. The purpose of this handling is to avoid erroneous fault detection. Special case is during ABS, only if the wheel is in pressure dump state, then the detection is run and the detection time is increased.	• Wheel speed sensor supply is enabled. • No Ohmic wheel speed sensor failure present. • No Wss Erratic or Wss Dropout fault present • At least one WSS > 6kph • No excessive high or low voltage • Diagnostic Mode Inactive • Emissions Rolls Test Inactive	3-120s depending on number of missing wss and situation	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
		The failsafe will not run in case • exactly one axle is moving (other axle is standstill) while the moving axle shows an average velocity of less than 10km/h (to prevent setting Missing Wss faults on a roller bench). • the dynamic failsafe is currently disabled because the system is currently in Diagnostic mode. Counter type: Counter up and the fault counter reset If all sensors show a speed greater than 6 km/h or the vehicle is in standstill (all sensors lower than 1.5 km/h) Fault maturation time is 3 sec – 15 sec for one, 3 sec – 30 sec for two (15 sec during ABS) and 120 sec for three missing sensors.					
WSS_MISSING_FRONT_RIGHT	C050B	Missing Wheel Speed Sensor If one sensor shows a speed of less than 1.5 km/h (standstill detection threshold) while the other sensors indicate a speed greater than 6 km/h, then a missing sensor signal fault occurs. The detection is dependant on the speed of the wheels showing a valid signal. If the average speed of moving wheel (6km/h) is greater than 50 km/h and/or any undroven wheel speed is greater than 6km/h, the fault detection time is faster. The entire test sequence is bypassed whenever unexpected wheel acceleration is detected to induce ABS (DRP) activation. The purpose of this handling is to avoid erroneous fault detection. Special case is during ABS, only if the wheel is in pressure dump state, then the detection is run and the detection time is increased.	• Wheel speed sensor not mounted correctly. • Wheel speed sensor to tone-ring gap out of tolerance. • Demagnetized tone-ring.	If one sensor shows a speed of less than 1.5 km/h (standstill detection threshold) while the other sensors indicate a speed greater than 6 km/h, then a missing sensor signal fault occurs. The detection is dependant on the speed of the wheels showing a valid signal. If the average speed of moving wheel (6km/h) is greater than 50 km/h and/or any undriven wheel speed is greater than 6km/h the fault detection time is faster. The entire test sequence is bypassed whenever unexpected wheel acceleration is detected to induce ABS (DRP) activation. The purpose of this handling is to avoid erroneous fault detection. Special case is during ABS, only if the wheel is in pressure dump state, then the detection is run and the detection time is increased.	• Wheel speed sensor supply is enabled. • No Ohmic wheel speed sensor failure present. • No Wss Erratic or Wss Dropout fault present • At least one WSS > 6kph • No excessive high or low voltage • Diagnostic Mode Inactive • Emissions Rolls Test Inactive	3-120s depending on number of missing wss and situation	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
		The failsafe will not run in case • exactly one axle is moving (other axle is standstill) while the moving axle shows an average velocity of less than 10km/h (to prevent setting Missing Wss faults on a roller bench). • the dynamic failsafe is currently disabled because the system is currently in Diagnostic mode. Counter type: Counter up and the fault counter reset If all sensors show a speed greater than 6 km/h or the vehicle is in standstill (all sensors lower than 1.5 km/h) Fault maturation time is 3 sec – 15 sec for one, 3 sec – 30 sec for two (15 sec during ABS) and 120 sec for three missing sensors.					
WSS_MISSING_REAR_LEFT	C0511	Missing Wheel Speed Sensor If one sensor shows a speed of less than 1.5 km/h (standstill detection threshold) while the other sensors indicate a speed greater than 6 km/h, then a missing sensor signal fault occurs. The detection is dependant on the speed of the wheels showing a valid signal. If the average speed of moving wheel (6km/h) is greater than 50 km/h and/or any undroven wheel speed is greater than 6km/h, the fault detection time is faster. The entire test sequence is bypassed whenever unexpected wheel acceleration is detected to induce ABS (DRP) activation. The purpose of this handling is to avoid erroneous fault detection. Special case is during ABS, only if the wheel is in pressure dump state, then the detection is run and the detection time is increased.	• Wheel speed sensor not mounted correctly. • Wheel speed sensor to tone-ring gap out of tolerance. • Demagnetized tone-ring.	If one sensor shows a speed of less than 1.5 km/h (standstill detection threshold) while the other sensors indicate a speed greater than 6 km/h, then a missing sensor signal fault occurs. The detection is dependant on the speed of the wheels showing a valid signal. If the average speed of moving wheel (6km/h) is greater than 50 km/h and/or any undriven wheel speed is greater than 6km/h the fault detection time is faster. The entire test sequence is bypassed whenever unexpected wheel acceleration is detected to induce ABS (DRP) activation. The purpose of this handling is to avoid erroneous fault detection. Special case is during ABS, only if the wheel is in pressure dump state, then the detection is run and the detection time is increased.	• Wheel speed sensor supply is enabled. • No Ohmic wheel speed sensor failure present. • No Wss Erratic or Wss Dropout fault present • At least one WSS > 6kph • No excessive high or low voltage • Diagnostic Mode Inactive • Emissions Rolls Test Inactive	3-120s depending on number of missing wss and situation	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
		The failsafe will not run in case • exactly one axle is moving (other axle is standstill) while the moving axle shows an average velocity of less than 10km/h (to prevent setting Missing Wss faults on a roller bench). • the dynamic failsafe is currently disabled because the system is currently in Diagnostic mode. Counter type: Counter up and the fault counter reset If all sensors show a speed greater than 6 km/h or the vehicle is in standstill (all sensors lower than 1.5 km/h) Fault maturation time is 3 sec – 15 sec for one, 3 sec – 30 sec for two (15 sec during ABS) and 120 sec for three missing sensors.					
WSS_MISSING_REAR_RIGHT	C0517	Missing Wheel Speed Sensor If one sensor shows a speed of less than 1.5 km/h (standstill detection threshold) while the other sensors indicate a speed greater than 6 km/h, then a missing sensor signal fault occurs. The detection is dependant on the speed of the wheels showing a valid signal. If the average speed of moving wheel (6km/h) is greater than 50 km/h and/or any undroven wheel speed is greater than 6km/h, the fault detection time is faster. The entire test sequence is bypassed whenever unexpected wheel acceleration is detected to induce ABS (DRP) activation. The purpose of this handling is to avoid erroneous fault detection. Special case is during ABS, only if the wheel is in pressure dump state, then the detection is run and the detection time is increased.	• Wheel speed sensor not mounted correctly. • Wheel speed sensor to tone-ring gap out of tolerance. • Demagnetized tone-ring.	If one sensor shows a speed of less than 1.5 km/h (standstill detection threshold) while the other sensors indicate a speed greater than 6 km/h, then a missing sensor signal fault occurs. The detection is dependant on the speed of the wheels showing a valid signal. If the average speed of moving wheel (6km/h) is greater than 50 km/h and/or any undriven wheel speed is greater than 6km/h the fault detection time is faster. The entire test sequence is bypassed whenever unexpected wheel acceleration is detected to induce ABS (DRP) activation. The purpose of this handling is to avoid erroneous fault detection. Special case is during ABS, only if the wheel is in pressure dump state, then the detection is run and the detection time is increased.	• Wheel speed sensor supply is enabled. • No Ohmic wheel speed sensor failure present. • No Wss Erratic or Wss Dropout fault present • At least one WSS > 6kph • No excessive high or low voltage • Diagnostic Mode Inactive • Emissions Rolls Test Inactive	3-120s depending on number of missing wss and situation	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
		The failsafe will not run in case • exactly one axle is moving (other axle is standstill) while the moving axle shows an average velocity of less than 10km/h (to prevent setting Missing Wss faults on a roller bench). • the dynamic failsafe is currently disabled because the system is currently in Diagnostic mode. Counter type: Counter up and the fault counter reset If all sensors show a speed greater than 6 km/h or the vehicle is in standstill (all sensors lower than 1.5 km/h) Fault maturation time is 3 sec – 15 sec for one, 3 sec – 30 sec for two (15 sec during ABS) and 120 sec for three missing sensors.					
WSS_ERRATIC_FRONT_LEFT	C0504	• Erratic Wheel Speed Sensor • If the absolute value of the unfiltered wheel acceleration is greater than 491 m/s/s, an erratic wheel speed sensor may be present. The fault occurrence counter will be incremented by 1.4s. If the fault occurrence counter reaches 40 s, then an erratic wheel speed sensor fault is set. • If the wheel acceleration is less than or equal to the above threshold, then the fault occurrence counter is decremented by monitor rate. This allows the system to slowly decay the fault occurrence counter so that only a very erratic wheel speed sensor with unrealistic acceleration values will set this fault.	• Wheel speed sensor not mounted correctly. • Missing tooth or teeth on the wheel speed sensor tone-ring. • Electro-magnetic interference (EMI).	$\|Wheel_Accel\| > 491\ m/s^2$	• reference_vehicle_velocity > 3.58 m/s • Diagnostic Mode Inactive • Emissions Rolls Test Inactive	40 s	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
		• If the vehicle velocity is below 3.58m/s, the failsafe will detect the fault if excessive acceleration takes place (even in standstill condition). For next ignition cycle, the failsafe won't pass the test completely until the vehicle speed is above the threshold to prevent passing a fault from the previous ignition cycle if the failure only occurs during driving conditions. • Counter: Count 1-up • Monitor Rate: 7ms					
WSS_ERRATIC_FRONT_RIGHT	C050A	• Erratic Wheel Speed Sensor • If the absolute value of the unfiltered wheel acceleration is greater than 491 m/s/s, an erratic wheel speed sensor may be present. The fault occurrence counter will be incremented by 1.4s. If the fault occurrence counter reaches 40 s, then an erratic wheel speed sensor fault is set. • If the wheel acceleration is less than or equal to the above threshold, then the fault occurrence counter is decremented by monitor rate. This allows the system to slowly decay the fault occurrence counter so that only a very erratic wheel speed sensor with unrealistic acceleration values will set this fault.	• Wheel speed sensor not mounted correctly. • Missing tooth or teeth on the wheel speed sensor tone-ring. • Electro-magnetic interference (EMI).	|Wheel_Accel| > 491 m/s²	• reference_vehicle_velocity > 3.58 m/s • Diagnostic Mode Inactive • Emissions Rolls Test Inactive	40 s	Type A. MIL Illumination.
		• If the vehicle velocity is below 3.58m/s, the failsafe will detect the fault if excessive acceleration takes place (even in standstill condition). For next ignition cycle, the failsafe won't pass the test completely until the vehicle speed is above the threshold to prevent passing a fault from the previous ignition cycle if the failure only occurs during driving conditions. • Counter: Count 1-up • Monitor Rate: 7ms					

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_ERRATIC_REAR_LEFT	C0510	• Erratic Wheel Speed Sensor • If the absolute value of the unfiltered wheel acceleration is greater than 491 m/s/s, an erratic wheel speed sensor may be present. The fault occurrence counter will be incremented by 1.4s. If the fault occurrence counter reaches 40 s, then an erratic wheel speed sensor fault is set. • If the wheel acceleration is less than or equal to the above threshold, then the fault occurrence counter is decremented by monitor rate. This allows the system to slowly decay the fault occurrence counter so that only a very erratic wheel speed sensor with unrealistic acceleration values will set this fault.	• Wheel speed sensor not mounted correctly. • Missing tooth or teeth on the wheel speed sensor tone-ring. • Electro-magnetic interference (EMI).	|Wheel_Accel| > 491 m/s²	• reference_vehicle_velocity > 3.58 m/s • Diagnostic Mode Inactive • Emissions Rolls Test Inactive	40 s	Type A. MIL Illumination.
		• If the vehicle velocity is below 3.58m/s, the failsafe will detect the fault if excessive acceleration takes place (even in standstill condition). For next ignition cycle, the failsafe won't pass the test completely until the vehicle speed is above the threshold to prevent passing a fault from the previous ignition cycle if the failure only occurs during driving conditions. • Counter: Count 1-up • Monitor Rate: 7ms					

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_ERRATIC_REAR_RIGHT	C0516	• Erratic Wheel Speed Sensor • If the absolute value of the unfiltered wheel acceleration is greater than 491 m/s/s, an erratic wheel speed sensor may be present. The fault occurrence counter will be incremented by 1.4s. If the fault occurrence counter reaches 40 s, then an erratic wheel speed sensor fault is set. • If the wheel acceleration is less than or equal to the above threshold, then the fault occurrence counter is decremented by monitor rate. This allows the system to slowly decay the fault occurrence counter so that only a very erratic wheel speed sensor with unrealistic acceleration values will set this fault.	• Wheel speed sensor not mounted correctly. • Missing tooth or teeth on the wheel speed sensor tone-ring. • Electro-magnetic interference (EMI).	|Wheel_Accel| > 491 m/s²	• reference_vehicle_velocity > 3.58 m/s • Diagnostic Mode Inactive • Emissions Rolls Test Inactive	40 s	Type A. MIL Illumination.
		• If the vehicle velocity is below 3.58m/s, the failsafe will detect the fault if excessive acceleration takes place (even in standstill condition). For next ignition cycle, the failsafe won't pass the test completely until the vehicle speed is above the threshold to prevent passing a fault from the previous ignition cycle if the failure only occurs during driving conditions. • Counter: Count 1-up • Monitor Rate: 7ms					

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_DROPOUT_FRONT_LEFT	C0505	• Wheel Speed Sensor Dropout • When wheel speed sensor acceleration is detected that is above 392 m/s/s, a timer is initialized to hold off wheel speed sensor dropout detection for 1000 msec. Once this sudden acceleration is detected (and the timer is greater than zero), subsequent accelerations/decelerations greater than 294 m/s/s will reset the timer to the greater of the current timer value or 500 msec. This is done to prevent setting a fault during subsequent performance activity. • Once the timer decays to zero (or is already zero), the wheel speed sensor dropout monitor checks if any wheel speed sensor edges have been detected. If wheel speed sensor edges have been detected then we check if the wheel velocity is greater than 0.2236 m/s. If it is then we can pass this failsafe. If not we reset the fault monitor because we can not monitor this fault condition at this time. • If no wheel speed sensor edges have been detected for more than 150ms while the last valid wheel velocity (which was calculated based on real speed edges) was greater than 30km/h a WSS Dropout fault will be detected. Furthermore the filtered vehicle velocity must be greater than 3.58m/s to detect the fault. • Counter: Count 1-up • Monitor Rate: 7ms	• Defective wheel speed sensor. • Wheel speed sensor not mounted correctly. • Defective wheel speed sensor wiring harness. • Missing tooth or teeth on the wheel speed sensor tone-ring.	When wheel speed sensor acceleration is detected that is above 392 m/s/s, a timer is initialized to hold off wheel speed sensor dropout detection for 1000 msec. Once this sudden acceleration is detected (and the timer is greater than zero), subsequent accelerations/decelerations greater than 294 m/s/s will reset the timer to the greater of the current timer value or 500 msec. This is done to prevent setting a fault during subsequent performance activity. If no wheel speed sensor edges have been detected then we see which axle the wheel is on because there can be different wheel speed thresholds. We also check if the brake pedal is applied. Wheels can decelerate much faster when the brake pedal is applied than when it is not applied so the brake pedal is used to determine the speed threshold at which the sensor dropout monitor can be executed. If the brake pedal is applied, a higher wheel speed threshold is used than when the brake pedal is not applied. If the brake pedal is applied the wheel speed sensor velocity threshold is 9 m/s for wheels on the front axle and 9 m/s for wheels on the back axle. If the brake pedal is not applied then the wheel speed sensor velocity threshold is 5.38 m/s for wheels on the front axle and 5.38 m/s for wheels on the back axle. If the last valid wheel velocity is greater than the wheel speed velocity threshold set above, the difference in time from the last time we checked for this fault is greater than 40 msec, and the filtered vehicle velocity is above 3.58 m/s then a wheel speed sensor dropout fault is detected. If any of these conditions are not true then conditions are not correct to do dropout detection so reset the fault monitor.	• Wheel speed sensor supply is enabled. • No ohmic wheel speed sensor failure present • Diagnostic Mode Inactive • Emissions Rolls Test Inactive	40 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_DROPOUT_FRONT_RIGHT	C050B	• Wheel Speed Sensor Dropout • When wheel speed sensor acceleration is detected that is above 392 m/s/s, a timer is initialized to hold off wheel speed sensor dropout detection for 1000 msec. Once this sudden acceleration is detected (and the timer is greater than zero), subsequent accelerations/decelerations greater than 294 m/s/s will reset the timer to the greater of the current timer value or 500 msec. This is done to prevent setting a fault during subsequent performance activity. • Once the timer decays to zero (or is already zero), the wheel speed sensor dropout monitor checks if any wheel speed sensor edges have been detected. If wheel speed sensor edges have been detected then we check if the wheel velocity is greater than 0.2236 m/s.	• Defective wheel speed sensor. • Wheel speed sensor not mounted correctly. • Defective wheel speed sensor wiring harness. • Missing tooth or teeth on the wheel speed sensor tone-ring.	When wheel speed sensor acceleration is detected that is above 392 m/s/s, a timer is initialized to hold off wheel speed sensor dropout detection for 1000 msec. Once this sudden acceleration is detected (and the timer is greater than zero), subsequent accelerations/decelerations greater than 294 m/s/s will reset the timer to the greater of the current timer value or 500 msec. This is done to prevent setting a fault during subsequent performance activity. If no wheel speed sensor edges have been detected then we see which axle the wheel is on because there can be different wheel speed thresholds. We also check if the brake pedal is applied. Wheels can decelerate much faster when the brake pedal is applied than when it is not applied so the brake pedal is used to determine the speed threshold at which the	• Wheel speed sensor supply is enabled. • No ohmic wheel speed sensor failure present • Diagnostic Mode Inactive • Emissions Rolls Test Inactive	40 ms	Type A. MIL Illumination.
		If it is then we can pass this failsafe. If not we reset the fault monitor because we can not monitor this fault condition at this time. • If no wheel speed sensor edges have been detected for more than 150ms while the last valid wheel velocity (which was calculated based on real speed edges) was greater than 30km/h a WSS Dropout fault will be detected. Furthermore the filtered vehicle velocity must be greater than 3.58m/s to detect the fault. • Counter: Count 1-up • Monitor Rate: 7ms		sensor dropout monitor can be executed. If the brake pedal is applied, a higher wheel speed threshold is used than when the brake pedal is not applied. If the brake pedal is applied the wheel speed sensor velocity threshold is 9 m/s for wheels on the front axle and 9 m/s for wheels on the back axle. If the brake pedal is not applied then the wheel speed sensor velocity threshold is 5.38 m/s for wheels on the front axle and 5.38 m/s for wheels on the back axle. If the last valid wheel velocity is greater than the wheel speed velocity threshold set above, the difference in time from the last time we checked for this fault is greater than 40 msec, and the filtered vehicle velocity is above 3.58 m/s then a wheel speed sensor dropout fault is detected. If any of these conditions are not true then conditions are not correct to do dropout detection so reset the fault monitor.			

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_DROPOUT_REAR_LEFT	C0511	• Wheel Speed Sensor Dropout • When wheel speed sensor acceleration is detected that is above 392 m/s/s, a timer is initialized to hold off wheel speed sensor dropout detection for 1000 msec. Once this sudden acceleration is detected (and the timer is greater than zero), subsequent accelerations/decelerations greater than 294 m/s/s will reset the timer to the greater of the current timer value or 500 msec. This is done to prevent setting a fault during subsequent performance activity. • Once the timer decays to zero (or is already zero), the wheel speed sensor dropout monitor checks if any wheel speed sensor edges have been detected. If wheel speed sensor edges have been detected then we check if the wheel velocity is greater than 0.2236 m/s.	• Defective wheel speed sensor. • Wheel speed sensor not mounted correctly. • Defective wheel speed sensor wiring harness. • Missing tooth or teeth on the wheel speed sensor tone-ring.	When wheel speed sensor acceleration is detected that is above 392 m/s/s, a timer is initialized to hold off wheel speed sensor dropout detection for 1000 msec. Once this sudden acceleration is detected (and the timer is greater than zero), subsequent accelerations/decelerations greater than 294 m/s/s will reset the timer to the greater of the current timer value or 500 msec. This is done to prevent setting a fault during subsequent performance activity. If no wheel speed sensor edges have been detected then we see which axle the wheel is on because there can be different wheel speed thresholds. We also check if the brake pedal is applied. Wheels can decelerate much faster when the brake pedal is applied than when it is not applied so the brake pedal is used to determine the speed threshold at which the	• Wheel speed sensor supply is enabled. • No ohmic wheel speed sensor failure present • Diagnostic Mode Inactive • Emissions Rolls Test Inactive	40 ms	Type A. MIL Illumination.
		If it is then we can pass this failsafe. If not we reset the fault monitor because we can not monitor this fault condition at this time. • If no wheel speed sensor edges have been detected for more than 150ms while the last valid wheel velocity (which was calculated based on real speed edges) was greater than 30km/h a WSS Dropout fault will be detected. Furthermore the filtered vehicle velocity must be greater than 3.58m/s to detect the fault. • Counter: Count 1-up • Monitor Rate: 7ms		sensor dropout monitor can be executed. If the brake pedal is applied, a higher wheel speed threshold is used than when the brake pedal is not applied. If the brake pedal is applied the wheel speed sensor velocity threshold is 9 m/s for wheels on the front axle and 9 m/s for wheels on the back axle. If the brake pedal is not applied then the wheel speed sensor velocity threshold is 5.38 m/s for wheels on the front axle and 5.38 m/s for wheels on the back axle. If the last valid wheel velocity is greater than the wheel speed velocity threshold set above, the difference in time from the last time we checked for this fault is greater than 40 msec, and the filtered vehicle velocity is above 3.58 m/s then a wheel speed sensor dropout fault is detected. If any of these conditions are not true then conditions are not correct to do dropout detection so reset the fault monitor.			

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_DROPOUT_REAR_RIGHT	C0517	• Wheel Speed Sensor Dropout • When wheel speed sensor acceleration is detected that is above 392 m/s/s, a timer is initialized to hold off wheel speed sensor dropout detection for 1000 msec. Once this sudden acceleration is detected (and the timer is greater than zero), subsequent accelerations/decelerations greater than 294 m/s/s will reset the timer to the greater of the current timer value or 500 msec. This is done to prevent setting a fault during subsequent performance activity. • Once the timer decays to zero (or is already zero), the wheel speed sensor dropout monitor checks if any wheel speed sensor edges have been detected. If wheel speed sensor edges have been detected then we check if the wheel velocity is greater than 0.2236 m/s. If it is then we can pass this failsafe. If not we reset the fault monitor because we can not monitor this fault condition at this time. • If no wheel speed sensor edges have been detected for more than 150ms while the last valid wheel velocity (which was calculated based on real speed edges) was greater than 30km/h a WSS Dropout fault will be detected. Furthermore the filtered vehicle velocity must be greater than 3.58m/s to detect the fault. • Counter: Count 1-up • Monitor Rate: 7ms	• Defective wheel speed sensor. • Wheel speed sensor not mounted correctly. • Defective wheel speed sensor wiring harness. • Missing tooth or teeth on the wheel speed sensor tone-ring.	When wheel speed sensor acceleration is detected that is above 392 m/s/s, a timer is initialized to hold off wheel speed sensor dropout detection for 1000 msec. Once this sudden acceleration is detected (and the timer is greater than zero), subsequent accelerations/decelerations greater than 294 m/s/s will reset the timer to the greater of the current timer value or 500 msec. This is done to prevent setting a fault during subsequent performance activity. If no wheel speed sensor edges have been detected then we see which axle the wheel is on because there can be different wheel speed thresholds. We also check if the brake pedal is applied. Wheels can decelerate much faster when the brake pedal is applied than when it is not applied so the brake pedal is used to determine the speed threshold at which the sensor dropout monitor can be executed. If the brake pedal is applied, a higher wheel speed threshold is used than when the brake pedal is not applied. If the brake pedal is applied the wheel speed sensor velocity threshold is 9 m/s for wheels on the front axle and 9 m/s for wheels on the back axle. If the brake pedal is not applied then the wheel speed sensor velocity threshold is 5.38 m/s for wheels on the front axle and 5.38 m/s for wheels on the back axle. If the last valid wheel velocity is greater than the wheel speed velocity threshold set above, the difference in time from the last time we checked for this fault is greater than 40 msec, and the filtered vehicle velocity is above 3.58 m/s then a wheel speed sensor dropout fault is detected. If any of these conditions are not true then conditions are not correct to do dropout detection so reset the fault monitor.	• Wheel speed sensor supply is enabled. • No ohmic wheel speed sensor failure present • Diagnostic Mode Inactive • Emissions Rolls Test Inactive	40 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_FAST_MISSING_FRONT_LEFT	C0505	• Fast Missing Wheel Speed Sensor • This failsafe is only active from • Ignition On until the vehicle reaches • 15km/h for the first time. • During this time the wheel speeds and wheel • speed pulses are monitored	• Wheel speed sensor not mounted correctly. • Wheel speed sensor to tone-ring gap out of tolerance. • Demagnetized tone-ring.	The wheel speed monitor starts at velocities above 4k. If a wheel speed sensor shows a velocity slower than 1.2km/h the wheel speed is considered to be missing and corresponding internal fault counter of the failsafe will be incremented. At the time the vehicle reaches 15km/h, these fault counters and the wheel speed pulse counters are used to decide whether a fault has to be latched or not. The failsafe will only latch a fault if only one wheel speed signal seems to be missing. If more than one wheel speed signal is missing, no fault will be latched by this failsafe because this is not required to be detected until 15km/h.	• Wheel speed sensor supply is enabled. • No other wheel speed sensor failure present • 15 km/h not reached this ignition cycle • Diagnostic Mode Inactive • Emissions Rolls Test Inactive SYSTEM_VOLTAGE_EXCESSIVE_LOW not latched	1 count	Type A. MIL Illumination.
				If a fast missing fault has been detected the failsafe monitors the conditions until either the failure condition disappears for enough time to remove the fault code or the fault can be removed in case it has been confirmed by another wss fault code.			
WSS_FAST_MISSING_FRONT_RIGHT	C050B	• Fast Missing Wheel Speed Sensor • This failsafe is only active from • Ignition On until the vehicle reaches • 15km/h for the first time. • During this time the wheel speeds and wheel • speed pulses are monitored	• Wheel speed sensor not mounted correctly. • Wheel speed sensor to tone-ring gap out of tolerance. • Demagnetized tone-ring.	The wheel speed monitor starts at velocities above 4k. If a wheel speed sensor shows a velocity slower than 1.2km/h the wheel speed is considered to be missing and corresponding internal fault counter of the failsafe will be incremented. At the time the vehicle reaches 15km/h, these fault counters and the wheel speed pulse counters are used to decide whether a fault has to be latched or not. The failsafe will only latch a fault if only one wheel speed signal seems to be missing. If more than one wheel speed signal is missing, no fault will be latched by this failsafe because this is not required to be detected until 15km/h.	• Wheel speed sensor supply is enabled. • No other wheel speed sensor failure present • 15 km/h not reached this ignition cycle • Diagnostic Mode Inactive • Emissions Rolls Test Inactive SYSTEM_VOLTAGE_EXCESSIVE_LOW not latched	1 count	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
				If a fast missing fault has been detected the failsafe monitors the conditions until either the failure condition disappears for enough time to remove the fault code or the fault can be removed in case it has been confirmed by another wss fault code.			
WSS_FAST_MISSING_REAR_LEFT	C0511	• Fast Missing Wheel Speed Sensor • This failsafe is only active from • Ignition On until the vehicle reaches • 15km/h for the first time. • During this time the wheel speeds and wheel • speed pulses are monitored	• Wheel speed sensor not mounted correctly. • Wheel speed sensor to tone-ring gap out of tolerance. • Demagnetized tone-ring. (should come from FMEA)	The wheel speed monitor starts at velocities above 4k. If a wheel speed sensor shows a velocity slower than 1.2km/h the wheel speed is considered to be missing and corresponding internal fault counter of the failsafe will be incremented. At the time the vehicle reaches 15km/h, these fault counters and the wheel speed pulse counters are used to decide whether a fault has to be latched or not. The failsafe will only latch a fault if only one wheel speed signal seems to be missing. If more than one wheel speed signal is missing, no fault will be latched by this failsafe because this is not required to be detected until 15km/h.	• Wheel speed sensor supply is enabled. • No other wheel speed sensor failure present • 15 km/h not reached this ignition cycle • Diagnostic Mode Inactive • Emissions Rolls Test Inactive SYSTEM_VOLTAGE_EXCESSIVE_LOW not latched	1 count	Type A. MIL Illumination.
				If a fast missing fault has been detected the failsafe monitors the conditions until either the failure condition disappears for enough time to remove the fault code or the fault can be removed in case it has been confirmed by another wss fault code.			

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_FAST_MISSING_REAR_RIGHT	C0517	• Fast Missing Wheel Speed Sensor • This failsafe is only active from • Ignition On until the vehicle reaches • 15km/h for the first time. • During this time the wheel speeds and wheel • speed pulses are monitored	• Wheel speed sensor not mounted correctly. • Wheel speed sensor to tone-ring gap out of tolerance. • Demagnetized tone-ring.	The wheel speed monitor starts at velocities above 4k. If a wheel speed sensor shows a velocity slower than 1.2km/h the wheel speed is considered to be missing and corresponding internal fault counter of the failsafe will be incremented. At the time the vehicle reaches 15km/h, these fault counters and the wheel speed pulse counters are used to decide whether a fault has to be latched or not. The failsafe will only latch a fault if only one wheel speed signal seems to be missing. If more than one wheel speed signal is missing, no fault will be latched by this failsafe because this is not required to be detected until 15km/h.	• Wheel speed sensor supply is enabled. • No other wheel speed sensor failure present • 15 km/h not reached this ignition cycle • Diagnostic Mode Inactive • Emissions Rolls Test Inactive SYSTEM_VOLTAGE_EXCESSIVE_LOW not latched	1 count	Type A. MIL Illumination.
				If a fast missing fault has been detected the failsafe monitors the conditions until either the failure condition disappears for enough time to remove the fault code or the fault can be removed in case it has been confirmed by another wss fault code.			
WSS_TOO_FAST_SENSOR_FRONT_LEFT	C0505	If this wheelspeed sensor reaches a speed over 3.73mph (6 km/h) while the other three show a speed of less than 0.93mph (1.5 km/h) the fault is detected.	- Wheel speed sensor not mounted correctly. - Wheel speed sensor to tone-ring gap out of tolerance. - Demagnitized tone-ring		• No electrical failure is currently present	40 msec	Type A. MIL Illumination.
WSS_TOO_FAST_SENSOR_FRONT_RIGHT	C050B	If this wheelspeed sensor reaches a speed over 3.73mph (6 km/h) while the other three show a speed of less than 0.93mph (1.5 km/h) the fault is detected.	- Wheel speed sensor not mounted correctly. - Wheel speed sensor to tone-ring gap out of tolerance. - Demagnitized tone-ring		• No electrical failure is currently present	40 msec	Type A. MIL Illumination.
WSS_TOO_FAST_SENSOR_REAR_LEFT	C0511	If this wheelspeed sensor reaches a speed over 3.73mph (6 km/h) while the other three show a speed of less than 0.93mph (1.5 km/h) the fault is detected.	- Wheel speed sensor not mounted correctly. - Wheel speed sensor to tone-ring gap out of tolerance. - Demagnitized tone-ring		• No electrical failure is currently present	40 msec	Type A. MIL Illumination.
WSS_TOO_FAST_SENSOR_REAR_RIGHT	C0517	If this wheelspeed sensor reaches a speed over 3.73mph (6 km/h) while the other three show a speed of less than 0.93mph (1.5 km/h) the fault is detected.	- Wheel speed sensor not mounted correctly. - Wheel speed sensor to tone-ring gap out of tolerance. - Demagnitized tone-ring		• No electrical failure is currently present	40 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_SHADOWZONE_FRONT_LEFT	C0501	• Detection is handled by the Polaris ASIC	• High resistance of wiring harness • High side wheel speed sensor supply shorted to battery voltage with a resistance (leakage current)	Polaris ASIC Low Grey Zone Detect bit = True (The low grey zone is 7 to 14mA) or Polaris ASIC High Grey Zone Detect bit = True (The high grey zone is 14 to 28mA)	• No electrical failure is currently present	750 ms	Type A. MIL Illumination.
WSS_SHADOWZONE_FRONT_RIGHT	C0507	• Detection is handled by the Polaris ASIC	• High resistance of wiring harness • High side wheel speed sensor supply shorted to battery voltage with a resistance (leakage current)	Polaris ASIC Low Grey Zone Detect bit = True (The low grey zone is 7 to 14mA) or Polaris ASIC High Grey Zone Detect bit = True (The high grey zone is 14 to 28mA)	• No electrical failure is currently present	750 ms	Type A. MIL Illumination.
WSS_SHADOWZONE_REAR_LEFT	C050D	• Detection is handled by the Polaris ASIC	• High resistance of wiring harness • High side wheel speed sensor supply shorted to battery voltage with a resistance (leakage current)	Polaris ASIC Low Grey Zone Detect bit = True (The low grey zone is 7 to 14mA) or Polaris ASIC High Grey Zone Detect bit = True (The high grey zone is 14 to 28mA)	• No electrical failure is currently present	750 ms	Type A. MIL Illumination.
WSS_SHADOWZONE_REAR_RIGHT	C0513	• Detection is handled by the Polaris ASIC	• High resistance of wiring harness • High side wheel speed sensor supply shorted to battery voltage with a resistance (leakage current)	Polaris ASIC Low Grey Zone Detect bit = True (The low grey zone is 7 to 14mA) or Polaris ASIC High Grey Zone Detect bit = True (The high grey zone is 14 to 28mA)	• No electrical failure is currently present	750 ms	Type A. MIL Illumination.
WSS_HS_OC_FRONT_LEFT	C0503	Polaris ASIC sets any of these bits = TRUE	• Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	Polaris ASIC sets HS Over Current = TRUE High Side Over Current (HS current > 40mA)	• Wheel speed sensor supply is enabled. • High Side failsafe is not blocked	100 msec	Type A. MIL Illumination.
WSS_HS_OC_FRONT_RIGHT	C0509	Polaris ASIC sets any of these bits = TRUE	• Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	Polaris ASIC sets any of these bits = TRUE High Side Over Current (HS current > 40mA)	• Wheel speed sensor supply is enabled. • High Side failsafe is not blocked	100 msec	Type A. MIL Illumination.
WSS_HS_OC_REAR_LEFT	C050F	Polaris ASIC sets any of these bits = TRUE	• Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	Polaris ASIC sets any of these bits = TRUE High Side Over Current (HS current > 40mA)	• Wheel speed sensor supply is enabled. • High Side failsafe is not blocked	100 msec	Type A. MIL Illumination.
WSS_HS_OC_REAR_RIGHT	C0515	Polaris ASIC sets any of these bits = TRUE	• Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	Polaris ASIC sets any of these bits = TRUE High Side Over Current (HS current > 40mA)	• Wheel speed sensor supply is enabled. • High Side failsafe is not blocked	100 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_UNDER_VOLTAGE_FRONT_LEFT	C0502	• Detection is handled by the Polaris ASIC	• Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	Polaris ASIC sets WSS Undervoltage disable bit = TRUE	• Wheel speed sensor supply is enabled	20 msec	Type A. MIL Illumination.
WSS_UNDER_VOLTAGE_FRONT_RIGHT	C0508	• Detection is handled by the Polaris ASIC	• Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	Polaris ASIC sets WSS Undervoltage disable bit = TRUE	• Wheel speed sensor supply is enabled	20 msec	Type A. MIL Illumination.
WSS_UNDER_VOLTAGE_REAR_LEFT	C050E	• Detection is handled by the Polaris ASIC	• Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	Polaris ASIC sets WSS Undervoltage disable bit = TRUE	• Wheel speed sensor supply is enabled	20 msec	Type A. MIL Illumination.
WSS_UNDER_VOLTAGE_REAR_RIGHT	C0514	• Detection is handled by the Polaris ASIC	• Defective wheel speed sensor • Defective wire harness to wheel speed sensor • Defective printed circuit board • Defective Polaris ASIC	Polaris ASIC sets WSS Undervoltage disable bit = TRUE	• Wheel speed sensor supply is enabled	20 msec	Type A. MIL Illumination.
ASIC_DECODE_THREE_LEVEL_FAULT_LF	C0555	Look for ASIC decoding a three level sensor when a two level sensor is configured: Check for the number of VDA bits received indicates that the ASIC is decoding for a three level sensor or Check for the tp out of range bit received indicates that the ASIC is decoding for a three level sensor	• wrong vehicle config file used • misbuild using wrong WSS	While a wheelspeed channel is expected to be configured for a 2-level sensor (i.e. decode modes 1 or 2), the MCU shall monitor the tp Out of Range and VDA Bit Counter SPI bits. If these bits are not zero, the MCU shall detect that the ASIC is incorrectly decoding in mode 3.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
ASIC_THREE_LEVEL_DATA_READ_FAULT_LF	P0606	• When the ASIC updates the VDA Data, VDA Bit Counter, Standstill, and tp Out of Range SPI fields, the ASIC shall also set the Data Read SPI flag.	• Defective system ASIC ASIC data read flag is not updated properly	The MCU shall monitor each wheel's Data Read SPI flag, and verify that the bit is set at least every 195ms.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
ASIC_TWO_LEVEL_DATA_READ_FAULT_LF	P0606	• When the ASIC updates the PWM Pulse Width and Standstill SPI register fields, the ASIC shall also set the Data Read SPI flag.	• Defective system ASIC ASIC data read flag is not updated properly	The MCU shall monitor each wheel's Data Read SPI flag, and verify that the bit is set after every sensor falling edge.	• Polaris is initialized	15 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
ASIC_DECODE_THREE_LEVEL_FAULT_RF	C0556	Look for ASIC decoding a three level sensor when a two level sensor is configured: Check for the number of VDA bits received indicates that the ASIC is decoding for a three level sensor or Check for the tp out of range bit received indicates that the ASIC is decoding for a three level sensor	• wrong vehicle config file used • misbuild using wrong WSS	While a wheelspeed channel is expected to be configured for a 2-level sensor (i.e. decode modes 1 or 2), the MCU shall monitor the tp Out of Range and VDA Bit Counter SPI bits. If these bits are not zero, the MCU shall detect that the ASIC is incorrectly decoding in mode 3.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
ASIC_THREE_LEVEL_DATA_READ_FAULT_RF	P0606	• When the ASIC updates the VDA Data, VDA Bit Counter, Standstill, and tp Out of Range SPI fields, the ASIC shall also set the Data Read SPI flag.	• Defective system ASIC ASIC data read flag is not updated properly	The MCU shall monitor each wheel's Data Read SPI flag, and verify that the bit is set at least every 195ms.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
ASIC_TWO_LEVEL_DATA_READ_FAULT_RF	P0606	• When the ASIC updates the PWM Pulse Width and Standstill SPI register fields, the ASIC shall also set the Data Read SPI flag.	• Defective system ASIC ASIC data read flag is not updated properly	The MCU shall monitor each wheel's Data Read SPI flag, and verify that the bit is set after every sensor falling edge.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
ASIC_DECODE_THREE_LEVEL_FAULT_LR	C0557	Look for ASIC decoding a three level sensor when a two level sensor is configured: Check for the number of VDA bits received indicates that the ASIC is decoding for a three level sensor or Check for the tp out of range bit received indicates that the ASIC is decoding for a three level sensor	• wrong vehicle config file used • misbuild using wrong WSS	While a wheelspeed channel is expected to be configured for a 2-level sensor (i.e. decode modes 1 or 2), the MCU shall monitor the tp Out of Range and VDA Bit Counter SPI bits. If these bits are not zero, the MCU shall detect that the ASIC is incorrectly decoding in mode 3.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
ASIC_THREE_LEVEL_DATA_READ_FAULT_LR	P0606	• When the ASIC updates the VDA Data, VDA Bit Counter, Standstill, and tp Out of Range SPI fields, the ASIC shall also set the Data Read SPI flag.	• Defective system ASIC ASIC data read flag is not updated properly	The MCU shall monitor each wheel's Data Read SPI flag, and verify that the bit is set at least every 195ms.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
ASIC_TWO_LEVEL_DATA_READ_FAULT_LR	P0606	• When the ASIC updates the PWM Pulse Width and Standstill SPI register fields, the ASIC shall also set the Data Read SPI flag.	• Defective system ASIC ASIC data read flag is not updated properly	The MCU shall monitor each wheel's Data Read SPI flag, and verify that the bit is set after every sensor falling edge.	• Polaris is initialized	15 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
ASIC_DECODE_THREE_LEVEL_FAULT_RR	C0558	Look for ASIC decoding a three level sensor when a two level sensor is configured: Check for the number of VDA bits received indicates that the ASIC is decoding for a three level sensor or Check for the tp out of range bit received indicates that the ASIC is decoding for a three level sensor	• wrong vehicle config file used • misbuild using wrong WSS	While a wheelspeed channel is expected to be configured for a 2-level sensor (i.e. decode modes 1 or 2), the MCU shall monitor the tp Out of Range and VDA Bit Counter SPI bits. If these bits are not zero, the MCU shall detect that the ASIC is incorrectly decoding in mode 3.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
ASIC_THREE_LEVEL_DATA_READ_FAULT_RR	P0606	• When the ASIC updates the VDA Data, VDA Bit Counter, Standstill, and tp Out of Range SPI fields, the ASIC shall also set the Data Read SPI flag.	• Defective system ASIC ASIC data read flag is not updated properly	The MCU shall monitor each wheel's Data Read SPI flag, and verify that the bit is set at least every 195ms.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
ASIC_TWO_LEVEL_DATA_READ_FAULT_RR	P0606	• When the ASIC updates the PWM Pulse Width and Standstill SPI register fields, the ASIC shall also set the Data Read SPI flag.	• Defective system ASIC ASIC data read flag is not updated properly	The MCU shall monitor each wheel's Data Read SPI flag, and verify that the bit is set after every sensor falling edge.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
WSS_3L_INFO_MISSING_FRONT_LEFT	C0555	Monitors if an intelligent 3-level wss doesn't send pulses (standstill or wheel speed pulses) for too long.	• Defective system ASIC ASIC data read flag is not updated properly	Monitors if an intelligent 3-level wss doesn't send pulses (standstill or wheel speed pulses) for too long. Furthermore it checks the number of received data bits in the transmission. If less than the minimum number of data bits (3) are received, a fault will be latched.	• Polaris is initialized. • Wheel Speed Sensor supply is enabled • No WSS electrical fault is present • SYSTEM_VOLTAGE_EXCESSIVE_LOW fault is not present	250 msec	Type A. MIL Illumination.
WSS_3L_INFO_MISSING_FRONT_RIGHT	C0556	Monitors if an intelligent 3-level wss doesn't send pulses (standstill or wheel speed pulses) for too long.	• Defective system ASIC ASIC data read flag is not updated properly	Monitors if an intelligent 3-level wss doesn't send pulses (standstill or wheel speed pulses) for too long. Furthermore it checks the number of received data bits in the transmission. If less than the minimum number of data bits (3) are received, a fault will be latched.	• Polaris is initialized. • Wheel Speed Sensor supply is enabled • No WSS electrical fault is present • SYSTEM_VOLTAGE_EXCESSIVE_LOW fault is not present	250 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_3L_INFO_MISSING_REAR_LEFT	C0557	Monitors if an intelligent 3-level wss doesn't send pulses (standstill or wheel speed pulses) for too long.	• Defective system ASIC ASIC data read flag is not updated properly	Monitors if an intelligent 3-level wss doesn't send pulses (standstill or wheel speed pulses) for too long. Furthermore it checks the number of received data bits in the transmission. If less than the minimum number of data bits (3) are received, a fault will be latched.	• Polaris is initialized. • Wheel Speed Sensor supply is enabled • No WSS electrical fault is present • SYSTEM_VOLTAGE_EXCESSIVE_LOW fault is not present	250 msec	Type A. MIL Illumination.
WSS_3L_INFO_MISSING_REAR_RIGHT	C0558	Monitors if an intelligent 3-level wss doesn't send pulses (standstill or wheel speed pulses) for too long.	• Defective system ASIC ASIC data read flag is not updated properly	Monitors if an intelligent 3-level wss doesn't send pulses (standstill or wheel speed pulses) for too long. Furthermore it checks the number of received data bits in the transmission. If less than the minimum number of data bits (3) are received, a fault will be latched.	• Polaris is initialized. • Wheel Speed Sensor supply is enabled • No WSS electrical fault is present • SYSTEM_VOLTAGE_EXCESSIVE_LOW fault is not present	250 msec	Type A. MIL Illumination.
WSS_PARITY_FRONT_LEFT	C0555	Decodes the additional information of a Philips KMI22/1 wheelspeed sensor which is a 3-level VDA compliant sensor.	VDA data bits are corrupted	It's a VDA compliant Philips KMI22/1 sensor so use the following mask for the data bits: 0 air gap (1=too large) 1 mode state (1=initial mode, 0=active mode) 2 digital input state (1=input voltage low) 3 validity direction recognition (1=direction bit is valid) 4 direction recognition (1=direction positive (forward driving)) 5-7 sensing distance bits (air gap) (Bit 5 is LSB, 7 MSB) (8) parity (1=even parity) The even parity flag should be the same as the calculated even parity. Else, it indicates that atleast one data bit is corrupted.	• Polaris is initialized. • Wheel Speed Sensor supply is enabled	35 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_PARITY_FRONT_RIGHT	C0556	Decodes the additional information of a Philips KMI22/1 wheelspeed sensor which is a 3-level VDA compliant sensor.	VDA data bits are corrupted	It's a VDA compliant Philips KMI22/1 sensor so use the following mask for the data bits: 0 air gap (1=too large) 1 mode state (1=initial mode, 0=active mode) 2 digital input state (1=input voltage low) 3 validity direction recognition (1=direction bit is valid) 4 direction recognition (1=direction positive (forward driving)) 5-7 sensing distance bits (air gap) (Bit 5 is LSB, 7 MSB) (8) parity (1=even parity) The even parity flag should be the same as the calculated even parity. Else, it indicates that atleast one data bit is corrupted.	• Polaris is initialized. • Wheel Speed Sensor supply is enabled	35 msec	Type A. MIL Illumination.
WSS_PARITY_REAR_LEFT	C0557	Decodes the additional information of a Philips KMI22/1 wheelspeed sensor which is a 3-level VDA compliant sensor.	VDA data bits are corrupted	It's a VDA compliant Philips KMI22/1 sensor so use the following mask for the data bits: 0 air gap (1=too large) 1 mode state (1=initial mode, 0=active mode) 2 digital input state (1=input voltage low) 3 validity direction recognition (1=direction bit is valid) 4 direction recognition (1=direction positive (forward driving)) 5-7 sensing distance bits (air gap) (Bit 5 is LSB, 7 MSB) (8) parity (1=even parity) The even parity flag should be the same as the calculated even parity. Else, it indicates that atleast one data bit is corrupted.	• Polaris is initialized. • Wheel Speed Sensor supply is enabled	35 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_PARITY_REAR_RIGHT	C0558	Decodes the additional information of a Philips KMI22/1 wheelspeed sensor which is a 3-level VDA compliant sensor.	VDA data bits are corrupted	It's a VDA compliant Philips KMI22/1 sensor so use the following mask for the data bits: 0 air gap (1=too large) 1 mode state (1=initial mode, 0=active mode) 2 digital input state (1=input voltage low) 3 validity direction recognition (1=direction bit is valid) 4 direction recognition (1=direction positive (forward driving)) 5-7 sensing distance bits (air gap) (Bit 5 is LSB, 7 MSB) (8) parity (1=even parity) The even parity flag should be the same as the calculated even parity. Else, it indicates that atleast one data bit is corrupted.	• Polaris is initialized. • Wheel Speed Sensor supply is enabled	35 msec	Type A. MIL Illumination.
WSS_VDA_TP_OUT_OF_RANGE_FRONT_LEFT	C0501	• The ASIC shall measure the width of each speed pulse or speed replacement pulse (tp). If tp is less than tp minimum threshold or greater than tp maximum threshold, the ASIC shall set the tp Out of Range SPI flag.	• standstill pulse width out of range • Defective system ASIC	POLARIS ASIC sends diagnostic information indicating that the standstill pulse width is out of range (error bit equals 1) (3 level WSS only)	• Polaris is initialized	15 msec -375ms	Type A. MIL Illumination.
WSS_VDA_TP_OUT_OF_RANGE_FRONT_RIGHT	C0507	• The ASIC shall measure the width of each speed pulse or speed replacement pulse (tp). If tp is less than tp minimum threshold or greater than tp maximum threshold, the ASIC shall set the tp Out of Range SPI flag.	• standstill pulse width out of range • Defective system ASIC	POLARIS ASIC sends diagnostic information indicating that the standstill pulse width is out of range (error bit equals 1) (3 level WSS only)	• Polaris is initialized	15 msec -375ms	Type A. MIL Illumination.
WSS_VDA_TP_OUT_OF_RANGE_REAR_LEFT	C050D	• The ASIC shall measure the width of each speed pulse or speed replacement pulse (tp). If tp is less than tp minimum threshold or greater than tp maximum threshold, the ASIC shall set the tp Out of Range SPI flag.	• standstill pulse width out of range • Defective system ASIC	POLARIS ASIC sends diagnostic information indicating that the standstill pulse width is out of range (error bit equals 1) (3 level WSS only)	• Polaris is initialized	15 msec -375ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_VDA_TP_OUT_OF_RANGE_REAR_RIGHT	C0513	• The ASIC shall measure the width of each speed pulse or speed replacement pulse (tp). If tp is less than tp minimum threshold or greater than tp maximum threshold, the ASIC shall set the tp Out of Range SPI flag.	• standstill pulse width out of range • Defective system ASIC	POLARIS ASIC sends diagnostic information indicating that the standstill pulse width is out of range (error bit equals 1) (3 level WSS only)	• Polaris is initialized	15 msec -375ms	Type A. MIL Illumination.
WSS_STANDSTILL_FAST_FRONT_LEFT	C0501	• The MCU shall detect if standstill pulses occur faster than every 95ms, for 5 consecutive standstill pulses.	• Defective system ASIC Standstill VDA transmission too short	POLARIS ASIC sends diagnostic information indicating that the standstill pulse transmission is too short - less than 105 msec (3 level WSS only)	• Polaris is initialized	Variable. See Fault Equation and detection rules. Range is from 25 - 475ms.	Type A. MIL Illumination.
WSS_STANDSTILL_SLOW_FRONT_LEFT	C0501	• The MCU shall detect if standstill pulses occur slower than every 205ms, or no standstill pulse at all for 1025ms.	• Defective system ASIC • Standstill VDA transmission too long	POLARIS ASIC sends diagnostic information indicating that the standstill pulse transmission is too long - more than 195 msec (3 level WSS only)	• Polaris is initialized	Variable. See Fault Equation and Detection Rules. Range is from 1025 - 5100ms.	Type A. MIL Illumination.
WSS_STANDSTILL_FAST_FRONT_RIGHT	C0507	• The MCU shall detect if standstill pulses occur faster than every 95ms, for 5 consecutive standstill pulses.	• Defective system ASIC Standstill VDA transmission too short	POLARIS ASIC sends diagnostic information indicating that the standstill pulse transmission is too short - less than 105 msec (3 level WSS only)	• Polaris is initialized	Variable. See Fault Equation and detection rules. Range is from 25 - 475ms.	Type A. MIL Illumination.
WSS_STANDSTILL_SLOW_FRONT_RIGHT	C0507	• The MCU shall detect if standstill pulses occur slower than every 205ms, or no standstill pulse at all for 1025ms.	• Defective system ASIC • Standstill VDA transmission too long	POLARIS ASIC sends diagnostic information indicating that the standstill pulse transmission is too long - more than 195 msec (3 level WSS only)	• Polaris is initialized	Variable. See Fault Equation and Detection Rules. Range is from 1025 - 5100ms.	Type A. MIL Illumination.
WSS_STANDSTILL_FAST_REAR_LEFT	C050D	• The MCU shall detect if standstill pulses occur faster than every 95ms, for 5 consecutive standstill pulses.	• Defective system ASIC Standstill VDA transmission too short	POLARIS ASIC sends diagnostic information indicating that the standstill pulse transmission is too short - less than 105 msec (3 level WSS only)	• Polaris is initialized	Variable. See Fault Equation and detection rules. Range is from 25 - 475ms.	Type A. MIL Illumination.
WSS_STANDSTILL_SLOW_REAR_LEFT	C050D	• The MCU shall detect if standstill pulses occur slower than every 205ms, or no standstill pulse at all for 1025ms.	• Defective system ASIC • Standstill VDA transmission too long	POLARIS ASIC sends diagnostic information indicating that the standstill pulse transmission is too long - more than 195 msec (3 level WSS only)	• Polaris is initialized	Variable. See Fault Equation and Detection Rules. Range is from 1025 - 5100ms.	Type A. MIL Illumination.
WSS_STANDSTILL_FAST_REAR_RIGHT	C0513	• The MCU shall detect if standstill pulses occur faster than every 95ms, for 5 consecutive standstill pulses.	• Defective system ASIC Standstill VDA transmission too short	POLARIS ASIC sends diagnostic information indicating that the standstill pulse transmission is too short - less than 105 msec (3 level WSS only)	• Polaris is initialized	Variable. See Fault Equation and detection rules. Range is from 25 - 475ms.	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_STANDSTILL_SLOW_REAR_RIGHT	C0513	• The MCU shall detect if standstill pulses occur slower than every 205ms, or no standstill pulse at all for 1025ms.	• Defective system ASIC • Standstill VDA transmission too long	POLARIS ASIC sends diagnostic information indicating that the standstill pulse transmission is too long - more than 195 msec (3 level WSS only)	• Polaris is initialized	Variable. See Fault Equation and Detection Rules. Range is from 1025 - 5100ms.	Type A. MIL Illumination.
SYS_ASIC_WSS_EDGE_MISMATCH_LF	P0606	The Wheel Speed signal generated by the ASIC and the one received by the main Micro should match to insure correct wheel speed calculation.	• ASIC outputs shorted to neighbouring pins • Open trace on circuit board. • Defective system ASIC	1) The micro monitors the number of edges received every loop for plausability (less than a max number). 2) The micro will compare the edges detected by the internal timer with the SPI flags sent by the ASIC to make sure they match.	• Polaris is initialized • No other ASIC faults detected	25 msec	Type A. MIL Illumination.
SYS_ASIC_WSS_EDGE_MISMATCH_RF	P0606	The Wheel Speed signal generated by the ASIC and the one received by the main Micro should match to insure correct wheel speed calculation.	• ASIC outputs shorted to neighbouring pins • Open trace on circuit board. • Defective system ASIC	1) The micro monitors the number of edges received every loop for plausability (less than a max number). 2) The micro will compare the edges detected by the internal timer with the SPI flags sent by the ASIC to make sure they match.	• Polaris is initialized • No other ASIC faults detected	25 msec	Type A. MIL Illumination.
SYS_ASIC_WSS_EDGE_MISMATCH_LR	P0606	The Wheel Speed signal generated by the ASIC and the one received by the main Micro should match to insure correct wheel speed calculation.	• ASIC outputs shorted to neighbouring pins • Open trace on circuit board. • Defective system ASIC	1) The micro monitors the number of edges received every loop for plausability (less than a max number). 2) The micro will compare the edges detected by the internal timer with the SPI flags sent by the ASIC to make sure they match.	• Polaris is initialized • No other ASIC faults detected	25 msec	Type A. MIL Illumination.
SYS_ASIC_WSS_EDGE_MISMATCH_RR	P0606	The Wheel Speed signal generated by the ASIC and the one received by the main Micro should match to insure correct wheel speed calculation.	• ASIC outputs shorted to neighbouring pins • Open trace on circuit board. • Defective system ASIC	1) The micro monitors the number of edges received every loop for plausability (less than a max number). 2) The micro will compare the edges detected by the internal timer with the SPI flags sent by the ASIC to make sure they match.	• Polaris is initialized • No other ASIC faults detected	25 msec	Type A. MIL Illumination.
MCU_WSS_EXCESSIVE_EDGES_DETECTED_FRONT_LEFT	C10EE	This fault is latched when the edge counts exceeds the threshold.	• Defective system ASIC • Defective wheel speed sensor	Excessive Edge counts > 55	• Wheel speed sensor supply is enabled	25 msec	Type A. MIL Illumination.
MCU_WSS_EXCESSIVE_EDGES_DETECTED_FRONT_RIGHT	C10EE	This fault is latched when the edge counts exceeds the threshold.	• Defective system ASIC • Defective wheel speed sensor	Excessive Edge counts > 55	• Wheel speed sensor supply is enabled	25 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
MCU_WSS_EXCESSIVE_EDGES_DETECTED_REAR_LEFT	C10EE	This fault is latched when the edge counts exceeds the threshold.	• Defective system ASIC • Defective wheel speed sensor	Excessive Edge counts > 55	• Wheel speed sensor supply is enabled	25 msec	Type A. MIL Illumination.
MCU_WSS_EXCESSIVE_EDGES_DETECTED_REAR_RIGHT	C10EE	This fault is latched when the edge counts exceeds the threshold.	• Defective system ASIC • Defective wheel speed sensor	Excessive Edge counts > 55	• Wheel speed sensor supply is enabled	25 msec	Type A. MIL Illumination.
WSS_TYPE_MISMATCH_FRONT_LEFT	C0555	• Probability counters are used to determine the likelihood of possible DWSS sensors. Therefore, no speed or time filtering is needed. Detection time depends on wheel speed. When the vehicle is at a stop, detection time is longest since no direction is transmitted (both sensor types look the same) and standstill pulses are used instead. At high-speeds, detection is shortest since missing or extra direction information will indicate the sensor installed.	• Incorrect WSS installed (Non-Directional or Infineon sensor)	Algorithm has detected that a directional WSS has incorrectly been installed	• WSS must be valid (supply enabled and no electrical problems)	5 msec	Type A. MIL Illumination.
WSS_TYPE_MISMATCH_FRONT_RIGHT	C0556	• Probability counters are used to determine the likelihood of possible DWSS sensors. Therefore, no speed or time filtering is needed. Detection time depends on wheel speed. When the vehicle is at a stop, detection time is longest since no direction is transmitted (both sensor types look the same) and standstill pulses are used instead. At high-speeds, detection is shortest since missing or extra direction information will indicate the sensor installed.	• Incorrect WSS installed (Non-Directional or Infineon sensor)	Algorithm has detected that a directional WSS has incorrectly been installed	• WSS must be valid (supply enabled and no electrical problems)	5 msec	Type A. MIL Illumination.
WSS_TYPE_MISMATCH_REAR_LEFT	C0557	• Probability counters are used to determine the likelihood of possible DWSS sensors. Therefore, no speed or time filtering is needed. Detection time depends on wheel speed. When the vehicle is at a stop, detection time is longest since no direction is transmitted (both sensor types look the same) and standstill pulses are used instead. At high-speeds, detection is shortest since missing or extra direction information will indicate the sensor installed.	• Incorrect WSS installed (Non-Directional or Infineon sensor)	Algorithm has detected that a directional WSS has incorrectly been installed	• WSS must be valid (supply enabled and no electrical problems)	5 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_TYPE_MISMATCH_REAR_RIGHT	C0558	• Probability counters are used to determine the likelihood of possible DWSS sensors. Therefore, no speed or time filtering is needed. Detection time depends on wheel speed. When the vehicle is at a stop, detection time is longest since no direction is transmitted (both sensor types look the same) and standstill pulses are used instead. At high-speeds, detection is shortest since missing or extra direction information will indicate the sensor installed.	• Incorrect WSS installed (Non-Directional or Infineon sensor)	Algorithm has detected that a directional WSS has incorrectly been installed	• WSS must be valid (supply enabled and no electrical problems)	5 msec	Type A. MIL Illumination.
SYS_ASIC_U_WS_OVER_VOLT	C05A3	If VU_WS exceeds the rising U_WS over-voltage detection threshold for the detection debounce time, the ASIC sets the U_WS Overvoltage Warning SPI flag and disable the four high-side switches.	Defective System ASIC	The MCU shall configure the wheelspeed sensor overvoltage bypass configuration to LOW. If the WSS overvoltage warning bit is set, fault is set.	Polaris is initialized	5 msec	Type A. MIL Illumination.
SYS_ASIC_WSS_SUPPLY_LOW	C05A4	• Within the ASIC, the U_WS and U12 voltages shall be internally divided down and shall feed dedicated ADC channels.	• Defective system ASIC	The MCU shall read the ASIC's U_WS Voltage Result SPI field and verify that "sufficient voltage" is present for wheelspeed operation. For ECUs with no U_WS voltage regulation: the MCU shall also read the ASIC's U12 Voltage Result SPI field and perform a plausibility check between U_WS and U12. Note: sufficient voltage for wheelspeed operation depends upon the type of wheelspeed sensor used.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
WSS_OVER_TEMP_WARNING	P0606	• MCU shall monitor the U_WS Overvoltage Warning SPI flag received from the ASIC	• Defective system ASIC • internal overheating	MCU detects that the U_WS Overvoltage Warning SPI flag received from the ASIC is TRUE	• Polaris is initialized	15 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SYS_ASIC_WSS_HS_STUCK_ON	C05A3	• The ASIC's open circuit detection (SM42) shall remain operational even if the channel's high-side supply is turned off or disabled. • Periodically (e.g. once per ignition cycle), the MCU shall enable the low-side wheelspeed supplies but shall leave the high-side supplies off. The MCU shall detect if an open-circuit is not detected on any channel. • Periodically (e.g. once per ignition cycle), the MCU shall command the wheelspeed high-side supplies off, low-side supplies on, and verify that each channel's Open Circuit SPI bit is set.	• Defective system ASIC	Any one wheel fails to detect an open-circuit during either the high-side or low-side supply ON check.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
MISMATCH_TIRE	C10EE	• Wheel Velocity Differences between one and the others > 20 %. • The mismatch tire ratio adjustment is disabled if: • Vehicle Velocity < 8.9 mph, • Cornering is detected, • Spinning wheels are detected, • Braking is detected, • Wheel speed sensor faults exist. • Counter: Count 1-up • Monitor Rate: 10ms	• Significantly different size tires installed on the vehicle. • Missing target ring (sensor picking up lug nuts) • Anything that generates consistent differences in apparent wheel rotational speed. • Different number of teeth on the exciter rings.	Wheel Velocity difference between one and the others > 20 %	• The mismatch tire ratio adjustment is disabled if: • Vehicle Velocity < 8.9 mph, • Cornering is detected, • Spinning wheels are detected, • Braking is detected, • Wheel speed sensor faults exist, • Emissions Rolls Test is active	1 Count	Type A. MIL Illumination.
WSS_DIRECTION_FAILURE_FRONT_LEFT	C2A01	• Number of valid directional and non-directional WSS sensors must be greater than 0. • Number of valid directional WSS sensors must be greater than 0. • Valid directional and non-directional WSS sensors must: • Show unfiltered wheel-speed velocity >= 15 km/h. • Show unfiltered wheel-speed acceleration < 50 m/s². • All valid directional and non-directional WSS sensors must show velocities within 15% of the slowest valid wheel.	• Wheel speed sensor not mounted correctly. • Electro-magnetic interference (EMI).	At least 1 sensor indicates Unknown, or at least 1 sensor indicates Forward and at least one sensor indicates Backwards For duration > 5 seconds While vehicle speed > 15 km/h.	• WSS must be valid (supply enabled and no electrical problems)	5 seconds	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_DIRECTION_FAILURE_FRONT_RIGHT	C2A02	• Number of valid directional and non-directional WSS sensors must be greater than 0. • Number of valid directional WSS sensors must be greater than 0. • Valid directional and non-directional WSS sensors must: • Show unfiltered wheel-speed velocity >= 15 km/h. • Show unfiltered wheel-speed acceleration < 50 m/s². • All valid directional and non-directional WSS sensors must show velocities within 15% of the slowest valid wheel.	• Wheel speed sensor not mounted correctly. • Electro-magnetic interference (EMI).	At least 1 sensor indicates Unknown, or at least 1 sensor indicates Forward and at least one sensor indicates Backwards For duration > 5 seconds While vehicle speed > 15 km/h.	• WSS must be valid (supply enabled and no electrical problems)	5 seconds	Type A. MIL Illumination.
WSS_DIRECTION_FAILURE_REAR_LEFT	C2A03	• Number of valid directional and non-directional WSS sensors must be greater than 0. • Number of valid directional WSS sensors must be greater than 0. • Valid directional and non-directional WSS sensors must: • Show unfiltered wheel-speed velocity >= 15 km/h. • Show unfiltered wheel-speed acceleration < 50 m/s². • All valid directional and non-directional WSS sensors must show velocities within 15% of the slowest valid wheel.	• Wheel speed sensor not mounted correctly. • Electro-magnetic interference (EMI).	At least 1 sensor indicates Unknown, or at least 1 sensor indicates Forward and at least one sensor indicates Backwards For duration > 5 seconds While vehicle speed > 15 km/h.	• WSS must be valid (supply enabled and no electrical problems)	5 seconds	Type A. MIL Illumination.
WSS_DIRECTION_FAILURE_REAR_RIGHT	C2A04	• Number of valid directional and non-directional WSS sensors must be greater than 0. • Number of valid directional WSS sensors must be greater than 0. • Valid directional and non-directional WSS sensors must: • Show unfiltered wheel-speed velocity >= 15 km/h. • Show unfiltered wheel-speed acceleration < 50 m/s². • All valid directional and non-directional WSS sensors must show velocities within 15% of the slowest valid wheel.	• Wheel speed sensor not mounted correctly. • Electro-magnetic interference (EMI).	At least 1 sensor indicates Unknown, or at least 1 sensor indicates Forward and at least one sensor indicates Backwards For duration > 5 seconds While vehicle speed > 15 km/h.	• WSS must be valid (supply enabled and no electrical problems)	5 seconds	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WSS_DIRECTION_FAILURE_UNKNOWN	C2A00	• Number of valid directional and non-directional WSS sensors must be greater than 0. • Number of valid directional WSS sensors must be greater than 0. • Valid directional and non-directional WSS sensors must: • Show unfiltered wheel-speed velocity >= 15 km/h. • Show unfiltered wheel-speed acceleration < 50 m/s². • All valid directional and non-directional WSS sensors must show velocities within 15% of the slowest valid wheel.	• Wheel speed sensor not mounted correctly. Electro-magnetic interference (EMI).	When an equal number of sensors report opposite directions, this DTC is latched and all DWSS sensors are marked Failed. num_dwss_forward_dir == num_dwss_reverse_dir	• WSS must be valid (supply enabled and no electrical problems)	5 seconds	Type A. MIL Illumination.
Group 3 - Solenoid and Valve							
SOL_OPEN_ISO_FRONT_LEFT	C0010	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Defective solenoid. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Leaky FET • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	After the driver is commanded on, the ASIC shall wait the open driver mask time, and then observe the filtered drain comparator feedback. If the drain feedback is high, the ASIC shall set the DRDx Open Driver Warning SPI bit. Drain comparator threshold: min value = 2.375 V max value = 2.625 V	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
SOL_OPEN_ISO_FRONT_RIGHT	C0014	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Defective solenoid. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Leaky FET • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	After the driver is commanded on, the ASIC shall wait the open driver mask time, and then observe the filtered drain comparator feedback. If the drain feedback is high, the ASIC shall set the DRDx Open Driver Warning SPI bit. Drain comparator threshold: min value = 2.375 V max value = 2.625 V	1. Solenoid is commanded off for 20 msec 2. Power Switch is On and not faulted 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SOL_OPEN_ISO_REAR_LEFT	C0018	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Defective solenoid. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Leaky FET • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	After the driver is commanded on, the ASIC shall wait the open driver mask time, and then observe the filtered drain comparator feedback. If the drain feedback is high, the ASIC shall set the DRDx Open Driver Warning SPI bit. Drain comparator threshold: min value = 2.375 V max value = 2.625 V	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
SOL_OPEN_ISO_REAR_RIGHT	C001C	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Defective solenoid. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Leaky FET • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	After the driver is commanded on, the ASIC shall wait the open driver mask time, and then observe the filtered drain comparator feedback. If the drain feedback is high, the ASIC shall set the DRDx Open Driver Warning SPI bit. Drain comparator threshold: min value = 2.375 V max value = 2.625 V	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
SOL_OPEN_DUMP_FRONT_LEFT	C0011	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Defective solenoid. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Leaky FET • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	After the driver is commanded on, the ASIC shall wait the open driver mask time, and then observe the filtered drain comparator feedback. If the drain feedback is high, the ASIC shall set the DRDx Open Driver Warning SPI bit. Drain comparator threshold: min value = 2.375 V max value = 2.625 V	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SOL_OPEN_DUMP_FRONT_RIGHT	C0015	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Defective solenoid. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Leaky FET • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	After the driver is commanded on, the ASIC shall wait the open driver mask time, and then observe the filtered drain comparator feedback. If the drain feedback is high, the ASIC shall set the DRDx Open Driver Warning SPI bit. Drain comparator threshold: min value = 2.375 V max value = 2.625 V	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
SOL_OPEN_DUMP_REAR_LEFT	C0019	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Defective solenoid. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Leaky FET • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	After the driver is commanded on, the ASIC shall wait the open driver mask time, and then observe the filtered drain comparator feedback. If the drain feedback is high, the ASIC shall set the DRDx Open Driver Warning SPI bit. Drain comparator threshold: min value = 2.375 V max value = 2.625 V	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
SOL_OPEN_DUMP_REAR_RIGHT	C001D	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Defective solenoid. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Leaky FET • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	After the driver is commanded on, the ASIC shall wait the open driver mask time, and then observe the filtered drain comparator feedback. If the drain feedback is high, the ASIC shall set the DRDx Open Driver Warning SPI bit. Drain comparator threshold: min value = 2.375 V max value = 2.625 V	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SOL_OPEN_3WAY_PRIMARY	C0001	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Defective solenoid. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Leaky FET Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	After the driver is commanded on, the ASIC shall wait the open driver mask time, and then observe the filtered drain comparator feedback. If the drain feedback is high, the ASIC shall set the DRDx Open Driver Warning SPI bit. Drain comparator threshold: min value = 2.375 V max value = 2.625 V	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
SOL_OPEN_3WAY_SECONDARY	C0003	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Defective solenoid. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Leaky FET Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	After the driver is commanded on, the ASIC shall wait the open driver mask time, and then observe the filtered drain comparator feedback. If the drain feedback is high, the ASIC shall set the DRDx Open Driver Warning SPI bit. Drain comparator threshold: min value = 2.375 V max value = 2.625 V	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
SOL_FDBK_UNEQUAL_TO_CMD_3WAY_PRIMARY	C0001	Whenever the power switch is closed and the driver FET is not turned on (solenoid commanded off) then the feedback voltage should be high. If the solenoid feedback voltage is measured to be > 43.49% and < 65.23% of the coil supply voltage for 30 msec, an open solenoid fault is indicated				30 ms	Type A. MIL Illumination.
SOL_FDBK_UNEQUAL_TO_CMD_3WAY_SECONDARY	C0003	Whenever the power switch is closed and the driver FET is not turned on (solenoid commanded off) then the feedback voltage should be high. If the solenoid feedback voltage is measured to be > 43.49% and < 65.23% of the coil supply voltage for 30 msec, an open solenoid fault is indicated.				30 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SOL_OPEN_NORMAL_CLOSE_DAP	C0004	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Defective solenoid. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Leaky FET Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	After the driver is commanded on, the ASIC shall wait the open driver mask time, and then observe the filtered drain comparator feedback. If the drain feedback is high, the ASIC shall set the DRDx Open Driver Warning SPI bit. Drain comparator threshold: min value = 2.375 V max value = 2.625 V	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
SOL_OPEN_PEDAL_SIM_ISO	C0024	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Defective solenoid. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Leaky FET Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	After the driver is commanded on, the ASIC shall wait the open driver mask time, and then observe the filtered drain comparator feedback. If the drain feedback is high, the ASIC shall set the DRDx Open Driver Warning SPI bit. Drain comparator threshold: min value = 2.375 V max value = 2.625 V	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
SOL_OPEN_NORMAL_OPEN_DAP	C0002	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Defective solenoid. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Leaky FET Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	After the driver is commanded on, the ASIC shall wait the open driver mask time, and then observe the filtered drain comparator feedback. If the drain feedback is high, the ASIC shall set the DRDx Open Driver Warning SPI bit. Drain comparator threshold: min value = 2.375 V max value = 2.625 V	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
DRIVER_SHORT_ISO_FRONT_LEFT	C0010	• Shorted Solenoid Driver • Vehicle battery voltage is applied to the high side of the solenoid coils in the ECU assembly by the power switch. The solenoids are energized using a field effect transistor (FET) to connect the low side of the coil to ground.	• Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	Solenoid_feedback ? 43%	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
DRIVER_SHORT_ISO_FRONT_RIGHT	C0014	• Shorted Solenoid Driver • Vehicle battery voltage is applied to the high side of the solenoid coils in the ECU assembly by the power switch. The solenoids are energized using a field effect transistor (FET) to connect the low side of the coil to ground.	• Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	Solenoid_feedback ? 43%	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
DRIVER_SHORT_ISO_REAR_LEFT	C0018	• Shorted Solenoid Driver • Vehicle battery voltage is applied to the high side of the solenoid coils in the ECU assembly by the power switch. The solenoids are energized using a field effect transistor (FET) to connect the low side of the coil to ground.	• Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	Solenoid_feedback ? 43%	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
DRIVER_SHORT_ISO_REAR_RIGHT	C001C	• Shorted Solenoid Driver • Vehicle battery voltage is applied to the high side of the solenoid coils in the ECU assembly by the power switch. The solenoids are energized using a field effect transistor (FET) to connect the low side of the coil to ground.	• Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	Solenoid_feedback ? 43%	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
DRIVER_SHORT_DUMP_FRONT_LEFT	C0011	• Shorted Solenoid Driver • Vehicle battery voltage is applied to the high side of the solenoid coils in the ECU assembly by the power switch. The solenoids are energized using a field effect transistor (FET) to connect the low side of the coil to ground.	• Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	Solenoid_feedback ? 43%	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
DRIVER_SHORT_DUMP_FRONT_RIGHT	C0015	• Shorted Solenoid Driver • Vehicle battery voltage is applied to the high side of the solenoid coils in the ECU assembly by the power switch. The solenoids are energized using a field effect transistor (FET) to connect the low side of the coil to ground.	• Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	Solenoid_feedback ? 43%	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
DRIVER_SHORT_DUMP_REAR_LEFT	C0019	• Shorted Solenoid Driver • Vehicle battery voltage is applied to the high side of the solenoid coils in the ECU assembly by the power switch. The solenoids are energized using a field effect transistor (FET) to connect the low side of the coil to ground.	• Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	Solenoid_feedback ? 43%	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
DRIVER_SHORT_DUMP_REAR_RIGHT	C001D	• Shorted Solenoid Driver • Vehicle battery voltage is applied to the high side of the solenoid coils in the ECU assembly by the power switch. The solenoids are energized using a field effect transistor (FET) to connect the low side of the coil to ground.	• Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	Solenoid_feedback ? 43%	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
DRIVER_SHORT_3WAY_PRIMARY	C0001	• Shorted Solenoid Driver Vehicle battery voltage is applied to the high side of the solenoid coils in the ECU assembly by the power switch. The solenoids are energized using a field effect transistor (FET) to connect the low side of the coil to ground.	• Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	Solenoid_feedback ? 43%	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
DRIVER_SHORT_3WAY_SECONDARY	C0003	• Shorted Solenoid Driver Vehicle battery voltage is applied to the high side of the solenoid coils in the ECU assembly by the power switch. The solenoids are energized using a field effect transistor (FET) to connect the low side of the coil to ground.	• Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	Solenoid_feedback ? 43%	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
DRIVER_SHORT_NORMAL_CLOSE_DAP	C0004	• Shorted Solenoid Driver Vehicle battery voltage is applied to the high side of the solenoid coils in the ECU assembly by the power switch. The solenoids are energized using a field effect transistor (FET) to connect the low side of the coil to ground.	• Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	Solenoid_feedback ? 43%	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
DRIVER_SHORT_PEDAL_SIM_ISO	C0024	• Shorted Solenoid Driver Vehicle battery voltage is applied to the high side of the solenoid coils in the ECU assembly by the power switch. The solenoids are energized using a field effect transistor (FET) to connect the low side of the coil to ground.	• Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	Solenoid_feedback ? 43%	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
DRIVER_SHORT_NORMAL_OPEN_DAP	C0002	• Shorted Solenoid Driver Vehicle battery voltage is applied to the high side of the solenoid coils in the ECU assembly by the power switch. The solenoids are energized using a field effect transistor (FET) to connect the low side of the coil to ground.	• Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	Solenoid_feedback ? 43%	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
DRIVER_SHORT_SIM_TEST	C05D5	• Shorted Solenoid Driver Vehicle battery voltage is applied to the high side of the solenoid coils in the ECU assembly by the power switch. The solenoids are energized using a field effect transistor (FET) to connect the low side of the coil to ground.	• Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	Solenoid_feedback ? 43%	1. Solenoid is commanded off for 20 msec 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	30 ms	Type A. MIL Illumination.
SOL_SHORT_ISO_FRONT_LEFT	C0010	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Solenoid coils shorted internally. • Solenoid shorted to a voltage supply or ground. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage high when the solenoid is not energized.	The MCU can make the distinction between open driver and shorted coil by performing a coil test pulse on the faulted channel with all other coil channels off. Drain comparator threshold: • min value = 2.375 V • max value = 2.625 V	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	15 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SOL_SHORT_ISO_FRONT_RIGHT	C0014	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Solenoid coils shorted internally. • Solenoid shorted to a voltage supply or ground. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage high when the solenoid is not energized.	The MCU can make the distinction between open driver and shorted coil by performing a coil test pulse on the faulted channel with all other coil channels off. Drain comparator threshold: • min value = 2.375 V • max value = 2.625 V	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	15 ms	Type A. MIL Illumination.
SOL_SHORT_ISO_REAR_LEFT	C0018	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Solenoid coils shorted internally. • Solenoid shorted to a voltage supply or ground. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage high when the solenoid is not energized.	The MCU can make the distinction between open driver and shorted coil by performing a coil test pulse on the faulted channel with all other coil channels off. Drain comparator threshold: • min value = 2.375 V • max value = 2.625 V	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	15 ms	Type A. MIL Illumination.
SOL_SHORT_ISO_REAR_RIGHT	C001C	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Solenoid coils shorted internally. • Solenoid shorted to a voltage supply or ground. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage high when the solenoid is not energized.	The MCU can make the distinction between open driver and shorted coil by performing a coil test pulse on the faulted channel with all other coil channels off. Drain comparator threshold: • min value = 2.375 V • max value = 2.625 V	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	15 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SOL_SHORT_DUMP_FRONT_LEFT	C0011	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Solenoid coils shorted internally. • Solenoid shorted to a voltage supply or ground. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage high when the solenoid is not energized.	The MCU can make the distinction between open driver and shorted coil by performing a coil test pulse on the faulted channel with all other coil channels off. Drain comparator threshold: • min value = 2.375 V • max value = 2.625 V	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	15 ms	Type A. MIL Illumination.
SOL_SHORT_DUMP_FRONT_RIGHT	C0015	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Solenoid coils shorted internally. • Solenoid shorted to a voltage supply or ground. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage high when the solenoid is not energized.	The MCU can make the distinction between open driver and shorted coil by performing a coil test pulse on the faulted channel with all other coil channels off. Drain comparator threshold: • min value = 2.375 V • max value = 2.625 V	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	15 ms	Type A. MIL Illumination.
SOL_SHORT_DUMP_REAR_LEFT	C0019	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Solenoid coils shorted internally. • Solenoid shorted to a voltage supply or ground. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage high when the solenoid is not energized.	The MCU can make the distinction between open driver and shorted coil by performing a coil test pulse on the faulted channel with all other coil channels off. Drain comparator threshold: • min value = 2.375 V • max value = 2.625 V	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	15 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SOL_SHORT_DUMP_REAR_RIGHT	C001D	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. • The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Solenoid coils shorted internally. • Solenoid shorted to a voltage supply or ground. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage high when the solenoid is not energized.	The MCU can make the distinction between open driver and shorted coil by performing a coil test pulse on the faulted channel with all other coil channels off. Drain comparator threshold: • min value = 2.375 V • max value = 2.625 V	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	15 ms	Type A. MIL Illumination.
SOL_SHORT_3WAY_PRIMARY	C0001	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Solenoid coils shorted internally. • Solenoid shorted to a voltage supply or ground. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	The MCU can make the distinction between open driver and shorted coil by performing a coil test pulse on the faulted channel with all other coil channels off. Drain comparator threshold: • min value = 2.375 V • max value = 2.625 V	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	15 ms	Type A. MIL Illumination.
SOL_SHORT_3WAY_SECONDARY	C0003	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Solenoid coils shorted internally. • Solenoid shorted to a voltage supply or ground. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	The MCU can make the distinction between open driver and shorted coil by performing a coil test pulse on the faulted channel with all other coil channels off. Drain comparator threshold: • min value = 2.375 V • max value = 2.625 V	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	15 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SOL_SHORT_NORMAL_CLOSE_DAP	C0004	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Solenoid coils shorted internally. • Solenoid shorted to a voltage supply or ground. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	The MCU can make the distinction between open driver and shorted coil by performing a coil test pulse on the faulted channel with all other coil channels off. Drain comparator threshold: • min value = 2.375 V • max value = 2.625 V	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	15 ms	Type A. MIL Illumination.
SOL_SHORT_PEDAL_SIM_ISO	C0024	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Solenoid coils shorted internally. • Solenoid shorted to a voltage supply or ground. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	The MCU can make the distinction between open driver and shorted coil by performing a coil test pulse on the faulted channel with all other coil channels off. Drain comparator threshold: • min value = 2.375 V • max value = 2.625 V	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	15 ms	Type A. MIL Illumination.
SOL_SHORT_NORMAL_OPEN_DAP	C0002	• The ASIC shall detect an open driver condition or a shorted coil condition on the external driver FETs by monitoring the drain voltage while the driver is commanded on. The ASIC shall generate a filtered drain comparator feedback signal by comparing the DRDx pin voltage to the drain comparator threshold, and by then filtering the result for the drain comparator feedback debounce time.	• Solenoid coils shorted internally. • Solenoid shorted to a voltage supply or ground. • Defective solenoid driver FET. • Defective printed circuit board. • Defective microprocessor. • Anything that keeps solenoid feedback voltage low when the solenoid is not energized.	The MCU can make the distinction between open driver and shorted coil by performing a coil test pulse on the faulted channel with all other coil channels off. Drain comparator threshold: • min value = 2.375 V • max value = 2.625 V	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	15 ms	Type A. MIL Illumination.
SOL_OVERTEMP_3WAY_PRIMARY	C0001	• Solenoid Over Temperature • At power up the solenoids are set to the maximum of the ambient temperature as reported by the Polaris ASIC or the solenoid temperature reading stored in NVRAM from the last ignition cycle.	Anything that causes the solenoid to be active for excessive (usually unintended) period of time	Solenoid_Temperature > 265 °C	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	1 s	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SOL_OVERTEMP_3WAY_SECONDARY	C0003	• Solenoid Over Temperature • At power up the solenoids are set to the maximum of the ambient temperature as reported by the Polaris ASIC or the solenoid temperature reading stored in NVRAM from the last ignition cycle.	Anything that causes the solenoid to be active for excessive (usually unintended) period of time	Solenoid_Temperature > 265 °C	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	1 s	Type A. MIL Illumination.
SOL_OVERTEMP_NORMAL_CLOSE_DAP	C0004	• Solenoid Over Temperature • At power up the solenoids are set to the maximum of the ambient temperature as reported by the Polaris ASIC or the solenoid temperature reading stored in NVRAM from the last ignition cycle.	Anything that causes the solenoid to be active for excessive (usually unintended) period of time	Solenoid_Temperature > 265 °C	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	1 s	Type A. MIL Illumination.
SOL_OVERTEMP_PEDAL_SIM_ISO	C0024	• Solenoid Over Temperature • At power up the solenoids are set to the maximum of the ambient temperature as reported by the Polaris ASIC or the solenoid temperature reading stored in NVRAM from the last ignition cycle.	Anything that causes the solenoid to be active for excessive (usually unintended) period of time	Solenoid_Temperature > 265 °C	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	1 s	Type A. MIL Illumination.
SOL_OVERTEMP_NORMAL_OPEN_DAP	C0002	• Solenoid Over Temperature • At power up the solenoids are set to the maximum of the ambient temperature as reported by the Polaris ASIC or the solenoid temperature reading stored in NVRAM from the last ignition cycle.	Anything that causes the solenoid to be active for excessive (usually unintended) period of time	Solenoid_Temperature > 265 °C	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	1 s	Type A. MIL Illumination.
SOL_DRIVER_OVERTEMP_ISO_FRONT_LEFT	C0010	• Driver Overtemp info transmitted via SPI from Polaris ASIC	• Anything that causes the solenoid driver to be active for excessive (usually unintended) period of time	Polaris ASIC sends diagnostic information that the driver used to control the coil has exceeded the maximum alloted temperature. Microprocessor recieves the information via SPI from the ASIC	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	5 msec	Type A. MIL Illumination.
SOL_DRIVER_OVERTEMP_ISO_FRONT_RIGHT	C0014	• Driver Overtemp info transmitted via SPI from Polaris ASIC	• Anything that causes the solenoid driver to be active for excessive (usually unintended) period of time	Polaris ASIC sends diagnostic information that the driver used to control the coil has exceeded the maximum alloted temperature. Microprocessor recieves the information via SPI from the ASIC	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	5 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SOL_DRIVER_OVERTEMP_ISO_REAR_LEFT	C0018	• Driver Overtemp info transmitted via SPI from Polaris ASIC	• Anything that causes the solenoid driver to be active for excessive (usually unintended) period of time	Polaris ASIC sends diagnostic information that the driver used to control the coil has exceeded the maximum alloted temperature. Microprocessor recieves the information via SPI from the ASIC	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	5 msec	Type A. MIL Illumination.
SOL_DRIVER_OVERTEMP_ISO_REAR_RIGHT	C001C	• Driver Overtemp info transmitted via SPI from Polaris ASIC	• Anything that causes the solenoid driver to be active for excessive (usually unintended) period of time	Polaris ASIC sends diagnostic information that the driver used to control the coil has exceeded the maximum alloted temperature. Microprocessor recieves the information via SPI from the ASIC	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	5 msec	Type A. MIL Illumination.
SOL_DRIVER_OVERTEMP_PEDAL_SIM_ISO	C0024	• Driver Overtemp info transmitted via SPI from Polaris ASIC	Anything that causes the solenoid to be active for excessive (usually unintended) period of time	Polaris ASIC sends diagnostic information that the driver used to control the coil has exceeded the maximum alloted temperature. Microprocessor recieves the information via SPI from the ASIC	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	5 msec	Type A. MIL Illumination.
SOL_DRIVER_OVERTEMP_NORMAL_OPEN_DAP	C0002	• Driver Overtemp info transmitted via SPI from Polaris ASIC	Anything that causes the solenoid to be active for excessive (usually unintended) period of time	Polaris ASIC sends diagnostic information that the driver used to control the coil has exceeded the maximum alloted temperature. Microprocessor recieves the information via SPI from the ASIC	1. Solenoid is commanded On 2. Power Switch is On 3. {EXCESSIVE_LOW_SYSTEM_VOLTAGE} 7.5 V < Supply Voltage < 18 V {EXCESSIVE_HIGH_SYSTEM_VOLTAGE}	5 msec	Type A. MIL Illumination.
CLAMP_ACTIVATION_FAILURE_NORMAL_OPEN_DAP	C0002	Polaris ASIC monitors the solenoid back EMF. If it is above +40V then the Polaris triggers a Clamping Response. If this occurs on two consecutive shut-offs then the Clamp Activation bit is set and the coil output is shut off. Microprocessor receives the information via SPI from the ASIC	• Defective / Missing Flyback Diode • Defective printed circuit board • Defective Polaris ASIC	Microprocessor receives the information via SPI from the ASIC every 5 msec. If the Clamp Activation bit is set then the bit and coil output are reset to allow another test run until the Clamp Activation Fault has matured.	1. Coil Overcurrent DTC is not set 2. No CLAMP_ACTIVATION_FAILURE DTC is set 3. execute as part of Power-Up System Test, Periodic Coil Test or anytime ABS Iso is activated during performance	45 counts (minimum 3 failures in 10 attempts)	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
CLAMP_ACTIVATION_FAILURE_PEDAL_SIM_ISO	C0024	Polaris ASIC monitors the solenoid back EMF. If it is above +40V then the Polaris triggers a Clamping Response. If this occurs on two consecutive shut-offs then the Clamp Activation bit is set and the coil output is shut off. Microprocessor receives the information via SPI from the ASIC	• Defective / Missing Flyback Diode • Defective printed circuit board • Defective Polaris ASIC	Microprocessor receives the information via SPI from the ASIC every 5 msec. If the Clamp Activation bit is set then the bit and coil output are reset to allow another test run until the Clamp Activation Fault has matured.	1. Coil Overcurrent DTC is not set 2. No CLAMP_ACTIVATION_FAILURE DTC is set 3. execute as part of Power-Up System Test, Periodic Coil Test or anytime ABS Iso is activated during performance	45 counts (minimum 3 failures in 10 attempts)	Type A. MIL Illumination.
LEAKY_DRIVER_UNKNOWN_ABS_CIRCUITS	C0024	• Slip Control Power Switch must be commanded ON than subsequently commanded OFF	• Defective FET • Defective printed circuit board	If the Slip Control Power decreases at a rate that is faster than expected, fault will be set. If the power decreases from 100% to 30% in 1 msec, fault is set.	• Power Switch is ON, then OFF • will only be retested after a power cycle	1 Count	Type A. MIL Illumination.
LEAKY_DRIVER_UNKNOWN_BOOST_CIRCUITS	C0024	• Slip Control Power Switch must be commanded ON than subsequently commanded OFF	• Defective FET • Defective printed circuit board	If the Slip Control Power decreases at a rate that is faster than expected, fault will be set. If the power decreases from 100% to 30% in 1 msec, fault is set.	• Power Switch is ON, then OFF • will only be retested after a power cycle	1 Count	Type A. MIL Illumination.
SOL_CC_DC_SATURATED_HIGH_ISO_FRONT_RIGHT	C0014	If a closed loop current control loop is broken, or if the target current is not physically achievable due to external limitations (e.g. coil resistance or supply voltage) or due the minimum on-time, the control loop's integrator shall cause the duty cycle command to saturate high or low. The time to reach saturation depends upon the tuning of the controller coefficients and the current feedback error.	Defective PCB Wiring	Duty cycle is out of range	Polaris is initialized	100 ms	Type A. MIL Illumination.
SOL_CC_DC_SATURATED_LOW_ISO_FRONT_RIGHT	C0014	If a closed loop current control loop is broken, or if the target current is not physically achievable due to external limitations (e.g. coil resistance or supply voltage) or due the minimum on-time, the control loop's integrator shall cause the duty cycle command to saturate high or low. The time to reach saturation depends upon the tuning of the controller coefficients and the current feedback error.	Defective PCB Wiring	Duty cycle is out of range	Polaris is initialized	100 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SOL_CC_DC_SATURATED_HIGH_ISO_FRONT_LEFT	C0010	If a closed loop current control loop is broken, or if the target current is not physically achievable due to external limitations (e.g. coil resistance or supply voltage) or due the minimum on-time, the control loop's integrator shall cause the duty cycle command to saturate high or low. The time to reach saturation depends upon the tuning of the controller coefficients and the current feedback error.	Defective PCB Wiring	Duty cycle is out of range	Polaris is initialized	100 ms	Type A. MIL Illumination.
SOL_CC_DC_SATURATED_LOW_ISO_FRONT_LEFT	C0010	If a closed loop current control loop is broken, or if the target current is not physically achievable due to external limitations (e.g. coil resistance or supply voltage) or due the minimum on-time, the control loop's integrator shall cause the duty cycle command to saturate high or low. The time to reach saturation depends upon the tuning of the controller coefficients and the current feedback error.	Defective PCB Wiring	Duty cycle is out of range	Polaris is initialized	100 ms	Type A. MIL Illumination.
SOL_CC_DC_SATURATED_HIGH_ISO_REAR_RIGHT	C001C	If a closed loop current control loop is broken, or if the target current is not physically achievable due to external limitations (e.g. coil resistance or supply voltage) or due the minimum on-time, the control loop's integrator shall cause the duty cycle command to saturate high or low. The time to reach saturation depends upon the tuning of the controller coefficients and the current feedback error.	Defective PCB Wiring	Duty cycle is out of range	Polaris is initialized	100 ms	Type A. MIL Illumination.
SOL_CC_DC_SATURATED_LOW_ISO_REAR_RIGHT	C001C	If a closed loop current control loop is broken, or if the target current is not physically achievable due to external limitations (e.g. coil resistance or supply voltage) or due the minimum on-time, the control loop's integrator shall cause the duty cycle command to saturate high or low. The time to reach saturation depends upon the tuning of the controller coefficients and the current feedback error.	Defective PCB Wiring	Duty cycle is out of range	Polaris is initialized	100 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SOL_CC_DC_SATURATED_HIGH_ISO_REAR_LEFT	C0018	If a closed loop current control loop is broken, or if the target current is not physically achievable due to external limitations (e.g. coil resistance or supply voltage) or due the minimum on-time, the control loop's integrator shall cause the duty cycle command to saturate high or low. The time to reach saturation depends upon the tuning of the controller coefficients and the current feedback error.	Defective PCB Wiring	Duty cycle is out of range	Polaris is initialized	100 ms	Type A. MIL Illumination.
SOL_CC_DC_SATURATED_LOW_ISO_REAR_LEFT	C0018	If a closed loop current control loop is broken, or if the target current is not physically achievable due to external limitations (e.g. coil resistance or supply voltage) or due the minimum on-time, the control loop's integrator shall cause the duty cycle command to saturate high or low. The time to reach saturation depends upon the tuning of the controller coefficients and the current feedback error.	Defective PCB Wiring	Duty cycle is out of range	Polaris is initialized	100 ms	Type A. MIL Illumination.
SOL_CC_DC_SATURATED_HIGH_NORMAL_OPEN_DAP	C0002	If a closed loop current control loop is broken, or if the target current is not physically achievable due to external limitations (e.g. coil resistance or supply voltage) or due the minimum on-time, the control loop's integrator shall cause the duty cycle command to saturate high or low. The time to reach saturation depends upon the tuning of the controller coefficients and the current feedback error.	Defective PCB Wiring	Duty cycle is out of range	Polaris is initialized	100 ms	Type A. MIL Illumination.
SOL_CC_DC_SATURATED_LOW_NORMAL_OPEN_DAP	C0002	If a closed loop current control loop is broken, or if the target current is not physically achievable due to external limitations (e.g. coil resistance or supply voltage) or due the minimum on-time, the control loop's integrator shall cause the duty cycle command to saturate high or low. The time to reach saturation depends upon the tuning of the controller coefficients and the current feedback error.	Defective PCB Wiring	Duty cycle is out of range	Polaris is initialized	100 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SOL_CC_DC_SATURATED_HIGH_PEDAL_SIM_ISO	C0024	If a closed loop current control loop is broken, or if the target current is not physically achievable due to external limitations (e.g. coil resistance or supply voltage) or due the minimum on-time, the control loop's integrator shall cause the duty cycle command to saturate high or low. The time to reach saturation depends upon the tuning of the controller coefficients and the current feedback error.	Defective PCB Wiring	Duty cycle is out of range	Polaris is initialized	100 ms	Type A. MIL Illumination.
SOL_CC_DC_SATURATED_LOW_PEDAL_SIM_ISO	C0024	If a closed loop current control loop is broken, or if the target current is not physically achievable due to external limitations (e.g. coil resistance or supply voltage) or due the minimum on-time, the control loop's integrator shall cause the duty cycle command to saturate high or low. The time to reach saturation depends upon the tuning of the controller coefficients and the current feedback error.	Defective PCB Wiring	Duty cycle is out of range	Polaris is initialized	100ms	Type A. MIL Illumination.
SOL_OVER_VOLTAGE_NORMAL_CLOSE_DAP	C0004	If the suppression diode is missing or failed the ASIC detects it by monitoring the solenoid back EMF. Reading above +40V sets the Overvoltage Warning SPI flag. The coils output is not shut-off by the ASIC. Software matures the fault by monitoring the SPI flag. NOTE: There are no suppression diodes on any of the Dump coils because they are not PWM'd.	Defective/Missing Suppression diode Defective PCB	Duty cycle is out of range	Polaris is initialized	5ms	Type A. MIL Illumination.
SOL_OVER_VOLTAGE_SIM_TEST	C05D5	If the suppression diode is missing or failed the ASIC detects it by monitoring the solenoid back EMF. Reading above +40V sets the Overvoltage Warning SPI flag. The coils output is not shut-off by the ASIC. Software matures the fault by monitoring the SPI flag. NOTE: There are no suppression diodes on any of the Dump coils because they are not PWM'd.	Defective/Missing Suppression diode Defective PCB	Duty cycle is out of range	Polaris is initialized	5ms	Type A. MIL Illumination.
DC_SOL_REGULATION_FAILURE	P0606	• The ASIC shall monitor the state of each DROx output and report if it does not match the commanded state.	• Defective system ASIC	The MCU shall monitor ASIC's "DROx Gate Monitor Fault" SPI bits.	• Polaris is initialized	15 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SOL_DUTY_CYCLE_FDBK_PLAUS_FAULT	P0606	The MCU shall monitor battery voltage and maintain an estimated coil temperature/resistance model. For a given current command, the MCU shall estimate the required duty cycle. The MCU shall verify that the estimated duty cycle against the ASIC's reported "CC_DRx Duty Cycle Command Feedback" match within a TBD tolerance. Current threshold is 20%	• Defective system ASIC ASIC cannot control sol current properly	The MCU shall monitor battery voltage and maintain an estimated coil temperature/resistance model. For a given current command, the MCU shall estimate the required duty cycle. The MCU shall verify that the estimated duty cycle against the ASIC's reported "CC_DRx Duty Cycle Command Feedback" match within a TBD tolerance. Current threshold is 10%	• Polaris is initialized	15 msec	Type A. MIL Illumination.
COIL_CURRENT_FDBK_PLAUS_FAULT	P0606	The ASIC channel performs coil current measurements once per switching period and places the conversion results in the "CC_DRx Current Result" SPI field. While a CC_DRx coil drive is active, the MCU monitors the ASIC's "CC_DRx Current Result" SPI field and verifies the result matches the commanded current. If not, the MCU disables the faulty coil driver channel.	• Defective system ASIC ASIC cannot control sol current properly	The ASIC channel performs coil current measurements once per switching period and places the conversion results in the "CC_DRx Current Result" SPI field. While a CC_DRx coil drive is active, the MCU monitors the ASIC's "CC_DRx Current Result" SPI field and verifies the result matches the commanded current. If not, the MCU disables the faulty coil driver channel.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
Group 4 - Electronic Control Unit (ECU)							
SPI_FAILURE_ASIC	P0606	• This fault can be set by problems communicating over SPI between the MICRO and the Polaris ASIC. It is checked ONCE at power up. • The SPI initialization will fail if the driver has not finished a previous transmission when a new transmission is required (not enough SPI throughput). • The SPI initialization will also fail if the driver detects an error (bad parity, control register data echo over the SPI or control register data read does not match). • If the Polaris ASIC fails to initialize SPI communication after 2 retries (3 attempts total) then this fault is set • Counter: Count 1-up • Monitor Rate: 1ms	• Defective printed circuit board. • Defective Polaris ASIC. • Defective microprocessor. • Noisy Power	Polaris Error Flag = TRUE Polaris.Error_Flags != 0 Polaris.Error_Flags_Observed |= Polaris.Error_Flags	• Power Switch is ON	3 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
FSC_SPI_TRANSMIT_FAILURE	P062F	• This fault can be set by problems communicating over SPI with the Polaris ASIC. The fault will set if the driver has not finished a previous transmission when a new transmission is required (not enough SPI throughout). The fault will also set if the driver detects an error (bad parity, control register data echo over the spi or control register data read does not match) in a single transmission and is unable to complete this transmission after 2 retries (3 attempts total). • Counter: Count 1-up • Monitor Rate: 1ms	• Defective printed circuit board. • Defective Polaris ASIC. • Defective microprocessor. • Noisy Power	Polaris Error Flag = TRUE Polaris.Error_Flags != 0 Polaris.Error_Flags_Observed |= Polaris.Error_Flags	• Power Switch is ON	3 ms	Type A. MIL Illumination.
NVRAM_DEVICE_INOPERATIVE	P062F	• This fault is set 1. When SPI driver is unable to do message transfer 2. If unable to write or time out before write operation could complete. 3. If requested message transfer not in time (including wait time)	• Problem in chip select line • fault in SPI driver related code/circuit.	device operational flag = FALSE (error during read write request occured)	• Power Switch is ON	5ms	Type A. MIL Illumination.
NVRAM_WRITE_FAILURE	P062F	• This fault is detected by the NVRAM handler. The NVRAM handler verifies a successful write event by reading back the information that is expected to be stored in NVRAM and also verifying the checksum.	• Communication problem with NVRAM chip • NVRAM hardware problem • PCB problem	If the NVRAM handler detects an unsuccessful write event three times, the fault is set.	• Power Switch in ON	60 msec	Type A. MIL Illumination.
COIL_DRIVER_SPI_FAILURE	P0606	• SPI Failure(SPI Overrun Failure) • This fault can be set by problems communicating over SPI with the Coil Driver ASIC. The fault will set if the driver has not finished a previous transmission when a new transmission is required (not enough SPI throughout). The fault will also set if the driver detects an error (bad parity, control register data echo over the spi or control register data read does not match) in a single transmission and is unable to complete this transmission after 2 retries (3 attempts total).	• SPI Noise • Part problem	SPI communication to Coil Driver failed	• Power Switch is ON	3ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
EXT_WATCHDOG_FAIL	P0606	• None.	• Defective system ASIC	Periodically (e.g. once per ignition cycle), the MCU shall perform the following watchdog test (or equivalent): (1) Start with the Watchdog Counter Value SPI field = 0, the WDEN pin high, and all other "watchdog-enabled functions" otherwise enabled. (2) Verify Watchdog Status SPI bit is 0 and all "watchdog-enabled functions" are disabled. (3) Service watchdog until the Watchdog Counter Value = 6. Verify the conditions from (2) remain. (4) Set the WDEN pin low, then service the watchdog. (5) Confirm the Watchdog Counter Value = 7 and all "watchdog-enabled functions" are disabled. (6) Allow the watchdog to timeout, then set the WDEN pin high. (7) Confirm the Watchdog Counter Value = 0, Watchdog Status bit is 0, and all "watchdog-enabled functions" are disabled.	• Polaris is initialized	10 msec	Type A. MIL Illumination.
AD_PERIPHERAL_TIMEOUT_FAILURE	P060B	• A/D Peripheral Timeout Failure • When reading an A/D channel, the software enters a "wait" loop where it looks for a bit in an A/D register to be set, indicating that the conversion is complete. A "timeout" mechanism exists that breaks out of the wait loop after 100 usec (well longer than it is ever expected to complete an A/D conversion) has elapsed. If this timeout mechanism is executed, a fault code is set. • Counter: Count 1-up • Monitor Rate: 10ms	• Defective printed circuit board. • Defective Polaris ASIC. • Defective microprocessor.	Adc Port Lockup Detected = TRUE	• Power Switch is ON	5ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
AD_EVENT_LOCKUP	P060B	A/D Event Lockup Failure Two detection methods: No A/D conversions in the last 5 msec: A counter is incremented when A/D conversion results are retrieved. Every 5 msec this counter is checked. If it is 0, then the AD_EVENT_LOCKUP fault will begin to mature. If greater than 0, then it is cleared. 2 consecutive failures are needed to set the fault. Adc_Synchronization_Failed flag is TRUE: The ASIC will set this flag TRUE when the conversion count (number of channels converted) is larger than what is expected (9). 2 consecutive failures are needed to set the fault.	• Defective printed circuit board. • Defective Polaris ASIC. • Defective microprocessor.	Adc Lockup Count = 0 or Adc Synchronization Failed = TRUE	• Power Switch is ON	5ms	Type A. MIL Illumination.
SOLENOID_TIMEOUT_FAILURE	P0606	• Solenoid Timeout Failure Each solenoid in the system is expected to generate a HET interrupt command to indicate the end of a solenoid pulse duration.. Each solenoid timeout interrupt results in logic that sums the total number of HET interrupts. This is done independently for each channel. At the completion of the System Self-Test, the number of valid HET interrupts, are compared. The total number of HET interrupts is expected to be equal to the number of solenoids in the system. If the number of interrupts that occurred does not equal the expected number, a failure is indicated and this fault is set. • After the system self test is complete, each solenoid is test again once per every 5 sec, as described above. • The fault is cleared when above condition does not exist. • Counter: Count 1-up • Monitor Rate: 10MS	• Defective microprocessor. • Incorrect microprocessor application code.	At least one solenoid fails to get all timeout interrupts for all 0.5 ms pulses	• Mode manager is normal mode • Power switch is not faulted • System is not initializing • System is not re-initializing • Engine is not being cranked • Diagnostic commands are not requested • System is not shutting down	5ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SOLENOID_PERIODIC_INTERRUPT_FAILURE	P0606	HET Periodic Interrupt Failure Verifies that one particular High End Timer interrupt (HET) feedback; occurs every pass through the schedule loop time (10MS). This fault is set if no HET interrupt feedback has occurred for 3 consequentive schedule loop time (10MS). The HET interrupt feedback that is checked is the solenoid feedback interrupts, This Solenoid feedback interrupt is scheduled every interval of the operating system. The fault is cleared when above condition does not exist. Counter: Count 1-up-Reset Monitor Rate: 10MS	• Defective microprocessor. Incorrect microprocessor application code, ex. Bad scheduler	periodic het interrupt flag = FALSE (periodic interrupt did not occur)	Power Switch is ON	5ms	Type A. MIL Illumination.
SYS_ASIC_U3_SELECT_FAILURE	P0606	• If the external U3 FET is present, the ASIC shall set the U3 External FET SPI bit. • Provide a SPI bit which reports whether the internal or external U3 FET has been selected.	• Defective system ASIC	The MCU shall read the ASIC's U3 External FET status bit and compares against the expected value.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_WDEN_STATUS_CORR	P062F	• The ASIC shall provide the WDEN Status SPI bit which reflects the filtered state of the WDEN pin. The MCU shall monitor the ASIC's WDEN Status SPI flag and verify it is the expected value.	• Defective system ASIC	WDEN Status SPI flag <> WDEN PIN status	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_EXCESS_STARTUP	P0606	• During the power-on sequence, the ASIC shall monitor the U5, U3, and U1 voltages, with respect to the discharge voltage threshold. • If the power-on sequence is delayed (e.g. due to a slow U5, U3, U1, discharge), the ASIC shall report the Excessive Startup Time SPI flag.	• Defective system ASIC	The MCU shall monitor the ASIC's Excessive Startup Time SPI flag.	• Polaris is initialized	15 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SYS_ASIC_ADC_REF_HIGH	P060B	• The ASIC shall provide three ADC test voltage channels fixed to internal voltage references: Vhigh (ADREFHI),Vlow (GND_Q1), and Vmid (ADREFHI/2).	• Defective system ASIC	Each software loop, the MCU shall read the ADC conversion results for the Vhigh, Vlow and Vmid ASIC ADC channels over SPI, and compare them against fixed detection thresholds. Note: This MCU requirement is the same as in SM137.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_ADC_REF_MID	P060B	• The ASIC shall provide three ADC test voltage channels fixed to internal voltage references: Vhigh (ADREFHI),Vlow (GND_Q1), and Vmid (ADREFHI/2).	• Defective system ASIC	Each software loop, the MCU shall read the ADC conversion results for the Vhigh, Vlow and Vmid ASIC ADC channels over SPI, and compare them against fixed detection thresholds. Note: This MCU requirement is the same as in SM137.	• Polaris is initialized	25 msec	Type A. MIL Illumination.
SYS_ASIC_ADC_REF_LOW	P060B	• The ASIC shall provide three ADC test voltage channels fixed to internal voltage references: Vhigh (ADREFHI),Vlow (GND_Q1), and Vmid (ADREFHI/2).	• Defective system ASIC	Each software loop, the MCU shall read the ADC conversion results for the Vhigh, Vlow and Vmid ASIC ADC channels over SPI, and compare them against fixed detection thresholds. Note: This MCU requirement is the same as in SM137.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_ADC_ATTN_BIT_STUCK	P060B	• The MCU shall periodically (e.g. once per ignition cycle) command each active (i.e. used) ASIC external ADC channel with the attenuation mode opposite of normal operation and verify that its attenuation enable feedback SPI bit is not stuck.	• Defective system ASIC	Any one of the 10 ASIC external ADC channel's attenuation enable feedback SPI bits is stuck	• Polaris is initialized	15 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SYS_ASIC_ADC_ATTN_FACTOR	P060B	• Each background conversion loop, the ASIC shall perform the conversion of the internal Vmid voltage both with and without the selectable attenuation switched in. The conversion results shall be stored respectively in the separate ADC Vmid with Attenuation Test Result and ADC Vmid Test Result SPI fields. • Each software loop, the MCU shall calculate the ASIC's ADC attenuation factor by reading the ADC Vmid with Attenuation Test Result and ADC Vmid Test Result SPI fields, calculate the ASIC's ADC attenuation factor by dividing the attenuated result by the non-attenuated result, and verify the resulting attenuation factor is within limits.	• Defective system ASIC	Calculated ADC attenuation factor < 0.6176 OR Calculated ADC attenuation factor > 0.6320	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_EXT_ADC_FAILURE	P060B	The ASIC reports the state of the attenuation (selected or not selected) for each external ADC channel via the "ADx Attenuation Feedback" SPI bits within the ADC result registers. For fault detection purposes, the feedback bits directly monitor the control signal state within the SAR Logic, as opposed to only echoing the "ADx Attenuation Select" command. Each time an ASIC external ADC channel is read over SPI, the SW also reads the "ADx Attenuation Feedback" bit and compare the result against the expected (i.e. commanded) attenuation setting.		Compare the ASIC external ADC channel read of SPI and the ADx Attenuation feedback bit against expected attenuation setting		15ms	Type A. MIL Illumination.
SYS_ASIC_SYNC_PULSE_DETECT	P0606	• ASIC provides SYNC ARMED SPI mapped bit that can be set and cleared through SPI, or cleared by detected valid SYNC rising edge event. • Provide un-armed SYNC edge detected SPI mapped bit.	• Defective system ASIC	Periodically (e.g. once per ignition cycle) the MCU shall send a rising edge on the SYNC pin, while the SYNC Armed SPI bit is low. The MCU shall verify that the Unarmed SYNC Edge Detected SPI flag is set.	• Polaris is initialized	15 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SYS_ASIC_SPI_DETECT	P0606	• None.	• Defective system ASIC	Periodically, and within the fault response time, the MCU shall send separate SPI frames with: (1) an incorrect CRC (2) an incorrect number of SPI bits (3) an invalid command (invalid address) (4) invalid data The MCU shall then verify that the CRC is corrupted in the ASIC's response frame to each of the above errors.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_REGISTER	P0606	• The ASIC shall provide the Storage SPI register. The register contents shall have no effect on the ASIC operation. Register contents shall only be modified by a SPI write and not by any internal ASIC action.	• Defective system ASIC	Every major software loop (e.g. 5 - 10ms), the MCU shall perform a write to, normal mode read from and dump mode read from the Storage SPI register. Each loop, the value written shall change, and shall include checkerboard (0xAA, 0x55), walking 1s and walking 0s). The MCU shall verify the written and read values match. After performing a write to a safety critical SPI register, the MCU shall perform a read back of the same register, and verify that the contents were written. The read shall occur within the same software loop, in order to allow the MCU to correct any mis-write within the fault response time. Note: The read back refers to a separate read request, and is not the same as verifying the write echo.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_DUPL_SEED	P0606	• None.	• Defective system ASIC	The MCU shall detect if ASIC provides the same seed value 3 times in a row.	• Polaris is initialized	15 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SYS_ASIC_AD_REFRESH_FAILURE	P060B	• The ASIC shall set the Data Read bit to indicate that an individual ADC result has been updated since the register was last read.	• Defective system ASIC	Each time an ASIC ADC channel is read over SPI, the MCU shall also read the Data Read bit. If the Data Read bit is not set, the MCU treats the result as old data. If the Data Read bit is not set and the time since the prior ADC read is longer than the ASIC ADCs background loop time, the MCU shall detect a fault Periodically (e.g. once per ignition cycle), the MCU shall read each ADC result register immediately 3 times in a row. If the Data Read bit is never low during the 3 reads, flag a fault that the Data Read bit is stuck high. Repeat for all ASIC ADC channels. Note: Because the ASIC could update the result register between two register reads (resulting in two high Data Read bits), 3 successive reads are required.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_AD_DATA_READ_STUCK	P060B	• The ASIC shall set the Data Read bit to indicate that an individual ADC result has been updated since the register was last read.	• Defective system ASIC	Periodically (e.g. once per ignition cycle), the MCU shall read each ADC result register immediately 3 times in a row. If the Data Read bit is never low during the 3 reads, flag a fault that the Data Read bit is stuck high. Repeat for all ASIC ADC channels. Note: Because the ASIC could update the result register between two register reads (resulting in two high Data Read bits), 3 successive reads are required.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_MISSING_SYNC_EDGE	P060B	• After a rising SYNC pin edge has occurred, the SW shall read the ASIC's "SYNC Armed Status" flag and detects if the bit is still high (indicating the rising SYNC pin edge was not detected).	• Defective system ASIC	The ASIC clears the "SYNC Armed" bit after a rising edge has occurred on the SYNC pin. The ASIC provides the "SYNC Armed Status" SPI flag, which reflects the state of the "SYNC Armed" SPI bit. After a rising SYNC pin edge has occurred, the SW reads the ASIC's "SYNC Armed Status" SPI bit and detects if the bit is still high (indicating the rising SYNC pin edge was not detected).	• Polaris is initialized	15 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
DC_SOL_ON_TIME_MON_FAILED	P0606	The ASIC shall monitor the filtered DRDx feedback voltage and shall provide an on-time counter (for each channel) which shall accumulate the QDRx on-time. At each valid SYNC edge, the ASIC shall latch the current accumulated value into the DRDx On-Time Feedback Register and clear the on-time counter. The MCU shall integrate the commanded on-time between valid SYNC pulses and verify it matches the ASIC's reported result. Current threshold is 250 * MICROSECOND	• Defective system ASIC ASIC is not controlling PWM properly	Compare the solenoid commanded on time to the measured on time. If the difference in the two times is >250 microsec for 10 consecutive checks then the fault is immediately matured	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_UNEXPECTED_SYNC_PULSE	P0606	• The MCU shall monitor the ASIC's Unarmed SYNC Edge Detected SPI bit and verify no expected SYNC pin edges have occurs. • After a rising SYNC pin edge has occurred (e.g. at the start of the next software loop), the MCU shall read the ASIC's SYNC Armed Status SPI bit and confirm that the rising SYNC pin edge occurred (in which case the bit will be low).		Fault will set if the MCU detects an unexpected sync pulse from the ASIC by monitoring the Unarmed SYNC Edge Detected SPI bit	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_SYNC_TIMEOUT	P0606	The ASIC detects if the time since the prior valid rising SYNC edge exceeds the SYNC timeout time. Then the ASIC turns off the coil drivers and sets the "SYNC Timeout" SPI bit. The SW monitors the ASIC's "SYNC Timeout" SPI bit to detect if a SYNC Timeout has occurred.			• Polaris is initialized	max 17ms	Type A. MIL Illumination.
SYS_ASIC_CONFIG_REG_FAILURE	P0606	• Configuration Registers: (These are written once at startup.) After writing once, read back and verify their contents during every subsequent 5ms SPI loop.	• register error • register rewrite error	Rewrite registers with an incorrect value Verify if the write was successful during the following 5ms SPI loop's read & verify. If the rewrite is not successful after 3 attempts in a row, set a fault.	• Polaris is initialized	15 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SYS_ASIC_CONTROL_REG_FAILURE	P0606	• Control Registers: (These are written every 5ms loop for control or failsafing purposes.) For those registers not covered by other SMs, read and verify every 5ms loop, prior to performing the write.	• register error • register rewrite error	Rewrite registers with an incorrect value Verify if the write was successful during the following 5ms SPI loop's read & verify. If the rewrite is not successful after 3 attempts in a row, set a fault.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
ENQ_PIN_FAILED	P0606	• The Polaris ASIC provides a digital push-pull output, ENQ. ENQ is high when the ENQ Enable SPI bit is set, the Watchdog Status is "in range", WDEN Status is high, and nRST Status is high. Otherwise ENQ is low. ENQ is used as a pre-driver to enable ECU circuitry.	• Defective ASIC.	The MCU shall continuously monitor the ASIC ENQ feedback signal state and verify that it has the expected state. The HW shall provide a digital feedback signal of ASIC ENQ signal to MCU digital input.	• Polaris is initialized	10 msec	Type A. MIL Illumination.
BROKEN_WIRE_BPWM_SWITCH_1	C004A	• Conversion results for VHigh and VLow ADC channels are out of range, then Broken Wire fault is set.	• Improper (broken wire) connection between the external analog sensor and the input pin. • Defective microprocessor.	• Each software loop, ADC conversion results for VHigh and VLow MMC ADC Channels are read. • If conversion results for VHigh and VLow are out of range, then Broken Wire fault is set.	• Power Switch is ON	5 msec	Type A. MIL Illumination.
BROKEN_WIRE_BPWM_SWITCH_5	C004A	• Conversion results for VHigh and VLow ADC channels are out of range, then Broken Wire fault is set.	• Improper (broken wire) connection between the external analog sensor and the input pin. • Defective microprocessor.	• Each software loop, ADC conversion results for VHigh and VLow MMC ADC Channels are read. • If conversion results for VHigh and VLow are out of range, then Broken Wire fault is set.	• Power Switch is ON	5 msec	Type A. MIL Illumination.
BROKEN_WIRE_TEMP_FDBK_A	P0606	• Conversion results for VHigh and VLow ADC channels are out of range, then Broken Wire fault is set.	• Improper (broken wire) connection between the external analog sensor and the input pin. • Defective microprocessor.	• Each software loop, ADC conversion results for VHigh and VLow MMC ADC Channels are read. • If conversion results for VHigh and VLow are out of range, then Broken Wire fault is set.	• Power Switch is ON	5 msec	Type A. MIL Illumination.
BROKEN_WIRE_COIL_THREE_WAY_PRIMARY_FDBK_A	C0001	• Broken wire faults is set when the low side driver drain feedback is not at expected value when coil and Base Brake Safety switch is commanded ON.	• Open coil detection • Defective microprocessor.	• The MCU monitors the low side driver drain feedback to determine an open coil failure while coil is commanded OFF and Base Brake Safety switch is commanded ON every 5msec. • Broken wire faults is set when the low side driver drain feedback is not at expected value when coil and Base Brake Safety switch is commanded ON.	• Power Switch is ON	30 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
BROKEN_WIRE_COIL_THREE_WAY_SECONDARY_FDBK_A	C0003	• Broken wire faults is set when the low side driver drain feedback is not at expected value when coil and Base Brake Safety switch is commanded ON.	• Open coil detection • Defective microprocessor.	• The MCU monitors the low side driver drain feedback to determine an open coil failure while coil is commanded OFF and Base Brake Safety switch is commanded ON every 5msec. • Broken wire faults is set when the low side driver drain feedback is not at expected value when coil and Base Brake Safety switch is commanded ON.	• Power Switch is ON	30 msec	Type A. MIL Illumination.
SYS_ASIC_U1_SELECT_FAILURE	P0606	• The U1 operating mode and voltage level selections are viewable via the U1 Mode Select Status and U1 Voltage Select Status SPI fields. The SPI feedback signals are internally routed so that they monitor the true state of the mode and voltage control circuits.	• Defective printed circuit board. • Defective ASIC. • Defective microprocessor.	The MCU verifies that the U1 Mode Select Status and U1 Voltage Select Status SPI fields in register 0x45 match the values which are hard-coded into SW corresponding the application's intended HW population. If a mismatch is detected, fault is set.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_NVM_FAIL	P062F	• During the ASIC's full active logic reset sequence (within the active mode), the ASIC shall read and compare the primary and inverted U1 mode and voltage SPI fields. • If primary and inverted SPI fields do not match, the ASIC shall configure the U1 regulator in the 1.1V, supervisor mode configuration and shall set the TRW NVM Fail SPI bit in registers 0x45 and 0x61.	• Defective printed circuit board. • Defective ASIC. • Defective microprocessor.	The MCU shall periodically verify that the TRW NVM Fail SPI bit (reg 0x45) is low. If the bit is read as high, fault is set.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_SM_DISABLED	P0606	• The ASIC shall set the Safety Mechanisms Disabled SPI bit when a test mode is active which prevents the ASIC from resetting the MCU or disabling power supplies in reaction to a fault.	• Defective printed circuit board. • Defective ASIC. • Defective microprocessor.	The MCU shall periodically verify that the Safety Mechanisms Disabled SPI bit is low. If the bit is read as high, fault is set.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_SPI_TRANSFER_ERROR	P0606	• The micro monitors the SPI data transmissions and checks for SPI transfer errors	• SPI transfer error • ASIC problem • PCB problem	If any of the below errors are observed in Spi Data transmission this fault will set. POLARIS_SPI_NOT_INITIALIZED POLARIS_SPI_TRANSFER_REJECTED POLARIS_SPI_TX_MSG_LENGTH_ERROR	• Continuous failsafing	15 msec	Type A. MIL Illumination.
Group 5 - Microcontroller							

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
ROM_CRC_FAILURE	P0606	• CRC ROM Failure R4 • The ROM self-test is a dynamic test that is called from the scheduler at a rate of 5 msec. Each ROM section is checksummed byte by byte. Each byte will be added to the current checksum for a section. If the byte being checked is the last byte of a section, then the setion is verified for a correct checksum stored at the end of the section.	• Defective microprocessor • Incorrect fault detection algorithm	calculated CRC != stored CRC	• Power Switch is ON	5 msec	Type A. MIL Illumination.
LMU_DATA_PATH_TEST_FAILURE	P0606	The fault will be set if the data written to the LMU SRAM does not match the data read back from the same location of the LMU SRAM	Permanent failure of the LMU (Local Memory Unit) SRAM data path	The test consists of the following sequence: 1. Write 8 different 8-bit values to sequential addresses in LMU SRAM. Data pattern: 0x1122334455667788 2. Perform a 64-bit read and compare against expected values 3. Write 4 different 16-bit values to sequential addresses in LMU SRAM. Data pattern: 0xEEDDCCBBAA998877 4. Perform a 64-bit read and compare against expected values 5. Write 2 different 32-bit values to sequential addresses in LMU SRAM. Data pattern: 0xA5A5A5A5A5A5A5A5 6. Perform a 64-bit read and compare against expected values	Always runs during initialization	1 Count	Type A. MIL Illumination.
SPINLOCK_FAULT_BUFFER_ERROR	P0606	Spinlock variable fails to go to available value before timeout expires.	Software Error CPU Failure	None	Always Enabled	10	Type A. MIL Illumination.
SPINLOCK_ONSTAR_FAULT_LATCHED_ERROR	P0606	Spinlock variable fails to go to available value before timeout expires.	Software Error CPU Failure	None	Always Enabled	10	Type A. MIL Illumination.
SPINLOCK_ONSTAR_FAULT_CLEARED_ERROR	P0606	Spinlock variable fails to go to available value before timeout expires.	Software Error CPU Failure	None	Always Enabled	10	Type A. MIL Illumination.
SPINLOCK_FMM_BLOCK_ERROR	P0606	Spinlock variable fails to go to available value before timeout expires.	Software Error CPU Failure	None	Always Enabled	10	Type A. MIL Illumination.
SPINLOCK_NVRAM_FAULT_BIT_ERROR	P0606	Spinlock variable fails to go to available value before timeout expires.	Software Error CPU Failure	None	Always Enabled	10	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
OS_TASK_MONITOR_FAULT_CORE0	P0606	Checks to be sure that all tasks on CPU0 are running	Software Error Partial Microcontroller Failure	None	Always Enabled	1 count	Type A. MIL Illumination.
OS_TASK_MONITOR_FAULT_CORE1	P0606	Checks to be sure that all tasks on CPU1 are running	Software Error Partial Microcontroller Failure	None	Always Enabled	1 count	Type A. MIL Illumination.
OS_TASK_MONITOR_FAULT_CORE2	P0606	Checks to be sure that all tasks on CPU2 are running	Software Error Partial Microcontroller Failure	None	Always Enabled	1 count	Type A. MIL Illumination.
OS_INTERNAL_FAILURE_CORE0	P0606	The OS has detected a serious failure such that, as determined by the OS vendor, it cannot continue safe operation on at least 1 CPU. This is most likely because of a failure in a hardware system that the OS depends on.	Failure in a hardware system that the OS depends on.	None	Always Enabled	10 msec	Type A. MIL Illumination.
OS_INTERNAL_FAILURE_CORE1	P0606	The OS has detected a serious failure such that, as determined by the OS vendor, it cannot continue safe operation on at least 1 CPU. This is most likely because of a failure in a hardware system that the OS depends on.	Failure in a hardware system that the OS depends on.	None	Always Enabled	10 msec	Type A. MIL Illumination.
OS_INTERNAL_FAILURE_CORE2	P0606	The OS has detected a serious failure such that, as determined by the OS vendor, it cannot continue safe operation on at least 1 CPU. This is most likely because of a failure in a hardware system that the OS depends on.	Failure in a hardware system that the OS depends on.	None	Always Enabled	10 msec	Type A. MIL Illumination.
RTOS_FAILURE_CORE0	P0606	EB OS detects an error situation and calls ErrorHook with a status code for which there is no other fault code.	Software Error	None	Always Enabled	5*Number of errors in 10ms update Cycle	Type A. MIL Illumination.
RTOS_FAILURE_CORE1	P0606	EB OS detects an error situation and calls ErrorHook with a status code for which there is no other fault code.	Software Error	None	Always Enabled	5*Number of errors in 10ms update Cycle	Type A. MIL Illumination.
RTOS_FAILURE_CORE2	P0606	EB OS detects an error situation and calls ErrorHook with a status code for which there is no other fault code.	Software Error	None	Always Enabled	5*Number of errors in 10ms update Cycle	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
UNEXPECTED_EXCEPTION_CORE0	P0606	The CPU detects a situation where it cannot successfully complete an instruction, such no memory exists at the read/write address or instruction code is invalid. The CPU branches to a predefined Trap address and control is transferred to the Elektrobit OS. The EB OS will call ProtectionHook with status code E_OS_PROTECTION_EXCEPTION provided the following two aspects are true. 1 – The trap was not a normal function of the OS. 2 – The OS does not have another more specific error code to use, such as E_OS_PROTECTION_MEMORY for a MPU violation.	Software Error Partial Microcontroller Failure	None	Always Enabled	10	Type A. MIL Illumination.
UNEXPECTED_EXCEPTION_CORE1	P0606	The CPU detects a situation where it cannot successfully complete an instruction, such no memory exists at the read/write address or instruction code is invalid. The CPU branches to a predefined Trap address and control is transferred to the Elektrobit OS. The EB OS will call ProtectionHook with status code E_OS_PROTECTION_EXCEPTION provided the following two aspects are true. 1 – The trap was not a normal function of the OS. 2 – The OS does not have another more specific error code to use, such as E_OS_PROTECTION_MEMORY for a MPU violation.	Software Error Partial Microcontroller Failure	None	Always Enabled	10	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
UNEXPECTED_EXCEPTION_CORE2	P0606	The CPU detects a situation where it cannot successfully complete an instruction, such no memory exists at the read/write address or instruction code is invalid. The CPU branches to a predefined Trap address and control is transferred to the Elektrobit OS. The EB OS will call ProtectionHook with status code E_OS_PROTECTION_EXCEPTION provided the following two aspects are true. 1 – The trap was not a normal function of the OS. 2 – The OS does not have another more specific error code to use, such as E_OS_PROTECTION_MEMORY for a MPU violation.	Software Error Partial Microcontroller Failure	None	Always Enabled	10	Type A. MIL Illumination.
FSMC_MISMATCH_VELOCITY	P0606	• Mismatched Wheel Velocity Failure • Both micro 1 and micro 2 are calculating the velocity for each wheel. All wheel speeds computed by the micro 1 are transmitted to the micro 2 every loop time. The micro 2 compares them to the appropriate velocities received from the micro 1.	• Defective • Microprocessor • At least one • wheel velocity • calculation • between • Micro 1 and • Micro 2 does not agree	Tolerance of any wheel velocity calculations is > +/- 10 km/h	• High wheel acceleration inhibits this routine	35 ms	Type A. MIL Illumination.
LOGICAL_SEQUENCE_FAULT_CORE0	P0606	If the software finds mismatch in current sequence compared to predefined sequence of the runnables then LSM flag in Core 0 is set.	Improper sequencing of runnables	Fault is set if LSM flag in Core 0 is set.	Continuous Failsafing	1 count	Type A. MIL Illumination.
LOGICAL_SEQUENCE_FAULT_CORE1	P0606	If the software finds mismatch in current sequence compared to predefined sequence of the runnables then LSM flag in Core 1 is set.	Improper sequencing of runnables	Fault is set if LSM flag in Core 1 is set.	Continuous Failsafing	1 count	Type A. MIL Illumination.
LOGICAL_SEQUENCE_FAULT_CORE2	P0606	If the software finds mismatch in current sequence compared to predefined sequence of the runnables then LSM flag in Core 2 is set.	Improper sequencing of runnables	Fault is set if LSM flag in Core 2 is set.	Continuous Failsafing	1 count	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
CPU_FAILURE_SEVERITY_X	P0606	• This failsafe is designed to detect when an unexpected interrupt has occurred	• Defective microprocessor • Improper Application Code	Fault is set when one of errors occur once: RAM ECC error RAM access error DMA error HET/NHET error MibSPI error PLL error CCM error	• Power Switch in ON	10msec	Type A. MIL Illumination.
CPU_FAILURE_SEVERITY_Y	P0606	Activates the FSP then checks to see if it truly got activated. Also checks to see if the ASIC saw the FSP pin activate.	• Defective microprocessor • Improper Application Code	If Polaris FSP test failed OR If Aurix FSP test failed	• Power Switch in ON	Checked every 20ms or instantaneously	Type A. MIL Illumination.
CPU_FAILURE_SEVERITY_TRANSIENT	P0606	The SW shall configure the MCU's fault manager to signal MCU faults which require an external warm-reset on the MCU.	• Defective microprocessor • Improper Application Code	The ASIC monitors the nERROR pin. If an external reset of the MCU is required the MCU asserts the nERROR pin to low for the nERROR debounce time. Then the ASIC then asserts the nRST pin to warm-reset the MCU.	• Power Switch in ON	10msec	Type A. MIL Illumination.
SYS_ASIC_SYNC_TIME_MISMATCH_FAULT	P0606	• At each valid SYNC edge, the ASIC shall store the time between that edge and the prior valid SYNC edge in the Prior SYNC Interval Time SPI register field.	• Defective system ASIC	The MCU shall measure time between SYNC edges (based upon the MCU clock) and verify the time matches the ASIC's Prior SYNC Interval Time SPI field.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_TARGET_CURRENT_DETECT	P0606	• None.	• Defective system ASIC	Periodically (e.g. once per ignition cycle), the MCU shall command the maximum coil current with the solid state relay off and verify that the ASIC sets the "CC_DRx High Target Unreachable" SPI flag. The MCU shall also command the minimum non-zero coil current with the solid state relay on and verify that the ASIC sets the "CC_DRx Low Target Unreachable" SPI flag. This test shall be performed on all CC_DRx channels.	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_DRIVER_SHORT_DETECT	P0606	• The ASIC shall not automatically inhibit the Shorted Driver Detection (SM37) when the SSR is off.	• Defective system ASIC	Periodically (e.g. once per ignition cycle), the MCU shall disable the SSR, enable the CC_DRx and DROx drivers, command 0A or 0% duty cycle, and verify that the Open Coil / Shorted Driver Warning Valid bits are set, and verify that a Shorted Driver Warning is reported on each driver channel.	• Polaris is initialized	15 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SYS_ASIC_SSR_SELF_TEST_FAILED	P0604	• The MCU performs various tests on the Solid State Relay during System Self Test.	• Solid State Relay problem • Defective ASIC • PCB problem	(1a) Se/Command: Watchdog Counter Value SPI field = 0, WDEN pin low, the Enable Failsafe SSR SPI bit = 0, and the SSR Shut Off Pin low (= off). (1b) Verify the Coil Supply Voltage is low. (2a) Set the WDEN pin high, the Enable Failsafe SSR SPI bit = 1, and the SSR Shut Off Pin high (= on). Do not service the Watchdog. (2b) Verify the Coil Supply Voltage is low. (3a) Service Watchdog until the Watchdog Counter Value SPI field = 6. (3b) Verify the Coil Supply Voltage is low. (4a) Set the WDEN pin low, then service the Watchdog once, such that the Watchdog Counter Value SPI field = 7. (4b) Verify the Coil Supply Voltage is low.	• Runs during initialization	30 msec	Type A. MIL Illumination.
				(5a) Set the Enable Failsafe SSR SPI bit = 0, then set the WDEN pin high. (5b) Verify the Coil Supply Voltage is low. (6a) Set the SSR Shut Off Pin low (= off), then set the Enable Failsafe SSR SPI bit = 1. (6b) Verify the Coil Supply Voltage is low. (7a) Allow the Watchdog to timeout, then set the SSR Shut Off Pin high (= on). The time between (4a) and (7a) should be counted toward the required timeout time. If the time between (4a) and (7a) is more than 34ms, a watchdog service event must be added in-between to prevent the Watchdog from timing out before (7a). (7b) Verify the Coil Supply Voltage is low and verify the Watchdog Counter Value SPI field = 0.			

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
				If any of the above tests failed , retry the re enable all the inputs that are being disabled for this test, and re run this test two more times. If it is still failed then set the fault. If any of the above tests failed , retry the re enable all the inputs that are being disabled for this test, and re run this test two more times. If it is still failed then set the fault.			
SYS_ASIC_WDOG_COUNT_TEST_FAILED	P0606	• This fault tests the watchdog by purposefully allowing the watchdog to time out and checking to see how the watchdog reacts	• Watchdog problem • Defective ASIC • PCB problem	Allow the Watchdog to timeout. Timeout shall occur 34ms to 42ms after the last watchdog service occurred, The time taken to timeout the watchdog counter should be counted toward the required timeout time. If the time is not in a range of 34 to 42 msec this fault should set	• Runs during initialization	34 msec	Type A. MIL Illumination.
WDOG_DYNAMIC_TEST_FAILURE	P0606	• Watchdog Dynamic Test Failure • The micro sends a bad watchdog response value back to the ASIC periodically to verify that the ASIC does move towards disabling the system when the watchdog is not correctly being updated. Each loop, the watchdog status counter is checked. After the bad value is sent, the logic tests the status counter to verify that it moved towards disabling the system. If the ASIC operation did not move towards disabling the system, the logic assumes that the watchdog is not able to function properly. As a result, the logic disables the system because the watchdog operation cannot be assumed to be correct. 2 occurrences of this failure is needed to set the fault.	• Defective printed circuit board. • Defective ASIC. • Defective microprocessor.	If the ASIC operation has not moved towards disabling the system, the logic assumes that the watchdog is not able to function properly. As a result, the logic disables the system because the watchdog operation cannot be assumed to be correct. 2 occurrences of this failure is needed to set the fault.	• Power Switch is ON	10 msec	Type A. MIL Illumination.
SYS_ASIC_U1_UV_RESET_FAULT	P0606		• ASIC power supply block problem • Defective ASIC • PCB problem	The MCU shall detect a fault if it does not receive a reset within the expected time. If a reset occurs, the MCU shall check NVM and the ASIC's Reset Source SPI Register, and verify that the reset was due to a planned test.	• Runs during initialization	10 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SYS_ASIC_OSCI_RESET_TEST_FAULT	P0606	• The ASIC shall provide a means to periodically verify that the ASIC is capable of detecting an Oscillator Fault condition and entering the Oscillator Fault Power-down Mode. • From within TRW Test Mode, the ASIC shall provide Main and Supervisor Oscillator Diagnostic bits, which are capable of diving the main oscillator frequency by 2, stopping the main oscillator, dividing the supervisor oscillator frequency by 2, and stopping the supervisor oscillator. • Periodically (e.g. once per ignition cycle) the MCU shall store a flag in NVM indicating that it will perform a oscillator diagnostic. The MCU shall then force one of the four oscillator test modes and start a timer.	• Oscillator problem • Defective ASIC • PCB problem	The MCU shall detect a fault if it does not receive a reset within the expected time. If a reset occurs, the MCU shall check NVM and the ASIC's Reset Source SPI Register, and verify that the reset was due to a planned test.	• Runs during initialization	10 msec	Type A. MIL Illumination.
SYS_ASIC_LOGIC_RST_STUCK_DETECT	P0606	• The MCU continuously monitors the External LOGIC_RST Reset SPI bit within the Reset Source Register.	• Reset source register problem • ASIC problem • PCB problem	The MCU shall read the ASIC's External LOGIC_RST Reset SPI field. If the SPI bit is high, fault is set.	• Continuous failsafing	30 msec	Type A. MIL Illumination.
MULTIPLE_STARTUP_FAILURE	P0606	The library of micro safety tests are run at every power-up. If any test fails the results are stored and the system is soft reset. If after the reset, any different test or procedure fails then a MULTIPLE_STARTUP_FAILURE is latched	• Defective CPU	Any two different Safety Test flags are reported as FAILED in two consecutive tests	Enabled at power up	1 count	Type A. MIL Illumination.
SBST_CORE2_FAILURE	P0606	Fault is set if SafeTlib test "CpuTst_CpuSbstPTst()" fails	Failure of the CPU core	Every 1 second the SafeTlib test "CpuTst_CpuSbstPTst()" is run. The fault is set if it returns a failure.	Continous - Always enabled	1 Count	Type A. MIL Illumination.
UNIMPLEMENTED_INTERRUPT_CORE0	P0606	When the failsafe is called during runtime, it will loop through all the SRC registers to find if there is any pending interrupt from disabled interrupt source	Defective CPU	If SRPN bits in SRC register of Interrupt router is zero then the fault will set if SRR bit of SRC register is set	Continuous Failsafing	300 counts	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
ADC_FAILURE	P060B	Fault sets under the following circumstances: An AD pin is read. Using the Conversion Diagnostics, a pull down is tied to the pin and read again. Then, a pull up is tied to the pin, and read again. Then, the pull devices are removed, and the pin is read a 4th time. The fault will be set if the pull down did not pull the value down by at least 20%, or, the pull up did not pull the value up by at least 20%, or the reread value changed from the initial value by more than 3%. Repeat on another AD pin.	• Defective CPU	If (pulled down value read > initial value read * 0.8) OR If (pulled up value read < initial value read * 1.2) OR If (reread value > initial value read*1.03) OR If (reread value < initial value read *0.97) THEN Set ADC_FAILURE	performed at power up	1 count	Type A. MIL Illumination.
RESET_SSCHECK_FAILURE	P0606	After a warm reset the RSTCON2.CSS bits are checked. If any are 0, then the fault will be set	• Defective CPU	If (warm reset == TRUE) AND (RSTCON2.CSS == 0)	performed at power up	1 count	Type A. MIL Illumination.
SPB_FAILURE	P0606	The correct value of different registers shall be tested to ensure the proper functioning of the SPB address lines. Fault set if any of the registers have an unexpected value after 5 consecutive checks in the 20 ms task .	failed System Peripheral Bus	Each of the required registers will be read during runtime to see if they provide the expected value that was loaded during initialization.	Power Switch is ON	100msec	Type A. MIL Illumination.
SMU_CONFIG_REGISTER_READBACK_FAILURE	P0606	after the SMU has been initialized it will loop through a table of SMU registers and compare each register value to the value that the MCAL has previously written to it. If there is a difference, then the SMU will be unlocked, the register updated, and then the SMU will be put back to it's previous state. The register will then be checked again. If it fails 3 times, then the SMU_CONFIG_REGISTER_READBACK_FAILURE will be set.	• Defective CPU	register value is not equal to test value written to it	performed at power up	1 count	Type A. MIL Illumination.
SBCU_CONFIG_REGISTER_READBACK_FAILURE	P0606	after the SMU has been initialized it will loop through a table of SMU registers and compare each register value to the value that the MCAL has previously written to it. If there is a difference, then the SMU will be unlocked, the register updated, and then the SMU will be put back to it's previous state. The register will then be checked again. If it fails 3 times, then the SMU_CONFIG_REGISTER_READBACK_FAILURE will be set.	• Defective CPU	register value is not equal to test value written to it	performed at power up	1 count	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
WDT_CONFIG_REGISTER_READBACK_FAILURE	P0606	On initialization: One or more of these Safety Watchdog registers has an incorrect value: WDTSCON0.REL WDTSCON1.IR0 WDTSCON1.IR1 WDTSCON1.DR WDTSCON1.UR WDTSCON1.TCTR During runtime: One or more of these CPU0 Watchdog registers has an incorrect value for 4 consecutive checks: WDTCPU0CON0.REL WDTCPU0CON1.IR0 WDTCPU0CON1.IR1 WDTCPU0CON1.DR WDTCPU0CON1.UR WDTCPU0CON1.TCTR	• Defective CPU	any register has an incorrect value for four consecutive checks	Enabled at power up	4 count	Type A. MIL Illumination.
CPU_BUS_MPU_CONFIG_REGISTER_READBACK_FAILURE	P0606	after the MPU has been initialized it will loop through a table of MPU registers and compare each register value to the value that the MCAL has previously written to it. If there is a difference, then the MPU will be unlocked, the register updated, and then the SMU will be put back to it's previous state. The register will then be checked again. If it fails 3 times, then the CPU_MPU_CONFIG_REGISTER_READBACK_FAILURE will be set.	• Defective CPU	register value is not equal to test value written to it	performed at power up	1 count	Type A. MIL Illumination.
LMU_MPU_CONFIG_REGISTER_READBACK_FAILURE	P0606	after the MPU has been initialized it will loop through a table of MPU registers and compare each register value to the value that the MCAL has previously written to it. If there is a difference, then the MPU will be unlocked, the register updated, and then the SMU will be put back to it's previous state. The register will then be checked again. If it fails 3 times, then the CPU_MPU_CONFIG_REGISTER_READBACK_FAILURE will be set.	• Defective CPU	register value is not equal to test value written to it	performed at power up	1 count	Type A. MIL Illumination.
PB_MICRO_REGISTER_READBACK_FAILURE	P0606	The ECU provides the capability to ensure the data integrity of register configuration. The software shall ensure the data integrity of the register configuration and compare the calculated checksum against an expected value.	• Defective CPU	register value is not equal to test value written to it	performed at power up	1 count	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SAFETY_LIB_DETECTED_FAILURE	P0606	The library of micro safety tests are run at every power-up. If any test fails the results are stored and the system is soft reset. If after the reset, the same test or procedure fails then a SAFETY_LIB_DETECTED_FAILURE is latched	• Defective CPU	Any one Safety Test flag is reported as FAILED in two consecutive tests	Enabled at power up	1 count	Type A. MIL Illumination.
STM_PLAUSIBILITY_FAILURE	P0606	STM and TBU timers are read without interrupt between, then after 20 ms, STM and TBU elaspsed times are read without interrupt between the readings, the 2.5% error is checked and Up/down failsafe monitor function is called. The fault is continiously checked every 20 ms.	• Defective CPU	The difference between the System Timer and Time Base Unit channel 1 >= 2.5%	Enabled at power up	105 msec	Type A. MIL Illumination.
EVR_CFGMON_FAILURE	P0606	The Power Management Status Register is checked at power-up. Two configuration bits are checked. Also the EVR Active flag is checked.	• Defective CPU	If any of the checked flags are FALSE then the fault is set immediately	performed at power up	1 count	Type A. MIL Illumination.
RAM_STARTUP_MBIST_FAILURE	P0606	The micro runs a RAM self test at power-up. If a failure is detected the the BIST is rerun after a warm reset. If a failure still exists then the failed bit will be set	• Defective CPU	If the failed bit is TRUE then set the fault	performed at power up	1 count	Type A. MIL Illumination.
Group 7 - IBC Motor							
MD_PU_I_SENSE_COMMON_MODE_FAULT	C0582	If {common mode Isense offset - zero Isense offset} is outside the normal range (+/- SPUT_ISENSE_MAX_CM_ISHIFT), this fault is set.		{common mode Isense offset - zero Isense offset} is outside normal range (29)		1 count/1 ms	Type A. MIL Illumination.
MD_PU_I_SENSE_NEGATIVE_FAULT	C0582	If {zero Isense offset - negative Isense offset } is outside the normal range (SPUT_ISENSE_MIN_NEG_ISHIFT to SPUT_ISENSE_MAX_NEG_ISHIFT), this fault is set		{zero Isense offset - negative Isense offset } is outside normal range (max 86A and min49A)		1 count/1 ms	Type A. MIL Illumination.
MD_PU_I_SENSE_POSITIVE_FAULT	C0582	If {positive Isense offset - zero Isense offset} is outside the normal range (SPUT_ISENSE_MIN_POS_ISHIFT to SPUT_ISENSE_MAX_POS_ISHIFT), this fault is set.		{positive Isense offset - zero Isense offset} is outside the normal range (max 95A and min 44A)		1 count/1 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
MD_IEM_OCCURRENCE_FAULT	C0582	Compares the number of times each electric drive interrupt has occurred in a 4ms period, and sets if the interrupt count does not fall in an acceptable range	Bridge FET failure			1 count/4 ms	Type A. MIL Illumination.
MD_IEM_PLAUSIBILITY_FAULT	C0582	This fault sets if a motor control interrupt is executed with the wronf proirity level, or an interrupt is executed when it should be disabled.	Bridge FET failure			1 count	Type A. MIL Illumination.
MD_MOTOR_PHASE_VOLTAGE_1_HIGH_FAULT	C057F	When phase 1 voltage is high, the microcontroller shall capture {M1_PH1_SEN phase voltage high}, if {M1_PH1_SEN phase voltage high} is less than RT_PHASE_VOLTAGE_HIGH_MIN then this fault is raised. Motor Phase Voltage HIGH Test is executed when the Inverter FET is switched on. IF motor phase <n> voltage < PHASE VOLTAGE THRESHOLD HIGH THEN faulty bucket is incremented	Bridge FET failure	M1_PH1_SEN phase voltage high < 3.46V	executed when the Inverter FET is switched on. Motor PWM is on	18 msec/128 counts	Type A. MIL Illumination.
MD_MOTOR_PHASE_VOLTAGE_1_LOW_FAULT	C0580	When phase 1 voltage is low, the microcontroller shall capture {M1_PH1_SEN phase voltage low}, if {M1_PH1_SEN phase voltage low} is greater than RT_PHASE_VOLTAGE_LOW_MAX then this fault is raised Motor Phase Voltage LOW Test is executed when the lower Inverter FET is switched on. IF motor phase <n> voltage > PHASE VOLTAGE THRESHOLD LOW THEN faulty bucket is incremented	Bridge FET failure	M1_PH1_SEN phase voltage low > 0.99V	executed when the lower Inverter FET is switched on. Motor PWM is on	18 msec/128 counts	Type A. MIL Illumination.
MD_MOTOR_PHASE_VOLTAGE_2_HIGH_FAULT	C057F	When phase 2 voltage is high, the microcontroller shall capture {M1_PH2_SEN phase voltage high}, if {M1_PH2_SEN phase voltage high} is less than RT_PHASE_VOLTAGE_HIGH_MIN then this fault is raised. Motor Phase Voltage HIGH Test is executed when the Inverter FET is switched on. IF motor phase <n> voltage < PHASE VOLTAGE THRESHOLD HIGH THEN faulty bucket is incremented	Bridge FET failure	M1_PH1_SEN phase voltage high < 3.46V	executed when the Inverter FET is switched on.	18 msec/128 counts	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
MD_MOTOR_PHASE_VOLTAGE_2_LOW_FAULT	C0580	When phase 2 voltage is low, the microcontroller shall capture {M1_PH2_SEN phase voltage low}, if {M1_PH2_SEN phase voltage low} is greater than RT_PHASE_VOLTAGE_LOW_MAX then this fault is raised. Motor Phase Voltage LOW Test is executed when the lower Inverter FET is switched on. IF motor phase <n> voltage > PHASE VOLTAGE THRESHOLD LOW THEN faulty bucket is incremented	Bridge FET failure	M1_PH1_SEN phase voltage low > 0.99V	executed when the lower Inverter FET is switched on.	18 msec/128 counts	Type A. MIL Illumination.
MD_MOTOR_PHASE_VOLTAGE_3_HIGH_FAULT	C057F	When phase 3 voltage is high, the microcontroller shall capture {M1_PH3_SEN phase voltage high}, if {M1_PH3_SEN phase voltage high} is less than RT_PHASE_VOLTAGE_HIGH_MIN then this fault is raised. Motor Phase Voltage HIGH Test is executed when the Inverter FET is switched on. IF motor phase <n> voltage < PHASE VOLTAGE THRESHOLD HIGH THEN faulty bucket is incremented	Bridge FET failure	M1_PH1_SEN phase voltage high < 3.46V	executed when the Inverter FET is switched on.	18 msec/128 counts	Type A. MIL Illumination.
MD_MOTOR_PHASE_VOLTAGE_3_LOW_FAULT	C0580	When phase 3 voltage is low, the microcontroller shall capture {M1_PH3_SEN phase voltage low}, if {M1_PH3_SEN phase voltage low} is greater than RT_PHASE_VOLTAGE_LOW_MAX then this fault is raised. Motor Phase Voltage LOW Test is executed when the lower Inverter FET is switched on. IF motor phase <n> voltage > PHASE VOLTAGE THRESHOLD LOW THEN faulty bucket is incremented	Bridge FET failure	M1_PH1_SEN phase voltage low > 0.99V	executed when the lower Inverter FET is switched on.	18 msec/128 counts	Type A. MIL Illumination.
MD_PU_PHASE_1_STUCK_HIGH_FAULT	C057F	Prior to initialising and enabling the bridge driver a power up test shall be performed to check no top or bottom FET is short circuit Drive stage power up tests confirm that with all FETs off, no phases are driven, Phase voltages checked against expectation, if high raise fault				2 counts/2ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
MD_PU_PHASE_1_STUCK_LOW_FAULT	C0580	Prior to initialising and enabling the bridge driver a power up test shall be performed to check no top or bottom FET is short circuit Drive stage power up tests confirm that with all FETs off, no phases are driven, Phase voltages checked against expectation, if low raise fault				2 counts/2ms	Type A. MIL Illumination.
MD_PU_PHASE_2_STUCK_HIGH_FAULT	C057F	Prior to initialising and enabling the bridge driver a power up test shall be performed to check no top or bottom FET is short circuit Drive stage power up tests confirm that with all FETs off, no phases are driven, Phase voltages checked against expectation, if high raise fault				2 counts/2ms	Type A. MIL Illumination.
MD_PU_PHASE_2_STUCK_LOW_FAULT	C0580	Prior to initialising and enabling the bridge driver a power up test shall be performed to check no top or bottom FET is short circuit Drive stage power up tests confirm that with all FETs off, no phases are driven, Phase voltages checked against expectation, if low raise fault				2 counts/2ms	Type A. MIL Illumination.
MD_PU_PHASE_3_STUCK_HIGH_FAULT	C057F	Prior to initialising and enabling the bridge driver a power up test shall be performed to check no top or bottom FET is short circuit Drive stage power up tests confirm that with all FETs off, no phases are driven, Phase voltages checked against expectation, if high raise fault				2 counts/2ms	Type A. MIL Illumination.
MD_PU_PHASE_3_STUCK_LOW_FAULT	C0580	Prior to initialising and enabling the bridge driver a power up test shall be performed to check no top or bottom FET is short circuit Drive stage power up tests confirm that with all FETs off, no phases are driven, Phase voltages checked against expectation, if low raise fault				2 counts/2ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
MD_PU_BRIDGE_BH1_UV_FAULT	C0580	Bridge driver boostrap high side 1 capacitor under voltage fault reported during Bridge driver configuration.				1 count/1ms	Type A. MIL Illumination.
MD_PU_BRIDGE_ERR_STUCK_HI_FAULT	C0582	Verify Error line goes active (low), when error condition is injected.				2 counts/2ms	Type A. MIL Illumination.
MD_PU_BRIDGE_ERR_STUCK_LO_FAULT	C0582	Verify Error line goes inactive (high), when injected error condition is removed.				2 counts/2ms	Type A. MIL Illumination.
MD_PU_BRIDGE_INIT_TIMEOUT_FAULT	C0582	Verify Bridge Driver initialization completed within SPUT_DRV_INIT_MAX_TIME.		If initialization of the bridge driver does not occur within 100ms @ 1ms /bit		1 count/1ms	Type A. MIL Illumination.
MD_PU_BRIDGE_MAX_POWER_DOWN_FAULT	C0582	Allow only BD_PU_MAX_POWER_DOWN_CYCLES of retry, during Bridge Driver power up sequence.		the number of power down cycles during a bridge driver power up sequence exceeds 3		1 count/1ms	Type A. MIL Illumination.
MD_PU_BRIDGE_OC_TIMEOUT_FAULT	C0582	Verify intermediate over current tests are completed within SPUT_DRV_OVER_CURRENT_MAX_TIME.		Immediate overcurrent tests are not completed within 10ms @ 0.1us/bit		2 counts/2ms	Type A. MIL Illumination.
MD_PU_BRIDGE_OCT_NOT_COMPLETED	C0582	Verify over current test is completed within SPUT_DRV_OCT_MAX_EXECUTION_TIME.		overcurrent tests are not completed within 50ms @ 0.1us/bit		2 counts/2ms	Type A. MIL Illumination.
MD_PU_BRIDGE_UNACCEPTABLE_ERR	C0582	Verify no un-acceptable errors are reported by Bridge device during power up.		Errors reported by Bridge driver during power up		3 counts/3ms	Type A. MIL Illumination.
MD_PU_ISENSE_ZERO_OFFSET_FAULT	C0582	Zero I sense outside valid range The microcontroller shall test that while M1_ITP (positive) offset is inactive and M1_ITN (negative) offset is inactive, M1_ISENSE_1 (zero I-sense offset) is within SPUT_ISENSE1_OFFSET_MAX_ERROR		zero Isense offset (M1_ISENSE_1) is outside the normal range		1 count/1ms	Type A. MIL Illumination.
MD_PU_MCU_FET_OP_STUCK_ON_FAULT	C0582	While bridge driver is enabled and prior to driving top or bottom FETs a power up test shall be performed to check no top or bottom FET is stuck on Turn all FETs off (MCU outputs off, bridge should drive FETs off) Monitor phase voltage whether is high/low	Bridge FET failure	Top and Bottom FET stuck on during a Power up test. (Phase voltage is high when FETs are turned OFF)		2 counts/2ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
MD_PU_BRIDGE_CONFIGSTATE_CHG_FAULT	C0594	This failsafe guarantees that the bridge driver is in an acceptable mode (Normal, Safe Off, Config, or Error) during the power-up test sequence. Unknown, Idle, Config Lock, Self Test, Rectification, and Sleep modes will cause this fault to latch.				3 msec	Type A. MIL Illumination.
MD_PU_BRIDGE_OVER_CURRENT_FAULT	C0590	This failsafe tests that over current detection on the bridge driver is working as it should. This failsafe operates during the power-up test.				2 msec	Type A. MIL Illumination.
MD_MOTOR_OPEN_PHASE1_FAULT	C0580	d-axis and q-axis demand is compared with phase 1 measured current, if difference is less than threshold and if actual current is less then threshold, raise a fault				4 counts/4ms	Type A. MIL Illumination.
MD_MOTOR_OPEN_PHASE2_FAULT	C0580	d-axis and q-axis demand is compared with phase 2 measured current, if difference is less than threshold and if actual current is less then threshold, raise a fault				4 counts/4ms	Type A. MIL Illumination.
MD_MOTOR_OPEN_PHASE3_FAULT	C0580	d-axis and q-axis demand is compared with phase 3 measured current, if difference is less than threshold and if actual current is less then threshold, raise a fault				4 counts/4ms	Type A. MIL Illumination.
MD_MOTOR_I_SENSE_DYNAMIC_COMM_MODE_FAULT	C0582	If ({common mode I-sense offset} – {zero I-sense offset}) is outside RT_ISENSE1_MAX_CM_ISHIFT_RANGE then this fault is raised. reference value is taken before applying both voltage offsets (Common), diagnostic_sample point is measured, if diagnostic_sample > reference +/- threshold then raise a fault		({common mode I-sense offset} – {zero I-sense offset}) is outside RT_ISENSE1_MAX_CM_ISHIFT_RANGE		4count/16ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
MD_MOTOR_I_SENSE_DYNAMIC_POSITIVE_FAULT	C0582	If {M1_ISENSE1 positive offset current} is outside expected limits then this fault is raised. reference value is taken before applying positive voltage offset (P), diagnostic_sample point is measured, if reference is not saturated and if diagnostic_sample < reference + threshold then raise a fault		{M1_ISENSE1 positive offset current} is outside expected limits		4count/16ms	Type A. MIL Illumination.
MD_MOTOR_I_SENSE_DYNAMIC_NEGATIVE_FAULT	C0582	If {M1_ISENSE1 negative offset current} is outside expected limits then this fault is raised. reference value is taken before applying negative voltage offset (N), diagnostic_sample point is measured, if reference is not saturated and if diagnostic_sample > reference + threshold then raise a fault		{M1_ISENSE1 negative offset current} is outside expected limits		4count/16ms	Type A. MIL Illumination.
MD_MOTOR_POSITION_SENSOR_FAULT	C058A	Motor electrical absolute position is determined from three Hall-effect sensors. There are two invalid states: all 0 and all 1. Safety mechanism is able to detect Hall-effect signal stuck high or stuck low by detecting invalid states before erroneous electrical angle is more than 60 deg.				1 msec (20 consecutive 50 usec observations)	Type A. MIL Illumination.
MD_MOTOR_POSITION_MISSING_CALIB_FAULT	C0596	The ED subsystem aggregates possible failure cases of the MPS1 SPI signal into a single DTC.		ED subsystem reports failure of MPS1 signal		1 msec (20 consecutive 50 usec observations)	Type A. MIL Illumination.
MD_MOTOR_POSITION_SENSOR_EEPROM_FAULT	C0596	· SPI error bits set during communication with EEPROM on MPS sensor, or incorrect data fingerprint found in EEPROM data read from sensor	· Malfunctioning or unpowered MPS sensor	o QSPI0_STATUS bit 3 or bit 6 are set during communication with EEPROM o EEPROM identification page[0] != 0x20 || EEPROM identification page[1] != 0x00 || EEPROM	N/A	1 count	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
MD_ISENSE_CROSS_CHECK_FAULT	C0582	The microcontroller shall capture M1_ISENSE1 and M1_ISENSE2 current samples, if average difference between M1_ISENSE1 and M1_ISENSE2 over five samples is greater than RT_ISENSE_CROSS_CHECK_LIMIT, then this fault is raised and assist removed reads two independent ADC by 5 samples and averages it to measure current flow and compares, if difference is more than allowed,		[Sum(5 samples of M1_ISENSE1)-Sum(5 samples of M1_ISENSE2)/5] > RT_ISENSE_CROSS_CHECK_LIMIT		20 counts/80ms	Type A. MIL Illumination.
MD_IEM_SEQUENCE_ERROR_FAULT	C0582	Motor Control tasks are deemed to not be executing in the correct order. For every configured interrupt, read out any complete sequences that are in the log. For each sequence read out, the CRC is calculated for the observation points, and is compared against the expected value for that interrupt/mode. Mode is determined from the first observation point in the sequence. A fault is raised when there is a mismatch and the CRC check is stopped for that interrupt.				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_CLOCK_FAIL_FAULT	C0582	During run time Bridge Driver reports internal clock failure (using ERR line and SPI error registers).				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_CONFIG_COMP_FAULT	C0582	To ensure correct configuraiton data is written into Bridge Driver IC. Configuration failure detection is required in order to mitigate: - Micro controller SPI failure. - Bridge Driver failure..		During initialization, if Bridge Driver state changes to CONFIG_LOCK, report config invalid fault.		3 counts/3ms	Type A. MIL Illumination.
MD_BRIDGE_CONFIG_ERROR_FAULT	C0582	During run time Bridge Driver reports config error (using ERR line and SPI error registers).				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_CONFIG_INVALID_FAULT	C0582	During initialisation, if Bridge Driver state changes to CONFIG_LOCK, report config invalid fault.				3 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
MD_BRIDGE_CONFIG_STALLED_FAULT	C0582	Verify configuration check is completed within BRIDGE_DRV_CFG_STALLED_TIMEOUT.				3 counts/3ms	Type A. MIL Illumination.
MD_BRIDGE_CB_UNDER_VOLTAGE_FAULT	C0580	During run time, the Bridge Driver reports charge pump buffer under voltage error on the CB pin of the Bridge driver ASIC (using ERR line and SPI error registers).				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_CF_BRIDGE_CONFIG_FAULT	C0582	During run time Bridge Driver reports error (using ERR line and SPI error registers).				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_CF_BRIDGE_ECC_FAULT	C0582	During run time Bridge Driver reports error (using ERR line and SPI error registers).				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_CF_REG1_OVER_VOLTAGE_FAULT	C057F	During run time Bridge Driver reports error (using ERR line and SPI error registers).				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_REFERENCE_VOLTAGE_FAULT	C0580	Verify Bridge Driver reference voltage is within limits.				18ms/128 counts	Type A. MIL Illumination.
MD_BRIDGE_3V3_UNDER_VOLTAGE_FAULT	C0580	Monitor Bridge Driver reporting under voltage error on its VCC (V3V3) pin.				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_3V3_OVER_VOLTAGE_FAULT	C057F	Bridge Driver is reporting over voltage on its VCC (V3V3) pin.				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_ERR_STUCK_LO_FAULT	C0582	Check M1_BD_ERR line state.				3 msec	Type A. MIL Illumination.
MD_BRIDGE_VS_OVER_VOLTAGE_FAULT	C057F	During run time Bridge Driver reports VS over voltage error (using ERR line and SPI error registers).				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_VS_UNDER_VOLTAGE_A_FAULT	C0580	Bridge driver will detect undervoltage condition. The software shall interrogate the Bridge Driver to determine whether the fault is valid and if valid raises the fault.				18ms/128 counts	Type A. MIL Illumination.
MD_BRIDGE_VS_UNDER_VOLTAGE_B_FAULT	C0580	During run time Bridge Driver reports VS under voltage error (using ERR line and SPI error registers), but battery voltage is greater than BD_VSU_UV_DETECT_THRESHOLD.				1 count/1ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
MD_BRIDGE_VDHP_OVER_VOLTAGE_FAULT	C057F	During run time Bridge Driver reports VDHP over voltage error (using ERR line and SPI error registers).		The voltage on the VS pin of the bridge driver ASIC is above 39.95V		1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_VDHP_UV_A_FAULT	C0580	Data read from Bridge Driver over SPI indicates an undervoltage on the VDHP pin of the Bridge Driver ASIC.		The voltage on the VS pin of the bridge driver ASIC is below 3.96V		18msec/128 counts	Type A. MIL Illumination.
MD_BRIDGE_VDHP_UV_B_FAULT	C0580	During run time Bridge Driver reports VDHP under voltage error (using ERR line and SPI error registers), but battery voltage is greater than BD_VDHU_UV_DETECT_THRESHOLD.		The voltage on the VS pin of the bridge driver ASIC is below 3.96V		1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_STATE_FAULT	C0582	This a temporary Bridge Driver diagnostic to indicate the FM if bridge driver is not enabled when it should be.				20 counts/20ms	Type A. MIL Illumination.
MD_BRIDGE_UNDEFINED_ERROR_FAULT	C0582	During run time SPI error status flag OR Bridge ERR line is active, but no faults are reported in SPI error registers.				1 count/1 ms	Type A. MIL Illumination.
MD_BRIDGE_UNEXPECTED_MODE_FAULT	C0582	Bridge Driver reports unexpected state.				16 counts/ 16ms	Type A. MIL Illumination.
MD_BRIDGE_UNEXPECTED_STATE_FAULT	C0582	Verify Bridge driver state is as expected during initialisation.				3 counts / 3 ms	Type A. MIL Illumination.
MD_BRIDGE_SOFF_STUCK_LO_FAULT	C0582	Check bridge driver status is reported as "normal" mode" when M1_BD_SOFF is inactive.				2 counts /2ms	Type A. MIL Illumination.
MD_BRIDGE_SPI_MSG_FAILED_FAULT	C0582	Bridge Driver reports SPI errors (using SPI error registers) OR received SPI message CRC is invalid.				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_SPI_RESP_TIMEOUT_FAULT	C0582	Verify Bridge Driver low level SPI communication is working.				1 count/1 ms	Type A. MIL Illumination.
MD_BRIDGE_REG_UNDER_VOLTAGE_FAULT	C0580	During run time Bridge Driver reports internal regulator under voltage error (using ERR line and SPI error registers), but battery voltage is greater than BD_IRU_UV_DETECT_THRESHOLD.		Bridge Driver internal regulator voltage < 6.5V @1/256V/bit		1 count/1 ms	Type A. MIL Illumination.
MD_BRIDGE_REG1_OVER_VOLTAGE_FAULT	C057F	During run time Bridge Driver reports Internal regulator over voltage error (using ERR line and SPI error registers).				1 count/1 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
MD_BRIDGE_REG6_OVER_VOLTAGE_FAULT	C057F	During run time Bridge Driver reports Internal regulator over voltage error (using ERR line and SPI error registers).				1 count/1 ms	Type A. MIL Illumination.
MD_BRIDGE_RECONFIGURED_EVENT	C0582	To indicate when Bridge driver reconfiguration was performed.				1 count/1 ms	Type A. MIL Illumination.
MD_BRIDGE_OVER_CURRENT_FAULT	C0590	Bridge Driver reporting amplifier over current errors.				1 count/1 ms	Type A. MIL Illumination.
MD_BRIDGE_OVER_TEMP_ERROR_FAULT	C05C2	During run time Bridge Driver reports over temperature error (using SPI error registers).				1 count/1 ms	Type A. MIL Illumination.
MD_BRIDGE_OSF_FAULT	C0582	During run time Bridge Driver reports output stage feedback failure (using ERR line and SPI error registers).				1 count /1ms	Type A. MIL Illumination.
MD_BRIDGE_ECC_FAIL_FAULT	C0582	During run time Bridge Driver reports ECC failure (using SPI error registers).				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_HS_OVER_VOLTAGE_FAULT	C057F	During run time Bridge Driver reports high side capacitor over voltage error (using ERR line and SPI error registers).		Bridge Driver highside capacitor voltage < 6.5V @1/256V/bit		1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_HS_UNDER_VOLTAGE_FAULT	C0580	During run time Bridge Driver reports high side capacitor under voltage error (using ERR line and SPI error registers), but battery voltage is greater than BD_HBCU_UV_DETECT_THRESHOLD.		Bridge Driver highside capacitor voltage < 6.5V @1/256V/bit		1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_NOT_DISABLED_FAULT	C0582	The microprocessor shall test that when M1_BD_ENA (bridge driver enable) is inactive, motor FETs can not be driven.				2 counts /2ms	Type A. MIL Illumination.
MD_BRIDGE_LATENT_WARNING_EVENT	C0582	The BD has reported a 'latent fault' (over SPI)				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_NOT_ENABLED_FAULT	C0582	The microprocessor shall test that when M1_BD_ENA (bridge driver enable) is active motor FETs can be driven.				2 counts/2ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
MD_BRIDGE_CP_OVER_VOLTAGE_FAULT	C057F	During run time Bridge Driver reports charge pump over voltage error (using ERR line and SPI error registers).				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_CP1_OVERLOAD_FAULT	C0582	During run time Bridge Driver reports CP1 overload error (using ERR line and SPI error registers).				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_CP2_OVERLOAD_FAULT	C0582	During run time Bridge Driver reports CP2 overload error (using ERR line and SPI error registers).				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_DDP_FAULT	C0582	During run time Bridge Driver reports digital driving path failure (using ERR line and SPI error registers).				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_DRV_BIST_CB_UV_FAULT	C0580	Perform Bridge driver charge pump buffer (CB) under voltage self test.				2 count/50ms	Type A. MIL Illumination.
MD_BRIDGE_DRV_BIST_CSA_FAULT	C0582	Perform Bridge driver amplifier gain BIST.				2 counts/50ms	Type A. MIL Illumination.
MD_BRIDGE_DRV_BIST_CSA_VRO_FAULT	C0582	Perform Bridge driver CSA VRO BIST.				2 counts/50ms	Type A. MIL Illumination.
MD_BRIDGE_DRV_BIST_SHORT_CCT_FAULT	C0582	Bridge driver built in high/low side short circuit detection test.				3 counts/75ms	Type A. MIL Illumination.
MD_BRIDGE_DRV_BIST_TIMEOUT_FAULT	C0582	Built-in selftest timeout.				1 count/1ms	Type A. MIL Illumination.
MD_BRIDGE_DRV_BIST_VCC_FAULT	C0582	Perform Bridge Driver's VCC built in self test.				2 counts/50ms	Type A. MIL Illumination.
MD_BRIDGE_DRV_INHIBIT_FAULT	C0582	Verify Bridge Driver will be in SLEEP mode, if Bridge driver is inhibited.				2counts/2ms	Type A. MIL Illumination.
MD_BRIDGE_DRV_WAKE_UP_FAULT	C0582	Remove Bridge inhibit and verify SPI comms is started and Bridge Driver state changes to IDLE.				2counts/2ms	Type A. MIL Illumination.
MD_BRIDGE_SHORT_CIRCUIT_FAULT	C0582	This failsafe checks the SPI communication from the bridge driver to see if it is reporting a short circuit fault. This failsafe operates at run-time				3 msec	Type A. MIL Illumination.
MOTOR_OVER_TEMP_FAIL	C05C2	Motor temperature is greater than threshold.	Motor over temperature.		Power ON, Continuous Failsafing	20 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
MD_PU_BRIDGE_PIR_CLOSE1_LSD_FAULT	C0580	· Driven phase is detected as not low when it should be driven low.	o Bridge driver disabled o Bridge driver in safe off mode o Bridge driver malfunctioning	· Driven phase voltage > 1.2V when < 1.2V expected	N/A	2 msec	Type A. MIL Illumination.
MD_PU_BRIDGE_PIR_CLOSE1_OPEN_CCT_FAULT	C0580	Non-driven phase voltages not pulled low while FETs are driven closed.	o Open motor phase	· phase voltage > 1.2V when < 1.2V expected	· If MD_PU_BRIDGE_PIR_CLOSE1_LSD_FAULT detects, this fault will not detect.	2 msec	Type A. MIL Illumination.
Group 10 - Ground Monitor							
GROUND_1_DISCONNECTED	U3008	The GND_1 and GND_2 connections are independent wire connections to vehicle ground. A loss of either individual circuit detectable. Normally each wire should carry 50% of the total current load. The ground loss detection circuit feedbacks are compared to determine the actual current ratio using the formula in fault equation. Gnd_1_voltage is based on Gnd_1_Fdbk_A Gnd_2_voltage is based on Gnd_2_Fdbk_B If the resulting value is above 0.9 then a missing a missing ground is indicated and GND_1 disconnected fault is set.		Voltageactual= (Gnd1voltage - Gnd2voltage /Gnd1voltage+Gnd2voltage)		200ms	Type A. MIL Illumination.
GROUND_2_DISCONNECTED	U3009	The GND_1 and GND_2 connections are independent wire connections to vehicle ground. A loss of either individual circuit detectable. Normally each wire should carry 50% of the total current load. The ground loss detection circuit feedbacks are compared to determine the actual current ratio using the formula in fault equation. Gnd_1_voltage is based on Gnd_1_Fdbk_A Gnd_2_voltage is based on Gnd_2_Fdbk_B If resulting value is below -0.9,GND_2 disconnected fault is set		Voltageactual= (Gnd1voltage - Gnd2voltage /Gnd1voltage+Gnd2voltage)		200ms	Type A. MIL Illumination.
Group 12 - Pressure Sensor							

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SCP1_CORRELATION_ERROR	C0574	The SCP1,SCP2 and PTS sensor signals are used to compare and identify a single failed sensor signal. This fault is set if the difference exceeds the error threshold value.	SCP1 signal failure	|SCP_1 - SCP_2| > THR		10ms Goal:18000	Type A. MIL Illumination.
SCP2_CORRELATION_ERROR	C0574	The SCP1,SCP2 and PTS sensor signals are used to compare and identify a single failed sensor signal. This fault is set if the difference exceeds the error threshold value.	SCP2 signal failure	|SCP_1 - SCP_2| > THR		10ms Goal:18000	Type A. MIL Illumination.
SCP1_OFFSET_ERROR	C0574	The offset required to zero the Secondary circuit pressure sensor is larger than the specification limit.	SCP1 signal failure	|SCP_1_Off| > THR		30ms Goal:18000	Type A. MIL Illumination.
SCP2_OFFSET_ERROR	C0574	The offset required to zero the Secondary circuit pressure sensor is larger than the specification limit.	SCP2 signal failure	|SCP_2_Off| > THR		30ms Goal:18000	Type A. MIL Illumination.
BP_MODEL_TOO_HIGH_ERROR	C053D	The system models an expected boost pressure based on motor position change. This fault indicates that the boost pressure sensor indicates higher pressure than predicted by the model and than evidenced by the vehicle deceleration.	Common cause Boost Pressure Sensor failure (in-range high)	• Valid braking request (driver or autonomous) • BP_Model (MPS) < Boost pressure - threshold • Vehicle deceleration is not observed		0.5s Goal:18000	Type A. MIL Illumination.
BP_MODEL_TOO_LOW_ERROR	C053D	The system models an expected boost pressure based on motor position change. This fault indicates that the boost pressure sensor indicates lower pressure than predicted by the model and than evidenced by the vehicle deceleration.	Common cause Boost_P failure (in-range-low)	• Valid braking request (driver or autonomous) • BP_Model (MPS) > Boost pressure + threshold • Vehicle deceleration is observed		0.5s Goal:18000	Type A. MIL Illumination.
BP1_CORRELATION_ERROR	C053D	The BP1, BP2, and DAP position signals are used to compare and identify a single failed sensor signal	BP1 signal failure	|Boost_P_1 – Boost_P_2| > THR		10ms	Type A. MIL Illumination.
BP2_CORRELATION_ERROR	C053D	The BP1, BP2, and DAP position signals are used to compare and identify a single failed sensor signal	BP2 signal failure	|Boost_P_1 – Boost_P_2| > THR		10ms	Type A. MIL Illumination.
BP_RAW_OFFSET_ERROR	C053D	The offset required to zero the Boost Pressure sensor is larger than the specification limit of 50 bar.	Boost Pressure Sensor Failure	|BP_RAW_Off| > THR		0.5s Goal:18000	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
BP1_OFFSET_ERROR	C053D	The offset required to zero the Boost Pressure sensor is larger than the specification limit	BP1 signal failure	|BOOST_P_1_Off| > THR		10ms	Type A. MIL Illumination.
BP2_OFFSET_ERROR	C053D	The offset required to zero the Boost Pressure sensor is larger than the specification limit	BP2 signal failure	|BOOST_P_2_Off| > THR		10ms	Type A. MIL Illumination.
MC_PRES_SEN_ERRATIC	C053D	• Pressure Sensor Erratic • This diagnostic checks both raw Boost Pressure principle and reference signals.	• Intermittent failure of the pressure sensor. • Intermittent open or short in the internal circuitry of the printed circuit board.	Ohmic Fault Status = (Sensor open or shorted to sensor supply) AND (Sensor shorted to ground) Ohmic Fault Status ? Previous Ohmic Fault Status	• Sensor voltage supply in range • Boost Pressure Sensor is enabled	min of 80ms	Type A. MIL Illumination.
MC_PRES_SEN_SHORTED_LOW	C053E	• Pressure Sensor Shorted Low • This diagnostic checks both raw Boost Pressure principle and reference signals.	• Defective pressure sensor. • Defective pressure sensor connector. • Defective printed circuit board. • Defective microprocessor feedback input port.	principal sensor voltage < 4.61% of principle sensor supply voltage OR reference sensor voltage < 4.85% of reference sensor supply voltage	• Sensor voltage supply in range • Boost Pressure Sensor is enabled	100 ms	Type A. MIL Illumination.
MC_PRES_SEN_OPEN_OR_SHRT_HIGH	C053F	• Pressure Sensor Open or Shorted High • This diagnostic checks both raw Boost Pressure principle and reference signals.	• Defective pressure sensor. • Defective pressure sensor connector. • Defective printed circuit board. • Defective microprocessor feedback input port.	principal sensor voltage > 95.24% of principle sensor supply voltage OR reference sensor voltage > 94.50% of reference sensor supply voltage	• Sensor voltage supply in range • Boost Pressure Sensor is enabled	100 ms	Type A. MIL Illumination.
SC_PRES_SEN_SHORTED_LOW	C0571	• Pressure Sensor Shorted Low • This diagnostic checks both raw Boost Pressure principle and reference signals.	• Defective pressure sensor. • Defective pressure sensor connector. • Defective printed circuit board. Defective microprocessor feedback input port.	principal sensor voltage < 4.61% of principle sensor supply voltage OR reference sensor voltage < 4.85% of reference sensor supply voltage	• Sensor voltage supply in range • Secondary Circuit Pressure Sensor is enabled	100 ms	Type A. MIL Illumination.
SC_PRES_SEN_OPEN_OR_SHRT_HIGH	C0572	• Pressure Sensor Open or Shorted High • This diagnostic checks both raw Boost Pressure principle and reference signals.	• Defective pressure sensor. • Defective pressure sensor connector. • Defective printed circuit board. Defective microprocessor feedback input port.	principal sensor voltage > 95.24% of principle sensor supply voltage OR reference sensor voltage > 94.50% of reference sensor supply voltage	• Sensor voltage supply in range • Secondary Circuit Pressure Sensor is enabled	100 ms	Type A. MIL Illumination.
SC_PRES_SEN_ERRATIC	C0574	• Pressure Sensor Erratic • This diagnostic checks both raw Boost Pressure principle and reference signals.	• Intermittent failure of the pressure sensor. • Intermittent open or short in the internal circuitry of the printed circuit board.	Ohmic Fault Status = (Sensor open or shorted to sensor supply) AND (Sensor shorted to ground) Ohmic Fault Status ? Previous Ohmic Fault Status	• Sensor voltage supply in range • Secondary Circuit Pressure Sensor is enabled	min of 80ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
PRESSURE_SENSOR_ MISSING_CALIBRATION	C0560	This fault only checks if the EOL calibration is sucessful or not. If the calibration was not yet done or if the calibration is not successful, then this fault is set. The NVRAM contains both calibrated offset and status, but only the status is checked to set the fault.				0.5s Goal:18000 counts	Type A. MIL Illumination.
Group 18 - Pedal Travel Sensor							
PTS_TO_SCP_MODEL_ TOO_HIGH_ERROR	C05CC	The BHS function includes a model of expected Pressure based on driver pedal position. MODEL_TOO_HIGH_ERROR detects the situation where the modeled pressure is much higher than the measured pressure.	• Master cylinder seal leakage to reservoir • Pedal Simulator seal leakage to reservoir • In-range failure of SCP sensor	BHS modeled pressure > SCP Measured Pressure + Cal_Threshold		150ms	Type A. MIL Illumination.
PTS_TO_SCP_MODEL_ TOO_LOW_ERROR	C05CC	The BHS function includes a model of expected Pressure based on driver pedal position. MODEL_TOO_LOW_ERROR detects the situation where the modeled pressure is much lower than the measured pressure.	• Pedal Simulator Valve is closed or blocked • Pedal Simulator seized/fails to store fluid • In-range failure of SCP sensor	BHS modeled pressure < SCP Measured Pressure – Cal_Threshold		~100ms	Type A. MIL Illumination.
PTS1_OUT_OF_RANGE _ERROR	C05CC	During normal operation the input piston travel is physically limited to ~25 mm, and during NO_BOOST operation it is limited to ~36 mm. The sensor is capable of measuring travel up to 43 mm. Reported travel by a single sensor in excess of these limits is indicative of a sensor error.	• Failure of PTS1 • Failure of travel sensor cursor rod	• PTS1 signal > max_travel_threshold(mode) AND • PTS2 signal and SCP signal agree that actual travel is in range		100ms	Type A. MIL Illumination.
PTS2_OUT_OF_RANGE _ERROR	C05CF	During normal operation the input piston travel is physically limited to ~25 mm, and during NO_BOOST operation it is limited to ~36 mm. The sensor is capable of measuring travel up to 43 mm. Reported travel by a single sensor in excess of these limits is indicative of a sensor error.	• Failure of PTS2 • Failure of travel sensor cursor rod	• PTS2 signal > max_travel_threshold(mode) AND • PTS1 signal and SCP signal agree that actual travel is in range		100ms	Type A. MIL Illumination.
PTS1_STEP_ERROR	C05CC	The PTS1 sensor signal changes at a physically implausible rate, resulting in a signal that disagrees with PTS2 signal, and a modeled pressure that disagrees with the SCP (i.e. PTS2 model and SCP signals agree on driver braking level, PTS1 model and SCP disagree)	• Failure of PTS1 signal line	• PTS1 signal gradient > Cal_Threshold • |PTS1 – PTS2| > Error_threshold • Model(PTS1) <> SCP and Model(PTS2) == SCP		100ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
PTS2_STEP_ERROR	C05CF	The PTS2 sensor signal changes at a physically implausible rate, resulting in a signal that disagrees with PTS1 signal, and a modeled pressure that disagrees with the SCP (i.e. PTS1 model and SCP signals agree on driver braking level, PTS2 model and SCP disagree)	• Failure of PTS2 signal line	• PTS2 signal gradient > Cal_Threshold • |PTS1 – PTS2| > Error_threshold • Model(PTS2) <> SCP and Model(PTS1) == SCP		100ms	Type A. MIL Illumination.
PTS1_SENT_RECEIVE_ERROR	C05CC	The PTS2 SENT message is comprised of a 12 bit data value (pedal travel), a 12 bit data value (motor position), a 4 bit CRC, and a 4 bit status field.			Any of the following conditions: • SENT message Checksum error • SENT status field indicates receive failure • Received pedal travel is out-of-range low (0) • Received pedal travel is out-of-range high (4095)	5ms	Type A. MIL Illumination.
PTS2_SENT_RECEIVE_ERROR	C05CF	The PTS1 SENT message is comprised of a 12 bit data value, its 12 bit complement, a 4 bit CRC, and a 4 bit status field			Any of the following conditions: • SENT message Checksum error • SENT status field indicates receive failure • Data value and its complement do not combine to 0xFFF • Received position is out-of-range low (0) • Received position is out-of-range high (4095)	5ms	Type A. MIL Illumination.
PTS1_SENT_MESSAGE_MISSING	C05CC	the SW indicates the failure to the driver interface and set the status of the received Pedal and Motor position value to invalid within FTTD_PEDAL_MOTOR POSITION_VALUE.	Signal line is open or shorted to GND. Shorted to supply Wiring	N/A	N/A	5 msec	Type A. MIL Illumination.
PTS2_MPS2_SENT_MESSAGE_MISSING	C05CF	the SW indicates the failure to the driver interface and set the status of the received Pedal and Motor position value to invalid within FTTD_PEDAL_MOTOR POSITION_VALUE.	Signal line is open or shorted to GND. Shorted to supply Wiring	N/A	N/A	5 msec	Type A. MIL Illumination.
PTS1_CORRELATION_ERROR	C05D0	The PTS1, PTS2, and BAS sensor signals are used in a 2-out-of-3 correlation scheme to identify a single failed sensor signal	PTS1 Signal Failure	• |PTS1 – PTS2| > Thr AND • |PTS1 – BAS| > Thr AND • |PTS2 – BAS| < Thr		~100 msec	Type A. MIL Illumination.
PTS2_CORRELATION_ERROR	C05D0	The PTS1, PTS2, and BAS sensor signals are used in a 2-out-of-3 correlation scheme to identify a single failed sensor signal	PTS2 Signal Failure	• |PTS1 – PTS2| > Thr AND • |PTS2 – BAS| > Thr AND • |PTS1 – BAS| < Thr		~100ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
PTS_MISSING_CALIBRATION_ERROR	C05D4	The PTS calibrations are stored in NVRAM and reused at the start of each drive cycle. This fault sets if the stored status indicates one of the failure cases for calibration: • PTS sensor electrical fault • Vehicle moving during calibration • Brake applied during calibration • Offset too big • Offset too small • Offset not steady			• PTS EOL zeroing was not completed successfully	• 15 seconds (EOL zeroing), or immediately on powerup	Type A. MIL Illumination.
PTS1_OFFSET_ERROR	C05CC	The offset required to zero the PTS sensor is larger than the specification limit.	Failure of PTS1 Sensor	|PTS1 Offset| > threshold		~100ms	Type A. MIL Illumination.
PTS2_OFFSET_ERROR	C05CF	The offset required to zero the PTS sensor is larger than the specification limit.	Failure of PTS2 Sensor	|PTS2 Offset| > threshold		~100ms	Type A. MIL Illumination.
Group 19 - Motor Position							
MPS_TO_BP_MODEL_TOO_HIGH_ERROR	C2A17	The system models expected boost pressure based on motor position change. This fault indicates that the boost pressure sensor indicates higher pressure than predicted by the model.	• DAP check valve failure/leakage • ABS Dump valve failure/leakage • DAP main seal leakage	BP_Model (MPS) > Boost pressure + threshold	• Valid braking request (driver or autonomous) • BP_Model (MPS) > Boost pressure + threshold • Vehicle deceleration change not observed	~100ms	Type A. MIL Illumination.
MPS2_CORRELATION_ERROR	C058E	MPS1 is SPI based with a 50 usec update rate. MPS2 is SENT based with a 1 msec update rate. During motor rotation there is an expected difference in MPS1 and MPS2 based on the different time sampling rates (time lag on MPS2).	• MPS2 Failure • Note: MPS1 failure results in BOOSTED_BRAKE_SYSTEM_FAILURE for lack of motor rotation / pressure build	|MPS1 – MPS2| > threshold + Offset_factor(motor speed)		~1000ms	Type A. MIL Illumination.
MPS1_STEP_ERROR	C058A	DAP position move more than a specified amount of distance within one loop.	MPS1 Signal Failure	DAP - DAP_prev > Threshold	start 100 ms after DAP finished calibration	10ms	Type A. MIL Illumination.
MPS2_SENT_RECEIVE_ERROR	C058E	Monitor MPS2 sent data received from the SentSensor.	MPS2 Signal Failure	This failsafe detects when MPS2 sent data received from the SentSensor is out of the valid range.	MPS signal data is received.	5 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
MPS_BIST_FAULT	C058A	Testing of this module should include running BIST at various MPS angles. The ECU performs an independent calculation parallel to internal MPU sensor BIST software. The fault will occur when the parallel calculations don't match.	MPS Built-in-Self-Test failure	The value calculated within the MPS does not equal the ECU calculated value.	BIST Inputs are not faulty.	3 counts	Type A. MIL Illumination.
MPS1_NOT_ALIVE_FAILURE	C058A	Any Condition	MPS1 Signal Failure	MPS == MPS_prev	MPS1 does not change for 5 consecutive readings.	100ms	Type A. MIL Illumination.
Group 22 - Power Supply Failures							
SYS_ASIC_VDBAT_RANGE_FAILURE	U3006	• KL30_1 Supply voltage outside of the specified range • If the ASIC A/D value for VDBat is outside the acceptable range (VDBat < 6V or VDBat >18V) continuously for 100ms then the fault is set.	• VDBAT Voltage is outside the voltage range	6V < KL30_1 Supply Voltage > 18V	• ASIC's VDBAT Voltage Result SPI field is outside the range of 6 and 18 volts for 100msec	100ms	Type A. MIL Illumination.
SYS_ASIC_PDBAT_RANGE_FAILURE	U3007	• KL30_2 Supply voltage outside of the specified range • If the ASIC A/D value for PDBat is outside the acceptable range (PDBat < 6V or PDBat >18V) continuously for 100ms then the fault is set.	• PDBAT Voltage is outside the voltage range	6V < KL30_2 Supply Voltage > 18V	• ASIC's PDBAT Voltage Result SPI field is outside the range of 6 and 18 volts for 100msec	100ms	Type A. MIL Illumination.
KL30_1_OPEN_OR_SHRTED_TO_GND	U3006	A feedback ratio is calculated based on the KL30_1_Fdbk_A and KL30_2_Fdbk_B. • If this feedback ratio exceeds the valid upper threshold ratio, then KL30_2_Open_or_Shrted_to_Gnd fault is set. • If the feedback ratio is lower than the valid lower threshold ratio, then KL30_1_Open_or_Shrted_to_Gnd fault is set		• If PSSW1 AND PSSW2 is turned ON, • Valid upper and lower threshold ratio is +10% and -10% of Supply Voltage, • If only PSSW1 OR PSSW2 is turned ON, • Valid upper and lower threshold ratio is +30% and -30% of Supply Voltage. 0V < KL30_2 Supply Voltage < 20.45V		75ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
KL30_2_OPEN_OR_SHRTED_TO_GND	U3007	A feedback ratio is calculated based on the KL30_1_Fdbk_A and KL30_2_Fdbk_B. • If this feedback ratio exceeds the valid upper threshold ratio, then KL30_2_Open_or_Shrted_to_Gnd fault is set. • If the feedback ratio is lower than the valid lower threshold ratio, then KL30_1_Open_or_Shrted_to_Gnd fault is set		• If PSSW1 AND PSSW2 is turned ON, • Valid upper and lower threshold ratio is +10% and -10% of Supply Voltage, • If only PSSW1 OR PSSW2 is turned ON, • Valid upper and lower threshold ratio is +30% and -30% of Supply Voltage. 0V < KL30_2 Supply Voltage < 20.45V		75ms	Type A. MIL Illumination.
SYSTEM_VOLTAGE_LOW	P0562	System voltage is monitored continuously but the fault is not enabled during Engine crank. When the system voltage is continuously lower than 8.5V for more than 150 msec then the fault is set. When the system voltage is continuously greater than 9.0V for more than 100 msec then the fault is cleared.	• Voltage Supply is providing low voltage levels. • Defective cables. • Defective printed circuit board.	Filtered system voltage < 8.5V	• Engine is not being cranked • System is not re-initializing or shutting down • System is not shutting down	150 ms	Type A. MIL Illumination.
SYSTEM_VOLTAGE_EXCESSIVE_LOW	P0562	System voltage is monitored continuously but the fault is not enabled during Engine crank. When the system voltage is continuously lower than 7.5V for more than 150 msec then the fault is set.	• Voltage Supply is providing excessively low voltage level. • Defective cable. • Defected printed circuit board.	Filtered system voltage < 7.5V	• Engine is not being cranked • System is not re-initializing or shutting down • System is not shutting down	150 ms	Type A. MIL Illumination.
SYSTEM_VOLTAGE_HIGH	P0563	System voltage is monitored continuously but the fault is not enabled during Engine crank. When the system voltage is continuously greater than 16.8V for more than 100 msec then the fault is set. When the system voltage is continuously less than 16.3V for more than 100 msec then the fault is cleared.	• Voltage Supply is providing high voltage levels. • Defective printed circuit board.	Filtered system voltage > 16.8 V	• Engine is not being cranked • System is not re-initializing or shutting down • System is not shutting down	100 ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SYSTEM_VOLTAGE_EXCESSIVE_HIGH	P0563	System voltage is monitored continuously but the fault is not enabled during Engine crank. When the system voltage is continuously greater than 18.8V for more than 15 msec then the fault is set. When the system voltage is continuously less than 18.3V for more than 100 msec then the fault is cleared.	• Voltage Supply is providing excessively high voltage levels. • Defective printed circuit board.	Filtered system voltage > 18.8V	• Engine is not being cranked • System is not re-initializing or shutting down • System is not shutting down	15 ms	Type A. MIL Illumination.
SYSTEM_VOLTAGE_ECU_SELF_TEST_HOLD	P0562	System Self Test will not start if either of the following conditions are present: System is not initialized System Voltage is outside the Excessive range (< 7.5V or >18.8V) If the System Self Test is delayed continuously for more than 100 msec then the fault is set.	• Voltage Supply is providing excessively high voltage levels. • Defective printed circuit board.	Filtered system voltage < 7.5V or Filtered system voltage > 18.8V	• System is not initialized • System Voltage is outside the Excessive range (<7.5 V or >18.8V)	100 ms	Type A. MIL Illumination.
SYSTEM_VOLTAGE_ERRATIC	P0562	If the filtered System Voltage toggles outside the Excessive Low or Excessive High range but does not stay there long enough to mature the fault then this fault is matured by an up/down counter on the condition	• Voltage Supply is toggling between low voltage levels to High voltage levels. • Defective cables. • Defective printed circuit board.	If the Filtered sysem voltage toggles as per the below range Filtered system voltage ? 8.5V Filtered system voltage ? 16.8 V	• Engine is not being cranked • System is not re-initializing or shutting down • System is not shutting down	300ms minimum	Type A. MIL Illumination.
INTERNAL_5V_SUPPLY_VOLT_ERRATIC	P0606	If the filtered 5V supply toggles outside the allowed range but does not stay there long enough to mature the INTERNAL_5V_SUPPLY_VOLT_FAILURE then this fault is matured by an up/down counter on the condition	• Defective internal 5 V supply circuit • Defective printed circuit board • Defective microprocessor feedback input port • Defective Polaris ASIC feedback input port	If the filtered System Voltage toggles as per the below range Filtered system voltage ? 4.75V Filtered system voltage ? 5.25 V	• Internal 5V supply is enabled • AND • None of the following are taking place: • System is initializing • System is re-initializing • Engine is being cranked • When requested by Diagnostic commands System is shutting down	800 counts/80ms minimum	Type A. MIL Illumination.
ECU_SELF_TEST_TIMEOUT	P0606	If the ECU self test does not complete in the alloted amount of time, then set this fault. This fault allows to properly inform the driver that the EBCM functionality is not available.	Faulted ECU	None	Runs duting startup	5 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
PWR_PTS_MPS_SUP1_RANGE_LOW	C05D1	The MCU provides two 5V sensor supplies for the Pedal Travel and Motor Position Sensors (each supply powers one circuit of the PTS and one circuit of the MPS). The MCU monitors the feedbacks on these two voltage supplies. If either supply is continuously < 4.85V for 100ms then the respective supply fault is set.		if PWR<4.85 for 100ms		100ms	Type A. MIL Illumination.
PWR_PTS_MPS_SUP1_RANGE_HIGH	C05D1	The MCU provides two 5V sensor supplies for the Pedal Travel and Motor Position Sensors (each supply powers one circuit of the PTS and one circuit of the MPS). The MCU monitors the feedbacks on these two voltage supplies. If either supply is continuously > 5.15V for 100ms then the respective supply fault is set.		if PWR>5.15V for 100ms		100ms	Type A. MIL Illumination.
PWR_PTS_MPS_SUP1_ERRATIC	C05D1	The MCU provides two 5V sensor supplies for the Pedal Travel and Motor Position Sensors (each supply powers one circuit of the PTS and one circuit of the MPS). The MCU monitors the feedbacks on these two voltage supplies. If a supply feedback is outside the acceptable range (< 4.85V or > 5.15V) then the respective erratic fault is matured at a weight of 50 toward a goal of 800 (fastest maturation = 80 msec). If the feedback voltage returns within the 4.85 - 5.15V range then the erratic fault is dematured at a weight of 1. Once the fault goal is reached then the fault is set and is ignition latched.		if PWR<4.85 or >5.15V		80ms minimum	Type A. MIL Illumination.
PWR_PTS_MPS_SUP2_RANGE_LOW	C05BB	The MCU provides two 5V sensor supplies for the Pedal Travel and Motor Position Sensors (each supply powers one circuit of the PTS and one circuit of the MPS). The MCU monitors the feedbacks on these two voltage supplies. If either supply is continuously < 4.85V for 100ms then the respective supply fault is set.		if PWR<4.85 for 100ms		100ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
PWR_PTS_MPS_SUP2_RANGE_HIGH	C05BB	The MCU provides two 5V sensor supplies for the Pedal Travel and Motor Position Sensors (each supply powers one circuit of the PTS and one circuit of the MPS). The MCU monitors the feedbacks on these two voltage supplies. If either supply is continuously > 5.15V for 100ms then the respective supply fault is set.		if PWR>5.15V for 100ms		100ms	Type A. MIL Illumination.
PWR_PTS_MPS_SUP2_ERRATIC	C05BB	The MCU provides two 5V sensor supplies for the Pedal Travel and Motor Position Sensors (each supply powers one circuit of the PTS and one circuit of the MPS). The MCU monitors the feedbacks on these two voltage supplies. If a supply feedback is outside the acceptable range (< 4.85V or > 5.15V) then the respective erratic fault is matured at a weight of 50 toward a goal of 800 (fastest maturation = 80 msec). If the feedback voltage returns within the 4.85 - 5.15V range then the erratic fault is dematured at a weight of 1. Once the fault goal is reached then the fault is set and is ignition latched.		if PWR<4.85 or >5.15V		80ms minimum	Type A. MIL Illumination.
PWR_SW_COIL_SUP_OPEN	C053B	The KL30 supply inputs are switched on/off by the two Power Switches. The downstream KL30_INT supplies the ABS Coils, the BB Coils and the Motor Driver. These three circuits are individually switched on/off by separate Safety Relays. When the Safety Relay is on the downstream voltage feedback is expected to be high. The MCU monitors the voltage feedback downstream from the ABS Coil Safety Relay. If the feedback voltage is less than 80% of KL30_INT for a continuous 50 msec then the fault is set.		If Feedback Voltage < 80%of KL30_x		50ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
PWR_SW_COIL_SUP_SHORT	C053B	The KL30 supply inputs are switched on/off by the two Power Switches. The downstream KL30_INT supplies the ABS Coils, the BB Coils and the Motor Driver. These three circuits are individually switched on/off by separate Safety Relays. When the Safety Relay is off the downstream voltage feedback is expected to be low. The MCU monitors the voltage feedback downstream from the ABS Coil Safety Relay. If the feedback voltage is not less than 80% of KL30_INT for a continuous 50 msec then the fault is set.		If Feedback Voltage > 80%of KL30_x		50ms	Type A. MIL Illumination.
PWR_SW_BB_COIL_SUP_OPEN	C053B	The KL30 supply inputs are switched on/off by the two Power Switches. The downstream KL30_INT supplies the ABS Coils, the BB Coils and the Motor Driver. These three circuits are individually switched on/off by separate Safety Relays. When the Safety Relay is on the downstream voltage feedback is expected to be high. The MCU monitors the voltage feedback downstream from the BB Coil Safety Relay. If the feedback voltage is less than 80% of KL30_INT for a continuous 50 msec then the fault is set.		If Feedback Voltage < 80%of KL30_x		50ms	Type A. MIL Illumination.
PWR_SW_BB_COIL_SUP_SHORT	C053B	The KL30 supply inputs are switched on/off by the two Power Switches. The downstream KL30_INT supplies the ABS Coils, the BB Coils and the Motor Driver. These three circuits are individually switched on/off by separate Safety Relays. When the Safety Relay is off the downstream voltage feedback is expected to be low. The MCU monitors the voltage feedback downstream from the BB Coil Safety Relay. If the feedback voltage is not less than 80% of KL30_INT for a continuous 50 msec then the fault is set.		If Feedback Voltage > 80%of KL30_x		50ms	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
PWR_SW_MOT_SUP_OPEN	C0595	The KL30 supply inputs are switched on/off by the two Power Switches. The downstream KL30_INT supplies the ABS Coils, the BB Coils and the Motor Driver. These three circuits are individually switched on/off by separate Safety Relays. When the Safety Relay is on the downstream voltage feedback is expected to be high. The MCU monitors the voltage feedback downstream from the Motor Safety Relay. If the feedback voltage is less than 80% of KL30_INT for a continuous 50 msec then the fault is set.		If Feedback Voltage < 80%of KL30_x		50ms	Type A. MIL Illumination.
PWR_SW_MOT_SUP_SHORT	C0595	The KL30 supply inputs are switched on/off by the two Power Switches. The downstream KL30_INT supplies the ABS Coils, the BB Coils and the Motor Driver. These three circuits are individually switched on/off by separate Safety Relays. When the Safety Relay is off the downstream voltage feedback is expected to be low. The MCU monitors the voltage feedback downstream from the Motor Safety Relay. If the feedback voltage is not less than 80% of KL30_INT for a continuous 50 msec then the fault is set.		If Feedback Voltage > 80%of KL30_x		50ms	Type A. MIL Illumination.
PWR_SW_PSSW1_SUP_OPEN	U3006	This fault is not enabled is a Watchdog fault is already set. The KL30_1 and KL30_2 voltage supply inputs are individually switched on/off by separate Power Switch circuits. When either Switch is turned on then it‘s respective Power Switch Feedback is expected to be high. If the feedback voltage is less than 80% of it‘s respective KL30_x supply voltage for a continuous 50 msec then the fault is set		If Feedback Voltage < 80%of KL30_x		50 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
PWR_SW_PSSW1_SUP_SHORT	U3006	The KL30_1 and KL30_2 voltage supply inputs are individually switched on/off by separate Power Switch circuits. When both Switches are turned off then both Power Switch Feedbacks are expected to be low. If the feedback voltage is not less than 80% of it's respective KL30_x supply voltage for a continuous 50 msec then the fault is set.		If Feedback Voltage > 80%of KL30_x		50ms	Type A. MIL Illumination.
PWR_SW_PSSW2_SUP_OPEN	U3007	This fault is not enabled is a Watchdog fault is already set. The KL30_1 and KL30_2 voltage supply inputs are individually switched on/off by separate Power Switch circuits. When either Switch is turned on then it's respective Power Switch Feedback is expected to be high. If the feedback voltage is less than 80% of it's respective KL30_x supply voltage for a continuous 50 msec then the fault is set.		If Feedback Voltage < 80%of KL30_x		50ms	Type A. MIL Illumination.
PWR_SW_PSSW2_SUP_SHORT	U3007	The KL30_1 and KL30_2 voltage supply inputs are individually switched on/off by separate Power Switch circuits. When both Switches are turned off then both Power Switch Feedbacks are expected to be low. If the feedback voltage is not less than 80% of it's respective KL30_x supply voltage for a continuous 50 msec then the fault is set.		If Feedback Voltage > 80%of KL30_x		50ms	Type A. MIL Illumination.
SYS_ASIC_VCP12_U12_VOLTAGE_LOW	P0606	The Polaris ASIC provides an internal VCP12 voltage regulator which is required to operate the I_SSR amplifier and to maintain regulation of the VA5p0 regulators and the U3 and U1 linear regulators. If the VCP12 voltage is less that 7.25 V for 44 ?sec then the Polaris sets the VPC12 Low Voltage Warning SPI bit to True. Software monitors this SPI bit. If it is continuously True for more than 100 msec then the fault is set.	Defective vehicle battery or Charging system Otherwise: -Defective system ASIC -Defective printed circuit board. • Defective system ASIC	VCP12 voltage is less that 7.25 V for 44 ?sec	• Polaris is initialized	100 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SYS_ASIC_CHARGE_PUMP_OVER_VOLT	P0606	The Polaris ASIC provides a two-stage charge pump to produce a voltage greater than the VCP12 voltage. If the charge pump voltage exceeds VCP12 voltage by more than 13V for 53 msec then the Polaris sets the Charge Pump Overvoltage Limit SPI bit to True. Software monitors this SPI bit. If it is continuously True for more than 100 msec then the fault is set.	• Defective system ASIC	charge pump voltage exceeds VCP12 voltage by more than 13V for 53 msec	• Polaris is initialized	100 msec (145.2 ms)	Type A. MIL Illumination.
SYS_ASIC_VDG_RANGE_FAULT	P0606	Verify that the KL30_1 Power Switch command is not stuck On. The ASIC VDG pin controls the KL30_1 Power Switch. While the Power Switch is commanded off, the SW reads the ASIC's VDG voltage feedback. When the VDG voltage is continuously >= 1.0V for more than 100 msec then the fault is set.	• Defective system ASIC	SSR ON: VDBat+3V <= VDG <= VDBat+12V SSR OFF: VDG <= 1.0V	• Polaris is initialized	100 msec	Type A. MIL Illumination.
SYS_ASIC_VBAT_SW_OVERCURRENT	P0606	The Polaris ASIC provides an overcurrent protected VBAT_SW output used for powering sensors and external circuits. If the VBAT_SW current draw exceeds 150 mA for 800 ?sec then the Polaris sets the VBAT_SW Overcurrent SPI bit to True. Software monitors this SPI bit. If it is continuously True for more than 25 msec then the fault is set.	• Defective system ASIC	VBAT_SW Enable and VBAT_SW Over-Current SPI bits are both TRUE	• Polaris is initialized	25 msec	Type A. MIL Illumination.
SYS_ASIC_VBAT_SW_CORR	P0606	The MCU shall read the ASIC's VBAT_SW Voltage Result SPI field and perform a plausibility check against the measured VBAT voltage pin on the MCU. When the difference between the two voltage values is continuously > 1.75V for more than 25 msec then the fault is set.	• Defective system ASIC	voltage difference > 1.75 volts	• Polaris is initialized	15 msec	Type A. MIL Illumination.
SYS_ASIC_VBAT_SW_DISABLE_CORR	P0606	Check that the ASIC VBAT_SW output is not leaking or stuck On. The MCU shall read the ASIC's VBAT_SW Voltage Result SPI field when the commanded VBAT_SW state is Off. If the voltage is continuously > 1.5V for more than 25 msec then the fault is set.	• Defective wiring harness • Defective ASCI • Defective CPU • Defective circuit board	voltage difference > 1.5 volts	-Polaris is initialized -Power Switch is OFF	25 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SYS_ASIC_U5_FAILURE	P0606	The U5 power supply regulates battery voltage down to 5V to supply such circuits as network communication transceivers, internal sensors and ADC references. If U5 is outside the acceptable range (<4.75V or >5.1V) continuously for 105 ?sec then the ASIC shall continue to attempt to regulate U5 and set the U5 Out of Range Warning SPI bit to True. Software monitors this SPI bit. If it becomes True then the fault is set immediately.	• Defective system ASIC	The MCU shall monitor the ASIC's U5 Out of Range Warning SPI bit. (<4.75V or >5.1V)	• Polaris is initialized	5 msec	Type A. MIL Illumination.
SYS_ASIC_CHARGE_PUMP_UNDER_VOLT	P0606	The Polaris ASIC provides a two-stage charge pump to produce a voltage greater than the VCP12 voltage. If the charge pump voltage exceeds VCP12 voltage by less than 9.5V for 5.5 msec then the Polaris sets the Charge Pump Undervoltage Limit SPI bit to True. Software monitors this SPI bit. If it is continuously True for more than 100 msec then the fault is set.	• Defective system ASIC	If the charge pump voltage exceeds VCP12 voltage by less than 9.5V for 5.5 msec	• Polaris is initialized	100 msec (105.5 ms)	Type A. MIL Illumination.
U5_ASIC_ADC_REF_FAULT	P0606	The 5V regulated supply is read at the ASIC. If it is not within the range, then the fault is set.	• Defective system ASIC or circuit board	Asic U5 is not within the 4.75V and 5.25V	Polaris is initialized	80 msec	Type A. MIL Illumination.
SYS_ASIC_U3_UV_RESET_FAULT	P0606	• When the U5, U3, or U1 Undervoltage Diagnostic SPI bit is set, the ASIC shall raise the effective U5 out of range lower warning level, or the U3 or U1 undervoltage fault threshold above the maximum U5, U3, or U1 regulation voltage, thus forcing a U5 out of range warning or U3 or U1 undervoltage fault. • Periodically, the MCU shall store a flag in NVM indicating that it will perform a U5, U3 or U1 undervoltage diagnostic. The MCU shall then force one of the three test modes and start a timer.	• ASIC power supply block problem • Defective ASIC • PCB problem	The MCU shall detect a fault if it does not receive a reset within the expected time. If a reset occurs, the MCU shall check NVM and the ASIC's Reset Source SPI Register, and verify that the reset was due to a planned test.	• Runs during initialization	10 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
SYS_ASIC_U3_OV_RESET_FAULT	P0606	• When the U5, U3, U1 Overvoltage Diagnostic SPI bit is set, the ASIC shall lower the effective overvoltage fault threshold below the minimum U5, U3, or U1 regulation voltage, thus forcing a U5, U3, or U1 overvoltage fault. • Periodically (e.g. once per ignition cycle at shutdown), the MCU shall store a flag in NVM indicating that it will perform a U5, U3 or U1 overvoltage diagnostic. The MCU shall then force one of the three test modes and start a timer.	• ASIC power supply block problem • Defective ASIC • PCB problem	The MCU shall detect a fault if it does not receive a reset within the expected time. If a reset occurs, the MCU shall check NVM and the ASIC's Reset Source SPI Register, and verify that the reset was due to a planned test.	• Runs during initialization	10 msec	Type A. MIL Illumination.
SYS_ASIC_U5_OV_RESET_FAULT	P0606	• When the U5, U3, U1 Overvoltage Diagnostic SPI bit is set, the ASIC shall lower the effective overvoltage fault threshold below the minimum U5, U3, or U1 regulation voltage, thus forcing a U5, U3, or U1 overvoltage fault. • Periodically (e.g. once per ignition cycle at shutdown), the MCU shall store a flag in NVM indicating that it will perform a U5, U3 or U1 overvoltage diagnostic. The MCU shall then force one of the three test modes and start a timer.	• ASIC power supply block problem • Defective ASIC • PCB problem	The MCU shall detect a fault if it does not receive a reset within the expected time. If a reset occurs, the MCU shall check NVM and the ASIC's Reset Source SPI Register, and verify that the reset was due to a planned test.	• Runs during initialization	10 msec	Type A. MIL Illumination.
Group 20 - BOOST SYSTEM							

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
BOOSTED_BRAKE_SYSTEM_FAILED	C0021	The Measured Boost Pressure is compared against an “error” threshold and sets a fault when the difference is large enough to cause possible under braking of the vehicle. The difference or “error” threshold itself is a function of the Boost Pressure Target such that larger errors are accepted as the requested pressure increases (i.e. a request of 30 bar that results in a 10 bar pressure is considered more consequential than a 20 bar error at a pressure request of 180 bar). This error threshold gets desensitized when slip control is active to account for the more dynamic boost pressure response when individual wheel control is active. Right now this is a percentage of the base error threshold, but will need to be enhanced.				1 msec	Type A. MIL Illumination.
		When the measured pressure is less than the error target the fault maturity counter accumulates at a rate proportional to the error. When the counter reaches a maturation threshold the fault will get set and the system will enter Push Through mode.					
BOOSTED_BRAKE_SYSTEM_DYNAMIC_LEAK	C0021	The leak detection logic compares pressure gradient threshold against the measured pressure gradient. Once the error last longer than a time threshold, and the pressure error integral passes its threshold, leak is detected. The pressure gradient can be estimated from Dap flow rate and PV information; Similarly, pressure can be estimated from Dap volume and PV information. Here the worst case PV is taken				1 msec	Type A. MIL Illumination.
BOOSTED_BRAKE_SYSTEM_LEAK_ISO_FAILED	C0021	Brake fluid leak on a channel or circuit without the ability to identify the location of the leak	Set if the leakage circuit cannot be isolated successfully			5 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
BOOST_POWER_MANAGEMENT_ENABLED_WARNING	C0021	This fault is set if the Power mode is not in Crank, and the System Voltage is outside an under_volt_threshold of 8.5 V.				20 msec	Type A. MIL Illumination.
BOOST_POWER_MANAGEMENT_ACTIVE_FAILURE	C0021	This fault is set if the Power mode is not in Crank, and the System Voltage is outside an under_volt_threshold of 7.4 V.				20 msec	Type A. MIL Illumination.
BOOST_SYSTEM_FADED_BRAKES_DETECTED	C0072	If the fade factor is greater than TBD for TBD msec, this fault is set.		TBD		TBD	Type A. MIL Illumination.
PTU_ESTABLISH_HOME_POSITION	C0021	Motor could not find home position in 4sec. Motor gets stuck somewhere				1 msec	Type A. MIL Illumination.
COMP_PORT_NOT_LEARNED	C0021	Read the NVRAM Comp port block. If == 0x00 then set this fault		Comp_Port == 0x00		1 msec	Type A. MIL Illumination.
ACU_NOT_CONFIGURED	C0021	Read DID 46, if DID 46 == 0F 00, clear the fault, otherwise, set the fault		If DID 46 != 0F00		5 msec	Type A. MIL Illumination.
ACU_DAP_COMPLIANCE_FAILURE	C2A17	After the end of every ignition cycle, the shutdown test is run to check for integrity of the system's hydraulics. The 3-way valves are energized and DAP is commanded to a certain position. If the build time has not been reached with extended DAP movement, then this fault is set	Primary 3-Way valve leaks to Reservoir through MC Secondary 3-Way valve leaks to Reservoir through MC DAP pushes fluid to T3 chamber of reservoir through failed(leaky) check valve Leaky ISO (LF,LR,RF,RR) valve(s) Failed Seal(s) on the DAP piston	Build Time hasn't been exceeded and Boost pressure does not reach 60 bar even with extended DAP movement	Runs During Shutdown	5msec	Type A. MIL Illumination.
ACU_DAP_COMPLIANCE_ERROR	C2A17	After the end of every ignition cycle, the shutdown test is run to check for integrity of the system's hydraulics. The 3-way valves are energized and DAP is commanded to a certain position. If the boost pressure falls below 50 bar during the wait time, this fault is set	Primary 3-Way valve leaks to Reservoir through MC Secondary 3-Way valve leaks to Reservoir through MC DAP pushes fluid to T3 chamber of reservoir through failed(leaky) check valve Leaky ISO (LF,LR,RF,RR) valve(s) Failed Seal(s) on the DAP piston	After the completion of wait (HOLD) time, Boost pressure < 50 bar	Runs During Shutdown	5 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
ACU_MC_COMPLIANCE_ERROR	C2A17	The Primary 3-way valve is de-energized and DAP is commanded to a certain position with the STV energized and Secondary 3-way valve. DAP stops its travel as soon as the Secondary Pressure sensor records a pressure of 30 bar. After the hold time, if the pressure drops below 20 bar, this fault is set.	Failed seals on Secondary Chamber of Master Cylinder Failed seals on Primary Chamber of Master Cylinder Failed Seal between the Primary and Secondary Master Cylinder Piston Leaky Simulator Test Valve Leaky Pedal Simulator Valve Leaky De-energized Primary 3-way Valve	Pressure recorded by the Secondary Pressure Sensor falls below 20 bar during this stage	Runs During Shutdown	5 msec	Type A. MIL Illumination.
ACU_SIM_TEST_PRESSURE_LOW_ERROR	C2A17	The Primary 3-way valve is de-energized and DAP is commanded to a certain position with the STV energized and Secondary 3-way valve. DAP stops its travel as soon as the Secondary Pressure sensor records a pressure of 30 bar. After the hold time, the pedal simulator valve is energized to let the fluid into the simulator and once again the DAP is commanded to a position until the secondary pressure reaches 20 bar. Then the DAP goes into a passive mode and then the pressure is monitored. If the pressure falls below 15 bar, this fault is set	Leaky Simulator Test Valve Leaky Pedal Simulator Valve Failed seals of Pedal Simulator piston Broken Pedal simulator piston spring	Pressure recorded by the Secondary Pressure Sensor falls below 15 bar during this stage	Runs During Shutdown	5 msec	Type A. MIL Illumination.
ACU_SIM_FILL_DELTA_POS_FAILURE	C2A17	The Primary 3-way valve is de-energized and DAP is commanded to a certain position with the STV energized and Secondary 3-way valve. DAP stops its travel as soon as the Secondary Pressure sensor records a pressure of 30 bar. After the hold time, the pedal simulator valve is energized to let the fluid into the simulator and once again the DAP is commanded to a position until the secondary pressure reaches 20 bar. If the position change is too small and the expected pressure is achieved, this fault is set	Blocked Pedal Simulator Valve Incompressible pedal simulator spring	The secondary MC pressure shoots up to 20 bar with very little (5 millimeter) travel of the DAP	Runs During Shutdown	5 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
ACU_3WAY_OFF_LEAKAGE_ERROR	C2A17	The Primary 3-way valve is de-energized and DAP is commanded to a certain position with the STV energized and Secondary 3-way valve. DAP stops its travel as soon as the Secondary Pressure sensor records a pressure of 30 bar. After the hold time, the pedal simulator valve is energized to let the fluid into the simulator and once again the DAP is commanded to a position until the secondary pressure reaches 20 bar. And then, the PSV, and both the 3-way valves are deenergized and this lets the fluid to the wheel ends. If the resultant secondary MC pressure drops below 15 bar, this fault is set.	Leaky LF Dump valve Leaky RF Dump valve Leaky LR Dump valve Leaky RR Dump valve LF Channel jounce hose leak RF Channel jounce hose leak LR channel jounce hose leak RR channel jounce hose leak	The secondary MC pressure drops below 15 bar during this stage	Runs During Shutdown	5 msec	Type A. MIL Illumination.
ACU_CIRCUIT_FLOW_RATE_ERROR	C2A17	All Dump valves are actuated for 200 ms (X4 times) to monitor the drop in pressure of the Secondary MC pressure sensor and if the pressure falls too slow compared to the calibration based pressure decay rate, this fault is set	Incompressible Master Cylinder pistons (Cannot be moved or limited movement)	The secondary circuit pressure drops too slow when all the four Dump valves are actuated	Runs During Shutdown	5 msec	Type A. MIL Illumination.
HYDRAULIC_SHUTDOWN_TEST_HAS_NOT_RUN	C0021	Shutdown Test is usually run at the end of every ignition cycle and if the shutdown test gets aborted due to any reason, after <TBD> miles or 10 ignition cycles (whichever occurs first), this fault is set	Shutdown test couldn't be completed from the past <TBD> miles or <TBD> ignition cycles.	Shutdown test couldn't be completed from the past <TBD> miles or 10 ignition cycles	Runs During Shutdown	5 msec	Type A. MIL Illumination.
HYDRAULIC_SHUTDOWN_TEST_NOT_RUN_WARNING	C0021	Shutdown Test is usually run at the end of every ignition cycle and if the shutdown test gets aborted due to any reason like the Pedal Travel Sensors detected a pedal travel <or> the ignition was turned ON, this fault is set	Shutdown test couldn't be completed because the Pedal Travel Sensors detected a pedal travel <or> the ignition was turned ON	Shutdown test couldn't be completed because the Pedal Travel Sensors detected a pedal travel <or> the ignition was turned ON	Runs During Shutdown	5 msec	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
BRAKE_BY_WIRE_HIGH_LEVEL_MONITOR_FAILURE	C0021	The goal of this fault monitor is to look for conditions where the base brake values are energized in a boosted brake mode, while there are any parts of the boost logic which indicate that boosted brakes should not be enabled. The validity of the driver inputs, base brake mode, Actuator control mode, Boost/Brake Arbitrator states, and the Electric drive states must all agree that boosted brakes are allowed for the base brake valves to be in a boosted condition. Otherwise the fault will be matured.	Base brake values are energized in a boosted brake mode, while there are any parts of the boost logic which indicate that boosted brakes should not be enabled.	• (Pedal Travel signal is not valid AND SCP is invalid) OR • Boost Arb targeted pressure is not available OR • BOOST System in INHIBITED OR • Electric Drive state is not active or not running OR • Actuator Control is not allowed	• Pedal travel sensor signal • SCP value • Boost Arb state • Electric drive status	200 msec	Type A. MIL Illumination.
Group 33 - Electronic Park Brake							
PB_MICRO_ADC_REFERENCE_FAULT	C0616	The conversion of all input voltages on the S12 micro is based on an ADC reference voltage. This fault indicates this voltage is outside of expected tolerance so none of the voltage readings can be considered accurate.	ECU internal defect. Incorrect 5V supply from ASIC.	The EPB Micro fault flag PB_MICRO_ADC_REFERENCE_FAULT = True	Filtered system voltage >= 7.5V AND SYSTEM_VOLTAGE_EXCESSIVE_LOW fault not set.	50 msec	Type A. MIL Illumination.
Group 38 - Systematic Errors							
TASK_OVERRUN_CORE0	P0606	A timer alarm used to activate a periodic task expires and the prior activation/execution of this task has not run to completion. The number of multiple activations allowed for the task has already been reached.	Software Error ECU Hardware Failure Input Signals To ECU causing high interrupt load	None	Always Enabled	9	Type A. MIL Illumination.
TASK_OVERRUN_CORE1	P0606	A timer alarm used to activate a periodic task expires and the prior activation/execution of this task has not run to completion. The number of multiple activations allowed for the task has already been reached.	Software Error ECU Hardware Failure Input Signals To ECU causing high interrupt load	None	Always Enabled	9	Type A. MIL Illumination.
TASK_OVERRUN_CORE2	P0606	A timer alarm used to activate a periodic task expires and the prior activation/execution of this task has not run to completion. The number of multiple activations allowed for the task has already been reached.	Software Error ECU Hardware Failure Input Signals To ECU causing high interrupt load	None	Always Enabled	9	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
MPU_FAULT_TRW_SCS_CORE0	P0606	Memory Protection Unit (MPU) detects an attempted memory access where there is no defined address range providing the needed permission.	Software Error Partial Microcontroller Failure	None	Always Enabled	10	Type A. MIL Illumination.
MPU_FAULT_TRW_SCS_CORE1	P0606	Memory Protection Unit (MPU) detects an attempted memory access where there is no defined address range providing the needed permission.	Software Error Partial Microcontroller Failure	None	Always Enabled	10	Type A. MIL Illumination.
MPU_FAULT_TRW_SCS_CORE2	P0606	Memory Protection Unit (MPU) detects an attempted memory access where there is no defined address range providing the needed permission.	Software Error Partial Microcontroller Failure	None	Always Enabled	10	Type A. MIL Illumination.
ICC_FAILURE_CORE0	P0606	ICC failsafe mechanism determines if any ICC receives or sends were skipped. At the beginning of every 10ms slot, every core in the scheduler runs the failsafe that checks if any of the ICC sends or receives were skipped in the previous 10ms slot. In case it was skipped the failsafe matures the ICC fault. The failsafe also tries to get back the ICC receives and sends to work normally from the next 10ms Slot.	ICC send or receive have been skipped.	At the beginning of every 10ms slot, every core in the scheduler runs the failsafe that checks if any of the ICC sends or receives were skipped in the previous 10ms slot.	Always Enabled	60	Type A. MIL Illumination.
ICC_FAILURE_CORE1	P0606	ICC failsafe mechanism determines if any ICC receives or sends were skipped. At the beginning of every 10ms slot, every core in the scheduler runs the failsafe that checks if any of the ICC sends or receives were skipped in the previous 10ms slot. In case it was skipped the failsafe matures the ICC fault. The failsafe also tries to get back the ICC receives and sends to work normally from the next 10ms Slot.	ICC send or receive have been skipped.	At the beginning of every 10ms slot, every core in the scheduler runs the failsafe that checks if any of the ICC sends or receives were skipped in the previous 10ms slot.	Always Enabled	60	Type A. MIL Illumination.

Component/ System	Fault Code	Monitoring Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameter and Enable Condition	Time Required	MIL Illumination
ICC_FAILURE_CORE2	P0606	ICC failsafe mechanism determines if any ICC receives or sends were skipped. At the beginning of every 10ms slot, every core in the scheduler runs the failsafe that checks if any of the ICC sends or receives were skipped in the previous 10ms slot. In case it was skipped the failsafe matures the ICC fault. The failsafe also tries to get back the ICC receives and sends to work normally from the next 10ms Slot.	ICC send or receive have been skipped.	At the beginning of every 10ms slot, every core in the scheduler runs the failsafe that checks if any of the ICC sends or receives were skipped in the previous 10ms slot.	Always Enabled	60	Type A. MIL Illumination.

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System Voltage Low	P0562	Detects if battery input voltage is below a threshold	Battery voltage is below a threshold	≤ 8.10 volts	Engine Speed	>= 500 rpm	5,000 ms	Type C, No SVS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Read Only Memory (ROM)	P0601	See Malfunction criteria for Case Description.	Software or calibration checksum is incorrect - Case 1 - Checksum error	Calculated Checksum <> Stored Checksum			Runs at controller shutdown	Type A, 1 Trips
			Flash ECC (error correction code) Circuit Test - Case 2 - Failed detection of invalid data written to ECC	No ECC error found or wrong address			Runs once per powerup	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Not Programmed	P0602	Indicates that the Control Module needs to be programmed	'No Start' Calibration is set to true which is only available on a new un-programmed Module	'No Start Calibration'	= TRUE	Continuous	1s loop, 1 failure	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Long Term Memory Reset	P0603	Non-volatile memory checksum error	Checksum at power-up does not match checksum at power-down			Runs at battery connect OR after a controller reset OR When Battery Backed RAM failure detected OR next controller init when Failure counter increments to 1 OR Fault is active OR Test not passed since code clear OR Test failed this key on OR MIL Request is ON	2 consecutive failed samples	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Random Access Memory (RAM) Failure	P0604	RAM ECC Circuit Test	Failed validation of test data written to ECC	No ECC error found or wrong address			Runs once per power up	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Internal Performance	P0606	See Malfunction Criteria for Case Description	ALU (arithmetic logic unit) and Register Test - Case 1 - Control Module fails to execute a diagnostic test algorithm			Continuous	1s loop, 3 failures in powerup cycle	Type A, 1 Trips
			Program Sequence Counter - Case 2 - Incorrect sequence of frame executionProgram Sequence Counter	10 samples in incorrect sequence in consecutive order		Continuous	1s loop, 3 failures in powerup cycle	
			Configuration Registers Test - Case 3 - Comparison of current configuration register settings with predefined values fails	Configuration register <> predefined value		Continuous	1s loop, 3 failures in powerup cycle	
			MMU Test - Case 4 - Test of memory management related instructions fails	Fails MMU (memory management unit) instruction		Continuous	1s loop, 3 failures in powerup cycle	
			Main State of Health fault detected by Auxillary Micro			Continuous	100ms loop, 9 failures in powerup cycle	
			Stack Limits Test - Case 6 - Verifies stack usage does not exceed maximum stack size	Stack usage exceeds 100%		Continuous	1s loop, 3 failures in powerup cycle	
			Auxiliary ALU Test - Case 7 - Auxiliary microprocessor fails to run a defined diagnostic algorithm			Continuous	1s loop, 3 failures in powerup cycle	
			Auxiliary RAM Test - Case 8 - Auxiliary microprocessor fails a write/read data diagnostic RAM test			Continuous	1s loop, 3 failures in powerup cycle	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Auxiliary ROM Test - Case 9 - Auxiliary microprocessor ROM checksum error			Continuous	1s loop, 3 failures in powerup cycle	
			Auxiliary Register Configuration Test - Case 10 - Configuration register values do not match expected pre-configured values			Continuous	1s loop, 3 failures in powerup cycle	
			Auxiliary Stack Test - Case 11 - Auxiliary microprocessor stack overflow			Continuous	1s loop, 3 failures in powerup cycle	
			Seed and Key Test - Case 12 - Seed and key test failed - invalid order, timeout, incorrect seed, incorrect key			Continuous	100ms loop, 3 failures in powerup cycle	
			Main Detected Seed Incorrect Order - Case 13 - Seed and key test failed - main microprocessor received seed from the auxiliary microprocessor out of order			Continuous	100ms loop, 3 failures in powerup cycle	
			Main Detected Unknown Seed - Case 14 - Seed and key test failed - main microprocessor received an unknown seed			Continuous	100ms loop, 3 failures in powerup cycle	
			Case 15 - ADC (analog to digital converter) tests Difference between applied test voltage and ADC measured value	 > 9%	Diagnostic Enabled AND Battery Voltage	= TRUE >= 7 V	100ms loop, 3 failures in powerup cycle	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			In a sampled window OR Difference between applied test voltage and ADC measured value Continuous for more than	>= 0.15 sec out of 0.4 sec > 9% >= 0.20 sec				
			SPI (serial peripheral interface) A Fault Detection Test - Case 16 - SPI A fault detected			Continuous	100ms loop, 9 failures in powerup cycle	
			SPI B Fault Detection Test - Case 17 - SPI B fault detected			Continuous	100ms loop, 9 failures in powerup cycle	
			Auxillary SPI Communication faulted			Continuous	100ms loop, 9 failures in powerup cycle	
			Main buck regulator faulted	<= 4.850 V OR >= 7.026 V		Continuous	100ms loop, 3 failures in powerup cycle	
			Secondary Power supply failed	<=4.496 OR >=5.494		Continuous	100ms loop, 3 failures in powerup cycle	
			5v Reference supply failed	<=4.596 OR >=5.414		Continuous	100ms loop, 3 failures in powerup cycle	
			Secondary micro detected fault of main micro			Continuous	100ms loop, 9 failures in powerup cycle	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Long Term Memory Performance	P062F	Checks Battery Independent Non-Volatile Data Memory (BINVDM) operation	Battery independent non-volatile status update failed	>= 2 consecutive failed samples			Runs at controller shutdown and after new data is written to EEPROM (which is checked every 5 hours)	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference 3 Circuit	P0697	Sets when the 5 Volt Reference 3 Circuit voltage is below a threshold or if it is above a threshold	5v Reference 3 circuit Voltage	<= 4.496 V (10% of nominal) OR >= 5.494 V (10% of nominal)	Battery Voltage	>= 8.10 V	320 Failed samples within 400 samples 1 sample every 12.5ms 5000 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference 4 Circuit	P06A3	Sets when the 5 Volt Reference 4 Circuit voltage is below a threshold or if it is above a threshold	5v Reference 4 circuit Voltage	<= 4.496 V (10% of nominal) OR >= 5.494 V (10% of nominal)	Battery Voltage	>= 8.10 V	320 Failed samples within 400 samples 1 sample every 12.5ms 5000 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Reference Voltage E Circuit/Open	P06D2	Sets when the 12 volt reference E Circuit voltage is below a threshold or if it is above a threshold	Reference Voltage E Circuit Voltage	<= 5.446 V (55% of nominal) OR >= 19.634 V (64% of nominal)	Battery Voltage	>= 8.10 V	320 Failed samples within 400 samples 1 sample every 12.5ms 5000 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Pack State of Charge Low	P0A7D	This diagnostic monitors for high voltage battery state of charge (SOC) which is too low. It monitors the SOC during each driving cycle. At the start of each driving cycle, if the SOC is below the SOC too low threshold, a maximum time is computed that represents worst case how much engine on time (generator on time) would be necessary in order to get the SOC back into range and above the SOC too low threshold. Once this time expires, the monitor is enabled and will accumulate sample counts. The monitor will accumulate fail counts if the SOC is not in range. The diagnostic will make a single pass/fail determination at the end of each driving cycle but only if there was sufficient distance accumulated that driving cycle. When driving cycles are too short to make a pass/ fail decision, the fail/ sample counters will be carried over to the next driving cycle so that	SOC	< 27.00	System Voltage (Applicable to this Program/MY: TRUE) Transmission Shifter Position (Applicable to this Program/MY: FALSE) Hood Position (Applicable to this Program/MY: FALSE) Battery Temperature Vehicle Speed Re-entry delay surpassed Hybrid/EV Battery Pack Voltage Sensor Fault Active (see Fault Bundle page) Hybrid/EV Battery Current Sensor Fault Active (see Fault Bundle page) Hybrid/EV Battery Temperature Sensor Fault Active (see Fault Bundle page)	> 8.10 V != Neutral != Open >= -10.00 C > 15.00 km/h **KtBSED_Cf_BSL_ReentryDelay** *(27.00 - SOC) (see Supporting Tables) No active DTCs No active DTCs No active DTCs	Drive cycle complete with total distance driven > 50.00 km AND Ratio of low SOC distance to total distance driven > 0.50	Type A, 1 Trips
			Pass		System Voltage (Applicable to this Program/MY: TRUE) Transmission Shifter	> 8.10 V != Neutral	Drive cycle complete with total distance driven > 50.00 km	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		they are not abandoned. At the end of each driving cycle in which sufficient pass/ fail data has been collected, the diagnostic will fail if the ratio of fail counts to sample counts is greater than a failure threshold and will pass otherwise. The diagnostic also can pass more quickly at the end of shorter driving cycles but only of the fail count = 0 (SOC was in range the entire enabled portion of the driving cycle) and sample counts are greater than some minimum fast pass threshold.			Position (Applicable to this Program/MY: FALSE) Hood Position (Applicable to this Program/MY: FALSE) Battery Temperature Vehicle Speed Re-entry delay surpassed Hybrid/EV Battery Pack Voltage Sensor Fault Active (see Fault Bundle page) Hybrid/EV Battery Current Sensor Fault Active (see Fault Bundle page) Hybrid/EV Battery Temperature Sensor Fault Active (see Fault Bundle page)	 != Open >= -10.00 C > 15.00 km/h **KtBSED_Cf_BSL_ReentryDelay** *(27.00 - SOC) (see Supporting Tables) No active DTCs No active DTCs No active DTCs	AND Ratio of low SOC distance to total distance driven < 0.50	
			Fast Pass		System Voltage (Applicable to this Program/MY: TRUE) Transmission Shifter Position (Applicable to this Program/MY: FALSE) Hood Position (Applicable to this	> 8.10 V != Neutral != Open	Drive cycle complete with total distance driven > 10.00 km AND Distance driven with low SOC = 0 km	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Program/MY: FALSE)			
					Battery Temperature	>= -10.00 C		
					Vehicle Speed	> 15.00 km/h		
					Re-entry delay surpassed	**KtBSED_Cf_BSL_ReentryDelay** *(27.00 - SOC) (see Supporting Tables)		
					Hybrid/EV Battery Pack Voltage Sensor Fault Active (see Fault Bundle page)	No active DTCs		
					Hybrid/EV Battery Current Sensor Fault Active (see Fault Bundle page)	No active DTCs		
					Hybrid/EV Battery Temperature Sensor Fault Active (see Fault Bundle page)	No active DTCs		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Pack Over temperature	P0A7E	This diagnostic detects if the max battery temperature is above a threshold. If the enable criteria are met and the temperature is above a calibrated threshold, the fail counter will increment. If the calibrated fail count threshold is met before the calibrated sample count, the diagnostic will report a FAIL and if not it will report a PASS. The diagnostic will continue to report as long as the enablement criteria are met.	Max Battery Temperature	> 72.00 °C	No Active DTCs (Battery temperature status) Short High Short Low Performance	 P0A9E P0AC8 P0ACD P0AEB P0BC5 P0C36 P0C7F P0C84 P0C8B P0C90 P0C95 P0C9A P0CAB P0CB0 P0CB5 P0CBA P0A9D P0AC7 P0ACC P0AEA P0BC4 P0C35 P0C7E P0C83 P0C8A P0C8F P0C94 P0C99 P0CAA P0CAF P0CB4 P0CB9 P1E8E P1E94 P1E9A P1EA0	80.00 fails / 100.00 samples at 100ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Communication	P1FBD P1FBE P1FBF P1FC0 U179C	10 seconds	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Pack Deterioration	P0A7F	This diagnostic monitor compares the calculated hybrid/EV battery pack power capability against a calibrated failure threshold table. The calculated battery power capability is a function of the sensed battery voltage, current, and temperature. The "minimum threshold" is the minimum battery power required to meet necessary vehicle emissions performance at ~ 30 % state of charge (SOC) at 20 C. A new battery would be expected to have reasonably large amounts of power under these conditions, and reduced power capability as the SOC or temperature drops. Because the power capability drops with decreasing SOC below the ~ 30 % point, the failure threshold is reduced proportionally with decreasing SOC from the ~ 30 % point. Above the ~ 30 % point, the failure threshold is held constant with increasing SOC. Because the power capability drops with	Calculated battery discharge power limits	< **KtBSED_P_BPD_D_EndOfLifePwrThrsh** (kW) - see Supporting Tables	Hybrid/EV Battery Temperature Hybrid/EV Battery SOC Run Crank Active System Voltage Hybrid/EV Battery Pack Voltage Sensor Fault Active (see Fault Bundle Page) Hybrid/EV Battery Current Sensor Fault Active (see Fault Bundle Page) Hybrid/EV Battery Temperature Sensor Fault Active (see Fault Bundle Page) Actual battery power exceedance of power limits in terms of % overshoot multiplied by seconds of duration	< 50.00 ºC, AND > -10.00 ºC > 30.00 %, AND < 100.00 % = TRUE > 8.10 V No active DTCs No active DTCs No active DTCs < 80.00 %-Sec	100 failures 100 ms /sample	Type B, 2 Trips
			Calculated battery charge power limits	< **KtBSED_P_BPD_C_EndOfLifePwrThrsh** (kW) - see Supporting Tables	Hybrid/EV battery Temperature Hybrid/EV battery SOC Run Crank Active	< 50.00 ºC, AND > -10.00 ºC > 0.00 %, AND < 60.00 % = TRUE	100 failures 100 ms /sample	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		decreasing temperature below the 20 C point, the failure threshold is reduced proportionally with decreasing temperature from the 20 C point. Above the 20 C point, the failure threshold is held constant with increasing temperature. If the calculated battery power capability falls below the failure threshold (which is a function of SOC and battery temperature) for greater than the calibrated amount of time, the diagnostic will fail. If an entire drive cycle (time betweeen rising and falling edges of Run Crank) is completed without failing, and the measured battery power exceeds the failure threshold (which is a function of SOC and temperature) for at least a calibrated amount of time, then the diagnostic will pass.			System Voltage Hybrid/EV Battery Pack Voltage Sensor Fault Active (see Fault Bundle Page) Hybrid/EV Battery Current Sensor Fault Active (see Fault Bundle Page) Hybrid/EV Battery Temperature Sensor Fault Active (see Fault Bundle Page) Actual battery power exceedance of power limits in terms of % overshoot multiplied by seconds of duration	> 8.10 V No active DTCs No active DTCs No active DTCs < 80.00 %-Sec		
			(DTC Pass) Actual battery discharge power	> **KtBSED_P_BPD_D_MinPassPowerThrsh** (kW) for 0.30 second - see Supporting Tables	Hybrid/EV battery temperature Hybrid/EV battery SOC Run Crank Transition No failure of the discharging power limit monitor during this drive cycle System Voltage Hybrid/EV Battery Pack Voltage Sensor Fault Active	< 50.00 ºC, AND > -10.00 ºC > 30.00 %, AND < 100.00 % True -> False > 8.10 V No active DTCs		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(see Fault Bundle Page)			
					Hybrid/EV Battery Current Sensor Fault Active (see Fault Bundle Page)	No active DTCs		
					Hybrid/EV Battery Temperature Sensor Fault Active (see Fault Bundle Page)	No active DTCs		
			(DTC Pass) Actual battery charge power	> **KtBSED_P_BPD_C_ MinPassPowerThrsh** (kW) for 0.50 second - see Supporting Tables	Hybrid/EV battery temperature	< 50.00 ºC, AND		
						> -10.00 ºC		
					Hybrid/EV battery SOC	> 0.00 %, AND		
						< 60.00 %		
					Run Crank Transition	True -> False		
					No failure of the discharging power limit monitor during this drive cycle			
					System Voltage	> 8.10 V		
					Hybrid/EV Battery Pack Voltage Sensor Fault Active (see Fault Bundle Page)	No active DTCs		
					Hybrid/EV Battery Current Sensor Fault Active (see Fault Bundle Page)	No active DTCs		
					Hybrid/EV Battery Temperature Sensor Fault Active (see Fault Bundle Page)	No active DTCs		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Pack Cooling Fan 1 Control Circuit Open	P0A81	This diagnostic detects if the host controller has detected an open fault on the output control circuit. If the enable criteria are met and a fault is detected on the circuit, the fail counter will increment. If the calibrated fail count threshold is met before the calibrated sample count, the diagnostic will report a FAIL and if not it will report a PASS. The diagnostic will continue to report as long as the enablement criteria are met.	Control Circuit Voltage	>=1.6 V and <= 5.85 V	System Voltage Fan Control Commanded Speed Run Crank Active Run Crank Active Time No Active DTCs (Run Crank Active Signal)	> 8.10 V < 10.00 % Pulse Width Modulation Duty Cycle = TRUE > 1.00 second P2534, P2535	16.00 fails / 20.00 samples at 250ms 5 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Pack Cooling Fan 1 Control Circuit Low	P0A84	This diagnostic detects if the host controller has detected a short to ground fault on the output control circuit. If the enable criteria are met and a fault is detected on the circuit, the fail counter will increment. If the calibrated fail count threshold is met before the calibrated sample count, the diagnostic will report a FAIL and if not it will report a PASS. The diagnostic will continue to report as long as the enablement criteria are met.	Control Circuit Voltage	<0.257 V	System Voltage Fan Control Commanded Speed Run Crank Active Run Crank Active Time No Active DTCs (Run Crank Active Signal)	> 8.10 V < 10.00 % Pulse Width Modulation Duty Cycle = TRUE > 1.00 second P2534, P2535	16.00 fails / 20.00 samples at 250ms 5 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Pack Cooling Fan 1 Control Circuit High	P0A85	This diagnostic detects if the host controller has detected a short to power fault on the output control circuit. If the enable criteria are met and a fault is detected on the circuit, the fail counter will increment. If the calibrated fail count threshold is met before the calibrated sample count, the diagnostic will report a FAIL and if not it will report a PASS. The diagnostic will continue to report as long as the enablement criteria are met.	Control Circuit Voltage	> 9 V	System Voltage Fan Control Commanded Speed Run Crank Active Run Crank Active Time No Active DTCs (Run Crank Active Signal)	> 8.10 V 11.00 % < Pulse Width Modulation Duty Cycle < 100.00 % = TRUE > 1.00 second P2534, P2535	16.00 fails / 20.00 samples at 250ms 5 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor A Range/ Performance	P0A9C	This diagnostic verifies that the hybrid/EV battery temperature sensor is neither inappropriately high nor low. It compares the sensed battery temperature with an average comprised of other battery temperature sensors. If the absolute value of the difference between the sensed battery temperature and the average is greater than the failure threshold for sufficient time, the diagnostic will fail.	Absolute value of the difference between the temperature input and the average of other battery temperature sensors	> 25.00 ºC	System Voltage Hybrid/EV Battery Temperature Sensor Circuit Low (see Fault Bundle page) Hybrid/EV Battery Temperature Sensor Circuit High (see Fault Bundle page) Loss of Communication with Battery Energy Control Module (see Fault Bundle page)	> 8.10 V No active DTCs No active DTCs No active DTCs	50 failures out of 67 samples 25 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor A Circuit Low	P0A9D	This diagnostic monitors for hybrid/EV battery pack temperature sensor voltage which is out of range low. The temperature sensor this diagnostic is monitoring is a negative temperature coefficient thermistor with a pull-up resistor on the sensing board, meaning a high temperature or sensor short to ground will result in a low sensed voltage. After conversion the sensed temperature is compared against a threshold. If the sensed temperature is above the failure threshold for sufficient time, the diagnostic will fail.	Battery temperature	> 160 C	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor A Circuit High	P0A9E	This diagnostic monitors for high voltage battery pack temperature sensor voltage which is out of range high. The temperature sensor this diagnostic is monitoring is a negative temperature coefficient thermistor with a pull-up resistor on the sensing board, meaning a low temperature or an open circuit will result in a high sensed voltage. After conversion the sensed temperature is compared against a threshold. If the sensed temperature is below the failure threshold for sufficient time, the diagnostic will fail.	Battery temperature	< -69 C	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor A Circuit Intermittent/ Erratic	P0A9F	This diagnostic monitors for a hybrid/ EV battery temperature sensor voltage which is erratic. An erratic temperature sensor can be caused by an intermittent connection which can be observed by monitoring the integrated absolute value of the change in sensor value over time. If over an evaluation period the integration is greater than a calibratable threshold then this evaluation period fails. If a calibratable number of evaluations fail, the diagnostic will fail.	Integrated absolute value of the change in sensor value in a 10 sample window	> 10	System voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	4 failures out of 5 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Positive Contactor Circuit Stuck Closed	P0AA1	The propulsion positive contactor is a high voltage relay that is used to connect the positive side of the high voltage battery to the positive side of the propulsion bus. This DTC detects when the propulsion positive contactor is stuck closed by monitoring for excessive voltage on the positive side of the propulsion bus when all contactors are commanded open for greater than a calibratable time. The calibratable time is necessary in order to guarantee that the propulsion bus has been fully discharged in order to prevent false failures.	Propulsion Positive Bus Voltage	> 21 Volts	Voltage Control Mode Propulsion Bus Voltage Sensor Propulsion Positive Bus Voltage High Voltage Battery Voltage Sensor [All Contactors OR [All Contactors AND Propulsion Bus Voltage]]	Not Active Not Failed Not Failed Not Failed Open for > 120 seconds Open < 30 % of High Voltage Battery Voltage	4 failures out of 6 samples 12.5 ms /sample 75 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Negative Contactor Circuit Stuck Closed	P0AA4	The propulsion negative contactor is a high voltage relay that is used to connect the negative side of the high voltage battery to the negative side of the propulsion bus. This DTC detects when the propulsion negative contactor is stuck closed by monitoring for excessive voltage on the negative side of the propulsion bus when all contactors are commanded open for greater than a calibratable time. The calibratable time is necessary in order to guarantee that the propulsion bus has been fully discharged in order to prevent false failures.	Propulsion Negative Bus Voltage	> 21 V	Voltage Control Mode Propulsion Bus Voltage Sensor Propulsion Negative Bus Voltage High Voltage Battery Voltage Sensor All Contactors OR [All Contactors AND Propulsion Bus Voltage]	Not Active Not Failed Not Failed Not Failed Open for > 120 seconds Open < 30 % of High Voltage Battery Voltage	4 failures out of 6 samples 12.5 ms /sample 75 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage System Isolation Fault	P0AA6	This DTC will determine if the measured resistance between the positive or negative side of the high voltage battery and chassis ground is below a threshold which indicates that the internals of the battery are no longer adequately isolated from chassis ground.	Active Isolation Resistance	< 78,000 Ohm	P0AA6 P0AA7 P0AA8 Propulsion Positive Contactor Propulsion Negative Contactor	DTC Not Active DTC Not Active DTC Not Active Open Open	Fail if last resistance measurement is below theshold AND any 5 measurements out of last 10 measurements are below resistance threshold. No more than one resistance measurement is taken per key cycle. Pass if any single resistance measurement exceeds resistance threshold	Type A, 1 Trips
			Active Isolation Resistance	< 102,000 Ohm	P0AA6 P0AA7 P0AA8 Propulsion Positive Contactor Propulsion Negative Contactor	DTC Active DTC Not Active DTC Not Active Open Open	Fail if last resistance measurement is below threshold AND any 5 measurements out of last 10 measurements are below resistance theshold. No more than one resistance measurement is taken per key cycle.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							Pass if any single resistance measurement exceeds resistance threshold	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Isolation Sensor Circuit	P0AA7	There is an Active Isolation Bias Switch to introduce an extra known resistance into the hybrid battery isolation measurement circuitry. This Active Isolation Bias Switch is used to determine active isolation resistance. This DTC verifies functionality of the switch by measuring the voltages of both Hybrid/EV Battery Pack Voltage Isolation Sensors with respect to ground while the switch is commanded on and off. Then the diagnostic monitor processes the voltage measurements through a mathematical algorithm and compares the output to a threshold value. If the output is less than the threshold value, then the Active Isolation Bias Switch is faulty.	(Hybrid/EV Battery Pack Voltage Isolation Sensor (Switch Commanded ON) - Hybrid/EV Battery Pack Voltage Isolation Sensor (Switch Commanded OFF))^2 + (Hybrid/EV Battery Pack Voltage Isolation Sensor 2 (Switch Commanded ON) - Hybrid/EV Battery Pack Voltage Isolation Sensor 2 (Switch Commanded OFF))^2	< 5 volts^2	P0AA8 P0AA9 P1E0C P1E0D P0AAA All Contactors Run/Crank	DTC Not Active DTC Not Active DTC Not Active DTC Not Active DTC Not Active Open for 8 seconds False	12.5 ms /sample 8 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Isolation Sensor Range/ Performance	P0AA8	This DTC verifies that the operational amplifier (op amp) output of the two hybrid/EV battery pack voltage isolation sensors is correct by summing the individual sensed values of the sensors and subtracting off the op amp output. If the result is greater than a threshold, then the DTC fails.	Absolute value of (Hybrid/ EV Battery Pack Voltage Isolation Sensor plus Hybrid/EV Battery Pack Voltage Isolation Sensor 2 minus High Voltage Battery Voltage)	> 5 volts	Active Isolation Bias Switch High Voltage Battery Voltage Status	Commanded Open Valid	40 failures out of 50 samples 12.5 ms /sample 625.00 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Isolation Sensor Circuit Low	P0AA9	This diagnostic monitors the Hybrid/EV Battery Pack Voltage Isolation Sensor for out of range low. It compares the voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail.	Hybrid/EV Battery Pack Voltage Isolation Sensor	< 5 volts	Active Isolation Bias Switch	Commanded Open	320 failures out of 400 samples 12.5 ms /sample 5,000 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Isolation Sensor Circuit High	P0AAA	This diagnostic monitors the Hybrid/EV Battery Pack Voltage Isolation Sensor for out of range high. It compares the voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Hybrid/EV Battery Pack Voltage Isolation Sensor	> 333 volts	Active Isolation Bias Switch	Commanded Open	320 failures out of 400 samples 12.5 ms /sample 5,000 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Pack Voltage Sense Circuit Rationality	P0ABB	This diagnostic verifies that the hybrid/EV battery pack voltage sensor is neither inappropriately high nor low. It compares the sensed battery pack voltage with the sum of the battery cell voltages. If the absolute value of the difference between the sensed battery pack voltage and the sum of the battery cell voltages is greater than the failure threshold for sufficient time, the diagnostic will fail.	Absolute value of the difference between the battery pack voltage and the sum of the battery cell voltages	> 10.00 V	P0ABC P0ABD Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	Not active Not active No active DTCs	32 failures out of 40 samples 25 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Pack Voltage Sense Circuit Low	P0ABC	This diagnostic monitors for hybrid/EV battery pack voltage sensor voltage which is out of range low. It compares the pack voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail.	High voltage battery pack voltage	< 4.80 V	System Voltage	> 8.10 V	8 failures out of 10 samples 25 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Pack Voltage Sense Circuit High	P0ABD	This diagnostic monitors for hybrid/EV voltage battery pack voltage sensor voltage which is out of range high. It compares the pack voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	High voltage battery pack voltage	> 116.52 V	System Voltage	> 8.10 V	8 failures out of 10 samples 25 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Pack Current Sensor Circuit Low	P0AC1	The hybrid/EV battery current is measured using a Hall-effect current sensor. This diagnostic monitors for battery current sensor output voltage which is out of range low. After conversion the sensed battery current is compared against a threshold. If the current is below the failure threshold for sufficient time, the diagnostic will fail.	Battery current	< -365.10 A	System Voltage	> 8.10 V	8 failures out of 10 samples 25 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Pack Current Sensor Circuit High	P0AC2	The hybrid/EV battery current is measured using a Hall-effect current sensor. This diagnostic monitors for battery current sensor output voltage which is out of range high. After conversion the sensed battery current is compared against a threshold. If the current is above the failure threshold for sufficient time, the diagnostic will fail.	Battery current	> 274.60 A	System Voltage	> 8.10 V	8 failures out of 10 samples 25 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor B Range/ Performance	P0AC6	This diagnostic verifies that the hybrid/EV battery temperature sensor is neither inappropriately high nor low. It compares the sensed battery temperature with an average comprised of other battery temperature sensors. If the absolute value of the difference between the sensed battery temperature and the average is greater than the failure threshold for sufficient time, the diagnostic will fail.	Absolute value of the difference between the temperature input and the average of other battery temperature sensors	> 25.00 ºC	System Voltage Hybrid/EV Battery Temperature Sensor Circuit Low (see Fault Bundle page) Hybrid/EV Battery Temperature Sensor Circuit High (see Fault Bundle page) Loss of Communication with Battery Energy Control Module (see Fault Bundle page)	> 8.10 V No active DTCs No active DTCs No active DTCs	50 failures out of 67 samples 25 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor B Circuit Low	P0AC7	This diagnostic monitors for hybrid/EV battery pack temperature sensor voltage which is out of range low. The temperature sensor this diagnostic is monitoring is a negative temperature coefficient thermistor with a pull-up resistor on the sensing board, meaning a high temperature or sensor short to ground will result in a low sensed voltage. After conversion the sensed temperature is compared against a threshold. If the sensed temperature is above the failure threshold for sufficient time, the diagnostic will fail.	Battery temperature	> 160 C	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor B Circuit High	P0AC8	This diagnostic monitors for high voltage battery pack temperature sensor voltage which is out of range high. The temperature sensor this diagnostic is monitoring is a negative temperature coefficient thermistor with a pull-up resistor on the sensing board, meaning a low temperature or an open circuit will result in a high sensed voltage. After conversion the sensed temperature is compared against a threshold. If the sensed temperature is below the failure threshold for sufficient time, the diagnostic will fail.	Battery temperature	< -69 C	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor B Circuit Intermittent/ Erratic	P0AC9	This diagnostic monitors for a hybrid/ EV battery temperature sensor voltage which is erratic. An erratic temperature sensor can be caused by an intermittent connection which can be observed by monitoring the integrated absolute value of the change in sensor value over time. If over an evaluation period the integration is greater than a calibratable threshold then this evaluation period fails. If a calibratable number of evaluations fail, the diagnostic will fail.	Integrated absolute value of the change in sensor value in a 10 sample window	> 10	System voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	4 failures out of 5 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor C Range/ Performance	P0ACB	This diagnostic verifies that the hybrid/EV battery temperature sensor is neither inappropriately high nor low. It compares the sensed battery temperature with an average comprised of other battery temperature sensors. If the absolute value of the difference between the sensed battery temperature and the average is greater than the failure threshold for sufficient time, the diagnostic will fail.	Absolute value of the difference between the temperature input and the average of other battery temperature sensors	> 25.00 ºC	System Voltage Hybrid/EV Battery Temperature Sensor Circuit Low (see Fault Bundle page) Hybrid/EV Battery Temperature Sensor Circuit High (see Fault Bundle page) Loss of Communication with Battery Energy Control Module (see Fault Bundle page)	> 8.10 V No active DTCs No active DTCs No active DTCs	50 failures out of 67 samples 25 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor C Circuit Low	P0ACC	This diagnostic monitors for hybrid/EV battery pack temperature sensor voltage which is out of range low. The temperature sensor this diagnostic is monitoring is a negative temperature coefficient thermistor with a pull-up resistor on the sensing board, meaning a high temperature or sensor short to ground will result in a low sensed voltage. After conversion the sensed temperature is compared against a threshold. If the sensed temperature is above the failure threshold for sufficient time, the diagnostic will fail.	Battery temperature	> 160 C	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor C Circuit High	P0ACD	This diagnostic monitors for high voltage battery pack temperature sensor voltage which is out of range high. The temperature sensor this diagnostic is monitoring is a negative temperature coefficient thermistor with a pull-up resistor on the sensing board, meaning a low temperature or an open circuit will result in a high sensed voltage. After conversion the sensed temperature is compared against a threshold. If the sensed temperature is below the failure threshold for sufficient time, the diagnostic will fail.	Battery temperature	< -69 C	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor C Circuit Intermittent/ Erratic	P0ACE	This diagnostic monitors for a hybrid/ EV battery temperature sensor voltage which is erratic. An erratic temperature sensor can be caused by an intermittent connection which can be observed by monitoring the integrated absolute value of the change in sensor value over time. If over an evaluation period the integration is greater than a calibratable threshold then this evaluation period fails. If a calibratable number of evaluations fail, the diagnostic will fail.	Integrated absolute value of the change in sensor value in a 10 sample window	> 10	System voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	4 failures out of 5 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Positive Contactor Control Circuit	P0AD9	Diagnoses the Propulsion Positive Contactor high side PWM output for open circuit faults	Control Voltage	≥ 1.15 V AND ≤ 2.81 V	12V Battery Voltage High Voltage Battery Current Command Status	> 8.1 V < 999 amps OFF	40 failures out of 50 samples 12.5 ms /sample 625 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Positive Contactor Control Circuit Low	P0ADB	Diagnoses the Propulsion Positive Contactor high side PWM output for short to ground circuit faults	Control Voltage	≤ 5.35 V	12V Battery Voltage High Voltage Battery Current Command Status	> 8.1 V < 999 amps ON	20 failures out of 25 samples 12.5 ms /sample 312.5 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Positive Contactor Control Circuit High	P0ADC	Diagnoses the Propulsion Positive Contactor high side PWM output for short to power circuit faults	Control Voltage	≥ 5.27 V AND ≤ 19.7 V	12V Battery Voltage High Voltage Battery Current Command Status	> 8.1 V < 999 amps OFF	40 failures out of 50 samples 12.5 ms /sample 625 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Negative Contactor Control Circuit	P0ADD	Diagnoses the Propulsion Negative Contactor high side PWM output for open circuit faults	Control Voltage	≥ 1.15 V AND ≤ 2.81 V	12V Battery Voltage High Voltage Battery Current Command Status	> 8.1 V < 999 amps OFF	40 failures out of 50 samples 12.5 ms /sample 625 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Negative Contactor Control Circuit Low	P0ADF	Diagnoses the Propulsion Negative Contactor high side PWM output for short to ground circuit faults	Control Voltage	≤ 5.35 V	12V Battery Voltage High Voltage Battery Current Command Status	> 8.1 V < 999 amps ON	20 failures out of 25 samples 12.5 ms /sample 312.5 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Negative Contactor Control Circuit High	P0AE0	Diagnoses the Propulsion Negative Contactor high side PWM output for short to power circuit faults	Control Voltage	≥ 5.27 V AND ≤ 19.7 V	12V Battery Voltage High Voltage Battery Current Command Status	> 8.1 V < 999 amps OFF	40 failures out of 50 samples 12.5 ms /sample 625 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Precharge Contactor Control Circuit	P0AE4	Diagnoses the Precharge Contactor high side driver circuit for open circuit faults.	Voltage	≥ 1.15 V AND ≤ 2.81 V	12V Battery Voltage High Voltage Battery Current Command Status	> 8.1 V < 999 amp Off	40 failures out of 50 samples 12.5 ms /sample 625 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Precharge Contactor Control Circuit Low	P0AE6	Diagnoses the the Precharge Contactor high side driver circuit for short to ground circuit faults	Voltage	≤ 5.35 V	12V Battery Voltage High Voltage Battery Current Command Status	> 8.1 V < 999 amps ON	13 failures out of 16 samples 12.5 ms /sample 200 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Precharge Contactor Control Circuit High	P0AE7	Diagnoses the the Precharge Contactor high side driver circuit for short to power circuit faults	Voltage	≥ 5.27 V AND ≤ 19.7 V	12V Battery Voltage High Voltage Battery Current Command Status	> 8.1 V < 999 amps OFF	40 failures out of 50 samples 12.5 ms /sample 625 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor D Range/ Performance	P0AE9	This diagnostic verifies that the hybrid/EV battery temperature sensor is neither inappropriately high nor low. It compares the sensed battery temperature with an average comprised of other battery temperature sensors. If the absolute value of the difference between the sensed battery temperature and the average is greater than the failure threshold for sufficient time, the diagnostic will fail.	Absolute value of the difference between the temperature input and the average of other battery temperature sensors	> 25.00 ºC	System Voltage Hybrid/EV Battery Temperature Sensor Circuit Low (see Fault Bundle page) Hybrid/EV Battery Temperature Sensor Circuit High (see Fault Bundle page) Loss of Communication with Battery Energy Control Module (see Fault Bundle page)	> 8.10 V No active DTCs No active DTCs No active DTCs	50 failures out of 67 samples 25 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor D Circuit Low	P0AEA	This diagnostic monitors for hybrid/EV battery pack temperature sensor voltage which is out of range low. The temperature sensor this diagnostic is monitoring is a negative temperature coefficient thermistor with a pull-up resistor on the sensing board, meaning a high temperature or sensor short to ground will result in a low sensed voltage. After conversion the sensed temperature is compared against a threshold. If the sensed temperature is above the failure threshold for sufficient time, the diagnostic will fail.	Battery temperature	> 160 C	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor D Circuit High	P0AEB	This diagnostic monitors for high voltage battery pack temperature sensor voltage which is out of range high. The temperature sensor this diagnostic is monitoring is a negative temperature coefficient thermistor with a pull-up resistor on the sensing board, meaning a low temperature or an open circuit will result in a high sensed voltage. After conversion the sensed temperature is compared against a threshold. If the sensed temperature is below the failure threshold for sufficient time, the diagnostic will fail.	Battery temperature	< -69 C	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Temperature Sensor D Circuit Intermittent/ Erratic	P0AEC	This diagnostic monitors for a hybrid/ EV battery temperature sensor voltage which is erratic. An erratic temperature sensor can be caused by an intermittent connection which can be observed by monitoring the integrated absolute value of the change in sensor value over time. If over an evaluation period the integration is greater than a calibratable threshold then this evaluation period fails. If a calibratable number of evaluations fail, the diagnostic will fail.	Integrated absolute value of the change in sensor value in a 10 sample window	> 10	System voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	4 failures out of 5 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery System Voltage Low	P0AFA	This diagnostic monitors for hybrid/EV battery pack voltage too low. It is a system monitor that checks the pack voltage by comparing its value against a battery temperature-dependent threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, battery pack voltage must be above its respective battery temperature-dependent threshold.	Hybrid/EV battery pack voltage	< **KtBSED_U_BUV_PackVoltThresh** (V) - see Supporting Tables	Hybrid/EV Battery Pack Voltage Sensor Fault Active (see Fault Bundle Page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	320 failures out of 400 samples 25 ms /sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery System Voltage High	P0AFB	This diagnostic monitors for hybrid/EV battery pack voltage too high. It is a system monitor that checks the pack voltage by comparing its value against a battery temperature-dependent threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the battery pack voltage must be below its respective battery temperature-dependent threshold.	Hybrid/EV battery pack voltage	> **KtBSED_U_BOV_PackVoltThresh** (V) - see Supporting Tables	Hybrid/EV Battery Pack Voltage Sensor Fault Active (see Fault Bundle Page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	320 failures out of 400 samples 25 ms /sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense A Circuit	P0B3B	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense A Circuit Range/ Performance	P0B3C	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense A Circuit Low	P0B3D	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense A Circuit High	P0B3E	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense B Circuit	P0B40	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense B Circuit Range/ Performance	P0B41	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense B Circuit Low	P0B42	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense B Circuit High	P0B43	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense C Circuit	P0B45	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense C Circuit Range/ Performance	P0B46	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense C Circuit Low	P0B47	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense C Circuit High	P0B48	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense D Circuit	P0B4A	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense D Circuit Range/ Performance	P0B4B	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense D Circuit Low	P0B4C	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense D Circuit High	P0B4D	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense E Circuit	P0B4F	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense E Circuit Range/ Performance	P0B50	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense E Circuit Low	P0B51	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense E Circuit High	P0B52	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense F Circuit	P0B54	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense F Circuit Range/ Performance	P0B55	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense F Circuit Low	P0B56	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense F Circuit High	P0B57	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense G Circuit	P0B59	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense G Circuit Range/ Performance	P0B5A	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense G Circuit Low	P0B5B	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense G Circuit High	P0B5C	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense H Circuit	P0B5E	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense H Circuit Range/ Performance	P0B5F	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense H Circuit Low	P0B60	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense H Circuit High	P0B61	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense I Circuit	P0B63	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense I Circuit Range/ Performance	P0B64	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense I Circuit Low	P0B65	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense I Circuit High	P0B66	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense J Circuit	P0B68	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense J Circuit Range/ Performance	P0B69	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense J Circuit Low	P0B6A	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense J Circuit High	P0B6B	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense K Circuit	P0B6D	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense K Circuit Range/ Performance	P0B6E	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense K Circuit Low	P0B6F	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense K Circuit High	P0B70	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense L Circuit	P0B72	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense L Circuit Range/ Performance	P0B73	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense L Circuit Low	P0B74	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense L Circuit High	P0B75	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense M Circuit	P0B77	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense M Circuit Range/ Performance	P0B78	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense M Circuit Low	P0B79	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense M Circuit High	P0B7A	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense N Circuit	P0B7C	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense N Circuit Range/ Performance	P0B7D	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense N Circuit Low	P0B7E	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense N Circuit High	P0B7F	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense O Circuit	P0B81	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense O Circuit Range/ Performance	P0B82	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense O Circuit Low	P0B83	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense O Circuit High	P0B84	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense P Circuit	P0B86	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense P Circuit Range/ Performance	P0B87	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense P Circuit Low	P0B88	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense P Circuit High	P0B89	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense Q Circuit	P0B8B	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense Q Circuit Range/ Performance	P0B8C	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense Q Circuit Low	P0B8D	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense Q Circuit High	P0B8E	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense R Circuit	P0B90	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense R Circuit Range/ Performance	P0B91	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense R Circuit Low	P0B92	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense R Circuit High	P0B93	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense S Circuit	P0B95	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense S Circuit Range/ Performance	P0B96	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense S Circuit Low	P0B97	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense S Circuit High	P0B98	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense T Circuit	P0B9A	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense T Circuit Range/ Performance	P0B9B	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense T Circuit Low	P0B9C	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense T Circuit High	P0B9D	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense U Circuit	P0B9F	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense U Circuit Range/ Performance	P0BA0	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense U Circuit Low	P0BA1	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense U Circuit High	P0BA2	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense V Circuit	P0BA4	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense V Circuit Range/ Performance	P0BA5	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense V Circuit Low	P0BA6	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense V Circuit High	P0BA7	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense W Circuit	P0BA9	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense W Circuit Range/ Performance	P0BAA	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense W Circuit Low	P0BAB	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense W Circuit High	P0BAC	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense X Circuit	P0BAE	This diagnostic monitors for a hybrid/ EV battery cell voltage sense line resistance which is too high (open circuit). High resistance cell sensing wires affect cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates the cell balancing gates in a test pattern after each normal cell voltage read in order to pull current through the sense wires and detect abnormal resistance. An increase in resistance manifests itself as an increase in voltage drop once the charge-balancing gate is closed. The voltage drop is used in a calculation and converted to resistance. If the resistance is above the failure threshold for sufficient time, the diagnostic will fail.	Calculated cell sense line resistance	> 30.00 Ω	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	7 failures out of 9 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense X Circuit Range/ Performance	P0BAF	This diagnostic verifies that the hybrid/EV cell voltage sensor is not stuck in range. It compares changes in sensed voltage over time with other cell sensed voltages. If sufficient samples elapse with unchanging sensor's voltage while the rest of the cell voltages are trending over time, the diagnostic will fail.	Difference in cell voltage from previous data sample to present data sample	trended at least 0.002 V in the same direction as the average cell voltage trended	System Voltage Absolute difference in calculated average cell voltage from previous cell voltage data sample to present cell voltage data sample Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	> 8.10 V > 0.022 V No active DTCs	35 failures out of 40 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense X Circuit Low	P0BB0	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is too low. It compares the sensed cell voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear until the failure is de-latched by a service technician using the CPID in secondary parameters. To pass, the cell voltage must be above its threshold.	Cell voltage X	< 1.64	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Sense X Circuit High	P0BB1	This diagnostic monitors for hybrid/EV battery cell voltage sensor voltage which is out of range high. It compares the sensed cell voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Cell voltage X	> 4.50 V	Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Pack Cooling Fan Sense Circuit Range/ Performance	P0BC8	The purpose of the performance diagnostic is to detect and report a failure of the feedback circuit. If the enable criteria are met, the speed difference between the commanded speed to the fan feedback speed is calculated. For the fan actuated state (fan ON), the speed difference is filtered and when this filtered difference exceeds the calibrated fault threshold, the diagnostic reports a FAIL. If filtered speed difference does not exceed the calibrated fault threshold, the diagnostic reports a PASS. The diagnostic will continue to report as long as the enablement criteria are met. For the fan non-actuated state (fan OFF), if the feedback speed exceeds the calibrated fault threshold, the diagnostic reports a FAIL. If feedback speed does not exceed the calibrated fault	Fan feedback performance fail in actuated state (fan on) Filtered (Command speed - Feedback speed) OR Filtered (Command speed - Feedback speed)	< **Fan Feedback Fault low Threshold** > **Fan Feedback Fault high Threshold**	System Voltage Cooling Fan Enable Fan Control Commanded Speed Fan ON Time No active DTCs: Run Crank Active Run Crank Active Time No Active DTCs (Run Crank Active Signal)	> 8.10 V = TRUE 11.00 % < Pulse Width Modulation Duty Cycle < 90.00 % > 20.00 seconds P0A81, P0A84, P0A85, P0D64, P0D65, P0D66, P0BC9, P0BCA, P0A9C, P0A9D and P0A9E = TRUE > 1.00 second P2534, P2535	Continuous check every 250ms (Fail time up to 43s depending on the severity of the problem. Speed error of higher magnitude will cause the diagnostic to fail quicker)	Type B, 2 Trips
			If the fan feedback diagnostic fails the actuated state (fan on) Filtered (Command speed - Feedback speed) OR Filtered (Command speed - Feedback speed)	> **Fan Feedback Repass Low Threshold** < **Fan Feedback Repass High Threshold**	System Voltage Cooling Fan Enable Fan Control Commanded Speed Fan ON Time No active DTCs: Run Crank Active Run Crank Active Time No Active DTCs (Run	> 8.10 V = TRUE 11.00 % < Pulse Width Modulation Duty Cycle < 90.00 % > 20.00 seconds P0A81, P0A84, P0A85, P0D64, P0D65, P0D66, P0BC9, P0BCA, P0A9C, P0A9D and P0A9E = TRUE > 1.00 second	Continuous check every 250ms (Repass time up to 43s depending on the severity of the problem. Speed error of lesser magnitude will cause the diagnostic to repass quicker)	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		threshold, the diagnostic reports a PASS. The diagnostic will continue to report as long as the enablement criteria are met.			Crank Active Signal)	P2534, P2535		
			Fan feedback performance fail in non-actuated state (fan off) Fan speed feedback RPM	 > 250.00	System Voltage Cooling Fan Enable Fan OFF Time Fan feedback performance fail in actuated state Run Crank Active Run Crank Active Time No Active DTCs (Run Crank Active Signal)	> 8.10 V = FALSE > 20.00 seconds = FALSE = TRUE > 1.00 second P2534, P2535	24.00 fails / 32.00 samples at 250ms 8 seconds	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Pack Cooling Fan Sensor Circuit Low	P0BC9	This diagnostic detects if the feedback speed is out of range low. If the enable criteria are met and the feedback speed read is below a calibrated threshold, the fail counter will increment. If the calibrated fail count threshold is met before the calibrated sample count, the diagnostic will report a FAIL and if not it will report a PASS. The diagnostic will continue to report as long as the enablement criteria are met.	Fan feedback frequency	< 5.00 Hz	System Voltage Cooling Fan Enable Fan control commanded speed Fan ON Time Run Crank Active Run Crank Active Time No Active DTCs (Run Crank Active Signal)	> 8.10 V = TRUE 11.00 % < Pulse Width Modulation Duty Cycle < 90.00 % > 20.00 seconds = TRUE > 1.00 second P2534, P2535	16.00 fails / 20.00 samples at 250ms 5 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Pack Cooling Fan Sensor Circuit High	P0BCA	This diagnostic detects if the feedback speed is out of range high. If the enable criteria are met and the feedback speed read is above a calibrated threshold, the fail counter will increment. If the calibrated fail count threshold is met before the calibrated sample count, the diagnostic will report a FAIL and if not it will report a PASS. The diagnostic will continue to report as long as the enablement criteria are met.	Fan feedback frequency	> 88.00 HZ	System Voltage Cooling Fan Enable Fan control commanded speed Fan ON Time Run Crank Active Run Crank Active Time No Active DTCs (Run Crank Active Signal)	> 8.10 V = TRUE 11.00 % < Pulse Width Modulation DC< 90.00 % > 20.00 seconds = TRUE > 1.00 second P2534, P2535	16.00 fails / 20.00 samples at 250ms 5 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Pack State of Charge High	P0C30	This diagnostic monitors for high voltage battery state of charge (SOC) which is too high. It monitors the SOC during each driving cycle. At the start of each driving cycle, if the SOC is above the SOC too high threshold, a maximum time is computed that represents, worst case, how much electric motor on time would be necessary in order to get the SOC back into range and below the SOC too high threshold. Once this time expires, the monitor is enabled and will accumulate sample counts. The monitor will accumulate fail counts if the SOC is not in range. The diagnostic will make a single pass/ fail determination at the end of each driving cycle but only if there was sufficient distance accumulated that driving cycle. When driving cycles are too short to make a pass/ fail decision, the fail/ sample counters will be carried over to the next driving cycle so that they are not	SOC	> **KtBSER_Pct_SOC_MaxInit** + 3.00 (see Supporting Tables)	System Voltage (Applicable to this Program/MY: TRUE)	> 8.10 V	Drive cycle complete with total distance driven > 50.00 km AND Ratio of high SOC distance to total distance driven > 0.50	Type A, 1 Trips
					Transmission Shifter Position (Applicable to this Program/MY: FALSE)	!= Neutral		
					Hood Position (Applicable to this Program/MY: TRUE)	!= Open		
					Battery Temperature	>= -10.00 C		
					Vehicle Speed	> 15.00 km/h		
					Re-entry delay surpassed	**KtBSED_Cf_BSH_ReentryDelay** *(SOC - [**KtBSER_Pct_SOC_MaxInit** + 3.00]) (see Supporting Tables)		
					Hybrid/EV Battery Pack Voltage Sensor Fault Active	No active DTCs		
					(see Fault Bundle page) Hybrid/EV Battery Current Sensor Fault Active	No active DTCs		
					(see Fault Bundle page) Hybrid/EV Battery Temperature Sensor Fault Active	No active DTCs		
					(see Fault Bundle page)			
			Pass		System Voltage	> 8.10 V	Drive cycle	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		abandoned. At the end of each driving cycle in which sufficient pass/fail data has been collected, the diagnostic will fail if the ratio of fail counts to sample counts is greater than a failure threshold and will pass otherwise. The diagnostic also can pass more quickly at the end of shorter driving cycles but only if the fail count = 0 (SOC was in range the entire enabled portion of the driving cycle) and sample counts are greater than some minimum fast pass threshold.			(Applicable to this Program/MY: TRUE) Transmission Shifter Position (Applicable to this Program/MY: FALSE) Hood Position (Applicable to this Program/MY: TRUE) Battery Temperature Vehicle Speed Re-entry delay surpassed Hybrid/EV Battery Pack Voltage Sensor Fault Active (see Fault Bundle page) Hybrid/EV Battery Current Sensor Fault Active (see Fault Bundle page) Hybrid/EV Battery Temperature Sensor Fault Active (see Fault Bundle page)	 != Neutral != Open >= -10.00 C > 15.00 km/h **KtBSED_Cf_BSH_ReentryDelay** *(SOC - [**KtBSER_Pct_SOC_MaxInit** + 3.00]) (see Supporting Tables) No active DTCs No active DTCs No active DTCs	complete with total distance driven > 50.00 km AND Ratio of high SOC distance to total distance driven< 0.50	
			Fast Pass		System Voltage (Applicable to this Program/MY: TRUE)	> 8.10 V	Drive cycle complete with total distance driven >	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Transmission Shifter Position (Applicable to this Program/MY: FALSE)	!= Neutral	10.00 km AND Distance driven with high SOC = 0 km	
					Hood Position (Applicable to this Program/MY: TRUE)	!= Open		
					Battery Temperature	>= -10.00 C		
					Vehicle Speed	> 15.00 km/h		
					Re-entry delay surpassed	**KtBSED_Cf_BSH_ReentryDelay** *(SOC - [**KtBSER_Pct_SOC_MaxInit** + 3.00]) (see Supporting Tables)		
					Hybrid/EV Battery Pack Voltage Sensor Fault Active (see Fault Bundle page)	No active DTCs		
					Hybrid/EV Battery Current Sensor Fault Active (see Fault Bundle page)	No active DTCs		
					Hybrid/EV Battery Temperature Sensor Fault Active (see Fault Bundle page)	No active DTCs		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery System Precharge Time Too Long	P0C78	The precharge contactor is used to bring two high voltage circuits to the same voltage so that the propulsion contactors are prevented from damage prior to closing of the propulsion contactors. This DTC sets if the Propulsion Bus Voltage does not get within a percentage band of high voltage battery voltage within a calibratable amount of time during the precharge. If the amount of time expires without reaching the required voltage, then the DTC fails.	Propulsion Bus Voltage	Is not within 95 % of high voltage battery pack voltage at 0.700 seconds from the start of contactor precharge	High Voltage Battery Voltage Sensor Propulsion Bus Voltage Sensor Propulsion Contactor Status	Valid Valid Precharging	Executed Once Per Precharge 0.700 seconds to fail less than 0.700 to pass	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Isolation Sensor Circuit 2 Low	P1E0C	This diagnostic monitors the Hybrid/EV Battery Pack Voltage Isolation Sensor 2 for out of range low. It compares the voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail.	Hybrid/EV Battery Pack Voltage Isolation Sensor 2	< 5 volts	Active Isolation Bias Switch	Commanded Open	320 failures out of 400 samples 12.5 ms /sample 5,000 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Voltage Isolation Sensor Circuit 2 High	P1E0D	This diagnostic monitors the Hybrid/EV Battery Pack Voltage Isolation Sensor 2 for out of range high. It compares the voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Hybrid/EV Battery Pack Voltage Isolation Sensor 2	> 333 volts	Active Isolation Bias Switch	Commanded Open	320 failures out of 400 samples 12.5 ms /sample 5,000 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Interface Control Module A Performance	P1E8E	This diagnostic monitors the battery interface control module for one of four microprocessor performance faults. These performance tests are not continuous monitors and instead each concurrently run once to completion on each run-crank rising or falling edge transition. (ADC digital output when analog input is saturated low) The analog to digital converter output is verified that it does not have any digital bits stuck True by reading the resulting digital value when the analog input is saturated low. The input is saturated low by connecting a negative voltage reference to its analog input. After conversion the sensed voltage is compared against a threshold. If the sensed voltage is above the failure threshold for sufficient time, the test will fail. (ADC digital output when analog input is	ADC digital output when analog input is saturated low	> 0.08 V	System Voltage Run Crank transition Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V True -> False, OR False -> True No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips
			ADC digital output when analog input is saturated high	< 4.93 V	System Voltage Run Crank transition Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V True -> False, OR False -> True No active DTCs	8 failures out of 10 samples 100 ms /sample	
			Absolute value of the difference between cell voltage input and balancing switch input	> 0.10 V	System Voltage Run Crank transition Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V True -> False, OR False -> True No active DTCs	13 failures out of 15 samples 100 ms /sample	
			Voltage movement of cell voltage input under test Voltage movement of cell voltage inputs not under test	< 0.05 V > 0.05 V	System Voltage Run Crank transition Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V True -> False, OR False -> True No active DTCs No active DTCs	1 test to pass (300ms) 6 consecutive attempts to fail (1.8s)	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		saturated high) The analog to digital converter output is verified that it does not have any digital bits stuck False by reading the resulting digital value when the analog input is saturated high. The input is saturated high by connecting its analog input to a voltage source which is greater than its voltage reference. After conversion the sensed voltage is compared against a threshold. If the sensed voltage is above the failure threshold for sufficient time, the test will fail. (Absolute value of the difference between cell voltage input and balancing switch input) The battery cell voltage sensing inputs are connected to high ohmage filter resistors. It takes very little parasitic current to create a voltage drop across the high resistance filter. This voltage drop will change the sensed voltage of the cell. Each cell voltage input is monitored for parasitic current			Hybrid/EV Battery Cell Voltage Sensor Circuit Low (see Fault Bundle page) Hybrid/EV Battery Cell Voltage Sensor Circuit High (see Fault Bundle page) Hybrid/EV Battery Cell Voltage Sensor Circuit Open (see Fault Bundle page)	No active DTCs No active DTCs		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		inducing a inappropriately large voltage drop. In order to ensure that the sensed voltage isn't too affected by parasitic current we compare the battery cell voltage sensing inputs to the voltage read through the cell balancing switch inputs when the balancing switch is open. The balance switch path has no high ohmage filter resistor and thus is less impacted by parasitic current. If the absolute difference between the voltage sensed through the regular cell voltage sense inputs and the cell balancing switch inputs is above the failure threshold for sufficient time, the test will fail. (Voltage movement of cell voltage input under test/ Voltage movement of cell voltage inputs not under test) The battery interface control module employs a multiplexer on the cell voltage sensing inputs to need only one analog to digital converter to sense all of the battery						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		cell voltages. The multiplexer may malfunction by no longer switching between the different cell voltage inputs. This would cause some battery cell voltages to go unsensed even though it does not appear so. The correct operation of the MUX is verified by using a sense wire specific current source to intrusively alter the voltage of each battery sense input in a predefined pattern. During this intrusive mode the cell voltages are monitored to verify every battery cell voltage can be observed. If a cell voltage is not altered when it should be, or is altered when it should not be, then the multiplexer is considered broken. Upon failure the test is retried a calibrated number of times. If the calibrated number of retries is exceded, the test will fail. If any of these tests fail, the diagnostic will fail. If all of these tests pass, the diagnostic will pass.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Interface Control Module A Cell Balancing Circuit	P1E92	This diagnostic monitors for a hybrid/ EV battery cell balancing gate stuck open or closed. A cell balancing gate stuck open or closed affects cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates on the periodic input received from the hybrid/EV battery cell voltage sensors, while the cell charge-balancing gates are enabled in either an “all odd-numbered gates on” or an “all even-numbered gates on” pattern. It uses these periodic cell voltage readings, as well as the normal cell voltage readings, to create a balancing circuit ratio. If the ratio is above the failure threshold for sufficient time, the diagnostic will fail.	(Cell voltage with balancing switch closed) / (Cell voltage with balancing switch open)	> 0.80	System Voltage Hybrid/EV Battery Cell Voltage Sensor Circuit Open (see Fault Bundle page) Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs No active DTCs	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Interface Control Module A Reference Voltage	P1E93	This diagnostic verifies that the primary battery interface control module reference voltage is neither biased inappropriately high nor low. The diagnostic senses a known voltage source (band-gap voltage source) and verifies that the sensed value is within its expected range in a non failure mode. If the sensed value is outside of the expected range for sufficient time, the diagnostic will fail.	Sensed band-gap voltage	< 1.10 V OR > 1.38 V	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Interface Control Module B Performance	P1E94	This diagnostic monitors the battery interface control module for one of four microprocessor performance faults. These performance tests are not continuous monitors and instead each concurrently run once to completion on each run-crank rising or falling edge transition. (ADC digital output when analog input is saturated low) The analog to digital converter output is verified that it does not have any digital bits stuck True by reading the resulting digital value when the analog input is saturated low. The input is saturated low by connecting a negative voltage reference to its analog input. After conversion the sensed voltage is compared against a threshold. If the sensed voltage is above the failure threshold for sufficient time, the test will fail. (ADC digital output when analog input is	ADC digital output when analog input is saturated low	> 0.08 V	System Voltage Run Crank transition Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V True -> False, OR False -> True No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips
			ADC digital output when analog input is saturated high	< 4.93 V	System Voltage Run Crank transition Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V True -> False, OR False -> True No active DTCs	8 failures out of 10 samples 100 ms /sample	
			Absolute value of the difference between cell voltage input and balancing switch input	> 0.10 V	System Voltage Run Crank transition Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V True -> False, OR False -> True No active DTCs	13 failures out of 15 samples 100 ms /sample	
			Voltage movement of cell voltage input under test Voltage movement of cell voltage inputs not under test	< 0.05 V > 0.05 V	System Voltage Run Crank transition Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V True -> False, OR False -> True No active DTCs No active DTCs	1 test to pass (300ms) 6 consecutive attempts to fail (1.8s)	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		saturated high) The analog to digital converter output is verified that it does not have any digital bits stuck False by reading the resulting digital value when the analog input is saturated high. The input is saturated high by connecting its analog input to a voltage source which is greater than its voltage reference. After conversion the sensed voltage is compared against a threshold. If the sensed voltage is above the failure threshold for sufficient time, the test will fail. (Absolute value of the difference between cell voltage input and balancing switch input) The battery cell voltage sensing inputs are connected to high ohmage filter resistors. It takes very little parasitic current to create a voltage drop across the high resistance filter. This voltage drop will change the sensed voltage of the cell. Each cell voltage input is monitored for parasitic current			Hybrid/EV Battery Cell Voltage Sensor Circuit Low (see Fault Bundle page) Hybrid/EV Battery Cell Voltage Sensor Circuit High (see Fault Bundle page) Hybrid/EV Battery Cell Voltage Sensor Circuit Open (see Fault Bundle page)	No active DTCs No active DTCs		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		inducing a inappropriately large voltage drop. In order to ensure that the sensed voltage isn't too affected by parasitic current we compare the battery cell voltage sensing inputs to the voltage read through the cell balancing switch inputs when the balancing switch is open. The balance switch path has no high ohmage filter resistor and thus is less impacted by parasitic current. If the absolute difference between the voltage sensed through the regular cell voltage sense inputs and the cell balancing switch inputs is above the failure threshold for sufficient time, the test will fail. (Voltage movement of cell voltage input under test/ Voltage movement of cell voltage inputs not under test) The battery interface control module employs a multiplexer on the cell voltage sensing inputs to need only one analog to digital converter to sense all of the battery						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		cell voltages. The multiplexer may malfunction by no longer switching between the different cell voltage inputs. This would cause some battery cell voltages to go unsensed even though it does not appear so. The correct operation of the MUX is verified by using a sense wire specific current source to intrusively alter the voltage of each battery sense input in a predefined pattern. During this intrusive mode the cell voltages are monitored to verify every battery cell voltage can be observed. If a cell voltage is not altered when it should be, or is altered when it should not be, then the multiplexer is considered broken. Upon failure the test is retried a calibrated number of times. If the calibrated number of retries is exceded, the test will fail. If any of these tests fail, the diagnostic will fail. If all of these tests pass, the diagnostic will pass.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Battery Interface Control Module B Cell Balancing Circuit	P1E98	This diagnostic monitors for a hybrid/ EV battery cell balancing gate stuck open or closed. A cell balancing gate stuck open or closed affects cell voltage sensing as well as the effectiveness of the charge-balancing functionality. The diagnostic operates on the periodic input received from the hybrid/EV battery cell voltage sensors, while the cell charge-balancing gates are enabled in either an “all odd-numbered gates on” or an “all even-numbered gates on” pattern. It uses these periodic cell voltage readings, as well as the normal cell voltage readings, to create a balancing circuit ratio. If the ratio is above the failure threshold for sufficient time, the diagnostic will fail.	(Cell voltage with balancing switch closed) / (Cell voltage with balancing switch open)	> 0.80	System Voltage Hybrid/EV Battery Cell Voltage Sensor Circuit Open (see Fault Bundle page) Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs No active DTCs	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Interface Control Module B Reference Voltage	P1E99	This diagnostic verifies that the primary battery interface control module reference voltage is neither biased inappropriately high nor low. The diagnostic senses a known voltage source (band-gap voltage source) and verifies that the sensed value is within its expected range in a non failure mode. If the sensed value is outside of the expected range for sufficient time, the diagnostic will fail.	Sensed band-gap voltage	< 1.10 V OR > 1.38 V	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Energy Control Module Hybrid/EV Battery Cell Overvoltage	P1EAB	This diagnostic monitors for hybrid/EV battery cell voltage too high. It is a system monitor that checks each cell's voltage by comparing their values collected using a secondary cell voltage sensing system against a calibratable threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear and must be cleared by a service technician using the CPID in secondary parameters. To pass all cell voltages must be below the threshold.	Cell Voltage	> 4.5 V	System Voltage Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	> 8.10 V No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	80 failures out of 100 samples 25 ms /sample	Type A, 1 Trips
			Any battery interface control module response to request to NOT test overvoltage signal	= Overvoltage signal detected	Inverter voltage System Voltage Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) Run Crank Transitions to DTC Clear: Must Send CPID	> 48 V > 8.10 V No active DTCs = ON for > 200 samples, at 25 ms / sample 0x7E4 07 AE 32 0C 0C 00 00 00	80 failures out of 80 samples 25 ms /sample	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Cell Overvoltage Signal/ Circuit Performance	P1EAC	This diagnostic monitors the battery interface control module's secondary voltage sensing system for its ability to detect a voltage which is too high. Each battery interface control module has the ability to enter an over voltage performance test where it applies a high voltage on its secondary voltage sensing input. These performance tests are not continuous monitors and instead are run once to completion on each run-crank rising edge transition. Upon failure the test is retried a calibrated number of times. If the calibrated number of retries is exceeded, the test will fail. If any of these tests fail, the diagnostic will fail. If all of these tests pass, the diagnostic will pass.	Any battery interface control module response to request to test overvoltage signal	= Overvoltage signal not detected > 400 samples, at 25 ms / sample	Run Crank Transitions to Inverter voltage System Voltage Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	= ON for > 200 samples, at 25 ms / sample > 48 V > 8.10 V No active DTCs	Failure after 4 retries without a pass	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Interface Control Module A Cell Overvoltage Signal/ Circuit Performance	P1EAD	This diagnostic monitors the battery interface control module's secondary voltage sensing system for its ability to detect a voltage which is too high. Each battery interface control module has the ability to enter an over voltage performance test where it applies a high voltage on its secondary voltage sensing input. These performance tests are not continuous monitors and instead are run once to completion on each run-crank rising edge transition. Upon failure the test is retried a calibrated number of times. If the calibrated number of retries is exceeded, the test will fail. If any of these tests fail for this module, the diagnostic will fail. If all of these tests for this module pass, the diagnostic will pass.	Any response from this battery interface control module to the request to test the overvoltage signal	= Overvoltage signal not detected > 400 samples, at 25 ms / sample	Run Crank Transitions to Inverter voltage System Voltage Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	= ON for > 200 samples, at 25 ms / sample > 48 V > 8.10 V No active DTCs	Failure after 4 retries without a pass	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Interface Control Module B Cell Overvoltage Signal/ Circuit Performance	P1EAE	This diagnostic monitors the battery interface control module's secondary voltage sensing system for its ability to detect a voltage which is too high. Each battery interface control module has the ability to enter an over voltage performance test where it applies a high voltage on its secondary voltage sensing input. These performance tests are not continuous monitors and instead are run once to completion on each run-crank rising edge transition. Upon failure the test is retried a calibrated number of times. If the calibrated number of retries is exceeded, the test will fail. If any of these tests fail for this module, the diagnostic will fail. If all of these tests for this module pass, the diagnostic will pass.	Any response from this battery interface control module to the request to test the overvoltage signal	= Overvoltage signal not detected > 400 samples, at 25 ms / sample	Run Crank Transitions to Inverter voltage System Voltage Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page)	= ON for > 200 samples, at 25 ms / sample > 48 V > 8.10 V No active DTCs	Failure after 4 retries without a pass	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Pack Current Sensor A Exceeded Learning Limit	P1EBA	The hybrid/EV battery current is measured using a Hall-effect current sensor. This diagnostic monitor verifies that the battery current sensor output voltage is neither biased inappropriately high nor low. The current sensor bias is calculated upon controller initialization when the battery contactors are open to guarantee zero current. After the bias is calculated it is compared against zero. If the absolute current bias is above the failure threshold the diagnostic will fail.	Absolute value of the current sensor bias	> 8.00 A	System Voltage High Voltage Contactor Status Charger Contactor Status No active DTCs Runs once immediately upon each controller initilization	> 8.10 V Open Open P0AC2, P0AC1	200 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery System Contactor(s) Stuck Open	P1EC0	This DTC determines if the propulsion system contactors have opened by comparing propulsion bus voltage to high voltage battery voltage during propulsion.	Propulsion Bus Voltage	< 80 % of High Voltage Battery Voltage	Propulsion Positive Contactor Propulsion Negative Contactor Propulsion Bus Voltage High Voltage Battery Voltage 12V Battery Voltage	Closed Closed Not Faulted Not Faulted > 8.1 V	3 failures out of 6 samples 12.5 ms /sample 75 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System Isolation / Impact Sensor Fault - Hybrid Battery System Contactors Open	P1F17	When the Air Bag Module detects that a crash has occurred, it requests the HPC2 to latch open all high voltage contactors for safety reasons. When the Air Bag Module is faulty and a high voltage isolation fault is present, for safety reasons it is assumed that a vehicle crash has occurred. This DTC detects when these faults have occurred and contactors are latched open for safety reasons.	Control Module Hybrid Battery Voltage System Isolation Fault (P1AF0,P1AF2, or P1E22)in HPC1	Active	Rollover or Airbag or Inertial Sensors Run/Crank	Not working ON	25 ms Once set, this DTC cannot pass. DTC passes when latch is not set.	Type A, 1 Trips
			Control Module Hybrid Battery Voltage System Isolation Fault (P1AF0,P1AF2, or P1E22)in HPC1	Active	Lost Communication with Inflatable Restraint Sensing and Diagnostic Module on Bus F (U184E) Run/Crank	Active ON	25 ms Once set, this DTC cannot pass. DTC passes when latch is not set.	
			Lost Comm with HPC1	Active	Lost Communication with Inflatable Restraint Sensing and Diagnostic Module on Bus F (U184E) Run/Crank	Active ON	25 ms Once set, this DTC cannot pass. DTC passes when latch is not set.	
			Lost Comm with HPC1 DTC Clear	Active Must Send CPID	Rollover or Airbag or Inertial Sensors Run/Crank 0x7E4 07 AE 32 01 01	Not working ON	25 ms Once set, this DTC cannot pass. DTC passes when latch is not set.	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Interface Control Module A Voltage Sensor Circuit Low	P1FD5	The battery interface control module monitors the voltage of a group of hybrid/EV battery cells in series contained in a battery module. This diagnostic monitors for hybrid/EV battery pack module voltage sensor voltage which is out of range low. It compares the module voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail.	Battery interface control module voltage	< 2.00 V	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Interface Control Module B Voltage Sensor Circuit Low	P1FD6	The battery interface control module monitors the voltage of a group of hybrid/EV battery cells in series contained in a battery module. This diagnostic monitors for hybrid/EV battery pack module voltage sensor voltage which is out of range low. It compares the module voltage against a threshold. If the voltage is below the failure threshold for sufficient time, the diagnostic will fail.	Battery interface control module voltage	< 2.00 V	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Interface Control Module A Voltage Sensor Circuit High	P1FDF	The battery interface control module monitors the voltage of a group of hybrid/EV battery cells in series contained in that battery module. This diagnostic monitors for hybrid/EV battery pack module voltage sensor voltage which is out of range high. It compares the module voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Battery interface control module voltage	> 58.80 V	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Interface Control Module B Voltage Sensor Circuit High	P1FE0	The battery interface control module monitors the voltage of a group of hybrid/EV battery cells in series contained in that battery module. This diagnostic monitors for hybrid/EV battery pack module voltage sensor voltage which is out of range high. It compares the module voltage against a threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail.	Battery interface control module voltage	> 58.80 V	System Voltage Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs	8 failures out of 10 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Interface Control Module A Voltage Sensor Circuit Range/ Performance	P1FE9	The battery interface control module monitors the voltage of a group of hybrid/EV battery cells in series. This diagnostic verifies that the hybrid/EV battery pack module voltage sensor is neither inappropriately high nor low. It compares the sensed module voltage with the sum of the battery cell voltages within that module. If the absolute value of the difference between the sensed module voltage and the sum of the relevant battery cell voltages is greater than the failure threshold for sufficient time, the diagnostic will fail.	Absolute value of the difference between the module voltage and the sum of the battery cell voltages within that module	> 0.30 V	System Voltage Hybrid/EV Battery Cell Voltage Sensor Circuit Low (see Fault Bundle page) Hybrid/EV Battery Cell Voltage Sensor Circuit High (see Fault Bundle page) Hybrid/EV Battery Cell Voltage Sensor Circuit Open (see Fault Bundle page) Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs No active DTCs No active DTCs No active DTCs	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Interface Control Module B Voltage Sensor Circuit Range/ Performance	P1FEA	The battery interface control module monitors the voltage of a group of hybrid/EV battery cells in series. This diagnostic verifies that the hybrid/EV battery pack module voltage sensor is neither inappropriately high nor low. It compares the sensed module voltage with the sum of the battery cell voltages within that module. If the absolute value of the difference between the sensed module voltage and the sum of the relevant battery cell voltages is greater than the failure threshold for sufficient time, the diagnostic will fail.	Absolute value of the difference between the module voltage and the sum of the battery cell voltages within that module	> 0.30 V	System Voltage Hybrid/EV Battery Cell Voltage Sensor Circuit Low (see Fault Bundle page) Hybrid/EV Battery Cell Voltage Sensor Circuit High (see Fault Bundle page) Hybrid/EV Battery Cell Voltage Sensor Circuit Open (see Fault Bundle page) Loss of Communication with Battery Interface Control Module (see Fault Bundle page)	> 8.10 V No active DTCs No active DTCs No active DTCs No active DTCs	28 failures out of 35 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Switch Run/ Start Position Circuit Low	P2534	Detects Run/Crank open circuit	Run Crank Line Voltage	< 2 volts	CAN Communication ECM Run/Crank Active Data	Enabled Available and Active	10 failed samples within 20 samples 1 sample every 250 ms 5000 ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Switch Run/ Start Position Circuit High	P2535	Detects Run/Crank Circuit High	Run Crank Line Voltage	> 5 volts	CAN Communication ECM Run/Crank Active Data	Enabled Available and False	10 failed samples within 20 samples 1 sample every 250 ms 5000 ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Hood Switch Performance	P257D	Detects if the Vehicle Hood Switch is in an Electrically Invalid Range (Rationality Check)	Hood Switch Position Sensor reading within an invalid range	Within the following ranges: 67.80 % < reading <= 71.50 % 43.40 % < reading <= 45.70 % 14.60 % < reading <= 17.20 %	Battery System in Range	= TRUE	80 failed samples within 100 samples 1 sample every 12.5ms 1250 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Hood Switch Circuit Low Voltage	P257E	Detects if the Vehicle Hood Switch is Shorted to Ground	Hood Switch Position Sensor reading below a threshold	<= 14.60 %	Battery System in Range	= TRUE	80 failed samples within 100 samples 1 sample every 12.5ms 1250 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Hood Switch Circuit High Voltage	P257F	Detects if the Vehicle Hood Switch is Shorted to Battery	Hood Switch Position Sensor reading above a threshold	>= 71.50 %	Battery System in Range	= TRUE	80 failed samples within 100 samples 1 sample every 12.5ms 1250 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Off Timer Performance	P262B	Detects a fault in the internal Control Module off-timer	The absolute value of the difference between the Control Module 'Off' Timer and Control Module 'On' Timer exceeds a threshold percentage	0.056 * Off Timer	Diagnostic Enabled RunCrank 'On' Time DTCs Not Active	= TRUE > 60 seconds P0601, P0602, P0603, P062F, P0604 and P0606	Runs once per drive cycle (when Run/ Crank transitions from TRUE to FALSE).	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Precharge Current Too High	P3061	This DTC sets if battery current remains over a threshold during precharge for a calibratable amount of time.	High Voltage Battery Current	> 6.00 Amperes	High Voltage Battery Current High Voltage Battery Voltage Contactor Status OR Charger Contactor Status	Not Faulted Not Faulted Precharging	7 consecutive failed samples 12.5 ms /sample 87.50 ms to Fail Successful Precharge to Pass	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Interface Control Module A Cell Overvoltage	P3240	This diagnostic monitors for hybrid/EV battery cell voltage too high. It is a system monitor that checks each cell's voltage in this module by comparing their values collected using a secondary cell voltage sensing system against a calibratable threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear and must be cleared by a service technician using the CPID in secondary parameters. To pass all cell voltages in this module must be below the threshold.	Cell Voltage	> 4.5 V	System Voltage Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	> 8.10 V No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	80 failures out of 100 samples 25 ms /sample	Type A, 1 Trips
			Any response from this battery interface control module to request to NOT test the overvoltage signal	= Overvoltage signal detected	Inverter voltage System Voltage Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) Run Crank Transitions to DTC Clear: Must Send CPID	> 48 V > 8.10 V No active DTCs = ON for > 200 samples, at 25 ms / sample 0x7E4 07 AE 32 0C 0C 00 00 00	80 failures out of 80 samples 25 ms /sample	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid/EV Battery Interface Control Module B Cell Overvoltage	P3241	This diagnostic monitors for hybrid/EV battery cell voltage too high. It is a system monitor that checks each cell's voltage in this module by comparing their values collected using a secondary cell voltage sensing system against a calibratable threshold. If the voltage is above the failure threshold for sufficient time, the diagnostic will fail. For safety reasons, failures of this DTC cannot be cleared with a code clear and must be cleared by a service technician using the CPID in secondary parameters. To pass all cell voltages in this module must be below the threshold.	Cell Voltage	> 4.5 V	System Voltage Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) DTC Clear: Must Send CPID	> 8.10 V No active DTCs 0x7E4 07 AE 32 0C 0C 00 00 00	80 failures out of 100 samples 25 ms /sample	Type A, 1 Trips
			Any response from this battery interface control module to request to NOT test the overvoltage signal	= Overvoltage signal detected	Inverter voltage System Voltage Hybrid/EV Battery Cell Voltage Sensor Fault Active (see Fault Bundle page) Run Crank Transitions to DTC Clear: Must Send CPID	> 48 V > 8.10 V No active DTCs = ON for > 200 samples, at 25 ms / sample 0x7E4 07 AE 32 0C 0C 00 00 00	80 failures out of 80 samples 25 ms /sample	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communication Bus A Off	U0073	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off state.	CAN Controller Interface in a Bus off state	= TRUE	Controller On ECU is sending / receiving on CAN (Battery Voltage OR Battery Voltage transition from to for time required)	= TRUE = TRUE >= 8.10 V <= 8.10 V >= 8.50 V >= 5,000 ms	5 failures out of 5 samples 1 s loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communication Bus B Off	U0074	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off state.	CAN Controller interface in a Bus off state	= TRUE	Controller On ECU is sending/recieving on CAN (Battery Voltage OR Battery Voltage transition from to for time required)	= TRUE = TRUE >= 8.10 V <= 8.10 V >= 8.50 V >= 5,000 ms	5 failures out of 5 samples 1 s loop	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With ECM on Bus A	U0100	Detects that CAN serial data communication has been lost with the ECM on Bus A	Messages have not been received from the ECM for a specified time	≥ 500ms	Controller On Bus A Communication Enabled Bus A Off Inhibit (Battery Voltage OR Battery Voltage transition from to for time required)	= TRUE >= 5 seconds =FALSE >= 8.10 V <= 8.10 V >= 8.50 V >= 5,000 ms	Runs in 10 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication with Transmission Control Module	U0101	Detects that CAN serial data communication has been lost with the TCM on Bus A	Messages have not been received from the TCM for a specified time	≥ 1500ms	Controller On Bus A Communication Enabled Bus A Off Inhibit (Battery Voltage OR Battery Voltage transition from to for time required)	= TRUE >= 5 seconds =FALSE >= 8.10 V <= 8.10 V >= 8.50 V >= 5,000 ms	Runs in 10ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication with Hybrid/EV Battery Interface Control Module A	U01A0	This diagnostic monitors the UART bus communication status between the battery systems module (BSM) and the battery interface control modules (BICM). The diagnostic monitors BICM data availability whenever the communications bus is active. The communication network between BICMs and BSM is in a daisy-chain architecture, therefore a break at any point in the communication bus results in a loss of BICM communication with the BSM. If any data is received the diagnostic will report a pass. If no data is received for greater than a calibratable amount of time the BSM will attempt to initiate the BICMs into a communications mode where the BICMs can perform their own internal communications loop back, bypassing the daisy-chain. If this is the first BICM in the daisy-chain that the BSM cannot reestablish	Intrusive test performed upon failure of DTC U179C indicated that this is the first BICM in the communication chain with which the BSM cannot regain communication with		Active DTCs	U179C	100 ms	Type B, 2 Trips
			(DTC Pass) Instrusive test performed upon failure of DTC U179C can re-establish communication with this BICM		Active DTCs	U179C	100 ms	
			(DTC Pass) U179C Pass				100 ms	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		communication with, this diagnostic will fail.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication with Hybrid/EV Battery Interface Control Module B	U01A1	This diagnostic monitors the UART bus communication status between the battery systems module (BSM) and the battery interface control modules (BICM). The diagnostic monitors BICM data availability whenever the communications bus is active. The communication network between BICMs and BSM is in a daisy-chain architecture, therefore a break at any point in the communication bus results in a loss of BICM communication with the BSM. If any data is received the diagnostic will report a pass. If no data is received for greater than a calibratable amount of time the BSM will attempt to initiate the BICMs into a communications mode where the BICMs can perform their own internal communications loop back, bypassing the daisy-chain. If this is the first BICM in the daisy-chain that the BSM cannot reestablish	Intrusive test performed upon failure of DTC U179C indicated that this is the first BICM in the communication chain with which the BSM cannot regain communication with		Active DTCs	U179C	100 ms	Type B, 2 Trips
			(DTC Pass) Instrusive test performed upon failure of DTC U179C can re-establish communication with this BICM		Active DTCs	U179C	100 ms	
			(DTC Pass) U179C Pass				100 ms	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		communication with, this diagnostic will fail.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Hybrid Powertrain Control Module	U0293	Detects that CAN serial data communication has been lost with the Hybrid Powertrain Control Module on Bus A	Messages have not been received from the HCP for a specified time	≥ 500ms	Controller On Bus A Communication Enabled Bus A Off Inhibit (Battery Voltage OR Battery Voltage transition from to for time required)	= TRUE >= 5 seconds =FALSE >= 8.10 V <= 8.10 V >= 8.50 V >= 5,000 ms	Runs in 10ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication with One or More Hybrid/EV Battery Interface Control Modules	U179C	This diagnostic monitors the UART bus communication status between the battery systems module (BSM) and the battery interface control modules (BICM). The diagnostic monitors BICM data availability whenever the communications bus is active. The communication network between BICMs and BSM is in a daisy-chain architecture, therefore a break at any point in the communication bus results in a loss of BICM communication with the BSM. If any data is received the diagnostic will report a pass. If no data is received for greater than a calibratable amount of time the diagnostic will fail.	Communication unavailable with one or more BICMs				45.00 consecutive failures 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication with Hybrid Powertrain Control Module on Bus B	U1817	Detects that CAN serial data communication has been lost with the Hybrid Powertrain Control Module on Bus B	Messages have not been received from the HCP for a specified time	≥ 500ms	Controller On Bus B Communication Enabled Bus B Off Inhibit (Battery Voltage OR Battery Voltage transition from to for time required)	=TRUE >= 5 seconds =FALSE >= 8.10 V <= 8.10 V >= 8.50 V >= 5,000 ms	Runs in 10ms loop	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With ECM on Bus B	U1818	Detects that CAN serial data communication has been lost with the ECM on Bus B	Messages have not been received from the ECM for a specified time	≥ 500ms	Controller On Bus B Communication Enabled Bus B Off Inhibit (Battery Voltage OR Battery Voltage transition from to for time required)	=TRUE >= 5 seconds =FALSE >= 8.10 V <= 8.10 V >= 8.50 V >= 5,000 ms	Runs in 10ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Improper Wake-up Performance	U3012	Control Module Wake-up Circuit Performance (Self Wakeup Fault)	Scheduled self wakeup	= did not occur			Runs once at powerup if a Self Wakeup request was active last power down	Type B, 2 Trips

Initial Supporting table - Fan Feedback Fault high Threshold

Description:

y/x	10	11	20	30	40	50	60	70	80	90
1	760	760	847	1,068	1,290	1,509	1,734	1,961	2,128	2,359

Initial Supporting table - Fan Feedback Fault low Threshold

Description:

y/x	10	11	20	30	40	50	60	70	80	90
1	-900	-900	-900	-900	-900	-900	-900	-900	-900	-900

Initial Supporting table - Fan Feedback Repass High Threshold

Description:

y/x	10	11	20	30	40	50	60	70	80	90
1	608	608	678	854	1,032	1,207	1,387	1,569	1,702	1,887

Initial Supporting table - Fan Feedback Repass Low Threshold

Description:

y/x	10	11	20	30	40	50	60	70	80	90
1	-720	-720	-720	-720	-720	-720	-720	-720	-720	-720

Initial Supporting table - KtBSED_Cf_BSH_ReentryDelay

Description:

y/x	-30	-20	-10	0	10	20	30	40	50
1	0	0	0	0	0	0	0	0	0

Initial Supporting table - KtBSED_Cf_BSL_ReentryDelay

Description:

y/x	-30	-20	-10	0	10	20	30	40	50
1	0	0	0	0	0	0	0	0	0

Initial Supporting table - KtBSED_P_BPD_C_EndOfLifePwrThrsh

Description:

y/x	-30	-20	-10	0	20	30	50
10	0.87	1.81	3.84	6.86	11.00	11.00	11.00
20	0.67	1.42	3.03	5.41	11.00	11.00	11.00
30	0.61	1.29	2.82	5.10	11.00	11.00	11.00
50	0.50	1.09	2.41	4.34	9.49	11.00	11.00
70	0.34	0.76	1.69	3.04	6.63	9.65	10.50
80	0.25	0.55	1.22	2.21	4.83	6.93	7.47
90	0.14	0.31	0.68	1.24	2.74	3.91	4.22

Initial Supporting table - KtBSED_P_BPD_C_MinPassPowerThrsh

Description:

y/x	-30	-20	-10	0	20	30	50
10	0.87	1.81	3.84	6.86	11.00	11.00	11.00
20	0.67	1.42	3.03	5.41	11.00	11.00	11.00
30	0.61	1.29	2.82	5.10	11.00	11.00	11.00
50	0.50	1.09	2.41	4.34	9.49	11.00	11.00
70	0.34	0.76	1.69	3.04	6.63	9.65	10.50
80	0.25	0.55	1.22	2.21	4.83	6.93	7.47
90	0.14	0.31	0.68	1.24	2.74	3.91	4.22

Initial Supporting table - KtBSED_P_BPD_D_EndOfLifePwrThrsh

Description:

y/x	-30	-20	-10	0	20	30	50
10	-0.75	-1.26	-2.28	-3.74	-6.18	-10.42	-10.50
20	-0.90	-1.59	-2.97	-5.05	-9.09	-10.50	-10.50
30	-0.97	-1.76	-3.35	-5.73	-10.50	-10.50	-10.50
50	-1.08	-2.04	-3.92	-6.66	-10.50	-10.50	-10.50
70	-1.20	-2.30	-4.44	-7.53	-10.50	-10.50	-10.50
80	-1.27	-2.43	-4.70	-7.99	-10.50	-10.50	-10.50
90	-1.32	-2.54	-4.92	-8.40	-10.50	-10.50	-10.50

Initial Supporting table - KtBSED_P_BPD_D_MinPassPowerThrsh

Description:

y/x	-30	-20	-10	0	20	30	50
10	-0.75	-1.26	-2.28	-3.74	-6.18	-10.42	-10.50
20	-0.90	-1.59	-2.97	-5.05	-9.09	-10.50	-10.50
30	-0.97	-1.76	-3.35	-5.73	-10.50	-10.50	-10.50
50	-1.08	-2.04	-3.92	-6.66	-10.50	-10.50	-10.50
70	-1.20	-2.30	-4.44	-7.53	-10.50	-10.50	-10.50
80	-1.27	-2.43	-4.70	-7.99	-10.50	-10.50	-10.50
90	-1.32	-2.54	-4.92	-8.40	-10.50	-10.50	-10.50

Initial Supporting table - KtBSER_Pct_SOC_MaxInit

Description:

y/x	1	3	4	4	4	4	4	4	5
1	60	60	60	60	60	60	60	60	60

Initial Supporting table - KtBSED_U_BOV_PackVoltThresh

Description:

y/x	-30	-20	-10	0	10	20	30	40	50
1	108.00	108.00	108.00	108.00	108.00	108.00	108.00	108.00	108.00

Initial Supporting table - KtBSED_U_BUV_PackVoltThresh

Description:

y/x	-30	-20	-10	0	10	20	30	40	50
1	39.46	39.46	39.46	39.46	39.46	43.15	43.15	43.15	43.15