

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
Transmission Electro-Hydraulic Control Module Read Only Memory	P0601	EPROM/Flash memory corruption (Incorrect program/calibrations checksum)	ROM test fail count ≥ 5	Ignition is On	Immediate Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Transmission Electro-Hydraulic Control Module Not Programmed	P0602	Non-programmed TEHCM (calibrations)	KeMEMD_b_NoStartCal=TRUE	Ignition is On	Immediate Continuous	None	A
Transmission Electro-Hydraulic Control Module Long-Term Memory Reset	P0603	Wrong copy of Non-volatile Memory to RAM	Non-volatile memory (static or dynamic) checksum failure	Ignition is On	Immediate Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Transmission Electro-Hydraulic Control Module Random Access Memory	P0604	RAM failure	RAM read/write failure (single word) RAM test fail count ≥ 5	Ignition is On	Immediate Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Transmission Electro-Hydraulic Control Module Long Term Memory Performance	P062F	NVM write error at key-down	TCM Non-Volatile Memory Incorrect flag = 1	Ignition voltage enable Ignition ON	Immediate Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Transmission Electro-Hydraulic Control Module Internal Temperature Too High	P0634	DTC detects the electronic circuitry is at high operating temperature	substrate temperature ≥ 146.3 DegC for time ≥ 5.0 sec	Ignition enable $0.0 \text{ DegC} \leq \text{substrate temperature} \leq 240 \text{ DegC}$ for time ≥ 0.25 sec P0634 not FA AND TFTKO	Time > 5 seconds Continuous	CeTRND_DSG_DfltGearOpt1Action, CeTRND_DSG_TCM_ShutdownAction, CeTRND_TorqMgntInhbAction, CeTRND_TUTD_InhAction (FA)	A

Common engine speed enable: 500 RPM \leq engine speed \leq 5800 RPM for time ≥ 5.0 seconds
 Common ignition voltage enable: 8.6 volts \leq ignition voltage \leq 19.0 volts
 Common vehicle speed enable: 5.0 KPH \leq vehicle speed for time ≥ 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
TCM internal temperature thermistor failed at a constant value or toggling at high frequency.	P0667	DTC Detects Substrate Sensor Performance Error	fail case 1 or fail case 2 or fail case 3 independently fail fail case 1: vehicle speed >= 8 KPH for time >= 300 seconds cumulative, TCC slip > 120 RPM for time >= 300 seconds cumulative, (-55.0 DegC <= TCM internal temperature <= 21.0 DegC), TFT >= 70.0 DegC, TFT delta from start up >= 55.0 DegC, TCM internal temperature delta < 2.0 DegC for time >= 100 seconds fail case 2: vehicle speed >= 8 KPH for time >= 300 seconds cumulative, TCC slip > 120 RPM for time >= 300 seconds cumulative, (120 DegC <= TCM internal temperature <= 150 DegC), TFT >= 70.0 DegC, TFT delta from start up >= 55.0 DegC, TCM internal temperature delta < 2.0 DegC for time >= 100 seconds fail case 3: TCM internal temperature delta >= 20 DegC, delta occurs 14 times over a 7 second sample period	P0667, P0716, P0717, P0722, P0723 not FA or TFTKO, P0711, P0712, P0713 not FA, Ignition voltage enable, engine speed enable, -54 DegC <= TCM internal temperature <= 149 DegC	Fail case 1 & 2: Time > 100 seconds Fail case 3: 14 counts in Time <= 7 seconds Continuous	CeTRND_SubTempFltActin (FATKO)	Special Type C
TCM internal temperature thermistor failed at a high temperature (short to power).	P0668	Substrate Sensor Short to Power Error	TCM substrate temperature >= 249 DegC for time >= 4.0 seconds	ignition voltage enable, engine speed enable, P0668 not fault active or test fail this key on	4.0 sec Continuous	CeTRND_SubTempFltAction (FA)	Special Type C
TCM internal temperature thermistor failed at a low temperature (open or short to ground).	P0669	Substrate Sensor Open/StoG Error	TCM substrate temperature <= -249 DegC for time >= 10 seconds	ignition voltage enable, engine speed enable, P0669, P0716, P0717, P0722, P0723 not FA or TTKO, TOSS speed >= 200 RPM for time >= 200 seconds, TCC slip >= 120 RPM for time >= 200 seconds,	10.0 sec Continuous	CeTRND_SubTempFltAction (FA)	Special Type C

Common engine speed enable: 500 RPM <= engine speed <= 5800 RPM for time >= 5.0 seconds
 Common ignition voltage enable: 8.6 volts <= ignition voltage <= 19.0 volts
 Common vehicle speed enable: 5.0 KPH <= vehicle speed for time >= 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
Trans Fluid Temp Sensor Circuit Range/ Performance	P0711	<p>The DTC detects the following failure modes of the transmission fluid temperature sensor:</p> <p>1) A sensor that remains at a constant value</p> <p>2) A sensor that remains at a value</p> <p>4) Transmission fluid temperature remains below 20° C for a calibrated time as a function of startup transmission fluid temperature.</p>	<p>fail case 1 or fail case 2 or fail case 3 or fail case 4 independently fail</p> <p><u>Fail Case 1</u> vehicle speed >= 8 KPH for time >= 300 seconds cumulative, TCC slip > 120 RPM for time >= 300 seconds cumulative, -50.0 <= TFT<= 21.0 DegC, engine coolant temperature >= 70.0 DegC, engine coolant temperature delta from start up >= 55.0 DegC TFT delta < 2.0 DegC for time >= 100 seconds</p> <p><u>Fail Case 2</u> vehicle speed >= 8 KPH for time >= 300 seconds cumulative, TCC slip > 120 RPM for time >= 300 seconds cumulative, 129 DegC <= TFT <= 170 DegC, engine coolant temperature >= 70.0 DegC, engine coolant temperature delta from start up >= 55.0 DegC, TFT delta < 2.0 DegC for time >= 100 seconds <u>*Fail Case 3</u> <u>*Bench Only</u> TFT delta >= 20 DegC, Delta occurs 14 times over a 7 second sample period <u>Fail Case 4</u> TFT <= 20° C after a calibrated amount of time based on a 2D lookup table.</p>	<p>For fail case 1, 2, and 4: P0711, P0716, P0717, P0722, P0723 not FA or TFTKO, engine coolant temperature valid, ignition voltage enable, engine speed enable, P0711 not TPTKO, -49 <= TCM internal temperature <= 169 DegC</p> <p><u>Fail case 1:</u> -50 deg C <= trans fluid temp <= +21 C at startup, Engine coolant => 70 deg C, Engine Coolant has changed => 55 deg C since startup, Vehicle speed since startup => 8 KPH for time => 300 seconds (cumulative timer)</p> <p><u>Fail case 2:</u> +129 deg C <= trans fluid temp <= +170 C at startup, Engine coolant => 70 deg C, Engine Coolant has changed => 55 deg C since startup, Vehicle speed since startup => 8 KPH for time => 300 seconds (cumulative timer)</p> <p><u>Fail case 3:</u> System Voltage is between 8 – 18 Volts. Engine Speed 450-7500 for 5 seconds.</p> <p><u>Fail case 4:</u> Acceleration position valid, engine torque accurate, engine speed accurate, ECT accurate, No soft landing default action present, No immediate landing default action present, 50<=engine torque<= 1492Nm, 8 <= TPS <= 100%, 511 kph>=vehicle speed>= 8 kph, 6500>= engine speed >= 500 RPM, 149 DegC>=Coolant>=-39 DegC</p>	<p><u>Fail case 1:</u> Time => 100.0 seconds Continuous</p> <p><u>Fail case 2:</u> Time => 100.0 seconds Continuous</p> <p><u>Fail case 3:</u> Time => 7.0 seconds 14 counts</p>	<p>CeTRND_FreezeAdaptsAction, CeTRND_TransTempFitAction,</p> <p><u>Calculate default transmission fluid temperature as follows:</u> If engine coolant temperature DTC is set, default transmission fluid temperature = 140 DegC else If engine run time < 60 seconds, default transmission fluid temperature = 47.25 Deg C else If engine run time >= 60 seconds AND engine coolant temperature < 20.25 Deg C, default transmission fluid temperature = 47.25 Deg C else If engine run time >= 60 seconds AND engine coolant temperature >= 20.25 Deg C, default transmission fluid temperature = engine coolant temperature</p> <p>Fault Active</p>	Special Type C
Transmission fluid temperature thermistor failed at a low temperature (short to ground).	P0712	Continuous short to ground in transmission fluid temperature sensor circuit	transmission fluid temperature <= -74 DegC for time >= 25 seconds	ignition voltage enable, engine speed enable, TOSS speed >= 200 RPM for time >= 200 seconds, TCC slip >= 120 RPM for time >= 200 seconds, P0712 not fraudt active or test fail this key on	25 seconds	CeTRND_FreezeAdaptsAction, CeTRND_TransTempFitAction, (FA)	Special Type C
Transmission fluid temperature thermistor failed at a high temperature (open or short to power).	P0713	Continuous short to voltage in transmission fluid temperature sensor circuit	transmission fluid temperature >= 174 DegC for time >= 10 seconds	ignition voltage enable, engine speed enable, P0713 not FA or TFTKO	10 seconds	CeTRND_FreezeAdapt Action, CeTRND_TransTempFitAction, Fault Active	Special Type C

Common engine speed enable: 500 RPM <= engine speed <= 5800 RPM for time >= 5.0 seconds
Common ignition voltage enable: 8.6 volts <= ignition voltage <= 19.0 volts
Common vehicle speed enable: 5.0 KPH <= vehicle speed for time >= 5.0 seconds

FA=Fault Active
FATKO=Fault Active This Key On
TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
Input Speed Sensor Performance	P0716	Unrealistically large drop in transmission input speed signal	0 < input speed delta < 500 RPM for time >= 2 seconds, Raw input speed >= 1050 RPM for time >= 2 seconds, Input speed drops more than 1000 RPM and does not recover for time >= 3.25 seconds	P0716 is not FA or TFTKO, ignition voltage enable, engine speed enable, engine torque valid, 1492 >=engine torque >= 50 Nm, throttle position is valid from ECM, throttle position >= 8 %, no P0717 P0722 P0723 FA or TFTKO, vehicle speed >= 16 KPH	Time>= 3.25 seconds Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Input Speed Sensor Circuit Low Voltage	P0717	Low transmission input speed signal with high vehicle speed	TISS < 100 RPM for time >= 4.5 seconds	P0717 is not FA or TFTKO, ignition voltage enable, engine speed enable, engine torque valid from ECM, vehicle speed >= 16 KPH, engine torque >= 50 Nm, P0722 P0723 not FA or TFTKO	Fail timer >= 4.5 seconds Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Output Speed Sensor Circuit Low Voltage	P0722	Low vehicle speed with large engine speed in drive range	transmission output speed <= 70 RPM for time >= 4.5 seconds	ignition voltage enable, engine speed enable, engine torque valid from ECM, 1492>=engine torque >= 50 Nm, throttle position valid from ECM, throttle position >= 8 %, P0716 P0717 P0723 not FA or TFTKO, PRNDL is not park/neutral, 1000 <= input speed <= 6500 RPM, 3200<=engine speed<=5000 RPM, TFT>=0°C	Fail timer >= 4.5 seconds Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Output Speed Sensor Circuit Intermittent	P0723	Unrealistically large drop in transmission output speed signal	input speed delta < 500 RPM for time >= 2 seconds, 0 < output speed delta < 500 RPM for time >= 2 seconds, raw output speed >= 1000 RPM for time >= 2 seconds, output speed drops more than 1200 RPM and does not recover for time >= 3.25 seconds	P0723 is not FA or TFTKO, ignition voltage enable, engine speed enable, no P0716 P0717 P0722 FA or TFTKO, range change timer >= 6 seconds	Fail timer >= 3.25 seconds Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A

Common engine speed enable: 500 RPM <= engine speed <= 5800 RPM for time >= 5.0 seconds
Common ignition voltage enable: 8.6 volts <= ignition voltage <= 19.0 volts
Common vehicle speed enable: 5.0 KPH <= vehicle speed for time >= 5.0 seconds

FA=Fault Active
FATKO=Fault Active This Key On
TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
TCC System Stuck OFF	P0741	High TCC slip with TCC commanded on	TCC Pressure \geq 800 Kpa for 5 seconds, When TCC slip error \geq 50 (Table based)/rpm for time \geq 6 seconds Increment fail counter by one. Set P0741 when fail counter \geq 3 counts	ignition voltage enable, no P0716, P0717, P0722, P0723, P2762, P2763, P2764, P0742 FA or TFTKO, 20 DegC \leq TFT \leq 130 DegC, engine torque valid from ECM, engine torque \geq 50 Nm, throttle position valid from ECM, 8 % \leq throttle position \leq 100 %, 2.6710 \leq 2nd gear ratio \leq 3.0730, 1.7131 \leq 3rd gear ratio \leq 1.9709, 1.3151 \leq 4th gear ratio \leq 1.5130, 0.9300 \leq 5th gear ratio \leq 1.0700, 0.6901 \leq 6th gear ratio \leq 0.7939, TCC commanded "on",	Fail timer \geq 6.0 seconds Fail Counter=3 Continuous	CeTRND_ForceTCC_OffAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, CeTRND_TUTD_InhAction, CeTRND_DSG_DfltGearOpt3Action, CeTRND_FreezeAdaptsAction, CeTRND_MUMD_InhAction, CeTRND_PCA_InhbAction (TFTKO)	B
TCC System Stuck ON	P0742	Low TCC slip with TCC commanded off.	-20 \leq TCC slip speed \leq 30 RPM for time \geq 2.5 seconds Increment fail counter by one, failure counter \geq 6 counts	ignition voltage enable, No P0716, P0717, P0722, P0723, P1751, P2762, P2763, P2764, P0741 FA or TFTKO, 20 DegC \leq TFT \leq 130 DegC, engine torque valid from ECM, 80 \leq engine torque \leq 1492 Nm, Throttle position valid from ECM, 8 % \leq throttle position \leq 100 %, vehicle speed \geq 16 KPH, 500 \leq engine speed \leq 6500 RPM, 0.6901 \leq gear ratio \leq 1.97094, Command Gear \geq 2, Solenoid A (mode 2 valve) enabled, TCC commanded "off"	Fail timer \geq 2.5 sec Fail Counter=6 Continuous	CeTRND_FreezeAdaptsAction, CeTRND_ForceTCC_ApplyAction, (TFTKO)	B
Shift Solenoid Valve A Stuck On	P0752	This DTC detects a neutral condition when 3 rd gear is commanded and the mode 2 valve is stuck in the ON position	gear box slip \geq 100.0 RPM	Command gear has achieved 1 st lock, 1 st free-wheel, or second, command gear = 3 rd	Time \geq 3.0 sec Continuous	CeTRND_FreezeAdaptsAction, CeTRND_DSG_DfltGearOpt4Action, CeTRND_TorqMgntInhbAction, CeTRND_TUTD_InhAction, CeTRND_ForceTCC_OffAction, CeTRND_MUMD_InhAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction (TFTKO)	A

Common engine speed enable: 500 RPM \leq engine speed \leq 5800 RPM for time \geq 5.0 seconds
Common ignition voltage enable: 8.6 volts \leq ignition voltage \leq 19.0 volts
Common vehicle speed enable: 5.0 KPH \leq vehicle speed for time \geq 5.0 seconds

FA=Fault Active
FATKO=Fault Active This Key On
TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
Shift Solenoid Valve B Stuck Off	P0756	This DTC detects a neutral condition when 1 st lock or 1 st free-wheel is commanded and the mode 3 valve is stuck in the OFF position	In sequence: <u>event 1:</u> command gear is 1 st lock or 1 st free-wheel and gear box slip \geq 100.0 RPM, <u>event 2:</u> command gear = 2 nd and 2 nd gear gear box slip \leq 35.2 RPM OR gear box slip \leq 100.0 RPM and shift time-out occurs, CB26 VBS is at maximum command pressure	Ignition vorage enable, No P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, High side driver is enabled, Throttle position signal and engine torque signals valid from ECM, throttle position \geq 10.0 %, 120.0 Nm \leq engine torque \leq 1492.0 Nm, transmission fluid temperature \geq 0.0	 <u>event 1:</u> time \geq 3.0 sec <u>event 2:</u> time \leq 4.0 sec Continuous	CeTRND_FreezeAdaptsAction, CeTRND_DSG_DfItGearOpt2Action, CeTRND_TorqMgntInhbAction, CeTRND_TUTD_InhAction CeTRND_MUMD_InhAction (TFTKO)	A
Pressure Control (PC) Solenoid B Stuck Off [C35R]	P0776 Dynamic Test	This DTC detects a neutral condition when 3 rd or 5 th gear is commanded, or steady state 3 rd or 5 th gear is achieved, C35R clutch system stuck OFF failure	DTC will set due to either a steady state or dynamic test failure Dynamic test: High speed mode: TOSS \geq 60 RPM. High speed mode: command gear slip \geq 100 RPM for time \geq 2.25 seconds. Low speed mode: TOSS < 60 RPM. Low speed mode: turbine speed \geq ((60 RPM * commanded gear ratio) + 100 RPM) for time \geq 2.25 seconds.	Dynamic test: transmission fluid temperature \geq 0.0 DegC, no P0716, P0717, P0722, P0723, P1815, P1820, P1822, P1823, P1825, P1826, turbine speed \geq 60 RPM, C35R is on-coming clutch and C35R on coming control is complete.	 <u>Dynamic test (shift in progress)</u> Time \geq 2.25 sec Continuous	CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_DSG_DfItGearOpt3Action, CeTRND_TorqMgntInhbAction, CeTRND_TUTD_InhAction CeTRND_TCC_SlndInhbAction CeTRND_MUMD_InhAction CeTRND_TCC_SlndInhbAction (TFTKO)	A
	P0776 Steady State Test 3 rd Gear	Neutral when holding clutch C35R is enabled for 3rd gear.	<u>Steady state test:</u> in sequence from 3rd gear: event 1: command gear is 3rd and gear box slip \geq 100.0 RPM for time \geq 3.0 sec, event 2: induce 3-4 upshift command gear is 4th and 4th gear gear box slip \geq 35.2 RPM for time \geq 4.0 sec, AND gear box slip \geq 100.0 RPM for time \geq 5.0 sec, C456 VBS is at maximum command pressure	<u>Steady state test:</u> Ignition vorage enable, transmission fluid temperature \geq 0.0 DegC, no P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, High side driver is enabled, average driven wheel speed \geq 80.0 RPM, side-to-side wheel speed difference \leq 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) \leq 7.0 % for time \leq 6.0 sec, 3rd or 5th gear ratio achieved.	 <u>3rd Gear Steady State Test</u> Time \geq 3.0 sec Continuous	Same as Dynamic Test	

Common engine speed enable: 500 RPM \leq engine speed \leq 5800 RPM for time \geq 5.0 seconds
 Common ignition voltage enable: 8.6 volts \leq ignition voltage \leq 19.0 volts
 Common vehicle speed enable: 5.0 KPH \leq vehicle speed for time \geq 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
	P0776 Steady State Test 5 th Gear	Neutral when holding clutch C35R is enabled for 5th gear.	Steady state test: in sequence from 5th gear event 1: command gear is 5th and gear box slip ≥ 100.0 RPM for time ≥ 3.0 sec, event 2: induce 5-6 upshift command gear is 6th and 6th gear gear box slip ≥ 35.2 RPM for time ≥ 4.0 sec, AND gear box slip ≥ 100.0 RPM for time ≥ 5.0 sec, CB26 VBS is at maximum command pressure	Steady state test: Ignition voltage enable, transmission fluid temperature ≥ 0.0 DegC, no P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, High side driver is enabled, average driven wheel speed ≥ 80.0 RPM, side-to-side wheel speed difference ≤ 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) ≤ 7.0 % for time ≤ 6.0 sec, 3rd or 5th gear ratio achieved.	5th Gear Steady State Test Time ≥ 3.0 sec Continuous	Same as Dynamic Test	
Pressure Control (PC) Solenoid B Stuck On [C35R]	P0777 Dynamic Test	This DTC detects a tie-up condition when a shift from 3 rd or 5 th gear is commanded, or steady state 1 st , 2 nd , 4 th , or 6 th gear, C35R clutch system stuck ON failure	DTC will set due to either a steady state or dynamic test failure Dynamic test (shift in progress) C35R clutch command pressure = 0 kPa for time \geq C35R zero capacity delay time, where C35R zero capacity delay time = f(transmission fluid temperature) and ([on-coming clutch delta transition pressure > 50 kPa and 300 kPa < on-coming command clutch command pressure < 1950 kPa] or [C35R clutch control state = exhaust and on-coming clutch control state = maximum pressure]). Attained gear slip ≤ 40 RPM for time \geq calculated fail time, where calculated fail time = f(shift type, throttle position, transmission fluid temperature)	Dynamic test (shift in progress) Transmission fluid temperature ≥ 0.0 DegC, no P0716, P0717, P0722, P0723, P1815, P1820, P1822, P1823, P1825, P1826. TOSS ≥ 200 RPM, Turbine Speed ≥ 200 RPM. C35R is off-going clutch.	Dynamic test (shift in progress) Time ≥ 1.2 sec Continuous	CeTRND_FreezeAdapts Action, CeTRND_PCA_InhbAction, CeTRND_DSG_DfltGearOpt1Action, CeTRND_TorqMgntInhbAction, CeTRND_TUTD_InhAction CeTRND_ForceTCC_OffAction CeTRND_MUMD_InhAction CeTRND_TCC_SlndInhbAction (TFTKO)	A

Common engine speed enable: 500 RPM \leq engine speed \leq 5800 RPM for time ≥ 5.0 seconds

Common ignition voltage enable: 8.6 volts \leq ignition voltage \leq 19.0 volts

Common vehicle speed enable: 5.0 KPH \leq vehicle speed for time ≥ 5.0 seconds

FA=Fault Active

FATKO=Fault Active This Key On

TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
<p style="color: red; text-align: center;">WARNING!</p> <p style="color: red; text-align: center;">Steady State Tie-Up Test could damage Transmission.</p>	P0777 Steady State Test	Tie-up when holding clutch is C35R.	<p>Steady state test: in sequence from command gear ≠ 3rd OR ≠ 5th gear: event 1: (scaling factor = 1 if command gear ≠ 1st scaling factor = 2 if command gear = 1st) transmission output speed deceleration ≥ (250 RPM/sec*scaling factor) for time ≥ 0.30 sec, event 2: release holding clutch, see "ss tie-up test DTC map", 35.2 RPM ≤ gear box slip ≤ 100.0 RPM for 0.50 sec ≤ time ≤ 1.0 sec</p>	<p>Steady state test: Ignition voltage enable, No P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, Throttle position signal and engine torque signals valid from ECM, High side driver is enabled, brake state = off OR delta gear box torque ≥ 250.0 Nm in time ≤ 0.350 sec, (if command gear = 1st free-wheel, throttle position ≥ 10.0% and 120.0 Nm ≤ engine torque ≤ 1492.0 Nm), average driven wheel speed ≥ 80.0 RPM, side-to-side wheel speed difference ≤ 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) ≤ 7.0 % for time ≤ 6.0 sec, transmission output speed delta ≥ 1300 RPM/sec or PS2 is exhausted with transmission output speed delta ≥ 10 RPM/sec, command gear = 1st, 2nd, 4th, or 6th and gear ratio achieved.</p>	<p>Steady State Test Time ≥ 0.30 Seconds</p> <p>Continuous</p>	Same as Dynamic Test	
Pressure Control (PC) Solenoid C Stuck Off [C456]	P0796 Dynamic Test	This DTC detects a neutral condition when 4 th , 5 th , or 6 th gear is commanded, or steady state 4 th , 5 th , or 6 th gear, C456 clutch system stuck OFF failure	<p>DTC will set due to either a steady state or dynamic test failure</p> <p><u>Dynamic test (shift in progress)</u> High speed mode: TOSS ≥ 60 RPM. High speed mode: command gear slip ≥ 100 RPM for time ≥ 2.25 seconds. Low speed mode: TOSS < 60 RPM. Low speed mode: turbine speed ≥ ((60 RPM * commanded gear ratio) + 100 RPM) for time ≥ 2.25 seconds.</p>	<p><u>Dynamic test (shift in progress)</u> Transmission fluid temperature ≥ 0.0 DegC, no P0716, P0717, P0722, P0723, P1815, P1820, P1822, P1823, P1825, P1826, turbine speed ≥ 60 RPM, C456 is on-coming clutch and C456 on coming control is complete.</p>	<p>Dynamic test (shift in progress) Time ≥ 2.25 sec</p>	<p>CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_DSG_DfltGearOpt1Action, CeTRND_TorgMgntInhbAction, CeTRND_TUTD_InhAction, CeTRND_ForceTCC_OffAction, CeTRND_MUMD_InhAction, CeTRND_TCC_SlndInhbAction (TFTKO)</p>	A
	P0796 Steady State Test in 4 th	Neutral when holding clutch C456 is enabled for 4th gear.	<p>Steady state test: in sequence from 4th gear: event 1: command gear is 4th and gear box slip ≥ 100.0 RPM for time ≥ 3.0 sec, event 2: induce 4-5 upshift command gear is 5th and 5th gear gear box slip ≥ 35.2 RPM for time ≥ 4.0 sec, AND gear box slip ≥ 100.0 RPM for time ≥ 5.0 sec, C35R VBS is at maximum command pressure</p>	<p>Steady state test: Ignition voltage enable, No P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, High side driver is enabled, average driven wheel speed ≥ 80.0 RPM, side-to-side wheel speed difference ≤ 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) ≤ 7.0 % for time ≤ 6.0 sec, 4th, 5th, or 6th gear ratio achieved.</p>	<p>Steady State Test: Time ≥ 3.0 sec</p>	Same as Dynamic Test	

Common engine speed enable: 500 RPM ≤ engine speed ≤ 5800 RPM for time ≥ 5.0 seconds
 Common ignition voltage enable: 8.6 volts ≤ ignition voltage ≤ 19.0 volts
 Common vehicle speed enable: 5.0 KPH ≤ vehicle speed for time ≥ 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
	P0796 Steady State Test in 5 th	Neutral when holding clutch C456 is enabled for 5th gear.	<u>Steady state test:</u> in sequence from 5th gear event 1: command gear is 5th and gear box slip \geq 100.0 RPM for time \geq 3.0 sec, event 2: induce 5-6 upshift command gear is 6th and 6th gear gear box slip \geq 35.2 RPM for time \geq 4.0 sec, AND gear box slip \geq 100.0 RPM for time \geq 5.0 sec, CB26 VBS is at maximum command pressure	<u>Steady state test:</u> Ignition vottage enable, No P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, High side driver is enabled, average driven wheel speed \geq 80.0 RPM, side-to-side wheel speed diference \leq 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) \leq 7.0 % for time \leq 6.0 sec, 4th, 5th, or 6th gear ratio achieved.	Steady State Test: Time \geq 3.0 sec	Same as Dynamic Test	
	P0796 Steady State Test in 6 th	Neutral when holding clutch C456 is enabled for 6th gear.	<u>Steady state test:</u> in sequence from 6th gear event 1: command gear is 6th and gear box slip \geq 100.0 RPM for time \geq 3.0 sec, event 2: induce 6-5 downshift command gear is 5th and 5th gear gear box slip \geq 35.2 RPM for time \geq 4.0 sec, AND gear box slip \geq 100.0 RPM for time \geq 5.0 sec, C35R VBS is at maximum command pressure	<u>Steady state test:</u> Ignition vottage enable, No P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, High side driver is enabled, average driven wheel speed \geq 80.0 RPM, side-to-side wheel speed diference \leq 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) \leq 7.0 % for time \leq 6.0 sec, 4th, 5th, or 6th gear ratio achieved.	Steady State Test: Time \geq 3.0 sec	Same as Dynamic Test	
Pressure Control (PC) Solenoid C Stuck On [C456]	P0797 Dynamic Test	This DTC detects a tie-up condition when a shift from 4 th , 5 th , or 6 th gear is commanded, or steadt state 1 st , 2 nd , or 3 rd gear, C456 clutch system stuck ON failure	DTC will set due to either a steady state or dynamic test failure, see below for steady state test <u>Dynamic test (shift in progress)</u> gear box slip \leq 40.0 RPM,	<u>Dynamic test:</u> C456 clutch command pressure = 0 kPa for time \geq C456 zero capacity delay time, where C456 zero capacity delay time = f(transmission fluid temperature) and [(on-coming clutch delta transition pressure > 50 kPa and 300 kPa < on-coming command clutch command pressure < 1950 kPa] or [C456 clutch control state = exhaust and on-coming clutch control state = maximum pressure]]. Attained gear slip \leq 40 RPM for time \geq calculated fail time, where calculated fail time = f(shift type, throttle position, transmission fluid temperature)	Dynamic test (shift in progress) Time \geq 1.2 sec Continuous	CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_DSG_DfltGearOpt3Action, CeTRND_TorqMgntInhbAction, CeTRND_TUTD_InhAction, CeTRND_ForceTCC_OffAction, CeTRND_MUMD_InhAction, CeTRND_TCC_SlndInhbAction (TFTKO)	A

Common engine speed enable: 500 RPM \leq engine speed \leq 5800 RPM for time \geq 5.0 seconds
 Common ignition voltage enable: 8.6 volts \leq ignition voltage \leq 19.0 volts
 Common vehicle speed enable: 5.0 KPH \leq vehicle speed for time \geq 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
	P0797 Steady State Test	Tie-up when holding clutch is C456.	<u>Steady state test:</u> in sequence from command gear ≠ 4th OR ≠ 5th OR ≠ 6th gear: event 1: (scaling factor = 1 if command gear ≠ 1st scaling factor = 2 if command gear = 1st) transmission output speed deceleration ≥ (250 RPM/sec*scaling factor) for time ≥ 0.250 sec, event 2: release holding clutch, see "ss tie-up test DTC map", 35.2 RPM ≤ gear box slip ≤ 100.0 RPM for 0.50 sec ≤ time ≤ 1.0 sec	<u>Steady state test:</u> Ignition voltage enable, No P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, Throttle position signal and engine torque signals valid from ECM, High side driver is enabled, brake state = off OR delta gear box torque ≥ 250.0 Nm in time ≤ 0.350 sec, (if command gear = 1st free-wheel, throttle position ≥ 10.0% and 120.0 Nm ≤ engine torque ≤ 1492.0 Nm), average driven wheel speed ≥ 80.0 RPM, side-to-side wheel speed difference ≤ 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) ≤ 7.0 % for time ≤ 6.0 sec, transmission output speed delta ≥ 1300 RPM/sec or PS4 is exhausted with transmission output speed delta ≥ 10 RPM/sec, command gear = 1st, 2nd, or 3rd and gear ratio achieved.	Steady State Test: Time ≥ 0.30 sec	Same as Dynamic Test	
Upshift Switch Circuit	P0815	This DTC detects the upshift switch Stuck ON	Fail Case 1: Upshift Switch Stuck ON in Park for at least 3 seconds. Fail Case 2: Switch stuck ON in D4 or D6 for 600 seconds. Fail Case 1 & 2 are true:	500 ≤ Engine Speed ≤ 6500 for at least 5 seconds, Ignition voltage, No IMS Failures, No P0826 Set, Range Change Timer > 6 seconds,	fail timer 1 ≥ 3.0 sec AND fail timer 2 ≥ 600.0 sec Continuous	CeTRND_TUTD_InhAction CeTRND_MUMD_InhAction (Fault Active)	Special Type C (Ignore TAP Request)
Downshift Switch Circuit	P0816	This DTC detects the downshift switch Stuck ON	Fail Case 1: Downshift Switch Stuck ON in Park for at least 3 seconds. Fail Case 2: Switch stuck ON in D4 or D6 for 600 seconds. Fail Case 1 & 2 are true:	500 ≤ Engine Speed ≤ 6500 for at least 5 seconds, Ignition voltage, No IMS Failures, No P0826 Set, Range Change Timer > 6 seconds,	fail timer 1 ≥ 3.0 sec AND fail timer 2 ≥ 600.0 sec Continuous	CeTRND_TUTD_InhAction CeTRND_MUMD_InhAction (Fault Active)	Special Type C (Ignore TAP Request)
Up and Down Shift Switch Circuit <i>Breakout Box Required to Test</i>	P0826	This DTC detects the upshift/downshift switch circuit at an illegal voltage	TUTD Circuit Invalid voltage for 8 seconds	500 ≤ Engine Speed ≤ 6500 for at least 5 seconds, Ignition voltage	Fail timer ≥ 8.0 seconds Continuous	CeTRND_TUTD_InhAction CeTRND_MUMD_InhAction (Fault Active)	Special Type C (Ignore TAP Request)
S3 pressure switch circuit low voltage.	P0872	CB26 Pressure Switch is Exhausted when it should be Pressurized (StoG)	start up test: not enabled normal test: TCM shutdown not in process, CB26 hydraulic pressure ≤ 100 kPa for stable time ≥ 0.45 seconds and pressure switch remains closed for time ≥ 5.5 seconds	Engine speed enable, Ignition voltage enable, P1915, P1825, P0711, P0712, P0713, P0965, P0966, P0967, P0969, P0970, P0971, P0973, P0974, P0976, P0977, P2719, P2720, P2721, P2728, P2729, P2730 not FA or TFTKO, 20 DegC ≤ TFT ≤ 150 DegC, Engine speed ≥ 1100rpm	Fail timer ≥ 5.5 seconds Continuous	CeTRND_FreezeAdaptsAction (TFTKO)	Special Type C (Inhibits RVT Steady State Test but Dynamic test functional)

Common engine speed enable: 500 RPM ≤ engine speed ≤ 5800 RPM for time ≥ 5.0 seconds
Common ignition voltage enable: 8.6 volts ≤ ignition voltage ≤ 19.0 volts
Common vehicle speed enable: 5.0 KPH ≤ vehicle speed for time ≥ 5.0 seconds

FA=Fault Active
FATKO=Fault Active This Key On
TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
S3 pressure switch circuit high voltage.	P0873	CB26 Pressure Switch is Pressurized when it should be Exhausted (Open or StoP)	start up test: not enabled normal test: TCM shutdown not in process, engine speed enable, CB26 hydraulic pressure >= 600 kPa for stable time >= 1 second and pressure switch remains open for time >= 5.5 seconds	Engine speed enable, Ignition voltage enable, P1915,P1825, P0711, P0712, P0713, P0965, P0966, P0967, P0969, P0970, P0971, P0973, P0974, P0976, P0977, P2719, P2720, P2721, P2728, P2729, P2730 not FA or TFTKO, 20 DegC <= TFT <= 150 DegC, Engine speed >=1100rpm	Fail timer ≥ 5.5 seconds Continuous	CeTRND_FreezeAdaptsAction (TFTKO)	Special Type C (Inhibits RVT Steady State Test but Dynamic test functional)
S1 pressure switch circuit low voltage.	P0877	C1234 Pressure Switch is Exhausted when it should be Pressurized (StoG)	start up test: not enabled normal test: TCM shutdown not in process, C1234 hydraulic pressure <= 100 kPa for stable time >= 0.45 seconds and pressure switch remains closed for time >= 5.5 seconds	Engine speed enable, Ignition voltage enable, P1915,P1825, P0711, P0712, P0713, P0965, P0966, P0967, P0969, P0970, P0971, P0973, P0974, P0976, P0977, P2719, P2720, P2721, P2728, P2729, P2730 not FA or TFTKO, 20 DegC <= TFT <= 150 DegC, Engine speed >=1100rpm	Fail timer ≥ 5.5 seconds Continuous	CeTRND_FreezeAdaptsAction (TFTKO)	Special Type C (Inhibits RVT Steady State Test but Dynamic test functional)
S1 pressure switch circuit high voltage.	P0878	C1234 Pressure Switch is Pressurized when it should be Exhausted (Open or StoP)	start up test: not enabled normal test: TCM shutdown not in process, engine speed enable, C1234 hydraulic pressure >= 600 kPa for stable time >= 1 second and pressure switch remains open for time >= 5.5 seconds	Engine speed enable, Ignition voltage enable, P1915,P1825, P0711, P0712, P0713, P0965, P0966, P0967, P0969, P0970, P0971, P0973, P0974, P0976, P0977, P2719, P2720, P2721, P2728, P2729, P2730 not FA or TFTKO, 20 DegC <= TFT <= 150 DegC, Engine speed >=1100rpm	Fail timer ≥ 5.5 seconds Continuous	CeTRND_FreezeAdaptsAction (TFTKO)	Special Type C (Inhibits RVT Steady State Test but Dynamic test functional)
Pressure Control (PC) Solenoid A Control Circuit Low Voltage	P0962	This DTC detects a continuous short to ground in the transmission line pressure VBS control circuit	hardware circuitry detects low pressure error is true for 300 milliseconds in a 375 millisecond sample	P0962 is not fault active or test fail this key on, ignition voltage enable, engine speed enable, line pressure control solenoid enabled	Fail time ≥ 0.30 sec in 0.375 sec sample Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Pressure Control (PC) Solenoid B Control Circuit Low Voltage	P0966	This DTC detects a continuous short to ground in the C35R VBS control circuit	hardware circuitry detects low pressure error is true for 300 milliseconds in a 375 millisecond sample	P0966 is not fault active or test fail this key on, ignition voltage enable, engine speed enable	Fail time ≥ 0.30 sec in 0.375 sec sample Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A

Common engine speed enable: 500 RPM <= engine speed <= 5800 RPM for time >= 5.0 seconds
 Common ignition voltage enable: 8.6 volts <= ignition voltage <= 19.0 volts
 Common vehicle speed enable: 5.0 KPH <= vehicle speed for time >= 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
Pressure Control (PC) Solenoid B Control Circuit High Voltage	P0967	This DTC detects a continuous short to power or open in the C35R VBS control circuit	hardware circuitry detects high pressure error is true for 300 milliseconds in a 375 millisecond sample	P0967 is not fault active or test fail this key on, ignition voltage enable, engine speed enable	Fail time ≥ 0.30 sec in 0.375 sec sample Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Pressure Control (PC) Solenoid C Control Circuit Low Voltage	P0970	This DTC detects a continuous short to ground in the C456/CBR1 VBS control circuit	hardware circuitry detects low pressure error is true for 300 milliseconds in a 375 millisecond sample	P0970 is not fault active or test fail this key on, ignition voltage enable, engine speed enable	Fail time ≥ 0.30 sec in 0.375 sec sample Continuous	CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, CeTRND_DSG_DfltGearOpt2Action (TFTKO)	A
Pressure Control (PC) Solenoid C Control Circuit High Voltage	P0971	This DTC detects a continuous short to power or open in the C456/CBR1 VBS control circuit	hardware circuitry detects high pressure error is true for 300 milliseconds in a 375 millisecond sample	P0971 is not fault active or test fail this key on, ignition voltage enable, engine speed enable	Fail time ≥ 0.30 sec in 0.375 sec sample Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Shift Solenoid A Control Circuit Low	P0973	This DTC detects a continuous short to ground in the mode 2 on/off solenoid control circuit	hardware circuitry detects ground short error is true for 1.2 seconds in 1.5 second sample	P0973 is not fault active or test fail this key on, ignition voltage enable, engine speed enable	Fail time ≥ 1.2 sec in 1.5 sec sample Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Shift Solenoid A Control Circuit High	P0974	This DTC detects a continuous short to power or open in the mode 2 on/off solenoid control circuit	hardware circuitry detects open or power short error is true for 1.2 seconds in 1.5 second sample	P0974 is not fault active or test fail this key on, ignition voltage enable, engine speed enable	Fail time ≥ 1.2 sec in 1.5 sec sample Continuous	CeTRND_1stGearInhbAction	B
Shift Solenoid B Control Circuit Low	P0976	This DTC detects a continuous short to ground in the mode 3 on/off solenoid control circuit	hardware circuitry detects open or power short error is true for 1.2 seconds in 1.5 second sample	P0976 is not fault active or test fail this key on, ignition voltage enable, engine speed enable	Fail time ≥ 1.2 sec in 1.5 sec sample Continuous	None	B

Common engine speed enable: 500 RPM ≤ engine speed ≤ 5800 RPM for time ≥ 5.0 seconds
 Common ignition voltage enable: 8.6 volts ≤ ignition voltage ≤ 19.0 volts
 Common vehicle speed enable: 5.0 KPH ≤ vehicle speed for time ≥ 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
Shift Solenoid B Control Circuit High	P0977	This DTC detects a continuous short to power or open in the mode 3 on/off solenoid control circuit	hardware circuitry detects open or power short error is true for 1.2 seconds in 1.5 second sample	P0977 is not fault active or test fail this key on, ignition voltage enable, engine speed enable	Fail time \geq 1.2 sec in 1.5 sec sample Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Shift valve 1 performance	P1751	This DTC detects gear box slip when the mode 2 valve solenoid is commanded ON as part of P0742 TCC Stuck OFF Test	<u>triggered by event 3</u> gear box slip \geq 100.0 RPM increment fail and sample counter, reset latch protect delay timer to 3.0 sec, mode 2 valve solenoid request = FALSE	P1751 uses P0742 enable, transmission input speed \geq 1100.0 RPM test sequence: <u>event1</u> if latch protect pressure = 0.0 kPa, set establish latch delay timer = 0.5 sec <u>event 2</u> if establish latch delay timer = 0.0 and mode 2 valve solenoid request = FALSE and gear box slip \leq 110.0 RPM, set line pressure command to 1000.0 kPa minimum latch protect pressure and and count down establish protect delay timer <u>event 3</u> when establish latch protect delay timer = 0.0 sec and command gear \neq 2 nd , mode 2 valve solenoid request = TRUE (command mode 2 valve solenoid = ON) <u>event 4</u> count down latch protect delay timer	Fail counter = 5 counts out of 5 sample counts Continuous	CeTRND_FreezeAdaptsAction, (TFTKO)	B

Common engine speed enable: 500 RPM \leq engine speed \leq 5800 RPM for time \geq 5.0 seconds
 Common ignition voltage enable: 8.6 volts \leq ignition voltage \leq 19.0 volts
 Common vehicle speed enable: 5.0 KPH \leq vehicle speed for time \geq 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
Internal Mode Switch-Invalid Range	P1825	This DTC detects an error in the decoded value for the IMS switches.	Any fail case will set P1825 IMS Invalid Range <u>fail case 1:</u> IMS range = TRANSITIONL1 for time ≥ 8.0 sec in both conditions, increment fail counter <u>fail case 2:</u> TRANSITIONL13 for time ≥ 8.0 sec, increment fail counter <u>fail case 3:</u> TRANSITIONL8 for time ≥ 1.25 sec, increment fail counter <u>fail case 4:</u> IMS range ≠ PARK OR NEUTRAL OR AND IMS range = (PARK OR NEUTRAL) OR OR IMS range = Illegal <u>fail case 5:</u> TRANSITIONL11 for time ≥ 3.0 sec, increment fail counter	Ignition vottage enable, Engine speed enable, <u>fail case 1:</u> C1234 or CB26 pressure switch = PRESSURIZED AND command gear = 1 st lock, CB26 pressure switch = PRESSURIZED <u>fail case 2:</u> C1234 or CB26 pressure switch = PRESSURIZED <u>fail case 3:</u> C1234 or CB26 pressure switch = PRESSURIZED <u>fail case 4:</u> ECM park/neutral serial data signal = PARK OR NEUTRAL OR ECM park/neutral serial data signal ≠ (PARK OR NEUTRAL) <u>fail case 5:</u> vehicle speed ≥ 16 KPH, C1234 or CB26 pressure switch = PRESSURIZED	<u>fail case 1:</u> fail counter ≥ 1 <u>fail case 2:</u> fail counter ≥ 1 <u>fail case 3:</u> fail counter ≥ 6 <u>fail case 4:</u> fail timer ≥ 4.0 sec <u>fail case 5:</u> fail counter ≥ 1 Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TUTD_InhAction CeTRND_MUMD_InhAction (TFTKO)	A
Pressure Control (PC)/Shift Lock Solenoid Control Circuit Low Voltage	P1831	High side driver #1 open or short to ground.	open or ground short is detected by hardware circuitry, fail counter >= 3 counts out of 5 count sample (0.3 sec out of 0.5 sec)	ignition voltage enable, engine speed enable, high side driver #1 enabled, P1831 not fault active or test fail this key on	Fail counter ≥ 3 out of 5 count sample at 100 msec count rate Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorgMgntInhbAction, CeTRND_TUTD_InhAction (TFTKO)	A
TUTD Shift Switch Enabled while not in TUTD Range	P1876	This DTC detects a TUTD Shift Switch Enabled while not in TUTD Range	range is not TUTD range enable (D4) while switch indicates enable for 3 counts of 2 seconds	500<=Engine Speed<=6500 rpm for at least 5 seconds; Ignition voltage enabled; U0100, P0815, P0816, P0826, P1915, P1825 not FA or TFTKO	Fail Time ≥ 2.0 seconds for 3 counts Continuous	CeTRND_TUTD_InhAction CeTRND_MUMD_InhAction (Fault Active)	Special Type C

Common engine speed enable: 500 RPM <= engine speed <= 5800 RPM for time >= 5.0 seconds
Common ignition voltage enable: 8.6 volts <= ignition voltage <= 19.0 volts
Common vehicle speed enable: 5.0 KPH <= vehicle speed for time >= 5.0 seconds

FA=Fault Active
FATKO=Fault Active This Key On
TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
Internal Mode Switch Does Not Indicate Park/Neutral (P/N) During Start	P1915	This DTC detects an error in the decoded value for the IMS switches during an engine start	PRNDL NOT park or neutral, Sequentially:engine speed < 50 RPM for time >= 250 ms, 50 RPM <= engine speed <= 480 RPM for time >= 70 ms, engine speed >= 525 RPM for time >= 3.25 sec. input shaft speed >= 200 RPM	6 V <= ignition voltage <= 18 V, P0722, P0723 not fault active or test fail this key on, transmission output speed <= 90 RPM,	Fail Time ≥ 3.25 seconds Once per ignition cycle	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_DSG_DfltGearOpt1Action (TFTKO)	A
No Ignition Voltage at the TCM	P2534	Detects a continuous open in TCM Ignition 1 Switch circuit	ignition voltage <= 2 V for time >= 10 seconds (200 counts)	ignition voltage enable, engine running flag	Fail Counts ≥ 200 out of 215 counts Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OfAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Pressure Control (PC) Solenoid D Stuck Off [CB26]	P2714 Dynamic Test	This DTC detects a neutral condition when 2 nd or 6 th gear is commanded, CB26 clutch system stuck OFF failure	DTC will set due to either a steady state or dynamic test failure <u>Dynamic test:</u> High speed mode: TOSS >= 60 RPM. High speed mode: command gear slip >= 100 RPM for time >= 2.25 seconds. Low speed mode: TOSS < 60 RPM. Low speed mode: turbine speed >= ((60 RPM * commanded gear ratio) + 100 RPM) for time >= 2.25 seconds.	<u>Dynamic test (shift in progress)</u> Transmission fluid temperature >= 0.0 DegC, no P0716, P0717, P0722, P0723, P1815, P1820, P1822, P1823, P1825, P1826, turbine speed >= 60 RPM, CB26 is on-coming clutch and CB26 on coming control is complete.	Dynamic test (shift in progress) Time ≥ 2.25 sec Continuous	CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_DSG_DfltGearOpt1Action, CeTRND_TorqMgntInhbAction, CeTRND_TUTD_InhbAction CeTRND_ForceTCC_OffAction CeTRND_MUMD_InhbAction CeTRND_TUTD_InhbAction CeTRND_TCC_SlndInhbAction (TFTKO)	A
	P2714 Steady State Test 2 nd Gear	Neutral when holding clutch CB26 is enabled for 2nd gear.	<u>Steady state test:</u> in sequence from 2nd gear: event 1: command gear is 2nd and gear box slip ≥ 100.0 RPM for time >= 3.0 sec, event 2: induce 3-4 upshift command gear is 3rd and 3rd gear gear box slip >= 35.2 RPM for time >= 4.0 sec, AND gear box slip >= 100.0 RPM for time >= 5.0 sec, C35R VBS is at maximum command pressure	<u>Steady state test:</u> Ignition vottage enable, No P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, High side driver is enabled, average driven wheel speed ≥ 80.0 RPM, side-to-side wheel speed diference ≤ 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) ≤ 7.0 % for time ≤ 6.0 sec, 2nd or 6th gear ratio achieved.	Steady State Test Time ≥ 3.0 sec Continuous	Same as Dynamic Test	A

Common engine speed enable: 500 RPM <= engine speed <= 5800 RPM for time >= 5.0 seconds
Common ignition voltage enable: 8.6 volts <= ignition voltage <= 19.0 volts
Common vehicle speed enable: 5.0 KPH <= vehicle speed for time >= 5.0 seconds

FA=Fault Active
FATKO=Fault Active This Key On
TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
	P2714 Steady State Test 6 th Gear	Neutral when holding clutch CB26 is enabled for 6th gear.	<u>Steady state test:</u> in sequence from 6th gear event 1: command gear is 6th and gear box slip \geq 100.0 RPM for time \geq 3.0 sec, event 2: induce 6-5 downshift command gear is 5th and 5th gear gear box slip \geq 35.2 RPM for time \geq 4.0 sec, AND gear box slip \geq 100.0 RPM for time \geq 5.0 sec, C35R VBS is at maximum command pressure	<u>Steady state test:</u> Ignition voltage enable, No P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, High side driver is enabled, average driven wheel speed \geq 80.0 RPM, side-to-side wheel speed difference \leq 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) \leq 7.0 % for time \leq 6.0 sec, 2nd or 6th gear ratio achieved.	Steady State Test Time \geq 3.0 sec Continuous	Same as Dynamic Test	Same as Dynamic Test
Pressure Control (PC) Solenoid D Stuck On [CB26]	P2715 Dynamic Test	Tie-up when on-coming clutch is CB26	Dynamic test: CB26 clutch command pressure = 0 kPa for time \geq CB26 zero capacity delay time, where CB26 zero capacity delay time = f(transmission fluid temperature) and ((on-coming clutch delta transition pressure > 50 kPa and 300 kPa < on-coming command clutch command pressure < 1950 kPa) or [CB26 clutch control state = exhaust and on-coming clutch control state = maximum pressure]). Attained gear slip \leq 40 RPM for time \geq calculated fail time, where calculated fail time = f(shift type, throttle position, transmission fluid temperature)	Dynamic test: Transmission fluid temperature \geq 0.0 DegC, no P0716, P0717, P0722, P0723, P1815, P1820, P1822, P1823, P1825, P1826. TOSS \geq 200 RPM, Turbine Speed \geq 200 RPM. CB26 is off-going clutch.	Dynamic test (shift in progress) Time \geq 1.2 sec Continuous	CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_DSG_DfltGearOpt4Action, CeTRND_TorqMgntInhbAction, CeTRND_TUTD_InhAction, CeTRND_ForceTCC_OffAction, CeTRND_MUMD_InhAction, CeTRND_TCC_SlndInhbAction (TFTKO)	A
Pressure Control (PC) Solenoid D Stuck On [CB26]	P2715 Steady State Test	Tie-up when holding clutch is CB26.	<u>Steady state test:</u> in sequence from command gear \neq 2nd OR OR \neq 6th gear: event 1: (scaling factor = 1 if command gear \neq 1st scaling factor = 2 if command gear = 1st) transmission output speed deceleration \geq (250 RPM/sec*scaling factor) for time \geq 0.250 sec, event 2: release holding clutch, see "ss tie-up test DTC map", 35.2 RPM \leq gear box slip \leq 100.0 RPM for 0.50 sec \leq time \leq 1.0 sec	<u>Steady state test:</u> Ignition voltage enable, No P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, Throttle position signal and engine torque signals valid from ECM, High side driver is enabled, brake state = off OR delta gear box torque \geq 250.0 Nm in time \leq 0.350 sec, (if command gear = 1 st free-wheel, throttle position \geq 10.0% and 120.0 Nm \leq engine torque \leq 1492.0 Nm), average driven wheel speed \geq 80.0 RPM, side-to-side wheel speed difference \leq 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) \leq 7.0 % for time \leq 6.0 sec, transmission output speed delta \geq 1300 RPM/sec or transmission output speed delta \geq 10 RPM/sec with PS3 Exhausted, command gear = 1 st , 3 rd , 4 th , or 5 th and gear ratio achieved.	Steady state: Time \geq 0.5 sec	Same as Dynamic Test	Same as Dynamic Test

Common engine speed enable: 500 RPM \leq engine speed \leq 5800 RPM for time \geq 5.0 seconds

Common ignition voltage enable: 8.6 volts \leq ignition voltage \leq 19.0 volts

Common vehicle speed enable: 5.0 KPH \leq vehicle speed for time \geq 5.0 seconds

FA=Fault Active

FATKO=Fault Active This Key On

TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
Pressure Control (PC) Solenoid D Control Circuit High	P2720	This DTC detects a continuous short to ground in the CB26 VBS control circuit	hardware circuitry detects high pressure error is true for 300 milliseconds in a 375 millisecond sample	P2720 is not fault active or test fail this key on, ignition voltage enable, engine speed enable	Fail time ≥ 0.30 sec in 0.375 sec sample Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Pressure Control (PC) Solenoid D Control Circuit Low	P2721	This DTC detects a continuous short to power or open in the CB26 VBS control circuit	hardware circuitry detects low pressure error is true for 300 milliseconds in a 375 millisecond sample	P2721 is not fault active or test fail this key on, ignition voltage enable, engine speed enable	Fail time ≥ 0.30 sec in 0.375 sec sample Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Pressure Control (PC) Solenoid E Stuck Off	P2723 Dynamic Test	Neutral when on-coming clutch C1234 is enabled.	Dynamic test: Transmission fluid temperature ≥ 0.0 DegC, no P0716, P0717, P0722, P0723, P1815, P1820, P1822, P1823, P1825, P1826, turbine speed ≥ 60 RPM, C1234 is on-coming clutch and C1234 on coming control is complete.	Dynamic test: High speed mode: TOSS ≥ 60 RPM. High speed mode: command gear slip ≥ 100 RPM for time ≥ 2.25 seconds. Low speed mode: TOSS < 60 RPM. Low speed mode: turbine speed ≥ ((60 RPM * commanded gear ratio) + 100 RPM) for time ≥ 2.25 seconds.	Dynamic test (shift in progress) Time ≥ 2.25 sec Continuous	CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_DSG_DfltGearOpt5Action, CeTRND_TUTD_InhbAction CeTRND_ForceTCC_OffAction CeTRND_TCC_SlndInhbAction CeTRND_MUMD_InhbAction (TFTKO)	A
	P2723 Steady State Test	Neutral when holding clutch C1234 is enabled for 1st gear.	Steady state test: in sequence from 1st gear: event 1: command gear is 1st and gear box slip ≥ 100.0 RPM for time ≥ 3.0 sec, event 2: induce 1-2 upshift command gear is 2nd and 2nd gear gear box slip ≥ 35.2 RPM for time ≥ 4.0 sec, AND gear box slip ≥ 100.0 RPM for time ≥ 5.0 sec, CB26 VBS is at maximum command pressure	Steady state test: Ignition vottage enable, No P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, High side driver is enabled, average driven wheel speed ≥ 80.0 RPM, side-to-side wheel speed difference ≤ 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) ≤ 7.0 % for time ≤ 6.0 sec, 1st, 2nd, 3rd, or 4th gear ratio achieved.	Time ≥ 3.0 sec Continuous	Same as Dynamic	

Common engine speed enable: 500 RPM ≤ engine speed ≤ 5800 RPM for time ≥ 5.0 seconds
 Common ignition voltage enable: 8.6 volts ≤ ignition voltage ≤ 19.0 volts
 Common vehicle speed enable: 5.0 KPH ≤ vehicle speed for time ≥ 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
	P2723 Steady state test	Neutral when holding clutch C1234 is enabled for 2nd gear.	Steady state test: in sequence from 2nd gear: event 1: command gear is 2nd and gear box slip \geq 100.0 RPM for time \geq 3.0 sec, event 2: induce 2-3 upshift command gear is 3rd and 3rd gear gear box slip \geq 35.2 RPM for time \geq 4.0 sec, AND gear box slip \geq 100.0 RPM for time \geq 5.0 sec, C35R VBS is at maximum command pressure	Steady state test: Ignition vottage enable, No P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, High side driver is enabled, average driven wheel speed \geq 80.0 RPM, side-to-side wheel speed diference \leq 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) \leq 7.0 % for time \leq 6.0 sec, 1st, 2nd, 3rd, or 4th gear ratio achieved.	Time \geq 3.0 sec Continuous	Same as Dynamic Test	
	P2723 Steady state test	Neutral when holding clutch C1234 is enabled for 3rd gear.	Steady state test: in sequence from 3rd gear: event 1: command gear is 3rd and gear box slip \geq 100.0 RPM for time \geq 3.0 sec, event 2: induce 3-4 upshift command gear is 4th and 4th gear gear box slip \geq 35.2 RPM for time \geq 4.0 sec, AND gear box slip \geq 100.0 RPM for time \geq 5.0 sec, C456 VBS is at maximum command pressure	Steady state test: Ignition vottage enable, No P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, High side driver is enabled, average driven wheel speed \geq 80.0 RPM, side-to-side wheel speed diference \leq 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) \leq 7.0 % for time \leq 6.0 sec, 1st, 2nd, 3rd, or 4th gear ratio achieved.	Time \geq 3.0 sec Continuous	Same as Dynamic Test	
	P2723 Steady state test	Neutral when holding clutch C1234 is enabled for 4th gear.	Steady state test: in sequence from 4th gear: event 1: command gear is 1st and gear box slip \geq 100.0 RPM for time \geq 3.0 sec, event 2: induce 4-5 upshift command gear is 5th and 5th gear gear box slip \geq 35.2 RPM for time \geq 4.0 sec, AND gear box slip \geq 100.0 RPM for time \geq 5.0 sec, C35R VBS is at maximum command pressure	Steady state test: Ignition vottage enable, No P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, High side driver is enabled, average driven wheel speed \geq 80.0 RPM, side-to-side wheel speed diference \leq 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) \leq 7.0 % for time \leq 6.0 sec, 1st, 2nd, 3rd, or 4th gear ratio achieved.	ime \geq 3.0 sec Continuous	Same as Dynamic Test	

Common engine speed enable: 500 RPM \leq engine speed \leq 5800 RPM for time \geq 5.0 seconds
 Common ignition voltage enable: 8.6 volts \leq ignition voltage \leq 19.0 volts
 Common vehicle speed enable: 5.0 KPH \leq vehicle speed for time \geq 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
Pressure Control (PC) Solenoid E Stuck On	P2724 Dynamic Test	Tie-up when off-going clutch is C1234 .	C1234 clutch command pressure = 0 kPa for time >= C1234 zero capacity delay time, where C1234 zero capacity delay time = f(transmission fluid temperature) and ((on-coming clutch delta transition pressure > 50 kPa and 300 kPa < on-coming command clutch command pressure < 1950 kPa) or [C1234 clutch control state = exhaust and on-coming clutch control state = maximum pressure]). Attained gear slip <= 40 RPM for time >= calculated fail time, where calculated fail time = f(shift type, throttle position, transmission fluid temperature)	Dynamic test: Transmission fluid temperature >= 0.0 DegC, no P0716, P0717, P0722, P0723, P1815, P1820, P1822, P1823, P1825, P1826. TOSS >= 200 RPM, Turbine Speed >= 200 RPM. C1234 is off-going clutch.	Dynamic test (shift in progress) Time ≥ 1.2 sec Continuous	CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_DSG_DfltGearOpt1Action, CeTRND_TorgMgntInhbAction, CeTRND_TUTD_InhAction, CeTRND_ForceTCC_OffAction, CeTRND_TCC_SlndInhbAction, CeTRND_MUMD_InhAction (TFTKO)	A
	P2724 Steady state test	Tie-up when holding clutch is C1234.	Steady state test: Ignition vorage enable, No P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, Throttle position signal and engine torque signals valid from ECM, High side driver is enabled, brake state = off OR delta gear box torque ≥ 250.0 Nm in time ≤ 0.350 sec, (if command gear = 1st free-wheel, throttle position ≥ 10.0% and 120.0 Nm ≤ engine torque ≤ 1492.0 Nm), average driven wheel speed ≥ 80.0 RPM, side-to-side wheel speed difference ≤ 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) ≤ 7.0 % for time ≤ 6.0 sec, transmission output speed delta ≥ 1300 RPM/sec and transmission output speed raw = 0.0 RPM, command gear = 5th or 6th and gear ratio achieved.	Steady state test: Ignition vorage enable, No P0716, P0717, P0722, P0723, P1915, P1825 DTCs FA AND TFTKO, Throttle position signal and engine torque signals valid from ECM, High side driver is enabled, brake state = off OR delta gear box torque ≥ 250.0 Nm in time ≤ 0.350 sec, (if command gear = 1 st free-wheel, throttle position ≥ 10.0% and 120.0 Nm ≤ engine torque ≤ 1492.0 Nm), average driven wheel speed ≥ 80.0 RPM, side-to-side wheel speed difference ≤ 150 RPM, delta wheel speed (average driven wheel to average non-driven wheel) ≤ 7.0 % for time ≤ 6.0 sec, transmission output speed delta ≥ 1300 RPM/sec or transmission output speed delta ≥ 10 RPM/sec with PS1 Exhausted, command gear = 5 th or 6 th and gear ratio achieved.	Time ≥ 0.5 sec. Continuous	Same as Dynamic	

Common engine speed enable: 500 RPM <= engine speed <= 5800 RPM for time >= 5.0 seconds
 Common ignition voltage enable: 8.6 volts <= ignition voltage <= 19.0 volts
 Common vehicle speed enable: 5.0 KPH <= vehicle speed for time >= 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
Pressure Control (PC) Solenoid E Control Circuit High	P2729	This DTC detects a continuous short to ground in the C1234 VBS control circuit	hardware circuitry detects high pressure error is true for 300 milliseconds in a 375 millisecond sample	P2729 is not fault active or test fail this key on, ignition voltage enable, engine speed enable	Fail time \geq 0.30 sec in 0.375 sec sample Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Pressure Control (PC) Solenoid E Control Circuit Low	P2730	This DTC detects a continuous short to power or open in the C1234 VBS control circuit	hardware circuitry detects low pressure error is true for 300 milliseconds in a 375 millisecond sample	P2730 is not fault active or test fail this key on, ignition voltage enable, engine speed enable	Fail time \geq 0.30 sec in 0.375 sec sample Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Torque Converter Clutch Pressure Control Solenoid Control Circuit Low	P2763	This DTC detects a continuous short to power or open in the TCC VBS control circuit	hardware circuitry detects high pressure error is true for 4.4 seconds in 5 second sample	P2763 is not fault active or test fail this key on, ignition voltage enable, engine speed enable, high side driver is enabled	Fail Time \geq 4.4 sec in a 5.0 sec sample Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Torque Converter Clutch Pressure Control Solenoid Control Circuit High	P2764	This DTC detects a continuous short to ground in the TCC VBS control circuit	hardware circuitry detects low pressure error is true for 4.4 seconds in 5 second sample	P2764 is not fault active or test fail this key on, ignition voltage enable, engine speed enable, high side driver is enabled	Fail Time \geq 4.4 sec in a 5.0 sec sample Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO)	A
Controller Area Network Bus Communication Error	U0073	TCM cannot communicate on the CAN Bus	GetCNDD_b_BusOffSt=TRUE for 5 counts (about 5 sec)	Ignition voltage enable	Fail Count = 5 out of 5 (Time \approx 5 sec) Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO) NOTE: CeTRND_EngSpdFitAction comes from CAN COM	A

Common engine speed enable: 500 RPM \leq engine speed \leq 5800 RPM for time \geq 5.0 seconds
 Common ignition voltage enable: 8.6 volts \leq ignition voltage \leq 19.0 volts
 Common vehicle speed enable: 5.0 KPH \leq vehicle speed for time \geq 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	DEFAULT ACTIONS	DTC TYPE
------------------	------------	--	-----------------------------------	--	---	-----------------	----------

Lost Communications with Engine Control System	U0100	Communication between TCM & Engine Control System Lost	No valid ECM CAN message for 12 counts (about 12 sec)	Ignition voltage enable	Fail Count = 12 out of 12 (Time ≈ 12 sec) Continuous	CeTRND_ForceHSD1_OffAction, CeTRND_ForceHSD2_OffAction, CeTRND_ForceTCC_OffAction, CeTRND_FreezeAdaptsAction, CeTRND_PCA_InhbAction, CeTRND_TCC_SlndInhbAction, CeTRND_TorqMgntInhbAction, (TFTKO) NOTE: CeTRND_EngSpdFitActio comes from CAN COM	A
--	-------	--	---	-------------------------	---	--	---

Common engine speed enable: 500 RPM <= engine speed <= 5800 RPM for time >= 5.0 seconds
 Common ignition voltage enable: 8.6 volts <= ignition voltage <= 19.0 volts
 Common vehicle speed enable: 5.0 KPH <= vehicle speed for time >= 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

P0741 Torque Vs TCC Slip Error Table

Torque (n-m)	TCC Slip Error (RPM)
0	50
64	50
128	50
192	50
256	50
320	50
384	50
448	50
512	50

P0711 Fail Case 4 Table

Start-Up Transmission Temperature (DegC)	Time for Transmission Temp to reach 20 DegC (sec)
-50	2500
-25	1000
-10	800
-5	520
20	200

Common engine speed enable: 500 RPM <= engine speed <= 5800 RPM for time >= 5.0 seconds
 Common ignition voltage enable: 8.6 volts <= ignition voltage <= 19.0 volts
 Common vehicle speed enable: 5.0 KPH <= vehicle speed for time >= 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

steady state tie-up test		DTC to set	C1234	C35R	CB26	C456/CBR1
command gear	holding clutch to release	attained gear				
1st LKD	C1234					
	CBR1	X				P2715
	CBR1	X				P0777
1st FW	C1234					
	no holding					P2715
	no holding					P0777
	no holding					797
2nd	C1234					
	CB26	X				
	CB26	X				P0797
3rd	C1234					
	C35R	X				P2715
	C35R	X				P0797
4th	C1234	X				
	C1234	X				P0777
	C456					P2715
5th	C456					
	C35R	X				P2724
	C35R	X				P2715
6th	C456					
	CB26	X				P2724
	CB26	X				P0777

Common engine speed enable: 500 RPM <= engine speed <= 5800 RPM for time >= 5.0 seconds
 Common ignition voltage enable: 8.6 volts <= ignition voltage <= 19.0 volts
 Common vehicle speed enable: 5.0 KPH <= vehicle speed for time >= 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TFTKO=Test Fail This Key On

08 GRP12a All Transmissions

Defaulted Gear Option	Variable Name	High Gear	Low Gear	Neutral Range	Reverse Range	OS shift RPM	DS Shift Hyst RPM	Engine RPM Over-run (OSS*Ratio>Eng RPM)
1	CeTRND_DS_DfltGearOpt1Action	5th	3rd	Neutral	Reverse	1470	400	3000
2	CeTRND_DS_DfltGearOpt2Action	3rd	1st	Neutral	Reverse	835	400	3000
3	CeTRND_DS_DfltGearOpt3Action	4th	1st	Neutral	Reverse	845	400	3000
4	CeTRND_DS_DfltGearOpt4Action	2nd	2nd	Neutral	Reverse	1520	400	3000
5	CeTRND_DS_DfltGearOpt5Action	5th	5th	Neutral	Reverse	1400	400	3000
6	CeTRND_DS_DfltGearOpt6Action	2nd	1st	Neutral	Reverse	825	400	3000
7	CeTRND_DS_DfltGearOpt7Action	3rd	3rd	Neutral	Reverse	1520	400	3000

Revision Log

Revision 0 - 22JUNE05 preliminary 2007 document

Revision 1 - 21JULY05 Descriptive Modifications

Revision 2 - 02Sept05 Descriptive Modifications

Revision 3 – 02NOV2005 Modifications

Revision 4 – 23Nov2005 Descriptive Modifications

- **NOTE: Author reserves the right to make changes and/or modifications without notice.**

Common engine speed enable: 500 RPM <= engine speed <= 5800 RPM for time >= 5.0 seconds
 Common ignition voltage enable: 8.6 volts <= ignition voltage <= 19.0 volts
 Common vehicle speed enable: 5.0 KPH <= vehicle speed for time >= 5.0 seconds

FA=Fault Active
 FATKO=Fault Active This Key On
 TFTKO=Test Fail This Key On