SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME REQUIRED AND FREQUENCY	MIL ILLUMINATION TYPE
MAF Sensor Range/Perf	P0101	0 to 240 gps 1000HZ to 12000HZ	Delta of 4-30 gps between the actual airflow and calculated airflow	Delta TPS < 2% EGR < 75% 9V > ign voltage < 16V Engine stable = 10 sec	395 test failures out of 400 tests 100 ms/test Continuous	DTC Type A
MAF Sensor Circuit Low Input	P0102	0 to 240 gps 1000HZ to 12000HZ	Frequency value < 1200HZ	RPM > 1 Ign voltage > 8V Conditions stable > 0.5 sec TPS < 75%	395 test failures out of 400 tests Every reference pulse	DTC Type A
MAF Sensor Circuit High Input	P0103	0 to 240gps 1000HZ to 12000HZ	Frequency value > 11500HZ	RPM > 1 Ign voltage > 8V Conditions stable > 0.5 sec TPS < 75%	395 test failures out of 400 tests Every reference pulse	DTC Type A
MAP Sensor Circuit - Low Input	P0107	This DTC detects a continuous short to low or open in either the signal circuit or the MAP sensor.	Raw MAP < 5 counts (12.2 kPa)	No TP sensor DTC's set Engine Running Throttle Position ≥ 0% when Engine speed is ≤ 1000 RPM or Throttle Position is ≥ 5% when Engine speed is > 1000 RPM	175 test failures within a 200 test sample. Every 3rd reference pulse	DTC Type B
MAP Sensor Circuit -High Input	P0108	This DTC detects a continuous short to high in either the signal circuit or the MAP sensor.	Raw MAP > 220 counts (91.5 kPa)	No TP sensor DTC's set Engine Running Throttle Position ≤ 2% when Engine speed is ≤ 3000 RPM or Throttle Position is ≤ 30% when Engine speed is > 3000 RPM	175 test failures within a 200 test sample. Every 3rd reference pulse	DTC Type B
Intake Air Temp. Sensor Circuit - Low Input	P0112	The DTC detects a continuous short to ground in the IAT signal circuit or the IAT sensor	Low Resistance Pullup Raw IAT < 7 counts (-34.75 C) High Resistance Pullup Raw IAT < 7 counts (-34.75 C)	No VS sensor DTC's set. No ECT sensor DTC's set No airflow sensor DTCs set Vehicle speed ≥ 25mph Engine run time > 30 seconds	175 test failures within a 200 test sample 100 ms/test Continuous	DTC Type B
Intake Air Temp. Sensor Circuit - High Input	P0113	The DTC detects a continuous open or short to high in the IAT signal circuit or the IAT sensor	Low Resistance pullup Raw IAT > 250 counts (147.5 C) High Resistance pullup Raw IAT > 250 counts (147.5 C)	No ECT sensor DTC's set No VS sensor DTC's set No airflow DTCs set Vehicle speed < 35mph Air flow < 12 g /second Coolant > 60°C Engine run time > 180 seconds	175 test failures within a 200 test sample 100 ms/test Continuous	DTC Type B

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME REQUIRED AND FREQUENCY	MIL ILLUMINATION TYPE
Engine Coolant Temp. Sensor Circuit-Low Input	P0117	The DTC detects a continuous short to ground in the ECTsignal circuit or the ECT sensor	Low Resistance Pullup Raw ECT < 37 counts (-12.25 C) High Resistance Pullup Raw ECT < 37 counts (-12.25 C)	Engine run time > 15 seconds	45 test failures within a 50 test sample 100 ms/test Continuous	DTC Type B
Engine Coolant Temp. Sensor Circuit-High Input	P0118	The DTC detects a continuous short to high or open in the ECT signal circuit or the ECT sensor	Low Resistance pullup Raw ECT > 247 counts (145.25 C) High Resistance pullup Raw ECT > 247 counts (145.25 C)	Engine run time > 3 seconds	45 test failures within a 50 test sample 100 ms/test Continuous	DTC Type B
Throttle Position Sensor Circuit Range/Rationality	P0121	The DTC detects a "skewed" or stuck TP sensor	The last throttle position value > or < predicted throttle position. Lookup table for stuck high or low based on engine RPM.	No TP sensor DTC's set or failures flagged No MAP sensor DTC's set Engine Running MAP < 50 kpa (stuck high) MAP > 70 kpa (stuck low) TP sensor Δ < 2%	95 test failures within a 100 test sample 12.5 ms/test Continuous	DTC Type A
Throttle Position Sensor Circuit- Low Input	P0122	This DTC detects a continuous short to low or open in either the signal circuit or the TP sensor.	Raw TP sensor signal < 2 counts (0.78%)	Engine running	95 test failures within a 100 test sample 12.5 ms/test Continuous	DTC Type A
Throttle Position Sensor Circuit- High Input	P0123	This DTC detects a continuous short to high in either the signal circuit or the TP sensor.	Raw TP sensor signal > 250 counts (97.66%)	Engine running	95 test failures within a 100 test sample 12.5 ms/test Continuous	DTC Type A
Min. Cool.Temp. to Allow C.L. Op. Not Achieved Without Excess. Time	P0125	The DTC detects if a stabilized minimum closed-loop is reached and maintained after engine start-up.	Minimum stabilized ECT = 20°C	No ECT sensor tests failing or DTC's set No IAT sensor DTC's set Vehicle speed > 5 mph IAT> 10°C ECT >10°C Start-up ECT <30°C Closed loop timer ≥120 seconds	20 consecutive test failures 100 ms/test Continuous	DTC Type B

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME REQUIRED AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-Low Voltage(Bank 1, Sensor 1)	P0131	This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady throttle and PE.	O2 sensor voltage < 0.175 volts or O2 sensor voltage < 0.600 volts in PE mode	No TP sensor DTC's No Evap/CCP DTC's No misfire DTC's No IAT sensor DTC's No MAP DTC's No Fuel trim DTC's No injector DTC's No EGR DTC's No EGR DTC's No ECT sensor DTC's No crank sensor DTC's No MAF DTC's Closed loop Air/Fuel ratio ≥ 14.4 but ≤ 14.9 Throttle position > 3% but < 40% Above met for 50 secounds	400 test failures in a 500 test sample 4 sets of samples 100 ms/test Continuous	DTC Type B
O2S Circuit-High Voltage(Bank 1, Sensor 1)	P0132	This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and DFCO	O2 sensor voltage > 0.975 volts or O2 sensor voltage > 0.110 volts in DFCO mode	No TP sensor DTC's No Evap/CCP DTC's No misfire DTC's No IAT sensor DTC's No MAP DTC's No Fuel trim DTC's No injector DTC's No EGR DTC's No ECT sensor DTC's No crank sensor DTC's No MAF DTC's Closed loop Air/Fuel ratio ≥ 14.4 but ≤ 14.9 Throttle position > 3% but < 40% Above met for 10 secounds	40 test failures in a 100 test sample 4 sets of samples 100 ms/test Continuous	DTC Type B

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME REQUIRED AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-Slow Response(Bank 1, Sensor 1)	P0133	This DTC determines if the O2 sensor functioning properly by checking its response time.	O2 sensor average transition time: L/R > 153 msec R/L > 148 msec	No TP sensor DTC's No Evap/CCP DTC's No misfire DTC's No IAT sensor DTC's No MAP DTC's No MAP DTC's No injector DTC's No injector DTC's No EGR DTC's No EGR DTC's No ECT sensor DTC's No crank sensor DTC's No map DTC's To crank sensor DTC's No MAF DTC's DTC P0135 (O2 Heater) not set Closed loop for > 60 sec C2 voltage low threshold .300 and high threshold .600 V Coolant temp > 85C 1000 < RPM < 3000 15qps < MAF < 28 qps	60 seconds after closed loop enable Once per key cycle	DTC Type B
O2S Circuit-No Activity Detected (Bank 1,Sensor 1)	P0134	This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 0.400V but < 0.500V	No TP sensor DTC's No Evap/CCP DTC's No misfire DTC's No IAT sensor DTC's No MAP DTC's No Fuel trim DTC's No injector DTC's No EGR DTC's No ECT sensor DTC's No crank sensor DTC's No MAF DTC's Engine run time > 30 seconds ECT >65°C	190 test failures in a 200 test sample 100 ms/test Continuous	DTC Type B
O2S Heater Circuit Malfunction (Bank 1, Sensor 1)	P0135	This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	The elapsed time to obtain ± .150V from the mean O2 bias voltage. *Time based on table: Time vs. Avg. MAF + Start up coolant offset.	No TP sensor DTC's No Evap/CCP DTC's No misfire DTC's No MAP DTC's No MAP DTC's No Fuel trim DTC's No EGR DTC's No EGR DTC's No ECT sensor DTC's No ecrank sensor DTC's No MAF DTC's Engine run time > 3 seconds Δ ECT vs. IAT < 5 °C ECT < 100°C IAT < 100°C Avg MAF < 20gps 9 < System Voltage < 16 for 3 seconds350 V < Avg. Bias < .500 V.	From cold start to a maximum time of 155 seconds. *Time determined by table. Once per key cycle	DTC Type B

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME REQUIRED AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-Low Voltage(Bank 1, Sensor 2)	P0137	This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady throttle and PE.	O2 sensor voltage < 0.010 volts or O2 sensor voltage < 0.600 volts in PE mode	No TP sensor DTC's No Evap/CCP DTC's No misfire DTC's No IAT sensor DTC's No MAP DTC's No Fuel trim DTC's No injector DTC's No EGR DTC's No EGR DTC's No ECT sensor DTC's No crank sensor DTC's No MAF DTC's ECT > 65C Closed loop Air/Fuel ratio ≥ 14.4 but ≤ 14.9 Throttle position > 3% but < 40% Above met for 150 secounds	1400 test failures in a 1500 test sample 4 sets of samples 100 ms/test Continuous	DTC Type B
O2S Circuit-High Voltage(Bank 1, Sensor 2)	P0138	This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and DFCO	O2 sensor voltage > 0.999 volts or O2 sensor voltage > 0.200 volts in DFCO mode	No TP sensor DTC's No Evap/CCP DTC's No misfire DTC's No IAT sensor DTC's No MAP DTC's No Fuel trim DTC's No injector DTC's No injector DTC's No EGR DTC's No ECT sensor DTC's No ecrank sensor DTC's No MAF DTC's ECT > 65C Closed loop Air/Fuel ratio ≥ 14.4 but ≤ 14.9 Throttle position > 3% but < 40% Above met for 10 secounds	750 test failures in a 1000 test samples 4 sets of samples 100 ms/test Continuous	DTC Type B

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME REQUIRED AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-No Activity Detected (Bank 1,Sensor 2)	P0140	This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 0.400V but < 0.500V	No TP sensor DTC's No Evap/CCP DTC's No misfire DTC's No IAT sensor DTC's No MAP DTC's No Fuel trim DTC's No injector DTC's No EGR DTC's No ECT sensor DTC's No crank sensor DTC's No MAF DTC's Engine run time > 30 seconds ECT > 65°C	1400 test failures in a 1500 test sample 100 ms/test Continuous	DTC Type B
O2S Heater Circuit Malfunction (Bank 1, Sensor 2)	P0141	This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	The elapsed time to obtain ± .150V from the mean O2 bias voltage. *Time based on table: Time vs. Avg. MAF + Start up coolant offset.	No TP sensor DTC's No Evap/CCP DTC's No misfire DTC's No IAT sensor DTC's No MAP DTC's No Fuel trim DTC's No injector DTC's No EGR DTC's No ECT sensor DTC's No crank sensor DTC's No MAF DTC's Engine run time > 3 seconds Δ ECT vs. IAT < 5 °C ECT < 100°C IAT < 100°C Avg MAF < 28 gps 9 < System Voltage < 16 for 3 seconds350 V < Avg. Bias < .500 V.	From cold start to a maximum time of 409 seconds. *Time determined by table. Once per key cycle	DTC Type B

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME REQUIRED AND FREQUENCY	MIL ILLUMINATION TYPE
System Too Lean (Bank 1)	P0171	Determines if the system is in a lean condition.	The average of short term fuel trim samples ≥ 1.08 and The average of adaptive index multiplier samples ≥ 1.2	The following DTC's are not set: VSS DTC's EST DTC's Crank sensor DTC's Cam sensor DTC's TPS DTC's Misfire DTC's Injector DTC's MAF DTC's O2 sensor DTC's MAP DTC's EGR DTC's EVap. DTC's EVap. DTC's IAT DTC's Throttle position < 90% Engine speed > 550 rpm but < 5000 rpm Baro > 70 kpa ECT > 20°C but < 110°C MAP > 18 kpa but < 95 kpa IAT > -20 °C but < 65°C Air flow > 3.5 g/s < 175 g/s Vehicle speed < 75 mph	30 samples failing lean ≥ 5 sets of samples Continuous	DTC Type B
System Too Rich (Bank 1)	P0172	Determines if the system is in a rich condition.	The average of short term fuel trim samples ≤ 0.985 and The average of adaptive index multiplier samples < 0.80	The following DTC's are not set: VSS DTC's EST DTC's Crank sensor DTC's Cam sensor DTC's Amsensor DTC's Misfire DTC's IAC DTC's Injector DTC's MAF DTC's O2 sensor DTC's MAP DTC's EGR DTC's EGR DTC's EVap. DTC's ECT DTC's IAT DTC's Throttle position < 90% Engine speed > 550 rpm but < 5000 rpm Baro > 70 kpa ECT > 20 °C but < 110 °C MAP > 18 kpa but < 95 kpa IAT > -20 °C but < 65 °C Air flow > 3.5 g/s < 175 g/s Vehicle speed < 75 mph	30 samples failing rich ≥ 5 sets of samples Continuous	DTC Type B

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME REQUIRED AND FREQUENCY	MIL ILLUMINATION TYPE
O2 Sys. Fault - Too Few O2S R/L or L/R Switches, Insufficient Activity (Bank 1, Sensor 1)	P1133	This DTC determines if the O2 sensor functioning properly by monitoring the number of L/R and R/L switches.	Number of switches in 100 seconds: L/R switches < 40 R/L switches < 40 O2 voltage between .300 and .600V	No Misfire DTC's No Crank sensor DTC's No injector DTC's No MAF DTC's No TP sensor DTC's No Evap. DTC's No IAT sensor DTC's No MAP DTC's No Fuel trim DTC's No EGR DTC's No ECT sensor DTC's DTC P0135 (O2 Heater) not set Closed loop	100 seconds after closed loop enable Once per key cycle	DTC Type B
O2S Incorrect Ratio (Bank 1, Sensor 1)	P1134	This DTC diagnoses degraded slow rich to lean or lean to rich response times.	Ratio of average response times. Ratio > 5.0 or < 0.4 O2 voltage between .300 and .600V	No Misfire DTC's No Crank sensor DTC's No injector DTC's No MAF DTC's No TP sensor DTC's No Evap. DTC's No IAT sensor DTC's No MAP DTC's No Fuel trim DTC's No EGR DTC's No ECT sensor DTC's DTC P0135 (O2 Heater) not set Closed loop	100 seconds after closed loop enable Once per key cycle	DTC Type B
Injector Circuit Fault	P1200	9V - 16V	Output state is invalid		5 sec Continuous	DTC Type B

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME REQUIRED AND FREQUENCY	MIL ILLUMINATION TYPE
Random Misfire Detected Cylinder 1 Misfire Detected	P0300 P0301	These DTC 's will determine if a random misfire or a cylinder specific misfire is occurring by	Deceleration index vs Engine Speed vs Load and Camshaft Position	Engine run time > 0-5 sec depending on start up rpm No VSS DTC's No transmission DTC's No fuel trim DTC's	Emission Level: 5 failed 200 revolution blocks out of 16 Catalyst Damaging Level	DTC Type B EMISSION DTC Type
Cylinder 2 Misfire Detected	P0302	monitoring crankshaft velocity.	FTP Threshold - 1.85%	No TP sensor DTC's No MAP sensor DTC's No ECT sensor DTC's No Evap DTC's No O2 sensor DTC's	1 failed 200 revolution block Continuous	A CATALYST DAMAGING
Cylinder 3 Misfire Detected	P0303 Catalyst Damage - see speed/ load chart	No Injector DTC's No EST DTC's No EGR DTC's				
Cylinder 4 Misfire Detected	P0304			No Crank sensor DTC's No Cam sensor DTC's No MAF sensor DTC's Fuel cutoff not active		
Cylinder 5 Misfire Detected	P0305			Brake torque management not active Fuel level > 10% ECT > -6.75°C but < 120°C		
Cylinder 6 Misfire Detected	P0306			Engine speed > 450 RPM but < 5800 RPM System voltage > 9 volts but < 16 volts + Throttle position Δ < 6.25%/100ms - Throttle position Δ < 1.5%/100ms Rough Road- Ratio of consecutive positive peak delta ref times to nonconsecutive peaks.		
Crankshaft Position Sensor Circuit- Range/Perf	P0336	24X Signal This diagnostic will detect an incorrect signal from the crankshaft sensor.	If in one engine cycle 48 med. res. pulses are not seen	Engine run time > 3 sec 3X crank signal	450 ref pulse failures within a 500 sample limit. 100 ms/test Continuous	DTC Type B
Camshaft Position Sensor Circuit Range/Perf	P0341	1X Signal This diagnostic will detect if the Cam Sensor signal is present.	Engine Running Cam Sensor reference pulse is not seen once every Engine cycle.		If Cam signal is not detected 450 out of 500 test samples. 100 ms/test Continuous	DTC Type B

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME REQUIRED AND FREQUENCY	MIL ILLUMINATION TYPE
Crank Angle Sensor Learned Error	P1336	This DTC will determine if the machining tolerence in the crankshaft system has been learned by the vehicle.	Sum of compensation factors not within range	PCM state = run	0.5 sec 100ms loop Continuous	DTC Type A
EST Output High	P1350	This diagnostic will determine if a failure has occured due to an open circuit.	EST voltage > 4.9 V	EST Enabled Engine speed < 450 RPM	EST circuit open ≥ 5 sec Once per igniton cycle	DTC Type B
EST Not Toggling After Enable	P1361	This diagnostic will determine if a failure has occured due to a grounded circuit.	EST voltage < 0.04V	EST Enabled Engine speed > 600 RPM No P1350 DTC	> 10 seconds Once per igniton cycle	DTC Type B
Crank to Low Res Correlate	P1374	Pulsed 0V to 10V	3X signal 24X signal	Engine runtime > 3 sec Incorrect number of 3X signals per engine cycle	450 out of 500 test samples 100 ms/test Continuous	DTC Type B

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME REQUIRED AND FREQUENCY	MIL ILLUMINATION TYPE
Exhaust Gas Recirculation - Insufficient Flow Detected	P0401	This diagnostic will determine if there is a reduction in EGR flow.	With EGR valve open, the peak + MAP Δ is monitored over a time of 2.5 seconds. This value is compared with a threshold from Engine Speed vs Baro table and the difference computed. The result is statistically filtered (EWMA) and compared to a decision limit. DTC is set when the filtered result exceeds the decision limit.	Test Enable No Injector DTC's set No Crank Sensor DTC's set No TP sensor DTC's set No MAP DTC's set No MAP DTC's set No IAT sensor DTC's set No IAT sensor DTC's set No IAT Sensor DTC's set No IAC DTC's set No IAC DTC's set No Linear EGR Pintle Position DTC set No Misfire DTC's set No MAF DTC's set No MAF DTC's set No MAF DTC's set MAP Δ < .4 KPA RPM Δ < 200 MPH Δ < 5 ECT > 80° C Baro > 65 kpa (12000 ft) Vehicle Speed > 30 mph IAC Δ < 2 counts AC clutch status is unchanged Transmission status is unchanged Transmission < 1% EGR Position < 1% EGR Position < 1% Engine Speed > 800 rpm but < 1500 rpm MAP Δ < 1.5 A/D count Compensated MAP > 20 kpa but < 50 kpa Run Test Stabilized MAP (valve closed) recorded and EGR valve "ramped" open over a time interval and peak MAP value recorded and MAP Δ computed. EGR valve "ramped" closed over a time interval.	2.5 seconds Once per trip or 13 times after NVM Failure.	DTC Type A

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME REQUIRED AND FREQUENCY	MIL ILLUMINATION TYPE
Catalyst System Efficiency Below Threshold	P0420	This diagnostic will determine the efficiency of the catalytic converter.	Deviation Difference Average = 14 mv from O2 sensor #2	No EST DTC's set No EGR DTC's set No MAT DTC's set No injector DTC's set No VS sensor DTC's set No VS sensor DTC's set No O2 sensor DTC's set No Misfire DTC's set No Misfire DTC's set No MAP sensor DTC's set No ECT sensor DTC's set No ECT sensor DTC's set No ECT sensor DTC's set No Evap DTC's set No Evap DTC's set No Evap DTC's set No Crank sensor DTC's set Converter Warm Up Status Engine in closed loop Commanded Air/Fuel ratio = 14.7:1 ECT > 75° C Air flow > 15 g/sec Catalyst is warm Test Enable Air Flow \leq 30 g/sec Δ engine load \leq 70% / sec Vehicle Speed \geq 40 mph but \leq 75 mph Engine load \leq 63% 1000 rpm \leq Engine speed \leq 3000 rpm	50 tests per trip Continuous	DTC Type A
Evap. Emission Control System - Malfunction	P0440	This diagnostic will detect a missing gas cap or a "gross" leak in the evap system.	Tank Vacuum has not reached 7.9" H2O and Test timer > 37.5 sec (Evap. Leak > 0.080")	No IAT DTC's set No MAP DTC's set No TP sensor DTC's set No Air flow DTC's set No O2 DTC's set No VSS DTC's set No Misfire DTC's set No Fuel Trim/Fuel Injector DTC's set No EGR DTC's set No Coolant DTC's set No AIR (if applicable) DTC's set Baro > 75 kPa (8000 ft) 4.4° ≤ Powerup ECT ≤ 30°C 4.4° ≤ Powerup IAT ≤ 30°C ECT-IAT no more than 8°C at start up IAT-ECT no more than 2°C at start up 15% ≤ Fuel Level ≤ 85% 8V < System Voltage < 16V	Test runs once per cold trip if all conditions are met. Test begins at 180s after start and ends when tank vacuum reaches 7.9" H2O or timer expires (37.5 sec).	DTC Type A (Behaves like Type B)

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME REQUIRED AND FREQUENCY	MIL ILLUMINATION TYPE
Evap. Emission System Leak Detection	P0442	This diagnostic will detect a smal leak in the evap system. Test begins after "gross" leak test and monitors the vacuum decay in the system. If vacuum decay slope exceeds threshold, ststem monitors for fuel vapor generation	Vacuum decay slope > calibrated threshold based on IAT and fuel level and excessive vapor generation is not present (Evap system leak between 0.040" and 0.080")	No IAT DTC's set No MAP DTC's set No TP sensor DTC's set No Air flow DTC's set No O2 DTC's set No VSS DTC's set No WSS DTC's set No Misfire DTC's set No Fuel Trim/Fuel Injector DTC's set No EGR DTC's set No Coolant DTC's set No AIR (if applicable) DTC's set Baro > 75 kPa (8000 ft) 4.4° ≤ Powerup ECT ≤ 30°C 4.4° ≤ Powerup IAT ≤ 30°C ECT-IAT no more than 8°C at start up IAT-ECT no more than 2°C at start up 15% ≤ Fuel Level ≤ 85% 8V < System Voltage < 16V	Test runs once per cold trip if all conditions are met.	DTC Type A (Behaves like Type B)
Evap. Emission Control System - Air Vent Circuit Fault	P0446	This diagnostic will detect a blockage in the evap system which would keep the system from venting. Test begins after small leak test and monitors tank vacuum for a period of time.	Tank Vacuum < 10" H2O for 4 seconds	No IAT DTC's set No MAP DTC's set No TP sensor DTC's set No Air flow DTC's set No O2 DTC's set No VSS DTC's set No WSS DTC's set No Fuel Trim/Fuel Injector DTC's set No Fuel Trim/Fuel Injector DTC's set No EGR DTC's set No Coolant DTC's set No AIR (if applicable) DTC's set Baro > 75 kPa (8000 ft) 4.4° ≤ Powerup ECT ≤ 30°C 4.4° ≤ Powerup IAT ≤ 30°C ECT-IAT no more than 8°C at start up IAT-ECT no more than 2°C at start up 15% ≤ Fuel Level ≤ 85% 8V < System Voltage < 16V	4 seconds Test runs once per cold trip if all conditions are met.	DTC Type A (Behaves like Type B)
Exhaust Gas Recirculation System - Pintle Position Error	P1406	This diagnostic will detect three conditions: 1. An open or short 2. Closed valve position too high 3. Position error too high	Pintle position < 7 A/D counts for 20 seconds Pintle position > 20 A/D counts from learned closed valve position for 20 seconds Deviation between actual position and desired position > 20% for 20 seconds	Ignition voltage > 9 volts 5 volt supply OK	All three tests must run before a 'test passed' is reported. Continuous	DTC Type B

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME REQUIRED AND FREQUENCY	MIL ILLUMINATION TYPE
Evap. Emission Control System - Open Purge Flow	P1441	This diagnostic will detect a purge solenoid stuck open. Test begins after Vent Circuit test and monitors tank vacuum after the system is sealed.	Tank Vacuum > 11" H2O within 25 sec.	No IAT DTC's set No MAP DTC's set No TP sensor DTC's set No Air flow DTC's set No O2 DTC's set No VSS DTC's set No WSS DTC's set No Misfire DTC's set No Fuel Trim/Fuel Injector DTC's set No EGR DTC's set No Coolant DTC's set No Coolant DTC's set No AIR (if applicable) DTC's set Baro > 75 kPa (8000 ft) $4.4^{\circ} \le \text{Powerup ECT} \le 30^{\circ}\text{C}$ $4.4^{\circ} \le \text{Powerup IAT} \le 30^{\circ}\text{C}$ ECT -IAT no more than 8°C at start up $15\% \le \text{Fuel Level} \le 85\%$ $8V < \text{System Voltage} < 16V$	Test runs once per cold trip if all conditions are met.	DTC Type B
Idle Control System RPM Lower Than Expected	P0506	This DTC will determine if a low idle condition exists. A low idle condition exists if the Actual RPM is below the desired RPM.	RPM < (Desired RPM - Δ RPM) Δ RPM from table based on RPM vs. ECT (Max Δ RPM = 100)	Test Enable: No CCP DTC's set No misfire DTC's set No EGR DTC's set No YS sensor DTC's set No VS sensor DTC's set No ECT DTC's set No ECT DTC's set No IAT DTC's set No IAT DTC's set No Injector DTC's set No Injector DTC's set No Injector DTC's set No Crank Sensor DTC's set No Air Flow DTC's set ECT > 70°C System Voltage > 9V but < 16 V IAT > -18°C Engine run time > 120 seconds Baro > 65 kPa (12000 ft) TP < 1.5% VS < 3 MPH Above met for a time > 5 seconds to enable diagnostic.	15 seconds Continous after enable	DTC Type B

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME REQUIRED AND FREQUENCY	MIL ILLUMINATION TYPE
Idle Control System RPM Higher Than Expected	P0507	This DTC will determine if a high idle condition exists. A high idle condition exists if the Actual RPM is above the desired RPM.	RPM > (Desired RPM + Δ RPM) Δ RPM from table based on RPM vs. ECT (Max Δ RPM =175)	Test Enable: No CCP DTC's set No misfire DTC's set No EGR DTC's set No FP sensor DTC's set No VS sensor DTC's set No ECT DTC's set No ECT DTC's set No MAP DTC's set No IAT DTC's set No IAT DTC's set No Injector DTC's set No Injector DTC's set No Crank Sensor DTC's set No Air Flow DTC's set ECT > 70°C System Voltage > 9V but < 16 V IAT > -18°C Engine run time > 120 seconds Baro > 65 kPa (12000 ft) TP < 1.5% VS < 3 MPH Above met for a time > 5 seconds to enable diagnostic.	15 seconds Continous after enable	DTC Type B
Check Sum Error	P0601	This DTC will be stored if the calibration check sum is incorrect	Output state invalid	PCM state = crank or run	0.5 sec 50ms loop Continuous	DTC Type B
PCM Programming Error	P0602	This DTC will be stored if the PCM has been replaced and has not been programmed	Output state invalid	PCM state = crank or run	0.5 sec 100ms loop Continuous	DTC Type B
V5BA Voltage Circuit Fault	P1635	5 Volts	Voltage state invalid		10 sec Continuous	DTC Type B
Fan 1 Relay Circuit Fault	P1651	0V to 12V	Output state invalid	PCM state = crank or run	20 sec Continuous	DTC Type B
CCP Solenoid Circuit Malfunction	P1655	0V to 12V	Output state invalid	PCM state = crank or run	20 sec Continuous	DTC Type B
CCP Vent Solenoid Circuit Malfunction	P1675	0V to 12V	Output state invalid	PCM state = crank or run	20 sec Continuous	DTC Type B