

**1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS**

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Mass Air Flow Sensor Circuit - Range/Rationality	P0101	0 kHz - 13 kHz Under conditions when the two should match, the Mass Air Flow reading should match calculated Mass Air Flow (based on speed density. If delta Mass Air Flow is too large, a faulty Mass Air Flow condition exists, such as a "skewed" sensor.	MAF $\Delta \geq$ a table value determined by the difference between the MAF sensor reading and the speed density calculation.	Engine Running TP sensor DTC's not active. MAP sensor DTC's not active. Evap. DTC's not active EGR DTC P0401 not active MAF sensor high / low DTC's not active. Crank Sensor DTC's not active IAT Sensor DTC's not active System voltage > 11V but < 16V Canister Purge DC $\leq$ 99.6% TP $\Delta \leq$ 3.9% EGR DC $\leq$ 89.8% EGR Pintle Position $\leq$ 89.8% Engine vacuum $\leq$ 75 kPa Throttle Position $\leq$ 89.8% The above must be present for a period of time greater than 2 seconds.	50 test failures within a 100 test sample.  Time necessary to complete sample: 10 sec  The Mass Air Flow reading and Mass Air Flow calculation are performed during the same cylinder event every 100 ms.	DTC Type A
Mass Air Flow Sensor Circuit - Low Input	P0102	0kHz - 13 kHz This DTC will determine if the MAF frequency is too low.	<b>LOW FREQUENCY TEST:</b> MAF $\leq$ 10 Hz	<b>LOW FREQUENCY TEST:</b> Engine Running Engine Run Time $\geq$ 0.4 seconds Engine Speed $\geq$ 300 RPM System Voltage $\geq$ 8 Volts The above must be present for a period of time greater than 0 seconds.	<b>LOW FREQUENCY TEST:</b> 4 test failures within a 16 test sample.  Time necessary to complete sample: 1 sec at 500 RPM  Test is run at every reading of the Mass Air Flow sensor frequency.	DTC Type A
Mass Air Flow Sensor Circuit - High Input	P0103	0kHz - 13 kHz This DTC will determine if the MAF frequency is too high	<b>HIGH FREQUENCY TEST:</b> MAF $\geq$ 11000 Hz	<b>HIGH FREQUENCY TEST:</b> Engine Running Engine Run Time $\geq$ 0.4 seconds Engine Speed $\geq$ 300 RPM System Voltage $\geq$ 8 Volts The above must be present for a period of time greater than 0 seconds.	<b>HIGH FREQUENCY TEST:</b> 6 test failures within a 16 test sample.  Time necessary to complete sample: 1 sec at 500 RPM  Test is run at every reading of the Mass Air Flow sensor frequency.	DTC Type A

## 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
MAP Sensor - Range/Rationality	P0106	.3V to 5.0V Under proper conditions, the MAP value should be within a window (based on throttle position and engine speed). If not, a faulty MAP condition such as a "skewed" sensor exists.	A table defining the minimum acceptable MAP value $\leq$ MAP $\leq$ a table defining the maximum acceptable MAP value	TP sensor DTC's not active Engine Running Engine Speed $\Delta < 75$ RPM Throttle Position $\Delta < 1.5\%$ Idle Air $\Delta < 4$ steps EGR Flow Rate $\Delta < 2\%$ Brake Switch State = no change Clutch Switch State = no change  AC Clutch State = no change Above stabilized for 2 seconds EGR DTC's not active Engine Speed $\geq 400$ RPM Engine Speed $\leq 5000$ RPM	24 test failures within a 100 test sample.  Time necessary to complete sample: 100 sec  Continuous	DTC Type B
MAP Sensor Circuit - Low Input	P0107	.3V to 5.0V This DTC detects a continuous short to low or open in either the signal circuit or the MAP sensor.	Raw MAP $< 0.04$ Volts (3 counts)	TP sensor DTC's not active Engine Running Throttle Position $\geq 0\%$ when Engine speed is $\leq 800$ RPM <b>or</b> Throttle Position is $\geq 12.5\%$ when Engine speed is $> 800$ RPM	40 test failures within a 100 test sample.  Time necessary to complete sample is based on engine speed. At 1600 RPM, the time would be 1 sec.  Continuous	DTC Type A
MAP Sensor Circuit - High Input	P0108	.3V to 5.0V This DTC detects an open sensor ground or continuous short to high in either the signal circuit or the MAP sensor.	Raw MAP $> 4.4$ Volts (222 counts)	Cold Start Run Time - Table value in seconds based on Powerup Coolant Temperature. <b>Run Test</b> TP sensor DTC's not active Throttle Position $\leq 0.4\%$ when Engine speed is $\leq 1200$ RPM <b>or</b> Throttle Position is $\leq 20\%$ when Engine speed is $> 1200$ RPM	40 test failures within a 100 test sample.  Time necessary to complete sample is based on engine speed. At 1600 RPM, the time would be 1 sec.  Continuous	DTC Type A
Intake Air Temp. Sensor Circuit -Low Input	P0112	.24V to 5.0V The DTC detects a continuous short to ground in the IAT signal circuit or the IAT sensor	<b>Low Resistance pull-up</b> Raw IAT $< 0.82$ Volts <b>High Resistance pull-up</b> Raw IAT $< 0.07$ Volts	VS sensor DTC's not active Vehicle speed $\geq 2$ mph Engine run time $> 100$ seconds	40 test failures within a 100 test sample  Time necessary to complete sample: 12.5 sec  Continuous	DTC Type A
Intake Air Temp. Sensor Circuit - High Input	P0113	.24V to 5.0V The DTC detects a continuous open or short to high in the IAT signal circuit or the IAT sensor	<b>Low Resistance pull-up</b> Raw IAT $> 4.9$ Volts <b>High Resistance pull-up</b> Raw IAT $> 4.9$ Volts	ECT sensor DTC's not active VS sensor DTC's not active MAF sensor DTC's not active Vehicle speed $< 2$ mph Mass Air flow $< 250$ g /s Coolant Temperature $> 84.7^\circ\text{C}$ Engine run time $> 100$ seconds	40 test failures within a 100 test sample  Time necessary to complete sample: 12.5 sec  Continuous	DTC Type A

98t50M\_LD\_yE.DOC

## 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Engine Coolant Temp. Sensor Circuit-Low Input	P0117	.24V to 5.0V The DTC detects a continuous short to ground in the ECT signal circuit or the ECT sensor	<b>Low Resistance pull-up</b> Raw ECT < 0.25 Volts <b>High Resistance pull-up</b> Raw ECT < 0.25 Volts	Engine run time > 5 seconds	40 test failures within a 100 test sample  Time necessary to complete sample: 50 sec  Continuous	DTC Type A
Engine Coolant Temp. Sensor Circuit-High Input	P0118	.24V to 5.0V The DTC detects a continuous short to high or open in the ECT signal circuit or the ECT sensor	<b>Low Resistance pull-up</b> Raw ECT > 4.9 Volts <b>High Resistance pull-up</b> Raw ECT > 4.9 Volts	Engine run time > 5 seconds	40 test failures within a 100 test sample  Time necessary to complete sample: 50 sec  Continuous	DTC Type A
Throttle Position Sensor Circuit-Range/Rationality	P0121	.5V to 5.0V The DTC detects a "skewed" or stuck TP sensor	<b>Stuck high test:</b> The last throttle position value is > predicted throttle position based on engine RPM.  <b>Stuck low test:</b> The last throttle position value is < predicted throttle position based on engine RPM.	<b>Test Enable:</b> No TP sensor short DTC's active No IAC DTC's active No MAP DTC's active Engine running BARO not defaulted TP Δ < 1.9% <b>Stuck high test:</b> MAP < 50 kPa  <b>Stuck low test:</b> Stuck high test has passed MAP > 65 kPa IAC > 10 counts but < 340 counts	<b>Stuck high test:</b> 50 test failures within a 100 test sample  <b>Stuck low test:</b> 50 test failures within a 100 test sample  Time necessary to complete each sample: 10 sec  Continuous	DTC Type B
Throttle Position Sensor Circuit-Low Input	P0122	.5V to 5.0V This DTC detects a continuous short to low or open in either the signal circuit or the TP sensor.	TP sensor signal voltage < 0.25 volts (13 counts)	Engine running	5 consecutive test failures within a 10 test sample  Time necessary to complete sample: 1 sec  Continuous	DTC Type A
Throttle Position Sensor Circuit-High Input	P0123	.5V to 5.0V This DTC detects a continuous short to high in either the signal circuit or the TP sensor.	TP sensor signal voltage > 4.7 volts (242 counts)	Engine running	5 consecutive test failures within a 10 test sample  Time necessary to complete sample: 1 sec  Continuous	DTC Type A

98t50M\_LD\_yE.DOC

**1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS**

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Min. Cool. Temp. to Allow C.L. Op. Not Achieved Without Excess. Time	P0125	.24V to 5.0V The DTC detects if a stabilized minimum closed-loop is reached and maintained after engine start-up.	<p>Minimum stabilized ECT &lt;20°C after 480 seconds</p> <p>Minimum stabilized ECT &lt; 20°C after 300 seconds.</p> <p>Minimum stabilized ECT &lt; 20°C after 120 seconds.</p>	<p><b>Diagnostic Enable</b> Engine running ECT sensor short tests not failing or DTC's not active IAT sensor DTC's not active IAT &gt; - 40°C ECT &gt; - 40°C Start-up ECT ≤ 40°C <b>Closed Loop Test:</b> For a vehicle saturated at -40°C (-40°F) Accumulated air flow since start &gt; 7500 (V6) 9000 (V8)grams Accumulated Idle time &lt; 360 seconds</p> <p>For a vehicle saturated at -7°C (20°F) Accumulated air flow since start &gt; 4500(V6) 5500(V8)grams Accumulated Idle time &lt; 225 seconds</p> <p>For a vehicle saturated at 10°C (50°F) Accumulated air flow since start &gt; 1600(V6) 2000(V8) grams Accumulated Idle time &lt; 90 seconds</p>	<p>10 consecutive test failures</p> <p>Continuous</p>	DTC Type B
O2S Circuit-Low Voltage (Bank 1, Sensor 1)	P0131	.1V to 1.0V This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady state throttle and during power enrichment (PE).	<p><b>Lean test:</b> O2 sensor voltage &lt; 86 mV</p> <p>or</p> <p><b>PE Lean Test:</b> O2 sensor voltage &lt; 598 mV</p>	<p><b>O2 Diagnostic Enable:</b> (the following criteria must be met to enable the O2 lean tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts <b>Test Enable (Lean test):</b> Closed loop low MAP not active Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position &gt; 3.5% but &lt; 99% Above met for 5 seconds <b>Test Enable (PE Lean test):</b> Closed loop Power Enrichment mode active High speed fuel cutoff not active Time elapsed since test enable ≥ 1 sec.</p>	<p><b>Lean Test:</b> 500 test failures in a 600 test sample</p> <p>Time necessary to complete sample: 60 sec</p> <p>Continuous</p> <p>or</p> <p><b>PE Lean Test:</b> 300 test failures in a 500 test sample.</p> <p>Time necessary to complete sample: 50 sec</p>	DTC Type A

1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-High Voltage (Bank 1, Sensor 1)	P0132	.1V to 1.0V This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and Decel fuel cutoff (DFCO)	<b>Rich Test:</b> O2 sensor voltage > 976 mV or <b>DFCO Rich Test:</b> O2 sensor voltage > 468 mV	<b>O2 Diagnostic Enable:</b> (the following criteria must be met to enable the O2 rich tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts <b>Test Enable (Rich Test):</b> Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 0% but < 50% Above met for 5 seconds <b>Test Enable (DFCO Rich Test):</b> Decel Fuel Cutoff mode active Closed loop Time elapsed since test enable ≥ 2 sec.	<b>Rich Test:</b> 400 test failures in a 500 test sample  Time necessary to complete sample: 50 sec  Continuous  or <b>DFCO Rich Test:</b> 300 test failures in a 500 test sample  Time necessary to complete sample: 50 sec	DTC Type A
O2S Circuit-Slow Response (Bank 1, Sensor 1)	P0133	.1V to 1.0V This DTC determines if the O2 sensor functioning properly by checking its response time.	O2 sensor average transition time: L/R > 125 milliseconds R/L > 125 milliseconds *O2 voltage < 300 mV = lean *O2 voltage > 600 mV = rich	<b>O2 Diagnostic Enable:</b> (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts <b>Response Test Enable:</b> Closed loop low MAP not active DTC's P0131, P0132, P0134 and P0135 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 15 g/s but ≤ 55 g/s Engine speed ≥ 1100 rpm but ≤ 3000 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds	100 seconds after closed loop enable  Once per ignition cycle	DTC Type B

**1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS**

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit- No Activity Detected (Bank 1, Sensor 1)	P0134	.1V to 1.0V This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 351 mV but < 551 mV	<p><b><i>O2 Diagnostic Enable:</i></b> (the following criteria must be met to enable the O2 open test)                      TP sensor DTC's not active                      Evap. DTC's not active                      IAT sensor DTC's not active                      MAP DTC's not active                      ECT sensor DTC's not active                      MAF sensor DTC's not active                      No intrusive tests in progress                      No device controls active                      System Voltage ≥ 9 Volts                      Engine Run Time ≥ 120 seconds</p> <p><b><i>O2 Sensor Temperature Test:</i></b>                      Not in DFEO                      ECT ≥ 80°C                      Air Flow ≥ 15 g/s</p> <p><b><i>O2 sensor Open test enable:</i></b>                      O2 Sensor Temperature Test = True                      DTC P0135 not active</p>	600 test failures with in a 1000 test sample  Time necessary to complete sample: 100 sec  Continuous	DTC Type A
O2S Heater Circuit Malfunction (Bank 1, Sensor 1)	P0135	11.5V to 14.5V This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	The elapsed time to obtain ± .150V from the mean O2 bias voltage.  *Time based on table: Time Vs Average Air Flow	System Voltage > 9V but < 17V (NOTE: If voltage remains outside this window for 4 consecutive seconds, the test is void for this cold start.) Air Flow < 27 g/sec (20 g/s 4.3L M/L only - Denso Sensors) Engine run time > 2 seconds ECT < 32°C IAT < 32°C Δ ECT-IAT ≤ 5°C	From cold start to a maximum time of 130 seconds.  *Time determined by table.	DTC Type B

# 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-Low Voltage (Bank 1, Sensor 2)  ③④⑤	P0137	.1V to 1.0V This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady state throttle and during power enrichment (PE).	<p><b><u>Lean test:</u></b> O2 sensor voltage &lt; 86 mV</p> <p>or</p> <p><b><u>PE Lean Test:</u></b> O2 sensor voltage &lt; 598 mV</p>	<p><b><u>O2 Diagnostic Enable:</u></b> (the following criteria must be met to enable the O2 lean tests)                      TP sensor DTC's not active                      Evap. DTC's not active                      IAT sensor DTC's not active                      MAP DTC's not active                      ECT sensor DTC's not active                      MAF sensor DTC's not active                      No intrusive tests in progress                      No device controls active                      System Voltage ≥ 9 Volts  <b><u>Test Enable (Lean test):</u></b>                      Closed loop low MAP not active                      Closed loop                      Air/Fuel ratio ≥ 14.5 but ≤ 14.8                      Throttle position &gt; 5% but &lt; 99%                      Above met for 5 seconds  <b><u>Test Enable (PE Lean test):</u></b>                      Closed loop                      Power Enrichment mode active                      High speed fuel cutoff not active                      Time elapsed since test enable ≥ 1 sec.</p>	<p><b><u>Lean Test:</u></b> 700 test failures in a 800 test sample</p> <p>Time necessary to complete sample: 80 sec</p> <p>Continuous</p> <p>or</p> <p><b><u>PE Lean Test:</u></b> 300 test failures in a 500 test sample.</p> <p>Time necessary to complete sample: 50 sec</p>	DTC Type B
O2S Circuit-High Voltage (Bank 1, Sensor 2)  ③④⑤	P0138	.1V to 1.0V This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and Decel fuel cutoff (DFCO)	<p><b><u>RichTest:</u></b> O2 sensor voltage &gt; 976 mV</p> <p>or</p> <p><b><u>DFCO Rich Test:</u></b> O2 sensor voltage &gt; 468 mV</p>	<p><b><u>O2 Diagnostic Enable:</u></b> (the following criteria must be met to enable the O2 rich tests)                      TP sensor DTC's not active                      Evap. DTC's not active                      IAT sensor DTC's not active                      MAP DTC's not active                      ECT sensor DTC's not active                      MAF sensor DTC's not active                      No intrusive tests in progress                      No device controls active                      System Voltage ≥ 9 Volts  <b><u>Test Enable (Rich Test):</u></b>                      Closed loop                      Air/Fuel ratio ≥ 14.5 but ≤ 14.8                      Throttle position &gt; 0% but &lt; 50%                      Above met for 5 seconds  <b><u>Test Enable (DFCO Rich Test):</u></b>                      Decel Fuel Cutoff mode active                      Closed loop                      Time elapsed since test enable ≥ 2 sec.</p>	<p><b><u>Rich Test:</u></b> 600 test failures in a 800 test sample</p> <p>Time necessary to complete sample: 80 sec</p> <p>Continuous</p> <p>or</p> <p><b><u>DFCO Rich Test:</u></b> 300 test failures in a 500 test sample</p> <p>Time necessary to complete sample: 50 sec</p>	DTC Type B

**1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS**

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit- No Activity Detected (Bank 1, Sensor 2)  ③④⑤	P0140	.1V to 1.0V This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 351 mV but < 551 mV	<b><i>O2 Diagnostic Enable:</i></b> (the following criteria must be met to enable the O2 open test) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts Engine Run Time ≥ 120 seconds <b><i>O2 Sensor Temperature Test:</i></b> Not in DFEO ECT ≥ 80°C Air Flow ≥ 15 g/s <b><i>O2 sensor Open test enable:</i></b> O2 Sensor Temperature Test = True DTC P0141 not active Closed Loop	600 test failures with in a 1000 test sample  Time necessary to complete sample: 100 sec  Continuous	DTC Type B
O2S Heater Circuit Malfunction (Bank 1, Sensor 2)  ③④⑤	P0141	11.5V to 14.5V This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	The elapsed time to obtain ± .150V from the mean O2 bias voltage.  *Time based on table: Time Vs Average Air Flow	System Voltage > 9V but < 17V (NOTE: If voltage remains outside this window for 4 consecutive seconds, the test is void for this cold start.) Air Flow < 27 g/sec (20 g/s 4.3L M/L only - Denso Sensors) Engine run time > 2 seconds ECT < 32°C IAT < 32°C Δ ECT-IAT ≤ 5°C	From cold start to a maximum time of 160 seconds.  *Time determined by table.	DTC Type B



**1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS**

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-Low Voltage (Bank 1, Sensor 3)  ①②	P0143	.1V to 1.0V This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady state throttle and during power enrichment (PE).	<b>Lean test:</b> O2 sensor voltage < 26 mV  or  <b>PE Lean Test:</b> O2 sensor voltage < 399 mV	<b>O2 Diagnostic Enable:</b> (the following criteria must be met to enable the O2 lean tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts <b>Test Enable (Lean test):</b> Closed loop low MAP not active Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 5% but < 99% Above met for 5 seconds  <b>Test Enable (PE Lean test):</b> Closed loop Power Enrichment mode active High speed fuel cutoff not active Time elapsed since test enable ≥ 2 sec.	<b>Lean Test:</b> 1100 test failures in a 1300 test sample  Time necessary to complete sample: 130 sec  Continuous  or  <b>PE Lean Test:</b> 400 test failures in a 500 test sample.  Time necessary to complete sample: 50 sec	DTC Type B
O2S Circuit-High Voltage (Bank 1, Sensor 3)  ①②	P0144	.1V to 1.0V This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and Decel fuel cutoff (DFCO)	<b>RichTest:</b> O2 sensor voltage > 993 mV  or  <b>DFCO Rich Test:</b> O2 sensor voltage > 468 mV	<b>O2 Diagnostic Enable:</b> (the following criteria must be met to enable the O2 rich tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts <b>Test Enable (Rich Test):</b> Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 0% but < 50% Above met for 5 seconds <b>Test Enable (DFCO Rich Test):</b> Decel Fuel Cutoff mode active Closed loop Time elapsed since test enable ≥ 2 sec.	<b>Rich Test:</b> 1100 test failures in a 1500 test sample  Time necessary to complete sample: 150 sec  Continuous  or  <b>DFCO Rich Test:</b> 400 test failures in a 500 test sample  Time necessary to complete sample: 50 sec	DTC Type B

## 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit- No Activity Detected (Bank 1, Sensor 3)  ①②	P0146	.1V to 1.0V This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 351 mV but < 473 mV	<p><b><i>O2 Diagnostic Enable:</i></b> (the following criteria must be met to enable the O2 open test)</p> TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts Engine Run Time ≥ 120 seconds <p><b><i>O2 Sensor Temperature Test:</i></b>                      Not in DFCO                      ECT ≥ 80°C                      Air Flow ≥ 15 g/s</p> <p><b><i>O2 sensor Open test enable:</i></b>                      O2 Sensor Temperature Test = True                      DTC P0147 not active                      Closed Loop</p>	800 test failures with in a 1000 test sample  Time necessary to complete sample: 100 sec  Continuous	DTC Type B
O2S Heater Circuit Malfunction (Bank 1, Sensor 3)  ①②	P0147	11.5V to 14.5V This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	The elapsed time to obtain ± .150V from the mean O2 bias voltage.  *Time based on table: Time Vs Average Air Flow	System Voltage > 9V but < 17V <i>NOTE: If voltage remains outside this window for 4 consecutive seconds, the test is void for this cold start.)</i> Air Flow < 27 g/sec Engine run time > 2 seconds ECT < 32°C IAT < 32°C Δ ECT-IAT ≤ 5°C	From cold start to a maximum time of 130 seconds.  *Time determined by table.	DTC Type B

**1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS**

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-Low Voltage (Bank 2, Sensor 1)	P0151	.1V to 1.0V This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady state throttle and during power enrichment (PE).	<b>Lean test:</b> O2 sensor voltage < 86 mV  or  <b>PE Lean Test:</b> O2 sensor voltage < 598 mV	<b>O2 Diagnostic Enable:</b> (the following criteria must be met to enable the O2 lean tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts <b>Test Enable (Lean test):</b> Closed loop low MAP not active Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 3.5% but < 99% Above met for 5 seconds <b>Test Enable (PE Lean test):</b> Closed loop Power Enrichment mode active High speed fuel cutoff not active Time elapsed since test enable ≥ 1 sec.	<b>Lean Test:</b> 500 test failures in a 600 test sample  Time necessary to complete sample: 60 sec  Continuous  or  <b>PE Lean Test:</b> 300 test failures in a 500 test sample.  Time necessary to complete sample: 50 sec	DTC Type A
O2S Circuit-High Voltage (Bank 2, Sensor 1)	P0152	.1V to 1.0V This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and Decel fuel cutoff (DFCO)	<b>RichTest:</b> O2 sensor voltage > 976 mV  or  <b>DFCO Rich Test:</b> O2 sensor voltage > 468 mV	<b>O2 Diagnostic Enable:</b> (the following criteria must be met to enable the O2 rich tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts <b>Test Enable (Rich Test):</b> Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 0% but < 50% Above met for 5 seconds <b>Test Enable (DFCO Rich Test):</b> Decel Fuel Cutoff mode active Closed loop Time elapsed since test enable ≥ 2 sec.	<b>Rich Test:</b> 400 test failures in a 500 test sample  Time necessary to complete sample: 50 sec  Continuous  or  <b>DFCO Rich Test:</b> 300 test failures in a 500 test sample  Time necessary to complete sample: 50 sec	DTC Type A

**1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS**

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-Slow Response (Bank 2, Sensor 1)	P0153	.1V to 1.0V This DTC determines if the O2 sensor functioning properly by checking its response time.	O2 sensor average transition time: L/R > 125 milliseconds R/L > 125 milliseconds  *O2 voltage < 300 mV = lean *O2 voltage > 600 mV = rich	<b><u>O2 Diagnostic Enable:</u></b> (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts <b><u>Response Test Enable:</u></b> Closed loop low MAP not active DTC's P0151, P0152, P0154 and P0155 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 15 g/s but ≤ 55 g/s Engine speed ≥ 1100 rpm but ≤ 3000 rpm Canister Purge Duty Cycle ≥ 0% Above present > 2 seconds	100 seconds after closed loop enable  Once per ignition cycle	DTC Type B
O2S Circuit- No Activity Detected (Bank 2, Sensor 1)	P0154	.1V to 1.0V This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 299 mV but < 598 mV	<b><u>O2 Diagnostic Enable:</u></b> (the following criteria must be met to enable the O2 open test) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts Engine Run Time ≥ 120 seconds <b><u>O2 Sensor Temperature Test:</u></b> Not in DFCO ECT ≥ 80°C Air Flow ≥ 15 g/s <b><u>O2 sensor Open test enable:</u></b> O2 Sensor Temperature Test = True DTC P0155 not active	600 test failures with in a 1000 test sample  Time necessary to complete sample: 100 sec  Continuous	DTC Type A
O2S Heater Circuit Malfunction (Bank 2, Sensor 1)	P0155	11.5V to 14.5V This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	The elapsed time to obtain ± .150V from the mean O2 bias voltage.  *Time based on table: Time Vs Average Air Flow	System Voltage > 9V but < 17V (NOTE: If voltage remains outside this window for 4 consecutive seconds, the test is void for this cold start.) Air Flow < 27 g/sec Engine run time > 2 seconds ECT < 32°C IAT < 32°C Δ ECT-IAT ≤ 5°C	From cold start to a maximum time of 130 seconds.  *Time determined by table.	DTC Type B

**1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS**

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-Low Voltage (Bank 2, Sensor 2)  ③④⑤	P0157	.1V to 1.0V This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady state throttle and during power enrichment (PE).	<b>Lean test:</b> O2 sensor voltage < 26 mV  or <b>PE Lean Test:</b> O2 sensor voltage < 399 mV	<b>O2 Diagnostic Enable:</b> (the following criteria must be met to enable the O2 lean tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts <b>Test Enable (Lean test):</b> Closed loop low MAP not active Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 5% but < 99% Above met for 5 seconds <b>Test Enable (PE Lean test):</b> Closed loop Power Enrichment mode active High speed fuel cutoff not active Time elapsed since test enable ≥ 2sec.	<b>Lean Test:</b> 1100 test failures in a 1300 test sample  Time necessary to complete sample: 130 sec  Continuous  or <b>PE Lean Test:</b> 400 test failures in a 500 test sample.  Time necessary to complete sample: 50 sec	DTC Type B
O2S Circuit-High Voltage (Bank 2, Sensor 2)  ③④⑤	P0158	.1V to 1.0V This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and Decel fuel cutoff (DFCO)	<b>Rich Test:</b> O2 sensor voltage > 993 mV  or <b>DFCO Rich Test:</b> O2 sensor voltage > 468 mV	<b>O2 Diagnostic Enable:</b> (the following criteria must be met to enable the O2 rich tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts <b>Test Enable (Rich Test):</b> Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 5% but < 99% Above met for 5 seconds <b>Test Enable (DFCO Rich Test):</b> Decel Fuel Cutoff mode active Closed loop Time elapsed since test enable ≥ 2 sec.	<b>Rich Test:</b> 1100 test failures in a 1500 test sample  Time necessary to complete sample: 150 sec  Continuous  or <b>DFCO Rich Test:</b> 400 test failures in a 500 test sample  Time necessary to complete sample: 50 sec	DTC Type B

**1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS**

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit- No Activity Detected (Bank 2, Sensor 2)  ③④⑤	P0160	.1V to 1.0V This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 351 mV but < 473 mV	<p><b><u>O2 Diagnostic Enable:</u></b> (the following criteria must be met to enable the O2 open test)</p> TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts Engine Run Time ≥ 120 seconds <p><b><u>O2 Sensor Temperature Test:</u></b>                      Engine Running                      Not in DFCO                      ECT ≥ 80°C                      Air Flow ≥ 15 g/s</p> <p><b><u>O2 Sensor Open Test Enable:</u></b>                      O2 Sensor Temperature Test = True                      DTC P0155 not active                      Closed Loop</p>	800 test failures with in a 1000 test sample  Time necessary to complete sample: 100 sec  Continuous	DTC Type B
O2S Heater Circuit Malfunction (Bank 2, Sensor 2)  ③④⑤	P0161	11.5V to 14.5V This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	The elapsed time to obtain ± .150V from the mean O2 bias voltage.  *Time based on table: Time Vs Average Air Flow	System Voltage > 9V but < 17V (NOTE: If voltage remains outside this window for 4 consecutive seconds, the test is void for this cold start.) Air Flow < 27 g/sec Engine run time > 2 seconds ECT < 32°C IAT < 32°C Δ ECT-IAT ≤ 5°C	From cold start to a maximum time of 255 seconds.  *Time determined by table.	DTC Type B

## 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
System Too Lean (Bank 1)	P0171	Determines if the system is in a lean condition.	The average of short term fuel trim samples $\geq 1.0$ and The average of adaptive index multiplier samples $\geq 1.20$	<b>Test Enable:</b> IAC / Idle DTC's not active O2 sensor DTC's not active TP sensor DTC's not active MAP DTC's not active EGR DTC's not active Evap. DTC's not active ECT DTC's not active MAF DTC's not active IAT DTC's not active VS sensor DTC's not active System Voltage DTC's not active Misfire DTC's not active Throttle position < 69.9% Engine speed > 575 rpm but < 4000 rpm Baro > 70 kPa ECT > 75°C but < 114°C MAP > 22 kPa but < 85 kPa IAT > -8.25 °C but < 76°C Air flow > 3 g/s < 85g/s Vehicle speed < 85 mph	If lean counter is $\geq 6$ counts  1 count $\cong$ 200 ms  Continuous	DTC Type B
System Too Rich (Bank 1)	P0172	Determines if the system is in a rich condition.	The average of short term fuel trim samples $\leq 1.0$ and If adaptive lag factor < 0.86, then purge valve is commanded closed. If the integrator exceeds 1.03 or the delta integrator during test exceeds 0.16 within 10 seconds, the diagnostic is turned OFF for 300 seconds to enable the Evap. canister to purge. If the integrator does not exceed 1.03 or the integrator does not change by 0.16 within 10 seconds, a fault is present.	<b>Test Enable:</b> IAC / Idle DTC's not active O2 sensor DTC's not active TP sensor DTC's not active MAP DTC's not active EGR DTC's not active Evap. DTC's not active ECT DTC's not active MAF DTC's not active IAT DTC's not active VS sensor DTC's not active System Voltage DTC's not active Misfire DTC's not active Throttle position < 69.9% Engine speed > 575 rpm but < 4000 rpm Baro > 70 kPa ECT > 75°C but < 114°C MAP > 22 kPa but < 85 kPa IAT > -8.25°C but < 76°C Air flow > 3 g/s < 85g/s Vehicle speed < 85 mph	If rich counter is $\geq 6$ counts  1 count $\cong$ 200 ms  Continuous	DTC Type B

## 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
System Too Lean (Bank 2)	P0174	Determines if the system is in a lean condition.	The average of short term fuel trim samples $\geq 1.0$ and The average of adaptive index multiplier samples $\geq 1.20$	<b>Test Enable:</b> IAC / Idle DTC's not active O2 sensor DTC's not active TP sensor DTC's not active MAP DTC's not active EGR DTC's not active Evap. DTC's not active ECT DTC's not active MAF DTC's not active IAT DTC's not active VS sensor DTC's not active System Voltage DTC's not active Misfire DTC's not active Throttle position < 69.9% Engine speed > 575 rpm but < 4000 rpm Baro > 70 kPa ECT > 75°C but < 114°C MAP > 22 kPa but < 85 kPa IAT > 8.25°C but < 76°C Air flow > 3 g/s < 85 g/s Vehicle speed < 85 mph	If lean counter is $\geq 6$ counts  1 count $\cong$ 200 ms  Continuous	DTC Type B
System Too Rich (Bank 2)	P0175	Determines if the system is in a rich condition.	The average of short term fuel trim samples $\leq 1.0$ and If adaptive lag factor < 0.86, then purge valve is commanded closed. If the integrator exceeds 1.03 or the delta integrator during test exceeds 0.16 within 10 seconds, the diagnostic is turned OFF for 300 seconds to enable the Evap. canister to purge. If the integrator does not exceed 1.03 or the integrator does not change by 0.16 within 10 seconds, a fault is present.	<b>Test Enable:</b> IAC / Idle DTC's not active O2 sensor DTC's not active TP sensor DTC's not active MAP DTC's not active EGR DTC's not active Evap. DTC's not active ECT DTC's not active MAF DTC's not active IAT DTC's not active VS sensor DTC's not active System Voltage DTC's not active Misfire DTC's not active Throttle position < 69.9% Engine speed > 575 rpm but < 4000 rpm Baro > 70 kPa ECT > 75°C but < 114°C MAP > 22 kPa but < 114 kPa IAT > -8.25 °C but < 114°C Air flow > 3 g/s < 85 g/s Vehicle speed < 85 mph	If rich counter is $\geq 6$ counts  1 count $\cong$ 200 ms  Continuous	DTC Type B



## 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Random Misfire Detected	P0300	This DTC will determine if a misfire is occurring in one or more cylinders in the engine.	Deceleration index Vs Engine Speed Vs Load and Camshaft Position  FTP Threshold - 1.85% I/M Threshold - 1.85% Catalyst Damage - see speed/load chart	<b>TEST Enable:</b> If start up ECT below -7 C then MFD delayed until ECT is above 21 C. If start up ECT is above -7° C then MFT begins after 5 seconds Fuel Level > 10% System voltage ≥ 11 volts but ≤ 16 volts Engine speed ≥ 450 RPM but ≤ 5000 RPM Vehicle speed DTC not active TP sensor DTC's not active MAF sensor DTC's not active Camshaft position sensor DTC's not active Crank sensor DTC's not active + Throttle position Δ < 1.9%/100ms - Throttle position Δ < 1.9%/100ms	Emission Level 10 failed 200 revolution blocks out of 16  Catalyst Damaging Level 4 failed 200 revolution block out of 16  Continuous	DTC Type B <i>EMISSION</i>  DTC Type A <i>CATALYST DAMAGING</i>
Knock Sensor 1 Circuit Malfunction	P0325	0V - 5V This diagnostic will detect excessive noise on the knock sensor circuit.	<b>SNEF STUCK LOW TEST:</b> Knock is detected for excessive amount of time.	<b>SNEF STUCK LOW TEST:</b> DTC P0327 not active Engine Run Time ≥ 120 seconds System voltage > 10V but ≤ 17.1V	<b>SNEF STUCK LOW TEST:</b> 10 test failures within a 100 test sample. Test is run every 500 msec. Time necessary to run test: 50 seconds	DTC Type B
Knock Sensor 1 Circuit - Low Input	P0327	0V - 5V This diagnostic will detect a lack of noise on the knock sensor circuit.	<b>KNOCK SENSOR UPDATE TEST</b> Learned Minimum noise Value updated with the filtered value every 50 msec.  <b>ACTIVE NOISE CHANNEL TEST:</b> Knock sensor noise ≤ 50 A/D counts or > 200 A/D counts. (ESC noise - Minimum Noise Value)	<b>KNOCK SENSOR UPDATE TEST:</b> Timing retard ≤ 0° System voltage > 10 V but ≤ 17.1 V ECT ≥ 60° C Engine Run Time ≥ 120 seconds Engine speed > 500 RPM but ≤ 900 RPM Knock sensor delta noise < 3 counts  <b>ACTIVE NOISE CHANNEL TEST:</b> ECT DTC's not active TP sensor DTC's not active Knock sensor update test complete ECT ≥ 60° C Engine speed > 2000 RPM but ≤ 3000 RPM Throttle position ≥ 5.9%	<b>Delta Min Noise to Low</b> 100 failures per ignition cycle  Time necessary to complete sample: 50 sec  Continuous  <b>ACTIVE NOISE CHANNEL TEST:</b> Noise counter ≥ 20 counts. 1 count = 100 ms	DTC Type B
Crankshaft Position Sensor Circuit- Range	P0336	3X / 4X Signal This diagnostic will detect a loss of crank sensor signal or long time constant intermittent that would result in a "no start" condition.	Crank Position Sensor Signal missing for a time ≥ .5 seconds.	Engine Cranking 4 or more Cam Shaft Position Signals Present	≥ 3 seconds  During engine crank.	DTC Type A

98t50M\_LD\_yE.DOC

## 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Crankshaft Position Sensor Circuit- Low Input	P0337	3X / 4X Signal This diagnostic will detect a low duty cycle from the crankshaft position sensor.	Crank sensor duty cycle High Ref/Low Ref < .3125	Engine speed < 4000 RPM Air Flow ≥ 5 g/second	15 Ref pulse failures within a 20 sample limit.  Time necessary to complete sample: Varies with engine speed  Once every TDC	DTC Type B
Crankshaft Position Sensor Circuit- Intermittent Input	P0339	3X / 4X Signal This diagnostic will detect an intermittent crankshaft position signal.	The calculated instantaneous engine speed $\Delta \geq 1000$ RPM or The calculated instantaneous engine speed = 0 RPM and 4 or more cam cycles have occurred for a period of 1 count (2 to 3 seconds)	Air Flow ≥ 5 g/second	10 test failures within a 400 sample limit.  Time necessary to complete sample: 5 sec	DTC Type B
Camshaft Position Sensor Circuit Malfunction	P0340	1X Signal This diagnostic will detect if the Cam Sensor signal is present.	Cam Sensor reference pulse is not seen once every 6 cylinders.	Engine Running	If Cam signal is not detected within 1.75 seconds, test has failed. Once every TDC	DTC Type B
Camshaft Position Sensor Circuit Range/Rationality	P0341	1X Signal This diagnostic will determine if the Cam Sensor is synchronized correctly.	Cam Sensor reference pulse is not detected at the correct interval every 6 cylinders.	Engine Running	40 failed tests within a 100 test sample.  Time necessary to complete sample: Varies with engine speed  Once every TDC	DTC Type B

## 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Exhaust Gas Recirculation - Insufficient Flow Detected	P0401	This diagnostic will determine if there is a reduction in EGR flow.	With EGR valve open, the peak + MAP $\Delta$ is monitored over a time of 2 seconds. This value is compared with a threshold from Engine Speed Vs Baro table and the difference computed. The result is statistically filtered (EWMA) and compared to a decision limit. DTC is set when the filtered result exceeds the decision limit.	<p><b>Test Enable</b></p> TP sensor DTC's not active MAP DTC's not active VS sensor DTC's not active IAT sensor DTC's not active ECT sensor DTC's not active IAC DTC's not active Linear EGR Pintle Position DTC not active Misfire DTC's not active EVAP DTC's not active ECT > 69.8° C Baro > 70 kPa Vehicle Speed > 25 mph IAC $\Delta$ < 8 counts AC clutch status is unchanged Transmission status is unchanged	2 seconds  Once per trip	DTC Type A
EGR Valve Open Pintle Position Error	P0404	Position error too high	<b>Deviation between actual and desired position &gt; 10% for 10 seconds</b>	Ignition voltage >9V	Continuous	DTC Type A
EGR Sensor Signal Low	P0405	Open / Short	<b>Pintle position &lt;6 A/D countd for 10 seconds</b>	Ignition voltage > 9V	Continuous	DTC Type A

## 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Secondary Air Injection System Malfunction  ③	P0410	<p>Passive: O2 sensors indicate lean condition present during open loop operation of air pump.</p> <p>Active: O2 sensors indicate lean condition present when AIR pump is turned on during closed loop operation.</p>	<p>Passive: O2 sensor &lt; 350 approx. 350 mv during open loop operation.</p> <p>Active: O2 sensor &lt; approx. 222 mv &gt;1.4 seconds or fuel integrator delta of 14 counts when pump turned on during closed loop operation.</p>	<p>Passive: No MAF, MAP, IAT, ECT, TPS, O2, injector, misfire, EGR, fuel system, AIR relay, IAC, or CCP DTC set O2 mid bias volt test passed, Engine run &gt; 2 seconds, Air flow &lt; 25 g/s.,  A/F ratio &gt; 13.1, engine load &lt; 40 %, PE, DFCO, COT not active.</p> <p>Active: Same as above except:  MBV test fail will not disable, Engine run time after closed loop to enable = 50 seconds. A/F = 14.7, fuel integrator &gt; 120 &amp; &lt; 136, RPM &gt; 550, ECT &gt; 55 C &lt; 107. Engine load &lt;40 %, ignition volts &gt; 11.7..</p>	<p>Passive: During open loop operation.  Once per trip.</p> <p>Active: 3 seconds. Up to three times per trip if passive test fails or is inconclusive.</p>	DTC Type B
Catalyst System Efficiency Below Threshold (Bank 1)  ①	P0420	This diagnostic will determine the efficiency (oxygen storage capacity) of the catalytic converter	<p><b><u>C/K,G,M/L TIER 1</u></b> OSC Time Difference ≥ 0.110 sec OSC Worst Pass Thresh = 1.375 sec</p> <p><b><u>ML TLEV</u></b> OSC Time Difference ≥ 0.0488 sec OSC Worst Pass Thresh = 0.975 sec</p> <p><b><u>ST TIER 1</u></b> OSC Time Difference ≥ 0.0488 sec OSC Worst Pass Thresh = 0.975 sec</p> <p><b><u>ST UTILITY TLEV</u></b> OSC Time Difference ≥ 0.116 sec OSC Worst Pass Thresh = 1.6 sec</p> <p>OSC Time Difference = OSC Worst Pass Thresh. - [OSC Compensation Factor * (Post Cat O2 Resp.Time - Pre Cat O2 Resp.Time)]</p>	<p><b><u>Trip Enable Criteria:</u></b> None of the following DTC's failing: AIR, ECT; Fuel Trim; EST; EGR; CAM; IAC; IAT; MAF; MAP; Oxygen Sensor; Purge System; TPS; VSS; Misfire; PRNDL/Trans.(auto.)</p> <p><b><u>Valid Idle Period Criteria</u></b> Engine Speed ≥ 900 rpm for minimum of 35 sec since end of last idle period. Min engine runtime for stable BLM ≥ 346 sec</p> <p><b><u>Test Enable Conditions</u></b> Predicted Catalyst Temperature ≥ 475°C Closed loop fuel control Barometric Pressure ≥ 73 kPa -6.75 ≤ IAT ≤ 75°C 75°C ≤ ECT ≤ 117°C 0 &lt; Idle Period ≤ 60 sec Tests Attempted this trip ≤ 18 Tests Attempted this idle period = 1 -105 rpm ≤ (Engine Speed - Desired Speed) ≤ 125 rpm</p>	<p>1 test attempted per valid idle period</p> <p>Maximum of 6 tests per trip until catalyst I/M flag set</p> <p>Maximum of 1 test per trip after catalyst I/M flag set</p> <p>frequency: 12.5 msec. Continuous</p>	DTC Type A

**1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS**

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Catalyst System Low Efficiency (Bank 1)  ②	P0420	This diagnostic will determine the efficiency (oxygen storage capacity) of the catalytic converter.	<p>OSC Time Difference &gt;= 0.3 (automatic) 0.35 (manual)</p> <p>OSC Time Difference = OSC Worst Pass Thresh. - [OSC Compensation Factor * (Post Cat O2 Resp.Time - Pre Cat O2 Resp.Time)]</p> <p>OSC Worst Pass Thresh. = 1.013 (automatic) 1.263 (manual)</p>	<p><b>Trip Enable Criteria:</b> None of the following DTC's failing: AIR, ECT; Fuel Trim; EST; EGR; CAM; IAC; IAT; MAF; MAP; Oxygen Sensor; Purge System; TPS; VSS; Misfire; PRNDL/Trans.(auto.)</p> <p><b>Valid Idle Period Criteria:</b> Engine speed &gt;= 1000 rpm for minimum of 32 sec. (automatics) or 40 sec. (manuals) since end of last idle period. Min. engine run time for stable BLM &amp;INT &gt;= 360 sec.</p> <p><b>Test Enable Conditions:</b> Predicted Catalyst Temperature &gt;= 390°C Closed loop fuel control Barometric Pressure &gt;= 72 kPa -6.75 &lt;= IAT &lt;= 75°C 75 &lt;= ECT &lt;= 118°C 0 &lt;= Idle period &lt;= 120 seconds Tests Attempted this trip &lt;= 6 Tests Attempted this idle period &lt;= 1 -110 rpm &lt;= (Engine Speed - Desired Speed) &lt;= 125 rpm</p>	<p>1 test attempted per valid idle period</p> <p>Maximum of 6 tests per trip until catalyst I/M flag set</p> <p>Maximum of 1 test per trip after catalyst I/M flag set</p> <p>frequency: 12.5 msec. Continuous</p>	DTC Type A
Catalyst System Low Efficiency (Bank 1)  ③	P0420	This diagnostic will determine the efficiency (oxygen storage capacity) of the catalytic converter.	<p>OSC Time Difference &gt;= 0.15</p> <p>OSC Time Difference = OSC Worst Pass Thresh. - [OSC Compensation Factor * (Post Cat O2 Resp.Time - Pre Cat O2 Resp.Time)]</p> <p>OSC Worst Pass Thresh. = 0.925</p>	<p><b>Trip Enable Criteria:</b> None of the following DTC's failing: AIR, ECT; Fuel Trim; EST; EGR; CAM; IAC; IAT; MAF; MAP; Oxygen Sensor; Purge System; TPS; VSS; Misfire; PRNDL/Trans.(auto.)</p> <p><b>Valid Idle Period Criteria:</b> Engine speed &gt;= 800 rpm for minimum of 41 sec. since end of last idle period. Min. engine run time for stable BLM &amp;INT &gt;= 360 sec.</p> <p><b>Test Enable Conditions:</b> Predicted Catalyst Temperature &gt;= 390°C Closed loop fuel control Barometric Pressure &gt;= 72 kPa -6.75 &lt;= IAT &lt;= 75°C 75 &lt;= ECT &lt;= 118°C 0 &lt;= Idle period &lt;= 120 seconds Tests Attempted this trip &lt;= 6 Tests Attempted this idle period &lt;= 1 -110 rpm &lt;= (Engine Speed - Desired Speed) &lt;= 125 rpm</p>	<p>1 test attempted per valid idle period</p> <p>Maximum of 6 tests per trip until catalyst I/M flag set</p> <p>Maximum of 1 test per trip after catalyst I/M flag set</p> <p>frequency: 12.5 msec. Continuous</p>	DTC Type A

## 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Catalyst System Low Efficiency (Bank 1)  ④	P0420	This diagnostic will determine the efficiency (oxygen storage capacity) of the catalytic converter.	<p>OSC Time Difference &gt;= 0.1125 (automatic) 0.126 (manual)</p> <p>OSC Time Difference = OSC Worst Pass Thresh. - [OSC Compensation Factor * (Post Cat O2 Resp.Time - Pre Cat O2 Resp.Time)]</p> <p>OSC Worst Pass Thresh. = 1.3 (automatic) 1.463 (manual)</p>	<p><b><u>Trip Enable Criteria:</u></b> None of the following DTC's failing: AIR, ECT; Fuel Trim; EST; EGR; CAM; IAC; IAT; MAF; MAP; Oxygen Sensor; Purge System; TPS; VSS; Misfire; PRNDL/Trans.(auto.)</p> <p><b><u>Valid Idle Period Criteria:</u></b> Engine speed &gt;= 1100 rpm for minimum of 43.5 sec. (manuals) or 900 rpm for minimum of 32 sec. (automatics) since end of last idle period. Min. engine run time for stable BLM &amp;INT &gt;= 360 sec.</p> <p><b><u>Test Enable Conditions:</u></b> Predicted Catalyst Temperature &gt;= 390°C Closed loop fuel control Barometric Pressure &gt;= 72 kPa -6.75 &lt;= IAT &lt;= 75°C 75 &lt;= ECT &lt;= 118°C 0 &lt;= Idle period &lt;= 120 seconds Tests Attempted this trip &lt;= 6 Tests Attempted this idle period &lt;= 1 -110 rpm &lt;= (Engine Speed - Desired Speed) &lt;= 125 rpm</p>	<p>1 test attempted per valid idle period</p> <p>Maximum of 6 tests per trip until catalyst I/M flag set</p> <p>Maximum of 1 test per trip after catalyst I/M flag set</p> <p>frequency: 12.5 msec. Continuous</p>	DTC Type A
Catalyst System Low Efficiency (Bank 1)  ⑤	P0420	This diagnostic will determine the efficiency (oxygen storage capacity) of the catalytic converter.	<p>OSC Time Difference &gt;= 0.325</p> <p>OSC Time Difference = OSC Worst Pass Thresh. - [OSC Compensation Factor * (Post Cat O2 Resp.Time - Pre Cat O2 Resp.Time)]</p> <p>OSC Worst Pass Thresh. = 2.6</p>	<p><b><u>Trip Enable Criteria:</u></b> None of the following DTC's failing: AIR, ECT; Fuel Trim; EST; EGR; CAM; IAC; IAT; MAF; MAP; Oxygen Sensor; Purge System; TPS; VSS; Misfire; PRNDL/Trans.(auto.)</p> <p><b><u>Valid Idle Period Criteria:</u></b> Engine speed &gt;= 900 rpm for minimum of 42 sec. since end of last idle period. Min. engine run time for stable BLM &amp;INT &gt;= 360 sec.</p> <p><b><u>Test Enable Conditions:</u></b> Predicted Catalyst Temperature &gt;= 385°C Closed loop fuel control Barometric Pressure &gt;= 72 kPa -6.75 &lt;= IAT &lt;= 75°C 75 &lt;= ECT &lt;= 118°C 0 &lt;= Idle period &lt;= 120 seconds Tests Attempted this trip &lt;= 6 Tests Attempted this idle period &lt;= 1 -110 rpm &lt;= (Engine Speed - Desired Speed) &lt;= 125 rpm</p>	<p>1 test attempted per valid idle period</p> <p>Maximum of 6 tests per trip until catalyst I/M flag set</p> <p>Maximum of 1 test per trip after catalyst I/M flag set</p> <p>frequency: 12.5 msec. Continuous</p>	DTC Type A

**1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS**

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Catalyst System Low Efficiency (Bank 2)  ③	P0430	This diagnostic will determine the efficiency (oxygen storage capacity) of the catalytic converter.	OSC Time Difference >= 0.2  OSC Time Difference = OSC Worst Pass Thresh. - [OSC Compensation Factor * (Post Cat O2 Resp.Time - Pre Cat O2 Resp.Time)]  OSC Worst Pass Thresh. = 1.263	<b><i>Trip Enable Criteria:</i></b> None of the following DTC's failing: AIR, ECT; Fuel Trim; EST; EGR; CAM; IAC; IAT; MAF; MAP; Oxygen Sensor; Purge System; TPS; VSS; Misfire; PRNDL/Trans.(auto.)  <b><i>Valid Idle Period Criteria:</i></b> Engine speed >= 800 rpm for minimum of 41 sec. since end of last idle period. Min. engine run time for stable BLM &INT >= 360 sec.  <b><i>Test Enable Conditions:</i></b> Predicted Catalyst Temperature >= 390°C Closed loop fuel control Barometric Pressure >= 72 kPa -6.75 <= IAT <= 75°C 75 <= ECT <= 118°C 0 <= Idle period <= 120 seconds Tests Attempted this trip <= 6 Tests Attempted this idle period <= 1 -110 rpm <= (Engine Speed - Desired Speed) <= 125 rpm	1 test attempted per valid idle period  Maximum of 6 tests per trip until catalyst I/M flag set  Maximum of 1 test per trip after catalyst I/M flag set  frequency: 12.5 msec. Continuous	DTC Type A
Catalyst System Low Efficiency (Bank 2)  ④	P0430	This diagnostic will determine the efficiency (oxygen storage capacity) of the catalytic converter.	OSC Time Difference >= 0.1125 (automatic) 0.303 (manual)  OSC Time Difference = OSC Worst Pass Thresh. - [OSC Compensation Factor * (Post Cat O2 Resp.Time - Pre Cat O2 Resp.Time)]  OSC Worst Pass Thresh. = 1.313 (automatic) 2.675 (manual)	<b><i>Trip Enable Criteria:</i></b> None of the following DTC's failing: AIR, ECT; Fuel Trim; EST; EGR; CAM; IAC; IAT; MAF; MAP; Oxygen Sensor; Purge System; TPS; VSS; Misfire; PRNDL/Trans.(auto.)  <b><i>Valid Idle Period Criteria:</i></b> Engine speed >= 1100 rpm for minimum of 43.5 sec. (manuals) or 900 rpm for minimum of 32 sec. (automatics) since end of last idle period. Min. engine run time for stable BLM &INT >= 360 sec.  <b><i>Test Enable Conditions:</i></b> Predicted Catalyst Temperature >= 390°C Closed loop fuel control Barometric Pressure >= 72 kPa -6.75 <= IAT <= 75°C 75 <= ECT <= 118°C 0 <= Idle period <= 120 seconds Tests Attempted this trip <= 6 Tests Attempted this idle period <= 1 -110 rpm <= (Engine Speed - Desired Speed) <= 125 rpm	1 test attempted per valid idle period  Maximum of 6 tests per trip until catalyst I/M flag set  Maximum of 1 test per trip after catalyst I/M flag set  frequency: 12.5 msec. Continuous	DTC Type A

## 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Catalyst System Low Efficiency (Bank 2)  ⑤	P0430	This diagnostic will determine the efficiency (oxygen storage capacity) of the catalytic converter.	OSC Time Difference $\geq 0.3375$  OSC Time Difference = OSC Worst Pass Thresh. - [OSC Compensation Factor * (Post Cat O2 Resp.Time - Pre Cat O2 Resp.Time)]  OSC Worst Pass Thresh. = 2.3	<b>Trip Enable Criteria:</b> None of the following DTC's failing: AIR, ECT; Fuel Trim; EST; EGR; CAM; IAC; IAT; MAF; MAP; Oxygen Sensor; Purge System; TPS; VSS; Misfire; PRNDL/Trans.(auto.)  <b>Valid Idle Period Criteria:</b> Engine speed $\geq 900$ rpm for minimum of 42 sec. since end of last idle period. Min. engine run time for stable BLM &INT $\geq 360$ sec.  <b>Test Enable Conditions:</b> Predicted Catalyst Temperature $\geq 385^{\circ}\text{C}$ Closed loop fuel control Barometric Pressure $\geq 72$ kPa $-6.75 \leq \text{IAT} \leq 75^{\circ}\text{C}$ $75 \leq \text{ECT} \leq 118^{\circ}\text{C}$ $0 \leq \text{Idle period} \leq 120$ seconds Tests Attempted this trip $\leq 6$ Tests Attempted this idle period $\leq 1$ $-110 \text{ rpm} \leq (\text{Engine Speed} - \text{Desired Speed}) \leq 125$ rpm	1 test attempted per valid idle period  Maximum of 6 tests per trip until catalyst I/M flag set  Maximum of 1 test per trip after catalyst I/M flag set  frequency: 12.5 msec. Continuous	DTC Type A
Evap. Emission Control System Malfunction	P0440	0.1 V - 4.98V This DTC will detect a weak vacuum condition (large leak or restriction) in the Evap. system.	<b><u>WEAK VACUUM TEST- STAGE I (Cold Test):</u></b> Tank Vac. < 13 or 9 in. H <sub>2</sub> O <b><u>depending on application</u></b> <b><u>WEAK VACUUM TEST- STAGE II (Warm Test):</u></b> Stage I test failed previous trip and this trip. Tank Vac. < 11 in. H <sub>2</sub> O  OR  If HC vapor is not present and the SMALL LEAK TEST has failed.	<b><u>TEST ENABLE:</u></b> MAP DTC's not active TP Sensor DTC's not active VS Sensor DTC's not active O2 Sensor DTC's not active ECT Sensor DTC's not active DTC P0125 not active IAT Sensor DTC's not active Fuel Level >12.5% but < 87.5% Powerup Vacuum Test Fail = False System Voltage > 10V but < 17V <b><u>COLD START TEST:</u></b> ECT > 3.75°C but < 30° C IAT > 3.75°C but < 30° C Cold Temperature $\Delta$ ( ECT - IAT): < 1.5°C if IAT > ECT < 8.25 °C if ECT > IAT Baro > 72.5 kPa Fuel Level Input = True Fuel Level Present Test = True	<b><u>WEAK VACUUM TEST- STAGE I (Cold Test):</u></b> Fault present for a time $\geq 30$ , 50 or 80 depending on application sec. (Vac. Weighted)  <b><u>WEAK VACUUM TEST- STAGE II (Warm Test):</u></b> Fault present for a time $\geq 1400$ sec.  Once per cold start	DTC Type A (Behaves as a Type B)

98t50M\_LD\_yE.DOC



## 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Evap. Emission Control System Leak Detected (Small Leak)	P0442	0.1 V - 4.98V This DTC will detect a small leak in the Evap. system between the fuel fill cap and up to but not including the purge solenoid.	<b><u>SMALL LEAK TEST FAIL:</u></b> Vacuum < 7 , 9 or 11" H <sub>2</sub> O for a time < 25,30 or 35 sec. Depending on application Vacuum Decay (determined by fuel level and intake temperature) ≥ a value determined by Start Vacuum minus Tank Vacuum for a period ≥ 15 or 12 seconds. Vacuum > 0.1 in. H <sub>2</sub> O for a time ≤ 35 , 50,60,80,85seconds. depending on application	<b><u>TEST ENABLE :</u></b> MAP DTC's not active TP Sensor DTC's not active VS Sensor DTC's not active O2 Sensor DTC's not active ECT Sensor DTC's not active DTC P0125 not active IAT Sensor DTC's not active Fuel Level >12.5% but < 87.5% <b><u>COLD START TEST:</u></b> ECT > 3.75°C but < 30° C IAT > 3.75°C but < 30° C Cold Temperature Δ ( ECT - IAT): < 1.5°C if IAT > ECT < 8.25 °C if ECT > IAT Baro > 72.5 kPa Fuel Level Input = True Fuel Level Present Test = True <b><u>FUEL SLOSH TEST:</u></b> Tank Vacuum Δ ≤ 0.6 in. H <sub>2</sub> O OR Fuel Level Δ ≤ 7.8% <b><u>WEAK VACUUM TEST (Stage I) :</u></b> Throttle position < 75% Vehicle speed < 65 mph Tank Vacuum ≥ 9 ,11,13in. H <sub>2</sub> O within 30,50,80 dending on app. seconds.	Vacuum Decay ≥ 12 or 15 seconds  Once per cold start	DTC Type A (Behaves as a Type B)

## 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Evap. Emission Control System Vent Control Malfunction	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filter, vent hose or canister.	<p><b><u>EXCESS VACUUM TEST - STAGE I :</u></b> Vent solenoid <b>commanded</b> OPEN Fuel Tank Vacuum <math>\geq</math> 7 in. H<sub>2</sub>O for 2 seconds(monitored during initial purge ramp)</p> <p style="text-align: center;"><b>OR</b></p> <p><b><u>EXCESS VACUUM TEST - STAGE II :</u></b> Vent solenoid <b>commanded</b> OPEN during normal purge. Fuel Tank Vacuum <math>\geq</math> 12.9 in. H<sub>2</sub>O for a time <math>\geq</math> 4 seconds</p>	<p><b><u>TEST ENABLE :</u></b> MAP DTC's not active TP Sensor DTC's not active VS Sensor DTC's not active O2 Sensor DTC's not active ECT Sensor DTC's not active DTC P0125 not active IAT Sensor DTC's not active Fuel Level &gt;12.5% but &lt; 87.5% System Voltage &gt; 10V but &lt; 17V</p> <p><b><u>COLD START TEST:</u></b> ECT &gt; 3.75°C but &lt; 30° C IAT &gt; 3.75°C but &lt; 30° C Cold Temperature <math>\Delta</math> ( ECT - IAT): &lt; 1.5°C if IAT &gt; ECT &lt; 8.25 °C if ECT &gt; IAT Baro &gt; 72.5 kPa Fuel Level Input = True Fuel Level Present Test = True</p> <p><b><u>FUEL SLOSH TEST:</u></b> Tank Vacuum <math>\Delta \geq</math> 0.6 in. H<sub>2</sub>O OR Fuel Level <math>\Delta \geq</math> 7.8%</p> <p><b><u>PURGE HC PRESENT :</u></b> Purge Closed Loop Multiplier <math>\geq</math> 0.6 for a time <math>\leq</math> a table value based on coolant temperature</p> <p><b><u>WEAK VACUUM TEST -Stage I:</u></b> Tank Vacuum <math>\geq</math> 9 11 or 13in. H<sub>2</sub>O within 30,50,80 seconds. depending on application</p>	<p><b><u>EXCESS VACUUM TEST - STAGE II :</u></b> 180 seconds</p> <p>Once per cold start at:</p> <ul style="list-style-type: none"> <li>• Powerup</li> <li>• Excess Vac. Stage I</li> <li>• Excess Vac. Stage II</li> </ul>	DTC Type A
EVAP Fuel Tank Pressure Sensor Circuit Low Voltage	P0452	This DTC will detect a vacuum sensor stuck low	tank vacuum raw voltage < 0.1 volt for 5 seconds	<b><u>runs countiously after a 1 second delay for sensor warmup</u></b>		DTC Type B
EVAP Fuel Tank Pressure Sensor Circuit High Voltage	P0453	This DTC will detect a vacuum sensor stuck hi	tank vacuum raw voltage >4.98 volt for 5 seconds	<b><u>runs countiously after a 1 second delay for sensor warmup</u></b>		DTC Type B
Vehicle Speed (VS) Sensor Signal Missing	P0500	The DTC detects a missing vehicle speed sensor signal, generally on an overrun or decel condition.	Vehicle Speed $\leq$ 1 MPH	MAP sensor DTC's not active MAP < 20 kPa Coolant Temperature $\geq$ 60° C Engine > 1400 RPM but < 4400 RPM Throttle Position < 3.125 %	Failing > 5 seconds  Continuous	DTC Type A

98t50M\_LD\_yE.DOC

# 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Idle Control System RPM Lower Than Expected	P0506	This DTC will determine if a low idle is the result of a IAC valve or circuit. A low idle is defined as 75 RPM below the desired idle.	Air flow $\Delta < 3$ g/s	<p><b><u>Test Enable: (non - intrusive)</u></b>                      TP sensor DTC's not active                      VS sensor DTC's not active                      ECT DTC's not active                      MAP DTC's not active                      ECT &gt; 50°C                      System Voltage &gt; 10V but &lt; 16 V                      IAT &gt; -25°C                      Engine run time &gt; 30 seconds                      Baro &gt; 70 kPa                      TP &lt; 1%                      VS &lt; 2 MPH                      Above met for a time &gt; 3 seconds to enable diagnostic.                      If non-intrusive test fails, intrusive test is run.</p> <p><b><u>Run Test: (intrusive)</u></b>                      Air Flow &gt; 17.5 g/sec but &lt; 50 g/sec                      VS &gt; 25 MPH but &lt; 85 MPH                      TP <math>\Delta &lt; 1\%</math>                      Engine Speed <math>\Delta &lt; 50</math> RPM                      IAC motor commanded 10 %/ 100 msec.</p>	10 seconds  Continuous after enable	DTC Type B
Idle Control System RPM Higher Than Expected	P0507	This DTC will determine if a high idle is the result of a IAC valve or circuit. A high idle is defined as 100 RPM above the desired idle.	Air flow $\Delta < 3$ g/s	<p><b><u>Test Enable: (non - intrusive)</u></b>                      TP sensor DTC's not active                      VS sensor DTC's not active                      ECT DTC's not active                      MAP DTC's not active                      ECT &gt; 50°C                      System Voltage &gt; 10V but &lt; 16 V                      IAT &gt; -25°C                      Engine run time &gt; 30 seconds                      Baro &gt; 70 kPa                      TP &lt; 1%                      VS &lt; 2 MPH                      Above met for a time &gt; 3 seconds to enable diagnostic.                      If non-intrusive test fails, intrusive test is run.</p> <p><b><u>Run Test: (intrusive)</u></b>                      Air Flow &gt; 17.5 g/sec but &lt; 50 g/sec                      VS &gt; 25 MPH but &lt; 85 MPH                      TP <math>\Delta &lt; 1\%</math>                      Engine Speed <math>\Delta &lt; 50</math> RPM                      IAC motor commanded 10 %/ 100 msec.</p>	10 seconds  Continuous after enable	DTC Type B
VCM Memory Error - Type 4 (Program Flash)	P0601	This diagnostic checksums the contents of flash EEPROM and compares it to the expected value.	The calculated checksum does not match the programmed value.	-----	Once per trip at controller initialization.	DTC Type A
VCM Memory Error - Not Programmed	P0602	This diagnostic checks the state of the Service Calibration Bit to determine if the controller needs to be programmed.	The Calibrated No Start For Service bit is true in the calibration.	-----	Once per trip at controller initialization.	DTC Type A

98t50M\_LD\_yE.DOC

## 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
VCM Memory Error - Type 2 (Keep Alive)	P0603	This diagnostic checks that data stored to the Non-Volatile Keep Alive section of memory is functioning correctly.	The checksum of the data does stored at powerdown does not match the checksum of the data present at powerup, and the data read from memory does not match the data that was stored to check memory function.	-----	Once per trip at controller initialization.	DTC Type A
VCM Memory Error - Type 1 (Volatile RAM)	P0604	This diagnostic checks that data stored to the Volatile section of memory is stored correctly.	The data read from the memory location does not match the data that was just stored to that location.	-----	Once per trip at controller initialization.	DTC Type A
VCM Memory Error - Type 3 (Boot Flash)	P0605	This diagnostic checks that the checksum of the Boot Flash section of memory matches a predetermined value.	The checksum of the data does not match the expected checksum.	-----	Once per trip at controller initialization.	DTC Type A
Transmission Clutch Switch Input Malfunction (Manual Trans. Only)  ①②④⑤	P0704	This DTC monitors the Transmission Clutch Switch for a transition during accelerations to the calibrated speed and back to 0 MPH.	No clutch switch circuit transitions detected	VS sensor DTC's not active Vehicle Speed is now = 0 mph and Vehicle Speed has been > 40 mph The brake switch is not currently pressed. (The clutch switch is wired in series with the brake switch)	2 consecutive test failures  Continuous.  100 mS	DTC Type B
O2 Sys. Fault - Too Few O2S R/L or L/R Switches, Insufficient Activity (Bank 1, Sensor 1)	P1133	.1V to 1.0V This DTC determines if the O2 sensor functioning properly by monitoring the number of L/R and R/L switches.	Number of switches in 100 seconds: L/R switches < 20 R/L switches < 20	<b><i>O2 Diagnostic Enable:</i></b> (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts <b><i>Response Test Enable:</i></b> Closed loop low MAP not active DTC's P0131, P0132, P0134 and P0135 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 15 g/s but ≤ 55 g/s Engine speed ≥ 1100 rpm but ≤ 3000 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds	100 seconds after closed loop enable  Once per key cycle	DTC Type B

# 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit - Transition Time Ratio Malfunction (Bank 1, Sensor 1)	P1134	.1V to 1.0V This DTC determines if the O2 sensor functioning properly by checking the ratio of average response time.	Ratio of average response times: Ratio > 5.0 or < 0.375  *O2 voltage < 300 mV = lean *O2 voltage > 600 mV = rich	<b><i>O2 Diagnostic Enable:</i></b> (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts <b><i>Response Test Enable:</i></b> Closed loop low MAP not active DTC's P0131, P0132, P0134 and P0135 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 15 g/s but ≤ 55 g/s Engine speed ≥ 1100 rpm but ≤ 3000 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds	100 seconds after closed loop enable  Once per ignition cycle	DTC Type B
O2 Sys. Fault - Too Few O2S R/L or L/R Switches, Insufficient Activity (Bank 2, Sensor 1)	P1153	.1V to 1.0V This DTC determines if the O2 sensor functioning properly by monitoring the number of L/R and R/L switches.	Number of switches in 100 seconds: L/R switches < 20 R/L switches < 20	<b><i>O2 Diagnostic Enable:</i></b> (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts <b><i>Response Test Enable:</i></b> Closed loop low MAP not active DTC's P0151, P0152, P0154 and P0155 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 15 g/s but ≤ 55 g/s Engine speed ≥ 1100 rpm but ≤ 3000 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds	100 seconds after closed loop enable  Once per key cycle	DTC Type B

# 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit - Transition Time Ratio Malfunction (Bank 2, Sensor 1)	P1154	.1V to 1.0V This DTC determines if the O2 sensor functioning properly by checking the ratio of the average response time.	Ratio of average response times: Ratio > 5.0 or < .375  *O2 voltage < 300 mV = lean *O2 voltage > 600 mV = rich	<b><i>O2 Diagnostic Enable:</i></b> (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts <b><i>Response Test Enable:</i></b> Closed loop low MAP not active DTC's P0151, P0152, P0154 and P0155 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 15 g/s but ≤ 55 g/s Engine speed ≥ 1100 rpm but ≤ 3000 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds	100 seconds after closed loop enable  Once per ignition cycle	DTC Type B
Crankshaft Position System Variation Not Learned (CASE)	P1336	This diagnostic will determine if the Crankshaft Position System Variation has been learned	Engine running	Manufactures Enable ounter must be zero	Continuous	DTC Type A
Camshaft Sensor Misinstalled	P1345	1X Signal This diagnostic will determine if the Cam sensor and high voltage switch have been installed correctly.	Cam signal falling edge out of phase ±26 degrees from crank falling edge.	-----	30 test failures within a 50 test sample size.  Time necessary to complete sample: Varies with engine speed  Every crank fall	DTC Type A
EST Output High	P1351	0 V-1V This diagnostic will determine if a failure has occurred due to an open circuit.	EST voltage >4.9 V	EST Enabled Engine speed < 250 RPM	20 test failures  Time necessary to complete sample: Executed during crank, approximately 3 seconds.  Once per ignition cycle	DTC Type A
EST Not Toggling After Enable	P1361	0 V-1V This diagnostic will determine if a failure has occurred due to a grounded circuit.	EST voltage <.04V	EST Enabled Engine speed < 250 RPM	20 test failures  Time necessary to complete sample: Executed during crank, approximately 3 seconds.  Once per ignition cycle	DTC Type A

98t50M\_LD\_yE.DOC

## 1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
EGR Valve Circuit Performance - actual position greater than commanded	P1404	Closed valve position too high	<b><i>Pintle position &gt; 10 A/D counts from learned closed position for 10 seconds for 5 subroutines</i></b>	EGR valve strokes to 100% duty cycle between subroutines. Enable parameters for stroke: 80°C < ETC < 120°C IAT < 100°C Desired EGR > 14%	Continuous	DTC Type A
Secondary Air Injection System Malfunction (Bank 1)  ③	P1415	Detects left bank AIR malfunction	Determines if left bank AIR diagnostic failed	Looks at results of diagnostic P0410. See P0410	See P0410 diagnostic description.	DTC Type B
Secondary Air Injection System Malfunction (Bank 2)  ③	P1416	Detects right bank AIR malfunction	Determines if right bank AIR diagnostic failed.	Looks at results of diagnostic P0410. See P0410.	See P0410 diagnostic description	DTC Type B
Evap. Emission Control System - Continuous Open Purge Flow	P1441	This DTC will determine if the purge solenoid is leaking.	<b><u>PURGE VALVE LEAK TEST:</u></b> Purge Valve closed TP > 0% but < 99.6% Vacuum ≥ 10 KPa Tank Vacuum ≥ 12 in. H <sub>2</sub> O for 2 sec within ≤ 37.5 seconds after 30 second delay.	<b><u>TEST ENABLE:</u></b> MAP DTC's not active TP Sensor DTC's not active VS Sensor DTC's not active O2 Sensor DTC's not active ECT Sensor DTC's not active DTC P0125 not active IAT Sensor DTC's not active Fuel Level >12.5% but < 87.5% System Voltage > 10V but < 17V <b><u>COLD START TEST:</u></b> ECT > 3.75°C but < 30° C IAT > 3.75°C but < 30° C Cold Temperature Δ ( ECT - IAT): < 1.5°C if IAT > ECT < 8.25 °C if ECT > IAT Baro >72.5 kPa Fuel Level Input = True Fuel Level Present Test = True <b><u>EXCESS VACUUM TEST -STAGE I:</u></b> Vent solenoid <b>commanded</b> OPEN Fuel Tank Vacuum < 7 in. H <sub>2</sub> O <b><u>WEAK VACUUM TEST -Stage I:</u></b> Throttle position < 75% Vehicle speed < 65 mph Tank Vacuum ≥ 9, 11 or 13 in. H <sub>2</sub> O within 30 ,50 or 80seconds.	<b><u>PURGE VALVE LEAK TEST:</u></b> 180seconds Max.  Once per cold start	DTC Type B

1998 5.0L (L30) C/K-truck, G-van Light Duty (<8500 GVW) ENGINE DIAGNOSTIC PARAMETERS

98t50M\_LD\_yE.DOC

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Idle Air Control - Low	P1508	This DTC will determine if a low idle is the result of an engine mechanical problem. A low idle is defined as 75 RPM below the desired idle.	Air flow $\Delta > 3$ g/s	<p><b><u>Test Enable: (non - intrusive)</u></b>                      TP sensor DTC's not active                      VS sensor DTC's not active                      ECT DTC's not active                      MAP DTC's not active                      ECT &gt; 50°C                      System Voltage &gt; 10V but &lt; 16 V                      IAT &gt; -25°C                      Engine run time &gt; 30 seconds                      Baro &gt; 70 kPa                      TP &lt; 1%                      VS &lt; 2 MPH                      Above met for a time &gt; 3 seconds to enable diagnostic.                      If non-intrusive test fails, intrusive test is run.</p> <p><b><u>Run Test: (intrusive)</u></b>                      Air Flow &gt; 17.5 g/sec but &lt; 50 g/sec                      VS &gt; 25 MPH but &lt; 85 MPH                      TP <math>\Delta &lt; 1\%</math>                      Engine Speed <math>\Delta &lt; 50</math> RPM                      IAC motor commanded 10 %/ 100 msec.</p>	10 seconds  Continuous after enable	DTC Type B
Idle Air Control - High	P1509	This DTC will determine if a high idle is the result of an engine mechanical problem. A high idle is defined as 100 RPM above the desired idle.	Air flow $\Delta > 3$ g/s	<p><b><u>Test Enable: (non - intrusive)</u></b>                      TP sensor DTC's not active                      VS sensor DTC's not active                      ECT DTC's not active                      MAP DTC's not active                      ECT &gt; 50°C                      System Voltage &gt; 10V but &lt; 16 V                      IAT &gt; -25°C                      Engine run time &gt; 30 seconds                      Baro &gt; 70 kPa                      TP &lt; 1%                      VS &lt; 2 MPH                      Above met for a time &gt; 3 seconds to enable diagnostic.                      If non-intrusive test fails, intrusive test is run.</p> <p><b><u>Run Test: (intrusive)</u></b>                      Air Flow &gt; 17.5 g/sec but &lt; 50 g/sec                      VS &gt; 25 MPH but &lt; 85 MPH                      TP <math>\Delta &lt; 1\%</math>                      Engine Speed <math>\Delta &lt; 50</math> RPM                      IAC motor commanded 10 %/ 100 msec.</p>	10 seconds  Continuous after enable	DTC Type B