

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Mass Air Flow Sensor Circuit - Range/Rationality	P0101	Under conditions when the two should match, the Mass Air Flow reading should match calculated Mass Air Flow (based on speed density. If delta Mass Air Flow is too large, a faulty Mass Air Flow condition exists, such as a "skewed" sensor.	MAF $\Delta \geq$ a table value determined by the difference between the MAF sensor reading and the speed density calculation.	Engine Running TP sensor DTC's not active. MAP sensor DTC's not active. Evap. DTC's not active EGR DTC P0401 not active MAF sensor high / low DTC's not active. Crank Sensor DTC's not active IAT Sensor DTC's not active System voltage > 11V but < 16V Canister Purge DC \leq 99.6% TP $\Delta \leq$ 3.9% EGR DC \leq 89.8% EGR Pintle Position \leq 89.8% Engine vacuum \leq 75 kPa Throttle Position \leq 89.8% The above must be present for a period of time greater than 2 seconds.	50 test failures within a 100 test sample. Time necessary to complete sample: 10 sec The Mass Air Flow reading and Mass Air Flow calculation are performed during the same cylinder event every 100 ms.	Lt Duty=B Federal Hvy Duty=C
Mass Air Flow Sensor Circuit - Low Input	P0102	This DTC will determine if the MAF frequency is too low.	LOW FREQUENCY TEST: MAF \leq 10 Hz	LOW FREQUENCY TEST: Engine Running Engine Run Time \geq 0.4 seconds Engine Speed \geq 300 RPM System Voltage \geq 8 Volts The above must be present for a period of time greater than 0 seconds.	LOW FREQUENCY TEST: 4 test failures within a 16 test sample. Time necessary to complete sample: 1 sec at 500 RPM Test is run at every reading of the Mass Air Flow sensor frequency.	DTC Type B
Mass Air Flow Sensor Circuit - High Input	P0103	This DTC will determine if the MAF frequency is too high	HIGH FREQUENCY TEST: MAF \geq 11000 Hz	HIGH FREQUENCY TEST: Engine Running Engine Run Time \geq 0.4 seconds Engine Speed \geq 300 RPM System Voltage \geq 8 Volts The above must be present for a period of time greater than 0 seconds.	HIGH FREQUENCY TEST: 6 test failures within a 16 test sample. Time necessary to complete sample: 1 sec at 500 RPM Test is run at every reading of the Mass Air Flow sensor frequency.	DTC Type B

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
MAP Sensor - Range/Rationality	P0106	Under proper conditions, the MAP value should be within a window (based on throttle position and engine speed). If not, a faulty MAP condition such as a "skewed" sensor exists.	A table defining the minimum acceptable MAP value \leq MAP \leq a table defining the maximum acceptable MAP value	TP sensor DTC's not active Engine Running Engine Speed $\Delta < 75$ RPM Throttle Position $\Delta < 1.5\%$ Idle Air $\Delta < 4$ steps EGR Flow Rate $\Delta < 2\%$ Brake Switch State = no change Clutch Switch State = no change AC Clutch State = no change Above stabilized for 2 seconds EGR DTC's not active Engine Speed ≥ 400 RPM Engine Speed ≤ 5000 RPM	24 test failures within a 100 test sample. Time necessary to complete sample: 100 sec Continuous	Lt Duty=B Federal Hvy Duty=C
MAP Sensor Circuit - Low Input	P0107	This DTC detects a continuous short to low or open in either the signal circuit or the MAP sensor.	Raw MAP < 0.04 Volts (3 counts)	TP sensor DTC's not active Engine Running Throttle Position $\geq 0\%$ when Engine speed is ≤ 800 RPM or Throttle Position is $\geq 12.5\%$ when Engine speed is > 800 RPM	40 test failures within a 100 test sample. Time necessary to complete sample is based on engine speed. At 1600 RPM, the time would be 1 sec. Continuous	DTC Type B
MAP Sensor Circuit - High Input	P0108	This DTC detects an open sensor ground or continuous short to high in either the signal circuit or the MAP sensor.	Raw MAP > 4.4 Volts (222 counts)	Cold Start Run Time - Table value in seconds based on Powerup Coolant Temperature. Run Test TP sensor DTC's not active Throttle Position $\leq 0.4\%$ when Engine speed is ≤ 1200 RPM or Throttle Position is $\leq 20\%$ when Engine speed is > 1200 RPM	40 test failures within a 100 test sample. Time necessary to complete sample is based on engine speed. At 1600 RPM, the time would be 1 sec. Continuous	DTC Type B
Intake Air Temp. Sensor Circuit -Low Input	P0112	The DTC detects a continuous short to ground in the IAT signal circuit or the IAT sensor	Low Resistance pull-up Raw IAT < 0.82 Volts High Resistance pull-up Raw IAT < 0.07 Volts	VS sensor DTC's not active Vehicle speed ≥ 2 mph Engine run time > 100 seconds	40 test failures within a 100 test sample Time necessary to complete sample: 12.5 sec Continuous	DTC Type B
Intake Air Temp. Sensor Circuit - High Input	P0113	The DTC detects a continuous open or short to high in the IAT signal circuit or the IAT sensor	Low Resistance pull-up Raw IAT > 4.9 Volts High Resistance pull-up Raw IAT > 4.9 Volts	ECT sensor DTC's not active VS sensor DTC's not active MAF sensor DTC's not active Vehicle speed < 2 mph Mass Air flow < 250 g/s Coolant Temperature $> 84.7^\circ\text{C}$ Engine run time > 100 seconds	40 test failures within a 100 test sample Time necessary to complete sample: 12.5 sec Continuous	DTC Type B

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Engine Coolant Temp. Sensor Circuit-Low Input	P0117	The DTC detects a continuous short to ground in the ECT signal circuit or the ECT sensor	Low Resistance pull-up Raw ECT < 0.25 Volts High Resistance pull-up Raw ECT < 0.25 Volts	Engine run time > 5 seconds	40 test failures within a 100 test sample Time necessary to complete sample: 50 sec Continuous	DTC Type B
Engine Coolant Temp. Sensor Circuit-High Input	P0118	The DTC detects a continuous short to high or open in the ECT signal circuit or the ECT sensor	Low Resistance pull-up Raw ECT > 4.9 Volts High Resistance pull-up Raw ECT > 4.9 Volts	Engine run time > 5 seconds	40 test failures within a 100 test sample Time necessary to complete sample: 50 sec Continuous	DTC Type B
Throttle Position Sensor Circuit-Range/Rationality	P0121	The DTC detects a "skewed" or stuck TP sensor	Stuck high test: The last throttle position value is > predicted throttle position based on engine RPM. Stuck low test: The last throttle position value is < predicted throttle position based on engine RPM.	Test Enable: No TP sensor short DTC's active No IAC DTC's active No MAP DTC's active Engine running BARO not defaulted TP Δ < 1.9% Stuck high test: MAP < 50 kPa Stuck low test: Stuck high test has passed MAP > 65 kPa IAC > 10 counts but < 340 counts	Stuck high test: 50 test failures within a 100 test sample Stuck low test: 50 test failures within a 100 test sample Time necessary to complete each sample: 10 sec Continuous	Lt Duty=B Federal Hvy Duty=C
Throttle Position Sensor Circuit-Low Input	P0122	This DTC detects a continuous short to low or open in either the signal circuit or the TP sensor.	TP sensor signal voltage < 0.25 volts (13 counts)	Engine running	5 consecutive test failures within a 10 test sample Time necessary to complete sample: 1 sec Continuous	DTC Type B
Throttle Position Sensor Circuit-High Input	P0123	This DTC detects a continuous short to high in either the signal circuit or the TP sensor.	TP sensor signal voltage > 4.7 volts (242 counts)	Engine running	5 consecutive test failures within a 10 test sample Time necessary to complete sample: 1 sec Continuous	DTC Type B

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Min. Cool. Temp. to Allow C.L. Op. Not Achieved Without Excess. Time	P0125	The DTC detects if a stabilized minimum closed-loop is reached and maintained after engine start-up.	<p>Minimum stabilized ECT <20C after 480 seconds</p> <p>Minimum stabilized ECT < 20°C after 300 seconds.</p> <p>Minimum stabilized ECT < 20°C after 120 seconds.</p>	<p>Diagnostic Enable Engine running ECT sensor short tests not failing or DTC's not active IAT sensor DTC's not active IAT > - 40°C ECT > - 40°C Start-up ECT ≤ 40°C Closed Loop Test: For a vehicle saturated at -40°C (-40°F) Accumulated air flow since start > 7500 (V6) 9000 (V8)grams Accumulated Idle time < 360 seconds</p> <p>For a vehicle saturated at -7°C (20°F) Accumulated air flow since start > 4500(V6) 5500(V8)grams Accumulated Idle time < 225 seconds</p> <p>For a vehicle saturated at 10°C (50°F) Accumulated air flow since start > 1600(V6) 2000(V8) grams Accumulated Idle time < 90 seconds</p>	<p>10 consecutive test failures</p> <p>Continuous</p>	<p>Lt Duty=B Federal Hvy Duty=C</p>
O2S Circuit-Low Voltage (Bank 1, Sensor 1) All Applications	P0131	This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady state throttle and during power enrichment (PE).	<p>Lean test: O2 sensor voltage < 86 mV</p> <p>or</p> <p>PE Lean Test: O2 sensor voltage < 598 mV</p>	<p>O2 Diagnostic Enable: (the following criteria must be met to enable the O2 lean tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7 Volts Test Enable (Lean test): Closed loop low MAP not active Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 3.5% but < 99% Above met for 5 seconds Test Enable (PE Lean test): Closed loop Power Enrichment mode active High speed fuel cutoff not active Time elapsed since test enable ≥ 1 sec.</p>	<p>Lean Test: 500 test failures in a 600 test sample</p> <p>Time necessary to complete sample: 60 sec</p> <p>Continuous</p> <p>or</p> <p>PE Lean Test: 300 test failures in a 500 test sample.</p> <p>Time necessary to complete sample: 50 sec</p>	<p>DTC Type B</p>

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-High Voltage (Bank 1, Sensor 1) All Applications	P0132	This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and Decel fuel cutoff (DFCO)	<p><u>RichTest:</u> O2 sensor voltage > 976 mV</p> <p>or</p> <p><u>DFCO Rich Test:</u> O2 sensor voltage > 468 mV</p>	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 rich tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7- Volts <u>Test Enable (Rich Test):</u> Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 0% but < 50% Above met for 5 seconds <u>Test Enable (DFCO Rich Test):</u> Decel Fuel Cutoff mode active Closed loop Time elapsed since test enable ≥ 2 sec.</p>	<p><u>Rich Test:</u> 400 test failures in a 500 test sample</p> <p>Time necessary to complete sample: 50 sec</p> <p>Continuous</p> <p>or</p> <p><u>DFCO Rich Test:</u> 300 test failures in a 500 test sample</p> <p>Time necessary to complete sample: 50 sec</p>	DTC Type B
O2S Circuit-Slow Response (Bank 1, Sensor 1) All Applications	P0133	This DTC determines if the O2 sensor functioning properly by checking its response time.	<p>O2 sensor average transition time: L/R > 125 milliseconds R/L > 125 milliseconds *O2 voltage < 300 mV = lean *O2 voltage > 600 mV = rich</p>	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9 Volts <u>Response Test Enable:</u> 11.7- Volts Closed loop low MAP not active DTC's P0131, P0132, P0134 and P0135 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 15 g/s but ≤ 55 g/s Engine speed ≥ 1100 rpm but ≤ 3000 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds</p>	<p>100 seconds after closed loop enable</p> <p>Once per ignition cycle</p>	Lt Duty=B Federal Hvy Duty=C

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit- No Activity Detected (Bank 1, Sensor 1)	P0134	This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 350 mV but < 550 mV all applications except: 4.3L S/T 4.3L LD G Van, and 4.3L C/K . These applications are O2 sensor >300 mV but < 600 mV.	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 open test) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7 - Volts Engine Run Time ≥ 120 seconds <u>O2 Sensor Temperature Test:</u> Not in DFCO ECT ≥ 58.5°C Air Flow ≥ 13 g/s <u>O2 sensor Open test enable:</u> O2 Sensor Temperature Test = True DTC P0135 not active Closed Loop</p>	800 test failures with in a 1000 test sample Time necessary to complete sample: 100 sec Continuous	DTC Type B
O2S Heater Circuit Malfunction (Bank 1, Sensor 1)	P0135	This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	The elapsed time to obtain ± .150V from the mean O2 bias voltage. *Time based on table: Time Vs Average Air Flow	System Voltage > 11.7 but <- 17 olts except 4.3L S/T, and C/K which are voltage > 11.7 Volts but < 18 volts (NOTE: If voltage remains outside this window for 4 consecutive seconds, the test is void for this cold start.) Air Flow < 27 g/sec -(4.3 S/T and G) 21 g/s (4.3 M/L Van) or 35 g/s (5.7L C/K/G) Engine run time > 2 seconds ECT < 33°C IAT < 33°C Δ ECT-IAT ≤ 5°C	From cold start to a maximum time of - 115 seconds. *Time determined by table.	Lt Duty=B Federal Hvy Duty=C
O2S Circuit-Low Voltage (Bank 1, Sensor 2) 4 Sensor Applications Only -	P0137	This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady state throttle and during power enrichment (PE).	<p><u>Lean test:</u> O2 sensor voltage < 26 mV</p> <p>or</p> <p><u>PE Lean Test:</u> O2 sensor voltage < 399 mV</p>	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 lean tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7 - Volts <u>Test Enable (Lean test):</u> Closed loop low MAP not active Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 3.5% but < 99% Above met for 5 seconds <u>Test Enable (PE Lean test):</u> Closed loop Power Enrichment mode active High speed fuel cutoff not active Time elapsed since test enable ≥ 2 sec.</p>	<p><u>Lean Test:</u> 1100 test failures in a 1300 test sample</p> <p>Time necessary to complete sample: 130 sec</p> <p>Continuous</p> <p>or</p> <p><u>PE Lean Test:</u> 400 test failures in a 500 test sample.</p> <p>Time necessary to complete sample: 50 sec</p>	DTC Type B

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-High Voltage (Bank 1, Sensor 2) 4 Sensor Applications On;y -	P0138	This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and Decel fuel cutoff (DFCO)	<p><u>RichTest:</u> O2 sensor voltage > 994mV</p> <p>or</p> <p><u>DFCO Rich Test:</u> O2 sensor voltage > 469 mV</p>	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 rich tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7 - Volts <u>Test Enable (Rich Test):</u> Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 0% but < 50% Above met for 5 seconds <u>Test Enable (DFCO Rich Test):</u> Decel Fuel Cutoff mode active Closed loop Time elapsed since test enable ≥ 2 sec.</p>	<p><u>Rich Test:</u> 1100 test failures in a 1500 test sample</p> <p>Time necessary to complete sample: 150 sec</p> <p>Continuous</p> <p>or</p> <p><u>DFCO Rich Test:</u> 400 test failures in a 500 test sample</p> <p>Time necessary to complete sample: 50 sec</p>	DTC Type B
O2S Circuit- No Activity Detected (Bank 1, Sensor 2) 4 Sensor Applications Only -	P0140	This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 400 mV but < 473 mV	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 open test) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7 - Volts Engine Run Time ≥ 120 seconds <u>O2 Sensor Temperature Test:</u> Not in DFCO ECT ≥ 58.5°C Air Flow ≥ 13 g/s <u>O2 sensor Open test enable:</u> O2 Sensor Temperature Test = True DTC P0141 not active Closed Loop</p>	<p>950 test failures with in a 1200 test sample</p> <p>Time necessary to complete sample: 120 sec</p> <p>Continuous</p>	DTC Type B
O2S Heater Circuit Malfunction (Bank 1, Sensor 2) 4 Sensor Applications Only	P0141	This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	<p>The elapsed time to obtain ± .150V from the mean O2 bias voltage.</p> <p>*Time based on table: Time Vs Average Air Flow</p>	<p>System Voltage > 11.7 but <18 Volts (NOTE: If voltage remains outside this window for 4 consecutive seconds, the test is void for this cold start.) Air Flow < 35 g/sec 5.7L C/K/G (27 g/s 4.3L GMT800) Engine run time > 2 seconds ECT < 33°C IAT < 33°C Δ ECT-IAT ≤ 5°C</p>	<p>From cold start to a maximum time of 245 seconds.</p> <p>*Time determined by table.</p>	Lt Duty=B Federal Hvy Duty=C

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-Low Voltage (Bank 1, Sensor 3) 3 Sensor Applications Only -	P0143	This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady state throttle and during power enrichment (PE).	<p><u>Lean test:</u> O2 sensor voltage < 26 mV</p> <p>or</p> <p><u>PE Lean Test:</u> O2 sensor voltage < 399 mV</p>	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 lean tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7 - Volts <u>Test Enable (Lean test):</u> Closed loop low MAP not active Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 3.5% but < 99% Above met for 5 seconds</p> <p><u>Test Enable (PE Lean test):</u> Closed loop Power Enrichment mode active High speed fuel cutoff not active Time elapsed since test enable ≥ 2 sec.</p>	<p><u>Lean Test:</u> 1100 test failures in a 1300 test sample</p> <p>Time necessary to complete sample: 130 sec</p> <p>Continuous</p> <p>or</p> <p><u>PE Lean Test:</u> 400 test failures in a 500 test sample.</p> <p>Time necessary to complete sample: 50 sec</p>	DTC Type B
O2S Circuit-High Voltage (Bank 1, Sensor 3) 3 Sensor Applications Only -	P0144	This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and Decel fuel cutoff (DFCO)	<p><u>RichTest:</u> O2 sensor voltage > 994mV</p> <p>or</p> <p><u>DFCO Rich Test:</u> O2 sensor voltage > 469 mV</p>	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 rich tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7 - Volts <u>Test Enable (Rich Test):</u> Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 0% but < 50% Above met for 5 seconds <u>Test Enable (DFCO Rich Test):</u> Decel Fuel Cutoff mode active Closed loop Time elapsed since test enable ≥ 2 sec.</p>	<p><u>Rich Test:</u> 1100 test failures in a 1500 test sample</p> <p>Time necessary to complete sample: 150 sec</p> <p>Continuous</p> <p>or</p> <p><u>DFCO Rich Test:</u> 400 test failures in a 500 test sample</p> <p>Time necessary to complete sample: 50 sec</p>	DTC Type B

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit- No Activity Detected (Bank 1, Sensor 3) 3 Sensor Applications Only -	P0146	This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 399 mV but < 473 mV	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 open test) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7- Volts Engine Run Time ≥ 120 seconds <u>O2 Sensor Temperature Test:</u> Not in DFCO ECT ≥ 58.5°C Air Flow ≥ 13 g/s <u>O2 sensor Open test enable:</u> O2 Sensor Temperature Test = True DTC P0147 not active Closed Loop</p>	- 950 test failures with in a 1200 test sample Time necessary to complete sample: 120 sec Continuous	DTC Type B
O2S Heater Circuit Malfunction (Bank 1, Sensor 3) 3 Sensor Applications Only -	P0147	This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	The elapsed time to obtain ± .150V from the mean O2 bias voltage. *Time based on table: Time Vs Average Air Flow	System Voltage > 11.7 but <18 Volts NOTE: If voltage remains outside this window for 4 consecutive seconds, the test is void for this cold start.) Air Flow < 27 g/sec 4.3L S/T C/K/G (21 g/s 4.3L M/L van only - Denso Sensors) Engine run time > 2 seconds ECT < 33°C IAT < 33°C Δ ECT-IAT ≤ 5°C	From cold start to a maximum time of 245 seconds. (270sec 4.3L M/L van only - Denso Sensors) *Time determined by table.	Lt Duty=B Federal Hvy Duty=C
O2S Circuit-Low Voltage (Bank 2, Sensor 1)	P0151	This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady state throttle and during power enrichment (PE).	<p><u>Lean test:</u> O2 sensor voltage < 86 mV</p> <p>or</p> <p><u>PE Lean Test:</u> O2 sensor voltage < 598 mV</p>	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 lean tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7 - Volts <u>Test Enable (Lean test):</u> Closed loop low MAP not active Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 3.5% but < 99% Above met for 5 seconds <u>Test Enable (PE Lean test):</u> Closed loop Power Enrichment mode active High speed fuel cutoff not active Time elapsed since test enable ≥ 1 sec.</p>	<p><u>Lean Test:</u> 500 test failures in a 600 test sample Time necessary to complete sample: 60 sec Continuous or <u>PE Lean Test:</u> 300 test failures in a 500 test sample. Time necessary to complete sample: 50 sec</p>	DTC Type B

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-High Voltage (Bank 2, Sensor 1)	P0152	This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and Decel fuel cutoff (DFCO)	<p><u>Rich Test:</u> O2 sensor voltage > 976 mV</p> <p>or</p> <p><u>DFCO Rich Test:</u> O2 sensor voltage > 468 mV</p>	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 rich tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7 - Volts <u>Test Enable (Rich Test):</u> Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 0% but < 50% Above met for 5 seconds <u>Test Enable (DFCO Rich Test):</u> Decel Fuel Cutoff mode active Closed loop Time elapsed since test enable ≥ 2 sec.</p>	<p><u>Rich Test:</u> 400 test failures in a 500 test sample</p> <p>Time necessary to complete sample: 50 sec</p> <p>Continuous</p> <p>or</p> <p><u>DFCO Rich Test:</u> 300 test failures in a 500 test sample</p> <p>Time necessary to complete sample: 50 sec</p>	DTC Type B
O2S Circuit-Slow Response (Bank 2, Sensor 1)	P0153	This DTC determines if the O2 sensor functioning properly by checking its response time.	<p>O2 sensor average transition time: L/R > 125 milliseconds R/L > 125 milliseconds</p> <p>*O2 voltage < 300 mV = lean *O2 voltage > 600 mV = rich</p>	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7- Volts <u>Response Test Enable:</u> Closed loop low MAP not active DTC's P0151, P0152, P0154 and P0155 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 15 g/s but ≤ 55 g/s Engine speed ≥ 1100 rpm but ≤ 3000 rpm Canister Purge Duty Cycle ≥ 0% Above present > 2 seconds</p>	<p>100 seconds after closed loop enable</p> <p>Once per ignition cycle</p>	Lt Duty=B Federal Hvy Duty=C

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit- No Activity Detected (Bank 2, Sensor 1)	P0154	This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 350 mV but < 600 mV for all except 4.3LS/T, and 4.3L C/K which is O2 sensor > 300 mV but <600 mV.	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 open test) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7 - Volts Engine Run Time ≥ 120 seconds <u>O2 Sensor Temperature Test:</u> Not in DFCO ECT ≥ 58.5°C Air Flow ≥ 13 g/s <u>O2 sensor Open test enable:</u> O2 Sensor Temperature Test = True DTC P0155 not active Closed Loop</p>	800 test failures with in a 1000 test sample Time necessary to complete sample: 100 sec Continuous	DTC Type B
O2S Heater Circuit Malfunction (Bank 2, Sensor 1)	P0155	This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	The elapsed time to obtain ± .150V from the mean O2 bias voltage. *Time based on table: Time Vs Average Air Flow	System Voltage > 11.7 but < 17 Volts except 4.3L C/K/G which is voltage >11.7 but < 18 volts. (NOTE: If voltage remains outside this window for 4 consecutive seconds, the test is void for this cold start.) Air Flow < 27 g/sec 4.3L (21 g/s 4.3L M/L only - Denso Sensors; 35 g/s - 5.7L only) Engine run time > 2 seconds ECT < 33°C IAT < 33°C Δ ECT-IAT ≤ 5°C	From cold start to a maximum time of - 115 seconds. *Time determined by table.	Lt Duty=B Federal Hvy Duty=C
O2S Circuit-Low Voltage (Bank 2, Sensor 2) 4 Sensor Applications Only -	P0157	This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady state throttle and during power enrichment (PE).	<p><u>Lean test:</u> O2 sensor voltage < 26 mV</p> <p>or</p> <p><u>PE Lean Test:</u> O2 sensor voltage < 399 mV</p>	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 lean tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7- Volts <u>Test Enable (Lean test):</u> Closed loop low MAP not active Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 3.5% but < 99% Above met for 5 seconds <u>Test Enable (PE Lean test):</u> Closed loop Power Enrichment mode active High speed fuel cutoff not active Time elapsed since test enable ≥ 2sec.</p>	<p><u>Lean Test:</u> 1100 test failures in a 1300 test sample</p> <p>Time necessary to complete sample: 130 sec</p> <p>Continuous</p> <p>or</p> <p><u>PE Lean Test:</u> 400 test failures in a 500 test sample.</p> <p>Time necessary to complete sample: 50 sec</p>	DTC Type B

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-High Voltage (Bank 2, Sensor 2) 4 Sensor Applications Only -	P0158	This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and Decel fuel cutoff (DFCO)	Rich Test: O2 sensor voltage > 994 mV or DFCO Rich Test: O2 sensor voltage > 469 mV	O2 Diagnostic Enable: (the following criteria must be met to enable the O2 rich tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7 - Volts Test Enable (Rich Test): Closed loop Air/Fuel ratio ≥ 14.5 but ≤ 14.8 Throttle position > 0% but < 50% Above met for 5 seconds Test Enable (DFCO Rich Test): Decel Fuel Cutoff mode active Closed loop Time elapsed since test enable ≥ 2 sec.	Rich Test: 1100 test failures in a 1500 test sample Time necessary to complete sample: 150 sec Continuous or DFCO Rich Test: 400 test failures in a 500 test sample Time necessary to complete sample: 50 sec	DTC Type B
O2S Circuit- No Activity Detected (Bank 2, Sensor 2) 4 Sensor Applications Only -	P0160	This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 399 mV but < 473 mV	O2 Diagnostic Enable: (the following criteria must be met to enable the O2 open test) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7 - Volts Engine Run Time ≥ 120 seconds O2 Sensor Temperature Test: Engine Running Not in DFCO ECT ≥ 58.5°C Air Flow ≥ 13 g/s O2 Sensor Open Test Enable: O2 Sensor Temperature Test = True DTC P0155 not active Closed Loop	950 test failures with in a 1200 test sample Time necessary to complete sample: 120 sec Continuous	DTC Type B
O2S Heater Circuit Malfunction (Bank 2, Sensor 2) 4 Sensor Applications Only -	P0161	This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	The elapsed time to obtain ± .150V from the mean O2 bias voltage. *Time based on table: Time Vs Average Air Flow	System Voltage > 11.7 but < - 17 Volts except 4.3L C/K/G which is O2 sensor >11.7 Volts but < 18 volts (NOTE: If voltage remains outside this window for 4 consecutive seconds, the test is void for this cold start.) Air Flow < 35 g/sec (27 g/s 4.3L GMT800) Engine run time > 2 seconds ECT < 33°C IAT < 33°C Δ ECT-IAT ≤ 5°C	From cold start to a maximum time of 245 seconds. *Time determined by table.	Lt Duty=B Federal Hvy Duty=C

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
System Too Lean (Bank 1)	P0171	Determines if the system is in a lean condition.	The average of short term fuel trim samples ≥ 1.0 and The average of adaptive index multiplier samples ≥ 1.20	<u>Test Enable:</u> O2 sensor DTC's not active TP sensor DTC's not active MAP DTC's not active EGR DTC's not active Evap. DTC's not active ECT DTC's not active MAF DTC's not active IAT DTC's not active VS sensor DTC's not active Misfire DTC's not active Throttle position < 69.9% Engine speed > 500 rpm but < 4000 rpm Baro > 70 kPa ECT > 75°C but < 114°C MAP > 22 kPa but < 85 kPa IAT > -8.25 °C but < 76°C Air flow > 3 g/s < 85g/s Vehicle speed < 85 mph	If lean counter is ≥ 6 counts 1 count \cong 200 ms Continuous	DTC Type B
System Too Rich (Bank 1)	P0172	Determines if the system is in a rich condition.	The average of short term fuel trim samples ≤ 1.0 and If adaptive lag factor < 0.86, then purge valve is commanded closed. If the integrator exceeds 1.023 or the delta integrator during test exceeds 0.16 within 10 seconds, the diagnostic is turned OFF for 300 seconds to enable the Evap. canister to purge. If the integrator does not exceed 1.023 or the integrator does not change by 0.16 within 10 seconds, a fault is present.	<u>Test Enable:</u> O2 sensor DTC's not active TP sensor DTC's not active MAP DTC's not active EGR DTC's not active Evap. DTC's not active ECT DTC's not active MAF DTC's not active IAT DTC's not active VS sensor DTC's not active Misfire DTC's not active Throttle position < 69.9% Engine speed > 500 rpm but < 4000 rpm Baro > 70 kPa ECT > 75°C but < 114°C MAP > 22 kPa but < 85 kPa IAT > -8.25°C but < 76°C Air flow > 3 g/s < 85g/s Vehicle speed < 85 mph	If rich counter is ≥ 6 counts 1 count \cong 200 ms Continuous	DTC Type B

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
System Too Lean (Bank 2)	P0174	Determines if the system is in a lean condition.	The average of short term fuel trim samples ≥ 1.0 and The average of adaptive index multiplier samples ≥ 1.20	Test Enable: O2 sensor DTC's not active TP sensor DTC's not active MAP DTC's not active EGR DTC's not active Evap. DTC's not active ECT DTC's not active MAF DTC's not active IAT DTC's not active VS sensor DTC's not active Misfire DTC's not active Throttle position < 69.9% Engine speed > 500 rpm but < 4000 rpm Baro > 70 kPa ECT > 75°C but < 114°C MAP > 22 kPa but < 85 kPa IAT > -8.25°C but < 76°C Air flow > 3 g/s < 85 g/s Vehicle speed < 85 mph	If lean counter is ≥ 6 counts 1 count \cong 200 ms Continuous	DTC Type B
System Too Rich (Bank 2)	P0175	Determines if the system is in a rich condition.	The average of short term fuel trim samples ≤ 1.0 and If adaptive lag factor < 0.86, then purge valve is commanded closed. If the integrator exceeds 1.023 or the delta integrator during test exceeds 0.16 within 10 seconds, the diagnostic is turned OFF for 300 seconds to enable the Evap. canister to purge. If the integrator does not exceed 1.023 or the integrator does not change by 0.16 within 10 seconds, a fault is present.	Test Enable: O2 sensor DTC's not active TP sensor DTC's not active MAP DTC's not active EGR DTC's not active Evap. DTC's not active ECT DTC's not active MAF DTC's not active IAT DTC's not active VS sensor DTC's not active Misfire DTC's not active Throttle position < 69.9% Engine speed > 500 rpm but < 4000 rpm Baro > 70 kPa ECT > 75°C but < 114°C MAP > 22 kPa but < 85kPa IAT > -8.25 °C but < 76°C Air flow > 3 g/s < 85 g/s Vehicle speed < 85 mph	If rich counter is ≥ 6 counts 1 count \cong 200 ms Continuous	DTC Type B

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Random Misfire Detected	P0300	This DTC will determine if a multiple or a cylinder specific misfire is occurring by monitoring crankshaft velocity.	Deceleration index Vs Engine Speed Vs Load with Engine position FTP Threshold 1.85% (L30, L31) I/M Threshold 1.85% (L30, L31) FTP Threshold 1.31% (LF6, L35) I/M Threshold 1.31% (LF6, L35) Catalyst Damage - see speed/load chart	TEST Enable: If start up ECT below -7 C then MFD delayed until ECT is above 21 C. If start up ECT \geq is above -7° C then MFT begins after 5 seconds Fuel Level > 10.156% ECT < 130 C System voltage \geq 11 volts but \leq 16 volts Engine speed \geq 450 RPM but \leq 5000 RPM Vehicle speed DTC not active TP sensor DTC's not active MAF sensor DTC's not active Camshaft position sensor DTC's not active Crank sensor DTC's not active + Throttle position $\Delta < 1.9\%/100\text{ms}$ - Throttle position $\Delta < 1.9\%/100\text{ms}$ Abusive Engine Speed (<i>Automatic Transmission</i>): -Abusive Engine Speed < 5600 rpm (L30, L31, LF6, L35) Abusive Engine Speed (<i>Manual Transmission</i>): -Abusive Engine Speed < 6100 rpm (L35) Not a Rough Road - ABS	Emission Level 10 failed 200 revolution blocks out of 16 Catalyst Damaging Level 4 failed 200 revolution blocks out of 16 Continuous	DTC Type B <i>EMISSION</i> DTC Type A <i>CATALYST DAMAGING</i>
Knock Sensor 1 Circuit Malfunction	P0325	This diagnostic will detect excessive noise on the knock sensor circuit.	SNEF STUCK LOW TEST: Knock is detected for excessive amount of time.	SNEF STUCK LOW TEST: DTC P0327 not active Engine Run Time \geq 120 seconds System voltage > 10V but \leq 17.1V	SNEF STUCK LOW TEST: 10 test failures within a 100 test sample. Test is run every 500 msec. Time necessary to run test: 50 seconds	Lt Duty=B Federal Hvy Duty=C
Knock Sensor 1 Circuit - Low Input	P0327	This diagnostic will detect a lack of noise on the knock sensor circuit.	KNOCK SENSOR UPDATE TEST Learned Minimum noise Value updated with the filtered value every 50 msec. ACTIVE NOISE CHANNEL TEST: Knock sensor noise \leq 50 A/D counts or > 200 A/D counts. (ESC noise - Minimum Noise Value)	KNOCK SENSOR UPDATE TEST: Timing retard $\leq 0^\circ$ System voltage > 10 V but ≤ 17.1 V ECT $\geq 60^\circ$ C Engine Run Time ≥ 120 seconds Engine speed > 500 RPM but ≤ 900 RPM Knock sensor delta noise < 3 counts ACTIVE NOISE CHANNEL TEST: ECT DTC's not active TP sensor DTC's not active Knock sensor update test complete ECT $\geq 60^\circ$ C Engine speed > 2000 RPM but ≤ 3000 RPM Throttle position $\geq 5.9\%$	Delta Min Noise to Low 100 failures per ignition cycle Time necessary to complete sample: 50 sec Continuous ACTIVE NOISE CHANNEL TEST: Noise counter ≥ 20 counts. 1 count $\cong 100$ ms	Lt Duty=B Federal Hvy Duty=C

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Crankshaft Position Sensor Circuit-Range	P0336	3X / 4X Signal This diagnostic will detect a loss of crank sensor signal or long time constant intermittent that would result in a " no start" condition.	Crank Position Sensor Signal missing for a time \geq .5 seconds.	Engine Cranking 4 or more Cam Shaft Position Signals Present	\geq 3 seconds During engine crank.	DTC Type B
Crankshaft Position Sensor Circuit- Low Input	P0337	3X / 4X Signal This diagnostic will detect a low duty cycle from the crankshaft position sensor.	Crank sensor duty cycle High Ref/Low Ref < .1875	Engine speed < 4000 RPM Air Flow \geq 5 g/second	15 Ref pulse failures within a 20 sample limit. Time necessary to complete sample: Varies with engine speed Once every TDC	DTC Type B
Crankshaft Position Sensor Circuit- Intermittent Input	P0339	3X / 4X Signal This diagnostic will detect an intermittent crankshaft position signal.	The calculated instantaneous engine speed $\Delta \geq$ 1000 RPM or The calculated instantaneous engine speed = 0 RPM and 4 or more cam cycles have occurred for a period of 1 count (2 to 3 seconds)	Air Flow \geq 5 g/second	10 test failures within a 500 sample limit. Time necessary to complete sample: 5 sec	DTC Type B
Camshaft Position Sensor Circuit Malfunction	P0340	1X Signal This diagnostic will detect if the Cam Sensor signal is present.	Cam Sensor reference pulse is not seen once every 6 cylinders.	Engine Running	If Cam signal is not detected within 1.75 seconds, test has failed. Once every TDC	DTC Type B
Camshaft Position Sensor Circuit Range/Rationality	P0341	1X Signal This diagnostic will determine if the Cam Sensor is synchronized correctly.	Cam Sensor reference pulse is not detected at the correct interval every 6 cylinders.	Engine Running	40 failed tests within a 100 test sample. Time necessary to complete sample: Varies with engine speed Once every TDC	DTC Type B

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Exhaust Gas Recirculation - Insufficient Flow Detected	P0401	This diagnostic will determine if there is a reduction in EGR flow.	With EGR valve open, the peak + MAP Δ is monitored over a time of 2 seconds. This value is compared with a threshold from Engine Speed Vs Baro table and the difference computed. The result is statistically filtered (EWMA) and compared to a decision limit. DTC is set when the filtered result exceeds the decision limit.	<p>Test Enable TP sensor DTC's not active MAP DTC's not active VS sensor DTC's not active IAT sensor DTC's not active ECT sensor DTC's not active IAC DTC's not active Linear EGR Pintle Position DTC not active Misfire DTC's not active ECT > 69.8° C Baro > 70 kPa Vehicle Speed > 27 mph IAC Δ < 8 counts IAT < 76.5° C AC clutch status is unchanged Transmission status is unchanged</p> <p>Start Test Throttle Position < 1.2% EGR Position > .95% but < 1.3% Engine Speed (<i>Manual Transmission</i>): > 1000 rpm but < 1900 rpm (4.3L LD)</p> <p>Engine Speed (<i>Automatic Transmission</i>) : > 800 rpm but < 1600 rpm (5.0L & 5.7L LD) > 800 rpm but < 1900 rpm (5.7L HD) > 900 rpm but < 1600 rpm (4.3L LD) > 900 rpm but < 1700 rpm (4.3L HD)</p> <p>MAP Δ < 1 A/D count (.39 kPa) Compensated MAP > 20 kPa but < 38 kPa Not in DFCO (<i>Automatic Transmission</i>) No change in DFCO state (<i>Manual Transmission</i>)</p> <p>Run Test Stabilized MAP (valve closed) recorded and EGR valve "ramped" open over a time interval and peak MAP value recorded and MAP Δ computed. EGR valve closed</p>	<p>2 seconds</p> <p>Once per trip after EGR I/M Flag is set</p> <p>Maximum of 9 tests per trip until EGR I/M flag set</p> <p>Maximum of 6 tests per trip if a significant deviation from the current EWMA value is detected</p>	DTC Type A
EGR Valve Open Pintle Position Error	P0404	Position error too high	Deviation between actual and desired position > 10% for 10 seconds	Ignition voltage >5V to enable	Continuous	DTC Type B
EGR Sensor Signal Low	P0405	Open / Short in pintle feedback system	Pintle position <6 A/D counts for 10 seconds	Ignition voltage > 5V to enable e	Continuous	DTC Type B
Secondary Air Injection System Malfunction	P0410	<p>Active:</p> <p>O2 sensors indicate lean condition present when AIR pump is turned on during closed loop operation.</p>	<p>Active:</p> <p>Fails when ; O2 sensor is not < approx. 222 mv for > 1.3 seconds OR fuel integrator delta not >= 20% when pump turned on during closed loop operation.</p>	<p>Active:</p> <p>No MAF, MAP, IAT, ECT, TPS, O2, VSS, Sys volt, Fuel Trim, misfire, or CCP DTC. Air flow < 25 g/s.(26 g/s for L31) , engine load < 34 % , PE, DFCO, COT not active. Engine run time after closed loop to enable = 20 seconds in fuel cells -.5. A/F = 14.7, fuel integrator >= 124 & <= 132, RPM > 750 -, ECT > 80 C° < 110 ignition volts > 11.7,.. - IAT > 2°C in fuel cells 5,</p>	<p>Active:</p> <p>Up to 8 seconds. Up to three times per trip.</p>	DTC Type B

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Catalyst System Low Efficiency (Bank 1)	P0420	This diagnostic will determine the efficiency (oxygen storage capacity) of the catalytic converter.	<p>OSC Time Difference \geq 0.05 to .33 sec</p> <p>OSC Time Difference = OSC Worst Pass Thresh - OSC Compensation Factor * (Post Cat O2 Resp Time - Pre Cat O2 Resp Time)</p> <p>OSC Worst Pass Thresh = 0.925 to 2.06 sec</p> <p>Depending on application</p>	<p><u>Trip Enable Criteria</u> No AIR DTC's failing No CAM DTC's failing No ECT DTC's failing No EGR DTC's failing No Fuel Trim DTC's failing No IAC DTC's failing No IAT DTC's failing No MAF DTC's failing No MAP DTC's failing No Oxygen Sensor DTC's failing No PRNDL/Transmission DTC's failing No Purge System DTC's failing No TPS DTC's failing No VSS DTC's failing No Misfire DTC's failing</p> <p><u>Valid Idle Period Criteria</u> Engine Speed \geq 800,900,1000 rpm for minimum of 32 to 42 sec since end of last idle period. Min engine runtime for stable BLM \geq 346, 360 sec Depending on application</p> <p><u>Test Enable Conditions</u> Predicted Catalyst Temperature \geq 475°C Closed loop fuel control Barometric Pressure \geq 73 kPa -6.75 \leq IAT \leq 75°C 75°C \leq ECT \leq 117°C 0 < Idle Period \leq 60 sec IAC change \leq 25 counts Tests Attempted this trip \leq 18 Tests Attempted this idle period =1 -109, -105 rpm \leq (Engine Speed - Desired Speed) \leq 125, 105 rpm</p> <p><u>Rapid Step Response Enable Criteria</u> OSC Time Difference Step \geq 0.105 to .26 sec OSC Time Difference \geq 0.000 sec Depending on application</p>	<p>1 test attempted per valid idle period</p> <p>Maximum of 6 tests per trip until catalyst I/M flag set.</p> <p>Maximum of 1 test per trip after catalyst I/M flag set.</p> <p>frequency: 12.5 ms continuous</p>	DTC Type A

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Catalyst System Low Efficiency (Bank 1)	P0430	This diagnostic will determine the efficiency (oxygen storage capacity) of the catalytic converter.	<p>OSC Time Difference \geq 0.05 to .33 sec</p> <p>OSC Time Difference = OSC Worst Pass Thresh - OSC Compensation Factor * (Post Cat O2 Resp Time Pre Cat O2 Resp Time)</p> <p>OSC Worst Pass Thresh = 0.925 to 2.06 sec</p> <p>Depending on application</p>	<p><u>Trip Enable Criteria</u> No AIR DTC's failing No CAM DTC's failing No ECT DTC's failing No EGR DTC's failing No Fuel Trim DTC's failing No IAC DTC's failing No IAT DTC's failing No MAF DTC's failing No MAP DTC's failing No Oxygen Sensor DTC's failing No PRNDL/Transmission DTC's failing No Purge System DTC's failing No TPS DTC's failing No VSS DTC's failing No Misfire DTC's failing</p> <p><u>Valid Idle Period Criteria</u> Engine Speed \geq 800,900,1000 rpm for minimum of 32 to 42 sec since end of last idle period. Min engine runtime for stable BLM \geq 346, 360 sec Depending on application</p> <p><u>Test Enable Conditions</u> Predicted Catalyst Temperature \geq 475°C Closed loop fuel control Barometric Pressure \geq 73 kPa -6.75 \leq IAT \leq 75°C 75°C \leq ECT \leq 117°C 0 < Idle Period \leq 60 sec IAC change \leq 25 counts Tests Attempted this trip \leq 18 Tests Attempted this idle period =1 -109,-105 rpm \leq (Engine Speed - Desired Speed) \leq 125, 105 rpm</p> <p><u>Rapid Step Response Enable Criteria</u> OSC Time Difference Step \geq 0.105 to .26 sec OSC Time Difference \geq 0.000 sec Depending on application</p>	<p>1 test attempted per valid idle period</p> <p>Maximum of 6 tests per trip until catalyst I/M flag set.</p> <p>Maximum of 1 test per trip after catalyst I/M flag set.</p> <p>frequency: 12.5 ms continuous</p>	DTC Type A

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Evap. Emission Control System Malfunction	P0440	This DTC will detect a weak vacuum condition (large leak or restriction) in the Evap. system.	<p><u>WEAK VACUUM TEST- STAGE I (Cold Test):</u> Tank Vac. < 13 or 9 in. H₂O <u>depending on application</u> <u>WEAK VACUUM TEST- STAGE II (Warm Test):</u> Stage I test failed previous trip and this trip. Tank Vac. < 11 in. H₂O</p>	<p><u>TEST ENABLE :</u> MAP DTC's not active TP Sensor DTC's not active VS Sensor DTC's not active O2 Sensor DTC's not active ECT Sensor DTC's not active DTC P0125 not active IAT Sensor DTC's not active Fuel Level >12.5% but < 87.5% Powerup Vacuum Test Fail = False System Voltage > 10V but < 18V Purge Closed Loop Multiplier ≥ 0.6 for a time ≤ a table value based on coolant temperature. If HC vapor is not present. <u>COLD START TEST:</u> ECT > 3.75°C but < 30° C IAT > 3.75°C but < 30° C Cold Temperature Δ (ECT - IAT): ° < 8.25 °C if ECT > IAT Baro > 72.5 kPa</p> <p><u>FUEL SLOSH TEST:</u> Tank Vacuum Δ ≤ value and Fuel Level Δ ≤ value based on fuel level.</p>	<p><u>WEAK VACUUM TEST- STAGE I (Cold Test):</u> Fault present for an integral time ≥ 30 , 50 or 80 depending on application sec.</p> <p><u>WEAK VACUUM TEST- STAGE II (Warm Test):</u> Fault present for a time ≥ 1400 sec.</p> <p>Once per cold start</p>	DTC Type A (Behaves as a Type B)

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Evap. Emission Control System Leak Detected (Small Leak)	P0442	This DTC will detect a small leak in the Evap. system between the fuel fill cap and up to but not including the purge solenoid.	<p><u>SMALL LEAK TEST FAIL:</u> Vacuum < 7 , 9 or 11" H₂O for a time < based on fuel level depending on application. Vacuum Decay (determined by fuel level and intake temperature) ≥ a value determined by Start Vacuum minus Tank Vacuum for a period ≥ 15 or 12 seconds. Vacuum > 0.1 in. H₂O for a time ≤ 35 , 50,60,80,85seconds. depending on application</p>	<p><u>TEST ENABLE :</u> MAP DTC's not active TP Sensor DTC's not active VS Sensor DTC's not active O2 Sensor DTC's not active ECT Sensor DTC's not active DTC P0125 not active IAT Sensor DTC's not active Fuel Level >12.5% but < 87.5% System Voltage > 10V but < 18V Purge Closed Loop Multiplier ≥ 0.6 for a time ≤ a table value based on coolant temperature. If HC vapor is not present. <u>COLD START TEST:</u> ECT > 3.75°C but < 30° C IAT > 3.75°C but < 30° C Cold Temperature Δ (ECT - IAT): ° < 8.25 °C if ECT > IAT Baro > 72.5 kPa</p> <p><u>.020" LEAK:</u> Fuel level > value based on application. Tank Vacuum Δ ≤ value and Fuel Level Δ ≤ value based on fuel level. <u>FUEL SLOSH TEST:</u> Tank Vacuum Δ ≤ value and Fuel Level Δ ≤ value based on fuel level. <u>WEAK VACUUM TEST (Stage I) :</u> Throttle position < 75% Vehicle speed < 65 mph Tank Vacuum ≥ 9 ,11,13in. H₂O within 30,50,80 dending on app. seconds.</p>	Once per cold start	DTC Type A (Behaves as a Type B)

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Evap. Emission Control System Vent Control Malfunction	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filter, vent hose or canister.	<p><u>EXCESS VACUUM TEST - STAGE I</u></p> <p>Vent solenoid commanded OPEN Fuel Tank Vacuum ≥ 7 in. H₂O for 2 seconds(monitored during initial purge ramp)</p> <p>OR</p> <p><u>EXCESS VACUUM TEST - STAGE II:</u></p> <p>Vent solenoid commanded OPEN during normal purge. Fuel Tank Vacuum ≥ 12.9 in. H₂O for a time ≥ 4 seconds</p>	<p><u>TEST ENABLE :</u></p> <p>MAP DTC's not active TP Sensor DTC's not active VS Sensor DTC's not active O2 Sensor DTC's not active ECT Sensor DTC's not active DTC P0125 not active IAT Sensor DTC's not active Fuel Level $>12.5\%$ but $< 87.5\%$ System Voltage $> 10V$ but $< 18V$ Purge Closed Loop Multiplier ≥ 0.6 for a time \leq a table value based on coolant temperature. If HC vapor is not present.</p> <p><u>COLD START TEST:</u></p> <p>ECT $> 3.75^{\circ}C$ but $< 30^{\circ} C$ IAT $> 3.75^{\circ}C$ but $< 30^{\circ} C$ Cold Temperature Δ (ECT - IAT):</p> <p style="padding-left: 40px;">◦ < 8.25 °C if ECT > IAT Baro > 72.5 kPa</p> <p><u>FUEL SLOSH TEST:</u></p> <p>Tank Vacuum $\Delta \leq$ value and Fuel Level $\Delta \leq$ value based on fuel level.</p> <p><u>WEAK VACUUM TEST -Stage I:</u></p> <p>Tank Vacuum ≥ 9 11 or 13in. H₂O within 30,50,80 seconds. depending on application</p>	<p><u>EXCESS VACUUM TEST - STAGE II :</u></p> <p>180 seconds</p> <p>Once per cold start at:</p> <ul style="list-style-type: none"> • Powerup • Excess Vac. Stage I • Excess Vac. Stage II 	DTC Type A
EVAP Fuel Tank Pressure Sensor Circuit Low Voltage	P0452	This DTC will detect a vacuum sensor stuck low	tank vacuum raw voltage < 0.1 volt for 5 seconds	<u>runs countiously after a 1 second delay for sensor warmup</u>		DTC Type B
EVAP Fuel Tank Pressure Sensor Circuit High Voltage	P0453	This DTC will detect a vacuum sensor stuck hi	tank vacuum raw voltage >4.98 volt for 5 seconds	<u>runs countiously after a 1 second delay for sensor warmup</u>		DTC Type B
Vehicle Speed (VS) Sensor Signal Missing	P0500	The DTC detects a missing vehicle speed sensor signal, generally on an overrun or decel condition.	Vehicle Speed ≤ 1 MPH	MAP sensor DTC's not active MAP < 20 kPa Coolant Temperature $\geq 60^{\circ} C$ Engine > 1400 RPM but < 4400 RPM Throttle Position $< 3.125\%$	Failing > 5 seconds Continuous	DTC Type B

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Idle Control System RPM Lower Than Expected	P0506	This DTC will determine if a low idle is the result of a IAC valve or circuit. A low idle is defined as 75 RPM below the desired idle.	Air flow $\Delta < 3$ g/s	<p><u>Test Enable: (non - intrusive)</u> TP sensor DTC's not active VS sensor DTC's not active ECT DTC's not active MAP DTC's not active ECT > 50°C System Voltage > 10V but < 16 V IAT > -25°C Engine run time > 30 seconds Baro > 70 kPa TP < 1% VS < 2 MPH Above met for a time > 3 seconds to enable diagnostic. If non-intrusive test fails, intrusive test is run.</p> <p><u>Run Test: (intrusive)</u> Air Flow > 17.5 g/sec but < 50 g/sec VS > 25 MPH but < 85 MPH TP $\Delta < 1\%$ Engine Speed $\Delta < 50$ RPM IAC motor commanded 10 %/ 100 msec.</p>	10 seconds Continuous after enable	DTC Type B
Idle Control System RPM Higher Than Expected	P0507	This DTC will determine if a high idle is the result of a IAC valve or circuit. A high idle is defined as 100 RPM above the desired idle.	Air flow $\Delta < 3$ g/s	<p><u>Test Enable: (non - intrusive)</u> TP sensor DTC's not active VS sensor DTC's not active ECT DTC's not active MAP DTC's not active ECT > 50°C System Voltage > 10V but < 16 V IAT > -25°C Engine run time > 30 seconds Baro > 70 kPa TP < 1% VS < 2 MPH Above met for a time > 3 seconds to enable diagnostic. If non-intrusive test fails, intrusive test is run.</p> <p><u>Run Test: (intrusive)</u> Air Flow > 17.5 g/sec but < 50 g/sec VS > 25 MPH but < 85 MPH TP $\Delta < 1\%$ Engine Speed $\Delta < 50$ RPM IAC motor commanded 10 %/ 100 msec.</p>	10 seconds Continuous after enable	DTC Type B
VCM Memory Error - Type 4 (Program Flash)	P0601	This diagnostic checksums the contents of flash EEPROM and compares it to the expected value.	The calculated checksum does not match the programmed value.	-----	Once per trip at controller initialization.	Lt Duty=A Federal Hvy Duty=C

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
VCM Memory Error - Not Programmed	P0602	This diagnostic checks the state of the Service Calibration Bit to determine if the controller needs to be programmed.	The Calibrated No Start For Service bit is true in the calibration.	-----	Once per trip at controller initialization.	Lt Duty=A Federal Hvy Duty=C
VCM Memory Error - Type 2 (Keep Alive)	P0603	This diagnostic checks that data stored to the Non-Volatile Keep Alive section of memory is functioning correctly.	The checksum of the data does stored at powerdown does not match the checksum of the data present at powerup, and the data read from memory does not match the data that was stored to check memory function.	-----	Once per trip at controller initialization.	Lt Duty=A Federal Hvy Duty=C
VCM Memory Error - Type 1 (Volatile RAM)	P0604	This diagnostic checks that data stored to the Volatile section of memory is stored correctly.	The data read from the memory location does not match the data that was just stored to that location.	-----	Once per trip at controller initialization.	Lt Duty=A Federal Hvy Duty=C
VCM Memory Error - Type 3 (Boot Flash)	P0605	This diagnostic checks that the checksum of the Boot Flash section of memory matches a predetermined value.	The checksum of the data does not match the expected checksum.	-----	Once per trip at controller initialization.	Lt Duty=A Federal Hvy Duty=C
Transmission Clutch Switch Input Malfunction (Manual Trans. Only)	P0704	This DTC monitors the Transmission Clutch Switch for a transition during accelerations to the calibrated speed and back to 0 MPH.	No clutch switch circuit transitions detected	VS sensor DTC's not active Vehicle Speed is now = 0 mph and Vehicle Speed has been > 40 mph The brake switch is not currently pressed. (The clutch switch is wired in series with the brake switch)	2 consecutive test failures Continuous. 100 mS	Lt Duty=B Federal Hvy Duty=C Manual Only
O2 Sys. Fault - Too Few O2S R/L or L/R Switches, Insufficient Activity (Bank 1, Sensor 1)	P1133	This DTC determines if the O2 sensor functioning properly by monitoring the number of L/R and R/L switches.	Number of switches in 100 seconds: L/R switches < 20 R/L switches < 20 - For 4.3L G LEV LR < 35 For 5.7 LD C/K LEV&TIER LR < 35 For 4.3L G LEV RL < 60 For 4.3 C/K LEV RL < 35 For 5.7 LD C/K LEV RL <60	O2 Diagnostic Enable: (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7 - Volts Response Test Enable: Closed loop low MAP not active DTC's P0131, P0132, P0134 and P0135 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 15 g/s but ≤ 55 g/s Engine speed ≥ 1100 rpm but ≤ 3000 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds	100 seconds after closed loop enable Once per key cycle	Lt Duty=B Federal Hvy Duty=C

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit - Transition Time Ratio Malfunction (Bank 1, Sensor 1)	P1134	This DTC determines if the O2 sensor functioning properly by checking the ratio of average response time.	Ratio of average response times: Ratio > 5.0 or < 0.375 *O2 voltage < 300 mV = lean *O2 voltage > 600 mV = rich	<i>O2 Diagnostic Enable:</i> (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7 - Volts <i>Response Test Enable:</i> Closed loop low MAP not active DTC's P0131, P0132, P0134 and P0135 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 15 g/s but ≤ 55 g/s Engine speed ≥ 1100 rpm but ≤ 3000 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds	100 seconds after closed loop enable Once per ignition cycle	Lt Duty=B Federal Hvy Duty=C
O2 Sys. Fault - Too Few O2S R/L or L/R Switches, Insufficient Activity (Bank 2, Sensor 1)	P1153	This DTC determines if the O2 sensor functioning properly by monitoring the number of L/R and R/L switches.	Number of switches in 100 seconds: L/R switches < 20 R/L switches < 20 - For 4.3L G LEV LR < 35 For 5.7 LD C/K LEV&TIER LR < 35 For 4.3L G LEV RL < 60 For 4.3 C/K LEV RL < 35 For 5.7 LD C/K LEV RL <60	<i>O2 Diagnostic Enable:</i> (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7- Volts <i>Response Test Enable:</i> Closed loop low MAP not active DTC's P0151, P0152, P0154 and P0155 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 15 g/s but ≤ 55 g/s Engine speed ≥ 1100 rpm but ≤ 3000 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds	100 seconds after closed loop enable Once per key cycle	Lt Duty=B Federal Hvy Duty=C

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit - Transition Time Ratio Malfunction (Bank 2, Sensor 1)	P1154	This DTC determines if the O2 sensor functioning properly by checking the ratio of the average response time.	Ratio of average response times: Ratio > 5.0 or < .375 *O2 voltage < 300 mV = lean *O2 voltage > 600 mV = rich	O2 Diagnostic Enable: (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 11.7 - Volts Response Test Enable: Closed loop low MAP not active DTC's P0151, P0152, P0154 and P0155 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 15 g/s but ≤ 55 g/s Engine speed ≥ 1100 rpm but ≤ 3000 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds	100 seconds after closed loop enable Once per ignition cycle	Lt Duty=B Federal Hvy Duty=C
Crankshaft Position System Variation Not Learned (CASE)	P1336	This diagnostic will determine if the Crankshaft Position System Variation has been learned	Engine running	Manufactures Enable counter must be zero ECT > 65.25 C	Continuous	DTC Type A
Camshaft Sensor Misinstalled	P1345	1X Signal This diagnostic will determine if the Cam sensor and high voltage switch have been installed correctly.	Cam signal falling edge out of phase ±26 degrees from crank falling edge.	-----	30 test failures within a 50 test sample size. Time necessary to complete sample: Varies with engine speed Every crank fall	DTC Type A
EST Output High	P1351	This diagnostic will determine if a failure has occurred due to an open circuit.	EST voltage >4.9 V	EST Enabled Engine speed < 250 RPM	20 test failures Time necessary to complete sample: Executed during crank, approximately 3 seconds. Once per ignition cycle	DTC Type A
EST Not Toggling After Enable	P1361	This diagnostic will determine if a failure has occurred due to a grounded circuit.	EST voltage <.04V	EST Enabled Engine speed < 250 RPM	20 test failures Time necessary to complete sample: Executed during crank, approximately 3 seconds. Once per ignition cycle	DTC Type A

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
EGR Valve Circuit Performance - actual position greater than commanded	P1404	Detects a valve that is stuck open when commanded closed.	Pintle position > 10 A/D counts from learned closed position for 10 seconds for 3 subroutines	EGR valve strokes to 100% duty cycle between subroutines. Enable parameters for stroke: 80°C < ECT < 120°C IAT < 100°C Desired EGR > 15%	Continuous	DTC Type A
Secondary Air Injection System Malfunction (Bank 1) -	P1415	Detects left bank AIR malfunction	Determines if left bank AIR diagnostic failed	Same as P0410. See P0410	See P0410 diagnostic description.	DTC Type B
Secondary Air Injection System Malfunction (Bank 2) -	P1416	Detects right bank AIR malfunction	Determines if right bank AIR diagnostic failed.	Same as P0410. See P0410	See P0410 diagnostic description	DTC Type B

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Evap. Emission Control System - Continuous Open Purge Flow	P1441	This DTC will determine if the purge solenoid is leaking.	<p><u>PURGE VALVE LEAK TEST:</u> Purge Valve closed TP > 0% but < 99.6% Vacuum ≥ 10 KPa Tank Vacuum ≥ 12 in. H₂O for 2 sec within ≤ 37.5 seconds after 30 second delay.</p>	<p><u>TEST ENABLE:</u> MAP DTC's not active TP Sensor DTC's not active VS Sensor DTC's not active O2 Sensor DTC's not active ECT Sensor DTC's not active DTC P0125 not active IAT Sensor DTC's not active Fuel Level >12.5% but < 87.5% System Voltage > 10V but < 18V Purge Closed Loop Multiplier ≥ 0.6 for a time ≤ a table value based on coolant temperature. If HC vapor is not present.</p> <p><u>COLD START TEST:</u> ECT > 3.75°C but < 30° C IAT > 3.75°C but < 30° C Cold Temperature Δ (ECT - IAT): ° < 8.25 °C if ECT > IAT Baro >72.5 kPa</p> <p><u>FUEL SLOSH TEST:</u> Tank Vacuum Δ ≤ value and Fuel Level Δ ≤ value based on fuel level.</p> <p><u>EXCESS VACUUM TEST -STAGE I:</u> Vent solenoid commanded OPEN Fuel Tank Vacuum < 7 in. H₂O</p> <p><u>WEAK VACUUM TEST -Stage I:</u> Throttle position < 75% Vehicle speed < 65 mph Tank Vacuum ≥ 9, 11 or 13 in. H₂O within 30 ,50 or 80seconds.</p>	<p><u>PURGE VALVE LEAK TEST:</u> 180seconds Max. Once per cold start</p>	DTC Type B

2000 Truck V8 group 1 5.0L (L30), 5.7L (L31), 5.7L (L31-HD)

2000file15_8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Idle Air Control - Low	P1508	This DTC will determine if a low idle is the result of an engine mechanical problem. A low idle is defined as 75 RPM below the desired idle.	Air flow $\Delta > 3$ g/s	<p><u>Test Enable: (non - intrusive)</u> TP sensor DTC's not active VS sensor DTC's not active ECT DTC's not active MAP DTC's not active ECT > 50°C System Voltage > 10V but < 16 V IAT > -25°C Engine run time > 30 seconds Baro > 70 kPa TP < 1% VS < 2 MPH Above met for a time > 3 seconds to enable diagnostic. If non-intrusive test fails, intrusive test is run.</p> <p><u>Run Test: (intrusive)</u> Air Flow > 17.5 g/sec but < 50 g/sec VS > 25 MPH but < 85 MPH TP $\Delta < 1\%$ Engine Speed $\Delta < 50$ RPM IAC motor commanded 10 %/ 100 msec.</p>	10 seconds Continuous after enable	DTC Type B
Idle Air Control - High	P1509	This DTC will determine if a high idle is the result of an engine mechanical problem. A high idle is defined as 100 RPM above the desired idle.	Air flow $\Delta > 3$ g/s	<p><u>Test Enable: (non - intrusive)</u> TP sensor DTC's not active VS sensor DTC's not active ECT DTC's not active MAP DTC's not active ECT > 50°C System Voltage > 10V but < 16 V IAT > -25°C Engine run time > 30 seconds Baro > 70 kPa TP < 1% VS < 2 MPH Above met for a time > 3 seconds to enable diagnostic. If non-intrusive test fails, intrusive test is run.</p> <p><u>Run Test: (intrusive)</u> Air Flow > 17.5 g/sec but < 50 g/sec VS > 25 MPH but < 85 MPH TP $\Delta < 1\%$ Engine Speed $\Delta < 50$ RPM IAC motor commanded 10 %/ 100 msec.</p>	10 seconds Continuous after enable	DTC Type B
Fuel Level No Change, Stuck in Range	P0461	This DTC will detect a fuel sender stuck in range	Delta Fuel level A/D counts change less than 10 counts over a accumulated 200 miles	runs continuously		C No Light
Fuel Level Stuck Low	P0462	This DTC will detect a fuel sender stuck out of range low	Fuel level A/D counts less than 20 A/D counts for 25 seconds	runs continuously		C No Light

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Fuel Level Stuck High	P0463	This DTC will detect a fuel sender stuck out of range high	Fuel level A/D counts more than 150 A/D counts for 25 seconds	runs continuously		C No Light