

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Mass Air Flow Sensor Circuit - Range/ Rationality	P0101	Under conditions when the two should match, the Mass Air Flow reading should match calculated Mass Air Flow (based on speed density). If delta Mass Air Flow is too large, a faulty Mass Air Flow condition exists, such as a "skewed" sensor.	MAF $\Delta \geq$ a table value determined by the difference between the MAF sensor reading and the speed density calculation.	Engine Running TP sensor DTC's not active. MAP sensor DTC's not active. Evap. DTC's not active EGR DTC P0401 not active MAF sensor high / low DTC's not active. System voltage > 10V but < 17V Canister Purge DC \leq 99.6% TPS $\Delta \leq$ 3.9% EGR DC \leq 89.8% EGR Pintle Position \leq 89.8% Engine vacuum \leq 65 kPa Throttle Position \leq 50% The above must be present for a period of time greater than 2 seconds.	50 test failures within a 100 test sample. Time necessary to complete sample: 10 sec The Mass Air Flow reading and Mass Air Flow calculation are performed during the same cylinder event every 100 ms.	DTC Type Calif - B Fed - C
Mass Air Flow Sensor Circuit - Low Input	P0102	This DTC will determine if the MAF frequency is too low.	<u>Powerup Test:</u> MAF \leq 60 Hz <u>LOW FREQUENCY TEST:</u> MAF \leq 300 Hz	<u>Powerup Test:</u> Engine "OFF" Ignition "ON" for 2 seconds <u>LOW FREQUENCY TEST:</u> Engine Speed \geq 300 RPM Engine Run Time \geq 2.0 seconds System Voltage \geq 10V Throttle Position < 50% The above must be present for a period of time greater than 2 seconds.	<u>Powerup Test:</u> 20 failures within a 25 test sample. Time necessary to complete sample: 250 ms Test is run every 12.5 ms until "Engine Run" flag is seen. <u>LOW FREQUENCY TEST:</u> 40 test failures within a 100 test sample. Time necessary to complete sample: 10 sec Test is run at every reading of the Mass Air Flow sensor frequency.	DTC Type Calif - B Fed - B

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Mass Air Flow Sensor Circuit - High Input	P0103	This DTC will determine if the MAF frequency is too high.	Powerup Test: MAF \geq 11000 Hz HIGH FREQUENCY TEST: MAF \geq 10400 Hz	Powerup Test: Engine "OFF" Ignition "ON" for 2 seconds HIGH FREQUENCY TEST: Engine Speed \geq 300 RPM Engine Run Time \geq 2.0 seconds System Voltage \geq 10V Throttle Position $<$ 50% The above must be present for a period of time greater than 2 seconds.	Powerup Test: 20 failures within a 25 test sample. Time necessary to complete sample: 250 ms Test is run every 12.5 ms until "Engine Run" flag is seen. HIGH FREQUENCY TEST: 40 test failures within a 100 test sample. Time necessary to complete sample: 10 sec Test is run at every reading of the Mass Air Flow sensor frequency.	DTC Type Calif - B Fed - B
MAP Sensor Circuit - Low Input	P0107	This DTC detects a continuous short to low or open in either the signal circuit or the MAP sensor.	Raw MAP $<$ 0.05V (3 counts)	TP sensor DTC's not active Engine Running Throttle Position \geq 0% when Engine speed is \leq 800 RPM or Throttle Position is \geq 12.5% when Engine speed is $>$ 800 RPM	40 test failures within a 100 test sample. Time necessary to complete sample is based on engine speed. At 1600 RPM, the time would be 938 ms Continuous	DTC Type Calif - B Fed - B
MAP Sensor Circuit - High Input	P0108	This DTC detects an open sensor ground or continuous short to high in either the signal circuit or the MAP sensor.	Raw MAP $>$ 4.34V (222 counts)	Cold Start Run Time - Table value in seconds based on Powerup Coolant Temperature. Run Test TP sensor DTC's not active Throttle Position \leq 0.4% when Engine speed is \leq 1200 RPM or Throttle Position is \leq 19.9% when Engine speed is $>$ 1200 RPM	40 test failures within a 100 test sample. Time necessary to complete sample is based on engine speed. At 1600 RPM, the time would be 938 ms Continuous	DTC Type Calif - B Fed - B
Intake Air Temp. Sensor Circuit -Low Input	P0112	The DTC detects a continuous short to ground in the IAT signal circuit or the IAT sensor	Low Resistance pull-up Raw IAT $<$ 0.82V High Resistance pull-up Raw IAT $<$ 0.08V	VS sensor DTC's not active Vehicle speed \geq 2 mph Engine run time $>$ 100 seconds	40 test failures within a 100 test sample Time necessary to complete sample: 12.5 sec Continuous	DTC Type Calif - B Fed - B

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Intake Air Temp. Sensor Circuit - High Input	P0113	The DTC detects a continuous open or short to high in the IAT signal circuit or the IAT sensor	Low Resistance pull-up Raw IAT > 5.0V High Resistance pull-up Raw IAT > 4.9V	ECT sensor DTC's not active VS sensor DTC's not active MAF sensor DTC's not active Vehicle speed < 2 mph Mass Air flow < 250 g /s Coolant Temperature > 84.7°C Engine run time > 100 seconds	40 test failures within a 100 test sample Time necessary to complete sample: 12.5 sec Continuous	DTC Type Calif - B Fed - B
Engine Coolant Temp. Sensor Circuit-Low Input	P0117	The DTC detects a continuous short to ground in the ECT signal circuit or the ECT sensor	Low Resistance pull-up Raw ECT < 0.78V High Resistance pull-up Raw ECT < 0.08V	Engine run time > 5 seconds	40 test failures within a 100 test sample Time necessary to complete sample: 50 sec Continuous	DTC Type Calif - B Fed - B
Engine Coolant Temp. Sensor Circuit-High Input	P0118	The DTC detects a continuous short to high or open in the ECT signal circuit or the ECT sensor	Low Resistance pull-up Raw ECT > 5.0V High Resistance pull-up Raw ECT > 4.9V	Engine run time > 5 seconds	40 test failures within a 100 test sample Time necessary to complete sample: 50 sec Continuous	DTC Type Calif - B Fed - B
Throttle Position Sensor Circuit Range/Rationality	P0121	The DTC detects a "skewed" or stuck TP sensor	Stuck high test: The last throttle position value is > predicted throttle position based on engine RPM. Stuck low test: The last throttle position value is < predicted throttle position based on engine RPM.	Test Enable: No MAP DTC's active Engine running BARO not defaulted TP Δ < 2.0% Stuck high test: MAP < 50 kPa Stuck low test: Stuck high test has passed MAP > 60 kPa IAC > 10 counts IAC < 340 counts	Stuck high test: 50 test failures within a 100 test sample Stuck low test: 50 test failures within a 100 test sample Time necessary to complete each sample: 50 sec Continuous	DTC Type Calif - B Fed - C
Throttle Position Sensor Circuit-Low Input	P0122	This DTC detects a continuous short to low or open in either the signal circuit or the TP sensor.	TP sensor signal voltage < 0.15V (8 counts)	Engine running	40 consecutive test failures within a 100 test sample Time necessary to complete sample: 1 sec Continuous	DTC Type Calif - B Fed - B

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Throttle Position Sensor Circuit-High Input	P0123	This DTC detects a continuous short to high in either the signal circuit or the TP sensor.	TP sensor signal voltage > 4.9V (249 counts)	Engine running	40 consecutive test failures within a 100 test sample Time necessary to complete sample: 1 sec Continuous	DTC Type Calif - B Fed - B
Min. Cool. Temp. to Allow CL Op. Not Achieved Without Excess. Time	P0125	The DTC detects if a stabilized minimum closed-loop is reached and maintained after engine start-up.	Minimum stabilized ECT < 45°C after 300 seconds. Minimum stabilized ECT < 45°C after 240 seconds.	<u>Diagnostic Enable</u> Engine running IAT > -7°C ECT > -7°C Start-up ECT ≤ 40°C <u>Closed Loop Test:</u> For a vehicle saturated between -7°C (20°F) and 10°C (50°F) Accumulated air flow since start > 8730 grams Accumulated Idle time < 225 seconds For a vehicle saturated at 10°C (50°F) Accumulated air flow since start > 5000 grams Accumulated Idle time < 180 seconds	10 consecutive test failures Continuous	DTC Type Calif - B Fed - X
O2S Circuit-Low Voltage (Bank 1, Sensor 1)	P0131	This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady state throttle and during power enrichment (PE).	<u>Lean test:</u> O2 sensor voltage < 86 mV or <u>PE Lean Test:</u> O2 sensor voltage < 598 mV	<u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 lean tests) TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V <u>Test Enable (Lean test):</u> Closed loop low MAP not active Closed loop Air/Fuel ratio ≥ 14.6 but ≤ 14.8 Throttle position > 5.0% but < 95% Above met for 5 seconds <u>Test Enable (PE Lean test):</u> Closed loop Power Enrichment mode active High speed fuel cutoff not active Time elapsed since test enable ≥ 10 sec.	<u>Lean Test:</u> 400 test failures in a 500 test sample Time necessary to complete sample: 50 sec Continuous or <u>PE Lean Test:</u> 100 test failures in a 200 test sample. Time necessary to complete sample: 20 sec	DTC Type Calif - B Fed - B

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-High Voltage (Bank 1, Sensor 1)	P0132	This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and Decel fuel cutoff (DFCO)	<p>Rich Test: O2 sensor voltage > 950 mV</p> <p>or</p> <p>DFCO Rich Test: O2 sensor voltage > 468 mV</p>	<p>O2 Diagnostic Enable: (the following criteria must be met to enable the O2 rich tests) TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V Test Enable (Rich Test): Closed loop Air/Fuel ratio ≥ 14.6 but ≤ 14.8 Throttle position > 0% but < 50% Above met for 5 seconds Test Enable (DFCO Rich Test): Decel Fuel Cutoff mode active Closed loop Time elapsed since test enable ≥ 10 sec.</p>	<p>Rich Test: 400 test failures in a 500 test sample</p> <p>Time necessary to complete sample: 50 sec</p> <p>Continuous</p> <p>or</p> <p>DFCO Rich Test: 100 test failures in a 200 test sample</p> <p>Time necessary to complete sample: 20 sec</p>	DTC Type Calif - B Fed - B
O2S Circuit-Slow Response (Bank 1, Sensor 1)	P0133	This DTC determines if the O2 sensor functioning properly by checking its response time.	<p>O2 sensor average transition time: L/R > 125 msec. R/L > 125 msec. *O2 voltage < 300 mV = lean *O2 voltage > 600 mV = rich</p>	<p>O2 Diagnostic Enable: (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V Response Test Enable: Closed loop low MAP not active DTC's P0131, P0132, P0134 and P0135 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 22.5 g/s but ≤ 55 g/s Engine speed ≥ 1200 rpm but ≤ 2200 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds</p>	<p>100 seconds after closed loop enable</p> <p>Once per ignition cycle</p>	DTC Type Calif - B Fed - C

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit- No Activity Detected (Bank 1, Sensor 1)	P0134	This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 350 mV but < 550 mV	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 open test)</p> TP sensor DTC's not active Evap. DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V Engine Run Time ≥ 120 seconds <p><u>O2 Sensor Temperature Test:</u> Engine Running Not in DFEO ECT ≥ 60°C Air Flow ≥ 10 g/s <p><u>O2 Sensor Open Test Enable:</u> O2 Sensor Temperature Test = True DTC P0135 not active</p> </p>	400 test failures with in a 500 test sample Time necessary to complete sample: 50 sec Continuous	DTC Type Calif - B Fed - B
O2S Heater Circuit Malfunction (Bank 1, Sensor 1)	P0135	This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	The elapsed time to obtain ±0.150V from the mean O2 bias voltage. *Time based on table: Time Vs Average Air Flow	System Voltage > 9V but < 17V (NOTE: If voltage remains outside this window for 4 consecutive seconds, the test is void for this cold start.) Air Flow < 45 g/sec Engine run time > 2 seconds ECT < 40°C IAT < 40°C Δ ECT-IAT ≤ 8°C	From cold start to a maximum time of 105 seconds. *Time determined by table.	DTC Type Calif - B Fed - C

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-Low Voltage (Bank 1, Sensor 2)	P0137	This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady state throttle and during power enrichment (PE).	<p>Lean test: O2 sensor voltage < 17 mV</p> <p>or</p> <p>PE Lean Test: O2 sensor voltage < 399 mV</p>	<p>O2 Diagnostic Enable: (the following criteria must be met to enable the O2 lean tests) TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V Test Enable (Lean test): Closed loop low MAP not active Closed loop Air/Fuel ratio ≥ 14.6 but ≤ 14.8 Throttle position > 5.0% but < 95% Above met for 5 seconds Test Enable (PE Lean test): Closed loop Power Enrichment mode active High speed fuel cutoff not active Time elapsed since test enable ≥ 15 sec.</p>	<p>Lean Test: 800 test failures in a 1000 test sample</p> <p>Time necessary to complete sample: 100 sec</p> <p>Continuous</p> <p>or</p> <p>PE Lean Test: 100 test failures in a 200 test sample.</p> <p>Time necessary to complete sample: 20 sec</p>	DTC Type Calif - B Fed - X
O2S Circuit-High Voltage (Bank 1, Sensor 2)	P0138	This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and Decel fuel cutoff (DFCO)	<p>Rich Test: O2 sensor voltage > 976 mV</p> <p>or</p> <p>DFCO Rich Test: O2 sensor voltage > 468 mV</p>	<p>O2 Diagnostic Enable: (the following criteria must be met to enable the O2 rich tests) TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V Test Enable (Rich Test): Closed loop Air/Fuel ratio ≥ 14.6 but ≤ 14.8 Throttle position > 0% but < 50% Above met for 5 seconds Test Enable (DFCO Rich Test): Decel Fuel Cutoff mode active Closed loop Time elapsed since test enable ≥ 15 sec.</p>	<p>Rich Test: 800 test failures in a 1000 test sample</p> <p>Time necessary to complete sample: 100 sec</p> <p>Continuous</p> <p>or</p> <p>DFCO Rich Test: 100 test failures in a 200 test sample</p> <p>Time necessary to complete sample: 20 sec</p>	DTC Type Calif - B Fed - X

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit- No Activity Detected (Bank 1, Sensor 2)	P0140	This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 399 mV but < 468 mV	<p><i>O2 Diagnostic Enable:</i> (the following criteria must be met to enable the O2 open test)</p> <p>TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V Engine Run Time ≥ 120 seconds</p> <p><i>O2 Sensor Temperature Test:</i> Engine Running Not in DFCO ECT ≥ 60°C Air Flow ≥ 15 g/s</p> <p><i>O2 Sensor Open Test Enable:</i> O2 Sensor Temperature Test = True DTC P0141 not active Closed Loop</p>	<p>800 test failures with in a 1000 test sample</p> <p>Time necessary to complete sample: 100 sec</p> <p>Continuous</p>	DTC Type Calif - B Fed - X
O2S Heater Circuit Malfunction (Bank 1, Sensor 2)	P0141	This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	<p>The elapsed time to obtain ±0.150V from the mean O2 bias voltage.</p> <p>*Time based on table: Time Vs Average Air Flow</p>	<p>System Voltage > 9V but < 17V (NOTE: If voltage remains outside this window for 4 consecutive seconds, the test is void for this cold start.) Air Flow < 45 g/sec Engine run time > 2 seconds ECT < 40°C IAT < 40°C Δ ECT-IAT ≤ 8°C</p>	<p>From cold start to a maximum time of 150 seconds.</p> <p>*Time determined by table.</p>	DTC Type Calif - B Fed - X

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-Low Voltage (Bank 2, Sensor 1)	P0151	This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady state throttle and during power enrichment (PE).	<p><u>Lean test:</u> O2 sensor voltage < 86 mV</p> <p>or</p> <p><u>PE Lean Test:</u> O2 sensor voltage < 598 mV</p>	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 lean tests) TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V <u>Test Enable (Lean test):</u> Closed loop low MAP not active Closed loop Air/Fuel ratio ≥ 14.6 but ≤ 14.8 Throttle position > 5.0% but < 95% Above met for 5 seconds <u>Test Enable (PE Lean test):</u> Closed loop Power Enrichment mode active High speed fuel cutoff not active Time elapsed since test enable ≥ 10 sec.</p>	<p><u>Lean Test:</u> 400 test failures in a 500 test sample</p> <p>Time necessary to complete sample: 50 sec</p> <p>Continuous</p> <p>or</p> <p><u>PE Lean Test:</u> 100 test failures in a 200 test sample.</p> <p>Time necessary to complete sample: 20 sec</p>	DTC Type Calif - B Fed - B
O2S Circuit-High Voltage (Bank 2, Sensor 1)	P0152	This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and Decel fuel cutoff (DFCO)	<p><u>Rich Test:</u> O2 sensor voltage > 950 mV</p> <p>or</p> <p><u>DFCO Rich Test:</u> O2 sensor voltage > 468 mV</p>	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 rich tests) TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V <u>Test Enable (Rich Test):</u> Closed loop Air/Fuel ratio ≥ 14.6 but ≤ 14.8 Throttle position > 0% but < 50% Above met for 5 seconds <u>Test Enable (DFCO Rich Test):</u> Decel Fuel Cutoff mode active Closed loop Time elapsed since test enable ≥ 10 sec.</p>	<p><u>Rich Test:</u> 400 test failures in a 500 test sample</p> <p>Time necessary to complete sample: 50 sec</p> <p>Continuous</p> <p>or</p> <p><u>DFCO Rich Test:</u> 100 test failures in a 200 test sample</p> <p>Time necessary to complete sample: 20 sec</p>	DTC Type Calif - B Fed - B

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit- Slow Response (Bank 2, Sensor 1)	P0153	This DTC determines if the O2 sensor functioning properly by checking its response time.	O2 sensor average transition time: L/R > 125 msec. R/L > 125 msec. *O2 voltage < 300 mV = lean *O2 voltage > 600 mV = rich	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 Response tests)</p> TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V <u>Response Test Enable:</u> Closed loop low MAP not active DTC's P0131, P0132, P0134 and P0135 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 22.5 g/s but ≤ 55 g/s Engine speed ≥ 1200 rpm but ≤ 2200 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds	100 seconds after closed loop enable Once per ignition cycle	DTC Type Calif - B Fed - C
O2S Circuit- No Activity Detected (Bank 2, Sensor 1)	P0154	This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 350 mV but < 550 mV	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 open test)</p> TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V Engine Run Time ≥ 120 seconds <u>O2 Sensor Temperature Test:</u> Engine Running Not in DFEO ECT ≥ 60°C Air Flow ≥ 10 g/s <u>O2 Sensor Open Test Enable:</u> O2 Sensor Temperature Test = True DTC P0147 not active	400 test failures with in a 500 test sample Time necessary to complete sample: 50 sec Continuous	DTC Type Calif - B Fed - B

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Heater Circuit Malfunction (Bank 2, Sensor 1)	P0155	This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	The elapsed time to obtain $\pm 0.150V$ from the mean O2 bias voltage. *Time based on table: Time Vs Average Air Flow	System Voltage > 9V but < 17V <i>NOTE: If voltage remains outside this window for 4 consecutive seconds, the test is void for this cold start.</i> Air Flow < 45 g/sec Engine run time > 2 seconds ECT < 40°C IAT < 40°C Δ ECT-IAT $\leq 8^\circ C$	From cold start to a maximum time of 105 seconds. *Time determined by table.	DTC Type Calif - B Fed - C
O2S Circuit-Low Voltage (Bank 2, Sensor 2)	P0157	This DTC determines if the O2 sensor or circuit is shorted to low by checking for a lean condition during steady state throttle and during power enrichment (PE).	<u>Lean test:</u> O2 sensor voltage < 17 mV or <u>PE Lean Test:</u> O2 sensor voltage < 399 mV	<u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 lean tests) TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage $\geq 9V$ <u>Test Enable (Lean test):</u> Closed loop low MAP not active Closed loop Air/Fuel ratio ≥ 14.6 but ≤ 14.8 Throttle position > 5% but < 95% Above met for 5 seconds <u>Test Enable (PE Lean test):</u> Closed loop Power Enrichment mode active High speed fuel cutoff not active Time elapsed since test enable ≥ 15 sec.	<u>Lean Test:</u> 800 test failures in a 1000 test sample Time necessary to complete sample: 100 sec Continuous or <u>PE Lean Test:</u> 100 test failures in a 200 test sample. Time necessary to complete sample: 20 sec	DTC Type Calif - B Fed - X

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit-High Voltage (Bank 2, Sensor 2)	P0158	This DTC determines if the O2 sensor or circuit is shorted to high by checking for a rich condition during steady throttle and Decel fuel cutoff (DFCO)	<p><u>Rich Test:</u> O2 sensor voltage > 976 mV</p> <p>or</p> <p><u>DFCO Rich Test:</u> O2 sensor voltage > 468 mV</p>	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 rich tests) TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V <u>Test Enable (Rich Test):</u> Closed loop Air/Fuel ratio ≥ 14.6 but ≤ 14.8 Throttle position > 5% but < 95% Above met for 5 seconds <u>Test Enable (DFCO Rich Test):</u> Decel Fuel Cutoff mode active Closed loop Time elapsed since test enable ≥ 15 sec.</p>	<p><u>Rich Test:</u> 800 test failures in a 1000 test sample</p> <p>Time necessary to complete sample: 100 sec</p> <p>Continuous</p> <p>or</p> <p><u>DFCO Rich Test:</u> 100 test failures in a 200 test sample</p> <p>Time necessary to complete sample: 20 sec</p>	DTC Type Calif - B Fed - X
O2S Circuit- No Activity Detected (Bank 2, Sensor 2)	P0160	This DTC determines if the O2 sensor or the O2 sensor circuit has developed an open.	O2 sensor > 399 mV but < 468 mV	<p><u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 open test) TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V Engine Run Time ≥ 120 seconds <u>O2 Sensor Temperature Test:</u> Engine Running Not in DFCO ECT ≥ 60°C Air Flow ≥ 15 g/s <u>O2 Sensor Open Test Enable:</u> O2 Sensor Temperature Test = True DTC P0155 not active Closed Loop</p>	<p>800 test failures with in a 1000 test sample</p> <p>Time necessary to complete sample: 100 sec</p> <p>Continuous</p>	DTC Type Calif - B Fed - X

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Heater Circuit Malfunction (Bank 2, Sensor 2)	P0161	This DTC determines if the O2 sensor heater is functioning properly by monitoring the amount of time necessary for the O2 sensor to become active after start - up.	The elapsed time to obtain $\pm 0.150V$ from the mean O2 bias voltage. *Time based on table: Time Vs Average Air Flow	System Voltage > 9V but < 17V <i>(NOTE: If voltage remains outside this window for 4 consecutive seconds, the test is void for this cold start.)</i> Air Flow < 45 g/sec Engine run time > 2 seconds ECT < 40°C IAT < 40°C Δ ECT-IAT $\leq 8^\circ C$	From cold start to a maximum time of 150 seconds. *Time determined by table.	DTC Type Calif - B Fed - X
System Too Lean (Bank 1)	P0171	Determines if the system is in a lean condition.	The average of short term fuel trim samples ≥ 1.0 and The average of adaptive index multiplier samples ≥ 1.23	Test Enable: AIR DTC's not active CAM DTC's not active O2 sensor DTC's not active MAP DTC's not active Purge DTC's not active ECT DTC's not active MAF DTC's not active IAT DTC's not active Misfire DTC's not active Throttle position < 95% Engine speed > 525 rpm but < 4500 rpm Baro > 75 kPa ECT > 0°C but < 115°C MAP > 20 kPa but < 98.9 kPa IAT > -20 °C but < 80°C Air flow > 3 g/s < 200 g/s Vehicle speed < 85 mph	If lean counter is ≥ 6 counts 1 count \cong 200 ms Continuous	DTC Type Calif - B Fed - B
System Too Rich (Bank 1)	P0172	Determines if the system is in a rich condition.	The average of short term fuel trim samples ≤ 1.0 and If adaptive lag factor < 0.84, then purge valve is commanded closed. If the integrator exceeds 1.0 within 5 seconds, the diagnostic is turned OFF for 300 seconds to enable the Evap. canister to purge. If the integrator does not exceed 1.0 within 10 seconds, a fault is present.	Test Enable: AIR DTC's not active CAM DTC's not active O2 sensor DTC's not active MAP DTC's not active Purge DTC's not active ECT DTC's not active MAF DTC's not active IAT DTC's not active Misfire DTC's not active Throttle position < 95% Engine speed > 525 rpm but < 4500 rpm Baro > 75 kPa ECT > 0°C but < 115°C MAP > 20 kPa but < 98.9 kPa IAT > -20 °C but < 80°C Air flow > 3 g/s < 200 g/s Vehicle speed < 85 mph	If rich counter is ≥ 6 counts 1 count \cong 200 ms Continuous	DTC Type Calif - B Fed - B

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
System Too Lean (Bank 2)	P0174	Determines if the system is in a lean condition.	The average of short term fuel trim samples ≥ 1.0 and The average of adaptive index multiplier samples ≥ 1.23	Test Enable: AIR DTC's not active CAM DTC's not active O2 sensor DTC's not active MAP DTC's not active Purge DTC's not active ECT DTC's not active MAF DTC's not active IAT DTC's not active Misfire DTC's not active Throttle position < 95% Engine speed > 525 rpm but < 4500 rpm Baro > 75 kPa ECT > 60°C but < 115°C MAP > 20 kPa but < 98.9 kPa IAT > -20 °C but < 80°C Air flow > 3 g/s < 200 g/s Vehicle speed < 85 mph	If lean counter is ≥ 6 counts 1 count \cong 200 ms Continuous	DTC Type Calif - B Fed - B
System Too Rich (Bank 2)	P0175	Determines if the system is in a rich condition.	The average of short term fuel trim samples ≤ 1.0 and If adaptive lag factor < 0.84, then purge valve is commanded closed. If the integrator exceeds 1.0 within 5 seconds, the diagnostic is turned OFF for 300 seconds to enable the Evap. canister to purge. If the integrator does not exceed 1.0 within 10 seconds, a fault is present	Test Enable: AIR DTC's not active CAM DTC's not active O2 sensor DTC's not active MAP DTC's not active Purge DTC's not active ECT DTC's not active MAF DTC's not active IAT DTC's not active Misfire DTC's not active Throttle position < 95% Engine speed > 525 rpm but < 4500 rpm Baro > 75 kPa ECT > 60°C but < 115°C MAP > 20 kPa but < 98.9 kPa IAT > -20 °C but < 80°C Air flow > 3 g/s < 200g/s Vehicle speed < 85 mph	If rich counter is ≥ 6 counts 1 count \cong 200 ms Continuous	DTC Type Calif - B Fed - B

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Random Misfire Detected	P0300	This DTC will determine if a multiple or cylinder specific misfire is occurring by monitoring crankshaft velocity. If a misfire is occurring on only one cylinder, then a single cylinder misfire is occurring and the corresponding cylinder specific DTC will be activated by the executive.	Deceleration index Vs Engine speed Vs Load with engine position FTP Threshold - 1.85% I/M Threshold - 1.85% Catalyst Damage - see speed/load chart	<u>TEST Enable:</u> If start up ECT < -7 C then MFD delayed until ECT is above 21 C. If start up ECT ≥ -7° C then MFT begins after 5 seconds ECT < 130 C Fuel Level > 10% System voltage ≥ 11V but ≤ 16V Engine speed ≥ 450 RPM but ≤ 4800 RPM Vehicle speed DTC not active TP sensor DTC's not active MAF sensor DTC's not active Camshaft position sensor DTC's not active Crank sensor DTC's not active ABS DTC's not active + Throttle position Δ < 1.9%/100 ms - Throttle position Δ < 1.9%/100 ms Abusive Engine Speed < 5500 RPM	Emission Level 10 failed 200 revolution blocks out of 16 Catalyst Damaging Level 4 failed 200 revolution blocks out of 16 Continuous	DTC Type Calif - B EMISSION Calif - A CATALYST DAMAGING Fed - X
Knock Sensor 1 Circuit Malfunction	P0325	This diagnostic will detect excessive noise on the knock sensor circuit.	<u>SNEF STUCK LOW TEST:</u> Knock is detected for excessive amount of time.	<u>SNEF STUCK LOW TEST:</u> DTC P0327 not active Engine Run Time ≥ 120 seconds System voltage > 10V but ≤ 17.1V	<u>SNEF STUCK LOW TEST:</u> 10 test failures within a 100 test sample. Time necessary to complete sample: 50 sec	DTC Type Calif - B Fed - C
Knock Sensor 1 Circuit - Low Input	P0327	This diagnostic will detect a lack of noise on the knock sensor circuit.	<u>KNOCK SENSOR UPDATE TEST</u> Learned Minimum noise Value updated with the filtered value every 50 msec. <u>ACTIVE NOISE CHANNEL TEST:</u> Knock sensor noise ≤ 25 A/D counts or > 255 A/D counts. (ESC noise - Minimum Noise Value)	<u>KNOCK SENSOR UPDATE TEST:</u> Timing retard ≤ 0° System voltage > 10V but ≤ 17.1V ECT ≥ 60° C Engine Run Time ≥ 120 seconds Engine speed > 525 RPM but ≤ 750 RPM <u>ACTIVE NOISE CHANNEL TEST:</u> ECT DTC's not active TP sensor DTC's not active Knock sensor update test complete ECT ≥ 60° C Engine speed > 2000 RPM but ≤ 10000 RPM Throttle position ≥ 5.8% Engine run time ≥ 120 seconds System voltage > 10V but ≤ 17.1V Timing retard ≤ 0°	<u>ACTIVE NOISE CHANNEL TEST:</u> Noise counter ≥ 100 counts. 1 count ≅ 100 ms	DTC Type Calif - B Fed - C
Crankshaft Position Sensor Circuit-Range	P0336	4X Signal This diagnostic will detect a loss of crank sensor signal or long time constant intermittent that would result in a "no start" condition.	Crank Position Sensor Signal missing for a time ≥ 0.5 seconds.	Engine Cranking 4 or more Cam Shaft Position Signals Present	≥ 3 seconds During engine crank.	DTC Type Calif - B Fed - B

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Crankshaft Position Sensor Circuit- Low Input	P0337	4X Signal This diagnostic will detect a low duty cycle from the crankshaft position sensor.	Crank sensor duty cycle < 50% (or the ratio High Ref/Low Ref < 0.1875)	Engine speed < 4000 RPM Air Flow ≥ 5 g/second	15 Ref pulse failures within a 20 sample limit. Time necessary to complete sample: Varies with engine speed Once every TDC	DTC Type Calif - B Fed - B
Crankshaft Position Sensor Circuit- Intermittent Input	P0339	4X Signal This diagnostic will detect an intermittent crankshaft position signal.	The calculated instantaneous engine speed $\Delta \geq 1000$ RPM or The calculated instantaneous engine speed = 0 RPM and 4 or more cam cycles have occurred for a period of 1 count (2 to 3 seconds)	Air Flow ≥ 5 g/second	10 test failures within a 500 sample limit. Time necessary to complete sample: 6.25 sec	DTC Type Calif - B Fed - C
Camshaft Position Sensor Circuit Malfunction	P0340	1X Signal This diagnostic will detect if the Cam Sensor signal is present.	Cam Sensor reference pulse is not seen once every 8 cylinders .	Engine Running	If Cam signal is not detected within 1.75 seconds, test has failed. Once every TDC	DTC Type Calif - B Fed - C
Camshaft Position Sensor Circuit Range/Rationality	P0341	1X Signal This diagnostic will determine if the Cam Sensor is synchronized correctly.	Cam Sensor reference pulse is not detected at the correct interval every 8 cylinders.	Engine Running	40 failed tests within a 100 test sample. Time necessary to complete sample: Varies with engine speed Once every TDC	DTC Type Calif - B Fed - C

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Exhaust Gas Recirculation - Insufficient Flow Detected	P0401	This diagnostic will determine if there is a reduction in EGR flow.	With EGR valve open, the peak + MAP Δ is monitored over a time of 2.6 seconds. This value is compared with a threshold from Engine Speed Vs Baro table and the difference computed. The result is statistically filtered (EWMA) and compared to a decision limit. DTC is set when the filtered result exceeds the decision limit.	<p>Test Enable TP sensor DTC's not active MAP DTC's not active VS sensor DTC's not active IAT sensor DTC's not active ECT sensor DTC's not active IAC DTC's not active Linear EGR Pintle Position DTC not active Misfire DTC's not active Transmission DTC's not active System Voltage DTC's not active Purge Control DTC's not active Engine Speed > 950 RPM MAT < 69.75 C ECT > 50.2° C Baro > 75 kPa (10,300 ft) Vehicle Speed > 15 mph IAC Δ < 5 counts AC clutch status is unchanged Transmission status is unchanged Engine run time > 120 seconds</p> <p>Start Test Throttle Position > 4% but < 30% Throttle Position Δ < 2% EGR Position > 15% but < 75% Engine Speed > 1200 rpm but < 2200 rpm MAP Δ < 1.5 kPa Vehicle Speed Δ < 3 mph Compensated MAP > 40 kPa but < 60 kPa No change in DFCO state</p> <p>Run Test Stabilized MAP (valve closed) recorded and EGR valve "ramped" open over a time interval and peak MAP value recorded and MAP Δ computed. EGR valve closed</p>	2.6 seconds Twice per trip	DTC Type Calif - A Fed - A
EGR Valve Open Pintle Position Error	P0404	Position error too high	Deviation between actual and desired position > 20% when position is < 70% or deviation is > 30% when desired position is > 70% for 10 seconds	Ignition voltage > 9V	Continuous	DTC Type Calif - B Fed - B
EGR Sensor Signal Low	P0405	Open / Short	Pintle position <6 A/D counts for 2 seconds	Ignition voltage > 9V	Continuous	DTC Type Calif - B Fed - B

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Secondary Air Injection System Malfunction ①	P0410	This diagnostic will determine if the secondary air injection system is functioning properly by monitoring O2 sensor voltage and short term fuel trim on both banks 1 and 2 when the air pump is turned on.	<p><u>AIR Passive Test 1</u> AIR pump ON A/F Ratio \geq 12:1 Startup ECT \leq 56.25 °C Hot/Cold Rich time ratio \geq0.39 OR Hot/Cold Lean time $<$ 0.60</p> <p><u>AIR Passive Test 2</u> AIR Passive test 1 has not run or failed. AIR Pump is ON O2 sensor #1 \geq 451 mV for a time \geq 5 seconds</p> <p><u>AIR Active Test</u> AIR Passive Test 1 and 2 have failed. AIR Pump ON O2 sensor voltage $<$ 299 mV OR Integrator $\Delta <$ 0.06 *Above tests are run on both banks 1 and 2.</p>	<p><u>AIR Passive Test Enable</u> ECT DTC's not active O2 sensor DTC's not active Misfire DTC's not active MAP sensor DTC's not active Fuel Trim DTC's not active Evap DTC's not active TP sensor DTC's not active IAT DTC's not active MAF DTC's not active System Voltage \geq 10V for a period $>$ 3 seconds IAT $>$ 0° C Engine run time $>$ 3 seconds</p> <p><u>AIR Active Test Enable</u> AIR Passive test failed ECT DTC's not active O2 sensor DTC's not active Misfire DTC's not active MAP sensor DTC's not active Fuel Trim DTC's not active Evap DTC's not active TP sensor DTC's not active IAT DTC's not active MAF DTC's not active Power enrichment not active Decel fuel cutoff not active Air/Fuel Ratio =14.7:1 Engine speed \geq 550 RPM Closed loop for a period $>$ 15 seconds Engine load $<$ 50% MAF \leq 100 g/second System voltage \geq 10V ECT \geq 75°C but \leq 105°C IAT $>$ 0°C Integrator $>$ 0.96 but $<$ 1.04 for 3 seconds</p>	<p><u>AIR Passive Test 1</u> Cold test is run for 30 seconds Hot test is run for 10 seconds</p> <p><u>AIR Passive Test 2</u> \geq 15 seconds</p> <p><u>AIR Active Test</u> $>$ 3.5 seconds</p> <p>Once per ignition cycle</p>	DTC Type Calif - B Fed - X

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Catalyst System Efficiency Below Threshold - (Bank 1)	P0420	This diagnostic will determine the efficiency of the catalytic converter.	Deviation Difference Average = 8 mV from O2 sensor (Bank1, Sensor 1)	<p><u>Converter Warm Up Status</u> Engine in closed loop Commanded Air/Fuel ratio = 14.7:1 Air flow > 15 g/sec Predicted catalyst warm up temperature > 450°C</p> <p><u>Test Enable</u> Converter Warm Up Test Passed IAT ≥ -9.75° C ECT > 75° C Air Flow > 15 g/sec but ≤ 50 g/sec Δ engine load ≤ 8.9% Vehicle Speed ≥ 20 mph but ≤ 85 mph (≥ 0 mph with scan tool installed) Engine air load ≤ 99% Engine speed ≤ 4700 rpm Throttle Position ≥ 1.9% VS sensor DTC's not active TP sensor DTC's not active O2 sensor DTC's not active Misfire DTC's not active MAP sensor DTC's not active Fuel Trim DTC's not active IAT sensor DTC's not active MAF DTC's not active ECT DTC's not active AIR DTC's not active</p>	<p>50 tests per trip</p> <p>Time necessary to complete sample: 173 sec</p> <p>Continuous</p>	<p>DTC Type Calif - A Fed - X</p>

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Catalyst System Efficiency Below Threshold - (Bank 2)	P0430	This diagnostic will determine the efficiency of the catalytic converter.	Deviation Difference Average = 8 mV from O2 sensor (Bank2, Sensor 1)	<p><u>Converter Warm Up Status</u> Engine in closed loop Commanded Air/Fuel ratio = 14.7:1 Air flow > 15 g/sec Predicted catalyst warm up temperature > 450°C</p> <p><u>Test Enable</u> Converter Warm Up Test Passed IAT ≥ -9.75° C ECT > 75° C Air Flow > 15 g/sec but ≤ 50 g/sec Δ engine load ≤ 8.9% Vehicle Speed ≥ 20 mph but ≤ 85 mph (≥ 0 mph with scan tool installed) Engine air load ≤ 99% Engine speed ≤ 4700 rpm Throttle Position ≥ 1.9% VS sensor DTC's not active TP sensor DTC's not active O2 sensor DTC's not active Misfire DTC's not active MAP sensor DTC's not active Fuel Trim DTC's not active IAT sensor DTC's not active MAF DTC's not active ECT DTC's not active AIR DTC's not active</p>	<p>50 tests per trip</p> <p>Time necessary to complete sample: 173 sec</p> <p>Continuous</p>	<p>DTC Type Calif - A Fed - X</p>

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Evap. Emission Control System Malfunction	P0440	This DTC will detect a weak vacuum condition (large leak or restriction) in the Evap. system.	<p><u>WEAK VACUUM TEST- STAGE I (Cold Test):</u> Tank Vac. < 13 or 9 in. H₂O <u>depending on application</u> <u>WEAK VACUUM TEST- STAGE II (Warm Test):</u> Stage I test failed previous trip and this trip. Tank Vac. < 11 in. H₂O</p>	<p><u>TEST ENABLE :</u> MAP DTC's not active TP Sensor DTC's not active VS Sensor DTC's not active O2 Sensor DTC's not active ECT Sensor DTC's not active DTC P0125 not active IAT Sensor DTC's not active Fuel Level >12.5% but < 87.5% Powerup Vacuum Test Fail = False System Voltage > 10V but < 18V Purge Closed Loop Multiplier ≥ 0.6 for a time ≤ a table value based on coolant temperature. If HC vapor is not present. <u>COLD START TEST:</u> ECT > 3.75°C but < 30° C IAT > 3.75°C but < 30° C Cold Temperature Δ (ECT - IAT): ° < 8.25 °C if ECT > IAT Baro > 72.5 kPa</p> <p><u>FUEL SLOSH TEST:</u> Tank Vacuum Δ ≤ value and Fuel Level Δ ≤ value based on fuel level.</p>	<p><u>WEAK VACUUM TEST- STAGE I (Cold Test):</u> Fault present for an integral time ≥ 30 , 50 or 80 depending on application sec.</p> <p><u>WEAK VACUUM TEST- STAGE II (Warm Test):</u> Fault present for a time ≥ 1400 sec.</p> <p>Once per cold start</p>	DTC Type A (Behaves as a Type B)

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Evap. Emission Control System Leak Detected (Small Leak)	P0442	This DTC will detect a small leak in the Evap. system between the fuel fill cap and up to but not including the purge solenoid.	<p><u>SMALL LEAK TEST FAIL:</u> Vacuum < 7 , 9 or 11" H₂O for a time < based on fuel level depending on application. Vacuum Decay (determined by fuel level and intake temperature) ≥ a value determined by Start Vacuum minus Tank Vacuum for a period ≥ 15 or 12 seconds. Vacuum > 0.1 in. H₂O for a time ≤ 35 , 50,60,80,85 seconds. depending on application</p>	<p><u>TEST ENABLE :</u> MAP DTC's not active TP Sensor DTC's not active VS Sensor DTC's not active O2 Sensor DTC's not active ECT Sensor DTC's not active DTC P0125 not active IAT Sensor DTC's not active Fuel Level >12.5% but < 87.5% System Voltage > 10V but < 18V Purge Closed Loop Multiplier ≥ 0.6 for a time ≤ a table value based on coolant temperature. If HC vapor is not present. <u>COLD START TEST:</u> ECT > 3.75°C but < 30° C IAT > 3.75°C but < 30° C Cold Temperature Δ (ECT - IAT): ° < 8.25 °C if ECT > IAT Baro > 72.5 kPa</p> <p><u>.020" LEAK:</u> Fuel level > value based on application. Tank Vacuum Δ ≤ value and Fuel Level Δ ≤ value based on fuel level. <u>FUEL SLOSH TEST:</u> Tank Vacuum Δ ≤ value and Fuel Level Δ ≤ value based on fuel level. <u>WEAK VACUUM TEST (Stage I) :</u> Throttle position < 75% Vehicle speed < 65 mph Tank Vacuum ≥ 9 ,11,13in. H₂O within 30,50,80 depending on app. seconds.</p>	Once per cold start	DTC Type A (Behaves as a Type B)

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Evap. Emission Control System Vent Control Malfunction	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filter, vent hose or canister.	<p><u>EXCESS VACUUM TEST - STAGE I</u></p> <p>Vent solenoid commanded OPEN Fuel Tank Vacuum ≥ 7 in. H₂O for 2 seconds(monitored during initial purge ramp)</p> <p>OR</p> <p><u>EXCESS VACUUM TEST - STAGE II:</u></p> <p>Vent solenoid commanded OPEN during normal purge. Fuel Tank Vacuum ≥ 12.9 in. H₂O for a time ≥ 4 seconds</p>	<p><u>TEST ENABLE :</u></p> <p>MAP DTC's not active TP Sensor DTC's not active VS Sensor DTC's not active O2 Sensor DTC's not active ECT Sensor DTC's not active DTC P0125 not active IAT Sensor DTC's not active Fuel Level $>12.5\%$ but $< 87.5\%$ System Voltage $> 10V$ but $< 18V$ Purge Closed Loop Multiplier ≥ 0.6 for a time \leq a table value based on coolant temperature. If HC vapor is not present.</p> <p><u>COLD START TEST:</u></p> <p>ECT $> 3.75^{\circ}C$ but $< 30^{\circ} C$ IAT $> 3.75^{\circ}C$ but $< 30^{\circ} C$ Cold Temperature Δ (ECT - IAT):</p> <p style="padding-left: 40px;">◦ < 8.25 °C if ECT > IAT Baro > 72.5 kPa</p> <p><u>FUEL SLOSH TEST:</u></p> <p>Tank Vacuum $\Delta \leq$ value and Fuel Level $\Delta \leq$ value based on fuel level.</p> <p><u>WEAK VACUUM TEST -Stage I:</u></p> <p>Tank Vacuum ≥ 9 11 or 13in. H₂O within 30,50,80 seconds. depending on application</p>	<p><u>EXCESS VACUUM TEST - STAGE II :</u></p> <p>180 seconds</p> <p>Once per cold start at:</p> <ul style="list-style-type: none"> • Powerup • Excess Vac. Stage I • Excess Vac. Stage II 	DTC Type A (Behaves as a Type B)
EVAP Fuel Tank Pressure Sensor Circuit Low Voltage	P0452	This DTC will detect a vacuum sensor stuck low	tank vacuum raw voltage < 0.1 volt for 5 seconds	<u>runs countiously after a 1 second delay for sensor warmup</u>		DTC Type B
EVAP Fuel Tank Pressure Sensor Circuit High Voltage	P0453	This DTC will detect a vacuum sensor stuck hi	tank vacuum raw voltage >4.98 volt for 5 seconds	<u>runs countiously after a 1 second delay for sensor warmup</u>		DTC Type B
Vehicle Speed (VS) Sensor Signal Missing	P0500	The DTC detects a missing speed signal between a combination of the rear and front speed sensors.	Vehicle Speed = 0 MPH	MAP sensor DTC's not active MAP < 20 kPa Coolant Temperature $> 60^{\circ} C$ Engine > 1400 RPM but < 4400 RPM Throttle Position < 3.125 %	Failing > 5 seconds Continuous	DTC Type Calif - B Fed - B

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Idle Control System RPM Lower Than Expected	P0506	This DTC will determine if a low idle is the result of a IAC valve or circuit. A low idle is defined as 100 RPM below the desired idle.	Air flow $\Delta < 6$ g/s	<p><u>Test Enable: (non - intrusive)</u> TP sensor DTC's not active VS sensor DTC's not active ECT DTC's not active MAP DTC's not active Transmission DTC's not active PRNDL DTC's not active Misfire DTC's not active IAT DTC's not active MAF DTC's not active ECT > 50°C System Voltage > 10.5V but < 16V IAT > -25°C Engine run time > 30 seconds Baro > 75 kPa (10000 ft) TP < 1% VS < 2 MPH Above met for a time > 3 seconds to enable diagnostic. If non-intrusive test fails, intrusive test is run.</p> <p><u>Run Test: (intrusive)</u> Air Flow > 25 g/sec but < 45 g/sec VS > 25 MPH but < 85 MPH TP $\Delta < 1\%$ Engine Speed $\Delta < 50$ RPM IAC motor commanded 10 %/ 100 msec.</p>	10 seconds Continuous after enable	DTC Type Calif - B Fed - B

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Idle Control System RPM Higher Than Expected	P0507	This DTC will determine if a high idle is the result of a IAC valve or circuit. A high idle is defined as 150 RPM above the desired idle.	Air flow $\Delta < 6$ g/s	<p><u>Test Enable: (non - intrusive)</u> TP sensor DTC's not active VS sensor DTC's not active ECT DTC's not active MAP DTC's not active Transmission DTC's not active PRNDL DTC's not active Misfire DTC's not active IAT DTC's not active MAF DTC's not active ECT > 50°C System Voltage > 10.5V but < 16V IAT > -25°C Engine run time > 30 seconds Baro > 75 kPa (10000 ft) TP < 1% VS < 2 MPH Above met for a time > 3 seconds to enable diagnostic. If non-intrusive test fails, intrusive test is run.</p> <p><u>Run Test: (intrusive)</u> Air Flow > 25 g/sec but < 45 g/sec VS > 25 MPH but < 85 MPH TP $\Delta < 1\%$ Engine Speed $\Delta < 50$ RPM IAC motor commanded 10 %/ 100 msec.</p>	10 seconds Continuous after enable	DTC Type Calif - B Fed - B
VCM Memory Error - Type 4 (Program Flash)	P0601	This diagnostic checksums the contents of flash EEPROM against the expected value.	The calculated checksum does not match the programmed value.	-----	Once per trip at controller initialization.	DTC Type Calif - A Fed - C
VCM Memory Error - Not Programmed	P0602	This diagnostic checks the state of the Service Calibration Bit to determine if the controller needs to be programmed.	The Calibrated No Start For Service bit is true in the calibration.	-----	Once per trip at controller initialization.	DTC Type Calif - A Fed - C
VCM Memory Error - Type 2 (Keep Alive)	P0603	This diagnostic checks that data stored to the Non-Volatile Keep Alive section of memory is stored correctly.	The data read from the memory location does not match the data that was just stored to that location.	-----	Continuous. On each memory data store as processor available time allows.	DTC Type Calif - A Fed - C
VCM Memory Error - Type 1 (Volatile RAM)	P0604	This diagnostic checks that data stored to the Volatile section of memory is stored correctly.	The data read from the memory location does not match the data that was just stored to that location.	-----	Continuous. On each memory data store as processor available time allows.	DTC Type Calif - A Fed - C

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
VCM Memory Error - Type 3 (Boot Flash)	P0605	This diagnostic checks that data stored to the Boot Flash section of memory is stored correctly.	The data read from the memory location does not match the data that was just stored to that location.	-----	Continuous. On each memory data store as processor available time allows.	DTC Type Calif - A Fed - C
Transmission Clutch Switch Input Malfunction (Manual Trans. Only)	P0704	This DTC will determine if the Transmission Clutch Switch has failed but looking for a clutch transition within a range from 0 MPH to some higher speed.	No clutch transitions detected	VS sensor DTC's not active Vehicle Speed > 50 mph	1 consecutive test failures Time necessary to complete sample: 100 ms	DTC Type Calif - B Fed - B
O2 Sys. Fault - Too Few O2S R/L or L/R Switches, Insufficient Activity (Bank 1, Sensor 1)	P1133	This DTC determines if the O2 sensor functioning properly by monitoring the number of L/R and R/L switches.	Number of switches in 100 seconds: L/R switches < 50 R/L switches < 50	<p><i>O2 Diagnostic Enable:</i> (the following criteria must be met to enable the O2 Response tests)</p> <p>TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V</p> <p><i>Response Test Enable:</i></p> <p>Closed loop low MAP not active DTC's P0131, P0132, P0134 and P0135 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 22.5 g/s but ≤ 55 g/s Engine speed ≥ 1200 rpm but ≤ 2200 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds</p>	100 seconds after closed loop enable Once per key cycle	DTC Type Calif - B Fed - C

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit - Transition Time Ratio Malfunction (Bank 1, Sensor 1)	P1134	This DTC determines if the O2 sensor functioning properly by checking the ratio of average response time.	Ratio of average response times: Ratio > 4 or < 0 *O2 voltage < 300 mV = lean *O2 voltage > 600 mV = rich	<u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V <u>Response Test Enable:</u> Closed loop low MAP not active DTC's P0131, P0132, P0134 and P0135 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 22.5 g/s but ≤ 55 g/s Engine speed ≥ 1200 rpm but ≤ 2200 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds	100 seconds after closed loop enable Once per ignition cycle	DTC Type Calif - B Fed - C
O2 Sys. Fault - Too Few O2S R/L or L/R Switches, Insufficient Activity (Bank 2, Sensor 1)	P1153	This DTC determines if the O2 sensor functioning properly by monitoring the number of L/R and R/L switches.	Number of switches in 100 seconds: L/R switches < 50 R/L switches < 50	<u>O2 Diagnostic Enable:</u> (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V <u>Response Test Enable:</u> Closed loop low MAP not active DTC's P0151, P0152, P0154 and P0155 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 22.5 g/s but ≤ 55 g/s Engine speed ≥ 1200 rpm but ≤ 2200 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds	100 seconds after closed loop enable Once per key cycle	DTC Type Calif - B Fed - C

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
O2S Circuit - Transition Time Ratio Malfunction (Bank 2, Sensor 1)	P1154	This DTC determines if the O2 sensor functioning properly by checking the ratio of the average response time.	Ratio of average response times: Ratio > 4 or < 0 *O2 voltage < 300 mV = lean *O2 voltage > 600 mV = rich	<i>O2 Diagnostic Enable:</i> (the following criteria must be met to enable the O2 Response tests) TP sensor DTC's not active Purge DTC's not active IAT sensor DTC's not active MAP DTC's not active ECT sensor DTC's not active MAF sensor DTC's not active Misfire DTC's not active AIR DTC's not active No intrusive tests in progress No device controls active System Voltage ≥ 9V <i>Response Test Enable:</i> Closed loop low MAP not active DTC's P0151, P0152, P0154 and P0155 not active Closed loop ECT > 57°C Engine run time > 75 seconds Air flow ≥ 22.5 g/s but ≤ 55 g/s Engine speed ≥ 1200 rpm but ≤ 2200 rpm Canister Purge Duty Cycle ≥ 0% Above present for > 2 seconds	100 seconds after closed loop enable Once per ignition cycle	DTC Type Calif - B Fed - C
Crankshaft Position System Variation Not Learned (CASE)	P1336	This diagnostic will determine if the Crankshaft Position System Variation has been learned	Engine running	Manufactures Enable counter must be zero ECT > 65.25 C	Continuous	DTC Type Calif - A Fed - C
Camshaft Sensor Misinstalled	P1345	1X Signal This diagnostic will determine if the Cam sensor and high voltage switch have been installed correctly.	Cam signal falling edge out of phase ± 15° from crank falling edge.	-----	30 test failures within a 50 test sample size. Time necessary to complete sample: Varies with engine speed Every crank fall	DTC Type Calif - A Fed - A
EST Output High	P1351	This diagnostic will determine if a failure has occurred due to an open circuit.	EST voltage > 4.9V	EST Enabled Engine speed < 250 RPM	20 test failure Time necessary to complete sample: Executed during crank, approximately 3 sec Once per ignition cycle	DTC Type Calif - A Fed - A

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
EST Not Toggling After Enable	P1361	This diagnostic will determine if a failure has occurred due to a grounded circuit.	EST voltage < 0.04V	EST Enabled Engine speed < 250 RPM	20 test failure Time necessary to complete sample: Executed during crank, approximately 3 sec Once per ignition cycle	DTC Type Calif - A Fed - A
EGR Valve Circuit Performance - actual position greater than commanded	P1404	This diagnostic detects if the valve is stuck open when commanded closed.	Actual Pintle position > 10 A/D counts from learned closed position for 10 seconds for 3 subroutines	EGR valve strokes to 100% duty cycle between subroutines. Enable parameters for stroke: 80°C < ETC < 120°C IAT < 80 °C Desired EGR > 40 %	Continuous	DTC Type Calif - B Fed - B
Secondary Air Injection System Malfunction (Bank 1) ①	P1415	This diagnostic will determine if the secondary air injection system is functioning properly by monitoring O2 sensor voltage and short term fuel trim on bank 1 when the air pump is turned on.	<u>AIR Passive Test 1</u> AIR pump ON A/F Ratio ≥ 12:1 Startup ECT ≤ 56.25 °C Hot/Cold Rich time ratio ≥ 0.39 OR Hot/Cold Lean time < 0.60 <u>AIR Passive Test 2</u> AIR Passive test 1 has not run or failed. AIR Pump is ON O2 sensor #1 ≥ 451 mV for a time ≥ 5 seconds <u>AIR Active Test</u> AIR Passive Test 1 and 2 have failed. AIR Pump ON O2 sensor voltage < 299 mV OR Integrator Δ < 0.06	<u>AIR Passive Test Enable</u> ECT DTC's not active O2 sensor DTC's not active Misfire DTC's not active MAP sensor DTC's not active Fuel Trim DTC's not active Evap DTC's not active TP sensor DTC's not active IAT DTC's not active MAF DTC's not active System Voltage ≥ 10V for a period > 3 seconds IAT > 0° C Engine run time > 3 seconds <u>AIR Active Test Enable</u> AIR Passive test failed ECT DTC's not active IAC DTC's not active O2 sensor DTC's not active Misfire DTC's not active MAP sensor DTC's not active Fuel Trim DTC's not active Evap DTC's not active TP sensor DTC's not active IAT DTC's not active MAF DTC's not active Power enrichment not active Decel fuel cutoff not active Air/Fuel Ratio =14.7:1 Engine speed ≥ 550 RPM Closed loop for a period > 15 seconds Engine load < 50% MAF ≤ 100 g/second System voltage ≥ 10V ECT ≥ 75°C but ≤ 105°C IAT > 0° C Integrator > 0.96 but < 1.04 for 3 seconds	<u>AIR Passive Test 1</u> Cold test is run for 30 seconds Hot test is run for 10 seconds <u>AIR Passive Test 2</u> ≥ 15 seconds <u>AIR Active Test</u> > 3.5 seconds Once per ignition cycle	DTC Type Calif - B Fed - X

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Secondary Air Injection System Malfunction (Bank 2) ①	P1416	This diagnostic will determine if the secondary air injection system is functioning properly by monitoring O2 sensor voltage and short term fuel trim on bank 2 when the air pump is turned on.	<p><u>AIR Passive Test 1</u> AIR pump ON A/F Ratio \geq 12:1 Startup ECT \leq 56.25 °C Hot/Cold Rich time ratio \geq 0.39 OR Hot/Cold Lean time $<$ 0.60</p> <p><u>AIR Passive Test 2</u> AIR Passive test 1 has not run or failed. AIR Pump is ON O2 sensor #1 \geq 451 mV for a time \geq 5 seconds</p> <p><u>AIR Active Test</u> AIR Passive Test 1 and 2 have failed. AIR Pump ON O2 sensor voltage $<$ 299 mV OR Integrator $\Delta <$ 0.06</p>	<p><u>AIR Passive Test Enable</u> ECT DTC's not active O2 sensor DTC's not active Misfire DTC's not active MAP sensor DTC's not active Fuel Trim DTC's not active Evap DTC's not active TP sensor DTC's not active IAT DTC's not active MAF DTC's not active System Voltage \geq 10V for a period $>$ 3 seconds IAT $>$ 0° C Engine run time $>$ 3 seconds</p> <p><u>AIR Active Test Enable</u> AIR Passive test failed ECT DTC's not active IAC DTC's not active O2 sensor DTC's not active Misfire DTC's not active MAP sensor DTC's not active Fuel Trim DTC's not active Evap DTC's not active TP sensor DTC's not active IAT DTC's not active MAF DTC's not active Power enrichment not active Decel fuel cutoff not active Air/Fuel Ratio =14.7:1 Engine speed \geq 550 RPM Closed loop for a period $>$ 15 seconds Engine load $<$ 50% MAF \leq 100 g/second System voltage \geq 10V ECT \geq 75°C but \leq 105°C IAT $>$ 0 °C Integrator $>$ 0.96 but $<$ 1.04 for 3 seconds</p>	<p><u>AIR Passive Test 1</u> Cold test is run for 30 seconds Hot test is run for 10 seconds</p> <p><u>AIR Passive Test 2</u> \geq 15 seconds</p> <p><u>AIR Active Test</u> $>$ 3.5 seconds</p> <p>Once per ignition cycle</p>	DTC Type Calif - B Fed - X

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Evap. Emission Control System - Continuous Open Purge Flow	P1441	This DTC will determine if the purge solenoid is leaking.	<p><u>PURGE VALVE LEAK TEST:</u> Purge Valve closed TP > 0% but < 99.6% Vacuum ≥ 10 KPa Tank Vacuum ≥ 12 in. H₂O for 2 sec within ≤ 37.5 seconds after 30 second delay.</p>	<p><u>TEST ENABLE:</u> MAP DTC's not active TP Sensor DTC's not active VS Sensor DTC's not active O2 Sensor DTC's not active ECT Sensor DTC's not active DTC P0125 not active IAT Sensor DTC's not active Fuel Level >12.5% but < 87.5% System Voltage > 10V but < 18V Purge Closed Loop Multiplier ≥ 0.6 for a time ≤ a table value based on coolant temperature. If HC vapor is not present.</p> <p><u>COLD START TEST:</u> ECT > 3.75°C but < 30° C IAT > 3.75°C but < 30° C Cold Temperature Δ (ECT - IAT): ° < 8.25 °C if ECT > IAT Baro >72.5 kPa</p> <p><u>FUEL SLOSH TEST:</u> Tank Vacuum Δ ≤ value and Fuel Level Δ ≤ value based on fuel level.</p> <p><u>EXCESS VACUUM TEST -STAGE I:</u> Vent solenoid commanded OPEN Fuel Tank Vacuum < 7 in. H₂O</p> <p><u>WEAK VACUUM TEST -Stage I:</u> Throttle position < 75% Vehicle speed < 65 mph Tank Vacuum ≥ 9, 11 or 13 in. H₂O within 30 ,50 or 80seconds.</p>	<p><u>PURGE VALVE LEAK TEST:</u> 180seconds Max. Once per cold start</p>	DTC Type B

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Idle Air Control - Low	P1508	This DTC will determine if a low idle is the result of an engine mechanical problem. A low idle is defined as 100 RPM below the desired idle.	Air flow $\Delta > 6$ g/s	<p><u>Test Enable: (non - intrusive)</u> TP sensor DTC's not active VS sensor DTC's not active ECT DTC's not active MAP DTC's not active Transmission DTC's not active PRNDL DTC's not active Misfire DTC's not active IAT DTC's not active MAF DTC's not active ECT > 50°C System Voltage > 10.5V but < 16V IAT > -25°C Engine run time > 30 seconds Baro > 75 kPa (10000 ft) TP < 1% VS < 2 MPH Above met for a time > 3 seconds to enable diagnostic. If non-intrusive test fails, intrusive test is run.</p> <p><u>Run Test: (intrusive)</u> Air Flow > 25 g/sec but < 45 g/sec VS > 25 MPH but < 85 MPH TP $\Delta < 1\%$ Engine Speed $\Delta < 50$ RPM IAC motor commanded 10 %/ 100 msec.</p>	10 seconds Continuous after enable	DTC Type Calif - B Fed - B

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Idle Air Control - High	P1509	This DTC will determine if a high idle is the result of an engine mechanical problem. A high idle is defined as 150 RPM above the desired idle.	Air flow $\Delta > 6$ g/s	<p><u>Test Enable: (non - intrusive)</u> TP sensor DTC's not active VS sensor DTC's not active ECT DTC's not active MAP DTC's not active Transmission DTC's not active PRNDL DTC's not active Misfire DTC's not active IAT DTC's not active MAF DTC's not active ECT > 50°C System Voltage > 10.5V but < 16V IAT > -25°C Engine run time > 30 seconds Baro > 75 kPa (10000 ft) TP < 1% VS < 2 MPH Above met for a time > 3 seconds to enable diagnostic. If non-intrusive test fails, intrusive test is run.</p> <p><u>Run Test: (intrusive)</u> Air Flow > 25 g/sec but < 45 g/sec VS > 25 MPH but < 85 MPH TP $\Delta < 1\%$ Engine Speed $\Delta < 50$ RPM IAC motor commanded 10 %/ 100 msec.</p>	10 seconds Continuous after enable	DTC Type Calif - B Fed - B

2000 Truck V8 group 3 7.4L (L29) ENGINE DIAGNOSTIC PARAMETERS

2000file17.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Fuel Level No Change, Stuck in Range	P0461	This DTC will detect a fuel sender stuck in range	Delta Fuel level A/D counts change less than 10 counts over a accumulated 200 miles	runs continuously		C No Light
Fuel Level Stuck Low	P0462	This DTC will detect a fuel sender stuck out of range low	Fuel level A/D counts less than 20 A/D counts for 25 seconds	runs continuously		C No Light
Fuel Level Stuck High	P0463	This DTC will detect a fuel sender stuck out of range high	Fuel level A/D counts more than 150 A/D counts for 25 seconds	runs continuously		C No Light