

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
MASS AIR FLOW SYSTEM PERFORMANCE (RATIONALITY)	P0101	This DTC determines if the MAF sensor is stuck within the normal operating range	Calculated Flow – Measured Flow > cal (table) Table look up as a function of calculated flow	Engine running TP sensor DTC's not active MAP sensor DTC's not active Evap DTC's not active EGR DTC P0401 not active MAF sensor high/low DTC's not active Crank sensor DTC's not active IAT sensor DTC's not active EGR flow diagnostic not active Traction control not active System voltage > 11V but < 18V Canister Purge DC ≤ 100% TP Δ ≤ 5% EGR DC ≤ 100% EGR Pintle Position ≤ 100% Engine vacuum ≤ 80 kPa MAP Delta 3 ≤ kPa Throttle Position ≤ 95% The above must be present for a period of time greater than 1.5 seconds	40 test failures in a 100 test sample The Mass Air Flow reading and Mass Air Flow calculation are performed during the same cylinder event every 100 ms.	DTC Type B
MASS AIR FLOW SENSOR CIRCUIT LOW FREQUENCY	P0102	Detects a continuous short to low or a open in either the signal circuit or the MAF sensor	<u>LOW FREQUENCY TEST:</u> MAF ≤ 1200 Hz	<u>LOW FREQUENCY TEST</u> Engine Running Engine Run Time ≥ 0 seconds Engine Speed ≥ 400 RPM System Voltage ≥ 8 volts The above must be present for a period of time greater than .7 seconds	<u>LOW FREQUENCY TEST:</u> 6 test failures in a 40 test sample. 1 sample per 100 ms Test is run at every reading of the Mass Air Flow sensor frequency	DTC Type B
MASS AIR FLOW SENSOR CIRCUIT HIGH FREQUENCY	P0103	Detects a continuous short to high in either the signal circuit or the MAF sensor	<u>HIGH FREQUENCY TEST:</u> MAF ≥ 12000 Hz	<u>HIGH FREQUENCY TEST:</u> Engine Running Engine Run Time ≥ 0 seconds Engine Speed ≥ 400 RPM System Voltage ≥ 8 volts The above must be present for a period of time greater than .7 seconds	<u>HIGH FREQUENCY TEST:</u> 18 test failures in a 24 test sample. 1 sample per 100 ms Test is run at every reading of the Mass Air Flow sensor frequency	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
MAP SENSOR RANGE/ PERFORMANCE (RATIONALITY)	P0106	This DTC determines if the MAP sensor is stuck within the normal operation range	MAP (kPa) > or < predicted MAP (lookup table as a function of TPS and RPM)	Engine Running MAP sensor DTC's not active TP sensor DTC's not active MAF circuit DTC's not active Evap DTC's not active Traction Control not active Engine Speed Δ 125 RPM Throttle Position Δ < 100% Idle Air Δ 10 g/sec EGR Position Max Δ < 20% Brake Switch State = no change Clutch Switch State = no change Power Steering = Stable PTO = not active AC Clutch State = no change Above stabilized for 1 second EGR DTC's not active Engine Speed \geq 500 RPM Engine Speed \leq 5000 RPM	20 test failures within a 30 test sample 1 sample/sec	DTC Type B
MANIFOLD ABSOLUTE PRESSURE SENSOR CIRCUIT LOW	P0107	This DTC detects a continuous short to low or open in either the signal circuit or the MAP sensor.	Raw MAP < .04 volts (3 counts)	TP sensor DTC's not active Engine Running Throttle Position is \geq 0% when engine speed is \leq 800 RPM Or Throttle Position is \geq 12.5 % when engine speed is > 800 RPM No 5v ref. DTC's	320 test failures in a 400 test sample. 1 sample/100 ms	DTC Type B
MANIFOLD ABSOLUTE PRESSURE SENSOR CIRCUIT HIGH	P0108	This DTC detects an open sensor ground or continuous short to high in either the signal circuit or the MAP sensor	Raw MAP > 4.89 Volts (250 counts)	Cold Start Run Time – Table value in seconds based on Powerup Coolant Temperature <u>Run Test</u> TP sensor DTC's not active Engine Running Throttle Position is \leq 1 % when engine speed is \leq 1200 RPM Or Throttle Position is \leq 20 % when engine speed is > 1200 RPM	320 test failures in a 400 test sample. 1 sample/100 ms	DTC Type B
INTAKE AIR TEMP SENSOR CIRCUIT LOW (HIGH TEMP)	P0112	This DTC detects a continuous short to ground in the IAT signal circuit or the IAT sensor	Raw IAT < .244 Volts	VS sensor DTC's not active Vehicle speed \geq 25 mph Engine run time > 30 seconds Coolant Temperature < 135°C	45 test failures in a 50test sample 1 sample/sec	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
INTAKE AIR TEMP SENSOR CIRCUIT HIGH (LOW TEMP)	P0113	This DTC detects a continuous open or short to high in the IAT signal circuit or the IAT sensor	Raw IAT > 4.95 Volts	MAF sensor DTC's not active ECT sensor DTC's not active VS sensor DTC's not active Coolant Temperature > 0 °C Mass Air Flow < 15 g/sec Vehicle Speed < 7 mph Engine run time > 100 seconds	45 test failures in a 50 test sample. 1 sample/sec	DTC Type B
ENGINE COOLANT TEMP SENSOR RATIONALITY (HIGH-SIDED)	P0116	Detects coolant temp sensor stuck in mid range	ECT – IAT > 15°C	Soak time > 10 hours IAT > 15°C IAT drop <3°C Vehicle Speed >15mph for 400 seconds	Immediate when enable conditions are met	DTC Type B
ENGINE COOLANT TEMP SENSOR CIRCUIT LOW (HIGH TEMP)	P0117	This DTC detects a continuous short to ground in the ECT signal circuit or the ECT sensor.	<u>Low Resistance Pull-up</u> Raw ECT < .234 Volts <u>High Resistance Pull-up</u> Raw ECT < .035 Volts	Engine run time > 10 seconds Or Engine run time < 10 seconds IAT < 50° C	45 test failures in a 50 test sample. 1 sample/sec	DTC Type B
ENGINE COOLANT TEMP SENSOR CIRCUIT HIGH (LOW TEMP)	P0118	Circuit Continuity This DTC detects a continuous short to high or open in the ECT signal circuit or the ECT sensor.	<u>Low Resistance Pull-up</u> Raw IAT > 4.93 Volts <u>High Resistance pull-up</u> Raw IAT > 4.95 Volts	Engine run time > 60 seconds Or Engine run time < 60 seconds IAT > 0° C	45 test failures in a 50 test sample. 1 sample/sec Continuous	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
THROTTLE POSITION SENSOR 1 CIRCUIT	P0120	1) TACM indicates a continuous or intermittent short or open in either the signal circuit or the TP sensor #1. OR 2) TACM indicates an invalid minimum mechanical position for the TP sensor #1. OR 3) TACM indicated reference voltage out of range.	1) Raw TP sensor signal < 0.376 V or > 4.506 V. OR 2) TP sensor minimum mechanical stop voltage < 0.376 V or > 0.714 V. OR 3) Vref out of range < 4.54 V or > 5.21 V.	Ignition in Run or Crank. Ignition voltage > 5.23 V. Valid TACM - PCM serial data. No TACM processor DTC.	1) Counter increments by 4 for every error, decrements by 1 for every pass; threshold is 133. Check runs every 3 ms. 2) One occurrence. Check runs at power-up. 3) Continuous. Counter increments by 1 for every error, decrements by 1 for every pass. Threshold is 10ms. For Ref direct short to ground. 4) Second continuous counter increments by 1 for every error and decrements by 1 for every pass, threshold is 1000 msec. Verify A/D input on Ref to be 5volts +/- tolerance.	DTC Type A
TP SENSOR CIRCUIT PERFORMANCE	*P0121	The DTC determines if a TPS sensor is stuck within the normal operating range	<u>Stuck high test:</u> The last throttle position value is > predicted throttle position based on engine RPM. <u>Stuck low test:</u> The last throttle position value is < predicted throttle position based on engine RPM	<u>Test Enable:</u> Engine Coolant Temp > 60° C No TP sensor short DTC's active No IAC DTC's active No MAP DTC's active No MAF DTC's active Engine run time > 120 sec BARO not defaulted MAP delta < 1.5 kPa MAP stable time > 1 sec <u>Stuck high test:</u> MAP < 55 kPa <u>Stuck low test:</u> MAP > 65 kPa IAC > 0 counts but < 310 counts	<u>Stuck high test:</u> 150 test failures within a 200 test sample <u>Stuck low test:</u> 150 test failures within a 200 test sample 1 sample/100ms	DTC Type B For use on vehicles without ETC
TP SENSOR CIRCUIT LOW	*P0122	This DTC detects a continuous short to low or open in either the signal circuit or the TP sensor	TP sensor signal voltage < .149 volts (7.6 counts)	No 5v ref DTC's	90 test failures in a 100 test sample size. 1 sample/100ms	DTC Type B For use on vehicles without ETC

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
TP SENSOR CIRCUIT HIGH	*P0123	This DTC detects a continuous short to high in either the signal circuit or the TP sensor.	TP sensor signal voltage > 4.89 volts. (249.9 counts)	No 5v ref DTC's	90 test failures in a 100 test sample size. 1 sample/100ms	DTC Type B For use on vehicles without ETC
CLOSED LOOP TEMPERATURE NOT ACHIEVED (ENGINE COOLANT TEMPERATURE RATIONALITY)	P0125	Under driving conditions, closed loop temperature should be achieved based on amount of cumulative air flow ingested and based on startup coolant temperature	A table defines cumulative airflow based on startup coolant temperature past which closed loop temperature is not achieved, at an acceptable rate	20 gps < airflow < 70 gps Engine runtime < 1600 seconds before test completes Engine runtime > 120 seconds -7°C < IAT < 54°C Vehicle speed > 3 mph for 0.5 miles ECT at startup < 40°C	Once per trip Time based on flow	DTC Type B
COOLANT TEMPERATURE BELOW STAT REGULATING TEMPERATURE	P0128	Under driving conditions, stat regulating temperature should be achieved based on amount of cumulative airflow ingested, and based on startup coolant temperature	A table defines maximum cumulative airflow based on startup coolant temperature, at which stat regulating temperature less 11° C must have been achieved	22 gps < airflow < 70 gps Engine runtime < 1600 seconds before test completes Engine runtime > 120 seconds -7°C < IAT < 54°C Vehicle speed > 3 mph for 1.5 miles ECT at startup < 74°C Stat regulating temp 90° C	Once per trip Time based on flow	DTC Type B
(B1S1) HEATED OXYGEN SENSOR CIRCUIT LOW	P0131	Circuit Continuity Detects a HO2S voltage stationary lean (low signal voltage) condition.	Oxygen sensor voltage < 200 mV <OR> In PE Oxygen sensor voltage < 400 mV	Closed Loop Fuel Control. TPS: 3-70% Fuel > 10% 10 V < System Voltage < 18 V Above conditions met for 2 sec No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Fuel Composition or Engine Protect faults active. Power Enrichment active 2 sec Fuel > 10% 10 V < System Voltage < 18V Engine runtime > 30 sec No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Fuel Composition or Engine Protect faults active.	310 failures out of 330 samples. Sensor monitored for 5 sets of samples. After 5 sets of failures, related sensors checked for same failure. If related sensor also failing, no action taken. 100 ms/sample Continuous 95 failures out of 100 samples 100 ms/sample Continuous	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
(B1S1) HEATED OXYGEN SENSOR CIRCUIT HIGH	P0132	Circuit Continuity Detects a HO2S voltage stationary rich (high signal voltage) condition.	Oxygen sensor voltage > 900 mV <OR> In DFCO Oxygen sensor voltage > 250 mV	Closed Loop Fuel Control. TPS: 3-70% Fuel > 10% 10 V < System Voltage < 18V Above conditions met for 2 sec No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Fuel Composition or Engine Protect faults active. Decel Fuel Cut Off active 4 sec Fuel > 10% 10 V < System Voltage < 18 V Engine runtime > 30 sec No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Fuel Composition or Engine Protect faults active.	310 failures out of 330 samples. Sensor monitored for 5 sets of samples. After 5 sets of failures, related sensors checked for same failure. If related sensor also failing, no action taken. 100 ms/sample Continuous 45 failures out of 50 samples 100 ms/sample Continuous	DTC Type B
(B1S1) HEATED OXYGEN SENSOR CIRCUIT SLOW RESPONSE	P0133	Detects slow rich to lean or lean to rich HO2S signal transition rates.	The oxygen sensor signal transitions from below 250 mV to above 600 mV or from above 600 mV to below 250 mV without reversal. HO2S sensor average transition time: L/R > 120 ms R/L > 112 ms	Closed Loop Fuel Control Engine runtime > 160 sec 1000 < RPM < 3000 29 < Air Flow < 55g/s. 10 V < System Voltage < 18V TPS > 5% Fuel > 10% ECT > 60 °C CCP > 0 775 °C < Calculated Oxygen Sensor Temp < 850 °C Above conditions met for 1 sec DTC's P0131, P0132, P0134 and P0135 not set No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Fuel Composition or Engine Protect faults active.	100 sec Once per trip.	DTC Type B
(B1S1) HEATED OXYGEN SENSOR CIRCUIT NO ACTIVITY	P0134	Circuit Continuity Detects a HO2S circuit open.	Oxygen sensor voltage remains between 350-550 mV	Closed Loop Fuel Control Engine runtime > 300 sec 10 V < System Voltage < 18V No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protection or Fuel Composition faults active.	570 failures out of 600 samples 100 ms/sample Continuous.	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
(B1S1) HEATED OXYGEN SENSOR HEATER CIRCUIT	P0135	Detects a malfunctioning HO2S heater circuit by monitoring the current through the circuit	.25 amps < Heater Current < 2.5 amps	10 V < System Voltage < 18 V Coolant > 50 °C 3 g/s < Airflow < 40 g/s Device control not active Engine runtime > 120 sec 500 < RPM < 3000 No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active.	8 failures out of 10 samples Frequency: 2 times per key cycle	DTC Type B
(B1S2) HEATED OXYGEN SENSOR CIRCUIT LOW	P0137	Circuit Continuity Detects a HO2S voltage stationary lean (low signal voltage) condition.	Oxygen sensor voltage < 80 mV <OR> In PE Oxygen sensor voltage < 490 mV	Closed Loop Fuel Control. TPS: 3-70% Fuel > 10% 10 V < System Voltage < 18 V Above conditions met for 2 sec No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active. Power Enrichment active 2 sec Fuel > 10% 10 V < System Voltage < 18V Engine runtime > 30 sec No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active.	380 failures out of 400 samples Sensor monitored for 5 sets of samples. After 5 sets of failures, related sensors checked for same failure. If related sensor also failing, no action taken. 100 ms/sample Continuous 95 failures out of 100 samples 100 ms/sample Continuous	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
(B1S2) HEATED OXYGEN SENSOR CIRCUIT HIGH	P0138	Circuit Continuity Detects a HO2S voltage stationary rich (high signal voltage) condition.	Oxygen sensor voltage > 950 mV <OR> In DFCO Oxygen sensor voltage > 250 mV	Closed Loop Fuel Control. TPS: 3-70% Fuel > 10% 10 V < System Voltage < 18 V Above conditions met for 2 sec No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active. Decel Fuel Cut Off active 4 sec Fuel > 10% 10 V < System Voltage < 18 V Engine runtime > 30 sec No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active.	380 failures out of 400 samples. Sensor monitored for 5 sets of samples. After 5 sets of failures, related sensors checked for same failure. If related sensor also failing, no action taken. 100 ms/sample Continuous 45 failures out of 50 samples. 100 ms/samples Continuous	DTC Type B
(B1S2) HEATED OXYGEN SENSOR CIRCUIT NO ACTIVITY	P0140	Circuit Continuity Detects a HO2S circuit open.	410 mV < B1S2 voltage < 490 mV Or Post O2 sensor fast pass B1S2 > 550 mV B1S2 < 350 mV	Engine runtime > 300 sec Closed Loop Fuel Control. 10 V < System Voltage < 18 V Fuel >10% 5% Δ TPS within 1 sec, 6 times DTC P0141 not set No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active. 10 V < System Voltage < 18 V Fuel > 10% Engine runtime < 200 sec DTC P0141 not set No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active.	1450 failures out of 1500 samples. 100 ms/sample Once per trip 550 more passing samples than failing samples. 100 ms/sample Once per trip	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
(B1S2) HEATED OXYGEN SENSOR HEATER CIRCUIT	P0141	Detects a malfunctioning HO2S heater circuit by monitoring the current through the circuit	.25 amps < Heater Current < 2.5 amps	10 V < System Voltage < 18 V. Coolant > 50 °C 3 g/s < Airflow < 40 g/s Device control not active Engine runtime > 120 sec 500 < RPM < 3000 No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active.	8 failures out of 10 samples Frequency: 2 times per key cycle	DTC Type B
(B2S1) HEATED OXYGEN SENSOR CIRCUIT LOW	P0151	Circuit Continuity Detects a HO2S voltage stationary lean (low signal voltage) condition.	Oxygen sensor voltage < 200 mV <OR> In PE Oxygen sensor voltage < 400 mV	Closed Loop Fuel Control. TPS: 3-70% Fuel > 10% 10 V < System Voltage < 18 V Above conditions met for 2 sec No AIR, EGR, No Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active. Power Enrichment active 2 sec Fuel > 10% 10 V < System Voltage < 18 V Engine runtime > 30 sec No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Fuel Composition or Engine Protect faults active.	310 failures out of 330 samples. Sensor monitored for 5 sets of samples. After 5 sets of failures, related sensors checked for same failure. If related sensor also failing, no action taken. 100 ms/sample Continuous 95 failures out of 100 samples 100 ms/sample Continuous	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
(B2S1) HEATED OXYGEN SENSOR CIRCUIT HIGH	P0152	Circuit Continuity Detects a HO2S voltage stationary rich (high signal voltage) condition.	<p>Oxygen sensor voltage > 900 mV</p> <p align="center"><OR></p> <p align="center">In DFCO Oxygen sensor voltage > 250 mV</p>	<p>Closed Loop Fuel Control. TPS: 3-70% Fuel > 10% 10 V < System Voltage < 18 V</p> <p>Above conditions met for 2 sec No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow,, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active.</p> <p>Decel Fuel Cut Off active 4 sec Fuel > 10% 10 V < System Voltage < 18 V</p> <p>Engine runtime > 30 sec No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Fuel Composition or Engine Protect faults active.</p>	<p>310 failures out of 330 samples. Sensor monitored for 5 sets of samples. After 5 sets of failures, related sensors checked for same failure. If related sensor also failing, no action taken.</p> <p align="center">100 ms/sample</p> <p align="center">Continuous</p> <p>45 failures out of 50 samples</p> <p align="center">100 ms/sample</p> <p align="center">Continuous</p>	DTC Type B
(B2S1) HEATED OXYGEN SENSOR CIRCUIT SLOW RESPONSE	P0153	Detects slow rich to lean or lean to rich HO2S signal transition rates.	<p>The oxygen sensor signal transitions from below 250 mV to above 600 mV or from above 600 mV to below 250 mV without reversal.</p> <p>HO2S sensor average transition time: L/R > 120 ms R/L > 112 ms</p>	<p>Closed Loop Fuel Control Engine runtime > 160 sec 1200 < RPM < 3000 18 < Air Flow < 55 g/s 10 V < System Voltage < 18 V TPS > 5% Fuel > 10% ECT > 60 °C CCP > 0</p> <p>775 °C < Predicted Oxygen Sensor Temp < 850 °C Above conditions met for 1 sec DTC's P0151, P0152, P0154 and P0155 not set No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active.</p>	<p align="center">100 sec</p> <p align="center">Once per trip.</p>	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
(B2S1) HEATED OXYGEN SENSOR CIRCUIT NO ACTIVITY	P0154	Circuit Continuity Detects a HO2S circuit open.	Oxygen sensor voltage remains between 350-550 mV	Closed Loop Fuel Control. Engine runtime > 300 sec 10 V < System Voltage < 18 V Fuel > 10% No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow,, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active.	570 failures out of 600 samples. 100 ms/sample Continuous	DTC Type B
(B2S1) HEATED OXYGEN SENSOR HEATER CIRCUIT	P0155	Detects a malfunctioning HO2S heater circuit by monitoring the current through the circuit	.25 amps < Heater Current < 2.5 amps	10 V < System Voltage < 18 V Coolant > 50 °C 3 g/s < Airflow < 40 g/s Device control not active Engine runtime > 120 sec 500 < RPM < 3000 No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow,, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active.	8 failures out of 10 samples Frequency: 2 times per key cycle	DTC Type B
(B2S2) HEATED OXYGEN SENSOR CIRCUIT LOW	P0157	Circuit Continuity Detects a HO2S voltage stationary lean (low signal voltage) condition.	Oxygen sensor voltage < 80 mV <p style="text-align: center;"><OR></p> Oxygen sensor voltage < 490 mV	Closed Loop Fuel Control. TPS: 3-70% Fuel > 10% 10 V < System Voltage < 18 V Above conditions met for 2 sec No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active. Power Enrichment active 2 sec Fuel > 10% 10 V < System Voltage < 18 V Engine runtime > 30 sec No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active.	380 failures out of 400 samples. Sensor monitored for 5 sets of samples. After 5 sets of failures, related sensors checked for same failure. If related sensor also failing, no action taken. 100 ms/sample Continuous 95 failures out of 100 samples. 100 ms/sample Continuous	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
(B2S2) HEATED OXYGEN SENSOR HEATER CIRCUIT	P0161	Detects a malfunctioning HO2S heater circuit by monitoring the current through the circuit	.25 amps < Heater Current < 2.5 amps	10 V < System Voltage < 18 V Coolant > 50 °C 3 g/s < Airflow < 40 g/s Device control not active Engine runtime > 120 sec 500 < RPM < 3000 No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active.	8 failures out of 10 samples Frequency: 2 times per key cycle	DTC Type B For use on vehicles with 4 sensors
BANK 1 FUEL TRIM SYSTEM LEAN	P0171	Determines if the fuel control system is in a lean condition	The normalized weighted long term fuel trim parameter > + 24 %	No VSS, Throttle, Purge control, Misfire, MAT, MAP, - Camel Mode, Injector, EST Control, EGR Sensor, Coolant, Crank sensor, Air flow, Knock Sensor or AIR DTC's BARO > 74 kPa 115°C > ECT > 50°C 90 g/s > MAF > 5 g/s 90 kPa > MAP > 26 kPa 90°C > IAT > -20°C 3000 rpm > Engine speed > 400 rpm TP < 90% VS < 85 mph Fuel Level > 10%	Continuous	DTC Type B
BANK 1 FUEL TRIM SYSTEM RICH	P0172	Determines if the fuel control system is in a rich condition	The normalized weighted long term fuel trim parameter < -18% and no excessive purge vapors present	No VSS, Throttle, Purge control, Misfire, MAT, MAP, - Camel Mode Injector, EST Control, EGR Sensor, Coolant, Crank sensor, Air flow, Knock Sensor or AIR DTC's BARO > 74 Kpa 115°C > ECT > 50°C 90 g/s > MAF > 5 g/s 90 Kpa > MAP > 26 KPa 90°C > IAT > -20°C 3000 rpm > Engine speed > 400 rpm TP < 90% VS < 85 mph Excess Purge Test: 40 g/s > MAF > 12 g/s Purge Duty Cycle > 30% RPM > 800	Continuous Excess purge test up to 5 seconds	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
BANK 2 FUEL TRIM SYSTEM LEAN	P0174	Determines if the fuel control system is in a lean condition	The normalized weighted long term fuel trim parameter >+ 24 %	No VSS, Throttle, Purge control, Misfire, MAT, MAP, - Camel Mode, Injector, EST Control, EGR Sensor, Coolant, Crank sensor, Air flow, Knock Sensor or AIR DTC's BARO > 74 KPa 115°C > ECT > 50°C 90 g/s > MAF > 5 g/s 90 Kpa > MAP > 26 KPa 90°C > IAT > -20°C 3000 rpm > Engine speed > 400 rpm TP < 90% VS < 85 mph Fuel Level > 10%	Continuous	DTC Type B
BANK 2 FUEL TRIM SYSTEM RICH	P0175	Determines if the fuel control system is in a rich condition	The normalized weighted long term fuel trim parameter < -18% and no excessive purge vapors present	No VSS, Throttle, Purge control, Misfire, MAT, MAP, - Camel Mode, Injector, EST Control, EGR Sensor, Coolant, Crank sensor, Air flow, Knock Sensor or AIR DTC's BARO > 74 KPa 115°C > ECT > 50°C 90 g/s > MAF > 5 g/s 90 Kpa > MAP > 26 KPa 90°C > IAT > -20°C 3000 rpm > Engine speed > 400 rpm TP < 90% VS < 85 mph Excess Purge Test: 40 g/s > MAF > 12 g/s Purge Duty Cycle > 30% RPM > 800	Continuous Excess purge test up to 5 seconds	DTC Type B
Injector Control Circuit (ODM)	P0200	Circuit Continuity Control circuit voltage is monitored during operation. It should be low during operation and near B+ when "off".	The PCM detects that the commanded state of the driver and the actual state of the control circuit do not match.	Engine speed > 400 rpm. Ignition voltage > 6.0 volts, but < 18 volts	5 seconds Continuous.	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
THROTTLE POSITION SENSOR 2 CIRCUIT	P0220	1) TACM indicates a continuous or intermittent short or open in either the signal circuit or the TP sensor #2. OR 2) TACM indicates an invalid minimum mechanical position for the TP sensor #2. OR 3) TACM indicated reference voltage out of range.	1) Raw TP sensor signal < 0.282 V or > 4.60 V. OR 2) TP sensor minimum mechanical stop voltage < 0.282 V or > 0.813V OR 3) Vref > 0.5 V	Ignition in Run or Crank. Ignition voltage > 5.23 V. Valid TACM - PCM serial data. No TACM processor DTC.	1) Counter increments by 4 for every error, decrements by 1 for every pass; threshold is 133. Check runs every 3 ms. 2) One occurrence. Check runs at power-up. 3) Continuous. Counter increments by 1 for every error, decrements by 1 for every pass. Threshold is 10ms. For Ref direct short to ground.	DTC Type A
FUEL PUMP CONTROL CIRCUIT (ODM)	P0230	Circuit Continuity Control circuit voltage is monitored during operation. It should be high during operation and near 0 volts when "off".	The PCM detects that the commanded state of the driver and the actual state of the control circuit do not match.	Engine speed > 400 rpm. Ignition voltage > 6.0 volts, but < 18 volts	2.5 seconds Continuous.	DTC Type B
ENGINE MISFIRE DETECTED	P0300	These DTC's will determine if a multiple or a cylinder specific misfire is occurring by monitoring crankshaft velocity.	Deceleration index Vs Engine speed Vs Load with Engine position FTP Threshold 1.0% I/M Threshold 1.0% Fuel level > 10% (Does not disable if a Fuel System DTC is active.) Fuel Delay when below minimum level = 500 cycles Catalyst Damage – see Speed/Load chart	No MAF DTC's No Cam Position Sensor DTC's No Crank Position Sensor DTC's No Vehicle Speed Sensor DTC's No Engine Coolant Sensor DTC's No Throttle Position Sensor DTC's No Engine Protection DTC's Engine speed > 450 RPM but ≤ 5200 RPM System voltage > 11 volts but < 18 volts + Throttle position Delta < 15% / 100 ms - Throttle position Delta < 15% / 100 ms ECT > -7C but < 130C If start up ECT below -7C then delayed until ECT is above 21C. Not a Rough Road - ABS Not an abusive engine speed condition Abusive engine speed = 5700 RPM Abusive engine speed delay = 1250 cycles	Emission Level: 5 failed 200 revolution blocks out of 16 or four (5 of 16) 100-engine cycle test after the first 16 tests Catalyst Damaging Level: 3 failed 200 revolution blocks out of 16 and the engine speed and load is inside the FTP region, or if the engine speed and load are outside the FTP region – 1 failed 200 revolution block Continuous	DTC Type B Catalyst Damaging DTC Type A (Flashes) DTC Type B Emission

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
CRANKSHAFT POSITION SYSTEM VARIATION NOT LEARNED	P0315	Monitor for valid crankshaft error compensation factors	Engine Running Factors are considered NOT valid if the factor sum is greater than 4.001 or less than 3.9989	OBD Manufacturer Enable Counter = 0 ECT > 60°C	100 ms/test	DTC Type A
KNOCK SENSOR CIRCUIT	P0325	Check knock detector integrated circuit.	Instant noise level greater than a defined value or instantaneous knock signal greater than 254 counts for a defined time.	To run test: Engine run time > 10 sec Ignition voltage > 10 Volts	24 failed tests within 30 tests. Each test is 500 msec.	DTC Type B
KNOCK SENSOR 1 CIRCUIT LOW	P0327	Check knock sensor filtered noise level - front knock sensor	Delta filtered noise level outside of defined range. Filtered noise counts < 10	To run test: 1600 < engine rpm < 3000 Coolant temp > 60° C Engine run time > 10 sec MAP < 45 kPa. Ignition voltage > 10 Volts	24 failed tests within 30 tests. Each test is 100 msec.	DTC Type B
KNOCK SENSOR 2 CIRCUIT LOW	P0332	Check knock sensor filtered noise level - rear knock sensor	Delta filtered noise level outside of defined range. Filtered noise counts < 10	To run test: 1600 < engine rpm < 3000 Coolant temp > 60° C Engine run time > 10 sec MAP < 45 kPa. Ignition voltage > 10 Volts	24 failed tests within 30 tests. Each test is 100 msec.	DTC Type B
CRANKSHAFT POSITION SENSOR CIRCUIT	P0335	4X signal This diagnostic will detect if there is no output from the crankshaft position sensor.	No output (~0 volts) from the crankshaft position sensor.	Cam is transitioning Sensed mass airflow ≥ 2.8984 No Cam Position Sensor DTC's No Airflow DTC's PCM state = READY or CRANK	30 test failures in a 40 test sample. 100 ms/test Continuous	DTC Type B
CRANKSHAFT POSITION SENSOR CIRCUIT RANGE/PERF.	P0336	4X signal This diagnostic will detect occurrences when engine position is no longer known.	Crank position sensor signal missing for a time ≥ .5 seconds	PCM state = CRANK or RUN	50 test failures in a 3120 test sample. 50 ms/test Continuous	DTC Type B
CAMSHAFT POSITION SENSOR CIRCUIT RANGE/PERF.	P0341	Monitor for cam position state change when expected at crankshaft sync.	Evaluated at crankshaft position synchronization.	Engine Running	15 Failures out of 100 100 ms/test Continuous	DTC Type B
CAMSHAFT POSITION SENSOR CIRCUIT LOW	P0342	Monitor for continuous low state when state should be high.	Evaluated at crankshaft position synchronization	Engine Running	15 Failures out of 50 100 msec / test Continuous	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
CAMSHAFT POSITION SENSOR CIRCUIT HIGH	P0343	Monitor for continuous high state when state should be low.	Evaluated at crankshaft position synchronization	Engine Running	15 Failures out of 50 100 msec / test Continuous	DTC Type B
IGNITION CONTROL #1 CIRCUIT	P0351	Monitor EST channel A (Cylinder 1)	EST line is Stuck Low, is open, or is Stuck High. If engine speed is < 1500 RPM test failures (if applicable) and samples increment by 1 each time the diagnostic executes. If engine speed is ≥ 1500 RPM test failures (if applicable) and samples increment by 2 each time the diagnostic executes in order to report a failure faster	10 Volts < Ignition Voltage < 18 Volts	30 Failures out of 100 12.5 msec / test Continuous	DTC Type B
IGNITION CONTROL #2 CIRCUIT	P0352	Monitor EST channel B (Cylinder 2)	EST line is Stuck Low, is open, or is Stuck High. If engine speed is < 1500 RPM test failures (if applicable) and samples increment by 1 each time the diagnostic executes. If engine speed is ≥ 1500 RPM test failures (if applicable) and samples increment by 2 each time the diagnostic executes in order to report a failure faster	10 Volts < Ignition Voltage < 18 Volts	30 Failures out of 100 12.5 msec / test Continuous	DTC Type B
IGNITION CONTROL #3 CIRCUIT	P0353	Monitor EST channel C (Cylinder 3)	EST line is Stuck Low, is open, or is Stuck High. If engine speed is < 1500 RPM test failures (if applicable) and samples increment by 1 each time the diagnostic executes. If engine speed is ≥ 1500 RPM test failures (if applicable) and samples increment by 2 each time the diagnostic executes in order to report a failure faster	10 Volts < Ignition Voltage < 18 Volts	30 Failures out of 100 12.5 msec / test Continuous	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
IGNITION CONTROL #4 CIRCUIT	P0354	Monitor EST channel D (Cylinder 4)	EST line is Stuck Low, is open, or is Stuck High. If engine speed is < 1500 RPM test failures (if applicable) and samples increment by 1 each time the diagnostic executes. If engine speed is ≥ 1500 RPM test failures (if applicable) and samples increment by 2 each time the diagnostic executes in order to report a failure faster	10 Volts < Ignition Voltage < 18 Volts	30 Failures out of 100 12.5 msec / test Continuous	DTC Type B
IGNITION CONTROL #5 CIRCUIT	P0355	Monitor EST channel E (Cylinder 5)	EST line is Stuck Low, is open, or is Stuck High. If engine speed is < 1500 RPM test failures (if applicable) and samples increment by 1 each time the diagnostic executes. If engine speed is ≥ 1500 RPM test failures (if applicable) and samples increment by 2 each time the diagnostic executes in order to report a failure faster	10 Volts < Ignition Voltage < 18 Volts	30 Failures out of 100 12.5 msec / test Continuous	DTC Type B
IGNITION CONTROL #6 CIRCUIT	P0356	Monitor EST channel F (Cylinder 6)	EST line is Stuck Low, is open, or is Stuck High. If engine speed is < 1500 RPM test failures (if applicable) and samples increment by 1 each time the diagnostic executes. If engine speed is ≥ 1500 RPM test failures (if applicable) and samples increment by 2 each time the diagnostic executes in order to report a failure faster	10 Volts < Ignition Voltage < 18 Volts	30 Failures out of 100 12.5 msec / test Continuous	DTC Type B
IGNITION CONTROL #7 CIRCUIT	P0357	Monitor EST channel G (Cylinder 7)	EST line is Stuck Low, is open, or is Stuck High. If engine speed is < 1500 RPM test failures (if applicable) and samples increment by 1 each time the diagnostic executes. If engine speed is ≥ 1500 RPM test failures (if applicable) and samples increment by 2 each time the diagnostic executes in order to report a failure faster	10 Volts < Ignition Voltage < 18 Volts	30 Failures out of 100 12.5 msec / test Continuous	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
IGNITION CONTROL #8 CIRCUIT	P0358	Monitor EST channel H (Cylinder 8)	EST line is Stuck Low, is open, or is Stuck High. If engine speed is < 1500 RPM test failures (if applicable) and samples increment by 1 each time the diagnostic executes. If engine speed is ≥ 1500 RPM test failures (if applicable) and samples increment by 2 each time the diagnostic executes in order to report a failure faster	10 Volts < Ignition Voltage < 18 Volts	30 Failures out of 100 12.5 msec / test Continuous	DTC Type B
EGR FLOW LOW	P0401	This DTC detects if EGR flow is insufficient.	Actual delta MAP change is less than a table lookup delta MAP change as a function of an EGR valve commanded position during a decel.	No TP DTCs set No MAP DTCs set No VSS DTCs set No IAT DTCs set No EGR Pintle DTCs set No System voltage DTCs set ECT between 60 ° C and 121 ° C 3° C < IAT < 100 ° C System voltage between 11 volts and 18 volts Vehicle speed between 25 MPH and 70 MPH RPM between 725 RPM and 1700 RPM IAC not moving more than 2 steps BARO > 74 kpa Altitude compensated High 42 kpa, Low 18 kpa MAP not changing more than .5 kpa Maximum Negative RPM change < 300 RPM TP < 1.1% VSS change < 4 MPH Not in DFCO	1.2 seconds Once per trip.	DTC Type A
EGR VALVE OPEN PINTLE POSITION ERROR	P0404	This DTC detects if the EGR desired vs actual pintle position error is too large.	The desired vs actual pintle position error > 12%.	System voltage 11 volts or greater. EGR flow test not in progress. Desired EGR position >0%.	Continuous every 100 ms.	DTC Type B
EGR VALVE POSITION SENSOR CIRCUIT LOW VOLTAGE	P0405	This DTC detects if the pintle position feedback circuit is open or shorted to ground.	Pintle Position < 3.1% (8 A/D counts) for 5 seconds	System voltage 11 volts or greater.	0.10 seconds. Continuous every 100 ms.	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
CATALYTIC CONVERTER LOW OXYGEN STORAGE	P0420	Oxygen Storage.	<p><u>OSC Time Difference</u> ≥ 0.194 sec</p> <p>OSC Time Difference = OSC Worst Pass Thresh – OSC Compensation Factor * (Post Cat O2 Resp Time - Pre Cat O2 Resp Time)</p> <p><u>OSC Worst Pass Thresh</u> = 2.41 sec</p>	<p><u>Trip Enable Criteria</u> No VSS, EGR Control, Throttle, Purge control, Purge Circuit, Oxygen sensor, Misfire, MAT, MAP, Camel Mode, Injector, EST Control, EGR Sensor, Coolant, Crank sensor, Cam sensor, Air flow, AIR, IAC, or Fuel trim DTC's failing</p> <p><u>Valid Idle Period Criteria</u> Engine Speed ≥ 850 rpm for minimum of 39 sec since end of last idle period</p> <p><u>Test Enable Conditions</u> Predicted Catalyst Temperature $\geq 400^{\circ}\text{C}$ Min engine runtime for stable BLM & PLM ≥ 600 sec Barometric Pressure ≥ 74 kPa $-15 \leq \text{IAT} \leq 85^{\circ}\text{C}$ $70^{\circ}\text{C} \leq \text{ECT} \leq 120^{\circ}\text{C}$ $0 < \text{Idle Period} \leq 60$ sec Tests Attempted this trip ≤ 6 Tests Attempted this idle period < 1 $-100 \text{ rpm} \leq (\text{Engine Speed} - \text{Desired Speed}) \leq +200 \text{ rpm}$</p> <p><u>Rapid Step Response Enable Criteria</u> OSC Time Difference Step ≥ 0.635 sec OSC Time Difference ≥ 0.000 sec</p> <p>All S/B and B/B applications use material burn-off delay algorithm. Diagnostic will not enable until the next ignition cycle after the following has been met, predicted catalyst temperature $\geq 400^{\circ}\text{C}$ for 1 hour (non-continuously). (Note that all other enable criteria must be met on the next ignition cycle for the test to run on that ignition cycle)</p>	<p>1 test attempted per valid idle period</p> <p>Minimum of 1 test per trip.</p> <p>Maximum of 6 tests per trip.</p> <p>Maximum of 6 trips to detect failure when Rapid Step Response is enabled</p> <p>frequency: 12.5 ms continuous</p>	DTC Type A

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
CATALYTIC CONVERTER LOW OXYGEN STORAGE	P0430	Oxygen Storage.	<p><u>OSC Time Difference</u> ≥ 0.195 sec</p> <p>OSC Time Difference = OSC Worst Pass Thresh – OSC Compensation Factor * (Post Cat O2 Resp Time - Pre Cat O2 Resp Time)</p> <p><u>OSC Worst Pass Thresh</u> = 2.55 sec</p>	<p><u>Trip Enable Criteria</u> No VSS, EGR Control, Throttle, Purge control, Purge Circuit, Oxygen sensor, Misfire, MAT, MAP, Camel Mode, Injector, EST Control, EGR Sensor, Coolant, Crank sensor, Cam sensor, Air flow, AIR, IAC, or Fuel trim DTC's failing</p> <p><u>Valid Idle Period Criteria</u> Engine Speed ≥ 850 rpm for minimum of 39 sec since end of last idle period.</p> <p><u>Test Enable Conditions</u> Predicted Catalyst Temperature $\geq 440^{\circ}\text{C}$ Min engine runtime for stable BLM & PLM ≥ 600 sec Barometric Pressure ≥ 74 kPa $-15 \leq \text{IAT} \leq 85^{\circ}\text{C}$ $70^{\circ}\text{C} \leq \text{ECT} \leq 120^{\circ}\text{C}$ $0 < \text{Idle Period} \leq 60$ sec Tests Attempted this trip ≤ 6 Tests Attempted this idle period < 1 $-100 \text{ rpm} \leq (\text{Engine Speed} - \text{Desired Speed}) \leq +200 \text{ rpm}$</p> <p><u>Rapid Step Response Enable Criteria</u> OSC Time Difference Step ≥ 0.636 sec OSC Time Difference ≥ 0.000 sec</p> <p>All S/B and B/B applications use material burn-off delay algorithm. Diagnostic will not enable until the next ignition cycle after the following has been met, predicted catalyst temperature $\geq 400^{\circ}\text{C}$ for 1 hour (non-continuously). (Note that all other enable criteria must be met on the next ignition cycle for the test to run on that ignition cycle)</p>	<p>1 test attempted per valid idle period</p> <p>Minimum of 1 test per trip.</p> <p>Maximum of 6 tests per trip.</p> <p>Maximum of 6 trips to detect failure when Rapid Step Response is enabled</p> <p>frequency: 12.5 ms continuous</p>	DTC Type A

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
EVAP SYSTEM SMALL LEAK DETECTED	P0442	<p>This DTC will detect a small leak (≥ 0.020) in the EVAP system between the fuel fill cap and the purge solenoid.</p> <p>The DTC will also be set if the fuel tank vacuum sensor is out of range when it tries to re-zero prior to test phase-1 or test phase-2.</p> <p>The DTC will also be set if the refueling rationality test is failed.</p>	<p><u>SMALL LEAK TEST FAIL:</u></p> <p>Engine Off Natural Vacuum The total pressure change achieved during the test is normalized against a target value that is based upon fuel level and ambient temperature. (1.4" water). The normalized value is entered into EWMA (with 0= perfect pass and 1=perfect fail). Once EWMA exceeds the fail threshold, the DTC light is illuminated. The DTC light can be turned off if the EWMA falls below the pass threshold for 3 trips.</p> <p>Fail threshold = 0.7087 Re-Pass threshold = 0.4823</p> <p>Vacuum sensor out of range <1.3volts or >1.7 volts. Vacuum sensor out of range is reported as a perfect fail to the EWMA.</p>	<p><u>TEST ENABLE :</u> VS Sensor DTC's not active</p> <p>Coolant Sensor DTC's not active IAT Sensor DTC's not active EVAP Vac Sensor Performance DTC not active. Evap CCP stuck open DTC not active. EVAP large leak DTC not active. Ignition off timer DTC not active. Fuel Level >15.0% but < 85.0%</p> <p>Valid Cold Start ECT > 3.75°C but < 30° C IAT > 3.75°C but < 30° C Cold Temp $\Delta^{\circ}\text{C}(\text{ECT}-\text{IAT}) < 8.25^{\circ}\text{C}$ if ECT > IAT BARO > 74.0 kPa Estimated ambient temperature at end of drive > 2°C but < 32°C. Drive time ≥ 10 minutes. Drive length ≥ 3 miles. Coolant $\geq 70^{\circ}\text{C}$. No fuel filling (fuel level increment $\geq 10\%$).</p>	<p>Once per cold start, during hot soak (up to 2500 sec.). Time since last complete test ≥ 17 hours if passing, or ≥ 10 hours if failing. No more than 2 attempts per day.</p>	DTC Type A EWMA
EVAP CANISTER PURGE SOLENOID VALVE CIRCUIT (ODM)	P0443	<p>Circuit Continuity Control circuit voltage is monitored during operation. It should be low during operation and near B+ when "off".</p>	<p>The PCM detects that the commanded state of the driver and the actual state of the control circuit do not match.</p>	<p>Engine speed > 400 rpm. Ignition voltage > 10.0 volts, but < 18 volts</p>	<p>5 seconds. continuous.</p>	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
EVAP CANISTER VENT BLOCKED	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filter, vent hose or canister.	<p><u>EXCESS VACUUM TEST - STAGE I:</u></p> <p>Vent solenoid commanded OPEN Fuel Tank Vacuum \geq 7 in. H₂O for 2 seconds(monitored during initial purge ramp) OR <u>EXCESS VACUUM TEST - STAGE II:</u></p> <p>Vent solenoid commanded OPEN during normal purge. Fuel Tank Vacuum \geq 9.0 in. H₂O for a time \geq 23 seconds. OR Vented Vacuum \leq -2.5 in. H₂O or Vented Vacuum \Rightarrow 5.0 in H₂O For 3 seconds after cold-start key-up.</p>	<p><u>TEST ENABLE :</u> MAP DTC's not active Volt-DTC's not active TP Sensor DTC's not active VS Sensor DTC's not active Coolant Sensor DTC's not active O2 Sensor DTC's not active IAT Sensor DTC's not active Fuel Level >15.0% but < 85.0% PLM > .89 System Voltage > 10V but < 18V <u>COLD START TEST:</u> ECT > 3.75°C but < 30° C IAT > 3.75°C but < 30° C Cold Temperature Δ (ECT - IAT): ° < 8.25 °C if ECT > IAT BARO > 75.0 kPa</p> <p><u>FUEL SLOSH TEST:</u> Tank Vacuum $\Delta \leq$ value and Fuel Level $\Delta \leq$ value based on fuel level <u>WEAK VACUUM TEST -Stage I:</u> Tank Vacuum \geq 11 in. H₂O within a value 40 integral seconds.</p>	<p><u>EXCESS VACUUM TEST - STAGE II:</u> 180 seconds</p> <p>Once per cold start at:</p> <ul style="list-style-type: none"> • Power-up • Excess Vac. Stage I • Excess Vac. Stage II <p>Test must complete within 360, 420, 460, 525, or 600 seconds from when purge is enabled, Depending on application</p>	DTC Type A
EVAP VENT SOLENOID CONTROL CIRCUIT (ODM)	P0449	Circuit Continuity Control circuit voltage is monitored during operation. It should be low during operation and near B+ when "off".	The PCM detects that the commanded state of the driver and the actual state of the control circuit do not match.	Engine speed > 400 rpm. Ignition voltage > 10.0 volts, but < 18 volts	5 seconds Continuous.	DTC Type B
EVAP SYSTEM PRESSURE LOW	P0452	This DTC will detect a vacuum sensor stuck low	tank vacuum raw voltage < 0.1 volt for 5 seconds	<u>runs continuously after a 1 second delay for sensor warm-up</u>		DTC Type B
EVAP SYSTEM PRESSURE HIGH	P0453	This DTC will detect a vacuum sensor stuck hi	tank vacuum raw voltage >4.90 volt for 5 seconds	<u>runs continuously after a 1 second delay for sensor warm-up</u>		DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
EVAP. Emission Control System Malfunction	P0455	This DTC will detect a weak vacuum condition (large leak or restriction) in the EVAP. system.	<u>WEAK VACUUM TEST- STAGE I</u> <u>(Cold Test):</u> Tank Vacuum < 9 or 13 in. H ₂ O for a time greater than (30-80 integral seconds) depending on application. <u>WEAK VACUUM TEST- STAGE II</u> <u>(Warm Test):</u> Stage I test failed previous trip and this trip. Tank Vac. < 11 in. H ₂ O	<u>TEST ENABLE :</u> MAP DTC's not active Volt-DTC's not active TP Sensor DTC's not active VS Sensor DTC's not active O2 Sensor DTC's not active Coolant Sensor DTC's not active IAT Sensor DTC's not active Fuel Level >15.0% but < 85.0% Power-up Vacuum Test Fail = False PLM > .89 System Voltage > 10V but < 18V <u>COLD START TEST:</u> ECT > 3.75°C but < 30° C IAT > 3.75°C but < 30° C Cold Temperature Δ (ECT - IAT): ◦ < 8.25 °C if ECT > IAT BARO > 75.0 kPa <u>FUEL SLOSH TEST:</u> Tank Vacuum Δ ≤ value and Fuel Level Δ ≤ value based on fuel level.	<u>WEAK VACUUM TEST- STAGE I</u> <u>(Cold Test):</u> Fault present for an integral time ≥ 50, or 70sec. depending on application. Test must complete within 360, 420, 460, 525, or 600 seconds from when purge is enabled, Depending on application <u>WEAK VACUUM TEST- STAGE II (Warm Test):</u> Fault present for a time ≥ 1400 sec. Once per cold start	DTC Type A (Behaves as a Type B)
Fuel Level No Change, Stuck in Range	P0461	This DTC will detect a fuel sender stuck in range	IF Delta Fuel Volume change less than 3 liters over a accumulated 105 miles. OR IF Transfer pump ON and at Idle delay =20 seconds then IF timer > 120 sec. AND Primary tank not increase by 4 liters. AND Secondary did Decrease > 4 liters OR If Primary is FULL and Secondary is EMPTY for > 275 miles.	runs continuously		DTC Type C No Light
Fuel Level Stuck Low	P0462	This DTC will detect a fuel sender stuck out of range low	Fuel level A/D counts less than 20 A/D counts for 100 seconds	runs continuously		DTC Type C No Light
Fuel Level Stuck High	P0463	This DTC will detect a fuel sender stuck out of	Fuel level A/D counts more than 150 A/D counts for 100 seconds	runs continuously		DTC Type C No Light

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
EVAP SYSTEM FLOW DURING NON-PURGE	P0496	This DTC will determine if the purge solenoid is leaking.	<p><u>PURGE VALVE LEAK TEST:</u> Purge Valve closed TP > 0% but < 99.6% Vacuum ≥ 10 KPa Tank Vacuum ≥ 12 in. H₂O for 2 sec within ≤ 37.5 seconds after 30 second delay.</p>	<p><u>TEST ENABLE :</u> MAP DTC's not active Volt-DTC's not active TP Sensor DTC's not active VS Sensor DTC's not active O2 Sensor DTC's not active Coolant Sensor DTC's not active IAT Sensor DTC's not active Fuel Level >15.0% but < 85.0% PLM > .89 System Voltage > 10V but < 18V</p> <p><u>COLD START TEST:</u> ECT > 3.75°C but < 30° C IAT > 3.75°C but < 30° C Cold Temperature Δ (ECT - IAT): ° < 8.25 °C if ECT > IAT BARO >75.0 kPa</p> <p><u>FUEL SLOSH TEST:</u> Tank Vacuum Δ ≤ value and Fuel Level Δ ≤ value based on fuel level and application.</p> <p><u>EXCESS VACUUM TEST -STAGE I :</u> Vent solenoid commanded OPEN Fuel Tank Vacuum < 7 in. H₂O</p> <p><u>WEAK VACUUM TEST -Stage I :</u> Throttle position < 75% Vehicle speed < 65 mph Tank Vacuum ≥ 11 in. H₂O within a value 40 integral seconds...</p>	<p><u>PURGE VALVE LEAK TEST:</u> 180 seconds Max. Once per cold start</p>	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
VEHICLE SPEED SENSOR SYSTEM PERFORMANCE (MANUAL TRANS)	P0500	This DTC detects a missing signal from the vehicle speed sensor in a manual transmission vehicle.	Vehicle speed = 0 when enable conditions met	Manual VSS diagnostic enabled No MAP DTC's set No TPS DTC's set No ECT DTC's set No idle system DTC's set No IAC valve DTC's set Coolant ≥ 35 °C Engine speed > 2500 rpm 10 % < throttle position < 100 % A/C off: 50 kpa < MAP < 104 kpa A/C on: 50 kpa < MAP < 104 kpa Above conditions met > 2 seconds to enable diagnostic	90 test failures in a 100 test sample 100 ms/test Continuous	DTC Type B
IDLE SYSTEM - LOW ENGINE SPEED	P0506	Determines if a low idle is a result of an engine mechanical problem. Low RPM is 100 RPM below desired	Idle > 100 RPM low from desired	Passive: No MAF, MAP, IAT, ECT, TP, Injector, Fuel System, Misfire, EGR, VSS or Purge DTC Engine Run > 60 sec. ECT ≥ 60 °C BARO > 65 kPa IGN. voltage > 9 & < 18 volts IAT > -10 °C TP < 1% VS ≤ 1 MPH Time > 5 seconds to fail. > 8 seconds to pass	Passive: Must be outside the fail criteria continuously for 5 seconds. Must be within pass criteria for 8 seconds continuously.	DTC Type B
IDLE SYSTEM - HIGH ENGINE SPEED	P0507	Determines if a high idle is a result of an engine mechanical problem. High RPM is 200 RPM above desired	Passive: Idle > 200 RPM high from desired	Passive: No MAF, MAP, IAT, ECT, TP, Injector, Fuel System, Misfire, EGR, VSS or Purge DTC Engine Run > 60 sec. ECT ≥ 60 °C BARO > 65 kPa IGN. voltage > 9 & < 18 volts IAT > -10 °C TP < 1% VS ≤ 1 MPH Time > 5 seconds to fail. > 8 seconds to pass	Passive: Must be outside the fail criteria continuously for 5 seconds. Must be within pass criteria for 8 seconds continuously.	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
PCM - FLASH EEPROM CHECKSUM ERROR	P0601	Indicates that PCM is unable to correctly read data from the flash memory.	Calculated checksum does not match expected checksum for the program.	Ignition in Run or Crank.	One occurrence. Check is performed at power-up and every 60 seconds thereafter.	DTC Type A
PCM - PROGRAMMING ERROR	P0602	Indicates that the PCM is not flashed.	PCM not flashed.	Ignition on.	1 test failure 100 ms after PCM powered-up	DTC Type A
PCM RAM FAILURE	P0604	Indicates that PCM is unable to correctly write and read data to and from RAM	Data read does not match data written	Ignition in Run or Crank	One occurrence. Check is performed at power-up and every 60 seconds thereafter.	DTC Type A
PCM INTEGRITY	P0606	Indicates that the PCM has detected an ETC internal processor integrity fault	ETC has process sequencing error, dual path consistency error, clock error, or computer is not operating properly	Ignition in Run/Crank or during key-off	Fault sets within 200 msec Runs every 18.75 msec	DTC Type A
5 VOLT REFERENCE A CIRCUIT	P0641	Determines if the supply voltage for the 5 volt reference is within an acceptable limit.	Compares the ratio of the 5 volt reference circuit voltage to the 5 volt supply voltage.	5 volt reference circuit voltage differs from 5 volt supply voltage by plus or minus approximately .01 volt. PCM is powered up	Condition present > 2 seconds Continuous.	DTC Type B
Malfunction Indicator Lamp Control Circuit MALF (ODM)	P0650	Control circuit voltage is monitored during operation. It should be low during operation and near B+ when "off".	The PCM detects that the commanded state of the driver and the actual state of the control circuit do not match.	Engine speed greater than 400 rpm. Ignition voltage > 6.0 volts, but < 18 volts	5 seconds. Continuous.	DTC Type B No MIL
5 VOLT REFERENCE B CIRCUIT	P0651	Determines if the supply voltage for the 5 volt reference is within an acceptable limit	Compares the ratio of the 5 volt reference circuit voltage to the 5 volt supply voltage.	5 volt reference circuit voltage differs from 5 volt supply voltage by plus or minus approximately .01 volt. PCM is powered up	Condition present > 2 seconds Continuous.	DTC Type B

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
TCM MIL REQUEST	P0700	Monitors the TCM MIL request line to determine when the TCM has detected a MIL illuminating fault.	The TCM MIL request line is active for more than 1 second.	Ignition on time > 7 seconds Ignition voltage > 11V	Continuous 100 msec	DTC Type A
CLUTCH SWITCH CIRCUIT	*P0704	Clutch switch state is monitored during vehicle operation.	The PCM detects that a clutch switch state transition has not occurred when the vehicle speed has gone from 0 MPH above a threshold value and back to 0 MPH.	No VSS codes present VSS > 24 MPH	7 test failures in a 8 test sample size 100ms Continuous	DTC Type C (Manual Only)
PRNDL SWITCH	P0706	Check for PRNDL switch malfunction	Start run is achieved if reverse or drive is indicated; or if in park or neutral if: TPS > 10% Torque > 75 ft-lbs VSS > 5 mph Fail counts: 10/15 samples	Ignition voltage >6 and < 18 V Gear > 1 Engine runtime > 10 seconds	Stuck in drive immediately upon start Stuck in PN 1 second Continuous Monitor	DTC Type C
TCM MIL REQUEST CONTROL CIRCUIT	P0802	Integrity check for the TCM MIL request line	TCM MIL request line is never active during integrity check.	Ignition on time < 7 seconds Ignition voltage > 11 V	Ignition on time < 7 seconds 100 msec	DTC Type A
IAT Sensor Circuit Intermittent High Voltage	P1111	This DTC determines if the IAT sensor is shorted high intermittently by checking for an IAT sensor output voltage above a threshold	IAT Voltage > 4.95 V	No MAF DTC's No IAT Sensor High DTC's ECT >= 0° C VSS < 7 mph MAF < 15 g/s Engine Run Time > 100 seconds	55 test failures in a 1000 test sample 1 sample/sec	DTC Type C
IAT Sensor Circuit Intermittent Low Voltage	P1112	This DTC determines if the IAT sensor is shorted low intermittently by checking for an IAT sensor output voltage below a threshold	IAT Voltage < 0.244 V	No IAT Sensor Low DTC's ECT < 135° C VSS >= 25 mph Engine Run Time > 30 seconds	55 test failures in a 1000 test sample 1 sample/sec	DTC Type C

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
ENGINE COOLANT TEMP SENSOR CIRCUIT INTERMITTENT LOW (HIGH TEMP)	P1114	This DTC detects a continuous short to ground in the ECT signal circuit or the ECT sensor.	<u>Low Resistance Pull-up</u> Raw ECT < .234 Volts <u>High Resistance Pull-up</u> Raw ECT < .035 Volts	Engine run time > 10 seconds Or Engine run time < 10 seconds IAT < 50° C	55 test failures in a 1000 test sample. 1 sample/sec	DTC Type C
ENGINE COOLANT TEMP SENSOR CIRCUIT INTERMITTENT HIGH (LOW TEMP)	P1115	Circuit Continuity This DTC detects a continuous short to high or open in the ECT signal circuit or the ECT sensor.	<u>Low Resistance Pull-up</u> Raw IAT > 4.93 Volts <u>High Resistance pull-up</u> Raw IAT > 4.95 Volts	Engine run time > 60 seconds Or Engine run time < 60 seconds IAT > 0° C	55 test failures in a 1000 test sample. 1 sample/sec	DTC Type C
THROTTLE POSITION SENSOR CIRCUIT INTERMITTENT HIGH	*P1121	This DTC detects a intermittent short to high or open in either the signal circuit or the TP sensor	TPS (V) > 4.89 v (250 counts)	No 5V Ref. DTC's	101 test failures in a 2000 test sample size. 1 sample/100 ms	DTC Type C For use on vehicles without ETC
THROTTLE POSITION SENSOR CIRCUIT INTERMITTENT LOW	*P1122	This DTC detects a continuous short to low or open in either the signal circuit or the TP sensor	TP sensor signal voltage < .149 volts (7.6 counts)	No 5v ref DTC's	101 test failures in a 2000 test sample size. 1 sample/100ms	DTC Type C For use on vehicles without ETC
ACCELERATOR PEDAL POSITION SYSTEM	P1125	PCM determines a limp home mode of operation due to multiple accelerator pedal sensor faults.	This DTC is set when: 1) 2 or more APP sensors are out of range, OR 2) all 3 APP sensors disagree, OR 3) one APP sensor is out of range AND the other 2 APP sensors disagree.	Ignition in Run or Crank. Ignition voltage > 5.23 V. Valid TACM - PCM serial data. No TACM processor DTC.	One occurrence. Check runs every 18.75 ms.	DTC Type A

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
HO2S SYSTEM - TOO FEW HO2S R/L AND L/R SWITCHES (BANK 1, SENSOR 1)	P1133	The DTC determines if the HO2S sensor is functioning properly by monitoring the number of L/R and R/L switches.	The oxygen sensor signal transitions from below 250 mV to above 600 mV or from above 600 mV to below 250 mV without reversal. Number of switches: L/R switches < 1 R/L switches < 1	Closed Loop Fuel Control Engine runtime > 160 sec 1000 < RPM < 3000 29 < Air Flow < 55 g/s. TPS > 5% 10 V < System Voltage < 18 V Fuel > 10% ECT > 60 °C CCP > 0 775 °C < Predicted Oxygen Sensor Temp < 850 °C Above conditions met for 1 sec DTC's P0131, P0132, P0134 and P0135 not set No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active.	100 sec Once per trip.	DTC Type B
HO2S SYSTEM - TOO FEW HO2S R/L AND L/R SWITCHES (BANK 2, SENSOR 1)	P1153	The DTC determines if the HO2S sensor is functioning properly by monitoring the number of L/R and R/L switches.	The oxygen sensor signal transitions from below 250 mV to above 600 mV or from above 600 mV to below 250 mV without reversal. Number of switches: L/R switches < 1 R/L switches < 1	Closed Loop Fuel Control Engine runtime > 160 sec 1000 < RPM < 3000 29 < Air Flow < 55 g/s. TPS > 5% 10 V < System Voltage < 18 V Fuel > 10% ECT > 60 °C CCP > 0 775 °C < Predicted Oxygen Sensor Temp < 850 °C Above conditions met for 1 sec DTC's P0151, P0152, P0154 and P0155 not set No AIR, EGR, Throttle, MAT, Injector, Coolant, Air Flow, Purge Control, Misfire, MAP, Engine Protect or Fuel Composition faults active.	100 sec Once per trip.	DTC Type B
ENGINE PROTECTION MODE ACTIVE	P1258	Monitor for engine protection mode active.	Coolant temperature \geq 129.4°C for more than 10 seconds.	No coolant sensor DTC's.	Set immediately upon engine protection mode active.	DTC Type A
ABS Rough Road Malfunction	P1380	This diagnostic detects if the ABS controller is indicating a fault. When this occurs, misfire will STILL run.	ABS controller sends a message to PCM indicating that a failure has occurred in the ABS module	none	450 failures out of 500 samples	DTC Type C (DTC sets when a P0300 is active)

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
ABS System Rough Road Detection Communication Fault	P1381	This diagnostic detects if the rough road information is no longer being received from the ABS module. When this occurs, misfire will STILL run.	Serial data messages are lost	none	450 failures out of 500 samples	DTC Type C (DTC sets when a P0300 is active)
EGR VALVE CIRCUIT PERFORMANCE Actual Position Commanded Position.	P1404	This DTC determines if the EGR valve pintle is stuck open when the valve is commanded closed.	Pintle Position > 10 A/D counts from learned closed position for 10 seconds for 3 subroutines	System voltage 11 volts or greater. EGR valve strokes to 100% duty cycle between subroutines. Enable parameters for stroke: 79°C < ECT < 121°C IAT < 100°C Desired EGR > 20 %	3 failures for 10 seconds each test (with 100% pintle movement for .7 seconds between tests). Continuous every 100 ms.	DTC Type B
TAC SYSTEM MAF PERFORMANCE	P1514	Indicates that measured engine airflow does not match estimated engine airflow as established by the TPS.	MAP based airflow - estimated airflow > 150 mg/cyl AND MAF based airflow - estimated airflow > 150 mg/cyl	Engine running = true. Ignition on > 1 sec. RPM > 500. No Throttle Actuation DTC's. No PCM-TACM Serial Data DTC. Both TPS Circuit DTC's are not set. No PCM Processor DTC's No TACM Processor DTC	Both counters are incremented by 2 for every error and decrement by 1 for every pass; both thresholds are 20; both counters must exceed threshold to set DTC. Check runs every 18.75 ms.	DTC Type A

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
COMMAND vs ACTUAL THROTTLE PERF. (PCM)	P1515	Indicates that the PCM has detected a throttle positioning error	ABS (throttle error) > 5%. [Throttle error = Measured throttle position - modeled throttle position]	Ignition in Run or Crank TACM determines PCM Desired Throttle Position is valid. Not in battery saver mode. No Airflow Actuation DTC. (Engine Running = true) OR (Ignition Voltage > 8.5 volts). No Throttle Actuation DTC. No PCM-TACM Serial Data DTC. Both TPS Circuit DTC's are not set. No PCM Processor DTC's. No TACM Processor DTC.	High counter increments by 2 for every throttle error > 5%; decrements by 1 if %<t.e.<5%; decrements by 5 if -5%<t.e.<0%; clears if t.e. < -5%. Check runs every 18.75 ms with TACM - PCM valid message received. Low counter increments by 2 for every throttle error < -5%; decrements by 1 if -5%<t.e.<0%; decrements by 5 if 0%<t.e.<5%; clears if t.e. > 5%. Check runs every 18.75 ms with TACM - PCM valid message received.	DTC Type A

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
COMMAND vs ACTUAL THROTTLE PERF. (TAC MODULE)	P1516	Indicates that the TAC Module has detected a throttle positioning error OR Either Processor cannot determine throttle positioning OR Both TP Sensors are invalid	ABS (throttle error): a) ≥ 2 degrees for >200 ms with no change in error sign. OR b) ≥ 2 degrees for >500 ms for throttle command changes ≥ 2 degrees. OR c) ≥ 5 degrees for >200 ms for throttle command changes ≥ 5 degrees. OR d) ≥ 5 degrees for > 300 ms with no change in error sign. OR 2) PCM processor DTC's. OR 3) TACM processor DTC. OR 4) both TPS Circuit DTC's are set. OR 5) PCM-TACM Serial Data DTC w/ any APP Sensor DTC or TP Sensor DTC. [Throttle error = Measured throttle position - commanded throttle position]	Ignition in Run or Crank. Ignition voltage > 5.23 V. Valid TACM - PCM serial data. Not in battery saver mode.	One occurrence. Check runs every 3 ms.	DTC Type A

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
PCM TO TAC MODULE SERIAL DATA CIRCUIT	P1518	Indicates that the serial data line between the PCM and TACM has intermittently or continuously failed.	<p>PCM: No message for 18.75 ms. Corrupted data in the message. Invalid message protocol. PCM processor DTC's. TACM processor DTC.</p> <p>TAC Module: No message for 25 ms. Corrupted data in the message. Invalid message protocol. PCM processor DTC's. TACM processor DTC. Throttle Authority Limit Exceeded.</p>	(Ignition in Run or Crank) AND engine not in crank state. Time since power-up > 0. Ignition in Run or Crank. Ignition voltage > 5.23 V. Valid TACM - PCM serial data.	<p>PCM and TACM continuous No valid message received for 500 ms.</p> <p>PCM Intermittent: Invalid or missing message increments counter by 10; valid message received decrements counter by 1; threshold is 254.</p> <p>TACM Intermittent: Invalid or missing message increments counter by 6; valid message received decrements counter by 1; threshold is 200.</p> <p>Check for invalid messages runs every 18.75 ms. Check for missing messages runs every 25 ms.</p> <p>Throttle Authority Limit Exceeded > 300 ms</p>	DTC Type A
SOAK TIMER (IGNITION OFF TIMER)	P1683	Monitor soak timer for proper increments in positive time at correct rate	<p>1) Initial soak timer value is not between 0 to 5 seconds</p> <p>2) After initial 2 second delay, the soak timer does not increase by 1 second increments</p> <p>3) Each 1 second increment of the soak timer is not within 1.0 +/- 0.3 seconds</p> <p>4) The soak timer value decrements by any amount</p>	PCM is powered down DTC sets on next key cycle if failure detected	Every key down	DTC Type B
Fuel Level No Change, Stuck in Range Secondary Tank	*P2066	This DTC will detect a fuel sender stuck in range	IF Delta Fuel Volume change less than 3 liters over a accumulated 65 miles. OR IF Transfer pump ON and at Idle delay =20 seconds then IF timer > 120 sec. AND Secondary tank not decrease by 4 liters AND Primary DID Increase > 4 liters. OR If Primary is FULL and Secondary is EMPTY for > 275 miles.	Fuel level greater than 30 liters		<p>DTC Type C No Light</p> <p>For use on vehicles with dual fuel tank</p>

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
Fuel Level Stuck Low Secondary Tank	*P2067	This DTC will detect a fuel sender stuck out of range low	Fuel level A/D counts less than 20 A/D counts for 100 seconds	runs continuously		DTC Type C No Light For use on vehicles with duel fuel tank
Fuel Level Stuck High Secondary Tank	*P2068	This DTC will detect a fuel sender stuck out of range high	Fuel level A/D counts more than 150 A/D counts for 100 seconds	runs continuously		DTC Type C No Light For use on vehicles with duel fuel tank
TAC MODULE PROCESSOR	P2108	Indicates that TAC Module is unable to correctly read data from the flash memory. Indicates that TAC Module is unable to correctly write and read data to and from RAM. Indicates that the TAC Module has detected an internal processor integrity fault.	1) Power-up test fails to read/write data OR 2) Max. allowed Running Resets exceeded OR 3) ROM checksum does not match expected checksum OR 4) RAM data read does not match data written OR 5) Failure of Interrupt process flag to match expected value. OR 6) Program is not executed in the proper order OR 7) Primary and Redundant RAM variables disagree OR 8) Primary and Redundant Indicated Pedal Position calculation difference = 0.0%. OR 9) Math/Logic test fails to equate to a predetermined value. OR 10) Internal Register data read does not match data written. OR 11) Internal Timer fails to increment OR 12) Watchdog Timer fails to increment OR 13) Failure of Processor Stack pointer to zero at Main Loop.	Ignition in Run or Crank. Ignition voltage > 5.23 V. Valid TACM - PCM serial data.	1) One occurrence Check runs at Reset initialization 2) 10 occurrences during ignition cycle Check runs at Reset initialization 3) One occurrence. Check runs at power up and every 60 seconds thereafter. 4) One occurrence. Check runs at power up and every 800 milliseconds thereafter 5) - 13) One occurrence. Check runs every 3 milliseconds. Second Watchdog timer runs in 10 millisecond loop.	DTC Type A

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
APP SENSOR 1 CIRCUIT	P2120	1) TACM indicates a continuous or intermittent short or open in either the signal circuit or the APP sensor #1. OR 2) TACM indicates an invalid minimum mechanical position for the APP sensor #1. OR 3) TACM indicated reference voltage out of range.	1) Raw APP sensor signal < 0.235 V or > 4.487 V. OR 2) APP sensor minimum mechanical stop voltage < 0.235 V. OR 3) Vref out of range < 4.54 V or > 5.21 V.	Ignition in Run or Crank. Ignition voltage > 5.23 V. Valid TACM - PCM serial data. No TACM processor DTC.	1) & 2) Counter increments by 4 for every error, decrements by 1 for every pass; threshold is 133. Check runs every 3 ms.	DTC Type C
APP SENSOR 1 PERFORMANCE	P2121	1) TACM indicates a continuous or intermittent correlation fault between APP sensors #1 and #2 AND #1 and #3. OR 2) TACM indicates an invalid minimum mechanical position correlation between APP sensor #1 and #2 AND #1 and #3. OR 3) PPS1 signal short to PPS2 signal, any reference, or ground.	1) ABS(raw APP sensor #2 voltage - raw APP sensor #1 voltage) > 0.269 V. OR 2) PPS1 to PPS2 > 0.05V when PPS2 reference is 0.0 V.	Ignition in Run or Crank. Ignition voltage > 5.23 V. Valid TACM - PCM serial data. No TACM processor DTC.	1) Counter increments by 4 for every error, decrements by 1 for every pass; threshold is 180 Check runs every 3 ms. 2) Counter increments by 4 for every error, decrements by 1 for every pass; threshold is 1333 Check runs every 3ms..	DTC Type C

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc

**2003 Heavy Duty (>8600 GVW) TRUCK
4.8L (LR4), 6.0L (LQ4), 8.1L (L18)
ENGINE DIAGNOSTIC PARAMETERS**

2003file8.doc

SENSED PARAMETER	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA AND THRESHOLD VALUE(S)	SECONDARY PARAMETERS AND ENABLE CONDITIONS	TIME LENGTH AND FREQUENCY	MIL ILLUMINATION TYPE
APP SENSOR 2 CIRCUIT	P2125	1) TACM indicates a continuous or intermittent short or open in either the signal circuit or the APP sensor #2. OR 2) TACM indicates an invalid minimum mechanical position for the APP sensor #2. OR 3) TACM indicated reference voltage out of range.	1) Raw APP sensor signal < 0.235 V or > 4.487 V. OR 2) APP sensor minimum mechanical stop voltage > 0.235 V. OR 3) Vref out of range < 4.54 V or > 5.21 V.	Ignition in Run or Crank. Ignition voltage > 5.23 V. Valid TACM - PCM serial data. No TACM processor DTC.	1) & 2) Counter increments by 4 for every error, decrements by 1 for every pass; threshold is 180. Check runs every 3 ms.	DTC Type C
THROTTLE POSITION SENSOR 1, 2 RANGE/PERF.	P2135	1) TACM indicates a continuous or intermittent correlation fault between TP sensors #1 and #2. OR 2) TACM indicates an invalid minimum mechanical position correlation between TP sensor #1 and #2. OR 3) TPS1 signal short to TPS2 signal, Any reference, or ground.	1) ABS(TPS1 raw – TPS2 raw) < 6.0%. OR 2) TPS1 sig to TPS2 sig > 0.05V when TPS2 reference = 0.0 V.	Ignition in Run or Crank. Ignition voltage > 5.23 V. Valid TACM - PCM serial data. No TACM processor DTC.	1) Counter increments by 4 for every error, decrements by 1 for every pass; threshold is 180. Check runs every 3 ms. 2) One occurrence. Check runs at power-up 3) Counter increments by 4 for every error, decrements by 1 for every pass; threshold is 1333 Check runs every 3ms..	DTC Type A

* These codes are not required with the 8.1L (L18) HD truck engine but are used for other applications within this OBD II Group

2003file8.doc