

## 08 GRP12b All Transmissions

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALF DETECTION PARAMETERS	SECONDARY PARAMETERS AND CONDITIONS	MONITORING TIME	DTC TYPE
Transmission Control Module Read Only Memory	P0601	EPROM/Flash memory corruption (Incorrect program/calibrations checksum)	ROM fail count $\geq 5$	None	Immediate	Type A
Transmission Control Module Not Programmed	P0602	Non-programmed TCM (calibrations)	KbCOND_NoStartCal = TRUE	None	Immediate	Type A
Transmission Control Module Long-Term Memory Reset	P0603	Wrong copy of Non-volatile Memory to RAM	Non-volatile memory (static or dynamic) checksum failure	None	Immediate	Type A
Transmission Control Module Random Access Memory	P0604	RAM failure	RAM read/write failure (single word) RAM fail count $\geq 5$	None	Immediate	Type A
Transmission Control Module Long Term Memory Performance	P062F	NVM write error at key-down	TCM Non-Volatile Memory Incorrect flag = 1	$8.0 \leq \text{Ignition Voltage} \leq 18.0 \text{ V}$ Ignition ON	Immediate	Type A

MAF DTCs	P0101-P0102-P0103
MAP DTCs	P0105-P0106-P0107-P0108
MAP Intermittent	P1106-P1107
ECT DTCs	P0115-P0116-P0117-P0118-P0125-P0126-P0128
TP DTCs	P0120-P0121-P0122-P0123-P0220-P0221-P0222-P0223-P0225-P0226-P0227-P0228-P1120-P1121-P1122-P1125
	P1280-P1281-P1282-P1283-P1285-P1286-P1287-P1288
System Voltage DTCs	P0562-P0563

Type A and Type B codes illuminate the "Service Engine Soon" lamp. FA = Fault Active  
 Type C codes illuminate the "Service Vehicle Soon" or "Wrench" lamp. FATKO = Fault Active This Key On

## 08 GRP12b All Transmissions

Transmission Fluid Temperature Sensor Performance	P0711	<p>The DTC detects the following failure modes of the TFT:</p> <p>1) A sensor that remains at a value. (Stuck Sensor)</p> <p>2) A sensor that remains at a value. (Stuck Sensor)</p> <p>4) Transmission Temperature remains below 20° C for a calibrated time dependant on startup transmission temperature.</p>	<p><u>Fail Case 1</u>  <math>\Delta TFT &lt; 2^{\circ} C</math>.                      TCC Slip <math>\geq 120</math> RPM for 300 sec cumul.                      -39° C. <math>\leq</math> TFT at startup <math>\leq 20^{\circ} C</math>.</p> <p><u>Fail Case 2</u>  <math>\Delta TFT &lt; 2^{\circ} C</math>.                      129° C <math>\leq</math> TFT at startup <math>\leq 149^{\circ} C</math>.</p> <p><u>Fail Case 4</u>                      TFT <math>\leq 20^{\circ} C</math> after a calibrated amount of time based on a 2D lookup table.</p>	<p><u>For fail case 1, 2, and 4:</u>                      Common ignition voltage enable,                      Common engine speed enable,                      No Engine Coolant DTC's,                      No OSS P0722, P0723 DTCs,                      No ISS P0716, P0717 DTCs,                      P0711 has not passed this ignition cycle,                      -39 deg C <math>\leq</math> trans fluid temp <math>\leq</math> 149 deg C</p> <p><u>Fail case 1:</u>                      -39 deg C <math>\leq</math> trans fluid temp <math>\leq</math> 20 C at startup,                      Engine coolant <math>\Rightarrow</math> 70 deg C,                      Engine Coolant has changed <math>\Rightarrow</math> 55 deg C since startup,                      Vehicle speed <math>\Rightarrow</math> 8 KPH for <math>&gt;</math> 300 seconds (cumulative timer)</p> <p><u>Fail case 2:</u>                      129 deg C <math>\leq</math> trans fluid temp <math>\leq</math> 149 C at startup,                      Engine coolant <math>\Rightarrow</math> 70 deg C,                      Engine Coolant has changed <math>\Rightarrow</math> 55 deg C since startup,                      Vehicle speed <math>\Rightarrow</math> 8 KPH for <math>\Rightarrow</math> 300 seconds (cumulative timer)</p> <p><u>Fail case 4:</u>                      Valid TPS, Torque signal, and Crank Signals.                      50 <math>\leq</math> Engine Torque <math>\leq</math> 1492                      8 <math>\leq</math> Throttle Position <math>\leq</math> 90                      8 <math>\leq</math> Vehicle Speed <math>\leq</math> 511                      500 <math>\leq</math> Engine Speed <math>\leq</math> 6500                      -39 <math>\leq</math> Coolant Temperature <math>\leq</math> 149</p>	<p><u>Fail case 1:</u>                      80.0 seconds</p> <p><u>Fail case 2:</u>                      80.0 seconds</p> <p><u>Fail case 4:</u>                      Between 200 &amp; 1900 seconds dependant on startup trans temperature.</p>	Type C
Transmission Fluid Temperature Sensor Circuit Low Voltage	P0712	Continuous Short-to-Ground in Trans Fluid Temperature sensor or TFT signal circuit	<p>Trans Temp Sensor <math>\leq</math> 43.19 ohm</p> <p>Trans Temp <math>&gt;</math> 150C</p>	<p>8V <math>\leq</math> Ignition Voltage <math>\leq</math> 18V for 5 sec                      500 <math>\leq</math> Engine RPM <math>\leq</math> 6500 for 5.0 sec</p>	12.0 sec	Type C
Transmission Fluid Temperature Sensor Circuit High Voltage	P0713	Continuous Open of Short to Voltage in Transmission Fluid Temperature sensor or TFT signal circuit	<p>Trans Temp Sensor <math>\geq</math> 171862 ohm</p> <p>Trans Temp <math>&lt;</math> -40C (-40F)</p>	<p>No P0716, P0717, P0722, P0723 DTCs                      500 <math>\leq</math> Engine RPM <math>\geq</math> 6500 for 5.0 sec                      8.0 <math>\leq</math> Ignition Voltage <math>\leq</math> 18.0 V                      OSS <math>\geq</math> 70 RPM for 200 sec cumul.                      TCC Slip <math>\geq</math> 120 RPM for 200 sec cumul.</p>	80.0 sec	Type C

MAF DTCs	P0101-P0102-P0103
MAP DTCs	P0105-P0106-P0107-P0108
MAP Intermittent	P1106-P1107
ECT DTCs	P0115-P0116-P0117-P0118-P0125-P0126-P0128
TP DTCs	P0120-P0121-P0122-P0123-P0220-P0221-P0222-P0223-P0225-P0226-P0227-P0228-P1120-P1121-P1122-P1125
	P1280-P1281-P1282-P1283-P1285-P1286-P1287-P1288
System Voltage DTCs	P0562-P0563

Type A and Type B codes illuminate the "Service Engine Soon" lamp. FA = Fault Active  
 Type C codes illuminate the "Service Vehicle Soon" or "Wrench" lamp. FATKO = Fault Active This Key On

## 08 GRP12b All Transmissions

Input Speed Sensor Performance	P0716	0 – 6500 RPM  Unrealistically large drop in Input Speed in a very period of time that remains	Input Speed drop $\geq$ 1000 RPM	No P0717, P0722, P0723, P0752, P0973, P0974 DTCs 8V $\leq$ Ignition Voltage $\leq$ 18V 500 $\leq$ Engine RPM $\leq$ 6500 for 5 sec No TP malfunction No Engine Torque malfunction 50 $\leq$ Engine Torque $\leq$ 1492 N-m TPS $\geq$ 8.0% Vehicle Speed $\geq$ 16.0 kph ISS $\geq$ 1050 RPM for 2.0 sec $\Delta$ ISS $\leq$ 500 RPM for 2.0 sec	3.25 sec	Type B
Input Speed Sensor Circuit Low Voltage	P0717	0 – 6500 RPM  Low Input Speed with large vehicle speed	Input Speed $<$ 100.0 RPM	No P0717, P0722, P0723 DTCs No Engine Torque malfunction 500 $\leq$ Engine RPM $\leq$ 6500 for 5 sec 8V $\leq$ Ignition Voltage $\leq$ 18V Vehicle Speed $\geq$ 16.0 kph 50 $\leq$ Engine Torque $\leq$ 1492 N-m	4.5 sec	Type B
Output Speed Sensor Circuit Low Voltage	P0722	0 - 6500 RPM  Low vehicle speed with large engine speed in Drive range	<u>Drive</u> 50 $\leq$ Engine Torque $\leq$ 1492 N-m Output Speed $\leq$ 70 RPM  <u>Park/Neutral</u> 1492 $\leq$ Engine Torque $\leq$ 1492 N-m	No, P0716, P0717, P0723 No TPS malfunction No Engine Torque malfunction 8V $\leq$ Ignition Voltage $\leq$ 18V 500 $\leq$ Engine RPM $\leq$ 6500 for 5.0 sec Range $\neq$ P/N TCC Slip $\geq$ -20 RPM Trans Temp $\geq$ -40° C. 1500 RPM $\leq$ Input Speed $\leq$ 5000 RPM TPS $\geq$ 8.0%	4.5 sec	Type B
Output Speed Sensor Circuit Intermittent	P0723	0 - 6500 RPM  Loss of vehicle speed when vehicle is moving	Drop in Output Speed $>$ 420 RPM in any Drive range	No P0716, P0717, P0974 DTC 8V $\leq$ Ignition Voltage $\leq$ 18V 500 $\leq$ Engine RPM $\geq$ 6500 for 5 sec Range $\neq$ P/N 50 Nm $\leq$ Engine Torque $\leq$ 1492 Nm Time since last range change $\geq$ 6.0 sec + $\Delta$ VSS, loop-to-loop, $\leq$ 175 RPM for 2.0 sec $\Delta$ ISS $\leq$ 500 RPM for 2.0 sec Output Speed $\geq$ 350 RPM for 2.0 sec	3.25 sec	Type B

MAF DTCs	P0101-P0102-P0103
MAP DTCs	P0105-P0106-P0107-P0108
MAP Intermittent	P1106-P1107
ECT DTCs	P0115-P0116-P0117-P0118-P0125-P0126-P0128
TP DTCs	P0120-P0121-P0122-P0123-P0220-P0221-P0222-P0223-P0225-P0226-P0227-P0228-P1120-P1121-P1122-P1125
	P1280-P1281-P1282-P1283-P1285-P1286-P1287-P1288
System Voltage DTCs	P0562-P0563

Type A and Type B codes illuminate the “Service Engine Soon” lamp. FA = Fault Active  
Type C codes illuminate the “Service Vehicle Soon” or “Wrench” lamp. FATKO = Fault Active This Key On

## 08 GRP12b All Transmissions

Torque Converter Clutch System - Stuck Off	P0741	High TCC slip with TCC commanded on	TCC slip $\geq$ 175 RPM  Count = 6	No P0716, P0717, P0722, P0723, P0742, P0842, P0843 No TPS malfunction No Engine Torque and Speed malfunctions $8V \leq$ Ignition Voltage $\leq$ 18V $500 \leq$ Engine RPM $\leq$ 6500 for 5.0 sec $50 \leq$ Engine Torque $\leq$ 1492 N-m $8.0\% \leq$ TPS $\leq$ 90% $20^\circ C. \leq$ Trans Temp $\leq$ 130° C. TCC Capacity $\geq$ 65% for 5.0 sec Commanded Gear > 1 TCC Mode = On or Locked On	5 sec	Type B
Torque Converter Clutch System - Stuck On	P0742	Low TCC slip with TCC commanded off	-20 rpm $\leq$ TCC Slip Speed $\leq$ 40 rpm  Count = 3	No P0716, P0717, P0722, P0723, P0741 No TPS malfunction No Engine Torque and Speed malfunctions $8V \leq$ Ignition Voltage $\leq$ 18V $500 \leq$ Engine RPM $\leq$ 6500 for 5.0 sec TCC commanded OFF $50 \leq$ Engine Torque $\leq$ 1492 N-m $20^\circ C. \leq$ Trans Temp $\leq$ 130° C. $8\% \leq$ TPS $\leq$ 90% $16 \text{ kph} \leq$ VSS $\leq$ 511 kph $1.6780 \leq$ Ratio $\leq$ .6650	6 sec	Type B
1-2 Shift Solenoid Valve Performance - No First or Fourth Gear	P0751	2-2-3-3 shift pattern	<u>Fail Case 1</u> Commanded 1st $1.480 <$ Ratio $<$ 1.650 1.5sec. after gear change  <u>Fail Case 2</u> Commanded 4th $0.95 <$ Ratio $<$ 1.05 1.5 sec. after gear change  Count = 2	No P0716, P0717, P0722, P0723, P0742, P0973, P0974, P0976, P0977, or TPS DTCs (see below) No Engine Torque malfunction $500 \leq$ Engine RPM $\leq$ 6500 for 5.0 sec $8V \leq$ Ignition Voltage $\leq$ 18V TPS $\geq$ 8.0% $150 \text{ RPM} \geq$ ISS $\geq$ 6000 RPM $20^\circ C. <$ Trans Temp $<$ 130° C. $150 \leq$ Input Speed $\leq$ 6500 RPM $50 \leq$ Engine Torque $\leq$ 1492 N-m Output Speed $\geq$ 53 RPM	<u>Fail Case 1</u> 2.0 sec  <u>Fail Case 2</u> 3.0 sec	<u>Type B</u>

MAF DTCs	P0101-P0102-P0103
MAP DTCs	P0105-P0106-P0107-P0108
MAP Intermittent	P1106-P1107
ECT DTCs	P0115-P0116-P0117-P0118-P0125-P0126-P0128
TP DTCs	P0120-P0121-P0122-P0123-P0220-P0221-P0222-P0223-P0225-P0226-P0227-P0228-P1120-P1121-P1122-P1125
	P1280-P1281-P1282-P1283-P1285-P1286-P1287-P1288
System Voltage DTCs	P0562-P0563

Type A and Type B codes illuminate the "Service Engine Soon" lamp. FA = Fault Active  
Type C codes illuminate the "Service Vehicle Soon" or "Wrench" lamp. FATKO = Fault Active This Key On

## 08 GRP12b All Transmissions

1-2 Shift Solenoid Valve Performance - No Second or Third Gear	P0752	1-1-4-4 shift pattern	<p><u>Fail Case 3</u> Commanded 2nd <math>2.7750 &lt; \text{Ratio} &lt; 3.0870</math> 1.5 sec. after gear change</p> <p><u>Fail Case 4</u> Commanded 3<sup>rd</sup> <math>0.670 &lt; \text{Ratio} &lt; 0.740</math> 1.5 sec. after gear change</p> <p>Count = 2</p>	See P0751	<p><u>Fail Case 3</u> 2.0 sec</p> <p><u>Fail Case 4</u> 2.0 sec</p>	<u>Type B</u>
2-3 Shift Solenoid Valve Performance - No First or Second Gear	P0756	4-3-3-4 shift pattern	<p><u>Fail Case 5</u> <math>-20 \leq \text{TCC Slip} \leq 8191</math> RPM <math>\text{VSS} \geq 53^* \text{ RPM}</math> Commanded 1st <math>0.65 \leq \text{Ratio} \leq 1.87</math> 1.5 sec. after gear change</p> <p><u>Fail Case 6</u> Commanded 2nd <math>0.95 \leq \text{Ratio} \leq 1.05</math> 1.5 sec. after gear change</p> <p>Count = 2</p>	See P0751	<p><u>Fail Case 5</u> 3.0 sec</p> <p><u>Fail Case 6</u> 3.0 sec</p>	<u>Type A</u>
2-3 Shift Solenoid Valve Performance - No Third or Fourth Gear	P0757	1-2-2-1 shift pattern	<p><u>Fail Case 7</u> <math>40 \leq \text{Engine Torque} \leq 1492</math> N-m Commanded 3rd <math>1.4800 &lt; \text{Ratio} &lt; 1.6500</math> 1.5 sec. after gear change</p> <p><u>Fail Case 8</u> <math>0 \leq \text{Engine Torque} \leq 1492</math> N-m Commanded 4<sup>th</sup> <math>1.6500 &lt; \text{Ratio} &lt; 3.0870</math> 1.5 sec. after gear change</p> <p>Count = 2</p>	See P0751	<p><u>Fail Case 7</u> 2.0 sec</p> <p><u>Fail Case 8</u> 2.0 sec</p>	<u>Type A</u>

MAF DTCs	P0101-P0102-P0103
MAP DTCs	P0105-P0106-P0107-P0108
MAP Intermittent	P1106-P1107
ECT DTCs	P0115-P0116-P0117-P0118-P0125-P0126-P0128
TP DTCs	P0120-P0121-P0122-P0123-P0220-P0221-P0222-P0223-P0225-P0226-P0227-P0228-P1120-P1121-P1122-P1125
	P1280-P1281-P1282-P1283-P1285-P1286-P1287-P1288
System Voltage DTCs	P0562-P0563

Type A and Type B codes illuminate the "Service Engine Soon" lamp. FA = Fault Active  
 Type C codes illuminate the "Service Vehicle Soon" or "Wrench" lamp. FATKO = Fault Active This Key On

## 08 GRP12b All Transmissions

Torque Converter Clutch Release Switch Circuit Low Voltage	P0842	Closed Release Switch, indicating TCC is applied when TCM is commanding TCC off and TCC slip shows TCC is OFF.	Release switch closed (grounding) for 6.0 sec  Count = 2	No P0716, P0717, P0741, P0742 P2764, P2763 DTCs No Engine Speed or Torque Malfunctions 500 ≤ Engine RPM ≤ 6500 for 5.0 sec TCC commanded OFF 80 RPM < Slip Speed 50 < Engine Torque < 1492 N-m 20° C. < Trans Temp < 130° C. 16 kph < VSS < 511 kph	10.0 sec	Type B
Torque Converter Clutch Release Switch Circuit High Voltage	P0843	Open Release Switch, indicating TCC not applied when TCM is commanding TCC ON and TCC slip shows TCC is locked	Release switch open for 6.0 sec  Count = 2	No P0716, P0717, P0741, P0742 P2764, P2763 DTCs No Engine Speed Malfunction 500 ≤ Engine RPM ≤ 6500 for 5.0 sec TCC commanded ON, or LockON -20 < Slip < 60 RPM 50 < Engine Torque < 1492 N-m 20° C. < Trans Temp < 130° C. 150 < TCC Pressure < 830 kPa	6.0 sec	Type B
1-2 Shift Solenoid Control Circuit Low Voltage	P0973	0 – 12 V  Continuous Short-to-Ground OR Open in Shift Solenoid A or SSA circuit (ODM)	SSA ODM feedback circuit state ≠ PCM commanded state	Ignition ON 8.0 ≤ Ignition Voltage ≤ 18.0 V	Fail count = 44 out of 50 (Time ≈ 4.4 sec)	Type B
1-2 Shift Solenoid Control Circuit High Voltage	P0974	0 – 12 V  Continuous Short-to-Power in Shift Solenoid A or SSA circuit (ODM)	SSA ODM feedback circuit state ≠ PCM commanded state	Ignition ON 8.0 ≤ Ignition Voltage ≤ 18.0 V	Fail count = 44 out of 50 (Time ≈ 4.4 sec)	Type B
2-3 Shift Solenoid Control Circuit Low Voltage	P0976	0 – 12 V  Continuous Short-to-Ground OR Open in Shift Solenoid B or SSB circuit (ODM)	SSB ODM feedback circuit state ≠ PCM commanded state	Ignition ON 8.0 ≤ Ignition Voltage ≤ 18.0 V	Fail count = 44 out of 50 (Time ≈ 4.4 sec)	Type A
2-3 Shift Solenoid Control Circuit High Voltage	P0977	0 – 12 V  Continuous Short-to-Power in Shift Solenoid B or SSB circuit (ODM)	SSB ODM feedback circuit state ≠ PCM commanded state	Ignition ON 8.0 ≤ Ignition Voltage ≤ 18.0 V	Fail count = 44 out of 50 (Time ≈ 4.4 sec)	Type A

MAF DTCs	P0101-P0102-P0103
MAP DTCs	P0105-P0106-P0107-P0108
MAP Intermittent	P1106-P1107
ECT DTCs	P0115-P0116-P0117-P0118-P0125-P0126-P0128
TP DTCs	P0120-P0121-P0122-P0123-P0220-P0221-P0222-P0223-P0225-P0226-P0227-P0228-P1120-P1121-P1122-P1125
	P1280-P1281-P1282-P1283-P1285-P1286-P1287-P1288
System Voltage DTCs	P0562-P0563

Type A and Type B codes illuminate the “Service Engine Soon” lamp. FA = Fault Active  
Type C codes illuminate the “Service Vehicle Soon” or “Wrench” lamp. FATKO = Fault Active This Key On

## 08 GRP12b All Transmissions

Internal Mode Switch (IMS) A Circuit Low Voltage	P1820	Detects IMS circuit A voltage being continuously low	IMS RANGE = Transitional 1 for $\geq 8$ seconds	No Engine Torque Malf Ignition ON $8V \leq$ Ignition Voltage $\leq 18V$ $500 \leq$ Engine RPM $\leq 6500$ for 5.0 sec IMS = Park/Neutral $\geq 1.0$ seconds $50 <$ Engine Torque $< 1492$ N-m	1 count	Type B
Internal Mode Switch (IMS) B Circuit High Voltage	P1822	Detects IMS circuit B voltage being continuously high	IMS RANGE = Transitional 13 for $\geq 8$ seconds	No Engine Torque Malf Ignition ON $8V \leq$ Ignition Voltage $\leq 18V$ $500 \leq$ Engine RPM $\leq 6500$ for 5.0 sec IMS = Park/Neutral $\geq 1.0$ seconds $50 <$ Engine Torque $< 1492$ N-m	1 count	Type B
Internal Mode Switch (IMS) P Circuit Low Voltage	P1823	Detects IMS circuit P voltage being continuously LOW	IMS RANGE = Transitional 8 for $\geq 8$ seconds	No Engine Torque Malf Ignition ON $8V \leq$ Ignition Voltage $\leq 18V$ $500 \leq$ Engine RPM $\leq 6500$ for 5.0 sec IMS = Park/Neutral $\geq 1.0$ seconds $50 <$ Engine Torque $< 1492$ N-m	1 count	Type
Internal Mode Switch (IMS) Invalid Range	P1825	Detects IMS range = Invalid	IMS RANGE = INVALID for $\geq 8$ seconds	No Engine Torque Malf Ignition ON $8V \leq$ Ignition Voltage $\leq 18V$ $500 \leq$ Engine RPM $\leq 6500$ for 5.0 sec IMS = Park/Neutral $\geq 1.0$ seconds $50 <$ Engine Torque $< 1492$ N-m	1 count	Type B
Internal Mode Switch (IMS) C Circuit High Voltage	P1826	Detects IMS circuit C voltage being continuously high	IMS Circuit C High for $\geq 8$ seconds	No Engine Torque Malf No VSS DTC DTC P1826 has not passed Ignition ON $8V \leq$ Ignition Voltage $\leq 18V$ $500 \leq$ Engine RPM $\leq 6500$ for 5.0 sec Vehicle Speed $\geq 16$ kph Gear Ratio = 1 <sup>st</sup> , 2 <sup>nd</sup> , 3 <sup>rd</sup> , or 4 <sup>th</sup> IMS = Park/Neutral $\geq 1.0$ seconds $50 <$ Engine Torque $< 1492$ N-m	1 count	Type B

MAF DTCs	P0101-P0102-P0103
MAP DTCs	P0105-P0106-P0107-P0108
MAP Intermittent	P1106-P1107
ECT DTCs	P0115-P0116-P0117-P0118-P0125-P0126-P0128
TP DTCs	P0120-P0121-P0122-P0123-P0220-P0221-P0222-P0223-P0225-P0226-P0227-P0228-P1120-P1121-P1122-P1125
System Voltage DTCs	P1280-P1281-P1282-P1283-P1285-P1286-P1287-P1288 P0562-P0563

Type A and Type B codes illuminate the "Service Engine Soon" lamp. FA = Fault Active  
Type C codes illuminate the "Service Vehicle Soon" or "Wrench" lamp. FATKO = Fault Active This Key On

## 08 GRP12b All Transmissions

Start In Wrong Range	P1915	Detects an IMS Range other than Park/Neutral during engine start up	IMS Range $\neq$ Park/Neutral $\geq$ 2 seconds	$8V \leq$ Ignition Voltage $\leq$ 18V Engine Speed $>$ 500 rpm Crank Request has been requested $\geq$ 409 second	1 count	Type B
IgnSwitch Run Crank Circuit	P2534	Detects a continuous open in TCM Ignition 1 Switch	Every 25 msec, the FAIL counter is incremented if an open is detected	Engine Running	Fail Counts $\geq$ 200 out of 220 counts	Type A
Torque Converter Clutch Pressure Control Solenoid Control Circuit High Voltage	P2763	Continuous Short-to-Voltage in TCC PWM circuit	Every 100 msec, the FAIL counter is incremented if a short to voltage is detected	Ignition ON $8V \leq$ Ignition Voltage $\leq$ 18V $500 \leq$ Engine RPM $\leq$ 6500 for 5.0 sec TCC Commanded ON	Fail Count = 44 out of 50 (Time $\approx$ 4.4 sec)  Continuous	Type B
Torque Converter Clutch Pressure Control Solenoid Control Circuit Low Voltage	P2764	Continuous Open/Short-to-Ground in TCC PWM circuit or TCC PWM solenoid	Every 100 msec, the FAIL counter is incremented if an open or a short to ground is detected	Ignition ON $8V \leq$ Ignition Voltage $\leq$ 18V $500 \leq$ Engine RPM $\leq$ 6500 for 5.0 sec	Fail Count = 44 out of 50 (Time $\approx$ 4.4 sec)  Continuous	Type B
Controller Area Network Bus Communication Error	<b>U0073</b>	TCM cannot communicate on the CAN Bus	GetCNDD_b_BusOffSt() = TRUE	Ignition ON  $8V \leq$ Ignition Voltage $\leq$ 18V for 5 seconds	1.0 sec	Type B
Lost Communications with Engine Control System	<b>U0100</b>	Communication between TCM & Engine Control System Lost	CAN Bus ECM Error flag = 1  1.0 Sec.	Ignition ON  $8V \leq$ Ignition Voltage $\leq$ 18V for 5 seconds	1.0 sec	Type B

MAF DTCs	P0101-P0102-P0103
MAP DTCs	P0105-P0106-P0107-P0108
MAP Intermittent	P1106-P1107
ECT DTCs	P0115-P0116-P0117-P0118-P0125-P0126-P0128
TP DTCs	P0120-P0121-P0122-P0123-P0220-P0221-P0222-P0223-P0225-P0226-P0227-P0228-P1120-P1121-P1122-P1125
	P1280-P1281-P1282-P1283-P1285-P1286-P1287-P1288
System Voltage DTCs	P0562-P0563

Type A and Type B codes illuminate the "Service Engine Soon" lamp. FA = Fault Active  
Type C codes illuminate the "Service Vehicle Soon" or "Wrench" lamp. FATKO = Fault Active This Key On