

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.	
Catalyst Bank 1	P0420	oxygen storage of catalyst	normalized oxygen storage less than normalized oxygen storage of a limit catalyst	<1 factor	exhaust gas mass flow exhaust gas mass flow catalyst temp. model catalyst temp. model engine speed engine speed engine load (RLKTDMN) engine load (RLKTDMX) modeled catalyst temp. gradient exhaust gas mass flow gradient fuel system closed loop time after dew point exceeded at secondary O2 sensor * ambient temperature secondary O2 sensor voltage error: fuel system trim rich or lean (P2177,P2178,P2187,P2188) short term fuel trim (< max) short term fuel trim (> min) error: critical misfire rate (P0300-P0306) error: cat. damaging misfire rate exceeded (P0300-P0306)	>35kg/h <150kg/h <700° C >480° C >960rpm <2760rpm >18% <70..80% <2.5° C / sec <8.33g/sec ² active > 40 sec. >-48° C > 0.55 V not set <1.25factor >0.75factor not set not set	max. 18 sec. continuous	once per trip	1 trip with: 0.4 sec continuous or 4 sec cum	
Misfire Emission Level Multiple Cylinder	P0300	crankshaft speed fluctuation cylinder 1 to cylinder 6	emissions relevant misfire rate	> 1,92%	engine speed	> 450rpm	first Interval: 1000 revs.	continuous	2 trips	
Cylinder #1	P0301				engine speed	< 6500rpm				with: 0.4 sec continuous
Cylinder #2	P0302				indicated torque (idle, no drive)	> 5,47%				

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
Cylinder #3	P0303				indicated torque (drive) (MISALUN)	> 5,47 . . . 20,7%			or 4 sec cum
Cylinder #4	P0304				engine speed gradient (NGALUN)	<12800rpm/sec			
Cylinder #5	P0305				volumetric efficiency gradient	<768%/rev			
Cylinder #6	P0306				cylinder events after engine start	> 6ignitions			
					engine coolant temperature	> -30°C			
					intake air temperature	> -30°C			
					error: crankshaft sensor (P0335, P0336, P0338)	not set			
					error: ref.mark of crank sensor (P0016-P0019)	not set			
Catalyst Damaging Level Multiple Cylinder	P0300		Catalyst damaging misfire rate (KFKSWFS; AHEKSB1)	> 16,7 . . . 4,7%	Includes all the above with the following exceptions:				First
Cylinder #1	P0301			see Misfire supplemental data (h) (2.5.1)	First interval when engine coolant start temperature is	< 0 °C	First Interval: 1000 revs	continuous	occurrenc e:
Cylinder #2	P0302				First interval when engine coolant start temperature is	> 0 °C	First Interval: 200 revs	continuous	immediat e MIL flashing
Cylinder #3	P0303								
Cylinder #4	P0304						Remaining intervals 200 revs	continuous	Second occurrenc e: immediat e MIL flashing with constant
Cylinder #5	P0305								
Cylinder #6	P0306								MIL afterwar ds

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
Fuel evaporative system (monitor during engine run) canister ventilation valve (AAV)	P0446	monitoring of tank pressure while	tank pressure too low because	< -25 hPa	engine start temperature (TMSTLDMN, TMSTDLDMX)	2 °C ... 38 °C	approx. 10 sec	once per trip	2 trips
		AAV is open and CPV is closed	canister vent. defective & closed		ambient temperature (TUMTLDU, TUMTLDO)	2 °C ... 38 °C			
canister purge valve (CPV)	P0496	monitoring of tank pressure while CPV and AAV are closed	final pressure too low because CPV defective and open	< -0.6 hPa	ambient pressure	>= 680.00 hPa	approx. 10 sec	once per trip	
					vehicle speed	<= 1,86 mph			
canister purge valve (CPV)	P0497	monitoring of tank pressure while CPV and AAV are closed	purge control stuck closed	> -0.2 hPa	angle accelerator pedal unfiltered tank pressure	0 ° >= -40.00 hPa			
					and unfiltered tank pressure	<= 10.00 hPa			
tank leak rough	P0455	AAV is closed and CPV is open	vacuum pressure built up gradient too low (KLTLD SFS05) because of large tank leakage (for example: open gas filler cap)	> 0.15 ... 0.19 hPa/s > -13 hPa	battery voltage and battery voltage	>= 10.45 V <= 18.00 V	approx. 20 sec	once per trip	
						fuel system status secondary air system *			
					tank fuel level (FTSDMN, FSTDMX)	11l ... 76l			
					error: fuel system trim rich or lean (P2177,P2178,P2187,P2188)	not set			
					multiplicative fuel trim adaption integrator deviation for time	< 0.015 6 sec.			
					lambda controller deviation or time since engine start exceeds threshold	< 0.03 > 400 sec			
					error: tank pressure sensor (P0450-P0453)	not set			
					error: engine speed sensor (P0335, P0336, P0338)	not set			

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
					error: ambient temperature sensor (U0073) error: canister purge valve (P0496,P0497) error: engine coolant temperature sensor (P0116-P0119) error: canister ventilation valve (P0446) error: critical misfire rate (P0300-P0306) error: fuel level sensor (P0461-P0463, P2066-P2068)	not set not set not set not set not set not set			
Fuel Evaporative System (monitor after ignition off) tank leak smallest	P0442	Monitor fuel tank's pressure after engine stop and ignition off Filter the normalized pressure from each trip with an EWMA filter. Compare filtered result with threshold. Pressure threshold for each trip For each trip following strategy: Look for maximum positive pressure. Abort if: - max. pos. pressure >=	Filtered normalized pressure Absolute max. neg. pressure + Max. pos. pressure (KFEONVPT) Max. pos. pressure	> 0.5 > 0.4 if previous result detected a leak > 1.20 ... 4.00 hPa > 1.20 ... 4.00 hPa	Engine coolant temperature at start. engine coolant temp. at start - intake air temp. ambient air temperature ambient air temperature engine has been running for a cal. min. time engine coolant temp. at engine stop ambient pressure driving distance (in current trip) covered driving distance (for vehicle lifetime) covered the fuel tank's level isn't at its minimum the fuel tank's level isn't at its maximum battery's voltage no refueling activity	<= 42°C <= 15°C >= 2°C <= 38°C >600sec >60°C >= 680hPa >= 4mi >= 12,27mi 11l 76l >11V	max. 4 trips for each trip max. 2900s continuous after engine stop and ignition off	once per trip	1 trip

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
		threshold. - max. pressure - current pressure >= threshold for a specific time. - pressure stays in range near zero for a specific time. - pressure <= threshold for a specific time (vacuum build-up instead of pressure build-up) - pressure-phase-time >= threshold. - diagnostic-time >= threshold Look for absolut maximum negative pressure Abort if: - max. neg. pressure <= threshold - diagnostic time >= threshold - current pressure - neg. pressure >= threshold for a specific time	(KFEONVPT) max. pressure - current pressure absolute pressure pressure pressure phase time diagnostic time Abs . max. neg. pressure (KFEONVPT) diagnostic time current pressure - neg. pressure	 >= 0.05 hPa 100s <= 0.69946 hPa 300s <= -0.75 hPa 25s >= 2400.00 s >= 2900.00 s > 1.20 ... 4.00 hPa >= 2900.00 s >= 0.05 hPa 100s	error: intake air temperature (P0111-P0114) error: canister purge valve (P0496,P0497) error: ambient pressure sensor (P2227-2229) error: vehicle speed sensor (P0501-P0503) error: engine coolant temperature sensor (P0116-P0119) error: tank pressure sensor (P0450-P0453) error: battery voltage error: air mass flow sensor (P0100-P0103) error: canister ventilation valve (P0446) error: tank leak rough (P0455)	not set not set not set not set not set not set not set not set not set not set			

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
		- pressure stays in ambient range for a specific time - canister vent valve re-opened for a more than N times because the pressure exceeds a threshold	absolute pressure no. canister vent valve openings pressure	<= 0.69946 hPa 300s > 2 0.74951 hPa					
Secondary Air System	P0411	passive functional check	relative secondary air mass flow. Ratio from calculated secondary air mass by pressure sensor signal and secondary air mass model	< 0.45 > 1.2	catalyst heating * secondary air system * intake air temperature intake air temperature engine coolant temperature	active active > 0 °C < 80.3 °C > 0 °C	max. 60s	once per trip	2 trips
Secondary Air Valve stuck open check	P2440	Look for pressure pulsations	Top peak of pulsation Bottom peak of pulsation Average of absolute value of pulsations	> 30 hpa < -30 hPa > 10 hPa	engine coolant temperature engine coolant temperature ambient pressure error: ambient pressure sensor (P2227-2229) error: intake air temperature (P0111-P0114) error: engine coolant temperature sensor (P0116-P0119) error: secondary air pump (power stage) (P0418, P2244,P2245) error: battery voltage mass airflow mass airflow change in air charge per working cycle	< 120 °C > 680 hPa. not set not set not set not set not set > 6 kg/h < 130 kg/h <= 7 %			

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
Pressure sensor secondary air system	P2432	circuit continuity - low	measured sensor voltage	< 0,498 V	error: ambient pressure sensor (P2227-2229) secondary air system *		0.5 sec	continuous	2 trips
	P2433	circuit continuity - high or open	measured sensor voltage	> 4,501 V					
	P2431	rationality - comparisson between: SAI system pressure signal & Barometric pressure signal	during ECU init- difference SAI pressure vs BARO pressure	< -50 hPa > 50 hPa		not set active			
Fuel System Rich/Lean Multiplicative and Additive					general enable contitions: fuel system status for time engine coolant temperature canister vent valve closed intake air temperature lambda setpoint error: camshaft control * error: reference mark sensor (P0335,P0336,P0338) error: throttle position sensor (P0121-P0123,P0221-P0223) error: engine coolant temperature sensor (P0116-P0119) error: power supply voltage error: power stage throttle actuator (P0221-P0223) error: intake air temperature (P0111-P0114) error: power stage canister purge valve (P0443, P0458, P0459)	closed loop >2,6 sec. >60.8°C TRUE <=65.3°C 0.98 < x < 1.02 not set not set not set not set not set not set not set not set not set	35 sec.	continuous	2 trips with: 0.4 sec continuo us or 4 sec cum

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
	P2177	fuel trim limits exceeds range multiplicative	delta lambda correction	>1.175factor	error: multiple misfire (P0300-P0306) error: lambda sensor upstream catalyst (P0130-P0134) error: lambda sensor heating upstream catalyst (P0134,P0135) error: canister purge system * special enable contitions	not set not set not set not set			
	P2178	fuel trim limits exceeds range multiplicative	or delta lambda correction	<0.825factor	indicated torque engine speed	> 17% ... 11% < 37% .. 46% => 1080 rpm <= 3000rpm			
	P2187	system too lean at idle	delta fuel load correction	>5.25%	indicated torque	> 4.8%			
	P2188	system too rich at idle	or delta fuel load correction	<-5.25%	engine speed	< 17.3% ... 11% => 520rpm <= 960rpm			
Diagnosis of Power Control Module	P0629	diagnosis short circuit to battery voltage	backward powerstage voltage of fuel pump diagnosis for a time and backward powerstage voltage of fuel pump diagnosis	> 2.21 V 0.1 sec. >= 2.74 V	general enabling conditions battery voltage locking request immobilizer special enabling condition fuel pump relay commanded "OFF"	< 17.9 V > 10 V not active TRUE	0.6 sec	continuous	2 trips

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
	P0628	diagnosis short circuit to ground only active if powerstage on	backward powerstage voltage of fuel pump diagnosis for a time	<= 2.21 V > 0.5 sec.	fuel pump relay commanded "ON"	TRUE			
	P0627	diagnosis wire interruption	backward powerstage voltage of fuel pump diagnosis and max-error: powerstage diagnosis set	> 2.74 V FALSE	condition output duty cycle PCM for power on diagnosis fuel pump relays commanded "OFF"	TRUE TRUE			
	P0627	powerstage locked	condition fault message of PCM powerstage is locked	TRUE					
Oxygen sensor (primary O2) bank 1 sensor 1	P0131	short circuit to ground for a cold sensor	primary sensor voltage	< 0.06 V	engine coolant temperature engine stop temperature last driving cycle dew point exceeded at primary O2 sensor * primary sensor heating active * heating power primary O2 sensor for more than engine speed battery voltage	< 39.8 °C > 60 °C TRUE TRUE > 80 % 10 sec. > 680 rpm > 10.5 V	0.1 sec.	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuous or 4 sec cum
	P0131	short circuit to ground for a warm sensor	primary sensor voltage	< 0.06 V	secondary O2 sensor voltage fuel system status (primary O2 sensor) secondary air system *	> 0.5 V closed loop inactive	10 sec.	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuous

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
					error: secondary air system (P0411,P0418,P2244,P2245, P2431-P2433) Fuel evaporative system monitoring (during engine run)	not set			or 4 sec cum
					air passed at primary O2 sensor	inactive			
					dew point exeeded at primary O2 sensor *	2200g			
					primary sensor heating active *	TRUE			
					heating power primary O2 sensor	TRUE			
					for more than engine speed battery voltage	> 80 %			
						10 sec. > 680 rpm > 10.5 V			
bank 1 sensor 1	P0132	short circuit to battery voltage	primary O2 sensor voltage	>1.08V	dew point exeeded at primary O2 sensor *	TRUE	5 sec.	Monitor runs	2 trips
					primary sensor heating active *	TRUE		whenever enable conditions are met	with: 0.4 sec continuo us or 4 sec cum
					heating power primary O2 sensor	> 80 %			
					for more than	10 sec.			
					desired A/F ratio engine speed battery voltage	> 0.995 > 680 rpm > 10.5 V			
bank 1 sensor 1	P0134	open circuit signal or ground line	when modelled exhaust gas temperature		battery voltage	> 10.5 V	9 sec.	Monitor runs	2 trips
		primary O2 sensor	at primary O2 sensor	< 800 °C	dew point exeeded at primary O2 sensor *	TRUE		whenever enable conditions are met	with: 0.4 sec continuo us or 4 sec cum
			primary O2 sensor voltage in a range	0.4 ... 0.6 V	for more than	30 sec.			
				(USDBO, USREF)	air passed at primary O2 sensor	2200g			
			when modelled exhaust gas temperature		for more than engine running	10 sec. > 680 rpm			

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
bank 1 sensor 1	P0134	open circuit signal or ground line primary O2 sensor	at primary O2 sensor primary O2 sensor voltage in a range	> 800 °C 0.4 ... 0.55 V(UBDBO,USRE FHOT)					
			internal resistance of the primary O2 sensor	> 20.000 Ohms	battery voltage dew point exeeded at primary O2 sensor * for more than air passed at primary O2 sensor for more than engine running modelled exhaust gas temperature	> 10.5 V TRUE 30 sec. 2200g 10 sec. > 680 rpm > 600 °C	0.1 sec.	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuo us or 4 sec cum
bank 1 sensor 1	P0130	heater coupling to the signal primary O2 sensor	primary O2 sensor voltage in range of (USMIN, USREMH)	0.06 ... 0.4 V	battery voltage dew point exeeded at primary O2 sensor * for more than air passed at primary O2 sensor for more than engine running fuel system status (primary O2 sensor) secondary air system * error: secondary air system (P0411,P0418,P2244,P2245, P2431-P2433) Fuel evaporative system monitoring (during engine run) secondary O2 sensor voltage air passed at primary O2 sensor	> 10.5 V TRUE 30 sec. 2200g 10 sec. > 680 rpm closed loop inactive not set inactive > 0.5 V 2200g	10 sec.	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuo us or 4 sec cum

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
	P0130	heater coupling to the signal primary O2 sensor	primary O2 sensor voltage in range of (USREFHKL, USMAX)	0.6 ... 1.08 V	battery voltage dew point exceeded at primary O2 sensor * for more than air passed at primary O2 sensor for more than engine running fuel system status (primary O2 sensor) secondary O2 sensor voltage	> 10.5 V TRUE 30 sec. 2200g 10 sec. > 680 rpm closed loop < 0.1 V	10 sec.	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuous or 4 sec cum
	P0130	heater coupling to the signal primary O2 sensor	primary O2 sensor voltage within time after heater turn on for occurrences out of heater turn ons	> 2.0 V <0.04sec > 4 = 6	dew point exceeded at primary O2 sensor * for more than heating power primary O2 sensor for more than engine running battery voltage	TRUE 10 sec. > 80 % 10 sec. > 680 rpm > 10.5 V	25 sec.	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuous or 4 sec cum
Oxygen sensor (primary O2) bank 1 sensor 1	P0133	dynamic response slow or low amplitude	time of lambda period corrected and weighted over engine speed and load	> 3 sec.	fuel system status (primary O2 sensor) lambda controller engine speed in a range of engine load in a range of modelled exhaust gas temperature purge not longer active than secondary air system * error: fuel system trim rich or lean (P2177,P2178,P2187,P2188)	closed loop 0.95 - 1.05 1000 ... 3000 rpm 18 ... 79.5 % > 300 °C 4 sec. inactive not set	10 lambda period measurements	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuous or 4 sec cum

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
					Fuel evaporative system monitoring (during engine run)	inactive			
					Adaption of purge mass error: camshaft system *	< 25 not set			
Oxygen sensor (primary O2) bank 1 sensor 1	P2097	offset check enrichment	adaption value closed loop secondary lambda control after an accumulated monitoring time of	> 0.79 sec. > 60 sec.	fuel system status (secondary O2 sensor) secondary air system * error: fuel system trim rich or lean (P2177,P2178,P2187,P2188) Fuel evaporative system monitoring (during engine run) Adaption of purge mass error: camshaft system *	closed loop inactive not set inactive < 25 not set	60 sec.	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuous or 4 sec cum
	P2096	offset check enleanment	adaption value closed loop secondary lambda control after an accumulated monitoring time of	< - 0.79 sec. > 60 sec.	fuel system status (secondary O2 sensor) secondary air system * error: fuel system trim rich or lean (P2177,P2178,P2187,P2188) Fuel evaporative system monitoring (during engine run) Adaption of purge mass error: camshaft system *	closed loop inactive not set inactive < 25 not set			
Oxygen Sensor Heating heater performance (primary O2) bank 1 sensor 1 (primary)	P0135	primary O2 sensor internal resistance	measured primary O2 sensor internal resistance		battery voltage battery voltage	>10.5V <18V	6 sec	continuous	2 trips with: 0.4 sec

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
		above threshold	nominal internal resistance	>88 . . . 328Ohms (KFRINV)	engine running	> 680 rpm			continuo us or 4 sec cum
			multiply times degradation factor	>3 . . . 20factor (FRINV1)	fuel system status	no fuel cut			
			for time	>6sec	dew point exeeded at primary O2 sensor intake air temperature engine off soak time modeled exhaust temp. at primary O2 sensor	TRUE >-30°C >120sec in range 300 . . . 550C (TADHMNV, TADHMXV)			
					error: primary O2 sensor electrical (P0130-P0134)	not set			
Oxygen Sensor sensor circuit (secondary O2) bank 1 sensor 2	P0137	short circuit to ground	secondary O2 sensor voltage with a demandet lambda value	<0.06V <= 1.005	secondary O2 heated and mod. exhaust gas temp. (dew point exeeded) for time engine running battery voltage mod. exhaust-gas temp. engine temp at stop engine coolant temperature error: engine coolant temperature sensor (P0116-P0119)	> 10sec >250° C >90sec > 680 rpm >10.7V <800° C >60° C <40° C not set	40 sec.	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuo us or 4 sec cum
bank 1 sensor 2	P0138	short circuit to battery voltage	secondary O2 sensor voltage >	>1.08V	secondary O2 heated and mod. exhaust gas temp. (dew point exeeded) for time	> 10sec >250° C >90sec	5 sec	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuo us

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
bank 1 sensor 2					engine running battery voltage mod. exhaust-gas temp.	> 680 rpm >10.7V <800° C			or 4 sec cum
	P0140	sensor line disconnection	secondary O2 sensor voltage and secondary O2 sensor voltage or secondary O2 sensor internal resistance when modeled exhaust gas temperature	>0.401V <0.499V >40000Ohm >600° C	secondary O2 heated and mod. exhaust gas temp. (dew point exceeded) for time engine running battery voltage mod. exhaust-gas temp.	> 10sec >250° C >90sec > 680 rpm >10.7V <800° C	max 150 sec	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuo us or 4 sec cum
bank 1 sensor 2	P2232	sensor line short circuit to heater output line	secondary O2 sensor within time after heater turn on for occurrences out of heater turn offs	> 2 V <0.04sec >4count =6count	dew point exeeded at primary O2 sensor * for more than heating power primary O2 sensor for more than engine running battery voltage	TRUE 20 sec. > 50 % 20 sec. > 680 rpm > 10.5 V	10 sec	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuo us or 4 sec cum
Oxygen Sensor Heating heater performance (secondary O2) bank 1 sensor 2 (secondary)	P0141	secondary O2 sensor internal resistance above threshold	measured secondary O2 sensor internal resistance nominal internal resistance multiply times degradation factor for time	>120 . . . 560Ohms (KFRINH) >3 . . . 30factor (FRINH1) >6sec	battery voltage battery voltage engine running fuel system status dew point exeeded at secondary O2 sensor * intake air temperature engine off soak time	>10.7V <18V > 680 rpm no fuel cut TRUE >-30°C >150sec	6 sec	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuo us or 4 sec cum

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
					modeled exhaust temp. at secondary O2 sensor error: secondary O2 sensor electrical (P0137,P0138,P0140,P2232)	350 . . . 550C (TADHMNH, TADHMXH) not set			
sensor response (secondary O2) bank 1 sensor 2	P2270	oscillation check low	secondary O2 sensor voltage for time then ramping in enrichment by at gradient for time (after enrichment limit reached)	>0.602 . . . 0.621V > 0.2 sec = 0.15 lambda 0.0488 l / sec >7 sec	dew point exeeded at secondary O2 sensor * for time fuel system status (secondary O2 sensor) all injectors activated engine air flow (intrusive test) and engine air flow for time engine air flow (passive monitor) error: secondary O2 sensor electrical (P0137,P0138,P0140,P2232) lambda controller engine running battery voltage	TRUE >10sec closed loop > 0.8 ms >5,56 g/sec <41,6 g/sec >3sec >7,78 g/sec not set 0.92 ... 1.07 > 680 rpm >10.7V	max. 600 sec	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuo us or 4 sec cum
bank 1 sensor 2	P2271	oscillation check high	secondary O2 sensor voltage for time then ramping in enleanment by at gradient for time (after enleanment limit reached)	>0.602 . . . 0.621V > 0.2 sec =0.10lambda 0.0488 l / sec >7 sec	dew point exeeded at secondary O2 sensor * for time fuel system status (secondary O2 sensor) all injectors activated engine air flow (intrusive test) and engine air flow	TRUE >10sec closed loop > 0.8 ms >5,56 g/sec <41,6 g/sec	max. 600 sec	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuo us or 4 sec cum

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
bank 1 sensor 2	P2271	fuel cut off check high			for time engine air flow (passive monitor) error: secondary O2 sensor electrical (P0137,P0138,P0140,P2232) lambda controller engine running battery voltage	>3sec >7,78 g/sec not set 0.92 ... 1.07 > 680 rpm >10.7V			
			secondary O2 sensor voltage time after fuel cut off	>0.149V >6,2sec	dew point exceeded at secondary O2 sensor * for time air passed after fuel cut off modeled exhaust temp at secondary O2 sensor dew point exceeded at primary O2 sensor * primary O2 sensor voltage error: cam sensor * error: evap canister purge sys. * error: evap purge valve electrical (P0443, P0458, P0459) error: battery voltage	TRUE >30sec >15g >350° C TRUE < 0.149 V not set not set not set not set	0.2 sec	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuo us or 4 sec cum
bank 1 sensor 2	P013A	fuel cut off check transient time	secondary O2 sensor time for voltage drop from to	> 0.15 sec 0.4 V 0.2 V	air passed after fuel cut off bank 1 sensor 2 voltage for time at fuel cut off dew point exceeded at secondary O2 sensor * dew point exceeded at primary O2 sensor * modeled exhaust temp air flow over catalyst	< 3 g > 0,5 V > 1 sec TRUE TRUE > 450° C > 4.17 g/sec	0.15 sec	Monitor runs whenever enable conditions are met	1 trip with: 0.4 sec continuo us or 4 sec cum

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
bank 1 sensor 2					engine speed in range engine load in range battery voltage	1100 - 3300 rpm 10 - 30 % > 11,0V			
	P013E	fuel cut off check response time	secondary O2 sensor voltage time after fuel cut off	> 0.152 V > 5 sec.	air passed after fuel cut off bank 1 sensor 2 voltage for time at fuel cut off dew point exeeded at secondary O2 sensor * dew point exeeded at primary O2 sensor * modeled exhaust temp air flow over catalyst engine speed in range engine load in range battery voltage	< 3 g > 0,5 V > 1 sec TRUE TRUE > 450° C > 4.17 g/sec 1100 - 3300 rpm 10 - 30 % > 11,0V	5 sec	Monitor runs whenever enable conditions are met	1 trip with: 0.4 sec continuo us or 4 sec cum
Camshaft Control System - Locking Pin									2 trips
Bank 1 Intake	P0011	rationality high	average of actual angle measurements versus locked position angle	> +/- 10degrees	engine speed	>560rpm	10 sec	0.01 sec	with: 0.4 sec continuo us or 4 sec cum
Bank 2 Intake	P0021				engine run time	< 1 sec.			
Bank 1 Exhaust	P0014				camshaft control circuit test	complete			
Bank 2 Exhaust	P0024				error: camshaft control circuit *	not set			

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
System - Control		rationality low / high							
Bank 1 Intake	P000A	rationality low / high	difference to start test (filtered actual angle versus filtered desired angle)	> 6 . . . 11 degrees	engine speed	>560rpm	approx.	0.01 sec	2 trips
Bank 2 Intake	P000C		(desired must remain above value)	(KFDWNWDMXE)	engine run time	> 1sec	20 ... 80 sec	continuous	with: 0.4 sec continuous
Bank 1 Exhaust	P000B		to test to complete the evaluation)		error: camshaft control circuit *	not set			or 4 sec cum
Bank 2 Exhaust	P000D		filtered actual angle remains	<	coolant temperature	< 143° C			
			filtered desired angle from test start		coolant temperature	>-48° C			
			within time (KFTDDNWNPA)	= 1.5 ... 2 sec (exhaust)	engine oil temperature	< 180° C			
			(detects 5 sec slow [time constant]) (KFTDDNWNPE)	= 1.2 ... 2 sec (intake)	engine oil temperature	>-48° C			
			for multiple activation occurrences (decrements upon activations where no difference is seen between desired and actual)	>7 counts (exhaust) >8 counts (intake)	cam-crank alignment adaptation	complete			
			difference (filtered actual angle max versus actual at test start)	>2degrees exh 1.8degrees in	catalyst heating *	inactive			
			(to detect slow response versus stuck cam if above this limit)						
		at time (overlaps with time to detect above)	=3sec						
		(passes after multiple good activations)							

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
System Control CSERS			in both cam phase rotation directions)						
Bank 1 Intake	P052B		difference between desired and actual camshaft angle	> 0°	engine speed	>560rpm	10 sec	0.01 sec	2 trips
Bank 2 Intake	P052D				engine run time	>1sec		continuous	with: 0.4 sec
Bank 1 Exhaust	P054B		for time		camshaft control circuit test	complete			continuous
Bank 2 Exhaust	P054D				error: camshaft control circuit *	not set			or 4 sec cum
					coolant temperature	< 143° C			
					coolant temperature	>-48° C			
					engine oil temperature	< 180° C			
					engine oil temperature	>-48° C			
					cam-crank alignment adaptation	complete			
					catalyst heating *	active			
System - Cam - Crank Alignment									
Bank 1 Intake	P0016	cam-crank adapted angle	adapted angle	> 10.8 degrees	engine run time >	>2sec	approx.	0.2 sec	2 trips
Bank 2 Intake	P0018	limit chekc	or adapted angle	< -12.7 degrees	offset between camshaft and crankshaft	< 1°	600 sec	continuous	with: 0.4 sec
Bank 1 Exhaust	P0017	(applies for each camshaft)	or actual angle with parked cams	> 15 degrees	error: camshaft sensor (P0011,P021,P014,P024,P000A-P000D)	not set			continuous
Bank 2 Exhaust	P0019		and	< 21 degrees	error: camshaft control circuit *	not set	fail after		or 4 sec cum
			for a time	> 10 sec.			2 adaptation cycles - required		
Bank 1 / Idler Sprocket	P0008		adapted angle for both cams	> 6.7 degrees					
Bank 2 / Idler Sprocket	P0009		adapted angle for both cams	< -7.9 degrees					
Engine coolant	P0117	range check high	coolant temperature	>142.5°C	intake air temperature	< 75°C	0.1 sec	continuous	2 trips

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
temperature sensor	P0118	range check low	coolant temperature	<-38.3° C	difference between intake air temp and intake air temp. at engine shut down last driving cycle error: engine coolant temperature sensor (P0116-P0119) or time after engine start	< 20...9°C not set >=60sec			with: 0.4 sec continuous or 4 sec cum
	P0116	plausibility check (low side check) plausibility check (high side check)	calculated coolant temperature model	>9.8° C	error: engine coolant temperature sensor (P0116-P0119)	not set	3 sec.	once per trip	with: 0.4 sec continuous or 4 sec cum
			minus measured temperature		measured coolant temperature engine speed integrated air mass	<93.8° C >1000rpm >1500g			
			measured temperature minus calculated coolant temperature model	>9.8°C	error: engine speed sensor (P0335, P0336, P0338) error: air mass flow sensor (P0100-P0103) error: engine coolant temperature sensor (P0116-P0119)	not set not set not set			
P0119	intermittent (discontinuity)	delta coolant temperature or delta coolant temperature (between A/D read sample count offset)	< -10°C > 10°C =3count	ignition	=ON	0,03 sec.	continuous	2 trips with: 0.4 sec continuous or 4 sec cum	
P050C	difference from intake air temperature after soaking	filtered difference (ECT at key on - IAT at key on)	>10°C	time after engine start previous accumulated air mass previous engine run time	>= 5 sec >4000g >500sec	0.1 sec.	continuous	1 trip with: 0.4 sec continuous	

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
			or filtered difference (ECT at key on - IAT at key on)	<-10° C	ECT at shut down coolant temp. calculated out of model engine off time error: intake air temperature (P0111-P0114) error: range check coolant temperature sensor (P0117,P0118) Block Heater	>84.75° C <=50.3°C >21600sec not set not set not detected			or 4 sec cum
Engine Coolant Thermostat Monitoring	P0128	Coolant Temperature Below Thermostat Regulating Temperature (plausibility check)	calculated coolant temp model minus measured coolant temperature model calculation limit Thermostat regulating temperature: 82°C (All critical OBD and emission functions are enabled above 64°C.)	>5.3° C 82°C	debouncing time error: coolant temperature sensor (P0116-P0119,P050C) error: vehicle speed sensor (P0501-P0503) est. ambient temperature est. ambient temperature vehicle speed engine speed coolant temperature at start integrated air mass flow time after start to run the model (depending on engine coolant temp at start)	>10 sec not set not set > -8.3°C <50°C >=3.125mph >960rpm < 51.0°C >3458g >= 22...16 sec (TWADTHMS)	approx. 900 sec	once per trip	2 trips with: 0.4 sec continuo us or 4 sec cum
Engine coolant overtemperature Protection mode	P1258		coolant temperature for a time	> 132.8 °C > 1 sec.	error: engine coolant temp (P0116-P0119) engine speed for a time	not set > 80 rpm > 30 sec.	1 sec.	continuous	1 trip

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
Intake air temperature sensor	P0111	response check	difference: max intake air temperature - min intake air temperature	>1,5° C	DRIVE PERIOD - COUNT EACH WITH: vehicle speed mass flow mass flow coolant temperature at start no fuel shut-off AND IDLE PERIOD - COUNT vehicle speed coolant temperature at start coolant temperature integrated air mass increases (KLTFA1ML)	>=24,8mph <250g / sec >15,6 g/sec <=120° C <=1.55mph <=120° C >75° C > 4002 . . . 15019 g	5 x 9 sec. 5 x 11 sec.	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuo us or 4 sec cum
	P0111	Difference from coolant temperature sensor	difference: intake air temperature - engine coolant temperature	>+35,3°C or <-20,3°C	engine temperaure at start coolcانت temperature decrease since engine stall minimum coolant temperature at engine stall last trip	<35,3°C > 39,8°C >80°C	300 sec. after start (block heater delay)	once per trip	2 trips with: 0.4 sec continuo us or 4 sec cum
	P0112	range check low	intake air temperature	>124,9° C	time after start	> 15sec	0.1 sec.	once per trip	2 trips
	P0113	range check high	intake air temperature	<-34,9° C	then time in idle and intake air temperature then IAT change (abs value) while integrated air mass increases	>3sec <-35,3° C <=2.3° C >=0g			with: 0.4 sec continuo us or 4 sec cum

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
	P0114	out of range check (Jump check)	difference: sensor signal - low pass filtered sensor signal for a time	> + / - 0.55 V > 5 sec.	IGNITION	=ON	5 sec.	continuous	2 trips
Mass air flow sensor	P0101	plausibility check low	mass air flow	<0 . . . 190g/sec	general enabling conditions battery voltage time after start crankshaft revolution counter error: throttle position sensor (P0121-P0123,P0221-P0223) error: intake air temperature (P0111-P0114) error: preassure sensor in front of throttle plate (P236-P238) error: camshaft control * error: power stage throttle actuator (P2100-P2103) error: ambient prassure (P2227- P2229) error: electrical failure air flow sensor (P100,P102,P103) error: canister purge valve (P0443,P0458,P0459,P0496,P04 97)	>10.5V >0.3sec >150rev not set not set not set not set not set not set	2 sec	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuo us or 4 sec cum
		plausibility check high	mass air flow	>7 . . . 390 g/sec					
		or fuel trim exceeded a max range limit (multiplicative) and correction factor (ratio modeled air mass at throttle	or delta lambda correction (1 - fuel trim factor) and correction factor air mass	>0.12 <0.85					

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
		to air mass measured by air mass flow meter)			for time	6 sec.			
		or fuel trim exceeded a min range limit (multiplicative) and correction factor (ratio modeled air mass at throttle to air mass measured by air mass flow meter)	or delta lambda correction (1 - fuel trim factor) and correction factor air mass	<-0.12 >1,15	lambda controller deviation ratio: manifold pressure to pressure in front of throttle time after start coolant temperature	< 0.03 < 1 >1 sec >9°C			
	P0101	PCV detection in front of TC correction factor (ratio modeled air mass at throttle to air mass measured by air mass flow meter)	2nd correction factor air mass (higher load - boost)	< 0.869	special enabling conditions multiplicative fuel trim adaption integrator deviation for time lambda controller deviation ratio: manifold pressure to pressure in front of throttle time after start coolant temperature throttle position throttle position	< 0.015 6 sec. < 0.03 < 1 >1 sec >9°C > 30% < 41%			
	P0100	circuit check (short circuit)	duty cylce	0	battery voltage key on	>7.5V > 0.2 sec	0.2 sec	continuous	2 trips with: 0.4 sec continuo us or 4 sec cum
	P0102	circuit check (unsound contact with high frequency)	duty cylce	<32us					

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
	P0103	circiut check (unsound contact with low frequency)	duty cylce	>910us					
pressure sensor upstream throttle valve	P0238	circiuit continuity - high or open	measured sensor voltage	> 4.88 V	engine speed	> 25 rpm	0.5 sec	continuous	2 trips
	P0237	circiuit continuity - low	measured sensor voltage	< 0.45 V					
	P0238	range check - high	measured pressure	> 300 kPa			2 sec		
	P0237	range check - low	measured pressure	< 50 kPa					
P0236	rationality high - comparsion between measured pressure and measured ambient pressure	diefference measured press. (incl. tolerance) minus measured ambient pressure (inc. tolerance)	> 0 hPa	engine speed throttle position error: ambient pressure sensor (rationality) (P2227-P2229) error: ambient pressure sensor (electrical) (P2228,P2229) error: pressure sensor upstream throttle plate (electrical) (P0237,P0238) error: throttle position sensor (P0121-P0123,P0221-P0223)	< 1120 rpm < 10% not set not set not set not set	6 sec	Monitor runs whenever enable conditions are met	2 trips	
									rationality low - comparsion between measured pressure and measured ambient pressure

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
Boost pressure control	P0299	comparison between desired boost pressure and current boost pressure	difference (positive) between set-point boost pressure and measured boost pressure (boost pressure too low)	27kPa	boost pressure control engine speed (NDLDRAPU) atmospheric pressure error: boost pressure sensor(P0236/P0237/P0238) error: throttle control unit (P0121-P0123,P0221- P0223,P2100-P2103) error: air mass flow sensor (P0100-P0103) difference between desired boost pressure - pressure before throttle (ambient pressure minus pressure loss of intake)	active > 2120 ... 3720 rpm > 66 kPa not set not set not set > 0	6 sec	continuous	2 trips
	P0234	comparison between desired boost pressure and current boost pressure	difference (negative) between set-point boost pressure and measured boost pressure or	> 25 kPa to 146.6 kPa	error: boost pressure sensor(P0236/P0237/P0238)	not set	1.2 s	continuous	2 trips
		max check	measured boost pressure (boost pressure too high)	> 220 256 kPa (KLMXDLDR)	intake air temperature	< +30°C	0,30 s	continuous	2 trips

12 OBDG03 Engine Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
Dump valve	P2261	counting of increased pulsation in the intake manifold (increased pulsation may occur when dump valve is jammed in closed position)	normalized difference between measured MAF sensor value and modeled value for number of times	>0,5 > 9 counts	intake air temperature error: intake air temperature (P0111-P0114) error: air mass flow sensor (P0101) conditions for an active supervision phase are Rel. load gradient - ratio of pressure in front of throttle valve to minimum pressure after air filter - dump valve is active	> 15 °C not set not set < 0% > 1.05 to 3.12 TRUE	0.48 sec	Monitor runs whenever enable conditions are met	2 trips
Barometric Pressure Sensor (ambient air pressure sensor)	P2227	rationality signal discontinuity	difference measured press. (incl. tolerance) minus pressure in front of throttle (inc. tolerance) or difference measured press. (incl. tolerance) minus pressure in front of throttle (inc. tolerance)	> 0 hPa < 0hPa	error: pressure sensor in front of throttle (P0236-P0238) error: ambient pressure sensor (electrical) (P2228, P2229) throttle angle engine speed	not set not set < 10% < 1120rpm	9 sec	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuous or 4 sec cum
			barometric pressure jump in a certain time	> 5kPa < 5kPa	difference at start: actual pressure to pressure at last key off error: air mass flow sensor (P0100-P0103) error: intake air temperature (P0111-P0114) error: pressure sensor upstream throttle (P0236-P0238)	> 10kPa not set not set not set	20 sec	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuous or 4 sec cum

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
					error: throttle position sensor (P0121-P0123,P0221-P0223) error: ambient pressure sensor (electrical) (P2228, P2229)	not set not set			
	P2228	range check low	sensor signal sensor voltage	<45kPa < 0.2V	key on	> 0.2 sec	2 sec 0.5 sec	continuous	2 trips with: 0.4 sec continuo us or 4 sec cum
	P2229	range check high	sensor signal sensor voltage	>115kPa >4,8V	key on	> 0.2 sec			
Idle Speed System (disabled during cold start)	P0506 P0507	functional check	desired rpm - actual rpm and idle speed controler limit reached desired rpm - actual rpm and idle speed controler limit reached or fuel cut off due to overspeed during this idle	>100rpm <-200rpm >3count	coolant temp. intake air temp engine speed altitude factor (sea level = 1.0) time after engine start cat heating * intrusive evap test vehicle speed error: throttle control unit (P0121-P0123,P0221-P0223,P2100-P2103) error: crankshaft sensor (P0335, P0336, P0338)	>-11.25° C >-11.25° C at idle >0.703factor > 4 sec. inactive not active = 0 km/h not set not set	10 sec	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuo us or 4 sec cum

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
Idle Speed System (enabled during cold start)	P050A P050A	functional check	desired rpm - actual rpm during catalyst heating on desired rpm - actual rpm during catalyst heating on	>100rpm <-200rpm	Engine coolant start temp. engine speed altitude factor (sea level = 1.0) time after engine start cat heating active * intrusive evap test vehicle speed error: throttle control unit (P0121-P0123,P0221- P0223,P2100-P2103) error: crankshaft sensor (P0335, P0336, P0338)	< 69°C at idle >0.703factor > 100sec. TRUE not active = 0 km/h not set not set	5 sec	Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuo us or 4 sec cum
Vehicle speed sensor	P0503 P0501 P0501 P0501	rationality (high range check) rationality (stuck check) CAN wheel speed message check plausibility check during fuel cut off	vehicle speed for time vehicle speed minus previous vehicle speed CAN wheel speed message corrupt or missing vehicle speed engine speed (NDV, NDV0) for a time	> 170.87mph > 0.2 sec. =0mph =corrupt =missing < 3.107 mph 3000 - 1400 rpm > 4 sec.	vehicle speed vehicle speed time Fuel system status coolant temperature	> 6.213 mph < 317.51 mph >10sec Fuel cut > 64.5 °C	0.4 sec continuous or 4 sec cumulative	continuous Monitor runs whenever enable conditions are met	2 trips with: 0.4 sec continuo us or 4 sec cum

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
	P0501	plausibility check	vehicle speed engine load for a time	< 2.485 mph > 80.3 % > 4 sec.	coolant temperature all injectors active engine speed	> 64.5 °C > 0,8 ms > 3520 rpm			
Crankshaft Position Sensor	P0335	circuit continuity	no engine signal but phase signals available	=0rpm	camshaft revolutions detected	>12counts	approx. 5 sec	0.01 sec continuous	1 trip with: 0.4 sec continuo us or 4 sec cum
		rationality check	reference gap missing (sensor signal but no reference)	>=6gaps	engine speed signal detected	> 1 rev			
	P0336	rationality check	unexpected re- synchronization (loss of reference mark)	>6count					
		rationality check	intermittent loss of engine speed signal	> 10 count					
	P0338	rationality check	difference in counted teeth between reference gap position events	>8teeth			approx. 2 sec	1 per rev continuous	1 trip 0.4 s cont. or 4 s cum.
Camshaft Position Sensor Bank 1 Intake	P0342	circuit low	differenece between 2 workingcycles depending on engine speed (KLPHNOKA)	< 1 teeth > 8 - 72 count	engine in synchronized mode	TRUE	10 revolutions	1 per rev continuous	2 trips
	P0343	circuit continuity or high	differenece between 2 workingcycles depending on engine speed (KLPHNOKA)	> 1 teeth > 8 - 72 count					
	P0341	plausibility check	differenece between 2 workingcycles depending on engine speed (KLPHNOKA)	> 1 or < 1 teeth > 8 - 72 count					

12 OBDG03 Engine Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
Bank 1 Exhaust	P0341	signal check	no cam position sensor signal	> 6 count					
	P0366	circuit low	differenece between 2 workingcycles depending on engine speed (KLPHNOKA)	< 1 teeth > 8 - 72 count	engine in synchronized mode	TRUE			
	P0367	circuit continuity or high	differenece between 2 workingcycles depending on engine speed (KLPHNOKA)	> 1 teeth > 8 - 72 count					
	P0368	plausibility check	differenece between 2 workingcycles depending on engine speed (KLPHNOKA)	> 1 or < 1 teeth > 8 - 72 count					
	P0366	signal check	no cam position sensor signal	> 6 count					
Bank 2 Intake	P0346	circuit low	differenece between 2 workingcycles depending on engine speed (KLPHNOKA)	< 1 teeth > 8 - 72 count	engine in synchronized mode	TRUE			
	P0347	circuit continuity or high	differenece between 2 workingcycles depending on engine speed (KLPHNOKA)	< 1 teeth > 8 - 72 count					
	P0348	plausibility check	differenece between 2 workingcycles depending on engine speed (KLPHNOKA)	< 1 teeth > 8 - 72 count					
	P0346	signal check	no cam position sensor signal	> 6 count					
	P0391	plausibility check	differenece between 2 workingcycles depending on engine speed (KLPHNOKA)	< 1 teeth > 8 - 72 count	engine in synchronized mode	TRUE			
Bank 2 Exhaust	P0392	circuit low	differenece between 2 workingcycles depending on engine speed (KLPHNOKA)	> 1 teeth > 8 - 72 count					

12 OBDG03 Engine Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
	P0393	circuit continuity or high	differenece between 2 workingcycles	> 1 or < 1 teeth					
	P0391	signal check	depending on engine speed (KLPHNOKA) no cam position sensor signal	> 8 - 72 count > 6 count					
Fuel tank pressure sensor	P0450	rationality - sensor signal change within time (oscillation check)	fuel tank pressure difference within for integrated time	>= 406.25 Pa = 1 sec >= 25.5 sec	time after canister vent valve open vehicle speed calc. ambient temperature canister purge flow (closed) time after purge valve closes	> 4 sec. ≤ 62.13 mph > -7.5 °C ≤ 0 g/sec > 0.2 sec.	4,5	continous	2 trips
	P0451	rationality - signal range check OR rationality - drift check	change of fuel tank pressure difference between fuel tank pressure and fuel tank pressure at engine start	> 1469 Pa < -3968 Pa > +/- 688 Pa	time after engine start time after canister vent valve open vehicle speed for time and integrated purge mass flow calculated ambient air temperature ambient pressure fuel level fuel level time after engine start Vent solenoid valve open Caniter purge flow (closed) ambient pressure fuel level fuel level Vehicle speed for time and integrated purge mass flow Vehicle speed	> 1 sec. > 4 sec. > 6.25 mph >= 30 sec. >= 0.3 g > -7.5 °C > 68000 Pa < 76 l > 11 l > 5 sec. TRUE ≤ 0 g/sec > 68000 Pa < 76 l > 11 l > 6.25 mph >= 30 sec. >= 0.3 g ≤ 62.13 mph	10 sec. 7 sec.		

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
					Canister load calculated ambient air temperature difference (ECT at start - ambient temperature)	< 6 3.8 < ... < 39.8 °C < 9.8°C			
	P0452	circuit continuity - ground	sensor voltage	< 0.1 V	Engine cranking	FALSE	10 sec	continuous	2 trips
	P0453	circuit continuity - voltage	sensor voltage	> 4.9 V					
Knock control sensor's evaluation IC Bank 1	P0327	Monitoring via knock- sensor- and cylinder-based basic reference noise signal (voltage).	Cylinder individual signal value (UDKSNU) (depends on engine speed) Cylinder individual signal value (UDKSNO) (depends on engine speed)	< 0.15015 - 0.29297 V	Knock control is active.	TRUE	0,3 sec	continuous	2 trips
				engine coolant tempetature	> 45 °C				
	P0328		> 5 .. 18,6 V	engine load (lower treshold) Engine speed for strong signals. Engine speed for weak signals.	35 - 65 % > 2520 rpm > 2520 rpm				
	P0326	non plausible signal		> 25 counts	Error: Camshaft sensor (during engine start) Engine speed gradient at a working cycle (NGKRWN) delta partial pressure (10 ms grid) in manifold (KFDYESPF) Error: knock-control circuit (P0324) error: crankshaft sensor (P0335, P0336, P0338)	not set < 1400 ... 3700 1/min*sec. < 20 ... 35 hPa not set not set			
Bank 2	P0332	Monitoring via knock- sensor- and cylinder-based basic reference noise signal (voltage).	Cylinder individual signal value (UDKSNU) (depends on engine speed) Cylinder individual signal value (UDKSNO) (depends on engine speed)	< 0.15015 - 0.29297 V	Knock control is active.	TRUE	0,3 sec	continuous	2 trips
				engine coolant tempetature	> 45 °C				
	P0333			> 5 .. 18,6 V	engine load (lower treshold) Engine speed for strong signals.	35 - 65 % > 2520 rpm			

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
	P0331	non plausible signal		> 25 counts	Engine speed for weak signals. Error: Camshaft sensor (during engine start) Engine speed gradient at a working cycle (NGKRWN) delta partial pressure (10 ms grid) in manifold (KFDYESPF) Error: knock-control circuit (P0324) error: crankshaft sensor (P0335, P0336, P0338)	> 2520 rpm not set < 1400 ... 3700 1/min*sec. < 20 ... 35 hPa not set not set			
Knock control sensor's evaluation IC	P0324	Parity Check	number of counts	> 5 counts	knock control active	TRUE	250 working	Zero and	2 trips
		monitoring of the coefficient RAM of the IC	out of combustions events	600	Engine speed gradient at a working cycle (NGKRWN) delta partial pressure (10 ms grid) in manifold error suspicison: knock control test pulse (P0324) engine speed	< 1400 ... 3700 1/min*sec. < 20 ... 35 hPa not set > 2000 rpm	cylces	Test pulse alternate every 250 working cycles.	
	P0324	Response to Zero Pulse monitor IC's integrator gradient	integrator gradient	< 200 V/s	same as for IC integrator's offset monitoring				
	P0324	Response to Test Pulse integrator value check	integrator value of test pulse	< 4.0 V	coolant temperature Engine speed gradient at a working cycle (NGKRWN) delta partial pressure (10 ms grid) in manifold (KFDYESPF) error suspicison: knock control zero test (P0324)	> 45 °C < 1400 ... 3700 1/min*sec. < 20 ... 35 hPa not set			

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
fuel injector cylinder #1	P0201	circuit continuity - open	Voltage	IC internal	engine speed	> 80 rpm	immediately	continuous	2 trips
	P0261	circuit continuity - ground			battery voltage	> 9,99 V			
cylinder #2	P0262	circuit continuity - voltage			battery voltage	< 17,90 V			
	P0202	circuit continuity - open			output activated and				
	P0264	circuit continuity - ground			deactivated for complete				
cylinder #3	P0265	circuit continuity - voltage			checking	TRUE			
	P0203	circuit continuity - open							
cylinder #4	P0267	circuit continuity - ground							
	P0268	circuit continuity - voltage							
	P0204	circuit continuity - open							
cylinder #5	P0270	circuit continuity - ground							
	P0271	circuit continuity - voltage							
	P0205	circuit continuity - open							
cylinder #6	P0273	circuit continuity - ground							
	P0274	circuit continuity - voltage							
	P0206	circuit continuity - open							
	P0276	circuit continuity - ground							
	P0277	circuit continuity - voltage							
canister ventilation valve	P0449	circuit continuity - open	Voltage	IC internal	engine speed	> 80 rpm	immediately	continuous	2 trips
	P0498	circuit continuity - ground			battery voltage	> 9,99 V			

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
	P0499	circuit continuity - voltage			battery voltage output activated and deactivated for complete checking	< 17,90 V TRUE			
canister purge valve	P0443 P0458 P0459	circuit continuity - open circuit continuity - ground circuit continuity - voltage	Voltage	IC internal	engine speed battery voltage battery voltage output activated and deactivated for complete checking	> 80 rpm > 9,99 V < 17,90 V TRUE	immediately	continuous	2 trips
upstream oxygen sensor heater Bank #1	P0030 P0031 P0032	circuit continuity - open circuit continuity - ground circuit continuity - voltage	Voltage	IC internal	engine speed battery voltage battery voltage output activated and deactivated for complete checking	> 80 rpm > 9,99 V < 17,90 V TRUE	immediately	continuous	2 trips
downstream oxygen sensor heater Bank #1	P0036 P0037 P0038	circuit continuity - open circuit continuity - ground circuit continuity - voltage	Voltage	IC internal	engine speed battery voltage battery voltage output activated and deactivated for complete checking	> 80 rpm > 9,99 V < 17,90 V TRUE	immediately	continuous	2 trips

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
secondary air pump	P2444	circuit continuity - open	Voltage	IC internal	engine speed	> 80 rpm	immediately	continuous	2 trips
	P2445	circuit continuity - ground			battery voltage	> 9,99 V			
	P0418	circuit continuity - voltage			battery voltage	< 17,90 V			
					output activated and deactivated for complete checking	TRUE			
intake camshaft control Intake Bank #1	P0010	circuit continuity - open	Voltage	IC internal	engine speed	> 80 rpm	immediately	continuous	2 trips
	P2088	circuit continuity - ground			battery voltage	> 9,99 V			
Intake Bank #2	P2089	circuit continuity - voltage			battery voltage	< 17,99 V			with: 0.4 sec continuo us or 4 sec cum
	P0020	circuit continuity - open			output activated and				
	P2092	circuit continuity - ground			deactivated for complete				
	P2093	circuit continuity - voltage			checking	TRUE			
exhaust camshaft control Exhaust Bank #1	P0013	circuit continuity - open							
Exhaust Bank #1	P2090	circuit continuity - ground							
	P2091	circuit continuity - voltage							
	P2095	circuit continuity - voltage							
Exhaust Bank #2	P0023	circuit continuity - open							
	P2094	circuit continuity - ground							
Dump valve turbo	P0033	circuit continuity - open	Voltage	IC internal	engine speed	> 80 rpm	immediately	continuous	2 trips
	P0034	circuit continuity - ground			battery voltage	> 9,99 V			

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
	P0035	circuit continuity - voltage			battery voltage output activated and deactivated for complete checking	< 17,90 V TRUE			
Boost control valve	P0244	circuit continuity - open	Voltage	IC internal	engine speed	> 80 rpm	immediately	continuous	2 trips
	P0245	circuit continuity - ground			battery voltage	> 9,99 V			
	P0246	circuit continuity - voltage			battery voltage output activated and deactivated for complete checking	< 17,90 V TRUE			
Ignition Coil circuit continuity Cylinder #1	P0351	circuit continuity - open or signal not plausible		>2 sec	engine speed	> 400rpm	approx.	engine	2 trips
			Voltage > during or minimum two fault counters		engine speed	<5000rpm	1 sec	cycle	with: 0.4 sec
	P2300	circuit continuity - ground		>2 sec	battery voltage	>10V		frequency	continuo us
Cylinder #2	P2301	circuit continuity - voltage		>2 sec	battery voltage	<18V			or 4 sec cum
	P0352	circuit continuity - open or signal not plausible		>2 sec				continuous	
			Voltage > during or minimum two fault counters						
	P2303	circuit continuity - ground		>2 sec					
	P2304	circuit continuity - voltage		>2 sec					
Cylinder #3	P0353	circuit continuity - open		>2 sec					
			Voltage > during or minimum two fault counters						
	P2306	circuit continuity - ground		>2 sec					
			Voltage > during						

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
Cylinder #4	P2307	circuit continuity - voltage	Voltage > during	>2 sec					
	P0354	circuit continuity - open	Voltage > during or minimum two fault counters	>2 sec					
Cylinder #5	P2309	circuit continuity - ground	Voltage > during	>2 sec					
	P2310	circuit continuity - voltage	Voltage > during	>2 sec					
	P0355	circuit continuity - open	Voltage > during or minimum two fault counters	>2 sec					
Cylinder #6	P2312	circuit continuity - ground	Voltage > during	>2 sec					
	P2313	circuit continuity - voltage	Voltage > during	>2 sec					
	P0356	circuit continuity - open	Voltage > during or minimum two fault counters	>2 sec					
	P2315	circuit continuity - ground	Voltage > during	>2 sec					
	P2316	circuit continuity - voltage	Voltage > during	>2 sec					
cold start ignition timing performance (during catalyst heating)	P050B	ignition timing efficiency to small during idle	averaged difference between current ignition efficiency and desired ignition efficiency	> 25%	condition idle desired ignition efficiency cat heating * time delay for activation altitude factor (sea level = 1.0) engine speed deviaton engine load dynamic vehicle speed engine load fuel system status	TRUE < 88% active 3 sec >0.703factor < 80rpm < 5% = 0 < 90% no fuel cut	10 sec cumulative	Monitor runs whenever enable conditions are met	2 trips

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
		ignition timing efficiency to small during part load	averaged difference between current ignition efficiency and desired ignition efficiency	> 25%	condition idle desired ignition efficiency cat heating * time delay for activation altitude factor (sea level = 1.0) engine speed deviaton engine load dynamic vehicle speed fuel system status	FALSE < 97% active 3 sec >0.703factor < 80rpm < 5% > 1,3 mph no fuel cut			
Electronic Throttle Control	P0638	motor control range check short term	powerstage duty cycle for a time	>80% >0.6 sec.	battery voltage	> 8V	0.6 sec (recoverable)	0.01 sec continuous	immediat e
	P0638	motor control range check long term	(absolute value) for a time	>80% > 5 sec.	engine speed coolant temperature intake air temperature	> 400 rpm > 5.3 °C > 5.3 °C	5.0 sec (latched)		
Electronic Throttle Control	P1551	limp-home throttle position out of range	throttle position OR throttle position	< 11.3909% > 38.7808%	vehicle speed engine speed engine coolant temperature engine coolant temperature intake air temperature intake air temperature battery voltage accelerator pedal position	<=0mph < 250rpm >= 5.3° C <=84.75° C >= 5.3° C <=60° C > 8V <14.9%	5 sec	0.01 sec at key on	immediat e
Electronic Throttle Control									

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
	P2100 P2103 P2102 P2101	powerstage SPI bus or signal error powerstage short circuit powerstage overheating or overcurrent powerstage open load	output circuits not deactivated as commanded	=deactivationfault		---	0.1 sec	0.01 sec at key on	immediate
	P2101	difference between set and actual position of throttle blade	difference between set and actual position of throttle blade for a time	>4 . . . 50% (DWDKSBAMX) dep. on rate of change > 0.5 sec.	electronic throttle adaptation battery voltage	not active > 8V	0.5 sec	0.01 sec continuous	
Electronic Throttle Control	P2119	functionality of return spring	throttle blade return response	>0.56sec	vehicle speed engine speed engine coolant temperature engine coolant temperature intake air temperature intake air temperature battery voltage accelerator pedal position	<=0mph < 250rpm >= 5.3° C <=84.75° C >= 5.3° C <=60° C > 8V <14.9%	0.56 sec	0.01 sec at key on once per ignition on	immediate
Electronic Throttle Control	P2176 P2176 P2176 P2176	throttle exchange detection learn fail or minimum throttle position out of range or initial throttle learn failed or learning prohibited due to	range check poti1 value at lower stop throttle potentiometer 1 voltage or throttle potentiometer 1 voltage or range check poti2 value at lower stop throttle potentiometer 2 voltage or throttle potentiometer 2 voltage	< 4.102 V > 4.5642 V < 0.3369 V >1.0 V	vehicle speed engine speed engine coolant temperature engine coolant temperature intake air temperature intake air temperature battery voltage accelerator pedal position	<=0mph <40rpm >=5.3° C <=100° C >=5.3° C <=143.3° C >9.99V <14.9%	1 sec	0.01 sec at key on once per ignition on	immediate

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
		secondary parameters not met							
Throttle Position Sensor 1 (primary)	P0121	plausibility to model	sensor difference	>9%	engine speed	> 480 rpm	0.4 sec. continuous	continuous	1 trip with: 0.4 sec continuo us or 4 sec cum
			for a time	> 0.28 sec.	accelerator pedal (WOT)	< 48 ... 100%			
					vehicle speed	<=0mph			
	P0122	range check poti voltage	sensor circuit low voltage	<0.176V	vehicle speed	<=0mph			
			for a time	> 0.14 sec	engine speed	< 250rpm			
			sensor circuit high voltage	>4.629V	engine coolant temperature	>=5.3° C			
P0123	range check poti voltage	for a time	> 0.14 sec	intake air temperature	>= 5.3° C				
				battery voltage	>8V				
Sensor 2 (redundant)	P0221	plausibility to model	sensor difference	>9%	engine speed	> 480 rpm	0.4 sec. continuous	continuous	1 trip with: 0.4 sec continuo us or 4 sec cum
			for a time	> 0.28 sec.	accelerator pedal (WOT)	< 48 ... 100%			
					vehicle speed	<=0mph			
	P0222	range check poti voltage	sensor circuit low voltage	<0.156V	vehicle speed	<=0mph			
			for a time	> 0.14 sec	engine speed	< 250rpm			
			sensor circuit high voltage	>4.883V	engine coolant temperature	>=5.3° C			
P0223	range check poti voltage	for a time	> 0.14 sec	intake air temperature	>= 5.3° C				
				battery voltage	>8V				

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
Function Monitoring of Microcontroller (PCM level 2 command check)	P0606	torque comparison	irreversible error of torque comparison (current and maximum allowed engine torque out of range)	TRUE	engine speed	>1200rpm	5sec	continuous	immediat e
		engine speed comparison	irreversible error of engine speed comparison (calculated and measured engine speed out of range)	TRUE	engine speed	>1200rpm			
		accelerator pedal signal comparison	irreversible error of accelerator pedal signal comparison (synchronism between the two pedal sensors out of range)	TRUE	engine speed	>1200rpm			
		monitoring of AD converter queue	irreversible error of AD- converter queue monitoring (queue not running)	TRUE	engine speed	>1200rpm			
		check of AD-converter signal	irreversible error of AD- converter signal check (converted low voltage test impuls out of range)	TRUE	engine speed	>1200rpm			
		check of ignition timing	irreversible error of comparison of ignition timing value (comparison of ignition timing value with its one's complement is wrong)	TRUE	engine speed	>1200rpm			
		verification of engine load value	irreversible error of engine load value verification (engine load value and verification	TRUE	engine speed	>1200rpm			

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
			value are not identical)						
		monitoring of injected fuel mass	irreversible error of fuel mass (calculated and measured requested fuel mass out of range)	TRUE	engine speed	>1200rpm			
		monitoring of mixture correction factor	irreversible error of mixture correction factor (adapted fuel mixture is out of range)	TRUE	engine speed	>1200rpm			
		monitoring of desired air/fuel ratio	irreversible error of air/fuel ratio (desired air/fuel ration is out of range)	TRUE	engine speed	>1200rpm			
	P2105	function controller response check	monitoring module has detected a fault of function controller	TRUE	engine speed	>1200rpm			
		watchdog output signal check	WDA signal activated	TRUE					
		overvoltage detection	internal supply voltage exceeded	TRUE					
ECM Monitoring	P0605	rationality check - verification of ROM checksum	wrong ROM checksum	5-times TRUE	PCM after-run time of the last driving cycle completely finished	TRUE	30 sec	at key off once per trip	immediate
	P0605	rationality check - verification of ROM checksum	wrong cyclic ROM checksum of critical regions	TRUE	partialchecksum on critical variables		5 sec	0.04 sec continuous	immediate
	P0604	writeability check of RAM	RAM read and write test failed	TRUE	PCM after-run time of the last driving cycle completely finished	TRUE	30 sec	at key off once per trip	immediate
	P0604	writeability check of RAM	cyclic RAM read and write test of critical regions failed	TRUE	power down calculation in the last driving cycle	TRUE	1 sec	0.04 sec continuous	immediate

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
					completely finished				
	P0603	rationality check - programming incomplete	shut down of power stages not possible	service ECU bits TRUE			0.05 sec	at key on once per trip	immediate
	P0603	writeability check of Time Processing Unit (TPU) parameter RAM	TPU parameter RAM read and write test failed	TRUE			0.05 sec	at key on once per trip	immediate
	P0603	rationality check - verification of Time Processing Unit (TPU) code RAM checksum	wrong TPU code RAM checksum	TRUE			0.3 sec	0.1 sec continuous	immediate
	P0603	rationality check - time difference check	difference between Time Processing Unit time and PCM time	> 0.001 sec			0.3 sec	0.1 sec continuous	immediate
Accelerator pedal position sensor	P 2123	range check high	accelerator position sensor voltage 1 for a time	> 4.824 V > 0.2 sec.	battery voltage is sufficient for 5V accelerator sensor supply	> 8V	0,4s	continuous	immediate with: 0.4 sec continuous
	P 2122	range check low	accelerator sensor voltage 1 and accelerator sensor voltage 2 for a time or accelerator sensor voltage 1	< 0.742 V < 0.625 V > 0.2 sec. < 0.742 V	condition upper limit violated (see max fault path of FP2P) (P2128) condition upper limit violated (see max fault path of FP1P) (P2123) battery voltage is sufficient for 5V accelerator sensor supply error reaction accelerator-travel sensor limphome (P2127,P2128) primary conditions for absolute difference check (P2138) error reaction accelerator-travel sensor limphome	FALSE FALSE > 8V FALSE TRUE FALSE		or 4 sec cum	

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
			for time	> 0.2 sec	synchronization between voltages 1 and 2 violated (see values of absolute difference in accelerator sensor voltages depending on ranges in FP1 FP1P absolute difference check below high contact resistance at accelerator voltage 1	TRUE FALSE			
	P 2138	absolute difference check fault time	absolute difference between both accelerator sensor voltages in the range from 1.191 V to 1.25 V or absolute difference between both accelerator sensor voltages in the range from 1.25 V to 2.637 V or absolute difference between both accelerator sensor voltages in the range above 2.637 V and fulfilled for the time	> 0.254 V > 0.313 V > 1.699 V > 0.24 sec	condition lower limit violated (see min fault path of FP1P) (P2122) condition lower limit violated (see min fault path of FP2P) (P2127) error reaction accelerator-travel sensor limphone (P2127,P2128) battery voltage is sufficient for 5V accelerator sensor supply condition upper limit violated (see max fault path of FP2P) (P2128) condition upper limit violated (see max fault path of FP1P) (P2123)	FALSE FALSE FALSE > 8V FALSE FALSE			
	P 2128	range check high fault time	accelerator sensor voltage for a time	> 4.824 V > 0.2 sec.	battery voltage is sufficient for 5V accelerator sensor supply	> 8V			

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
	P 2127	range check low	accelerator sensor voltage 1 and accelerator sensor voltage 2 for time or accelerator sensor voltage 2 for time	< 0.742 V < 0.625 V > 0.2 sec. < 0.625 V > 0.2 sec	condition upper limit violated (see max fault path of FP2P) (P2122) condition upper limit violated (see max fault path of FP1P) (P2127) battery voltage is sufficient for 5V accelerator sensor supply error reaction accelerator-travel sensor limphone (P2127,P2128) primary conditions for absolute difference check (P2138) error reaction accelerator-travel sensor limphone (P2127,P2128) synchronization between voltages 1 and 2 violated (see values of absolute difference in accelerator sensor voltages depending on ranges in FP1 FP2P absolute difference check below) high contact resistance at accelerator voltage 1 (P2128)	FALSE FALSE > 8V FALSE TRUE FALSE TRUE FALSE			
Transmission Control Module MIL Illumination requested (Specific TCM DTC shown in freeze frame)	P0700	OBD emission fault detected by the TCM	signal input	=TCM MILFAULT	-	---	0.01 sec	0.01 sec continuous	immediat e

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
demand controlled fuel supply (FSCM) MIL Illumination requested	P069E	OBD emission fault detected by the FSCM	signal input	=FSCM MILFAULT	-	---	0.01 sec	0.01 sec	immediate
OBD ISO-15765 Communication Bus	U0101	Communication with TCM	TCM Message Timeout	=message	Automatic Transmission	equipped	5 sec	0.01 sec	immediate
	U0402		or Invalid Message Content	=missing, delayed, or invalid content	CAN Bus consisting of: ignition on for battery voltage battery voltage normal bus communication	initialized and ready >3sec >10V <18V running	continuous		
	U0073	ISO-15765 Bus Error	Invalid Message Received or Dual Port Ram Hardware Error; or No Communication / Bus Off	=invalid =error =bus off	CAN Bus consisting of: ignition on for battery voltage battery voltage normal bus communication	initialized and ready >3sec >10V <18V running--	0.5 sec 0.01 sec 0.03	0.01 sec continuous	immediate
	U0109	Communication with FSCM	FSCM Message Timeout or Invalid Message Content	=message =missing, delayed, or invalid content	FSCM CAN Bus consisting of: ignition on for battery voltage battery voltage normal bus communication	equipped-- initialized-- and ready >3sec >10V <18V running	2 sec	0.01 sec continuous	immediate
Diagnosis Tuning Recognition	P160D	Engine performance identification	internal performance comparison external performance comparison (CAN)	+/- 2 kW +/- 2 kW	engine speed	TRUE	5 sec.	1 sec. continuous	immediate

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
Diagnosis of ECU programming: RPO	P160E	ECU RAM check	Diagnosis programming of Engine System Regular Production Option Identifier	IC internal	ignition on	TRUE	2 sec.	1 sec. continuous	immediate
Diagnosis of ECU programming: "Service ECU"	P0602	ECU RAM check	Codeword: calibration for service ECM	>0			4 sec.	continuous	
Diagnosis of ECU programming: "Variantcode"	P0610	ECU RAM check	variant code not programmed	IC internal			2 sec.		
Diagnosis of ECU programming: "VIN"	P0630	ECU RAM check	vehicle identification number not programmed	IC internal			2 sec.		
Fuel level sensor	P0463	fuel level sensor short circuit to battery voltage	sensor voltage	> 4.75 V	general enabling conditions battery voltage battery voltage	 >10V <18V	2 sec.	continuous	2 trips with: 0.4 sec continuous or 4 sec cum
	P0462	fuel level sensor short circuit to ground	sensor voltage for a time	< 0.25 V			2 sec.		
	P0461	fuel level sensor stuck	fuel level stays in a band of for a distance of	2 l	special enabling conditions Error: fuel level sensor (P0461-P0463) Error: secondary fuel level sensor (P2066-P2068) error: vehicle speed sensor (P0501-P0503) engine speed	not set not set not set > 80 rpm	279.6 miles		

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
Diagnosis Tank 2 - fuel level sensor	P2068	secondary fuel level sensor short circuit to battery voltage	sensor voltage for a time	> 4.75 V	general enabling conditions battery voltage battery voltage	 >10V <18V	2 sec.	continuous	2 trips with: 0.4 sec continuo us or 4 sec cum
	P2067	secondary fuel level sensor short circuit to ground	sensor voltage for a time	< 0.25 V			2 sec.		
	P2066	secondary fuel level sensor stuck	fuel level stays in a band of for a distance of	2 l	special enabling conditions Error: fuel level sensor (P0461- P0463) Error: secondary fuel level sensor (P2066-P2068)	not set not set	85.75 miles		
	P2066	Transfer pump failure	fuel level primary tank and secondary fuel tank level for a time	< 4 l > 16 l > 250 sec.	error: vehicle speed sensor (P0501-P0503) engine speed	not set > 80 rpm	250 sec.		
Ignition driver 1	P06D1	Internal SPI communication	IC-Internal		Engine speed	< 5000 rpm	4 sec.	0.01 sec.	2 trips
					Battery voltage	> 10 V		continuous	
					Battery voltage	< 18 V			
5V reference voltage monitoring	P0641	circuit continuity - open	Voltage	IC Internal	ignition key on	TRUE		3 sec	2 trips
	P0642	circuit continuity - ground			ECM power relay	TRUE			
	P0643	circuit continuity - voltage							
	P0651	circuit continuity - open	Voltage	IC Internal					

12 OBDG03 Engine Diagnostics

ECM SECTION
1 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
	P0652	circuit continuity - ground							
	P0653	circuit continuity - voltage							
	P0697	circuit continuity - open	Voltage	IC Internal					
	P0698	circuit continuity - ground							
	P0699	circuit continuity - voltage							
Real time clock Engine off timer Status Check	P2610	engine off timer signal check	engine off timer state >= (State 3 corresponds to engine off time which does not match the time from the ETC watchdog time, and a battery disconnection has not been detected)	3	engine speed real time clock active	> 240 rpm TRUE		0.1 sec.	2 trips
Real time clock Engine off timer Rationality check	P2610	engine off timer incremental check	reference clock time delta - Engine Off Timer delta reference clock time delta - Engine Off Timer delta or reference clock and Engine Off Timer (EOT) required synchronization time >	> 6 counts < 6 counts > 6 seconds	engine speed failure counts engine speed failure counts ECM afterrun complete	> 240 rpm >= 3 counts > 240 rpm >= 3 counts TRUE		0.1 sec.	2 trips

12 OBDG03 Engine Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Primary Malfunction Signal and Criteria	Threshold Conditions	Secondary Parameters	Enable Conditions	Time Required	Frequency of Checks	MIL Illum.
			(reference clock is an independently captured time value based on the ECM processor clock)						
Brake Pedal Position Sensor Circuit Low	P057C		Brake Pedal Position Sensor Voltage	< 0.25V	none			0.5 sec	2 trips
Brake Pedal Position Sensor Circuit High	P057D		Brake Pedal Position Sensor Voltage	>4.75V	none			0.5 sec	2 trips
end							* see glossary of secondary parameter		

12 OBDG03 Engine Diagnostics

Engine Support Tables

P0011, P0021, P000A,
P000C
P0021, P0024, P000B,
P000D

KFDWNWDMXE (internal manufacturer cross reference)

KFDWNWDMXA (internal manufacturer cross reference)

Maximum Allowed Deviation - Intake Camshaft Position

degrees crank	Modeled Engine Oil Temperature (° C)				
Engine Speed (rpm)	800	2000	4000	6000	129.9984375
800	6.00	6.00	7.00	9.00	11.00
1200	6.00	6.00	6.00	6.00	7.00
1600	6.00	6.00	6.00	6.00	7.00
2000	6.00	6.00	6.00	6.00	6.00
2500	6.00	6.00	6.00	6.00	6.00
4000	6.00	6.00	6.00	6.00	6.00

KFTDDNWNPE (internal manufacturer cross reference)

Maximum Allowed Deviation - Intake Camshaft Position

degrees crank	Engine Speed (rpm)			
Modeled Engine Oil Temperature (° C)	800	2000	4000	6000
-30	2.00	2.00	2.00	2.00
20	1.60	1.60	1.60	1.60
40	1.20	1.20	1.20	1.20
110	1.20	1.20	1.20	1.20
120	1.20	1.20	1.20	1.20

KFTDDNWNPA (internal manufacturer cross reference)

Maximum Allowed Deviation - Intake Camshaft Position

degrees crank	Engine Speed (rpm)			
Modeled Engine Oil Temperature (° C)	800	2000	4000	6000
-30	2.00	2.00	2.00	2.00
20	1.60	1.60	1.60	1.60
40	1.50	1.50	1.50	1.50
110	1.50	1.50	1.50	1.50
120	1.50	1.50	1.50	1.50

P0111

KLTF1ML (internal manufacturer cross reference)

Minimum airmass to enable the stuck check monitor

temperature difference engine coolant - ambient temperature (°C)	-30	-9.75	0
airmass (kg)	15.019	11.014	4.005

P0128

TWADTHMS (internal manufacturer cross reference)

Engine start temperature depend. time for freezing temperature model of thermostat monitoring

	Engine Coolant Temperature at start (°C)					
	-48.00	-40.50	-33.00	-10.50	12.00	27
Time (sec)	22.00	18.00	16.00	16.00	16.00	16.00

P0134

(internal manufacturer cross reference)

USDB0 Minimum Voltage for evaluation **0.400 V**
USREF Maximum Voltage for evaluation cold sensor **0.600 V**
USREFHOT Maximum Voltage for evaluation hot sensor **0.550 V**

P0130

USMIN Minimum Voltage for evaluation **0.060 V**
USREMH Maximum Voltage for evaluation **0.400 V**
USREFHCLT Minimum Voltage for evaluation **0.600 V**
USMAX Maximum Voltage for evaluation **1.080 V**

12 OBDG03 Engine Diagnostics

Engine Support Tables

P0133 (internal manufacturer cross reference)

NTPKTU	Minimum engine speed	1000.000 rpm
NTPKTO	Maximum engine speed	3000.000 rpm
RLTPVKU	Minimum load	18.000 %
RLTPVKO	Maximum load	79.500 %

P0135 KFRINV (internal manufacturer cross reference)

Sensor Element (Ceramic) Impedance, Nominal Value - Secondary O2 Sensor

Ohms	Modeled Exhaust Gas Temperature at Secondary O2 Sensor (° C)				
Normalized Heater Power	299.990625	374.990625	449.990625	524.990625	599.990625
0.68	328	256	192	136	104
0.78	232	192	144	112	88
1.00	136	120	104	88	88

FRINV1 (internal manufacturer cross reference)

Multiplication Factor for Internal Resistance KFRINH Nominal Value - Secondary O2 Sensor

	Modeled Exhaust Gas Temperature at Secondary O2 Sensor (° C)				
	269.990625	350.00625	429.9984375	509.990625	590.00625
factor	20.00	10.00	5.00	3.00	3.00

(internal manufacturer cross reference)

TADHMNV	Minimum modelled exhaust temperature	300 °C
TADHMXV	Maximum modelled exhaust temperature	550 °C

P0141 KFRINH (internal manufacturer cross reference)

Sensor Element (Ceramic) Impedance, Nominal Value - Secondary O2 Sensor

Ohms	Modeled Exhaust Gas Temperature at Secondary O2 Sensor (° C)				
Normalized Heater Power	300	375	450	525	600
0.68	560	424	344	272	208
0.78	344	288	240	200	176
1.0	184	168	152	136	120

FRINH1 (internal manufacturer cross reference)

Multiplication Factor for Internal Resistance KFRINH Nominal Value - Secondary O2 Sensor

	Modeled Exhaust Gas Temperature at Secondary O2 Sensor (° C)				
	270	350	430	510	590
factor	30.00	20.00	10.00	6.00	4.00

(internal manufacturer cross reference)

TADHMNH	Minimum modelled exhaust temperature	350 °C
TADHMXH	Maximum modelled exhaust temperature	550 °C

P0234 KLMXDLDLDR (internal manufacturer cross reference)

Error threshold for absolute boost pressure too high

Intake air temperature (°C)	-48	-21	6.75	30	61.5	88.5	116.25	143.25
pressure threshold (kPa)	2200	2300	2400	2560	2560	2560	2560	2560

P0299 NDLDRAPU (internal manufacturer cross reference)

Engine speed threshold to enable diagnosis

ambient pressure (hPa)	600	980
engine speed (1/min)	3720	2120

12 OBDG03 Engine Diagnostics

Engine Support Tables

P0300, P0301, P0302
P0303, P0304, P0305,
P0306

MISALUN (internal manufacturer cross reference)
Indicated drive torque for enabling the misfire monitor

	Engine Speed (RPM)							
	600.00	1320.00	2400.00	3120.00	3800.00	4720	5520	6120
Torque (%)	5.47	8.20	9.77	10.94	12.89	16.015625	18.75	20.70313

NGALUN (internal manufacturer cross reference)
Engine Speed Gradient for disabling the misfire monitor

	Engine Speed (RPM)							
	600.00	1320.00	2400.00	3120.00	3800.00	4720	5520	6120
Engine Speed Gradient (RPM / s)	12799.99	12799.99	12799.99	12799.99	12799.99	12799.99	12799.99	12799.99

KFKSWFS (internal manufacturer cross reference)
Misfire Weighing Factors for Catalyst Protector

	Indicated Engine Torque					
Engine Speed (RPM)	14.84375	30.078125	39.84375	50	60.15625	75
1000	32	32	32	32	37	37
2000	32	32	37	32	37	59
3000	32	32	37	37	48	48
4000	32	37	43	53	69	64
5000.00	32	43	59	75	85	85
6000.0	32	59	96	107	114	80

AHEKSB1 Summary Counter weighed misfire for Catalyst Gemaging Misfire **3200.00**

Misfirerate for Catalyst Protection in % Calculated from KFKSWFS and AHEKSB1: Value=AHEKSB1/KFKSWFS/600*100 (%)

	Indicated Engine Torque					
Engine Speed (RPM)	14.84375	30.078125	39.84375	50	60.15625	75
1000	16.67	16.67	16.67	16.67	14.41	14.41
2000	16.67	16.67	14.41	16.67	14.41	9.04
3000	16.67	16.67	14.41	14.41	11.11	11.11
4000	16.67	14.41	12.40	10.06	7.73	8.33
5000.00	16.67	12.40	9.04	7.11	6.27	6.27
6000.0	16.67	9.04	5.56	4.98	4.68	6.67

P0326, P0327, P0328,
P0331, P0332, P0333

NGKRWN (internal manufacturer cross reference)

RPM dynamic threshold for disabling knock diagnosis

	400	800	1200	1600	2000	2400	2800	3200	3600	4000	4400	4800	5200	5600	6000	6400
RPM	400	800	1200	1600	2000	2400	2800	3200	3600	4000	4400	4800	5200	5600	6000	6400
RPM per second	1400	1550	1700	1950	2200	2450	2650	2800	3000	3100	3250	3400	3500	3600	3700	3700

KFDYESPF (internal manufacturer cross reference)
Intake Manifold Pressure delta for disabling knock diagnosis

	Engine Speed (RPM)															
Intake Manifold Press (kPa)	400	800	1200	1600	2000	2400	2800	3200	3600	4000	4400	4800	5200	5600	6000	6400
ECT (° C)	400	800	1200	1600	2000	2400	2800	3200	3600	4000	4400	4800	5200	5600	6000	6400
50.25	35	34	24	20	19	19	18	18	18	19	19	19	19	20	21	21
69.75	30	28	27	23	21	21	20	20	20	20	20	20	20	19	20	20
90	24	24	25	22	22	22	22	22	22	22	21	21	21	19	20	20
120	22	21	21	23	22	24	25	23	24	22	20	20	20	19	20	20

P0327, P0332

UDKSNV (internal manufacturer cross reference)
Reference voltage threshold for knock sensor diagnosis - Lower Limit

	Engine Speed (rpm)															
	400	800	1200	1600	2000	2400	2800	3200	3600	4000	4400	4800	5200	5600	6000	6400
Peak RMS Voltage (V)	0.150	0.150	0.150	0.150	0.150	0.150	0.150	0.150	0.293	0.293	0.293	0.293	0.293	0.293	0.293	0.293

12 OBDG03 Engine Diagnostics

Engine Support Tables

P0328, P0333

UDKSNO (internal manufacturer cross reference)

Reference voltage threshold for knock sensor diagnosis - Upper Limit

	Engine Speed (rpm)															
	400	800	1200	1600	2000	2400	2800	3200	3600	4000	4400	4800	5200	5600	6000	6400
Peak RMS Voltage (V)	5.000	5.000	5.000	5.000	5.000	5.400	6.000	6.600	7.800	9.000	10.350	11.850	13.500	15.300	17.100	18.600

P0341, P0342, P0343
P0346, P0347, P0348
P0366, P0367, P0368
P0391, P0392, P0393

KLPHNOKA (internal manufacturer cross reference)

Threshold for number of counts for detection of camshaft position sensor error

	Engine Speed (RPM)			
	600.000	1600.000	3200.000	7200.000
Number of Counts	8.000	17.000	34.000	72.000

P0420

RLKTDMM (internal manufacturer cross reference)

Engine Load lower limit for enabling catalyst monitor

	Engine Speed (RPM)				
	1000.000	1520.000	2000.000	2520.000	3000.000
Engine Load (%)	18.000	18.000	18.000	18.000	18.000

RLKTDMM (internal manufacturer cross reference)

Engine Load upper limit for enabling catalyst monitor

	Engine Speed (RPM)				
	1000.000	1520.000	2000.000	2520.000	3000.000
Engine Load (%)	80.250	80.250	77.250	72.750	69.750

TVKTDMPTE (internal manufacturer cross reference)

Time Delay for enabling catalyst monitor after secondary O2 sensor has reached dewpoint eni

	Engine Coolant Temperature at Start (° C)			
	0.000	20.250	39.750	60.000
Time Delay (sec)	10.000	20.000	30.000	40.000

P0446, P0496, P0497,
P0455

FSTDMM	Minimum Fuel tank level	11.0
FSTDMM	Maximum Fuel tank level	76.0
TUMTDLU	Minimum Ambient Temperature	2.0
TUMTDLO	Maximum Ambient Temperature	38.0
TMSTLDMN	Minimum Coolant Temperature at Engine Start	2.0
TMSTLDMX	Maximum Coolant Temperature at Engine Start	38.0

12 OBDG03 Engine Diagnostics

Engine Support Tables

P0442

KFEONVPT (internal manufacturer cross reference)
Vacuum / Pressure Threshold for Fuel Tank Leak Detector

Vacuum / Pressure (hPa)	Ambient Temperature (Model) (° C)									
Fuel Level (%)	0	5.25	9.75	15	20.25	24.75	30	35.25	39.75	
5	1.80	1.91	2.00	2.35	2.70	3.00	3.35	3.70	4.00	
10	1.74	1.84	1.93	2.27	2.61	2.90	3.24	3.58	3.87	
20	1.63	1.69	1.80	2.12	2.43	2.70	3.02	3.33	3.60	
30	1.51	1.55	1.67	1.96	2.25	2.50	2.79	3.08	3.33	
40	1.40	1.40	1.53	1.80	2.07	2.30	2.57	2.84	3.07	
50	1.35	1.35	1.40	1.65	1.89	2.10	2.34	2.59	2.80	
60	1.29	1.30	1.33	1.54	1.75	1.93	2.14	2.35	2.53	
70	1.25	1.25	1.27	1.44	1.62	1.77	1.94	2.12	2.27	
80	1.20	1.20	1.20	1.34	1.48	1.60	1.74	1.88	2.00	

Vacuum / Pressure (Pa)	Tank Capacity 82.5 Liters Ambient Temperature (Model) (° C)									
Fuel Level (%)	0	5.25	9.75	15	20.25	24.75	30	35.25	39.75	
5	180	191	200	235	270	300	335	370	400	
10	174	184	193	227	261	290	324	358	387	
20	163	169	180	212	243	270	302	333	360	
30	151	155	167	196	225	250	279	308	333	
40	140	140	153	180	207	230	257	284	307	
50	135	135	140	165	189	210	234	259	280	
60	129	130	133	154	175	193	214	235	253	
70	125	125	127	144	162	177	194	212	227	
80	120	120	120	134	148	160	174	188	200	

P0455

KLTLDSFS05 (internal manufacturer cross reference)
Vacuum Gradient Threshold for Fuel Tank Leak Detection

Fuel Level liters	0	10	20	30	40	50	60	70	75	80
hPa / sec	0.150	0.150	0.160	0.170	0.175	0.180	0.185	0.190	0.190	0.190

Fuel Level (%)	Tank Capacity 82.5 Liters									
Pa / sec	0	12.1	24.2	36.4	48.5	60.6	72.7	84.8	90.9	97.0
Pa / sec	15.0	15.0	16.0	17.0	17.5	18.0	18.5	19.0	19.0	19.0

P0451

TUMDSTDMN Minimum Coolant Temperature at Engine Start 3.8 °C
TUMDSTDMX Maximum Coolant Temperature at Engine Start 39.8 °C

P0501

(internal manufacturer cross reference)
NDV Minimum engine speed for diagnosis 1400 rpm
NDV0 Maximum engine speed for diagnosis 3000 rpm

P2101

DWDKSBAMX (internal manufacturer cross reference)
Maximum Throttle Angle Deviation per computation cycle

	Percent Throttle Opening (%)				
	0	0.300598145	0.999450684	5.000305176	14.99938965
Percent Throttle Delta (%)	4	6	11	20	50

End Cal Tables

Glossary of Secondary Parameters

Secondary parameters	Enable condition	Definition
dew point exceeded at primary O2 sensor	TRUE	time integrated heat quantity is larger than calibrated map values dependent on engine start temperature (0.46 .. 1262 KJ) exhaust pipe temperature at primary oxygen sensor > 60°C
dew point exceeded at secondary O2 sensor	TRUE	time integrated heat quantity is larger than calibrated map values dependent on engine start temperature (1.8 ... 1400 KJ) exhaust pipe temperature at primary oxygen sensor > 60°C
primary sensor heating active	TRUE	dew point exceeded at primary O2 sensor engine speed > 680 rpm battery voltage < 18 V engine temperature > -9.8 °C error: primary oxygen sensor --> not set
secondary air system	active	intake air temperature > - 11 ... < 80 °C engine coolant temperature > - 11 ... < 120 °C engine speed < 3500 rpm mass airflow < 100 g/sec. battery voltage > 10 ... < 18 V cat heating --> active
cat heating	active	nmot > 680rpm altitude < 3000m intake air temp. > -12°C engine start temperature -10,5°C < ... < 69,75°C difference of intake air. temp minus engine coolant start temp. <=15°C error: air flow meter --> not set error: intake air temperature sensor -->not set error: engine temperature sensor --> not set error: ambient pressure sensor --> not set
error: camshaft control system	not set	P0011, P0021, P0014, P0024, P000A, P000B, P000C, P000D P0341-P0343, P0366-P0368, P0346-P0348, P0391-P0393
error: evap. canister purge system	not set	P0449, P0498, P0499, P0443, P0458, P0459, P0442, P0446, P0455, P0496, P0497
error: camshaft control circuit	not set	P0341-P0346, P0366-P0368, P0346-P0348, P0391-P0393

12 OBDG03 Engine Diagnostics

FSCM SECTION
2 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Fuel Rail Pressure (FRP) Sensor Performance (rationality)	P018B	This DTC detects a fuel pressure sensor response stuck within the normal operating range	Absolute value of fuel pressure change as sensed during intrusive test.	<= 30 kPa	1. FRP Circuit Low DTC (P018C) 2. FRP Circuit High DTC (P018D) 3. FuelPump Circuit Low DTC (P0231) 4. FuelPump Circuit High DTC (P0232) 5. FuelPump Circuit Open DTC (P023F) 6. Reference Voltage DTC (P0641) 7. Fuel Pump Control Module Driver Over-temperature DTC (P064A) 8. Control Module Internal Performance DTC (P0606) 9. Engine run time	not active not active not active not active not active not active not active >=5 seconds	Frequency: Continuous; 12.5 ms loop. 60 seconds between intrusive tests that pass Intrusive test requested if fuel system is clamped for >= 5 seconds or fuel pressure error variance <= typically (0.3 to 0.6) (calculated over a 2.5sec period); otherwise report pass Duration of intrusive test is fueling related (5 to 12 seconds). Intrusive test is run when fuel flow is below Max allowed fuel flow rate (Typical values in the range of 11 to 50 g/s)	DTC Type A 1 trip

12 OBDG03 Engine Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					10. Emissions fuel level (PPEI \$3FB) 11. Fuel pump control 12. Fuel pump control state 13. Engine fuel flow 14. ECM fuel control system failure (PPEI \$1ED)	not low enabled normal or FRP Rationality control > 0.047 g/s failure has not occurred		
Fuel Rail Pressure (FRP) Sensor Circuit Low Voltage	P018C	This DTC detects if the fuel pressure sensor circuit is shorted low	FRP sensor voltage	< 0.14 V	Ignition	Run or Crank	72 failures out of 80 samples 1 sample/12.5 ms	DTC Type A 1 trip
Fuel Rail Pressure (FRP) Sensor Circuit High Voltage	P018D	This DTC detects if the fuel pressure sensor circuit is shorted high	FRP sensor voltage	> 4.86 V	Ignition	Run or Crank	72 failures out of 80 samples 1 sample/12.5 ms	DTC Type A 1 trip
Fuel Pump Control Circuit Low Voltage	P0231	This DTC detects if the fuel pump control circuit is shorted to low	Fuel Pump Current	> 14.48A	Ignition OR HS Comm OR Fuel Pump Control AND Ignition Run/Crank Voltage	Run or Crank enabled enabled 9V < voltage < 32V	72 test failures in 80 test samples if Fuel Pump Current <100A 1 sample/12.5 ms	DTC Type A 1 trip

12 OBDG03 Engine Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Fuel Pump Control Circuit High Voltage	P0232	This DTC detects if the fuel pump control circuit is shorted to high	Voltage measured at fuel pump circuit	> 3.86 V	Commanded fuel pump output Fuel pump control enable Time that above conditions are met	0% duty cycle (off) False >=4.0 seconds	36 test failures in 40 test samples; 1 sample/12.5ms Pass/Fail determination made only once per trip	DTC Type A 1 trip
Fuel Pump Control Circuit (Open)	P023F	This DTC detects if the fuel pump control circuit is open	Fuel Pump Current AND Fuel Pump Duty Cycle	<=0.5A >20%	Ignition OR HS Comm OR Fuel Pump Control AND Ignition Run/Crank Voltage	Run or Crank enabled enabled 9V < voltage < 32V	72 test failures in 80 test samples; 1 sample/12.5ms	DTC Type A 1 trip
Fuel System Control Module Enable Control Circuit	P025A	This DTC detects if there is a fault in the fuel pump control enable circuit	PPEI (PPEI (Powertrain Platform Electrical Interface) Fuel System Request (\$1ED)	≠ Fuel Pump Control Module Enable Control Circuit	Ignition AND PPEI Fuel System Request (\$1ED)	Run or Crank valid	72 failures out of 80 samples 1 sample/12.5 ms	DTC Type A 1 trip
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if any software or calibration check sum is incorrect	Calculated Checksum (CRC16)	≠ stored checksum for any of the parts (boot, software, application calibration, system calibration)	Ignition	Run or Crank	1 failure if it occurs during the first ROM test of the ignition cycle, otherwise 5 failures	DTC Type A 1 trip

12 OBDG03 Engine Diagnostics

FSCM SECTION
2 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					OR HS Comm OR Fuel Pump Control	enabled enabled	Frequency: Runs continuously in the background	
Control Module Not Programmed	P0602	Indicates that the FSCM needs to be programmed	This DTC is set via calibration, when KeMEMD_b_NoStartCal	= TRUE	Ignition OR HS Comm OR Fuel Pump Control	Run or Crank enabled enabled	Runs once at power up	DTC Type A 1 trip
Control Module Long Term Memory Reset	P0603	Non-volatile memory checksum error at controller power-up	Checksum at power- up	≠ checksum at power-down	Ignition OR HS Comm OR Fuel Pump Control	Run or Crank enabled enabled	1 failure Frequency: Once at power-up	DTC Type A 1 trip
Control Module Random Access Memory (RAM)	P0604	Indicates that control module is unable to correctly write and read data to and from RAM	Data read	≠ Data written	Ignition OR HS Comm OR Fuel Pump Control	Run or Crank enabled enabled	1 failure if it occurs during the first RAM test of the ignition cycle, otherwise 5 failures Frequency: Runs continuously in the background.	DTC Type A 1 trip

12 OBDG03 Engine Diagnostics

FSCM SECTION
2 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Control Module Internal Performance 1. Main Processor Configuration Register Test 2. Processor clock test 3. External watchdog test	P0606	This DTC indicates the FSCM has detected an internal processor fault or external watchdog fault (PID 2032 discriminates the source of the fault)	1. For all I/O configuration register faults: •Register contents 2. For Processor Clock Fault: •EE latch flag in EEPROM. OR • RAM latch flag. 3. For External Watchdog Fault: • Software control of fuel pump driver	Incorrect value. 0x5A5A 0x5A Control Lost	Ignition OR HS Comm OR Fuel Pump Control 1. For all I/O configuration register faults: •KeMEMD_b_ProcFitCfgRegEnbl 2. For Processor Clock Fault: •KeMEMD_b_ProcFitCLKDiagEn bl 3. For External Watchdog Fault: •KeFRPD_b_FPExtWDogDiagEn bl 3. For External Watchdog Fault: •Control Module ROM(P0601) 3. For External Watchdog Fault: •Control Module RAM(P0604)	Run or Crank enabled enabled TRUE TRUE TRUE not active not active	Tests 1 and 2 1 failure Frequency: Continuously (12.5ms) Test 3 3 failures out of 15 samples 1 sample/12.5 ms	DTC Type A 1 trip
Control Module Long Term Memory (EEPROM) Performance	P062F	Indicates that the NVM Error flag has not been cleared	Last EEPROM write	Did not complete	Ignition OR	Run or Crank	1 test failure Once on controller power-up	DTC Type A 1 trip

12 OBDG03 Engine Diagnostics

FSCM SECTION
2 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					HS Comm OR Fuel Pump Control	enabled enabled		
5Volt Reference Circuit (Short High/Low/Out of Range)	P0641	Detects continuous short or out of range on the #1 5V sensor reference circuit	Reference voltage AND Output OR Reference voltage AND Output OR Reference voltage AND Output active	>= 0.5V inactive >= 5.5V active <= 4.5V active	Ignition	Run or Crank	15 failures out of 20 samples 1 sample/12.5 ms	DTC Type A 1 trip
			OR Reference voltage	> 102.5% nominal (i.e., 5.125V) OR <97.5% nominal (i.e., 4.875V)				
Fuel Pump Control Module - Driver Over- temperature 1	P064A	This DTC detects if an internal fuel pump driver overtemperature condition exists under normal operating conditions	Pump Driver Temp	> 150C	Ignition OR HS Comm OR Fuel Pump Control KeFRPD_b_FPOverTempDiagE nbl Ignition Run/Crank	Run or Crank enabled enabled TRUE 9V<voltage<32V	3 failures out of 15 samples 1 sample/12.5 ms	DTC Type B 2 trips

12 OBDG03 Engine Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Ignition 1 Switch Circuit Low Voltage	P2534	This DTC detects if the Ignition1 Switch circuit is shorted to low or open	Ignition 1 voltage	<= 6 V	Engine	Running	180 failures out of 200 samples 1 sample/25.0 ms	DTC Type A 1 trip
Fuel Pump Flow Performance (rationality)	P2635	This DTC detects degradation in the performance of the SID1 electronic return- less fuel system	Filtered fuel rail pressure error	<= Low Threshold (function of desired fuel rail pressure and fuel flow rate. 15% of resultant Target Pressure) OR >= High Threshold (function of desired fuel rail pressure and fuel flow rate. 15% of resultant Target Pressure) (See Supporting Tables tab)	1. FRP Circuit Low DTC (P018C)	not active	Filtered fuel rail pressure error Time Constant = 12.5 seconds Frequency: Continuous 12.5 ms loop	DTC Type B 2 trips
					2. FRP Circuit High DTC (P018D)	not active		
					3. Fuel Rail Pressure Sensor Performance DTC (P018B)	not active		
					4. FuelPump Circuit Low DTC (P0231)	not active		
					5. FuelPump Circuit High DTC (P0232)	not active		
					6. FuelPump Circuit Open DTC (P023F)	not active		
					7. Reference Voltage DTC (P0641)	not active		

12 OBDG03 Engine Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					8. Fuel Pump Control Module Driver Over-temperature DTC's (P064A)	not active		
					9. Control Module Internal Performance DTC (P0606)	not active		
					10. An ECM fuel control system failure (PPEI \$1ED)	has not occurred		
					11. The Barometric pressure (PPEI \$4C1) signal	valid (for absolute fuel pressure sensor)		
					12. Engine run time	>= 30 seconds		
					13. Emissions fuel level (PPEI \$3FB)	not low		
					14. Fuel pump control	enabled		
					15. Fuel pump control state	normal		
					16. Battery Voltage	11V<=voltage=<32V		
					17. Fuel flow rate (See Supporting Tables tab)	> 0.047 g/s AND <= Max allowed fuel flow rate as a function of desired rail pressure & Vbatt (Typical values in the range of 11 to 50 g/s)		
					18. Fuel Pressure Control System	Is not responding to an over-pressurization due to pressure build during DFCO or a decreasing desired pressure command.		

12 OBDG03 Engine Diagnostics

FSCM SECTION
2 OF 2 SECTIONS

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Control Module Communication Bus "A" Off	U0073	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off state	Bus Status	Off	Power mode	Run/Crank	5 failures out of 5 samples (5 seconds)	DTC Type B 2 trips
Lost Communication With ECM/PCM "A"	U0100	Detects that CAN serial data communication has been lost with the ECM	Message \$0C9	Undetected	1. Power mode 2. Ignition Run/Crank Voltage 3. U0073	Run/Crank 11V<voltage<32V not active	12 failures out of 12 samples (12 seconds)	DTC Type B 2 trips

FSCM Support Tables

P2635 Fuel Pump Performance Maximum Fuel Flow map (grams / s)

X-axis= Desired Fuel Pressure (kiloPascals)
Y-axis= Battery voltage (volts)

	200	250	300	350	400	450	500	550	600
4.5	25.14063	25.14063	25.14063	25.14063	25.14063	23.10938	19.92969	16.84375	13.83594
6	25.14063	25.14063	25.14063	25.14063	25.14063	23.10938	19.92969	16.84375	13.83594
7.5	25.14063	25.14063	25.14063	25.14063	25.14063	23.10938	19.92969	16.84375	13.83594
9	25.14063	25.14063	25.14063	25.14063	25.14063	23.10938	19.92969	16.84375	13.83594
10.5	25.14063	25.14063	25.14063	25.14063	25.14063	23.10938	19.92969	16.84375	13.83594
12	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	22.66406
13.5	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063
15	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063
16.5	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063
18	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063
19.5	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063
21	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063
22.5	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063
24	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063
25.5	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063
27	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063
28.5	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063	25.14063

FSCM Support Tables

P2635 Fuel Pump Performance Filtered Pressure Error Fault Threshold High map (kiloPascals)

X-axis= Target Fuel Pressure (kiloPascals)
Y-axis= Fuel Flow (grams / s)

	200	250	300	350	400	450	500	550	600
0	33.29688	47.17188	61.04688	74.92188	88.79688	102.6719	116.5469	130.4219	144.2969
1.5	33.29688	47.17188	61.04688	74.92188	88.79688	102.6719	116.5469	130.4219	144.2969
3	33.29688	47.17188	61.04688	74.92188	88.79688	102.6719	116.5469	130.4219	144.2969
4.5	33.29688	47.17188	61.04688	74.92188	88.79688	102.6719	116.5469	130.4219	144.2969
6	33.29688	47.17188	61.04688	74.92188	88.79688	102.6719	116.5469	130.4219	144.2969
7.5	33.29688	47.17188	61.04688	74.92188	88.79688	102.6719	116.5469	130.4219	144.2969
9	33.29688	47.17188	61.04688	74.92188	88.79688	102.6719	116.5469	130.4219	144.2969
10.5	33.29688	47.17188	61.04688	74.92188	88.79688	102.6719	116.5469	130.4219	144.2969
12	33.29688	47.17188	61.04688	74.92188	88.79688	102.6719	116.5469	130.4219	144.2969
13.5	21.28125	47.17188	61.04688	74.92188	88.79688	102.6719	116.5469	130.4219	144.2969
15	11.70313	47.17188	61.04688	74.92188	88.79688	102.6719	116.5469	130.4219	144.2969
16.5	11.70313	28.76563	61.04688	74.92188	88.79688	102.6719	116.5469	130.4219	144.2969
18	11.70313	16.57813	61.04688	74.92188	88.79688	102.6719	116.5469	130.4219	144.2969
19.5	11.70313	16.57813	29.78125	74.92188	88.79688	102.6719	116.5469	130.4219	144.2969
21	11.70313	16.57813	21.45313	46.28125	88.79688	102.6719	116.5469	130.4219	144.2969
22.5	11.70313	16.57813	21.45313	26.32813	88.79688	102.6719	116.5469	130.4219	144.2969
24	11.70313	16.57813	21.45313	26.32813	31.20313	102.6719	116.5469	130.4219	144.2969
25.5	11.70313	16.57813	21.45313	26.32813	31.20313	47.39063	116.5469	130.4219	144.2969
27	11.70313	16.57813	21.45313	26.32813	31.20313	36.07813	59.71875	130.4219	144.2969
28.5	11.70313	16.57813	21.45313	26.32813	31.20313	36.07813	40.95313	69.59375	144.2969
30	11.70313	16.57813	21.45313	26.32813	31.20313	36.07813	40.95313	45.82813	77.25
31.5	11.70313	16.57813	21.45313	26.32813	31.20313	36.07813	40.95313	45.82813	50.70313
33	11.70313	16.57813	21.45313	26.32813	31.20313	36.07813	40.95313	45.82813	50.70313
34.5	11.70313	16.57813	21.45313	26.32813	31.20313	36.07813	40.95313	45.82813	50.70313
36	11.70313	16.57813	21.45313	26.32813	31.20313	36.07813	40.95313	45.82813	50.70313
37.5	11.70313	16.57813	21.45313	26.32813	31.20313	36.07813	40.95313	45.82813	50.70313
39	11.70313	16.57813	21.45313	26.32813	31.20313	36.07813	40.95313	45.82813	50.70313
40.5	11.70313	16.57813	21.45313	26.32813	31.20313	36.07813	40.95313	45.82813	50.70313
42	11.70313	16.57813	21.45313	26.32813	31.20313	36.07813	40.95313	45.82813	50.70313
43.5	11.70313	16.57813	21.45313	26.32813	31.20313	36.07813	40.95313	45.82813	50.70313
45	11.70313	16.57813	21.45313	26.32813	31.20313	36.07813	40.95313	45.82813	50.70313
46.5	11.70313	16.57813	21.45313	26.32813	31.20313	36.07813	40.95313	45.82813	50.70313
48	11.70313	16.57813	21.45313	26.32813	31.20313	36.07813	40.95313	45.82813	50.70313

FSCM Support Tables

P2635 Fuel Pump Performance Filtered Pressure Error Fault RePass Threshold High map (kiloPascals)

X-axis= Target Fuel Pressure (kiloPascals)
Y-axis= Fuel Flow (grams / s)

	200	250	300	350	400	450	500	550	600
0	28.3125	40.09375	51.89063	63.6875	75.48438	87.28125	99.0625	110.8594	122.6563
1.5	28.3125	40.09375	51.89063	63.6875	75.48438	87.28125	99.0625	110.8594	122.6563
3	28.3125	40.09375	51.89063	63.6875	75.48438	87.28125	99.0625	110.8594	122.6563
4.5	28.3125	40.09375	51.89063	63.6875	75.48438	87.28125	99.0625	110.8594	122.6563
6	28.3125	40.09375	51.89063	63.6875	75.48438	87.28125	99.0625	110.8594	122.6563
7.5	28.3125	40.09375	51.89063	63.6875	75.48438	87.28125	99.0625	110.8594	122.6563
9	28.3125	40.09375	51.89063	63.6875	75.48438	87.28125	99.0625	110.8594	122.6563
10.5	28.3125	40.09375	51.89063	63.6875	75.48438	87.28125	99.0625	110.8594	122.6563
12	28.3125	40.09375	51.89063	63.6875	75.48438	87.28125	99.0625	110.8594	122.6563
13.5	18.09375	40.09375	51.89063	63.6875	75.48438	87.28125	99.0625	110.8594	122.6563
15	9.9375	40.09375	51.89063	63.6875	75.48438	87.28125	99.0625	110.8594	122.6563
16.5	9.9375	24.45313	51.89063	63.6875	75.48438	87.28125	99.0625	110.8594	122.6563
18	9.9375	14.09375	51.89063	63.6875	75.48438	87.28125	99.0625	110.8594	122.6563
19.5	9.9375	14.09375	25.3125	63.6875	75.48438	87.28125	99.0625	110.8594	122.6563
21	9.9375	14.09375	18.23438	39.34375	75.48438	87.28125	99.0625	110.8594	122.6563
22.5	9.9375	14.09375	18.23438	22.375	75.48438	87.28125	99.0625	110.8594	122.6563
24	9.9375	14.09375	18.23438	22.375	26.51563	87.28125	99.0625	110.8594	122.6563
25.5	9.9375	14.09375	18.23438	22.375	26.51563	40.28125	99.0625	110.8594	122.6563
27	9.9375	14.09375	18.23438	22.375	26.51563	30.65625	50.76563	110.8594	122.6563
28.5	9.9375	14.09375	18.23438	22.375	26.51563	30.65625	34.8125	59.15625	122.6563
30	9.9375	14.09375	18.23438	22.375	26.51563	30.65625	34.8125	38.95313	65.67188
31.5	9.9375	14.09375	18.23438	22.375	26.51563	30.65625	34.8125	38.95313	43.09375
33	9.9375	14.09375	18.23438	22.375	26.51563	30.65625	34.8125	38.95313	43.09375
34.5	9.9375	14.09375	18.23438	22.375	26.51563	30.65625	34.8125	38.95313	43.09375
36	9.9375	14.09375	18.23438	22.375	26.51563	30.65625	34.8125	38.95313	43.09375
37.5	9.9375	14.09375	18.23438	22.375	26.51563	30.65625	34.8125	38.95313	43.09375
39	9.9375	14.09375	18.23438	22.375	26.51563	30.65625	34.8125	38.95313	43.09375
40.5	9.9375	14.09375	18.23438	22.375	26.51563	30.65625	34.8125	38.95313	43.09375
42	9.9375	14.09375	18.23438	22.375	26.51563	30.65625	34.8125	38.95313	43.09375
43.5	9.9375	14.09375	18.23438	22.375	26.51563	30.65625	34.8125	38.95313	43.09375
45	9.9375	14.09375	18.23438	22.375	26.51563	30.65625	34.8125	38.95313	43.09375
46.5	9.9375	14.09375	18.23438	22.375	26.51563	30.65625	34.8125	38.95313	43.09375
48	9.9375	14.09375	18.23438	22.375	26.51563	30.65625	34.8125	38.95313	43.09375

FSCM Support Tables

P2635 Fuel Pump Performance Filtered Pressure Error Fault Threshold Low map (kiloPascals)

X-axis= Target Fuel Pressure (kiloPascals)
Y-axis= Fuel Flow (grams / s)

	200	250	300	350	400	450	500	550	600
0	-10.5313	-14.4063	-18.0625	-21.5	-24.7656	-27.8594	-30.7656	-33.5313	-36.125
1.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
3	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
4.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
6	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
7.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
9	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
10.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
12	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
13.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
15	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
16.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
18	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
19.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
21	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
22.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
24	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
25.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
27	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
28.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
30	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
31.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
33	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
34.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
36	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
37.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
39	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
40.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
42	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
43.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
45	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
46.5	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703
48	-38.7031	-54.8281	-70.9531	-87.0781	-103.203	-119.328	-135.453	-151.578	-167.703

FSCM Support Tables

P2635 Fuel Pump Performance Filtered Pressure Error Fault RePass Threshold Low map (kiloPascals)

X-axis= Target Fuel Pressure (kiloPascals)
Y-axis= Fuel Flow (grams / s)

	200	250	300	350	400	450	500	550	600
0	-8.95313	-12.25	-15.3438	-18.2813	-21.0469	-23.6719	-26.1563	-28.5	-30.7031
1.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
3	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
4.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
6	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
7.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
9	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
10.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
12	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
13.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
15	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
16.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
18	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
19.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
21	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
22.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
24	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
25.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
27	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
28.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
30	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
31.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
33	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
34.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
36	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
37.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
39	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
40.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
42	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
43.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
45	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
46.5	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547
48	-32.8906	-46.5938	-60.3125	-74.0156	-87.7188	-101.422	-115.125	-128.844	-142.547

FSCM Support Tables

P2635 Maximum Engine Intake Boost curve (kiloPascals)

X-axis= barometric pressure (kiloPascals)

40	50	60	70	80	90	100	110	120
0	0	0	0	0	0	0	0	0