

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit – Bank 1	P0010	Detects a VVT system error by monitoring the circuit for electrical integrity	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		System supply voltage is within limits Output driver is commanded on, Ignition switch is in crank or run position	> 11 Volts	20 failures out of 25 samples 250 ms / sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Performance – Bank 1	P0011	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Intake cam Bank 1) Cam Position Error > 6.00 deg. (CamPosErrorLimlc1)	DTC's are NOT active: P0010, IntakeCamSensorTFTKO CrankSensorTFTKO CrankIntakeCamCorrelati onFA.  Engine is running VVT is enabled Desired camshaft position > 0 Power Take Off (PTO) not active	System Voltage > 11 Volts, Engine is running VVT is enabled Desired cam position > 0 Power Take Off (PTO) not active  Both Desired & Measured cam positions cannot be < 6.00 (CamPosErrorLimlc1) or have both > 19.00 deg. (MaxTravelInt - CamPosErrorLimlc1).  Desired cam position cannot vary more than 3.00 Cam Deg for at least 3.00 sec. (KtPHSD_t_StablePositionTimelc1)	135.00 failures out of 150.00 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit – Bank 1	P0013	Detects a VVT system error by monitoring the circuit for electrical integrity	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		System supply voltage is within limitsOutput driver is commanded on, Ignition switch is in crank or run position	> 11 Volts	20 failures out of 25 samples250 ms / sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft System Performance – Bank 1	P0014	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Exhaust cam Bank 1) Cam Position Error > 6.00 deg. (CamPosErrorLimEc1)	DTC's are NOT active: P0013, ExhaustCamSensorTFTKO CrankSensorTFTKO CrankExhaustCamCorrelationFA	System Voltage > 11 Volts, Engine is running VVT is enabled Desired cam position > 0 Power Take Off (PTO) not active  Both Desired & Measured cam positions cannot be < 6.00 deg. (CamPosErrorLimEc1) or have both > ( 19.00 ) (MaxTravelExh - CamPosErrorLimEc1).  Desired cam position cannot vary more than 3.00 Cam Deg for at least 3.00 sec. (KtPHSD_t_StablePositionTimeEc1)	135.00 failures out of 150.00 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)- Camshaft Position (CMP) Correlation Bank 1 Sensor A	P0016	Detects cam to crank misalignment by monitoring if cam sensor pulse for bank 1 sensor A occurs during the incorrect crank position	4 cam sensor pulses more than -7.9 crank degrees before or 12.1 crank degrees after nominal position in one cam revolution.		Crankshaft and camshaft position signals are synchronized  Engine is Spinning  Cam phaser is in "parked" position  No Active DTCs:  Time since last execution of diagnostic	P0335, P0336 P0340,P0341 5VoltReferenceA_FA 5VoltReferenceB_FA  < 1.0 seconds	2 failures out of 3 tests.  A failed test is 4 failures out of 5 samples.  There is a delay after the first failed test to allow the camshaft position to return to the park position.  This time is defined by the table "Cam Correlation Oil Temperature Threshold".  One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)- Camshaft Position (CMP) Correlation Bank 1 Sensor B	P0017	Detects cam to crank misalignment by monitoring if cam sensor pulse for bank 1 sensor B occurs during the incorrect crank position	4 cam sensor pulses more than -7.9 crank degrees before or 12.1 crank degrees after nominal position in one cam revolution.		Crankshaft and camshaft position signals are synchronized  Engine is Spinning  Cam phaser is in "parked" position  No Active DTCs:  Time since last execution of diagnostic	P0335, P0336 P0365,P0366 5VoltReferenceA_FA 5VoltReferenceB_FA  < 1.0 seconds	2 failures out of 3 tests.  A failed test is 4 failures out of 5 samples.  There is a delay after the first failed test to allow the camshaft position to return to the park position.  This time is defined by the table "Cam Correlation Oil Temperature Threshold".  One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 1	P0030	This DTC checks the Heater Output Driver circuit for electrical integrity.	Voltage low during driver open state (indicates short-to-ground or open circuit) or voltage high during driver closed state (indicates short to voltage).		Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 2	P0036	This DTC checks the Heater Output Driver circuit for electrical integrity.	Voltage low during driver open state (indicates short-to-ground or open circuit) or voltage high during driver closed state (indicates short to voltage).		Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 1	P0053	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	$3.7 < \Omega < 8.7$	No Active DTC's  Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,800 seconds -30.0 < °C < 45.0 < 32.0 volts < 0.20 seconds	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 2	P0054	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	$4.0 < \Omega < 10.7$	No Active DTC's  Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,800 seconds -30.0 < °C < 45.0 < 32.0 volts < 0.30 seconds	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
MAP / MAF / Throttle Position Correlation	P0068	Detect when MAP and MAF do not match estimated engine airflow as established by the TPS	<p>Difference between MAP and estimated MAP exceeds threshold (kPa), or P0651 (5 Volt Ref), or P0107 (MAP circuit low), or P0108 (MAP circuit high) have failed this key cycle, then MAP portion of diagnostic fails</p> <p>Absolute difference between MAF and estimated MAF exceed threshold (grams/sec), or P0102 (MAF circuit low), or P0103 (MAF circuit hi) have failed this key cycle, or maximum MAF versus RPM (Table) is greater than or equal to maximum MAF versus battery voltage, then MAF portion of diagnostic fails</p>	<p>Table, f(TPS). See supporting tables</p> <p>Table, f(TPS). See supporting tables</p> <p>Table, f(RPM). See supporting tables</p> <p>Table, f(Volts). See supporting tables</p>	Engine Speed	<p>&gt; 800 RPM</p> <p>Run/Crank voltage &gt; 6.41</p>	<p>Continuously fail MAP and MAF portions of diagnostic for 0.1875 s</p> <p>Continuous in MAIN processor</p>	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module SIDI High Pressure Pump min/max authority	P0089	This DTC Detects pump control windup to its max or min authority	High Pressure Fuel Pump Delivery Angle  High Pressure Fuel Pump Delivery Angle	$\geq 240^\circ$  Or $\leq 0^\circ$	Battery Voltage  Low Side Fuel Pressure  Engine Run Time    Barometric Pressure Inlet Air Temp  Fuel Temp  Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and	$\geq 11$ Volts  $> 0.275$ MPa  $\geq$ KtFHPD_t_PumpCntrlEng RunThrsh(see supporting tables) Enabled when a code clear is not active or not exiting device control Engine is not cranking  $\geq 70.0$ KPA $\geq -20.0$ degC  $-20 \leq \text{Temp degC} \leq 90$	Windup High -  750 failures out of 938 samples  Windup Low -  750 failures out of 938 Samples	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Cntrl Solenoid Enable Low Side Open Circuit	P0090	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the high pressure fuel pump solenoid low side is open circuit		Engine Speed Battery Voltage	>= 50 RPM >= 11 volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Cntrl Solenoid Enable Low Side Short to Ground	P0091	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the high pressure fuel pump solenoid low side is short to ground		Engine Speed  Battery Voltage	>= 50 RPM  >= 11 volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Cntrl Solenoid Enable Low Side Short to Power P0092	P0092	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the high pressure fuel pump solenoid low side is short to power		Engine Speed  Battery Voltage	>= 50 RPM >= 11  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0096	Detects an IAT2 sensor that has stuck in range by comparing to IAT and engine coolant temperature at startup	ABS(Power Up IAT - Power Up IAT2)  AND  ABS(Power Up ECT – Power Up IAT2) >= ABS(Power Up ECT – Power Up IAT)	> 30 deg C	Time between current ignition cycle and the last time the engine was running  Powertrain Relay Voltage for a time  No Active DTCs:	> 28,800 seconds  >= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 Low (applications with humidity)	P0097	Detects a continuous short to ground or open in the IAT 2 signal circuit	Raw IAT 2 Input	< 10 Hertz (~-60 deg C)	Powertrain Relay Voltage for a time  No Active DTCs:	>= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 High (applications with humidity)	P0098	Detects a continuous high frequency in the IAT 2 signal circuit	Raw IAT 2 Input	> 390 Hertz (~150 deg C)	Powertrain Relay Voltage for a time  No Active DTCs:	>= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Intermittent In-Range	P0099	Detects a noisy or erratic IAT 2 signal circuit or IAT 2 sensor	String Length  Where: "String Length" = sum of "Diff" calculated over  And where: "Diff" = ABS(current IAT 2 reading - IAT 2 reading from 100 milliseconds previous)	> 125.00 DegC  10 consecutive IAT 2 samples	Powertrain Relay Voltage for a time  No Active DTCs:	>= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault	4 failures out of 5 samples  Each sample takes 1.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Start Diagnostic	P00C6	This DTC checks the high side fuel pressure during engine cranking	The ECM detects that the fuel pressure is not rising or has fallen beyond acceptable limits during engine cranking	<p>Pressure Fall Test: High Side Fuel Rail Pressure &lt;= Supporting Table KtFHPD_p_HPS_PressFallLoThrsh</p> <p>Pressure Rise Test: High Side Fuel Pressure &lt; Supporting Table KtFHPC_p_HighPressStart</p>	<p>Low side feed fuel pressure</p> <p>Engine Run Time Run/Crank Voltage Engine Coolant</p> <p>For each engine start, only 1 diagnostic is performed. The pressure rise test will run if High side fuel pressure is less than KtFHPC_p_HighPressStart, otherwise, the pressure fall diagnostic will run. The pressure fall runs when the engine is cranking.</p>	<p>&gt;= 0 KPA</p> <p>&lt; = 0 sec &gt; 8 Volts -100 &lt;= °C &lt;= 80</p> <p>All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT, IAT2 and ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and Manufacturers enable</p>	<p>Pressure Fall Test: Injected cylinder events &gt;= Supporting Table KtFHPD_Cnt_HPS_PressFallLoThrsh</p> <p>Pressure Rise Test: Time &gt;= Supporting Table KtFHPC_t_HighPressStartTmout</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Barometric Pressure Inlet Air Temp	counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active >= 70.0 KPA >= -20.0 DegC		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Press Regulator Solenoid Supply Voltage Control Circuit/Open	P00C8	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the Fuel Press Regulator Solenoid Supply Voltage Control Circuit/Open		Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Press Regulator Solenoid Supply Voltage Control Circuit Low	P00C9	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the Fuel Press Regulator Solenoid Supply Voltage Control short to ground		Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Press Regulator Solenoid Supply Voltage Control Circuit High	P00CA	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the Fuel Press Regulator Solenoid Supply Voltage Control short to power		Engine Speed Battery Voltage	>= 50 RPM >= 11  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (naturally aspirated)	P0101	Determines if the MAF sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 300 kPa*(g/s)  > 17 grams/sec  > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 575 RPM <= 6,600 RPM >= -7 Deg C <= 125 Deg C >= -20 Deg C <= 125 Deg C  >= 0.50  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  See "Residual Weight Factor" tables.  MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA  EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP	Continuous  Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit Low Frequency	P0102	Detects a continuous short to low or a open in either the signal circuit or the MAF sensor	MAF Output	<= 500 Hertz (~ 0.25 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 11.0 Volts  >= 1.0 seconds	200 failures out of 250 samples  1 sample every cylinder firing event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit High Frequency	P0103	Detects a high frequency output from the MAF sensor	MAF Output	>= 11,000 Hertz (~ 328.00 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 11.0 Volts  >= 1.0 seconds	200 failures out of 250 samples  1 sample every cylinder firing event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (naturally aspirated)	P0106	Determines if the MAP sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 300 kPa*(g/s)	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 575 RPM <= 6,600 RPM >= -7 Deg C <= 125 Deg C >= -20 Deg C <= 125 Deg C  >= 0.50  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM  MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  See "Residual Weight Factor" tables.  No Active DTCs: MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA  No Pending DTCs: EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP	Continuous  Calculations are performed every 12.5 msec	Type B, 2 Trips
			Manifold Pressure OR	< 50.0 kPa	Time between current ignition cycle and the last	999 failures out of 5 samples		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Manifold Pressure	> 115.0 kPa	time the engine was running  Engine is not rotating  No Active DTCs:  No Pending DTCs:	> 409.6 seconds  EngineModeNotRunTimer Error MAP_SensorFA AAP_SnsrFA  MAP_SensorCircuitFP AAP_SnsrCktFP	1 sample every 12.5 msec	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit Low	P0107	Detects a continuous short to low or open in either the signal circuit or the MAP sensor.	MAP Voltage	< 3.0 % of 5 Volt Range (This is equal to 0.15 Volts or 3.5 kPa)	Continuous		320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit High	P0108	Detects an open sensor ground or continuous short to high in either the signal circuit or the MAP sensor.	MAP Voltage	> 90.0 % of 5 Volt Range (This is equal to 4.50 Volts, or 115.0 kPa)	Continuous		320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0111	Detects an IAT sensor that has stuck in range by comparing to IAT2 and engine coolant temperature at startup	ABS(Power Up IAT - Power Up IAT2)  AND  ABS(Power Up ECT – Power Up IAT) > ABS(Power Up ECT – Power Up IAT2)	> 30 deg C	Time between current ignition cycle and the last time the engine was running  Powertrain Relay Voltage for a time  No Active DTCs:	> 28,800 seconds  >= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Low	P0112	Detects a continuous short to ground in the IAT signal circuit or the IAT sensor	Raw IAT Input	< 58 Ohms (~150 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit High	P0113	Detects a continuous open circuit in the IAT signal circuit or the IAT sensor	Raw IAT Input	> 142,438 Ohms (~-60 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Intermittent In-Range	P0114	Detects a noisy or erratic IAT signal circuit or IAT sensor	String Length  Where: "String Length" = sum of "Diff" calculated over  And where: "Diff" = ABS(current IAT reading - IAT reading from 100 milliseconds previous)	> 125.00 DegC  10 consecutive IAT samples	Continuous		4 failures out of 5 samples  Each sample takes 1.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Performance	P0116	This DTC detects ECT temp sensor stuck in mid range.	<p>A failure will be reported if any of the following (1-3) occur after the following soak conditions, Engine off time &gt; 25,200 seconds Propulsion system off time &gt; 0 seconds</p> <p>1) ECT at power up &gt; IAT at power up by an IAT based table lookup value (fast fail).</p> <p>2) ECT at power up &gt; IAT at power up by 15.8 Deg C and a block heater has not been detected.</p> <p>3) ECT at power up &gt; IAT at power up by 15.8 Deg C and the time spent cranking the engine without starting is greater than 10.0 seconds with the LowFuelConditionDiag</p>	<p>See "P0116: Fail if power up ECT exceeds IAT by these values" in the Supporting tables section</p> <p>= False</p>	<p>No Active DTC's</p> <p>Non-volatile memory initialization</p> <p>Test complete this trip Test aborted this trip IAT LowFuelCondition Diag</p> <p>=====</p> <p>Block Heater detection is enabled when either of the following occurs:</p> <p>1) ECT at power up &gt; IAT at power up by</p> <p>2) Cranking time</p> <p>=====</p> <p>Block Heater is detected and diagnostic is aborted when 1) or 2) occurs:</p> <p>1a) Vehicle drive time</p> <p>1b) Vehicle speed</p> <p>1c) Additional Vehicle drive time is provided to 1a when Vehicle speed is below 1b as follows:</p>	<p>VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_Ckt_FA IgnitionOffTime Valid TimeSinceEngineRunning Valid</p> <p>= Not occurred</p> <p>= False = False ≥ -7 °C</p> <p>= False</p> <p>=====</p> <p>&gt; 15.8 °C</p> <p>&lt; 10.0 seconds</p> <p>=====</p> <p>&gt; 400 seconds</p> <p>with &gt; 14.9 MPH</p> <p>0.50 times the seconds with vehicle speed below 1b</p>	<p>1 failure</p> <p>500 msec/ sample</p> <p>Once per valid cold start</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					1d) IAT drops from power up IAT  2a) ECT drops from power up ECT  2b) Engine run time  ===== Diagnostic is aborted when 3) or 4) occurs:  3) Engine run time with vehicle speed below 1b  4) Minimum IAT during test	$\geq 5.3^{\circ}\text{C}$  $\geq 5^{\circ}\text{C}$  Within $\leq 60$ seconds  =====  $> 1800$ seconds  $\leq -7^{\circ}\text{C}$		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit Low	P0117	Circuit Continuity This DTC detects a short to ground in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ 150°C)	< 47 Ohms			5 failures out of 6 samples  1 sec/ sample  Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit High	P0118	Circuit Continuity This DTC detects a short to high or open in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ -60°C)	> 320,000 Ohms	Engine run time OR IAT min	> 10.0 seconds  ≥ 0.0 °C	5 failures out of 6 samples  1 sec/ sample  Continuous	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Circuit Intermittent	P0119	Circuit Continuity This DTC detects large step changes in the ECT signal circuit or the ECT sensor. Allowable high and low limits are calculated for the next sample based on the previous sample.	ECT temperature step change:  1) positive step change is greater than high limit  OR  2) negative step change is lower than low limit.		No Active DTC's	P0117 P0118	3 failures out of 4 samples  1 sec/ sample  Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (naturally aspirated)	P0121	Determines if the Throttle Position Sensor input is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	> 300 kPa*(g/s)  > 17 grams/sec  <= 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 575 RPM <= 6,600 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 125 Deg C  >= 0.50  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est  See "Residual Weight Factor" tables.  No Active DTCs:  MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA  No Pending DTCs:  EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP	Continuous  Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit Low	P0122	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage <	0.3250		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit High	P0123	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage >	4.750		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature Below Stat Regulating Temperature	P0128	This DTC detects if the engine coolant temperature rises too slowly due to an ECT or Cooling system fault	<p>Energy is accumulated after the first combustion event using Range #1 or #2 below:</p> <p>Thermostat type is divided into normal (non-heated) and electrically heated.</p> <p>For this application the "type" cal (KeTHMG_b_TMS_ElectHstEquipped) = 0 If the type cal is equal to one, the application has an electrically heated t-stat, if equal to zero the the application has a non heated t-stat. See appropriate section below.</p> <p>***** Type cal above = 1 (Electrically heated t-stat) == == == == Range #1 (Primary) ECT reaches Commanded temperature minus 11 °C when Ambient min is &lt; 52 °C and ≥ 10 °C. Note: Warm up target for range #1 will be at least 64 °C == == == == Range #2 (Alternate) ECT reaches Commanded temperature minus 11 °C when Ambient min is &lt; 10 °C and ≥ -7 °C. Note: Warm up target for range #2 will be at least</p>	<p>See "P0128: Maximum Accumulated Energy for Start-up ECT conditions" in the Supporting tables section</p> <p>This diagnostic models the net energy into and out of the cooling system during the warm-up process. The five energy terms are: Heat from combustion, heat from after-run, heat loss to environment, heat loss to cabin and heat loss to DFCO.</p>	<p>No Active DTC's</p> <p>Engine not run time</p> <p>Engine run time</p> <p>Fuel Condition</p> <p>T-Stat Heater duty commanded cycle Time over duty cycle limit</p> <p>ECT at start run</p>	<p>ECT_Sensor_Ckt_FA VehicleSpeedSensor_FA OAT_PtEstFiltFA IAT_SensorCircuitFA MAF_SensorFA THMR_AWP_AuxPumpFA THMR_AHV_FA THMR_SWP_Control_FA ECT_Sensor_Perf_FA</p> <p>≥ 1,800 seconds 10 ≤ Eng Run Tme ≤ 1,800 seconds</p> <p>Ethanol ≤ 87 %</p> <p>≤ 20.0 % duty cycle &lt; 5.0 seconds</p> <p>-10 ≤ ECT ≤ 66 °C</p>	<p>1 failure to set DTC</p> <p>1 sec/ sample</p> <p>Once per ignition key cycle</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			64 °C  ***** Type cal above = 0 (non - heated t-stat) == == == == Range #1 (Primary) ECT reaches 71 °C when Ambient min is < 52 °C and ≥ 10 °C. == == == == Range #2 (Alternate) ECT reaches 71 °C when Ambient min is < 10 °C and ≥ -7 °C.  *****					



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 1	P0132	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	== Open Test Criteria == No Active DTC's  System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition ===== No Active DTC's  Low Fuel Condition Diag Fuel Condition  Initial delay after Open Test Criteria met (cold start condition)  Initial delay after Open Test Criteria met (not cold start condition)  Equivalence Ratio Air Per Cylinder Fuel Control State	===== TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 150 seconds ≤ 87 % Ethanol ===== MAP_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt _FA FuelInjectorCircuit_FA AIR System FA = False ≤ 87 % Ethanol  > 45.0 seconds when engine soak time > 28,800 seconds  > 45.0 seconds when engine soak time ≤ 28,800 seconds  0.9912 ≤ ratio ≤ 1.0137 50 ≤ mgram ≤ 500 not = Power Enrichment	100 failures out of 125 samples  Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for	> 5.0 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Slow Response Bank 1 Sensor 1	P0133	This DTC determines if the O2 sensor response time is degraded.	The average response time is calculated over the test time, and compared to the threshold. Refer to P0133 - O2S Slow Response Bank 1 Sensor 1 "Pass/Fail Threshold table" in the Supporting Tables tab.		<p>No Active DTC's</p> <p>Bank 1 Sensor 1 DTC's not active</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition</p> <p>O2 Heater on for Learned Htr resistance</p>	<p>TPS_ThrottleAuthorityDefault MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA EthanolCompositionSensor_FA EngineMisfireDetected_FA</p> <p>P0131, P0132, P0134</p> <p>10.0 &lt; Volts &lt; 32.0 = Not active = Not active = Not active = Not active = False = Not Valid, See definition of Green Sensor Delay Criteria (B1S1) in Supporting Tables tab.</p> <p>≥ 40 seconds = Valid ( the heater resistance has learned since NVM reset, see</p>	<p>Sample time is 60 seconds</p> <p>Frequency: Once per trip</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Engine Coolant IAT Engine run Accum  Time since any AFM status change Time since Purge On to Off change Time since Purge Off to On change  Engine airflow Engine speed Fuel Condition Baro Air Per Cylinder  Fuel Control State Closed Loop Active LTM fuel cell Transient Fuel Mass Baro Fuel Control State Fuel State Commanded Proportional Gain  ===== All of the above met for	enable conditions for "HO2S Heater Resistance DTC's" ) > 70 °C > -40 °C > 120 seconds  > 2.0 seconds > 0.0 seconds > 1.5 seconds  14 ≤ grams/second ≤ 40 1,000 ≤ RPM ≤ 3,500 < 87 % Ethanol > 70 kpa ≥ 200 mGrams  = Closed Loop = TRUE = Enabled ≤ 100.0 mgrams = Not Defaulted not = Power Enrichment DFCO not active  ≥ 0.0 %  ===== > 3.0 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Insufficient Activity Bank 1 Sensor 1	P0134	This DTC determines if the O2 sensor circuit is open.	Oxygen Sensor Signal	> 1,700 mvolts	No Active DTC's  System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition	TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 150 seconds ≤ 87 % Ethanol	200 failures out of 250 samples.  Frequency: Continuous 100 msec loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 1	P0135	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.3 < Amps < 2.5	No Active DTC's  System Voltage Heater Warm-up delay O2S Heater device control  B1S1 O2S Heater Duty Cycle  All of the above met for	ECT_Sensor_FA  10.0 < Volts < 32.0 = Complete  = Not active  > zero  > 120 seconds	8 failures out of 10 samples  Frequency: 2 tests per trip 30 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 2	P0137	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 50 mvolts	No Active DTC's  AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active All Fuel Injectors for active Cylinders Fuel Condition Fuel State  All of the above met for	TPS_ThrottleAuthority DefaultedMAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA = Not active = Not active = Not active = Not active 10.0 < Volts < 32.0 = Not active = Not active = Not active = Not active = False 0.9912 ≤ ratio ≤ 1.0137 50 ≤ mgrams ≤ 500 = Closed Loop = TRUE  Enabled (On) Ethanol <= 87 %DFCO not active  > 5.0 seconds	430 failures out of 540 samples  Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 2	P0138	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	== Open Test Criteria == No Active DTC's  System Voltage AFM Status Heater Warm-up delay Engine Run Time Fuel Condition ===== No Active DTC's  Low Fuel Condition Diag Fuel Condition  Initial delay after Open Test Criteria met (cold start condition)  Initial delay after Open Test Criteria met (not cold start condition)  Equivalence Ratio Air Per Cylinder Fuel Control State	===== TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds ≤ 87 %Ethanol ===== MAP_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA AIR System FA = False ≤ 87 % Ethanol  > 105.0 seconds when engine soak time > 28,800 seconds  > 105.0 seconds when engine soak time ≤ 28,800 seconds  0.9912 ≤ ratio ≤ 1.0137 50 ≤ mgrams ≤ 500 not = Power Enrichment	100 failures out of 125 samples  Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for	> 5.0 seconds		



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Rich to Lean Bank 1 Sensor 2	P013A	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Rich to Lean voltages range during Rich to Lean transition. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Post O2 sensor normalized integral value  OR  The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units   > 43.0 grams (upper voltage threshold is 450 mvolts and lower voltage threshold is 150 mvolts)	No Active DTC's   B1S2 DTC's Not Active this key cycle  System Voltage Learned heater resistance  ICAT MAT Burnoff delay Green O2S Condition  Low Fuel Condition Diag Post fuel cell  DTC's Passed  =====	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013B, P013E, P013F, P2270 or P2271  10.0 < Volts < 32.0 = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" ) = Not Valid = Not Valid, See definition of Green Sensor Delay Criteria (B1S2) in Supporting Tables tab.  = False = enabled  P2270 (and P2272 if applicable) P013E (and P014A if applicable)  =====	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA
					After above conditions are met: DFCO mode is			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					continued (wo driver initiated pedal input).			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Lean to Rich Bank 1 Sensor 2	P013B	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Lean to Rich voltages range during Lean to Rich transition. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	The EWMA of the Post O2 sensor normalized integral value  OR  The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units   > 108 grams (lower voltage threshold is 300 mvolts and upper voltage threshold is 600 mvolts)	No Active DTC's   B1S2 DTC's Not Active this key cycle  System Voltage Learned heater resistance  ICAT MAT Burnoff delay Green O2S Condition  Low Fuel Condition Diag Post fuel cell  DTC's Passed	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013A, P013E, P013F, P2270 or P2271  10.0 < Volts < 32.0 = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" ) = Not Valid = Not Valid, See definition of Green Sensor Delay Criteria (B1S2) in Supporting Tables tab. = False = enabled  P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable) P013F (and P014B if	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>=====</p> <p>After above conditions are met: Fuel Enrich mode continued.</p> <p>=====</p> <p>During this test the following must stay TRUE or the test will abort: 0.96 ≤ Fuel EQR ≤ 1.01</p>	<p>applicable)</p> <p>=====</p>		



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(no driver initiated pedal input).			



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>=====</p> <p>After above conditions are met: Fuel Enrich mode entered.</p> <p>=====</p> <p>During this test the following must stay TRUE or the test will abort: <math>0.96 \leq \text{Fuel EQR} \leq 1.01</math></p>	<p>=====</p>		



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Insufficient Activity Bank 1 Sensor 2	P0140	This DTC determines if the O2 sensor circuit is open.	Oxygen Sensor Signal	> 1,700 mvolts	No Active DTC's  System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition	TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 150 seconds ≤ 87 % Ethanol	200 failures out of 250 samples.  Frequency: Continuous 100 msec loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 2	P0141	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.3 > amps > 2.5	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle  All of the above met for	ECT_Sensor_FA 10.0 < Volts < 32.0 = Complete  = Not active  > zero  > 120 seconds	8 failures out of 10 samples  Frequency: 2 tests per trip 30 seconds delay between tests and 1 second execution rate.	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Learned Htr resistance  Engine Coolant IAT Engine run Accum  Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)  Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)  Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell  EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State  ===== All of the above met for at least 1.0 seconds, and then the Force Cat Rich	= Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )  > 70 °C > -40 °C > 120 seconds  1,250 ≤ RPM ≤ 2,300  1,100 ≤ RPM ≤ 2,450  3 ≤ gps ≤ 12  34.2 ≤ MPH ≤ 74.6  31.7 ≤ MPH ≤ 82.0  0.85 ≤ C/L Int ≤ 1.07 = TRUE not in control of purge not in estimate mode = enabled  = not active  = not active  ≥ 180.0 sec 600 ≤ °C ≤ 900 = DFCE possible  =====		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					intrusive stage is requested. ===== Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders ===== After above conditions are met: DFCO Mode is entered (wo driver initiated pedal input).	===== ≥ 690 mvolts = DFCO active ≤ 3 cylinders =====		

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 1	P015B	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test which runs in an enriched fuel mode to achieve the required response.	<p>The EWMA of the Pre O2 sensor normalized L2R time delay value</p> <p>OR</p> <p>[The Accumulated time monitored during the L2R Delayed Response Test (Gross failure).</p> <p>AND</p> <p>Pre O2 sensor voltage is</p> <p>OR</p> <p>At end of Cat Rich stage the Pre O2 sensor output is</p>	<p>&gt; 0.5 EWMA (sec)</p> <p>≥ 1.5 Seconds</p> <p>&lt; 350 mvolts</p> <p>&lt; 690 mvolts</p>	<p>No Active DTC's</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition</p> <p>O2 Heater (pre sensor) on for</p>	<p>TPS_ThrottleAuthorityDefault MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA P0131, P0132, P0134</p> <p>10.0 &lt; Volts &lt; 32.0 = Not active = Not active = Not active = Not active = False = Not Valid, See definition of Green Sensor Delay Criteria for the following locations: B1S1, B2S1 (if applicable) and B1S2 in Supporting Tables tab.</p> <p>≥ 40 seconds</p>	<p>Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponsesActive = TRUE, multiple tests per trip are allowed</p>	<p>Type A, 1 Trips EWMA</p>

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Learned Htr resistance  Engine Coolant IAT Engine run Accum  Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)  Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)  Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time  Predicted Catalyst temp Fuel State Number of fueled cylinders  =====	= Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" ) > 70 °C > -40 °C > 120 seconds  1,250 ≤ RPM ≤ 2,300  1,100 ≤ RPM ≤ 2,450  3 ≤ gps ≤ 12 34.2 ≤ MPH ≤ 74.6 31.7 ≤ MPH ≤ 82.0  0.85 ≤ C/L Int ≤ 1.07 = TRUE not in control of purge not in estimate mode = enabled = not active = not active ≥ 180.0 sec  600 ≤ °C ≤ 900 = DFCO inhibit ≥ 0 cylinders  =====		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					When above conditions are met: Fuel Enrich mode is entered.			





Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Catalyst Diag. Post O2 Diag. Device Control EVAP Diag.	Intrusive Test Not Active Intrusive Test Not Active Not Active "tank pull down" Not Active		
					No active DTC:	IAC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR System FA EvapExcessPrgePsb1_FA Ethanol Comp Snsr FA FuelInjectorCkt_FA EngMisfireDetected_FA EGRValvePerf_FA EGRValveCkt_FA MAP_EngVacuumStatus AmbPresDfltStatus TC_BoostPresSnsrFA O2Snsr_B1_Snsr_1_FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Rich Bank 1	P0172	<p>Determines if the fuel control system is in a rich condition, based on the filtered long-term fuel trim metric.</p> <p>There are two methods to determine a Rich fault. They are Passive and Intrusive. A Passive Test decision cannot be made when Purge is enabled. The Intrusive test is described below: Intrusive Test: When the filtered Purge Long Term Fuel Trim metric is <math>\leq 0.850</math>, purge is ramped off to determine if excess purge vapor is the cause of the rich condition. If the filtered Purge Long Term Fuel Trim metric <math>&gt; 0.850</math>, the test passes without checking the filtered Non-Purge Long Term Fuel Trim metric.</p> <p>Performing intrusive tests too frequently may also affect EVAP and EPAIII emissions, and the execution frequency of other diagnostics.</p>	<p><b>Passive Test:</b> The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (a value <math>&gt; 1.05</math> effectively nullifies the short-term fuel trim criteria)</p> <p><b>Intrusive Test:</b> For 2 out of 3 intrusive segments, the filtered Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (a value <math>&gt; 1.05</math> effectively nullifies the short-term fuel trim criteria)</p> <p><b>Segment Def'n:</b> Segments can last up to 35 seconds and are separated by the lesser of 30 seconds of purge-on time or enough time to purge 18 grams of vapor.</p>	<p><math>\leq 0.840</math></p> <p><math>\leq 2.000</math></p> <p><math>\leq 0.850</math></p> <p><math>\leq 0.840</math></p> <p><math>\leq 2.000</math></p>		<p>Secondary Parameters and Enable Conditions are identical to those for P0171, with the exception that fuel level is not considered.</p>	<p>Frequency: 100 ms Continuous Loop</p>	<p>Type B, 2 Trips</p>

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			A maximum of 3 completed segments or 30 attempts are allowed for each intrusive test. After an intrusive test report is completed, another intrusive test cannot occur for 300 seconds to allow sufficient time to purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge-on Long Term fuel trim > 0.850 for at least 60 seconds, indicating that the canister has been purged.					



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			----- Low Drive Test (Commanded high Pressure - Measured high Pressure)  AND Modeled Injection Pressure	----- Enabled >= 3.000 MPa  >= 3.00 MPa	Pressure  Engine Run Time  ----- Engine Speed Desired High Side Pressure Vehicle Speed  Battery Voltage Low Pressure Fuel Pump Pressure  Engine Run Time	>= KtFHPD_t_PumpCntrlEng RunThrsh(see supporting tables)  Enabled when a code clear is not active or not exiting device control  Engine is not cranking  ----- 1,000 <= RPM <= 2,200 7.00 <= MPa <= 8.00  >= 18.64 MPH  >= 11 Volts >= 0.275 MPa  >= KtFHPD_t_PumpCntrlEng RunThrsh(see supporting tables)  Enabled when a code clear is not active or not exiting device control	----- LoDrive Test >= 240 counts (12.5ms per count)	
			----- Sensor Stuck Test Measured High Pressure (max - min)	----- Enabled <= 0.100 MPa	----- Engine Speed  Vehicle Speed	>= KtFHPD_t_PumpCntrlEng RunThrsh(see supporting tables)  Enabled when a code clear is not active or not exiting device control  Engine is not cranking  ----- >= 2,000 RPM >= 18.64 MPH Enabled when a code clear is not active or not exiting device control Engine is not cranking Additional Enable Conditions: All must be	----- Stuck Test Engine Run Time >= KtFHPD_t_Pump CntrlEngRunThr sh(See Supporting Tables) or Accumulating engine crank time >= KtFHPD t SnsP	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and Manufacturers enable counter is 0)Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active Fuel InjCkt Not (FA or TFTKO) EST Driver Not(FA) Misfire detected Not(FA) MAFR sensor Not (FA) MAPR sensor Not (FA) APSR Pedal sensor Not(FA) TPSR sensor Not (FA) VSPR speed sensor Not(FA) SystemRPM Not (FA) Manual Clutch not engaged or vehicle has automatic transmission All cylinder are fuel enabled	rfStuckCrankTm out(See Supporting Tables)	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Barometric Pressure Inlet Air Temp Fuel Temp	and >= 70.0 KPA >= -20.0 DegC -20 <= Temp degC <= 90		



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Sensor Out of Range Low	P0192	This DTC checks the circuit for electrical integrity during operation.	High Pressure Fuel Sensor	$\leq 5\%$ of 5Vref	Battery Voltage	$\geq 11$ Volts  Engine Running	Both Run Continuously Engine Synchronous Mode 800 failures out of 1,000 samples Time Based Mode 400 failures out of 500 samples 6.25 ms Sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Sensor Out of Range High	P0193	This DTC checks the circuit for electrical integrity during operation.	High Pressure Fuel Sensor	>= 95 % of 5Vref	Battery Voltage	>= 11 Volts  Engine Running	Both Run Continuously Engine Synchronous Mode 800 failures out of 1,000 samples Time Based Mode 400 failures out of 500 samples 6.25 ms Sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Open Circuit (SIDI only)	P0201	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector 1 has determined to be an open circuit		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Open Circuit (SIDI only)	P0202	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector 2 has determined to be an open circuit		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Open Circuit (SIDI only)	P0203	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector has determined to be an open circuit		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Open Circuit (SIDI only)	P0204	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector has determined to be an open circuit		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit Low	P0222	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage <	0.250		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts;  57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit High	P0223	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage >	4.590		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts;  57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to ground	P0261	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to power	P0262	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to ground	P0264	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector 2 low side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to power	P0265	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to ground	P0267	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to power	P0268	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to ground	P0270	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to power	P0271	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Random Misfire Detected	P0300	These DTC's will determine if a random or a cylinder specific misfire is occurring by monitoring various terms derived from crankshaft velocity. The rate of misfire over an interval is compared to both emissions and catalyst damaging thresholds. The pattern of crankshaft acceleration after the misfire is checked to differentiate between real misfire and other sources of crank shaft noise.	Deceleration Value vs. Engine Speed and Engine load	[ (>Idle_SCD_dt AND > Idle_SCD_ddt) OR (>SCD_dt AND > SCD_ddt) OR (>Idle_Cyl_Mode_dt AND > Idle_Cyl_Mode_ddt ) OR (>Cyl Mode dt AND > Cyl Mode ddt) OR (>Rev Mode Table) OR (> AFM Table in Cyl Deactivation mode)] - see details on Supporting Tables Tab (P0300 Section)	Engine Run Time  Engine Coolant Temp Or If ECT at startup Then ECT  System Voltage + Throttle delta - Throttle delta  Early Termination option: (used on plug ins that may not have enough engine run time at end of trip for normal interval to complete.)	> 2 crankshaft revolution  -7 °C < ECT < 125 °C < -7 °C 21 °C < ECT < 125 °C  9.00 < volts < 32.00 < 95.00 % per 25 ms < 95.00 % per 25 ms  Not Enabled	Emission Exceedence = any ( 5 ) failed 200 rev blocks out of ( 16 ) 200 rev block tests  Failure reported for (1) Exceedence in 1st ( 16 ) 200 rev block tests, or ( 4 ) Exceedences thereafter.  OR when Early Termination Reporting = Enabled and engine rev > 1,000 revs and < 3,200 revs at end of trip	Type B, 2 Trips (Mil Flashes with Catalyst Damaging Misfire)	
Cylinder 1 Misfire Detected	P0301		The equation used to calculate deceleration value is tailored to specific vehicle operating conditions. Tables used are 1st tables encountered that are not max of range.	Misfire Percent Emission Failure Threshold	≥ 0.63 % P0300				
Cylinder 2 Misfire Detected	P0302		Undetectable region at a given speed/load point is where all tables are max of range point. see Algorithm Description Document for additional details.	Misfire Percent Catalyst Damage	> "Catalyst_Damaging Misfire_Percentage" Table whenever secondary conditions are met.	(at low speed/loads, one cylinder may not cause cat damage)		any Catalyst Exceedence = ( 1 ) 200 rev block as data supports for catalyst damage.	
Cylinder 3 Misfire Detected	P0303					Engine Speed Engine Load Misfire counts	> 1,000 rpm AND > 20 % load AND < 180 counts on one cylinder	Failure reported with (1 or 3) Exceedences in FTP, or (1) Exceedence outside FTP.	
Cylinder 4 Misfire Detected	P0304								
If cylinders present:									
Cylinder 5 Misfire Detected	P0305								
Cylinder 6 Misfire Detected	P0306								
Cylinder 7 Misfire Detected	P0307								
Cylinder 8 Misfire Detected	P0308		When engine speed and load are less than the FTP calcs (3) catalyst damage exceedences are allowed.	≤ 0 FTP rpm AND ≤ 0 FTP % load					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Engine Speed	450 < rpm < ((Engine Over Speed Limit) - 400  Engine speed limit is a function of inputs like Gear and temperature  see Engine OverSpeed Limit in supporting tables	Continuous  4 cycle delay	
				disable conditions:	No active DTCs:	TPS_FA EnginePowerLimited MAF_SensorTFTKO MAP_SensorTFTKO IAT_SensorTFTKO ECT_Sensor_Ckt_TFTKO 5VoltReferenceB_FA CrankSensorTFTKO CrankSensorFA CamLctnIntFA CamLctnExhFA CamSensorAnyLctnTFTKO O AnyCamPhaser_FA AnyCamPhaser_TFTKO AmbPresDfstdStatus	4 cycle delay	
					P0315 & engine speed	> 1,000 rpm	4 cycle delay	
					Fuel Level Low	LowFuelConditionDiagnostic	500 cycle delay	
					Cam and Crank Sensors	in sync with each other	4 cycle delay	
					Misfire requests TCC unlock	Not honored because Transmission in hot mode or POPD intrusive	4 cycle delay	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						diagnostic running		
					Fuel System Status	≠ Fuel Cut	4 cycle delay	
					Active Fuel Management	Transition in progress	0 cycle delay	
					Undetectable engine speed and engine load region	invalid speed load range in decel index tables	4 cycle delay	
					Abusive Engine Over Speed	> 8,192 rpm	0 cycle delay	
					Below zero torque (except CARB approved 3000 rpm to redline triangle.)	< ZeroTorqueEngineLoad in Supporting Tables	4 cycle delay	
					Below zero torque: TPS Veh Speed	≤ 1 % > 19 mph	4 cycle delay	
					EGR Intrusive test	Active	12 cycle delay	
					Manual Trans	Clutch shift	4 cycle delay	
					Throttle Position AND Automatic transmission shift	> 100.00 %	7 cycle delay	
					Driveline Ring Filter active After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early. Filter Driveline ring:	> "Ring Filter" # of engine cycles after misfire in Supporting Tables		
					Stop filter early:	> "Number of Normals" # of engine cycles after		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Abnormal engine speed oscillations: (Rough road etc) Off Idle, number of consecutive decelerating cylinders after "misfire": (Number of decels can vary with misfire detection equation)</p>	<p>misfire in Supporting Tables tab</p>		
					<p>TPS Engine Speed Veh Speed</p>	<p>&gt; 3 % &gt; 1,000 rpm &gt; 3 mph</p>		
					<p>Consecutive decels while in SCD Mode Cyl Mode Rev Mode</p>	<p>&gt; Abnormal SCD Mode &gt; Abnormal Cyl Mode &gt; Abnormal Rev Mode in Supporting Tables</p>		
					<p>Misfire Crankshaft Pattern Recognition checks each "misfire" candidate in 100 engine Cycle test to see if it looks like real misfire, or some disturbance like rough road. The check is based on a multiplier times the ddt_jerk value used to detect misfire at that speed and load. At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present.</p>			
					<p>Pattern Recog Enabled:</p>	<p>Disabled</p>		



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position System Variation Not Learned	P0315	Monitor for valid crankshaft error compensation factors	Sum of Compensation factors. Each Cylinder pair shares one compensation factor. A perfect factor would be 1.0000. Unlearned factors are defaulted out of range so the sum of factors would be out of range.	$\geq 2.0040$ OR $\leq 1.9960$	OBD Manufacturer Enable Counter	MEC = 0	0.50 seconds  Frequency Continuous100 msec	Type A, 1 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock)  VaKNKD_k_PerfCylFlatFil tInt		Cumulative Number of Engine Revs Above Min Eng Speed (per keycycle)	≥ 200 Revs	Weight Coefficient = 0.010  Updated each engine event	



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank 1	P0325	This diagnostic checks for an open in the knock sensor circuit	Filtered FFT Output	> OpenCktThrshMin and < OpenCktThrshMax  See Supporting Tables for OpenCktThrshMin & OpenCktThrshMax	Diagnostic Enabled?  Engine Run Time  Engine Speed  Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)  Engine Air Flow  ECT  IAT	Yes  ≥ 2.0 seconds  ≥ 400 RPM and ≤ 8,500 RPM  ≥ 100 revs  ≥ 40 mg/cylinder and ≤ 2,000 mg/cylinder  ≥ -40 deg's C  ≥ -40 deg's C	First Order Lag Filter with Weight Coefficient  Weight Coefficient = 0.0100  Updated each engine event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Knock Sensor (KS) Performance Bank 1	P0326	This diagnostic checks for knock sensor performance out of the normal expected range, on a per sensor basis, due to 1. Excessive knock or 2. Abnormal engine noise or 3. Flat signal	Common Enable Criteria  (Applies to all 3 parts of the performance diag)		Diagnostic Enabled?  Engine Run Time  Engine Speed  Engine Air Flow  ECT  IAT	Yes  ≥ 2.0 seconds  ≤ 8,500 RPM  ≥ 40 mg/cylinder and ≤ 2,000 mg/cylinder  ≥ -40 deg's C  ≥ -40 deg's C	First Order LagFilters with WeightCoefficien ts  Weight Coefficient =  0.0100  Updated each engine event	Type B, 2 Trips	
			Specific Enable Criteriaand Thresholds for 3 individual parts of the performance diag:  1. Excessive Knock Diag: Filtered Knock Intensity	> 0.30 (no units)	Engine Speed  Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	≥ 400 RPM  ≥ 100 Revs			Updated each engine event
			(where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)  2. Abnormal Noise Diag: Filtered FFT Intensity:	< Abnormal Noise Threshold (see Supporting Tables)	Engine Speed  Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	≥ 2,000 RPM  ≥ 400 Revs			
3. Flat Signal Diag:	< 0.000 (no units)	Engine SpeedCumulative	≥ 8,500 RPM	Updated each engine event					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock)		Number of Engine Revs Above Min Eng Speed (per keycycle)	≥ 100 Revs	WeightCoefficient =  0.010  Updated each engine event	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 1	P0327	This diagnostic checks for an out of range low knock sensor signal	Sensor Input or Return Signal Line	< 8.0 Percent  (of 5 V reference)	Diagnostic Enabled?  Engine Speed	Yes  > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 1	P0328	This diagnostic checks for an out of range high knock sensor signal	Sensor Input or Return Signal Line	> 39.0 Percent  (of 5 Volt Reference)	Diagnostic Enabled?  Engine Speed	Yes  > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Circuit	P0335	Determines if a fault exists with the crank position sensor signal	Time since last crankshaft position sensor pulse received	>= 4.0 seconds	Starter engaged AND (cam pulses being received OR ( DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow	= FALSE  = FALSE  = FALSE  > 3.0 grams/second ) )	Continuous every 100 msec	Type B, 2 Trips
			No crankshaft pulses received	>= 1.0 seconds	Engine is Running  Starter is not engaged  No DTC Active:	5VoltReferenceB_FA	Continuous every 12.5 msec	
			No crankshaft pulses received		Engine is Running OR Starter is engaged  No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA P0365 P0366	2 failures out of 10 samples  One sample per engine revolution	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Performance	P0336	Determines if a performance fault exists with the crank position sensor signal	Time in which 10 or more crank re-synchronizations occur	< 10.0 seconds	Engine Air Flow Cam-based engine speed No DTC Active:	>= 3.0 grams/second > 450 RPM 5VoltReferenceB_FA P0335	Continuous every 250 msec	Type B, 2 Trips
			No crankshaft synchronization gap found	>= 0.4 seconds	Engine is Running Starter is not engaged No DTC Active:	5VoltReferenceB_FA	Continuous every 12.5 msec	
			Time since starter engaged without detecting crankshaft synchronization gap	>= 1.5 seconds	Starter engaged AND ( cam pulses being received OR ( DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow	= FALSE = FALSE = FALSE > 3.0 grams/second ) )	Continuous every 100 msec	
			Crank pulses received in one engine revolution OR Crank pulses received in one engine revolution	< 51 > 65	Engine is Running OR Starter is engaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA P0365 P0366	8 failures out of 10 samples  One sample per engine revolution	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor A	P0340	Determines if a fault exists with the cam position bank 1 sensor A signal	Time since last camshaft position sensor pulse received	>= 5.5 seconds	Starter engaged AND (cam pulses being received OR ( DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow	= FALSE  = FALSE  = FALSE  > 3.0 grams/second ) )	Continuous every 100 msec	Type B, 2 Trips
			OR  Time that starter has been engaged without a camshaft sensor pulse	>= 4.0 seconds				
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running  Starter is not engaged  No DTC Active:	5VoltReferenceA_FA	Continuous every 100 msec	
			No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized  Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged  No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	Continuous every MEDRES event	
			The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized  No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	8 failures out of 10 samples  Continuous every engine cycle	



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor A	P0341	Determines if a performance fault exists with the cam position bank 1 sensor A signal	The number of camshaft pulses received during first 12 MEDRES events is OR  (There are 12 MEDRES events per engine cycle)	< 4 > 10	Crankshaft is synchronized  Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged  No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized  No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	8 failures out of 10 samples  Continuous every engine cycle	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT	P0351	This diagnostic checks the circuit for electrical integrity during operation. Monitors EST for Cylinder 1 (Cylinders 1 and 4 for V6 with waste spark)	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT	P0352	This diagnostic checks the circuit for electrical integrity during operation. Monitors EST for Cylinder 2 (Cylinders 2 and 5 for V6 with waste spark)	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT	P0353	This diagnostic checks the circuit for electrical integrity during operation. Monitors EST for Cylinder 3 (Cylinders 3 and 6 for V6 with waste spark)	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT	P0354	This diagnostic checks the circuit for electrical integrity during operation. Monitors EST for Cylinder 4 (if applicable)	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor B	P0365	Determines if a fault exists with the cam position bank 1 sensor B signal	Time since last camshaft position sensor pulse received	>= 5.5 seconds	Starter engaged AND (cam pulses being received	= FALSE = FALSE = FALSE > 3.0 grams/second ) )	Continuous every 100 msec	Type B, 2 Trips
			OR					
			Time that starter has been engaged without a camshaft sensor pulse	>= 4.0 seconds	OR ( DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow			
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running  Starter is not engaged  No DTC Active:			
No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized  Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged  No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	Continuous every MEDRES event				
The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized  No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	8 failures out of 10 samples  Continuous every engine cycle				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor B	P0366	Determines if a performance fault exists with the cam position bank 1 sensor B signal	The number of camshaft pulses received during first 12 MEDRES events is OR  (There are 12 MEDRES events per engine cycle)	< 4 > 10	Crankshaft is synchronized  Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged  No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized  No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	8 failures out of 10 samples  Continuous every engine cycle	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Incorrect Airflow	P0411	Detects an insufficient flow condition. This test is run during Phase 1 (AIR pump commanded On, Valve commanded Open). Leaks downstream of the valve are detected via an evaluation of average pressure error and average "String Length"(SL) – a term that represents the absolute pressure delta accumulated every 6.25ms, then averaged over the duration of the test. Low SL values are indicative of downstream leaks or blockages.	Average Pressure Error or  OR the following <b>String Length (SL) Test:</b>  Average Pressure Error or  and the Average String Length  NOTE: Average Pressure Error is the average difference between the predicted pressure and the measured pressure	> 4.5 kPa < -7.5 kPa   > 5.0 kPa < -1.0 kPa   < SL Threshold Bank 1 Table	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not  SL Stability time SL RPM range  No active DTCs:	> 60 kPa > -11.0 deg C > -11.0 deg C < 56.0 > 1,800.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec  > 4.0 seconds < 4,700 RPM > 4,900  AIRSystemPressureSens or FA AIRValveControlCircuit FA AIRPumpControlCircuit FA MAF_SensorFA AmbientAirDefault_NA IAT_SensorFA ECT_Sensor_FA EngineMisfireDetected_F A CatalystSysEfficiencyLoB 1_FA CatalystSysEfficiencyLoB 2_FA ControllerProcessorPerf_ FA 5VoltReferenceA_FA 5VoltReferenceB_FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA	Phase 1 Conditional test weight > 7.0 seconds  Total 'String Length' accumulation time > 10.0 sec  Frequency: Once per trip when AIR pump is commanded On  Conditional test weight is calculated by multiplying the following Factors: Phase 1 Baro Test Weight Factor, Phase 1 MAF Test Weight Factor, Phase 1 System Volt Test Weight Factor, Phase 1 Ambient Temp Test Weight Factor (see Supporting Tables)	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Solenoid Control Circuit	P0412	This DTC checks the AIR solenoid circuit for electrical integrity	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.	20 failures out of 25 samples	System Voltage	10.0 Volts 2.0	25 samples (250 ms per sample)  Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Pump Control Circuit	P0418	This DTC checks the AIR Pump circuit for electrical integrity	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.	20 failures out of 25 samples	System Voltage	> 10.0 Volts < 32.0	25 samples (250 ms per sample)  Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 1	P0420 - Applies to applications that use the Idle Catalyst Monitor Algorithm	The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (I.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Lean and Rich A/F excursions  Normalized Ratio OSC Value Calculation Information and Definitions = 1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time) 2. BestFailing OSC value from a calibration table (based on temp and exhaust gas flow) 3. WorstPassing OSC value (based on temp and exhaust gas flow)  Normalized Ratio Calculation = (1-2) / (3-2)	Normalized Ratio OSC Value (EWMA filtered)	< 0.35	<u>There must be a valid idle period. The criteria are:</u>  Driver must be off the accel pedal. This checks that the final accel pedal position (comprehending deadband and hysteresis) is essentially zero.  Idle Speed Control System Is Active  Vehicle Speed  Engine speed  Engine run time  Tests attempted this trip  The catalyst diagnostic has not yet completed for the current trip.  <u>Catalyst Idle Conditions Met Criteria is satisfied which includes the General Enable met and the Valid Idle Period Criteria met. as well as:</u>	< 1.24 MPH  > 1,100 RPM for a minimum of 25 seconds since end of last idle period.  > MinimumEngineRunTime, This is a function of Coolant Temperature, please see Supporting Tables  < 255	1 test attempted per valid idle period  Minimum of 1 test per trip  Maximum of 8 tests per trip  Frequency: Fueling Related : 12.5 ms  OSC Measurements: 100 ms  Temp Prediction: 1000ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part. The Catalyst Monitoring Test is done during idle. Several conditions must be met in order to execute this test. These conditions and their related values are listed in the secondary parameters area of this document.</p>			<p>Green Converter Delay</p> <p>Induction Air</p> <p>Intrusive test(s): Fueltrim Post O2 EVAP EGROther vehicle functions:</p> <p>Power Take Off RunCrank Voltage Ethanol Estimation</p> <p>ECT</p> <p>Barometric Pressure</p> <p>Idle Time before going intrusive is</p> <p>Idle time is incremented if Vehicle speed</p> <p>Short Term Fuel Trim</p>	<p>Not Active</p> <p>&gt; -20 ° C &lt; 250 ° C</p> <p>Not Active</p> <p>Not Active &gt; 10.90 Volts NOT in Progress</p> <p>&gt; 50 ° C &lt; 130 ° C</p> <p>&gt; 70 KPA</p> <p>&lt; 50 Seconds</p> <p>&lt; 1.24 MPH and the drivers foot is off accel pedal and the idle speed control system is active as identified in the Valid Idle Period Criteria section.</p> <p>&gt; 0.90 &lt; 1.25</p> <p>&gt; 600.00 degC</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Predicted catalyst temp AND Engine Airflow</p> <p>for at least</p> <p>with a closed throttle time</p> <p>Also, in order to increment the WarmedUpEvents counter, either the vehicle speed must exceed the vehicle speed cal or the driver must NOT be off the accel pedal as stated in the Valid Idle Period Criteria section above.</p> <p>Closed loop fueling (Please see "Closed Loop Enable Criteria" section of the "Supporting Tables" tab for details.)</p>	<p>&gt; MinAirflowToWarmCatalyst table (g/s) (refer to "Supporting Tables" tab) (Based on engine coolant at the time the WarmedUpEvents counter resets to 0.)</p> <p>28 seconds</p> <p>&lt; 120 seconds consecutively (closed throttle consideration involves having the driver off the accel pedal as stated in the Valid Idle Period Criteria Section) .</p> <p>Enabled in Drive Range</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					PRNDL  Idle Stable Criteria:  MAF  Predicted catalyst temperature  <u>Engine Fueling Criteria at                      Beginning of Idle Period</u> The following fueling related must also be met from between 4 and 7 seconds after the Catalyst Idle Conditions Met Criteria has been met for at least 4 seconds prior to allowing intrusive control:  Number of pre-O2 switches  Short Term Fuel Trim Avg  Rapid Step Response (RSR) feature will initiate multiple tests:  If the difference between current EWMA value and the current OSC Normalized Ratio value is  and the current OSC	on an Auto Transmission vehicle.  Must hold true from after Catalyst Idle Conditions Met to the end of test  > 2.50 g/s < 11.00 g/s  < 900 degC           >= 2  > 0.96 < 1.04           > 0.64    < 0.27		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Normalized Ratio value is</p> <p>Maximum RSR tests to detect failure when RSR is enabled.</p> <p><u>Green Converter Delay Criteria</u> This is part of the check for the Catalyst Idle Conditions Met Criteria section</p> <p>The diagnostic will not be enabled until the following has been met:</p> <p>Predicted catalyst temperature</p> <p>for</p> <p>Note: this feature is only enabled when the vehicle is new and cannot be enabled in service</p> <p>PTO</p> <p><u>General Enable</u> DTC's Not Set</p>	<p>24</p> <p>&gt; 0 ° C</p> <p>0 seconds non-continuously.</p> <p>Not Active</p> <p>MAF_SensorFA MAF_SensorTFTKO AmbPresDfstdStatus IAT_SensorCircuitFA IAT_SensorCircuitTFTKO ECT_Sensor_FA O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA O2S_Bank_2_Sensor_1_FA</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						O2S_Bank_2_Sensor_2_ FA FuelTrimSystemB1_FA FuelTrimSystemB1_TFTK O FuelTrimSystemB2_FA FuelTrimSystemB2_TFTK O EngineMisfireDetected_F A EvapPurgeSolenoidCircuit _FA IAC_SystemRPM_FA EGRValvePerformance_F A EGRValveCircuit_FA CamSensorAnyLocationF A CrankSensorFA TPS_Performance_FA EnginePowerLimited		





Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>then opened for 60 seconds to normalize the system pressure. The vent is again closed to begin the vacuum portion of the test (phase-2). As the fuel temperature continues to fall, a vacuum will begin forming. The vacuum will continue until it reaches a vacuum peak. When the pressure rises 62.27 Pa from vacuum peak, the test then completes. If the key is turned on while the diagnostic test is in progress, the test will abort.</p>			<p>Startup delta deg C (ECT-IAT)</p> <p>OR</p> <p>2. Short Soak and Previous EAT Valid</p> <p>Previous time since engine off</p> <p>OR</p> <p>3. Less than a short soak and Previous EAT Not Valid</p> <p>Previous time since engine off</p> <p>AND</p> <p>Vehicle Speed</p> <p>AND</p> <p>Mass Air Flow</p> <p>Must expire Estimate of Ambient Temperature Valid Conditioning Time. "P0442: Estimate of Ambient Temperature Valid Conditioning Time" in Supporting Tables Tab.</p> <p>OR</p> <p>4. Not a Cold Start and greater than a Short Soak</p> <p>Previous time since engine off</p> <p>AND</p> <p>Vehicle Speed</p> <p>AND</p> <p>Mass Air Flow</p>	<p>≤ 8 °C</p> <p>≤ 7,200 seconds</p> <p>≤ 7,200 seconds</p> <p>≥ 19.9 mph</p> <p>≥ 6 g/sec</p> <p>&gt; 7,200 seconds</p> <p>≥ 19.9 mph</p> <p>≥ 6 g/sec</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Must expire maximum value in Estimate of Ambient Temperature Valid Conditioning Time. Please see "P0442: Estimate of Ambient Temperature Valid Conditioning Time" in Supporting Tables Tab.</p> <p>1. High Fuel Volatility</p> <p>During the volatility phase, pressure in the fuel tank is integrated vs. time. If the integrated pressure is then test aborts and unsuccessful attempts is incremented.</p> <p>OR</p> <p>2. Vacuum Refueling Detected</p> <p>See P0454 Fault Code for information on vacuum refueling algorithm.</p> <p>OR</p> <p>3. Fuel Level Refueling Detected</p> <p>See P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>4. Vacuum Out of Range</p>	< -5		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>and No Refueling</p> <p>See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>5. Vacuum Out of Range and Refueling Detected</p> <p>See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>6. Vent Valve Override Failed</p> <p>Device control using an off-board tool to control the vent solenoid, cannot exceed during the EONV test</p> <p>OR</p> <p>7. Key up during EONV test</p> <p>No active DTCs:</p>	<p>0.50 seconds</p> <p>MAF_SensorFA ECT_Sensor_FA IAT_SensorFA VehicleSpeedSensor_FA IgnitionOffTimeValid AmbientAirDefault</p> <p>P0443</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						P0446 P0449 P0452 P0453 P0455 P0496		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Canister Purge Solenoid Valve Circuit (ODM)  (Not Sealed Fuel System)	P0443	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		PT Relay Voltage	Voltage ≥ 11 volts	20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent System Performance  (Not Sealed Fuel System)	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filler, vent hose or EVAP canister.  This test runs with normal purge and vent valve is open.	Vent Restriction Prep Test: Vented Vacuum for OR Vented Vacuum for  Vent Restriction Test: Tank Vacuum for before Purge Volume  After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time.	< -623 Pa 60 seconds  > 1,245 Pa 60 seconds  > 2,989 Pa 5 seconds ≥ 10 liters	Fuel Level System Voltage  Startup IAT  Startup ECT BARO  No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts 4 °C ≤ Temperature ≤ 30 °C ≤ 35 °C ≥ 70 kPa  MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited  P0443 P0449 P0452 P0453 P0454	Once per Cold Start  Time is dependent on driving conditions  Maximum time before test abort is 1,000 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent Solenoid Control Circuit (ODM)  (Not Sealed Fuel System)	P0449	This DTC checks the circuit for electrical integrity during operation. If the P0449 is active, an intrusive test is performed with the vent solenoid commanded closed for 15 seconds.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.				20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Performance  (Not Sealed Fuel System)	P0451	The DTC will be set if the fuel tank vacuum sensor is out of range when it tries to re-zero prior to the phase-1 or phase-2 portions of the engine-off natural vacuum small leak test.	<p>The tank vacuum sensor voltage is compared to a window about the nominal sensor voltage offset (~1.5 volts)</p> <p>Upper voltage threshold (voltage addition above the nominal voltage)</p> <p>Lower voltage threshold (voltage subtraction below the nominal voltage)</p> <p>The difference between tank vacuum sensor voltage and the nominal offset voltage is then normalized against the appropriate threshold listed above to produce a ratio between 0.0 and 1.0. This normalized re-zero ratio is then filtered with a EWMA (with 0= perfect pass and 1=perfect fail).</p> <p>When EWMA is the DTC light is illuminated.</p> <p>The DTC light can be turned off if the EWMA is and stays below the EWMA fail threshold for 2 additional consecutive trips.</p>	<p>0.2 volts</p> <p>0.2 volts</p> <p>&gt; 0.73 (EWMA Fail Threshold),</p> <p>≤0.40 (EWMA Re-Pass Threshold)</p>	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		This test is executed during an engine-off natural vacuum small leak test. The number of times that it executes can range from zero to two per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.	Type A, 1 Trips  EWMA  Average run length: 6 Run length is 2 trips after code clear or non-volatile reset

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Low Voltage  (Not Sealed Fuel System)	P0452	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too low out of range.	FTP sensor signal  The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~3736 Pa).	< 0.15 volts (3.0 % of Vref or ~ 1,681 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples  12.5 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit High Voltage  (Not Sealed Fuel System)	P0453	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too high out of range.	FTP sensor signal  The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~ -3736 Pa).	> 4.85 volts ( 97 % of Vref or ~ -4,172 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples  12.5 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Intermittent  (Not Sealed Fuel System)	P0454	This DTC will detect intermittent tank vacuum sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	If an abrupt change in tank vacuum is detected the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that a refueling event occurred. If a refueling is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem. An abrupt change is defined as a change in vacuum: in the span of 1.0 seconds. But in 12.5 msec. A refueling event is confirmed if the fuel level has a persistent change of for 30 seconds.	> 112 Pa < 249 Pa  10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes and the canister vent solenoid is closed		This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.  12.5 ms / sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Large Leak Detected  (Not Sealed Fuel System)	P0455	This DTC will detect a weak vacuum condition (large leak or purge blockage) in the EVAP system.  Purge valve is controlled (to allow purge flow) and vent valve is commanded closed.	Purge volume while Tank vacuum  After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time.  Weak Vacuum Follow-up Test (fuel cap replacement test) Weak Vacuum Test failed.  Passes if tank vacuum  Note: Weak Vacuum Follow-up Test can only report a pass.	> 16 liters  ≤ 2,740 Pa          ≥ 2,740 Pa	Fuel Level System Voltage  BARO Purge Flow  No active DTCs:  Cold Start Test  If ECT > IAT, Startup temperature delta (ECT-IAT): Cold Test Timer Startup IAT  Startup ECT  Weak Vacuum Follow-up Test This test can run following a weak vacuum failure or on a hot restart.	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts ≥ 70 kPa ≥ 3.00 %  MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited  P0443 P0449 P0452 P0453 P0454  ≤ 8 °C ≤ 1,000 seconds 4 °C ≤ Temperature ≤ 30 °C  ≤ 35 °C	Once per cold start  Time is dependent on driving conditions  Maximum time before test abort is 1,000 seconds  Weak Vacuum Follow-up Test  With large leak detected, the follow-up test is limited to 1,300 seconds. Once the MIL is on, the follow-up test runs indefinitely.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Performance  (For use on vehicles with a single fuel tank)	P0461	This DTC will detect a fuel sender stuck in range in the primary fuel tank.	Delta fuel volume change over an accumulated 239 miles.	< 3 liters	Engine Running  No active DTCs:	VehicleSpeedSensor_FA	250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Low Voltage	P0462	This DTC will detect a fuel sender stuck out of range low in the primary fuel tank.	Fuel level Sender % of 5V range	< 10 %			100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit High Voltage	P0463	This DTC will detect a fuel sender stuck out of range high in the primary fuel tank.	Fuel level Sender % of 5V range	> 60 %			100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Intermittent  (Not Sealed Fuel System)	P0464	This DTC will detect intermittent fuel level sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	<p>If a change in fuel level is detected, the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that an actual refueling event occurred. If a refueling event is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem.</p> <p>An intermittent change in fuel level is defined as:</p> <p>The fuel level changes by and does not remain for 30 seconds during a 600 second refueling rationality test.</p>	10 % > 10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		<p>This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.</p> <p>100 ms / sample</p>	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Open (ODM) (Not used on EREV)	P0480	This DTC checks for open circuit failures during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	Voltage $\geq$ 11 volts	50 failures out of 63 samples  100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Open (ODM)	P0481	This DTC checks for open circuit failures during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	Voltage ≥ 11 volts	50 failures out of 63 samples  100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Flow During Non- Purge  (Not Sealed Fuel System)	P0496	This DTC will determine if the purge solenoid is leaking to engine manifold vacuum.  This test will run with the purge valve closed and the vent valve closed.	Tank Vacuum for  Test time	> 2,491 Pa 5 seconds  ≥ refer to "P0496: Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level table" in Supporting Tables Tab.	Fuel Level System Voltage  BARO Startup IAT  Startup ECT Engine Off Time  No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts ≥ 70 kPa 4 °C ≤ Temperature ≤ 30 °C  ≤ 35 °C ≥ 28,800.0 seconds  MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited  P0443 P0449 P0452 P0453 P0454	Once per cold start  Cold start: max time is 1,000 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Low Engine Speed Idle System	P0506	This DTC will determine if a low idle exists	Filtered Engine Speed Error  filter coefficient	> 91.00 rpm  0.00300	Baro  Coolant Temp  Engine run time Ignition voltage Time since gear change  Time since a TCC mode change  IAT Vehicle speed Commanded RPM delta Idle time  For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa  > 60 °C and < 120 °C Must verify KfECTI_T_EngCoolHotLo Thresh is less than KfECTI_T_EngCoolHotHi Thresh  ≥ 60 sec  32 ≥ volts ≥ 11  ≥ 3 sec  > 3 sec  > -20 °C  ≤ 1.67 kph  ≤ 25 rpm  > 5 sec    > 5.00 pct or < 5.00 pct   PTO not active	Diagnostic runs in every 12.5 ms loop  Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	Transfer Case not in 4WD LowState  Off-vehicle device control (service bay control) must not be active.  following conditions not TRUE: (VeTESR_e_EngSpdReqI ntvType = CeTESR_e_EngSpdMinLi mit AND VeTESR_e_EngSpdReqR espType = CeTESR_e_NoSuggestio n)  Clutch is not depressed  TC_BoostPresSnsrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorCircuitFA EvapFlowDuringNonPurg e_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_F A IgnitionOutputDriver_FA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA FuelLevelDataFault		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for Idle time	LowFuelConditionDiagnos tic Clutch Sensor FA AmbPresDfltStatus P2771  > 5 sec		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Engine Speed Idle System	P0507	This DTC will determine if a high idle exists	Filtered Engine Speed Error  filter coefficient	< -182.00 rpm  0.00300	Baro  Coolant Temp  Engine run time Ignition voltage Time since gear change Time since a TCC mode change  IAT Vehicle speed Commanded RPM delta  For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa  > 60 °C and < 120 °C Must verify KfECTI_T_EngCoolHotLo Thresh is less than KfECTI_T_EngCoolHotHi Thresh  ≥ 60 sec 32 ≥ volts ≥ 11 ≥ 3 sec > 3 sec  > -20 °C ≤ 1.67 kph ≤ 25 rpm  > 5.00 pct or < 5.00 pct  PTO not active  Transfer Case not in 4WD LowState	Diagnostic runs in every 12.5 ms loop  Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	Off-vehicle device control (service bay control) must not be active.  following conditions not TRUE: (VeTESR_e_EngSpdReqIntvType = CeTESR_e_EngSpdMinLimit AND VeTESR_e_EngSpdReqRespType = CeTESR_e_NoSuggestion)  Clutch is not depressed  TC_BoostPresSnrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorCircuitFA EvapFlowDuringNonPurge_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_FA IgnitionOutputDriver_FA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA FuelLevelDataFaultLow FuelConditionDiagnostic Clutch SensorFA AmbPresDfltStatus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for Idle time	P2771  > 5 sec		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Rough Idle	P050D	Monitors the combustion performance when the cold start emission reduction strategy is active by accumulating and determining the percentage of engine cycles that have less than complete combustion relative to the total number of engine cycles in which Dual Pulse is active.	Deceleration index vs. Engine Speed Vs Engine load  Deceleration index calculation is tailored to specific vehicle. Tables used are 1st tables encountered that are not max of range. Undetectable region at a given speed/load point is where all tables are max of range point. see Algorithm Description Document for additional details.  Incomplete combustion identified by P0300 threshold tables:	(>Idle SCD AND >Idle SCD ddt Tables) OR (>Idle Cyl Mode AND > Idle Cyl Mode ddt Tables)	Misfire Algorithm Enabled (Refer to P0300 for Enablement Requirements)  OBD Manufacturer Enable Counter  To enable the diagnostic, the Cold Start Emission Reduction Strategy Must Be Active per the following:  Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure  In addition, Dual Pulse Strategy Is Enabled and Active Per the following:  Engine Speed  Accel Position  For the engine speeds and loads in which Dual Pulse is active:  Dual Pulse Error induced misfires percentage  Dual Pulse Error induced	= 0  < 500.00 degC > -10.00 degC <= 56.00 degC >= 60.00 KPa  >= 250.00 RPM <= 3,000.00 RPM  <= 1.00 Pct  >= catalyst damaging misfire  < 90% of the maximum achievable catalyst	Runs once per trip when the cold start emission reduction strategy is active and Dual Pulse is enabled and active.  Frequency: Engine Cycle  Test completes after Dual Pulse is no longer active OR The first 500 engine cycles have been reached	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					misfires percentage  Engine Cycles  The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following:  Catalyst Temperature AND Engine Run Time OR Engine Run Time OR  Barometric Pressure  Dual Pulse Strategy will exit per the following:  Engine Speed OR Accel Position  Dual Pulse Strategy will also exit if the any of the "Additional Dual Pulse Enabling Criteria" is not satisfied:	damaging misfire.  >= 50 < 501  >= 1,000.00 degC  >= 17.50 seconds  > "Extended Engine Exit Time" This Extended Engine Exit time is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details.  < 60.00 KPa  > 3,200.00 RPM > 2.00 Pct		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					"Additional Dual Pulse Enabling Criteria":  Green Engine Enrichment  Misfire Converter Protection strategy  Engine Metal Overtemp strategy  Fuel control state  Output State Control  DOD Or DFCO  Power Enrichment  Piston Protection  Hot Coolant Enrichment  Injector Flow Test   General Enable  DTC's Not Set:	Not Enabled  Not being requested  Not being requested  Open Loop  Not being requested for fuel  Not Active  Not Active  Not Active  Not Active  Not Active  Not Active   AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfTempSensorCktFA CrankSensorFaultActive FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA AnyCamPhaser_TFTKO Clutch Sensor FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						FuelInjectorCircuit_TFTKO FHPR_b_FRP_SnsrCkt_FA FHPR_b_FRP_SnsrCkt_TFTKO FHPR_b_PumpCkt_FA FHPR_b_PumpCkt_TFTKO TransmissionEngagedState_FA EngineTorqueInaccurate FuelPumpRlyCktFA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System Voltage Low	P0562	This DTC determines if the current system voltage is below the minimum required voltage for proper ECM operation.	System voltage	≤ 9 volts	Ignition is "ON"  Engine Speed	≥ 400 RPM	5 failures out of 6 samples  1 second/sample	Type C, 1 Trips Not "Special Type C"

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System Voltage High	P0563	This DTC determines if the current system voltage is above the maximum allowed voltage for proper ECM operation.	System voltage	≥ 18 volts	Ignition is "ON"		5 failures out of 6 samples  1 second/sample	Type C, 1 Trips  Not "Special Type C"



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Mutil- Function Switch Circuit	P0564	Detect when cruise control multi-function switch circuit (analog) voltage is in an illegal range	Cruise Control analog circuit voltage must be in an "illegal range" or "between ranges" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 0.500 seconds	MIL: Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control On Switch Circuit	P0565		Cruise Control On switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	MIL Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Resume Circuit	P0567	Detects a failure of the cruise resume switch in a continuously applied state	Cruise Control Resume switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 90.000 seconds	MIL: Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Set Circuit	P0568	Detects a failure of the cruise set switch in a continuously applied state	Cruise Control Set switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 90.000 seconds	MIL: Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Input Circuit	P0575	Detects rolling count or protection value errors in Cruise Control Switch Status serial data signal	If x of y rolling count / protection value faults occur, disable cruise for duration of fault		Cruise Control Switch Serial Data Error Diagnostic Enable	1.00	10 / 16 counts	MIL: Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Low	P057C	detects short to ground for brake pedal position sensor	If x of y samples are observed below failure threshold, default brake pedal position to zero percent.	5.00	Brake Pedal Position Sensore Low Voltage Diagnostic Enable	1.00	20 / 32.00 counts	MIL: Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit High	P057D	detects open circuit for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	95.00	Brake Pedal Position Sensore High Voltage Diagnostic Enable	1.00	20.00 / 32.00 counts	MIL: Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi- function Circuit Low Voltage	P0580	detects short to ground failure for cruise multi-function switch circuit	Cruise Control analog circuit voltage must be in an "Open Short To Ground" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	MIL: Type C, 1 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi- function Circuit High Voltage	P0581		Cruise Control analog circuit voltage must be in an "Short To Power" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	MIL: Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if the calibration check sum is incorrect or the flash memory detects an uncorrectable error via the Error Correcting Code.	The Primary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	Type A, 1 Trips
			The Primary Processor's Error Correcting Code hardware in the flash memory detects an error. Covers all software and calibrations.	254 failures detected via Error Correcting Code			Diagnostic runs continuously via the flash hardware.	
			The Primary Processor's calculated checksum does not match the stored checksum value for a selected subset of the calibrations.	2 consecutive failures detected or 5 total failures detected.			Diagnostic runs continuously. Will report a detected fault within 200 ms.	
			The Secondary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	
				In all cases, the failure count is cleared when controller shuts down				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Not Programmed	P0602	This DTC will be stored if the PCM is a service PCM that has not been programmed.	Output state invalid		PCM State	= crank or run  PCM is identified through calibration as a Service PCM	Diagnostic runs at powerup and once per second continuously after that	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Long Term Memory Reset	P0603	Non-volatile memory checksum error at controller power-up	Checksum at power-up does not match checksum at power-down				Diagnostic runs at powerup  Diagnostic reports a fault if 1 failure occurs	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM RAM Failure	P0604	Indicates that the ECM has detected a RAM fault	Indicates that the primary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	Type A, 1 Trips
			Indicates that the primary processor is unable to correctly read data from or write data to cached RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor is unable to correctly read data from or write data to TPU RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor detects a mismatch between the data and dual data is found during RAM updates. Detects a mismatch in data and dual data updates >	0.45200 s			When dual store updates occur.	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Indicates that the primary processor detects an illegal write attempt to protected RAM. Number of illegal writes are >	65,534 counts			Diagnostic runs continuously (background loop)	
			Indicates that the secondary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Fault	P0606	Indicates that the ECM has detected an internal processor integrity fault	Loss or invalid message of SPI communication from the Secondary Processor at initialization detected by the Primary Processor or loss or invalid message of SPI communication from the Secondary Processor after a valid message was received by the Primary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received		Run/Crank voltage >= 6.41 or Run/Crank voltage >= 11.00 , else the failure will be reported for all conditions	In the primary processor, 159 / 399 counts intermittent or 39 counts continuous; 39 counts continuous @ initialization. 12.5 ms /count in the ECM main processor	Type A, 1 Trips
			Loss or invalid message of SPI communication from the Primary Processor at initialization detected by the Secondary Processor or loss or invalid message of SPI communication from the Primary Processor after a valid message was received by the Secondary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received			In the secondary processor, 20 / 200 counts intermittent or 0.1875 s continuous; 0.4750 s continuous @ initialization. 12.5 ms /count in the ECM secondary processor	
			Checks for stack over or underflow in secondary processor by looking for corruption of known pattern at stack boundaries. Checks number of stack over/ under flow since last powerup reset >=	5		KeMEMD_b_StackLimitTestEnbl == 1 Value of KeMEMD_b_StackLimitTestEnbl is: 1 . (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			MAIN processor is verified by responding to a seed sent from the secondary with a key response to secondary. Checks number of incorrect keys	2 incorrect seeds within 8 messages, 0.2000 seconds		ignition in Run or Crank	150 ms for one seed continually failing	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			received > or Secondary processor has not received a new within time limit					
			Time new seed not received exceeded			always running	0.450 seconds	
			MAIN processor receives seed in wrong order			always running	3 / 17 counts intermittent. 50 ms/count in the ECM main processor	
			2 fails in a row in the Secondary processor's ALU check			KePISD_b_ALU_TestEnbl d == 1 Value of KePISD_b_ALU_TestEnbl d is: 1. (If 0, this test is disabled)	25 ms	
			2 fails in a row in the Secondary processor's configuration register masks versus known good data			KePISD_b_ConfigRegTestEnbl d == 1 Value of KePISD_b_ConfigRegTestEnbl d is: 1. (If 0, this test is disabled)	12.5 to 25 ms	
			Secondary processor detects an error in the toggling of a hardware discrete line controlled by the MAIN processor: number of discrete changes > = or < = over time window(50ms)	7 17		KePISD_b_MainCPU_SOH_FltEnbl d == 1 Value of KePISD_b_ConfigRegTestEnbl d is: 1. (If 0, this test is disabled)  time from initialization >= 0.4875 seconds	50 ms	
			memory and complement memory do not agree				0.19 seconds	



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Software background task first pass time to complete exceeds			Run/Crank voltage > 6.41	360.000 seconds	
			2 fails in a row in the MAIN processor's ALU check			KePISD_b_ALU_TestEnbl == 1 Value of KePISD_b_ALU_TestEnbl is: 1. (If 0, this test is disabled)	25 ms	
			2 fails in a row in the MAIN processor's configuration register masks versus known good data			KePISD_b_ConfigRegTestEnbl == 1 Value of KePISD_b_ConfigRegTestEnbl is: 1. (If 0, this test is disabled)	12.5 to 25 ms	
			Checks number of stack over/under flow since last powerup reset >=	5		KeMEMD_b_StackLimitTestEnbl == 1 Value of KeMEMD_b_StackLimitTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			Voltage deviation >	0.4950		KePISD_b_A2D_CnvrtrTestEnbl == 1 Value of KePISD_b_A2D_CnvrtrTestEnbl is: 1. (If 0, this test is disabled)	5 / 10 counts or 0.150 seconds continuous; 50 ms/count in the ECM main processor	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occurred since last	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_FlashECC_CktTestEnbl == 1 Value of KeMEMD_b_FlashECC_CktTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			controller initialization. Counter >=					
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_RAM_ECC_CktTestEnbl == 1 Value of KeMEMD_b_RAM_ECC_CktTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM variable, depends on length of time to write flash to RAM	
			MAIN processor DMA transfer from Flash to RAM has 1 failure			KePISD_b_DMA_XferTestEnbl == 1 Value of KePISD_b_DMA_XferTestEnbl is: 0. (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Control Circuit	P0615	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage  Engine Speed	Voltage ≥ 11 volts  ≥ 0 RPM	8 failures out of 10 samples  250 ms / sample	Type C, 1 Trips  Not "Special Type C"

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit Open	P0627	This DTC checks for an open and shorted high circuit while the device is commanded off.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage  Engine Speed	Voltage ≥ 11 volts  ≥ 0 RPM	8 failures out of 10 samples  250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit Low Voltage	P0628	This DTC checks for a shorted low circuit while the device is commanded on.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage  Engine Speed	Voltage ≥ 11 volts  ≥ 0 RPM	8 failures out of 10 samples  250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit High Voltage	P0629	This DTC checks for an open and shorted high circuit while the device is commanded off.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage  Engine Speed	Voltage $\geq$ 11 volts  $\geq$ 0 RPM	8 failures out of 10 samples  250 ms / sample	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module EEPROM Error	P062F	Indicates that the NVM Error flag has not been cleared	The next write to NVM will not succeed or the assembly calibration integrity check failed.		Ignition State	= unlock/accessory, run, or crank	1 test failure  Diagnostic runs once at powerup	Type A, 1 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VIN Not Programmed or Mismatched - Engine Control Module (ECM)	P0630	This DTC checks that the VIN is correctly written	At least one of the programmed VIN digits	= 00 or FF	OBD Manufacturer Enable Counter	= 0	250 ms / test Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #1 Circuit	P0641	Detects a continuous or intermittent short on the 5 volt reference circuit #1	ECM Vref1 < or ECM Vref1 > or the difference between ECM filtered Vref1 and Vref1 >	4.8750 5.1250  0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Air Conditioning Clutch Relay Control Circuit	P0645	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage  Engine Speed	Voltage ≥ 11 volts  ≥ 400 RPM	20 failures out of 25 samples  250 ms / sample	Type C, 1 Trips  Not "Special Type C"

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM)	P0650	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage  Remote Vehicle Start is not active	Voltage ≥ 11 volts	20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips  NO MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #2 Circuit	P0651	Detects a continuous or intermittent short on the 5 volt reference circuit #2	ECM Vref2 < or ECM Vref2 > or the difference between ECM filtered Vref2 and Vref2 >	4.8750 5.1250  0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM)	P0685	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples  250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Feedback Circuit Low	P0689	This DTC is a check to determine if the Powertrain relay is functioning properly.	PT Relay feedback voltage is	≤ 5 volts	Run/Crank Voltage  Powertrain relay commanded "ON"  No active DTCs:	≥ 11 volts  PowertrainRelayStateOn_ FA	5 failures out of 6 samples  1 second/sample	Type C, 1 Trips  Not "Special Type C"

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Feedback Circuit High	P0690	This DTC is a check to determine if the Powertrain relay is functioning properly.	Voltage stuck high  PT Relay feedback voltage is when commanded 'OFF'	> 4.0 volts	Powertrain relay commanded "ON"  No active DTCs:	>= 2 Seconds  PowertrainRelayStateOn_ FA	Stuck Test: 100 ms/ sample  50.00 failures out of 63.00 Samples	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Low Voltage (ODM)	P0691	This DTC checks for short to low voltage circuit failures during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	Voltage ≥ 11 volts	50 failures out of 63 samples  100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit High Voltage (ODM)	P0692	This DTC checks for short to high voltage circuit failures during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	Voltage ≥ 11 volts	50 failures out of 63 samples  100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Low Voltage (ODM)	P0693	This DTC checks for short to low voltage circuit failures during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	Voltage ≥ 11 volts	50 failures out of 63 samples  100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit High Voltage (ODM)	P0694	This DTC checks for short to high voltage circuit failures during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	Voltage ≥ 11 volts	50 failures out of 63 samples  100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #3 Circuit	P0697	Detects a continuous or intermittent short on the 5 volt reference circuit #3	ECM Vref3 < or ECM Vref3 > or the difference between ECM filtered Vref3 and Vref3 >	4.8750 5.1250  0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Control Module (FPCM) Requested MIL Illumination	P069E	Monitors the FPCM MIL request line to determine when the FPCM has detected a MIL illuminating fault.	Fuel Pump Control Module Emissions-Related DTC set			Time since power-up > 3 seconds	Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #4 Circuit	P06A3	Detects a continuous or intermittent short on the 5 volt reference circuit #4	ECM Vref4 < or ECM Vref4 > or the difference between ECM filtered Vref4 and Vref4 >	4.8750 5.1250  0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 1 Performance	P06B6	This diagnostic checks for a fault with the internal test circuit used only for the '20 kHz' method of the Open Circuit Diagnostic	FFT Diagnostic Output	> OpenTestThreshLo and < OpenTestThreshHi  See Supporting Tables	Diagnostic Enabled?  Engine Run Time  Engine Speed   Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)  Engine Air Flow	Yes  ≥ 2.0 seconds  > 400 RPM and < 3,500 RPM  ≥ 200 Revs  ≥ 40 mg/cylinder and ≤ 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient  Weight Coefficient =  0.0100  Updated each engine event	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Module (TCM) Requested MIL Illumination	P0700	Monitors the TCM MIL request line to determine when the TCM has detected a MIL illuminating fault.	Transmission Emissions-Related DTC set			Time since power-up > 3 seconds	Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Traction Control Torque Request Circuit	P0856	Determines if torque request from the EBTCM is valid	Serial Communication 2's complement message - (\$140 for PPEI2 or \$1C9 for PPEI3, \$1CA/\$1C6 for Hybrid))  OR Serial Communication message (\$140 for PPEI2 or \$1C9 for PPEI3, \$1CA/\$1C6 for Hybrid)) rolling count value  OR Too many minimum limit torque request transitions occur from TRUE to FALSE to TRUE within a time period  Torque request greater than torque request diagnostic maximum threshold	Message <> 2's complement of message  Message rolling count value <> previous message rolling count value plus one  Requested torque intervention type toggles from not increasing request to increasing request  > 250 Nm for engine based traction torque system, OR > 4,000 Nm for axle based traction torque system	Serial communication to EBTCM (U0108)  Power Mode Engine Running  Status of traction in GMLAN message (\$4E9)	No loss of communication  = Run = True  = Traction Present	Count of 2's complement values not equal >= 20  Performed on every received message  10 rolling count failures out of 10 samples  Performed on every received message  >= 5 multi-transitions out of 5 samples.  Performed every 200 ms  >= 4 out of 10 samples  Performed on every received message	Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (naturally aspirated)	P1101	Determines if there are multiple air induction problems affecting airflow and/or manifold pressure.	Filtered Throttle Model Error  AND ( ABS(Measured Flow – Modeled Air Flow) Filtered OR ABS(Measured MAP – MAP Model 1) Filtered  AND ABS(Measured MAP – MAP Model 2) Filtered	<= 300 kPa*(g/s)   > 17 grams/sec  > 25.0 kPa )   > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 575 RPM <= 6,600 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 125 Deg C  >= 0.50  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor Based on MAF Est  MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  See "Residual Weight Factor" tables.  MAP_SensorCircuitFA EGRValvePerformance_FA A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA	Continuous  Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Pending DTCs:	IAT_SensorFA EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Low	P11C2	Detects a continuous short to power in the Humidity Sensor circuit	Humidity Duty Cycle	<= 5.0 %	Powertrain Relay Voltage for a time  No Active DTCs:	>= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit High	P11C3	Detects a continuous open or short to low in the Humidity Sensor circuit	Humidity Duty Cycle	>= 95.0 %	Powertrain Relay Voltage for a time  No Active DTCs:	>= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Intermittent	P11C4	Detects a noisy or erratic humidity sensor input	String Length  Where: "String Length" = sum of "Diff" calculated over  And where: "Diff" = ABS(current Humidity reading - Humidity reading from 100 milliseconds previous)	> 40 %  10 consecutive Humidity samples	Powertrain Relay Voltage for a time  No Active DTCs:	>= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault	4 failures out of 5 samples	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 low side circuit shorted to high side circuit	P1248	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to low side		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 low side circuit shorted to high side circuit	P1249	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to low side		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 low side circuit shorted to high side circuit	P124A	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to low side		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 low side circuit shorted to high side circuit	P124B	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to low side		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Coil Positive Voltage Circuit Group 1 * * SIDI ONLY **	P135A	This diagnostic checks for voltage supply to the Ignition Coils (applicable only for SIDI applications)	Common Enable Criteria  Ignition Module Supply Voltage.  Three possible power supply sources for Ignition Coils: Case 1: Battery Case 2: Ignition Run/ Crank Case 3: PT Relay  Case Specific Enable Criteria	< 2.5 Volts  Ignition Coil Power Source =  (see corresponding case specific enable criteria below)	Diagnostic Enabled?  PT Relay	Yes  5 Engine Revs  > 11.0 volts  > 11.0 volts	50 Failures out of 63 Samples  6.25 msec rate	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Emissions Reduction System Fault	P1400	Model based test computes power from exhaust flow and thermal energy resulting from elevated idle speed and retarded spark advance. Detects if the cold start emission reduction system has failed resulting in the delivered power being out of range.	Average desired accumulated exhaust power - Average actual accumulated exhaust power (too much energy delivered to catalyst)  Average desired accumulated exhaust power - Average actual accumulated exhaust power (too little energy delivered to catalyst)  (EWMA filtered)	< -32.00 KJ/s (high RPM failure mode)  > 6.00 KJ/s (low RPM failure mode)	To enable the diagnostic, the Cold Start Emission Reduction Strategy must be Active per the following:  Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure  The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following:  Catalyst Temperature AND Engine Run Time OR Engine Run Time OR  Barometric Pressure  Other Enable Criteria:	< 500.00 degC  > -10.00 degC  <= 56.00 degC  >= 60.00 KPa  >= 1,000.00 degC  >= 17.50 seconds  > "Extended Engine Exit Time" This Extended Engine Exit time is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details.  < 60.00 KPa	Runs once per trip when the cold start emission reduction strategy is active  Frequency: 100ms Loop  Test completes after 10 seconds of accumulated qualified data.	EWMA Based - Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>OBD Manufacturer Enable Counter</p> <p>Vehicle Speed</p> <p>Allow diagnostic to calculate residual in an off-idle state. If the value of the OffIdleEnable is equal to 1 then the "DriverOffAccelPedal" will not be checked. However, if the value of OffIdleEnable is 0 then driver must be off the accel pedal</p> <p>A change in throttle position (tip-in/tip-out) will initiate a delay in the calculation of the average qualified residual value. Therefore: When the Pedal Close Delay Timer is : the diagnostic will continue the calculation.</p> <p>For Manual Transmission vehicles:</p>	<p>0</p> <p>&lt; 1.24 MPH</p> <p>0 (A value of 1 allows diagnostic to run and calculate the residual while off idle. A value of 0 requires calculation of the residual at idle)</p> <p>&gt; 5.00 seconds</p> <p>Clutch Pedal Top of Travel Achieved and Clutch Pedal Bottom of Travel Achieved. Refer to the "Clutch Pedal Top of Travel Achieved criteria" and "Clutch Pedal Bottom of Travel Achieved criteria" section of the "Supporting Tables" tab criteria</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>The diagnostic will delay calculation of the residual value and potentially weight the residual calculation differently based on engine run time. This is to ensure the diagnostic is operating in idle speed control as well as during the peak catalyst light off period. The "Time Weighting Factor" must be :</p> <p>General Enable:</p> <p>DTC's Not Set:</p>	<p>&gt; 0 These are scalar values that are a function of engine run time. Refer to "Supporting Tables" for details.</p> <p>AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFP CrankSensorFaultActive FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA EngineMisfireDetected_F A Clutch Sensor FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA 5VoltReferenceMAP_OO R_Flt TransmissionEngagedStat e_FA EngineTorqueInaccurate</p>		



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Engine Speed Request Circuit	P150C	Determines if engine speed request from the TCM is valid	Serial Communication rolling count value  Transmission engine speed protection	+ 1 from previous \$19D message (PTEI3)  not equal to 2's complement of transmission engine speed request + Transmission alive rolling count	Diagnostic enable bit  Engine run time  # of Protect Errors  # of Alive Rolling Errors  No idle diagnostic 506/507 code  No Serial communication loss to TCM  Engine Running  Power mode	1  0.50 sec  10 protect errors out of 10 samples  6 rolling count errors out of 10 samples  IAC_SystemRPM_FA  (U0101)  = TRUE  Run Crank Active	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Steady State Actuation Fault	P1516	Detect an inability to maintain a steady state throttle position	Throttle is considered to be steady state when: change in throttle position over 12.5 msec is <	0.25 percent 4.00 s		Run/Crank voltage > 6.41	0.49 ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Economy Mode Circuit Low	P159F	This DTC will detect a fuel saver switch input that is too low out of range.	Fuel Saver Switch % of 5V range  The normal operating range of the fuel saver mode switch is:  Switch depressed % of 5V range:  Switch released % of 5V range:	< 29.0 %          < 66.8 % ≥ 29.0 %    < 88.8 % ≥ 72.8 %			200 failures out of 250 samples  25 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Economy Mode Circuit High	P15A0	This DTC will detect a fuel saver switch input that is too high out of range.	Fuel Saver Switch % of 5V range  The normal operating range of the fuel saver mode switch is:  Switch depressed % of 5V range:  Switch released % of 5V range:	≥ 88.8 %    < 66.8 % ≥ 29.0 %  < 88.8 % ≥ 72.8 %			200 failures out of 250 samples  25 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Economy Mode Switch Performance	P15A1	This DTC will detect a fuel saver switch input that is in an indeterminate range.	Fuel Saver Switch % of 5V is in an indeterminate range:  The normal operating range of the fuel saver mode switch is:  Switch depressed % of 5V range:  Switch released % of 5V range:	$66.8\% \leq \% \text{ of } 5 \text{ volts} < 72.8\%$    $< 66.8\%$ $\geq 29.0\%$  $< 88.8\%$ $\geq 72.8\%$			200 failures out of 250 samples  25 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Remote Vehicle Speed Limiting Signal Circuit	P162B	Determines if the speed request from OnStar is valid	Password Protect error - Serial Communication message - (\$3ED)  OR  Rolling count error - Serial Communication message (\$3ED) rolling count value	Message <> two's complement of message   Message <> previous message rolling count value + one	Vehicle Requested Speed Limit	< 135 MPH  Can be lower speed if being requested by another non_ECM module  No loss of communication	>= 10 Password Protect errors out of 10 samples  OR  >= 10 Rolling count errors out of 10 samples  Performed on every received message	Type C, 1 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active and Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -20.0 degC -20 <= Temp degC <= 90		



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation	P1682	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage & the Powertrain Relay Ignition Voltage	Run/Crank – PT Relay Ignition  >	3.00 Volts		Powertrain commanded on  AND  (Run/Crank voltage > Table, f(IAT). See supporting tables  OR PT Relay Ignition voltage > 5.50 )  AND  Run/Crank voltage > 5.50 .	240 / 480 counts or 0.1750 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS SENT Comm Circuit Low	P16A0	Detects a Low Circuit Fault in the TPS SENT Communication Circuit	Voltage for wave pulse is below state threshold as defined by SAE J2716 SENT Protocol	0.5 V		Run/Crank voltage > 6.41	79 / 159 counts;  57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS SENT Comm Circuit High	P16A1	Detects a High Circuit Fault in the TPS SENT Communication Circuit	Voltage for wave pulse is above state threshold as defined by SAE J2716 SENT Protocol	4.1 V		Run/Crank voltage > 6.41	79 / 159 counts;  57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS SENT Comm Circuit Performance	P16A2	Detects a Message Fault in the TPS SENT Communication Circuit	Message Pulse < Message Pulse > or Message Age Limit >=  or Signal CRC fails	0.125977 ms 0.209991 ms  3.125 ms		Run/Crank voltage > 6.41	79 / 159 counts;  57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Redundant Memory Performance	P16F3	<p>Detect Processor Calculation faults due to RAM corruptions, ALU failures and ROM failures</p> <p>For all of the following cases: If the individual diagnostic threshold is equal to 2048 ms, this individual case is not applicable. If any of the following cases are X out of Y diagnostics and the fail (x) is greater than the sample (Y), this individual case is also not applicable.</p>	Desired Throttle Area calculated does not equal its redundant calculation	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	Type A, 1 Trips
			Equivance Ratio torque compensation exceeds threshold	-75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Absolute difference between Equivance Ratio torque compensation and its dual store out of bounds given by threshold	75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of Accessory torque and its redundant calculation is out of bounds given by threshold range	75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Filtered Air-per-cylinder and its redundant calculation is out of bounds given by threshold range	123.64 mg	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference between the previous Final Advance and the current Final Advance not Adjusted for Equivalence Ratio is out of bounds given by threshold range	14.08 degrees		Engine speed >0rpm	Up/down timer 140 ms continuous, 0.5 down time multiplier	
			Torque Learn offset is out of bounds given by threshold range	High Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold  0.00 Nm			multiplier	
			One step ahead calculation of air-per-cylinder and two step ahead is greater than threshold	80.00 mg		Engine speed > 625 rpm	Up/down timer 440 ms continuous, 0.5 down time multiplier	
			Difference between Unmanaged Spark and PACS Spark is greater than threshold	14.07 degrees	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Engine Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			Zero pedal axle torque is out of bounds given by threshold range	High Threshold 1,110.48 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Creep Coast Axle Torque is out of bounds given by threshold range	High Threshold 1,110.48 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Absolute difference of Friction torque and its redundant calculation is out of bounds given by threshold range	75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			Arbitrated Air-Per-Cylinder filter coefficient is out of bounds given by threshold range	High Threshold 1.000  Low Threshold 0.074	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Launch spark is active but the launch spark redundant path indicates it should not be active	N/A		Engine speed < 7,000.00 or 7,200.00 rpm (hysteresis pair)	Up/down timer 140 ms continuous, 0.5 down time multiplier	
			Rate limited vehicle speed and its dual store do not equal	N/A		Time since first CAN message with vehicle speed >= 0.500 sec	10 / 20 counts; 25.0msec/count	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Preload Throttle Area and its dual store do not equal	N/A	Ignition State	Accessory, run or crank  AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded engine torque due to fast actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded engine torque due to slow actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			TOS to wheel speed conversion factor is out of bounds given by threshold	High Threshold: 1.10	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			range	T/C Range Hi  0.10 T/C Range Lo  Low Threshold:  1.10 T/C Range Hi  0.10 T/C Range Lo				
			TOS to wheel speed conversion factor and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	
			Cylinders active greater than commanded	2 cylinders		Engine run flag = TRUE > 2.00 s Number of cylinder events since engine run > 24	Up/down timer 140 ms continuous, 0.5 down time multiplier	
						No fuel injector faults		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						active		
			Transfer case neutral request from four wheel drive logic does not match with operating conditions	N/A	Ignition State	Accessory, run or crank  Transfer case range valid and not over-ridden  FWD Apps only	32 / 400 counts; 25.0msec/count	
			Transfer case neutral and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	
			Driver progression mode and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Predicted torque for uncorrected zero pedal determination is greater than calculated limit.	Table, f(Engine, Oil Temp). See supporting tables + 75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Predicted Request Without Motor is greater than its redundant calculation plus threshold	74.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Immediate Request Without Motor is greater than its redundant calculation plus threshold	74.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Positive Torque Offset is greater than its redundant calculation plus threshold  OR  Positive Torque Offset is less than its redundant calculation minus threshold	75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Engine Request is greater than its redundant calculation plus threshold	75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Hybrid Predicted Crankshaft Request is greater than its redundant calculation plus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Hybrid Immediate Crankshaft Request is less than its redundant calculation minus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Regeneration Brake Assist is not within a specified range	Brake Regen Assist < 0 Nm or Brake Regen Assist >	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous.	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				0.00 Nm			0.5 down time multiplier	
			Cylinder Spark Delta Correction exceeds the absolute difference as compared to Unadjusted Cylinder Spark Delta	14.07 degrees	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			1. Cylinder Torque Offset exceeds step size threshold  OR  2. Sum of Cylinder Torque Offset exceeds sum threshold	1. 75.00 Nm  2. 75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Capacity Minimum Immediate Without Motor is greater than its dual store plus threshold	75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Capacity Minimum Engine Off is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Engine Capacity Minimum Engine Immediate Without Motor is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Immediate Engine Request is greater than its redundant calculation plus threshold	75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			PTO Torque Request exceeds allowed rate limited PTO Torque Request	9.38 Nm/25ms	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Speed Lores Intake Firing (event based) calculation does not equal its redundant	N/A		Engine speed greater than 0rpm	Up/down timer 140 ms continuous, 0.5	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			calculation				down time multiplier	
			Engine Speed Lores Intake Firing timing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 140 ms continuous, 0.5 down time multiplier	
			Idle speed control calculated predicted minimum torque request exceeds calculated torque limit	Table, f(Engine, Oil Temp). See supporting tables + 75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Idle speed control calculated predicted minimum torque without reserves exceeds calculated torque limit	Table, f(Engine, Oil Temp). See supporting tables + 75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference between Driver Requested Immediate Torque primary path and its secondary exceeds threshold	1,110.48 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Driver Immediate Request is less than its redundant calculation minus threshold	1,110.48 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded Immediate Request is greater than its redundant calculation plus threshold  OR  Commanded Immediate	1,110.48 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Request is less than its redundant calculation minus threshold					
			Commanded Immediate Response Type is set to Inactive	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Cylinders active greater than commanded	1 cylinder		Engine speed greater than 0rpm and less than 3,200 rpm AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Difference between Cruise Axle Torque Arbitrated Request and Cruise Axle Torque Request exceeds	138.81 Nm		Cruise has been engaged for more than 4.00 seconds	Up/down timer 2,048 ms continuous, 0.5 down time	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			threshold				multiplier	
			Desired engine torque request greater than redundant calculation plus threshold	74.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Engine min capacity above threshold	75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 132 ms continuous, 0.5 down time multiplier	
			No fast unmanaged retarded spark above the applied spark plus the threshold	Table, f(Erpm). See supporting tables		Engine speed greater than 0rpm	Up/down timer 140 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of adjustment factor based on temperature and its dual store above threshold	2.76 m/s	Ignition State	Accessory, run or crank	Up/down timer 180 ms continuous, 0.5 down time multiplier	
			1. Absolute difference of redundant calculated engine speed above threshold	500 RPM		Engine speed greater than 0 RPM	Up/down timer 140 ms continuous, 0.5 down time multiplier	
			After throttle blade pressure and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Speed Control's Predicted Torque Request and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			Engine oil temperature and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 420 ms continuous, 0.5 down time multiplier	
			Desired throttle position greater than redundant calculation plus threshold	8.22 percent	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the rate limited pre-throttle pressure and its redundant calculation greater than threshold	0.06 kpa	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Throttle desired torque	75.00	Ignition State	Accessory, run or crank	Up/down timer	



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			above desired torque plus threshold	Nm			475 ms continuous, 0.5 down time multiplier	
			Desired filtered throttle torque exceeds the threshold plus the higher of desired throttle torque or modeled throttle torque	75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Torque feedback proportional term is out of allowable range or its dual store copy does not match	High Threshold 37.50 Nm  Low Threshold -37.50 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Torque feedback integral term magnitude or rate of change is out of allowable range or its dual store copy do not match	High Threshold 70.31 Nm  Low Threshold -75.00 Nm  Rate of change threshold 4.69 Nm/loop	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of Final Torque feedback proportional plus integral term and its redundant calculation is out of bounds given by threshold range	High Threshold 75.00 Nm  Low Threshold -75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference of torque desired throttle area and its redundant calculation is out of bounds given by threshold range	High Threshold 0.50 %  Low Threshold -0.50 %	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of torque model coefficients and its redundant calculation is out of bounds given by threshold range	High Threshold 0.0001484 Low Threshold - 0.0001484	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Difference of base friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 75.00 Nm  Low Threshold	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				- 75.00 Nm				
			Accessory drive friction torque is out of bounds given by threshold range	High Threshold 75.00 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AC friction torque is greater than commanded by AC control software or less than threshold limit	High Threshold 40.00 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of Oil temperature delta friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 75.00 Nm  Low Threshold -75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Generator friction torque is out of bounds given by threshold range	High Threshold 75.00 Nm  Low Threshold	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				0.00 Nm				
			Supercharger friction torque is out of bounds given by threshold range	High Threshold 75.00 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Filtered Torque error magnitude or its increase rate of change is out of allowable range or its dual store copy do not match	High Threshold 75.00 Nm  Low Threshold -75.00 Nm  Rate of change threshold		Engine speed >0rpm MAF, MAP and Baro DTCs are false	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				4.69 Nm/loop				
			Torque error compensation is out of bounds given by threshold range	High Threshold 75.00 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Delta Torque Baro compensation is out of bounds given by threshold range	High Threshold 5.09 Nm  Low Threshold -2.50 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			1. Difference of reserve torque value and its redundant calculation exceed threshold  OR  2. Reserve request does not agree with operating conditions or Difference of final predicted torque and its redundant calculation exceed threshold  OR  3. Rate of change of reserve torque exceeds threshold, increasing direction only  OR  4. Reserve engine torque above allowable capacity threshold	1. 74.00 Nm  2. N/A  3. 74.00 Nm  4. 74.00 Nm	3. & 4.: Ignition State	1. & 2.: Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 75.00 Nm  3. & 4.: Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Engine Vacuum and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the	Table. f(Engine		Engine speed >0rpm	Up/down timer	



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			calculated Intake Manifold Pressure during engine event versus during time event is greater than threshold	Torque). See supporting tables			140 ms continuous, 0.5 down time multiplier	
			Min. Axle Torque Capacity is greater than threshold	0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Driver Predicted Request is greater than its redundant calculation plus threshold  OR  Driver Predicted Request is less than its redundant calculation minus threshold	1,110.48 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Cold Delta Friction Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Predicted torque for zero pedal determination is greater than calculated limit.	Table, f(Engine, Oil Temp). See supporting tables + 75.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Axle Torque and its dual store do not match	1 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Steady State Estimated Engine Torque and its dual store are not equal	N/A		AFM not changing from Active to Inactive and preload torque not	Up/down timer 1,988 ms continuous,	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						changing and one loop after React command  Engine speed >0rpm	0.5 down time multiplier	
			Difference of Weighting factor for number of cylinders fueled and its redundant calculation is above threshold	0.26		Engine run flag = TRUE > 10.00 s	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Difference of minimum spark advance limit and its redundand calculation is out of bounds given by threshold range	14.08 degrees	Ignition State	Accessory, run or crank	Up/down timer 140 ms continuous, 0.5 down time multiplier	
			Difference of commanded spark advance and adjusted delivered is out of bounds given by threshold range	14.08 degrees		Engine speed >0rpm	Up/down timer 140 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference between Estimated Engine Torque and its dual store are above a threshold	75.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Absolute difference between Estimated Engine Torque without reductions due to torque control and its dual store are above a threshold	75.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by threshold range	14.08 degrees		Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 75.00 Nm	Up/down timer 440 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Engine Capacity Minimum Running Immediate Brake Torque Excluding Cylinder Sensitivity and its redundant calculation is out of bounds given by threshold range	75.00 Nm		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			One step ahead calculation of air-per-cylinder greater than two step ahead calculation by threshold for time	Threshold: Dynamically calculated based on current engine conditions Fault Pending Threshold:  100 ms		Engine speed > 625 rpm	Up/down timer 440 ms continuous, 0.5 down time multiplier	
			Rate limited cruise axle torque request and its dual store do not match within a threshold	138.81 Nm	Ignition State	Accessory, run or crank	Up/down timer 163 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			1. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its redundant calculation is out of bounds given by threshold range  OR  2. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its dual store do not equal  OR  3. Absolute difference of Calculated accelerator pedal position and its dual store do not equal	1. 5.00 %  2. N/A  3. N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded axle torque	1,110.48	Ignition State	Accessory, run or crank	Up/down timer	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			is greater than its redundant calculation by threshold	Nm			475 ms continuous, 0.5 down time multiplier	
			Commanded axle torque is less than its redundant calculation by threshold	-65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Preload Throttle Area is greater than its redundant calculation by threshold	0.10 %		Engine speed >0rpm  AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Preload timer and its redundant calculation do not equal	N/A	Ignition State	Accessory, run or crank  AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AC friction torque is greater than commanded by AC control software	40.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Speed Lores Intake Firing (time based) calculation does not equal its redundant calculation	N/A		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the calculated spark offset for equivalence ratio and its redundant calculation is greater than a threshold	14.08 degrees		Engine speed >0rpm	Up/down timer 140 ms continuous, 0.5 down time multiplier	



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Transmission Torque Request cacluations do not equal their dual stores	N/A		Run or Crank = TRUE > 0.50 s	16 / 32 counts; 25.0msec/count	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Performance  (For use on vehicles with mechanical transfer pump dual fuel tanks)	P2066	This DTC will detect a fuel sender stuck in range in the secondary fuel tank.	<p>*****</p> <p>Fuel Level in Secondary Tank Remains in an Unreadable Range too Long</p> <p>*****</p> <p>If fuel volume in primary tank is and fuel volume in secondary tank is and remains in this condition for</p> <p>OR</p> <p>*****</p> <p>Fuel Level is in a Readable Range for both Primary and Secondary Tanks too Long</p> <p>*****</p> <p>Volume in primary tank is and volume in secondary tank is and remains in this condition for</p> <p>OR</p> <p>*****</p> <p>Distance Traveled without a Secondary Fuel Level Change</p> <p>*****</p> <p>If the vehicle is driven a distance of 220 miles without the secondary fuel level changing by 3 liters, then the sender must be</p>	<p>≥ 1,024.0 liters</p> <p>&lt; 2.0 liters</p> <p>124 miles</p> <p>&lt; 1,024 liters</p> <p>&gt; 2 liters</p> <p>2,430 seconds</p>	<p>Engine Running</p> <p>No active DTCs:</p> <p>Volume in secondary tank</p>	<p>VehicleSpeedSensor_FA</p> <p>≥ 2.0 liters</p>	250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			stuck.					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Circuit Low Voltage  (For use on vehicles with dual fuel tanks)	P2067	This DTC will detect a fuel sender stuck out of range low in the secondary fuel tank.	Fuel level Sender % of 5V range	< 10 %			100 failures out of 125 samples  100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Circuit High Voltage  (For use on vehicles with dual fuel tanks)	P2068	This DTC will detect a fuel sender stuck out of range low in the secondary fuel tank.	Fuel level Sender % of 5V range	> 60 %			100 failures out of 125 samples  100 ms / sample	Type B, 2 Trips

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Low Limit Bank 1 (Too Rich)	P2096	Determines if the post catalyst O2 sensor based fuel control system has reached it's low limit authority, indicating a rich emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too rich, the post catalyst O2 integral offset control is decreased. This results in lean bias fuel control in an attempt to correct the rich post O2 voltage.	Rich Fail counter  High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18 % for >= 5.0 seconds. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14 % for >= 5.0 seconds.	>= 480 counts per 600 sample counts  Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration  The following conditions must be true for > 40.0 seconds:  Ambient Air Pressure Engine AirFlow Intake Manifold Pressure Induction Air Temperature Start-up Coolant Temp. PTO Intrusive diag. fuel control  Long Term Secondary Fuel Trim Enabled (see "Long Term Secondary Fuel Trim Enable Criteria" in Supporting Tables)  High Vapor Conditions  No Fault Active for:	No No Yes Yes Yes  >= 70 kPa >= 0.0 g/s <= 10,000.0 >= 0 kPa <= 200 >= -20 deg. C <= 200 >= -20 deg. C Not Active Not Active           Not Present  AmbientAirDefault AIR System FA Ethanol Composition Sensor FA ECT_Sensor_FA EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorFA CamSensorAnyLocationFA EvapEmissionSystem_FA	Frequency: Continuous Monitoring in 100ms loop. Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EvapFlowDuringNonPurge_FA FuelTankPressureSnrCkt_FA EvapPurgeSolenoidCircuit_FA EvapSmallLeak_FA EvapVentSolenoidCircuit_FA FuelInjectorCircuit_FA MAF_SensorFA MAF_SensorTFTKO MAP_SensorFA MAP_EngineVacuumStatus EngineMisfireDetected_FA A/F Imbalance Bank1 O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA The above general enable conditions must be true for: > 40.0 seconds Minimum accumulated counts in each cell required before counters will increment: Deceleration 0 Idle 0 Cruise 0 Light Acceleration 0 Heavy Acceleration 0 Fail counter will increment if sample counter increments AND Post oxygen sensor control integral offset (in		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					mV) is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Heavy Acceleration	<= N/A (control min.= 0) N/A (control min.= 0) -500 (control min.= -500) -500 (control min.= -500) -500 (control min.= -500) > 840 mV 840 mV 840 mV 840 mV 840 mV		



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System High Limit Bank 1 (Too Lean)	P2097	Determines if the post catalyst O2 sensor based fuel control system has reached it's high limit authority, indicating a lean emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too lean, the post catalyst O2 integral offset control is increased. This results in rich bias fuel control in an attempt to correct the lean post O2 voltage.	Lean Fail counter  High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18 % for >= 5.0 seconds. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14 % for >= 5.0 seconds.	>= 480 counts per 600 sample counts  Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	Same as P2096 except for the following:  Fail counter will increment if sample counter increments AND Post oxygen sensor control integral offset (in mV) is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Heavy Acceleration	>= N/A (control max.= 0 ) N/A (control max.= 0 ) 700 (control max.= 700 ) 700 (control max.= 700 ) 700 (control max.= 700 )  < 670 mV 670 mV 670 mV 670 mV 670 mV	Frequency: Continuous Monitoring in 100ms loop. Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Throttle Actuator Position Performance	P2101	1) Detect a throttle positioning error2) Throttle control is driving the throttle in the incorrect direction3) Throttle control exceeds the reduced power limit	Difference between measured throttle position and modeled throttle position >	8.22 percent	TPS minimum learn is not active and Throttle is being Controlled and (Engine Running or Ignition Voltage > or Ignition Voltage > )	Run/Crank voltage > 6.41  Ignition voltage failure is false (P1682)	15 counts; 12.5 ms/count in the primary processor	Type A, 1 Trips
			OR					
			Difference between modeled throttle position and measured throttle position >	8.22 percent	Ignition voltage failure is false (P1682)	AND  ((Engine Running AND Ignition Voltage > 5.50 ) OR Ignition Voltage > 11.00 )		
			Throttle Position >	38.38 percent		Powertrain Relay voltage > 6.41  TPS minimum learn is active	11 counts; 12.5 ms/count in the primary processor	
			Throttle Position >	37.38 percent		Powertrain Relay voltage > 6.41  Reduced Power is True	11 counts; 12.5 ms/count in the primary processor	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle return to default	P2119	Throttle unable to return to default throttle position after de- energizing ETC motor.	(Normalized TPS1 Voltage > AND Normalilzed TPS2 Voltage > On the main processor)	1.7700		Throttle de-energized for Actuator, Controller, or Ignition Faults (P21104, P2100, P2101, P2102, P2103, P1682, P0068, P16F3) No TPS circuit faults PT Relay Voltage > 5.500  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	0.4969 s	Type C, 1 Trips
			OR					
			(Normalized TPS1 Voltage < AND Normalilzed TPS2 Voltage < On the main processor)	1.3900				
				1.3640				
			(Normalized TPS1 Voltage > AND Normalilzed TPS2 Voltage > On the main processor)	1.7700 1.7960		Throttle de-energized for Battery Saver Mode  Engine not running No TPS circuit faults PT Relay Voltage > 5.500  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	1.5000 s	
			OR	1.3900				
			(Normalized TPS1 Voltage < AND Normalilzed TPS2 Voltage < On the main processor)	1.3640				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Lo	P2122	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage <	0.4625		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Hi	P2123	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage >	4.7500		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Lo	P2127	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage <	0.3250		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P0697)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Hi	P2128	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage >	2.6000		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P0697)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position (TP) Sensor 1-2 Correlation	P2135	Detects a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor	Difference between TPS1 displaced and TPS2 displaced >	6.775 % offset at min. throttle position with a linear threshold to 9.705 % at max. throttle position		Run/Crank voltage > 6.41  No TPS sensor faults (P0122, P0123, P0222, P0223)  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts or 58 counts continuous; 3.125 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min TPS1 ) and (normalized min TPS2) >	5.000 % Vref		Run/Crank voltage > 6.41  No TPS sensor faults (P0122, P0123, P0222, P0223)  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts or 58 counts continuous; 3.125 ms/count in the main processor	



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1-2 Correlation	P2138	Detects a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor	Difference between APP1 displaced and APP2 displaced >	5.000 % offset at min. pedal position with a linear threshold to 10.001 % at max. pedal position		Run/Crank voltage > 6.41  No APP sensor faults (P2122, P2123,P2127, P2128)  No 5V reference errors or faultst for # 3 & # 4 5V reference circuits (P06A3, P0697)	19 / 39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min APP1 ) and (normalized min APP2) >	5.000 % Vref		Run/Crank voltage > 6.41  No APP sensor faults (P2122, P2123,P2127, P2128)  No 5V reference errors or faultst for # 3 & # 4 5V reference circuits (P06A3, P0697)	19 / 39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 high side circuit shorted to ground	P2147	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 high side circuit shorted to power	P2148	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 high side circuit shorted to ground	P2150	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 high side circuit shorted to power	P2151	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 high side circuit shorted to ground	P2153	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 high side circuit shorted to power	P2154	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 high side circuit shorted to ground	P2156	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 high side circuit shorted to power	P2157	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 5 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Minimum Throttle Position Not Learned	P2176	TP sensors were not in the minimum learn window after multiple attempts to learn the minimum.	During TPS min learn on the Main processor, TPS Voltage >  AND  Number of learn attempts >	0.6170   10 counts		Run/Crank voltage > 6.41  TPS minimum learn is active	2.0 secs	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 1 / 2 Correlation	P2199	Detects a difference between the IAT and IAT2 sensors	ABS (IAT - IAT2)	> 55.0 deg C	Powertrain Relay Voltage for a time  No Active DTCs:	>= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Bank 1 Air-Fuel Ratio Imbalance	P219A	This monitor determines if a cylinder-to-cylinder air-fuel ratio imbalance is present on bank 1.	<p>Filtered Ratio &gt;</p> <p>Note: The input to this metric is the pre catalyst oxygen sensor voltage. This voltage is used to generate a Variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to the air-fuel ratio imbalance (variance is higher with an imbalance than without). Multiple samples are collected in making a decision.</p> <p>The observed Variance is dependant on engine speed and load and so each result is normalized for speed and load by comparing it to a known "good system" result for that speed and load, and generating a Ratio metric.</p> <p>The Ratio metric is calculated by selecting a threshold calibration from a 17x17 table (Supporting Table KtFABD_U_VarThresh1) and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table (Supporting Table</p>	0.65	<p>System Voltage</p> <p>Fuel Level</p> <p>Engine Coolant Temperature</p> <p>Cumulative engine run time</p> <p>Diagnostic enabled at Idle (regardless of other operating conditions)</p> <p>Engine speed</p> <p>Engine speed delta during a short term sample period</p> <p>Mass Airflow (MAF)</p> <p>Cumulative delta MAF during a short term sample period</p> <p>Filtered MAF delta between samples Note: first order lag filter coefficient applied to MAF = 0.050</p> <p>Air Per Cylinder (APC)</p> <p>APC delta during short term sample period</p> <p>Filtered APC delta between samples</p>	<p>no lower than 11.0 Volts for more than 0.2 seconds</p> <p>&gt; 10.0 percent AND no fuel level sensor fault</p> <p>&gt; -20 degrees C</p> <p>&gt; 30.0 seconds</p> <p>No</p> <p>900 to 4,200 RPM</p> <p>&lt; 150 rpm</p> <p>7 to 200 g/s</p> <p>&lt; 2 g/s</p> <p>&lt; 0.25 g/s</p> <p>60 to 600 mg/cylinder</p> <p>&lt; 50 mg/cylinder</p> <p>&lt; 0.30 percent</p>	<p>Minimum of 1 test per trip, up to 6 tests per trip during RSR or FIR.</p> <p>The front O2 sensor voltage is sampled once per cylinder event. Therefore, the time required to complete a single test (when all enable conditions are met) decreases as engine speed increases. For example, 14.10 seconds of data is required at 1000 rpm while double this time is required at 500 rpm and half this time is required at 2000 rpm. This data is collected only when enable conditions are met, and as such significantly more operating time is required than is indicated above. Generally, a report will be</p>	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>KtFABD_U_Normalizer1). This quotient is then multiplied by a quality factor calibration from a 17 x 17 table (Supporting Table KtFABD_K_QualFactor1). This result is referred to as the Ratio. Note that the quality factor ranges between 0 and 1 and represents robustness to false diagnosis in the current operating region. Regions with low quality factors are not used.</p> <p>Finally, a EWMA filter is applied to the Ratio metric to generate the Filtered Ratio malfunction criteria metric. Generally, a normal system will result in a negative Filtered Ratio while a failing system will result in a positive Filtered Ratio.</p> <p>The range of the Filtered Ratio metric is application specific since both the emissions sensitivity and relationship between imbalance and the Variance metric are application specific.</p>		<p>Note: first order lag filter coefficient applied to APC = 0.100</p> <p>Spark Advance</p> <p>Throttle Area (percent of max)</p> <p>Intake Cam Phaser Angle</p> <p>Exhaust Cam Phaser Angle</p> <p>Quality Factor (QF)</p> <p>QF calibrations are located in a 17x17 lookup table versus engine speed and load (Supporting Table KtFABD_K_QualFactor1). Quality factor values less than "1" indicate that we don't have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data.</p> <p>Fuel Control Status Closed Loop and Long Term FT Enabled for</p> <p>AIR pump not on CASE learn not active EGR - no device control, no intrusive diagnostics</p>	<p>5 to 55 degrees</p> <p>5 to 200 percent</p> <p>0 to 25 degrees</p> <p>0 to 25 degrees</p> <p>&gt;= 0.99</p>	<p>made within 5 minutes of operation.</p> <p>For RSR or FIR, 18 tests must complete before the diagnostic can report.</p>	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>EVAP - no device control, no intrusive diagnostics</p> <p>Engine OverSpeed Protection Not Active</p> <p>Idle speed control normal PTO Not Active</p> <p>Injector base pulse width above min limit</p> <p><b>Rapid Step Response (RSR):</b> RSR will trigger if the Ratio result from the last test is AND it exceeds the last Filtered ratio by</p> <p>Once triggered, the filtered ratio is reset to:</p> <p><b>Fast Initial Response (FIR):</b> FIR will trigger when an NVM reset or code clear occurs. Once triggered, the filtered ratio is reset to:</p> <p>No Fault Active for:</p>	<p>&gt;= 0.65</p> <p>&gt;= 1.30</p> <p>0.00</p> <p>0.00</p> <p>EngineMisfireDetected_F A MAP_SensorFA MAF_SensorFA ECT_Sensor_FA TPS_ThrottleAuthorityDef aulted FuelInjectorCircuit_FA AIR System FA EvapExcessPurgePsbI_F A</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						CamSensorAnyLocationF A		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Performance (naturally aspirated)	P2227	Compares baro sensor to the calculated baro estimate (part throttle calculation or unthrottled MAP)	Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 9.0 kPa ≤ 1.24 miles	Engine Run Time  No Active DTCs:	> 30.00 seconds  AmbPresSnsrCktFA ECT_Sensor_Ckt_FA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA	320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips
			OR  Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 20.0 kPa > 1.24 miles	Time between current ignition cycle and the last time the engine was running  Engine is not rotating  No Active DTCs:	> 409.6 seconds  EngineModeNotRunTimer Error MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA	999 failures out of 5 samples  1 sample every 12.5 msec	
			Barometric Pressure OR Barometric Pressure	< 50.0 kPa > 115.0 kPa	No Pending DTCs:	MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP		



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (non-boosted applications)	P2228	Detects a continuous short to low or open in either the signal circuit or the BARO sensor.	BARO Voltage	< 40.0 % of 5 Volt Range (2.0 Volts = 128.0 kPa)	Engine Run Time	> 30.00 seconds	320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (non-boosted applications)	P2229	Detects an open sensor ground or continuous short to high in either the signal circuit or the BARO sensor.	BARO Voltage	> 90.0 % of 5 Volt Range (4.5 Volts = 127.8 kPa)	Engine Run Time	> 30.00 seconds	320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Intermittent	P2230	Detects a noisy or erratic barometric pressure input	String Length  Where: "String Length" = sum of "Diff" calculated over  And where: "Diff" = ABS(current BARO reading - BARO reading from 12.5 milliseconds previous)	> 150 kPa  80 consecutive BARO samples	No Active DTCs:	AmbPresSnsrCktFA ECT_Sensor_Ckt_FA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA	4 failures out of 5 samples	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time  Predicted Catalyst temp Fuel State  ===== All of the above met for at least 1.0 seconds, and then the Force Cat Rich intrusive stage is requested. ===== During Stuck Lean test the following must stay TRUE or the test will abort: $0.96 \leq \text{Fuel EQR} \leq 1.01$	not in control of purge not in estimate mode = enabled = not active  = not active  $\geq 180.0 \text{ sec}$  $600 \leq ^\circ\text{C} \leq 900$ = DFCE possible  =====		



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Predicted Catalyst temp Fuel State  DTC's Passed  ===== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	600 ≤ °C ≤ 900 DFCO possible  = P2270 (and P2272 if applicable) = P013E (and P014A if applicable) = P013A (and P013C if applicable)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump	P228C	Detects measured fuel rail pressure bias too low from desired fuel pressure.	Desired Pressure - Measure Pressure	>= 3.00 Mpa	Battery Voltage  Low Side Fuel Pressure  Engine Run Time  Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and	>= 11 Volts  > 0.275 MPa  >= KtFHPD_t_PumpCntrlEng RunThrsh(see supporting tables) Enabled when a code clear is not active or not exiting device control Engine is not cranking	Pressure Error - 750 failures out of 938 samples	Type A, 1 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active  Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -20.0 degC -20 <= Temp degC <= 90		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump	P228D	Detects measured fuel rail pressure bias too high from desired fuel pressure	Desired Pressure - Measure Pressure	<= -3.00 Mpa	Battery Voltage  Low Side Fuel Pressure  Engine Run Time  Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement	>= 11 Volts  > 0.275 MPa  >= KtFHPD_t_PumpCntrlEng RunThrsh(see supporting tables) Enabled when a code clear is not active or not exiting device control Engine is not cranking	Pressure Error - 750 failures out of 938 samples	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active  Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -20.0 DegC -20 <= Temp degC <= 90		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Bank 1	P2430	This DTC detects a stuck in range pressure sensor signal when the AIR pump is commanded on.	Average Pressure Error  AND Signal Variation	< 0.50 kPa  < 0.15 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not  No active DTCs:	> 60 kPa > -11.0 deg C > -11.0 deg C < 56.0 > 1,800.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec  AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRSysPressSnsrB1CktL oFA AIRSysPressSnsrB1CktHi FA ControllerProcessorPerf_ FA 5VoltReferenceA_FA 5VoltReferenceB_FA	Stuck in range cumulative time > 5.0 seconds  Frequency: Once per trip when SAI pump is commanded On	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Performance Bank 1	P2431	This DTC detects a skewed pressure sensor signal via a comparison of the AIR pressure sensor signal and estimated BARO, as well as an evaluation of the quality of the comparison.	Difference between AIR pressure sensor and BARO (Pump Commanded Off) or  OR  Difference between AIR pressure sensor and BARO (Pump Commanded On)	> 10.0 kPa  < -10.0 kPa  > 50.0 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not  Transfer Case not in 4WD Low Run/crank active  No active DTCs:	> 60 kPa > -11.0 deg C > -11.0 deg C < 56.0 > 1,800.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec           AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRSysPressSnsrB1CktLoFA AIRSysPressSnsrB1CktHiFA MAF_SensorFA EngineMisfireDetected_FA ControllerProcessorPerf_FA 5VoltReferenceA_FA 5VoltReferenceB_FA	Skewed sensor cumulative test weight > 5.0 seconds  Continuous 6.25ms loop  Skewed sensor cumulative test weight is based on distance from the last Baro update. See Baro Skewed Sensor Weight Factor table.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Low Voltage Bank 1	P2432	This DTC detects an out of range low AIR pressure sensor signal	AIR Pressure Sensor signal	< 6 % of 5Vref for 800 failures out of 1,000 samples	No active DTCs:	ControllerProcessorPerf_ FA 5VoltReferenceA_FA 5VoltReferenceB_FA	1,000 samples (6.25 ms per sample)  Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Hi Voltage Bank 1	P2433	This DTC detects an out of range high AIR pressure sensor signal	AIR Pressure Sensor signal	> 94 % of 5Vref for 800 failures out of 1,000 samples	No active DTCs:	ControllerProcessorPerf_ FA 5VoltReferenceA_FA 5VoltReferenceB_FA	1,000 samples (6.25 ms per sample)  Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Shut-off Valve Stuck Open	P2440	This DTC detects if the AIR system control valve is stuck open. This test is run during Phase 2 (Pump commanded On, valve commanded closed)	Average Pressure Error  or	< Bank 1 Valve Pressure Error table  > 32 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Stability Time  AIR diagnostic Phase 1 passed  No active DTCs:	> 60 kPa > -11.0 deg C > -11.0 deg C < 56.0 > 1,800.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec > 0.5 seconds  AIRSystemPressureSens or FA AIRValveControlCircuit FA AIRPumpControlCircuit FA MAF_SensorFAAmbientAirDefault_NA IAT_SensorFAECT_Sensor_FA EngineMisfireDetected_FA CatalystSysEfficiencyLoB1_FA CatalystSysEfficiencyLoB2_FA ControllerProcessorPerf_FA 5VoltReferenceA_FA 5VoltReferenceB_FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA	Phase 2 Conditional test weight > 1.5 sec  Frequency: Once per trip when AIR pump commanded On  Conditional test weight is calculated by multiplying the following Factors: Phase 2 Baro Test Weight Factor, Phase 2 MAF Test Weight Factor, Phase 2 System Volt Test Weight Factor, Phase 2 Ambient Temp Test Weight Factor (see Supporting Tables)	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pump Stuck On	P2444	This DTC detects if the SAI pump is stuck On. This test is run during Phase 3 (Pump commanded Off, valve commanded closed)	Average Pressure Error  or	> Bank 1 Pump Pressure Error table  < -32 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Stability Time  AIR diagnostic Phase 1 passed AIR diagnostic Phase 2 passed  No active DTCs:	> 60 kPa > -11.0 deg C > -11.0 deg C < 56.0 > 1,800.0 seconds > 10.0 Volts < 32.0 < 20 kPa for > 2.0 sec. < 5,000 RPM > 50 gm/s for > 3.0 sec. > 4.0 seconds  Phase 3 cumulative test weight is based on the distance from the last Baro update. See Baro Skewed Sensor Weight Factor table.  AIRSystemPressureSensorFA AIRValveControlCircuit FA AIRPumpControlCircuit FA MAF_SensorFA AmbientAirDefault_NA IAT_SensorFA ECT_Sensor_FA EngineMisfireDetected_FA CatalystSysEfficiencyLoB1_FA CatalystSysEfficiencyLoB2_FA ControllerProcessorPerf_FA 5VoltReferenceA_FA 5VoltReferenceB_FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA	Phase 3 Cumulative test weight > 2.0 sec.  Frequency: Once per trip when AIR pump commanded On	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Torque Request Circuit	P2544	Determines if the torque request from the TCM is valid	Protect error - Serial Communication message - (\$199 - PTEI3)  OR  Rolling count error - Serial Communication message (\$199 - PPEI3) rolling count value  OR  Range Error - Serial Communication message - (\$199 - PTEI3) TCM Requested Torque Increase  OR  Multi-transition error - Trans torque intervention type request change	Message <> two's complement of message   Message <> previous message rolling count value + one   > 250 Nm   Requested torque intervention type toggles from not increasing request to increasing request	Diagnostic enabled/ disabled   Power Mode   Engine Running Run/Crank Active   No Serial communication loss to TCM (U0101)	Enabled   = Run   = True > 0.50 Sec   No loss of communication	>= 10 Protect errors during key cycle.  Performed on every received message  >= 6 Rolling count errors out of 10 samples.  Performed on every received message  >= 6 range errors out of 10 samples.  Performed on every received message  >= 3 multi-transitions out of 5 samples. Performed every 200 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM/PCM Internal Engine Off Timer Performance  11.12.41 and beyond	P2610	<p>This DTC determines if the hardware timer does not initialize or count properly. There are two tests to ensure proper functioning of the timer: Count Up Test (CUT) and Range Test (RaTe).</p> <p>Count Up Test (CUT): Verifies that the HWIO timer is counting up with the proper increment.</p> <p>Range Test (RaTe): When the run/crank is not active both the hardware and mirror timers are started. The timers are compared when ECM shutdown is initiated or run/crank becomes active.</p>	<p>Count Up Test:  Time difference between the current read and the previous read of the timer</p> <p>Range Test:  The variation of the HWIO timer and mirror timer is</p>	<p>&gt; 1.50 seconds</p> <p>&gt; 25 %.</p>			<p>Count Up Test: 8 failures out of 40 samples  1 sec / sample</p> <p>Continuous while run/crank is not active and until controller shutdown is initiated.</p> <p>Range Test: Once per trip when controller shutdown is initiated or run/crank becomes active.</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position Signal Output Circuit Low	P2615	Electrical Integrity of the Camshaft Position Signal Output Circuit - Shorted to Ground	ECM detects that commanded and actual states of output driver do not match because the output is shorted to ground		Powertrain Relay Voltage  Engine is not cranking  Camshaft Position Output is commanded high	>= 11.00 Volts	40 failures out of 50 samples  1 sample every 100 msec	Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position Signal Output Circuit High	P2616	Electrical Integrity of the Camshaft Position Signal Output Circuit - Shorted to Power	ECM detects that commanded and actual states of output driver do not match because the output is shorted to power		Powertrain Relay Voltage  Engine is not cranking  Camshaft Position Output is commanded low	>= 11.00 Volts	40 failures out of 50 samples  1 sample every 100 msec	Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2Sensor Circuit Range / Performance Bank 1 Sensor 1	P2A00	This DTC determines if the O2 sensor voltage is not meeting the voltage criteria to enable closed loop fueling.	<p>=====</p> <p>Closed Loop O2S ready flag</p> <p>A) O2S signal must be To set Closed Loop ready flag</p> <p>=====</p> <p>Closed Loop O2S ready flag</p> <p>B) Once set to ready O2S cannot be</p> <p>for</p> <p>Then set Closed Loop ready flag</p> <p>=====</p>	<p>=====</p> <p>= False</p> <p>&lt; 1,250 mvolts</p> <p>= True</p> <p>=====</p> <p>= True</p> <p>&gt; 1,250 mvolts</p> <p>&gt; 5.0 seconds</p> <p>= False</p> <p>=====</p>	<p>No Active DTC's</p> <p>System Voltage</p> <p>Engine Speed</p> <p>Engine Airflow</p> <p>Engine Coolant</p> <p>Engine Metal Overtemp Active</p> <p>Converter Overtemp</p> <p>ActiveFuel State</p> <p>AFM Status</p> <p>Predicted Exhaust Temp (B1S1)</p> <p>Engine run time</p> <p>Fuel Enrichment</p> <p>All of the above met for</p>	<p>TPS_ThrottleAuthorityDefaulted</p> <p>MAP_SensorFA</p> <p>ECT_Sensor_FA</p> <p>FuelInjectorCircuit_FAP0131, P0151P0132, P0152</p> <p>10.0 &lt; Volts &lt; 32.0</p> <p>500 ≤ RPM ≤ 3,400</p> <p>3.2 ≤ gps ≤ 30.0</p> <p>≥ 70.0 °C</p> <p>= False</p> <p>= False</p> <p>DFCO not active</p> <p>= All Cylinders active</p> <p>≥ 0.0 °C</p> <p>&gt; 100 seconds</p> <p>= Not Active</p> <p>&gt; 5 seconds</p>	<p>200 failures out of 250 samples.</p> <p>Frequency: Continuous 100 msec loop</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communicati on Bus A Off	U0073	This DTC monitors for a BUS A off condition	Bus off failures out of these samples	≥ 5 counts ≥ 5 counts	General Enable Criteria:  U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Ignition voltage    Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line or Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds	Not Active on Current Key Cycle  Enabled  Not Active  Not Active   ≥= 11.00 or ≥= 6.41  = run   = 0 ( 1 indicates enabled)  = Active  > 11.00	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips Trip(s) Type Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					CAN hardware is bus OFF for	> 0.1125 seconds		



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With TCM	U0101	This DTC monitors for a loss of communication with the transmission control module	Message is not received from controller for  Message \$0C7  Message \$0F9  Message \$1F5	  ≥ 10.0 seconds  ≥ 10.0 seconds  ≥ 10.0 seconds	General Enable Criteria:  U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Ignition voltage    Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line or Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds  Power Mode is in	Not Active on Current Key Cycle  Enabled  Not Active  Not Active  ≥= 11.00 or ≥= 6.41  = run  = 0 ( 1 indicates enabled)  = Active  > 11.00	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips Trip(s) Type Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					accessory or run or crank and High Voltage Virtual Network Management is not active for  U0101  TCM	> 0.4000 seconds  Not Active on Current Key Cycle  is present on the bus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Fuel Pump Control Module	U0109	This DTC monitors for a loss of communication with the fuel pump control module	Message is not received from controller for	≥ 10.0 seconds	General Enable Criteria:  U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Ignition voltage  Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line or Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds  Power Mode is in	Not Active on Current Key Cycle  Enabled  Not Active  Not Active  >= 11.00 or >= 6.41  = run  = 0 ( 1 indicates enabled)  = Active  > 11.00	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips Trip(s) Type Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					accessory or run or crank and High Voltage Virtual Network Management is not active for  U0109  Fuel Pump Control Module	> 0.4000 seconds  Not Active on Current Key Cycle  is present on the bus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Heater Coolant Pump Control Circuit Open	B2920	This DTC checks the Heater Coolant Pump Driver Output circuit for electrical integrity	Voltage low during driver open state (indicates short-to-ground or open circuit). Fault present state for Open circuit is determined from output driver status byte.		Run Crank Ignition in Range  Engine not cranking  Run Crank active  == Above is true and ==  Last Open Circuit Test	= True  = True  = True  =====	5 failures out of 10 samples  1 sec/ sample  Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Heater Coolant Pump Control Circuit Low	B2922	This DTC checks the Heater Coolant Pump Driver Output circuit for electrical integrity	Voltage low during driver open state (indicates short-to-ground or open circuit). Fault present state for Ground Short circuit is determined from output driver status byte.		Run Crank Ignition in Range  Engine not cranking  Run Crank active  == Above is true and ==  Last Ground Short Circuit Test	= True  = True  = True  =====	5 failures out of 10 samples  1 sec/ sample  Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Heater Coolant Pump Control Circuit High	B2923	This DTC checks the Heater Coolant Pump Driver Output circuit for electrical integrity	Voltage high during driver closed state (indicates short-to-power). Fault present state for Power Short circuit is determined from output driver status byte.		Run Crank Ignition in Range  Engine not cranking  Run Crank active  == Above is true and ==  Last Power Short Circuit Test	= True  = True  = True  =====	5 failures out of 10 samples  1 sec/ sample  Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 1	P0420 - Applies to applications that use the Decel Catalyst Monitor Algorithm	Oxygen StorageThe catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (i.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (i.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Rich (intrusive rich) and Lean (decel fuel cutoff) A/F excursions  Normalized Ratio OSC Value Calculation Information and Definitions = 1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time) 2. BestFailing OSC value from a calibration table (based on temp and exhaust gas flow) 3. WorstPassing OSC value (based on temp and exhaust gas flow)	Normalized Ratio OSC Value (EWMA filtered)	< 0.35	All enable criteria associated with P0420 can be found under P2270 - (O2 Sensor Signal Stuck Lean Bank 1 Sensor 2)  Rapid Step Response (RSR) feature will initiate multiple tests:  If the difference between current EWMA value and the current OSC Normalized Ratio value is  and the current OSC Normalized Ratio value is  Maximum number of RSR tests to detect failure when RSR is enabled.  General Enable Criteria  In addition to the p-codes listed under P2270, the following DTC's shall also not be set:	> 0.56  < 0.33  15  O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_2_FA	1 test attempted per valid decel period  Minimum of 1 test per trip  Maximum of 3 tests per trip  Frequency: Fueling Related : 12.5 ms  OSC Measurements: 100 ms  Temp Prediction: 1000ms	Type A, 1 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>Normalized Ratio Calculation = (1-2) / (3-2)</p> <p>A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part.</p> <p>The Catalyst Monitoring Test is completed during a decel fuel cutoff event. This fuel cutoff event occurs following a rich intrusive fueling event initiated by the O2 Sensor Signal Stuck Lean Bank 1 Sensor 2 test (P2270). Several conditions must be met in order to execute this test.</p> <p>These conditions and their related values are listed in the "Secondary Parameters" and "Enable Conditions" section of this document for P2270 (O2 Sensor Signal Stuck Lean Bank 1 Sensor 2)</p>						

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Powertrain Control Module (HPC) Requested MIL Illumination	P0AC4	Monitors the HPC MIL request line to determine when the HPC has detected a MIL illuminating fault.	HPC Emissions-Related DTC set			Time since power-up > 3 seconds	Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Control Torque Request Circuit	P15F2	Determines if torque request from the HCP is valid	<p>1. Serial Communication 2's complement not equal for message \$181 for Strong Hybrid or Mild Hybrid Applications</p> <p>OR</p> <p>2. Serial Communication rolling count value shall be + 1 from previous \$181 message for Strong Hybrid or Mild Hybrid Applications</p>	<p>Message &lt;&gt; 2's complement of Engine Torque Signal</p> <p>and if Mild Hybrid:</p> <p>Message &lt;&gt; 2's complement of Motor Torque Signal</p> <p>OR</p> <p>Message rolling count value &lt;&gt; previous message rolling count value plus one</p>	<p>Secondary High Speed Bus is Present and No Serial communication loss to HCP (U1817)</p> <p>Run Crank Active</p> <p>Low Voltage not Present</p> <p>No Serial communication loss to HCP (U1817)</p> <p>Hybrid Type = Mild or Strong</p> <p>If Mild Hybrid Only: Torque source type = Crankshaft Torque</p>	<p>No loss of communication</p> <p>&gt;= 0.20 Sec</p> <p>&gt; 6.41</p> <p>= Mild</p> <p>= Crankshaft Torque</p>	<p>1. &gt;= 5 Protect errors out of 15 samples</p> <p>OR</p> <p>2. &gt;= 5 Rolling count errors out of 15 samples</p> <p>Pass diagnostic if samples &gt;= 15</p> <p>Performed every received message</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Hybrid Control Speed Request Circuit	P15F9	Determines if torque request from the HCP is valid	1. Serial Communication 2's complement not equal for message \$281  OR  2. Serial Communication rolling count value shall be + 1 from previous \$281 message	Message <> 2's complement of message   Message rolling count value <> previous message rolling count value plus one	Secondary High Speed Bus is Present  No Serial communication loss to HCP (U1817)		>= 10.00 Password Protect errors out of 16.00 samples  OR  >= 10.00 Rolling count errors out of 16.00 samples  Pass diagnostic if samples >= 16.00  Performed every 12.5 msec	Type B, 2 Trips
					Run Crank Active	>= 0.50 Sec		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Signal Message Counter Incorrect	P15FB	Detects rolling count or protection value errors in Chassis Brake Pedal Position Emissions Related serial data signal	If x of y rolling count / protection value faults occur, default brake pedal position to zero for duration of fault		Chassis Brake Pedal Position Emissions Related Serial Data Error Diagnostic Enable	1.00	10.00 / 16.00 counts	Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communicati on Bus B Off	U0074	This DTC monitors for a BUS B off condition	Bus off failures out of these samples	≥ 4 counts ≥ 5 counts	General Enable Criteria:  U0074  Normal CAN transmission on Bus B  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Ignition voltage    Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl    Ignition Accessory Line or Battery Voltage   General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds	Not Active on Current Key Cycle  Enabled  Not Active  Not Active    ≥= 11.00 or ≥= 6.41  = run    = 0 ( 1 indicates enabled)   = Active  > 11.00	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips Trip(s) Type Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					CAN hardware is bus OFF for	> 0.1125 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Hybrid Powertrain Control Module	U0293	This DTC monitors for a loss of communication with the Hybrid Powertrain Control Module.	Message is not received from controller for	≥ 0.5 seconds	General Enable Criteria:  U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Ignition voltage  Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line or Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for >  3.0000	Not Active on Current Key Cycle  Enabled  Not Active  Not Active  >= 11.00 or >= 6.41  = run  = 0 ( 1 indicates enabled)  = Active  > 11.00	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips Trip(s) Type Type A, 1 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					seconds  Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for  U0293  Hybrid Powertrain Control Module	> 0.4000 seconds  Not Active on Current Key Cycle  is present on the bus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on with Hybrid Powertrain Control Module on Bus B	U1817	This DTC monitors for a loss of communication with the Hybrid Powertrain Control Module on Bus B	Message is not received from controller for	≥ 0.5 seconds	General Enable Criteria:  U0074  Normal CAN transmission on Bus B  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Ignition voltage  Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line or Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000	Not Active on Current Key Cycle  Enabled  Not Active  Not Active  >= 11.00 or >= 6.41  = run  = 0 ( 1 indicates enabled) = Active  > 11.00	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips Trip(s) Type Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					seconds  Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for  U1817  Hybrid Powertrain Control Module	> 0.4000 seconds  Not Active on Current Key Cycle  is present on the bus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve Control Circuit	P0033	Detect Turbocharger Bypass Valve - Open Circuit	ECM detects that commanded and actual states of output driver do not match because the output is open circuit		Diagnostic Enabled  EnabledPowertrain relay Voltage  Ignition run crank voltage  Engine is not cranking	1  >= 11.00 Volts  >= 6.00 Volts	20 failures out of 100 samples  1 sample every 100ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve Control Circuit Low	P0034	Detect Turbocharger Bypass Valve - Shorted to Ground	ECM detects that commanded and actual states of output driver do not match because the output is shorted to ground		Diagnostic Enabled  EnabledPowertrain relay Voltage  Ignition run crank voltage  Engine is not cranking	1  >= 11.00 Volts  >= 6.00 Volts	20 failures out of 100 samples  1 sample every 100ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve Control Circuit High	P0035	Detect Turbocharger Bypass Valve - Shorted to Power	ECM detects that commanded and actual states of output driver do not match because the output is shorted to power		Diagnostic Enabled  EnabledPowertrain relay Voltage  Ignition run crank voltage  Engine is not cranking	1  >= 11.00 Volts  >= 6.00 Volts	20 failures out of 100 samples  1 sample every 100ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Pressure Measurement System - Multiple Sensor Correlation (turbocharged)	P00C7	Detects an inconsistency between pressure sensors in the induction system in which a particular sensor cannot be identified as the failed sensor	ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure) OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure) OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure) OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure)	> 10.0 kPa  <= 10.0 kPa  <= 10.0 kPa  <= 10.0 kPa  > 10.0 kPa  <= 10.0 kPa  <= 10.0 kPa  > 10.0 kPa  > 10.0 kPa	Time between current ignition cycle and the last time the engine was running  Engine is not rotating  Manifold Pressure Manifold Pressure Baro Pressure Baro Pressure Turbocharger Boost Pressure Turbocharger Boost Pressure  No Active DTCs:  No Pending DTCs:	> 10.0 seconds  >= 50.0 kPa <= 115.0 kPa >= 50.0 kPa <= 115.0 kPa  >= 50.0 kPa <= 115.0 kPa  EngineModeNotRunTimer Error MAP_SensorFA AAP_SnsrFA AAP2_SnsrFA  MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP	4 failures out of 5 samples  1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	> 10.0 kPa  > 10.0 kPa				



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (turbocharge d)	P0101	Determines if the MAF sensor is stuck within the normal operating range	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC.  MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered  MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered  MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered  MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered  TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered  TPS model fails when Filtered Throttle Model Error  TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed	> 20 grams/sec  > 24.0 kPa  > 30.0 kPa  > 30.0 kPa  > 30.0 kPa  > 200 kPa*(g/s)  > 24.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 125 Deg C  >= 0.00  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est  MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM  TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM	Continuous  Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>See table "TIAP-MAP Correlation Offset"</p> <p>OR</p> <p>Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset"</p> <p>TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time</p> <p>High Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND Manifold Pressure</p> <p>AND</p>	<p>&gt; 24.0 kPa</p> <p>&gt; 1.0 seconds</p> <p>&gt; 1.0 seconds</p> <p>&gt; a threshold in gm/sec as a function of engine speed See table "TIAP-MAP Correlation Min Air Flow"</p> <p>&gt; a threshold in kPa as a function of engine speed See table "TIAP-MAP Correlation Min MAP"</p>	<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>See "Residual Weight Factor" tables.</p> <p>MAP_SensorCircuitFA EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Filtered Mass Air Flow - Mass Air Flow  Low Engine Air Flow is TRUE when Mass Air Flow  AND Manifold Pressure  AND Mass Air Flow - Filtered Mass Air Flow	< 3.0 gm/sec  < a threshold in gm/sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow"  < a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP"  < 2.0 gm/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (turbocharge d)	P0106	Determines if the MAP sensor is stuck within the normal operating range	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC.  MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered  MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered  MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered  MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered  TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered  TPS model fails when Filtered Throttle Model Error  TIAP Correlation model fails when  High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table "TIAP-MAP	> 20 grams/sec  > 24.0 kPa  > 30.0 kPa  > 30.0 kPa  > 30.0 kPa  > 200 kPa*(g/s)  > 24.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 125 Deg C  >= 0.00  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est  MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM  TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM	Continuous  Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Correlation Offset"</p> <p>OR</p> <p>Low Engine Air Flow is TRUE</p> <p>AND</p> <p>Measured TIAP - measured Baro - offset as a function of engine speed</p> <p>See table "TIAP-Baro Correlation Offset"</p> <p>TIAP Correlation is valid when</p> <p>High Engine Air Flow has been TRUE for a period of time</p> <p>OR</p> <p>Low Engine Air Flow has been TRUE for a period of time</p> <p>High Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND</p> <p>Manifold Pressure</p> <p>AND</p> <p>Filtered Mass Air Flow - Mass Air Flow</p>	<p>&gt; 24.0 kPa</p> <p>&gt; 1.0 seconds</p> <p>&gt; 1.0 seconds</p> <p>&gt; a threshold in gm/sec as a function of engine speed</p> <p>See table "TIAP-MAP Correlation Min Air Flow"</p> <p>&gt; a threshold in kPa as a function of engine speed</p> <p>See table "TIAP-MAP Correlation Min MAP"</p> <p>&lt; 3.0 gm/sec</p>	<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>See "Residual Weight Factor" tables.</p> <p>MAP_SensorCircuitFA</p> <p>EGRValvePerformance_F A</p> <p>MAF_SensorCircuitFA</p> <p>CrankSensor_FA</p> <p>ECT_Sensor_FA</p> <p>IAT_SensorFA</p> <p>MnfdTempSensorFA</p> <p>TC_BoostPresSnsrCktFA</p> <p>AmbientAirDefault</p> <p>EGRValve_FP</p> <p>ECT_Sensor_Ckt_FP</p> <p>IAT_SensorCircuitFP</p> <p>MnfdTempSensorCktFP</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Low Engine Air Flow is TRUE when Mass Air Flow	< a threshold in gm/sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow"				
			AND Manifold Pressure	< a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP"				
			AND Mass Air Flow - Filtered Mass Air Flow	< 2.0 gm/sec				
			Manifold Pressure OR Manifold Pressure  OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	< 50.0 kPa > 115.0 kPa  > 10.0 kPa > 10.0 kPa <= 10.0 kPa	Time between current ignition cycle and the last time the engine was running  Engine is not rotating  No Active DTCs:   No Pending DTCs:	> 10.0 seconds  EngineModeNotRunTimer Error MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA  MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP	4 failures out of 5 samples  1 sample every 12.5 msec	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (turbocharge d)	P0121	Determines if the Throttle Position Sensor input is stuck within the normal operating range	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC.  MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered  MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered  MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered  MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered  TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered  TPS model fails when Filtered Throttle Model Error  TIAP Correlation model fails when  High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table "TIAP-MAP	> 20 grams/sec  > 24.0 kPa  > 30.0 kPa  > 30.0 kPa  > 30.0 kPa  > 200 kPa*(g/s)  > 24.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 125 Deg C  >= 0.00  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est  MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM  TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM	Continuous  Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Correlation Offset"</p> <p>OR</p> <p>Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset"</p> <p>TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time</p> <p>High Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND Manifold Pressure</p> <p>AND Filtered Mass Air Flow - Mass Air Flow</p>	<p>&gt; 24.0 kPa</p> <p>&gt; 1.0 seconds</p> <p>&gt; 1.0 seconds</p> <p>&gt; a threshold in gm sec as a function of engine speed See table "TIAP-MAP Correlation Min Air Flow"</p> <p>&gt; a threshold in kPa as a function of engine speed See table "TIAP-MAP Correlation Min MAP"</p> <p>&lt; 3.0 gm/sec</p>	<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>See "Residual Weight Factor" tables.</p> <p>MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP</p>		



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Low Engine Air Flow is TRUE when Mass Air Flow  AND Manifold Pressure  AND Mass Air Flow - Filtered Mass Air Flow	< a threshold in gm sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow"  < a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP"  < 2.0 gm/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Engine Overboost Turbocharge r with wastegate. Not supercharge r with mechanical compressor	P0234	Detect Negative Boost Pressure Control Deviation	Desired Boost Pressure - Actual Boost Pressure	< (KtBSTD_p_CntrlDevN egLim - KtBSTD_p_CntrlDevA mbAirCorr)  See Tables in Supporting Tables Sheet	Diagnostic Enabled  Engine Speed  Engine Speed  Desired Boost Pressure  Desired Boost Pressure  Desired Boost Pressure Derivative  Desired Boost Pressure Derivative  Ambient Pressure  Ambient Pressure  Coolant Temp  Coolant Temp  Intake Air Temp  Intake Air Temp  Wait for steady state:  No Active DTCs:	1  > 1,600 rpm  < 6,000 rpm  > 140.0 kPa  < 300.0 kPa  > -75.0 kPa/s  < 75.0 kPa/s  > 60.0 kPa  < 120.0 kPa  > -40.0 Deg C  < 120.0 Deg C  > -40.0 Deg C  < 80.0 Deg C  > KtBSTD_t_CntrlDevEnbID elay See Table in Supporting Tables Sheet  Desired Boost Pressure > BasicPressure  AmbientAirDefault_Snsr BSTR_b_PCA_CktFA BSTR_b_TurboBypassCkt FA ECT_Sensor_FAIAAT_Sen	15 failures out of 15 samples  1 sample every 100ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Active DVCs:	sorFA BSTR_b_ExcsvBstTFTK O BSTR_b_PCA_CktTFTK O TC_BoostPresSnsrFA AnyCamPhaser_FA BSTR_b_PresCntrlTooLo TFTKO BSTR_b_PresCntrlTooHiT FTKO EnginePowerLimited  BSTR_b_DVC_PCA_DC_ Actv BSTR_b_DVC_PCA_Pstn Actv BSTR_b_DVC_TurboCom prBypActv		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Boost Pressure (TIAP) Sensor Performance	P0236	Determines if the Turbocharger Boost (TIAP) Pressure Sensor input is stuck within the normal operating range	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC.  MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered  MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered  MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered  MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered  TIAP1 model fails when ABS(Measured TIAP - TIAP Model 1) Filtered  TPS model fails when Filtered Throttle Model Error  TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table "TIAP-MAP Correlation Offset"	> 20 grams/sec  > 24.0 kPa > 30.0 kPa  > 30.0 kPa  > 30.0 kPa  > 200 kPa*(g/s)       > 24.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 125 Deg C  >= 0.00  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est  MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM  TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM	Continuous  Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>OR</p> <p>Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset"</p> <p>TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time</p> <p>High Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND Manifold Pressure</p> <p>AND Filtered Mass Air Flow - Mass Air Flow</p>	<p>&gt; 24.0 kPa</p> <p>&gt; 1.0 seconds</p> <p>&gt; 1.0 seconds</p> <p>&gt; a threshold in gm/sec as a function of engine speed See table "TIAP-MAP Correlation Min Air Flow"</p> <p>&gt; a threshold in kPa as a function of engine speed See table "TIAP-MAP Correlation Min MAP"</p> <p>&lt; 3.0 gm/sec</p>	<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>See "Residual Weight Factor" tables.</p> <p>MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Low Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND Manifold Pressure</p> <p>AND Mass Air Flow - Filtered Mass Air Flow</p>	<p>&lt; a threshold in gm/sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow"</p> <p>&lt; a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP"</p> <p>&lt; 2.0 gm/sec</p>				
			<p>Turbocharger Boost Pressure OR Turbocharger Bosst Pressure OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)</p>	<p>&lt; 50.0 kPa  &gt; 115.0 kPa  &lt;= 10.0 kPa  &gt; 10.0 kPa  &gt; 10.0 kPa</p>	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Engine is not rotating</p> <p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>&gt; 10.0 seconds</p> <p>EngineModeNotRunTimer Error MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA</p> <p>MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP</p>	<p>4 failures out of 5 samples</p> <p>1 sample every 12.5 msec</p>	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r Boost Pressure Sensor Circuit Low	P0237	Detects a continuous short to low or open in either the signal circuit or the turbocharger boost pressure sensor.	Turbocharger Boost Pressure Voltage	< 18.0 % of 5 Volt Range (This is equal to 0.90 Volts, or 419.1 kPa)	Engine Run Time	> 0.00 seconds	320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r Boost Pressure Sensor Circuit High	P0238	Detects an open sensor ground or continuous short to high in either the signal circuit or the turbocharger boost pressure sensor.	Turbocharger Boost Pressure Voltage	> 78.0 % of 5 Volt Range (This is equal to 3.90 Volts, or 399.6 kPa)	Engine Run Time	> 0.00 seconds	320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Wastegate / Supercharger Boost Solenoid A Control Circuit	P0243	Detect Turbocharger Boost Solenoid -Open Circuit	ECM detects that commanded and actual states of output driver do not match because the output is open circuit		Diagnostic Enabled  Powertrain relay voltage  Ignition run crank voltage  Engine is not cranking	1  >= 11.00 Volts  >= 6.00 Volts	10 failures out of 20 samples  1 sample every 100ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Wastegate / Supercharger Boost Solenoid A Control Circuit Low	P0245	Detect Turbocharger Boost Solenoid - Shorted to ground	ECM detects that commanded and actual states of output driver do not match because the output is shorted to ground		Diagnostic Enabled  Powertrain relay voltage  Ignition run crank voltage  Engine is not cranking	1  >= 11.00 Volts  >= 6.00 Volts	10 failures out of 20 samples  1 sample every 100ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r Wastegate / Supercharge r Boost Solenoid A Control Circuit High	P0246	Detect Turbocharger Boost Solenoid - Shorted to Power	ECM detects that commanded and actual states of output driver do not match because the output is shorted to power		Diagnostic Enabled  Powertrain relay voltage  Ignition run crank voltage  Engine is not cranking	1  >= 11.00 Volts  >= 6.00 Volts	10 failures out of 20 samples  1 sample every 100ms	Type B, 2 Trips

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Engine Underboost Turbocharger with wastegate. Not supercharger with mechanical compressor	P0299	Detect Positive Boost Pressure Control Deviation	Desired Boost Pressure - Actual Boost Pressure	> (KtBSTD_p_CntrlDevPosLim + KtBSTD_p_CntrlDevAmbAirCorr)  See Tables in Supporting Tables Sheet	Diagnostic Enabled Engine Speed Engine Speed Desired Boost Pressure Desired Boost Pressure Desired Boost Pressure Derivative Desired Boost Pressure Derivative Ambient Pressure Ambient Pressure Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Wait for steady state:  No Active DTCs:	1  > 1,600 rpm < 6,000 rpm > 140.0 kPa < 300.0 kPa > -75.0 kPa/s < 75.0 kPa/s > 60.0 kPa < 120.0 kPa > -40.0 Deg C < 120.0 Deg C > -40.0 Deg C < 80.0 Deg C  > KtBSTD_t_CntrlDevEnable See Table in Supporting Tables Sheet  Desired Boost Pressure > Basic Pressure  AmbientAirDefault_Snr BSTR_b_PCA_CktFA BSTR_b_TurboBypassCktFA ECT_Sensor_FA	15 failures out of 15 samples  1 sample every 100ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Active DVCs:	IAT_SensorFA BSTR_b_ExcsvBstTFTK O BSTR_b_PCA_CktTFTK O TC_BoostPresSnsrFA AnyCamPhaser_FA BSTR_b_PresCntrlTooLo TFTKO BSTR_b_PresCntrlTooHiT FTKO EnginePowerLimited  BSTR_b_DVC_PCA_DC_ Actv BSTR_b_DVC_PCA_Pstn Actv BSTR_b_DVC_TurboCom prBypActv		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (turbocharge d)	P1101	Determines if there are multiple air induction problems affecting airflow and/or manifold pressure.	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC.  MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered  MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered  MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered  MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered  TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered  TPS model fails when Filtered Throttle Model Error  TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table "TIAP-MAP	> 20 grams/sec  > 24.0 kPa  > 30.0 kPa  > 30.0 kPa  > 30.0 kPa  > 200 kPa*(g/s)  > 24.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 125 Deg C  >= 0.00  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est  MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM  TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM	Continuous  Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Correlation Offset"</p> <p>OR</p> <p>Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset"</p> <p>TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time</p> <p>High Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND Manifold Pressure</p> <p>AND Filtered Mass Air Flow - Mass Air Flow</p>	<p>&gt; 24.0 kPa</p> <p>&gt; 1.0 seconds</p> <p>&gt; 1.0 seconds</p> <p>&gt; a threshold in gm sec as a function of engine speed See table "TIAP-MAP Correlation Min Air Flow"</p> <p>&gt; a threshold in kPa as a function of engine speed See table "TIAP-MAP Correlation Min MAP"</p> <p>&lt; 3.0 gm/sec</p>	<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>See "Residual Weight Factor" tables.</p> <p>MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Low Engine Air Flow is TRUE when Mass Air Flow	< a threshold in gm sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow"				
			AND Manifold Pressure	< a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP"				
			AND Mass Air Flow - Filtered Mass Air Flow	< 2.0 gm/sec				



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Intake Air Temperature Sensor 3 Circuit Performance (applications with humidity sensor and manifold temperature sensor)	P112B	Detects an IAT3 sensor that has stuck in range by comparing to IAT and IAT2 at startup	ABS(Power Up IAT - Power Up IAT2)	<= 30 deg C	Time between current ignition cycle and the last time the engine was running	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips	
			AND						
			ABS(Power Up IAT - Power Up IAT3)	> 25 deg C	Powertrain Relay Voltage for a time				
			AND ABS(Power Up IAT2 - Power Up IAT3)	> 25 deg C	No Active DTCs:				
			Power Up IAT is between Power Up IAT2 and Power Up IAT3		Time between current ignition cycle and the last time the engine was running	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met		
			AND						
			ABS(Power Up IAT2 - Power Up IAT3)	> 25 Deg C	Powertrain Relay Voltage for a time				
			AND		No Active DTCs:				
			ABS(Power Up IAT - Power Up IAT3) > ABS(Power Up IAT - Power Up IAT2)						
			Power Up IAT2 is between Power Up IAT and Power Up IAT3		Time between current ignition cycle and the last time the engine was running	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met		
			AND						
			ABS(Power Up IAT - Power Up IAT3)	> 25 deg C	Powertrain Relay Voltage for a time				
			AND		No Active DTCs:				
			ABS(Power Up IAT2 - Power Up IAT3) > ABS(Power Up IAT2 -						

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Power Up IAT)					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 3 Low (applications with manifold temperature and humidity)	P112C	Detects a continuous short to ground in the IAT 3 signal circuit or the IAT 3 sensor	Raw IAT 3 Input	< 57 Ohms (~150 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 3 High (applications with manifold temperature and humidity)	P112D	Detects a continuous open circuit in the IAT 3 signal circuit or the IAT 3 sensor	Raw IAT 3 Input	> 162,529 Ohms (~-60 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 3 Intermittent In-Range	P112E	Detects a noisy or erratic IAT 3 signal circuit or IAT 3 sensor	String Length  Where: "String Length" = sum of "Diff" calculated over  And where: "Diff" = ABS(current IAT 3 reading - IAT 3 reading from 100 milliseconds previous)	> 250.00 DegC  10 consecutive IAT 3 samples	Continuous		4 failures out of 5 samples  Each sample takes 1.0 seconds	Type B, 2 Trips

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Performance (turbocharged)	P2227	Compares baro sensor to the calculated baro estimate (part throttle calculation or unthrottled MAP)	Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 15.0 kPa <= 0.06 miles	Engine Run Time  No Active DTCs:	> 0.00 seconds  AmbPresSnsrCktFA ECT_Sensor_Ckt_FA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA	320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips
			OR  Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 20.0 kPa > 0.06 miles	Time between current ignition cycle and the last time the engine was running  Engine is not rotating	> 10.0 seconds	4 failures out of 5 samples  1 sample every 12.5 msec	
			Barometric Pressure OR Barometric Pressure	< 50.0 kPa > 115.0 kPa	No Active DTCs:	EngineModeNotRunTimer Error MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA		
			OR  ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	> 10.0 kPa  <= 10.0 kPa  > 10.0 kPa	No Pending DTCs:	MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (boosted applications)	P2228	Detects a continuous short to low or open in either the signal circuit or the BARO sensor.	BARO Voltage	< 34.5 % of 5 Volt Range ( 1.7 Volts = 128.0 kPa)	Engine Run Time	> 0.00 seconds	320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (boosted applications)	P2229	Detects an open sensor ground or continuous short to high in either the signal circuit or the BARO sensor.	BARO Voltage	> 90.0 % of 5 Volt Range (4.5 Volts = 127.8 kPa)	Engine Run Time	> 0.00 seconds	320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve - Mechanical Turbocharge r with wastegate. Not supercharge r with mechanical compressor	P2261	Detect Stuck Closed Bypass Valve	Accumulation time is high pass filtered. Accumulated air mass flow or boost pressure larger then thresholds	0.25 Second < Accumulation time < 1.00 Second	Diagnostic Enabled  Engine Speed  Pressure ratio over the compressor	1  >= 1,500 rpm  >KtBSTD_r_ExcsvBstPre sLim Enable condition kept true for 0.8 seconds extra See Tables in Supporting Tables Sheet	7 Failed tests out of 10 Tests  1 sample every 25ms	Type B, 2 Trips
			Filter Frequency	10.00 Hz				
			Filtered Air Mass Flow	> 40.000 g/s	Relative Boost Pressure (Boost - Ambient) and Negative Transient in Manifold Air Pressure	IF ( RelativeBoost < 0.0 kPa OR DerivativeMAP > 10.00 kPa/s ) [ FALSE ] Else ( RelativeBoost >= 25.0 kPa AND DerivativeMAP <= -150.00 kPa ) [ TRUE ]		
			Filtered Boost Pressure	> 40.00 kPa		> 6.0 percentEnable condition kept true for 0.50 seconds extra		
					Bypass Valve Commanded Open	TC_BoostPresSnsrFA MAF_SensorFABSTR_b_ TurboBypassCktFA		
					No Active DTCs:			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Output Speed Sensor (TOSS)	P0502	No activity in the TOSS circuit	TOSS Raw Speed	≤ 60 RPM	Engine TorqueMinimum Throttle openingEngine SpeedIgnition voltagePTO EngineTorqueInaccurate P0503	54.0 ≤ N-M ≤ 8,191.8 ≥ 8.0 % 1,500 ≤ RPM ≤ 6,500 11.0 ≤ Volts ≤ 32.00 not activeKeETQC_b_MinTra nsRemedial = TRUE: MSFR_b_EngMisfDtctd_F A, MAFR_b_MAF_SnsrTFT KO, MAPR_b_MAP_SnsrTFT KO  KeETQC_b_MinTransRe medial = FALSE: FULR_b_FuellnjCkt_TFT KO, MAFR_b_MAF_SnsrTFT KO, XOYR_b_SecurityFit, Not failed this key cycle	≥ 4.5 sec	Type Type B, 2 Trips  Type B, 2 Trips trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Output Speed Sensor (TOSS)	P0503	TOSS Signal Intermittent	Loop-to-Loop change in TOSS	≥ 350 RPM	Raw Output Speed Output Speed change Time since transfer case range change Ignition voltage Engine Speed Vehicle Speed PTO	> 300 RPM for ≥ 2.0 sec ≤ 150 RPM for ≥ 2.0 sec ≥ 6.0 sec 11.0 ≤ Volts ≤ 32.00 200 ≤ RPM ≤ 7,500 for ≥ 5.0 seconds 200.00 MPH for ≥ 5.0 sec not active	≥ 3.3 sec	Type Type B, 2 Trips  Type B, 2 Trips trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Range / Performance	P0806	Detects if Clutch Pedal Position Sensor is Stuck in a range indicative of a vehicle NOT in gear, when the vehicle is determined to be in gear. Gear determination is made by verifying that the ratio of engine RPM versus Transmission Output Speed (N/TOS) represents a valid gear.	Filtered Clutch Pedal Position Error when the vehicle is determined to be in gear	> 4 %	N/TOS Ratio:  Transfer Case:  Vehicle speed:  Engine Torque:  Clutch Pedal Position:  OR  No Active DTCs:	Must match actual gear (i.e. vehicle in gear)  Not in 4WD Low range  > 6.2 MPH  > EngTorqueThreshold Table  < ResidualErrEnableLow Table > ResidualErrEnableHigh Table  ClutchPstnSnsrCktHi FA ClutchPstnSnsrCktLo FA CrankSensor_FA Transmission Output Shaft Angular Velocity Validity VehicleSpeedSensor_FA	25 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Low	P0807	Detects Continuous Circuit Out-of-Range Low or Open	Clutch Position Sensor Circuit  for	< 4 % of Vref  200 counts out of 250 samples	Engine Not Cranking System Voltage  No active DTCs:	> 11.0 Volts  5VoltReferenceB_FA	25 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit High	P0808	Detects Continuous Circuit Out-of-Range High	Clutch Position Sensor Circuit  for	> 96 % of Vref  200 counts out of 250 samples	Engine Not Cranking System Voltage  No active DTCs:	> 11.0 Volts  5VoltReferenceB_FA	25 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position not learned	P0 0	Detects Invalid Clutch Pedal fully applied learn Position values	fully applied learn Position	6.0  > 3 .0	BD Manufacturer's Enable Counter	= 0	250 ms loop Continuous	Type , 1 Trips

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Insufficient Switching Bank 1 Sensor 1	P1133	This DTC determines if the O2 sensor is no longer sufficiently switching.	Fault condition present if Half Cycle L/R or R/L Switches are below the threshold.  OR Slope Time L/R Switches  OR Slope Time R/L Switches	H/C L/R switches < Threshold, or H/C R/L switches < Threshold, (refer to table named "P1133 - O2S HC L to R Switches Limit Bank 1 Sensor 1" Pass/Fail Threshold table & "P1133 - O2S HC R to L Switches Limit Bank 1 Sensor 1" Pass/Fail Threshold table in Supporting tables tab)  < 5  < 5	No Active DTC's      Bank 1 Sensor 1 DTC's not active  System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition  O2 Heater on for Learned Htr resistance	TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefaultMAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA EthanolCompositionSensor_FA EngineMisfireDetected_FA  = P0131, P0132 or P0134  10.0 < Volts < 32.0 = Not active = Not active = Not active = Not active = False = Not Valid, See definition of Green Sensor Delay Criteria (B1S1) in Supporting Tables tab.  ≥ 40 seconds = Valid ( the heater resistance has learned since NVM reset, see	Sample time is 60 seconds  Frequency: Once per trip	Type B, 2 Trips



Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Engine Coolant IAT Engine run Accum  Time since any AFM status change Time since Purge On to Off change Time since Purge Off to On change  Engine airflow Engine speed Fuel Baro Air Per Cylinder  Fuel Control State Closed Loop Active LTM fuel cell Transient Fuel Mass Baro Fuel Control State Fuel State Commanded Proportional Gain  ===== All of the above met for Time	enable conditions for "HO2S Heater Resistance DTC's" ) > 70 °C > -40 °C > 120 seconds  > 2.0 seconds > 0.0 seconds > 1.5 seconds  14 ≤ gps ≤ 40 1,000 ≤ RPM ≤ 3,500 < 87 % Ethanol > 70 kpa ≥ 200 mgrams  = Closed Loop = TRUE = Enabled ≤ 100.0 mgrams = Not Defaulted not = Power Enrichment DFCO not active  ≥ 0.0 %  ===== > 3.0 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Composition Sensor Circuit Low	P0178	Detects Out of Range Low Frequency Signal	Flex Fuel Sensor Output Frequency	< 45 Hertz	Powertrain Relay	> 11.0 Volts	50 failures out of 63 samples 100 ms loop Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Composition Sensor Circuit High	P0179	Detects Out of Range High Frequency Signal	Flex Fuel Sensor Output Frequency	> 155 Hertz <= 185	Powertrain Relay	> 11.0 Volts	50 failures out of 63 samples 100 ms loop Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Conductivity Out Of Range (water in fuel)	P2269	Detects the presence of High Conductivity Fuel (e.g. water in fuel) via a specific range of sensor frequency	Flex Fuel Sensor Output Frequency	> 185 Hertz	Powertrain Relay	> 11.0 Volts	50 failures out of 63 samples 100 ms loop Continuous	Type B, 2 Trips

**Engine run time greater than**  
**KtFSTA\_t\_ClosedLoopAutostart (HYBRID ONLY)**  
     AutoStart CoolantX1   X2   X3   X4   X5   X6   X7   X8   X9   X10   X11  
     Close Loop Enable TimeY1   Y2   Y3   Y4   Y5   Y6   Y7   Y8   Y9   Y10   Y11  
**and**  
**KtFSTA\_t\_ClosedLoopTime**  
     Start-Up CoolantX1   X2   X3   X4   X5   X6   X7   X8   X9   X10   X11  
     Close Loop Enable TimeY1   Y2   Y3   Y4   Y5   Y6   Y7   Y8   Y9   Y10   Y11  
**and pre converter O2 sensor voltage less**  
**than**  
**KfFULC\_U\_O2\_SensorReadyThresh**  
**Lo**  
     Voltage < XXXXmilliVolts  
**for**  
**KcFULC\_O2\_SensorReadyEvents**  
     Time (events \* 12.5 milliseconds) > XXXXevents  
**and**  
**COSC (Converter Oxygen Storage Control) not**  
**enabled**  
**and**  
**Consumed AirFuel Ratio is stoichiometry i.e. not in component**  
**protection**  
**and**  
**POPD or Catalyst Diagnostic not intrusive**  
**and**  
**Turbo Scavenging Mode not**  
**enabled**  
**and**  
**All cylinders whose valves are active also have their injectors**  
**enabled**  
**and**  
**O2S\_Bank\_1\_TFTKO, O2S\_Bank\_2\_TFTKO, FuelInjectorCircuit\_FA and**  
**CylinderDeacDriverTFTKO = False**  
  
**Long Term FT Enable Criteria**

Closed Loop Enable and  
Coolant greater than  
KfFCLL\_T\_AdaptiveLoCoolant

Coolant > XXXXCelcius

or less than  
KfFCLL\_T\_AdaptiveHiCoolant

Coolant < XXXXCelcius

and  
KtFCLL\_p\_AdaptiveLowMAP\_Limit

Barometric Pressure	X1	X2	X3	X4	X5	X6	X7	X8	X9
Manifold Air Pressure	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9

and  
TPS\_ThrottleAuthorityDefaulted =  
False

and  
Flex Fuel Estimate Algorithm is not active

and  
Excessive fuel vapors boiling off from the engine oil algorithm (BOFR) is not  
enabled

and  
Catalyst or EVAP large leak test not  
intrusive

Secondary Fuel Trim Enable  
Criteria

Closed Loop Enable and  
KfFCLP\_U\_O2ReadyThrshLo

Voltage < XXXXmilliVolts

for  
KcFCLP\_Cnt\_O2RdyCyclesThrsh

Time (events \* 12.5 milliseconds) > XXXXevents

Long Term Secondary Fuel Trim  
Enable Criteria

KtFCLP\_t\_PostIntglDisableTime

12 OBDG05A Engine Diagnostics

MAIN SECTION  
1 OF 1 SECTION

Start-Up Coolant	X1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Post Integral Enable Time	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11

Plus

**KtFCLP\_t\_PostIntglRampInTime**

Start-Up Coolant	X1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Post Integral Ramp In Time	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11

and

**KeFCLP\_T\_IntegrationCatalystMax**

Modeled Catalyst Temperature < XXXXCelcius

and

**KeFCLP\_T\_IntegrationCatalystMin**

Modeled Catalyst Temperature > XXXXCelcius

and

**PO2S\_Bank\_1\_Snsr\_2\_FA** and

**PO2S\_Bank\_2\_Snsr\_2\_FA = False**

**Description:** Table of delta MAP values as a function of desired throttle position. The output of this table provides a delta MAP that if the measured minus the estimated MAP exceeds, is considered a fail.

**Notes:**

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	39.15	39.15	35.01	32.52	30.65	27.27	23.49	255.00	255.00



**Description:** Table of delta MAF values as a function of desired throttle position. The output of this table provides a delta MAF that if the measured minus the estimated MAF exceeds, is considered a fail.

**Notes:**

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	15.84	15.84	17.20	17.56	20.43	24.10	36.18	255.00	255.00

**Description:** Table of maximum MAF values vs. engine speed. This is the maximum MAF the engine can see under all ambient conditions.

**Notes:**

y/x	600.00	1,400.00	2,200.00	3,000.00	3,800.00	4,600.00	5,400.00	6,200.00	7,000.00
1.00	15.00	32.00	60.00	70.00	82.00	103.00	117.00	134.00	138.00

**Description:** Table of maximum MAF values vs. system voltage. The output of the air meter is clamped to lower values as system voltage drops off.

**Notes:**

y/x	6.00	7.00	8.00	9.00	10.00	11.00	12.00	13.00	14.00
1.00	31.00	72.00	130.00	190.00	238.00	238.00	238.00	238.00	238.00

**Description:** The Run/Crank voltages required to pull in the PT relay as a function of induction air temperature.

**Notes:**

y/x	23.00	85.00	95.00	105.00	125.00
1.00	7.00	8.70	9.00	9.20	10.00

**Description:** The max time for the Last Seed Timeout as a function of operating loop time sequence.

**Notes:**

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	0.175	0.175	0.175	409.594

**Description:** The enabling flags for the program sequence watch as a function of operating loop time sequence.

**Notes:**

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	1	1	1	1

12 OBDG05A Engine Diagnostics

MAIN SECTION  
1 OF 1 SECTION

**Description:** Threshold for determining when the difference between commanded spark and applied spark exceeds the torque security requirement. It is a function of engine rpm and APC.

**Notes:**

y/x	500.00	980.74	1,461.48	1,942.23	2,422.97	2,903.71	3,384.45	3,865.20	4,345.94	4,826.68	5,307.42	5,788.16	6,268.91	6,749.65	7,230.39	7,711.13	8,191.88
80.00	125.00	63.30	57.55	65.80	63.95	60.77	59.25	61.73	67.50	71.45	73.59	70.20	59.33	42.55	40.78	40.78	40.78
160.00	125.00	57.17	46.16	50.73	48.92	46.52	46.47	49.48	55.00	52.59	49.64	48.19	42.64	33.84	32.92	32.92	32.92
240.00	125.00	52.17	38.56	39.92	38.88	37.69	38.23	41.30	46.41	41.80	37.14	36.59	33.41	28.16	27.59	27.59	27.59
320.00	125.00	47.58	32.19	32.75	32.25	31.67	32.48	34.53	37.56	33.53	29.69	29.50	27.52	24.11	23.77	23.77	23.77
400.00	125.00	40.42	26.86	27.72	27.56	27.31	28.25	29.67	31.52	27.98	24.64	24.31	23.05	21.06	20.86	20.86	20.86
480.00	125.00	35.13	23.05	23.81	23.95	24.02	24.98	26.03	27.14	24.02	21.05	20.59	19.80	18.70	18.59	18.59	18.59
560.00	125.00	31.06	20.17	20.84	21.17	21.41	22.31	23.13	23.84	21.03	18.38	17.88	17.36	16.81	16.77	16.77	16.77
640.00	125.00	27.84	17.92	18.55	18.97	19.31	20.16	20.80	21.25	18.70	16.31	15.78	15.45	15.28	15.27	15.27	15.27
720.00	125.00	25.50	16.30	16.89	17.38	17.77	18.56	19.09	19.38	17.03	14.83	14.30	14.09	14.14	14.14	14.14	14.14
800.00	125.00	25.50	16.30	16.89	17.38	17.77	18.56	19.09	19.38	17.03	14.83	14.30	14.09	14.14	14.14	14.14	14.14
880.00	125.00	25.50	16.30	16.89	17.38	17.77	18.56	19.09	19.38	17.03	14.83	14.30	14.09	14.14	14.14	14.14	14.14
960.00	125.00	25.50	16.30	16.89	17.38	17.77	18.56	19.09	19.38	17.03	14.83	14.30	14.09	14.14	14.14	14.14	14.14
1,040.00	125.00	25.50	16.30	16.89	17.38	17.77	18.56	19.09	19.38	17.03	14.83	14.30	14.09	14.14	14.14	14.14	14.14
1,120.00	125.00	25.50	16.30	16.89	17.38	17.77	18.56	19.09	19.38	17.03	14.83	14.30	14.09	14.14	14.14	14.14	14.14
1,200.00	125.00	25.50	16.30	16.89	17.38	17.77	18.56	19.09	19.38	17.03	14.83	14.30	14.09	14.14	14.14	14.14	14.14
1,280.00	125.00	25.50	16.30	16.89	17.38	17.77	18.56	19.09	19.38	17.03	14.83	14.30	14.09	14.14	14.14	14.14	14.14
1,360.00	125.00	25.50	16.30	16.89	17.38	17.77	18.56	19.09	19.38	17.03	14.83	14.30	14.09	14.14	14.14	14.14	14.14

**Description:** Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

**Notes:**

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	23.49	23.49	23.49	23.49	23.49	23.49



**Description:** Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

**Notes:**

y/x	-40.00	-20.00	-10.00	0.00	50.00	90.00
200.00	218.00	218.00	218.00	218.00	218.00	218.00
400.00	55.00	50.00	40.00	40.00	40.00	25.00
600.00	55.00	50.00	40.00	40.00	40.00	25.00
700.00	55.00	50.00	40.00	40.00	40.00	25.00
800.00	55.00	50.00	40.00	40.00	40.00	25.00
900.00	55.00	50.00	40.00	40.00	40.00	25.00
1,000.00	55.00	50.00	40.00	40.00	40.00	25.00
1,100.00	55.00	50.00	25.00	15.00	10.00	10.00
1,300.00	55.00	50.00	15.00	5.00	5.00	5.00
1,500.00	55.00	50.00	10.00	0.00	0.00	0.00
2,000.00	55.00	40.00	0.00	-12.25	-15.00	-15.00
2,500.00	0.00	0.00	-12.25	-14.25	-17.25	-17.25
3,000.00	-4.00	-8.50	-11.50	-13.50	-16.50	-16.50
3,500.00	-2.50	-7.00	-9.75	-12.00	-14.75	-14.75
4,500.00	-0.75	-5.25	-8.25	-10.50	-13.25	-13.25
5,500.00	-2.00	-6.50	-9.50	-11.50	-14.25	-14.25
7,200.00	-6.75	-11.25	-14.25	-16.25	-19.00	-19.00

**Description:** Quality weight-based on engine run time. This allows adjustment of the weighting factors at various engine run times in order to prevent the updating of the cumulative quality timer or to change the value of the average qualified residual energy calculation to prevent false Fails of the diagnostic under circumstances inappropriate to update the calculation of the average qualified residual value.

**Notes:**

y/x	0	1	2	2	5	10	15	20	30
1	0	0	0	1	1	1	1	1	1

**Description:** Exit Catalyst Warm-up mode if Engine Run Time is greater than this value. This table is based on percent ethanol (x-axis) and catmon's NormRatio\_EWMA value (y-axis). The NormRatio\_EWMA value determines the state of the catalyst. Typically, NormRatio\_EWMA values below 0.35 (0 is bad and 1 is good) represent catalysts that have degraded. The emission performance of these degraded catalysts can be improved by extending catalyst light off of GetE85R\_Pct\_FFS\_CompAtEngFloat.

**Notes:**

y/x	0	25	50	75	100
0.000	18	18	18	18	18
0.125	18	18	18	18	18
0.250	18	18	18	18	18
0.375	18	18	18	18	18
0.500	18	18	18	18	18
0.625	18	18	18	18	18
0.750	18	18	18	18	18
0.875	18	18	18	18	18
1.000	18	18	18	18	18

**Description:** This is the x-axis for the KtCSED\_K\_TimeWght calibration table. Refer to the description for KtCSED\_K\_TimeWght for details.

**Notes:**

y/x	1	2	3	4	5	6	7	8	9
1	0	1	2	2	5	10	15	20	30

**Description:** Cam Position Error Limit for performance diagnostic

**Notes:**

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

Description:																	
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

Description:																	
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
1,200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
1,600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2,000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2,400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2,800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3,200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3,600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4,000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4,400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4,800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5,200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5,600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
6,000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
6,400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
6,800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Description:																	
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
1,200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
1,600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2,000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2,400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2,800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3,200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3,600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4,000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4,400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4,800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5,200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5,600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
6,000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
6,400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
6,800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0



Description:																	
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
800	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
1,200	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
1,600	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
2,000	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
2,400	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
2,800	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
3,200	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
3,600	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
4,000	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
4,400	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
4,800	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
5,200	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
5,600	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
6,000	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
6,400	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
6,800	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0

Description:																	
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
800	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
1,200	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
1,600	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
2,000	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
2,400	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
2,800	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
3,200	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
3,600	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
4,000	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
4,400	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
4,800	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
5,200	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
5,600	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
6,000	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
6,400	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
6,800	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0

Description:																	
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
1,200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
1,600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2,000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2,400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2,800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3,200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3,600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4,000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4,400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4,800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5,200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5,600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
6,000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
6,400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
6,800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Description:																	
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
1,200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
1,600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2,000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2,400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2,800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3,200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3,600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4,000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4,400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4,800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5,200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5,600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
6,000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
6,400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
6,800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Description:

Notes:

y/x	65	70	75	80	85	90	95	100	105
1	7	7	7	5	3	3	3	3	3

Description:

Notes:

y/x	65	70	75	80	85	90	95	100	105
1	3.2	3.2	3.2	3.2	3.2	3.2	3.2	3.2	3.2

Description:

Notes:

y/x	65	70	75	80	85	90	95	100	105
1	0.7	0.7	0.8	0.8	0.8	0.9	0.9	1.0	1.0

Description:

Notes:

y/x	65	70	75	80	85	90	95	100	105
1	20	20	20	15	10	10	10	10	10



Description:

Notes:

y/x	65	70	75	80	85	90	95	100	105
1	20	20	20	15	10	10	10	10	10

**Description:** This cal value is a 1x5 array of minimum engine run time values based on powerup coolant temperatures. When the appropriate required minimum engine run time value is chosen based on the coolant temperature at powerup, this value is the minimum time from engine start before stabilized conditions are met. Used in determining if a ValidIdleIsMet condition exists.

**Notes:** Axis is the coolant and the output is the min engine run time

y/x	40	50	60	70	80
1	0	0	0	0	0

**Description:** This is a 1x3 table with the axis being engine coolant temperature. The implementation of this cal value as a table also included some changes to the way that the WarmedUpEvents counter increments and resets. To summarize, whenever WarmedUpEvents resets to 0 (this could be either at startup, if the closed throttle time exceeds a cal value, or if the predicted exhaust temperature falls below the ExhWarmMin cal value), the appropriate MinAirflowToWrmupCat value is chosen from the table based on engine coolant at the time the WarmedUpEvents counter reset to 0. This cal value is used along with the min exhaust temp to increment the WarmedUpEvents counter.

**Notes:** Axis is the engine coolant and the output is the minimum airflow required to warmup the catalyst.

y/x	0	45	90
1	10	9	8

**Description:**

**Notes:**

y/x	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	6,000
1	1.750	1.500	1.375	1.125	1.000	0.875	0.750	0.625	0.500	0.500

**Description:** KtMTCl\_M\_TorqueEnable: The diagnostic is inhibited if torque (NM) is less than this value. Prevents false fails in regions where false in-gear N/TOS ratios are possible due to low torque, where high torque would otherwise cause slip and prevent a valid in-gear state.

**Notes:** Axis is Percent Clutch Pedal Position (%), 0% = bottom of pedal travel.

y/x	0.00	6.25	12.50	18.75	25.00	31.25	37.50	43.75	50.00	56.25	62.50	68.75	75.00	81.25	87.50	93.75	100.00
1	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

**Description:** KaMTCI\_Pct\_ResidErrCalcEnbLow[x]: Represents the lower threshold of a deadband where the diagnostic will be inhibited to prevent false fails due to clutch slip that can falsely indicate a valid in-gear N/TOS ratio.

**Notes:** Axis identifies Gear, where "0" - "5" is gear 1 - 6, respectively; "6" is reverse and "7" is neutral

y/x	0	1	2	3	4	5	6	7
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

**Description:** KaMTCI\_Pct\_ResidErrCalcEnbHigh[x]: Represents the upper threshold of a deadband where the diagnostic will be inhibited to prevent false fails due to clutch slip that can falsely indicate a valid in-gear N/TOS ratio.

**Notes:** Axis identifies Gear, where "0" - "5" is gear 1 - 6, respectively; "6" is reverse and "7" is neutral

y/x	0	1	2	3	4	5	6	7
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

<b>Description:</b> Long Term Fuel Trim Cell I.D.s used for diagnosis. Cells identified as "CeFADD_e_NonSelectedCell" are not used for diagnosis.				
<b>Notes:</b> Axis is Long Term Fuel Trim Cell I.D.				
<b>P0171/172/174/175 Long-Term Fuel Trim Cell Usage - Part 1</b>				
y/x	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR_e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell
<b>P0171/172/174/175 Long-Term Fuel Trim Cell Usage - Part 2</b>				
y/x	CeFADR_e_Cell04_PurgOnAirMode 1	CeFADR_e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_NonSelectedCell
<b>P0171/172/174/175 Long-Term Fuel Trim Cell Usage - Part 3</b>				
y/x	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR_e_Cell10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell
<b>P0171/172/174/175 Long-Term Fuel Trim Cell Usage - Part 4</b>				
y/x	CeFADR_e_Cell12_PurgOffAirMode 1	CeFADR_e_Cell13_PurgOffAirMode 0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_NonSelectedCell



**Description:** Supercharger Intake Flow Rationality Diagnostic Failure Matrix

**Notes:** This table describes combinations of individual model failures that will set P0101, P0106, P012B, P0121 and P1101 on supercharged applications.

y/x	1	2	3	4	5	6	7
1	TPS Model Failure	MAF Model Failure	MAP1 Model Failure	MAP2 Model Failure	SCIAP1 Model Failure	SCIAP2 Model Failure	DTC Set
2	F	F	F	F	F	F	No DTC
3	F	F	F	F	F	T	No DTC
4	F	F	F	F	T	F	No DTC
5	F	F	F	F	T	T	P012B
6	F	F	F	T	F	F	No DTC
7	F	F	F	T	F	T	P1101
8	F	F	F	T	T	F	P1101
9	F	F	F	T	T	T	P1101
10	F	F	T	F	F	F	No DTC
11	F	F	T	F	F	T	P1101
12	F	F	T	F	T	F	P1101
13	F	F	T	F	T	T	P1101
14	F	F	T	T	F	F	P0106
15	F	F	T	T	F	T	P1101
16	F	F	T	T	T	F	P1101
17	F	F	T	T	T	T	P1101
18	F	T	F	F	F	F	No DTC
19	F	T	F	F	F	T	P0101
20	F	T	F	F	T	F	No DTC
21	F	T	F	F	T	T	P0101 & P012B
22	F	T	F	T	F	F	P1101
23	F	T	F	T	F	T	P0101
24	F	T	F	T	T	F	P1101
25	F	T	F	T	T	T	P0101 & P012B
26	F	T	T	F	F	F	P1101
27	F	T	T	F	F	T	P1101
28	F	T	T	F	T	F	P1101
29	F	T	T	F	T	T	P1101
30	F	T	T	T	F	F	P1101
31	F	T	T	T	F	T	P1101
32	F	T	T	T	T	F	P1101
33	F	T	T	T	T	T	P1101
34	T	F	F	F	F	F	P0121

12 OBDG05A Engine Diagnostics

MAIN SECTION  
1 OF 1 SECTION

35	T	F	F	F	F	T	No DTC
36	T	F	F	F	T	F	P0121
37	T	F	F	F	T	T	P1101
38	T	F	F	T	F	F	P1101
39	T	F	F	T	F	T	P1101
40	T	F	F	T	T	F	P1101
41	T	F	F	T	T	T	P1101
42	T	F	T	F	F	F	P0121
43	T	F	T	F	F	T	P1101
44	T	F	T	F	T	F	P0121
45	T	F	T	F	T	T	P1101
46	T	F	T	T	F	F	P1101
47	T	F	T	T	F	T	P1101
48	T	F	T	T	T	F	P1101
49	T	F	T	T	T	T	P1101
50	T	T	F	F	F	F	P0121
51	T	T	F	F	F	T	P1101
52	T	T	F	F	T	F	P0121
53	T	T	F	F	T	T	P1101
54	T	T	F	T	F	F	P1101
55	T	T	F	T	F	T	P1101
56	T	T	F	T	T	F	P1101
57	T	T	F	T	T	T	P1101
58	T	T	T	F	F	F	P0121
59	T	T	T	F	F	T	P1101
60	T	T	T	F	T	F	P0121
61	T	T	T	F	T	T	P1101
62	T	T	T	T	F	F	P1101
63	T	T	T	T	F	T	P1101
64	T	T	T	T	T	F	P1101
65	T	T	T	T	T	T	P1101

**Description:** Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

**Notes:** This table describes combinations of individual model failures that will set P0101, P0106, P0121, P0236 and P1101 on turbocharged applications.

y/x	1	2	3	4	5	6	7	8	9
1	MAF Model	MAP1 Model	MAP2 Model	MAP3 Model	TIAP1 Model	TPS Model	TIAP Correlation	TIAP Correlation	DTC Set
2	Failed	Failed	Failed	Failed	Failed	Failed	Failed	Valid	
3	F	F	F	F	F	F	F	F	No DTC
4	F	F	F	F	F	F	F	T	No DTC
5	F	F	F	F	F	F	T	F	No DTC
6	F	F	F	F	F	F	T	T	No DTC
7	F	F	F	F	F	T	F	F	No DTC
8	F	F	F	F	F	T	F	T	No DTC
9	F	F	F	F	F	T	T	F	No DTC
10	F	F	F	F	F	T	T	T	No DTC
11	F	F	F	F	T	F	F	F	No DTC
12	F	F	F	F	T	F	F	T	No DTC
13	F	F	F	F	T	F	T	F	No DTC
14	F	F	F	F	T	F	T	T	No DTC
15	F	F	F	F	T	T	F	F	P1101
16	F	F	F	F	T	T	F	T	P0121
17	F	F	F	F	T	T	T	F	P1101
18	F	F	F	F	T	T	T	T	P0236
19	F	F	F	T	F	F	F	F	P1101
20	F	F	F	T	F	F	F	T	P1101
21	F	F	F	T	F	F	T	F	P1101
22	F	F	F	T	F	F	T	T	P1101
23	F	F	F	T	F	T	F	F	P1101
24	F	F	F	T	F	T	F	T	P1101
25	F	F	F	T	F	T	T	F	P1101
26	F	F	F	T	F	T	T	T	P1101
27	F	F	F	T	T	F	F	F	P1101
28	F	F	F	T	T	F	F	T	P1101
29	F	F	F	T	T	F	T	F	P1101
30	F	F	F	T	T	F	T	T	P1101
31	F	F	F	T	T	T	F	F	P1101
32	F	F	F	T	T	T	F	T	P1101
33	F	F	F	T	T	T	T	F	P1101
34	F	F	F	T	T	T	T	T	P1101

12 OBDG05A Engine Diagnostics

MAIN SECTION  
1 OF 1 SECTION

35	F	F	T	F	F	F	F	F	P1101
36	F	F	T	F	F	F	F	T	P1101
37	F	F	T	F	F	F	T	F	P1101
38	F	F	T	F	F	F	T	T	P1101
39	F	F	T	F	F	T	F	F	P1101
40	F	F	T	F	F	T	F	T	P1101
41	F	F	T	F	F	T	T	F	P1101
42	F	F	T	F	F	T	T	T	P1101
43	F	F	T	F	T	F	F	F	P1101
44	F	F	T	F	T	F	F	T	P1101
45	F	F	T	F	T	F	T	F	P1101
46	F	F	T	F	T	F	T	T	P1101
47	F	F	T	F	T	T	F	F	P1101
48	F	F	T	F	T	T	F	T	P1101
49	F	F	T	F	T	T	T	F	P1101
50	F	F	T	F	T	T	T	T	P1101
51	F	F	T	T	F	F	F	F	P1101
52	F	F	T	T	F	F	F	T	P1101
53	F	F	T	T	F	F	T	F	P1101
54	F	F	T	T	F	F	T	T	P1101
55	F	F	T	T	F	T	F	F	P1101
56	F	F	T	T	F	T	F	T	P1101
57	F	F	T	T	F	T	T	F	P1101
58	F	F	T	T	F	T	T	T	P1101
59	F	F	T	T	T	F	F	F	No DTC
60	F	F	T	T	T	F	F	T	No DTC
61	F	F	T	T	T	F	T	F	No DTC
62	F	F	T	T	T	F	T	T	No DTC
63	F	F	T	T	T	T	F	F	P1101
64	F	F	T	T	T	T	F	T	P1101
65	F	F	T	T	T	T	T	F	P1101
66	F	F	T	T	T	T	T	T	P1101
67	F	T	F	F	F	F	F	F	P1101
68	F	T	F	F	F	F	F	T	P1101
69	F	T	F	F	F	F	T	F	P1101
70	F	T	F	F	F	F	T	T	P0236
71	F	T	F	F	F	T	F	F	P1101
72	F	T	F	F	F	T	F	T	P0121

12 OBDG05A Engine Diagnostics

MAIN SECTION  
1 OF 1 SECTION

73	F	T	F	F	F	T	T	F	P1101
74	F	T	F	F	F	T	T	T	P0236
75	F	T	F	F	T	F	F	F	P1101
76	F	T	F	F	T	F	F	T	P1101
77	F	T	F	F	T	F	T	F	P1101
78	F	T	F	F	T	F	T	T	P0236
79	F	T	F	F	T	T	F	F	P1101
80	F	T	F	F	T	T	F	T	P0121
81	F	T	F	F	T	T	T	F	P1101
82	F	T	F	F	T	T	T	T	P0236
83	F	T	F	T	F	F	F	F	P1101
84	F	T	F	T	F	F	F	T	P1101
85	F	T	F	T	F	F	T	F	P1101
86	F	T	F	T	F	F	T	T	P1101
87	F	T	F	T	F	T	F	F	P1101
88	F	T	F	T	F	T	F	T	P1101
89	F	T	F	T	F	T	T	F	P1101
90	F	T	F	T	F	T	T	T	P1101
91	F	T	F	T	T	F	F	F	P1101
92	F	T	F	T	T	F	F	T	P1101
93	F	T	F	T	T	F	T	F	P1101
94	F	T	F	T	T	F	T	T	P1101
95	F	T	F	T	T	T	F	F	P1101
96	F	T	F	T	T	T	F	T	P1101
97	F	T	F	T	T	T	T	F	P1101
98	F	T	F	T	T	T	T	T	P1101
99	F	T	T	F	F	F	F	F	P1101
100	F	T	T	F	F	F	F	T	P1101
101	F	T	T	F	F	F	T	F	P1101
102	F	T	T	F	F	F	T	T	P1101
103	F	T	T	F	F	T	F	F	P1101
104	F	T	T	F	F	T	F	T	P1101
105	F	T	T	F	F	T	T	F	P1101
106	F	T	T	F	F	T	T	T	P1101
107	F	T	T	F	T	F	F	F	P1101
108	F	T	T	F	T	F	F	T	P1101
109	F	T	T	F	T	F	T	F	P1101
110	F	T	T	F	T	F	T	T	P1101

12 OBDG05A Engine Diagnostics

MAIN SECTION  
1 OF 1 SECTION

111	F	T	T	F	T	T	F	F	P1101
112	F	T	T	F	T	T	F	T	P1101
113	F	T	T	F	T	T	T	F	P1101
114	F	T	T	F	T	T	T	T	P1101
115	F	T	T	T	F	F	F	F	P0106
116	F	T	T	T	F	F	F	T	P0106
117	F	T	T	T	F	F	T	F	P0106
118	F	T	T	T	F	F	T	T	P0106
119	F	T	T	T	F	T	F	F	P1101
120	F	T	T	T	F	T	F	T	P1101
121	F	T	T	T	F	T	T	F	P1101
122	F	T	T	T	F	T	T	T	P1101
123	F	T	T	T	T	F	F	F	P1101
124	F	T	T	T	T	F	F	T	P1101
125	F	T	T	T	T	F	T	F	P1101
126	F	T	T	T	T	F	T	T	P1101
127	F	T	T	T	T	T	F	F	P1101
128	F	T	T	T	T	T	F	T	P1101
129	F	T	T	T	T	T	T	F	P1101
130	F	T	T	T	T	T	T	T	P1101
131	T	F	F	F	F	F	F	F	P1101
132	T	F	F	F	F	F	F	T	P1101
133	T	F	F	F	F	F	T	F	P1101
134	T	F	F	F	F	F	T	T	P0236
135	T	F	F	F	F	T	F	F	P1101
136	T	F	F	F	F	T	F	T	P0121
137	T	F	F	F	F	T	T	F	P1101
138	T	F	F	F	F	T	T	T	P0236
139	T	F	F	F	T	F	F	F	P1101
140	T	F	F	F	T	F	F	T	P1101
141	T	F	F	F	T	F	T	F	P1101
142	T	F	F	F	T	F	T	T	P0236
143	T	F	F	F	T	T	F	F	P1101
144	T	F	F	F	T	T	F	T	P0121
145	T	F	F	F	T	T	T	F	P1101
146	T	F	F	F	T	T	T	T	P0236
147	T	F	F	T	F	F	F	F	P1101
148	T	F	F	T	F	F	F	T	P1101

12 OBDG05A Engine Diagnostics

MAIN SECTION  
1 OF 1 SECTION

149	T	F	F	T	F	F	T	F	P1101
150	T	F	F	T	F	F	T	T	P1101
151	T	F	F	T	F	T	F	F	P1101
152	T	F	F	T	F	T	F	T	P1101
153	T	F	F	T	F	T	T	F	P1101
154	T	F	F	T	F	T	T	T	P1101
155	T	F	F	T	T	F	F	F	P1101
156	T	F	F	T	T	F	F	T	P1101
157	T	F	F	T	T	F	T	F	P1101
158	T	F	F	T	T	F	T	T	P1101
159	T	F	F	T	T	T	F	F	P1101
160	T	F	F	T	T	T	F	T	P1101
161	T	F	F	T	T	T	T	F	P1101
162	T	F	F	T	T	T	T	T	P1101
163	T	F	T	F	F	F	F	F	P1101
164	T	F	T	F	F	F	F	T	P1101
165	T	F	T	F	F	F	T	F	P1101
166	T	F	T	F	F	F	T	T	P1101
167	T	F	T	F	F	T	F	F	P1101
168	T	F	T	F	F	T	F	T	P1101
169	T	F	T	F	F	T	T	F	P1101
170	T	F	T	F	F	T	T	T	P1101
171	T	F	T	F	T	F	F	F	P1101
172	T	F	T	F	T	F	F	T	P1101
173	T	F	T	F	T	F	T	F	P1101
174	T	F	T	F	T	F	T	T	P1101
175	T	F	T	F	T	T	F	F	P1101
176	T	F	T	F	T	T	F	T	P1101
177	T	F	T	F	T	T	T	F	P1101
178	T	F	T	F	T	T	T	T	P1101
179	T	F	T	T	F	F	F	F	P1101
180	T	F	T	T	F	F	F	T	P1101
181	T	F	T	T	F	F	T	F	P1101
182	T	F	T	T	F	F	T	T	P1101
183	T	F	T	T	F	T	F	F	P1101
184	T	F	T	T	F	T	F	T	P1101
185	T	F	T	T	F	T	T	F	P1101
186	T	F	T	T	F	T	T	T	P1101

12 OBDG05A Engine Diagnostics

MAIN SECTION  
1 OF 1 SECTION

187	T	F	T	T	T	F	F	F	P1101
188	T	F	T	T	T	F	F	T	P1101
189	T	F	T	T	T	F	T	F	P1101
190	T	F	T	T	T	F	T	T	P1101
191	T	F	T	T	T	T	F	F	P1101
192	T	F	T	T	T	T	F	T	P1101
193	T	F	T	T	T	T	T	F	P1101
194	T	F	T	T	T	T	T	T	P1101
195	T	T	F	F	F	F	F	F	P1101
196	T	T	F	F	F	F	F	T	P1101
197	T	T	F	F	F	F	T	F	P1101
198	T	T	F	F	F	F	T	T	P0236
199	T	T	F	F	F	T	F	F	P1101
200	T	T	F	F	F	T	F	T	P0121
201	T	T	F	F	F	T	T	F	P1101
202	T	T	F	F	F	T	T	T	P0236
203	T	T	F	F	T	F	F	F	P1101
204	T	T	F	F	T	F	F	T	P1101
205	T	T	F	F	T	F	T	F	P1101
206	T	T	F	F	T	F	T	T	P0236
207	T	T	F	F	T	T	F	F	P1101
208	T	T	F	F	T	T	F	T	P0121
209	T	T	F	F	T	T	T	F	P1101
210	T	T	F	F	T	T	T	T	P0236
211	T	T	F	T	F	F	F	F	P1101
212	T	T	F	T	F	F	F	T	P1101
213	T	T	F	T	F	F	T	F	P1101
214	T	T	F	T	F	F	T	T	P1101
215	T	T	F	T	F	T	F	F	P1101
216	T	T	F	T	F	T	F	T	P1101
217	T	T	F	T	F	T	T	F	P1101
218	T	T	F	T	F	T	T	T	P1101
219	T	T	F	T	T	F	F	F	P1101
220	T	T	F	T	T	F	F	T	P1101
221	T	T	F	T	T	F	T	F	P1101
222	T	T	F	T	T	F	T	T	P1101
223	T	T	F	T	T	T	F	F	P1101
224	T	T	F	T	T	T	F	T	P1101



12 OBDG05A Engine Diagnostics

MAIN SECTION  
1 OF 1 SECTION

225	T	T	F	T	T	T	T	F	P1101
226	T	T	F	T	T	T	T	T	P1101
227	T	T	T	F	F	F	F	F	P1101
228	T	T	T	F	F	F	F	T	P1101
229	T	T	T	F	F	F	T	F	P1101
230	T	T	T	F	F	F	T	T	P1101
231	T	T	T	F	F	T	F	F	P1101
232	T	T	T	F	F	T	F	T	P1101
233	T	T	T	F	F	T	T	F	P1101
234	T	T	T	F	F	T	T	T	P1101
235	T	T	T	F	T	F	F	F	P1101
236	T	T	T	F	T	F	F	T	P1101
237	T	T	T	F	T	F	T	F	P1101
238	T	T	T	F	T	F	T	T	P1101
239	T	T	T	F	T	T	F	F	P1101
240	T	T	T	F	T	T	F	T	P1101
241	T	T	T	F	T	T	T	F	P1101
242	T	T	T	F	T	T	T	T	P1101
243	T	T	T	T	F	F	F	F	P1101
244	T	T	T	T	F	F	F	T	P1101
245	T	T	T	T	F	F	T	F	P1101
246	T	T	T	T	F	F	T	T	P1101
247	T	T	T	T	F	T	F	F	P1101
248	T	T	T	T	F	T	F	T	P1101
249	T	T	T	T	F	T	T	F	P1101
250	T	T	T	T	F	T	T	T	P1101
251	T	T	T	T	T	F	F	F	P1101
252	T	T	T	T	T	F	F	T	P1101
253	T	T	T	T	T	F	T	F	P1101
254	T	T	T	T	T	F	T	T	P1101
255	T	T	T	T	T	T	F	F	P1101
256	T	T	T	T	T	T	F	T	P1101
257	T	T	T	T	T	T	T	F	P1101
258	T	T	T	T	T	T	T	T	P1101

**Description:** P0101\_P0106\_P0121\_P012B\_P0236\_P1101 TPS Residual Weight Factor based on RPM

**Notes:**

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,600
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.000

**Description:** P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAF Residual Weight Factor based on RPM

**Notes:**

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,600
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.896	0.000

**Description:** P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAF Residual Weight Factor based on MAF Est

**Notes:**

y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

**Description:** P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP1 Residual Weight Factor based on RPM

**Notes:**

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,600
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.000

**Description:** P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP2 Residual Weight Factor based on RPM

**Notes:**

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,600
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.925	1.000	1.000	1.000	1.000	1.000	1.000	0.000

**Description:** P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP3 Residual Weight Factor based on RPM

**Notes:**

y/x	0	250	750	1,250	1,750	2,250	2,750	3,250	3,750	4,250	4,750	5,250	5,750	6,250	6,750	7,250	9,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP Residual Weight Factor based on RPM

**Notes:**

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,600
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000



**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-MAP Correlation Offset

**Notes:**

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-Baro Correlation Offset

**Notes:**

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	0.0	1.5	3.5	6.0	9.0	12.0	16.0	20.0	25.0

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-MAP Correlation Min Air Flow

**Notes:**

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	17.0	32.0	32.0	32.0	32.0	32.0	32.0	32.0	32.0

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-Baro Correlation Max Air Flow

**Notes:**

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	5.0	9.0	13.0	16.0	20.0	24.0	28.0	31.0	32.0

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-MAP Correlation Min MAP

**Notes:**

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	110.0	110.0	110.0	110.0	110.0	110.0	110.0	110.0	110.0

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-Baro Correlation Max MAP

**Notes:**

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	35.0	35.0	35.0	35.0	35.0	35.0	35.0	35.0	35.0

**Description:** P0101\_P0106\_P0121\_P012B\_P1101 Boost Residual Weight Factor based on % of Boost

**Notes:**

y/x	0	0	0	0	0	0	0	0	0	1	1	1	1	1	1	1	1
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

**Description:** P0101\_P0106\_P0121\_P012B\_P1101 SCIAP1 Residual Weight Factor based on RPM

**Notes:**

y/x	0	1,500	2,200	2,500	2,800	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,500	6,500	8,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000



**Description:** P0101\_P0106\_P0121\_P012B\_P1101 SCIAP2 Residual Weight Factor based on RPM

**Notes:**

y/x	0	1,500	2,200	2,500	2,800	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,500	6,500	8,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

**Description:** OAT Performance Diagnostic counter increment for determining OAT-IAT equilibrium for engine running

**Notes:**

y/x	0.0	5.0	10.0	15.0	20.0	25.0	30.0	50.0	80.0
1.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0	8.0	9.0
5.0	-5.0	-2.0	-1.0	0.0	1.0	2.0	3.0	4.0	5.0
10.0	-4.0	-1.0	0.0	0.0	1.0	2.0	3.0	4.0	5.0
20.0	-2.0	-1.0	0.0	0.0	1.0	2.0	3.0	4.0	5.0
30.0	-1.0	0.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0
40.0	0.0	0.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0
50.0	0.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0
60.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0	8.0
70.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0	8.0	9.0

**Description:** OAT Performance Diagnostic counter increment for determining OAT-IAT equilibrium for engine off (for hybrid applications)

**Notes:**

y/x	0.0	5.0	10.0	15.0	20.0	25.0	30.0	50.0	80.0
1.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0	8.0

**Description:** Engine run time following an autostart, as a function of begin run coolant, which must be exceeded to enable CLOSED LOOP.

**Notes:** Time in seconds: Hybrid use Only

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

**Description:** Engine run time, as a function of startup coolant temperature, which must be exceeded to enable CLOSED LOOP.

**Notes:** Time in seconds

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	0.0	0.0	100.0	55.0	19.0	18.0	18.0	18.0	18.0	18.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

**Description:** KtFCLL\_p\_AdaptiveLowMAP\_Limit

**Notes:** MAP in KPa

y/x	65	70	75	80	85	90	95	100	105
1	14.0	14.0	14.0	15.5	17.0	18.5	20.0	20.0	20.0

**Description:** Disable integral offset after engine start for this amount of time.

**Notes:** Time in seconds

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	400.0	400.0	400.0	275.0	150.0	150.0	150.0	150.0	150.0	100.0	50.0	10.0	10.0	10.0	10.0	10.0	10.0

**Description:** Time required to ramp integral offset to desired value.

**Notes:** Time in seconds

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	50.0	50.0	50.0	50.0	50.0	50.0	50.0	50.0	40.0	30.0	20.0	10.0	10.0	10.0	10.0	10.0	10.0



**Description:** Lower limit checked against when determining if an oxygen sensor is in range

**Notes:** Voltage in millivolts

y/x	1
1	1,250

**Description:** Number of times an oxygen sensor value must be in range before declaring it ready

**Notes:** Time (events \* 12.5 milliseconds)

y/x	1
1	10

**Description:** LTM learning is inhibited if the engine coolant temperature is below this calibration.

**Notes:** Degrees Celcius

y/x	1
1	40

**Description:** LTM learning is inhibited if the engine coolant temperature is above this calibration.

**Notes:** Degrees Celcius

y/x	1
1	120

**Description:** Lower threshold defining not ready window for post oxygen sensor voltage.

**Notes:** Voltage in millivolts

y/x	1
1	1,100

**Description:** Number of post catalyst oxygen sensor samples which must be outside not ready window before post oxygen sensor is READY.

**Notes:** Time (events \* 12.5 milliseconds)

y/x	1
1	10

**Description:** Maximum allowed estimated catalytic converter temperature for post O2 integral terms to be updated.

**Notes:** Modeled catalyst Temperature in Celcius

y/x	1
1	930

**Description:** Minimum allowed estimated catalytic converter temperature to begin using post O2 integration correction terms. Converter temperature must remain above this threshold to ramp-in the post O2 integration adjustments. Once the ramp-in has started, a converter temperature below this threshold will freeze the ramp-in multiplier. Post O2 integration will not be allowed below this converter temperature

**Notes:** Modeled catalyst Temperature in Celcius

y/x	1
1	650



**Description:** KtEPSI\_t\_RtnHomeDlyLmt

**Notes:**

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	300.0	300.0	160.0	18.0	18.0	18.0	18.0	10.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0

12 OBDG05A Engine Diagnostics

**Description:** Bank 1 lookup table of Variance metric used to calculate the Ratio for the current sample period

**Notes:** Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,500	4,000	4,500	5,000	6,000
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	68.75	68.75	64.50	87.50	47.00	38.00	34.50	47.50	45.00	45.00	9,999.00	9,999.00
80	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	68.75	68.75	64.50	87.50	47.00	38.00	34.50	47.50	45.00	45.00	9,999.00	9,999.00
120	9,999.00	9,999.00	9,999.00	88.00	88.00	87.00	87.00	60.75	73.75	52.00	76.50	41.25	34.50	41.25	41.25	9,999.00	9,999.00
160	9,999.00	9,999.00	9,999.00	88.00	88.00	94.50	59.00	83.50	90.25	33.25	29.25	35.00	29.00	30.50	30.50	9,999.00	9,999.00
200	9,999.00	9,999.00	9,999.00	87.00	87.00	137.00	82.00	80.25	87.00	39.50	32.00	34.50	27.50	33.00	33.00	9,999.00	9,999.00
240	9,999.00	9,999.00	9,999.00	163.50	163.50	159.00	120.50	101.00	80.75	53.75	50.50	61.00	62.00	46.00	46.00	9,999.00	9,999.00
280	9,999.00	9,999.00	9,999.00	170.75	170.75	188.50	150.25	112.00	94.00	68.50	66.75	73.50	51.25	64.00	64.00	9,999.00	9,999.00
320	9,999.00	9,999.00	9,999.00	207.50	207.50	264.50	164.25	118.00	102.00	84.00	76.00	75.75	67.25	65.75	65.75	9,999.00	9,999.00
360	9,999.00	9,999.00	9,999.00	223.75	223.75	199.50	209.25	145.00	134.75	97.50	98.25	82.50	87.00	86.25	86.25	9,999.00	9,999.00
400	9,999.00	9,999.00	9,999.00	262.50	262.50	236.00	182.25	136.50	137.50	104.25	91.75	82.00	80.00	99.50	99.50	9,999.00	9,999.00
440	9,999.00	9,999.00	9,999.00	260.00	260.00	235.00	209.00	168.25	170.25	140.00	124.50	96.75	93.25	92.00	92.00	9,999.00	9,999.00
480	9,999.00	9,999.00	9,999.00	260.00	260.00	217.75	217.75	195.75	173.75	154.75	142.50	101.25	91.50	91.75	92.00	9,999.00	9,999.00
520	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	217.75	208.50	199.25	186.50	154.75	133.25	123.75	96.25	96.25	9,999.00	9,999.00	9,999.00
560	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	199.25	199.25	199.25	9,999.00	123.75	123.75	96.25	96.25	9,999.00	9,999.00	9,999.00
640	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
800	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00

12 OBDG05A Engine Diagnostics

**Description:** Bank 2 lookup table of Variance metric used to calculate the Ratio for the current sample period

**Notes:** Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,500	4,000	4,500	5,000	6,000
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	68.75	68.75	64.50	87.50	47.00	38.00	34.50	47.50	45.00	45.00	9,999.00	9,999.00
80	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	68.75	68.75	64.50	87.50	47.00	38.00	34.50	47.50	45.00	45.00	9,999.00	9,999.00
120	9,999.00	9,999.00	9,999.00	88.00	88.00	87.00	87.00	60.75	73.75	52.00	76.50	41.25	34.50	41.25	41.25	9,999.00	9,999.00
160	9,999.00	9,999.00	9,999.00	88.00	88.00	94.50	59.00	83.50	90.25	33.25	29.25	35.00	29.00	30.50	30.50	9,999.00	9,999.00
200	9,999.00	9,999.00	9,999.00	87.00	87.00	137.00	82.00	80.25	87.00	39.50	32.00	34.50	27.50	33.00	33.00	9,999.00	9,999.00
240	9,999.00	9,999.00	9,999.00	163.50	163.50	159.00	120.50	101.00	80.75	53.75	50.50	61.00	62.00	46.00	46.00	9,999.00	9,999.00
280	9,999.00	9,999.00	9,999.00	170.75	170.75	188.50	150.25	112.00	94.00	68.50	66.75	73.50	51.25	64.00	64.00	9,999.00	9,999.00
320	9,999.00	9,999.00	9,999.00	207.50	207.50	264.50	164.25	118.00	102.00	84.00	76.00	75.75	67.25	65.75	65.75	9,999.00	9,999.00
360	9,999.00	9,999.00	9,999.00	223.75	223.75	199.50	209.25	145.00	134.75	97.50	98.25	82.50	87.00	86.25	86.25	9,999.00	9,999.00
400	9,999.00	9,999.00	9,999.00	262.50	262.50	236.00	182.25	136.50	137.50	104.25	91.75	82.00	80.00	99.50	99.50	9,999.00	9,999.00
440	9,999.00	9,999.00	9,999.00	260.00	260.00	235.00	209.00	168.25	170.25	140.00	124.50	96.75	93.25	92.00	92.00	9,999.00	9,999.00
480	9,999.00	9,999.00	9,999.00	260.00	260.00	217.75	217.75	195.75	173.75	154.75	142.50	101.25	91.50	91.75	92.00	9,999.00	9,999.00
520	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	217.75	208.50	199.25	186.50	154.75	133.25	123.75	96.25	96.25	9,999.00	9,999.00	9,999.00
560	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	199.25	199.25	199.25	9,999.00	123.75	123.75	96.25	96.25	9,999.00	9,999.00	9,999.00
640	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
800	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00

12 OBDG05A Engine Diagnostics

MAIN SECTION  
1 OF 1 SECTION

**Description:** Bank 1 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

**Notes:** Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,500	4,000	4,500	5,000	6,000
40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
80	0.00	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
120	0.00	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
160	0.00	0.00	0.00	0.00	1.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
200	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
240	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
280	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
320	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
360	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
400	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
440	0.00	0.00	0.00	0.00	1.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
480	0.00	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
520	0.00	0.00	0.00	0.00	0.00	0.00	0.00	1.00	0.00	0.00	0.00	1.00	1.00	0.00	0.00	0.00	0.00
560	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
640	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
720	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
800	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

12 OBDG05A Engine Diagnostics

MAIN SECTION  
1 OF 1 SECTION

**Description:** Bank 2 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

**Notes:** Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,500	4,000	4,500	5,000	6,000
40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
80	0.00	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
120	0.00	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
160	0.00	0.00	0.00	0.00	1.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
200	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
240	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
280	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
320	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
360	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
400	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
440	0.00	0.00	0.00	0.00	1.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
480	0.00	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
520	0.00	0.00	0.00	0.00	0.00	0.00	0.00	1.00	0.00	0.00	0.00	1.00	1.00	0.00	0.00	0.00	0.00
560	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
640	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
720	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
800	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

12 OBDG05A Engine Diagnostics

**Description:** Bank 1 Normalizer table used in the calculation of the Ratio for the current sample period.

**Notes:** Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,500	4,000	4,500	5,000	6,000
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	223.50	223.50	160.00	147.25	138.75	93.25	117.00	62.25	48.75	48.75	9,999.00	9,999.00
80	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	223.50	223.50	160.00	147.25	138.75	93.25	117.00	62.25	48.75	48.75	9,999.00	9,999.00
120	9,999.00	9,999.00	9,999.00	133.25	133.25	133.00	133.00	138.00	104.00	99.50	71.25	103.50	106.00	45.50	45.50	9,999.00	9,999.00
160	9,999.00	9,999.00	9,999.00	133.25	133.25	133.50	118.25	142.00	143.50	185.25	182.25	169.50	122.25	112.50	112.50	9,999.00	9,999.00
200	9,999.00	9,999.00	9,999.00	230.75	230.75	149.25	244.50	137.75	115.50	171.75	181.00	203.75	199.25	162.25	162.25	9,999.00	9,999.00
240	9,999.00	9,999.00	9,999.00	177.50	177.50	153.50	186.75	198.50	216.25	208.75	177.25	174.50	133.75	104.50	104.50	9,999.00	9,999.00
280	9,999.00	9,999.00	9,999.00	152.75	152.75	125.00	156.00	179.00	186.50	197.00	195.00	178.25	195.00	177.00	177.00	9,999.00	9,999.00
320	9,999.00	9,999.00	9,999.00	112.75	112.75	55.25	143.25	165.75	177.00	179.25	189.25	183.25	177.50	174.00	174.00	9,999.00	9,999.00
360	9,999.00	9,999.00	9,999.00	88.50	88.50	95.00	76.25	129.75	124.00	158.50	157.00	180.00	175.25	166.75	166.75	9,999.00	9,999.00
400	9,999.00	9,999.00	9,999.00	34.00	34.00	48.00	94.00	136.00	125.50	154.25	157.25	184.75	164.50	149.00	149.00	9,999.00	9,999.00
440	9,999.00	9,999.00	9,999.00	31.00	31.00	47.25	63.00	98.25	82.25	88.00	65.50	126.25	149.75	144.25	144.25	9,999.00	9,999.00
480	9,999.00	9,999.00	9,999.00	31.00	31.00	32.50	32.50	48.00	58.50	80.00	91.50	120.50	115.75	130.00	144.25	9,999.00	9,999.00
520	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	32.50	37.50	42.25	50.25	80.00	88.75	86.00	121.50	121.50	9,999.00	9,999.00	9,999.00
560	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	42.25	42.25	42.25	9,999.00	86.00	86.00	121.50	121.50	9,999.00	9,999.00	9,999.00
640	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
800	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00

12 OBDG05A Engine Diagnostics

MAIN SECTION  
1 OF 1 SECTION

**Description:** Bank 2 Normalizer table used in the calculation of the Ratio for the current sample period.

**Notes:** Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,500	4,000	4,500	5,000	6,000
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	223.50	223.50	160.00	147.25	138.75	93.25	117.00	62.25	48.75	48.75	9,999.00	9,999.00
80	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	223.50	223.50	160.00	147.25	138.75	93.25	117.00	62.25	48.75	48.75	9,999.00	9,999.00
120	9,999.00	9,999.00	9,999.00	133.25	133.25	133.00	133.00	138.00	104.00	99.50	71.25	103.50	106.00	45.50	45.50	9,999.00	9,999.00
160	9,999.00	9,999.00	9,999.00	133.25	133.25	133.50	118.25	142.00	143.50	185.25	182.25	169.50	122.25	112.50	112.50	9,999.00	9,999.00
200	9,999.00	9,999.00	9,999.00	230.75	230.75	149.25	244.50	137.75	115.50	171.75	181.00	203.75	199.25	162.25	162.25	9,999.00	9,999.00
240	9,999.00	9,999.00	9,999.00	177.50	177.50	153.50	186.75	198.50	216.25	208.75	177.25	174.50	133.75	104.50	104.50	9,999.00	9,999.00
280	9,999.00	9,999.00	9,999.00	152.75	152.75	125.00	156.00	179.00	186.50	197.00	195.00	178.25	195.00	177.00	177.00	9,999.00	9,999.00
320	9,999.00	9,999.00	9,999.00	112.75	112.75	55.25	143.25	165.75	177.00	179.25	189.25	183.25	177.50	174.00	174.00	9,999.00	9,999.00
360	9,999.00	9,999.00	9,999.00	88.50	88.50	95.00	76.25	129.75	124.00	158.50	157.00	180.00	175.25	166.75	166.75	9,999.00	9,999.00
400	9,999.00	9,999.00	9,999.00	34.00	34.00	48.00	94.00	136.00	125.50	154.25	157.25	184.75	164.50	149.00	149.00	9,999.00	9,999.00
440	9,999.00	9,999.00	9,999.00	31.00	31.00	47.25	63.00	98.25	82.25	88.00	65.50	126.25	149.75	144.25	144.25	9,999.00	9,999.00
480	9,999.00	9,999.00	9,999.00	31.00	31.00	32.50	32.50	48.00	58.50	80.00	91.50	120.50	115.75	130.00	144.25	9,999.00	9,999.00
520	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	32.50	37.50	42.25	50.25	80.00	88.75	86.00	121.50	121.50	9,999.00	9,999.00	9,999.00
560	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	42.25	42.25	42.25	9,999.00	86.00	86.00	121.50	121.50	9,999.00	9,999.00	9,999.00
640	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
800	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00

**Description:** Crankshaft decel threshold while in SCD mode. Thresholds are a function of rpm and % engine Load.

**Notes:** KtMISF\_dt\_SCD\_IdleMode

Note: Misfire's Load term is %, but not PID\$04. PID \$04 is not robust to temperature and altitude shifts. (especially decel and jerk thresholds since they track actual air trapped in cylinder)

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
7	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
9	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
11	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
13	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
15	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
17	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
19	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
29	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
33	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
38	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
42	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
48	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
54	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
60	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767



**Description:** Crankshaft jerk threshold while in SCD mode. Thresholds are a function of rpm and % engine Load.

**Notes:** KtMISF\_ddt\_SCD\_IdleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
7	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
9	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
11	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
13	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
15	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
17	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
19	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
29	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
33	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
38	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
42	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
48	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
54	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
60	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**Description:** Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

**Notes:** KtMISF\_dt\_SCD\_OffIdleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
7	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
9	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
11	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
13	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
15	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
17	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
19	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
29	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
33	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
38	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
42	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
48	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
54	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
61	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**Description:** Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

**Notes:** KtMISF\_ddt\_SCD\_OffIdleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
7	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
9	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
11	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
13	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
15	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
17	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
19	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
29	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
33	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
38	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
42	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
48	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
54	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
61	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

## 12 OBDG05A Engine Diagnostics

**Description:** Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

**Notes:** KtMSFD\_dt\_IdleCylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
7	4,500	4,500	4,000	1,700	1,200	800	600	450	300	175	75	80	75
9	4,500	4,500	4,900	2,000	1,300	800	450	425	300	175	100	82	75
11	4,500	4,500	4,900	2,000	1,600	800	450	425	300	175	100	95	95
12	4,500	4,500	4,900	2,000	1,600	900	550	500	300	175	100	100	80
13	4,500	4,500	4,900	2,000	1,600	1,200	800	500	300	175	100	120	80
15	4,500	4,500	4,000	1,700	1,600	1,500	950	500	350	225	125	120	90
17	4,500	4,500	4,000	1,700	1,500	1,500	1,100	1,000	450	225	150	130	100
19	4,500	4,500	4,000	1,700	1,500	1,500	1,100	1,000	450	250	175	150	120
22	4,500	4,500	4,000	1,700	1,500	1,600	1,100	1,000	550	450	275	175	120
25	4,500	4,500	4,000	2,150	1,500	1,600	1,100	1,000	750	700	500	200	140
29	4,500	4,500	4,000	2,400	1,500	1,600	1,100	1,000	900	750	500	240	150
33	4,500	4,500	4,500	3,000	1,800	1,800	1,100	1,000	900	750	500	275	200
38	4,500	4,500	4,500	3,500	2,000	1,800	1,100	1,000	900	750	500	300	200
42	5,000	5,000	5,000	4,000	3,000	2,500	1,500	1,400	1,000	750	500	350	210
48	5,500	5,500	5,500	4,500	3,500	3,000	2,500	2,000	1,400	750	500	350	260
54	6,000	6,000	6,000	5,000	4,000	3,500	2,500	2,500	1,600	750	500	400	300
60	6,500	6,500	6,500	5,500	4,500	4,000	3,000	3,000	2,000	750	600	450	350

## 12 OBDG05A Engine Diagnostics

## MAIN SECTION 1 OF 1 SECTION

**Description:** Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

**Notes:** KtMSFD\_ddt\_IdleCylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
7	4,500	4,500	4,000	1,600	1,300	800	600	840	400	300	175	125	105
9	4,500	4,500	4,000	2,000	1,300	800	600	450	450	300	175	125	105
11	4,500	4,500	4,900	2,000	1,600	800	800	500	475	300	200	130	130
12	4,500	4,500	4,900	2,000	1,600	1,000	800	575	475	300	200	130	120
13	4,500	4,500	4,900	2,000	1,600	1,300	1,200	575	400	300	200	130	110
15	4,500	4,500	4,000	1,800	1,600	1,500	1,200	575	450	375	200	145	110
17	4,500	4,500	4,000	2,100	1,500	1,500	1,200	700	600	400	225	170	125
19	4,500	4,500	4,000	2,200	2,000	1,500	1,200	1,000	600	450	275	200	175
22	4,500	4,500	4,000	2,500	2,100	1,800	1,300	1,000	750	500	310	225	200
25	4,500	4,500	4,000	2,500	2,100	2,500	1,300	1,200	1,050	750	525	275	250
29	4,500	4,500	4,000	3,400	2,600	3,000	1,300	1,200	1,050	750	525	325	250
33	5,500	5,500	5,500	4,000	3,500	3,800	1,600	1,300	1,050	750	525	400	300
38	6,000	6,000	6,000	4,500	3,500	3,800	1,800	1,500	1,050	750	550	500	350
42	8,000	8,000	8,000	5,000	4,000	4,000	2,400	2,000	1,400	750	625	500	400
48	9,000	9,000	9,000	5,500	5,000	5,000	3,000	2,500	2,000	800	700	650	500
54	9,000	9,000	9,000	6,000	5,500	5,500	3,500	3,000	2,200	1,200	750	650	600
60	9,500	9,500	9,500	6,500	6,000	6,000	4,000	3,500	2,600	1,200	800	700	650

## 12 OBDG05A Engine Diagnostics

**Description:** Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

**Notes:** KtMISF\_CylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
7	1,800	1,800	1,800	1,400	1,150	800	575	500	280	165	125	80	75	70	30	20	20	20	12	22	12	13	11	10	8	7
9	1,800	1,800	1,800	1,400	1,150	800	575	525	300	170	125	82	75	70	40	25	25	22	12	10	11	12	7	10	8	7
11	1,800	1,800	1,800	1,600	1,150	800	575	525	375	175	125	95	95	82	45	30	28	28	13	10	10	10	8	7	8	7
12	1,800	1,800	1,800	1,600	1,150	850	600	550	375	200	125	100	80	75	45	40	30	28	15	11	9	7	8	7	7	7
13	1,800	1,800	1,800	1,600	1,200	900	650	550	400	200	150	120	80	75	45	40	30	28	17	11	9	6	8	7	7	7
15	1,800	1,800	1,800	1,600	1,300	1,050	650	550	400	250	160	120	90	75	45	40	30	30	19	12	9	7	8	7	7	7
17	1,800	1,800	1,800	2,000	1,500	1,100	825	550	400	275	200	130	100	75	50	50	35	30	23	12	10	8	8	7	7	7
19	1,800	1,800	1,800	2,200	1,700	1,250	900	600	500	300	225	150	120	75	65	60	45	40	24	15	12	9	8	7	7	7
22	1,800	1,800	1,800	2,300	1,900	1,500	1,100	700	600	350	225	175	120	100	75	60	50	40	25	17	13	10	8	7	7	7
25	3,500	3,500	3,500	2,500	1,900	1,600	1,100	800	600	350	275	200	140	120	90	65	55	50	30	19	16	10	8	8	7	7
29	3,500	3,500	3,500	3,000	2,200	1,800	1,200	900	700	450	300	240	150	140	100	85	60	55	32	22	18	12	9	8	7	7
33	4,500	4,500	4,500	3,000	2,800	2,300	1,400	1,000	700	500	300	275	200	150	100	85	70	60	35	25	18	14	10	9	7	7
38	4,500	4,500	4,500	3,500	3,000	2,400	1,500	1,100	800	650	350	300	200	170	120	100	80	70	45	27	22	16	12	10	7	7
42	5,000	5,000	5,000	4,000	3,500	2,500	1,800	1,400	1,000	700	375	350	210	170	135	125	90	75	45	35	25	18	13	12	8	8
48	5,500	5,500	5,500	4,500	3,500	3,000	2,500	2,000	1,400	700	500	350	260	200	180	150	90	75	50	40	26	19	15	13	9	9
54	6,000	6,000	6,000	5,000	4,000	3,500	2,500	2,500	1,600	700	500	400	300	220	190	150	115	100	70	45	32	22	18	14	14	14
61	6,500	6,500	6,500	5,500	4,500	4,000	3,000	3,000	2,000	800	600	450	350	275	200	175	135	125	80	65	35	25	22	16	15	15

12 OBDG05A Engine Diagnostics

**Description:** Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

**Notes:** KtMISF\_ddt\_CylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	
7	1,400	1,400	1,400	1,400	1,200	800	600	550	350	250	175	125	105	90	55	40	35	30	22	22	13	13	11	10	12	12	
9	1,400	1,400	1,400	1,400	1,200	800	600	550	400	225	175	125	105	95	60	45	35	30	20	14	14	12	10	10	12	12	
11	1,500	1,500	1,500	1,500	1,200	825	800	550	475	300	200	130	130	110	65	45	40	36	23	16	14	10	10	10	10	11	11
12	1,800	1,800	1,800	1,500	1,200	900	800	575	475	300	200	130	120	110	65	45	40	36	24	18	14	11	10	10	10	11	11
13	1,800	1,800	1,800	1,500	1,200	1,000	800	575	500	300	200	130	110	110	65	50	45	36	27	20	14	11	10	10	10	11	11
15	1,800	1,800	1,800	1,600	1,400	1,300	800	575	500	300	200	145	110	110	80	75	50	40	27	22	15	12	10	10	10	11	11
17	1,800	1,800	1,800	2,100	1,550	1,300	800	700	600	300	225	170	125	110	90	75	50	40	30	24	18	13	10	11	10	10	
19	2,000	2,000	2,000	2,200	2,000	1,300	1,000	1,000	600	450	275	200	175	135	100	95	60	60	30	27	19	15	12	11	10	10	
22	2,400	2,400	2,400	2,500	2,100	1,800	1,300	1,000	750	500	310	225	200	150	140	115	80	70	35	27	21	17	13	11	10	10	
25	3,800	3,800	3,800	2,500	2,100	2,500	1,300	1,300	1,000	800	475	275	250	200	180	125	100	75	45	35	22	18	16	13	10	10	
29	4,000	4,000	4,000	3,400	2,600	3,000	1,300	1,300	1,200	800	475	325	250	225	200	140	125	85	55	40	28	20	20	13	11	11	
33	5,500	5,500	5,500	4,000	3,500	3,800	1,600	1,400	1,200	800	500	400	300	250	200	155	135	100	65	50	34	23	22	13	13	13	
38	6,000	6,000	6,000	4,500	3,500	3,800	1,800	1,500	1,200	1,200	525	500	350	350	225	180	155	125	70	55	39	27	24	14	14	14	
42	8,000	8,000	8,000	5,000	4,000	4,000	2,400	2,000	1,400	1,200	625	500	400	350	300	200	170	135	75	65	43	29	24	16	16	16	
48	9,000	9,000	9,000	5,500	5,000	5,000	3,000	2,500	2,000	1,200	700	650	500	400	300	225	190	140	85	75	50	35	25	18	20	20	
54	9,000	9,000	9,000	6,000	5,500	5,500	3,500	3,000	2,200	1,200	750	650	600	400	350	300	225	175	110	85	55	55	32	22	25	25	
61	9,500	9,500	9,500	6,500	6,000	6,000	4,000	3,500	2,600	1,200	800	700	650	450	350	300	250	200	150	95	70	55	36	25	27	27	

12 OBDG05A Engine Diagnostics

**Description:** Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

**Notes:** KtMISF\_RevolutionMode

y/x	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
7	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	23	20	15	11	10	10
9	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	26	20	15	14	11	11
11	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32	24	17	14	11	11
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	34	26	17	17	13	13
13	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	40	30	22	18	15	15
15	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	45	35	25	20	16	16
17	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	50	38	25	22	17	17
19	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	55	40	30	25	20	20
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	60	50	35	30	24	22
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	70	50	40	30	26	25
29	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	80	60	45	40	30	27
33	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	90	70	50	40	35	30
38	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	100	80	60	50	35	35
42	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	115	90	70	55	45	40
48	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	120	100	80	60	50	45
54	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	130	110	90	70	55	50
61	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	140	110	100	80	65	60



12 OBDG05A Engine Diagnostics

MAIN SECTION  
1 OF 1 SECTION

**Description:** Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

**Notes:** KtMISF\_DoDCylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	
0	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
13	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
19	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
31	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
38	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
44	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
50	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
56	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
63	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
69	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
75	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
81	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
88	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
94	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
100	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**Description:** %air load that represents Zero Brake torque along the Neutral rev line. The Zero torque threshold is adjusted for Baro via P0300\_ZeroTorqueBaro

**Notes:** KtMISF\_ZeroTorqSpd

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
1	12.00	10.00	8.50	7.50	7.50	7.50	7.50	7.50	7.50	7.50	7.50	8.00	8.00	8.00	8.00	8.00	8.00	8.50	10.87	13.24	15.61	17.98	20.35	22.72	25.09	27.46

**Description:** adjusts zero torque for altitude

**Notes:** KtMSFD\_K\_ZeroTorqBaro

y/x	65	70	75	80	85	90	95	100	105
1	0.82	0.85	0.88	0.90	0.93	0.95	0.97	1.00	1.03

**Description:** Zero torque engine load while in Active Fuel Management

**Notes:** KtMSFD\_ZeroTorqDoD

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
1	12.00	10.00	8.50	7.50	7.50	7.50	7.50	7.50	7.50	7.50	7.50	8.00	8.00	8.00	8.00	8.00	8.00	8.50	10.87	13.24	15.61	17.98	20.35	22.72	25.09	27.46

**Description:** Catalyst Damaging Misfire Percentage" Table whenever secondary conditions are met.

**Notes:** KtMSFD\_Pct\_CatalystMisfire

y/x	0	1,000	2,000	3,000	4,000	5,000	6,000	7,000
0	22.1	22.1	19.6	16.6	4.6	4.6	4.6	4.6
10	22.1	22.1	19.6	16.6	4.6	4.6	4.6	4.6
20	22.1	22.1	19.6	16.6	4.6	4.6	4.6	4.6
30	19.6	19.6	16.6	11.6	4.6	4.6	4.6	4.6
40	15.6	15.6	13.6	9.6	4.6	4.6	4.6	4.6
50	13.6	13.6	8.6	4.6	4.6	4.6	4.6	4.6
60	4.6	4.6	4.6	4.6	4.6	4.6	4.6	4.6
70	4.6	4.6	4.6	4.6	4.6	4.6	4.6	4.6
80	4.6	4.6	4.6	4.6	4.6	4.6	4.6	4.6
90	4.6	4.6	4.6	4.6	4.6	4.6	4.6	4.6
100	4.6	4.6	4.6	4.6	4.6	4.6	4.6	4.6

**Description:** Only used if Rough Road source = TOSS: dispersion value on Transmission Output Speed Sensor above which rough road is indicated present

**Notes:** KtRRDI\_a\_RoughRoadThresh

y/x	600	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000
100	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
200	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
300	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
400	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
500	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
600	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
700	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
800	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
900	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,000	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,100	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,200	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,300	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,400	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

**Description:** Only used if Wheel speed from ABS is used. If difference between wheel speed readings is larger than this limit, rough road is present

**Notes:** KtRRDI\_a\_WhlSpdRoughRoadLim

y/x	0	12	24	36	48	60	72	85	97	109	121	133	145	157	169	181	193
1	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05

**Description:** Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Cylinder Mode Equation)

**Notes:** KaMSFD\_Cnt\_CylAbnormal

y/x	0	1	2	3	4	5	6	7	8
1	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00



**Description:** Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (SCD Mode Equation)

**Notes:** KaMSFD\_Cnt\_SCD\_CylAbnormal

y/x	0	1	2	3	4	5	6	7	8
1	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00

**Description:** Abnormal Rev Mode Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Rev Mode Equation)

**Notes:** KaMSFD\_Cnt\_RevAbnormal

y/x	0	1	2	3	4	5	6	7	8
1	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00

**Description:** Crankshaft should return to normal after the misfire. If crankshaft snap value after single isolated misfire being evaluated is larger than the misfire's Jerk threshold times this multiplier, its not a real misfire.

**Notes:** KtMSFD\_K\_SCD\_MinPttrnRecogMult

y/x	0	1,000	2,000	3,000	4,000	5,000	6,000	7,000	8,000
1	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85

**Description:** Crankshaft should return to normal after the misfire. If crankshaft snap value after the misfire being evaluated is larger than the misfire's Jerk threshold times this multiplier, its not a real misfire. However, if random misfire occurs every engine cycle, more noise is allowed to be considered "normal" since the crankshaft does not have time to fully return to normal before the next misfire occurs.

**Notes:** KtMSFD\_K\_SCD\_MaxPptrnRecogMult

y/x	0	1,000	2,000	3,000	4,000	5,000	6,000	7,000	8,000
1	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00

**Description:** Driveline Ring Filter  
 After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

**Notes:** KaMSFD\_Cnt\_RingFilter

y/x	0	1	2	3	4	5	6	7	8
1	7.00	7.00	7.00	7.00	7.00	7.00	7.00	7.00	7.00

**Description:** Number of Normals for the Driveline Ring Filter  
After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

**Notes:** KaMSFD\_Cnt\_NumOfNormalsFil

y/x	0	1	2	3	4	5	6	7	8
1	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00

<b>Description:</b> Engine OverSpeed Limit versus gear						
<b>Notes:</b> KaEOSC_n_EngOvrspdLimitGear						
<b>P0300 Engine OverSpeed Limit - Part 1</b>						
y/x	CeTGRR_e_TransGr1	CeTGRR_e_TransGr2	CeTGRR_e_TransGr3	CeTGRR_e_TransGr4	CeTGRR_e_TransGr5	CeTGRR_e_TransGr6
1	7,000	7,000	7,000	7,000	7,000	7,000
<b>P0300 Engine OverSpeed Limit - Part 2</b>						
y/x	CeTGRR_e_TransGrEVT 1	CeTGRR_e_TransGrEVT 2	CeTGRR_e_TransGrNeut	CeTGRR_e_TransGrRvrs	CeTGRR_e_TransGrPark	
1	7,000	7,000	4,000	7,000	4,000	

Description: P00C6

Notes:

y/x	-40	-32	-24	-16	-8	0	8	16	20	24	32	40	48	64	80	96	112
0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
13	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
25	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
38	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
50	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
63	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
75	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
88	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
100	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5



Description: P00C6

Notes:

y/x	-40	-32	-24	-16	-8	0	8	16	20	24	32	40	48	64	80	96	112
0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
13	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
25	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
38	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
50	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
63	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
75	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
88	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
100	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

Description: P00C6

Notes:

y/x	-40	-32	-24	-16	-8	0	8	16	20	24	32	40	48	64	80	96	112
0	6.0	6.0	6.0	4.0	3.0	1.0	0.8	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7
13	6.0	6.0	6.0	4.0	3.0	1.0	0.8	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7
25	6.0	6.0	6.0	4.0	3.0	1.0	0.8	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7
38	7.0	7.0	7.0	8.0	4.0	2.0	0.8	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7
50	8.0	8.0	8.0	10.0	6.0	6.0	2.8	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7
63	3.0	3.0	6.0	10.0	6.0	6.0	3.0	1.9	1.9	1.9	1.9	1.9	1.9	1.9	1.9	1.9	1.9
75	3.0	3.0	6.0	10.0	6.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
88	3.0	3.0	6.0	10.0	6.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
100	3.0	3.0	6.0	10.0	6.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0

Description P00C6																	
otes																	
y/x	-40	-32	-24	-16	-8	0	8	16	20	24	32	40	48	64	80	96	112
1	5.0	5.0	5.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0

**Description:** P0089,P163A,P228C,P228D,P0191

**Notes:**

y/x	-30	-20	-10	0	10	20	80	100	110
1	30.0	30.0	30.0	10.0	10.0	10.0	20.0	30.0	30.0

**Description:** P0191

**Notes:**

y/x	-30	-20	-10	0	10	20	80	100	110
1	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

Description: P0191

Notes:

y/x	0	13	25	38	50	63	75	88	100
65	240.0	240.0	240.0	240.0	240.0	240.0	240.0	240.0	240.0
70	240.0	240.0	240.0	240.0	240.0	240.0	240.0	240.0	240.0
75	230.0	230.0	230.0	230.0	230.0	230.0	230.0	230.0	230.0
80	220.0	220.0	220.0	220.0	220.0	220.0	220.0	220.0	220.0
85	210.0	210.0	210.0	210.0	210.0	210.0	210.0	210.0	210.0
90	200.0	200.0	200.0	200.0	200.0	200.0	200.0	200.0	200.0
95	190.0	190.0	190.0	190.0	190.0	190.0	190.0	190.0	190.0
100	180.0	180.0	180.0	180.0	180.0	180.0	180.0	180.0	180.0
105	180.0	180.0	180.0	180.0	180.0	180.0	180.0	180.0	180.0

**Description:** KtAIRD\_dp\_SAI\_SL\_ThrshBank1: Bank 1 SAI Flow (Phase 1) Test Average String Length failure threshold versus MAF (g/sec).

**Notes:**

y/x	0.0	3.0	6.0	9.0	12.0	15.0	18.0	21.0	24.0	27.0	30.0	33.0	36.0	39.0	42.0	45.0	48.0
1.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

**Description:** KtAIRD\_dp\_SAI\_SL\_ThrshBank2: Bank 2 SAI Flow (Phase 1) Test Average String Length failure threshold versus MAF (g/sec).

**Notes:** For dual Bank SAI systems only.

y/x	0.0	3.0	6.0	9.0	12.0	15.0	18.0	21.0	24.0	27.0	30.0	33.0	36.0	39.0	42.0	45.0	48.0
1.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0



**Description:** KtAIRD\_K\_SAI\_TstBaroDsbl: SAI Flow (Phase 1) Test baro weight factor.

**Notes:** Axis is atmospheric pressure (kPa)

y/x	40	50	60	70	80	90	100	110	120
1	0.0	0.0	0.5	1.0	1.0	1.0	1.0	1.0	0.0

**Description:** KtAIRD\_K\_SAI\_TstMAF\_Dsbl: SAI Flow (Phase 1) Test MAF weight factor.

**Notes:** Axis is Mass Airflow (g/sec).

y/x	0.0	3.0	6.0	9.0	12.0	15.0	18.0	21.0	24.0	27.0	30.0	33.0	36.0	39.0	42.0	45.0	48.0
1.0	0.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	0.5	0.0	0.0	0.0	0.0	0.0

**Description:** KtAIRD\_K\_SAI\_TstVoltDsbl: SAI Flow (Phase 1) Test system voltage weight factor.

**Notes:** Axis is system voltage (V).

y/x	5.0	6.0	7.0	8.0	9.0	10.0	11.0	12.0	13.0	14.0	15.0	16.0	17.0	18.0	19.0	20.0	21.0
1.0	0.0	0.0	0.0	0.0	0.0	0.5	0.8	1.0	1.0	1.0	1.0	1.0	0.8	0.5	0.5	0.5	0.5

**Description:** KtAIRD\_K\_SAI\_TstTempDsbl: SAI Flow (Phase 1) Test ambient temperature weight factor.

**Notes:** Axis is Ambient (IAT) Temp (C).

y/x	-30	-20	-10	0	10	20	30	40	50
1	0.0	0.0	0.0	0.5	1.0	1.0	1.0	1.0	1.0

**Description:** KtAIRD\_K\_APPD\_BaroQlty: The AIR Pressure Sensor Test quality factor based on the distance traveled since the last unthrottled ambient pressure update.

**Notes:** P2436 is applicable on dual valve applications only. Axis is distance traveled from last Baro update in Km (1Km = 0.62 Miles).

y/x	0.0	2.0	4.0	6.0	8.0	10.0	12.0	14.0	16.0	18.0	20.0	22.0	24.0	26.0	28.0	30.0	32.0
1.0	1.0	0.8	0.5	0.3	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

**Description:** KaAIRD\_p\_VlvTstPresErrMin[CeAIRR\_e\_PresSnsrOne]: Sensor 1 minimum average pressure error (kPa) threshold for the valve-shut (Phase 2) test .

**Notes:** Axis is Conditional Test Weight Time in seconds.

y/x	0	1	2	3	4	5	6	7	8
1	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0

**Description:** KaAIRD\_p\_VlvTstPresErrMin[CeAIRR\_e\_PresSnsrTwo]: Sensor 2 minimum average pressure error (kPa) threshold for the valve-shut (Phase 2) test .

**Notes:** For dual sensor SAI systems only. Axis is Conditional Test Weight Time in seconds.

y/x	0	1	2	3	4	5	6	7	8
1	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0

**Description:** KtAIRD\_K\_VlvTstBaroDsbl: Ambient pressure component of the conditional test weight for the valve-shut (Phase 2) test .

**Notes:** Axis is ambient pressure (kPa).

y/x	40	50	60	70	80	90	100	110	120
1	0.0	0.0	0.5	1.0	1.0	1.0	1.0	1.0	0.0



**Description:** KtAIRD\_K\_VlvTstMAF\_Dsblid: Mass Airflow (MAF) component of the conditional test weight for the valve-shut (Phase 2) test.

**Notes:**

y/x	0.0	3.0	6.0	9.0	12.0	15.0	18.0	21.0	24.0	27.0	30.0	33.0	36.0	39.0	42.0	45.0	48.0
1.0	0.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	0.5	0.0	0.0	0.0	0.0	0.0

**Description:** KtAIRD\_K\_VlvTstVoltDsbl: System Voltage component of the conditional test weight for the valve-shut (Phase 2) test.

**Notes:** Axis is system volts (V).

y/x	5.0	6.0	7.0	8.0	9.0	10.0	11.0	12.0	13.0	14.0	15.0	16.0	17.0	18.0	19.0	20.0	21.0
1.0	0.0	0.0	0.0	0.0	0.0	0.5	0.8	1.0	1.0	1.0	1.0	1.0	0.8	0.5	0.5	0.5	0.5

Description: tAIRD\_ \_VI TstTempDsbl: Ambient Temperature component of the conditional test eig t ort e al e-s ut (P ase 2) test.

Notes: A is is ambient temperature (IAT) in Deg C.

y	-30	-20	-10	0	10	20	30	40	50
1	0.0	0.0	0.0	0.5	1.0	1.0	1.0	1.0	1.0

**Description:** KaAIRD\_p\_PmpTstPres rr ax eAIRR\_e\_Pres nsr ne : ensor 1 maximum average pressure error threshold for the pump-off (Phase ) test.

**Notes:** Axis is onditional Test eight Time in seconds.

y/x	0	1	2	3	4	5	6	7	8
1	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5

**Description:** KaAIRD\_p\_PmpTstPresErrMax[CeAIRR\_e\_PresSnsrTwo]: Sensor 2 maximum average pressure error threshold for the pump-off (Phase 3) test.

**Notes:** For dual sensor SAI systems only. Axis is Conditional Test Weight Time in seconds.

y/x	0	1	2	3	4	5	6	7	8
1	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5

**Description:** EOT Sensor Cold Start Fast Fail Threshold

**Notes:** X Axis is defined as PowerUp Coolant Temperature

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	80.0	80.0	80.0	60.0	60.0	40.0	40.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0

Description:

Notes:

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	15,000	14,000	13,000	12,000	11,000	10,000	9,000	8,000	7,000	6,000	5,000	4,000	5,000	4,000	3,000	3,000	3,000

**Description:** RPM\_Weighting\_Factor\_X\_Axis

**Notes:** Engine RPM Axis for KtEOPD\_r\_EngSpdWeight

y/x	1	2	3	4	5	6	7	8	9
1	0	500	900	1,000	1,500	1,750	2,000	3,500	4,000



**Description:** RPM\_Weighting\_Factor

**Notes:** X axis is Engine RPM defined by KnEOPD\_n\_EngSpdFilteredBpt

y/x	0	500	900	1,000	1,500	1,750	2,000	3,500	4,000
1	0.00	0.00	0.00	0.45	0.45	0.45	0.46	0.44	0.00

**Description:** Oil\_Temp\_Weighting\_Factor\_X\_Axis

**Notes:**

y/x	1	2	3	4	5	6	7	8	9
1	-40	40	60	80	90	100	120	130	140

**Description:** Oil\_Temp\_Weighting\_Factor

**Notes:** X axis is Oil Temperature defined by KnEOPD\_T\_EngFilteredBpt

y/x	-40	40	60	80	90	100	120	130	140
1	0.58	0.70	0.70	0.70	0.70	0.70	0.70	0.70	0.00

**Description:** Eng\_Load\_Stability\_Weighting\_Factor\_X\_Axis

**Notes:**

y/x	1	2	3	4	5	6	7	8	9
1	0	5	10	20	30	50	100	200	399

**Description:** Eng\_Load\_Stability\_Weighting\_Factor

**Notes:** X Axis is Engine Load Stability defined by KnEOPD\_m\_EngLoadStabilityBpt

y/x	0	5	10	20	30	50	100	200	399
1	1.00	1.00	0.50	0.30	0.10	0.00	0.00	0.00	0.00

**Description:** Oil\_Pressure\_Pred\_Weighting\_Factor\_X\_Axis

**Notes:**

y/x	1	2	3	4	5	6	7	8	9
1	0	170	250	275	360	375	400	500	600

**Description:** Oil\_Pressure\_Pred\_Weighting\_Factor

**Notes:** X Axis is Predicted Oil Pressure defined by KnEOPD\_p\_EngOilPredictedBpt

y/x	0	170	250	275	360	375	400	500	600
1	0.00	0.00	0.10	1.00	1.00	1.00	1.00	0.86	0.00

**Description:** Vehicle Speed Axis

**Notes:**

y/x	1	2	3	4	5	6	7	8	9
1	0	20	40	60	80	100	120	140	160



**Description:** Ambient\_Temperature\_Axis

**Notes:**

y/x	1	2	3	4	5	6	7	8	9
1	-30	-15	0	15	30	45	60	75	90

**Description:** AC High Side Pressure Sensor Sensor Engage Test Predicted Delta Pressure

**Notes:** X Axis is defined by KnACCD\_T\_HSPRat\_EngageTstAmb and Y Axis is defined by KnACCD\_v\_HSPRat\_EngageTstVehSpd

y/x	-30	-15	0	15	30	45	60	75	90
0	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	100.00
20	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	100.00
40	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	100.00
60	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	100.00
80	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	100.00
100	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	100.00
120	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	100.00
140	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	100.00
160	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	100.00

**Description:** Delta\_Predicted\_Weighting\_Factor

**Notes:** X Axis is defined by KnACCD\_T\_HSPRat\_EngageTstAmb and Y Axis is defined by KnACCD\_v\_HSPRat\_EngageTstVehSpd

y/x	-30	-15	0	15	30	45	60	75	90
0	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
20	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
40	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
60	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
80	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
100	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
120	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
140	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
160	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998

**Description:** Coolant\_Weighting\_Factor\_X\_Axis

**Notes:**

y/x	1	2	3	4	5	6	7	8	9
1	-30	-10	10	30	50	70	90	110	130

**Description:** Coolant\_Weighting\_Factor

**Notes:** X Axis is Engine Coolant defined by KnACCD\_T\_HSPRat\_EngageTstCool

y/x	-30	-10	10	30	50	70	90	110	130
1	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000

**Description:** Ambient Temperature Axis for the On Test

**Notes:**

y/x	1	2	3	4	5
1	-20	0	20	60	100

**Description:** AC High Side Pressure Sensor Rationality On Test Threshold

**Notes:** X Axis is defined by KnACCD\_T\_HSPRat\_OnTestPresMin

y/x	-20	0	20	60	100
1	300.0	350.0	400.0	450.0	500.0

**Description:** FanSpeed\_Weighting\_Factor\_X\_Axis

**Notes:**

y/x	1	2	3	4	5	6	7	8	9
1	0	13	25	38	50	63	75	88	100



**Description:** FanSpeed\_Weighting\_Factor

**Notes:** X Axis is Fan Speed as desfined by KnACCD\_Pct\_HSPRat\_EngageTestFan

y/x	0	13	25	38	50	63	75	88	100
1	1	1	1	1	1	1	1	1	1

**Description:** Ambient Temperature Axis for the Off Test

**Notes:**

y/x	1	2	3	4	5
1	-20	0	20	60	100

**Description:** AC High Side Pressure Sensor Rationality Off Test Threshold

**Notes:** X Axis is defined by KnACCD\_T\_HSPRat\_OffTestPresMax

y/x	-20	0	20	60	100
1	300	350	400	450	500

**Description:** Abnormal Noise Threshold

**Notes:** Used for P0324, P0326 and P0331; X-axis = Engine Air Flow (mg per cylinder) see "APC Breakpoints" (KnKNKD\_m\_APC\_Axis) table; Y-axis = Engine Speed (RPM)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.033	0.035	0.034	0.038	0.044	0.050	0.060	0.061	0.071	0.072	0.082	0.084	0.084	0.084	0.084	0.084	0.084

**Description:** KtKNKD\_k\_OpenMin20K: When using the 20 kHz method (KtKNKD\_e\_OpenMethod = 1), to set an Open Circuit DTC (P0325 or P0330) the filtered diagnostic FFT Output must be greater than KtKNKD\_k\_OpenMin20K and less than KtKNKD\_k\_OpenMax20K.

**Notes:** X-axis = Engine Speed (RPM)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	2.2637	2.3027	2.2910	2.2324	2.1348	2.0039	1.8457	1.6680	1.4766	1.2754	1.0742	0.8770	0.6914	0.5234	0.3789	0.2637	0.1855

**Description:** KtKNKD\_k\_OpenMax20K: When using the 20 kHz method (KtKNKD\_e\_OpenMethod = 1), to set an Open Circuit DTC (P0325 or P0330) the filtered diagnostic FFT Output must be greater than KtKNKD\_k\_OpenMin20K and less than KtKNKD\_k\_OpenMax20K.

**Notes:** X-axis = Engine Speed (RPM)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	5.4063	5.5117	5.4961	5.3750	5.1641	4.8750	4.5254	4.1309	3.7051	3.2617	2.8203	2.3906	1.9902	1.6367	1.3398	1.1172	0.9863

**Description:** KtKNKD\_k\_OpenMinNN: When using the Normal Noise method (KtKNKD\_e\_OpenMethod = 2), to set an Open Circuit DTC (P0325 or P0330) the filtered diagnostic FFT Output must be greater than KtKNKD\_k\_OpenMinNN and less than KtKNKD\_k\_OpenMaxNN.

**Notes:** X-axis = Engine Speed (RPM)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.0000	0.0000	0.0000	0.0000	0.0078	0.0430	0.0664	0.0801	0.0859	0.0879	0.0879	0.0898	0.0957	0.1113	0.1367	0.1758	0.2305

**Description:** KtKNKD\_k\_OpenMaxNN: When using the Normal Noise method (KtKNKD\_e\_OpenMethod = 2), to set an Open Circuit DTC the filtered diagnostic FFT Output must be greater than KtKNKD\_k\_OpenMinNN and less than KtKNKD\_k\_OpenMaxNN.

**Notes:** X-axis = Engine Speed (RPM)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.0508	0.0508	0.0508	0.0508	0.0508	0.0508	0.1406	0.2031	0.2285	0.2363	0.2383	0.2500	0.2852	0.3613	0.4902	0.6895	0.9746



**Description:** KtKNKD\_k\_OpenTestCktMin: When using the 20 kHz method (KtKNKD\_e\_OpenMethod = 1), to set an OpenTestCkt DTC (P06B6 or P06B7) the filtered diagnostic FFT Output must be greater than KtKNKD\_k\_OpenTestCktMin and less than KtKNKD\_k\_OpenTestCktMax.

**Notes:** X-axis = Engine Speed (RPM)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.016	0.014	0.020	0.031	0.045	0.078	0.109	0.145	0.182	0.223	0.264	0.307	0.350	0.391	0.430	0.467	0.500

**Description:** KtKNKD\_k\_OpenTestCktMax: When using the 20 kHz method (KtKNKD\_e\_OpenMethod = 1), to set an OpenTestCkt DTC (P06B6 or P06B7) the filtered diagnostic FFT Output must be greater than KtKNKD\_k\_OpenTestCktMin and less than KtKNKD\_k\_OpenTestCktMax.

**Notes:** X-axis = Engine Speed (RPM)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.033	0.035	0.053	0.088	0.131	0.207	0.301	0.402	0.508	0.629	0.807	1.104	1.623	2.518	3.986	6.291	9.766

**Description:** P0128: Maximum Total Energy transferred to Cooling System for Ambient and Start-up ECT conditions (Primary Test)

**Notes:** Z axis is the cooling system energy failure threshold (kJ), X axis is ECT Temperature at Power up (° C)

y/x	-20	-5	10	30	45	60	75
1	2,100	1,800	1,500	1,200	900	600	300

**Description:** P0128: Maximum Total Energy transferred to Cooling System for Ambient and Start-up ECT conditions (Primary Test)

**Notes:** Z axis is the cooling system energy failure threshold (kJ), X axis is ECT Temperature at Power up (° C)

y/x	-20	-5	10	30	45	60	75
1	2,100	1,800	1,500	1,200	900	600	300

**Description:** Data is EAT Valid Conditioning Time (in seconds) and Axis is Ignition Off Time (in seconds)

**Notes:** KtEONV\_t\_IdleCondTimePreset

**P0442: Estimate of Ambient Temperature Valid Conditioning Time as a Function of Ignition Off Time - Part 1**

y/x	0	600	1,200	1,800	2,400	3,000	3,600	4,200	4,800	5,400	6,000	6,600	7,200	7,800	8,400	9,000	9,600
1	400	400	450	500	600	550	500	400	380	350	340	320	300	200	200	200	200

**P0442: Estimate of Ambient Temperature Valid Conditioning Time as a Function of Ignition Off Time - Part 2**

y/x	10,200	10,800	11,700	12,600	13,500	14,400	15,300	16,200	17,100	18,000	19,200	20,400	21,600	22,800	24,000	25,200	
1	200	200	200	200	100	100	100	100	100	100	100	100	100	100	100	100	

Description: Data is Engine Off Time Before Vehicle Off Maximum Table (in seconds) and Axis is Estimated Ambient Coolant in Deg C

Notes: KtEONV\_t\_EngOffTimeBeforeVehicleOffMax

x	-10	-4	1		13	18	24	29	35	41	46	52	58	63	69	4	80
1	44	44	44	44	68	82	105	153	320	480	480	480	480	480	480	480	480

**Description:** Data is Purge Valve Leak Test Engine Vacuum Test Time (in seconds) and Axis is Fuel Level in %

**Notes:** KtEVPD\_t\_PVLT\_EngineVacTimeCold

y/x	0	6	12	19	25	31	37	44	50	56	62	69	75	81	87	94	100
1	68	67	66	65	64	64	63	62	61	60	59	58	57	56	55	54	53

**Description:** Data is TransferPumpOnTimeLimit (in seconds) and Axis is Fuel Level in %

**Notes:** KtFLVC\_t\_XferFuelPmpOnTmLim

y/x	0	3	6	9	13	16	19	22	25	28	31	34	38	41	44	47	50	53	56	59	63	66	69	72	75	78	81	84	88	91	94	97	100	
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0



12 OBDG05A Engine Diagnostics

MAIN SECTION  
1 OF 1 SECTION

**Description:** Data is EONV Pressure Threshold in Pascals, X axis (horizontal) is fuel level in % and Y axis (vertical) is temperature in deg C

**Notes:** KtEONV\_p\_PressureThreshold

y/x	0.0000	6.2499	12.4998	18.7497	24.9996	31.2495	37.4994	43.7493	49.9992	56.2491	62.4990	68.7490	74.9989	81.2488	87.4987	93.7486	99.9985
-10.0000	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
-4.3750	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
1.2500	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
6.8750	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
12.5000	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
18.1250	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
23.7500	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
29.3750	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
35.0000	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
40.6250	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
46.2500	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
51.8750	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
57.5000	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
63.1250	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
68.7500	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
74.3750	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500
80.0000	-1.7002	-1.7002	-1.7002	-1.7002	-1.7002	-1.6084	-1.5176	-1.4258	-1.3350	-1.2432	-1.1523	-1.0605	-0.9697	-0.8779	-0.7871	-0.7500	-0.7500

**Description:** This value is needed for LowFuelConditionDiagnostic flag which is located in Fault Bundle

**Notes:** This value is needed for LowFuelConditionDiagnostic flag which is located in Fault Bundle

y/x	1
1	10.0

**Description:** This value is needed for LowFuelConditionDiagnostic flag which is located in Fault Bundle

**Notes:** This value is needed for LowFuelConditionDiagnostic flag which is located in Fault Bundle

y/x	1
1	30.0

**Description:** This value is needed for Transfer Pump is Commanded On flag which is located in Fault Bundle

**Notes:** This value is needed for Transfer Pump is Commanded On flag which is located in Fault Bundle

y/x	1
1	0.0

**Description:** This value is needed for Transfer Pump is Commanded On flag which is located in Fault Bundle

**Notes:** This value is needed for Transfer Pump is Commanded On flag which is located in Fault Bundle

y/x	1
1	0.0

**Description:** This value is needed for Transfer Pump is Commanded On flag which is located in Fault Bundle

**Notes:** This value is needed for Transfer Pump is Commanded On flag which is located in Fault Bundle

y/x	1
1	0.0

**Description:** P0133 - O2S Slow Response Bank 1 Sensor 1 "Pass/Fail Threshold table"

**Notes:** X axis is Lean to Rich response time (in sec), Please see the table below named "KnEOSD\_t\_ST\_LRC\_LimRS1" for the 17 X axis table breakpoints. Y axis is Rich to Lean response time (sec), Please see the cal table below named "KnEOSD\_t\_ST\_RLC\_LimRS1" for the 17 Y axis table breakpoints. Z axis is the pass/fail result, Note: If the cell contains a "0" then the fault is indicated, if it contains a "1" a fault is not indicated.

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
2	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
3	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
4	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
5	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
6	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
7	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
8	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
9	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
10	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
11	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
12	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
13	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
15	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

**Description:** P0153 - O2S Slow Response Bank 2 Sensor 1 "Pass/Fail Threshold table"

**Notes:** X axis is Lean to Rich response time (in sec), Please see the table below named "KnEOSD\_t\_ST\_LRC\_LimRS2" for the 17 X axis table breakpoints. Y axis is Rich to Lean response time (sec), Please see the cal table below named "KnEOSD\_t\_ST\_RLC\_LimRS2" for the 17 Y axis table breakpoints. Z axis is the pass/fail result, Note: If the cell contains a "0" then the fault is indicated, if it contains a "1" a fault is not indicated.

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
2	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
3	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
4	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
5	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
6	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
7	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
8	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
9	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
10	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
11	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
12	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
13	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
15	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0



**Description:** P1133 - O2S HC L to R Switches Limit Bank 1 Sensor 1 Threshold table

**Notes:** X axis is estimated Ethanol percentage, Please see the table below named "KnE85G\_Pct\_FFS\_CompAtEngAxis" for the 5 X axis table breakpoints. Y axis is Average airflow during the response test (gps). Z axis is the limit for L2R Half Cycle switches, Note: The cell contains the mininum switches, below which the fault is indicated.

y/x	0	20	30	50	80
0.0	31	31	31	31	31
6.3	31	31	31	31	31
12.5	31	31	31	31	31
18.8	31	31	31	31	31
25.0	31	31	31	31	31
31.3	31	31	31	31	31
37.5	31	31	31	31	31
43.8	31	31	31	31	31
50.0	31	31	31	31	31
56.3	31	31	31	31	31
62.5	31	31	31	31	31
68.8	31	31	31	31	31
75.0	31	31	31	31	31
81.3	31	31	31	31	31
87.5	31	31	31	31	31
93.8	31	31	31	31	31
100.0	31	31	31	31	31

**Description:** P1133 - O2S HC R to L Switches Limit Bank 1 Sensor 1 Threshold table

**Notes:** X axis is estimated Ethanol percentage, Please see the table below named "KnE85G\_Pct\_FFS\_CompAtEngAxis" for the 5 X axis table breakpoints. Y axis is Average airflow during the response test (gps). Z axis is the limit for R2L Half Cycle switches, Note: The cell contains the mininum switches, below which the fault is indicated.

y/x	0	20	30	50	80
0.0	31	31	31	31	31
6.3	31	31	31	31	31
12.5	31	31	31	31	31
18.8	31	31	31	31	31
25.0	31	31	31	31	31
31.3	31	31	31	31	31
37.5	31	31	31	31	31
43.8	31	31	31	31	31
50.0	31	31	31	31	31
56.3	31	31	31	31	31
62.5	31	31	31	31	31
68.8	31	31	31	31	31
75.0	31	31	31	31	31
81.3	31	31	31	31	31
87.5	31	31	31	31	31
93.8	31	31	31	31	31
100.0	31	31	31	31	31

**Description:** P1153 - O2S HC L to R Switches Limit Bank 2 Sensor 1 Threshold table

**Notes:** X axis is estimated Ethanol percentage, Please see the table below named "KnE85G\_Pct\_FFS\_CompAtEngAxis" for the 5 X axis table breakpoints. Y axis is Average airflow during the response test (gps). Z axis is the limit for L2R Half Cycle switches, Note: The cell contains the mininum switches, below which the fault is indicated.

y/x	0	20	30	50	80
0.0	31	31	31	31	31
6.3	31	31	31	31	31
12.5	31	31	31	31	31
18.8	31	31	31	31	31
25.0	31	31	31	31	31
31.3	31	31	31	31	31
37.5	31	31	31	31	31
43.8	31	31	31	31	31
50.0	31	31	31	31	31
56.3	31	31	31	31	31
62.5	31	31	31	31	31
68.8	31	31	31	31	31
75.0	31	31	31	31	31
81.3	31	31	31	31	31
87.5	31	31	31	31	31
93.8	31	31	31	31	31
100.0	31	31	31	31	31

**Description:** P1153 - O2S HC R to L Switches Limit Bank 2 Sensor 1 Threshold table

**Notes:** X axis is estimated Ethanol percentage, Please see the table below named "KnE85G\_Pct\_FFS\_CompAtEngAxis" for the 5 X axis table breakpoints. Y axis is Average airflow during the response test (gps). Z axis is the limit for R2L Half Cycle switches, Note: The cell contains the mininum switches, below which the fault is indicated.

y/x	0	20	30	50	80
0.0	31	31	31	31	31
6.3	31	31	31	31	31
12.5	31	31	31	31	31
18.8	31	31	31	31	31
25.0	31	31	31	31	31
31.3	31	31	31	31	31
37.5	31	31	31	31	31
43.8	31	31	31	31	31
50.0	31	31	31	31	31
56.3	31	31	31	31	31
62.5	31	31	31	31	31
68.8	31	31	31	31	31
75.0	31	31	31	31	31
81.3	31	31	31	31	31
87.5	31	31	31	31	31
93.8	31	31	31	31	31
100.0	31	31	31	31	31

**Description:** This Calibration is the airflow (in gps) above which the green airflow is acculmulated to expire the condition

**Notes:** The specific diagnostic (from summary table) will not be enabled until the next ignition cycle after the airflow criteria below (by sensor location) has been met:

y/x	1
1	22

**Description:** This Calibration is the acculmulated airflow (in grams) limit above which the green condition is expired

**Notes:** Note: This feature is only enabled when the vehicle is new and cannot be enabled in service

y/x	CiOXYR_O2_Bank1_Sensor1	CiOXYR_O2_Bank1_Sensor2	CiOXYR_O2_Bank2_Sensor1	CiOXYR_O2_Bank2_Sensor2
1	120,000	360,000	120,000	360,000

**Description:** X Table Axis (in sec) for P0133, L2R Reponse time breakpoints for table

**Notes:**

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.040	0.056	0.072	0.088	0.104	0.120	0.136	0.152	0.168	0.184	0.200	0.216	0.232	0.248	0.270	1.000

**Description:** Y Table Axis (in sec) for P0133, R2L Reponse time breakpoints for table

**Notes:**

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.040	0.056	0.072	0.088	0.104	0.120	0.136	0.152	0.168	0.184	0.200	0.216	0.232	0.248	0.270	1.000



**Description:** X Table Axis (in sec) for P0153, L2R Reponse time breakpoints for table

**Notes:**

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.040	0.056	0.072	0.088	0.104	0.120	0.136	0.152	0.168	0.184	0.200	0.216	0.232	0.248	0.270	1.000

**Description:** Y Table Axis (in sec) for P0153, R2L Reponse time breakpoints for table

**Notes:**

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.040	0.056	0.072	0.088	0.104	0.120	0.136	0.152	0.168	0.184	0.200	0.216	0.232	0.248	0.270	1.000

**Description:** X Table Axis for P01133, P01153 (both L2R and R2L tables)

**Notes:** Ethanol percentage breakpoints

y/x	1	2	3	4	5
1	0	20	30	50	80

<b>Bundle Name:</b> 5VoltReferenceA_FA
P0641
<b>Bundle Name:</b> 5VoltReferenceB_FA
P0651
<b>Bundle Name:</b> 5VoltReferenceMAP_OOR_Fit
P0697
<b>Bundle Name:</b> A/F Imbalance Bank1
P219A
<b>Bundle Name:</b> A/F Imbalance Bank2
P219B
<b>Bundle Name:</b> AAP_SnsrCktFP
Naturally aspirated: P2228, P2229. Turbocharged: P0237, P0238
<b>Bundle Name:</b> AAP_SnsrFA
Naturally Aspirated: P2227, P2228, P2229, P2230. Turbocharged: P0237, P0238.
<b>Bundle Name:</b> AAP_SnsrTFTKO
Naturally Aspirated: P2227, P2228, P2229, P2230. Turbocharged: P0237, P0238.
<b>Bundle Name:</b> AAP2_SnsrCktFP
P2228, P2229
<b>Bundle Name:</b> AAP2_SnsrFA
P2227, P2228, P2229, P2230
<b>Bundle Name:</b> AAP2_SnsrTFTKO
P2227, P2228, P2229, P2230
<b>Bundle Name:</b> AccCktLo_FA
P2537
<b>Bundle Name:</b> AcceleratorPedalFailure
P2122, P2123, P2127, P2128, P2138, P0697, P06A3
<b>Bundle Name:</b> ACCMLostComm
U016B
<b>Bundle Name:</b> ACFailedOnSD
See ACCM Document
<b>Bundle Name:</b> ACHighSidePressSnsrCktFA
P0532, P0533
<b>Bundle Name:</b> ACThrmlRefrigSpdVld
See ACCM Document
<b>Bundle Name:</b> AfterThrottlePressTFTKO
Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.
<b>Bundle Name:</b> AfterThrottlePressureFA
Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.

<b>Bundle Name:</b> AfterThrottleVacuumTFTKO
Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.
<b>Bundle Name:</b> AIR System FA
P0411, P2440, P2444
<b>Bundle Name:</b> AIRPumpControlCircuit FA
P0418
<b>Bundle Name:</b> AIRSystemPressureSensor FA
P2430, P2431, P2432, P2433, P2435, P2436, P2437, P2438
<b>Bundle Name:</b> AIRValveControlCircuit FA
P0412
<b>Bundle Name:</b> AmbientAirDefault
Baro Sensor Present: P2227, P2228, P2229, P2230. No Baro Sensor Present: P0101, P0102, P0103, P0106, P0107, P0108, P0111, P0112, P0113, P0114, P0121, P0122, P0123, P012B, P012C, P012D, P0222, P0223, P1221
<b>Bundle Name:</b> AmbPresDfltStatus
Baro Sensor Present: P2227, P2228, P2229, P2230. No Baro Sensor Present: P0101, P0102, P0103, P0106, P0107, P0108, P0111, P0112, P0113, P0114, P0121, P0122, P0123, P012B, P012C, P012D, P0222, P0223, P1221
<b>Bundle Name:</b> AmbPresSnsrCktFA
P2228, P2229
<b>Bundle Name:</b> AmbPresSnsrCktFP
P2228, P2229
<b>Bundle Name:</b> AnyCamPhaser_FA
P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024
<b>Bundle Name:</b> AnyCamPhaser_TFTKO
P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024
<b>Bundle Name:</b> BrakeBoosterSensorFA
P0556, P0557, P0558
<b>Bundle Name:</b> BrakeBoosterVacuumValid
P0556, P0557, P0558
<b>Bundle Name:</b> BSTR_b_ExcsvBstFA
P226B
<b>Bundle Name:</b> BSTR_b_ExcsvBstTFTKO
P226B
<b>Bundle Name:</b> BSTR_b_IC_PmpCktFA
P023A, P023C
<b>Bundle Name:</b> BSTR_b_PCA_CktFA
P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P0247, P0249, P0250
<b>Bundle Name:</b> BSTR_b_PCA_CktLoFA

P0034, P0047, P0245, P0249
<b>Bundle Name:</b> BSTR_b_PCA_CktLoTFTKO
P0034, P0047, P0245, P0249
<b>Bundle Name:</b> BSTR_b_PCA_CktTFTKO
P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P0247, P0249, P0250
<b>Bundle Name:</b> BSTR_b_PCA_FA
P0234, P0299, P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P2261, P0247, P0249, P0250
<b>Bundle Name:</b> BSTR_b_PCA_PstnSnsrFA
P003A, P2564, P2565
<b>Bundle Name:</b> BSTR_b_PCA_PstnSnsrTFTKO
P003A, P2564, P2565
<b>Bundle Name:</b> BSTR_b_PCA_TFTKO
P0234, P0299, P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P2261, P0247, P0249, P0250
<b>Bundle Name:</b> BSTR_b_PresCntrlTooHiFA
P0234
<b>Bundle Name:</b> BSTR_b_PresCntrlTooHiTFTKO
P0234
<b>Bundle Name:</b> BSTR_b_PresCntrlTooLoFA
P0299
<b>Bundle Name:</b> BSTR_b_PresCntrlTooLoTFTKO
P0299
<b>Bundle Name:</b> BSTR_b_PstnCntrlFA
P166D, P166E
<b>Bundle Name:</b> BSTR_b_PstnCntrlTooHiFA
P166E
<b>Bundle Name:</b> BSTR_b_PstnCntrlTooHiTFTKO
P166E
<b>Bundle Name:</b> BSTR_b_PstnCntrlTooLoFA
P166D
<b>Bundle Name:</b> BSTR_b_PstnCntrlTooLoTFTKO
P166D
<b>Bundle Name:</b> BSTR_b_TurboBypassCktFA
P0033, P0034, P0035, P00C0, P00C1, P00C2
<b>Bundle Name:</b> BSTR_b_TurboBypassCktTFTKO
P0033, P0034, P0035, P00C0, P00C1, P00C2
<b>Bundle Name:</b> BSTR_b_TurboBypB_CktFA
P00C0, P00C1, P00C2
<b>Bundle Name:</b> BSTR_b_TurboBypB_CktTFTKO

P00C0, P00C1, P00C2
<b>Bundle Name:</b> CamLctnExhFA
P0017, P0019, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> CamLctnIntFA
P0016, P0018, P0340, P0341, P0345, P0346
<b>Bundle Name:</b> CamSensor_FA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> CamSensor_TFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> CamSensorAnyLctnTFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> CamSensorAnyLocationFA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> CamSensorFA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> CamSensorTFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> CatalystSysEfficiencyLoB1_FA
P0420
<b>Bundle Name:</b> CatalystSysEfficiencyLoB2_FA
P0430
<b>Bundle Name:</b> ClutchPstnSnsr FA
P0806, P0807, P0808
<b>Bundle Name:</b> ClutchPstnSnsrCktHi FA
P0808
<b>Bundle Name:</b> ClutchPstnSnsrCktLo FA
P0807
<b>Bundle Name:</b> ClutchPstnSnsrNotLearned
P080A
<b>Bundle Name:</b> CommBusAOff_VICM_FA
U0073
<b>Bundle Name:</b> CommBusBOff_VICM_FA
U0074
<b>Bundle Name:</b> CoolingFanSpeedTooHigh_FA
P0495
<b>Bundle Name:</b> CrankCamCorrelationTFTKO
P0016, P0017, P0018, P0019
<b>Bundle Name:</b> CrankExhaustCamCorrelationFA

P0017, P0019
<b>Bundle Name:</b> CrankExhaustCamCorrFA
P0017, P0019
<b>Bundle Name:</b> CrankIntakeCamCorrelationFA
P0016, P0018
<b>Bundle Name:</b> CrankIntakeCamCorrFA
P0016, P0018
<b>Bundle Name:</b> CrankSensor_FA
P0335, P0336
<b>Bundle Name:</b> CrankSensor_TFTKO
P0335, P0336
<b>Bundle Name:</b> CrankSensorFA
P0335, P0336
<b>Bundle Name:</b> CrankSensorFaultActive
P0335, P0336
<b>Bundle Name:</b> CrankSensorTestFailedTKO
P0335, P0336
<b>Bundle Name:</b> CrankSensorTFTKO
P0335, P0336
<b>Bundle Name:</b> CylDeacSystemTFTKO
P3400
<b>Bundle Name:</b> CylnderDeacDriverTFTKO
P3401, P3409, P3417, P3425, P3433, P3441, P3449
<b>Bundle Name:</b> ECT_Sensor_Ckt_FA
P0117, P0118, P0119
<b>Bundle Name:</b> ECT_Sensor_Ckt_FP
P0117, P0118
<b>Bundle Name:</b> ECT_Sensor_Ckt_High_FP
P0118
<b>Bundle Name:</b> ECT_Sensor_Ckt_Low_FP
P0117
<b>Bundle Name:</b> ECT_Sensor_Ckt_TFTKO
P0117, P0118, P0119
<b>Bundle Name:</b> ECT_Sensor_Ckt_TPTKO
P0117, P0118, P0019
<b>Bundle Name:</b> ECT_Sensor_DefaultDetected
P0117, P0118, P0116, P0125
<b>Bundle Name:</b> ECT_Sensor_FA



P0117, P0118, P0116, P0125, P0128
<b>Bundle Name:</b> ECT_Sensor_Perf_FA
P0116
<b>Bundle Name:</b> ECT_Sensor_TFTKO
P0117, P0118, P0116, P0125, P0119
<b>Bundle Name:</b> EGRValve_FP
P0405, P0406, P042E
<b>Bundle Name:</b> EGRValveCircuit_FA
P0403, P0404, P0405, P0406
<b>Bundle Name:</b> EGRValveCircuit_TFTKO
P0403, P0404, P0405, P0406
<b>Bundle Name:</b> EGRValvePerformance_FA
P0401, P042E
<b>Bundle Name:</b> EGRValvePerformance_TFTKO
P0401, P042E
<b>Bundle Name:</b> ELCP_PumpCircuit_FA
P2400, P2401, P2402
<b>Bundle Name:</b> ELCP_SwitchCircuit_FA
P2418, P2419, P2420
<b>Bundle Name:</b> ELCP_Circuit_FA
P1459, P145A
<b>Bundle Name:</b> EngineMetalOvertempActive
P1258
<b>Bundle Name:</b> EngineMisfireDetected_FA
P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308
<b>Bundle Name:</b> EngineMisfireDetected_TFTKO
P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308
<b>Bundle Name:</b> EngineModeNotRunTimer_FA
P2610
<b>Bundle Name:</b> EngineModeNotRunTimerError
P2610
<b>Bundle Name:</b> EnginePowerLimited
P0068, P0122, P0123, P0222, P0223, P0606, P16F3, P1104, P2100, P2101, P2102, P2103, P160E, P160D, P0191, P0192, P0193, P00C8, P00C9
<b>Bundle Name:</b> EngineTorqueEstInaccurate
EngineMisfireDetected_FA, FuelInjectorCircuit_FA, FuelInjectorCircuit_TFTKO, FuelTrimSystemB1_FA, FuelTrimSystemB2_FA, MAF_SensorTFTKO, MAP_SensorTFTKO, EGRValuePerforamnce_FA
<b>Bundle Name:</b> EngModeNotRunTmErr
P2610

<b>Bundle Name:</b> EngOilModeledTempValid
ECT_Sensor_FA, IAT_SensorCircuitFA
<b>Bundle Name:</b> EngOilPressureSensorCktFA
P0522, P0523
<b>Bundle Name:</b> EngOilPressureSensorFA
P0521, P0522, P0523
<b>Bundle Name:</b> EngOilTempSensorCircuitFA
P0197, P0198
<b>Bundle Name:</b> Ethanol Composition Sensor FA
P0178, P0179, P2269
<b>Bundle Name:</b> EvapEmissionSystem_FA
P0455, P0446
<b>Bundle Name:</b> EvapExcessPurgePsbl_FA
Conventional fuel system, P0442, P0443, P0455, P0496
<b>Bundle Name:</b> EvapFlowDuringNonPurge_FA
P0496
<b>Bundle Name:</b> EvapPurgeSolenoidCircuit_FA
P0443
<b>Bundle Name:</b> EvapReducedPurgePsbl_FA
Only EREV sealed fuel system, P0443, P0446, P0449, P0459, P0497, P0499, P2419, P2422
<b>Bundle Name:</b> EvapSmallLeak_FA
P0442
<b>Bundle Name:</b> EvapVentSolenoidCircuit_FA
P0449
<b>Bundle Name:</b> ExhaustCamSensor_FA
P0017, P0019, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> ExhaustCamSensor_TFTKO
P0017, P0019, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> ExhaustCamSensorFA
P0017, P0019, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> ExhaustCamSensorTFTKO
P0017, P0019, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> FanOutputDriver_FA
P0480, P0481, P0482, P0691, P0692, P0693, P0694, P0695, P0696
<b>Bundle Name:</b> FHPD_b_HPC_PresErrNeg_FA
P228D
<b>Bundle Name:</b> FHPD_b_HPC_PresErrNeg_TFTKO
P228D

<b>Bundle Name:</b> FHPD_b_HPC_PresErrPos_FA
P228C
<b>Bundle Name:</b> FHPD_b_HPC_PresErrPos_TFTKO
P228C
<b>Bundle Name:</b> FHPD_b_HPC_Windup_TFTKO
P0089
<b>Bundle Name:</b> FHPD_b_HPC_Windup_FA
P0089
<b>Bundle Name:</b> FHPD_b_PumpCurr_FA
P163A
<b>Bundle Name:</b> FHPD_b_PumpCurr_TFTKO
P163A
<b>Bundle Name:</b> FHPR_b_FRP_SnsrCkt_FA
P0192, P0193
<b>Bundle Name:</b> FHPR_b_FRP_SnsrCkt_TFTKO
P0192, P0193
<b>Bundle Name:</b> FHPR_b_FRP_SnsrPerfDiag_FA
P0191
<b>Bundle Name:</b> FHPR_b_FRP_SnsrPerfDiag_TFTKO
P0191
<b>Bundle Name:</b> FHPR_b_PumpCkt_FA
P0090, P0091, P0092, P00C8, P00C9, P00CA
<b>Bundle Name:</b> FHPR_b_PumpCkt_TFTKO
P0090, P0091, P0092, P00C8, P00C9, P00CA
<b>Bundle Name:</b> FTP_SensorCircuit_FA
P0452, P0453
<b>Bundle Name:</b> FuelInjectorCircuit_FA
P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, PP0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216E, P217B, P217E, P2148, P2151, P2154, P2157, P216C, P216F, P217C, P217F, P1248, P1249, P124A, P124B, P124C, P124D, P124E, P124F
<b>Bundle Name:</b> FuelInjectorCircuit_TFTKO
P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, PP0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216E, P217B, P217E, P2148, P2151, P2154, P2157, P216C, P216F, P217C, P217F, P1248, P1249, P124A, P124B, P124C, P124D, P124E, P124F
<b>Bundle Name:</b> FuelLevelDataFault
P0461, P0462, P0463, P2066, P2067, P2068
<b>Bundle Name:</b> FuelTankPressureSnsrCkt_FA
P0452, P0453
<b>Bundle Name:</b> FuelTrimSystemB1_FA

P0171, P0172
<b>Bundle Name:</b> FuelTrimSystemB1_TFTKO
P0171, P0172
<b>Bundle Name:</b> FuelTrimSystemB2_FA
P0174, P0175
<b>Bundle Name:</b> FuelTrimSystemB2_TFTKO
P0174, P0175
<b>Bundle Name:</b> HumidityFA
P0097, P0098, P11C2, P11C3, P2227, P2228, P2229, P2230
<b>Bundle Name:</b> HumTempSnsrCktFA
P0097, P0098
<b>Bundle Name:</b> HumTempSnsrCktFP
P0097, P0098
<b>Bundle Name:</b> HumTempSnsrFA
P0096, P0097, P0098, P0099
<b>Bundle Name:</b> IAC_SystemRPM_FA
P0506, P0507
<b>Bundle Name:</b> IAT_ContCorrFA
P2199
<b>Bundle Name:</b> IAT_SensorCircuitFA
P0112, P0113
<b>Bundle Name:</b> IAT_SensorCircuitFP
P0112, P0113
<b>Bundle Name:</b> IAT_SensorCircuitTFTKO
P0112, P0113
<b>Bundle Name:</b> IAT_SensorFA
P0111, P0112, P0113, P0114
<b>Bundle Name:</b> IAT_SensorTFTKO
P0111, P0112, P0113, P0114
<b>Bundle Name:</b> IgnitionOffTimer_FA
P2610
<b>Bundle Name:</b> IgnitionOffTimeValid
P2610
<b>Bundle Name:</b> IgnitionOutputDriver_FA
P0351, P0352, P0353, P0354, P0355, P0356, P0357, P0358
<b>Bundle Name:</b> IntakeCamSensor_FA
P0016, P0018, P0340, P0341, P0345, P0346
<b>Bundle Name:</b> IntakeCamSensor_TFTKO

P0016, P0018, P0340, P0341, P0345, P0346
<b>Bundle Name:</b> IntakeCamSensorFA
P0016, P0018, P0340, P0341, P0345, P0346
<b>Bundle Name:</b> IntakeCamSensorTFTKO
P0016, P0018, P0340, P0341, P0345, P0346
<b>Bundle Name:</b> IntkCamPhaser_FA
P0010, P0011, P0020, P0021
<b>Bundle Name:</b> KS_Ckt_Perf_B1B2_FA
P0324, P0325, P0326, P0327, P0328, P0330, P0332, P0333, P06B6, P06B7
<b>Bundle Name:</b> Long Name
Short Name
<b>Bundle Name:</b> LostCommBCM_FA
U0140
<b>Bundle Name:</b> LostCommBusB_VICM_FA
U182D
<b>Bundle Name:</b> LowFuelConditionDiagnostic
Flag set to TRUE if the fuel level < KeFLVI_Pct_FuelLevelLowDiag (see supporting table for numeric value) % AND No Active DTCs: FuelLevelDataFault, P0462, P0463 for at least KeFLVI_t_FuelLevelLowTime (see supporting table for numeric value) seconds.
<b>Bundle Name:</b> MAF_SensorCircuitFA
P0102, P0103, P010C, P010D
<b>Bundle Name:</b> MAF_SensorCircuitTFTKO
P0102, P0103, P010C, P010D
<b>Bundle Name:</b> MAF_SensorFA
P0101, P0102, P0103, P010C, P010D
<b>Bundle Name:</b> MAF_SensorFP
P0102, P0103, P010C, P010D
<b>Bundle Name:</b> MAF_SensorPerfFA
P0101
<b>Bundle Name:</b> MAF_SensorPerfTFTKO
P0101
<b>Bundle Name:</b> MAF_SensorTFTKO
P0101, P0102, P0103, P010C, P010D
<b>Bundle Name:</b> MAF_SnsrCktFA
P121B, P121C
<b>Bundle Name:</b> MAF_SnsrCktTFTKO
P121B, P121C
<b>Bundle Name:</b> MAP_EngineVacuumStatus
P0106, P0107, P0108 Fault Active OR P0107, P0108 Fault Pending

<b>Bundle Name:</b> MAP_SensorCircuitFA
P0107, P0108
<b>Bundle Name:</b> MAP_SensorCircuitFP
P0107, P0108
<b>Bundle Name:</b> MAP_SensorFA
P0106, P0107, P0108
<b>Bundle Name:</b> MAP_SensorPerfFA
P0106
<b>Bundle Name:</b> MAP_SensorPerfTFTKO
P0106
<b>Bundle Name:</b> MAP_SensorTFTKO
P0106, P0107, P0108
<b>Bundle Name:</b> MnfdTempSensorCktFA
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
<b>Bundle Name:</b> MnfdTempSensorCktFP
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
<b>Bundle Name:</b> MnfdTempSensorCktTFTKO
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
<b>Bundle Name:</b> MnfdTempSensorFA
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
<b>Bundle Name:</b> MnfdTempSensorTFTKO
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
<b>Bundle Name:</b> ModuleOffTime_FA
P2610
<b>Bundle Name:</b> no validity name is assigned to this fault bundle
<b>Bundle Name:</b> OAT_AmbientFilteredFA
ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor_FA, IAT_SensorFA, ECT_Sensor_DefaultDetected, MAF_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: not applicable. All other cases: not applicable.
<b>Bundle Name:</b> OAT_AmbientSensorFA
ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: not applicable. All other cases: not applicable.
<b>Bundle Name:</b> OAT_EstAmbTemp_FA
Only EREV sealed fuel system, P0071, P0072, P0073, P0502, P0503, P0722, P0723
<b>Bundle Name:</b> OAT_PtEstFiltFA
ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor_FA, IAT_SensorFA, ECT_Sensor_DefaultDetected, MAF_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: VehicleSpeedSensor_FA, IAT_SensorFA, MAF_SensorFA. All other cases:

EngModeNotRunTmErr, VehicleSpeedSensor_FA, IAT_SensorFA, ECT_Sensor_DefaultDetected.
<b>Bundle Name:</b> OAT_PtEstRawFA
ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: IAT_SensorFA. All other cases: IAT_SensorFA, ECT_Sensor_DefaultDetected.
<b>Bundle Name:</b> PowertrainRelayFault
P1682
<b>Bundle Name:</b> PowertrainRelayStateOn_Error
P0685
<b>Bundle Name:</b> PowertrainRelayStateOn_FA
P0685
<b>Bundle Name:</b> PPS1_OutOfRange
P2122, P2123
<b>Bundle Name:</b> PPS1_OutOfRange_Composite
P2122, P2123, P06A3
<b>Bundle Name:</b> PPS2_OutOfRange
P2127, P2128
<b>Bundle Name:</b> PPS2_OutOfRange_Composite
P2127, P2128, P0697
<b>Bundle Name:</b> SCIAP_SensorCircuitFA
P012C, P012D
<b>Bundle Name:</b> SCIAP_SensorCircuitFP
P012C, P012D
<b>Bundle Name:</b> SCIAP_SensorFA
P012B, P012C, P012D
<b>Bundle Name:</b> SCIAP_SensorPerfFA
P012B
<b>Bundle Name:</b> SCIAP_SensorPerfTFTKO
P012B
<b>Bundle Name:</b> SCIAP_SensorTFTKO
P012B, P012C, P012D
<b>Bundle Name:</b> SuperchargerBypassValveFA
P2261
<b>Bundle Name:</b> TC_BoostPresSnsrCktFA
P0237, P0238
<b>Bundle Name:</b> TC_BoostPresSnsrFA
P0236, P0237, P0238
<b>Bundle Name:</b> TCM_EngSpdReqCkt
P150C

<b>Bundle Name:</b> THMR_AHV_FA
P2681, P26A3, P26A6, P26A7, P26A9
<b>Bundle Name:</b> THMR_AWP_AuxPumpFA
B2920, B2923, B2922
<b>Bundle Name:</b> THMR_ECT_Sensor_Ckt_FA
P0116, P0117, P0118, P00B6
<b>Bundle Name:</b> THMR_Insuff_Flow_FA
P00B7
<b>Bundle Name:</b> THMR_RCT_Sensor_Ckt_FA
P00B3, P00B4
<b>Bundle Name:</b> THMR_SWP_Control_FA
P261D, P261A, P261C
<b>Bundle Name:</b> THMR_Therm_Control_FA
P0597, P0598, P0599
<b>Bundle Name:</b> ThrotTempSensorFA
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
<b>Bundle Name:</b> ThrotTempSensorTFTKO
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
<b>Bundle Name:</b> ThrottlePositionSnrPerfFA
P0121
<b>Bundle Name:</b> ThrottlePositionSnrPerfTFTKO
P0121
<b>Bundle Name:</b> TIAP_SensorPerfFA
P0236
<b>Bundle Name:</b> TPS_FA
P0122, P0123, P0222, P0223, P2135
<b>Bundle Name:</b> TPS_FaultPending
P0122, P0123, P0222, P0223, P2135
<b>Bundle Name:</b> TPS_Performance_FA
P0068, P0121, P1104, P2100, P2101, P2102, P2103
<b>Bundle Name:</b> TPS_Performance_TFTKO
P0068, P0121, P1104, P2100, P2101, P2102, P2103
<b>Bundle Name:</b> TPS_TFTKO
P0122, P0123, P0222, P0223, P2135
<b>Bundle Name:</b> TPS_ThrottleAuthorityDefaulted
P0068, P0122, P0123, P0222, P0223, P16F3, P1104, P2100, P2101, P2102, P2103, P2135



<b>Bundle Name:</b> TPS1_OutOfRange_Composite
P0122, P0123, P06A3
<b>Bundle Name:</b> TPS2_OutOfRange_Composite
P0222, P0223, P06A3
<b>Bundle Name:</b> Trans Output Rotations Rolling Count Validity
<b>Bundle Name:</b> Transfer Pump is Commanded On
Fuel Volume in Primary Fuel Tank < KeFLVC_V_PriFuelTankXferPmpEnbl (see supporting table for numeric value) liters AND Fuel Volume in Secondary Fuel Tank ≥ KeFLVC_V_SecFuelTankXferPmpEnbl (see supporting table for numeric value) liters AND Transfer Pump on Time < TransferPumpOnTimeLimit (see supporting table for numeric value) AND Transfer Pump had been Off for at least KeFLVC_t_XferFuelPmpMinOffTm (see supporting table for numeric value) seconds AND Evap Diagnostic (Purge Valve Leak Test, Large Leak Test, and Waiting for Purge) is not running AND Engine Running
<b>Bundle Name:</b> Transmission Actual Gear Validity
<b>Bundle Name:</b> Transmission Engaged State Validity
<b>Bundle Name:</b> Transmission Estimated Gear Validity
<b>Bundle Name:</b> Transmission Gear Ratio Validity
<b>Bundle Name:</b> Transmission Gear Selector Position Validity
<b>Bundle Name:</b> Transmission Oil Temperature Validity
<b>Bundle Name:</b> Transmission Output Shaft Angular Velocity Validity
<b>Bundle Name:</b> Transmission Overall Actual Torque Ratio Validity
<b>Bundle Name:</b> Transmission Overall Estimated Torque Ratio Validity
<b>Bundle Name:</b> Transmission Shift Lever Position Validity
<b>Bundle Name:</b> Transmission Turbine Angular Velocity Validity
<b>Bundle Name:</b> TransmissionEngagedState_FA
MYD/MYC/MYB:, P182E, P1915
<b>Bundle Name:</b> TransmissionGearDefaulted
MYD/MYC/MYB:, P182E, P1915
<b>Bundle Name:</b> VehicleSpeedSensor_FA
P0502, P0503, P0722, P0723

<b>Bundle Name:</b> VehicleSpeedSensorError
P0502, P0503, P0722, P0723
<b>Bundle Name:</b> VentCircuit_FA
P0449, P0498, P0499
<b>Bundle Name:</b> VICM_WakeupDiag_FA
P06E4
<b>Bundle Name:</b> VICM_WakeupDiag_TFTKO
P06E4