

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit – Bank 1	P0010	Detects a VVT system error by monitoring the circuit for electrical integrity	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		System supply voltage is within limits Output driver is commanded on, Ignition switch is in crank or run position	> 11 Volts	20 failures out of 25 samples 250 ms / sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Performance – Bank 1	P0011	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Intake cam Bank 1) Cam Position Error > 5.00 deg. (CamPosErrorLimlc1)	DTC's are NOT active: P0010, IntakeCamSensorTFTKO CrankSensorTFTKO CrankIntakeCamCorrelationFA. Engine is running VVT is enabled Desired camshaft position > 0 Power Take Off (PTO) not active	System Voltage > 11 Volts, Engine is running VVT is enabled Desired cam position > 0 Power Take Off (PTO) not active Both Desired & Measured cam positions cannot be < 5.00 (CamPosErrorLimlc1) or have both > 20.00 deg. (MaxTravelInt - CamPosErrorLimlc1). Desired cam position cannot vary more than 4.50 Cam Deg for at least 1.00 sec. (KtPHSD_t_StablePositionTimeIc1)	75.00 failures out of 225.00 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit – Bank 1	P0013	Detects a VVT system error by monitoring the circuit for electrical integrity	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		System supply voltage is within limits Output driver is commanded on, Ignition switch is in crank or run position	> 11 Volts	20 failures out of 25 samples 250 ms / sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft System Performance – Bank 1	P0014	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Exhaust cam Bank 1) Cam Position Error > 5.00 deg. (CamPosErrorLimEc1)	DTC's are NOT active: P0013, ExhaustCamSensorTFTKO CrankSensorTFTKO CrankExhaustCamCorrelationFA	System Voltage > 11 Volts, Engine is running VVT is enabled Desired cam position > 0 Power Take Off (PTO) not active Both Desired & Measured cam positions cannot be < 5.00 deg. (CamPosErrorLimEc1) or have both > (20.00) (MaxTravelExh - CamPosErrorLimEc1). Desired cam position cannot vary more than 4.50 Cam Deg for at least 1.00 sec. (KtPHSD_t_StablePositionTimeEc1)	100.00 failures out of 300.00 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)- Camshaft Position (CMP) Correlation Bank 1 Sensor A	P0016	Detects cam to crank misalignment by monitoring if cam sensor pulse for bank 1 sensor A occurs during the incorrect crank position	2 cam sensor pulses more than -9.0 crank degrees before or 12.0 crank degrees after nominal position in one cam revolution.		Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic	P0335, P0336 P0340,P0341 5VoltReferenceA_FA 5VoltReferenceB_FA < 30.0 seconds	2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table "Cam Correlation Oil Temperature Threshold". One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft - Sprocket Correlation Diagnostic	P0016 and P0017	On engines with a dual intermediate sprocket between the crankshaft and the camshafts, this diagnostic detects a timing misalignment between the crankshaft, sprocket and camshafts that will cause the bank 1 camshafts to be misaligned.	Bank 1 Cam Sensor A pulses more than -6.0 crank degrees before or 9.9 crank degrees after nominal position in one cam revolution + Bank 1 Cam Sensor B pulses more than -5.6 crank degrees before or 9.9 crank degrees after nominal position in one cam revolution.	>= 8	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs:	P0335, P0336 P0340, P0341 P0365, P0366 5VoltReferenceA_FA 5VoltReferenceB_FA	2 failures out of 3 tests. A failed test is 1 out of 10 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table "Cam Correlation Oil Temperature Threshold". One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)- Camshaft Position (CMP) Correlation Bank 1 Sensor B	P0017	Detects cam to crank misalignment by monitoring if cam sensor pulse for bank 1 sensor B occurs during the incorrect crank position	2 cam sensor pulses more than -10.0 crank degrees before or 13.0 crank degrees after nominal position in one cam revolution.		Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic	P0335, P0336 P0365,P0366 5VoltReferenceA_FA 5VoltReferenceB_FA < 30.0 seconds	2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table "Cam Correlation Oil Temperature Threshold". One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)- Camshaft Position (CMP) Correlation Bank 2 Sensor A	P0018	Detects cam to crank misalignment by monitoring if cam sensor pulse for bank 2 sensor A occurs during the incorrect crank position	2 cam sensor pulses more than -11.0 crank degrees before or 13.0 crank degrees after nominal position in one cam revolution.		Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic	P0335, P0336 P0345, P0346 5VoltReferenceA_FA 5VoltReferenceB_FA < 30.0 seconds	2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table "Cam Correlation Oil Temperature Threshold". One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft - Sprocket Correlation Diagnostic	P0018 and P0019	On engines with a dual intermediate sprocket between the crankshaft and the camshafts, this diagnostic detects a timing misalignment between the crankshaft, sprocket and camshafts that will cause the bank 2 camshafts to be misaligned.	Bank 2 Cam Sensor A pulses more than -6.1 crank degrees before or 9.9 crank degrees after nominal position in one cam revolution + Bank 2 Cam Sensor B pulses more than -7.3 crank degrees before or 9.9 crank degrees after nominal position in one cam revolution	>= 8	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs:	P0335, P0336 P0345, P0346 P0390, P0391 5VoltReferenceA_FA 5VoltReferenceB_FA	2 failures out of 3 tests. A failed test is 1 out of 10 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table "Cam Correlation Oil Temperature Threshold". One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)- Camshaft Position (CMP) Correlation Bank 2 Sensor B	P0019	Detects cam to crank misalignment by monitoring if cam sensor pulse for bank 2 sensor B occurs during the incorrect crank position	2 cam sensor pulses more than -9.3 crank degrees before or 11.1 crank degrees after nominal position in one cam revolution.		Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic	P0335, P0336 P0390, P0391 5VoltReferenceA_FA 5VoltReferenceB_FA < 30.0 seconds	2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table "Cam Correlation Oil Temperature Threshold". One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit – Bank 2	P0020	Detects a VVT system error by monitoring the circuit for electrical integrity	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		System supply voltage is within limits Output driver is commanded on, Ignition switch is in crank or run position	> 11 Volts	20 failures out of 25 samples 250 ms / sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Performance – Bank 2	P0021	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Intake cam Bank 2) Cam Position Error > 5.00 deg. (CamPosErrorLimlc2)	DTC's are NOT active: P0020, IntakeCamSensorTFTKO CrankSensorTFTKO CrankIntakeCamCorrelationFA	System Voltage > 11 Volts, Engine is running VVT is enabled Desired cam position > 0 Power Take Off (PTO) not active Both Desired & Measured cam positions cannot be < 5.00 deg. (CamPosErrorLimlc2) or have both > (20.00) deg. (MaxTravellnt - CamPosErrorLimlc2). Desired cam position cannot vary more than 4.50 Cam Deg for at least 1.00 sec. (KtPHSD_t_StablePositionTimelc2)	75.00 failures out of 225.00 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit – Bank 2	P0023	Detects a VVT system error by monitoring the circuit for electrical integrity	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		System supply voltage is within limits Output driver is commanded on, Ignition switch is in crank or run position	> 11 Volts	20 failures out of 25 samples 250 ms / sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft System Performance – Bank 2	P0024	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Exhaust cam Bank 2) Cam Position Error > 5.00 deg. (CamPosErrorLimEc2)	DTC's are NOT active: P0023, ExhaustCamSensorTFTKO CrankSensorTFTKO CrankExhaustCamCorrelationFA	System Voltage > 11 volts, Volts, Engine is running VVT is enabled Desired cam position > 0 Power Take Off (PTO) not active Both Desired & Measured cam positions cannot be < 5.00 deg. (CamPosErrorLimEc2) or have both > (20.00) (MaxTravelExh - CamPosErrorLimEc2). Desired cam position cannot vary more than 4.50 Cam Deg for at least 1.00 sec. (KitPHSD_t_StablePositionTimeEc2)	100.00 failures out of 300.00 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 1	P0030	This DTC checks the Heater Output Driver circuit for electrical integrity.	Voltage low during driver open state (indicates short-to-ground or open circuit) or voltage high during driver closed state (indicates short to voltage).		Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 2	P0036	This DTC checks the Heater Output Driver circuit for electrical integrity.	Voltage low during driver open state (indicates short-to-ground or open circuit) or voltage high during driver closed state (indicates short to voltage).		Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 2 Sensor 1	P0050	This DTC checks the Heater Output Driver circuit for electrical integrity.	Voltage low during driver open state (indicates short-to-ground or open circuit) or voltage high during driver closed state (indicates short to voltage).		Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 1	P0053	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	$6.1 < \Omega < 13.4$	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,800 seconds -30.0 < °C < 45.0 < 32.0 volts < 0.22 seconds	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 2	P0054	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	$6.1 < \Omega < 13.4$	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,800 seconds -30.0 < °C < 45.0 < 32.0 volts < 0.25 seconds	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 2 Sensor 2	P0056	This DTC checks the Heater Output Driver circuit for electrical integrity.	Voltage low during driver open state (indicates short-to-ground or open circuit) or voltage high during driver closed state (indicates short to voltage).		Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 2 Sensor 1	P0059	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	$6.1 < \Omega < 13.4$	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,800 seconds -30.0 < °C < 45.0 < 32.0 volts < 0.22 seconds	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 2 Sensor 2	P0060	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	$6.1 < \Omega < 13.4$	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,800 seconds -30.0 < °C < 45.0 < 32.0 volts < 0.25 seconds	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
MAP / MAF / Throttle Position Correlation	P0068	Detect when MAP and MAF do not match estimated engine airflow as established by the TPS	<p>Difference between MAP and estimated MAP exceeds threshold (kPa), or P0651 (5 Volt Ref), or P0107 (MAP circuit low), or P0108 (MAP circuit high) have failed this key cycle, then MAP portion of diagnostic fails</p> <p>Absolute difference between MAF and estimated MAF exceed threshold (grams/sec), or P0102 (MAF circuit low), or P0103 (MAF circuit hi) have failed this key cycle, or maximum MAF versus RPM (Table) is greater than or equal to maximum MAF versus battery voltage, then MAF portion of diagnostic fails</p>	<p>Table, f(TPS). See supporting tables</p> <p>Table, f(TPS). See supporting tables</p> <p>Table, f(RPM). See supporting tables</p> <p>Table, f(Volts). See supporting tables</p>	Engine Speed	<p>> 800 RPM</p> <p>Run/Crank voltage > 6.41</p>	<p>Continuously fail MAP and MAF portions of diagnostic for 0.1875 s</p> <p>Continuous in MAIN processor</p>	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module SIDI High Pressure Pump min/ max authority	P0089	This DTC Detects pump control windup to its max or min authority	High Pressure Fuel Pump Delivery Angle High Pressure Fuel Pump Delivery Angle	$\geq 240^\circ$ Or $\leq 0^\circ$	Battery Voltage Low Side Fuel Pressure Engine Run Time Barometric Pressure Inlet Air Temp Fuel Temp Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and	≥ 11 Volts > 0.275 MPa \geq KtFHPD_t_PumpCntrlEng RunThrsh(see supporting tables) Enabled when a code clear is not active or not exiting device control Engine is not cranking ≥ 70.0 KPA ≥ -10.0 degC $-10 \leq \text{Temp degC} \leq 100$	Windup High - 750 failures out of 938 samples Windup Low - 750 failures out of 938 Samples	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Cntrl Solenoid Enable Low Side Open Circuit	P0090	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the high pressure fuel pump solenoid low side is open circuit		Engine Speed Battery Voltage	>= 50 RPM >= 11 volts Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Cntrl Solenoid Enable Low Side Short to Ground	P0091	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the high pressure fuel pump solenoid low side is short to ground		Engine Speed Battery Voltage	>= 50 RPM >= 11 volts Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Cntrl Solenoid Enable Low Side Short to Power P0092	P0092	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the high pressure fuel pump solenoid low side is short to power		Engine Speed Battery Voltage	>= 50 RPM >= 11 Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0096	Detects an IAT2 sensor that has stuck in range by comparing to IAT and engine coolant temperature at startup	ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up ECT – Power Up IAT2) >= ABS(Power Up ECT – Power Up IAT)	> 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 Low (applications with humidity)	P0097	Detects a continuous short to ground or open in the IAT 2 signal circuit	Raw IAT 2 Input	< 13 Hertz (~-60 deg C)	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 High (applications with humidity)	P0098	Detects a continuous high frequency in the IAT 2 signal circuit	Raw IAT 2 Input	> 390 Hertz (~150 deg C)	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Intermittent In-Range	P0099	Detects a noisy or erratic IAT 2 signal circuit or IAT 2 sensor	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current IAT 2 reading - IAT 2 reading from 100 milliseconds previous)	> 100.00 DegC 10 consecutive IAT 2 samples	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Start Diagnostic	P00C6	This DTC checks the high side fuel pressure during engine cranking	The ECM detects that the fuel pressure is not rising or has fallen beyond acceptable limits during engine cranking	<p>Pressure Fall Test: High Side Fuel Rail Pressure <= Supporting Table KtFHPD_p_HPS_PressFallLoThrsh</p> <p>Pressure Rise Test: High Side Fuel Pressure < Supporting Table KtFHPC_p_HighPressStart</p>	<p>Low side feed fuel pressure</p> <p>Engine Run Time Run/Crank Voltage Engine Coolant</p> <p>For each engine start, only 1 diagnostic is performed. The pressure rise test will run if High side fuel pressure is less than KtFHPC_p_HighPressStart, otherwise, the pressure fall diagnostic will run. The pressure fall runs when the engine is cranking.</p>	<p>>= 0 KPA</p> <p>< = 0 sec > 8 Volts -100 <= °C <= 65</p> <p>All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT, IAT2 and ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and Manufacturers enable</p>	<p>Pressure Fall Test: Injected cylinder events >= Supporting Table KtFHPD_Cnt_HPS_PressFallLoThrsh</p> <p>Pressure Rise Test: Time >= Supporting Table KtFHPC_t_HighPressStartTmout</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Barometric Pressure Inlet Air Temp	counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active >= 70.0 KPA >= -10.0 DegC		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Press Regulator Solenoid Supply Voltage Control Circuit/Open	P00C8	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the Fuel Press Regulator Solenoid Supply Voltage Control Circuit/Open		Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Press Regulator Solenoid Supply Voltage Control Circuit Low	P00C9	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the Fuel Press Regulator Solenoid Supply Voltage Control short to ground		Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Press Regulator Solenoid Supply Voltage Control Circuit High	P00CA	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the Fuel Press Regulator Solenoid Supply Voltage Control short to power		Engine Speed Battery Voltage	>= 50 RPM >= 11 Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (naturally aspirated)	P0101	Determines if the MAF sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 350 kPa*(g/s) > 20 grams/sec > 20.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 500 RPM <= 6,800 RPM >= -7 Deg C <= 126 Deg C >= -20 Deg C <= 125 Deg C >= 0.50 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM See "Residual Weight Factor" tables. MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit Low Frequency	P0102	Detects a continuous short to low or a open in either the signal circuit or the MAF sensor	MAF Output	<= 800 Hertz (~ 0.90 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 0.0 seconds >= 300 RPM >= 10.0 Volts >= 1.0 seconds	300 failures out of 375 samples 1 sample every cylinder firing event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit High Frequency	P0103	Detects a high frequency output from the MAF sensor	MAF Output	>= 14,500 Hertz (~ 630.00 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 0.0 seconds >= 300 RPM >= 10.0 Volts >= 1.0 seconds	300 failures out of 375 samples 1 sample every cylinder firing event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (naturally aspirated)	P0106	Determines if the MAP sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 350 kPa*(g/s)	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 500 RPM <= 6,800 RPM >= -7 Deg C <= 126 Deg C >= -20 Deg C <= 125 Deg C >= 0.50 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM See "Residual Weight Factor" tables.	Continuous Calculations are performed every 12.5 msec	Type B, 2 Trips
			Manifold Pressure OR	< 50.0 kPa	Time between current ignition cycle and the last	4 failures out of 5 samples		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Manifold Pressure	> 115.0 kPa	time the engine was running Engine is not rotating No Active DTCs: No Pending DTCs:	> 409.6 seconds EngineModeNotRunTimer Error MAP_SensorFA AAP_SnsrFA MAP_SensorCircuitFP AAP_SnsrCktFP	1 sample every 12.5 msec	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit Low	P0107	Detects a continuous short to low or open in either the signal circuit or the MAP sensor.	MAP Voltage	< 3.0 % of 5 Volt Range (This is equal to 0.15 Volts or 3.5 kPa)	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit High	P0108	Detects an open sensor ground or continuous short to high in either the signal circuit or the MAP sensor.	MAP Voltage	> 90.0 % of 5 Volt Range (This is equal to 4.50 Volts, or 115.0 kPa)	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0111	Detects an IAT sensor that has stuck in range by comparing to IAT2 and engine coolant temperature at startup	ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up ECT – Power Up IAT) > ABS(Power Up ECT – Power Up IAT2)	> 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Low	P0112	Detects a continuous short to ground in the IAT signal circuit or the IAT sensor	Raw IAT Input	< 58 Ohms (~150 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit High	P0113	Detects a continuous open circuit in the IAT signal circuit or the IAT sensor	Raw IAT Input	> 142,438 Ohms (~-60 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Intermittent In-Range	P0114	Detects a noisy or erratic IAT signal circuit or IAT sensor	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current IAT reading - IAT reading from 100 milliseconds previous)	> 80.00 DegC 10 consecutive IAT samples	Continuous		4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Performance	P0116	This DTC detects ECT temp sensor stuck in mid range.	<p>A failure will be reported if any of the following (1-3) occur after the following soak conditions, Engine off time > 28,800 seconds Propulsion system off time > 0 seconds</p> <p>1) ECT at power up > IAT at power up by an IAT based table lookup value (fast fail).</p> <p>2) ECT at power up > IAT at power up by 15.0 Deg C and a block heater has not been detected.</p> <p>3) ECT at power up > IAT at power up by 15.0 Deg C and the time spent cranking the engine without starting is greater than 10.0 seconds with the LowFuelConditionDiag</p>	<p>See "P0116: Fail if power up ECT exceeds IAT by these values" in the Supporting tables section</p> <p>= False</p>	<p>No Active DTC's</p> <p>Non-volatile memory initialization</p> <p>Test complete this trip Test aborted this trip IAT LowFuelCondition Diag</p> <p>=====</p> <p>Block Heater detection is enabled when either of the following occurs:</p> <p>1) ECT at power up > IAT at power up by</p> <p>2) Cranking time</p> <p>=====</p> <p>Block Heater is detected and diagnostic is aborted when 1) or 2) occurs:</p> <p>1a) Vehicle drive time</p> <p>1b) Vehicle speed</p> <p>1c) Additional Vehicle drive time is provided to 1a when Vehicle speed is below 1b as follows:</p>	<p>VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_Ckt_FA IgnitionOffTime Valid TimeSinceEngineRunning Valid</p> <p>= Not occurred</p> <p>= False = False ≥ -7 °C</p> <p>= False</p> <p>=====</p> <p>> 15.0 °C</p> <p>< 10.0 seconds</p> <p>=====</p> <p>> 400 seconds</p> <p>with > 14.9 MPH</p> <p>0.50 times the seconds with vehicle speed below 1b</p>	<p>1 failure</p> <p>500 msec/ sample</p> <p>Once per valid cold start</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					1d) IAT drops from power up IAT 2a) ECT drops from power up ECT 2b) Engine run time ===== Diagnostic is aborted when 3) or 4) occurs: 3) Engine run time with vehicle speed below 1b 4) Minimum IAT during test	$\geq 5.3^{\circ}\text{C}$ $\geq 5^{\circ}\text{C}$ Within ≤ 60 seconds ===== > 1800 seconds $\leq -7^{\circ}\text{C}$		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit Low	P0117	Circuit Continuity This DTC detects a short to ground in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ 150°C)	< 46 Ohms			5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit High	P0118	Circuit Continuity This DTC detects a short to high or open in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ -60°C)	> 419,000 Ohms	Engine run time OR IAT min	> 10.0 seconds ≥ -7.0 °C	5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Circuit Intermittent	P0119	Circuit Continuity This DTC detects large step changes in the ECT signal circuit or the ECT sensor. Allowable high and low limits are calculated for the next sample based on the previous sample.	ECT temperature step change: 1) positive step change is greater than high limit OR 2) negative step change is lower than low limit.		No Active DTC's	P0117 P0118	3 failures out of 4 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (naturally aspirated)	P0121	Determines if the Throttle Position Sensor input is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	> 350 kPa*(g/s) > 20 grams/sec <= 20.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 500 RPM <= 6,800 RPM > -7 Deg C < 126 Deg C > -20 Deg C < 125 Deg C >= 0.50 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est See "Residual Weight Factor" tables. No Active DTCs: MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA No Pending DTCs: EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit Low	P0122	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage <	0.3250		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit High	P0123	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage >	4.750		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					2) When Cooling system power is < 12.0 kW then it is set to 3) With Decel Fuel Cut Off active, Cooling System energy is reduced by multiplying actual power by 4) With Hybrid Engine Off Active, Cooling System Energy is reduced by ===== Diagnostic will restart (using the lower value) if ECT drops	0.0 kW 0.20 times 1.00 kW each second ===== ≥ 5.0 °C below previous minimum ECT		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 1	P0132	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	== Open Test Criteria == No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition ===== No Active DTC's Low Fuel Condition Diag Fuel Condition Initial delay after Open Test Criteria met (cold start condition) Initial delay after Open Test Criteria met (not cold start condition) Equivalence Ratio Air Per Cylinder Fuel Control State	===== TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 150 seconds ≤ 87 % Ethanol ===== MAP_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA AIR System FA = False ≤ 87 % Ethanol > 45.0 seconds when engine soak time > 28,800 seconds > 45.0 seconds when engine soak time ≤ 28,800 seconds 0.9805 ≤ ratio ≤ 1.0996 50 ≤ mgram ≤ 500 not = Power Enrichment	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for	> 3.0 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Slow Response Bank 1 Sensor 1	P0133	This DTC determines if the O2 sensor response time is degraded.	The average response time is calculated over the test time, and compared to the threshold. Refer to P0133 - O2S Slow Response Bank 1 Sensor 1 "Pass/Fail Threshold table" in the Supporting Tables tab.		No Active DTC's Bank 1 Sensor 1 DTC's not active System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition O2 Heater on for Learned Htr resistance	TPS_ThrottleAuthorityDefault MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA EthanolCompositionSensor_FA EngineMisfireDetected_FA P0131, P0132, P0134 10.0 < Volts < 32.0 = Not active = Not active = Not active = Not active = False = Not Valid, See definition of Green Sensor Delay Criteria (B1S1) in Supporting Tables tab. ≥ 60 seconds = Valid (the heater resistance has learned since NVM reset, see	Sample time is 60 seconds Frequency: Once per trip	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Engine Coolant IAT Engine run Accum Time since any AFM status change Time since Purge On to Off change Time since Purge Off to On change Engine airflow Engine speed Fuel Condition Baro Air Per Cylinder Fuel Control State Closed Loop Active LTM fuel cell Transient Fuel Mass Baro Fuel Control State Fuel State Commanded Proportional Gain ===== All of the above met for	enable conditions for "HO2S Heater Resistance DTC's") > 54 °C > -40 °C > 60 seconds > 0.0 seconds > 4.0 seconds > 4.0 seconds 15 ≤ grams/second ≤ 43 1,000 ≤ RPM ≤ 3,000 < 87 % Ethanol > 70 kpa ≥ 125 mGrams = Closed Loop = TRUE = Enabled ≤ 100.0 mgrams = Not Defaulted not = Power Enrichment DFCO not active ≥ 0.0 % ===== > 2.0 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Insufficient Activity Bank 1 Sensor 1	P0134	This DTC determines if the O2 sensor circuit is open.	Oxygen Sensor Signal	> 1,700 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition	TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 150 seconds ≤ 87 % Ethanol	100 failures out of 125 samples. Frequency: Continuous 100 msec loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 1	P0135	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.3 < Amps < 1.2	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA 10.0 < Volts < 32.0 = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 2 tests per trip 10 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 2	P0137	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 50 mvolts	No Active DTC's AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active All Fuel Injectors for active Cylinders Fuel Condition Fuel State All of the above met for	TPS_ThrottleAuthorityDefaultedMAP_SensorFAAIR System FAEthanol Composition Sensor FAEvapPurgeSolenoidCircuit_FAEvapFlowDuringNonPurge_FAEvapVentSolenoidCircuit_FAEvapSmallLeak_FAEvapEmissionSystem_FAFuelTankPressureSnrCkt_FAFuelInjector Circuit_FA = Not active = Not active = Not active = Not active 10.0 < Volts < 32.0 = Not active = Not active = Not active = Not active = False 0.9805 ≤ ratio ≤ 1.0996 50 ≤ mgrams ≤ 500 = Closed Loop = TRUE Enabled (On) Ethanol ≤ 87 % DFCO not active > 3.0 seconds	430 failures out of 540 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 2	P0138	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	== Open Test Criteria == No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Fuel Condition ===== No Active DTC's Low Fuel Condition Diag Fuel Condition Initial delay after Open Test Criteria met (cold start condition) Initial delay after Open Test Criteria met (not cold start condition) Equivalence Ratio Air Per Cylinder Fuel Control State	===== TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds ≤ 87 Ethanol ===== MAP_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA AIR System FA = False ≤ 87 % Ethanol > 45.0 seconds when engine soak time > 28,800 seconds > 45.0 seconds when engine soak time ≤ 28,800 seconds 0.9805 ≤ ratio ≤ 1.0996 50 ≤ mgrams ≤ 500 not = Power Enrichment	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for	> 3.0 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Rich to Lean Bank 1 Sensor 2	P013A	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Rich to Lean voltages range during Rich to Lean transition. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Post O2 sensor normalized integral value OR The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units > 74.0 grams (upper voltage threshold is 450 mvolts and lower voltage threshold is 150 mvolts)	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition Low Fuel Condition Diag Post fuel cell DTC's Passed =====	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013B, P013E, P013F, P2270 or P2271 10.0 < Volts < 32.0 = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid = Not Valid, See definition of Green Sensor Delay Criteria (B1S2) in Supporting Tables tab. = False = enabled P2270 (and P2272 if applicable) P013E (and P014A if applicable) =====	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA
					After above conditions are met: DFCO mode is			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					continued (wo driver initiated pedal input).			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Lean to Rich Bank 1 Sensor 2	P013B	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Lean to Rich voltages range during Lean to Rich transition. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	The EWMA of the Post O2 sensor normalized integral value OR The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units > 75 grams (lower voltage threshold is 350 mvolts and upper voltage threshold is 600 mvolts)	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition Low Fuel Condition Diag Post fuel cell DTC's Passed	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013A, P013E, P013F, P2270 or P2271 10.0 < Volts < 32.0 = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid = Not Valid, See definition of Green Sensor Delay Criteria (B1S2) in Supporting Tables tab. = False = enabled P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable) P013F (and P014B if	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>=====</p> <p>After above conditions are met: Fuel Enrich mode continued.</p> <p>=====</p> <p>During this test the following must stay TRUE or the test will abort: 0.96 ≤ Fuel EQR ≤ 1.08</p>	<p>applicable)</p> <p>=====</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Rich to Lean Bank 2 Sensor 2	P013C	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Rich to Lean voltages range during Rich to Lean transition. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Post O2 sensor normalized integral value OR The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units > 74.0 grams (upper voltage threshold is 450 mvolts and lower voltage threshold is 150 mvolts)	No Active DTC's B2S2 DTC's Not Active this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition Low Fuel Condition Diag Post fuel cell DTC's Passed =====	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013D, P014A, P014B, P2272 or P2273 10.0 < Volts < 32.0 = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid = Not Valid, See definition of Green Sensor Delay Criteria (B2S2) in Supporting Tables tab. = False = enabled P2270 (and P2272 if applicable) P013E (and P014A if applicable) =====	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA
					After above conditions are met:			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					DFCO mode is continued (wo driver initiated pedal input).			

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Lean to Rich Bank 2 Sensor 2	P013D	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Lean to Rich voltages range during Lean to Rich transition. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	The EWMA of the Post O2 sensor normalized integral value OR The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units > 75 grams (lower voltage threshold is 350 mvolts and upper voltage threshold is 600 mvolts)	No Active DTC's B2S2 DTC's Not Active this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition Low Fuel Condition Diag Post fuel cell DTC's Passed	TPS_ThrottleAuthorityDefault ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013C, P014A, P014B, P2272 or P2273 10.0 < Volts < 32.0 = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid = Not Valid, See definition of Green Sensor Delay Criteria (B2S2) in Supporting Tables tab. = False = enabled P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable)	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>=====</p> <p>After above conditions are met: Fuel Enrich mode continued.</p> <p>=====</p> <p>During this test the following must stay TRUE or the test will abort: $0.96 \leq \text{Fuel EQR} \leq 1.08$</p>	<p>P013F (and P014B if applicable)</p> <p>=====</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(wo driver initiated pedal input).			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					===== After above conditions are met: Fuel Enrich mode entered. ===== During this test the following must stay TRUE or the test will abort: $0.96 \leq \text{Fuel EQR} \leq 1.08$	=====		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Insufficient Activity Bank 1 Sensor 2	P0140	This DTC determines if the O2 sensor circuit is open.	Oxygen Sensor Signal	> 1,700 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition	TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 150 seconds ≤ 87 % Ethanol	100 failures out of 125 samples. Frequency: Continuous 100 msec loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 2	P0141	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.3 > amps > 1.2	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA 10.0 < Volts < 32.0 = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 2 tests per trip 10 seconds delay between tests and 1 second execution rate.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(wo driver initiated pedal input).			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					cylinders ===== After above conditions are met: Fuel Enrich mode entered. ===== During this test the following must stay TRUE or the test will abort: 0.96 \leq Fuel EQR \leq 1.08	\geq 1 cylinders =====		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 2 Sensor 1	P0151	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 40 mvolts	No Active DTC's AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active All Fuel Injectors for active Cylinders Fuel Condition Fuel State All of the above met for	TPS_ThrottleAuthority DefaultedMAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA = Not active = Not active = Not active = Not active 10.0 < Volts < 32.0 = Not active = Not active = Not active = Not active = False 0.9805 ≤ equiv. ratio ≤ 1.0996 50 ≤ APC ≤ 500 mgrams = Closed Loop = TRUE Enabled (On) ≤ 87 % Ethanol DFCO not active > 3.0 seconds	380 failures out of 475 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 2 Sensor 1	P0152	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	== Open Test Criteria == No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition ===== No Active DTC's Low Fuel Condition Diag Fuel Condition Initial delay after Open Test Criteria met (cold start condition) Initial delay after Open Test Criteria met (not cold start condition) Equivalence Ratio Air Per Cylinder	===== TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 150 seconds <= 87 % Ethanol ===== MAP_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA AIR System FA = False ≤ 87 % Ethanol > 105.0 seconds when engine soak time > 28,800 seconds > 105.0 seconds when engine soak time ≤ 28,800 seconds 0.9805 ≤ ratio ≤ 1.0996 50 ≤ mgrams ≤ 500	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Fuel Control State All of the above met for	not = Power Enrichment > 3 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Slow Response Bank 2 Sensor 1	P0153	This DTC determines if the O2 sensor response time is degraded.	The average response time is calculated over the test time, and compared to the threshold. Refer to P0153 - O2S Slow Response Bank 2 Sensor 1 "Pass/Fail Threshold table in the Supporting Tables tab.		No Active DTC's Bank 2 Sensor 1 DTC's not active System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition O2 Heater on for Learned Htr resistance	TPS_ThrottleAuthorityDefault MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA EthanolCompositionSensor_FA EngineMisfireDetected_FA = P0151, P0152 or P0154 10.0 < Volts < 32.0 = Not active = Not active = Not active = Not active = False = Not Valid, See definition of Green Sensor Delay Criteria (B2S1) in Supporting Tables tab. ≥ 60 seconds = Valid (the heater resistance has learned since NVM reset, see	Sample time is 60 seconds Frequency: Once per trip	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Engine Coolant IAT Engine run Accum Time since any AFM status change Time since Purge On to Off change Time since Purge Off to On change Engine airflow Engine speed Fuel Condition Baro Air Per Cylinder Fuel Control State Closed Loop Active LTM fuel cell Transient Fuel Mass Baro Fuel Control State Fuel State Commanded Proportional Gain ===== All of the above met for	enable conditions for "HO2S Heater Resistance DTC's") > 54 °C > -40 °C > 60 seconds > 0.0 seconds > 4.0 seconds > 4.0 seconds 15 ≤ grams/second ≤ 43 1,000 ≤ RPM ≤ 3,000 < 87 % Ethanol > 70 kpa >= 125 mGrams = Closed Loop = TRUE = Enabled ≤ 100.0 mgrams = Not Defaulted not = Power Enrichment DFCO not active ≥ 0.0 % ===== > 2.0 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Insufficient Activity Bank 2 Sensor 1	P0154	This DTC determines if the O2 sensor circuit is open.	Oxygen Sensor Signal	> 1,700 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition	TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 150 seconds ≤ 87 % Ethanol	100 failures out of 125 samples. Frequency: Continuous 100 msec loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 2 Sensor 1	P0155	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.3 > amps > 1.2	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA 10.0 < Volts < 32.0 = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 2 tests per trip 10 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 2 Sensor 2	P0158	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	== Open Test Criteria == No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition ===== No Active DTC's Low Fuel Condition Diag Fuel Condition Initial delay after Open Test Criteria met (cold start condition) Initial delay after Open Test Criteria met (not cold start condition) Equivalence Ratio Air Per Cylinder Fuel Control State	===== TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 150 seconds ≤ 87 % Ethanol ===== MAP_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt _FA FuelInjectorCircuit_FA AIR System FA = False ≤ 87 % Ethanol > 105.0 seconds when engine soak time > 28,800 seconds > 105.0 seconds when engine soak time ≤ 28,800 seconds 0.9805 ≤ ratio ≤ 1.0996 50 ≤ mgrams ≤ 500 not = Power Enrichment	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for	> 3 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Learned Htr resistance Engine Coolant IAT Engine run Accum Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State ===== All of the above met for at least 2.5 seconds, and then the Force Cat Rich	= Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") > 54 °C > -40 °C > 60 seconds 1,025 ≤ RPM ≤ 2,325 975 ≤ RPM ≤ 2,375 3 ≤ gps ≤ 12 44.1 ≤ MPH ≤ 80.2 39.8 ≤ MPH ≤ 82.0 0.90 ≤ C/L Int ≤ 1.07 = TRUE not in control of purge not in estimate mode = enabled = not active = not active ≥ 180.0 sec 500 ≤ °C ≤ 980 = DFCO possible =====		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					intrusive stage is requested. ===== Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders ===== After above conditions are met: DFCO Mode is entered (wo driver initiated pedal input).	===== ≥ 680 mvolts = DFCO active ≤ 5 cylinders =====		

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 1	P015B	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test which runs in an enriched fuel mode to achieve the required response.	<p>The EWMA of the Pre O2 sensor normalized L2R time delay value</p> <p>OR</p> <p>[The Accumulated time monitored during the L2R Delayed Response Test (Gross failure).</p> <p>AND</p> <p>Pre O2 sensor voltage is</p> <p>OR</p> <p>At end of Cat Rich stage the Pre O2 sensor output is</p>	<p>> 0.6 EWMA (sec)</p> <p>≥ 2.0 Seconds</p> <p>< 325 mvolts</p> <p>< 680 mvolts</p>	<p>No Active DTC's</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition</p> <p>O2 Heater (pre sensor) on for</p>	<p>TPS_ThrottleAuthorityDefault MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA P0131, P0132, P0134</p> <p>10.0 < Volts < 32.0 = Not active = Not active = Not active = Not active = False = Not Valid, See definition of Green Sensor Delay Criteria for the following locations: B1S1, B2S1 (if applicable) and B1S2 in Supporting Tables tab.</p> <p>≥ 60 seconds</p>	<p>Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponsesActive = TRUE, multiple tests per trip are allowed</p>	<p>Type A, 1 Trips EWMA</p>

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Learned Htr resistance Engine Coolant IAT Engine run Accum Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State Number of fueled cylinders =====	= Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") > 54 °C > -40 °C > 60 seconds 1,025 ≤ RPM ≤ 2,325 975 ≤ RPM ≤ 2,375 3 ≤ gps ≤ 12 44.1 ≤ MPH ≤ 80.2 39.8 ≤ MPH ≤ 82.0 0.90 ≤ C/L Int ≤ 1.07 = TRUE not in control of purge not in estimate mode = enabled = not active = not active ≥ 180.0 sec 500 ≤ °C ≤ 980 = DFCO inhibit ≥ 1 cylinders =====		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					When above conditions are met: Fuel Enrich mode is entered.			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Learned Htr resistance Engine Coolant IAT Engine run Accum Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State ===== All of the above met for at least 2.5 seconds, and	= Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") > 54 °C > -40 °C > 60 seconds 1,025 ≤ RPM ≤ 2,325 975 ≤ RPM ≤ 2,375 3 ≤ gps ≤ 12 44.1 ≤ MPH ≤ 80.2 39.8 ≤ MPH ≤ 82.0 0.90 ≤ C/L Int ≤ 1.07 = TRUE not in control of purge not in estimate mode = enabled = not active = not active ≥ 180.0 sec 500 ≤ °C ≤ 980 = DFCO possible =====		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					then the Force Cat Rich intrusive stage is requested. ===== Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders ===== After above conditions are met: DFCO Mode is entered (wo driver initiated pedal input).	===== ≥ 680 mvolts = DFCO active ≤ 5 cylinders =====		

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 2 Sensor 1	P015D	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test which runs in an enriched fuel mode to achieve the required response.	<p>The EWMA of the Pre O2 sensor normalized L2R time delay value</p> <p>OR</p> <p>[The Accumulated time monitored during the L2R Delayed Response Test (Gross failure).</p> <p>AND</p> <p>Pre O2 sensor voltage is below]</p> <p>OR</p> <p>At end of Cat Rich stage the Pre O2 sensor output is</p>	<p>> 0.6 EWMA (sec)</p> <p>≥ 2.0 Seconds</p> <p>< 325 mvolts</p> <p>< 680 mvolts</p>	<p>No Active DTC's</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition</p> <p>O2 Heater (pre sensor) on for</p>	<p>TPS_ThrottleAuthorityDefault MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA P0131, P0132, P0134</p> <p>10.0 < Volts < 32.0 = Not active = Not active = Not active = Not active = False = Not Valid, See definition of Green Sensor Delay Criteria for the following locations: B1S1, B2S1 and B1S2 in Supporting Tables tab.</p> <p>≥ 60 seconds</p>	<p>Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponsesActive = TRUE, multiple tests per trip are allowed</p>	<p>Type A, 1 Trips EWMA</p>

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Learned Htr resistance Engine Coolant IAT Engine run Accum Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State Number of fueled cylinders ===== When above conditions	= Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") > 54 °C > -40 °C > 60 seconds 1,025 ≤ RPM ≤ 2,325 975 ≤ RPM ≤ 2,375 3 ≤ gps ≤ 12 44.1 ≤ MPH ≤ 80.2 39.8 ≤ MPH ≤ 82.0 0.90 ≤ C/L Int ≤ 1.07 = TRUE not in control of purge not in estimate mode = enabled = not active = not active ≥ 180.0 sec 500 ≤ °C ≤ 980 = DFCO inhibit ≥ 1 cylinders =====		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					are met: Fuel Enrich mode is entered.			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Insufficient Activity Bank 2 Sensor 2	P0160	This DTC determines if the O2 sensor circuit is open.	Oxygen Sensor Signal	> 1,700 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition	TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 150 seconds ≤ 87 % Ethanol	100 failures out of 125 samples. Frequency: Continuous 100 msec loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 2 Sensor 2	P0161	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.3 > amps > 1.2	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA 10.0 < Volts < 32.0 = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 2 tests per trip 10 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Catalyst Diag. Post O2 Diag. Device Control EVAP Diag.	Intrusive Test Not Active Intrusive Test Not Active Not Active "tank pull down" Not Active		
					No active DTC:	IAC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR System FA EvapExcessPrgePsb1_FA Ethanol Comp Snsr FA FuelInjectorCkt_FA EngMisfireDetected_FA EGRValvePerf_FA EGRValveCkt_FA MAP_EngVacuumStatus AmbPresDfltStatus TC_BoostPresSnsrFA O2Snsr_B1_Snsr_1_FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Rich Bank 1	P0172	<p>Determines if the fuel control system is in a rich condition, based on the filtered long-term fuel trim metric.</p> <p>There are two methods to determine a Rich fault. They are Passive and Intrusive. A Passive Test decision cannot be made when Purge is enabled. The Intrusive test is described below: Intrusive Test: When the filtered Purge Long Term Fuel Trim metric is ≤ 0.735, purge is ramped off to determine if excess purge vapor is the cause of the rich condition. If the filtered Purge Long Term Fuel Trim metric > 0.735, the test passes without checking the filtered Non-Purge Long Term Fuel Trim metric.</p> <p>Performing intrusive tests too frequently may also affect EVAP and EPAIII emissions, and the execution frequency of other diagnostics.</p>	<p>Passive Test: The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (a value > 1.05 effectively nullifies the short-term fuel trim criteria)</p> <p>Intrusive Test: For 3 out of 5 intrusive segments, the filtered Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (a value > 1.05 effectively nullifies the short-term fuel trim criteria)</p> <p>Segment Def'n: Segments can last up to 45 seconds and are separated by the lesser of 12 seconds of purge-on time or enough time to purge 11 grams of vapor.</p>	<p>≤ 0.730</p> <p>≤ 1.996</p> <p>≤ 0.735</p> <p>≤ 0.730</p> <p>≤ 1.996</p>		<p>Secondary Parameters and Enable Conditions are identical to those for P0171, with the exception that fuel level is not considered.</p>	<p>Frequency: 100 ms Continuous Loop</p>	<p>Type B, 2 Trips</p>

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			A maximum of 5 completed segments or 30 attempts are allowed for each intrusive test. After an intrusive test report is completed, another intrusive test cannot occur for 300 seconds to allow sufficient time to purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge-on Long Term fuel trim > 0.735 for at least 200 seconds, indicating that the canister has been purged.					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Catalyst Diag. Post O2 Diag. Device Control EVAP Diag. No active DTC:	Intrusive Test Not Active Intrusive Test Not Active Not Active "tank pull down" Not Active IAC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR System FA EvapExcessPrgePsb1_FA Ethanol Comp Snsr FA FuelInjectorCkt_FA EngMisfireDetected_FA EGRValvePerf_FA EGRValveCkt_FA MAP_EngVacuumStatus AmbPresDfltStatus TC_BoostPresSnsrFA O2Snsr_B2_Snsr_1_FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Rich Bank 2	P0175	<p>Determines if the fuel control system is in a rich condition, based on the filtered long-term fuel trim metric.</p> <p>There are two methods to determine a Rich fault. They are Passive and Intrusive. A Passive Test decision cannot be made when Purge is enabled. The Intrusive test is described below: Intrusive Test: When the filtered Purge Long Term Fuel Trim metric is ≤ 0.735, purge is ramped off to determine if excess purge vapor is the cause of the rich condition. If the filtered Purge Long Term Fuel Trim metric > 0.735, the test passes without checking the filtered Non-Purge Long Term Fuel Trim metric.</p> <p>Performing intrusive tests too frequently may also affect EVAP and EPAIII emissions, and the execution frequency of other diagnostics.</p>	<p>Passive Test: The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (a value > 1.05 effectively nullifies the short-term fuel trim criteria)</p> <p>Intrusive Test: For 3 out of 5 intrusive segments, the filtered Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (a value > 1.05 effectively nullifies the short-term fuel trim criteria)</p> <p>Segment Def'n: Segments can last up to 45 seconds and are separated by the lesser of 12 seconds of purge-on time or enough time to purge 11 grams of vapor.</p>	<p>≤ 0.730</p> <p>≤ 1.996</p> <p>≤ 0.735</p> <p>≤ 0.730</p> <p>≤ 1.996</p>		<p>Secondary Parameters and Enable Conditions are identical to those for P0174, with the exception that fuel level is not considered.</p>	<p>Frequency: 100 ms Continuous Loop</p>	<p>Type B, 2 Trips</p>

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>A maximum of 5 completed segments or 30 attempts are allowed for each intrusive test.</p> <p>After an intrusive test report is completed, another intrusive test cannot occur for 300 seconds to allow sufficient time to purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge-on Long Term fuel trim > 0.735 for at least 200 seconds, indicating that the canister has been purged.</p>					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Sensor Performance	P0191	This DTC detects a skewed fuel rail sensor via a comparison of measured pressure and commanded/ modeled pressure	Idle test (Low Side Fuel Pressure - High Side Fuel Pressure)	Enabled <= -0.650 MPa OR >= 0.600 MPa	Vehicle Speed Pedal Position = 0 for Battery Voltage Low Pressure Fuel Pump Pressure Engine Run Time	Enabled when a code clear is not active or not exiting device control Engine is not cranking <= 0.62 MPH 320 Counts (12.5ms per count) >= 11 Volts >= 0.275 MPa >= KtFHPD_t_PumpCntrlEngRunThrsh(see supporting tables) Enabled when a code clear is not active or not exiting device control Engine is not cranking >= KtFHPD_Cnt_SnsPrfIdlePumpOffDly(see supporting tables)	Idle Test > = 240 counts (12.5ms per count)	Type A, 1 Trips
			High Drive Test (Relief Pressure - Measured high Pressure)	Enabled <= -5.00 MPa	Delay counts after pump is turned off Engine Speed Desired High Side Pressure Vehicle Speed Battery Voltage Low Pressure Fuel Pump	Enabled when a code clear is not active or not exiting device control Engine is not cranking >= KtFHPD_Cnt_SnsPrfIdlePumpOffDly(see supporting tables)	----- KtFHPD_Cnt_SnsPrfIdlePumpOffDly runs in 12.5 ms loopHigh Drive Test >= 160 counts (12.5ms per count)	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			----- Low Drive Test (Commanded high Pressure - Measured high Pressure) AND Modeled Injection Pressure	----- Enabled >= 3.000 MPa >= 3.00 MPa	Pressure Engine Run Time ----- Engine Speed Desired High Side Pressure Vehicle Speed Battery Voltage Low Pressure Fuel Pump Pressure Engine Run Time	>= KtFHPD_t_PumpCntrlEng RunThrsh(see supporting tables) Enabled when a code clear is not active or not exiting device control Engine is not cranking ----- 1,200 <= RPM <= 2,400 5.00 <= MPa <= 7.00 >= 37.28 MPH >= 11 Volts >= 0.275 MPa >= KtFHPD_t_PumpCntrlEng RunThrsh(see supporting tables) Enabled when a code clear is not active or not exiting device control	----- LoDrive Test >= 240 counts (12.5ms per count)	
			----- Sensor Stuck Test Measured High Pressure (max - min)	----- Enabled <= 0.100 MPa	----- Engine Speed Vehicle Speed	>= KtFHPD_t_PumpCntrlEng RunThrsh(see supporting tables) Enabled when a code clear is not active or not exiting device control Engine is not cranking ----- >= 2,000 RPM >= 18.64 MPH Enabled when a code clear is not active or not exiting device control Engine is not cranking Additional Enable Conditions: All must be	----- Stuck Test Engine Run Time >= KtFHPD_t_Pump CntrlEngRunThr sh(See Supporting Tables) or Accumulating engine crank time >= KtFHPD t SnsP	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and Manufacturers enable counter is 0)Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active Fuel InjCkt Not (FA or TFTKO) EST Driver Not(FA) Misfire detected Not(FA) MAFR sensor Not (FA) MAPR sensor Not (FA) APSR Pedal sensor Not(FA) TPSR sensor Not (FA) VSPR speed sensor Not(FA) SystemRPM Not (FA) Manual Clutch not engaged or vehicle has automatic transmission All cylinder are fuel enabled	rfStuckCrankTm out(See Supporting Tables)	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Barometric Pressure Inlet Air Temp Fuel Temp	and >= 70.0 KPA >= -10.0 DegC -10 <= Temp degC <= 100		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Sensor Out of Range Low	P0192	This DTC checks the circuit for electrical integrity during operation.	High Pressure Fuel Sensor	<= 5 % of 5Vref	Battery Voltage	>= 11 Volts Engine Running	Both Run Continuously Engine Synchronouse Mode 800 failures out of 1,000 samples Time Based Mode 400 failures out of 500 samples 6.25 ms Sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Sensor Out of Range High	P0193	This DTC checks the circuit for electrical integrity during operation.	High Pressure Fuel Sensor	>= 95 % of 5Vref	Battery Voltage	>= 11 Volts Engine Running	Both Run Continuously Engine Synchronous Mode 800 failures out of 1,000 samples Time Based Mode 400 failures out of 500 samples 6.25 ms Sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Open Circuit (SIDI only)	P0201	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector 1 has determined to be an open circuit		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Open Circuit (SIDI only)	P0202	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector 2 has determined to be an open circuit		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Open Circuit (SIDI only)	P0203	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector has determined to be an open circuit		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Open Circuit (SIDI only)	P0204	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector has determined to be an open circuit		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 Open Circuit (SIDI only)	P0205	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector 5 has determined to be an open circuit		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 Open Circuit (SIDI only)	P0206	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector 6 has determined to be an open circuit		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit Low	P0222	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage <	0.250		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit High	P0223	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage >	4.590		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to ground	P0261	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to power	P0262	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to ground	P0264	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector 2 low side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to power	P0265	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to ground	P0267	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to power	P0268	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to ground	P0270	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to power	P0271	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 Low side circuit shorted to ground	P0273	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 Low side circuit shorted to power	P0274	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 Low side circuit shorted to ground	P0276	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 Low side circuit shorted to power	P0277	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector low side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Random Misfire Detected	P0300	These DTC's will determine if a random or a cylinder specific misfire is occurring by monitoring various terms derived from crankshaft velocity. The rate of misfire over an interval is compared to both emissions and catalyst damaging thresholds. The pattern of crankshaft acceleration after the misfire is checked to differentiate between real misfire and other sources of crank shaft noise.	Deceleration Value vs. Engine Speed and Engine load	[(>Idle_SCD_dt AND > Idle_SCD_ddt) OR (>SCD_dt AND > SCD_ddt) OR (>Idle_Cyl_Mode_dt AND > Idle_Cyl_Mode_ddt) OR (>Cyl Mode dt AND > Cyl Mode ddt) OR (>Rev Mode Table) OR (> AFM Table in Cyl Deactivation mode)] - see details on Supporting Tables Tab (P0300 Section)	Engine Run Time Engine Coolant Temp Or If ECT at startup Then ECT System Voltage + Throttle delta - Throttle delta Early Termination option: (used on plug ins that may not have enough engine run time at end of trip for normal interval to complete.)	> 2 crankshaft revolution -7 °C < ECT < 127 °C < -7 °C 21 °C < ECT < 127 °C 9.00 < volts < 32.00 < 60.00 % per 25 ms < 60.00 % per 25 ms Not Enabled	Emission Exceedence = any (5) failed 200 rev blocks out of (16) 200 rev block tests Failure reported for (1) Exceedence in 1st (16) 200 rev block tests, or (4) Exceedences thereafter. OR when Early Termination Reporting = Enabled and engine rev > 1,000 revs and < 3,200 revs at end of trip	Type B, 2 Trips (Mil Flashes with Catalyst Damaging Misfire)	
Cylinder 1 Misfire Detected	P0301		The equation used to calculate deceleration value is tailored to specific vehicle operating conditions. Tables used are 1st tables encountered that are not max of range.	Misfire Percent Emission Failure Threshold	≥ 0.75 % P0300				
Cylinder 2 Misfire Detected	P0302		Undetectable region at a given speed/load point is where all tables are max of range point. see Algorithm Description Document for additional details.	Misfire Percent Catalyst Damage	> "Catalyst_Damaging Misfire_Percentage" Table whenever secondary conditions are met.	(at low speed/loads, one cylinder may not cause cat damage)			
Cylinder 3 Misfire Detected	P0303					Engine Speed Engine Load Misfire counts	> 1,000 rpm AND > 19 % load AND < 180 counts on one cylinder	Failure reported for (1) Exceedence in 1st (16) 200 rev block tests, or (4) Exceedences thereafter.	
Cylinder 4 Misfire Detected	P0304								
If cylinders present:									
Cylinder 5 Misfire Detected	P0305								
Cylinder 6 Misfire Detected	P0306							any Catalyst Exceedence = (1) 200 rev block as data supports for catalyst damage.	
Cylinder 7 Misfire Detected	P0307								
Cylinder 8 Misfire Detected	P0308		When engine speed and load are less than the FTP calcs (3) catalyst damage exceedences are allowed.	≤ 0 FTP rpm AND ≤ 0 FTP % load			Failure reported with (1 or 3) Exceedences in FTP, or (1) Exceedence outside FTP.		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Engine Speed	350 < rpm < ((Engine Over Speed Limit) - 150 Engine speed limit is a function of inputs like Gear and temperature see Engine OverSpeed Limit in supporting tables	Continuous 4 cycle delay	
				disable conditions:	No active DTCs:	TPS_FA EnginePowerLimited MAF_SensorTFTKO MAP_SensorTFTKO IAT_SensorTFTKO ECT_Sensor_Ckt_TFTKO 5VoltReferenceB_FA CrankSensorTFTKO CrankSensorFA CamLctnIntFA CamLctnExhFA CamSensorAnyLctnTFTKO O AnyCamPhaser_FA AnyCamPhaser_TFTKO AmbPresDfstdStatus	4 cycle delay	
					P0315 & engine speed	> 1,000 rpm	4 cycle delay	
					Fuel Level Low	LowFuelConditionDiagnostic	500 cycle delay	
					Cam and Crank Sensors	in sync with each other	4 cycle delay	
					Misfire requests TCC unlock	Not honored because Transmission in hot mode or POPD intrusive	4 cycle delay	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						diagnostic running		
					Fuel System Status	≠ Fuel Cut	4 cycle delay	
					Active Fuel Management	Transition in progress	7 cycle delay	
					Undetectable engine speed and engine load region	invalid speed load range in decel index tables	4 cycle delay	
					Abusive Engine Over Speed	> 8,192 rpm	0 cycle delay	
					Below zero torque (except CARB approved 3000 rpm to redline triangle.)	< ZeroTorqueEngineLoad in Supporting Tables	4 cycle delay	
					Below zero torque: TPS Veh Speed	≤ 1 % > 40 mph	4 cycle delay	
					EGR Intrusive test	Active	0 cycle delay	
					Manual Trans	Clutch shift	4 cycle delay	
					Throttle Position AND Automatic transmission shift	> 95.00 %	7 cycle delay	
					Driveline Ring Filter active After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early. Filter Driveline ring:	> "Ring Filter" # of engine cycles after misfire in Supporting Tables		
					Stop filter early:	> "Number of Normals" # of engine cycles after		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Abnormal engine speed oscillations: (Rough road etc) Off Idle, number of consecutive decelerating cylinders after "misfire": (Number of decels can vary with misfire detection equation)</p>	<p>misfire in Supporting Tables tab</p>		
					<p>TPS Engine Speed Veh Speed</p>	<p>> 3 % > 900 rpm > 3 mph</p>		
					<p>Consecutive decels while in SCD Mode Cyl Mode Rev Mode</p>	<p>> Abnormal SCD Mode > Abnormal Cyl Mode > Abnormal Rev Mode in Supporting Tables</p>		
					<p>Misfire Crankshaft Pattern Recognition checks each "misfire" candidate in 100 engine Cycle test to see if it looks like real misfire, or some disturbance like rough road. The check is based on a multiplier times the ddt_jerk value used to detect misfire at that speed and load. At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present.</p>			
					<p>Pattern Recog Enabled:</p>	<p>Enabled</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position System Variation Not Learned	P0315	Monitor for valid crankshaft error compensation factors	Sum of Compensation factors. Each Cylinder pair shares one compensation factor. A perfect factor would be 1.0000. Unlearned factors are defaulted out of range so the sum of factors would be out of range.	≥ 3.0040 OR ≤ 2.9960	OBD Manufacturer Enable Counter	MEC = 0	0.50 seconds Frequency Continuous100 msec	Type A, 1 Trips

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Per Cylinder	P0324	This diagnostic checks for knock sensor performance out of the normal expected range on a per cylinder basis due to: 1. Excessive knock or 2. Abnormal engine noise or 3. Flat signal	Common Enable Criteria (Applies to all 3 parts of the performance diag)		Diagnostic Enabled?	Yes		Type B, 2 Trips
					Engine Run Time	≥ 2.0 seconds		
					Engine Speed	≤ 8,500 RPM		
					Engine Air Flow	≥ 0 mg/cylinder and ≤ 2,000 mg/cylinder		
					ECT	≥ -40 deg's C		
					IAT	≥ -40 deg's C		
			Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag:				First Order Lag Filters with Weight Coefficients	
			1. Excessive Knock Diag: Filtered Knock Intensity	> 8.00 (no units)	Engine Speed		Weight Coefficient = 0.0300	
			VaKNKD_k_PerfCylKnock IntFilt (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)		Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	≥ 400 RPM ≥ 132 Revs	Updated each engine event	
			2. Abnormal Noise Diag: Filtered FFT Intensity	< Abnormal Noise Threshold (see Supporting Tables)	Engine Speed	≥ 2,200 RPM	Weight Coefficient = 0.0200	
			(where 'FFT Intensity' = Non-knocking, background noise)		Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	≥ 200 Revs	Updated each engine event	
			3. Flat Signal Diag:	< 0.008 (no units)	Engine Speed	≥ 8,500 RPM		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock) VaKNKD_k_PerfCylFlatFil tInt		Cumulative Number of Engine Revs Above Min Eng Speed (per keycycle)	≥ 400 Revs	Weight Coefficient = 0.010 Updated each engine event	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank 1	P0325	This diagnostic checks for an open in the knock sensor circuit	Filtered FFT Output	> OpenCktThrshMin and < OpenCktThrshMax See Supporting Tables for OpenCktThrshMin & OpenCktThrshMax	Diagnostic Enabled? Engine Run Time Engine Speed Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above) Engine Air Flow ECT IAT	Yes ≥ 2.0 seconds ≥ 400 RPM and ≤ 8,500 RPM ≥ 133 revs ≥ 50 mg/cylinder and ≤ 2,000 mg/cylinder ≥ -40 deg's C ≥ -40 deg's C	First Order Lag Filter with Weight Coefficient Weight Coefficient = 0.0100 Updated each engine event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Bank 1	P0326	This diagnostic checks for knock sensor performance out of the normal expected range, on a per sensor basis, due to 1. Excessive knock or 2. Abnormal engine noise or 3. Flat signal	Common Enable Criteria (Applies to all 3 parts of the performance diag)		Diagnostic Enabled?	Yes		Type B, 2 Trips
			Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag:		Engine Run Time	≥ 2.0 seconds		
			1. Excessive Knock Diag: Filtered Knock Intensity	> 8.00 (no units)	Engine Speed	≤ 8,500 RPM	Engine Air Flow	
		(where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)		ECT	≥ -40 deg's C			
				IAT	≥ -40 deg's C			
			2. Abnormal Noise Diag: Filtered FFT Intensity:	< Abnormal Noise Threshold (see Supporting Tables)	Engine Speed	≥ 400 RPM		
		(where 'FFT Intensity' = Non-knocking, background noise)			Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	≥ 133 Revs	Weight Coefficient = 0.0100	Updated each engine event
			3. Flat Signal Diag:	< 0.008 (no units)	Engine Speed	≥ 2,200 RPM		
					Cumulative Engine Revs Above Min Eng Speed (per key cycle)	≥ 199 Revs	Weight Coefficient = 0.0067	Updated each engine event
					Engine Speed Cumulative	≥ 8,500 RPM		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock)		Number of Engine Revs Above Min Eng Speed (per keycycle)	≥ 133 Revs	WeightCoefficient = 0.010 Updated each engine event	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 1	P0327	This diagnostic checks for an out of range low knock sensor signal	Sensor Input or Return Signal Line	< 8.0 Percent (of 5 V reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 1	P0328	This diagnostic checks for an out of range high knock sensor signal	Sensor Input or Return Signal Line	> 39.0 Percent (of 5 Volt Reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank 2	P0330	This diagnostic checks for an open in the knock sensor circuit	Filtered FFT Output	> OpenCktThrshMin and < OpenCktThrshMax See Supporting Tables for OpenCktThrshMin & OpenCktThrshMax	Diagnostic Enabled? Engine Run Time Engine Speed Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above) Engine Air Flow ECT IAT	Yes ≥ 2.0 seconds ≥ 400 RPM and ≤ 8,500 RPM 133 revs ≥ 50 mg/cylinder and ≤ 2,000 mg/cylinder ≥ -40 deg's C ≥ -40 deg's C	First Order Lag Filter with Weight Coefficient Weight Coefficient = 0.0100 Updated each engine event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Bank 2	P0331	This diagnostic checks for knock sensor performance out of the normal expected range, on a per sensor basis, due to 1. Excessive knock or 2. Abnormal engine noise on a per bank basis or 3. Flat signal	Common Enable Criteria (Applies to all 3 parts of the performance diag)		Diagnostic Enabled?	Yes		Type B, 2 Trips
			Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag:		Engine Run Time	≥ 2.0 seconds		
			1. Excessive Knock Diag: Filtered Knock Intensity	> 8.00 (no units)	Engine Speed	≤ 8,500 RPM		
			(where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)		Engine Air Flow	≥ 0 mg/cylinder and ≤ 2,000 mg/cylinder		
			2. Abnormal Noise Diag: Filtered FFT Intensity:	< Abnormal Noise Threshold (see Supporting Tables)	ECT	≥ -40 deg's C		
			(where 'FFT Intensity' = Non-knocking, background noise)		IAT	≥ -40 deg's C		
			3. Flat Signal Diag: Filtered Signal Delta (Current FFT Intensity -	< 0.008 (no units)	Engine Speed	≥ 400 RPM	First Order Lag Filters with Weight Coefficients	
					Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	≥ 133 Revs	Weight Coefficient = 0.0100	
					Engine Speed	≥ 2,200 RPM	Updated each engine event	
					Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	≥ 199 Revs	Weight Coefficient = 0.0067	
					Engine Speed Cumulative Number of Engine Revs Above Min Eng Speed	≥ 8,500 RPM ≥ 133 Revs	Updated each engine event	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Ave_Intensity_No-Knock)		(per keycycle)		WeightCoefficient t = 0.010 Updated each engine event	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 2	P0332	This diagnostic checks for an out of range low knock sensor signal	Sensor Input or Return Signal Line	< 8.0 Percent (of 5 Volt Reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 2	P0333	This diagnostic checks for an out of range high knock sensor signal	Sensor Input or Return Signal Line	> 39.00 Percent (of 5 Volt Reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Circuit	P0335	Determines if a fault exists with the crank position sensor signal	Time since last crankshaft position sensor pulse received	>= 4.0 seconds	Starter engaged AND (cam pulses being received OR (DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow	= FALSE = FALSE = FALSE > 3.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips
			No crankshaft pulses received	>= 0.1 seconds	Engine is Running Starter is not engaged No DTC Active:	5VoltReferenceB_FA	Continuous every 12.5 msec	
			No crankshaft pulses received		Engine is Running OR Starter is engaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA P0365 P0366	2 failures out of 10 samples One sample per engine revolution	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Performance	P0336	Determines if a performance fault exists with the crank position sensor signal	Time in which 20 or more crank re-synchronizations occur	< 25.0 seconds	Engine Air Flow Cam-based engine speed No DTC Active:	>= 3.0 grams/second > 450 RPM 5VoltReferenceB_FA P0335	Continuous every 250 msec	Type B, 2 Trips
			No crankshaft synchronization gap found	>= 0.4 seconds	Engine is Running Starter is not engaged No DTC Active:	5VoltReferenceB_FA	Continuous every 12.5 msec	
			Time since starter engaged without detecting crankshaft synchronization gap	>= 1.5 seconds	Starter engaged AND (cam pulses being received OR (DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow	= FALSE = FALSE = FALSE > 3.0 grams/second))	Continuous every 100 msec	
			Crank pulses received in one engine revolution OR Crank pulses received in one engine revolution	< 51 > 65	Engine is Running OR Starter is engaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA P0365 P0366	8 failures out of 10 samples One sample per engine revolution	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor A	P0340	Determines if a fault exists with the cam position bank 1 sensor A signal	Time since last camshaft position sensor pulse received	>= 5.5 seconds	Starter engaged AND (cam pulses being received OR (DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow	= FALSE = FALSE = FALSE > 3.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips
			OR Time that starter has been engaged without a camshaft sensor pulse	>= 4.0 seconds				
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged No DTC Active:	5VoltReferenceA_FA	Continuous every 100 msec	
			No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	Continuous every MEDRES event	
			The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor A	P0341	Determines if a performance fault exists with the cam position bank 1 sensor A signal	The number of camshaft pulses received during first 12 MEDRES events is OR (There are 12 MEDRES events per engine cycle)	< 4 > 6	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 2 Sensor A	P0345	Determines if a fault exists with the cam position bank 2 sensor A signal	Time since last camshaft position sensor pulse received	>= 5.5 seconds	Starter engaged AND (cam pulses being received	= FALSE = FALSE = FALSE > 3.0 grams/second)	Continuous every 100 msec	Type B, 2 Trips
			OR					
			Time that starter has been engaged without a camshaft sensor pulse	>= 4.0 seconds	OR (DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow			
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged No DTC Active:			
No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	Continuous every MEDRES event				
The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 2 Sensor A	P0346	Determines if a performance fault exists with the cam position bank 2 sensor A signal	The number of camshaft pulses received during first 12 MEDRES events is OR (There are 12 MEDRES events per engine cycle)	< 4 > 6	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT	P0351	This diagnostic checks the circuit for electrical integrity during operation. Monitors EST for Cylinder 1 (Cylinders 1 and 4 for V6 with waste spark)	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT	P0352	This diagnostic checks the circuit for electrical integrity during operation. Monitors EST for Cylinder 2 (Cylinders 2 and 5 for V6 with waste spark)	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT	P0353	This diagnostic checks the circuit for electrical integrity during operation. Monitors EST for Cylinder 3 (Cylinders 3 and 6 for V6 with waste spark)	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT	P0354	This diagnostic checks the circuit for electrical integrity during operation. Monitors EST for Cylinder 4 (if applicable)	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #5 CIRCUIT	P0355	This diagnostic checks the circuit for electrical integrity during operation. Monitors EST for Cylinder 5 (if applicable)	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #6 CIRCUIT	P0356	This diagnostic checks the circuit for electrical integrity during operation. Monitors EST for Cylinder 6 (if applicable)	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor B	P0365	Determines if a fault exists with the cam position bank 1 sensor B signal	Time since last camshaft position sensor pulse received	>= 5.5 seconds	Starter engaged AND (cam pulses being received	= FALSE = FALSE = FALSE > 3.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips
			OR					
			Time that starter has been engaged without a camshaft sensor pulse	>= 4.0 seconds	OR (DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow			
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged No DTC Active:			
No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	Continuous every MEDRES event				
The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor B	P0366	Determines if a performance fault exists with the cam position bank 1 sensor B signal	The number of camshaft pulses received during first 12 MEDRES events is OR (There are 12 MEDRES events per engine cycle)	< 4 > 6	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 2 Sensor B	P0390	Determines if a fault exists with the cam position bank 2 sensor B signal	Time since last camshaft position sensor pulse received	>= 5.5 seconds	Starter engaged AND (cam pulses being received	= FALSE = FALSE = FALSE > 3.0 grams/second)	Continuous every 100 msec	Type B, 2 Trips
			OR					
			Time that starter has been engaged without a camshaft sensor pulse	>= 4.0 seconds	OR (DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow			
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged No DTC Active:			
No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	Continuous every MEDRES event				
The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 2 Sensor B	P0391	Determines if a performance fault exists with the cam position bank 2 sensor B signal	The number of camshaft pulses received during first 12 MEDRES events is OR (There are 12 MEDRES events per engine cycle)	< 4 > 6	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Solenoid Control Circuit	P0412	This DTC checks the AIR solenoid circuit for electrical integrity	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.	20 failures out of 25 samples	System Voltage	> 10.0 Volts < 32.0	25 samples (250 ms per sample) Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Pump Control Circuit	P0418	This DTC checks the AIR Pump circuit for electrical integrity	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.	20 failures out of 25 samples	System Voltage	> 10.0 Volts < 32.0	25 samples (250 ms per sample) Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 1	P0420 - Applies to applications that use the Idle Catalyst Monitor Algorithm	The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (I.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Lean and Rich A/F excursions Normalized Ratio OSC Value Calculation Information and Definitions = 1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time) 2. BestFailing OSC value from a calibration table (based on temp and exhaust gas flow) 3. WorstPassing OSC value (based on temp and exhaust gas flow) Normalized Ratio Calculation = (1-2) / (3-2)	Normalized Ratio OSC Value (EWMA filtered)	< 0.34	<u>There must be a valid idle period. The criteria are:</u> Driver must be off the accel pedal. This checks that the final accel pedal position (comprehending deadband and hysteresis) is essentially zero. Idle Speed Control System Is Active Vehicle Speed Engine speed Engine run time Tests attempted this trip The catalyst diagnostic has not yet completed for the current trip. <u>Catalyst Idle Conditions Met Criteria is satisfied which includes the General Enable met and the Valid Idle Period Criteria met. as well as:</u>	< 1.24 MPH > 965 RPM for a minimum of 5 seconds since end of last idle period. > MinimumEngineRunTime, This is a function of Coolant Temperature, please see Supporting Tables < 255	1 test attempted per valid idle period Minimum of 1 test per trip Maximum of 8 tests per trip Frequency: Fueling Related : 12.5 ms OSC Measurements: 100 ms Temp Prediction: 1000ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part. The Catalyst Monitoring Test is done during idle. Several conditions must be met in order to execute this test. These conditions and their related values are listed in the secondary parameters area of this document.</p>			<p>Green Converter Delay</p> <p>Induction Air</p> <p>Intrusive test(s): Fueltrim Post O2 EVAP EGROther vehicle functions:</p> <p>Power Take Off RunCrank Voltage Ethanol Estimation</p> <p>ECT</p> <p>Barometric Pressure</p> <p>Idle Time before going intrusive is</p> <p>Idle time is incremented if Vehicle speed</p> <p>Short Term Fuel Trim</p>	<p>Not Active</p> <p>> -20 ° C < 250 ° C</p> <p>Not Active</p> <p>Not Active > 10.90 Volts NOT in Progress</p> <p>> 40 ° C < 127 ° C</p> <p>> 70 KPA</p> <p>< 50 Seconds</p> <p>< 1.24 MPH and the drivers foot is off accel pedal and the idle speed control system is active as identified in the Valid Idle Period Criteria section.</p> <p>> 0.60 < 1.40</p> <p>> 450.00 degC</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Predicted catalyst temp AND Engine Airflow</p> <p>for at least</p> <p>with a closed throttle time</p> <p>Also, in order to increment the WarmedUpEvents counter, either the vehicle speed must exceed the vehicle speed cal or the driver must NOT be off the accel pedal as stated in the Valid Idle Period Criteria section above.</p> <p>Closed loop fueling (Please see "Closed Loop Enable Criteria" section of the "Supporting Tables" tab for details.)</p>	<p>> MinAirflowToWarmCatalyst table (g/s) (refer to "Supporting Tables" tab) (Based on engine coolant at the time the WarmedUpEvents counter resets to 0.)</p> <p>15 seconds</p> <p>< 60 seconds consecutively (closed throttle consideration involves having the driver off the accel pedal as stated in the Valid Idle Period Criteria Section) .</p> <p>Enabled in Drive Range</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Normalized Ratio value is</p> <p>Maximum RSR tests to detect failure when RSR is enabled.</p> <p><u>Green Converter Delay Criteria</u> This is part of the check for the Catalyst Idle Conditions Met Criteria section</p> <p>The diagnostic will not be enabled until the following has been met:</p> <p>Predicted catalyst temperature</p> <p>for</p> <p>Note: this feature is only enabled when the vehicle is new and cannot be enabled in service</p> <p>PTO</p> <p><u>General Enable</u> DTC's Not Set</p>	<p>24</p> <p>> 0 ° C</p> <p>0 seconds non-continuously.</p> <p>Not Active</p> <p>MAF_SensorFA MAF_SensorTFTKO AmbPresDfstdStatus IAT_SensorCircuitFA IAT_SensorCircuitTFTKO ECT_Sensor_FA O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA O2S_Bank_2_Sensor_1_FA</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						O2S_Bank_2_Sensor_2_ FA FuelTrimSystemB1_FA FuelTrimSystemB1_TFTK O FuelTrimSystemB2_FA FuelTrimSystemB2_TFTK O EngineMisfireDetected_F A EvapPurgeSolenoidCircuit _FA IAC_SystemRPM_FA EGRValvePerformance_F A EGRValveCircuit_FA CamSensorAnyLocationF A CrankSensorFA TPS_Performance_FA EnginePowerLimited		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 2	P0430 - Applies to applications that use the Idle Catalyst Monitor Algorithm	The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (I.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Lean and Rich A/F excursions Normalized Ratio OSC Value Calculation Information and Definitions = 1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time) 2. BestFailing OSC value from a calibration table (based on temp and exhaust gas flow) 3. WorstPassing OSC value (based on temp and exhaust gas flow) Normalized Ratio Calculation = (1-2) / (3-2)	Normalized Ratio OSC Value (EWMA filtered)	< 0.33	<u>There must be a valid idle period. The criteria are:</u> Driver must be off the accel pedal. This checks that the final accel pedal position (comprehending deadband and hysteresis) is essentially zero. Idle Speed Control System Is Active Vehicle Speed Engine speed Engine run time Tests attempted this trip The catalyst diagnostic has not yet completed for the current trip. <u>Catalyst Idle Conditions Met Criteria is satisfied which includes the General Enable met and the Valid Idle Period</u>	< 1.24 MPH > 965 RPM for a minimum of 5 seconds since end of last idle period. > MinimumEngineRunTime, This is a function of Coolant Temperature, please see Supporting Tables < 255	1 test attempted per valid idle period Minimum of 1 test per trip Maximum of 8 tests per trip Frequency: Fueling Related : 12.5 ms OSC Measurements: 100 ms Temp Prediction: 1000ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part. The Catalyst Monitoring Test is done during idle. Several conditions must be met in order to execute this test. These conditions and their related values are listed in the secondary parameters area of this document.			<p><u>Criteria met, as well as:</u></p> <p>Green Converter Delay</p> <p>Induction Air</p> <p>Intrusive test(s): Fueltrim Post O2 EVAP EGROther vehicle functions:</p> <p>Power Take Off RunCrank Voltage Ethanol Estimation</p> <p>ECT</p> <p>Barometric Pressure</p> <p>Idle Time before going intrusive is</p> <p>Idle time is incremented if Vehicle speed</p> <p>Short Term Fuel Trim</p> <p>Predicted catalyst temp</p>	<p>Not Active</p> <p>> -20 ° C < 250 ° C</p> <p>Not Active</p> <p>Not Active > 10.90 Volts NOT in Progress</p> <p>> 40 ° C < 127 ° C</p> <p>> 70 KPA</p> <p>< 50 Seconds</p> <p>< 1.24 MPH and the drivers foot is off accel pedal and the idle speed control system is active as identified in the Valid Idle Period Criteria section.</p> <p>> 0.60 < 1.40</p> <p>> 450.00 degC</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>AND</p> <p>Engine Airflow</p> <p>for at least</p> <p>with a closed throttle time</p> <p>Also, in order to increment the WarmedUpEvents counter, either the vehicle speed must exceed the vehicle speed cal or the driver must NOT be off the accel pedal as stated in the Valid Idle Period Criteria section above.</p> <p>Closed loop fueling (Please see "Closed Loop Enable Criteria" section of the "Supporting Tables" tab for details.)</p> <p>PRNDL</p> <p>Idle Stable Criteria:</p>	<p>></p> <p>MinAirflowToWarmCatalyst table (g/s) (refer to "Supporting Tables" tab) (Based on engine coolant at the time the WarmedUpEvents counter resets to 0.)</p> <p>15 seconds</p> <p>< 60 seconds consecutively (closed throttle consideration involves having the driver off the accel pedal as stated in the Valid Idle Period Criteria Section) .</p> <p>Enabled in Drive Range on an Auto Transmission vehicle.</p> <p>Must hold true from after</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>MAF</p> <p>Predicted catalyst temperature</p> <p><u>Engine Fueling Criteria at Beginning of Idle Period</u> The following fueling related must also be met from between 4 and 7 seconds after the Catalyst Idle Conditions Met Criteria has been met for at least 4 seconds prior to allowing intrusive control:</p> <p>Number of pre-O2 switches</p> <p>Short Term Fuel Trim Avg</p> <p>Rapid Step Response (RSR) feature will initiate multiple tests:</p> <p>If the difference between current EWMA value and the current OSC Normalized Ratio value is</p> <p>and the current OSC Normalized Ratio value is</p> <p>Maximum RSR tests to</p>	<p>Catalyst Idle Conditions Met to the end of test</p> <p>> 3.50 g/s < 12.50 g/s</p> <p>< 900 degC</p> <p>>= 2</p> <p>> 0.96 < 1.04</p> <p>> 0.52</p> <p>< 0.17</p> <p>24</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>detect failure when RSR is enabled.</p> <p><u>Green Converter Delay Criteria</u> This is part of the check for the Catalyst Idle Conditions Met Criteria section</p> <p>The diagnostic will not be enabled until the following has been met:</p> <p>Predicted catalyst temperature</p> <p>for</p> <p>Note: this feature is only enabled when the vehicle is new and cannot be enabled in service</p> <p>PTO</p> <p>General Enable DTC's Not Set</p>	<p>> 0 ° C</p> <p>0 seconds non-continuously.</p> <p>Not Active</p> <p>MAF_SensorFA MAF_SensorTFTKO AmbPresDfItDStatus IAT_SensorCircuitFA IAT_SensorCircuitTFTKO ECT_Sensor_FA O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA O2S_Bank_2_Sensor_1_FA</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						O2S_Bank_2_Sensor_2_ FA FuelTrimSystemB1_FA FuelTrimSystemB1_TFTK O FuelTrimSystemB2_FA FuelTrimSystemB2_TFTK O EngineMisfireDetected_F A EvapPurgeSolenoidCircuit _FA IAC_SystemRPM_FA EGRValvePerformance_F A EGRValveCircuit_FA CamSensorAnyLocationF A CrankSensorFA TPS_Performance_FA EnginePowerLimited		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>value in Estimate of Ambient Temperature Valid Conditioning Time. Please see "P0442: Estimate of Ambient Temperature Valid Conditioning Time" in Supporting Tables Tab.</p> <p>1. High Fuel Volatility</p> <p>During the volatility phase, pressure in the fuel tank is integrated vs. time. If the integrated pressure is then test aborts and unsuccessful attempts is incremented.</p> <p>OR</p> <p>2. Vacuum Refueling Detected</p> <p>See P0454 Fault Code for information on vacuum refueling algorithm.</p> <p>OR</p> <p>3. Fuel Level Refueling Detected</p> <p>See P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>4. Vacuum Out of Range and No Refueling</p>	<p>< -5</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>5. Vacuum Out of Range and Refueling Detected</p> <p>See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>6. Vent Valve Override Failed</p> <p>Device control using an off-board tool to control the vent solenoid, cannot exceed during the EONV test</p> <p>OR</p> <p>7. Key up during EONV test</p> <p>No active DTCs:</p>	0.50 seconds		
						<p>MAF_SensorFA ECT_Sensor_FA IAT_SensorFA VehicleSpeedSensor_FA IgnitionOffTimeValid AmbientAirDefault</p>		
						<p>P0443 P0446</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						P0449 P0452 P0453 P0455 P0496		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Canister Purge Solenoid Valve Circuit (ODM) (Not Sealed Fuel System)	P0443	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		PT Relay Voltage	Voltage \geq 11 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent System Performance (Not Sealed Fuel System)	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filler, vent hose or EVAP canister. This test runs with normal purge and vent valve is open.	Vent Restriction Prep Test: Vented Vacuum for OR Vented Vacuum for Vent Restriction Test: Tank Vacuum for before Purge Volume After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time.	< -623 Pa 60 seconds > 1,245 Pa 60 seconds > 2,989 Pa 5 seconds ≥ 6 liters	Fuel Level System Voltage Startup IAT Startup ECT BARO No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts 4 °C ≤ Temperature ≤ 30 °C ≤ 35 °C ≥ 70 kPa MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454	Once per Cold Start Time is dependent on driving conditions Maximum time before test abort is 1,000 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent Solenoid Control Circuit (ODM) (Not Sealed Fuel System)	P0449	This DTC checks the circuit for electrical integrity during operation. If the P0449 is active, an intrusive test is performed with the vent solenoid commanded closed for 15 seconds.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.				20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Performance (Not Sealed Fuel System)	P0451	The DTC will be set if the fuel tank vacuum sensor is out of range when it tries to re-zero prior to the phase-1 or phase-2 portions of the engine-off natural vacuum small leak test.	<p>The tank vacuum sensor voltage is compared to a window about the nominal sensor voltage offset (~1.5 volts)</p> <p>Upper voltage threshold (voltage addition above the nominal voltage)</p> <p>Lower voltage threshold (voltage subtraction below the nominal voltage)</p> <p>The difference between tank vacuum sensor voltage and the nominal offset voltage is then normalized against the appropriate threshold listed above to produce a ratio between 0.0 and 1.0. This normalized re-zero ratio is then filtered with a EWMA (with 0= perfect pass and 1=perfect fail).</p> <p>When EWMA is the DTC light is illuminated.</p> <p>The DTC light can be turned off if the EWMA is and stays below the EWMA fail threshold for 2 additional consecutive trips.</p>	<p>0.2 volts</p> <p>0.2 volts</p> <p>> 0.73 (EWMA Fail Threshold),</p> <p>≤ 0.40 (EWMA Re-Pass Threshold)</p>	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		This test is executed during an engine-off natural vacuum small leak test. The number of times that it executes can range from zero to two per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.	Type A, 1 Trips EWMA Average run length: 6 Run length is 2 trips after code clear or non-volatile reset

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Low Voltage (Not Sealed Fuel System)	P0452	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too low out of range.	FTP sensor signal The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~3736 Pa).	< 0.15 volts (3.0 % of Vref or ~ 1,681 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples 12.5 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit High Voltage (Not Sealed Fuel System)	P0453	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too high out of range.	FTP sensor signal The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~-3736 Pa).	> 4.85 volts (97 % of Vref or ~ -4,172 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples 12.5 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Intermittent (Not Sealed Fuel System)	P0454	This DTC will detect intermittent tank vacuum sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	If an abrupt change in tank vacuum is detected the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that a refueling event occurred. If a refueling is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem. An abrupt change is defined as a change in vacuum: in the span of 1.0 seconds. But in 12.5 msec. A refueling event is confirmed if the fuel level has a persistent change of for 30 seconds.	> 112 Pa < 249 Pa 10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes and the canister vent solenoid is closed		This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures. 12.5 ms / sample	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Large Leak Detected (Not Sealed Fuel System)	P0455	This DTC will detect a weak vacuum condition (large leak or purge blockage) in the EVAP system. Purge valve is controlled (to allow purge flow) and vent valve is commanded closed.	Purge volume while Tank vacuum After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time. Weak Vacuum Follow-up Test (fuel cap replacement test) Weak Vacuum Test failed. Passes if tank vacuum Note: Weak Vacuum Follow-up Test can only report a pass.	> 17 liters ≤ 2,740 Pa ≥ 2,740 Pa	Fuel Level System Voltage BARO Purge Flow No active DTCs: Cold Start Test If ECT > IAT, Startup temperature delta (ECT-IAT): Cold Test Timer Startup IAT Startup ECT Weak Vacuum Follow-up Test This test can run following a weak vacuum failure or on a hot restart.	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts ≥ 70 kPa ≥ 1.50 % MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454 ≤ 8 °C ≤ 1,000 seconds 4 °C ≤ Temperature ≤ 30 °C ≤ 35 °C	Once per cold start Time is dependent on driving conditions Maximum time before test abort is 1,000 seconds Weak Vacuum Follow-up Test With large leak detected, the follow-up test is limited to 1,300 seconds. Once the MIL is on, the follow-up test runs indefinitely.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Performance (For use on vehicles with a single fuel tank)	P0461	This DTC will detect a fuel sender stuck in range in the primary fuel tank.	Delta fuel volume change over an accumulated 124 miles.	< 3 liters	Engine Running No active DTCs:	VehicleSpeedSensor_FA	250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Low Voltage	P0462	This DTC will detect a fuel sender stuck out of range low in the primary fuel tank.	Fuel level Sender % of 5V range	< 10 %			100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit High Voltage	P0463	This DTC will detect a fuel sender stuck out of range high in the primary fuel tank.	Fuel level Sender % of 5V range	> 60 %			100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Intermittent (Not Sealed Fuel System)	P0464	This DTC will detect intermittent fuel level sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	<p>If a change in fuel level is detected, the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that an actual refueling event occurred. If a refueling event is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem.</p> <p>An intermittent change in fuel level is defined as:</p> <p>The fuel level changes by and does not remain for 30 seconds during a 600 second refueling rationality test.</p>	10 % > 10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		<p>This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.</p> <p>100 ms / sample</p>	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Open (ODM) (Not used on EREV)	P0480	This DTC checks for open circuit failures during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	Voltage ≥ 11 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Open (ODM)	P0481	This DTC checks for open circuit failures during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	Voltage ≥ 11 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Flow During Non- Purge (Not Sealed Fuel System)	P0496	This DTC will determine if the purge solenoid is leaking to engine manifold vacuum. This test will run with the purge valve closed and the vent valve closed.	Tank Vacuum for Test time	> 2,491 Pa 5 seconds ≥ refer to "P0496: Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level table" in Supporting Tables Tab.	Fuel Level System Voltage BARO Startup IAT Startup ECT Engine Off Time No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts ≥ 70 kPa 4 °C ≤ Temperature ≤ 30 °C ≤ 35 °C ≥ 28,800.0 seconds MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454	Once per cold start Cold start: max time is 1,000 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Low Engine Speed Idle System	P0506	This DTC will determine if a low idle exists	Filtered Engine Speed Error filter coefficient	> 94.00 rpm 0.00350	Baro Coolant Temp Engine run time Ignition voltage Time since gear change Time since a TCC mode change IAT Vehicle speed Commanded RPM delta Idle time For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa > 60 °C and < 123 °C Must verify KfECTI_T_EngCoolHotLo Thresh is less than KfECTI_T_EngCoolHotHi Thresh ≥ 60 sec 255 ≥ volts ≥ 11 ≥ 3 sec > 3 sec > -20 °C ≤ 1.67 kph ≤ 25 rpm > 5 sec > 88.00 pct or < 25.00 pct PTO not active	Diagnostic runs in every 12.5 ms loop Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	Transfer Case not in 4WD LowState Off-vehicle device control (service bay control) must not be active. following conditions not TRUE: (VeTESR_e_EngSpdReqI ntvType = CeTESR_e_EngSpdMinLi mit AND VeTESR_e_EngSpdReqR espType = CeTESR_e_NoSuggestio n) Clutch is not depressed TC_BoostPresSnsrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorCircuitFA EvapFlowDuringNonPurg e_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_F A IgnitionOutputDriver_FA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA FuelLevelDataFault		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for Idle time	LowFuelConditionDiagnos tic Clutch Sensor FA AmbPresDfltStatus P2771 > 5 sec		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Engine Speed Idle System	P0507	This DTC will determine if a high idle exists	Filtered Engine Speed Error filter coefficient	< -188.00 rpm 0.00350	Baro Coolant Temp Engine run time Ignition voltage Time since gear change Time since a TCC mode change IAT Vehicle speed Commanded RPM delta For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa > 60 °C and < 123 °C Must verify KfECTI_T_EngCoolHotLo Thresh is less than KfECTI_T_EngCoolHotHi Thresh ≥ 60 sec 255 ≥ volts ≥ 11 ≥ 3 sec > 3 sec > -20 °C ≤ 1.67 kph ≤ 25 rpm > 88.00 pct or < 25.00 pct PTO not active Transfer Case not in 4WD LowState	Diagnostic runs in every 12.5 ms loop Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	Off-vehicle device control (service bay control) must not be active. following conditions not TRUE: (VeTESR_e_EngSpdReqIntvType = CeTESR_e_EngSpdMinLimit AND VeTESR_e_EngSpdReqRespType = CeTESR_e_NoSuggestion) Clutch is not depressed TC_BoostPresSnrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorCircuitFA EvapFlowDuringNonPurge_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_FA IgnitionOutputDriver_FA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA FuelLevelDataFaultLow FuelConditionDiagnostic Clutch SensorFA AmbPresDfltStatus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for Idle time	P2771 > 5 sec		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Rough Idle	P050D	Monitors the combustion performance when the cold start emission reduction strategy is active by accumulating and determining the percentage of engine cycles that have less than complete combustion relative to the total number of engine cycles in which Dual Pulse is active.	Deceleration index vs. Engine Speed Vs Engine load Deceleration index calculation is tailored to specific vehicle. Tables used are 1st tables encountered that are not max of range. Undetectable region at a given speed/load point is where all tables are max of range point. see Algorithm Description Document for additional details. Incomplete combustion identified by P0300 threshold tables:	(>Idle SCD AND >Idle SCD ddt Tables) OR (>Idle Cyl Mode AND > Idle Cyl Mode ddt Tables)	Misfire Algorithm Enabled (Refer to P0300 for Enablement Requirements) OBD Manufacturer Enable Counter To enable the diagnostic, the Cold Start Emission Reduction Strategy Must Be Active per the following: Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure In addition, Dual Pulse Strategy Is Enabled and Active Per the following: Engine Speed Accel Position For the engine speeds and loads in which Dual Pulse is active: Dual Pulse Error induced misfires percentage Dual Pulse Error induced	= 0 < 350.00 degC > -10.00 degC <= 56.00 degC >= 74.00 KPa >= 450.00 RPM <= 2,200.00 RPM <= 1.00 Pct >= catalyst damaging misfire < 90% of the maximum achievable catalyst	Runs once per trip when the cold start emission reduction strategy is active and Dual Pulse is enabled and active. Frequency: Engine Cycle Test completes after Dual Pulse is no longer active OR The first 500 engine cycles have been reached	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					misfires percentage Engine Cycles The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following: Catalyst Temperature AND Engine Run Time OR Engine Run Time OR Barometric Pressure Dual Pulse Strategy will exit per the following: Engine Speed OR Accel Position Dual Pulse Strategy will also exit if the any of the "Additional Dual Pulse Enabling Criteria" is not satisfied:	damaging misfire. >= 50 < 501 >= 900.00 degC >= 18.38 seconds > "Extended Engine Exit Time" This Extended Engine Exit time is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details. < 74.00 KPa > 2,400.00 RPM > 2.00 Pct		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					"Additional Dual Pulse Enabling Criteria": Green Engine Enrichment Misfire Converter Protection strategy Engine Metal Overtemp strategy Fuel control state Output State Control DOD Or DFCO Power Enrichment Piston Protection Hot Coolant Enrichment Injector Flow Test General Enable DTC's Not Set:	Not Enabled Not being requested Not being requested Open Loop Not being requested for fuel Not Active Not Active Not Active Not Active Not Active AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFA CrankSensorFaultActive FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA AnyCamPhaser_TFTKO Clutch Sensor FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						VehicleSpeedSensor_FA FuelInjectorCircuit_TFTKO FHPR_b_FRP_SnsrCkt_FA FHPR_b_FRP_SnsrCkt_TFTKO FHPR_b_PumpCkt_FA FHPR_b_PumpCkt_TFTKO TransmissionEngagedState_FA EngineTorqueInaccurate FuelPumpRlyCktFA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Mutil-Function Switch Circuit	P0564	Detect when cruise control multi-function switch circuit (analog) voltage is in an illegal range	Cruise Control analog circuit voltage must be in an "illegal range" or "between ranges" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	TRUE 1.00	fail continuously for greater than 0.500 seconds	MIL: Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control On Switch Circuit	P0565		Cruise Control On switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	TRUE 1.00	fail continuously for greater than 20.00 seconds	MIL Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Resume Circuit	P0567	Detects a failure of the cruise resume switch in a continuously applied state	Cruise Control Resume switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	TRUE 1.00	fail continuously for greater than 90.000 seconds	MIL: Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Set Circuit	P0568	Detects a failure of the cruise set switch in a continuously applied state	Cruise Control Set switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	TRUE 1.00	fail continuously for greater than 90.000 seconds	MIL: Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Input Circuit	P0575	Detects rolling count or protection value errors in Cruise Control Switch Status serial data signal	If x of y rolling count / protection value faults occur, disable cruise for duration of fault		Cruise Control Switch Serial Data Error Diagnostic Enable	TRUE 1.00	10 / 16 counts	MIL: Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Low	P057C	detects short to ground for brake pedal position sensor	If x of y samples are observed below failure threshold, default brake pedal position to zero percent.	5.00	Brake Pedal Position Sensore Low Voltage Diagnostic Enable	TRUE 1.00	20 / 32.00 counts	MIL: Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit High	P057D	detects open circuit for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	95.00	Brake Pedal Position Sensore High Voltage Diagnostic Enable	TRUE 1.00	20.00 / 32.00 counts	MIL: Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi-function Circuit Low Voltage	P0580	detects short to ground failure for cruise multi-function switch circuit	Cruise Control analog circuit voltage must be in an "Open Short To Ground" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	TRUE 1.00	fail continuously for greater than 2.00 seconds	MIL: Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi- function Circuit High Voltage	P0581		Cruise Control analog circuit voltage must be in an "Short To Power" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	TRUE 1.00	fail continuously for greater than 2.00 seconds	MIL: Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if the calibration check sum is incorrect or the flash memory detects an uncorrectable error via the Error Correcting Code.	The Primary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	Type A, 1 Trips
			The Primary Processor's Error Correcting Code hardware in the flash memory detects an error. Covers all software and calibrations.	254 failures detected via Error Correcting Code			Diagnostic runs continuously via the flash hardware.	
			The Primary Processor's calculated checksum does not match the stored checksum value for a selected subset of the calibrations.	2 consecutive failures detected or 5 total failures detected.			Diagnostic runs continuously. Will report a detected fault within 200 ms.	
			The Secondary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	
				In all cases, the failure count is cleared when controller shuts down				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Not Programmed	P0602	This DTC will be stored if the PCM is a service PCM that has not been programmed.	Output state invalid		PCM State	= crank or run PCM is identified through calibration as a Service PCM	Diagnostic runs at powerup and once per second continuously after that	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Long Term Memory Reset	P0603	Non-volatile memory checksum error at controller power-up	Checksum at power-up does not match checksum at power-down				Diagnostic runs at powerup Diagnostic reports a fault if 1 failure occurs	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM RAM Failure	P0604	Indicates that the ECM has detected a RAM fault	Indicates that the primary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	Type A, 1 Trips
			Indicates that the primary processor is unable to correctly read data from or write data to cached RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor is unable to correctly read data from or write data to TPU RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor detects a mismatch between the data and dual data is found during RAM updates. Detects a mismatch in data and dual data updates >	0.46800 s			When dual store updates occur.	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Indicates that the primary processor detects an illegal write attempt to protected RAM. Number of illegal writes are >	65,534 counts			Diagnostic runs continuously (background loop)	
			Indicates that the secondary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Fault	P0606	Indicates that the ECM has detected an internal processor integrity fault	Loss or invalid message of SPI communication from the Secondary Processor at initialization detected by the Primary Processor or loss or invalid message of SPI communication from the Secondary Processor after a valid message was received by the Primary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received		Run/Crank voltage >= 6.41 or Run/Crank voltage >= 11.00, else the failure will be reported for all conditions	In the primary processor, 159 / 399 counts intermittent or 39 counts continuous; 39 counts continuous @ initialization. 12.5 ms /count in the ECM main processor	Type A, 1 Trips
			Loss or invalid message of SPI communication from the Primary Processor at initialization detected by the Secondary Processor or loss or invalid message of SPI communication from the Primary Processor after a valid message was received by the Secondary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received			In the secondary processor, 20 / 200 counts intermittent or 0.1875 s continuous; 0.4750 s continuous @ initialization. 12.5 ms /count in the ECM secondary processor	
			Checks for stack over or underflow in secondary processor by looking for corruption of known pattern at stack boundaries. Checks number of stack over/under flow since last powerup reset >=	5		KeMEMD_b_StackLimitTestEnbl == 1 Value of KeMEMD_b_StackLimitTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			MAIN processor is verified by responding to a seed sent from the secondary with a key response to secondary. Checks number of incorrect keys	2 incorrect seeds within 8 messages, 0.2000 seconds		ignition in Run or Crank	150 ms for one seed continually failing	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			received > or Secondary processor has not received a new within time limit					
			Time new seed not received exceeded			always running	0.450 seconds	
			MAIN processor receives seed in wrong order			always running	3 / 17 counts intermittent. 50 ms/count in the ECM main processor	
			2 fails in a row in the Secondary processor's ALU check			KePISD_b_ALU_TestEnbl d == 1 Value of KePISD_b_ALU_TestEnbl d is: 1. (If 0, this test is disabled)	25 ms	
			2 fails in a row in the Secondary processor's configuration register masks versus known good data			KePISD_b_ConfigRegTestEnbl d == 1 Value of KePISD_b_ConfigRegTestEnbl d is: 1. (If 0, this test is disabled)	12.5 to 25 ms	
			Secondary processor detects an error in the toggling of a hardware discrete line controlled by the MAIN processor: number of discrete changes > = or < = over time window(50ms)	7 17		KePISD_b_MainCPU_SOH_FltEnbl d == 1 Value of KePISD_b_ConfigRegTestEnbl d is: 1. (If 0, this test is disabled) time from initialization >= 0.4875 seconds	50 ms	
			memory and complement memory do not agree				0.19 seconds	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Software background task first pass time to complete exceeds			Run/Crank voltage > 6.41	360.000 seconds	
			2 fails in a row in the MAIN processor's ALU check			KePISD_b_ALU_TestEnbl == 1 Value of KePISD_b_ALU_TestEnbl is: 1. (If 0, this test is disabled)	25 ms	
			2 fails in a row in the MAIN processor's configuration register masks versus known good data			KePISD_b_ConfigRegTestEnbl == 1 Value of KePISD_b_ConfigRegTestEnbl is: 1. (If 0, this test is disabled)	12.5 to 25 ms	
			Checks number of stack over/under flow since last powerup reset >=	5		KeMEMD_b_StackLimitTestEnbl == 1 Value of KeMEMD_b_StackLimitTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			Voltage deviation >	0.4950		KePISD_b_A2D_CnvtrTestEnbl == 1 Value of KePISD_b_A2D_CnvtrTestEnbl is: 1. (If 0, this test is disabled)	5 / 10 counts or 0.150 seconds continuous; 50 ms/count in the ECM main processor	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occurred since last	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_FlashECC_CktTestEnbl == 1 Value of KeMEMD_b_FlashECC_CktTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			controller initialization. Counter >=					
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_RAM_ECC_CktTestEnbl == 1 Value of KeMEMD_b_RAM_ECC_CktTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM variable, depends on length of time to write flash to RAM	
			MAIN processor DMA transfer from Flash to RAM has 1 failure			KePISD_b_DMA_XferTestEnbl == 1 Value of KePISD_b_DMA_XferTestEnbl is: 0. (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit Open	P0627	This DTC checks for an open and shorted high circuit while the device is commanded off.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage Engine Speed	Voltage ≥ 11 volts ≥ 0 RPM	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit Low Voltage	P0628	This DTC checks for a shorted low circuit while the device is commanded on.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage Engine Speed	Voltage ≥ 11 volts ≥ 0 RPM	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit High Voltage	P0629	This DTC checks for an open and shorted high circuit while the device is commanded off.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage Engine Speed	Voltage ≥ 11 volts ≥ 0 RPM	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module EEPROM Error	P062F	Indicates that the NVM Error flag has not been cleared	The next write to NVM will not succeed or the assembly calibration integrity check failed.		Ignition State	= unlock/accessory, run, or crank	1 test failure Diagnostic runs once at powerup	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VIN Not Programmed or Mismatched - Engine Control Module (ECM)	P0630	This DTC checks that the VIN is correctly written	At least one of the programmed VIN digits	= 00 or FF	OBD Manufacturer Enable Counter	= 0	250 ms / test Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #1 Circuit	P0641	Detects a continuous or intermittent short on the 5 volt reference circuit #1	ECM Vref1 < or ECM Vref1 > or the difference between ECM filtered Vref1 and Vref1 >	4.8750 5.1250 0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM)	P0650	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips NO MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #2 Circuit	P0651	Detects a continuous or intermittent short on the 5 volt reference circuit #2	ECM Vref2 < or ECM Vref2 > or the difference between ECM filtered Vref2 and Vref2 >	4.8750 5.1250 0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM)	P0685	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Feedback Circuit High	P0690	This DTC is a check to determine if the Powertrain relay is functioning properly.	Voltage stuck high PT Relay feedback voltage is when commanded 'OFF'	> 4.0 volts	Powertrain relay commanded "ON" No active DTCs:	PowertrainRelayStateOn_ FA	Stuck Test: 100 ms/ sample Continuous failures ≥ 2 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Low Voltage (ODM)	P0691	This DTC checks for short to low voltage circuit failures during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	Voltage ≥ 11 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit High Voltage (ODM)	P0692	This DTC checks for short to high voltage circuit failures during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	Voltage ≥ 11 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Low Voltage (ODM)	P0693	This DTC checks for short to low voltage circuit failures during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	Voltage ≥ 11 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit High Voltage (ODM)	P0694	This DTC checks for short to high voltage circuit failures during operation.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Run/Crank Voltage	Voltage ≥ 11 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #3 Circuit	P0697	Detects a continuous or intermittent short on the 5 volt reference circuit #3	ECM Vref3 < or ECM Vref3 > or the difference between ECM filtered Vref3 and Vref3 >	4.8750 5.1250 0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Control Module (FPCM) Requested MIL Illumination	P069E	Monitors the FPCM MIL request line to determine when the FPCM has detected a MIL illuminating fault.	Fuel Pump Control Module Emissions-Related DTC set			Time since power-up > 3 seconds	Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 1 Performance	P06B6	This diagnostic checks for a fault with the internal test circuit used only for the '20 kHz' method of the Open Circuit Diagnostic	FFT Diagnostic Output	> OpenTestThreshLo and < OpenTestThreshHi See Supporting Tables	Diagnostic Enabled? Engine Run Time Engine Speed Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above) Engine Air Flow	Yes ≥ 2.0 seconds > 400 RPM and < 5,000 RPM ≥ 200 Revs ≥ 50 mg/cylinder and ≤ 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient Weight Coefficient = 0.0200 Updated each engine event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 2 Performance	P06B7	This diagnostic checks for a fault with the internal test circuit used only for the '20 kHz' method of the Open Circuit Diagnostic	FFT Diagnostic Output	> OpenTestThreshLo and < OpenTestThreshHi See Supporting Tables	Diagnostic Enabled? Engine Run Time Engine Speed Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above) Engine Air Flow	Yes ≥ 2.0 seconds > 400 RPM and < 5,000 RPM ≥ 200 Revs ≥ 50 mg/cylinder and ≤ 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient Weight Coefficient = 0.0200 Updated each engine event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Module (TCM) Requested MIL Illumination	P0700	Monitors the TCM MIL request line to determine when the TCM has detected a MIL illuminating fault.	Transmission Emissions-Related DTC set			Time since power-up > 3 seconds	Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (naturally aspirated)	P1101	Determines if there are multiple air induction problems affecting airflow and/or manifold pressure.	Filtered Throttle Model Error AND (ABS(Measured Flow – Modeled Air Flow) Filtered OR ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 350 kPa*(g/s) > 20 grams/sec > 20.0 kPa) > 20.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 500 RPM <= 6,800 RPM > -7 Deg C < 126 Deg C > -20 Deg C < 125 Deg C >= 0.50 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor Based on MAF Est MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM See "Residual Weight Factor" tables. MAP_SensorCircuitFA EGRValvePerformance_FA A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Pending DTCs:	IAT_SensorFA EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Low	P11C2	Detects a continuous short to power in the Humidity Sensor circuit	Humidity Duty Cycle	<= 5.0 %	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit High	P11C3	Detects a continuous open or short to low in the Humidity Sensor circuit	Humidity Duty Cycle	>= 95.0 %	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Intermittent	P11C4	Detects a noisy or erratic humidity sensor input	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current Humidity reading - Humidity reading from 100 milliseconds previous)	> 80 % 10 consecutive Humidity samples	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	4 failures out of 5 samples	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 low side circuit shorted to high side circuit	P1248	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to low side		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 low side circuit shorted to high side circuit	P1249	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to low side		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 low side circuit shorted to high side circuit	P124A	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to low side		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 low side circuit shorted to high side circuit	P124B	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to low side		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 low side circuit shorted to high side circuit	P124C	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to low side		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 low side circuit shorted to high side circuit	P124D	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to low side		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
EngineMetal OvertempAct ive	P1258	The objective of the algorithm is to protect the engine in the event of engine metal overtemperature, mainly due to loss of coolant	Engine Coolant For	>= 129 °C >= 2 seconds	Engine Run Time If feature was active and it set the coolant sensor fault then feature will be enabled on coolant sensor fault pending on the next trip.	>= 30 Seconds	Fault present for >= 0 seconds	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Coil Positive Voltage Circuit Group 1 * * SIDI ONLY * *	P135A	This diagnostic checks for voltage supply to the Ignition Coils (applicable only for SIDI applications)	Common Enable Criteria Ignition Module Supply Voltage. Three possible power supply sources for Ignition Coils: Case 1: Battery Case 2: Ignition Run/ Crank Case 3: PT Relay Case Specific Enable Criteria	< 2.5 Volts Ignition Coil Power Source = (see corresponding case specific enable criteria below)	Diagnostic Enabled? PT Relay	Yes 5 Engine Revs > 11.0 volts > 11.0 volts	24 Failures out of 30 Samples 6.25 msec rate	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Coil Positive Voltage Circuit Group 2 * * SIDI ONLY * *	P135B	This diagnostic checks for voltage supply to the Ignition Coils (applicable only for SIDI applications)	Common Enable Criteria		Diagnostic Enabled?	Yes	24 Failures out of 30 Samples 6.25 msec rate	Type: Type A, 1 Trips
			Ignition Module Supply Voltage.	< 2.5 Volts				
			Three possible power supply sources for Ignition Coils: Case 1: Battery Case 2: Ignition Run/ Crank Case 3: PT Relay	Ignition Coil Power Source = (see corresponding case specific enable criteria below)	PT Relay			
			Additional Case Specific Enable Criteria	Case 1: Battery	Delay starting at Key-On	5 Engine Revs		
			Case 2: Ignition Run/ Crank	Ignition Run/Crank Voltage	> 11.0 volts			
			Case 3: PT Relay	PT Relay Voltage	> 11.0 volts			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>OBD Manufacturer Enable Counter</p> <p>Vehicle Speed</p> <p>Allow diagnostic to calculate residual in an off-idle state. If the value of the OffIdleEnable is equal to 1 then the "DriverOffAccelPedal" will not be checked. However, if the value of OffIdleEnable is 0 then driver must be off the accel pedal</p> <p>A change in throttle position (tip-in/tip-out) will initiate a delay in the calculation of the average qualified residual value. Therefore: When the Pedal Close Delay Timer is : the diagnostic will continue the calculation.</p> <p>For Manual Transmission vehicles:</p>	<p>0</p> <p>< 1.24 MPH</p> <p>0 (A value of 1 allows diagnostic to run and calculate the residual while off idle. A value of 0 requires calculation of the residual at idle)</p> <p>> 5.00 seconds</p> <p>Clutch Pedal Top of Travel Achieved and Clutch Pedal Bottom of Travel Achieved. Refer to the "Clutch Pedal Top of Travel Achieved criteria" and "Clutch Pedal Bottom of Travel Achieved criteria" section of the "Supporting Tables" tab criteria</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>The diagnostic will delay calculation of the residual value and potentially weight the residual calculation differently based on engine run time. This is to ensure the diagnostic is operating in idle speed control as well as during the peak catalyst light off period. The "Time Weighting Factor" must be :</p> <p>General Enable:</p> <p>DTC's Not Set:</p>	<p>> 0 These are scalar values that are a function of engine run time. Refer to "Supporting Tables" for details.</p> <p>AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFP CrankSensorFaultActive FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA EngineMisfireDetected_F A Clutch Sensor FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA 5VoltReferenceMAP_OO R_Flt TransmissionEngagedStat e_FA EngineTorqueInaccurate</p>		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Engine Speed Request Circuit	P150C	Determines if engine speed request from the TCM is valid	Serial Communication rolling count value Transmission engine speed protection	+ 1 from previous \$19D message (PTEI3) not equal to 2's complement of transmission engine speed request + Transmission alive rolling count	Diagnostic enable bit Engine run time # of Protect Errors # of Alive Rolling Errors No idle diagnostic 506/507 code No Serial communication loss to TCM Engine Running Power mode	1 0.50 sec 10 protect errors out of 10 samples 6 rolling count errors out of 10 samples IAC_SystemRPM_FA (U0101) = TRUE Run Crank Active	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Steady State Actuation Fault	P1516	Detect an inability to maintain a steady state throttle position	Throttle is considered to be steady state when: change in throttle position over 12.5 msec is <	0.25 percent 4.00 s		Run/Crank voltage > 6.41	0.49 ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active and Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -10.0 degC -10 <= Temp degC <= 100		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation	P1682	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage & the Powertrain Relay Ignition Voltage	Run/Crank – PT Relay Ignition >	3.00 Volts		Powertrain commanded on AND (Run/Crank voltage > Table, f(IAT). See supporting tables OR PT Relay Ignition voltage > 5.50) AND Run/Crank voltage > 5.50 .	240 / 480 counts or 0.1750 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS SENT Comm Circuit Low	P16A0	Detects a Low Circuit Fault in the TPS SENT Communication Circuit	Voltage for wave pulse is below state threshold as defined by SAE J2716 SENT Protocol	0.5 V		Run/Crank voltage > 6.41	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS SENT Comm Circuit High	P16A1	Detects a High Circuit Fault in the TPS SENT Communication Circuit	Voltage for wave pulse is above state threshold as defined by SAE J2716 SENT Protocol	4.1 V		Run/Crank voltage > 6.41	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS SENT Comm Circuit Performance	P16A2	Detects a Message Fault in the TPS SENT Communication Circuit	Message Pulse < Message Pulse > or Message Age Limit >= or Signal CRC fails	0.125977 ms 0.209991 ms 3.125 ms		Run/Crank voltage > 6.41	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Redundant Memory Performance	P16F3	<p>Detect Processor Calculation faults due to RAM corruptions, ALU failures and ROM failures</p> <p>For all of the following cases: If the individual diagnostic threshold is equal to 2048 ms, this individual case is not applicable. If any of the following cases are X out of Y diagnostics and the fail (x) is greater than the sample (Y), this individual case is also not applicable.</p>	Desired Throttle Area calculated does not equal its redundant calculation	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	Type A, 1 Trips
			Equivance Ratio torque compensation exceeds threshold	-74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Absolute difference between Equivance Ratio torque compensation and its dual store out of bounds given by threshold	74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of Accessory torque and its redundant calculation is out of bounds given by threshold range	74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Filtered Air-per-cylinder and its redundant calculation is out of bounds given by threshold range	92.69 mg	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference between the previous Final Advance and the current Final Advance not Adjusted for Equivalence Ratio is out of bounds given by threshold range	10.48 degrees		Engine speed >0rpm	Up/down timer 156 ms continuous, 0.5 down time multiplier	
			Torque Learn offset is out of bounds given by threshold range	High Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold 0.00 Nm			multiplier	
			One step ahead calculation of air-per-cylinder and two step ahead is greater than threshold	80.00 mg		Engine speed > 625 rpm	Up/down timer 456 ms continuous, 0.5 down time multiplier	
			Difference between Unmanaged Spark and PACS Spark is greater than threshold	10.48 degrees	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Engine Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			Zero pedal axle torque is out of bounds given by threshold range	High Threshold 818.09 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Creep Coast Axle Torque is out of bounds given by threshold range	High Threshold 818.09 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Absolute difference of Friction torque and its redundant calculation is out of bounds given by threshold range	74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			Arbitrated Air-Per-Cylinder filter coefficient is out of bounds given by threshold range	High Threshold 1.000 Low Threshold 0.074	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Launch spark is active but the launch spark redundant path indicates it should not be active	N/A		Engine speed < 5,800.00 or 6,000.00 rpm (hysteresis pair)	Up/down timer 156 ms continuous, 0.5 down time multiplier	
			Rate limited vehicle speed and its dual store do not equal	N/A		Time since first CAN message with vehicle speed >= 0.500 sec	10 / 20 counts; 25.0msec/count	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Preload Throttle Area and its dual store do not equal	N/A	Ignition State	Accessory, run or crank AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded engine torque due to fast actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded engine torque due to slow actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			TOS to wheel speed conversion factor is out of bounds given by threshold	High Threshold: 1.10	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			range	T/C Range Hi 0.10 T/C Range Lo Low Threshold: 1.10 T/C Range Hi 0.10 T/C Range Lo				
			TOS to wheel speed conversion factor and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	
			Cylinders active greater than commanded	2 cylinders		Engine run flag = TRUE > 2.00s Number of cylinder events since engine run > 24	Up/down timer 156ms continuous, 0.5 down time multiplier	
						No fuel injector faults		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						active		
			Transfer case neutral request from four wheel drive logic does not match with operating conditions	N/A	Ignition State	Accessory, run or crank Transfer case range valid and not over-ridden FWD Apps only	32 / 0 counts; 25.0msec/count	
			Transfer case neutral and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	
			Driver progression mode and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Predicted torque for uncorrected zero pedal determination is greater than calculated limit.	Table, f(Engine, Oil Temp). See supporting tables + 74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Predicted Request Without Motor is greater than its redundant calculation plus threshold	73.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Immediate Request Without Motor is greater than its redundant calculation plus threshold	73.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Positive Torque Offset is greater than its redundant calculation plus threshold OR Positive Torque Offset is less than its redundant calculation minus threshold	74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Engine Request is greater than its redundant calculation plus threshold	74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Hybrid Predicted Crankshaft Request is greater than its redundant calculation plus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Hybrid Immediate Crankshaft Request is less than its redundant calculation minus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Regeneration Brake Assist is not within a specified range	Brake Regen Assist < 0 Nm or Brake Regen Assist >	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous.	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				1,000.00 Nm			0.5 down time multiplier	
			Cylinder Spark Delta Correction exceeds the absolute difference as compared to Unadjusted Cylinder Spark Delta	10.48 degrees	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			1. Cylinder Torque Offset exceeds step size threshold OR 2. Sum of Cylinder Torque Offset exceeds sum threshold	1. 74.77 Nm 2. 74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Capacity Minimum Immediate Without Motor is greater than its dual store plus threshold	74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Capacity Minimum Engine Off is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Engine Capacity Minimum Engine Immediate Without Motor is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Immediate Engine Request is greater than its redundant calculation plus threshold	74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			PTO Torque Request exceeds allowed rate limited PTO Torque Request	9.35 Nm/25ms	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Speed Lores Intake Firing (event based) calculation does not equal its redundant	N/A		Engine speed greater than 0rpm	Up/down timer 156 ms continuous, 0.5	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			calculation				down time multiplier	
			Engine Speed Lores Intake Firing timing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 156 ms continuous, 0.5 down time multiplier	
			Idle speed control calculated predicted minimum torque request exceeds calculated torque limit	Table, f(Engine, Oil Temp). See supporting tables + 74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Idle speed control calculated predicted minimum torque without reserves exceeds calculated torque limit	Table, f(Engine, Oil Temp). See supporting tables + 74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference between Driver Requested Immediate Torque primary path and its secondary exceeds threshold	818.09 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Driver Immediate Request is less than its redundant calculation minus threshold	818.09 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded Immediate Request is greater than its redundant calculation plus threshold OR Commanded Immediate	818.09 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Request is less than its redundant calculation minus threshold					
			Commanded Immediate Response Type is set to Inactive	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Cylinders active greater than commanded	1 cylinder		Engine speed greater than 0rpm and less than 3,200 rpm AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Difference between Cruise Axle Torque Arbitrated Request and Cruise Axle Torque Request exceeds	102.26 Nm		Cruise has been engaged for more than 4.00 seconds	Up/down timer 2,048 ms continuous, 0.5 down time	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			threshold				multiplier	
			Desired engine torque request greater than redundant calculation plus threshold	73.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Engine min capacity above threshold	74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 84 ms continuous, 0.5 down time multiplier	
			No fast unmanaged retarded spark above the applied spark plus the threshold	Table, f(Erpm). See supporting tables		Engine speed greater than 0rpm	Up/down timer 156 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of adjustment factor based on temperature and its dual store above threshold	2.76 m/s	Ignition State	Accessory, run or crank	Up/down timer 116 ms continuous, 0.5 down time multiplier	
			1. Absolute difference of redundant calculated engine speed above threshold	500 RPM		Engine speed greater than 0 RPM	Up/down timer 156 ms continuous, 0.5 down time multiplier	
			After throttle blade pressure and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Speed Control's Predicted Torque Request and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			Engine oil temperature and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 276 ms continuous, 0.5 down time multiplier	
			Desired throttle position greater than redundant calculation plus threshold	6.08 percent	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the rate limited pre-throttle pressure and its redundant calculation greater than threshold	0.06 kpa	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Throttle desired torque	74.77	Ignition State	Accessory, run or crank	Up/down timer	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			above desired torque plus threshold	Nm			475 ms continuous, 0.5 down time multiplier	
			Desired filtered throttle torque exceeds the threshold plus the higher of desired throttle torque or modeled throttle torque	74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Torque feedback proportional term is out of allowable range or its dual store copy does not match	High Threshold 37.38 Nm Low Threshold -37.38 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Torque feedback integral term magnitude or rate of change is out of allowable range or its dual store copy do not match	High Threshold 70.09 Nm Low Threshold -74.77 Nm Rate of change threshold 4.67 Nm/loop	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of Final Torque feedback proportional plus integral term and its redundant calculation is out of bounds given by threshold range	High Threshold 74.77 Nm Low Threshold -74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference of torque desired throttle area and its redundant calculation is out of bounds given by threshold range	High Threshold 0.50 % Low Threshold -0.50 %	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of torque model coefficients and its redundant calculation is out of bounds given by threshold range	High Threshold 0.0001479 Low Threshold - 0.0001479	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Difference of base friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 74.77 Nm Low Threshold	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				- 74.77 Nm				
			Accessory drive friction torque is out of bounds given by threshold range	High Threshold 74.77 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AC friction torque is greater than commanded by AC control software or less than threshold limit	High Threshold 40.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of Oil temperature delta friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 74.77 Nm Low Threshold -74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Generator friction torque is out of bounds given by threshold range	High Threshold 74.77 Nm Low Threshold	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				0.00 Nm				
			Supercharger friction torque is out of bounds given by threshold range	High Threshold 74.77 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Filtered Torque error magnitude or its increase rate of change is out of allowable range or its dual store copy do not match	High Threshold 74.77 Nm Low Threshold -74.77 Nm Rate of change threshold		Engine speed >0rpm MAF, MAP and Baro DTCs are false	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				4.67 Nm/loop				
			Torque error compensation is out of bounds given by threshold range	High Threshold 74.77 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Delta Torque Baro compensation is out of bounds given by threshold range	High Threshold 5.35 Nm Low Threshold -0.72 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			1. Difference of reserve torque value and its redundant calculation exceed threshold OR 2. Reserve request does not agree with operating conditions or Difference of final predicted torque and its redundant calculation exceed threshold OR 3. Rate of change of reserve torque exceeds threshold, increasing direction only OR 4. Reserve engine torque above allowable capacity threshold	1. 73.77 Nm 2. N/A 3. 73.77 Nm 4. 73.77 Nm	3. & 4.: Ignition State	1. & 2.: Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 74.77 Nm 3. & 4.: Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Engine Vacuum and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the	Table. f(Engine		Engine speed >0rpm	Up/down timer	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			calculated Intake Manifold Pressure during engine event versus during time event is greater than threshold	Torque). See supporting tables			156 ms continuous, 0.5 down time multiplier	
			Min. Axle Torque Capacity is greater than threshold	0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Driver Predicted Request is greater than its redundant calculation plus threshold OR Driver Predicted Request is less than its redundant calculation minus threshold	818.09 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Cold Delta Friction Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Predicted torque for zero pedal determination is greater than calculated limit.	Table, f(Engine, Oil Temp). See supporting tables + 74.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Axle Torque and its dual store do not match	1 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Steady State Estimated Engine Torque and its dual store are not equal	N/A		AFM not changing from Active to Inactive and preload torque not	Up/down timer 1,988 ms continuous,	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						changing and one loop after React command Engine speed >0rpm	0.5 down time multiplier	
			Difference of Weighting factor for number of cylinders fueled and its redundant calculation is above threshold	0.26		Engine run flag = TRUE > 10.00 s	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Difference of minimum spark advance limit and its redundant calculation is out of bounds given by threshold range	10.48 degrees	Ignition State	Accessory, run or crank	Up/down timer 156 ms continuous, 0.5 down time multiplier	
			Difference of commanded spark advance and adjusted delivered is out of bounds given by threshold range	10.48 degrees		Engine speed >0rpm	Up/down timer 156 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference between Estimated Engine Torque and its dual store are above a threshold	74.77 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Absolute difference between Estimated Engine Torque without reductions due to torque control and its dual store are above a threshold	74.77 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by threshold range	10.48 degrees		Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 74.77 Nm	Up/down timer 456 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Engine Capacity Minimum Running Immediate Brake Torque Excluding Cylinder Sensitivity and its redundant calculation is out of bounds given by threshold range	74.77 Nm		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			One step ahead calculation of air-per-cylinder greater than two step ahead calculation by threshold for time	Threshold: Dynamically calculated based on current engine conditions Fault Pending Threshold: 100 ms		Engine speed > 625 rpm	Up/down timer 456 ms continuous, 0.5 down time multiplier	
			Rate limited cruise axle torque request and its dual store do not match within a threshold	102.26 Nm	Ignition State	Accessory, run or crank	Up/down timer 163 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			1. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its redundant calculation is out of bounds given by threshold range OR 2. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its dual store do not equal OR 3. Absolute difference of Calculated accelerator pedal position and its dual store do not equal	1. 5.00 % 2. N/A 3. N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded axle torque	818.00	Ignition State	Accessory, run or crank	Up/down timer	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			is greater than its redundant calculation by threshold	Nm			475 ms continuous, 0.5 down time multiplier	
			Commanded axle torque is less than its redundant calculation by threshold	-65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Preload Throttle Area is greater than its redundant calculation by threshold	0.10 %		Engine speed >0rpm AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Preload timer and its redundant calculation do not equal	N/A	Ignition State	Accessory, run or crank AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AC friction torque is greater than commanded by AC control software	40.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Speed Lores Intake Firing (time based) calculation does not equal its redundant calculation	N/A		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the calculated spark offset for equivalence ratio and its redundant calculation is greater than a threshold	10.48 degrees		Engine speed >0rpm	Up/down timer 156 ms continuous, 0.5 down time multiplier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Transmission Torque Request cacluations do not equal their dual stores	N/A		Run or Crank = TRUE > 0.50 s	16 / 32 counts; 25.0msec/count	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Throttle Actuator Position Performance	P2101	1) Detect a throttle positioning error2) Throttle control is driving the throttle in the incorrect direction3) Throttle control exceeds the reduced power limit	Difference between measured throttle position and modeled throttle position >	6.08 percent	TPS minimum learn is not active and Throttle is being Controlled and (Engine Running or Ignition Voltage > or Ignition Voltage >)	Run/Crank voltage > 6.41	15 counts; 12.5 ms/count in the primary processor	Type A, 1 Trips
			OR					
			Difference between modeled throttle position and measured throttle position >	6.08 percent		TPS minimum learn is not active and Throttle is being Controlled	AND ((Engine Running AND Ignition Voltage > 5.50) OR Ignition Voltage > 11.00)	
			Throttle Position >	38.38 percent		Powertrain Relay voltage > 6.41	11 counts; 12.5 ms/count in the primary processor	
			Throttle Position >	37.38 percent		Powertrain Relay voltage > 6.41 Reduced Power is True	11 counts; 12.5 ms/count in the primary processor	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Lo	P2122	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage <	0.4625		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Hi	P2123	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage >	4.7500		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Lo	P2127	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage <	0.3250		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P0697)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Hi	P2128	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage >	2.6000		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P0697)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position (TP) Sensor 1-2 Correlation	P2135	Detects a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor	Difference between TPS1 displaced and TPS2 displaced >	6.775 % offset at min. throttle position with a linear threshold to 9.705 % at max. throttle position		Run/Crank voltage > 6.41 No TPS sensor faults (P0122, P0123, P0222, P0223) No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts or 58 counts continuous; 3.125 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min TPS1) and (normalized min TPS2) >	5.000 % Vref		Run/Crank voltage > 6.41 No TPS sensor faults (P0122, P0123, P0222, P0223) No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts or 58 counts continuous; 3.125 ms/count in the main processor	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1-2 Correlation	P2138	Detects a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor	Difference between APP1 displaced and APP2 displaced >	5.000 % offset at min. pedal position with a linear threshold to 10.001 % at max. pedal position		Run/Crank voltage > 6.41 No APP sensor faults (P2122, P2123,P2127, P2128) No 5V reference errors or faultst for # 3 & # 4 5V reference circuits (P06A3, P0697)	19 / 39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min APP1) and (normalized min APP2) >	5.000 % Vref		Run/Crank voltage > 6.41 No APP sensor faults (P2122, P2123,P2127, P2128) No 5V reference errors or faultst for # 3 & # 4 5V reference circuits (P06A3, P0697)	19 / 39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 high side circuit shorted to ground	P2147	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 high side circuit shorted to power	P2148	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 high side circuit shorted to ground	P2150	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 high side circuit shorted to power	P2151	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 high side circuit shorted to ground	P2153	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 high side circuit shorted to power	P2154	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 high side circuit shorted to ground	P2156	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 high side circuit shorted to power	P2157	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 high side circuit shorted to ground	P216B	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 high side circuit shorted to power	P216C	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 high side circuit shorted to ground	P216E	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to ground		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 high side circuit shorted to power	P216F	This DTC checks the circuit for electrical integrity during operation.	The ECM detects that the fuel injector high side is shorted to power		Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Minimum Throttle Position Not Learned	P2176	TP sensors were not in the minimum learn window after multiple attempts to learn the minimum.	During TPS min learn on the Main processor, TPS Voltage > AND Number of learn attempts >	0.6170 10 counts		Run/Crank voltage > 6.41 TPS minimum learn is active	2.0 secs	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 1 / 2 Correlation	P2199	Detects a difference between the IAT and IAT2 sensors	ABS (IAT - IAT2)	> 55.0 deg C	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Bank 1 Air-Fuel Ratio Imbalance	P219A	This monitor determines if a cylinder-to-cylinder air-fuel ratio imbalance is present on bank 1.	<p>Filtered Ratio ></p> <p>Note: The input to this metric is the pre catalyst oxygen sensor voltage. This voltage is used to generate a Variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to the air-fuel ratio imbalance (variance is higher with an imbalance than without). Multiple samples are collected in making a decision.</p> <p>The observed Variance is dependant on engine speed and load and so each result is normalized for speed and load by comparing it to a known "good system" result for that speed and load, and generating a Ratio metric.</p> <p>The Ratio metric is calculated by selecting a threshold calibration from a 17x17 table (Supporting Table KtFABD_U_VarThresh1) and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table (Supporting Table</p>	0.62	<p>System Voltage</p> <p>Fuel Level</p> <p>Engine Coolant Temperature</p> <p>Cumulative engine run time</p> <p>Diagnostic enabled at Idle (regardless of other operating conditions)</p> <p>Engine speed</p> <p>Engine speed delta during a short term sample period</p> <p>Mass Airflow (MAF)</p> <p>Cumulative delta MAF during a short term sample period</p> <p>Filtered MAF delta between samples Note: first order lag filter coefficient applied to MAF = 0.050</p> <p>Air Per Cylinder (APC)</p> <p>APC delta during short term sample period</p> <p>Filtered APC delta between samples</p>	<p>no lower than 11.0 Volts for more than 0.2 seconds</p> <p>> 10.0 percent AND no fuel level sensor fault</p> <p>> -20 degrees C</p> <p>> 120.0 seconds</p> <p>No</p> <p>1,600 to 4,000 RPM</p> <p>< 100 rpm</p> <p>0 to 1,000 g/s</p> <p>< 5 g/s</p> <p>< 0.60 g/s</p> <p>165 to 700 mg/cylinder</p> <p>< 75 mg/cylinder</p> <p>< 3.50 percent</p>	<p>Minimum of 1 test per trip, up to 10 tests per trip during RSR or FIR.</p> <p>The front O2 sensor voltage is sampled once per cylinder event. Therefore, the time required to complete a single test (when all enable conditions are met) decreases as engine speed increases. For example, 6.00 seconds of data is required at 1000 rpm while double this time is required at 500 rpm and half this time is required at 2000 rpm. This data is collected only when enable conditions are met, and as such significantly more operating time is required than is indicated above. Generally, a report will be</p>	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>KtFABD_U_Normalizer1). This quotient is then multiplied by a quality factor calibration from a 17 x 17 table (Supporting Table KtFABD_K_QualFactor1). This result is referred to as the Ratio. Note that the quality factor ranges between 0 and 1 and represents robustness to false diagnosis in the current operating region. Regions with low quality factors are not used.</p> <p>Finally, a EWMA filter is applied to the Ratio metric to generate the Filtered Ratio malfunction criteria metric. Generally, a normal system will result in a negative Filtered Ratio while a failing system will result in a positive Filtered Ratio.</p> <p>The range of the Filtered Ratio metric is application specific since both the emissions sensitivity and relationship between imbalance and the Variance metric are application specific.</p>		<p>Note: first order lag filter coefficient applied to APC = 0.250</p> <p>Spark Advance</p> <p>Throttle Area (percent of max)</p> <p>Intake Cam Phaser Angle</p> <p>Exhaust Cam Phaser Angle</p> <p>Quality Factor (QF)</p> <p>QF calibrations are located in a 17x17 lookup table versus engine speed and load (Supporting Table KtFABD_K_QualFactor1). Quality factor values less than "1" indicate that we don't have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data.</p> <p>Fuel Control Status Closed Loop and Long Term FT Enabled for</p> <p>AIR pump not on CASE learn not active EGR - no device control, no intrusive diagnostics</p>	<p>-100 to 70 degrees</p> <p>0 to 200 percent</p> <p>0 to 50 degrees</p> <p>0 to 50 degrees</p> <p>>= 0.99</p> <p>>= 5.0 seconds Please see "Closed Loop Enable Criteria" and "Long Term FT Enable Criteria" in Supporting Tables.</p>	<p>made within 5 minutes of operation.</p> <p>For RSR or FIR, 30 tests must complete before the diagnostic can report.</p>	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					EVAP - no device control, no intrusive diagnostics Engine OverSpeed Protection Not Active Idle speed control normal PTO Not Active Injector base pulse width above min limit Rapid Step Response (RSR): RSR will trigger if the Ratio result from the last test is AND it exceeds the last Filtered ratio by Once triggered, the filtered ratio is reset to: Fast Initial Response (FIR): FIR will trigger when an NVM reset or code clear occurs. Once triggered, the filtered ratio is reset to: No Fault Active for:	 >= 0.65 >= 0.75 0.00 0.00 EngineMisfireDetected_F A MAP_SensorFA MAF_SensorFA ECT_Sensor_FA TPS_ThrottleAuthorityDef aulted FuelInjectorCircuit_FA AIR System FA EvapExcessPurgePsbl_F A		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						CamSensorAnyLocationF A		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Bank 2 Air-Fuel Ratio Imbalance	P219B	This monitor determines if a cylinder-to-cylinder air-fuel ratio imbalance is present on bank 2.	<p>Filtered Ratio ></p> <p>Note: The input to this metric is the pre catalyst oxygen sensor voltage. This voltage is used to generate a Variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to the air-fuel ratio imbalance (variance is higher with an imbalance than without). Multiple samples are collected in making a decision.</p> <p>The observed Variance is dependant on engine speed and load and so each result is normalized for speed and load by comparing it to a known "good system" result for that speed and load, and generating a Ratio metric.</p> <p>The Ratio metric is calculated by selecting a threshold calibration from a 17x17 table (Supporting Table KtFABD_U_VarThresh2) and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table (Supporting Table</p>	0.78	<p>See Bank 1 (P219A) Secondary Parameters and Enable Conditions.</p> <p>Quality Factor (QF)</p> <p>QF calibrations are located in a 17x17 lookup table versus engine speed and load (Supporting Table KtFABD_K_QualFactor2). Quality factor values less than "1" indicate that we don't have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data.</p> <p>Rapid Step Response (RSR):</p> <p>RSR will trigger if the Ratio result from the last test is</p> <p>AND it exceeds the last Filtered ratio by</p> <p>Once triggered, the filtered ratio is reset to:</p> <p>Fast Initial Response (FIR):</p> <p>FIR will trigger when an NVM reset or code clear occurs. Once triggered, the</p>	<p>>= 0.99</p> <p>>= 0.65</p> <p>>= 0.75</p> <p>0.00</p>	See Bank 1 info	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>KtFABD_U_Normalizer2). This quotient is then multiplied by a quality factor calibration from a 17 x 17 table (Supporting Table KtFABD_K_QualFactor2). This result is referred to as the Ratio. Note that the quality factor ranges between 0 and 1 and represents robustness to false diagnosis in the current operating region. Regions with low quality factors are not used.</p> <p>Finally, a EWMA filter is applied to the Ratio metric to generate the Filtered Ratio malfunction criteria metric. Generally, a normal system will result in a negative Filtered Ratio while a failing system will result in a positive Filtered Ratio.</p> <p>The range of the Filtered Ratio metric is application specific since both the emissions sensitivity and relationship between imbalance and the Variance metric are application specific.</p>		filtered ratio is reset to:	0.00		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Performance (naturally aspirated)	P2227	Compares baro sensor to the calculated baro estimate (part throttle calculation or unthrottled MAP)	Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 15.0 kPa ≤ 1.24 miles	Engine Run Time No Active DTCs:	> 0.00 seconds AmbPresSnsrCktFA ECT_Sensor_Ckt_FA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips
			OR Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 20.0 kPa > 1.24 miles	Time between current ignition cycle and the last time the engine was running Engine is not rotating No Active DTCs:	> 409.6 seconds EngineModeNotRunTimer Error MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA	4 failures out of 5 samples 1 sample every 12.5 msec	
			Barometric Pressure OR Barometric Pressure	< 50.0 kPa > 115.0 kPa	No Pending DTCs:	MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (non-boosted applications)	P2228	Detects a continuous short to low or open in either the signal circuit or the BARO sensor.	BARO Voltage	< 40.0 % of 5 Volt Range (2.0 Volts = 128.0 kPa)	Engine Run Time	> 0.00 seconds	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (non-boosted applications)	P2229	Detects an open sensor ground or continuous short to high in either the signal circuit or the BARO sensor.	BARO Voltage	> 90.0 % of 5 Volt Range (4.5 Volts = 127.8 kPa)	Engine Run Time	> 0.00 seconds	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Intermittent	P2230	Detects a noisy or erratic barometric pressure input	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current BARO reading - BARO reading from 12.5 milliseconds previous)	> 100 kPa 80 consecutive BARO samples	No Active DTCs:	AmbPresSnsrCktFA ECT_Sensor_Ckt_FA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA	4 failures out of 5 samples	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State ===== All of the above met for at least 2.5 seconds, and then the Force Cat Rich intrusive stage is requested. ===== During Stuck Lean test the following must stay TRUE or the test will abort: $0.96 \leq \text{Fuel EQR} \leq 1.08$	not in control of purge not in estimate mode = enabled = not active = not active $\geq 180.0 \text{ sec}$ $500 \leq ^\circ\text{C} \leq 980$ = DFCE possible =====		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Predicted Catalyst temp Fuel State DTC's Passed ===== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	500 ≤ °C ≤ 980 DFCO possible = P2270 (and P2272 if applicable) = P013E (and P014A if applicable) = P013A (and P013C if applicable)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State ===== All of the above met for at least 2.5 seconds, and then the Force Cat Rich intrusive stage is requested. ===== During Stuck Lean test the following must stay TRUE or the test will abort: $0.96 \leq \text{Fuel EQR} \leq$ 1.08	not in control of purge not in estimate mode = enabled = not active = not active $\geq 180.0 \text{ sec}$ $500 \leq ^\circ\text{C} \leq 980$ = DFCE possible =====		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Fuel State DTC's Passed ===== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	= DFCO possible = P2270 (and P2272 if applicable) = P013E (and P014A if applicable) = P013A (and P013C if applicable)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump	P228C	Detects measured fuel rail pressure bias too low from desired fuel pressure.	Desired Pressure - Measure Pressure	>= 3.00 Mpa	Battery Voltage Low Side Fuel Pressure Engine Run Time Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and	>= 11 Volts > 0.275 MPa >= KtFHPD_t_PumpCntrlEng RunThrsh(see supporting tables) Enabled when a code clear is not active or not exiting device control Engine is not cranking	Pressure Error - 750 failures out of 938 samples	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -10.0 degC -10 <= Temp degC <= 100		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump	P228D	Detects measured fuel rail pressure bias too high from desired fuel pressure	Desired Pressure - Measure Pressure	<= -3.00 Mpa	Battery Voltage Low Side Fuel Pressure Engine Run Time Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement	>= 11 Volts > 0.275 MPa >= KtFHPD_t_PumpCntrlEng RunThrsh(see supporting tables) Enabled when a code clear is not active or not exiting device control Engine is not cranking	Pressure Error - 750 failures out of 938 samples	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -10.0 DegC -10 <= Temp degC <= 100		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Bank 1	P2430	This DTC detects a stuck in range pressure sensor signal when the AIR pump is commanded on.	Average Pressure Error AND Signal Variation	< 0.50 kPa < 0.15 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not No active DTCs:	> 74 kPa > -10.0 deg C > -10.0 deg C < 56.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRSysPressSnsrB1CktL oFA AIRSysPressSnsrB1CktHi FA ControllerProcessorPerf_ FA 5VoltReferenceA_FA 5VoltReferenceB_FA	Stuck in range cumulative time > 5.0 seconds Frequency: Once per trip when SAI pump is commanded On	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Performance Bank 1	P2431	This DTC detects a skewed pressure sensor signal via a comparison of the AIR pressure sensor signal and estimated BARO, as well as an evaluation of the quality of the comparison.	Difference between AIR pressure sensor and BARO (Pump Commanded Off) or OR Difference between AIR pressure sensor and BARO (Pump Commanded On)	> 18.0 kPa < -10.0 kPa > 18.0 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Transfer Case not in 4WD Low Run/crank active No active DTCs:	> 74 kPa > -10.0 deg C > -10.0 deg C < 56.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRSysPressSnsrB1CktLoFA AIRSysPressSnsrB1CktHiFA MAF_SensorFA EngineMisfireDetected_FA ControllerProcessorPerf_FA 5VoltReferenceA_FA 5VoltReferenceB_FA	Skewed sensor cumulative test weight > 5.0 seconds Continuous 6.25ms loop Skewed sensor cumulative test weight is based on distance from the last Baro update. See Baro Skewed Sensor Weight Factor table.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Low Voltage Bank 1	P2432	This DTC detects an out of range low AIR pressure sensor signal	AIR Pressure Sensor signal	< 6 % of 5Vref for 800 failures out of 1,000 samples	No active DTCs:	ControllerProcessorPerf_ FA 5VoltReferenceA_FA 5VoltReferenceB_FA	1,000 samples (6.25 ms per sample) Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Hi Voltage Bank 1	P2433	This DTC detects an out of range high AIR pressure sensor signal	AIR Pressure Sensor signal	> 94 % of 5Vref for 800 failures out of 1,000 samples	No active DTCs:	ControllerProcessorPerf_ FA 5VoltReferenceA_FA 5VoltReferenceB_FA	1,000 samples (6.25 ms per sample) Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Bank 2	P2435	This DTC detects a stuck in range pressure sensor signal when the AIR pump is commanded on.	Average Pressure Error AND Signal Variation	< 0.50 kPa < 0.15 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not No active DTCs:	> 74 kPa > -10.0 deg C > -10.0 deg C < 56.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRSysPressSnsrB1CktL oFA AIRSysPressSnsrB1CktHi FA ControllerProcessorPerf_ FA 5VoltReferenceA_FA 5VoltReferenceB_FA	Stuck in range cumulative time > 5.0 seconds Frequency: Once per trip when SAI pump is commanded On	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Performance Bank 2	P2436	This DTC detects a skewed pressure sensor signal via a comparison of the AIR pressure sensor signal and estimated BARO, as well as an evaluation of the quality of the comparison.	Difference between AIR pressure sensor and BARO (Pump Commanded Off) or OR Difference between AIR pressure sensor and BARO (Pump Commanded On)	> 18.0 kPa < -10.0 kPa > 18.0 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Transfer Case not in 4WD Low Run/crank active No active DTCs:	> 74 kPa > -10.0 deg C > -10.0 deg C < 56.0 > 3,600.0 seconds > 10.0 OR < 32.0 Volts < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRSysPressSnsrB1CktLoFA AIRSysPressSnsrB1CktHiFA MAF_SensorFA EngineMisfireDetected_FA ControllerProcessorPerf_FA 5VoltReferenceA_FA 5VoltReferenceB_FA	Skewed sensor cumulative test weight > 5.0 seconds Continuous 6.25ms loop Skewed sensor cumulative test weight is based on distance from the last Baro update. See Baro Skewed Sensor Weight Factor table.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Low Voltage Bank 2	P2437	This DTC detects an out of range low AIR pressure sensor signal	AIR Pressure Sensor signal	< 6 % of 5Vref for 800 failures out of 1,000 samples	No active DTCs:	ControllerProcessorPerf_ FA 5VoltReferenceA_FA 5VoltReferenceB_FA	1,000 samples (6.25 ms per sample) Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Hi Voltage Bank 2	P2438	This DTC detects an out of range high AIR pressure sensor signal	AIR Pressure Sensor signal	> 94 % of 5Vref for 800 failures out of 1,000 samples	No active DTCs:	ControllerProcessorPerf_ FA 5VoltReferenceA_FA 5VoltReferenceB_FA	1,000 samples (6.25 ms per sample) Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Shut-off Valve Stuck Open	P2440	This DTC detects if one or both of the AIR system control valves is stuck open. This test is run during Phase 2 (Pump commanded On, valve commanded closed)	Average Pressure Error or or	< Bank 1 Valve Pressure Error table < Bank 2 Valve Pressure Error table > 32 kPa for either Bank	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Stability Time AIR diagnostic Phase 1 passed No active DTCs:	> 74 kPa > -10.0 deg C > -10.0 deg C < 56.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec > 0.5 seconds AIRSystemPressureSens or FA AIRValveControlCircuit FA AIRPumpControlCircuit FA MAF_SensorFA AmbientAirDefault_NA IAT_SensorFA ECT_Sensor_FA EngineMisfireDetected_FA CatalystSysEfficiencyLoB1_FA CatalystSysEfficiencyLoB2_FA ControllerProcessorPerf_FA 5VoltReferenceA_FA 5VoltReferenceB_FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA	Phase 2 Conditional test weight > 1.5 sec Frequency: Once per trip when AIR pump commanded On Conditional test weight is calculated by multiplying the following Factors: Phase 2 Baro Test Weight Factor, Phase 2 MAF Test Weight Factor, Phase 2 System Volt Test Weight Factor, Phase 2 Ambient Temp Test Weight Factor (see Supporting Tables)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pump Stuck On	P2444	This DTC detects if the SAI pump is stuck On. This test is run during Phase 3 (Pump commanded Off, valve commanded closed)	Average Pressure Error or or	> Bank 1 Pump Pressure Error table > Bank 2 Pump Pressure Error table < -32 kPa for either bank	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Stability Time AIR diagnostic Phase 1 passed AIR diagnostic Phase 2 passed No active DTCs:	> 74 kPa > -10.0 deg C > -10.0 deg C < 56.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for > 2.0 sec < 5,000 RPM > 50 gm/s for > 3.0 sec > 4.0 seconds Phase 3 cumulative test weight is based on the distance from the last Baro update. See Baro Skewed Sensor Weight Factor table. AIRSystemPressureSensorFA AIRValveControlCircuit FA AIRPumpControlCircuit FA MAF_SensorFA AmbientAirDefault_NA IAT_SensorFA ECT_Sensor_FA EngineMisfireDetected_FA CatalystSysEfficiencyLoB1_FA CatalystSysEfficiencyLoB2_FA ControllerProcessorPerf_FA 5VoltReferenceA_FA 5VoltReferenceB_FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA	Phase 3 Cumulative test weight > 2.0 sec. Frequency: Once per trip when AIR pump is commanded On	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Torque Request Circuit	P2544	Determines if the torque request from the TCM is valid	Protect error - Serial Communication message - (\$199 - PTEI3) OR Rolling count error - Serial Communication message (\$199 - PPEI3) rolling count value OR Range Error - Serial Communication message - (\$199 - PTEI3) TCM Requested Torque Increase OR Multi-transition error - Trans torque intervention type request change	Message <> two's complement of message Message <> previous message rolling count value + one > 350 Nm Requested torque intervention type toggles from not increasing request to increasing request	Diagnostic enabled/ disabled Power Mode Engine Running Run/Crank Active No Serial communication loss to TCM (U0101)	Enabled = Run = True > 0.50 Sec No loss of communication	>= 16 Protect errors during key cycle. Performed on every received message >= 6 Rolling count errors out of 10 samples. Performed on every received message >= 6 range errors out of 10 samples. Performed on every received message >= 4 multi-transitions out of 5 samples. Performed every 200 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM/PCM Internal Engine Off Timer Performance 11.12.41 and beyond	P2610	<p>This DTC determines if the hardware timer does not initialize or count properly. There are two tests to ensure proper functioning of the timer: Count Up Test (CUT) and Range Test (RaTe).</p> <p>Count Up Test (CUT): Verifies that the HWIO timer is counting up with the proper increment.</p> <p>Range Test (RaTe): When the run/crank is not active both the hardware and mirror timers are started. The timers are compared when ECM shutdown is initiated or run/crank becomes active.</p>	<p>Count Up Test: Time difference between the current read and the previous read of the timer</p> <p>Range Test: The variation of the HWIO timer and mirror timer is</p>	<p>> 1.50 seconds</p> <p>> 25 %.</p>			<p>Count Up Test: 8 failures out of 40 samples 1 sec / sample</p> <p>Continuous while run/crank is not active and until controller shutdown is initiated.</p> <p>Range Test: Once per trip when controller shutdown is initiated or run/crank becomes active.</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communicati on Bus A Off	U0073	This DTC monitors for a BUS A off condition	Bus off failures out of these samples	≥ 5 counts ≥ 5 counts	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line or Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds	Not Active on Current Key Cycle Enabled Not Active Not Active ≥= 11.00 or ≥= 6.41 = run = 0 (1 indicates enabled) = Active > 11.00	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					CAN hardware is bus OFF for	> 0.1125 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With TCM	U0101	This DTC monitors for a loss of communication with the transmission control module	Message is not received from controller for Message \$0C7 Message \$0F9 Message \$1F5	 ≥ 10.0 seconds ≥ 10.0 seconds ≥ 10.0 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line or Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds Power Mode is in	Not Active on Current Key Cycle Enabled Not Active Not Active ≥= 11.00 or ≥= 6.41 = run = 0 (1 indicates enabled) = Active > 11.00	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					accessory or run or crank and High Voltage Virtual Network Management is not active for U0101 TCM	> 0.4000 seconds Not Active on Current Key Cycle is present on the bus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Fuel Pump Control Module	U0109	This DTC monitors for a loss of communication with the fuel pump control module	Message is not received from controller for	≥ 10.0 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line or Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds Power Mode is in	Not Active on Current Key Cycle Enabled Not Active Not Active >= 11.00 or >= 6.41 = run = 0 (1 indicates enabled) = Active > 11.00	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					accessory or run or crank and High Voltage Virtual Network Management is not active for U0109 Fuel Pump Control Module	> 0.4000 seconds Not Active on Current Key Cycle is present on the bus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Composition Sensor Circuit Low	P0178	Detects Out of Range Low Frequency Signal	Flex Fuel Sensor Output Frequency	< 45 Hertz	Powertrain Relay	> 11.0 Volts	50 failures out of 63 samples 100 ms loop Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Composition Sensor Circuit High	P0179	Detects Out of Range High Frequency Signal	Flex Fuel Sensor Output Frequency	> 155 Hertz <= 185	Powertrain Relay	> 11.0 Volts	50 failures out of 63 samples 100 ms loop Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Performance (For use on vehicles with mechanical transfer pump dual fuel tanks)	P2066	This DTC will detect a fuel sender stuck in range in the secondary fuel tank.	<p>*****</p> <p>Fuel Level in Secondary Tank Remains in an Unreadable Range too Long</p> <p>*****</p> <p>If fuel volume in primary tank is and fuel volume in secondary tank is and remains in this condition for</p> <p>OR</p> <p>*****</p> <p>Fuel Level is in a Readable Range for both Primary and Secondary Tanks too Long</p> <p>*****</p> <p>Volume in primary tank is and volume in secondary tank is and remains in this condition for</p> <p>OR</p> <p>*****</p> <p>Distance Traveled without a Secondary Fuel Level Change</p> <p>*****</p> <p>If the vehicle is driven a distance of 180 miles without the secondary fuel level changing by 3 liters, then the sender must be</p>	<p>≥ 1,023.0 liters</p> <p>< 2.0 liters</p> <p>62 miles</p> <p>< 1,023 liters</p> <p>> 2 liters</p> <p>3,630 seconds</p>	<p>Engine Running</p> <p>No active DTCs:</p> <p>Volume in secondary tank</p>	<p>VehicleSpeedSensor_FA</p> <p>≥ 2.0 liters</p>	250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			stuck.					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Circuit Low Voltage (For use on vehicles with dual fuel tanks)	P2067	This DTC will detect a fuel sender stuck out of range low in the secondary fuel tank.	Fuel level Sender % of 5V range	< 10 %			100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Circuit High Voltage (For use on vehicles with dual fuel tanks)	P2068	This DTC will detect a fuel sender stuck out of range low in the secondary fuel tank.	Fuel level Sender % of 5V range	> 60 %			100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Low Limit Bank 1 (Too Rich)	P2096	Determines if the post catalyst O2 sensor based fuel control system has reached it's low limit authority, indicating a rich emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too rich, the post catalyst O2 integral offset control is decreased. This results in lean bias fuel control in an attempt to correct the rich post O2 voltage.	Rich Fail counter High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 101 % for >= 10,000,000,000.0 seconds. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 100 % for >= 5.0 seconds.	>= 540 counts per 675 sample counts Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration The following conditions must be true for > 0.0 seconds: Ambient Air Pressure Engine AirFlow Intake Manifold Pressure Induction Air Temperature Start-up Coolant Temp. PTO Intrusive diag. fuel control Long Term Secondary Fuel Trim Enabled (see "Long Term Secondary Fuel Trim Enable Criteria" in Supporting Tables) High Vapor Conditions No Fault Active for:	Yes Yes Yes Yes Yes >= 70 kPa >= 0.0 g/s <= 10,000.0 >= 10 kPa <= 255 >= -20 deg. C <= 150 >= -20 deg. C Not Active Not Active Not Present AmbientAirDefault AIR System FA Ethanol Composition Sensor FA ECT_Sensor_FA EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorFA CamSensorAnyLocationFA EvapEmissionSystem_FA	Frequency: Continuous Monitoring in 100ms loop. Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EvapFlowDuringNonPurge_FA FuelTankPressureSnrCkt_FA EvapPurgeSolenoidCircuit_FA EvapSmallLeak_FA EvapVentSolenoidCircuit_FA FuelInjectorCircuit_FA MAF_SensorFA MAF_SensorTFTKO MAP_SensorFA MAP_EngineVacuumStatus EngineMisfireDetected_FA A/F Imbalance Bank1 O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA The above general enable conditions must be true for: Minimum accumulated counts in each cell required before counters will increment: Deceleration 10,000,000,272,564,200 Idle 10,000,000,272,564,200 Cruise 50 Light Acceleration 50 Heavy Acceleration 50 Fail counter will increment if sample counter increments AND Post oxygen sensor control integral offset (in		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					mV) is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Heavy Acceleration	<= -96 (control min.= -160) -96 (control min.= -160) -656 (control min.= -720) -656 (control min.= -720) -656 (control min.= -720) > 2,000 mV 2,000 mV 753 mV 753 mV 753 mV		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System High Limit Bank 1 (Too Lean)	P2097	Determines if the post catalyst O2 sensor based fuel control system has reached it's high limit authority, indicating a lean emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too lean, the post catalyst O2 integral offset control is increased. This results in rich bias fuel control in an attempt to correct the lean post O2 voltage.	Lean Fail counter High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 101 % for >= 10,000,000,000.0 seconds. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 100 % for >= 5.0 seconds.	>= 720 counts per 675 sample counts Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	Same as P2096 except for the following: Fail counter will increment if sample counter increments AND Post oxygen sensor control integral offset (in mV) is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Heavy Acceleration	>= 96 (control max.= 160) 96 (control max.= 160) 528 (control max.= 592) 528 (control max.= 592) 528 (control max.= 592) < 0 mV 0 mV 589 mV 589 mV 589 mV	Frequency: Continuous Monitoring in 100ms loop. Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Low Limit Bank 2 (Too Rich)	P2098	Determines if the post catalyst O2 sensor based fuel control system has reached it's low limit authority, indicating a rich emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too rich, the post catalyst O2 integral offset control is decreased. This results in lean bias fuel control in an attempt to correct the rich post O2 voltage.	Rich Fail counter High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 101 % for >= 10,000,000,000.0 seconds. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 100 % for >= 5.0 seconds.	>= 540 counts per 675 sample counts Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	Same as P2096 except for the following: Bank1 Fault Active criteria are replaced by the equivalent Bank2 Fault Active criteria. Fail counter will increment if sample counter increments AND Post oxygen sensor control integral offset is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Heavy Acceleration	<= -96 (control min.= -160) -96 (control min.= -160) -656 (control min.= -720) -656 (control min.= -720) -656 (control min.= -720) > 2,000 mV 2,000 mV 753 mV 753 mV 753 mV	Frequency: Continuous Monitoring in 100ms loop. Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System High Limit Bank 2 (Too Lean)	P2099	Determines if the post catalyst O2 sensor based fuel control system has reached it's high limit authority, indicating a lean emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too lean, the post catalyst O2 integral offset control is increased. This results in rich bias fuel control in an attempt to correct the lean post O2 voltage.	Lean Fail counter High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 101 % for >= 10,000,000,000.0 seconds. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 100 % for >= 5.0 seconds.	>= 720 counts per 675 sample counts Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	Same as P2096 except for the following: Bank1 Fault Active criteria are replaced by the equivalent Bank2 Fault Active criteria. Fail counter will increment if sample counter increments AND Post oxygen sensor control integral offset is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Heavy Acceleration	>= 96 (control max.= 160) 96 (control max.= 160) 528 (control max.= 592) 528 (control max.= 592) < 0 mV 0 mV 589 mV 589 mV 589 mV	Frequency: Continuous Monitoring in 100ms loop. Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Conductivity Out Of Range (water in fuel)	P2269	Detects the presence of High Conductivity Fuel (e.g. water in fuel) via a specific range of sensor frequency	Flex Fuel Sensor Output Frequency	> 185 Hertz	Powertrain Relay	> 11.0 Volts	50 failures out of 63 samples 100 ms loop Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Output Speed Sensor (TOSS)	P0502	No activity in the TOSS circuit	TOSS Raw Speed	≤ 60 RPM	Engine TorqueMinimum Throttle openingEngine SpeedIgnition voltagePTO EngineTorqueInaccurate P0503	90.0 ≤ N-M ≤ 8,191.8 ≥ 8.0 % 1,500 ≤ RPM ≤ 6,500 11.0 ≤ Volts ≤ 32.00 not activeKeETQC_b_MinTransRemedial = TRUE: MSFR_b_EngMisfDtctd_FA, MAFR_b_MAF_SnsrTFT KO, MAPR_b_MAP_SnsrTFT KO KeETQC_b_MinTransRemedial = FALSE: FULR_b_FuellnjCkt_TFT KO, MAFR_b_MAF_SnsrTFT KO, XOYR_b_SecurityFit, Not failed this key cycle	≥ 4.5 sec	Type Type B, 2 Trips Type B, 2 Trips trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Output Speed Sensor (TOSS)	P0503	TOSS Signal Intermittent	Loop-to-Loop change in TOSS	≥ 350 RPM	Raw Output Speed Output Speed change Time since transfer case range change Ignition voltage Engine Speed Vehicle Speed PTO	> 300 RPM for ≥ 2.0 sec ≤ 150 RPM for ≥ 2.0 sec ≥ 6.0 sec 11.0 ≤ Volts ≤ 32.00 200 ≤ RPM ≤ 7,500 for ≥ 5.0 seconds ≤ 511.99 MPH for ≥ 5.0 sec not active	≥ 3.3 sec	Type Type B, 2 Trips Type B, 2 Trips trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Range / Performance	P0806	Detects if Clutch Pedal Position Sensor is Stuck in a range indicative of a vehicle NOT in gear, when the vehicle is determined to be in gear. Gear determination is made by verifying that the ratio of engine RPM versus Transmission Output Speed (N/TOS) represents a valid gear.	Filtered Clutch Pedal Position Error when the vehicle is determined to be in gear	> 5 %	N/TOS Ratio: Transfer Case: Vehicle speed: Engine Torque: Clutch Pedal Position: OR No Active DTCs:	Must match actual gear (i.e. vehicle in gear) Not in 4WD Low range > 3.4 MPH > EngTorqueThreshold Table < ResidualErrEnableLow Table > ResidualErrEnableHigh Table ClutchPstnSnsrCktHi FA ClutchPstnSnsrCktLo FA CrankSensor_FA Transmission Output Shaft Angular Velocity Validity VehicleSpeedSensor_FA	25 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Low	P0807	Detects Continuous Circuit Out-of-Range Low or Open	Clutch Position Sensor Circuit for	< 4 % of Vref 200 counts out of 250 samples	Engine Not Cranking System Voltage No active DTCs:	> 11.0 Volts 5VoltReferenceB_FA	25 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit High	P0808	Detects Continuous Circuit Out-of-Range High	Clutch Position Sensor Circuit for	> 96 % of Vref 200 counts out of 250 samples	Engine Not Cranking System Voltage No active DTCs:	> 11.0 Volts 5VoltReferenceB_FA	25 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Not Learned	P080A	Detects Invalid Clutch Pedal Fully Applied Learn Position values	Fully Applied Learn Position OR	< 9.0 % > 36.0 %	OBD Manufacturer's Enable Counter	= 0	250 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Switch State Undertermin ed	P155A	Detects when cruise switch state cannot be determined, such as low voltage conditions	cruise switch state remains undetermined for greater than a calibratable time				fail continuously for greater than 15.3 seconds	MIL: Type C, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Economy Mode Circuit Low	P159F	This DTC will detect a fuel saver switch input that is too low out of range.	Fuel Saver Switch % of 5V range The normal operating range of the fuel saver mode switch is: Switch depressed % of 5V range: Switch released % of 5V range:	< 29.0 % < 66.8 % ≥ 29.0 % < 88.8 % ≥ 72.8 %			200 failures out of 250 samples 25 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Economy Mode Circuit High	P15A0	This DTC will detect a fuel saver switch input that is too high out of range.	Fuel Saver Switch % of 5V range The normal operating range of the fuel saver mode switch is: Switch depressed % of 5V range: Switch released % of 5V range:	≥ 88.8 % < 66.8 % ≥ 29.0 % < 88.8 % ≥ 72.8 %			200 failures out of 250 samples 25 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Economy Mode Switch Performance	P15A1	This DTC will detect a fuel saver switch input that is in an indeterminate range.	Fuel Saver Switch % of 5V is in an indeterminate range: The normal operating range of the fuel saver mode switch is: Switch depressed % of 5V range: Switch released % of 5V range:	$66.8\% \leq \% \text{ of } 5 \text{ volts} < 72.8\%$ $< 66.8\%$ $\geq 29.0\%$ $< 88.8\%$ $\geq 72.8\%$			200 failures out of 250 samples 25 ms / sample	Type B, 2 Trips

Engine run time greater than
KtFSTA_t_ClosedLoopAutostart (HYBRID ONLY)
 AutoStart CoolantX1 X2 X3 X4 X5 X6 X7 X8 X9 X10 X11
 Close Loop Enable TimeY1 Y2 Y3 Y4 Y5 Y6 Y7 Y8 Y9 Y10 Y11
and
KtFSTA_t_ClosedLoopTime
 Start-Up CoolantX1 X2 X3 X4 X5 X6 X7 X8 X9 X10 X11
 Close Loop Enable TimeY1 Y2 Y3 Y4 Y5 Y6 Y7 Y8 Y9 Y10 Y11
and pre converter O2 sensor voltage less than
KfFULC_U_O2_SensorReadyThresh
Lo
 Voltage < XXXXmilliVolts
for
KcFULC_O2_SensorReadyEvents
 Time (events * 12.5 milliseconds) > XXXXevents
and
COSC (Converter Oxygen Storage Control) not enabled
and
Consumed AirFuel Ratio is stoichiometry i.e. not in component protection
and
POPD or Catalyst Diagnostic not intrusive
and
Turbo Scavenging Mode not enabled
and
All cylinders whose valves are active also have their injectors enabled
and
O2S_Bank_1_TFTKO, O2S_Bank_2_TFTKO, FuelInjectorCircuit_FA and CylnderDeacDriverTFTKO = False

Long Term FT Enable Criteria

Closed Loop Enable and
Coolant greater than
KfFCLL_T_AdaptiveLoCoolant

Coolant > XXXXCelcius

or less than
KfFCLL_T_AdaptiveHiCoolant

Coolant < XXXXCelcius

and
KtFCLL_p_AdaptiveLowMAP_Limit

Barometric Pressure	X1	X2	X3	X4	X5	X6	X7	X8	X9
Manifold Air Pressure	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9

and
TPS_ThrottleAuthorityDefaulted =
False

and
Flex Fuel Estimate Algorithm is not active

and
Excessive fuel vapors boiling off from the engine oil algorithm (BOFR) is not
enabled

and
Catalyst or EVAP large leak test not
intrusive

Secondary Fuel Trim Enable
Criteria

Closed Loop Enable and
KfFCLP_U_O2ReadyThrshLo

Voltage < XXXXmilliVolts

for
KcFCLP_Cnt_O2RdyCyclesThrsh

Time (events * 12.5 milliseconds) > XXXXevents

Long Term Secondary Fuel Trim
Enable Criteria

KtFCLP_t_PostIntglDisableTime

12 OBDG05B Engine Diagnostics

MAIN SECTION
1 OF 2 SECTIONS

Start-Up Coolant	X1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Post Integral Enable Time	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11

Plus

KtFCLP_t_PostIntglRampInTime

Start-Up Coolant	X1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Post Integral Ramp In Time	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11

and

KeFCLP_T_IntegrationCatalystMax

Modeled Catalyst Temperature < XXXXCelcius

and

KeFCLP_T_IntegrationCatalystMin

Modeled Catalyst Temperature > XXXXCelcius

and

PO2S_Bank_1_Snsr_2_FA and

PO2S_Bank_2_Snsr_2_FA = False

Description: Table of delta MAP values as a function of desired throttle position. The output of this table provides a delta MAP that if the measured minus the estimated MAP exceeds, is considered a fail.

Notes:

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	40.13	36.99	20.80	19.78	11.14	22.44	21.73	18.77	255.00

Description: Table of delta MAF values as a function of desired throttle position. The output of this table provides a delta MAF that if the measured minus the estimated MAF exceeds, is considered a fail.

Notes:

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	18.95	19.70	14.20	19.48	14.28	31.40	35.20	56.65	255.00

Description: Table of maximum MAF values vs. engine speed. This is the maximum MAF the engine can see under all ambient conditions.

Notes:

y/x	600.00	1,400.00	2,200.00	3,000.00	3,800.00	4,600.00	5,400.00	6,200.00	7,000.00
1.00	20.00	50.00	80.00	115.00	150.00	176.00	194.00	203.00	210.00

Description: Table of maximum MAF values vs. system voltage. The output of the air meter is clamped to lower values as system voltage drops off.

Notes:

y/x	6.00	7.00	8.00	9.00	10.00	11.00	12.00	13.00	14.00
1.00	0.00	20.00	60.00	150.00	250.00	300.00	300.00	300.00	300.00

Description: The Run/Crank voltages required to pull in the PT relay as a function of induction air temperature.

Notes:

y/x	23.00	85.00	95.00	105.00	125.00
1.00	7.00	8.70	9.00	9.20	10.00

Description: The max time for the Last Seed Timeout as a function of operating loop time sequence.

Notes:

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	0.175	0.175	0.175	409.594

Description: The enabling flags for the program sequence watch as a function of operating loop time sequence.

Notes:

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	1	1	1	1

Description: Threshold for determining when the difference between commanded spark and applied spark exceeds the torque security requirement. It is a function of engine rpm and APC.

Notes:

y/x	500.00	980.74	1,461.48	1,942.23	2,422.97	2,903.71	3,384.45	3,865.20	4,345.94	4,826.68	5,307.42	5,788.16	6,268.91	6,749.65	7,230.39	7,711.13	8,191.88
80.00	125.00	18.05	20.27	24.36	28.61	27.39	26.61	27.55	29.88	30.61	31.14	28.16	19.73	11.31	10.42	10.42	10.42
160.00	125.00	18.39	19.66	22.31	25.52	25.94	24.42	24.14	24.88	26.11	27.39	25.58	18.97	12.34	11.66	11.66	11.66
240.00	125.00	18.73	19.09	20.59	23.03	24.64	22.58	21.53	21.33	22.80	24.48	23.58	18.66	13.72	13.20	13.20	13.20
320.00	125.00	19.11	18.58	19.14	21.00	23.47	21.00	19.47	18.67	20.27	22.16	22.03	18.81	15.58	15.23	15.23	15.23
400.00	125.00	18.92	18.09	17.88	19.30	22.42	19.66	17.77	16.61	18.25	20.23	20.73	18.89	17.05	16.84	16.84	16.84
480.00	125.00	18.61	17.52	16.77	17.81	20.66	17.58	15.73	14.91	16.34	18.08	18.47	16.75	15.03	14.84	14.84	14.84
560.00	125.00	18.19	16.19	15.30	16.38	18.48	15.59	13.97	13.36	14.69	16.27	16.61	15.02	13.44	13.27	13.27	13.27
640.00	125.00	17.22	14.52	13.78	14.75	16.72	14.02	12.53	12.05	13.30	14.77	15.05	13.45	11.86	11.69	11.69	11.69
720.00	125.00	15.81	13.28	12.66	13.56	15.41	12.84	11.48	11.06	12.25	13.64	13.86	12.27	10.66	10.48	10.48	10.48
800.00	125.00	15.81	13.28	12.66	13.56	15.41	12.84	11.48	11.06	12.25	13.64	13.86	12.27	10.66	10.48	10.48	10.48
880.00	125.00	15.81	13.28	12.66	13.56	15.41	12.84	11.48	11.06	12.25	13.64	13.86	12.27	10.66	10.48	10.48	10.48
960.00	125.00	15.81	13.28	12.66	13.56	15.41	12.84	11.48	11.06	12.25	13.64	13.86	12.27	10.66	10.48	10.48	10.48
1,040.00	125.00	15.81	13.28	12.66	13.56	15.41	12.84	11.48	11.06	12.25	13.64	13.86	12.27	10.66	10.48	10.48	10.48
1,120.00	125.00	15.81	13.28	12.66	13.56	15.41	12.84	11.48	11.06	12.25	13.64	13.86	12.27	10.66	10.48	10.48	10.48
1,200.00	125.00	15.81	13.28	12.66	13.56	15.41	12.84	11.48	11.06	12.25	13.64	13.86	12.27	10.66	10.48	10.48	10.48
1,280.00	125.00	15.81	13.28	12.66	13.56	15.41	12.84	11.48	11.06	12.25	13.64	13.86	12.27	10.66	10.48	10.48	10.48
1,360.00	125.00	15.81	13.28	12.66	13.56	15.41	12.84	11.48	11.06	12.25	13.64	13.86	12.27	10.66	10.48	10.48	10.48

Description: Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

Notes:

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	11.14	11.14	11.14	11.14	11.14	11.14

Description: Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

Notes:

y/x	-40.00	-20.00	-10.00	0.00	50.00	90.00
200.00	400.00	400.00	400.00	400.00	400.00	400.00
400.00	400.00	400.00	400.00	400.00	400.00	400.00
500.00	400.00	400.00	400.00	400.00	400.00	400.00
550.00	400.00	400.00	400.00	400.00	400.00	400.00
800.00	323.25	323.25	323.25	323.25	209.30	188.74
1,000.00	323.25	323.25	323.25	323.25	191.05	172.46
1,200.00	311.36	278.39	254.85	251.31	108.68	93.42
1,400.00	215.24	190.95	174.00	170.54	65.96	52.25
1,600.00	157.34	138.13	125.34	121.94	45.91	35.06
2,100.00	69.88	57.49	50.73	47.44	18.97	14.85
2,600.00	46.48	37.57	33.61	29.97	16.77	12.14
3,100.00	53.43	43.08	38.48	34.27	18.93	13.56
3,600.00	58.87	47.48	42.42	37.78	20.90	14.99
4,100.00	64.83	52.65	47.24	42.28	24.24	17.92
4,600.00	73.03	60.24	54.56	49.35	30.40	23.76
5,100.00	83.17	69.89	63.98	58.57	38.89	32.00
7,200.00	112.17	97.56	91.07	85.12	63.47	55.89

Description: Quality weight-based on engine run time. This allows adjustment of the weighting factors at various engine run times in order to prevent the updating of the cumulative quality timer or to change the value of the average qualified residual energy calculation to prevent false Fails of the diagnostic under circumstances inappropriate to update the calculation of the average qualified residual value.

Notes:

y/x	0	1	3	3	4	5	10	15	20
1	0	0	0	1	1	1	1	1	1

Description: Exit Catalyst Warm-up mode if Engine Run Time is greater than this value. This table is based on percent ethanol (x-axis) and catmon's NormRatio_EWMA value (y-axis). The NormRatio_EWMA value determines the state of the catalyst. Typically, NormRatio_EWMA values below 0.35 (0 is bad and 1 is good) represent catalysts that have degraded. The emission performance of these degraded catalysts can be improved by extending catalyst light off of GetE85R_Pct_FFS_CompAtEngFloat.

Notes:

y/x	0	25	50	75	100
0.000	18	18	18	18	18
0.125	18	18	18	18	18
0.250	18	18	18	18	18
0.375	18	18	18	18	18
0.500	18	18	18	18	18
0.625	18	18	18	18	18
0.750	18	18	18	18	18
0.875	18	18	18	18	18
1.000	18	18	18	18	18

Description: This is the x-axis for the KtCSED_K_TimeWght calibration table. Refer to the description for KtCSED_K_TimeWght for details.

Notes:

y/x	1	2	3	4	5	6	7	8	9
1	0	1	3	3	4	5	10	15	20

Description: Cam Position Error Limit for performance diagnostic

Notes:

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

Description:																	
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

Description:																	
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

Description:																	
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,200	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,600	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,000	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,400	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,800	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

Description:																	
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0

Description:																	
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0

Description:																	
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0

Description:																	
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
2,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
3,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
4,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
5,600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
6,800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0

Description:

Notes:

y/x	65	70	75	80	85	90	95	100	105
1	7	7	7	5	3	3	3	3	3

Description:

Notes:

y/x	65	70	75	80	85	90	95	100	105
1	3.2	3.2	3.2	3.2	3.2	3.2	3.2	3.2	3.2

Description:

Notes:

y/x	65	70	75	80	85	90	95	100	105
1	0.7	0.7	0.8	0.8	0.8	0.9	0.9	1.0	1.0

Description:

Notes:

y/x	65	70	75	80	85	90	95	100	105
1	20	20	20	15	10	10	10	10	10

Description:

Notes:

y/x	65	70	75	80	85	90	95	100	105
1	20	20	20	15	10	10	10	10	10

Description: This cal value is a 1x5 array of minimum engine run time values based on powerup coolant temperatures. When the appropriate required minimum engine run time value is chosen based on the coolant temperature at powerup, this value is the minimum time from engine start before stabilized conditions are met. Used in determining if a ValidIdleIsMet condition exists.

Notes: Axis is the coolant and the output is the min engine run time

y/x	40	50	60	70	80
1	400	400	400	400	400

Description: This is a 1x3 table with the axis being engine coolant temperature. The implementation of this cal value as a table also included some changes to the way that the WarmedUpEvents counter increments and resets. To summarize, whenever WarmedUpEvents resets to 0 (this could be either at startup, if the closed throttle time exceeds a cal value, or if the predicted exhaust temperature falls below the ExhWarmMin cal value), the appropriate MinAirflowToWrmupCat value is chosen from the table based on engine coolant at the time the WarmedUpEvents counter reset to 0. This cal value is used along with the min exhaust temp to increment the WarmedUpEvents counter.

Notes: Axis is the engine coolant and the output is the minimum airflow required to warmup the catalyst.

y/x	0	45	90
1	12	8	4

Description: Abnormal Noise Threshold

Notes: Used for P0324, P0326 and P0331; X-axis = Engine Air Flow (mg per cylinder) see "APC Breakpoints" (KnKNKD_m_APC_Axis) table; Y-axis = Engine Speed (RPM)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.177	0.174	0.228	0.235	0.232	0.245	0.306	0.311	0.346	0.326	0.315	0.430	0.391	0.391	0.391	0.391	0.391

Description: KtKNKD_k_OpenMin20K: When using the 20 kHz method (KtKNKD_e_OpenMethod = 1), to set an Open Circuit DTC (P0325 or P0330) the filtered diagnostic FFT Output must be greater than KtKNKD_k_OpenMin20K and less than KtKNKD_k_OpenMax20K.

Notes: X-axis = Engine Speed (RPM)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	6.3203	6.3750	6.1816	5.9570	5.8047	5.7461	5.7520	5.7695	5.7500	5.6797	5.6094	5.6895	6.4492	6.4492	6.4492	6.4492	6.4492

Description: KtKNKD_k_OpenMax20K: When using the 20 kHz method (KtKNKD_e_OpenMethod = 1), to set an Open Circuit DTC (P0325 or P0330) the filtered diagnostic FFT Output must be greater than KtKNKD_k_OpenMin20K and less than KtKNKD_k_OpenMax20K.

Notes: X-axis = Engine Speed (RPM)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	25.6992	25.3535	24.7832	24.2305	23.8301	23.6172	23.5605	23.5703	23.5176	23.2578	22.6465	21.5625	19.9199	19.9199	19.9199	19.9199	19.9199

Description: KtKNKD_k_OpenMinNN: When using the Normal Noise method (KtKNKD_e_OpenMethod = 2), to set an Open Circuit DTC (P0325 or P0330) the filtered diagnostic FFT Output must be greater than KtKNKD_k_OpenMinNN and less than KtKNKD_k_OpenMaxNN.

Notes: X-axis = Engine Speed (RPM)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	1.3281	1.0977	1.1855	1.1855	1.1855	1.1855

Description: KtKNKD_k_OpenMaxNN: When using the Normal Noise method (KtKNKD_e_OpenMethod = 2), to set an Open Circuit DTC the filtered diagnostic FFT Output must be greater than KtKNKD_k_OpenMinNN and less than KtKNKD_k_OpenMaxNN.

Notes: X-axis = Engine Speed (RPM)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	1.6895	1.8184	2.1934	2.1934	2.1934	2.1934

Description: KtKNKD_k_OpenTestCktMin: When using the 20 kHz method (KtKNKD_e_OpenMethod = 1), to set an OpenTestCkt DTC (P06B6 or P06B7) the filtered diagnostic FFT Output must be greater than KtKNKD_k_OpenTestCktMin and less than KtKNKD_k_OpenTestCktMax.

Notes: X-axis = Engine Speed (RPM)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.061	0.070	0.131	0.221	0.250	0.449	0.689	0.570	0.529	0.740	1.320	1.840	1.520	1.520	1.520	1.520	1.520

Description: KtKNKD_k_OpenTestCktMax: When using the 20 kHz method (KtKNKD_e_OpenMethod = 1), to set an OpenTestCkt DTC (P06B6 or P06B7) the filtered diagnostic FFT Output must be greater than KtKNKD_k_OpenTestCktMin and less than KtKNKD_k_OpenTestCktMax.

Notes: X-axis = Engine Speed (RPM)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.131	0.170	0.301	0.449	0.619	1.000	1.221	1.760	1.770	2.340	3.410	4.240	4.090	4.090	4.090	4.090	4.090

Description:

Notes:

y/x	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	6,000
1	1.750	1.500	1.375	1.125	1.000	0.875	0.750	0.625	0.500	0.500

Description: KtMTCl_M_TorqueEnable: The diagnostic is inhibited if torque (NM) is less than this value. Prevents false fails in regions where false in-gear N/TOS ratios are possible due to low torque, where high torque would otherwise cause slip and prevent a valid in-gear state.

Notes: Axis is Percent Clutch Pedal Position (%), 0% = bottom of pedal travel.

y/x	0.00	6.25	12.50	18.75	25.00	31.25	37.50	43.75	50.00	56.25	62.50	68.75	75.00	81.25	87.50	93.75	100.00
1	10.0	10.0	10.0	10.0	10.0	25.0	50.0	75.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

Description: KaMTCI_Pct_ResidErrCalcEnbLow[x]: Represents the lower threshold of a deadband where the diagnostic will be inhibited to prevent false fails due to clutch slip that can falsely indicate a valid in-gear N/TOS ratio.

Notes: Axis identifies Gear, where "0" - "5" is gear 1 - 6, respectively; "6" is reverse and "7" is neutral

y/x	0	1	2	3	4	5	6	7
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Description: KaMTCI_Pct_ResidErrCalcEnbHigh[x]: Represents the upper threshold of a deadband where the diagnostic will be inhibited to prevent false fails due to clutch slip that can falsely indicate a valid in-gear N/TOS ratio.

Notes: Axis identifies Gear, where "0" - "5" is gear 1 - 6, respectively; "6" is reverse and "7" is neutral

y/x	0	1	2	3	4	5	6	7
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Description: Long Term Fuel Trim Cell I.D.s used for diagnosis. Cells identified as "CeFADD_e_NonSelectedCell" are not used for diagnosis.				
Notes: Axis is Long Term Fuel Trim Cell I.D.				
P0171/172/174/175 Long-Term Fuel Trim Cell Usage - Part 1				
y/x	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR_e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell
P0171/172/174/175 Long-Term Fuel Trim Cell Usage - Part 2				
y/x	CeFADR_e_Cell04_PurgOnAirMode 1	CeFADR_e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_NonSelectedCell
P0171/172/174/175 Long-Term Fuel Trim Cell Usage - Part 3				
y/x	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR_e_Cell10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell
P0171/172/174/175 Long-Term Fuel Trim Cell Usage - Part 4				
y/x	CeFADR_e_Cell12_PurgOffAirMode 1	CeFADR_e_Cell13_PurgOffAirMode 0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_NonSelectedCell

Description: Supercharger Intake Flow Rationality Diagnostic Failure Matrix

Notes: This table describes combinations of individual model failures that will set P0101, P0106, P012B, P0121 and P1101 on supercharged applications.

y/x	1	2	3	4	5	6	7
1	TPS Model Failure	MAF Model Failure	MAP1 Model Failure	MAP2 Model Failure	SCIAP1 Model Failure	SCIAP2 Model Failure	DTC Set
2	F	F	F	F	F	F	No DTC
3	F	F	F	F	F	T	No DTC
4	F	F	F	F	T	F	No DTC
5	F	F	F	F	T	T	P012B
6	F	F	F	T	F	F	No DTC
7	F	F	F	T	F	T	P1101
8	F	F	F	T	T	F	P1101
9	F	F	F	T	T	T	P1101
10	F	F	T	F	F	F	No DTC
11	F	F	T	F	F	T	P1101
12	F	F	T	F	T	F	P1101
13	F	F	T	F	T	T	P1101
14	F	F	T	T	F	F	P0106
15	F	F	T	T	F	T	P1101
16	F	F	T	T	T	F	P1101
17	F	F	T	T	T	T	P1101
18	F	T	F	F	F	F	No DTC
19	F	T	F	F	F	T	P0101
20	F	T	F	F	T	F	No DTC
21	F	T	F	F	T	T	P0101 & P012B
22	F	T	F	T	F	F	P1101
23	F	T	F	T	F	T	P0101
24	F	T	F	T	T	F	P1101
25	F	T	F	T	T	T	P0101 & P012B
26	F	T	T	F	F	F	P1101
27	F	T	T	F	F	T	P1101
28	F	T	T	F	T	F	P1101
29	F	T	T	F	T	T	P1101
30	F	T	T	T	F	F	P1101
31	F	T	T	T	F	T	P1101
32	F	T	T	T	T	F	P1101
33	F	T	T	T	T	T	P1101
34	T	F	F	F	F	F	P0121

35	T	F	F	F	F	T	No DTC
36	T	F	F	F	T	F	P0121
37	T	F	F	F	T	T	P1101
38	T	F	F	T	F	F	P1101
39	T	F	F	T	F	T	P1101
40	T	F	F	T	T	F	P1101
41	T	F	F	T	T	T	P1101
42	T	F	T	F	F	F	P0121
43	T	F	T	F	F	T	P1101
44	T	F	T	F	T	F	P0121
45	T	F	T	F	T	T	P1101
46	T	F	T	T	F	F	P1101
47	T	F	T	T	F	T	P1101
48	T	F	T	T	T	F	P1101
49	T	F	T	T	T	T	P1101
50	T	T	F	F	F	F	P0121
51	T	T	F	F	F	T	P1101
52	T	T	F	F	T	F	P0121
53	T	T	F	F	T	T	P1101
54	T	T	F	T	F	F	P1101
55	T	T	F	T	F	T	P1101
56	T	T	F	T	T	F	P1101
57	T	T	F	T	T	T	P1101
58	T	T	T	F	F	F	P0121
59	T	T	T	F	F	T	P1101
60	T	T	T	F	T	F	P0121
61	T	T	T	F	T	T	P1101
62	T	T	T	T	F	F	P1101
63	T	T	T	T	F	T	P1101
64	T	T	T	T	T	F	P1101
65	T	T	T	T	T	T	P1101

Description: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

Notes: This table describes combinations of individual model failures that will set P0101, P0106, P0121, P0236 and P1101 on turbocharged applications.

y/x	1	2	3	4	5	6	7	8	9
1	MAF Model	MAP1 Model	MAP2 Model	MAP3 Model	TIAP1 Model	TPS Model	TIAP Correlation	TIAP Correlation	DTC Set
2	Failed	Failed	Failed	Failed	Failed	Failed	Failed	Valid	
3	F	F	F	F	F	F	F	F	No DTC
4	F	F	F	F	F	F	F	T	No DTC
5	F	F	F	F	F	F	T	F	No DTC
6	F	F	F	F	F	F	T	T	No DTC
7	F	F	F	F	F	T	F	F	No DTC
8	F	F	F	F	F	T	F	T	No DTC
9	F	F	F	F	F	T	T	F	No DTC
10	F	F	F	F	F	T	T	T	No DTC
11	F	F	F	F	T	F	F	F	No DTC
12	F	F	F	F	T	F	F	T	No DTC
13	F	F	F	F	T	F	T	F	No DTC
14	F	F	F	F	T	F	T	T	No DTC
15	F	F	F	F	T	T	F	F	P1101
16	F	F	F	F	T	T	F	T	P0121
17	F	F	F	F	T	T	T	F	P1101
18	F	F	F	F	T	T	T	T	P0236
19	F	F	F	T	F	F	F	F	P1101
20	F	F	F	T	F	F	F	T	P1101
21	F	F	F	T	F	F	T	F	P1101
22	F	F	F	T	F	F	T	T	P1101
23	F	F	F	T	F	T	F	F	P1101
24	F	F	F	T	F	T	F	T	P1101
25	F	F	F	T	F	T	T	F	P1101
26	F	F	F	T	F	T	T	T	P1101
27	F	F	F	T	T	F	F	F	P1101
28	F	F	F	T	T	F	F	T	P1101
29	F	F	F	T	T	F	T	F	P1101
30	F	F	F	T	T	F	T	T	P1101
31	F	F	F	T	T	T	F	F	P1101
32	F	F	F	T	T	T	F	T	P1101
33	F	F	F	T	T	T	T	F	P1101
34	F	F	F	T	T	T	T	T	P1101

12 OBDG05B Engine Diagnostics

MAIN SECTION
1 OF 2 SECTIONS

35	F	F	T	F	F	F	F	F	P1101
36	F	F	T	F	F	F	F	T	P1101
37	F	F	T	F	F	F	T	F	P1101
38	F	F	T	F	F	F	T	T	P1101
39	F	F	T	F	F	T	F	F	P1101
40	F	F	T	F	F	T	F	T	P1101
41	F	F	T	F	F	T	T	F	P1101
42	F	F	T	F	F	T	T	T	P1101
43	F	F	T	F	T	F	F	F	P1101
44	F	F	T	F	T	F	F	T	P1101
45	F	F	T	F	T	F	T	F	P1101
46	F	F	T	F	T	F	T	T	P1101
47	F	F	T	F	T	T	F	F	P1101
48	F	F	T	F	T	T	F	T	P1101
49	F	F	T	F	T	T	T	F	P1101
50	F	F	T	F	T	T	T	T	P1101
51	F	F	T	T	F	F	F	F	P1101
52	F	F	T	T	F	F	F	T	P1101
53	F	F	T	T	F	F	T	F	P1101
54	F	F	T	T	F	F	T	T	P1101
55	F	F	T	T	F	T	F	F	P1101
56	F	F	T	T	F	T	F	T	P1101
57	F	F	T	T	F	T	T	F	P1101
58	F	F	T	T	F	T	T	T	P1101
59	F	F	T	T	T	F	F	F	No DTC
60	F	F	T	T	T	F	F	T	No DTC
61	F	F	T	T	T	F	T	F	No DTC
62	F	F	T	T	T	F	T	T	No DTC
63	F	F	T	T	T	T	F	F	P1101
64	F	F	T	T	T	T	F	T	P1101
65	F	F	T	T	T	T	T	F	P1101
66	F	F	T	T	T	T	T	T	P1101
67	F	T	F	F	F	F	F	F	P1101
68	F	T	F	F	F	F	F	T	P1101
69	F	T	F	F	F	F	T	F	P1101
70	F	T	F	F	F	F	T	T	P0236
71	F	T	F	F	F	T	F	F	P1101
72	F	T	F	F	F	T	F	T	P0121

12 OBDG05B Engine Diagnostics

MAIN SECTION
1 OF 2 SECTIONS

73	F	T	F	F	F	T	T	F	P1101
74	F	T	F	F	F	T	T	T	P0236
75	F	T	F	F	T	F	F	F	P1101
76	F	T	F	F	T	F	F	T	P1101
77	F	T	F	F	T	F	T	F	P1101
78	F	T	F	F	T	F	T	T	P0236
79	F	T	F	F	T	T	F	F	P1101
80	F	T	F	F	T	T	F	T	P0121
81	F	T	F	F	T	T	T	F	P1101
82	F	T	F	F	T	T	T	T	P0236
83	F	T	F	T	F	F	F	F	P1101
84	F	T	F	T	F	F	F	T	P1101
85	F	T	F	T	F	F	T	F	P1101
86	F	T	F	T	F	F	T	T	P1101
87	F	T	F	T	F	T	F	F	P1101
88	F	T	F	T	F	T	F	T	P1101
89	F	T	F	T	F	T	T	F	P1101
90	F	T	F	T	F	T	T	T	P1101
91	F	T	F	T	T	F	F	F	P1101
92	F	T	F	T	T	F	F	T	P1101
93	F	T	F	T	T	F	T	F	P1101
94	F	T	F	T	T	F	T	T	P1101
95	F	T	F	T	T	T	F	F	P1101
96	F	T	F	T	T	T	F	T	P1101
97	F	T	F	T	T	T	T	F	P1101
98	F	T	F	T	T	T	T	T	P1101
99	F	T	T	F	F	F	F	F	P1101
100	F	T	T	F	F	F	F	T	P1101
101	F	T	T	F	F	F	T	F	P1101
102	F	T	T	F	F	F	T	T	P1101
103	F	T	T	F	F	T	F	F	P1101
104	F	T	T	F	F	T	F	T	P1101
105	F	T	T	F	F	T	T	F	P1101
106	F	T	T	F	F	T	T	T	P1101
107	F	T	T	F	T	F	F	F	P1101
108	F	T	T	F	T	F	F	T	P1101
109	F	T	T	F	T	F	T	F	P1101
110	F	T	T	F	T	F	T	T	P1101

12 OBDG05B Engine Diagnostics

MAIN SECTION
1 OF 2 SECTIONS

111	F	T	T	F	T	T	F	F	P1101
112	F	T	T	F	T	T	F	T	P1101
113	F	T	T	F	T	T	T	F	P1101
114	F	T	T	F	T	T	T	T	P1101
115	F	T	T	T	F	F	F	F	P0106
116	F	T	T	T	F	F	F	T	P0106
117	F	T	T	T	F	F	T	F	P0106
118	F	T	T	T	F	F	T	T	P0106
119	F	T	T	T	F	T	F	F	P1101
120	F	T	T	T	F	T	F	T	P1101
121	F	T	T	T	F	T	T	F	P1101
122	F	T	T	T	F	T	T	T	P1101
123	F	T	T	T	T	F	F	F	P1101
124	F	T	T	T	T	F	F	T	P1101
125	F	T	T	T	T	F	T	F	P1101
126	F	T	T	T	T	F	T	T	P1101
127	F	T	T	T	T	T	F	F	P1101
128	F	T	T	T	T	T	F	T	P1101
129	F	T	T	T	T	T	T	F	P1101
130	F	T	T	T	T	T	T	T	P1101
131	T	F	F	F	F	F	F	F	P1101
132	T	F	F	F	F	F	F	T	P1101
133	T	F	F	F	F	F	T	F	P1101
134	T	F	F	F	F	F	T	T	P0236
135	T	F	F	F	F	T	F	F	P1101
136	T	F	F	F	F	T	F	T	P0121
137	T	F	F	F	F	T	T	F	P1101
138	T	F	F	F	F	T	T	T	P0236
139	T	F	F	F	T	F	F	F	P1101
140	T	F	F	F	T	F	F	T	P1101
141	T	F	F	F	T	F	T	F	P1101
142	T	F	F	F	T	F	T	T	P0236
143	T	F	F	F	T	T	F	F	P1101
144	T	F	F	F	T	T	F	T	P0121
145	T	F	F	F	T	T	T	F	P1101
146	T	F	F	F	T	T	T	T	P0236
147	T	F	F	T	F	F	F	F	P1101
148	T	F	F	T	F	F	F	T	P1101

149	T	F	F	T	F	F	T	F	P1101
150	T	F	F	T	F	F	T	T	P1101
151	T	F	F	T	F	T	F	F	P1101
152	T	F	F	T	F	T	F	T	P1101
153	T	F	F	T	F	T	T	F	P1101
154	T	F	F	T	F	T	T	T	P1101
155	T	F	F	T	T	F	F	F	P1101
156	T	F	F	T	T	F	F	T	P1101
157	T	F	F	T	T	F	T	F	P1101
158	T	F	F	T	T	F	T	T	P1101
159	T	F	F	T	T	T	F	F	P1101
160	T	F	F	T	T	T	F	T	P1101
161	T	F	F	T	T	T	T	F	P1101
162	T	F	F	T	T	T	T	T	P1101
163	T	F	T	F	F	F	F	F	P1101
164	T	F	T	F	F	F	F	T	P1101
165	T	F	T	F	F	F	T	F	P1101
166	T	F	T	F	F	F	T	T	P1101
167	T	F	T	F	F	T	F	F	P1101
168	T	F	T	F	F	T	F	T	P1101
169	T	F	T	F	F	T	T	F	P1101
170	T	F	T	F	F	T	T	T	P1101
171	T	F	T	F	T	F	F	F	P1101
172	T	F	T	F	T	F	F	T	P1101
173	T	F	T	F	T	F	T	F	P1101
174	T	F	T	F	T	F	T	T	P1101
175	T	F	T	F	T	T	F	F	P1101
176	T	F	T	F	T	T	F	T	P1101
177	T	F	T	F	T	T	T	F	P1101
178	T	F	T	F	T	T	T	T	P1101
179	T	F	T	T	F	F	F	F	P1101
180	T	F	T	T	F	F	F	T	P1101
181	T	F	T	T	F	F	T	F	P1101
182	T	F	T	T	F	F	T	T	P1101
183	T	F	T	T	F	T	F	F	P1101
184	T	F	T	T	F	T	F	T	P1101
185	T	F	T	T	F	T	T	F	P1101
186	T	F	T	T	F	T	T	T	P1101

12 OBDG05B Engine Diagnostics

MAIN SECTION
1 OF 2 SECTIONS

187	T	F	T	T	T	F	F	F	P1101
188	T	F	T	T	T	F	F	T	P1101
189	T	F	T	T	T	F	T	F	P1101
190	T	F	T	T	T	F	T	T	P1101
191	T	F	T	T	T	T	F	F	P1101
192	T	F	T	T	T	T	F	T	P1101
193	T	F	T	T	T	T	T	F	P1101
194	T	F	T	T	T	T	T	T	P1101
195	T	T	F	F	F	F	F	F	P1101
196	T	T	F	F	F	F	F	T	P1101
197	T	T	F	F	F	F	T	F	P1101
198	T	T	F	F	F	F	T	T	P0236
199	T	T	F	F	F	T	F	F	P1101
200	T	T	F	F	F	T	F	T	P0121
201	T	T	F	F	F	T	T	F	P1101
202	T	T	F	F	F	T	T	T	P0236
203	T	T	F	F	T	F	F	F	P1101
204	T	T	F	F	T	F	F	T	P1101
205	T	T	F	F	T	F	T	F	P1101
206	T	T	F	F	T	F	T	T	P0236
207	T	T	F	F	T	T	F	F	P1101
208	T	T	F	F	T	T	F	T	P0121
209	T	T	F	F	T	T	T	F	P1101
210	T	T	F	F	T	T	T	T	P0236
211	T	T	F	T	F	F	F	F	P1101
212	T	T	F	T	F	F	F	T	P1101
213	T	T	F	T	F	F	T	F	P1101
214	T	T	F	T	F	F	T	T	P1101
215	T	T	F	T	F	T	F	F	P1101
216	T	T	F	T	F	T	F	T	P1101
217	T	T	F	T	F	T	T	F	P1101
218	T	T	F	T	F	T	T	T	P1101
219	T	T	F	T	T	F	F	F	P1101
220	T	T	F	T	T	F	F	T	P1101
221	T	T	F	T	T	F	T	F	P1101
222	T	T	F	T	T	F	T	T	P1101
223	T	T	F	T	T	T	F	F	P1101
224	T	T	F	T	T	T	F	T	P1101

12 OBDG05B Engine Diagnostics

MAIN SECTION
1 OF 2 SECTIONS

225	T	T	F	T	T	T	T	F	P1101
226	T	T	F	T	T	T	T	T	P1101
227	T	T	T	F	F	F	F	F	P1101
228	T	T	T	F	F	F	F	T	P1101
229	T	T	T	F	F	F	T	F	P1101
230	T	T	T	F	F	F	T	T	P1101
231	T	T	T	F	F	T	F	F	P1101
232	T	T	T	F	F	T	F	T	P1101
233	T	T	T	F	F	T	T	F	P1101
234	T	T	T	F	F	T	T	T	P1101
235	T	T	T	F	T	F	F	F	P1101
236	T	T	T	F	T	F	F	T	P1101
237	T	T	T	F	T	F	T	F	P1101
238	T	T	T	F	T	F	T	T	P1101
239	T	T	T	F	T	T	F	F	P1101
240	T	T	T	F	T	T	F	T	P1101
241	T	T	T	F	T	T	T	F	P1101
242	T	T	T	F	T	T	T	T	P1101
243	T	T	T	T	F	F	F	F	P1101
244	T	T	T	T	F	F	F	T	P1101
245	T	T	T	T	F	F	T	F	P1101
246	T	T	T	T	F	F	T	T	P1101
247	T	T	T	T	F	T	F	F	P1101
248	T	T	T	T	F	T	F	T	P1101
249	T	T	T	T	F	T	T	F	P1101
250	T	T	T	T	F	T	T	T	P1101
251	T	T	T	T	T	F	F	F	P1101
252	T	T	T	T	T	F	F	T	P1101
253	T	T	T	T	T	F	T	F	P1101
254	T	T	T	T	T	F	T	T	P1101
255	T	T	T	T	T	T	F	F	P1101
256	T	T	T	T	T	T	F	T	P1101
257	T	T	T	T	T	T	T	F	P1101
258	T	T	T	T	T	T	T	T	P1101

Description: P0101_P0106_P0121_P012B_P0236_P1101 TPS Residual Weight Factor based on RPM

Notes:

y/x	500	1,000	1,250	1,500	1,750	2,000	2,250	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAF Residual Weight Factor based on RPM

Notes:

y/x	500	1,000	1,250	1,500	1,750	2,000	2,250	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.771	0.573	0.536	0.500

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAF Residual Weight Factor based on MAF Est

Notes:

y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP1 Residual Weight Factor based on RPM

Notes:

y/x	500	1,000	1,250	1,500	1,750	2,000	2,250	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP2 Residual Weight Factor based on RPM

Notes:

y/x	500	1,000	1,250	1,500	1,750	2,000	2,250	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
1	1.000	1.000	0.946	0.896	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.673

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP3 Residual Weight Factor based on RPM

Notes:

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,500
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Description: P0101_P0106_P0121_P0236_P1101 TIAP Residual Weight Factor based on RPM

Notes:

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,500
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Offset

Notes:

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	1.0	1.0	1.0	1.0	2.0	2.0	2.0	3.0	3.0

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Offset

Notes:

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min Air Flow

Notes:

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	15.0	27.0	32.0	32.0	32.0	32.0	32.0	32.0	32.0

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Max Air Flow

Notes:

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	2.6	3.3	4.5	5.4	7.0	8.8	11.0	12.4	12.4

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min MAP

Notes:

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	124.0	126.0	127.0	128.0	129.0	128.0	127.0	127.0	127.0

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Max MAP

Notes:

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	34.1	27.3	26.1	25.4	25.7	24.1	29.5	29.4	29.4

Description: P0101_P0106_P0121_P012B_P1101 Boost Residual Weight Factor based on % of Boost

Notes:

y/x	0	0	0	0	0	0	0	0	0	1	1	1	1	1	1	1	1
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Description: P0101_P0106_P0121_P012B_P1101 SCIAP1 Residual Weight Factor based on RPM

Notes:

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,500
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Description: P0101_P0106_P0121_P012B_P1101 SCIAP2 Residual Weight Factor based on RPM

Notes:

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,500
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Description: OAT Performance Diagnostic counter increment for determining OAT-IAT equilibrium for engine running

Notes:

y/x	0.0	5.0	10.0	15.0	20.0	25.0	30.0	50.0	80.0
1.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0	8.0	9.0
5.0	-5.0	-2.0	-1.0	0.0	1.0	2.0	3.0	4.0	5.0
10.0	-4.0	-1.0	0.0	0.0	1.0	2.0	3.0	4.0	5.0
20.0	-2.0	-1.0	0.0	0.0	1.0	2.0	3.0	4.0	5.0
30.0	-1.0	0.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0
40.0	0.0	0.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0
50.0	0.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0
60.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0	8.0
70.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0	8.0	9.0

Description: OAT Performance Diagnostic counter increment for determining OAT-IAT equilibrium for engine off (for hybrid applications)

Notes:

y/x	0.0	5.0	10.0	15.0	20.0	25.0	30.0	50.0	80.0
1.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0	8.0

Description: Engine run time following an autostart, as a function of begin run coolant, which must be exceeded to enable CLOSED LOOP.

Notes: Time in seconds: Hybrid use Only

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	320.0	225.0	190.0	130.0	70.0	19.0	19.0	19.0	19.0	11.0	11.0	11.0	11.0	11.0	11.0	11.0	11.0

Description: Engine run time, as a function of startup coolant temperature, which must be exceeded to enable CLOSED LOOP.

Notes: Time in seconds

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	320.0	225.0	190.0	130.0	70.0	19.0	19.0	19.0	19.0	11.0	11.0	11.0	11.0	11.0	11.0	11.0	11.0

Description: KtFCLL_p_AdaptiveLowMAP_Limit

Notes: MAP in KPa

y/x	65	70	75	80	85	90	95	100	105
1	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

Description: Disable integral offset after engine start for this amount of time.

Notes: Time in seconds

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	100.0	100.0	100.0	100.0	75.0	50.0	50.0	50.0	50.0	50.0	50.0	50.0	50.0	50.0	50.0	50.0	50.0

Description: Time required to ramp integral offset to desired value.

Notes: Time in seconds

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	50.0	50.0	50.0	45.0	40.0	40.0	40.0	40.0	30.0	25.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

Description: Lower limit checked against when determining if an oxygen sensor is in range

Notes: Voltage in millivolts

y/x	1
1	1,100

Description: Number of times an oxygen sensor value must be in range before declaring it ready

Notes: Time (events * 12.5 milliseconds)

y/x	1
1	10

Description: LTM learning is inhibited if the engine coolant temperature is below this calibration.

Notes: Degrees Celcius

y/x	1
1	55

Description: LTM learning is inhibited if the engine coolant temperature is above this calibration.

Notes: Degrees Celcius

y/x	1
1	120

Description: Lower threshold defining not ready window for post oxygen sensor voltage.	
Notes: Voltage in millivolts	
y/x	1
1	1,100

Description: Number of post catalyst oxygen sensor samples which must be outside not ready window before post oxygen sensor is READY.	
Notes: Time (events * 12.5 milliseconds)	
y/x	1
1	10

Description: Maximum allowed estimated catalytic converter temperature for post O2 integral terms to be updated.

Notes: Modeled catalyst Temperature in Celcius

y/x	1
1	1,000

Description: Minimum allowed estimated catalytic converter temperature to begin using post O2 integration correction terms. Converter temperature must remain above this threshold to ramp-in the post O2 integration adjustments. Once the ramp-in has started, a converter temperature below this threshold will freeze the ramp-in multiplier. Post O2 integration will not be allowed below this converter temperature

Notes: Modeled catalyst Temperature in Celcius

y/x	1
1	450

Description: P0128: Maximum Total Energy transferred to Cooling System for Ambient and Start-up ECT conditions (Primary Test)

Notes: Z axis is the cooling system energy failure threshold (kJ), X axis is ECT Temperature at Power up (° C)

y/x	-20	-5	10	30	45	60	75
1	2,100	1,800	1,500	1,200	900	600	300

Description: P0128: Maximum Total Energy transferred to Cooling System for Ambient and Start-up ECT conditions (Primary Test)

Notes: Z axis is the cooling system energy failure threshold (kJ), X axis is ECT Temperature at Power up (° C)

y/x	-20	-5	10	30	45	60	75
1	2,100	1,800	1,500	1,200	900	600	300

Description: KtEPSI_t_RtnHomeDlyLmt

Notes:

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	300.0	300.0	7.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0

Description: Data is EAT Valid Conditioning Time (in seconds) and Axis is Ignition Off Time (in seconds)

Notes: KtEONV_t_IdleCondTimePreset

P0442: Estimate of Ambient Temperature Valid Conditioning Time as a Function of Ignition Off Time - Part 1

y/x	0	600	1,200	1,800	2,400	3,000	3,600	4,200	4,800	5,400	6,000	6,600	7,200	7,800	8,400	9,000	9,600
1	100	100	250	350	450	500	500	500	500	400	350	300	250	200	150	100	100

P0442: Estimate of Ambient Temperature Valid Conditioning Time as a Function of Ignition Off Time - Part 2

y/x	10,200	10,800	11,700	12,600	13,500	14,400	15,300	16,200	17,100	18,000	19,200	20,400	21,600	22,800	24,000	25,200	
1	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	

Description: Data is Engine Off Time Before Vehicle Off Maximum Table (in seconds) and Axis is Estimated Ambient Coolant in Deg C

Notes: KtEONV_t_EngOffTimeBefVehOffMax

y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	20	20	20	60	120	160	200	250	250	400	400	400	400	400	400	400	400

Description: Data is Purge Valve Leak Test Engine Vacuum Test Time (in seconds) and Axis is Fuel Level in %

Notes: KtEVPD_t_PVLT_EngineVacTimeCold

y/x	0	6	12	19	25	31	37	44	50	56	62	69	75	81	87	94	100
1	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60

Description: Data is TransferPumpOnTimeLimit (in seconds) and Axis is Fuel Level in %

Notes: KtFLVC_t_XferFuelPmpOnTmLim

y/x	0	3	6	9	13	16	19	22	25	28	31	34	38	41	44	47	50	53	56	59	63	66	69	72	75	78	81	84	88	91	94	97	100	
1	30	35	40	45	50	55	60	65	70	85	90	95	135	135	160	160	260	260	360	360	360	360	360	360	460	460	460	460	460	460	460	460	460	460

Description: Data is EONV Pressure Threshold in Pascals, X axis (horizontal) is fuel level in % and Y axis (vertical) is temperature in deg C

Notes: KtEONV_p_PressureThreshold

y/x	0.0000	6.2499	12.4998	18.7497	24.9996	31.2495	37.4994	43.7493	49.9992	56.2491	62.4990	68.7490	74.9989	81.2488	87.4987	93.7486	99.9985
-10.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
-4.3750	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
1.2500	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
6.8750	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
12.5000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
18.1250	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
23.7500	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
29.3750	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
35.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
40.6250	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
46.2500	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
51.8750	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
57.5000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
63.1250	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
68.7500	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
74.3750	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000
80.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-1.0000	-0.8330	-0.6660	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000	-0.5000

Description: This value is needed for LowFuelConditionDiagnostic flag which is located in Fault Bundle	
Notes: This value is needed for LowFuelConditionDiagnostic flag which is located in Fault Bundle	
y/x	1
1	10.0

Description: This value is needed for LowFuelConditionDiagnostic flag which is located in Fault Bundle	
Notes: This value is needed for LowFuelConditionDiagnostic flag which is located in Fault Bundle	
y/x	1
1	30.0

Description: This value is needed for Transfer Pump is Commanded On flag which is located in Fault Bundle

Notes: This value is needed for Transfer Pump is Commanded On flag which is located in Fault Bundle

y/x	1
1	0.0

Description: This value is needed for Transfer Pump is Commanded On flag which is located in Fault Bundle

Notes: This value is needed for Transfer Pump is Commanded On flag which is located in Fault Bundle

y/x	1
1	0.0

Description: This value is needed for Transfer Pump is Commanded On flag which is located in Fault Bundle

Notes: This value is needed for Transfer Pump is Commanded On flag which is located in Fault Bundle

y/x	1
1	0.0

12 OBDG05B Engine Diagnostics

MAIN SECTION
1 OF 2 SECTIONS

Description: Bank 1 lookup table of Variance metric used to calculate the Ratio for the current sample period

Notes: Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,200	3,400	3,600	3,800	4,000
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
80	9,999.00	14.25	14.25	11.50	8.50	12.50	12.50	15.50	10.75	10.50	13.50	7.50	9.25	7.50	6.50	6.75	5.25
120	9,999.00	14.25	14.25	11.50	8.50	12.50	12.50	15.50	10.75	10.50	13.50	7.50	9.25	7.50	6.50	6.75	5.25
160	9,999.00	24.00	24.00	14.00	12.00	15.75	15.50	14.00	19.50	19.00	12.75	6.50	10.50	7.00	6.50	7.00	8.50
200	9,999.00	64.00	64.00	28.75	17.00	35.50	20.75	27.25	15.75	15.25	9.50	6.75	10.00	10.25	7.00	6.00	8.00
240	9,999.00	53.25	53.25	26.50	16.50	50.00	21.50	23.75	21.75	21.75	14.25	9.00	17.25	8.25	9.00	9.25	12.00
280	9,999.00	73.00	73.00	35.50	31.00	50.75	21.00	42.25	29.50	30.00	19.75	6.50	13.00	9.50	7.50	9.00	14.75
320	9,999.00	42.00	42.00	31.50	39.75	46.25	26.75	39.75	29.75	31.50	19.50	8.50	17.25	12.00	11.25	13.75	24.25
360	9,999.00	47.25	47.25	39.50	31.25	43.50	29.00	41.50	21.50	32.50	39.50	13.75	17.50	14.50	13.50	19.75	25.25
400	9,999.00	64.00	64.00	52.00	50.50	54.00	35.75	40.50	24.75	36.25	23.00	15.50	20.50	14.75	14.25	16.75	23.75
440	9,999.00	63.25	63.25	37.25	46.25	40.75	45.75	79.00	42.25	39.00	32.25	21.50	18.50	17.75	20.50	22.25	30.50
480	9,999.00	57.50	57.50	38.00	39.00	42.00	58.00	78.75	62.25	58.25	39.75	18.75	16.50	20.75	18.50	23.75	25.00
520	9,999.00	54.00	54.00	35.00	26.00	38.00	38.75	43.25	47.25	62.00	79.00	15.00	19.50	21.00	17.50	20.25	33.75
560	9,999.00	54.75	54.75	34.75	37.50	38.50	41.00	45.25	56.50	62.00	70.50	15.00	19.50	21.00	17.50	20.25	33.75
600	9,999.00	54.75	54.75	34.75	37.50	38.50	42.00	45.25	56.50	62.00	62.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
640	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
680	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00

12 OBDG05B Engine Diagnostics

MAIN SECTION
1 OF 2 SECTIONS

Description: Bank 2 lookup table of Variance metric used to calculate the Ratio for the current sample period

Notes: Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,200	3,400	3,600	3,800	4,000
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
80	9,999.00	14.50	14.50	11.50	8.00	12.75	12.50	15.25	11.00	11.00	14.75	8.00	9.25	7.50	6.50	6.75	7.00
120	9,999.00	14.50	14.50	11.50	8.00	12.75	12.50	15.25	11.00	11.00	14.75	8.00	9.25	7.50	6.50	6.75	7.00
160	9,999.00	26.00	26.00	13.50	12.00	15.50	14.25	14.00	18.25	19.25	12.75	6.50	10.50	7.25	6.00	7.25	8.50
200	9,999.00	63.75	63.75	28.75	17.00	35.75	19.50	27.25	15.50	15.25	9.00	7.00	9.50	10.25	7.25	6.00	8.00
240	9,999.00	51.75	51.75	27.75	16.50	49.00	24.00	23.75	22.25	21.75	14.00	8.75	17.25	8.00	9.00	9.75	12.00
280	9,999.00	72.25	72.25	35.25	30.50	50.25	21.00	42.25	27.75	30.00	19.75	7.00	14.25	9.50	7.50	9.00	14.75
320	9,999.00	41.50	41.50	30.25	38.25	45.75	28.75	40.50	28.25	29.25	19.75	8.50	19.00	11.50	11.25	13.50	23.50
360	9,999.00	47.75	47.75	41.00	33.25	42.00	29.00	40.50	23.50	33.25	39.25	13.50	18.75	14.00	13.25	21.50	25.00
400	9,999.00	65.00	65.00	52.00	48.75	55.75	35.75	41.25	24.75	36.25	23.00	15.75	21.00	14.75	14.25	17.75	23.75
440	9,999.00	64.00	64.00	37.25	49.00	41.25	44.50	78.50	43.50	39.00	32.25	19.50	18.50	18.00	20.25	22.50	30.25
480	9,999.00	58.50	58.50	35.50	38.50	41.75	57.50	80.00	61.25	58.25	41.25	16.75	15.75	20.75	17.00	25.50	24.50
520	9,999.00	54.00	54.00	34.75	26.50	36.50	40.50	44.25	45.75	62.00	82.25	15.00	19.25	19.25	17.50	20.75	32.00
560	9,999.00	56.50	56.50	34.50	37.50	39.25	41.50	44.75	58.25	60.75	71.50	15.00	19.25	19.25	17.50	20.75	32.00
600	9,999.00	56.50	56.50	34.50	37.50	39.25	42.00	44.75	58.25	60.75	60.75	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
640	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
680	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00

Description: Bank 1 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

Notes: Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,200	3,400	3,600	3,800	4,000
40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
80	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
120	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
160	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
200	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
240	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
280	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
320	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
360	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
400	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
440	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
480	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
520	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
560	0.00	0.00	1.00	1.00	1.00	1.00	0.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
600	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
640	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
680	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

Description: Bank 2 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

Notes: Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,200	3,400	3,600	3,800	4,000
40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
80	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
120	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
160	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
200	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
240	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
280	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
320	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
360	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
400	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
440	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
480	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
520	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
560	0.00	0.00	1.00	1.00	1.00	1.00	0.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
600	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
640	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
680	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

Description: Bank 1 Normalizer table used in the calculation of the Ratio for the current sample period.

Notes: Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,200	3,400	3,600	3,800	4,000
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
80	9,999.00	152.75	152.75	189.25	188.75	143.00	129.50	138.25	157.50	148.75	97.50	90.50	66.75	80.50	59.75	60.00	59.75
120	9,999.00	152.75	152.75	189.25	188.75	143.00	129.50	138.25	157.50	148.75	97.50	90.50	66.75	80.50	59.75	60.00	59.75
160	9,999.00	168.00	168.00	164.25	160.25	150.25	165.75	191.50	165.50	132.25	138.75	130.25	110.50	104.00	91.00	81.50	76.50
200	9,999.00	223.25	223.25	263.75	253.75	212.75	214.75	196.75	197.50	176.50	155.50	152.25	135.75	126.50	112.25	117.25	101.75
240	9,999.00	238.75	238.75	255.75	256.50	220.25	237.50	228.25	232.00	209.00	224.75	209.25	189.75	176.75	170.00	180.75	171.75
280	9,999.00	250.25	250.25	252.50	251.50	223.50	264.50	234.25	265.75	265.00	259.75	263.00	236.50	212.00	200.50	205.00	198.25
320	9,999.00	277.25	277.25	270.00	262.50	266.25	289.25	281.75	283.00	279.75	281.50	283.00	255.75	227.25	224.75	203.00	205.75
360	9,999.00	270.50	270.50	268.25	277.75	279.50	291.50	275.00	292.00	281.00	269.00	286.25	274.50	267.25	251.75	232.00	216.75
400	9,999.00	274.75	274.75	267.50	280.50	267.75	278.50	269.75	273.50	269.75	280.50	282.25	271.50	274.50	263.50	257.00	238.75
440	9,999.00	283.50	283.50	304.50	291.25	291.75	277.75	238.50	255.00	264.50	268.25	274.25	268.00	266.75	252.75	243.50	230.75
480	9,999.00	278.75	278.75	305.00	304.00	297.00	275.25	243.25	252.75	246.75	260.50	267.50	258.25	259.00	250.00	240.25	231.00
520	9,999.00	270.75	270.75	292.25	301.50	291.25	296.50	286.00	267.50	250.00	222.25	272.75	260.50	259.25	264.25	243.25	225.50
560	9,999.00	274.00	274.00	280.75	277.75	262.50	270.25	252.00	249.50	245.50	234.00	272.75	260.50	259.25	264.25	243.25	225.50
600	9,999.00	274.00	274.00	280.75	277.75	262.50	257.25	252.00	249.50	245.50	245.50	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
640	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
680	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00

12 OBDG05B Engine Diagnostics

Description: Bank 2 Normalizer table used in the calculation of the Ratio for the current sample period.

Notes: Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,200	3,400	3,600	3,800	4,000
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
80	9,999.00	154.00	154.00	186.25	189.50	141.50	131.50	138.75	156.75	134.25	96.75	90.50	65.50	80.25	60.00	60.50	60.25
120	9,999.00	154.00	154.00	186.25	189.50	141.50	131.50	138.75	156.75	134.25	96.75	90.50	65.50	80.25	60.00	60.50	60.25
160	9,999.00	167.50	167.50	165.50	161.00	151.00	168.50	190.75	170.50	130.00	138.00	130.50	111.00	103.00	93.00	82.25	75.50
200	9,999.00	224.50	224.50	262.75	255.00	212.00	214.75	197.75	199.25	176.75	159.00	152.75	133.50	128.25	113.00	116.25	105.50
240	9,999.00	238.50	238.50	254.00	257.00	221.50	236.25	228.75	232.00	208.50	221.00	212.50	191.00	176.00	169.00	179.75	174.50
280	9,999.00	250.50	250.50	253.50	251.00	223.75	263.75	236.25	268.75	265.00	260.00	262.50	235.50	212.50	200.75	205.25	196.50
320	9,999.00	278.00	278.00	270.50	263.50	266.75	288.50	280.75	284.50	282.50	281.00	282.50	254.25	226.00	223.25	204.00	206.50
360	9,999.00	269.00	269.00	266.00	274.50	281.75	291.50	276.25	289.50	280.50	269.00	286.50	272.50	267.50	252.75	231.00	216.50
400	9,999.00	273.75	273.75	267.00	282.25	266.00	278.25	269.00	273.25	270.00	280.75	282.50	270.75	274.75	263.50	256.00	238.25
440	9,999.00	282.25	282.25	304.50	288.00	291.00	279.00	238.75	253.50	264.50	268.75	276.00	268.25	266.25	253.75	243.50	231.75
480	9,999.00	277.25	277.25	307.50	303.00	297.00	275.75	241.75	253.75	247.25	258.75	269.50	259.25	259.75	250.75	238.50	231.00
520	9,999.00	270.75	270.75	292.50	301.25	292.50	295.00	285.00	268.50	249.75	218.75	273.00	261.00	260.75	264.25	241.25	227.25
560	9,999.00	272.25	272.25	281.25	277.75	262.25	270.00	252.50	247.50	246.50	232.50	273.00	261.00	260.75	264.25	241.25	227.25
600	9,999.00	272.25	272.25	281.25	277.75	262.25	257.25	252.50	247.50	246.50	246.50	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
640	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
680	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00

Description: Crankshaft decel threshold while in SCD mode. Thresholds are a function of rpm and % engine Load.

Notes: KtMISF_dt_SCD_IdleMode

Note: Misfire's Load term is %, but not PID\$04. PID \$04 is not robust to temperature and altitude shifts. (especially decel and jerk thresholds since they track actual air trapped in cylinder)

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
9	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
11	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
13	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
15	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
17	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
19	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
29	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
33	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
38	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
42	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
48	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
54	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
80	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

Description: Crankshaft jerk threshold while in SCD mode. Thresholds are a function of rpm and % engine Load.

Notes: KtMISF_ddt_SCD_IdleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
9	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
11	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
13	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
15	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
17	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
19	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
29	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
33	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
38	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
42	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
48	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
54	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
80	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

Description: Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: KtMISF_dt_SCD_OffIdleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
9	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
11	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
13	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
15	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
17	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
19	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
29	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
33	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
38	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
42	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
48	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
54	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
80	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

Description: Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

Notes: KtMISF_ddt_SCD_OffIdleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
9	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
11	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
13	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
15	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
17	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
19	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
29	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
33	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
38	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
42	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
48	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
54	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
80	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

Description: Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: KtMSFD_dt_IdleCylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600
8	2,000	1,800	1,600	1,300	1,050	900	700	600	500	400	300	170	155
9	1,800	1,600	1,400	1,100	950	800	600	500	400	300	250	130	120
11	1,600	1,500	1,350	1,050	798	600	500	400	300	270	200	120	99
12	1,500	1,400	1,150	990	697	537	430	320	255	230	130	98	84
13	1,600	1,500	1,200	1,100	726	563	445	370	275	240	150	107	92
15	1,700	1,600	1,298	1,133	798	631	460	400	300	250	180	124	115
17	1,800	1,675	1,370	1,200	840	680	550	420	340	260	200	139	127
19	1,900	1,768	1,527	1,232	900	700	600	450	370	320	220	161	136
22	2,000	1,865	1,547	1,269	976	750	650	490	385	350	230	181	149
25	2,150	1,950	1,600	1,310	1,000	800	700	510	390	370	240	200	155
29	2,200	2,000	1,634	1,357	1,018	850	720	530	400	385	270	230	175
33	2,500	2,300	2,000	1,700	1,200	900	775	550	450	430	300	241	186
38	2,600	2,400	2,100	1,750	1,300	1,000	800	600	500	445	315	260	200
42	2,800	2,600	2,150	1,800	1,400	1,050	875	700	620	460	350	270	210
48	3,000	2,800	2,200	1,900	1,500	1,200	1,000	800	700	500	400	280	220
54	3,400	3,000	2,300	2,000	1,600	1,400	1,100	900	800	700	500	300	230
80	3,800	3,400	2,400	2,200	1,800	1,600	1,150	1,000	900	800	600	330	240

Description: Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

Notes: KtMSFD_ddt_IdleCylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600
8	2,400	1,900	1,700	1,500	1,150	800	750	700	600	500	400	210	175
9	2,200	1,700	1,500	1,300	1,050	700	650	600	500	400	300	190	145
11	2,000	1,400	1,450	1,200	850	650	600	500	400	300	250	160	125
12	1,900	1,500	1,280	1,050	775	500	450	375	305	265	190	140	110
13	2,000	1,576	1,350	1,200	855	550	510	455	345	285	220	160	120
15	2,100	1,700	1,400	1,220	1,000	650	580	500	385	300	240	175	130
17	2,200	1,800	1,450	1,300	1,100	750	600	525	420	340	260	185	140
19	2,300	1,900	1,580	1,350	1,240	800	620	575	430	405	280	200	150
22	2,400	2,000	1,600	1,400	1,280	875	650	600	440	420	290	220	160
25	2,550	2,150	1,680	1,435	1,380	900	700	650	460	435	320	240	175
29	2,600	2,200	1,700	1,450	1,400	950	750	675	480	450	350	260	190
33	2,900	2,400	2,100	1,800	1,650	1,000	800	700	500	470	385	270	200
38	3,000	2,500	2,200	1,900	1,700	1,100	850	750	600	480	400	280	220
42	3,200	2,700	2,250	2,000	1,800	1,200	925	800	700	500	450	300	230
48	3,400	2,900	2,300	2,100	1,900	1,300	1,100	900	800	601	475	320	250
54	3,800	3,100	2,400	2,200	2,100	1,500	1,200	1,000	900	800	600	350	275
80	4,000	3,500	2,500	2,300	2,200	1,700	1,300	1,100	1,000	900	700	380	300

12 OBDG05B Engine Diagnostics

Description: Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: KtMISF_CylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
8	2,000	1,900	1,800	1,200	815	615	600	550	500	400	300	200	86	64	52	46	40	32	17	14	10	9	7	6	5	4
9	1,900	1,800	1,700	1,135	798	596	550	500	400	300	200	100	71	52	45	38	34	28	15	11	8	7	6	5	4	3
11	1,800	1,700	1,600	1,057	745	551	500	400	300	200	100	90	55	45	38	31	27	23	13	9	6	5	5	4	3	2
12	1,600	1,530	1,513	1,011	697	503	400	234	186	117	95	67	44	41	36	28	20	19	9	8	6	5	4	3	2	2
13	1,625	1,580	1,559	1,054	735	568	435	266	197	132	120	73	49	47	38	31	22	20	9	10	8	6	5	3	2	2
15	1,650	1,600	1,584	1,148	797	628	460	290	210	144	131	80	50	49	41	35	24	23	11	11	8	6	5	4	3	2
17	1,700	1,650	1,600	1,293	893	678	515	381	271	154	150	92	55	50	48	37	30	25	14	12	9	7	6	4	3	3
19	1,750	1,680	1,621	1,378	1,038	779	587	411	329	171	160	116	81	67	53	40	35	29	17	13	9	7	7	5	4	3
22	1,800	1,700	1,636	1,407	1,144	804	601	469	392	208	181	131	94	83	62	47	41	34	19	15	10	8	7	5	4	4
25	1,900	1,780	1,659	1,467	1,177	865	732	500	435	239	198	148	109	97	73	58	47	40	20	17	11	8	6	6	5	4
29	2,000	1,800	1,694	1,586	1,250	938	760	580	471	280	250	178	121	109	80	67	60	50	24	19	11	10	7	6	5	5
33	2,200	1,900	1,717	1,600	1,300	1,005	795	760	508	327	278	194	150	127	100	79	63	54	27	21	13	12	9	7	7	6
38	2,400	2,100	1,900	1,700	1,500	1,075	950	791	581	384	314	225	181	140	109	84	69	59	31	22	14	13	10	8	7	7
42	2,600	2,300	2,100	1,900	1,700	1,200	1,050	826	661	428	341	287	200	169	120	94	77	62	37	26	16	13	12	9	8	7
48	2,800	2,500	2,300	2,100	1,900	1,400	1,200	912	702	491	369	320	245	180	139	100	85	66	43	28	19	15	12	10	9	9
54	2,900	2,700	2,500	2,300	2,100	1,600	1,400	1,000	731	605	427	376	281	193	156	114	95	77	47	30	20	17	14	11	10	10
80	3,000	2,900	2,700	2,500	2,300	1,800	1,600	1,205	826	657	481	421	303	251	194	145	118	99	56	41	24	20	17	15	12	10

12 OBDG05B Engine Diagnostics

Description: Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

Notes: KtMISF_ddt_CylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
8	2,100	2,000	1,900	1,250	940	690	750	650	550	450	155	130	91	82	58	42	36	31	18	15	10	9	7	6	5	4
9	2,000	1,900	1,800	1,195	833	640	650	550	450	350	133	120	67	55	45	37	34	30	16	12	8	7	6	5	4	3
11	1,900	1,800	1,680	1,149	790	597	550	450	350	250	116	105	57	46	41	34	27	23	14	8	6	5	5	4	3	2
12	1,700	1,580	1,546	1,122	746	562	454	263	219	145	112	88	51	43	40	31	24	20	10	7	6	5	4	3	1	1
13	1,725	1,600	1,579	1,206	809	591	500	309	260	175	142	100	57	50	46	33	30	22	11	10	8	6	4	3	2	2
15	1,750	1,650	1,604	1,330	890	664	536	332	295	200	170	116	62	51	50	42	32	26	13	11	9	7	5	4	2	2
17	1,800	1,680	1,621	1,400	1,000	711	562	410	320	229	183	136	66	55	52	50	38	28	14	12	10	7	6	4	3	3
19	1,850	1,700	1,664	1,530	1,150	800	609	440	391	284	200	150	98	79	65	54	45	35	18	14	10	8	7	5	3	3
22	1,900	1,750	1,683	1,600	1,260	864	624	540	420	300	221	173	109	94	85	61	51	42	21	16	11	9	7	5	4	4
25	2,000	1,800	1,705	1,650	1,300	923	800	607	481	355	260	200	114	109	88	71	61	47	24	19	14	11	8	7	4	4
29	2,100	2,000	1,824	1,700	1,350	1,038	864	700	507	390	319	231	138	110	94	79	69	50	29	22	14	12	9	8	5	5
33	2,300	2,100	1,900	1,750	1,500	1,150	1,000	800	609	467	351	279	154	129	101	85	70	58	30	24	15	13	11	8	7	6
38	2,500	2,300	2,100	1,900	1,700	1,300	1,100	900	705	518	368	327	186	150	118	97	75	65	37	27	21	15	13	9	7	7
42	2,700	2,500	2,300	2,100	1,900	1,400	1,200	1,000	753	573	386	374	222	180	138	109	82	68	40	31	22	18	14	10	8	7
48	2,900	2,700	2,500	2,300	2,100	1,500	1,300	1,050	800	632	420	394	266	201	167	136	91	74	48	32	25	20	16	11	10	9
54	3,100	2,900	2,700	2,500	2,300	1,700	1,500	1,100	835	719	462	454	300	207	181	143	107	87	55	35	28	23	19	12	11	10
80	3,300	3,100	2,900	2,700	2,500	1,900	1,700	1,300	911	700	562	503	355	289	202	154	130	117	64	46	31	27	22	15	14	10

Description: Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: KtMISF_RevolutionMode

y/x	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
9	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
11	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
13	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
15	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
17	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
19	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
29	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
33	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
38	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
42	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
48	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
54	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
80	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

Description: Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: KtMISF_DoDCylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	
0	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
13	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
19	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
31	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
38	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
44	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
50	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
56	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
63	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
69	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
75	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
81	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
88	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
94	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
100	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

Description: %air load that represents Zero Brake torque along the Neutral rev line. The Zero torque threshold is adjusted for Baro via P0300_ZeroTorqueBaro

Notes: KtMISF_ZeroTorqSpd

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
1	12.82	8.55	7.60	7.46	7.36	7.41	7.36	7.69	7.69	7.69	8.12	7.98	7.79	7.98	8.17	8.55	8.69	8.26	11.48	14.69	17.90	21.12	24.33	27.55	30.76	33.98

Description: adjusts zero torque for altitude

Notes: KtMSFD_K_ZeroTorqBaro

y/x	65	70	75	80	85	90	95	100	105
1	0.83	0.86	0.88	0.91	0.93	0.96	0.98	1.00	1.02

Description: Zero torque engine load while in Active Fuel Management

Notes: KtMSFD_ZeroTorqDoD

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	
1	32.00	31.00	30.00	30.00	30.00	30.00	30.00	30.00	20.00	19.00	18.00	17.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00

Description: Catalyst Damaging Misfire Percentage" Table whenever secondary conditions are met.

Notes: KtMSFD_Pct_CatalystMisfire

y/x	0	1,000	2,000	3,000	4,000	5,000	6,000	7,000
0	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
10	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
20	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
30	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
40	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
50	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
60	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
70	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
80	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
90	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
100	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8

Description: Only used if Rough Road source = TOSS: dispersion value on Transmission Output Speed Sensor above which rough road is indicated present

Notes: KtRRDI_a_RoughRoadThresh

y/x	600	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000
100	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
300	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
500	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
700	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
900	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,100	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,300	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0

Description: Only used if Wheel speed from ABS is used. If difference between wheel speed readings is larger than this limit, rough road is present

Notes: KtRRDI_a_WhlSpdRoughRoadLim

y/x	0	12	24	36	48	60	72	85	97	109	121	133	145	157	169	181	193
1	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

Description: Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Cylinder Mode Equation)

Notes: KaMSFD_Cnt_CylAbnormal

y/x	0	1	2	3	4	5	6	7	8
1	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00

Description: Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (SCD Mode Equation)

Notes: KaMSFD_Cnt_SCD_CylAbnormal

y/x	0	1	2	3	4	5	6	7	8
1	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00

Description: Abnormal Rev Mode Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Rev Mode Equation)

Notes: KaMSFD_Cnt_RevAbnormal

y/x	0	1	2	3	4	5	6	7	8
1	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00

Description: Crankshaft should return to normal after the misfire. If crankshaft snap value after single isolated misfire being evaluated is larger than the misfire's Jerk threshold times this multiplier, its not a real misfire.

Notes: KtMSFD_K_SCD_MinPttrnRecogMult

y/x	0	1,000	2,000	3,000	4,000	5,000	6,000	7,000	8,000
1	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85

Description: Crankshaft should return to normal after the misfire. If crankshaft snap value after the misfire being evaluated is larger than the misfire's Jerk threshold times this multiplier, its not a real misfire. However, if random misfire occurs every engine cycle, more noise is allowed to be considered "normal" since the crankshaft does not have time to fully return to normal before the next misfire occurs.

Notes: KtMSFD_K_SCD_MaxPtrnRecogMult

y/x	0	1,000	2,000	3,000	4,000	5,000	6,000	7,000	8,000
1	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00

Description: Driveline Ring Filter
 After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

Notes: KaMSFD_Cnt_RingFilter

y/x	0	1	2	3	4	5	6	7	8
1	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00

Description: Number of Normals for the Driveline Ring Filter
After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

Notes: KaMSFD_Cnt_NumOfNormalsFil

y/x	0	1	2	3	4	5	6	7	8
1	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00

Description: Engine OverSpeed Limit versus gear						
Notes: KaEOSC_n_EngOvrspdLimitGear						
P0300 Engine OverSpeed Limit - Part 1						
y/x	CeTGRR_e_TransGr1	CeTGRR_e_TransGr2	CeTGRR_e_TransGr3	CeTGRR_e_TransGr4	CeTGRR_e_TransGr5	CeTGRR_e_TransGr6
1	7,200	7,200	7,200	7,200	7,200	7,200
P0300 Engine OverSpeed Limit - Part 2						
y/x	CeTGRR_e_TransGrEVT 1	CeTGRR_e_TransGrEVT 2	CeTGRR_e_TransGrNeut	CeTGRR_e_TransGrRvrs	CeTGRR_e_TransGrPark	
1	7,200	7,200	3,200	7,200	3,200	

Description: P00C6

Notes:

y/x	-40	-30	-20	-10	-5	0	8	16	20	24	32	40	48	64	80	90	112
0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
13	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
25	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
38	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
50	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
63	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
75	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
88	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
100	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5

Description: P00C6

Notes:

y/x	-40	-30	-20	-10	-5	0	8	16	20	24	32	40	48	64	80	90	112
0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
13	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
25	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
38	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
50	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
63	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
75	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
88	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
100	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

Description: P00C6

Notes:

y/x	-40	-30	-20	-10	-5	0	8	16	20	24	32	40	48	64	80	90	112
0	15.0	15.0	10.0	8.0	5.5	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
13	15.0	15.0	10.0	8.0	5.5	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
25	15.0	15.0	11.3	9.0	6.1	4.4	3.3	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
38	15.0	15.0	12.5	12.0	6.8	4.8	3.5	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
50	15.0	15.0	13.8	12.0	7.4	5.1	3.8	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
63	15.0	15.0	15.0	12.0	8.0	5.5	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
75	15.0	15.0	15.0	12.0	8.0	5.5	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
88	15.0	15.0	15.0	15.0	8.0	5.5	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
100	15.0	15.0	15.0	15.0	8.0	5.5	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0

Description: P00C6

Notes:

y/x	-40	-30	-20	-10	-5	0	8	16	20	24	32	40	48	64	80	90	112
1	11.0	11.0	10.0	9.0	8.0	5.0	5.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0

Description: P0089,P163A,P228C,P228D,P0191

Notes:

y/x	-30	-20	-10	0	10	20	80	100	110
1	60.0	60.0	40.0	30.0	30.0	30.0	30.0	40.0	60.0

Description: P0191

Notes:

y/x	-30	-20	-10	0	10	20	80	100	110
1	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

Description: P0191

Notes:

y/x	0	13	25	38	50	63	75	88	100
65	195.0	195.0	195.0	195.0	195.0	195.0	195.0	195.0	195.0
70	190.0	190.0	190.0	190.0	190.0	190.0	190.0	190.0	190.0
75	185.0	185.0	185.0	185.0	185.0	185.0	185.0	185.0	185.0
80	180.0	180.0	180.0	180.0	180.0	180.0	180.0	180.0	180.0
85	175.0	175.0	175.0	175.0	175.0	175.0	175.0	175.0	175.0
90	170.0	170.0	170.0	170.0	170.0	170.0	170.0	170.0	170.0
95	165.0	165.0	165.0	165.0	165.0	165.0	165.0	165.0	165.0
100	160.0	160.0	160.0	160.0	160.0	160.0	160.0	160.0	160.0
105	160.0	160.0	160.0	160.0	160.0	160.0	160.0	160.0	160.0

Description: P0133 - O2S Slow Response Bank 1 Sensor 1 "Pass/Fail Threshold table"

Notes: X axis is Lean to Rich response time (in sec), Please see the table below named "KnEOSD_t_ST_LRC_LimRS1" for the 17 X axis table breakpoints. Y axis is Rich to Lean response time (sec), Please see the cal table below named "KnEOSD_t_ST_RLC_LimRS1" for the 17 Y axis table breakpoints. Z axis is the pass/fail result, Note: If the cell contains a "0" then the fault is indicated, if it contains a "1" a fault is not indicated.

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
2	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
3	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
4	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
5	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
6	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
7	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
8	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
9	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
10	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
11	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
12	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
13	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
14	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
15	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Description: P0153 - O2S Slow Response Bank 2 Sensor 1 "Pass/Fail Threshold table"

Notes: X axis is Lean to Rich response time (in sec), Please see the table below named "KnEOSD_t_ST_LRC_LimRS2" for the 17 X axis table breakpoints. Y axis is Rich to Lean response time (sec), Please see the cal table below named "KnEOSD_t_ST_RLC_LimRS2" for the 17 Y axis table breakpoints. Z axis is the pass/fail result, Note: If the cell contains a "0" then the fault is indicated, if it contains a "1" a fault is not indicated.

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
2	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
3	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
4	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
5	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
6	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
7	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
8	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
9	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
10	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
11	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
12	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
13	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
14	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
15	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Description: P1133 - O2S HC L to R Switches Limit Bank 1 Sensor 1 Threshold table

Notes: X axis is estimated Ethanol percentage, Please see the table below named "KnE85G_Pct_FFS_CompAtEngAxis" for the 5 X axis table breakpoints. Y axis is Average airflow during the response test (gps). Z axis is the limit for L2R Half Cycle switches, Note: The cell contains the mininum switches, below which the fault is indicated.

y/x	0	10	20	50	80
0.0	22	22	22	22	22
6.3	22	22	22	22	22
12.5	22	22	22	22	22
18.8	22	22	22	22	22
25.0	23	23	23	23	23
31.3	24	24	24	24	24
37.5	24	24	24	24	24
43.8	25	25	25	25	25
50.0	25	25	25	25	25
56.3	25	25	25	25	25
62.5	25	25	25	25	25
68.8	25	25	25	25	25
75.0	25	25	25	25	25
81.3	25	25	25	25	25
87.5	25	25	25	25	25
93.8	25	25	25	25	25
100.0	25	25	25	25	25

Description: P1133 - O2S HC R to L Switches Limit Bank 1 Sensor 1 Threshold table

Notes: X axis is estimated Ethanol percentage, Please see the table below named "KnE85G_Pct_FFS_CompAtEngAxis" for the 5 X axis table breakpoints. Y axis is Average airflow during the response test (gps). Z axis is the limit for R2L Half Cycle switches, Note: The cell contains the mininum switches, below which the fault is indicated.

y/x	0	10	20	50	80
0.0	22	22	22	22	22
6.3	22	22	22	22	22
12.5	22	22	22	22	22
18.8	22	22	22	22	22
25.0	23	23	23	23	23
31.3	24	24	24	24	24
37.5	24	24	24	24	24
43.8	25	25	25	25	25
50.0	25	25	25	25	25
56.3	25	25	25	25	25
62.5	25	25	25	25	25
68.8	25	25	25	25	25
75.0	25	25	25	25	25
81.3	25	25	25	25	25
87.5	25	25	25	25	25
93.8	25	25	25	25	25
100.0	25	25	25	25	25

Description: P1153 - O2S HC L to R Switches Limit Bank 2 Sensor 1 Threshold table

Notes: X axis is estimated Ethanol percentage, Please see the table below named "KnE85G_Pct_FFS_CompAtEngAxis" for the 5 X axis table breakpoints. Y axis is Average airflow during the response test (gps). Z axis is the limit for L2R Half Cycle switches, Note: The cell contains the mininum switches, below which the fault is indicated.

y/x	0	10	20	50	80
0.0	22	22	22	22	22
6.3	22	22	22	22	22
12.5	22	22	22	22	22
18.8	22	22	22	22	22
25.0	23	23	23	23	23
31.3	24	24	24	24	24
37.5	24	24	24	24	24
43.8	25	25	25	25	25
50.0	25	25	25	25	25
56.3	25	25	25	25	25
62.5	25	25	25	25	25
68.8	25	25	25	25	25
75.0	25	25	25	25	25
81.3	25	25	25	25	25
87.5	25	25	25	25	25
93.8	25	25	25	25	25
100.0	25	25	25	25	25

Description: P1153 - O2S HC R to L Switches Limit Bank 2 Sensor 1 Threshold table

Notes: X axis is estimated Ethanol percentage, Please see the table below named "KnE85G_Pct_FFS_CompAtEngAxis" for the 5 X axis table breakpoints. Y axis is Average airflow during the response test (gps). Z axis is the limit for R2L Half Cycle switches, Note: The cell contains the mininum switches, below which the fault is indicated.

y/x	0	10	20	50	80
0.0	22	22	22	22	22
6.3	22	22	22	22	22
12.5	22	22	22	22	22
18.8	22	22	22	22	22
25.0	23	23	23	23	23
31.3	24	24	24	24	24
37.5	24	24	24	24	24
43.8	25	25	25	25	25
50.0	25	25	25	25	25
56.3	25	25	25	25	25
62.5	25	25	25	25	25
68.8	25	25	25	25	25
75.0	25	25	25	25	25
81.3	25	25	25	25	25
87.5	25	25	25	25	25
93.8	25	25	25	25	25
100.0	25	25	25	25	25

Description: This Calibration is the airflow (in gps) above which the green airflow is acculmulated to expire the condition

Notes: The specific diagnostic (from summary table) will not be enabled until the next ignition cycle after the airflow criteria below (by sensor location) has been met:

y/x	1
1	22

Description: This Calibration is the acculmulated airflow (in grams) limit above which the green condition is expired

Notes: Note: This feature is only enabled when the vehicle is new and cannot be enabled in service

y/x	CiOXYR_O2_Bank1_Sensor1	CiOXYR_O2_Bank1_Sensor2	CiOXYR_O2_Bank2_Sensor1	CiOXYR_O2_Bank2_Sensor2
1	120,000	720,000	120,000	720,000

Description: X Table Axis (in sec) for P0133, L2R Reponse time breakpoints for table

Notes:

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.010	0.021	0.032	0.043	0.054	0.065	0.076	0.088	0.099	0.110	0.121	0.132	0.143	0.154	0.165	2.000

Description: Y Table Axis (in sec) for P0133, R2L Reponse time breakpoints for table

Notes:

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.010	0.021	0.033	0.044	0.056	0.067	0.079	0.090	0.101	0.113	0.124	0.136	0.147	0.159	0.170	2.000

Description: X Table Axis (in sec) for P0153, L2R Reponse time breakpoints for table

Notes:

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.010	0.021	0.032	0.043	0.054	0.065	0.076	0.088	0.099	0.110	0.121	0.132	0.143	0.154	0.165	2.000

Description: Y Table Axis (in sec) for P0153, R2L Reponse time breakpoints for table

Notes:

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.010	0.021	0.033	0.044	0.056	0.067	0.079	0.090	0.101	0.113	0.124	0.136	0.147	0.159	0.170	2.000

Description: X Table Axis for P01133, P01153 (both L2R and R2L tables)

Notes: Ethanol percentage breakpoints

y/x	1	2	3	4	5
1	0	10	20	50	80

Description: KtAIRD_dp_SAI_SL_ThrshBank1: Bank 1 SAI Flow (Phase 1) Test Average String Length failure threshold versus MAF (g/sec).

Notes:

y/x	0.0	3.0	6.0	9.0	12.0	15.0	18.0	21.0	24.0	27.0	30.0	33.0	36.0	39.0	42.0	45.0	48.0
1.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

Description: KtAIRD_dp_SAI_SL_ThrshBank2: Bank 2 SAI Flow (Phase 1) Test Average String Length failure threshold versus MAF (g/sec).

Notes: For dual Bank SAI systems only.

y/x	0.0	3.0	6.0	9.0	12.0	15.0	18.0	21.0	24.0	27.0	30.0	33.0	36.0	39.0	42.0	45.0	48.0
1.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

Description: KtAIRD_K_SAI_TstBaroDsbl: SAI Flow (Phase 1) Test baro weight factor.

Notes: Axis is atmospheric pressure (kPa)

y/x	40	50	60	70	80	90	100	110	120
1	0.0	0.0	0.5	1.0	1.0	1.0	1.0	1.0	0.0

Description: KtAIRD_K_SAI_TstMAF_Dsbl: SAI Flow (Phase 1) Test MAF weight factor.

Notes: Axis is Mass Airflow (g/sec).

y/x	0.0	3.0	6.0	9.0	12.0	15.0	18.0	21.0	24.0	27.0	30.0	33.0	36.0	39.0	42.0	45.0	48.0
1.0	0.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	0.5	0.0	0.0	0.0	0.0	0.0

Description: KtAIRD_K_SAI_TstVoltDsbl: SAI Flow (Phase 1) Test system voltage weight factor.

Notes: Axis is system voltage (V).

y/x	5.0	6.0	7.0	8.0	9.0	10.0	11.0	12.0	13.0	14.0	15.0	16.0	17.0	18.0	19.0	20.0	21.0
1.0	0.0	0.0	0.0	0.0	0.0	0.5	0.8	1.0	1.0	1.0	1.0	1.0	0.8	0.5	0.5	0.5	0.5

Description: KtAIRD_K_SAI_TstTempDsbl: SAI Flow (Phase 1) Test ambient temperature weight factor.

Notes: Axis is Ambient (IAT) Temp (C).

y/x	-30	-20	-10	0	10	20	30	40	50
1	0.0	0.0	0.0	0.5	1.0	1.0	1.0	1.0	1.0

Description: KtAIRD_K_APPD_BaroQlty: The AIR Pressure Sensor Test quality factor based on the distance traveled since the last unthrottled ambient pressure update.

Notes: P2436 is applicable on dual valve applications only. Axis is distance traveled from last Baro update in Km (1Km = 0.62 Miles).

y/x	0.0	2.0	4.0	6.0	8.0	10.0	12.0	14.0	16.0	18.0	20.0	22.0	24.0	26.0	28.0	30.0	32.0
1.0	1.0	0.8	0.5	0.3	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Description: KaAIRD_p_VlvTstPresErrMin[CeAIRR_e_PresSnsrOne]: Sensor 1 minimum average pressure error (kPa) threshold for the valve-shut (Phase 2) test .

Notes: Axis is Conditional Test Weight Time in seconds.

y/x	0	1	2	3	4	5	6	7	8
1	-6.0	-6.0	-6.0	-6.0	-6.0	-6.0	-6.0	-6.0	-6.0

Description: KaAIRD_p_VlvTstPresErrMin[CeAIRR_e_PresSnsrTwo]: Sensor 2 minimum average pressure error (kPa) threshold for the valve-shut (Phase 2) test .

Notes: For dual sensor SAI systems only. Axis is Conditional Test Weight Time in seconds.

y/x	0	1	2	3	4	5	6	7	8
1	-6.0	-6.0	-6.0	-6.0	-6.0	-6.0	-6.0	-6.0	-6.0

Description: KtAIRD_K_VlvTstBaroDsbl: Ambient pressure component of the conditional test weight for the valve-shut (Phase 2) test .

Notes: Axis is ambient pressure (kPa).

y/x	40	50	60	70	80	90	100	110	120
1	0.0	0.0	0.5	1.0	1.0	1.0	1.0	1.0	0.0

Description: KtAIRD_K_VlvTstMAF_Dsblid: Mass Airflow (MAF) component of the conditional test weight for the valve-shut (Phase 2) test.

Notes:

y/x	0.0	3.0	6.0	9.0	12.0	15.0	18.0	21.0	24.0	27.0	30.0	33.0	36.0	39.0	42.0	45.0	48.0
1.0	0.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	0.5	0.0	0.0	0.0	0.0	0.0

Description: KtAIRD_K_VlvTstVoltDsblD: System Voltage component of the conditional test weight for the valve-shut (Phase 2) test.

Notes: Axis is system volts (V).

y/x	5.0	6.0	7.0	8.0	9.0	10.0	11.0	12.0	13.0	14.0	15.0	16.0	17.0	18.0	19.0	20.0	21.0
1.0	0.0	0.0	0.0	0.0	0.0	0.5	0.8	1.0	1.0	1.0	1.0	1.0	0.8	0.5	0.5	0.5	0.5

Description: KtAIRD_K_VlvTstTempDsbl: Ambient Temperature component of the conditional test weight for the valve-shut (Phase 2) test.

Notes: Axis is ambient temperature (IAT) in Deg C.

y/x	-30	-20	-10	0	10	20	30	40	50
1	0.0	0.0	0.0	0.5	1.0	1.0	1.0	1.0	1.0

Description: KaAIRD_p_PmpTstPresErrMax[CeAIRR_e_PresSnsrOne]: Sensor 1 maximum average pressure error threshold for the pump-off (Phase 3) test.

Notes: Axis is Conditional Test Weight Time in seconds.

y/x	0	1	2	3	4	5	6	7	8
1	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5

Description: KaAIRD_p_PmpTstPresErrMax[CeAIRR_e_PresSnsrTwo]: Sensor 2 maximum average pressure error threshold for the pump-off (Phase 3) test.

Notes: For dual sensor SAI systems only. Axis is Conditional Test Weight Time in seconds.

y/x	0	1	2	3	4	5	6	7	8
1	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5

Description: EOT Sensor Cold Start Fast Fail Threshold

Notes: X Axis is defined as PowerUp Coolant Temperature

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	80.0	80.0	80.0	60.0	60.0	40.0	40.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0

Description:

Notes:

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	15,000	14,000	13,000	12,000	11,000	10,000	9,000	8,000	7,000	6,000	5,000	4,000	5,000	4,000	3,000	3,000	3,000

Description: RPM_Weighting_Factor_X_Axis

Notes: Engine RPM Axis for KtEOPD_r_EngSpdWeight

y/x	1	2	3	4	5	6	7	8	9
1	0	500	900	1,000	1,500	1,750	2,000	3,500	4,000

Description: RPM_Weighting_Factor									
Notes: X axis is Engine RPM defined by KnEOPD_n_EngSpdFilteredBpt									
y/x	0	500	900	1,000	1,500	1,750	2,000	3,500	4,000
1	0.00	0.00	0.00	0.45	0.45	0.45	0.46	0.44	0.00

Description: Oil_Temp_Weighting_Factor_X_Axis

Notes:

y/x	1	2	3	4	5	6	7	8	9
1	-40	40	60	80	90	100	120	130	140

Description: Oil_Temp_Weighting_Factor

Notes: X axis is Oil Temperature defined by KnEOPD_T_EngFilteredBpt

y/x	-40	40	60	80	90	100	120	130	140
1	0.58	0.70	0.70	0.70	0.70	0.70	0.70	0.70	0.00

Description: Eng_Load_Stability_Weighting_Factor_X_Axis

Notes:

y/x	1	2	3	4	5	6	7	8	9
1	0	5	10	20	30	50	100	200	399

Description: Eng_Load_Stability_Weighting_Factor

Notes: X Axis is Engine Load Stability defined by KnEOPD_m_EngLoadStabilityBpt

y/x	0	5	10	20	30	50	100	200	399
1	1.00	1.00	0.50	0.30	0.10	0.00	0.00	0.00	0.00

Description: Oil_Pressure_Pred_Weighting_Factor_X_Axis

Notes:

y/x	1	2	3	4	5	6	7	8	9
1	0	170	250	275	360	375	400	500	600

Description: Oil_Pressure_Pred_Weighting_Factor

Notes: X Axis is Predicted Oil Pressure defined by KnEOPD_p_EngOilPredictedBpt

y/x	0	170	250	275	360	375	400	500	600
1	0.00	0.00	0.10	1.00	1.00	1.00	1.00	0.86	0.00

Description: Vehicle Speed Axis

Notes:

y/x	1	2	3	4	5	6	7	8	9
1	0	20	40	60	80	100	120	140	160

Description: Ambient_Temperature_Axis

Notes:

y/x	1	2	3	4	5	6	7	8	9
1	-20	0	20	60	60	60	60	60	100

Description: AC High Side Pressure Sensor Sensor Engage Test Predicted Delta Pressure

Notes: X Axis is defined by KnACCD_T_HSPRat_EngageTstAmb and Y Axis is defined by KnACCD_v_HSPRat_EngageTstVehSpd

y/x	-20	0	20	60	60	60	60	60	60	100
0	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	50.00	100.00
20	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	50.00	100.00
40	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	50.00	100.00
60	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	50.00	100.00
80	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	50.00	100.00
100	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	50.00	100.00
120	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	50.00	100.00
140	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	50.00	100.00
160	0.00	5.00	20.00	50.00	50.00	50.00	50.00	50.00	50.00	100.00

Description: Delta_Predicted_Weighting_Factor

Notes: X Axis is defined by KnACCD_T_HSPRat_EngageTstAmb and Y Axis is defined by KnACCD_v_HSPRat_EngageTstVehSpd

y/x	-20	0	20	60	60	60	60	60	100
0	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
20	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
40	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
60	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
80	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
100	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
120	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
140	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998
160	0.00999	0.04999	0.20000	0.50000	0.50000	0.50000	0.50000	0.50000	0.99998

Description: Coolant_Weighting_Factor_X_Axis

Notes:

y/x	1	2	3	4	5	6	7	8	9
1	-20	0	20	60	60	60	60	60	100

Description: Coolant_Weighting_Factor									
Notes: X Axis is Engine Coolant defined by KnACCD_T_HSPRat_EngageTstCool									
y/x	-20	0	20	60	60	60	60	60	100
1	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000

Description: Ambient Temperature Axis for the On Test

Notes:

y/x	1	2	3	4	5
1	-20	0	20	60	100

Description: AC High Side Pressure Sensor Rationality On Test Threshold

Notes: X Axis is defined by KnACCD_T_HSPRat_OnTestPresMin

y/x	-20	0	20	60	100
1	300.0	350.0	400.0	450.0	500.0

Description: FanSpeed_Weighting_Factor_X_Axis

Notes:

y/x	1	2	3	4	5	6	7	8	9
1	0	5	20	50	50	50	50	50	100

Description: FanSpeed_Weighting_Factor

Notes: X Axis is Fan Speed as desfined by KnACCD_Pct_HSPRat_EngageTestFan

y/x	0	5	20	50	50	50	50	50	100
1	1	1	1	1	1	1	1	1	1

Description: Ambient Temperature Axis for the Off Test

Notes:

y/x	1	2	3	4	5
1	-20	0	20	60	100

Description: AC High Side Pressure Sensor Rationality Off Test Threshold

Notes: X Axis is defined by KnACCD_T_HSPRat_OffTestPresMax

y/x	-20	0	20	60	100
1	300	350	400	450	500

Bundle Name: 5VoltReferenceA_FA
P0641
Bundle Name: 5VoltReferenceB_FA
P0651
Bundle Name: 5VoltReferenceMAP_OOR_Fit
P0697
Bundle Name: A/F Imbalance Bank1
P219A
Bundle Name: A/F Imbalance Bank2
P219B
Bundle Name: AAP_SnsrCktFP
Naturally aspirated: P2228, P2229. Turbocharged: P0237, P0238
Bundle Name: AAP_SnsrFA
Naturally Aspirated: P2227, P2228, P2229, P2230. Turbocharged: P0237, P0238.
Bundle Name: AAP_SnsrTFTKO
Naturally Aspirated: P2227, P2228, P2229, P2230. Turbocharged: P0237, P0238.
Bundle Name: AAP2_SnsrCktFP
P2228, P2229
Bundle Name: AAP2_SnsrFA
P2227, P2228, P2229, P2230
Bundle Name: AAP2_SnsrTFTKO
P2227, P2228, P2229, P2230
Bundle Name: AccCktLo_FA
P2537
Bundle Name: AcceleratorPedalFailure
P2122, P2123, P2127, P2128, P2138, P0697, P06A3
Bundle Name: ACCMLostComm
U016B
Bundle Name: ACFailedOnSD
See ACCM Document
Bundle Name: ACHighSidePressSnsrCktFA
P0532, P0533
Bundle Name: ACThrmlRefrigSpdVld
See ACCM Document
Bundle Name: AfterThrottlePressTFTKO
Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.
Bundle Name: AfterThrottlePressureFA
Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.

Bundle Name: AfterThrottleVacuumTFTKO
Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.
Bundle Name: AIR System FA
P0411, P2440, P2444
Bundle Name: AIRPumpControlCircuit FA
P0418
Bundle Name: AIRSystemPressureSensor FA
P2430, P2431, P2432, P2433, P2435, P2436, P2437, P2438
Bundle Name: AIRValveControlCircuit FA
P0412
Bundle Name: AmbientAirDefault
Baro Sensor Present: P2227, P2228, P2229, P2230. No Baro Sensor Present: P0101, P0102, P0103, P0106, P0107, P0108, P0111, P0112, P0113, P0114, P0121, P0122, P0123, P012B, P012C, P012D, P0222, P0223, P1221
Bundle Name: AmbPresDfltStatus
Baro Sensor Present: P2227, P2228, P2229, P2230. No Baro Sensor Present: P0101, P0102, P0103, P0106, P0107, P0108, P0111, P0112, P0113, P0114, P0121, P0122, P0123, P012B, P012C, P012D, P0222, P0223, P1221
Bundle Name: AmbPresSnsrCktFA
P2228, P2229
Bundle Name: AmbPresSnsrCktFP
P2228, P2229
Bundle Name: AnyCamPhaser_FA
P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024
Bundle Name: AnyCamPhaser_TFTKO
P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024
Bundle Name: BrakeBoosterSensorFA
P0556, P0557, P0558
Bundle Name: BrakeBoosterVacuumValid
P0556, P0557, P0558
Bundle Name: BSTR_b_ExcsvBstFA
P226B
Bundle Name: BSTR_b_ExcsvBstTFTKO
P226B
Bundle Name: BSTR_b_IC_PmpCktFA
P023A, P023C
Bundle Name: BSTR_b_PCA_CktFA
P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P0247, P0249, P0250
Bundle Name: BSTR_b_PCA_CktLoFA

P0034, P0047, P0245, P0249
Bundle Name: BSTR_b_PCA_CktLoTFTKO
P0034, P0047, P0245, P0249
Bundle Name: BSTR_b_PCA_CktTFTKO
P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P0247, P0249, P0250
Bundle Name: BSTR_b_PCA_FA
P0234, P0299, P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P2261, P0247, P0249, P0250
Bundle Name: BSTR_b_PCA_PstnSnsrFA
P003A, P2564, P2565
Bundle Name: BSTR_b_PCA_PstnSnsrTFTKO
P003A, P2564, P2565
Bundle Name: BSTR_b_PCA_TFTKO
P0234, P0299, P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P2261, P0247, P0249, P0250
Bundle Name: BSTR_b_PresCntrlTooHiFA
P0234
Bundle Name: BSTR_b_PresCntrlTooHiTFTKO
P0234
Bundle Name: BSTR_b_PresCntrlTooLoFA
P0299
Bundle Name: BSTR_b_PresCntrlTooLoTFTKO
P0299
Bundle Name: BSTR_b_PstnCntrlFA
P166D, P166E
Bundle Name: BSTR_b_PstnCntrlTooHiFA
P166E
Bundle Name: BSTR_b_PstnCntrlTooHiTFTKO
P166E
Bundle Name: BSTR_b_PstnCntrlTooLoFA
P166D
Bundle Name: BSTR_b_PstnCntrlTooLoTFTKO
P166D
Bundle Name: BSTR_b_TurboBypassCktFA
P0033, P0034, P0035, P00C0, P00C1, P00C2
Bundle Name: BSTR_b_TurboBypassCktTFTKO
P0033, P0034, P0035, P00C0, P00C1, P00C2
Bundle Name: BSTR_b_TurboBypB_CktFA
P00C0, P00C1, P00C2
Bundle Name: BSTR_b_TurboBypB_CktTFTKO

P00C0, P00C1, P00C2
Bundle Name: CamLctnExhFA
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: CamLctnIntFA
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: CamSensor_FA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensor_TFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorAnyLctnTFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorAnyLocationFA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorFA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorTFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CatalystSysEfficiencyLoB1_FA
P0420
Bundle Name: CatalystSysEfficiencyLoB2_FA
P0430
Bundle Name: ClutchPstnSnsr FA
P0806, P0807, P0808
Bundle Name: ClutchPstnSnsrCktHi FA
P0808
Bundle Name: ClutchPstnSnsrCktLo FA
P0807
Bundle Name: ClutchPstnSnsrNotLearned
P080A
Bundle Name: CommBusAOff_VICM_FA
U0073
Bundle Name: CommBusBOff_VICM_FA
U0074
Bundle Name: CoolingFanSpeedTooHigh_FA
P0495
Bundle Name: CrankCamCorrelationTFTKO
P0016, P0017, P0018, P0019
Bundle Name: CrankExhaustCamCorrelationFA

P0017, P0019
Bundle Name: CrankExhaustCamCorrFA
P0017, P0019
Bundle Name: CrankIntakeCamCorrelationFA
P0016, P0018
Bundle Name: CrankIntakeCamCorrFA
P0016, P0018
Bundle Name: CrankSensor_FA
P0335, P0336
Bundle Name: CrankSensor_TFTKO
P0335, P0336
Bundle Name: CrankSensorFA
P0335, P0336
Bundle Name: CrankSensorFaultActive
P0335, P0336
Bundle Name: CrankSensorTestFailedTKO
P0335, P0336
Bundle Name: CrankSensorTFTKO
P0335, P0336
Bundle Name: CylDeacSystemTFTKO
P3400
Bundle Name: CylnderDeacDriverTFTKO
P3401, P3409, P3417, P3425, P3433, P3441, P3449
Bundle Name: ECT_Sensor_Ckt_FA
P0117, P0118, P0119
Bundle Name: ECT_Sensor_Ckt_FP
P0117, P0118
Bundle Name: ECT_Sensor_Ckt_High_FP
P0118
Bundle Name: ECT_Sensor_Ckt_Low_FP
P0117
Bundle Name: ECT_Sensor_Ckt_TFTKO
P0117, P0118, P0119
Bundle Name: ECT_Sensor_Ckt_TPTKO
P0117, P0118, P0019
Bundle Name: ECT_Sensor_DefaultDetected
P0117, P0118, P0116, P0125
Bundle Name: ECT_Sensor_FA

P0117, P0118, P0116, P0125, P0128
Bundle Name: ECT_Sensor_Perf_FA
P0116
Bundle Name: ECT_Sensor_TFTKO
P0117, P0118, P0116, P0125, P0119
Bundle Name: EGRValve_FP
P0405, P0406, P042E
Bundle Name: EGRValveCircuit_FA
P0403, P0404, P0405, P0406
Bundle Name: EGRValveCircuit_TFTKO
P0403, P0404, P0405, P0406
Bundle Name: EGRValvePerformance_FA
P0401, P042E
Bundle Name: EGRValvePerformance_TFTKO
P0401, P042E
Bundle Name: ELCP_PumpCircuit_FA
P2400, P2401, P2402
Bundle Name: ELCP_SwitchCircuit_FA
P2418, P2419, P2420
Bundle Name: ELCP_Circuit_FA
P1459, P145A
Bundle Name: EngineMetalOvertempActive
P1258
Bundle Name: EngineMisfireDetected_FA
P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308
Bundle Name: EngineMisfireDetected_TFTKO
P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308
Bundle Name: EngineModeNotRunTimer_FA
P2610
Bundle Name: EngineModeNotRunTimerError
P2610
Bundle Name: EnginePowerLimited
P0068, P0122, P0123, P0222, P0223, P0606, P16F3, P1104, P2100, P2101, P2102, P2103, P160E, P160D, P0191, P0192, P0193, P00C8, P00C9
Bundle Name: EngineTorqueEstInaccurate
EngineMisfireDetected_FA, FuelInjectorCircuit_FA, FuelInjectorCircuit_TFTKO, FuelTrimSystemB1_FA, FuelTrimSystemB2_FA, MAF_SensorTFTKO, MAP_SensorTFTKO, EGRValuePerforamnce_FA
Bundle Name: EngModeNotRunTmErr
P2610

Bundle Name: EngOilModeledTempValid
ECT_Sensor_FA, IAT_SensorCircuitFA
Bundle Name: EngOilPressureSensorCktFA
P0522, P0523
Bundle Name: EngOilPressureSensorFA
P0521, P0522, P0523
Bundle Name: EngOilTempSensorCircuitFA
P0197, P0198
Bundle Name: Ethanol Composition Sensor FA
P0178, P0179, P2269
Bundle Name: EvapEmissionSystem_FA
P0455, P0446
Bundle Name: EvapExcessPurgePsbl_FA
Conventional fuel system, P0442, P0443, P0455, P0496
Bundle Name: EvapFlowDuringNonPurge_FA
P0496
Bundle Name: EvapPurgeSolenoidCircuit_FA
P0443
Bundle Name: EvapReducedPurgePsbl_FA
Only EREV sealed fuel system, P0443, P0446, P0449, P0459, P0497, P0499, P2419, P2422
Bundle Name: EvapSmallLeak_FA
P0442
Bundle Name: EvapVentSolenoidCircuit_FA
P0449
Bundle Name: ExhaustCamSensor_FA
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: ExhaustCamSensor_TFTKO
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: ExhaustCamSensorFA
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: ExhaustCamSensorTFTKO
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: FanOutputDriver_FA
P0480, P0481, P0482, P0691, P0692, P0693, P0694, P0695, P0696
Bundle Name: FHPD_b_HPC_PresErrNeg_FA
P228D
Bundle Name: FHPD_b_HPC_PresErrNeg_TFTKO
P228D

Bundle Name: FHPD_b_HPC_PresErrPos_FA
P228C
Bundle Name: FHPD_b_HPC_PresErrPos_TFTKO
P228C
Bundle Name: FHPD_b_HPC_Windup_TFTKO
P0089
Bundle Name: FHPD_b_HPC_Windup_FA
P0089
Bundle Name: FHPD_b_PumpCurr_FA
P163A
Bundle Name: FHPD_b_PumpCurr_TFTKO
P163A
Bundle Name: FHPR_b_FRP_SnsrCkt_FA
P0192, P0193
Bundle Name: FHPR_b_FRP_SnsrCkt_TFTKO
P0192, P0193
Bundle Name: FHPR_b_FRP_SnsrPerfDiag_FA
P0191
Bundle Name: FHPR_b_FRP_SnsrPerfDiag_TFTKO
P0191
Bundle Name: FHPR_b_PumpCkt_FA
P0090, P0091, P0092, P00C8, P00C9, P00CA
Bundle Name: FHPR_b_PumpCkt_TFTKO
P0090, P0091, P0092, P00C8, P00C9, P00CA
Bundle Name: FTP_SensorCircuit_FA
P0452, P0453
Bundle Name: FuelInjectorCircuit_FA
P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, PP0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216E, P217B, P217E, P2148, P2151, P2154, P2157, P216C, P216F, P217C, P217F, P1248, P1249, P124A, P124B, P124C, P124D, P124E, P124F
Bundle Name: FuelInjectorCircuit_TFTKO
P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, PP0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216E, P217B, P217E, P2148, P2151, P2154, P2157, P216C, P216F, P217C, P217F, P1248, P1249, P124A, P124B, P124C, P124D, P124E, P124F
Bundle Name: FuelLevelDataFault
P0461, P0462, P0463, P2066, P2067, P2068
Bundle Name: FuelTankPressureSnsrCkt_FA
P0452, P0453
Bundle Name: FuelTrimSystemB1_FA

P0171, P0172
Bundle Name: FuelTrimSystemB1_TFTKO
P0171, P0172
Bundle Name: FuelTrimSystemB2_FA
P0174, P0175
Bundle Name: FuelTrimSystemB2_TFTKO
P0174, P0175
Bundle Name: HumidityFA
P0097, P0098, P11C2, P11C3, P2227, P2228, P2229, P2230
Bundle Name: HumTempSnsrCktFA
P0097, P0098
Bundle Name: HumTempSnsrCktFP
P0097, P0098
Bundle Name: HumTempSnsrFA
P0096, P0097, P0098, P0099
Bundle Name: IAC_SystemRPM_FA
P0506, P0507
Bundle Name: IAT_ContCorrFA
P2199
Bundle Name: IAT_SensorCircuitFA
P0112, P0113
Bundle Name: IAT_SensorCircuitFP
P0112, P0113
Bundle Name: IAT_SensorCircuitTFTKO
P0112, P0113
Bundle Name: IAT_SensorFA
P0111, P0112, P0113, P0114
Bundle Name: IAT_SensorTFTKO
P0111, P0112, P0113, P0114
Bundle Name: IgnitionOffTimer_FA
P2610
Bundle Name: IgnitionOffTimeValid
P2610
Bundle Name: IgnitionOutputDriver_FA
P0351, P0352, P0353, P0354, P0355, P0356, P0357, P0358
Bundle Name: IntakeCamSensor_FA
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntakeCamSensor_TFTKO

P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntakeCamSensorFA
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntakeCamSensorTFTKO
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntkCamPhaser_FA
P0010, P0011, P0020, P0021
Bundle Name: KS_Ckt_Perf_B1B2_FA
P0324, P0325, P0326, P0327, P0328, P0330, P0332, P0333, P06B6, P06B7
Bundle Name: Long Name
Short Name
Bundle Name: LostCommBCM_FA
U0140
Bundle Name: LostCommBusB_VICM_FA
U182D
Bundle Name: LowFuelConditionDiagnostic
Flag set to TRUE if the fuel level < KeFLVI_Pct_FuelLevelLowDiag (see supporting table for numeric value) % AND No Active DTCs: FuelLevelDataFault, P0462, P0463 for at least KeFLVI_t_FuelLevelLowTime (see supporting table for numeric value) seconds.
Bundle Name: MAF_SensorCircuitFA
P0102, P0103, P010C, P010D
Bundle Name: MAF_SensorCircuitTFTKO
P0102, P0103, P010C, P010D
Bundle Name: MAF_SensorFA
P0101, P0102, P0103, P010C, P010D
Bundle Name: MAF_SensorFP
P0102, P0103, P010C, P010D
Bundle Name: MAF_SensorPerfFA
P0101
Bundle Name: MAF_SensorPerfTFTKO
P0101
Bundle Name: MAF_SensorTFTKO
P0101, P0102, P0103, P010C, P010D
Bundle Name: MAF_SnsrCktFA
P121B, P121C
Bundle Name: MAF_SnsrCktTFTKO
P121B, P121C
Bundle Name: MAP_EngineVacuumStatus
P0106, P0107, P0108 Fault Active OR P0107, P0108 Fault Pending

Bundle Name: MAP_SensorCircuitFA
P0107, P0108
Bundle Name: MAP_SensorCircuitFP
P0107, P0108
Bundle Name: MAP_SensorFA
P0106, P0107, P0108
Bundle Name: MAP_SensorPerfFA
P0106
Bundle Name: MAP_SensorPerfTFTKO
P0106
Bundle Name: MAP_SensorTFTKO
P0106, P0107, P0108
Bundle Name: MnfdTempSensorCktFA
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
Bundle Name: MnfdTempSensorCktFP
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
Bundle Name: MnfdTempSensorCktTFTKO
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
Bundle Name: MnfdTempSensorFA
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
Bundle Name: MnfdTempSensorTFTKO
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
Bundle Name: ModuleOffTime_FA
P2610
Bundle Name: no validity name is assigned to this fault bundle
Bundle Name: OAT_AmbientFilteredFA
ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor_FA, IAT_SensorFA, ECT_Sensor_DefaultDetected, MAF_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: not applicable. All other cases: not applicable.
Bundle Name: OAT_AmbientSensorFA
ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: not applicable. All other cases: not applicable.
Bundle Name: OAT_EstAmbTemp_FA
Only EREV sealed fuel system, P0071, P0072, P0073, P0502, P0503, P0722, P0723
Bundle Name: OAT_PtEstFiltFA
ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor_FA, IAT_SensorFA, ECT_Sensor_DefaultDetected, MAF_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: VehicleSpeedSensor_FA, IAT_SensorFA, MAF_SensorFA. All other cases:

EngModeNotRunTmErr, VehicleSpeedSensor_FA, IAT_SensorFA, ECT_Sensor_DefaultDetected.
Bundle Name: OAT_PtEstRawFA
ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: IAT_SensorFA. All other cases: IAT_SensorFA, ECT_Sensor_DefaultDetected.
Bundle Name: PowertrainRelayFault
P1682
Bundle Name: PowertrainRelayStateOn_Error
P0685
Bundle Name: PowertrainRelayStateOn_FA
P0685
Bundle Name: PPS1_OutOfRange
P2122, P2123
Bundle Name: PPS1_OutOfRange_Composite
P2122, P2123, P06A3
Bundle Name: PPS2_OutOfRange
P2127, P2128
Bundle Name: PPS2_OutOfRange_Composite
P2127, P2128, P0697
Bundle Name: SCIAP_SensorCircuitFA
P012C, P012D
Bundle Name: SCIAP_SensorCircuitFP
P012C, P012D
Bundle Name: SCIAP_SensorFA
P012B, P012C, P012D
Bundle Name: SCIAP_SensorPerfFA
P012B
Bundle Name: SCIAP_SensorPerfTFTKO
P012B
Bundle Name: SCIAP_SensorTFTKO
P012B, P012C, P012D
Bundle Name: SuperchargerBypassValveFA
P2261
Bundle Name: TC_BoostPresSnsrCktFA
P0237, P0238
Bundle Name: TC_BoostPresSnsrFA
P0236, P0237, P0238
Bundle Name: TCM_EngSpdReqCkt
P150C

Bundle Name: THMR_AHV_FA
P2681, P26A3, P26A6, P26A7, P26A9
Bundle Name: THMR_AWP_AuxPumpFA
B2920, B2923, B2922
Bundle Name: THMR_ECT_Sensor_Ckt_FA
P0116, P0117, P0118, P00B6
Bundle Name: THMR_Insuff_Flow_FA
P00B7
Bundle Name: THMR_RCT_Sensor_Ckt_FA
P00B3, P00B4
Bundle Name: THMR_SWP_Control_FA
P261D, P261A, P261C
Bundle Name: THMR_Therm_Control_FA
P0597, P0598, P0599
Bundle Name: ThrotTempSensorFA
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
Bundle Name: ThrotTempSensorTFTKO
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
Bundle Name: ThrottlePositionSnrPerfFA
P0121
Bundle Name: ThrottlePositionSnrPerfTFTKO
P0121
Bundle Name: TIAP_SensorPerfFA
P0236
Bundle Name: TPS_FA
P0122, P0123, P0222, P0223, P2135
Bundle Name: TPS_FaultPending
P0122, P0123, P0222, P0223, P2135
Bundle Name: TPS_Performance_FA
P0068, P0121, P1104, P2100, P2101, P2102, P2103
Bundle Name: TPS_Performance_TFTKO
P0068, P0121, P1104, P2100, P2101, P2102, P2103
Bundle Name: TPS_TFTKO
P0122, P0123, P0222, P0223, P2135
Bundle Name: TPS_ThrottleAuthorityDefaulted
P0068, P0122, P0123, P0222, P0223, P16F3, P1104, P2100, P2101, P2102, P2103, P2135

Bundle Name: TPS1_OutOfRange_Composite
P0122, P0123, P06A3
Bundle Name: TPS2_OutOfRange_Composite
P0222, P0223, P06A3
Bundle Name: Trans Output Rotations Rolling Count Validity
Bundle Name: Transfer Pump is Commanded On
Fuel Volume in Primary Fuel Tank < KeFLVC_V_PriFuelTankXferPmpEnbl (see supporting table for numeric value) liters AND Fuel Volume in Secondary Fuel Tank ≥ KeFLVC_V_SecFuelTankXferPmpEnbl (see supporting table for numeric value) liters AND Transfer Pump on Time < TransferPumpOnTimeLimit (see supporting table for numeric value) AND Transfer Pump had been Off for at least KeFLVC_t_XferFuelPmpMinOffTm (see supporting table for numeric value) seconds AND Evap Diagnostic (Purge Valve Leak Test, Large Leak Test, and Waiting for Purge) is not running AND Engine Running
Bundle Name: Transmission Actual Gear Validity
Bundle Name: Transmission Engaged State Validity
Bundle Name: Transmission Estimated Gear Validity
Bundle Name: Transmission Gear Ratio Validity
Bundle Name: Transmission Gear Selector Position Validity
Bundle Name: Transmission Oil Temperature Validity
Bundle Name: Transmission Output Shaft Angular Velocity Validity
Bundle Name: Transmission Overall Actual Torque Ratio Validity
Bundle Name: Transmission Overall Estimated Torque Ratio Validity
Bundle Name: Transmission Shift Lever Position Validity
Bundle Name: Transmission Turbine Angular Velocity Validity
Bundle Name: TransmissionEngagedState_FA
MYD/MYC/MYB:, P182E, P1915
Bundle Name: TransmissionGearDefaulted
MYD/MYC/MYB:, P182E, P1915
Bundle Name: VehicleSpeedSensor_FA
P0502, P0503, P0722, P0723

Bundle Name: VehicleSpeedSensorError
P0502, P0503, P0722, P0723
Bundle Name: VentCircuit_FA
P0449, P0498, P0499
Bundle Name: VICM_WakeupDiag_FA
P06E4
Bundle Name: VICM_WakeupDiag_TFTKO
P06E4

LD OBD Gasoline Monitoring Requirements Checklist											
Component/System	MONITORING REQUIREMENTS: List DTC of monitor that detects the following failure malfunction:										
Catalyst	(e)(1.2.2)										
	Conversion Efficiency										
	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Heated Catalyst	(e)(2.2)										
	Heating Performance										
	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Misfire	(e)(3.2.1)	(e)(3.2.2)	(e)(3.2.2)								
	Catalyst damage misfire	FTP level misfire - First 1000 revs	FTP level misfire - 4 x 1000 revs								
	P0300	P0300	P0300	NA	NA	NA	NA	NA	NA	NA	NA
Evaporative System	(e)(4.2.2)(A)	(e)(4.2.2)(B)	(e)(4.2.2)(C)	(e)(4.2.5)							
	No purge flow	0.040 inch leak	0.020 inch leak	0.090 inch leak in lieu of 0.040 inch							
	P0455	P0442	P0442	P0455	NA	NA	NA	NA	NA	NA	NA
Secondary Air	(e)(5.2.3)	(e)(5.2.4)									
	Insufficient flow threshold	Insufficient flow functional in lieu of threshold									
	P0411	P0411	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fuel System	(e)(6.2.1)(A)	(e)(6.2.1)(B)	(e)(6.2.1)(C)	(e)(6.2.2)	(e)(6.2.3)	(e)(6.2.4)					
	FTP emission threshold	Secondary fuel trim FTP emission threshold	Air-fuel ratio cylinder imbalance	Adaptive limits reached	Secondary fuel trim adaptive limits	Fails to enter closed loop					
	P0171, P0172, P0174, P0175	P2096, P2097, P2098, P2099	P219A, P219B	P0171, P0172, P0174, P0175	P2096, P2097, P2098, P2099	NA	NA	NA	NA	NA	NA
Upstream O2/Exhaust Gas Sensor Monitoring	(e)(7.2.1)(A)	(e)(7.2.1)(A)	(e)(7.2.1)(B)	(e)(7.2.1)(B)	(e)(7.2.1)(B)	(e)(7.2.1)(B)	(e)(7.2.1)(B)	(e)(7.2.1)(C)	(e)(7.2.1)(D)	(e)(7.2.3)(A)	(e)(7.2.3)(B)
	FTP emission threshold-slow response	FTP emission threshold-other characteristic	open circuit	out-of-range high	shorted high	out-of-range low	shorted low	Feedback: fails to enter, defaults out	Sufficient for other diagnostics	Heater Performance	Heater Circuit Continuity
	P0133, P0153	P015A, P015B, P015C	P0134, P0154	P0132, P0152	P0132, P0152	P0131, P0151	P0131, P0151	NA	P0131, P0151, P0132, P0152, P0134, P0154, P0133, P0153, P015A, P015B, P015C	P0053, P0059, P0135, P0155	P0030, P0050
Downstream O2/Exhaust Gas Sensor Monitoring	(e)(7.2.2)(A)	(e)(7.2.2)(B)	(e)(7.2.2)(D)	(e)(7.2.2)(B)	(e)(7.2.2)(D)	(e)(7.2.2)(B)	(e)(7.2.2)(C)	(e)(7.2.3)(A)	(e)(7.2.3)(B)	(d)(2.2.3) & (e)(6.2.4)	
	Emissions threshold	open circuit	out-of-range high	shorted high	out-of-range low	shorted low	Sufficient for other diagnostics	Heater Performance	Heater Circuit Continuity	Feedback: fails to enter, defaults out	
	P013A, P013B, P013C, P013D, P013E, P013F, P014A, P014B	P0140, P0160	P2271, P2273	P0138, P0158	P2270, P2272	P0137, P0157	P013A, P013B, P013C, P013D, P013E, P013F, P014A, P014B, P2270, P2271, P2272, P2273	P0054, P0060, P0141, P0161	P0036, P0056	P0054, P0060, P0137, P0157, P0138, P0158, P0140, P0160, P0141, P0161, P013A, P013B, P013C, P013D, P013E, P013F, P014A, P014B, P2270, P2271,	NA

12 OBDG05B Engine Diagnostics

MAIN SECTION
1 OF 2 SECTIONS

										P2272, P2273	
EGR	(e)(8.2.1) Low Flow Threshold	(e)(8.2.1) High Flow Threshold	(e)(8.2.2) Low Flow Functional in lieu of Threshold	(e)(8.2.2) High Flow Functional in lieu of Threshold							
	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Crankcase Ventilation	(e)(9.2.2) Disconnection										
	P0106, P0171, P0174, P0300	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Engine Cooling System	(e)(10.2.1) Time to reach threshold temp	(e)(10.2.2)(A) open circuit	(e)(10.2.2)(A) out-of-range high	(e)(10.2.2)(A) shorted high	(e)(10.2.2)(A) out-of-range low	(e)(10.2.2)(A) shorted low	(e)(10.2.2)(B) Time to reach closed loop	(e)(10.2.2)(C) Stuck below the highest minimum enable temp	(e)(10.2.2)(D) Stuck above the lowest maximum enable temp		
	P0128	P0118, P0119	P0118	P0118	P0117	P0117	NA	P0128	P0116	NA	NA
Cold Start Strategy	(e)(11.2.1)(A) Threshold monitor	(e)(11.2.1)(B) Functional monitor in lieu of threshold	(e)(11.2.2)(A) Single element functional fail	(e)(11.2.2)(B) Threshold monitor							
	P1400	P1400	P1400, P050D	P1400	NA	NA	NA	NA	NA	NA	NA
VVT System	(e)(13.2.1) Target error threshold monitor	(e)(13.2.2) Slow Response threshold monitor	(e)(13.2.3) Target error or slow response functional monitor in lieu of threshold								
	P0011, P0014, P0021, P0024	P0011, P0014, P0021, P0024	P0011, P0014, P0021, P0024	NA	NA	NA	NA	NA	NA	NA	NA
Direct Ozone Reduction (DOR) System	(e)(14.2.1) Functional monitor for <50% std credit DOR systems	(e)(14.2.2) Threshold monitor for >50% std credit DOR systems									
	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA

LD OBD Gasoline Monitoring Requirements Checklist

List DTC of monitor used that detects the following failure mode:

Monitor/System	Out-of-range Low	Circuit Low	Out-of-range High	Circuit High	Open Circuit	Rationality Low	Rationality High	Other Rationality	Functional #1	Functional #2	Other Functional
AC Refrigerant Pressure Sensor A	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Barometric Pressure	P2228	P2228	P2229	P2229	P2228	P2227	P2227	P2230	NA	NA	NA
Boost Control (Turbo)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Brake Booster Pressure	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Cam Position Bank 1 Exhaust	P0365	P0365	P0365	P0365	P0365	P0366	P0366	P0017	NA	NA	NA
Cam Position Bank 1 Intake	P0340	P0340	P0340	P0340	P0340	P0341	P0341	P0016	NA	NA	NA
Cam Position Bank 2 Exhaust	P0390	P0390	P0390	P0390	P0390	P0391	P0391	P0019	NA	NA	NA
Cam Position Bank 2 Intake	P0345	P0345	P0345	P0345	P0345	P0346	P0346	P0018	NA	NA	NA
Cam Position Output Signal	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Canister Purge Solenoid	NA	NA	NA	NA	P0443	NA	NA	NA	P0496	NA	P0443
Canister Vent Solenoid	NA	NA	NA	NA	P0449	NA	NA	NA	P0446	NA	P0449
Clutch Pedal Position	P0807	P0807	P0808	P0808	P0807	P0806	NA	P080A	NA	NA	NA
Crank Position	P0335	P0335	P0335	P0335	P0335	P0336	P0336	NA	NA	NA	NA
Crank Position Output Signal	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
ELCP Pressure Sensor	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
ELCP Switching Valve	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
ELCP Vacuum Pump	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Engine Oil Pressure	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Engine Oil Temperature	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
EST A	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	P0351
EST B	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	P0352
EST C	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	P0353
EST D	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	P0354
EST E	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	P0355
EST F	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	P0356
EST G	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
EST H	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fan Control #1	P0691	P0691	P0692	P0692	P0480	NA	NA	NA	NA	NA	NA
Fan Control #2	P0693	P0693	P0694	P0694	P0481	NA	NA	NA	NA	NA	NA
Fan Control #3	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fuel Composition	P0178	P0178	P0179	P0179	P0178	NA	NA	P2269	NA	NA	NA
Fuel Economy Mode Switch	P159F	P159F	P15A0	P15A0	NA	NA	NA	P15A1	NA	NA	NA
Fuel Level	P0462	P0462	P0463	P0463	P0463	P0461	P0461	P0464	NA	NA	NA
Fuel Level #2	P2067	P2067	P2068	P2068	P2068	P2066	P2066	P0464	NA	NA	NA

12 OBDG05B Engine Diagnostics

MAIN SECTION
1 OF 2 SECTIONS

Fuel Pump #2	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fuel Pump Control	P0628	P0628	P0629	P0629	P0627	NA	NA	NA	NA	NA	NA
Fuel Tank Vapor Pressure	P0452	P0452	P0453	P0453	P0452	P0451	P0451	P0454	NA	NA	NA
Humidity	P11C2	P11C2	P11C3	P11C3	P11C2	NA	NA	P11C4	NA	NA	NA
Hybrid Control Torque Request Circuit	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Ignition Off Timer	NA	NA	NA	NA	NA	NA	NA	NA	P2610	NA	NA
Ignition Switch Accessory Position	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Intake Air Temperature	P0112	P0112	P0113	P0113	P0113	P0111	P0111	P0114, P2199	NA	NA	NA
Intake Air Temperature 2	P0097	P0097	P0098	P0098	P0097	P0096	P0096	P0099, P2199	NA	NA	NA
Intake Air Temperature 3	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Intake Manifold Runner Control	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Intake Manifold Tuning Valve Control	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Intake Manifold Tuning Valve Position	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Knock Sensor-Flat	P0327	P0327	P0328	P0328	P0325	NA	NA	NA	NA	NA	NA
Knock Sensor-Flat #2	P0332	P0332	P0333	P0333	P0330	NA	NA	NA	NA	NA	NA
Malfunction Indicator Lamp	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	P0650
Manifold Absolute Pressure	P0107	P0107	P0108	P0108	P0107	P0106	P0106	P1101	NA	NA	NA
Mass Air Flow	P0102	P0102	P0103	P0102	P0102	P0101	P0101	P1101	NA	NA	NA
Mass Air Flow 2	NA	NA	NA	NA	NA	NA	NA	P1101	NA	NA	NA
Mass Air Flow Supply Voltage Control	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Outside Air Temperature	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Powertrain Relay Control	NA	NA	NA	NA	NA	NA	NA	NA	P0690	NA	P0685
Powertrain Relay Feedback	NA	NA	NA	NA	NA	NA	NA	P0690	NA	NA	NA
Reverse Inhibit	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Secondary AIR Pressure Sensor Bank1	P2432	P2432	P2433	P2433	P2432	P2431	P2431	P2430	NA	NA	NA
Secondary AIR Pressure Sensor Bank2	P2437	P2437	P2438	P2438	P2437	P2436	P2436	P2435	NA	NA	NA
Secondary AIR Pump Command Bank1	NA	NA	NA	NA	NA	NA	NA	NA	P2440	NA	P0412
Secondary AIR Pump Command Bank2	NA	NA	NA	NA	NA	NA	NA	NA	P2440	NA	NA
Secondary AIR Pump Solenoid Relay	NA	NA	NA	NA	NA	NA	NA	NA	P2444	NA	P0418
SIDI Ignition Module Supply Voltage Group 1	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	P135A
SIDI Ignition Module	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	P135R

12 OBDG05B Engine Diagnostics

MAIN SECTION
1 OF 2 SECTIONS

Supply Voltage Group 2												
Skip Shift Solenoid	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Supercharger Boost	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Supercharger Inlet Pressure	NA	NA	NA	NA	NA	NA	NA	P1101	NA	NA	NA	NA
Supercharger Intercooler	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Traction Control Torque Request Circuit	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Transmission Control Torque Request Circuit A	NA	NA	NA	NA	NA	NA	NA	P2544	NA	NA	NA	NA
Turbocharger Boost Pressure	NA	NA	NA	NA	NA	NA	NA	P1101	NA	NA	NA	NA
Turbocharger Intercooler	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Twin Turbo Control	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Wastegate Control (Turbo)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Economy Mode Circuit Low	P159F	This DTC will detect a fuel saver switch input that is too low out of range.	Fuel Saver Switch % of 5V range The normal operating range of the fuel saver mode switch is: Switch depressed % of 5V range: Switch released % of 5V range:	< 29.0 % < 66.8 % ≥ 29.0 % < 88.8 % ≥ 72.8 %			200 failures out of 250 samples 25 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Economy Mode Circuit High	P15A0	This DTC will detect a fuel saver switch input that is too high out of range.	Fuel Saver Switch % of 5V range The normal operating range of the fuel saver mode switch is: Switch depressed % of 5V range: Switch released % of 5V range:	≥ 88.8 % < 66.8 % ≥ 29.0 % < 88.8 % ≥ 72.8 %			200 failures out of 250 samples 25 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Economy Mode Switch Performance	P15A1	This DTC will detect a fuel saver switch input that is in an indeterminate range.	Fuel Saver Switch % of 5V is in an indeterminate range: The normal operating range of the fuel saver mode switch is: Switch depressed % of 5V range: Switch released % of 5V range:	$66.8\% \leq \% \text{ of } 5 \text{ volts} < 72.8\%$ $< 66.8\%$ $\geq 29.0\%$ $< 88.8\%$ $\geq 72.8\%$			200 failures out of 250 samples 25 ms / sample	Type B, 2 Trips