

## 13 OBDG02A FSCM Diagnostics

### Section 1 : C101\_Common LUV -WA7, LUW

Contains information that is common to all C101 ERFS applications within 13OBDG2A with RPO LUV 1.4L turbocharged I-4 engine  
with engine RPOs                    1) LUV 1.4L turbocharged I-4, 2) LUW 1.8L I-4  
with VPPCs                            1) D1SC, 2) G1SC, 3) G1UB, 4) G1UC

### Section 2: C101\_LUV &WA7

Contains information that is common to all C101 ERFS applications within 13OBDG2A in combination with RPO WA7 Aero Performance Package  
with engine RPOs                    1) LUV 1.4L turbocharged I-4  
with VPPCs                            1) D1SC

13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Fuel Rail Pressure (FRP) Sensor Performance (rationality)	P018B	This DTC detects a fuel pressure sensor response stuck within the normal operating range	Absolute value of fuel pressure change as sensed during intrusive test.	<= 30 kPa	1. FRP Circuit Low DTC (P018C) 2. FRP Circuit High DTC (P018D) 3. FuelPump Circuit Low DTC (P0231) 4. FuelPump Circuit High DTC (P0232) 5. FuelPump Circuit Open DTC (P023F) 6. Reference Voltage DTC (P0641) 7. Fuel Pump Control Module Driver Over-temperature DTC (P064A)	Not active Not active Not active Not active Not active Not active	<p><u>Frequency:</u> Continuous; 12.5 ms loop. 60 seconds between intrusive tests that pass</p> <p>Intrusive test requested if fuel system is clamped for &gt;= 5 seconds or fuel pressure error variance &lt;= typically (0.3 to 0.6) (calculated over a 2.5sec period); otherwise report pass</p> <p>Duration of intrusive test is fueling related (5 to 12 seconds).</p> <p>Intrusive test is run when fuel flow is below Max allowed fuel flow rate (Typical values in the range of 11 to 50 g/s)</p>	DTC Type A 1 trip

13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					8. Control Module Internal Performance DTC (P0606)  9. Engine run time 10. Emissions fuel level (PPEI \$3FB) 11. Fuel pump control 12. Fuel pump control state 13. Engine fuel flow  14. ECM fuel control system failure (PPEI \$1ED)	Not active  >=5 seconds Not low  Enabled Normal or FRP rationality control  > 0.047 g/s  Not failed		
Fuel Rail Pressure (FRP) Sensor Circuit Low Voltage	P018C	This DTC detects if the fuel pressure sensor circuit is shorted low	FRP sensor voltage	< 0.14 V	Ignition	Run or Crank	72 failures out of 80 samples  1 sample/12.5 ms	DTC Type A 1 trip
Fuel Rail Pressure (FRP) Sensor Circuit High Voltage	P018D	This DTC detects if the fuel pressure sensor circuit is shorted high	FRP sensor voltage	> 4.86 V	Ignition	Run or Crank	72 failures out of 80 samples  1 sample/12.5 ms	DTC Type A 1 trip
Fuel Pump Control Circuit Low Voltage	P0231	This DTC detects if the fuel pump control circuit is shorted to low	Fuel Pump Current	> 14.48A	Ignition OR HS Comm OR Fuel Pump Control	Run or Crank  enabled  enabled	72 test failures in 80 test samples if Fuel Pump Current <100A  1 sample/12.5 ms	DTC Type A 1 trip

13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					AND Ignition Run/Crank Voltage	9V < voltage < 32V		
Fuel Pump Control Circuit High Voltage	P0232	This DTC detects if the fuel pump control circuit is shorted to high	Voltage measured at fuel pump circuit	> 3.86 V	Commanded fuel pump output  Fuel pump control enable  Time that above conditions are met	0% duty cycle (off)  False  >=4.0 seconds	36 test failures in 40 test samples; 1 sample/12.5ms  Pass/Fail determination made only once per trip	DTC Type A 1 trip
Fuel Pump Control Circuit (Open)	P023F	This DTC detects if the fuel pump control circuit is open	Fuel Pump Current  AND Fuel Pump Duty Cycle	<=0.5A  □  >20%	Ignition OR HS Comm  OR Fuel Pump Control AND Ignition Run/Crank Voltage	Run or Crank  enabled  enabled  9V < voltage < 32V	72 test failures in 80 test samples; 1 sample/12.5ms	DTC Type A 1 trip
Fuel System Control Module Enable Control Circuit	P025A	This DTC detects if there is a fault in the fuel pump control enable circuit	PPEI (PPEI (Powertrain Platform Electrical Interface) Fuel System Request (\$1ED)	≠ Fuel Pump Control Module Enable Control Circuit	Ignition AND PPEI Fuel System Request (\$1ED)	Run or Crank  valid	72 failures out of 80 samples  1 sample/12.5 ms	DTC Type A 1 trip
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if any software or calibration check sum is incorrect	Calculated Checksum (CRC16)	≠ stored checksum for any of the parts (boot, software, application calibration, system calibration)	Ignition	Run or Crank	1 failure if it occurs during the first ROM test of the ignition cycle, otherwise 5 failures	DTC Type A 1 trip

13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					OR  HS Comm OR Fuel Pump Control	enabled  enabled	Frequency: Runs continuously in the background	
Control Module Not Programmed	P0602	Indicates that the FSCM needs to be programmed	This DTC is set via calibration, when  KeMEMD_b_NoStartC al	= TRUE	Ignition OR HS Comm OR Fuel Pump Control	Run or Crank  enabled  enabled	Runs once at power up	DTC Type A 1 trip
Control Module Long Term Memory Reset	P0603	Non-volatile memory checksum error at controller power-up	Checksum at power- up	≠ checksum at power-down	Ignition OR HS Comm OR Fuel Pump Control	Run or Crank  enabled  enabled	1 failure  Frequency: Once at power-up	DTC Type A 1 trip
Control Module Random Access Memory (RAM)	P0604	Indicates that control module is unable to correctly write and read data to and from RAM	Data read	≠ Data written	Ignition OR HS Comm  OR Fuel Pump Control	Run or Crank  enabled  enabled	1 failure if it occurs during the first RAM test of the ignition cycle, otherwise 5 failures  Frequency: Runs continuously in the background.	DTC Type A 1 trip

13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Control Module Internal Performance  1. Main Processor Configuration Register Test  2. Processor clock test  3. External watchdog test	P0606	This DTC indicates the FSCM has detected an internal processor fault or external watchdog fault (PID 2032 discriminates the source of the fault )	1. For all I/O configuration register faults:  •Register contents  2. For Processor Clock Fault: •EE latch flag in EEPROM. OR  • RAM latch flag.  3. For External Watchdog Fault: • Software control of fuel pump driver	  Incorrect value.  0x5A5A  0x5A  Control Lost	  Ignition OR HS Comm OR Fuel Pump Control 1. For all I/O configuration register faults: •KeMEMD_b_ProcFitCfgR egEnbl  2. For Processor Clock Fault: •KeMEMD_b_ProcFitCLK DiagEnbl 3. For External Watchdog Fault: •KeFRPD_b_FPExtWDog DiagEnbl  3. For External Watchdog Fault: •Control Module ROM(P0601)  3. For External Watchdog Fault: •Control Module RAM(P0604)	  Run or Crank  enabled  enabled  TRUE  TRUE  TRUE  not active  not active	Tests 1 and 2 1 failure Frequency: Continuously (12.5ms)  Test 3 3 failures out of 15 samples  1 sample/12.5 ms	DTC Type A 1 trip
Control Module Long Term Memory (EEPROM) Performance	P062F	Indicates that the NVM Error flag has not been cleared	Last EEPROM write	Did not complete	  Ignition OR	  Run or Crank	1 test failure Once on controller power-up	DTC Type A 1 trip

13 OBDG02A FSCM Diagnostics

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					HS Comm OR Fuel Pump Control	enabled  enabled		
5Volt Reference Circuit (Short High/Low/Out of Range)	P0641	Detects continuous short or out of range on the #1 5V sensor reference circuit	Reference voltage AND Output OR Reference voltage AND Output OR Reference voltage AND Output	>= 0.5V inactive  >= 5.5V active  <= 4.5V active	Ignition	Run or Crank	15 failures out of 20 samples 1 sample/12.5 ms	DTC Type A 1 trip
			OR Reference voltage	> 105% nominal (i.e., 5.25V) OR <95% nominal (i.e., 4.75V)				
Fuel Pump Control Module - Driver Over-temperature 1	P064A	This DTC detects if an internal fuel pump driver overtemperature condition exists under normal operating conditions	Pump Driver Temp	> 150C	Ignition OR HS Comm OR Fuel Pump Control  KeFRPD_b_FPOverTemp DiagEnbl	Run or Crank  Enabled  Enabled  TRUE	3 failures out of 15 samples 1 sample/12.5 ms	DTC Type B 2 trips
					Ignition Run/Crank	9V<voltage<32V		

13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Ignition 1 Switch Circuit Low Voltage	P2534	This DTC detects if the Ignition1 Switch circuit is shorted to low or open	Ignition 1 voltage	<= 6 V	Engine	Running	180 failures out of 200 samples  1 sample/25.0 ms	DTC Type A 1 trip
Fuel Pump Flow Performance (rationality)	P2635	This DTC detects degradation in the performance of the SIDI electronic return- less fuel system	Filtered fuel rail pressure error	<= Low Threshold ( continuously calculated function of desired fuel rail pressure and actual fuel flow rate )  OR  >= High Threshold ( continously calculated function of desired fuel rail pressure and actual fuel flow rate)  <b>( See Supporting                      Tables tab and                      Supporting                      Calculations tab)</b>	1. FRP Circuit Low DTC (P018C)	Not active	Filtered fuel rail pressure error Time Constant = 12.5 seconds  Frequency: Continuous 12.5 ms loop	DTC Type B 2 trips
					2. FRP Circuit High DTC (P018D)	Not active		
					3. Fuel Rail Pressure Sensor Performance DTC (P018B)	Not active		



13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					4. FuelPump Circuit Low DTC (P0231)	Not active		
					5. FuelPump Circuit High DTC (P0232)	Not active		
					6. FuelPump Circuit Open DTC (P023F)	Not active		
					7. Reference Voltage DTC (P0641)	Not active		
					8. Fuel Pump Control Module Driver Over-temperature DTC's (P064A)	Not active		
					9. Control Module Internal Performance DTC (P0606)	Not active		
					10. An ECM fuel control system failure (PPEI \$1ED)	Not occurred		
					11. The Barometric pressure (PPEI \$4C1) signal	Valid (for absolute fuel pressure sensor)		
					12. Engine run time	>= 30 seconds		
					13. Emissions fuel level (PPEI \$3FB)	Not low		
					14. Fuel pump control	Enabled		
					15. Fuel pump control state	Normal		
					16. Battery Voltage	11V<=voltage=<32V		
					17. Fuel flow rate ( See Supporting Tables tab )	> 0.047 g/s <b>AND</b> <= Max allowed fuel flow rate as a function of desired rail pressure & Vbatt (Typical values in the range of 11 to 50 g/s)		

13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					18. Fuel Pressure Control System	Is not responding to an over-pressurization due to pressure build during DFCO or a decreasing desired pressure command.		
Control Module Communication Bus "A" Off	U0073	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off state	Bus Status	Off	Power mode	Run/Crank	5 failures out of 5 samples ( 5 seconds)	DTC Type B 2 trips
Lost Communication With ECM/PCM "A"	U0100	Detects that CAN serial data communication has been lost with the ECM	Message \$0C9	Undetected	1. Power mode  2. Ignition Run/Crank Voltage 3. U0073	Run/Crank  11V<voltage<32V  not active	12 failures out of 12 samples (12 seconds)	DTC Type B 2 trips

13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Fuel Rail Pressure (FRP) Sensor Performance (rationality)	P018B	This DTC detects a fuel pressure sensor response stuck within the normal operating range	Absolute value of fuel pressure change as sensed during intrusive test.	<= 30 kPa	1. FRP Circuit Low DTC (P018C) 2. FRP Circuit High DTC (P018D) 3. FuelPump Circuit Low DTC (P0231) 4. FuelPump Circuit High DTC (P0232) 5. FuelPump Circuit Open DTC (P023F) 6. Reference Voltage DTC (P0641) 7. Fuel Pump Control Module Driver Over-temperature DTC (P064A) 8. Control Module Internal Performance DTC (P0606) 9. Engine run time	Not active Not active Not active Not active Not active Not active Not active >=5 seconds	Frequency: Continuous; 12.5 ms loop. 60 seconds between intrusive tests that pass Intrusive test requested if fuel system is clamped for >= 5 seconds or fuel pressure error variance <= typically (0.3 to 0.6) (calculated over a 2.5sec period); otherwise report pass Duration of intrusive test is fueling related (5 to 12 seconds). Intrusive test is run when fuel flow is below Max allowed fuel flow rate (Typical values in the range of 11 to 50 g/s)	DTC Type A 1 trip

13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					10. Emissions fuel level (PPEI \$3FB) 11. Fuel pump control 12. Fuel pump control state 13. Engine fuel flow 14. ECM fuel control system failure (PPEI \$1ED)	Not low Enabled Normal or FRP rationality control > 0.047 g/s Not failed		
Fuel Rail Pressure (FRP) Sensor Circuit Low Voltage	P018C	This DTC detects if the fuel pressure sensor circuit is shorted low	FRP sensor voltage	< 0.14 V	Ignition	Run or Crank	72 failures out of 80 samples  1 sample/12.5 ms	DTC Type A 1 trip
Fuel Rail Pressure (FRP) Sensor Circuit High Voltage	P018D	This DTC detects if the fuel pressure sensor circuit is shorted high	FRP sensor voltage	> 4.86 V	Ignition	Run or Crank	72 failures out of 80 samples  1 sample/12.5 ms	DTC Type A 1 trip
Fuel Pump Control Circuit Low Voltage	P0231	This DTC detects if the fuel pump control circuit is shorted to low	Fuel Pump Current	> 14.48A	Ignition OR HS Comm OR Fuel Pump Control AND Ignition Run/Crank Voltage	Run or Crank  enabled  enabled  9V < voltage < 32V	72 test failures in 80 test samples if Fuel Pump Current <100A  1 sample/12.5 ms	DTC Type A 1 trip

13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Fuel Pump Control Circuit High Voltage	P0232	This DTC detects if the fuel pump control circuit is shorted to high	Voltage measured at fuel pump circuit	> 3.86 V	Commanded fuel pump output  Fuel pump control enable  Time that above conditions are met	0% duty cycle (off)  False  >=4.0 seconds	36 test failures in 40 test samples; 1 sample/12.5ms  Pass/Fail determination made only once per trip	DTC Type A 1 trip
Fuel Pump Control Circuit (Open)	P023F	This DTC detects if the fuel pump control circuit is open	Fuel Pump Current  AND Fuel Pump Duty Cycle	<=0.5A  □  >20%	Ignition OR HS Comm OR Fuel Pump Control AND Ignition Run/Crank Voltage	Run or Crank  enabled  enabled  9V < voltage < 32V	72 test failures in 80 test samples; 1 sample/12.5ms	DTC Type A 1 trip
Fuel System Control Module Enable Control Circuit	P025A	This DTC detects if there is a fault in the fuel pump control enable circuit	PPEI (PPEI (Powertrain Platform Electrical Interface) Fuel System Request (\$1ED)	≠ Fuel Pump Control Module Enable Control Circuit	Ignition AND PPEI Fuel System Request (\$1ED)	Run or Crank  valid	72 failures out of 80 samples  1 sample/12.5 ms	DTC Type A 1 trip

13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Mechanical Actuator Performance (Functionality)	P059F	Compare commanded shutter position to sensed position	Failure to achieve commanded position	Two (2) consecutive intrusive tests fail to achieve commanded position.  Intrusive tests are triggered immediately following any failure to achieve a commanded position.	1. Power mode  2. Shutter Control 3. Ignition Run/Crank Voltage	Run/Crank  Enabled 11V < voltage < 32V	Frequency: 1 sample after every shutter movement.  Intrusive test requested if shutter movement is commanded and position feedback differs after 19.5 seconds; otherwise report pass.  Duration of intrusive test is shutter movement related (40 to 120 seconds)	DTC Type B 2 trips
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if any software or calibration check sum is incorrect	Calculated Checksum (CRC16)	≠ stored checksum for any of the parts (boot, software, application calibration, system calibration)	Ignition OR  HS Comm OR Fuel Pump Control	Run or Crank  enabled enabled	1 failure if it occurs during the first ROM test of the ignition cycle, otherwise 5 failures  Frequency: Runs continuously in the background	DTC Type A 1 trip
Control Module Not Programmed	P0602	Indicates that the FSCM needs to be programmed	This DTC is set via calibration, when KeMEMD_b_NoStartCal	= TRUE	Ignition OR HS Comm OR Fuel Pump Control	Run or Crank  enabled enabled	Runs once at power up	DTC Type A 1 trip

13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Control Module Long Term Memory Reset	P0603	Non-volatile memory checksum error at controller power-up	Checksum at power-up	≠ checksum at power-down	Ignition OR HS Comm OR Fuel Pump Control	Run or Crank  enabled  enabled	1 failure  Frequency: Once at power-up	DTC Type A 1 trip
Control Module Random Access Memory (RAM)	P0604	Indicates that control module is unable to correctly write and read data to and from RAM	Data read	≠ Data written	Ignition OR HS Comm  OR Fuel Pump Control	Run or Crank  enabled  enabled	1 failure if it occurs during the first RAM test of the ignition cycle, otherwise 5 failures  Frequency: Runs continuously in the background.	DTC Type A 1 trip
Control Module Internal Performance  1. Main Processor Configuration Register Test  2. Processor clock test	P0606	This DTC indicates the FSCM has detected an internal processor fault or external watchdog fault (PID 2032 discriminates the source of the fault )	1. For all I/O configuration register faults:  •Register contents  2. For Processor Clock Fault: •EE latch flag in EEPROM. OR	Incorrect value.  0x5A5A	Ignition OR HS Comm OR Fuel Pump Control  1. For all I/O configuration register faults: •KeMEMD_b_ProcFitCfgRe gEnbl	Run or Crank  enabled  enabled  TRUE	Tests 1 and 2 1 failure Frequency: Continuously (12.5ms)  Test 3 3 failures out of 15 samples  1 sample/12.5 ms	DTC Type A 1 trip

13 OBDG02A FSCM Diagnostics

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
3. External watchdog test			<ul style="list-style-type: none"> <li>• RAM latch flag.</li> </ul> 3. For External Watchdog Fault: <ul style="list-style-type: none"> <li>• Software control of fuel pump driver</li> </ul>	0x5A  Control Lost	2. For Processor Clock Fault: <ul style="list-style-type: none"> <li>•KeMEMD_b_ProcFitCLKDiagEnbl</li> </ul> 3. For External Watchdog Fault: <ul style="list-style-type: none"> <li>•KeFRPD_b_FPExtWDogDiagEnbl</li> </ul> 3. For External Watchdog Fault: <ul style="list-style-type: none"> <li>•Control Module ROM(P0601)</li> </ul> 3. For External Watchdog Fault: <ul style="list-style-type: none"> <li>•Control Module RAM(P0604)</li> </ul>	TRUE  TRUE  not active  not active		
Control Module Long Term Memory (EEPROM) Performance	P062F	Indicates that the NVM Error flag has not been cleared	Last EEPROM write	Did not complete	Ignition OR HS Comm OR Fuel Pump Control	Run or Crank  enabled  enabled	1 test failure Once on controller power-up	DTC Type A 1 trip
5Volt Reference Circuit (Short High/Low/Out of Range)	P0641	Detects continuous short or out of range on the #1 5V sensor reference circuit	Reference voltage AND Output OR Reference voltage AND Output OR Reference voltage AND Output	>= 0.5V  inactive  >= 5.5V  active  <= 4.5V  active	Ignition	Run or Crank	15 failures out of 20 samples 1 sample/12.5 ms	DTC Type A 1 trip



13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
			OR Reference voltage □	> 105% nominal (i.e., 5.25V) OR <95% nominal (i.e., 4.75V)				
Fuel Pump Control Module - Driver Over-temperature 1	P064A	This DTC detects if an internal fuel pump driver overtemperature condition exists under normal operating conditions	Pump Driver Temp	> 150C	Ignition OR HS Comm OR Fuel Pump Control  KeFRPD_b_FPOverTempD iagEnbl  Ignition Run/Crank	Run or Crank  Enabled  Enabled  TRUE  9V<voltage<32V	3 failures out of 15 samples  1 sample/12.5 ms	DTC Type B 2 trips
Ignition 1 Switch Circuit Low Voltage	P2534	This DTC detects if the Ignition1 Switch circuit is shorted to low or open	Ignition 1 voltage	<= 6 V	Engine	Running	180 failures out of 200 samples  1 sample/25.0 ms	DTC Type A 1 trip

13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Fuel Pump Flow Performance (rationality)	P2635	This DTC detects degradation in the performance of the SIDI electronic return-less fuel system	Filtered fuel rail pressure error	<= Low Threshold ( continuously calculated function of desired fuel rail pressure and actual fuel flow rate )  OR  >= High Threshold ( continuously calculated function of desired fuel rail pressure and actual fuel flow rate)  <b>( See Supporting                      Tables tab and                      Supporting                      Calculations tab)</b>	1. FRP Circuit Low DTC (P018C)	Not active	Filtered fuel rail pressure error Time Constant = 12.5 seconds  Frequency: Continuous 12.5 ms loop	DTC Type B 2 trips
					2. FRP Circuit High DTC (P018D)	Not active		
					3. Fuel Rail Pressure Sensor Performance DTC (P018B)	Not active		
					4. FuelPump Circuit Low DTC (P0231)	Not active		
					5. FuelPump Circuit High DTC (P0232)	Not active		
					6. FuelPump Circuit Open DTC (P023F)	Not active		
					7. Reference Voltage DTC (P0641)	Not active		
					8. Fuel Pump Control Module Driver Over- temperature DTC's (P064A)	Not active		
					9. Control Module Internal Performance DTC (P0606)	Not active		

13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					10. An ECM fuel control system failure (PPEI \$1ED)	Not occurred		
					11. The Barometric pressure (PPEI \$4C1) signal	Valid (for absolute fuel pressure sensor)		
					12. Engine run time	>= 30 seconds		
					13. Emissions fuel level (PPEI \$3FB)	Not low		
					14. Fuel pump control	Enabled		
					15. Fuel pump control state	Normal		
					16. Battery Voltage	11V<=voltage=<32V		
					17. Fuel flow rate ( See Supporting Tables tab )	> 0.047 g/s <b>AND</b> <= Max allowed fuel flow rate as a function of desired rail pressure & Vbatt (Typical values in the range of 11 to 50 g/s)		
					18. Fuel Pressure Control System	Is not responding to an over-pressurization due to pressure build during DFCO or a decreasing desired pressure command.		
Control Module Communication Bus "A" Off	U0073	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off state	Bus Status	Off	Power mode	Run/Crank	5 failures out of 5 samples ( 5 seconds)	DTC Type B 2 trips
Lost Communication With ECM/PCM "A"	U0100	Detects that CAN serial data communication has been lost with the ECM	Message \$0C9	Undetected	1. Power mode	Run/Crank	12 failures out of 12 samples (12 seconds)	DTC Type B 2 trips

13 OBDG02A FSCM Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					2. Ignition Run/Crank Voltage 3. U0073	11V<voltage<32V  not active		
Lost Communication With "Actuator"	U0284	Detects loss of communication condition has occurred between ECU and device Active Grill Air Shutter "A" actuator	PWM Message	Undetected	1. Power mode   2. Ignition Run/Crank Voltage	Run/Crank   11V < voltage < 32V	Frequency: 100ms  150 failures out of 167 samples	DTC Type B 2 trips

# 13 OBDG02A FSCM Diagnostics

## Supporting Tables - LUV

X-axis= Desired Fuel Pressure ( kiloPascals )  
 Y-axis= Battery voltage ( volts )

	200	250	300	350	400	450	500	550	600
4.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	8.438	6.016
6	10.87	10.87	10.87	10.87	10.87	10.87	10.87	8.438	6.016
7.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	8.438	6.016
9	10.87	10.87	10.87	10.87	10.87	10.87	10.87	8.438	6.016
10.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	8.438	6.016
12	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
13.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
15	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
16.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
18	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
19.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
21	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
22.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
24	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
25.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
27	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87
28.5	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87	10.87

### P2635 - Fuel Injector curve (grams/second)

X-axis= Fuel Pressure ( kiloPascals )

128	148	168	188	208	228	248	268	288	308	328	348	368	388	408	428	448
3.163	3.255	3.347	3.439	3.531	3.622	3.714	3.806	3.898	3.99	4.082	4.174	4.266	4.358	4.449	4.542	4.633
468	488	508	528	548	568	588	608	628	648	668	688	708	728	748	768	
4.725	4.817	4.909	5.001	5.093	5.185	5.277	5.368	5.46	5.552	5.644	5.736	5.828	5.92	6.012	6.104	

### P2635 - Maximum Engine Intake Boost curve (kiloPascals)

X-axis= barometric pressure ( kiloPascals )

40	50	60	70	80	90	100	110	120
125	155	185	205	215	215	215	215	215

# 13 OBDG02A FSCM Diagnostics

## Supporting Tables - LUV

### P2635 - Minimum Fuel Injector Pulse Width curve ( seconds)

X-axis= engine speed ( revolutions / minute)

0	512	1024	1536	2048	2560	3072	3584	4096	4608	5120	5632	6144	6656	7168	7680	8192
0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25

### 13 OBDG02A FSCM Diagnostics

#### Supporting Tables - LUW

X-axis= Desired Fuel Pressure ( kiloPascals )  
 Y-axis= Battery voltage ( volts )

	200	250	300	350	400	450	500	550	600
4.5	11.7	11.7	11.7	11.7	11.7	11.66	8.758	6.078	3.602
6	11.7	11.7	11.7	11.7	11.7	11.66	8.758	6.078	3.602
7.5	11.7	11.7	11.7	11.7	11.7	11.66	8.758	6.078	3.602
9	11.7	11.7	11.7	11.7	11.7	11.66	8.758	6.078	3.602
10.5	11.7	11.7	11.7	11.7	11.7	11.66	8.758	6.078	3.602
12	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	9.063
13.5	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
15	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
16.5	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
18	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
19.5	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
21	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
22.5	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
24	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
25.5	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
27	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7
28.5	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7	11.7

#### P2635 - Fuel Injector Flow curve ( grams / second )

X-axis= Fuel Pressure ( kiloPascals )

128	148	168	188	208	228	248	268	288	308	328	348	368	388	408	428	448
2.087	2.201	2.316	2.43	2.544	2.658	2.772	2.886	3	3.115	3.229	3.343	3.457	3.571	3.637	3.719	3.802

468	488	508	528	548	568	588	608	628	648	668	688	708	728	748	768
3.852	3.953	4.087	4.189	4.291	4.393	4.495	4.597	4.699	4.801	4.903	5.006	5.108	5.21	5.312	5.414

#### P2635 - Minimum Fuel Injector Pulse Width curve ( seconds )

X-axis= engine speed ( revolutions / minute )

0	512	1024	1536	2048	2560	3072	3584	4096	4608	5120	5632	6144	6656	7168	7680	8192
0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797	0.797

## Supporting Calculations

**Calculation of Fault Thresholds:**

**Givens:** Measured values observed at a typical operating point for an 80mph roadload --  
 Engine rpm = 1900 rev/min, Instantaneous Fuel Flow = 1.265 g/s, Fuel Line Pressure = 304 kPa (gage)

**Example :** Pressure Error Fault Threshold Low at chosen operating point:

Min Injector Flow [g/s] = Minimum Injector Pulse Width [ms] \* Injector Slope[mg/ms/inj] \* Number of Fuel Injectors / 2 [inj/rev] \* Engine Speed [rev/min] \* 1/60 [min/s] \* 1/1000 [g/mg]

Min Injector Flow =  $0.25 * 1.565918 * 4 / 2 * 1900 / 60 / 1000 = 0.0247 \text{ g/s}$

Max Overfueling Error [] = (Instantaneous Injector Flow [g/s] / Min Injector Flow [g/s])  
 $= 1.265 \text{ (g/s)} / 0.0247 \text{ (g/s)}$   
 $= 51.2147 / 100 \text{ (decimal conversion)}$   
 $= 0.512147 \text{ ( 51 \%)}$

The overfueling fuel flow error is limited to the range of between 105% and 115% overfueling depending on the actual fuel flow. The MaxOverfuelingError calculated above is **outside the scaling range**; therefore, the overperformance fault threshold for this operating point is then calculated using the limited value (105% or 1.05) as follows:

Pressure Error Fault Threshold Low[kPa]  
 $= \text{Injector Pressure Drop [kPa]} * (1 - (\text{Max Overfueling Error})^2)$   
 $= 304 * (1 - (1.05 * 1.05))$   
 $= \mathbf{-31.16 \text{ kPa}}$

**Example :** Pressure Error Fault Threshold High at same given operating point as the above example:

Max Injector Flow[g/s] = Injector Slope[mg/ms/inj] \* Number of Fuel Injectors [inj] \* 1/1000 [g/mg] \* 1000 [ms/s]

Max Injector Flow[g/s] =  $1.565918 * 4 * 1/1000 * 1000 = 6.26 \text{ g/s}$

Max Underfueling Error [] = (Instantaneous Injector Flow [g/s] / Max Injector Flow [g/s])  
 $= 1.265 \text{ (g/s)} / 6.26 \text{ (g/s)}$   
 $= 0.202 \text{ ( 20\%)}$

The underfueling fuel flow error is limited to the range between 85% and 95% overfueling depending on the actual fuel flow. The MaxUnderfuelingError calculated above falls **below limited range**, therefore it is **limited** to;

Max Underfueling Error [] = 0.85

The underperformance fault threshold for this operating point is then calculated as:

Pressure Error Fault Threshold High [kPa]  
 $= \text{Injector Pressure Drop [kPa]} * (1 - (\text{Max Underfueling Error})^2)$   
 $= 304 * (1 - (0.85 * 0.85))$   
 $= \mathbf{84.36 \text{ kPa}}$