Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Open – Bank 1	P0010	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply voltage is within limits Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples250 ms / sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Performance – Bank 1	P0011	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Intake cam Bank 1) Cam Position Error > 6.00 deg. (CamPosErrorLimlc1)	DTC's are NOT active: P0010, IntakeCamSensorTFTKO CrankSensorTFTKO CrankIntakeCamCorrelati onFA.	System Voltage > 11.00 Volts, Engine is running VVT is enabled Desired cam position > 0 Power Take Off (PTO) not active Both Desired & Measured cam positions cannot be < 6.00 (CamPosErrorLimlc1) or have both > 24.00 deg. (PerfMaxlc1). Desired cam position cannot vary more than 3.00 Cam Deg for at least 3.00 sec. (StablePositionTimelc1)	100.00 failures out of 125.00 samples100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Open – Bank 1	P0013	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: $\leq 0.5~\Omega$ impedance between signal and controller power Open Circuit: $\geq 200~\mathrm{K}~\Omega$ impedance between signal and controller ground	System supply voltage is within limitsOutput driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples250 ms / sample, continuous	Type B, 2 Trips

	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft System Performance – Bank 1	P0014	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Exhaust cam Bank 1) Cam Position Error > 6.00 deg. (CamPosErrorLimEc1)	DTC's are NOT active: P0013, ExhaustCamSensorTFTK O CrankSensorTFTKO CrankExhaustCamCorrela tionFA	System Voltage > 11.00 Volts, Engine is running VVT is enabled Desired cam position > 0 Power Take Off (PTO) not active Both Desired & Measured cam positions cannot be < 6.00 deg. (CamPosErrorLimEc1) or have both > (16.50) (PerfMaxEc1). Desired cam position cannot vary more than 3.00 Cam Deg for at least 3.00 sec. (StablePositionTimeEc1)	100.00 failures out of 125.00 samples100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft - Sprocket Correlation Diagnostic	P0016 and P0017	On engines with a dual intermediate sprocket between the crankshaft and the camshafts, this diagnostic detects a timing misalignment between the crankshaft, sprocket and camshafts that will cause the bank 1 camshafts to be misaligned.	Bank 1 Cam Sensor A pulses more than -7.0 crank degrees before or 9.0 crank degrees after nominal position in one cam revolution + Bank 1 Cam Sensor B pulses more than -7.0 crank degrees before or 9.0 crank degrees after nominal position in one cam revolution.	>= 8	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs:	P0335, P0336 P0340, P0341 P0365, P0366 5VoltReferenceA_FA 5VoltReferenceB_FA	2 failures out of 3 tests. A failed test is 1 out of 10 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table "Cam Correlation Oil Temperature Threshold". One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 1	P0030	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0031 may also set

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0031	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short-to-ground).	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0030 may also set

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0032	Diagnoses the Heater Output low side driver circuit for circuit faults.	on state (indicates short	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 2	P0036	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit).	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0037 may also set

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0037	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short-to-ground).	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0036 may also set

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0038	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power).	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 1	P0053	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	7.5 < Ω < 13.0	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,820 seconds -30.0 < °C < 45.0 < 31.9 volts < 0.17 seconds	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0054	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	7.5 < Ω < 13.0	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,820 seconds -30.0 < °C < 45.0 < 31.9 volts < 0.17 seconds	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
MAP / MAF / Throttle Position Correlation	P0068	Detect when MAP and MAF do not match estimated engine airflow as established by the TPS	Difference between MAP and estimated MAP exceeds threshold (kPa), or P0651 (5 Volt Ref), or P0107 (MAP circuit low), or P0108 (MAP circuit high) have failed this key cycle, then MAP portion of diagnostic fails Absolute difference between MAF and estimated MAF exceed threshold (grams/sec), or P0102 (MAF circuit low), or P0103 (MAF circuit hi) have failed this key cycle, or maximum MAF versus RPM (Table) is greater than or equal to maximum MAF versus battery voltage, then MAF portion of diagnostic fails	Table, f(TPS). See supporting tables: Delta MAP Threshold f(TPS) Table, f(TPS). See supporting tables: Delta MAF Threshold f(TPS) Table, f(RPM). See supporting tables: Maximum MAF f (RPM) Table, f(Volts). See	Engine Speed	> 800 RPM Run/Crank voltage > 6.41	Continuously fail MAP and MAF portions of diagnostic for 0.1875 s Continuous in MAIN processor	Type A, 1 Trips
				supporting tables: Maximum MAF f (Volts)				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Circuit Performance (applications with humidity sensor and manifold temperature sensor)	that has stuck in range by comparing to IAT and IAT3 at startup Performance applications with humidity ensor and nanifold emperature	ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up IAT - Power Up IAT3) AND ABS(Power Up IAT2 - Power Up IAT3)	> 25 deg C <= 25 deg C > 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips	
			Power Up IAT is between Power Up IAT2 and Power Up IAT3 AND ABS(Power Up IAT2 - Power Up IAT3) AND ABS(Power Up IAT - Power Up IAT2) > ABS(Power Up IAT3) ABS(Power Up IAT - Power Up IAT - Power Up IAT3)	> 25 Deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	
			Power Up IAT3 is between Power Up IAT and Power Up IAT2 AND ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up IAT3 -	> 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Power Up IAT2) > ABS(Power Up IAT3 - Power Up IAT)			HumTempSnsrCktFA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 Low (applications with humidity)	P0097	Detects a continuous short to ground or open in the IAT 2 signal circuit	Raw IAT 2 Input	< 13 Hertz (~-60 deg C)	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 High (applications with humidity)	P0098	Detects a continuous high frequency in the IAT 2 signal circuit	Raw IAT 2 Input	> 390 Hertz (~150 deg C)	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Intermittent In-Range	P0099	Detects a noisy or erratic IAT 2 signal circuit or IAT 2 sensor	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current IAT 2 reading - IAT 2 reading from 100 milliseconds previous)	> 125.00 DegC 10 consecutive IAT 2 samples	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp Sensor Circuit Low Voltage	P00B3	This DTC detects a short to ground in the RCT signal circuit or the RCT sensor.	RCT Resistance (@ 150°C)	< 34 Ohms	Engine run time OR IAT min	> 10.0 seconds ≤ 70.3 °C	5 failures out of 10 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp Sensor Circuit High Voltage	P00B4	Circuit Continuity This DTC detects a short to high or open in the RCT signal circuit or the RCT sensor.	RCT Resistance (@ -60°C)	> 260,000 Ohms	Engine run time OR IAT min	> 60.0 seconds ≥ -7.0 °C	5 failures out of 10 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp - Engine Coolant Temp (ECT) Correlation	P00B6	difference between ECT and RCT after a soak condition.	A failure will be reported if any of the following occur: 1) Absolute difference between ECT at power up & RCT at power up is ≥ an IAT based threshold table lookup value(fast fail). 2) Absolute difference between ECT at power up & RCT at power up is > by 20.0 °C and a block heater has not been detected.	up ECT exceeds RCT by these values in the Supporting tables section	No Active DTC's Engine Off Soak Time Propulsion Off Soak Time Non-volatile memory initization Test complete this trip Test aborted this trip IAT LowFuelCondition Diag	VehicleSpeedSensor_FA IAT_SensorCircuitFA THMR_RCT_Sensor_Ckt _FA THMR_ECT_Sensor_Ckt _FA IgnitionOffTimeValid TimeSinceEngineRunning Valid > 28,800 seconds > 0 seconds = Not occurred = False = False ≥ -7 °C = False	1 failure 500 msec/ sample Once per valid cold start	Type B, 2 Trips
			3) ECT at power up > RCT at power up by 20.0 °C and the time spent cranking the engine without starting is greater than or equal to 10.0 seconds with the LowFuelConditionDiag	= False	Block Heater detection is enabled when either of the following occurs: 1) ECT at power up > IAT at power up by 2) Cranking time ===================================	> 20.0 °C < 10.0 Seconds ====================================		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					below 1b as follows:	1b		
					1d) IAT drops from power up IAT	≥ 3.3°C		
					2a) ECT drops from power up ECT	> 2°C		
					2b) Engine run time	Within > 60 Seconds		
					Diagnostic is aborted when 3) or 4) occurs:	=======================================		
					3) Engine run time with vehicle speed below 1b	> 1800 Seconds		
					4) Minimum IAT during test	≤ -7.0 °C		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Flow Insufficient	P00B7	This DTC detects a Insufficient Flow Condition (i.e Stuck Closed Thermostat)	Engine Coolant Temp (ECT) is greater than 120 Deg C and Difference between ECT and RCT is greater than 40 Deg C. When above is present for more than 5 seconds, fail counts start.		No Active DTC's Engine run time OR Engine Coolant Temp	THMR_RCT_Sensor_Ckt _FA THMR_ECT_Sensor_Ckt _FA > 300 seconds > 105.5 Deg C	30 failures out of 300 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (naturally aspirated)	P0101	Determines if the MAF sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 500 kPa*(g/s) > 15 grams/sec > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 7,000 RPM >= -7 Deg C <= 125 Deg C >= -20 Deg C <= 125 Deg C >= 0.25 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM	Calculation are performed every 12.5 msec	Type B, 2 Trips
					No Active DTCs:	See "Residual Weight Factor" tables. MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA		
				No Pending DTCs:	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit Low Frequency		Detects a continuous short to low or a open in either the signal circuit or the MAF sensor	MAF Output	<= 1,837 Hertz (~ 0.00 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 10.0 Volts >= 1.0 seconds	200 failures out of 250 samples 1 sample every cylinder firing event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit High Frequency	P0103	Detects a high frequency output from the MAF sensor	MAF Output	>= 13,200 Hertz (~ 820.9 gm/sec)	Engine Speed	> 1.0 seconds >= 300 RPM >= 10.0 Volts >= 1.0 seconds	200 failures out of 250 samples 1 sample every cylinder firing event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (naturally aspirated)	P0106	Determines if the MAP sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 500 kPa*(g/s) > 25.0 kPa > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 7,000 RPM >= -7 Deg C <= 125 Deg C >= -20 Deg C <= 125 Deg C >= 0.25 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM See "Residual Weight Factor" tables.	Calculations are performed every 12.5 msec	Type B, 2 Trips
					No Active DTCs: No Pending DTCs:	MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA EGRValve_FP		
					No Pending DTCs.	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		
			Manifold Pressure OR	< 50.0 kPa	Time between current ignition cycle and the last		4 failures out of 5 samples	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Manifold Pressure	> 115.0 kPa	time the engine was running Engine is not rotating No Active DTCs:	> 6.0 seconds EngineModeNotRunTimer	1 sample every 12.5 msec	
						Error MAP_SensorFA AAP_SnsrFA		
					No Pending DTCs:	MAP_SensorCircuitFP AAP_SnsrCktFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit Low	P0107	Detects a continuous short to low or open in either the signal circuit or the MAP sensor.	, c	< 3.0 % of 5 Volt Range (This is equal to 0.15 Volts or 3.5 kPa)	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit High	P0108	Detects an open sensor ground or continuous short to high in either the signal circuit or the MAP sensor.	MAP Voltage	> 90.0 % of 5 Volt Range (This is equal to 4.50 Volts, or 115.0 kPa)	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Performance	P0111	Detects an IAT sensor that has stuck in range by comparing to IAT2 and IAT3 at startup	ABS(Power Up IAT - Power Up IAT2) AND	> 25 deg C	Time between current ignition cycle and the last time the engine was running	> 28,800 seconds	Executes once at the beginning of each ignition cycle if enable conditions are	Type B, 2 Trips
(applications with humidity sensor and			ABS(Power Up IAT - Power Up IAT3)	> 25 deg C	Powertrain Relay Voltage for a time	>= 11.00 Volts >= 0.9 seconds	met	
manifold temperature sensor)	manifold temperature		AND ABS(Power Up IAT2 - Power Up IAT3)	<= 25 deg C	No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	FA	
			Power Up IAT2 is between Power Up IAT and Power Up IAT3 AND ABS(Power Up IAT - Power Up IAT3) AND ABS(Power Up IAT2 - Power Up IAT) > ABS(Power Up IAT2 - Power Up IAT3)	> 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	
			Power Up IAT3 is between Power Up IAT and Power Up IAT2 AND ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up IAT3 -	> 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Power Up IAT) > ABS(Power Up IAT3 - Power Up IAT2)			HumTempSnsrCktFA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Low	P0112	Detects a continuous short to ground in the IAT signal circuit or the IAT sensor	Raw IAT Input	< 94 Ohms (~150 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit High	P0113	Detects a continuous open circuit in the IAT signal circuit or the IAT sensor	Raw IAT Input	> 63,000 Ohms (~-60 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Intermittent In-Range	P0114	Detects a noisy or erratic IAT signal circuit or IAT sensor	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current IAT reading - IAT reading from 100 milliseconds previous)	> 125.00 DegC 10 consecutive IAT samples	Continuous		4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Performance	P0116	This DTC detects ECT temp sensor stuck in mid range.	A failure will be reported if any of the following (1-3) occur after the following soak conditions, Engine off time > 28,800 seconds Propulsion system off time > 0 seconds 1) ECT at power up > IAT at power up by an IAT based table lookup value (fast fail). 2) ECT at power up > IAT at power up by 20.0 Deg C and a block heater has not been detected. 3) ECT at power up > IAT at power up by 20.0 Deg C and the time spent cranking the engine without starting is greater than 10.0 seconds with the LowFuelConditionDiag	See the table named: P0116_Fail if power up ECT exceeds IAT by these values in the Supporting tables section = False	Non-volatile memory initization Test complete this trip Test aborted this trip IAT LowFuelCondition Diag ===================================	VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_Ckt_FA IgnitionOffTime Valid TimeSinceEngineRunning Valid = Not occurred = False = False ≥ -7 °C = False ====================================	1 failure 500 msec/ sample Once per valid cold start	Type B, 2 Trips
					and diagnostic is aborted when 1) or 2) occurs: 1a) Vehicle drive time 1b) Vehicle speed	> 400 seconds > 14.9 MPH		
					1c) Additional Vehicle drive time is provided to 1a when Vehicle speed is below 1b as follows:	0.50 times the seconds with vehicle speed below 1b		
				1d) IAT drops from power				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					up IAT	≥3.3°C		
					2a) ECT drops from power up ECT	≥ 2°C		
					2b) Engine run time	Within ≤ 60 seconds		
					Diagnostic is aborted when 3) or 4) occurs:	=======================================		
					3) Engine run time with vehicle speed below 1b	> 1800 seconds		
					4) Minimum IAT during test	≤-7 °C		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit Low	P0117	Circuit Continuity This DTC detects a short to ground in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ 150°C)	< 34 Ohms			5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit High	P0118	Circuit Continuity This DTC detects a short to high or open in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ -60°C)	> 260,000 Ohms	Engine run time OR IAT min	> 15.0 seconds ≥ -7.0 °C	5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Circuit Intermittent	P0119	Circuit Continuity This DTC detects large step changes in the ECT signal circuit or the ECT sensor. Allowable high and low limits are calculated for the next sample based on the previous sample.	ECT temperature step change: 1) postive step change is greater than calculated high limit OR 2) negitive step change is lower than calculated low limit. The calculated high and low limits use the following calibrations: 1) Sensor time constant 2) Sensor low limit 3) Sensor high limit *****Generic Example***** If the last ECT reading was 90 Deg C, the Time constant was calibrated at 10 seconds, the low limit was calibrated to -80 Deg C and the high limit was calibrated to 200 Deg C the caluculated limits are 101 Deg C and 73 Deg C. The next reading (after the 90 Deg C reading) must be between 73 Deg C and 101 Deg C to be valid. ***********************************	15.0 seconds -65.0 Deg C 200.0 Deg C	No Active DTC's	P0117 P0118	3 failures out of 4 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (naturally aspirated)	P0121	Determines if the Throttle Position Sensor input is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	> 500 kPa*(g/s) > 15 grams/sec <= 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 7,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 125 Deg C > -125 Deg C >= 0.25 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est See "Residual Weight Factor" tables.	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips
					No Active DTCs:	MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA		
					No Pending DTCs:	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit Low	P0122	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage <	0.3250		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit High	P0123	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage >	4.750		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine	P0128	This DTC detects if the	Energy is accumulated		No Active DTC's	ECT_Sensor_Ckt_FA	1 failure to set	Type B,
Coolant		engine coolant	after the first conbustion			VehicleSpeedSensor_FA	DTC	2 Trips
Temperature		temperature rises too	event using Range #1 or			OAT_PtEstFiltFA		
Below Stat		slowly due to an ECT	#2 below:			IAT_SensorCircuitFA	1 sec/ sample	
Regulating		or Cooling system fault	_, , , , , , , , , , , , , , , , , , ,			MAF_SensorFA THMR_AWP_AuxPumpF		
Temperature			Thermostat type is divided				Once per ignition	
) (energy		and electri	into normal (non-heated)			A TUMB ALIVERA	key cycle	
based "Deluxe"			and electrically heated.			THMR_AHV_FA		
method			For this application the			THMR_SWP_Control_FA ECT_Sensor_Perf_FA		
metriod			"type" cal			ECT_Sensor_Pen_FA		
			(KeTHMG_b_TMS_ElecT		Engine not run time			
			hstEquipped) = 1		(soaking time before			
			If the type cal is equal to		current trip)	≥ 1,800 seconds		
			one, the application has		odirone dip)	1,000 30001103		
			an electrically heated t-			30 ≤ Eng Run Tme ≤		
			stat, if equal to zero the		Engine run time	1,800 seconds		
			the application has an non		9 4 4 4	,		
			heated t-stat. See		Fuel Condition	Ethanol ≤87 %		
			appropiate section below.					
					Distance traveled	≥ 1.00 km		

			Type cal above = 1					
			(Electrically heated t-stat)		*******	********		
			== == == ==	See the two tables	If Engine RPM is			
			Range #1 (Primary) ECT	named:	continuously greater than	9,999 rpm		
			reaches Commanded	P0128_Maximum	for this time period	5.0 seconds		
			temperature minus 26 °C	Accumulated Energy	The discussion to at few this			
			when Ambient min is ≤ 52 °C and > 10 °C.	for Start-up ECT conditions - Primary	The diagnostic test for this key cycle will abort			
			Note: Warm up target for	and	**************************************	******		
			range #1 will be at least	P0128_Maximum				
			79°C	Accumulated Energy	*******	******		
			73 0	for Start-up ECT	If T-Stat Heater			
	Range reache	Range #2 (Alternate) ECT	conditions - Alternate	commanded duty cycle	> 20.0 % duty cycle			
		reaches Commanded	in the Supporting	for this time period	> 9,999.0 seconds			
			temperature minus 46 °C	tables section.				
			when Ambient min is ≤		The diagnostic test for this			
			10 °C and > -7 °C.	This diagnostic models	key cycle will abort			
			Note: Warm up target for	the net energy into and				
			range #2 will be at least	out of the cooling	*******	*******		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			59 °C ***********************************	system during the warm-up process. The five energy terms are: heat from combustion, heat from after-run, heat loss to enviroment, heat loss to cabin and heat loss to DFCO.	ECT at start run	-60 ≤ ECT ≤ 74 °C		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 1	P0131	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 20.0 mVolts	AIR intrusive test Fuel intrusive test Idle intrusive test Idle intrusive test Idle intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control Low Fuel Condition Diag Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active All Fuel Injectors for active Cylinders Fuel Condition Fuel State All of the above met for	TPS_ThrottleAuthorityDef aulted MAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA = Not active = Talse 0.9912 < ratio < 1.0137 60 < mgram < 500 = Closed Loop = TRUE Enabled (On) Ethanol ≤ 87 % DFCO not active > 3.0 seconds	380 failures out of 475 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 1	P0132	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	== Open Test Criteria == No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition ====================================	=====================================	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips
					No Active DTC's Low Fuel Condition Diag Fuel Condition	MAP_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA AIR System FA = False ≤ 87 % Ethanol		
					Initial delay after Open Test Criteria met (cold start condition) Initial delay after Open Test Criteria met (not cold start condition)	> 10.0 seconds when engine soak time > 28,820 seconds > 10.0 seconds when engine soak time ≤ 28,820 seconds		
					Equivalence Ratio Air Per Cylinder Fuel Control State	0.9912 ≤ ratio ≤ 1.0137 60 ≤ mgram ≤ 500 not = Power Enrichment		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for	> 3.0 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.		
O2S Slow Response Bank 1 Sensor 1) (For use with ESPD	sponse nk 1 nsor 1) the O2 sensor response time is degraded.	response time is	Fault condition present when the average response time is caluclated over the test time, and compared to the threshold. OR	Refer to P0133_O2S Slow Response Bank 1 Sensor 1 "Pass/Fail Threshold table" in the Supporting Tables tab	No Active DTC's	TPS_ThrottleAuthorityDef aulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg	Sample time is 60 seconds Frequency: Once per trip	Type B, 2 Trips		
			Slope Time L/R Switches OR	< 5		e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt				
			Slope Time R/L Switches < 5	< 5		_FA FuelInjectorCircuit_FA AIR System FA EthanolCompositionSens or_FA EngineMisfireDetected_F				
					Bank 1 Sensor 1 DTC's not active	A P0131, P0132, P0134				
							System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition	10.0 < Volts < 32.0 = Not active = False = Not Valid, See definition		
					2.3511 3.25 3511ditto11	of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S1, B2S1 (if applicable)				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
	Code	Monitor Description	Manunction Criteria	Threshold value	C2 Heater on for Learned Htr resistance Engine Coolant IAT Engine run Accum Time since any AFM status change Time since Purge On to Off change Time since Purge Off to On change Engine airflow Engine speed Fuel Condition Baro Air Per Cylinder Fuel Control State Closed Loop Active LTM fuel cell Transient Fuel Mass Baro Fuel Control State Fuel State Commanded Proportional	in Supporting Tables tab. ≥ 40 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") > 60 °C > -40 °C > 150 seconds > 2.0 seconds > 2.0 seconds > 2.0 seconds 12 ≤ grams/second ≤ 30 1,200 <= RPM <= 3,500 < 87 % Ethanol > 70 kpa ≥ 100 mGrams = Closed Loop = TRUE = Enabled ≤ 100.0 mgrams = Not Defaulted not = Power Enrichment DFCO not active	Time Required	
					Gain ======== All of the above met for	≥ 0.0 % ====================================		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Insufficient Activity Bank 1 Sensor 1	P0134	This DTC determines if the O2 sensor circuit is open.	Oxygen Sensor Signal	> 1,700 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition	TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 50 seconds ≤ 87 % Ethanol	100 failures out of 125 samples. Frequency: Continuous 100 msec loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 1	P0135	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.3 < Amps < 2.5	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA 10.0 < Volts < 32.0 = Complete = Not active > zero > 30 seconds	8 failures out of 10 samples Frequency: 2 tests per trip 10 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0137	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 20 mvolts	AIR intrusive test Fuel intrusive test Idle intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active All Fuel Injectors for active Cylinders Fuel Condition Fuel State All of the above met for	TPS_ThrottleAuthority DefaultedMAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA = Not active = Talse 0.9912 ≤ ratio ≤ 1.0137 60 ≤ mgrams ≤ 500 = Closed Loop = TRUE Enabled (On) Ethanol <= 87 % DFCO not active > 3.0 seconds	380 failures out of 475 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 2) (For Single Bank Exhaust Only	the O2 sensor circuit is shorted to high. 2) gle	System Voltage AFM Status Heater Warm-up del Engine Run Time Fuel Condition	System Voltage AFM Status Heater Warm-up delay Engine Run Time	=====================================	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips		
					No Active DTC's Low Fuel Condition Diag Fuel Condition	MAP_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA AIR System FA = False ≤ 87 % Ethanol		
					Initial delay after Open Test Criteria met (cold start condition) Initial delay after Open Test Criteria met (not cold start condition) Equivalence Ratio Air Per Cylinder Fuel Control State	> 15.0 seconds when engine soak time > 28,820 seconds > 15.0 seconds when engine soak time ≤ 28,820 seconds 0.9912 ≤ ratio ≤ 1.0137 60 ≤ mgrams ≤ 500 not = Power Enrichment		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for	> 3.0 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Rich to Lean Bank 1 Sensor 2	P013A	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Rich to Lean voltages range during Rich to Lean transition. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Post O2 sensor normalized integral value OR The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 9.5 units > 10.0 grams (upper voltage threshold is 450 mvolts and lower voltage threshold is 150 mvolts)	B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013B, P013E, P013F, P2270 or P2271 10.0 < Volts < 32.0 = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA
					Low Fuel Condition Diag Post fuel cell	= False = enabled		
					DTC's Passed	P2270 (and P2272 if applicable)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						P013E (and P014A if applicable)		
					After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	=======================================		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Lean to Rich Bank 1 Sensor 2	P013B	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Lean to Rich voltages range during Lean to Rich transition. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	The EWMA of the Post O2 sensor normalized integral value OR The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 9.5 units > 140 grams (lower voltage threshold is 350 mvolts and upper voltage threshold is 650 mvolts)	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013A, P013E, P013F, P2270 or P2271 10.0 < Volts < 32.0 = Valid (the heater resistance has learned since NVM reset, see enable conditions for "H02S Heater Resistance DTC's")	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA
					ICAT MAT Burnoff delay	= Not Valid		
					Green O2S Condition Green Cat System	= Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.		
					Condition	= Not Valid, System is not valid until accumulated airflow is greater than		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Diag Post fuel cell DTC's Passed	360,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service). = False = enabled P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable) P2271 (and P2273 if applicable) P013F (and P014B if applicable)		
					After above conditions are met: Fuel Enrich mode continued. ===================================	=======================================		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 2	P013E	This DTC determines if the post catalyst O2 sensor has an initial delayed response to an A/F change from Rich to Lean. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	Post O2 sensor voltage AND The Accumulated mass air flow monitored during the Delayed Response Test under DFCO DFCO begins after: 1) Catalyst has been rich for a minimum of AND 2) Catalyst Rich Accumulation Air Flow is greater or equal to	> 450 mvolts > 20 grams > 0 secs > 5 grams	B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013A, P013B, P013F, P2270 or P2271 10.0 < Volts < 32.0 = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips
					ICAT MAT Burnoff delay Green O2S Condition	= Not Valid = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.		
				Low Fuel Condition Diag Post fuel cell	= False = enabled			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					DTC's Passed	P2270 (and P2272 if applicable)		
					Number of fueled cylinders	≤3 cylinders		
					After above conditions are met: DFCO mode entered (wo driver initiated pedal input).			

P013F	This DTC determines if the post catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test	Post O2 sensor voltage AND The Accumulated mass air flow monitored during	< 350 mvolts	No Active DTC's	TPS_ThrottleAuthorityDef aulted	Frequency:	Type B,
	which increases the delivered A/F ratio to achieve the required rich threshold.	the Delayed Response Test	> 260 grams	B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance	ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013A, P013B, P013E, P2270 or P2271 10.0 < Volts < 32.0 = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")	Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed	2 Trips
				ICAT MAT Burnoff delay	= Not Valid		
				Green O2S Condition Green Cat System Condition	= Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. = Not Valid, System is not		
					Green O2S Condition Green Cat System	ICAT MAT Burnoff delay Green O2S Condition = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.	ICAT MAT Burnoff delay Green O2S Condition = Not Valid = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Green Cat System Condition = Not Valid, System is not valid until accumulated

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Diag Post fuel cell DTC's Passed Number of fueled cylinders	360,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service). = False = enabled P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable) ≥ 1 cylinders ====================================		
					or the test will abort: 0.95 ≤ Fuel EQR ≤ 1.10			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Insufficient Activity Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0140	This DTC determines if the O2 sensor circuit is open.	Oxygen Sensor Signal	> 1,700 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition	TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 50 seconds ≤ 87 % Ethanol	100 failures out of 125 samples. Frequency: Continuous 100 msec loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0141	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.		0.3 > amps > 2.5	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA 10.0 < Volts < 32.0 = Complete = Not active > zero > 30 seconds	8 failures out of 10 samples Frequency: 2 tests per trip 10 seconds delay between tests and 1 second execution rate.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 1	P015A	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Rich to Lean. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Pre O2 sensor normalized R2L time delay value OR [The Accumulated time monitored during the R2L Delayed Response Test (Gross failure). AND Pre O2 sensor voltage is	> 0.5 EWMA (sec) ≥ 2.5 Seconds > 550 mvolts	System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition	TPS_ThrottleAuthorityDef aulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_FA EvapEmissionSystem_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSens or_FA EngineMisfireDetected_F A P0131, P0132, P0134 10.0 < Volts < 32.0 = Not active = Not Alid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for	Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_Rap idResponselsAct ive = TRUE, multiple tests per trip are allowed	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					O2 Heater (pre sensor) on for Learned Htr resistance	the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. ≥ 40 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")		
					Engine Coolant IAT Engine run Accum	> 60 °C > -40 °C > 150 seconds		
					Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)	1,500 ≤ RPM ≤2,800 1,400 ≤ RPM ≤2,900		
					Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)	$2 \le \text{gps} \le 20$ $43.5 \le \text{MPH} \le 68.4$ $40.4 \le \text{MPH} \le 71.5$		
					Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell	0.92 ≤ C/L Int ≤ 1.08 = TRUE not in control of purge not in estimate mode = enabled		
					EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State	= not active = not active ≥ 40.0 sec 550 ≤ °C ≤ 900 = DFCO possible		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for at least 1.0 seconds, and then the Force Cat Rich intrusive stage is requested. Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders	=====================================		
					initiated pedal imput).			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 1	P015B	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test which runs in an enriched fuel mode to achieve the required response.	The EWMA of the Pre O2 sensor normalized L2R time delay value OR [The Accumulated time monitored during the L2R Delayed Response Test (Gross failure). AND Pre O2 sensor voltage is OR At end of Cat Rich stage the Pre O2 sensor output is	> 0.5 EWMA (sec) ≥ 2.5 Seconds < 350 mvolts < 690 mvolts	System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition	TPS_ThrottleAuthorityDef aulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSens or_FA EngineMisfireDetected_F A P0131, P0132, P0134 10.0 < Volts < 32.0 = Not active = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for	Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_Rap idResponselsAct ive = TRUE, multiple tests per trip are allowed	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					O2 Heater (pre sensor) on for Learned Htr resistance	the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. ≥ 40 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for		
					Engine Coolant IAT Engine run Accum	"HO2S Heater Resistance DTC's") > 60 °C > -40 °C > 150 seconds		
					Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)	1,500 ≤ RPM ≤ 2,800 1,400 ≤ RPM ≤ 2,900		
					Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)	$2 \le \text{gps} \le 20$ $43.5 \le \text{MPH} \le 68.4$ $40.4 \le \text{MPH} \le 71.5$		
					Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor)	0.92 ≤ C/L Int ≤ 1.08 = TRUE not in control of purge not in estimate mode = enabled = not active = not active		
					on Time Predicted Catalyst temp	≥ 40.0 sec 550 ≤ °C ≤ 900		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Fuel State Number of fueled cylinders	= DFCO inhibit ≥1 cylinders		
					When above conditions are met: Fuel Enrich mode is entered.			
					During this test: Engine Airflow must stay between: and the delta Engine Airflow over 12.5msec must be:	3≤gps≤ 15 ≤3.0gps		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Lean Bank 1	P0171	Determines if the fuel control system is in a lean condition, based on the filtered long-term and short-term fuel trim.	n is in a trim metric , based long- AND t-term	>= 1.250 >= 0.100	Engine speed BARO Coolant Temp MAP Inlet Air Temp MAF Fuel Level Long Term Fuel Trim data accumulation:	400 <rpm< 7,000=""> 70 kPa -20 <°C< 150 10 <kpa< -20="" 1.0="" 150="" 255="" 512.0="" <g="" <°c<="" s<=""> 10 % or if fuel sender is faulty > 34.0 seconds of data must accumulate on each trip, with at least 14.0 seconds of data in the current fuel trim cell before a pass or fail decision can be made.</kpa<></rpm<>	Frequency: 100 ms Continuous Loop	Type B, 2 Trips
					Sometimes, certain Long- Term Fuel Trim Cells are not utilized for control and/or diagnosis	(Please see "Long-Term Fuel Trim Cell Usage" in Supporting Tables for a list of cells utilized for diagnosis)		
					Closed Loop Long Term FT	Enabled Enabled (Please see "Closed Loop Enable Criteria" and "Long Term FT Enable Criteria" in Supporting Tables.)		
					Fuel Consumed	> 0.2 liters of fuel consumed after a fuel fill event ("Virtual Flex Fuel Sensor applications only)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Catalyst Diag. Post O2 Diag. Device Control EVAP Diag.	Intrusive Test Not Active Not Active "tank pull down" Not Active		
					No active DTC:	IAC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR System FA EvapExcessPrgePsbl_FA Ethanol Comp Snsr FA FuelInjectorCkt_FA EngMisfireDetected_FA EGRValvePerf_FA EGRValveCkt_FA MAP_EngVacuumStatus AmbPresDfltdStatus TC_BoostPresSnsrFA O2Snsr_B1_Snsr_1_FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Rich Bank 1	P0172	Determines if the fuel control system is in a rich condition, based on the filtered longterm fuel trim metric.	Passive Test: The filtered Non-Purge Long Term Fuel Trim metric	<= 0.750		Secondary Parameters and Enable Conditions are identical to those for P0171, with the exception that fuel level is not considered.	Frequency: 100 ms Continuous Loop	Type B, 2 Trips
		There are two methods to determine a Rich fault. They are Passive and Intrusive. A Passive Test decision cannot be made when Purge is enabled. The Intrusive test is	The filtered Short Term Fuel Trim metric (a value > 1.05 effectively nullifies the short-term fuel trim criteria)	<= 2.000		considered.		
		described below: Intrusive Test: When the filtered Purge Long Term Fuel Trim metric is <= 0.755, purge is ramped off to determine if excess	Intrusive Test: For 2 out of 3 intrusive segments, the filtered Purge Long Term Fuel Trim metric AND	<= 0.755				
		purge vapor is the cause of the rich condition. If the filtered Purge Long Term Fuel Trim metric > 0.755, the test passes without	The filtered Non-Purge Long Term Fuel Trim metric AND	<= 0.750				
		checking the filtered Non-Purge Long Term Fuel Trim metric.	The filtered Short Term Fuel Trim metric (a value > 1.05 effectively nullifies the short-term	<= 2.000				
		Performing intrusive tests too frequently may also affect EVAP	fuel trim criteria)					
		and EPAIII emissions, and the execution frequency of other diagnostics.	cution Segments can last up to fother 60 seconds and are					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			A maximum of 3 completed segments or 20 attempts are allowed for each intrusive test. After an intrusive test report is completed, another intrusive test cannot occur for 100 seconds to allow sufficient time to purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge-on Long Term fuel trim > 0.755 for at least 150 seconds, indicating that the canister has been purged.					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Open Circuit (PFI) - 3 DTC Implmentatio n	P0201	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0261 may also set (Injector 1 Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Open Circuit (PFI) - 3 DTC Implmentatio n	P0202	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0264 may also set (Injector 2 Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Open Circuit (PFI) - 3 DTC Implmentatio n	P0203	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0267 may also set (Injector 3 Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Open Circuit (PFI) - 3 DTC Implmentatio n	P0204	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0270 may also set (Injector 4 Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit Low	P0222	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage <	0.250		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit High	P0223	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage >	4.590		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to ground (PFI)	P0261	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0201 may also set (Injector 1 Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to power (PFI)	P0262	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	within range for a duration	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to ground (PFI)	P0264	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0202 may also set (Injector 2 Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to power (PFI)	P0265	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	on state indicates short to	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running		20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to ground (PFI)	P0267	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0203 may also set (Injector 3 Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Injector 3 Low side circuit shorted to power (PFI)	P0268	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	within range for a duration	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to ground (PFI)	P0270	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0204 may also set (Injector 4 Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Injector 4 Low side circuit shorted to power (PFI)	P0271	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	within range for a duration	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Random Misfire Detected Cylinder 1 Misfire Detected Cylinder 2 Misfire Detected Cylinder 3 Misfire Detected Cylinder 4 Misfire Detected	P0300 P0301 P0302 P0303 P0304	These DTC's will determine if a random or a cylinder specific misfire is occurring by monitoring various terms derived from crankshaft velocity. The rate of misfire over an interval is compared to both emissions and catalyst damaging thresholds. The pattern of crankshaft acceleration after the misfire is checked to differentiate between real misfire and other sources of crank shaft noise.	Deceleration Value vs. Engine Speed and Engine load The equation used to calculate deceleration value is tailored to specific vehicle operating conditions. The selection of the equation used is based on the 1st tables encountered that are not max of range. If all tables are max of range at a given speed/load, that speed load region is an <i>Undetectable region</i> see Algorithm Description Document for additional details. Misfire Percent Emission Failure Threshold	> SCD_Jerk) OR	Engine Run Time Engine Coolant Temp Or If ECT at startup Then ECT System Voltage + Throttle delta - Throttle delta - Throttle delta Early Termination option: (used on plug ins that may not have enough engine run time at end of trip for normal interval to complete.)	> 2 crankshaft revolution -7°C < ECT < 125°C < -7°C 21°C < ECT < 125°C 9.00 < volts < 32.00 < 25.00 % per 25 ms < 25.00 % per 25 ms Not Enabled	Emission Exceedence = any (5) failed 200 rev blocks out of (16) 200 rev block tests Failure reported for (1) Exceedence in 1st (16) 200 rev block tests, or (4) Exceedences thereafter. OR when Early Termination Reporting = Enabled and engine rev > 1,000 revs and < 3,200 revs at end of trip any Catalyst Exceedence = (1) 200 rev block as data supports for catalyst damage. Failure reported	Type B, 2 Trips (Mil Flashes with Catalyst damage level of Misfire)
			Misfire Percent Catalyst Damage	> Catalyst_Damage_ Misfire_Percentage in Supporting Tables	(at low speed/loads, one cylinder may not cause cat damage)		with (1 or 3) Exceedences in FTP, or (1) Exceedence outside FTP.	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			When engine speed and load are less than the FTP cals (3) catalyst damage exceedences are allowed.	whenever secondary conditions are met. ≤ 0 FTP rpm AND ≤ 0 FTP % load	Engine Speed Engine Load Misfire counts	> 1,000 rpm AND > 25 % load AND < 180 counts on one cylinder	Continuous	
				disable conditions:	Engine Speed	550 < rpm < ((Engine Over Speed Limit) - 400 Engine speed limit is a function of inputs like Gear and temperature see EngineOverSpeedLimit in supporting tables	4 cycle delay	
					No active DTCs:	TPS_FA EnginePowerLimited MAF_SensorTFTKO MAP_SensorTFTKO IAT_SensorTFTKO IAT_Sensor_Ckt_TFTKO 5VoltReferenceB_FA CrankSensorTFTKO CrankSensorFA CamLctnIntFA CamLctnExhFA CamSensorAnyLctnTFTK O AnyCamPhaser_FA AnyCamPhaser_TFTKO AmbPresDfltdStatus	4 cycle delay	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P0315 & engine speed	> 1,000 rpm	4 cycle delay	
					Fuel Level Low	LowFuelConditionDiagnos tic	500 cycle delay	
					Cam and Crank Sensors	in sync with each other	4 cycle delay	
					Misfire requests TCC unlock	Not honored because Transmission in hot mode or POPD intrusive diagnostic running	4 cycle delay	
					Fuel System Status	≠ Fuel Cut	4 cycle delay	
					Active FuelManagement	Transition in progress	7 cycle delay	
					Undetectable engine speed and engine load region	Undetectable region from Malfunction Criteria	4 cycle delay	
					Abusive Engine Over Speed	> 7,250 rpm	0 cycle delay	
					Below zero torque (except CARB approved 3000 rpm to redline triangle.)	< ZeroTorqueEngLoad in Supporting Tables	4 cycle delay	
					Below zero torque: TPS Vehicle Speed	≤ 1 % > 19 mph	4 cycle delay	
					EGR Intrusive test	Active	12 cycle delay	
					Manual Trans	Clutch shift	4 cycle delay	
					Accel Pedal Position AND Automatic transmission shift	> 95.00 %	7 cycle delay	
					Driveline Ring Filter active			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early. Filter Driveline ring:	> "Ring Filter" # of engine cycles after misfire in Supporting Tables		
					Stop filter early:	> "Number of Normals" # of engine cycles after misfire in Supporting Tables tab		
					Engine Speed	> 1 % > 1,000 rpm		
					Veh Speed Consecutive decels while in SCD Mode Cyl Mode Rev Mode			
					Misfire Crankshaft Pattern Recognition checks each "misfire" candidate in 100 engine Cycle test to see if it looks like real misfire, or some disturbance like rough road. The check is			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					based on a multiplier times the ddt_jerk value used to detect misfire at that speed and load. At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present. Pattern Recog Enabled: Engine Speed Veh Speed "misfire" unrecognized if: Crankshaft snap after: isolated "misfire" repetative "misfire"	Enabled 630 < rpm < 6,100 > 3.1 mph > Min_PatternMultiplier > Max_PatternMultiplier in Supporting Tables		
					Ratio of Unrecog/Recog	> 0.80	discard test	
					Rough Road: Non-Crankshaft based: Rough Road Source	Disabled TOSS		
					IF Rough Road Source = WheelSpeedInECM ABS/TCS Wheel speed noise VSES	active > WSSRoughRoadThres active	discard test	
					IF Rough Road Source = "FromABS" ABS/TCS RoughRoad VSES	active detected active	discard test	
					IF Rough Road Source = "TOSS"			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					TOSS dispersion	>TOSSRoughRoadThres in supporting tables	discard test	
					AND No Active DTCs	Transmission Output Shaft Angular Velocity Validity TransmissionEngagedStat e_FA (Auto Trans only) Clutch Sensor FA (Manual Trans only)	4 cycle delay	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position System Variation Not Learned	P0315	Monitor for valid crankshaft error compensation factors		≥ 2.0040 OR ≤ 1.9960	OBD Manufacturer Enable Counter	MEC = 0	0.50 seconds Frequency Continuous100 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Per Cylinder	P0324	This diagnostic checks for knock sensor performance out of the normal expected range on a per cylinder basis due to: 1. Excessive knock or 2. Abnormal engine noise or 3. Flat signal	Common Enable Criteria (Applies to all 3 parts of the performance diag) Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag: 1. Excessive Knock Diag: Filtered Knock Intensity VaKNKD_k_PerfCylKnock IntFilt (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)	> 1.30 (no units)	Diagnostic Enabled? Engine Run Time Engine Speed Engine Air Flow ECT IAT Engine Speed Cumlative Number of Engine Revs Above Min Eng Speed (per key cycle)	Yes ≥ 2.0 seconds ≤ 5,000 RPM ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder ≥ -40 deg's C ≥ -40 deg's C ≥ 1,500 RPM ≥ 100 Revs	First Order Lag Filters with Weight Coefficients Excessive Knk Weight Coefficient = 0.0400 Updated each engine event	Type B, 2 Trips
		2. Abnormal Noise Diag: Filtered FFT Intensity (where 'FFT Intensity' = Non-knocking, background noise)	<pre> AbnormalNoise_Thre shold (see Supporting Tables)</pre>	Individual Cylinders enabled for Abnormal Noise Engine Speed Cumlative Number of Engine Revs Above Min Eng Speed (per key	See AbnormalNoise_ CylsEnabled (Supporting Tables) ≥ 8,500 RPM ≥ 400 Revs	Abn Noise Weight Coefficient = 0.0100 Updated each engine event		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					cycle)			
			3. Flat Signal Diag: Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock) VaKNKD_k_PerfCylFlatFil tInt	< 0.008 (no units)	Engine Speed Cumlative Number of Engine Revs Above Min Eng Speed (per keycycle)	≥ 8,500 RPM ≥ 400 Revs	Flat Signal Weight Coefficient = 0.010 Updated each engine event	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank	P0325	This diagnostic checks for an open in the knock sensor circuit	Filtered FFT Output	> OpenCktThrshMin and < OpenCktThrshMax	Diagnostic Enabled? Engine Run Time	Yes ≥ 2.0 seconds	First Order Lag Filter with Weight Coefficient	Type B, 2 Trips
				See Supporting Tables	Engine Speed	≥ 570 RPM and ≤ 8,500 RPM	Weight Coefficient = 0.0100	
				Thresholds for OpenMethod = 20 kHz: OpenCktThrshMin (20 kHz) & OpenCktThrshMax (20 kHz)	Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)	≥ 100 revs	Updated each engine event	
				Thresholds for OpenMethod = NormalNoise: OpenCktThrshMin (Normal Noise) & OpenCktThrshMax	Engine Air Flow	≥ 40 mg/cylinder and ≤ 2,000 mg/cylinder		
				(Normal Noise)	IAT	≥ -40 deg's C ≥ -40 deg's C		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Bank 1	P0326	This diagnostic checks for knock sensor performance out of the normal expected range, on a per sensor basis, due to 1. Excessive knock or 2. Abnormal engine noise or 3. Flat signal	Common Enable Criteria (Applies to all 3 parts of the performance diag) Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag: 1. Excessive Knock Diag: Filtered Knock Intensity (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)	> 1.30 (no units)	Diagnostic Enabled? Engine Run Time Engine Speed Engine Air Flow ECT IAT Engine Speed Cumlative Number of Engine Revs Above Min Eng Speed (per key cycle)	Yes ≥ 2.0 seconds ≤ 5,000 RPM ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder ≥ -40 deg's C ≥ -40 deg's C ≥ 1,500 RPM ≥ 100 Revs	First Order Lag Filters with Weight Coefficients Excessive Knk Weight Coefficient = 0.0100 Updated each engine event	Type B, 2 Trips
		2. Abnormal Noise Diag: Filtered FFT Intensity: (where 'FFT Intensity' = Non-knocking, background noise)	< AbnormalNoise_ Threshold (see Supporting Tables)	Individual Cylinders enabled for Abnormal Noise Engine Speed Cumlative Number of Engine Revs Above Min Eng Speed (per key	See AbnormalNoise_ CylsEnabled (Supporting Tables) ≥ 2,500 RPM ≥ 100 Revs	Abnormal Noise Weight Coefficient = 0.0100 Updated each engine event		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					cycle)			
			3. Flat Signal Diag: Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock)	< 0.008 (no units)	Engine SpeedCumlative Number of Engine Revs Above Min Eng Speed (per keycycle)	≥ 8,500 RPM ≥ 100 Revs	Flat Signal Weight Coefficient = 0.010 Updated each engine event	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 1	P0327	This diagnostic checks for an out of range low knock sensor signal	Sensor Input or Return Signal Line	< 8.0 Percent (of 5 V reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 1	P0328	This diagnostic checks for an out of range high knock sensor signal	Sensor Input or Return Signal Line	> 39.0 Percent (of 5 Volt Reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
<u> </u>	P0335	Determines if a fault exists with the crank position sensor signal	Time since last crankshaft position sensor pulse received	>= 4.0 seconds	Starter engaged AND (cam pulses being received OR (DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow	= FALSE = FALSE = FALSE > 3.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips
			No crankshaft pulses received	>= 0.1 seconds	Engine is Running Starter is not engaged No DTC Active:	5VoltReferenceB_FA	Continuous every 12.5 msec	
			No crankshaft pulses received		Engine is Running OR Starter is engaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA P0365 P0366	2 failures out of 10 samples One sample per engine revolution	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Performance	P0336	Determines if a performance fault exists with the crank position sensor signal	Time in which 10 or more crank re- synchronizations occur	< 10.0 seconds	Engine Air Flow Cam-based engine speed No DTC Active:	>= 3.0 grams/second > 450 RPM 5VoltReferenceB_FA P0335	Continuous every 250 msec	Type B, 2 Trips
		No crankshaft synchronization gap found	>= 0.4 seconds	Engine is Running Starter is not engaged No DTC Active:	5VoltReferenceB_FA	Continuous every 12.5 msec		
			Time since starter engaged without detecting crankshaft synchronization gap	>= 1.5 seconds	Starter engaged AND (cam pulses being received OR (DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow	= FALSE = FALSE = FALSE > 3.0 grams/second))	Continuous every 100 msec	
			Crank pulses received in one engine revolution OR Crank pulses received in one engine revolution	< 51 > 65	Engine is Running OR Starter is engaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA P0365 P0366	8 failures out of 10 samples One sample per engine revolution	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor A	P0340	exists with the cam position bank 1 sensor A signal OR Time that starter has engaged without a	OR Time that starter has been	>= 5.5 seconds >= 4.0 seconds	Starter engaged AND (cam pulses being received OR (DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow	= FALSE = FALSE = FALSE > 3.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips
		Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged No DTC Active:	5VoltReferenceA_FA	Continuous every 100 msec		
		No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	Continuous every MEDRES event		
	1	The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor A	P0341	Determines if a performance fault exists with the cam position bank 1 sensor A signal	The number of camshaft pulses received during first 12 MEDRES events is OR (There are 12 MEDRES events per engine cycle)	< 4 >6	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT	P0351	Diagnoses the Ignition Control (EST) low side driver circuit for circuit faults. Monitors EST for Cylinder 1 (Cylinders 1 and 4 for V6 with waste spark).	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver off state (indicates short-to-ground or open circuit)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground Open Circuit: ≥ 200 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips
			Voltage high during driver on state (indicates short-to-power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT	P0352	Diagnoses the Ignition Control (EST) low side driver circuit for circuit faults. Monitors EST for Cylinder 2 (Cylinders 2 and 5 for V6 with waste spark).	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver off state (indicates short-to-ground or open circuit)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground Open Circuit: ≥ 200 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips
			Voltage high during driver on state (indicates short- to-power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT	P0353	Diagnoses the Ignition Control (EST) low side driver circuit for circuit faults. Monitors EST for Cylinder 3 (Cylinders 3 and 6 for V6 with waste spark).	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver off state (indicates short-to-ground or open circuit)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground Open Circuit: ≥ 200 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips
			Voltage high during driver on state (indicates short- to-power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT	P0354	Diagnoses the Ignition Control (EST) low side driver circuit for circuit faults. Monitors EST for Cylinder 4 (if applicable).	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver off state (indicates short-to-ground or open circuit)	Short to ground: $\leq 0.5 \Omega$ impedance between signal and controller ground Open Circuit: $\geq 200 \text{ k}\Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips
			Voltage high during driver on state (indicates short- to-power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor B	P0365	Determines if a fault exists with the cam position bank 1 sensor B signal	position sensor pulse received >= 5.5 OR Time that starter has been engaged without a camshaft sensor pulse >= 4.0 Fewer than 4 camshaft	>= 5.5 seconds >= 4.0 seconds > 3.0 seconds	Starter engaged AND (cam pulses being received OR (DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow Engine is running Starter is not engaged	= FALSE = FALSE = FALSE > 3.0 grams/second))	Continuous every 100 msec Continuous every 100 msec	Type B, 2 Trips
					No DTC Active:	5VoltReferenceA_FA		
			No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	Continuous every MEDRES event	
		The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor B	P0366	Determines if a performance fault exists with the cam position bank 1 sensor B signal	The number of camshaft pulses received during first 12 MEDRES events is OR (There are 12 MEDRES events per engine cycle)	< 4 > 6	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Incorrect Airflow	P0411	Detects an insufficient flow condition. This test is run during Phase 1 (AIR pump commanded On, Valve commanded Open). Leaks downstream of the valve are detected via an evaluation of average pressure error and average "String Length" (SL) — a term that represents the absolute pressure delta accumulated every 6.25ms, then averaged over the duration of the test. Low SL values are indicative of downstream leaks or blockages.	Average Pressure Error or OR the following String Length (SL) Test: Average Pressure Error or and the Average String Length NOTE: Average Pressure Error is the average difference between the predicted pressure and the measured pressure	> 10.0 kPa < -4.9 kPa > 1.0 kPa < -1.0 kPa < SL Threshold Bank 1 Table	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not SL Stability time SL RPM range No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec > 5.0 seconds < 6,000 RPM > 6,500 AIRSystemPressureSens or FA AIRValveControlCircuit FA AIRPumpControlCircuit FA AMF_SensorFA AmbientAirDefault_NA IAT_SensorFA ECT_Sensor_FA EngineMisfireDetected_F A CatalystSysEfficiencyLoB 1_FA CatalystSysEfficiencyLoB 2_FA ControllerProcessorPerf_FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA	Phase 1 Conditional test weight > 7.0 seconds Total 'String Length' accumulation time > 10.0 sec Frequency: Once per trip when AIR pump is commanded On Conditional test weight is calculated by multiplying the following Factors: Phase 1 Baro Test Weight Factor, Phase 1 MAF Test Weight Factor, Phase 1 System Volt Test Weight Factor, Phase 1 Ambient Temp Test Weight Factor (see Supporting Tables)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Solenoid Control Circuit	P0412	This DTC checks the AIR solenoid circuit for electrical integrity	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.	20 failures out of 25 samples	System Voltage	> 10.0 Volts < 32.0	25 samples (250 ms per sample) Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Pump Control Circuit	P0418	This DTC checks the AIR Pump circuit for electrical integrity	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.	20 failures out of 25 samples	System Voltage	> 10.0 Volts < 32.0	25 samples (250 ms per sample) Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 1	P0420	NOTE: The information contained below applies to applications that use the Idle Catalyst Monitor Algorithm The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (I.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through	Normalized Ratio OSC Value (EWMA filtered)	< 0.35	There must be a valid idle period. The criteria are: Driver must be off the accel pedal. This checks that the final accel pedal position (comprehending deadband and hysteresis) is essentially zero. Idle Speed Control System Is Active Vehicle Speed Engine speed Engine run time	< 1.24 MPH > 1,100 RPM for a minimum of 5 seconds since end of last idle period. > CatmonMinEngineRunTi meToEnable This is a function of Coolant Temperature,	1 test attempted per valid idle period Minimum of 1 test per trip Maximum of 8 tests per trip Frequency: Fueling Related: 12.5 ms OSC Measurements: 100 ms Temp Prediction: 12.5ms	Type A, 1 Trips
		forced Lean and Rich A/F excursions Normalized Ratio OSC Value Calculation Information and Definitions = 1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time) 2. BestFailing OSC value from a calibration table (based on temp and exhaust gas flow)			Tests attempted this trip The catalyst diagnostic has not yet completed for the current trip. Catalyst Idle Conditions Met Criteria is satified which includes the General Enable met and the Valid Idle Period	please see "Supporting Tables" for details. < 255		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		3. WorstPassing OSC			Criteria met, as well as:			
		value (based on temp and exhaust gas flow)			Green Converter Delay	Not Active		
		Normalized Ratio Calculation = (1-2) / (3-2)			Induction Air	>-20 ° C < 250 ° C		
		A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part. The Catalyst Monitoring			Intrusive test(s): Fueltrim Post O2 EVAP EGROther vehicle functions:	Not Active		
		Test is done during idle. Several conditions must be meet in order to execute this test. These conditions and			Power Take Off RunCrank Voltage Ethanol Estimation	Not Active > 10.90 Volts NOT in Progress		
		their related values are listed in the secondary parameters area of this document.			ECT	>40 ° C < 140 ° C		
					Barometric Pressure	> 70 KPA		
					Idle Time before going intrusive is	< 50 Seconds		
					Idle time is incremented if Vehicle speed	< 1.24 MPH and the drivers foot is off accel pedal and the idle speed control system is active as identified in the Valid Idle Period Criteria section.		
					Short Term Fuel Trim	> 0.80 < 1.30		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Predicted catalyst temp AND	> 550.00 degC		
					Engine Airflow	> CatmonMinAirflowForW armCatalystDeterminati on		
						table (g/s) (refer to "Supporting Tables" tab) (Based on engine coolant at the time the WarmedUpEvents counter resets to 0.)		
					for at least	15 seconds		
					with a closed throttle time	< 60 seconds consecutively (closed throttle consideration involves having the driver off the accel pedal as stated in the Valid Idle Period Criteria Section).		
					Also, in order to increment the WarmedUpEvents counter, either the vehicle speed must exceed the vehicle speed cal or the driver must NOT be off the accel pedal as stated in the Valid Idle Period Criteria section above.			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Closed loop fueling (Please see "Closed Loop Enable Criteria" section of the "Supporting Tables" tab for details.)			
					PRNDL	Enabled in Drive Range on an Auto Transmission vehicle.		
					Idle Stable Criteria:	Must hold true from after Catalyst Idle Conditions Met to the end of test		
					MAF	> 1.50 g/s < 7.00 g/s		
					Predicted catalyst temperature	< 950 degC		
					Engine Fueling Criteria at Beginning of Idle Period The following fueling related must also be met from between 4 and 7 seconds after the Catalyst Idle Conditions Met Criteria has been met for at least 4 seconds prior to allowing intrusive control:			
					Number of pre-O2 switches	>= 2		
					Short Term Fuel Trim Avg	> 0.96 < 1.04		
					Rapid Step Response			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(RSR) feature will initiate multiple tests:			
					If the difference between current EWMA value and the current OSC Normalized Ratio value is	> 0.50		
					and the current OSC Normalized Ratio value is	< 0.28		
					Maximum RSR tests to detect failure when RSR is enabled.	24		
					Green Converter Delay Criteria This is part of the check for the Catalyst Idle Conditions Met Criteria section			
					The diagnostic will not be enabled until the following has been met:			
					Predicted catalyst temperature for	> 0 ° C 0 seconds non- continuously.		
					Note: this feature is only enabled when the vehicle is new and cannot be enabled in service	Not Active		
					PTO General Enable DTC's Not Set	MAF_SensorFA MAF_SensorTFTKO AmbPresDfltdStatus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						IAT_SensorCircuitFA IAT_SensorCircuitTFTKO ECT_Sensor_FA O2S_Bank_1_Sensor_1_ FA O2S_Bank_1_Sensor_2_ FA O2S_Bank_2_Sensor_1_ FA O2S_Bank_2_Sensor_2_ FA FuelTrimSystemB1_FA FuelTrimSystemB1_TFTK O FuelTrimSystemB2_TFTK O EngineMisfireDetected_F A EvapPurgeSolenoidCircuit_FA IAC_SystemRPM_FA EGRValvePerformance_F A EGRValveCircuit_FA CamSensorAnyLocationF A CrankSensorFA TPS_Performance_FA EnginePowerLimited		

	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Small Leak Detected (Not Sealed Fuel System)	P0442		calibration pressure threshold table that is based upon fuel level and ambient temperature. (Please see P0442: EONV Pressure Threshold (Pascals) Table in Supporting Tables). The normalized value is calculated by the following equation: 1 - (peak pressure - peak vacuum) / pressure threshold. The normalized value is entered into EWMA (with 0= perfect pass and 1= perfect fail).	> 0.57 (EWMA Fail Threshold), ≤ 0.35 (EWMA Re- Pass Threshold)	Fuel Level Drive Time Drive length ECT Baro Distance since assembly plant Engine not run time before key off must be Time since last complete test if normalized result and EWMA is passing OR Time since last complete test if normalized result or EWMA is failing Estimated ambient temperature at end of drive Estimate of Ambient Air Temperature Valid ************************************	10 % ≤ Percent ≤ 90 % ≥ 600 seconds ≥ 5.0 miles ≥ 70 °C ≥ 70 kPa ≥ 10.0 miles ≤ refer to P0442: Engine Off Time Before Vehicle Off Maximum as a Function of Estimated Ambient Temperature Table in Supporting Tables. ≥ 17 hours ≥ 10 hours 0 °C≤Temperature≤ 34 °C	Once per trip, during hot soak (up to 2,400 sec.). No more than 2 unsuccessful attempts between completed tests.	Type A, 1 Trips EWMA Average run length is 8 to 12 trips under normal condition s Run length is 3 to 6 trips after code clear or non-volatile reset

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		the pressure drops (-62.27) Pa from peak pressure, the vent is then opened for 60 seconds to normalize the system pressure. The vent is again closed to begin the vacuum portion of the test (phase-2). As the fuel temperature continues to fall, a vacuum will begin forming. The vacuum will continue until it reaches a vacuum peak. When the pressure rises 62.27 Pa from vacuum peak, the test then completes. If the key is turned on while the diagnostic test is in progress, the test will abort.			Startup delta deg C (ECT-IAT) OR 2. Short Soak and Previous EAT Valid Previous time since engine off OR 3. Less than a short soak and Previous EAT Not Valid Previous time since engine off AND Vehicle Speed AND Mass Air Flow Must expire Estimate of Ambient Temperature Valid Conditioning Time. P0442: Estimate of Ambient Temperature Valid Conditioning Time Table in Supporting Tables. OR 4. Not a Cold Start and greater than a Short Soak Previous time since engine off AND Vehicle Speed AND Mass Air Flow Mass Air Flow Mass Air Flow	≤ 8 °C ≤ 7,200 seconds ≤ 7,200 seconds ≥ 25 mph ≥ 7 g/sec > 7,200 seconds ≥ 25 mph ≥ 7 g/sec		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Must expire maximum value in Estimate of Ambient Temperature Valid Conditioning Time. Please see P0442: Estimate of Ambient Temperature Valid Conditioning Time in Supporting Tables.			
					High Fuel Volatility During the volatility phase, pressure in the fuel tank is integrated vs. time. If the integrated pressure is then test aborts and unsuccessful attempts is incremented. OR Vacuum Refueling Detected	< -5		
					See P0454 Fault Code for information on vacuum refueling algorithm. OR 3. Fuel Level Refueling Detected			
					See P0464 Fault Code for information on fuel level refueling. OR			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Monitor Description	Malfunction Criteria	Threshold Value	4. Vacuum Out of Range and No Refueling See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling. OR 5. Vacuum Out of Range and Refueling Detected See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for	Enable Conditions	Time Required	
					information on fuel level refueling. OR 6. Vent Valve Override Failed			
					Device control using an off-board tool to control the vent solenoid, cannot exceed during the EONV test OR	0.50 seconds		
					7. Key up during EONV test No active DTCs:	MAF_SensorFA ECT_Sensor_FA IAT_SensorFA VehicleSpeedSensor_FA IgnitionOffTimeValid AmbientAirDefault		

Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P0443 P0446 P0449 P0452 P0453 P0455 P0496		
	Fault	Fault Code Monitor Description	Fault Code Monitor Description Malfunction Criteria	Fault Code Monitor Description Malfunction Criteria Threshold Value	Fault Code Monitor Description Malfunction Criteria Threshold Value Secondary Parameters	Fault Code Monitor Description Malfunction Criteria Threshold Value Secondary Parameters Enable Conditions	Fault Code Monitor Description Malfunction Criteria Threshold Value Secondary Parameters Enable Conditions Time Required P0443 P0464 P0449 P0452 P0453 P0456 P0496 P0496

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Canister Purge Solenoid Valve Circuit (ODM) (Not Sealed Fuel System and For Single DTC Implementati on Only)	P0443	Diagnoses the canister purge solenoid low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit or short-to-ground) Voltage high during driver on state (indicates short to power)	Open circuit: $\geq 200 \text{ K }\Omega$ impedence between signal and controller ground: $\leq 0.5 \Omega$ impedence between signal and controller ground Short to power: $\leq 0.5 \Omega$ impedence between signal and controller ground	PT Relay Voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent System Performance (Not Sealed Fuel System)	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filler, vent hose or EVAP canister. This test runs with normal purge and vent valve is open.	Vent Restriction Prep Test: Vented Vacuum for OR Vented Vacuum for Vent Restriction Test: Tank Vacuum for before Purge Volume After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time.	<-623 Pa 60 seconds > 1,245 Pa 60 seconds > 2,989 Pa 5 seconds ≥ 8 liters	Fuel Level System Voltage Startup IAT Startup ECT BARO No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts 4 °C ≤ Temperature ≤ 30 °C ≤ 35 °C ≥ 70 kPa MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454	Once per Cold Start Time is dependent on driving conditions Maximum time before test abort is 1,000 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent Solenoid Control Circuit (ODM) (Not Sealed Fuel System and For Single DTC Implementati on Only)	P0449	Diagnoses the vent solenoid low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit or short-to-ground) Voltage high during driver on state (indicates short to power)	Open circuit: ≥ 200 K Ω impedence between signal and controller ground: ≤ 0.5 Ω impedence between signal and controller ground Short to power: ≤ 0.5 Ω impedence between signal and controller power			20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips
			If the P0449 is active, an intrusive test is performed with the vent solenoid commanded closed for 15 seconds.					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Performance (Not Sealed Fuel System)	Pressure (FTP) Sensor Circuit Performance (Not Sealed Fuel	The DTC will be set if the fuel tank vacuum sensor is out of range when it tries to re-zero prior to the phase-1 or phase-2 portions of the engine-off natural vacuum small leak test.	The tank vacuum sensor voltage is compared to a window about the nominal sensor voltage offset (~1.5 volts) Upper voltage threshold (voltage addition above the nominal voltage) Lower voltage threshold (voltage subtraction below the nominal voltage) The difference between tank vacuum sensor voltage and the nominal offset voltage is then normalized against the appropriate threshold listed above to produce a ratio between 0.0 and 1.0. This normalized re-zero ratio is then filtered with a EWMA (with 0= perfect pass and 1=perfect fail).	0.2 volts 0.2 volts	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		This test is executed during an engine-off natural vacuum small leak test. The number of times that it executes can range from zero to two per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.	Type A, 1 Trips EWMA Average run length: 6 Run length is 2 trips after code clear or non- volatile reset
			When EWMA is the DTC light is illuminated.	> 0.73 (EWMA Fail Threshold),				
			The DTC light can be turned off if the EWMA is and stays below the EWMA fail threshold for 3 additional consecutive trips.	≤ 0.40 (EWMA Re-Pass Threshold)				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Low Voltage (Not Sealed Fuel System)	P0452	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too low out of range.	The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~-3736 Pa).	< 0.15 volts (3.0 % of Vref or ~ 1,681 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples 12.5 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit High Voltage (Not Sealed Fuel System)	P0453	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too high out of range.	FTP sensor signal The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~-3736 Pa).	> 4.85 volts (97 % of Vref or ~ -4,172 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples 12.5 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Intermittent (Not Sealed Fuel System)	P0454	This DTC will detect intermittent tank vacuum sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	If an abrupt change in tank vacuum is detected the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that a refueling event occurred. If a refueling is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem. An abrupt change is defined as a change in vacuum: in the span of 1.0 seconds. But in 12.5 msec. A refueling event is confirmed if the fuel level has a persistent change of for 30 seconds.	> 112 Pa < 249 Pa 10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes and the canister vent solenoid is closed		This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Large Leak Detected (Not Sealed Fuel System)	P0455	This DTC will detect a weak vacuum condition (large leak or purge blockage) in the EVAP system. Purge valve is controlled (to allow purge flow) and vent valve is commanded closed.	Purge volume while Tank vacuum After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time. Weak Vacuum Follow-up Test (fuel cap replacement test) Weak Vacuum Test failed. Passes if tank vacuum Note: Weak Vacuum Follow-up Test can only report a pass.	> 10 liters ≤2,740 Pa ≥2,740 Pa	Fuel Level System Voltage BARO Purge Flow No active DTCs: Cold Start Test If ECT > IAT, Startup temperature delta (ECT- IAT): Cold Test Timer Startup IAT Startup ECT Weak Vacuum Follow-up Test This test can run following a weak vacuum failure or on a hot restart.	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts ≥ 70 kPa ≥ 3.80 % MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454 ≤ 8 °C ≤ 1,000 seconds 4 °C≤Temperature≤ 30 °C ≤ 35 °C	Once per cold start Time is dependent on driving conditions Maximum time before test abort is 1,000 seconds Weak Vacuum Follow-up Test With large leak detected, the follow-up test is limited to 1,300 seconds. Once the MIL is on, the follow-up test runs indefinitely.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Performance (For use on vehicles with a single fuel tank)	P0461	This DTC will detect a fuel sender stuck in range in the primary fuel tank.	Delta fuel volume change over an accumulated 149 miles.	< 3 liters	Engine Running No active DTCs:	VehicleSpeedSensor_FA	250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Low	P0462	This DTC will detect a fuel sender stuck out of range low in the	Fuel level Sender % of 5V range	< 10 %			100 failures out of 125 samples	Type B, 2 Trips
Voltage		primary fuel tank.					100 ms / sample	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Fuel Level Sensor 1 Circuit High	P0463	This DTC will detect a fuel sender stuck out of range high in the	Fuel level Sender % of 5V range	> 60 %			100 failures out of 125 samples	Type B, 2 Trips
Voltage		primary fuel tank.					100 ms / sample	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Intermittent (Not Sealed Fuel System)	P0464	This DTC will detect intermittent fuel level sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	If a change in fuel level is detected, the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that an actual refueling event occurred. If a refueling event is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem. An intermittent change in fuel level is defined as: The fuel level changes by and does not remain for 30 seconds during a 600 second refueling rationality test.	10 % > 10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Open (ODM) (Not used on EREV)	P0480	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0691 may also set (Fan 1 Short to Ground).

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Open (ODM)	P0481	Diagnoses the cooling fan 2 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0693 may also set (Fan 2 Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Flow During Non- Purge (Not Sealed Fuel System)	P0496	This DTC will determine if the purge solenoid is leaking to engine manifold vacuum. This test will run with the purge valve closed and the vent valve closed.	Tank Vacuum for Test time	> 2,491 Pa 5 seconds ≥ refer to P0496: Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level Table in Supporting Tables.	Fuel Level System Voltage BARO Startup IAT Startup ECT Engine Off Time No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts ≥ 70 kPa 4 °C≤Temperature≤ 30 °C ≤ 35 °C ≥ 28,800.0 seconds MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0443 P0449 P0452 P0453 P0454	Once per cold start Cold start: max time is 1,000 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Low Engine Speed Idle System	P0506	This DTC will determine if a low idle exists	Filtered Engine Speed Error	> 91.00 rpm	Baro	> 70 kPa	Diagnostic runs in every 12.5 ms loop	Type B, 2 Trips
			filter coefficient	0.00300	Coolant Temp	> 60 °C and < 124 °C	Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	
					Engine run time	≥ 60 sec		
					Ignition voltage	32 ≥ volts ≥ 11		
					Time since gear change	≥ 3 sec		
					Time since a TCC mode change	> 3 sec		
					IAT	> -20 °C		
					Vehicle speed	≤ 1.24 kph		
					Commanded RPM delta	≤ 25 rpm		
					Idle time	> 10 sec		
					For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 90.00 pct < 15.00 pct		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						PTO not active Transfer Case not in 4WD LowState Off-vehicle device control (service bay control) must not be active. following conditions not TRUE: (VeTESR_e_EngSpdReql ntvType = CeTESR_e_EngSpdMinLi mit AND VeTESR_e_EngSpdReqR espType = CeTESR_e_NoSuggestio n) Clutch is not depressed TC_BoostPresSnsrFA ECT_Sensor_FA		
					No active DTCs	EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorCircuitFA EvapFlowDuringNonPurg e_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_F A IgnitionOutputDriver FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA FuelLevelDataFault LowFuelConditionDiagnos tic Clutch Sensor FA AmbPresDfltdStatus P2771		
					All of the above met for Idle time	> 10 sec		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Engine Speed Idle System	P0507	This DTC will determine if a high idle exists	Filtered Engine Speed Error	< -182.00 rpm	Baro	> 70 kPa	Diagnostic runs in every 12.5 ms loop	Type B, 2 Trips
			filter coefficient	0.00300	Coolant Temp	> 60 °C and < 124 °C	Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	
					Engine run time	≥ 60 sec		
					Ignition voltage	32 ≥ volts ≥ 11		
					Time since gear change	≥ 3 sec		
					Time since a TCC mode change	> 3 sec		
					IAT	> -20 °C		
					Vehicle speed	≤ 1.24 kph		
					Commanded RPM delta	≤ 25 rpm		
					For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 90.00 pct < 15.00 pct		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						PTO not active Transfer Case not in 4WD LowState Off-vehicle device control (service bay control) must not be active. following conditions not TRUE: (VeTESR_e_EngSpdReqIntvType = CeTESR_e_EngSpdMinLimit AND VeTESR_e_EngSpdReqRespType = CeTESR_e_NoSuggestion) Clutch is not depressed		
					No active DTCs	TC_BoostPresSnsrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorCircuitFA EvapFlowDuringNonPurg e_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_F A IgnitionOutputDriver_FA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						FuelLevelDataFaultLow FuelConditionDiagnostic Clutch SensorFA AmbPresDfltdStatus P2771		
					All of the above met for Idle time	> 10 sec		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Mutil- Functon Switch Circuit	P0564	Detect when cruise control multi-function switch circuit (analog) voltage is in an illegal range	Cruise Control analog circuit voltage must be in an "illegal range" or "between ranges" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 0.500 seconds	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Resume Circuit	P0567	Detects a failure of the cruise resume switch in a continously applied state	Cruise Control Resume switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 90.000 seconds	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Set Circuit	P0568	Detects a failure of the cruise set switch in a continously applied state	Cruise Control Set switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 90.000 seconds	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Input Circuit	P0575	Detects rolling count or protection value errors in Cruise Control Switch Status serial data signal	If x of y rolling count / protection value faults occur, disable cruise for duration of fault		Cruise Control Switch Serial Data Error Diagnostic Enable	1.00	5 / 10 counts	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Range/ Performance	P057B	057B This diagnostic monitors the Brake Pedal Position Sensor for a stuck in range failure			Brake Pedal Position Sensor Circuit Range / Performance Diagnostic Enable	1.00 ignition voltage > 10.00		MIL: Type A, 1 Trips
			Calculated EWMA value must be greater than calibratable theshold after calibratable number of tests have completed to report a "test passed" for P057B	EWMA value looked up in supporting table P057B KtBRKI_K_FastTestPointWeight as a function of calculated brake pedal position delta EWMA value is > 0.70	calculated brake pedal position delta sample counter > 250.00 for fast test OR calculated brake pedal position delta sample counter > 1,000.00 for slow test	calculated brake pedal position delta > 100.00 OR (for slow test) shift lever has been in park once this key cycle vehicle speed >= 5.00 accelerator pedal position < 5.00	total number of EWMA tests > 2.00	
			Calculated EWMA Value must be less than calibratable threshold after calibratable number of tests have completed to report a "test failed" for P057B. This test runs once per key cycle	EWMA value looked up in supporting table P057B KtBRKI_K_CmpltTestP ointWeight as a function of calculated brake pedal position delta EWMA value is less thatn 0.30	no DTC's active (P057C, P057D)	shift lever has been in park once this key cycle vehicle speed >= 5.00 accelerator pedal position < 5.00	total number of EWMA tests > 2.00	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Low	P057C	detects short to ground for brake pedal position sensor		5.00	Brake Pedal Position Sensore Low Voltage Diagnostic Enable	1.00	20 / 32.00 counts	MIL: Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit High	P057D	detects open circuit for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	95.00	Brake Pedal Position Sensore High Voltage Diagnostic Enable	1.00	20.00 / 32.00 counts	MIL: Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control	P0597	Diagnoses the T-stat Heater low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and	Run Crank Ignition in Range	= True	15 failures out of 30 samples	Type B, 2 Trips Note: In
Open Circuit			,	controller ground.	Engine not cranking Run Crank active	= True = True	1 sec/ sample	certian controlle
						- True	Continuous	rs P0598
					== Above is true and ==	=========		may also set
					Last Open Circuit Test	= not Indeterminate		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control	P0598	Diagnoses the T-stat Heater low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and	Run Crank Ignition in Range	= True	15 failures out of 30 samples	Type B, 2 Trips Note: In
Circuit Low			,	controller ground	Engine not cranking Run Crank active	= True = True	1 sec/ sample	certian controlle
					== Above is true and ==	=======================================	Continuous	rs P0597 may also set
					Last Ground Short Circuit Test	= not Indeterminate		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control Circuit High	P0599	Diagnoses the T-stat Heater low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Run Crank Ignition in Range Engine not cranking Run Crank active == Above is true and == Last Power Short Circuit Test	= True = True = True = True ====================================	15 failures out of 30 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if the calibration check sum is incorrect or the flash memory detects an uncorrectable error via the Error Correcting Code.	calculated checksum does not match the stored checksum value. Covers all software and calibrations. Calculated checksum detected during the first pass. 5 failures if the fault occurs after the first pass is complete. The Primary Processor's 254	Diagnostic runs continuously in the background.	Type A, 1 Trips			
			The Primary Processor's Error Correcting Code hardware in the flash memory detects an error. Covers all software and calibrations.	254 failures detected via Error Correcting Code			Diagnostic runs continuously via the flash hardware.	
			The Primary Processor's calculated checksum does not match the stored checksum value for a selected subset of the calibrations.	2 consecutive failures detected or 5 total failures detected.			Diagnostic runs continuously. Will report a detected fault within 200 ms.	
			The Secondary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	
				In all cases, the failure count is cleared when controller shuts down				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Not Programmed	P0602	This DTC will be stored if the PCM is a service PCM that has not been programmed.	Output state invalid		PCM State	= crank or run PCM is identified through calibration as a Service PCM	Diagnostic runs at powerup and once per second continuously after that	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Long Term Memory Reset	P0603	Non-volatile memory checksum error at controller power-up	Checksum at power-up does not match checksum at power-down				Diagnostic runs at powerup Diagnostic reports a fault if 1 failure occurs	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM RAM Failure	P0604 Indicates that the ECM has detected a RAM fault	Indicates that the primary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	Type A, 1 Trips	
		Indicates that the primary processor is unable to correctly read data from or write data to cached RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)		
		processor is unable to correctly read data from or write data to TPU RAM. Detects data read does not match data written >=	Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)					
			Indicates that the primary processor detects a mismatch between the data and dual data is found during RAM updates. Detects a mismatch in data and dual data updates >	0.44000 s			When dual store updates occur.	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Indicates that the primary processor detects an illegal write attempt to protected RAM. Number of illegal writes are >	65,534 counts			Diagnostic runs continuously (background loop)	
			Indicates that the secondary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Fault	P0606	Indicates that the ECM has detected an internal processor integrity fault	Loss or invalid message of SPI communication from the Secondary Processor at initialization detected by the Primary Processor or loss or invalid message of SPI communication from the Secondary Processor after a valid message was received by the Primary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was recieved		Run/Crank voltage >= 6.41 or Run/Crank voltage >= 11.00 , else the failure will be reported for all conditions	In the primary processor, 159 / 399 counts intermittent or 39 counts continuous; 39 counts continuous @ initialization. 12.5 ms /count in the ECM main processor	Type A, 1 Trips
		Loss or invalid message of SPI communication from the Primary Processor at initialization detected by the Secondary Processor or loss or invalid message of SPI communication from the Primary Processor after a valid message was received by the Secondary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was recieved			In the secondary processor, 20/200 counts intermittent or 0.1875 s continuous; 0.4750 s continuous @ initialization. 12.5 ms /count in the ECM secondary processor		
		Checks for stack over or underflow in secondary processor by looking for corruption of known pattern at stack boundaries. Checks number of stack over/ under flow since last powerup reset >=	5		KeMEMD_b_StackLimitTe stEnbl == 1 Value of KeMEMD_b_StackLimitTe stEnbl is: 1 . (If 0, this test is disabled)	variable, depends on length of time to corrupt stack		
		MAIN processor is verified by responding to a seed sent from the secondary with a key response to secondary. Checks number of incorrect keys	2 incorrect seeds within 8 messages, 0.2000 seconds		ignition in Run or Crank	150 ms for one seed continually failing		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			received > or Secondary processor has not received a new within time limit					
			Time new seed not received exceeded			always running	0.450 seconds	
			MAIN processor receives seed in wrong order			always running	3 / 17 counts intermittent. 50 ms/count in the ECM main processor	
			2 fails in a row in the Secondary processor's ALU check			KePISD_b_ALU_TestEnbl d == 1 Value of KePISD_b_ALU_TestEnbl d is: 1. (If 0, this test is disabled)	25 ms	
			2 fails in a row in the Secondary processor's configuration register masks versus known good data			KePISD_b_ConfigRegTes tEnbId == 1 Value of KePISD_b_ConfigRegTes tEnbId is: 1. (If 0, this test is disabled)	12.5 to 25 ms	
			Secondary processor detects an error in the toggling of a hardware discrete line controlled by the MAIN processor: number of discrete changes > = or < = over time window(50ms)	7 17		KePISD_b_MainCPU_SO H_FItEnbld == 1 Value of KePISD_b_ConfigRegTes tEnbld is: 1 . (If 0, this test is disabled) time from initialization >= 0.4875 seconds	50 ms	
			memory and complement memory do not agree				0.19 seconds	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Software background task first pass time to complete exceeds			Run/Crank voltage > 6.41	360.000 seconds	
			2 fails in a row in the MAIN processor's ALU check			KePISD_b_ALU_TestEnbl d == 1 Value of KePISD_b_ALU_TestEnbl d is: 1. (If 0, this test is disabled)	25 ms	
			2 fails in a row in the MAIN processor's configuration register masks versus known good data			KePISD_b_ConfigRegTes tEnbId == 1 Value of KePISD_b_ConfigRegTes tEnbId is: 1. (If 0, this test is disabled)	12.5 to 25 ms	
			Checks number of stack over/under flow since last powerup reset >=	5		KeMEMD_b_StackLimitTe stEnbl == 1 Value of KeMEMD_b_StackLimitTe stEnbl is: 1 . . (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			Voltage deviation >	0.4950		KePISD_b_A2D_CnvrtrTe stEnbId == 1 Value of KePISD_b_A2D_CnvrtrTe stEnbId is: 1. (If 0, this test is disabled)	5 / 10 counts or 0.150 seconds continuous; 50 ms/count in the ECM main processor	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occured since last	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_FlashECC_ CktTestEnbl == 1 Value of KeMEMD_b_FlashECC_ CktTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			controller initialization. Counter >=					
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occured since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_RAM_ECC_CktTestEnbl == 1 Value of KeMEMD_b_RAM_ECC_CktTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to write flash to RAMvariable, depends on length of time to write flash to RAM	
			MAIN processor DMA transfer from Flash to RAM has 1 failure			KePISD_b_DMA_XferTest EnbId == 1 Value of KePISD_b_DMA_XferTest EnbId is: 0. (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM	
			Safety critical software is not executed in proper order.	>= 1 incorrect sequence.		Table, f(Loop Time). See supporting tables: Program Sequence Watch Enable f(Loop Time) (If 0, this Loop Time test is disabled)	Fail Table, f(Loop Time). See supporting tables: PSW Sequence Fail f (Loop Time)	
							Sample Table, f (Loop Time)See supporting tables: PSW Sequence Sample f(Loop Time)	
							counts	
							50 ms/count in	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							the ECM main processor	
			MAIN processor determines a seed has not changed within a specified time period within the 50ms task.	Previous seed value equals current seed value.		KePISD_b_SeedUpdKey StorFitEnbl == 1 Value of KePISD_b_SeedUpdKey StorFitEnbl is: 1. (If 0, this test is disabled)	Table, f(Loop Time). See supporting tables: Last Seed Timeout f (Loop Time)	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Control Circuit Open - For 3 DTC implementati on only	P0615	Diagnoses the starter relay high side driver circuit for circuit faults	Voltage high during driver off states (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Run/Crank Voltage Engine Speed	Voltage ≥ 11 volts ≥ 0 RPM	8 failures out of 10 samples 50 ms / sample	Type C, No MIL Not "Special Type C" Note: In certain controlle rs P0617 may also set (Starter Relay Control Short to Power)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Control Circuit Low	P0616	Diagnoses the starter relay high side driver circuit for circuit faults	Voltage low during driver on state (indicates short to ground)	Short to Ground: ≤ 0.5 Ω impedance between signal and	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples	Type C, No MIL
Voltage				controller ground	Engine Speed	≥0RPM	50 ms / sample	Not "Special Type C"

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Control Circuit High Voltage	P0617	Diagnoses the starter relay high side driver circuit for circuit faults	Voltage high during driver off states (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Run/Crank Voltage Engine Speed	Voltage ≥ 11 volts ≥ 0 RPM	8 failures out of 10 samples 50 ms / sample	Type C, No MIL Not "Special Type C" Note: In certain controlle rs P0615 may also set (Starter Relay Control Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control	P0627	Diagnoses the fuel pump relay control high side driver circuit for	Voltage high during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples	Type B, 2 Trips
Circuit Open		circuit faults		controller ground	Engine Speed	≥0 RPM	250 ms / sample	Note: In certain controlle rs P0629 may also set (Fuel Pump Relay Control Short to Power)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit Low Voltage	P0628	Diagnoses the fuel pump relay control high side driver circuit for circuit faults	Voltage low during driver on state (indicates short to ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage Engine Speed	Voltage ≥ 11 volts ≥ 0 RPM	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control	P0629	Diagnoses the fuel pump relay control high side driver circuit for	Voltage high during driver off state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples	Type B, 2 Trips
Circuit High Voltage		circuit faults		controller power	Engine Speed	≥0RPM	250 ms / sample	Note: In certain controlle rs P0627 may also set (Fuel Pump Relay Control Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module EEPROM Error	P062F	Indicates that the NVM Error flag has not been cleared	The next write to NVM will not succeed or the assembly calibration integrity check failed.		Ignition State	= unlock/accessory, run, or crank	1 test failure Diagnostic runs once at powerup	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VIN Not Programmed or Mismatched - Engine Control Module (ECM)	P0630	This DTC checks that the VIN is correctly written	At least one of the programmed VIN digits	= 00 or FF	OBD Manufacturer Enable Counter	= 0	250 ms / test Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #1 Circuit	P0641	Detects a continuous or intermittent short on the 5 volt reference circuit #1		4.875 5.125 0.0495		Run/Crank voltage > 6.41	19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Open - For 3 DTC implementati on only	P0650	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11 volts	20 failures out of 25 samples 250 ms / sample	Type B, No MIL Note: In certain controlle rs P263A may also set (MIL Control Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #2 Circuit	P0651	Detects a continuous or intermittent short on the 5 volt reference circuit #2		4.875 5.125 0.0495		Run/Crank voltage > 6.41	19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Bank 1	P0660	Diagnoses the Intake Manifold Tuning (IMT) Valve low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: >= 200K Ohms impedance between signal and controller ground	Powertrain Relay Voltage Engine Speed	>= 11.00 Volts >= 400 RPM	32 failures out of 40 samples 1 sample every 12.5 msec	Type B, 2 Trips Note in certain controlle rs P0661 may also set (Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Low Voltage Bank 1)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Low Voltage Bank 1	P0661	Diagnoses the Intake Manifold Tuning (IMT) Valve low side driver circuit for circuit faults	Voltage low during driver off state (indicates short-to-ground or open circuit)	Short to ground: <= 0.5 Ohms impedance between signal and controller ground Open Circuit: >= 200K Ohms impedance between signal and controller ground	Powertrain Relay Voltage Engine Speed	>= 11.00 Volts >= 400 RPM	32 failures out of 40 samples 1 sample every 12.5 msec	Type B, 2 Trips Note in certain controlle rs P0660 may also set (Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Bank 1)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit High Voltage Bank 1	P0662	Diagnoses the Intake Manifold Tuning (IMT) Valve low side driver circuit for circuit faults	Voltage low during driver on state (indicates short- to-power)	Short to power: <= 0.5 Ohms impedance between signal and controller power	Powertrain Relay Voltage Engine Speed	>= 11.00 Volts >= 400 RPM	32 failures out of 40 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Open - For 3 DTC implementati on only	P0685	Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω ohms impedance between signal and controller ground	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0686 may also set (Powertr ain Relay Control Short to Ground).

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Low	P0686	Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0685 may also set (Powertr ain Relay Control Open Circuit).

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Powertrain Relay Control (ODM) High	P0687	powertrain relay control	on state (indicates short	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Feedback Circuit High	P0690	This DTC is a check to determine if the Powertrain relay is functioning properly.	Powertrain Relay Voltage	>= 4.00 volts will increment the fail counter	Powertrain relay commanded "OFF"	>= 2.00 seconds	50 failures out of 63 samples	Type B, 2 Trips
					No active DTCs:	PowertrainRelayStateOn_ FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Low Voltage (ODM)	P0691	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short- to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0480 may also set (Fan 1 Open Circuit).

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit High Voltage (ODM)	P0692	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	`	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Low Voltage (ODM)	P0693	Diagnoses cooling fan 2 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short- to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0481 may also set (Fan 2 Open Circuit).

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Cooling Fan 2 Relay Control Circuit High Voltage (ODM)	P0694	Diagnoses the cooling fan 2 relay control low side driver circuit for circuit faults	on state (indicates short	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #3 Circuit	P0697	Detects a continuous or intermittent short on the 5 volt reference circuit #3		4.875 5.125 0.0495		Run/Crank voltage > 6.41	19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Control Module (FPCM) Requested MIL Illumination	P069E	Monitors the FPCM MIL request line to determine when the FPCM has detected a MIL illuminating fault.	Fuel Pump Control Module Emissions- Related DTC set			Time since power-up > 3 seconds	Continuous	Type A, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #4 Circuit	P06A3	Detects a continuous or intermittent short on the 5 volt reference circuit #4		4.875 5.125 0.0495		Run/Crank voltage > 6.41	19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 1 Performance	P06B6	This diagnostic checks for a fault with the internal test circuit used only for the '20 kHz' method of the Open Circuit Diagnostic	FFT Diagnostic Output	> OpenTestCktThrshMin and < OpenTestCktThrshMax See Supporting Tables	Diagnostic Enabled? Engine Run Time Engine Speed Cumlative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above) Engine Air Flow	Yes ≥ 2.0 seconds > 570 RPM and < 5,000 RPM ≥ 200 Revs ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient Weight Coefficient = 0.0100 Updated each engine event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Control Module (TCM) Requested MIL Illumination	P0700	Monitors the TCM MIL request line to determine when the TCM has detected a MIL illuminating fault.	Transmission Emissions- Related DTC set			Time since power-up > 3 seconds	Continuous	Type A, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Traction Control Torque Request Circuit	P0856	Determines if torque request from the EBTCM is valid	Serial Communication 2's complement message - (\$140 for PPEI2 or \$1C9 for PPEI3, \$1CA/\$1C6 for Hybrid))	Message <> 2's complement of message	Serial communication to EBTCM (U0108) Power Mode	No loss of communication	Count of 2's complement values not equal >= 16	Type C, No MIL
					Engine Running	= Run = True	every received message	
			OR Serial Communication message (\$140 for PPEI2 or \$1C9 for PPEI3, \$1CA/ \$1C6 for Hybrid)) rolling count value	Message rolling count value <> previous message rolling count value plus one	Status of traction in GMLAN message (\$4E9)	= Traction Present	6 rolling count failures out of 10 samples Performed on every received message	
			OR Too many minimum limit torque request transitions occur from TRUE to FALSE to TRUE within a time period	Requested torque intervention type toggles from not increasing request to increasing request			>= 3 multi- transitions out of 5 samples. Performed every 200 ms	
			Torque request greater than torque request diagnostic maximum threshold	> 250 Nm for engine based traction torque system, OR > 1,000,000 Nm for axle based traction torque system			Performed on every received message	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (naturally aspirated)	P1101	Determines if there are multiple air induction problems affecting airflow and/or manifold pressure.	Filtered Throttle Model Error AND (ABS(Measured Flow – Modeled Air Flow) Filtered OR ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 500 kPa*(g/s) > 15 grams/sec > 25.0 kPa) > 25.0 kPa	Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 7,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 125 Deg C > -20 Deg C < 125 Deg C >= 0.25 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM See "Residual Weight Factor" tables.	Calculation are performed every 12.5 msec	Type B, 2 Trips
					No Active DTCs:	MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Pending DTCs:	IAT_SensorFA EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Low	P11C2	Detects a continuous short to power in the Humidity Sensor circuit	Humidity Duty Cycle	<= 5.0 %	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit High	P11C3	Detects a continuous open or short to low in the Humidity Sensor circuit	Humidity Duty Cycle	>= 95.0 %	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Intermittent	P11C4	Detects a noisy or erratic humidity sensor input	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current Humidity reading - Humidity reading from 100 milliseconds previous)	> 80 % 10 consecutive Humidity samples	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	4 failures out of 5 samples Each sample takes 1.00 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Emissions Reduction System Fault	P1400	Model based test computes power from exhaust flow and thermal energy resulting from elevated idle speed and retarded spark advance. Detects if the cold start emission reduction system has failed resulting in the delivered power being out of range.	Average desired accumulated exhaust power - Average actual accumulated exhaust power (too much energy delivered to catalyst) Average desired accumulated exhaust power - Average actual accumulated exhaust power (too little energy delivered to catalyst) (EWMA filtered)	< -32.00 KJ/s (high RPM failure mode) > 6.50 KJ/s (low RPM failure mode)	To enable the diagnostic, the Cold Start Emission Reduction Strategy must be Active per the following: Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following: Catalyst Temperature AND Engine Run Time OR Engine Run Time OR Engine Run Time OR Barometric Pressure	< 300.00 degC > -10.00 degC <= 40.00 degC >= 70.00 KPa >= 700.00 degC >= 30.00 seconds > CatalystLightOffExtende dEngineRunTimeExit This Extended Engine run time exit is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details. < 70.00 KPa	Runs once per trip when the cold start emission reduction strategy is active Frequency: 100ms Loop Test completes after 10 seconds of accumulated qualified data.	EWMA Based - Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					OBD Manufacturer Enable Counter	0		
					Vehicle Speed	< 1.2 MPH		
					Allow diagnostic to calculate residual in an off-idle state. If the value of the OffIdleEnable is equal to 1 then the "DriverOffAccelPedal" will not be checked. However, if the value of OffIdleEnable is 0 then driver must be off the accel pedal	0 (A value of 1 allows diagnostic to run and calculate the residual while off idle. A value of 0 requires calculation of the residual at idle)		
					A change in throttle position (tip-in/tip-out) will initiate a delay in the calculation of the average qualified residual value. Therefore: When the Pedal Close Delay Timer is: the diagnostic will continue the calculation.	> 5.00 seconds		
					For Manual Transmission vehicles:	Clutch Pedal Top of Travel Achieved and Clutch Pedal Bottom of Travel Achieved. Refer to the "Clutch Pedal Top of Travel Achieved criteria" and "Clutch Pedal Bottom of Travel Achieved criteria" section of the "Supporting Tables" tab criteria		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					The diagnostic will delay calculation of the residual value and potentially weight the residual calculation differently based on engine run time. This is to ensure the diagnostic is operating in idle speed control as well as during the peak catalyst light off period. The time weighting factor must be:	> 0 These are scalar values that are a function of engine run time. Refer to ColdStartDiagnosticDel ayBasedOnEngineRunTime and the cal axis, ColdStartDiagnosticDel ayBasedOnEngineRunTimeCalAxis in the "Supporting Tables" for details.		
					General Enable: DTC's Not Set:	AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFP		
						CrankSensorFaultActive FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA EngineMisfireDetected_F A Clutch Sensor FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA 5VoltReferenceMAP_OO		
						R_Flt TransmissionEngagedStat e FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EngineTorqueInaccurate		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Engine Speed Request	P150C	Determines if engine speed request from the TCM is valid	Serial Communication rolling count value	+ 1 from previous \$19D message (PTEI3)	Diagnostic enable bit	1	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips
Circuit			Transmission engine speed protection	not equal to 2's complement of transmission engine speed request + Transmission alive rolling count	Engine run time	0.50 sec		
					# of Protect Errors	16 protect errors out of 10 samples		
					# of Alive Rolling Errors	5 rolling count errors out of 10 samples		
					No idle diagnostic 506/507 code	IAC_SystemRPM_FA		
					No Serial communication loss to TCM	(U0101)		
					Engine Running	= TRUE		
					Power mode	Run Crank Active		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Steady State Actuation Fault	P1516	Detect an inablity to maintain a steady state throttle position	The absolute difference between desired and indicated throttle position is >	2.00 percent		Run/Crank voltage > 6.41 Ignition voltage failure is false (P1682) TPS minimum learn is not active and Throttle is being Controlled Throttle is considered in a steadystate condition when the desired throttle position over a 12.5 ms period is < 0.25 percent for a settling time period > 4.00 s	0.49 ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation	P1682	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage & the Powertrain Relay Ignition Voltage	Run/Crank – PT Relay gnition >	3.00 Volts		Powertrain commanded on AND (Run/Crank voltage > Table, f(IAT). See supporting tables: PT Relay Pull-in Run/Crank Voltage f(IAT) OR PT Relay Ignition voltage > 5.50) AND Run/Crank voltage > 5.50 .	240 / 480 counts or 0.1750 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Redundant Memory Performance	P16F3	Detect Processor Calculation faults due to RAM corruptions, ALU failures and ROM failures	Desired Throttle Area calculated does not equal its redundant calculation	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	Type A, 1 Trips
		cases: If the individual diagnostic threshold is equal to 2048 ms, this indivudual case is not applicable. If any of the following cases are X out of Y diagnostics and the fail (x) is greater than the sample (Y), this individual case is also	Equivance Ratio torque compensation exceeds threshold	-60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	_
		not applicable.	Absolute difference between Equivance Ratio torque compensation and its dual store out of bounds given by threshold	60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	-
		Absolute difference of Accessory torque and its redundant calculation is out of bounds given by threshold range	60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Filtered Air-per-cylinder and its redundant calculation is out of bounds given by threshold range	114.30 mg	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	_
			Absolute difference between the previous Final Advance and the current Final Advance not Adjusted for Equivalence Ratio is out of bounds given by threshold range	13.38 degrees		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	-
			Torque Learn offset is out of bounds given by threshold range	High Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	_

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold 0.00 Nm			multipier	
			One step ahead calculation of air-per-cylinder and two step ahead is greater than threshold	80.00 mg		Engine speed > 500 rpm	Up/down timer 428 ms continuous, 0.5 down time multipier	
			Difference between Unmanaged Spark and PACS Spark is greater than threshold	13.38 degrees	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded Predicted Engine Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multipier	
			Zero pedal axle torque is out of bounds given by threshold range	High Threshold 1,832.62 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Creep Coast Axle Torque is out of bounds given by threshold range	High Threshold 1,832.62 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Absolute difference of Friction torque and its redundant calculation is out of bounds given by threshold range	60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multipier	
			Arbitrated Air-Per-Cylinder filter coefficient is out of bounds given by threshold range		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Launch spark is active but the launch spark redundant path indicates it should not be active	N/A		Engine speed < 7,800.00 or 7,900.00 rpm (hysteresis pair)	Up/down timer 128 ms continuous, 0.5 down time multipier	_
			Rate limited vehicle speed and its dual store do not equal	N/A		Time since first CAN message with vehicle speed >= 0.500 sec	10 / 20 counts; 25.0msec/count	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Preload Throttle Area and its dual store do not equal	N/A	Ignition State	Accessory, run or crank AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multipier	-
			Commanded engine torque due to fast actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded engine torque due to slow actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	-
			TOS to wheel speed conversion factor is out of bounds given by threshold	High Threshold:	Ignition State	Accessory, run or crank	255/6 counts; 25.0msec/count	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			range	T/C Range Hi 0.10 T/C Range Lo Low Threshold: 1.10 T/C Range Hi 0.10 T/C Range Lo				
			TOS to wheel speed conversion factor and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	
			Cylinders active greater than commanded	2 cylinders		Engine run flag = TRUE > 2.00 s Number of cylinder events since engine run > 24 No fuel injector faults	Up/down timer 128 ms continuous, 0.5 down time multipier	

ode			Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				active		
	Transfer case neutral request from four wheel drive logic does not match with operating conditions	N/A	Ignition State	Accessory, run or crank Transfer case range valid and not over-ridden FWD Apps only	32/6 counts; 25.0msec/count	-
	Transfer case neutral and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	255/6 counts; 25.0msec/count	-
	Driver progression mode and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	-
		request from four wheel drive logic does not match with operating conditions Transfer case neutral and its dual store do not equal Driver progression mode and its dual store do not	request from four wheel drive logic does not match with operating conditions Transfer case neutral and its dual store do not equal Driver progression mode and its dual store do not	request from four wheel drive logic does not match with operating conditions Transfer case neutral and its dual store do not equal Driver progression mode and its dual store do not	Transfer case neutral request from four wheel drive logic does not match with operating conditions Transfer case range valid and not over-ridden FWD Apps only Transfer case neutral and its dual store do not equal Driver progression mode and its dual store do not	Transfer case neutral request from four wheel drive logic does not match with operating conditions Transfer case neutral and its dual store do not equal Driver progression mode and its dual store do not equal N/A Ignition State Accessory, run or crank Accessory, run or crank Accessory, run or crank Accessory, run or crank Driver progression mode and its dual store do not equal N/A Ignition State Accessory, run or crank Up/down timer 475 ms continuous, 0.5 down time

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Predicted torque for uncorrected zero pedal determination is greater than calculated limit.	Table, f(Engine, Oil Temp). See supporting tables + 60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Engine Predicted Request Without Motor is greater than its redundant calculation plus threshold	59.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Engine Immediate Request Without Motor is greater than its redundant calculation plus threshold	59.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Positive Torque Offset is greater than its redundant calculation plus threshold OR	60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Positive Torque Offset is less than its redundant calculation minus threshold					
			Commanded Predicted Engine Request is greater than its redundant calculation plus threshold	60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Hybrid Predicted Crankshaft Request is greater than its redundant calculation plus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	-
			Commanded Hybrid Immediate Crankshaft	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048	-
			Request is less than its redundant calculation minus threshold	Nill			ms continuous, 0.5 down time multipier	
			Regeneration Brake Assist is not within a specified range	Brake Regen Assist < 0 Nm or Brake Regen Assist >	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous.	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				0.00 Nm			0.5 down time multipier	
			Cylinder Spark Delta Correction exceeds the absolute difference as compared to Unadjusted Cylinder Spark Delta	13.38 degrees	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Cylinder Torque Offset exceeds step size threshold OR 2. Sum of Cylinder	1. 60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			OR				0.5 down	time

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Capacity Minimum Immediate Without Motor is greater than its dual store plus threshold		Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	-
			Engine Capacity Minimum Engine Off is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Engine Capacity Minimum Engine Immediate Without Motor is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Immediate Engine Request is greater than its redundant calculation plus threshold	60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	-
			PTO Torque Request exceeds allowed rate limited PTO Torque Request	7.50 Nm/25ms	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	-
			Engine Speed Lores Intake Firing (event based) calculation does not equal its redundant	N/A		Engine speed greater than 0rpm	Up/down timer 128 ms continuous, 0.5	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			calculation				down time multipier	
			Engine Speed Lores Intake Firing timing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Idle speed control calculated predicted minimum torque request exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: Speed Control External Load f(Oil Temp, RPM) + 60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Idle speed control calculated predicted minimum torque without reserves exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: Speed Control External Load f(Oil Temp, RPM) + 60.00	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Nm				
			Difference between Driver Requested Immediate Torque primary path and its secondary exceeds threshold	1,832.62 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	-
			Driver Immediate Request is less than its redundant calculation minus threshold	1,832.62 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	-
			Commanded Immediate Request is greater than its redundant calculation plus threshold	1,832.62 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR Commanded Immediate Request is less than its redundant calculation minus threshold					
			Commanded Immediate Response Type is set to Inactive	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Difference between Cruise Axle Torque Arbitrated Request and Cruise Axle Torque Request exceeds threshold	229.08 Nm		Cruise has been engaged for more than 4.00 seconds	Up/down timer 2,048 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired engine torque request greater than redundant calculation plus threshold	59.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Engine min capacity above threshold	60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 138 ms continuous, 0.5 down time multipier	-
			No fast unmanaged retarded spark above the applied spark plus the threshold	Table, f(RPM,APC). See supporting tables: Delta Spark Threshold f (RPM,APC)		Engine speed greater than 0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	_
			Absolute difference of adjustment factor based on temperature and its dual store above threshold	2.76 m/s	Ignition State	Accessory, run or crank	Up/down timer 228 ms continuous, 0.5 down time multipier	_

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of redundant calculated engine speed above threshold	1,476 RPM		Engine speed greater than 0 RPM	Up/down timer 128 ms continuous, 0.5 down time multipier	
			After throttle blade pressure and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Speed Control's Preditcted Torque Request and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine oil temperature and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 438 ms continuous, 0.5 down time multipier	
			Desired throttle position greater than redundant calculation plus threshold	9.32 percent	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference of the rate limited pre-throttle pressure and its redundant calculation greater than threshold	0.06 kpa	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Throttle desired torque above desired torque plus threshold	60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired filtered throttle torque exceeds the threshold plus the higher of desired throttle torque or modeled throttle torque	60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Torque feedback proportional term is out of allowable range or its dual store copy does not match	High Threshold 30.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	-
				Low Threshold -30.00 Nm				
			Torque feedback integral term magnitude or rate of change is out of allowable range or its dual store	High Threshold 56.25 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5	<u> </u>

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			copy do not match	Low Threshold -60.00 Nm Rate of change threshold 3.75 Nm/loop			down time multipier	
			Difference of Final Torque feedback proportional plus integral term and its redundant calculation is out of bounds given by threshold range	High Threshold 60.00 Nm Low Threshold -60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Difference of torque desired threttle area and	High Threshold	Ignition State	Accessory, run or crank	Up/down timer	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			its redundant calculation is out of bounds given by threshold range	0.50 % Low Threshold - 0.50 %			ms continuous, 0.5 down time multipier	
			Difference of torque model coefficients and its redundant calculation is out of bounds given by threshold range	High Threshold 0.0002100 Low Threshold - 0.0002100	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Difference of base friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 60.00 Nm Low Threshold -60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Accessory drive friction torque is out of bounds given by threshold range	High Threshold 60.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			AC friction torque is greater than commanded by AC control software or less than threshold limit	High Threshold 20.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Difference of Oil temperature delta friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold - 60.00 Nm				
			Generator friction torque is out of bounds given by threshold range	High Threshold 60.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Supercharger friction torque is out of bounds given by threshold range	High Threshold 60.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Filtered Torque error magnitude or its increase rate of change is out of allowable range or its dual store copy do not match	High Threshold 60.00 Nm Low Threshold -60.00 Nm Rate of change threshold 3.75 Nm/loop		Engine speed >0rpm MAF, MAP and Baro DTCs are false	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Torque error compensation is out of bounds given by threshold range	High Threshold 60.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Delta Torque Baro compensation is out of bounds given by threshold range	High Threshold 5.30 Nm Low Threshold -2.19 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			1. Difference of reserve torque value and its redundant calculation exceed threshold OR 2. Reserve request does not agree with operating conditions or Difference of final predicted torque and its redundant calculation exeed threshold OR 3. Rate of change of reserve torque exceeds threshold, increasing direction only OR 4. Reserve engine torque above allowable capacity threshold	1. 59.00 Nm 2. N/A 3. 59.00 Nm 4. 59.00 Nm	3. & 4.: Ignition State	1. & 2.: Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 60.00 Nm 3. & 4.: Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Engine Vacuum and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference of the calculated Intake Manifold Pressure during engine event versus during time	Table, f(Desired Engine Torque). See supporting tables: Delta MAP Threshold		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			event is greater than threshold	f(Desired Engine Torque)			down time multipier	
			Min. Axle Torque Capacity is greater than threshold	0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Driver Predicted Request is greater than its redundant calculation plus threshold	1,832.62 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Driver Predicted Request is less than its redundant calculation minus threshold					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Cold Delta Friction Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Predicted torque for zero pedal determination is greater than calculated limit.	Table, f(Oil Temp, RPM). See supporting tables: Speed Control External Load f(Oil Temp, RPM) + 60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	-
			Commanded Predicted Axle Torque and its dual store do not match	1 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	-
			Steady State Estimated Engine Torque and its dual store are not equal	N/A		AFM not changing from Active to Inactive and preload torque not changing and one loop	Up/down timer 1,988 ms continuous, 0.5	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						after React command Engine speed >0rpm	down time multipier	
			Difference of Weighting factor for number of cylinders fueled and its redundant calculation is above threshold	0.26		Engine run flag = TRUE > 10.00 s	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Difference of minimum spark advance limit and its redundant calculation is out of bounds given by threshold range	13.38 degrees	Ignition State	Accessory, run or crank	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Difference of commanded spark advance and adjusted delivered is out of bounds given by threshold range	13.38 degrees		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	_

Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Absolute difference between Estimated Engine Torque and its dual store are above a threshold	60.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multipier	
		Absolute difference between Estimated Engine Torque without reductions due to torque control and its dual store are above a threshold	60.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multipier	
		Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by threshold range	13.38 degrees		Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 60.00 Nm	Up/down timer 428 ms continuous, 0.5 down time multipier	
			Absolute difference between Estimated Engine Torque and its dual store are above a threshold Absolute difference between Estimated Engine Torque without reductions due to torque control and its dual store are above a threshold Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by	Absolute difference between Estimated Engine Torque and its dual store are above a threshold Absolute difference between Estimated Engine Torque without reductions due to torque control and its dual store are above a threshold Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by	Absolute difference between Estimated Engine Torque and its dual store are above a threshold Absolute difference between Estimated Engine Torque without reductions due to torque control and its dual store are above a threshold Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by	Absolute difference between Estimated Engine Torque and its dual store are above a threshold Absolute difference between Estimated Engine Torque without reductions due to torque control and its dual store are above a threshold Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by threshold range threshold angle threshold angle threshold range threshold	Absolute difference between Estimated Engine Torque and its dual store are above a threshold Absolute difference between Estimated Engine Torque and its dual store are above a threshold Absolute difference between Estimated Engine Torque without reductions due to torque control and its dual store are above a threshold Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by threshold range when spark control greater than optimum to allow fast transitions for torque disturbances) >

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Engine Capacity Minimum Running Immediate Brake Torque Excluding Cylinder Sensitivity and its redundant calculation is out of bounds given by threshold range			Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multipier	
			One step ahead calculation of air-per-cylinder greater than two step ahead calculation by threshold for time	Threshold: Dynamically calculated based on current engine conditions Fault Pending Threshold: 100 ms		Engine speed > 500 rpm	Up/down timer 428 ms continuous, 0.5 down time multipier	
			Rate limited cruise axle torque request and its dual store do not match within a threshold	229.08 Nm	Ignition State	Accessory, run or crank	Up/down timer 163 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Component/ System	Fault Code	Monitor Description	1. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its redundant calculation is out of bounds given by threshold range OR 2. Absolute difference of Calculated accelerator pedal position compensated for carpet	1. 5.00 % 2. N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			learn and error conditions and its dual store do not equal					
			3. Absolute difference of Calculated accelerator pedal position and its dual store do not equal					
			Commanded axle torque is greater than its	1,832.62 Nm	Ignition State	Accessory, run or crank	Up/down timer	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			redundant calculation by threshold				ms continuous, 0.5 down time multipier	
			Commanded axle torque is less than its redundant calculation by threshold	-65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	_
			Preload timer and its redundant calculation do not equal	N/A	Ignition State	Accessory, run or crank AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multipier	_
			AC friction torque is greater than commanded by AC control software	20.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Engine Speed Lores	N/A		Engine speed >0rpm	Up/down timer	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Intake Firing (time based) calculation does not equal its redundant calculation				175 ms continuous, 0.5 down time multipier	
			Absolute difference of the calculated spark offset for equivalence ratio and its redundant cacluation is greater than a threshold	13.38 degrees		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	_
			Transmission Torque Request cacluations do not equal their dual stores	N/A		Run or Crank = TRUE > 0.50 s	16/32 counts; 25.0msec/count	_
			Absolute difference of the predicted motor torque ACS and its redundant cacluation is greater than a threshold	0.01 Nm			Up/down timer 2,048 ms continuous, 0.5 down time multipier	-
			Absolute difference of maximum throttle area and its redundant	15 mm2			Up/down timer 228 ms continuous,	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			cacluation is greater than a threshold				0.5 down time multipier	
			Absolute difference of Desired TIAP and its redundant cacluation is greater than a threshold	5.00 kPa			Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Stuck Open	P2070	Detects an Intake Manifold Tuning Valve that is stuck in the open position	Time after the close command without the Intake Manifold Tuning Valve reaching the closed position	>= 5.00 seconds	Intake Manifold Tuning Valve is commanded closed No Active DTCs:	P0660 P2077 P2078	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Stuck Closed	P2071	Detects an Intake Manifold Tuning Valve that is stuck in the closed position	Time after the open command without the Intake Manifold Tuning Valve reaching the open position	>= 5.00 seconds	Intake Manifold Tuning Valve is commanded closed No Active DTCs:	P0660 P2077 P2078	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Position Sensor/ Switch Circuit Range/ Performance	P2076	Detects an Intake Manifold Tuning Valve Actuator that has initiated its learn sequence for too long a period of time, or too many times per ignition cycle	Valve Position AND Valve Position for a time period OR Valve Position AND Valve Position for a time period for	>= 5.0 % <= 35.0 % >= 5.0 seconds >= 5.0 % <= 35.0 % >= 0.2 seconds >= 10 times in one ignition cycle	Powertrain Relay Voltage Powertrain Relay Voltage Engine Run Time	>= 11.00 Volts <= 999.00 Volts >= 1.0 seconds	Executes every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Position Sensor/ Switch Circuit Low	P2077	Detects a continuous open or short to low in the Intake Manifold Tuning Valve Position Sensor circuit	Valve Position	>= 95.0 %	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Position Sensor/ Switch Circuit High	P2078	Detects a continuous short to high in the Intake Manifold Tuning Valve Position Sensor circuit	Valve Position	<= 5.0 %	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Low– Bank 1	P2088	Diagnoses the VVT system high side driver circuit for circuit faults.	commanded state of the driver and the actual state	Short to ground: ≤ 0.5 Ω to a voltage source within the Vehicle Ground Voltage Range relative to PWRGND	System supply voltage is within limits. Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	failures out of 25 samples250 ms / sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit High – Bank 1	P2089	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply voltage is within limits. Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	failures out of 25 samples250 ms / sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Low – Bank 1	P2090	Diagnoses the VVT system high side driver circuit for circuit faults.	commanded state of the driver and the actual state	≤ 0.5 Ω to a voltage source within the Vehicle Ground	System supply voltage is within limits. Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples250 ms / sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit High – Bank 1	P2091	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply voltage is within limits. Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	failures out of 25 samples250 ms / sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Low Limit Bank 1 (Too Rich)	P2096	Determines if the post catalyst O2 sensor based fuel control system has reached it's low limit authority, indicating a rich emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too rich, the post catalyst O2 integral offset control is decreased. This results in lean bias fuel control in an attempt to correct the rich post O2 voltage.		>= 350 counts per 500 sample counts Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration The following conditions must be true for > 1.0 seconds: Ambient Air Pressure Engine AirFlow Intake Manifold Pressure Induction Air Temperature Start-up Coolant Temp. PTO Intrusive diag. fuel control Long Term Secondary Fuel Trim Enabled (see "Long Term Secondary Fuel Trim Enable Criteria" in Supporting Tables) High Vapor Conditions No Fault Active for:	No No Yes No No No >= 70 kPa >= 0.0 g/s <= 10,000.0 >= 0 kPa <= 200 >= -20 deg. C <= 200 >= -20 deg. C Not Active Not Active Not Active Not Active Not Present AmbientAirDefault AIR System FA Ethanol Composition Sensor FA ECT_Sensor_FA EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorFA CamSensorAnyLocationF A EvapEmissionSystem_FA	Frequency: Continuous Monitoring in 100ms loop. Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System	Code				The above general enable conditions must be true for: Minimum accumulated counts in each cell required before counters will increment: Deceleration Idle Cruise Light Acceleration Heavy Acceleration Fail counter will increment if sample counter increments AND	EvapFlowDuringNonPurg e_FA FuelTankPressureSnsrCkt _FA EvapPurgeSolenoidCircuit _FA EvapSmallLeak_FA EvapVentSolenoidCircuit_FA FuelInjectorCircuit_FA MAF_SensorFA MAF_SensorFTKO MAP_EngineVacuumStat us EngineMisfireDetected_F A A/F Imbalance Bank1 O2S_Bank_1_Sensor_1_ FA O2S_Bank_1_Sensor_2_ FA > 1.0 seconds 300 300 100 100 100 300		Illum.
					Post oxygen sensor control integral offset (in			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					mV) is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Heavy Acceleration	<= 10 (control min.= 0) 10 (control min.= 0) -465 (control min.= -475) -465 (control min.= -475) -465 (control min.= -475) > 720 mV 720 mV 720 mV 720 mV 720 mV 720 mV		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System High Limit Bank 1 (Too Lean)	P2097	Determines if the post catalyst O2 sensor based fuel control system has reached it's high limit authority, indicating a lean emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too lean, the post catalyst O2 integral offset control is increased. This results in rich bias fuel control in an attempt to correct the lean post O2 voltage.	High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18 % for >= 1.0 seconds. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14 % for >= 5.0 seconds.	>= 350 counts per 500 sample counts Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	Same as P2096 except for the following: Fail counter will increment if sample counter increments AND Post oxygen sensor control integral offset (in mV) is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration	>= 75 (control max.= 100) 75 (control max.= 100) 450 (control max.= 475) 450 (control max.= 475) 450 (control max.= 475) < 620 mV 620 mV 620 mV 620 mV 620 mV 620 mV	Frequency: Continuous Monitoring in 100ms loop. Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Throttle Actuator Position Performance	P2101	1) Detect a throttle positioning error2) Throttle control is driving the throttle in the incorrect direction3) Throttle control exceeds the reduced power limit	Difference between measured throttle position and modeled throttle position > OR Difference between modeled throttle position and measured throttle position and measured throttle position >	9.32 percent 9.32 percent	TPS minimum learn is not active and Throttle is being Controlled and (Engine Running or Ignition Voltage > or Ignition Voltage >)	Run/Crank voltage > 6.41 Ignition voltage failure is false (P1682) TPS minimum learn is not active and Throttle is being Controlled AND ((Engine Running AND Ignition Voltage > 5.50) OR Ignition Voltage > 11.00)	not)	Type A, 1 Trips
			Throttle Position >	38.37 percent		Powertrain Relay voltage > 6.41 TPS minimum learn is active		
			Throttle Position >	40.00 percent		Powertrain Relay voltage > 6.41 Reduced Power is True	11 counts; 12.5 ms/count in the primary processor	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle return to default	P2119	Throttle unable to return to default throttle position after deenergizing ETC motor.	(Normalized TPS1 Voltage > AND Normalized TPS2 Voltage > On the main processor) OR (Normalized TPS1 Voltage < AND Normalized TPS2 Voltage < On the main processor)	1.6470 1.7570 1.1370 1.0270		Throttle de-energized for Actuator, Controller, or Ignition Faults (P21104, P2100, P2101, P2102, P2103, P1682, P0068, P16F3) No TPS circuit faults PT Relay Voltage > 5.500 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	0.4969 s	Type C, No MIL
			(Normalized TPS1 Voltage > AND Normalized TPS2 Voltage > On the main processor) OR (Normalized TPS1 Voltage < AND Normalized TPS2 Voltage < On the main processor)	1.6470 1.7570 1.1370 1.0270		Throttle de-energized for Battery Saver Mode Engine not running No TPS circuit faults PT Relay Voltage > 5.500 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	1.5000 s	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Lo	P2122	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage <	0.4625		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips
						circuit (P06A3)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Hi	P2123	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage >	4.7500		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Lo	P2127	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage <	0.3250		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P0697)	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Hi	P2128	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage >	2.6000		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P0697)	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position (TP) Sensor 1-2 Correlation	P2135	Detects a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor	Difference between TPS1 displaced and TPS2 displaced >	7.022 % offset at min. throttle position with a linear threshold to 9.664 % at max. throttle position		Run/Crank voltage > 6.41 No TPS sensor faults (P0122, P0123, P0222, P0223) No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts or 58 counts continuous; 3.125 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min TPS1) and (normalized min TPS2) >	5.000 % Vref		Run/Crank voltage > 6.41 No TPS sensor faults (P0122, P0123, P0222, P0223) No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts or 58 counts continuous; 3.125 ms/count in the main processor	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1-2 Correlation	P2138	Detects a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor	Difference between APP1 displaced and APP2 displaced >	5.000 % offset at min. pedal position with a linear threshold to 10.001 % at max. pedal position		No APP sensor faults (P2122, P2123,P2127, P2128) 15 counts continuous, ms/count in	counts intermittent or 15	Type A, 1 Trips
			Difference between (normalized min APP1) and (normalized min APP2) >	5.000 % Vref		Run/Crank voltage > 6.41 No APP sensor faults (P2122, P2123,P2127, P2128) No 5V reference errors or faulst for # 3 & # 4 5V reference circuits (P06A3, P0697)	19/39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Minimum Throttle Position Not Learned	P2176	TP sensors were not in the minmum learn window after multiple attempts to learn the minimum.	During TPS min learn on the Main processor, TPS Voltage >	0.9550		Run/Crank voltage > 6.41 TPS minimum learn is active	2.0 secs	Type A, 1 Trips
			Number of learn attempts >	10 counts				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling System Performance	P2181	This DTC detects thermostat malfunction (i.e. stuck open)	Engine Coolant Temp (ECT) is ≤ commanded temperature minus 11 Deg C and normalized ratio is ≤ than 0.65. When above is present for more than 0 seconds, fail counts start. Engine total airgrams is accumulated when 11 ≤ AirFlow ≤ 100 grams per second. == Ratio Definition:===		No Active DTC's Engine not run time Engine run time Fuel Condition ECT at Power Up	MAF_SensorFA IAT_SensorFA THMR_RCT_Sensor_Ckt _FA THMR_ECT_Sensor_Ckt _FA ≥ 7,200 seconds 120 ≤ Time ≤ 1,400 seconds Ethanol ≤ 100 % -40.0 ≤ ECT ≤ 45.0 °C	225 failures out of 280 samples 1 sec/ sample Once per ignition key cycle	Type B, 2 Trips
			Current temp difference between ECT and RCT minus PwrUp difference divided by total airgrams. Note: Minimum total airgrams is 500.0 grams.		IAT min T-Stat Heater duty cycle commanded Airflow	-40.0 ≤ ECT ≤ 45.0 °C -7 °C ≤ IAT ≤ 60 °C. ≤ 10 % 11.0 ≤ Airflow ≤ 100.0 gps		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Bank 1 Air- Fuel Ratio Imbalance	P219A	This monitor determines if a cylinder-to-cylinder airfuel ratio imbalance is present on bank 1.	Filtered Ratio > Note: The input to this metric is the pre catalyst oxygen sensor voltage. This voltage is used to generate a Variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to the air-fuel ratio imbalance (variance is	0.23 If the diagnostic has reported a failure on the prior trip, the Filtered Ratio must fall below 0.25 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing when the Filtered Ratio remains near the initial	System Voltage Fuel Level Engine Coolant Temperature Cumulative engine run time Diagnostic enabled at Idle (regardless of other	no lower than 11.0 Volts for more than 0.2 seconds > 10.0 percent AND no fuel level sensor fault > -20 degrees C > 30.0 seconds	Minimum of 1 test per trip, up to 6 tests per trip during RSR or FIR. The front O2 sensor voltage is sampled once per cylinder event. Therefore, the time required to complete a	Type A, 1 Trips
			higher with an imbalance than without). Multiple samples are collected in making a decision. The observed Variance is dependant on engine speed and load and so	failure threshold of 0.23.	operating conditions) Engine speed range Engine speed delta during a short term sample period	No 1,200 to 3,200 RPM <100 RPM	single test (when all enable conditions are met) decreases as engine speed increases. For example, 16.20 seconds of	
			each result is normalized for speed and load by comparing it to a known "good system" result for that speed and load, and generating a Ratio metric.		Mass Airflow (MAF) range Cumulative delta MAF during a short term sample period	10 to 100 g/s <5 g/s	data is required at 1000 rpm while double this time is required at 500 rpm and half this time is	
		The Ratio metric is calculated by selecting the appropriate threshold calibration from a 17x17 table (Supporting Table		Filtered MAF delta between samples Note: first order lag filter coefficient applied to MAF = 0.050	<0.20 g/s	required at 2000 rpm. This data is collected only when enable conditions are met, and as such		
		"Variance Threshold Bank1") and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table		Air Per Cylinder (APC) APC delta during short term sample period Filtered APC delta between samples	<pre>220 to 500 mg/cylinder <75 mg/cylinder <9.99 percent</pre>	significantly more operating time is required than is indicated above. Generally, a report will be		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		1	(Supporting Table		Note: first order lag filter		made within 5	
			"Normalizer Bank1").		coefficient applied to APC		minutes of	
			This quotient is then		= 0.100		operation.	
			multiplied by a quality					
			factor calibration from a		Spark Advance	0 to 60 degrees	For RSR or FIR,	
			17 x 17 table (Supporting			_	6 tests must	
			Table "Quality Factor		Throttle Area (percent of	2 to 100 percent	complete before	
			Bank1"). This result is		max)		the diagnostic	
			referred to as the Ratio.		·		can report.	
			Note that the quality factor		Intake Cam Phaser Angle	0 to 28 degrees		
			ranges between 0 and 1					
			and represents		Exhaust Cam Phaser	0 to 28 degrees		
			robustness to false		Angle			
			diagnosis in the current					
			operating region. Regions		Quality Factor (QF)	>= 0.99		
			with low quality factors		QF calibrations are			
			are not used.		located in a 17x17 lookup			
					table versus engine speed			
			Finally, a EWMA filter is		and load (Supporting			
			applied to the Ratio metric		Table "Quality Factor			
			to generate the Filtered		Bank1"). QF values less			
			Ratio malfunction criteria		than "1" indicate that we			
			metric. Generally, a		don't have 4sigma/2sigma			
			normal system will result		robustness in that region.			
			in a negative Filtered		The quality of the data is			
			Ratio while a failing		determined via statistical			
			system will result in a		analysis of Variance data.			
			positive Filtered Ratio.		, , , , , , , , , , , , , , , , , , , ,			
			[Fuel Control Status			
			The range of the Filtered		Closed Loop and Long	>= 1.2 seconds		
			Ratio metric is application		Term FT Enabled for:	(Please see "Closed		
			specific since both the			Loop Enable Criteria"		
			emissions sensitivity and			and "Long Term FT		
			relationship between			Enable Criteria" in		
			imbalance and the			Supporting Tables)		
			Variance metric are		AIR pump not on			
			application specific.		CASE learn not active			
					EGR - no device control,			
			Some applications may		no intrusive diagnostics			
			need to command a		EVAP - no device control,			
			unique cam phaser value		no intrusive diagnostics			
			before performing the		Engine OverSpeed			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			above calculations since cam phasing has been shown to have an impact on overall signal quality. This application Does Not Use this feature.		Protection Not Active Idle speed control normal PTO Not Active Injector base pulse width above min limit Rapid Step Response (RSR): RSR will trigger if the Ratio result from the last test is AND it exceeds the last Filtered ratio by Once triggered, the filtered ratio is reset to: Fast Initial Response (FIR): FIR will trigger when an NVM reset or code clear occurs. Once triggered, the filtered ratio is reset to: No Fault Active for:	>= 0.15 >= 0.10 0.00 EngineMisfireDetected_F A MAP_SensorFA ECT_Sensor_FA TPS_ThrottleAuthorityDef aulted FuelInjectorCircuit_FA AIR System FA EvapExcessPurgePsbl_F A CamSensorAnyLocationF A		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Performance (naturally aspirated)	P2227	Compares baro sensor to the calculated baro estimate (part throttle calculation or unthrottled MAP)	Difference between baro sensor reading and estimated baro when distance since last estimated baro update OR Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 15.0 kPa <= 0.06 miles > 20.0 kPa > 0.06 miles	Engine Run Time No Active DTCs:	> 0.00 seconds AmbPresSnsrCktFA ECT_Sensor_Ckt_FA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips
			Barometric Pressure OR Barometric Pressure	< 50.0 kPa > 115.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating No Active DTCs: No Pending DTCs:	> 6.0 seconds EngineModeNotRunTimer Error MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP	4 failures out of 5 samples 1 sample every 12.5 msec	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (non- boosted applications)	P2228	Detects a continuous short to low or open in either the signal circuit or the BARO sensor.	BARO Voltage	< 40.0 % of 5 Volt Range (2.0 Volts = 50.9 kPa)	Engine Run Time	> 0.00 seconds	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (non- boosted applications)	P2229	Detects an open sensor ground or continuous short to high in either the signal circuit or the BARO sensor.	BARO Voltage	> 90.0 % of 5 Volt Range (4.5 Volts = 115.0 kPa)	Engine Run Time	> 0.00 seconds	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Intermittent	P2230	Detects a noisy or erratic barometric pressure input	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current BARO reading - BARO reading from 12.5 milliseconds previous)	> 40 kPa 5 consecutive BARO samples	No Active DTCs:	AmbPresSnsrCktFA ECT_Sensor_Ckt_FA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA	10 failures out of 15 samples Each sample takes 0.06 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Lean Bank 1 Sensor 2	P2270	This DTC determines if the post catalyst O2 sensor is stuck in a normal lean voltage range and thereby can no longer be used for post oxygen sensor fuel control or for catalyst monitoring. The diagnostic is an intrusive test (during coast) which increases the delivered fuel to achieve the required rich threshold.	Post O2 sensor signal AND The Accumulated mass air flow monitored during the Stuck Lean Voltage Test	< 775 mvolts > 60 grams	B1S2 DTC's Not active this key cycle System Voltage ICAT MAT Burnoff delay Green O2S Condition	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA MAP_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013A, P013B, P013E, P013F, P2270 or P2271 10.0 < Volts < 32.0 = Not Valid = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips
					Low Fuel Condition Diag Pedal position	= False ≤ 3.0 %		
					Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)	1,500 ≤ RPM ≤ 2,800 1,400 ≤ RPM ≤ 2,900		
					Engine Airflow	2≤gps≤20		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Vehicle Speed to initially enable test Vehicle Speed range to	43.5≤ MPH ≤68.4		
					keep test enabled (after initially enabled)	40.4≤ MPH ≤71.5		
					Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State ==================================	0.92 ≤ C/L Int ≤ 1.08 = TRUE not in control of purge not in estimate mode = enabled = not active = not active ≥ 40.0 sec 550 ≤ °C ≤ 900 = DFCO possible ====================================		
					0.95≤ Fuel EQR ≤ 1.10		1	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Rich Bank 1 Sensor 2	P2271	This DTC determines if the post catalyst O2 sensor is stuck in a normal rich voltage range and thereby can no longer be used for post oxygen sensor fuel control or for catalyst monitoring. The diagnostic is an intrusive test which requests the DFCO mode to achieve the required lean threshold.	Post O2 sensor signal AND The Accumulated mass air flow monitored during the Stuck Rich Voltage Test	> 100 mvolts > 30 grams	B1S2 DTC's Not Active this key cycle System Voltage ICAT MAT Burnoff delay Green O2S Condition	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013A, P013B, P013E, P013F or P2270 10.0 < Volts < 32.0 = Not Valid = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips
					Low Fuel Condition Diag Engine Speed Engine Airflow Vehicle Speed Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell	= False 1,500 ≤ RPM ≤ 2,800 2 ≤ gps ≤ 20 43.5 ≤ MPH ≤ 68.4 0.92 ≤ C/L Int ≤ 1.08 = TRUE not in control of purge not in estimate mode = enabled		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Take Off EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State DTC's Passed ========= After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	= not active = not active = not active ≥ 40.0 sec 550 ≤ °C ≤ 900 DFCO possible = P2270 (and P2272 if applicable) = P013E (and P014A if applicable) = P013A (and P013C if applicable) ===================================		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Bank 1	P2430	This DTC detects a stuck in range pressure sensor signal when the AIR pump is commanded on.	Average Pressure Error AND Signal Variation	< 0.50 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRSysPressSnsrB1CktL oFA AIRSysPressSnsrB1CktHi FA ControllerProcessorPerf_ FA	Stuck in range cumulative time > 5.0 seconds Frequency: Once per trip when SAI pump is commanded On	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Performance Bank 1	P2431	This DTC detects a skewed pressure sensor signal via a comparison of the AIR pressure sensor signal and estimated BARO, as well as an evaluation of the quality of the comparison.	Difference between AIR pressure sensor and BARO (Pump Commanded Off) or OR Difference between AIR pressure sensor and BARO (Pump Commanded On)	> 15.0 kPa < -15.0 kPa > 50.0 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Transfer Case not in 4WD Low Run/crank active No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRSysPressSnsrB1CktL oFA AIRSysPressSnsrB1CktHi FA MAF_SensorFA EngineMisfireDetected_F A ControllerProcessorPerf_ FA	Skewed sensor cumulative test weight > 30.0 seconds Continuous 6.25ms loop Skewed sensor cumulatative test weight is based on distance from the last Baro update. See Baro Skewed Sensor Weight Factor table.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Low Voltage Bank 1	P2432	This DTC detects an out of range low AIR pressure sensor signal	AIR Pressure Sensor signal	< 6 % of 5Vref for 800 failures out of 1,000 samples	No active DTCs:	ControllerProcessorPerf_ FA	1,000 samples (6.25 ms per sample) Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Hi Voltage Bank 1	P2433	This DTC detects an out of range high AIR pressure sensor signal	AIR Pressure Sensor signal	> 94 % of 5Vref for 800 failures out of 1,000 samples	No active DTCs:	ControllerProcessorPerf_ FA	1,000 samples (6.25 ms per sample) Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Shut-off Valve Stuck Open	P2440	This DTC detects if the AIR system control valve is stuck openThis test is run during Phase 2 (Pump commanded On, valve commanded closed)	Average Pressure Error or	< Bank 1 Valve Pressure Error table > 32 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Stability Time AIR diagnostic Phase 1 passed No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec > 0.5 seconds AIRSystemPressureSens or FA AIRValveControlCircuit FA AIRPumpControlCircuit FA MAF_SensorFAAmbientAi rDefault_NA IAT_SensorFAECT_Sens or_FA EngineMisfireDetected_F A CatalystSysEfficiencyLoB 1_FA CatalystSysEfficiencyLoB 2_FA ControllerProcessorPerf	Phase 2 Conditional test weight > 1.5 sec Frequency: Once per trip when AIR pump commanded On Conditional test weight is calculated by multiplying the following Factors: Phase 2 Baro Test Weight Factor, Phase 2 MAF Test Weight Factor, Phase 2 System Volt Test Weight Factor, Phase 2 Ambient Temp Test Weight Factor (see Supporting Tables)	Type B, 2 Trips
						FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pump Stuck On	P2444	This DTC detects if the SAI pump is stuck On. This test is run during Phase 3 (Pump commanded Off, valve commanded closed)	Average Pressure Error or	> Bank 1 Pump Pressure Error table < -32 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Stability Time AIR diagnostic Phase 1 passed AIR diagnostic Phase 2 passed No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for > 2.0 sec. < 5,000 RPM > 50 gm/s for > 3.0 sec. > 4.0 seconds Phase 3 cumulatative test weight is based on the distance from the last Baro update. See Baro Skewed Sensor Weight Factor table. AIRSystemPressureSens orFA AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRPumpControlCircuit FA AMF_SensorFA ECT_SensorFA ECT_SensorFA ECT_SensorFA CatalystSysEfficiencyLoB 1_FA CatalystSysEfficiencyLoB 2_FA ControllerProcessorPerf_FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA	Phase 3 Cumlatative test weight > 2.0 sec. Frequency: Once per trip when AIR pump commanded On	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Control Torque Request	P2544	Determines if the torque request from the TCM is valid	Protect error - Serial Communication message - (\$199 - PTEI3)	Message <> two's complement of message	Diagnostic enabled/ disabled	Enabled	>= 16 Protect errors during key cycle.	Type B, 2 Trips
Circuit			OR		Power Mode	= Run	Performed on every received message	
			Rolling count error - Serial Communication message (\$199 - PPEI3) rolling count value	Message <> previous message rolling count value + one	Ignition Voltage	> 6.41 volts	>= 6 Rolling count errors out of 10 samples.	
		OR		Engine Running Run/Crank Active	= True > 0.50 Sec	Performed on every received message		
			Range Error - Serial Communication message - (\$199 - PTEI3) TCM Requested Torque Increase	> 450 Nm	No Serial communication loss to TCM (U0101)	No loss of communication	>= 6 range errors out of 10 samples. Performed on every received message	
			OR Multi-transition error - Trans torque intervention type request change	Requested torque intervention type toggles from not increasing request to increasing request			>= 4 multi- transitions out of 5 samples. Performed every 200 msec	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Off Timer Performance	P262B	This DTC determines if the hardware timer does not initialize or count properly. There are two tests to ensure proper functioning of the timer: Count Up Test (CUT) and Range Test (RaTe). Count Up Test (CUT): Verifies that the HWIO timer is counting up with the proper increment.	Count Up Test: Time difference between the current read and the previous read of the timer	>1.50 seconds			Count Up Test: 4 failures out of 20 samples 1 sec / sample Continuous while run/crank is not active and until controller shutdown is initiated.	Type B, 2 Trips
		Range Test (RaTe): When the run/crank is not active both the hardware and mirror timers are started. The timers are compared when module shutdown is initiated or run/crank becomes active.	Range Test: The variation of the HWIO timer and mirror timer is	> 25 %.			Range Test: Once per trip when controller shutdown is initiated or run/ crank becomes active.	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Low	P263A	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11 volts	20 failures out of 25 samples 250 ms / sample	Type A, No MIL Note: In certain controlle rs P0650 may also set (MIL Control Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) High	P263B	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	on state (indicates short	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11 volts	20 failures out of 25 samples 250 ms / sample	Type A, No MIL NO MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communicati on Bus A Off	a BUS A off co	This DTC monitors for a BUS A off condition	Bus off failures exceeds before the sample time of is reached	5 counts (equivalent to 0.06 seconds) 0.56 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Ignition voltage	Not Active on Current Key Cycle Enabled Not Active Not Active >= 11.00 or >= 6.41	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips
					Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds CAN hardware is bus OFF for	= run = 0 (1 indicates enabled) = Active > 11.00 > 0.1125 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With TCM	U0101	This DTC monitors for a loss of communication with the transmission control module	Message is not received from controller for Message \$0AB Message \$0BD Message \$0C7 Message \$0F9 Message \$189 Message \$19D Message \$1AF Message \$1BE Message \$1BF Message \$1F5 Message \$4C9	≥ 10.0 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is	Not Active on Current Key Cycle Enabled Not Active Not Active >= 11.00 or >= 6.41 = run = 0 (1 indicates enabled) = Active > 11.00	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					not active for	> 0.4000 seconds		
					U0101	Not Active on Current Key Cycle		
					тсм	is present on the bus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Fuel Pump Control Module	U0109	This DTC monitors for a loss of communication with the fuel pump control module	Message is not received from controller for Message \$1EB Message \$4D9	≥ 10.0 seconds ≥ 10.0 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is	Not Active on Current Key Cycle Enabled Not Active Not Active >= 11.00 or >= 6.41 = run = 0 (1 indicates enabled) = Active > 11.00	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					not active for	> 0.4000 seconds		
					U0109	Not Active on Current Key Cycle		
					Fuel Pump Control Module	is present on the bus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Anti- Lock Brake System (ABS) Control Module	U0121	This DTC monitors for a loss of communication with the Anti-Lock Brake System (ABS) Control Module (Non-OBD Module ID 243).	loss of communication with the onti-Lock Brake system (ABS) Control odule (Non-OBD odule ID 243). Message \$0C1 ≥ 10.0 seconds Message \$0D1 ≥ 10.0 seconds Message \$1C6 ≥ 10.0 seconds Message \$1C7 ≥ 10.0 seconds Message \$1C7 ≥ 10.0 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Ignition voltage	Not Active on Current Key Cycle Enabled Not Active Not Active >= 11.00 or >= 6.41	Diagnostic runs in 12.5 ms loop	Type C, No MIL "Special Type C"	
					Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual	= run = 0 (1 indicates enabled) = Active > 11.00		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Network Management is not active for	>0.4000 seconds		
					U0121	Not Active on Current Key Cycle		
					Anti-Lock Brake System Control Module	is present on the bus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Body Control Module	U0140	This DTC monitors for a loss of communication with the Body Control Module.	Message is not received from controller for Message \$0F1 Message \$12A Message \$1E1 Message \$1F1 Message \$1F3 Message \$3C9 Message \$3CB Message \$3F1 Message \$451 Message \$4D7 Message \$4E1 Message \$4E9	≥ 10.0 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is	Not Active on Current Key Cycle Enabled Not Active Not Active >= 11.00 or >= 6.41 = run = 0 (1 indicates enabled) = Active > 11.00 > 0.4000 seconds	Diagnostic runs in 12.5 ms loop	Type C, No MIL "Special Type C"

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					not active for			
					U0140	Not Active on Current Key Cycle		
					Body Control Module	is present on the bus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Output Speed Sensor (TOSS)	P0502	No activity in the TOSS circuit	TOSS Raw Speed	≤ 60 RPM	Engine TorqueMinimum Throttle openingEngine Speed Ignition voltage PTO EngineTorqureInaccurate	90.0 ≤ N-M ≤ 8,191.8 ≥ 15.0 % 1,500 ≤ RPM ≤ 6,500 9.0 ≤ Volts ≤ 16.00 not active KeETQC_b_MinTransRe medial = TRUE: MSFR_b_EngMisfDtctd_F A, MAFR_b_MAF_SnsrTFT KO, MAPR_b_MAP_SnsrTFT KO KeETQC_b_MinTransRe medial = FALSE: FULR_b_FuelInjCkt_TFT KO, MAFR_b_MAF_SnsrTFT	≥ 4.5 sec	Type B, 2 Trips
					P0503	KO, XOYR_b_SecurityFlt, Not failed this key cycle		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Output Speed Sensor (TOSS)	P0503	TOSS Signal Intermittent	Loop-to-Loop change in TOSS	≥ 350 RPM	Raw Output Speed Output Speed change Time since transfer case range change Ignition voltage Engine Speed Vehicle Speed PTO	> 200 RPM for ≥ 2.0 sec ≤ 150 RPM for ≥ 2.0 sec ≥ 3.0 sec 9.0 ≤ Volts ≤ 16.00 200 ≤ RPM ≤ 7,500 for ≥ 5.0 seconds ≤ 250.00 MPH for ≥ 5.0 sec not active	≥ 3.3 sec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Range / Performance	P0806	Detects if Clutch Pedal Position Sensor is Stuck in a range indicative of a vehicle NOT in gear, when the vehicle is determined to be in gear. Gear determination is made by verifying that the ratio of engine RPM versus Transmission Output Speed (N/TOS) represents a valid gear.	Filtered Clutch Pedal Position Error when the vehicle is determined to be in gear	> 3 %	N/TOS Ratio: Transfer Case: Vehicle speed: Engine Torque: Clutch Pedal Position: OR No Active DTCs:	Must match actual gear (i.e. vehicle in gear) Not in 4WD Low range > 18.6 MPH > EngTorqueThreshold (see Supporting Tables) < ResidualErrEnableLow (see Supporting Tables) > ResidualErrEnableHigh (see Supporting Tables) ClutchPstnSnsrCktHi FA ClutchPstnSnsrCktLo FA CrankSensor_FA Transmission Output Shaft Angular Velocity Validity VehicleSpeedSensor_FA	25 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Low	P0807	Detects Continuous Circuit Out-of-Range Low or Open	Clutch Position Sensor Circuit for		Engine Not Cranking System Voltage No active DTCs:	> 9.0 Volts	25 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Clutch Pedal Position Sensor Circuit High	P0808	Detects Continuous Circuit Out-of-Range High	Clutch Position Sensor Circuit for		Engine Not Cranking System Voltage No active DTCs:	> 9.0 Volts	25 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Not Learned	P080A	Detects Invalid Clutch Pedal Fully Applied Learn Position values	Fully Applied Learn Position OR	< 12.0 % > 35.0 %	OBD Manufacturer's Enable Counter	= 0	250 ms loop Continuous	Type A, 1 Trips

X11

Y11

X11

Y11

X10

Y10

X10

Y10

X9

Y9

X9

Y9

Closed Loop Enab	le Clarifi	cation: C	alibration	n values a	are in the	Support	ing Tables
Engine run time greater than							
:	RID ONLY	()					
AutoStart CoolantX1	X2	X3	X4	X5	X6	X7	X8
Close Loop Enable TimeY1	Y2	Y3	Y4	Y5	Y6	Y7	Y8
and							
KtFSTA_t_ClosedLoopTime							
Start-Up CoolantX1	X2	X3	X4	X5	X6	X7	X8
Close Loop Enable TimeY1	Y2	Y3	Y4	Y5	Y6	Y7	Y8
and pre converter 02 sensor voltage less							
than							
KfFULC_U_O2_SensorReadyThrsh							
Lo							
Voltage< XXX	XmilliVolt	ts					
for							
KcFULC_O2_SensorReadyEvents							
Time (events * 12.5 milliseconds) > XXX	Xevents						
and '———							
COSC (Converter Oxygen Storage Contro	I) not						
enabled	,						
and							
Consumed AirFuel Ratio is stoichiometry	i.e. not i	n compo	nent				
protection							
and							
POPD or Catalyst Diagnostic not intrusive	j						
and							
Turbo Scavenging Mode not							
enabled							
and							
All cylinders whose valves are active also	have th	eir iniect	ors				
enabled	maro in	ojoot	0.0				
and							
O2S_Bank_ 1_TFTKO, O2S_Bank_ 2_TFT	KO. Fuel	Iniector(Circuit FA	and			
CylnderDeacDriverTFTKO = False	, , , , , , , ,	,000010	• • • • • • • • • • • • • • • • • •				
Long Term FT Enable Criteria							
Long form i Linable Officia							

Closed Loop Enable Clarification: Calibration values are in the Supporting Tables Closed Loop Enable and Coolant greater than KfFCLL T AdaptiveLoCoolant Coolant> XXXXCelcius or less than KfFCLL_T_AdaptiveHiCoolant Coolant < XXXX Celcius land KtFCLL_p_AdaptiveLowMAP_Limit Barometric PressureX1 X2 X3 X5 X4 X6 X7 X8 X9 Y2 Y5 Manifold Air PressureY1 Y3 Y4 Y6 Y7 Y8 **Y9** and TPS_ThrottleAuthorityDefaulted = False and Flex Fuel Estimate Algorithm is not active land Excessive fuel vapors boiling off from the engine oil algorithm (BOFR) is not enabled land Catalyst or EVAP large leak test not intrusive Secondary Fuel Trim Enable Criteria Closed Loop Enable and KfFCLP U O2ReadyThrshLo Voltage< XXXXmilliVolts for KcFCLP Cnt O2RdyCyclesThrsh Time (events * 12.5 milliseconds) > XXXX events Long Term Secondary Fuel Trim

Enable Criteria

KtFCLP_t_PostIntglDisableTime

				,						,
Closed Loop Enal	ole Clarifi	cation: C	alibratio	n values	are in the	Support	ing Table	es		
Start-Up CoolantX1	X2	Х3	X4	X5	X6	X7	X8	X9	X10	X11
Post Integral Enable TimeY1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11
Plus										
KtFCLP_t_PostIntglRampInTime	\/O	\/O	3/4	\/F	\/O	\/ 7	1/0	\/O	V/40	V/44
Start-Up CoolantX1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Post Integral Ramp In TimeY1 and	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11
KeFCLP_T_IntegrationCatalystMax										
	XCelcius	1								
and	1X Ocicius									
KeFCLP_T_IntegrationCatalystMin										
	XCelcius									
and										
PO2S_Bank_1_Snsr_2_FA and										
PO2S_Bank_2_Snsr_2_FA = False										
and										
(KeFCLP_Pct_CatAccuSlphrPostDsbl										
Modeled converter sulfur percent < XXXX	Parcent									
modeled converter suital percent \ XXXX	i Giceiit									
and										
Post Integral < KaFCLP_U_SIphrIntglOfs	t_Thrsh)									
V avia: Boot O2 Sanoar										
X axis: Post O2 Sensor Y axis: Post O2 Mode										
Z: Post Integral threshold										
2. Fost integral tilleshold										

Supporting Table - P0101	P0106 P0121	P012B P0236	P1101 TPS Residual Weight Factor based on RPM
11 0 .			_

Description: P0101_P0106_P0121_P012B_P0236_P1101 TPS Residual Weight Factor based on RPM

y/x	0	1,500	2,200	2,500	2,700	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,250	5,625	7,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Supporting Table - P0101	P0106 P0121	P012B P0236	P1101 MAF Residual We	eight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAF Residual Weight Factor based on RPM

y/x	0	800	1,500	2,500	2,800	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,500	6,500	7,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.900	0.950	0.950	1.000	0.950	0.950

Supporting Table - P0101	P0106 P0121 P012B	P0236 P1101 MAF Resi	idual Weight Factor based on MAF Est

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAF Residual Weight Factor based on MAF Est

Ì	y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350
	1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Supporting Table - P0101 P010	6 P0121 P012B	P0236 P1101 MAP1	Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP1 Residual Weight Factor based on RPM

y/x	0	800	1,500	2,500	2,800	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,500	6,500	7,000
1	0.900	0.900	0.900	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Supporting Table - P0101 P0	106 P0121 P012E	B P0236 P1101 MAP2	Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP2 Residual Weight Factor based on RPM

y/x	0	800	1,500	2,500	2,800	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,500	6,500	7,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

Supporting Table - P0806 EngTorqueThreshold Table

Description: The diagnostic is inhibited if torque (NM) is less than this value. Prevents false fails in regions where false in-gear N/TOS ratios are possible due to low torque, where high torque would otherwise cause slip and prevent a valid in-gear state.

Notes: DTCs: P0806; Calibration Name: KtMTCl_M_TorqueEnable; Axis is Percent Clutch Pedal Position (%), 0% = bottom of pedal travel.

y,	/x	0.00	6.25	12.50	18.75	25.00	31.25	37.50	43.75	50.00	56.25	62.50	68.75	75.00	81.25	87.50	93.75	100.00
1		10.0	10.0	15.0	25.0	30.0	50.0	50.0	60.0	70.0	75.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Supporting Table - P0806 ResidualErrEnableLow Table

Description: Represents the lower threshold of a deadband where the diagnostic will be inhibited to prevent false fails due to clutch slip that can falsely indicate a valid in-gear N/TOS ratio.

Notes: DTCs: P0806; Calibration Name: KaMTCI_Pct_ResidErrCalcEnbLow; Axis identifies Gear, where "0" - "5" is gear 1 - 6, respectively; "6" is reverse and "7" is neutral

	y/x	0	1	2	3	4	5	6	7
ı	1	100.0	100.0	100.0	100.0	100.0	100.0	100.0	100.0

Supporting Table - P0806 ResidualErrEnableHigh Table

Description: Represents the upper threshold of a deadband where the diagnostic will be inhibited to prevent false fails due to clutch slip that can falsely indicate a valid in-gear N/TOS ratio.

Notes: DTCs: P0806; Calibration Name: KaMTCI_Pct_ResidErrCalcEnbHigh; Axis identifies Gear, where "0" - "5" is gear 1 - 6, respectively; "6" is reverse and "7" is neutral

y/x	0	1	2	3	4	5	6	7
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Supporting Table - Closed Loop	Enable Clarification - KtFSTA	t ClosedLoopTime

Description: Engine run time, as a function of startup coolant temperature, which must be exceeded to enable CLOSED LOOP.

Notes: Time in seconds

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	180.0	120.0	60.0	40.0	26.0	26.0	26.0	12.0	6.0	4.0	2.0	1.0	1.0	1.0	1.0	1.0	1.0

	Supporting Table - Closed Loop Enable Clarification - KtFCLL_p_AdaptiveLowMAP_Limit														
Description	Description: KtFCLL_p_AdaptiveLowMAP_Limit														
Notes: MA	AP in KPa														
y/x	65	70	75	80	85	90	95	100	105						
1	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0						

Supporting Table - Closed Loop Enable Clarification - KtFCLP_t_PostIntglDisableTime

Description: Disable integral offset after engine start for this amount of time.

Notes: Time in seconds

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	1,000.0	800.0	700.0	600.0	270.0	170.0	170.0	170.0	170.0	170.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

Supporting Table - Closed Loop Enable Clarification - KtFCLP_t_PostIntglRampInTime

Description: Time required to ramp integral offset to desired value.

Notes: Time in seconds

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

Supporting Table - Closed Loop Enable Clarification - KfFULC_U_O2_SensorReadyThrshLo					
Description: Lower limit checked against when determining if an oxygen sensor is in range					
Notes: Voltage in millivolts					
y/x 1					
1	1,000				

Supporting Table - Closed Loop Enable Clarification - KcFULC_O2_SensorReadyEvents					
Description: Number of times an oxygen sensor value must be in range before declaring it ready					
Notes: Time (events * 12.5 milliseconds)					
1/x					
1	40				

Supporting Table - Closed Loop Enable Clarification - KfFCLL_T_AdaptiveLoCoolant					
Description: LTM learning is inhibited if the engine coolant temperature is below this calibration.					
Notes: Degrees Celcius					
1					
1	40				

Supporting Table - Closed Loop Enable Clarification - KfFCLL_T_AdaptiveHiCoolant					
Description: LTM learning is inhibited if the engine coolant temperature is above this calibration.					
Notes: Degrees Celcius					
//x 1					
1	120				

13 OBDG02B Engine Diagnostics

Supporting Table - Closed Loop Enable Clarification - KfFCLP_U_O2ReadyThrshLo							
Description: Lower threshold defining not ready window for post oxygen sensor voltage.							
Notes: Voltage in millivolts							
y/x 1							
1	1,000						

Supporting Table - Closed Loop Enable Clarification - KcFCLP_Cnt_O2RdyCyclesThrsh							
Description: Number of post catalyst oxygen sensor samples which must be outside not ready window before post oxygen sensor is READY.							
Notes: Time (events * 12.5 milliseconds)							
y/x 1							
1	80						

13 OBDG02B E	Supporting Information						
Supporting Table - Closed Loop Enable Clarification - KeFCLP_T_IntegrationCatalystMax							
Description: Maximum allowed estimated catalytic converter temperature for post O2 integral terms to be updated.							
Notes: Modeled catalyst Temperature in Celcius							
y/x	1						
1	830						

Supporting Table - Closed Loop Enable Clarification - KeFCLP_T_IntegrationCatalystMin

Description: Minimum allowed estimated catalytic converter temperature to begin using post O2 integration correction terms. Converter temperature must remain above this threshold to ramp-in the post O2 integration adjustments. Once the ramp-in has started, a converter temperature below this threshold will freeze the ramp-in multiplier. Post O2 integration will not be allowed below this converter temperature

Notes: Modeled catalyst Temperature in Celcius

	y/x	1
1	1	450

Supporting Table - Closed Loop Enable Clarification - KeFCLP_Pct_CatAccuSlphrPostDsbl								
Description: Sulphur percent threshold above which post integral learning is disabled if the threshold criteria KaFCLP_U_SlphrIntglOfst_Thrsh is also met.								
Notes: Percent								
//x 1								
1	255							

Supporting Table - Closed Loop Enable Clarification - KaFCLP_U_SlphrIntglOfst_Thrsh

Description: Integral Offset voltage thresholds (bank and cell specific cals) used with KeFCLP_Pct_CatAccuSlphrPostDsbl to check for sulphur poisoning.

Notes: millivolts

y/x	CiOXYR_O2_PostCat1	CiOXYR_O2_PostCat2
CiFCLP_Decel	2,048	2,048
CiFCLP_Idle	2,048	2,048
CiFCLP_Cruise	2,048	2,048
CiFCLP_LightAccel	2,048	2,048
CiFCLP_HeavyAccel	2,048	2,048

Supporting Table - P00B6_Fail if power up ECT exceeds RCT by these values

Description: KtTHMD_T_DCRD_FastFailTempDiff

Notes: X axis is IAT Temperature at Power up (° C), Z axis is the Fast Failure temp difference (° C) The 17 X-axis breakpoints for the table below are (L to R) -40, -28, -16, -4, 8, 20, 32, 44, 56, 68, 80, 92, 104, 116, 128, 140 and 152. Note: Remove for applications with single coolant sensor

ľ	y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
١		80	80	80	60	60	40	40	30	30	30	30	30	30	30	30	30	30

Supporting Table - P0116_Fail if power up ECT exceeds IAT by these values

Description: KtECTD_T_HSC_FastFailTempDiff

Notes: X axis is IAT Temperature at Power up (° C), Z axis is the Fast Failure temp difference (° C)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	106	94	82	70	60	46	40	30	30	30	30	30	30	1.3(1)	37	49	61

Supporting Information

Supporting Table - P0128	Maximum Accumulate	d Energy for Start-up	ECT conditions - Primary
- 1 1 1 5 · · · · · · · · · · · · · · · ·			,

Description: Maximum Total Energy transferred to Cooling System for Ambient and Start-up ECT conditions (Primary Test)

Notes: Z axis is the cooling system energy failure threshold (kJ), X axis is ECT Temperature at Power up (° C), (Deluxe version)

y/x	-20	-5	10	30	45	60	75
1	13,400	13,400	13,400		9,200	7,400	5,600

Supporting Table - P0128_Maximum Accumulated Energy for Start-up ECT conditions - Alternate

Description: Maximum Total Energy transferred to Cooling System for Ambient and Start-up ECT conditions (Alternate Test)

Notes: Z axis is the cooling system energy failure threshold (kJ), X axis is ECT Temperature at Power up (° C), (Deluxe version)

y/x	-20	-5	10	30	45	60	75
1	13,220	13,220	11,300	8,740	6,820	4,900	4,900

Supporting Table - P1400_ColdStartDiagnosticDelayBasedOnEngineRunTime

Description: Quality weight-based on engine run time. This allows adjustment of the weighting factors at various engine run times in order to prevent the updating of the cumulative quality timer or to change the value of the average qualified residual energy calculation to prevent false Fails of the diagnostic under circumstances inappropriate to update the calculation of the average qualified residual value.

Notes: KtCSED_K_TimeWght - This is used for P1400.

ı	y/x	0	2	3	4	7	10	15	20	30
١	1	0	0	1	1	1	1	1	1	1

	Supp	orting Table -	P1400_Cold	StartDiagnost	icDelayBased	lOnEngineRui	nTimeCalAxis	;							
Description: This	escription: This is the x-axis for the KtCSED_K_TimeWght calibration table. Refer to the description for KtCSED_K_TimeWght for details.														
Notes: KnCSED_	t_TimeWght - This	is used for P1400.													
y/x	1	2	3	4	5	6	7	8	9						
1	0	2	3	4	7	10	15	20	30						

Supporting Table - P0011_CamPosErrorLimIc1

Description: P0011 - Cam Position Error Limit for performance diagnostic

Notes: KtPHSD_phi_CamPosErrorLimIc1

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

Supporting Table - P0014_CamPosErrorLimEc1

Description: P0014 - Cam Position Error Limit for performance diagnostic

Notes: KtPHSD_phi_CamPosErrorLimEc1

		_ : : : : :															
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

Supporting Table - P0011_StablePositionTimelc1

Description: P0011 - Delay after transient move

Notes: KtPHSD_t_StablePositionTimeIc1

110103.	ואוו ווטט_נ	_Otabler o	SitionThine	101													
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
1,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
1,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
3,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
3,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0

Supporting Table - P0014_StablePositionTimeEc1

Description: P0014 - Delay after transient move

Notes: KtPHSD_t_StablePositionTimeEc1

NOICS.	תורווטט_נ	_Otablel C	3 III O I I I I I I I														
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
1,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
1,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
3,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
3,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
1,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0

Supporting Table - P0011_PerfMaxIc1

Description: P0011 - Range of phaser travel where diagnostic cannot make a decision if both desired & measured positions are greater than

Notes:

v/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
<u>. </u>	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
3	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
4	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
5	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
7	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
3	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
)	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
10	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
l1	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
12	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
13	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
14	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
5	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
16	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
17	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0

Supporting Table - P0014_PerfMaxEc1

Description: P0014 - Range of phaser travel where diagnostic cannot make a decision if both desired & measured positions are greater than

Notes:

	=																
y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
2	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
3	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
5	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
3	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
,	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
}	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
)	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
0	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
1	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
2	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
3	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
4	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
5	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
6	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
17	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5

OBD GF	ROUP: 130	S OBDG02B		ng Table	e - P00′	16 P001			Cam C		on Oil Te	empera	ture Th	reshold		ONS STDS	: CARB SUL
Descrip	tion: KtEF	PSI_t_RtnF	HomeDlyLn	nt													
Notes:																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	300.0	300.0	160.0	18.0	18.0	18.0	18.0	10.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0

Supporting Table - P0442: Engine Off Time Before Vehicle Off Maximum as a Function of Estimated Ambient Temperature Table

Description: Data is Engine Off Time Before Vehicle Off Maximum Table (in seconds) and Axis is Estimated Ambient Coolant in Deg C

Notes: KtEONV_t_EngOffTimeBefVehOffMax

y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	44	44	44	44	68	82	105	153	320	480	480	480	480	480	480	480	480

Supporting Table - P0496: Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level Table

Description: Data is Purge Valve Leak Test Engine Vacuum Test Time (in seconds) and Axis is Fuel Level in %

Notes: KtEVPD_t_PVLT_EngineVacTimeCold

y/x	0	6	12	19	25	31	37	44	50	56	62	69	75	81	87	94	100
1	100	100	80	75	70	65	60	60	60	60		55	50	45	40	30	30

Supporting Table - P0461, P2066, P2636: Transfer Pump Enable Time Table

Description: Data is TransferPumpOnTimeLimit (in seconds) and Axis is Fuel Level in %

Notes: KtFLVC_t_XferFuelPmpOnTmLim

y/x	0	3	6	9	13	16	19	22	25	28	31	34	38	41	44	47	50	53	56	59	63	66	69	72	75	78	81	84	88	91	94	97	100
1	30	35	40	45	50	55	60	65	70	85	90	95	135	135	160	160	260	260	360	360	360	360	360	460	460	460	460	460	460	460	460	460	460

Supporting Table - P0442: EONV Pressure Threshold (Pascals) Table

Description: Data is EONV Pressure Threshold in Pascals, X axis (horizontal) is fuel level in % from 0 to 100 with step size 6.25, and Y axis (vertical) is temperature in deg C from -10 to 80 with step size 5.625

Notes: KtEONV_p_PressureThreshold

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
2	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
3	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
4	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
5	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
6	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
7	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
8	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
9	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
10	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
11	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
12	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
13	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
14	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
15	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
16	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
17	-398.4	-398.4	-398.4	-398.4	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3

Supporting Table - P219A Variance Threshold Bank1 Table

Description: Bank 1 lookup table of Variance metric used to calculate the Ratio for the current sample period

Notes: DTCs: P219A; Calibration Name: KtFABD_U_VarThresh1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,200	4,000	4,500	5,000	6,000
40	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00
80	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00
120	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00
160	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00
200	200.00	200.00	200.00	200.00	200.00	7.25	7.25	7.25	7.25	7.25	7.25	6.50	6.50	200.00	200.00	200.00	200.00
240	200.00	200.00	200.00	200.00	200.00	7.25	7.25	6.75	6.50	6.50	6.50	6.50	6.50	200.00	200.00	200.00	200.00
280	200.00	200.00	200.00	200.00	200.00	7.50	7.50	6.75	7.50	7.00	7.00	6.50	6.50	200.00	200.00	200.00	200.00
320	200.00	200.00	200.00	200.00	200.00	9.25	9.00	7.50	7.50	8.25	7.50	7.50	7.50	200.00	200.00	200.00	200.00
360	200.00	200.00	200.00	200.00	200.00	8.25	9.00	8.50	8.50	7.75	7.00	8.00	8.00	200.00	200.00	200.00	200.00
400	200.00	200.00	200.00	200.00	200.00	8.00	9.00	8.75	8.50	7.75	7.00	9.00	9.00	200.00	200.00	200.00	200.00
440	200.00	200.00	200.00	200.00	200.00	8.00	9.00	9.25	11.00	9.00	9.25	8.50	8.50	200.00	200.00	200.00	200.00
480	200.00	200.00	200.00	200.00	200.00	10.00	10.25	11.50	12.50	10.25	8.50	8.50	8.50	200.00	200.00	200.00	200.00
520	200.00	200.00	200.00	200.00	200.00	10.00	10.25	11.50	11.75	11.00	10.75	10.50	10.50	200.00	200.00	200.00	200.00
560	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	11.00	11.00	10.75	10.50	10.50	200.00	200.00	200.00	200.00
640	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00
720	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00
800	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00

Supporting Table - P219A Quality Factor Bank1 Table

Description: Bank 1 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

Notes: DTCs: P219A; Calibration Name: KtFABD_K_QualFactor1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

		•															
y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,200	4,000	4,500	5,000	6,000
40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
80	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
120	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
160	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
200	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
240	0.00	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
280	0.00	0.00	0.00	0.00	1.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
320	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
360	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
400	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
440	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
480	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
520	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
560	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
640	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
720	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
800	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

Supporting Table - P219A Normalizer Bank1 Table

Description: Bank 1 Normalizer table used in the calculation of the Ratio for the current sample period.

Notes: DTCs: P219A; Calibration Name: KtFABD_U_Normalizer1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

		•						· .			`	- /	· •				
y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,200	4,000	4,500	5,000	6,000
40	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00
80	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00
120	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00
160	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00
200	400.00	400.00	400.00	400.00	400.00	7.00	7.00	7.00	7.75	7.75	7.75	8.75	8.75	400.00	400.00	400.00	400.00
240	400.00	400.00	400.00	400.00	400.00	7.00	7.00	7.75	7.75	7.75	7.75	8.75	8.75	400.00	400.00	400.00	400.00
280	400.00	400.00	400.00	400.00	400.00	12.25	12.25	12.25	12.25	13.00	13.75	14.75	14.75	400.00	400.00	400.00	400.00
320	400.00	400.00	400.00	400.00	400.00	22.50	18.75	18.75	19.50	21.50	22.25	22.25	22.25	400.00	400.00	400.00	400.00
360	400.00	400.00	400.00	400.00	400.00	28.50	26.00	24.00	25.00	21.50	23.00	23.50	23.50	400.00	400.00	400.00	400.00
400	400.00	400.00	400.00	400.00	400.00	28.75	28.50	28.00	30.50	22.75	24.75	26.75	26.75	400.00	400.00	400.00	400.00
440	400.00	400.00	400.00	400.00	400.00	35.00	36.00	29.50	28.50	32.75	27.50	34.50	34.50	400.00	400.00	400.00	400.00
480	400.00	400.00	400.00	400.00	400.00	37.50	43.50	36.00	30.50	32.00	44.50	47.00	47.00	400.00	400.00	400.00	400.00
520	400.00	400.00	400.00	400.00	400.00	37.50	43.50	36.00	39.50	48.50	48.25	57.25	57.25	400.00	400.00	400.00	400.00
560	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	48.50	48.50	48.25	57.25	57.25	400.00	400.00	400.00	400.00
640	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00
720	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00
800	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00

CeFADD_e_SelectedNonPurgeCell

CeFADR_e_Cell15_PurgOffDecel

CeFADD_e_NonSelectedCell

Supporting Table - P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage

Description: Identifies which Long Term Fuel Trim Cell I.D.s are used for diagnosis. Only cells identified as "CeFADD_e NonSelectedCell" are not used for diagnosis. Notes: DTCs: P0171, P0172, P0174, P0175; Calibration Name: KaFADD_e_SelectCellSet; Axis is Long Term Fuel Trim Cell I.D. P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 1 CeFADR e Cell00 PurgOnAirMode CeFADR e Cell01 PurgOnAirMode CeFADR e Cell02 PurgOnAirMode y/x CeFADR_e_Cell03_PurgOnAirMode CeFADD_e_SelectedPurgeCell CeFADD_e_SelectedPurgeCell CeFADD_e_SelectedPurgeCell CeFADD_e_SelectedPurgeCell P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 2 y/x CeFADR_e_Cell04_PurgOnAirMode CeFADR_e_Cell05_PurgOnAirMode CeFADR_e_Cell06_PurgOnIdle CeFADR_e_Cell07_PurgOnDecel CeFADD_e_SelectedPurgeCell CeFADD_e_SelectedPurgeCell CeFADD_e_SelectedPurgeCell CeFADD_e_NonSelectedCell P0171 P0172 P0174 P0175 Long-Term Fuel Trim Cell Usage - Part 3 y/x CeFADR_e_Cell08_PurgOffAirMode CeFADR_e_Cell09_PurgOffAirMode CeFADR_e_Cell10_PurgOffAirMode CeFADR_e_Cell11_PurgOffAirMode

CeFADD_e_SelectedNonPurgeCell

CeFADR e Cell13 PurgOffAirMode

CeFADD_e_SelectedNonPurgeCell

CeFADD_e_SelectedNonPurgeCell

CeFADD_e_SelectedNonPurgeCell

CeFADR_e_Cell14_PurgOffIdle

CeFADD_e_SelectedNonPurgeCell

CeFADR_e_Cell12_PurgOffAirMode

CeFADD_e_SelectedNonPurgeCell

P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 4

y/x

Supporting Table - P0420_P0430_CatmonMinEngineRunTimeToEnable

Description: This cal value is a 1x5 array of minimum engine run time values based on powerup coolant temperatures. When the appropriate required minimum engine run time value is chosen based on the coolant temperature at powerup, this value is the minimum time from engine start before stabilized conditions are met. Used in determining if a ValidIdleIsMet condition exists.

Notes: KtCATD_t_EngRunTimeMin - Used for P0420 and P0430. Axis is the coolant and the output is the min engine run time

y/x	40	50	60	70	80
1	120	120	120	120	120

Supporting Table - P0420_P0430_CatmonMinAirflowForWarmCatalystDetermination

Description: This is a 1x3 table with the axis being engine coolant temperature. The implementation of this cal value as a table also included some changes to the way that the WarmedUpEvents counter increments and resets. To summarize, whenever WarmedUpEvents resets to 0 (this could be either at startup, if the closed throttle time exceeds a cal value, or if the predicted exhaust temperature falls below the ExhWarmMin cal value), the appropriate MinAirflowToWrmupCat value is chosen from the table based on engine coolant at the time the WarmedUpEvents counter reset to 0. This cal value is used along with the min exhaust temp to increment the WarmedUpEvents counter.

Notes: KtCATD_dm_MinAirFlowToWrmCat - Used for P0420 and P0430. Axis is the engine coolant and the output is the minimum airflow required to warmup the catalyst.

ı	y/x	0	45	90
١	1	6	4	2

Supporting Table - P0133_O2S Slow Response Bank 1 Sensor 1 "Pass/Fail Threshold table"

Description: KaEOSD_x_ST_ResponseLimRS1[x][y]

Notes: X axis is Lean to Rich response time (in sec), Please see the table below named "KnEOSD_t_ST_LRC_LimRS1" for the 17 X axis table breakpoints. Y axis is Rich to Lean response time (sec), Please see the cal table below named "KnEOSD_t_ST_RLC_LimRS1" for the 17 Y axis table breakpoints. Z axis is the pass/fail result, Note: If the cell contains a "0" then the fault is indicated, if it contains a "1" a fault is not indicated.

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0	0
1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0	0
2	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0	0
3	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
4	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
5	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
6	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
7	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0
8	0	0	0	1	1	1	1	1	1	1	1	0	0	0	0	0	0
9	0	0	0	0	0	1	1	1	1	1	1	0	0	0	0	0	0
10	0	0	0	0	0	0	0	1	1	1	1	0	0	0	0	0	0
11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
12	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
13	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
15	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Supporting Table - P1133_O2S HC L to R Switches Limit Bank 1 Sensor 1 "Pass/Fail Threshold table"

Description: KtEOSD_d_HC_LRSLimRS1

Notes: X axis is estimated Ethanol percentage, Please see the table below named "KnE85G_Pct_FFS_CompAtEngAxis" for the 5 X axis table breakpoints. Y axis is Average airflow during the response test (gps). Z axis is the limit for L2R Half Cycle switches, Note: The cell contains the minumum switches, below which the fault is indicated.

y/x	0	10	20	50	80
0.0	26	26	26	26	26
6.3	26	26	26	26	26
12.5	26	26	26	26	26
18.8	26	26	26	26	26
25.0	26	26	26	26	26
31.3	26	26	26	26	26
37.5	26	26	26	26	26
43.8	26	26	26	26	26
50.0	26	26	26	26	26
56.3	26	26	26	26	26
62.5	26	26	26	26	26
68.8	26	26	26	26	26
75.0	26	26	26	26	26
81.3	26	26	26	26	26
87.5	26	26	26	26	26
93.8	26	26	26	26	26
100.0	26	26	26	26	26

Supporting Table - P1133_O2S HC R to L Switches Limit Bank 1 Sensor 1 "Pass/Fail Threshold table"

Description: KtEOSD_d_HC_RLSLimRS1

Notes: X axis is estimated Ethanol percentage, Please see the table below named "KnE85G_Pct_FFS_CompAtEngAxis" for the 5 X axis table breakpoints. Y axis is Average airflow during the response test (gps). Z axis is the limit for R2L Half Cycle switches, Note: The cell contains the minumum switches, below which the fault is indicated.

y/x	0	10	20	50	80
0.0	26	26	26	26	26
6.3	26	26	26	26	26
12.5	26	26	26	26	26
18.8	26	26	26	26	26
25.0	26	26	26	26	26
31.3	26	26	26	26	26
37.5	26	26	26	26	26
43.8	26	26	26	26	26
50.0	26	26	26	26	26
56.3	26	26	26	26	26
62.5	26	26	26	26	26
68.8	26	26	26	26	26
75.0	26	26	26	26	26
81.3	26	26	26	26	26
87.5	26	26	26	26	26
93.8	26	26	26	26	26
100.0	26	26	26	26	26

Supporting Table - Multiple DTC Use_Green Sensor Delay Criteria - Airflow

Description: This Calibration is the airflow (in gps) above which the green airflow is acculmulated to expire the condition.

Notes: Used for: P0133, P013A, P013B, P013C, P013D, P013E, P013F, P014A, P014B, P0153, P015A, P015B, P015C, P015D, P1133, P1153, P2270, P2271, P2272 and P2273. The specific diagnostic (from summary table) will not be enabled until the next ignition cycle after the airflow criteria below (by sensor location) has been met:

y/x	1
1	20

Supporting Table - Multiple DTC Use_Green Sensor Delay Criteria - Limit

Description: This Calibration is the acculmulated airflow (in grams) limit above which the green condition is expired

Notes: Used for: P0133, P013A, P013B, P013C, P013D, P013E, P013F, P014A, P014B, P0153, P015A, P015B, P015C, P015D, P1133, P1153, P2270, P2271, P2272 and P2273. Note: This feature is only enabled when the vehicle is new and cannot be enabled in service

y/x	CiOXYR_O2_Bank1_Sensor1	CiOXYR_O2_Bank1_Sensor2	CiOXYR_O2_Bank2_Sensor1	CiOXYR_O2_Bank2_Sensor2
1	120,000	120,000	120,000	120,000

Supporting Table - P0133	_KnEOSD_t_ST_LRC_LimRS1
--------------------------	-------------------------

Description: KnEOSD_t_ST_LRC_LimRS1. X Table Axis (in sec) for P0133, L2R Reponse time breakpoints for table

Notes:

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.012	0.026	0.039	0.052	0.061	0.068	0.074	0.075	0.078	0.084	0.091	0.101	0.113	0.139	0.184	0.214

Supporting Table - P0133_	KnEOSD_t_ST_RLC_LimRS1
---------------------------	------------------------

Description: KnEOSD_t_ST_RLC_LimRS1. Y Table Axis (in sec) for P0133, R2L Reponse time breakpoints for table

Notes:

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.012	0.026	0.039	0.052	0.061	0.068	0.074	0.075	0.078	0.084	0.091	0.101	0.113	0.139	0.184	0.214

Supporting Table - P0411 SL Threshold Bank 1 Table

Description: Bank 1 SAI Flow (Phase 1) Test Average String Length failure threshold versus MAF (g/sec).

Notes: DTCs: P0411; Cal: KtAIRD_dp_SAI_SL_ThrshBank1

y/x	0.0	3.0	6.0	9.0	12.0	15.0	18.0	21.0	24.0	27.0	30.0	33.0	36.0	39.0	42.0	45.0	48.0
1.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

Supporting Table - P0411 Phase 1 Baro Test Weight Factor

Description: SAI Flow (Phase 1) Test baro weight factor.

Notes: DTC: P0411; Cal: KtAIRD_K_SAI_TstBaroDsbld; Axis is atmospheric pressure (kPa)

y/x	40	50	60	70	80	90	100	110	120
1	0.0	0.0	0.5	1.0	1.0	1.0	1.0	1.0	0.0

Supporting Table - P0411 Phase 1 MAF Test Weight Factor

Description: KtAIRD_K_SAI_TstMAF_Dsbld: SAI Flow (Phase 1) Test MAF weight factor.

Notes: Axis is Mass Airflow (g/sec).

У	//x	0.0	3.0	6.0	9.0	12.0	15.0	18.0	21.0	24.0	27.0	30.0	33.0	36.0	39.0	42.0	45.0	48.0
1	1.0	0.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	0.5	0.0	0.0	0.0	0.0	0.0

Supporting Table - P0411 Phase 1 System Volt Test Weight Factor

Description: SAI Flow (Phase 1) Test system voltage weight factor.

Notes: DTC: P0411; Cal: KtAIRD_K_SAI_TstVoltDsbld; Axis is system voltage (V).

y/x	5.0	6.0	7.0	8.0	9.0	10.0	11.0	12.0	13.0	14.0	15.0	16.0	17.0	18.0	19.0	20.0	21.0
1.0	0.0	0.0	0.0	0.0	0.0	0.5	0.8	1.0	1.0	1.0	1.0	1.0	0.8		0.5	0.5	0.5

Supporting Table - P0411 Phase 1 Amb Temp Test Weight Factor
Description: SAI Flow (Phase 1) Test ambient temperature weight factor.

Notes: DTC: P0411	Cal: KtAIRD k	(SAI	TstTempDshld:	Axis is Ambient	(IAT) Temp (C)
110(03. D 0. 0 1 1	, Oai. IXV III VD I	· 0/ 11	i ot i offip books,		,

y/x	-30	-20	-10	0	10	20	30	40	50
1	0.0	0.0	0.0	0.5	1.0	1.0	1.0	1.0	1.0

Supporting Table - P2431_P2436 Baro Skewed Sensor Weight Factor

Description: The AIR Pressure Sensor Test quality factor based on the distance traveled since the last unthrottled ambient pressure update.

Notes: DTCs: P2431 & P2436; Cal: KtAIRD_K_APPD_BaroQlty; P2436 is applicable on dual valve applications only. Axis is distance traveled from last Baro update in Km (1Km = 0.62 Miles).

1	y/x	0.0	2.0	4.0	6.0	8.0	10.0	12.0	14.0	16.0	18.0	20.0	22.0	24.0	26.0	28.0	30.0	32.0
1	1.0	1.0	0.8	0.5	0.3	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0		0.0	0.0

Supporting Table - P2440 Bank 1 Valve Pressure Error

Description: Sensor 1 minimum average pressure error (kPa) threshold for the valve-shut (Phase 2) test .

Notes: DTCs: P2440; Cal: KaAIRD_p_VIvTstPresErrMin[CeAIRR_e_PresSnsrOne]; Axis is Conditional Test Weight Time in seconds.

y/x	0	1	2	3	4	5	6	7	8
1	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0

Supporting Table - P2440 Phase 2 Baro Test Weight Factor

Description: Ambient pressure component of the conditional test weight for the valve-shut (Phase 2) test .

Notes: DTCs: P2440; Cal: KtAIRD_K_VlvTstBaroDsbld; Axis is ambient pressure (kPa).

y/x	40	50	60	70	80	90	100	110	120
1	0.0	0.0	0.5	1.0	1.0	1.0	1.0	1.0	0.0

Supporting Table - P2440 Phase 2 MAF Test Weight Factor

Description: Mass Airflow (MAF) component of the conditional test weight for the valve-shut (Phase 2) test.

Notes: DTCs: P2440; Cal: KtAIRD_K_VIvTstMAF_Dsbld; Axis is mass airflow (g/s).

	y/x	0.0	3.0	6.0	9.0	12.0	15.0	18.0	21.0	24.0	27.0	30.0	33.0	36.0	39.0	42.0	45.0	48.0
1	1.0	0.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	0.5	0.0	0.0	0.0	0.0	0.0

Supporting Table - P2440 Phase 2 System Volt Test Weight Factor

Description: System Voltage component of the conditional test weight for the valve-shut (Phase 2) test.

Notes: DTCs: P2440; Cal: KtAIRD_K_VlvTstVoltDsbld; Axis is system volts (V).

y/x	5.0	6.0	7.0	8.0	9.0	10.0	11.0	12.0	13.0	14.0	15.0	16.0	17.0	18.0	19.0	20.0	21.0
1.0	0.0	0.0	0.0	0.0	0.0		0.8	1.0	1.0	1.0	1.0	1.0		0.5	0.5	0.5	0.5

Supporting Table - P2440 Phase 2 Amb Temp Test Weight Factor
Description: Ambient Temperature component of the conditional test weight for the valve-shut (Phase 2) test.
Notes: DTCs: P2440; Cal: KtAIRD_K_VIvTstTempDsbld; Axis is ambient temperature (IAT) in Deg C.

y/x	-30	-20	-10	0	10	20	30	40	50
1	0.0	0.0	0.0	0.5	1.0	1.0	1.0	1.0	1.0

Supporting Table - P2444 Bank 1 Pump Pressure Error

Description: Sensor 1 maximum average pressure error threshold for the pump-off (Phase 3) test.

Notes: DTCs: P2444; Cal: KaAIRD_p_PmpTstPresErrMax[CeAIRR_e_PresSnsrOne]; Axis is Conditional Test Weight Time in seconds.

y/x	0	1	2	3	4	5	6	7	8
1	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0

Supporting Table - P0606_PSW Sequence Sample f(Loop Time)

Description: Sample threshold for PSW per operating loop.

Notes: P0606, KaPISD_Cnt_SequenceSmpl[x]

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	4	4	4	4

Supporting Table - P16F3_Delta Spark Threshold f(RPM,APC)

Description: Threshold for determining when the difference between commanded spark and applied spark exceeds the torque security requirement. It is a function of engine rpm and APC.

Notes: P16F3, KtSPRK_phi_DeltTorqueScrtyAdv

y/x	500.00	980.74	1,461.48	1,942.23	2,422.97	2,903.71	3,384.45	3,865.20	4,345.94	4,826.68	5,307.42	5,788.16	6,268.91	6,749.65	7,230.39	7,711.13	8,191.88
80.00	125.00	60.56	62.67	70.34	67.64	66.78	64.83	62.25	59.05	55.95	53.86	52.88	52.27	52.09	52.09	52.09	52.09
160.00	125.00	50.52	47.70	52.73	50.55	48.41	47.02	45.31	42.17	39.30	36.95	35.59	34.72	34.48	34.48	34.48	34.48
240.00	125.00	40.73	37.17	40.05	39.47	36.55	35.25	34.22	32.47	30.28	28.13	26.81	26.00	25.77	25.77	25.77	25.77
320.00	125.00	33.13	29.98	32.23	31.61	28.98	28.06	27.38	25.78	24.36	22.70	21.52	20.78	20.58	20.58	20.58	20.58
400.00	125.00	27.91	25.13	26.97	26.34	24.02	23.31	22.80	21.33	20.11	18.89	17.97	17.30	17.13	17.13	17.13	17.13
480.00	125.00	24.11	21.63	23.17	22.59	20.50	19.94	19.53	18.19	17.09	16.08	15.34	14.81	14.66	14.66	14.66	14.66
560.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
640.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
720.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
800.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
880.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
960.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
1,040.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
1,120.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
1,200.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
1,280.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
1,360.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38

Supporting Table - P16F3_Delta MAP Threshold f(Desired Engine Torque)

Description: Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

Notes: P16F3, KtMAPI_p_ES_TB_MAP_DeltaThresh

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	28.32	28.32	28.32	28.32	28.32	28.32

Supporting Table - P16F3_Speed Control External Load f(Oil Temp, RPM)

Description: Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

Notes: P16F3, KtSPDC_M_ExternalLoad

y/x	-40.00	-20.00	-10.00	0.00	50.00	90.00
200.00	4,096.00	4,096.00	4,096.00	4,096.00	4,096.00	4,096.00
400.00	1,412.00	1,412.00	1,412.00	1,412.00	1,412.00	1,412.00
600.00	150.00	150.00	150.00	150.00	150.00	150.00
700.00	150.00	150.00	150.00	150.00	150.00	150.00
1,000.00	150.00	150.00	150.00	150.00	150.00	150.00
1,200.00	150.00	150.00	150.00	150.00	150.00	150.00
1,600.00	150.00	150.00	150.00	150.00	150.00	150.00
2,000.00	150.00	150.00	150.00	150.00	150.00	150.00
2,500.00	150.00	150.00	150.00	150.00	150.00	150.00
3,000.00	150.00	150.00	150.00	150.00	150.00	150.00
3,500.00	150.00	150.00	150.00	150.00	150.00	150.00
4,000.00	150.00	150.00	150.00	150.00	150.00	150.00
4,500.00	150.00	150.00	150.00	150.00	150.00	150.00
5,000.00	150.00	150.00	150.00	150.00	150.00	150.00
6,000.00	150.00	150.00	150.00	150.00	150.00	150.00
7,000.00	150.00	150.00	150.00	150.00	150.00	150.00
8,000.00	150.00	150.00	150.00	150.00	150.00	150.00

Supporting Table - P0068_Delta MAP Threshold f(TPS)

Description: Table of delta MAP values as a function of desired throttle position. The output of this table provides a delta MAP that if the measured minus the estimated MAP exceeds, is considered a fail.

Notes: P0068, KtTPSD_p_MAP_DesThrDelt

y/x	0.69	5.00	10.00	15.00	20.00	25.00	30.00	40.00	55.00
1.00	42.00	41.00	1 KU U 7	31.00	28.60	28.32	29.14	70.00	110.00

Supporting Table - P0068_Delta MAF Threshold f(TPS)

Description: Table of delta MAF values as a function of desired throttle position. The output of this table provides a delta MAF that if the measured minus the estimated MAF exceeds, is considered a fail.

Notes: P0068, KtTPSD_dm_MAF_DesThrDelt

y/x	0.69	5.00	10.00	15.00	25.00	30.00	40.00	55.00
1.00	10.00	11.43	13.38	14.33	22.16	28.16	70.00	120.00

Supporting Table - P0068_Maximum MAF f(RPM)

Description: Table of maximum MAF values vs. engine speed. This is the maximum MAF the engine can see under all ambient conditions.

Notes: P0068, KtTPSD_dm_MaxMAF_VsRPM

)	y/x	600.00	1,400.00	2,200.00	3,000.00	3,800.00	4,600.00	5,400.00	6,200.00	7,000.00
•	1.00	255.00	255.00	255.00	255.00	255.00	255.00	255.00	255.00	255.00

Supporting Table - P0068_Maximum MAF f(Volts)

Description: Table of maximum MAF values vs. system voltage. The output of the air meter is clamped to lower values as system voltage drops off.

Notes: P0068, KtTPSD_dm_MaxMAF_VsVoltage

y/x	6.00	7.00	8.00	9.00	10.00	11.00	12.00	13.00	14.00
1.00	511.99	511.99		511.99	511.99	511.99	511.99	511.99	511.99

Supporting Table - P0606_Last Seed Timeout f(Loop Time)

Description: The max time for the Last Seed Timeout as a function of operating loop time sequence.

Notes: P0606, KaPISD_t_LastSeedTimeout[x]

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	0.175	0.175	0.175	409.594

Supporting Table - P0606_Program Sequence Watch Enable f(Loop Time)

Description: The enabling flags for the program sequence watch as a function of operating loop time sequence.

Notes: P0606, KaPISD_b_ProgSeqWatchEnbl

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	1	1	1	0

Supporting Table - P0606_PSW Sequence Fail f(Loop Time)

Description: Fail threshold for PSW per operating loop.

Notes: P0606, KaPISD_Cnt_SequenceFail[x]

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	3	3	3	5

Supporting Table - P0606_PSW Sequence Sample f(Loop Time)

Description: Sample threshold for PSW per operating loop.

Notes: P0606, KaPISD_Cnt_SequenceSmpl[x]

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	4	4	4	4

Supporting Table - P1682_PT Relay Pull-in Run/Crank Voltage f(IAT)

Description: The Run/Crank voltages required to pull in the PT relay as a function of induction air temperature.

Notes: P1682, KtEROR_U_PT_RelayPullInEnbl

ľ	y/x	23.00	85.00	95.00	105.00	125.00
١	1.00	7.00	8.70	9.00	9.20	10.00

Supporting Table - P16F3_Delta Spark Threshold f(RPM,APC)

Description: Threshold for determining when the difference between commanded spark and applied spark exceeds the torque security requirement. It is a function of engine rpm and APC.

Notes: P16F3, KtSPRK_phi_DeltTorqueScrtyAdv

y/x	500.00	980.74	1,461.48	1,942.23	2,422.97	2,903.71	3,384.45	3,865.20	4,345.94	4,826.68	5,307.42	5,788.16	6,268.91	6,749.65	7,230.39	7,711.13	8,191.88
80.00	125.00	60.56	62.67	70.34	67.64	66.78	64.83	62.25	59.05	55.95	53.86	52.88	52.27	52.09	52.09	52.09	52.09
160.00	125.00	50.52	47.70	52.73	50.55	48.41	47.02	45.31	42.17	39.30	36.95	35.59	34.72	34.48	34.48	34.48	34.48
240.00	125.00	40.73	37.17	40.05	39.47	36.55	35.25	34.22	32.47	30.28	28.13	26.81	26.00	25.77	25.77	25.77	25.77
320.00	125.00	33.13	29.98	32.23	31.61	28.98	28.06	27.38	25.78	24.36	22.70	21.52	20.78	20.58	20.58	20.58	20.58
400.00	125.00	27.91	25.13	26.97	26.34	24.02	23.31	22.80	21.33	20.11	18.89	17.97	17.30	17.13	17.13	17.13	17.13
480.00	125.00	24.11	21.63	23.17	22.59	20.50	19.94	19.53	18.19	17.09	16.08	15.34	14.81	14.66	14.66	14.66	14.66
560.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
640.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
720.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
800.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
880.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
960.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
1,040.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
1,120.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
1,200.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
1,280.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38
1,360.00	125.00	22.11	19.80	21.19	20.64	18.67	18.17	17.81	16.55	15.55	14.63	13.97	13.50	13.38	13.38	13.38	13.38

Supporting Table - P16F3_Delta MAP Threshold f(Desired Engine Torque)

Description: Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

Notes: P16F3, KtMAPI_p_ES_TB_MAP_DeltaThresh

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	28.32	28.32	28.32	28.32		28.32

Supporting Table - P16F3_Speed Control External Load f(Oil Temp, RPM)

Description: Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

Notes: P16F3, KtSPDC_M_ExternalLoad

y/x	-40.00	-20.00	-10.00	0.00	50.00	90.00
200.00	4,096.00	4,096.00	4,096.00	4,096.00	4,096.00	4,096.00
400.00	1,412.00	1,412.00	1,412.00	1,412.00	1,412.00	1,412.00
600.00	150.00	150.00	150.00	150.00	150.00	150.00
700.00	150.00	150.00	150.00	150.00	150.00	150.00
1,000.00	150.00	150.00	150.00	150.00	150.00	150.00
1,200.00	150.00	150.00	150.00	150.00	150.00	150.00
1,600.00	150.00	150.00	150.00	150.00	150.00	150.00
2,000.00	150.00	150.00	150.00	150.00	150.00	150.00
2,500.00	150.00	150.00	150.00	150.00	150.00	150.00
3,000.00	150.00	150.00	150.00	150.00	150.00	150.00
3,500.00	150.00	150.00	150.00	150.00	150.00	150.00
4,000.00	150.00	150.00	150.00	150.00	150.00	150.00
4,500.00	150.00	150.00	150.00	150.00	150.00	150.00
5,000.00	150.00	150.00	150.00	150.00	150.00	150.00
6,000.00	150.00	150.00	150.00	150.00	150.00	150.00
7,000.00	150.00	150.00	150.00	150.00	150.00	150.00
8,000.00	150.00	150.00	150.00	150.00	150.00	150.00

Supporting Table - P0300_IdleSCD_Decel

Description: Crankshaft decel threshold while in SCD mode. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_dt_SCD_IdleMode

Note: Misfire's Load term is %, but not PID\$04. PID\$04 is not robust to temperature and alititude shifts. (especially decel and jerk thresholds since they track actual air trapped in cylinder)

	T	l	- Contract	1		- Lance	1		T		1		
y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
8	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
9	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
11	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
12	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
13	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
14	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
15	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
16	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
17	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
18	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
19	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
21	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
22	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
24	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
25	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
27	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
30	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768

Supporting Table - P0300_IdleSCD_Jerk

Description: Crankshaft jerk threshold while in SCD mode. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_ddt_SCD_ldleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
8	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
9	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
11	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
12	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
13	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
14	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
15	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
16	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
17	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
18	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
19	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
21	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
22	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
24	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
25	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
27	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
30	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768

Supporting Table - P0300_SCD_Decel

Description: Crankshaft decel threshold. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_dt_SCD_OffIdleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
8	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
9	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
11	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
12	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
13	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
15	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
17	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
19	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
22	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
25	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
29	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
33	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
38	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
42	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
48	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
54	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
61	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768

Supporting Table - P0300_SCD_Jerk

Description: Crankshaft jerk threshold. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_ddt_SCD_OffIdleMode

1101001													
y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
8	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
9	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
11	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
12	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
13	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
15	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
17	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
19	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
22	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
25	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
29	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
33	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
38	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
42	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
48	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
54	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
61	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768

13 OBDG02B Engine Diagnostics

Supporting Table - P0300_IdleCylModeDecel TEST GROUP: DGMXV01.8031

OBD GROUP: 130BDG02B TEST GROUP: DGMXV01.8031 EMISSIONS STDS: CARB SULEV

Description: Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMSFD_dt_ldleCylinderMode

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,600	1,800	2,000
8	590	550	420	300	270	250	230	205	160	160	160	160	160
9	635	590	445	330	310	280	270	249	190	190	190	190	190
11	1,000	900	500	475	500	480	469	350	250	250	250	250	250
12	1,800	1,500	1,000	800	700	600	527	400	380	380	380	380	380
13	2,250	2,010	1,200	1,050	900	660	547	410	400	400	400	400	400
14	2,550	2,250	1,350	1,175	970	680	554	425	410	410	410	410	410
15	2,800	2,430	1,420	1,250	1,000	740	551	430	415	415	415	415	415
16	3,100	2,540	1,560	1,340	1,030	750	576	440	418	418	418	418	418
17	3,430	2,630	1,650	1,370	1,050	790	570	465	421	421	421	421	421
18	3,600	2,700	1,760	1,410	1,060	800	580	470	425	425	425	425	425
19	3,700	2,750	1,890	1,460	1,070	834	610	480	422	422	422	422	422
21	3,850	2,800	1,950	1,500	1,090	870	620	520	430	430	430	430	430
22	3,900	2,850	1,980	1,540	1,170	890	650	550	440	440	440	440	440
24	3,950	2,900	2,020	1,580	1,220	920	670	600	450	450	450	450	450
25	4,000	2,940	2,050	1,610	1,270	980	750	650	500	600	600	600	600
27	4,050	2,980	2,060	1,650	1,290	1,050	800	730	550	700	700	700	700
30	4,100	3,000	2,070	1,670	1,300	1,100	850	870	600	800	800	800	800

Supporting Table - P0300_IdleCylModeJerk

Description: Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMSFD_ddt_ldleCylinderMode

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,600	1,800	2,000
8	1,400	600	450	430	350	310	280	210	100	100	100	100	100
9	1,500	900	550	500	440	390	300	270	150	150	150	150	150
11	1,800	1,300	700	650	550	500	380	320	270	270	270	270	270
12	2,100	1,800	880	770	660	590	550	480	400	400	400	400	400
13	2,500	2,200	1,300	1,143	950	800	700	600	490	490	490	490	490
14	2,900	2,500	1,800	1,400	1,100	940	830	700	570	570	570	570	570
15	3,200	2,780	2,200	1,450	1,280	1,000	930	730	596	596	596	596	596
16	3,500	3,000	2,400	1,505	1,360	1,110	960	750	660	660	660	660	660
17	3,690	3,100	2,500	1,545	1,400	1,170	990	800	700	700	700	700	700
18	3,800	3,200	2,600	1,584	1,430	1,200	1,000	830	720	720	720	720	720
19	3,900	3,300	2,650	1,605	1,450	1,250	1,010	840	772	772	772	772	772
21	4,100	3,400	2,700	1,635	1,470	1,350	1,030	860	760	760	760	760	760
22	4,300	3,500	2,750	1,655	1,520	1,450	1,050	880	765	765	765	765	765
24	4,500	3,600	2,800	1,685	1,580	1,500	1,100	900	800	800	800	800	800
25	4,630	3,700	2,850	1,700	1,620	1,550	1,150	950	830	830	830	830	830
27	4,790	3,800	2,900	1,765	1,660	1,600	1,200	1,050	900	900	900	900	900
30	4,870	3,900	3,000	1,850	1,700	1,700	1,300	1,200	900	900	900	900	900

Supporting Table - P0300_CylMode_Decel

Description: Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_CylinderMode

y/x 400 500 600 700 800 900 1,000 1,100 1,200 1,400 1,600 1,800 2,000 2,200 2,400 2,600 2,800 3,000 3,500 4,000 4,500 5,000 5,500 6,000 6,500 7,000																										
y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
8	800	800	700	600	550	500	450	400	275	225	150	85	70	65	40	33	29	25	15	12	10	9	7	6	6	6
9	750	750	675	625	525	460	400	350	250	200	120	75	66	61	32	27	24	18	14	11	9	8	6	6	6	6
11	700	700	600	580	510	420	379	300	225	185	114	64	52	45	32	25	24	22	14	11	8	7	6	6	5	5
12	1,200	1,200	1,000	900	650	575	488	300	250	220	98	72	55	46	32	31	27	22	12	10	8	7	5	5	4	4
13	1,400	1,400	1,200	1,000	670	640	560	351	280	239	125	84	57	50	39	33	28	24	14	9	7	6	4	4	3	3
15	1,600	1,600	1,350	1,050	750	690	589	407	388	249	139	99	74	55	42	35	32	25	16	9	7	5	5	5	3	3
17	1,700	1,700	1,500	1,175	923	800	689	525	458	260	156	115	80	58	45	39	36	27	16	10	7	6	6	5	4	4
19	1,900	1,900	1,700	1,300	1,044	902	733	650	479	268	171	136	90	74	51	44	41	33	18	11	7	6	6	5	4	4
22	2,250	2,250	1,900	1,550	1,095	1,003	858	678	502	341	232	170	107	79	60	48	45	42	19	13	8	8	7	7	5	5
25	2,550	2,550	2,250	1,750	1,338	1,156	957	740	589	350	276	205	130	105	83	55	52	45	26	17	13	10	9	8	6	6
29	2,800	2,800	2,550	1,900	1,600	1,405	1,100	870	660	363	320	220	138	112	95	75	60	50	27	20	16	12	10	8	6	6
33	3,050	3,050	2,800	2,250	1,779	1,520	1,375	1,001	754	418	354	265	157	120	97	84	71	59	32	22	17	13	12	9	8	8
38	3,200	3,200	3,050	2,550	1,900	1,700	1,486	1,157	836	576	407	294	181	130	102	98	80	64	36	25	19	15	12	11	9	9
42	3,450	3,450	3,200	2,800	2,250	1,900	1,650	1,250	889	605	454	310	217	152	109	109	91	78	44	28	21	16	13	11	9	9
48	3,700	3,700	3,450	3,050	2,550	2,250	1,800	1,550	1,000	717	482	360	244	166	126	116	107	82	51	32	23	20	15	12	10	10
54	4,000	4,000	3,700	3,200	2,800	2,550	2,000	1,800	1,100	760	582	429	310	214	160	145	123	100	57	39	29	22	16	13	12	12
61	4,400	4,400	4,000	3,450	3,050	2,800	2,250	1,873	1,238	804	649	476	341	250	185	164	142	120	65	49	32	24	19	15	14	14

Supporting Table - P0300_CylMode_Jerk

Description: Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_ddt_CylinderMode

y/x 400 500 600 700 800 900 1,000 1,100 1,200 1,400 1,600 1,800 2,000 2,200 2,400 2,600 2,800 3,000 3,500 4,000 4,500 5,000 5,500 6,000 6,500 7,000																										
y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
8	1,550	1,550	1,400	1,225	1,100	975	800	550	375	300	250	150	100	75	60	55	47	40	23	21	16	13	10	9	8	8
9	1,400	1,400	1,275	1,150	1,050	925	775	534	355	280	175	107	80	67	55	48	42	36	22	20	15	12	9	8	7	7
11	1,300	1,300	1,200	1,100	1,000	900	750	485	330	250	152	90	74	63	53	46	41	36	21	17	14	11	9	7	6	6
12	1,300	1,300	1,250	1,100	1,000	950	803	500	366	253	164	101	75	58	52	45	37	32	19	16	12	10	7	7	5	5
13	1,500	1,500	1,350	1,250	1,150	1,050	850	556	419	325	237	122	75	64	51	41	35	29	20	14	11	8	6	6	5	5
15	1,800	1,800	1,550	1,400	1,225	1,100	925	689	522	341	240	135	82	77	57	51	47	30	26	14	9	8	8	7	6	6
17	2,000	2,000	1,800	1,600	1,400	1,260	1,000	796	547	391	276	185	127	90	79	61	52	30	30	19	13	9	9	8	7	7
19	2,500	2,500	2,100	1,997	1,621	1,450	1,182	1,000	639	439	344	212	163	111	93	63	56	46	34	20	15	10	9	9	8	8
22	3,000	3,000	2,550	2,400	1,989	1,827	1,444	1,305	756	513	376	240	200	143	116	95	68	56	35	27	20	14	11	11	11	11
25	3,300	3,300	3,000	2,718	2,300	2,050	1,700	1,387	1,033	694	469	285	201	165	145	112	86	74	40	34	25	21	15	11	11	11
29	3,700	3,700	3,300	3,000	2,700	2,250	1,975	1,512	1,296	708	535	342	233	191	161	120	99	88	49	36	27	22	17	13	12	12
33	3,900	3,900	3,700	3,300	3,000	2,500	2,100	1,886	1,396	909	704	373	261	220	172	136	109	95	58	39	29	24	19	14	13	13
38	4,250	4,250	3,900	3,700	3,300	2,800	2,400	2,030	1,525	1,110	790	448	310	253	199	145	118	109	65	45	31	25	21	14	13	13
42	4,500	4,500	4,250	3,900	3,550	3,200	2,650	2,150	1,600	1,200	863	518	345	297	225	180	137	121	78	55	32	25	23	14	13	13
48	4,800	4,800	4,500	4,250	3,775	3,500	2,900	2,200	1,750	1,306	925	606	416	319	261	202	157	141	87	63	33	26	24	15	14	14
54	5,100	5,100	4,800	4,500	4,000	3,800	3,100	2,400	1,900	1,365	1,111	706	475	372	292	236	190	162	99	68	40	27	25	16	15	15
61	5,500	5,500	5,100	4,800	4,300	4,250	3,400	2,600	2,150	1,412	1,233	817	522	424	318	270	215	197	112	76	43	30	26	20	17	17

Supporting Table - P0300_RevMode_Decel

Description: Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_RevolutionMode

y/x	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
8	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
9	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
11	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
12	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
13	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
15	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
17	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
19	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
22	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
25	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
29	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
33	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
38	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
42	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
48	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
54	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
61	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768

Supporting Table - P0300_AFM_Decel

Description: Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_DoDCylinderMode

110100.	0360 101 1	000010	ooo. oai	raino. IX		, D O y III IGC	1141040												
y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500
0	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
6	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
13	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
19	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
25	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
31	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
38	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
44	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
50	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
56	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
63	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
69	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
75	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
81	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
88	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
94	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
100	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768

Supporting Table - P0300_ZeroTorqueEngLoad

Description: %air load that represents Zero Brake torque along the Neutral rev line. The Zero torque threshold is adjusted for Baro via P0300_ZeroTorqueBaro

Notes: Used for P0300-P0308. Cal Name: KtMISF_ZeroTorqSpd

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
1	19.00	11.70	11.25	11.00	10.60	10.40	10.30	10.20	10.10	10.00	10.10	10.30	10.60	10.60	10.60	10.70	10.90	10.90	13.53	16.60	18.79	21.41	24.04	26.67	29.30	31.93

Supporting	Table -	P0300	_ZeroTorqBaro

Description: adjusts zero torque for altitude

Notes: Used for P0300-P0308. Cal Name: KtMSFD_K_ZeroTorqBaro

y/x	65	70	75	80	85	90	95	100	105
1	0.82	0.85	0.88	0.90	0.93	0.95	0.97	1.00	1.03

Supporting Table - P0300_Catalyst_Damage_Misfire_Percentage

Description: Catalyst Damaging Misfire Percentage" Table whenever secondary conditions are met.

Notes: Used for P0300-P0308. Cal Name: KtMSFD_Pct_CatalystMisfire

y/x	0	1,000	2,000	3,000	4,000	5,000	6,000	7,000
0	22.5	22.5	22.5	22.5	22.5	22.5	12.5	12.5
10	22.5	22.5	22.5	22.5	22.5	22.5	12.5	8.0
20	22.5	22.5	22.5	22.5	22.5	22.5	8.0	6.3
30	22.5	22.5	22.5	12.5	12.5	12.5	8.0	6.3
40	22.5	22.5	12.5	12.5	12.5	12.5	8.0	6.3
50	22.5	12.5	12.5	12.5	8.0	8.0	8.0	6.3
60	22.5	12.5	12.5	12.5	8.0	6.3	8.0	6.3
70	12.5	12.5	12.5	8.0	8.0	6.3	8.0	6.3
80	12.5	12.5	8.0	6.3	6.3	6.3	6.3	6.3
90	12.5	12.5	8.0	6.3	6.3	6.3	6.3	6.3
100	12.5	12.5	8.0	6.3	6.3	6.3	6.3	6.3

Supporting Table - P0300_TOSSRoughRoadThres

Description: Only used if Rough Road source = TOSS: dispersion value on Transmission Output Speed Sensor above which rough road is indicated present

Notes: Used for P0300-P0308. Cal Name: KtRRDI_a_RoughRoadThresh

11																			
y/x	600	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000
100	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
200	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
300	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
400	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
500	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
600	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
700	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
800	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
900	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,000	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,100	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,200	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,300	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,400	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

Supporting Table - P0300_Abnormal Cylinder Mode

Description: Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Cylinder Mode Equation)

Notes: Used for P0300-P0308. Cal Name: KaMSFD_Cnt_CylAbnormal

y/x	0	1	2	3	4	5	6	7	8
1	2.00	2.00	2.00	4.00	4.00	4.00	4.00	4.00	4.00

Supporting Table - Po	0300_Abnormal SCD Mode	

Description: Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (SCD Mode Equation)

Notes: Used for P0300-P0308. Cal Name: KaMSFD_Cnt_SCD_CylAbnormal

y/x	0	1	2	3	4	5	6	7	8
1	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00

Supporting	Table - P0300	_Abnormal Rev Mode

Description: Abnormal Rev Mode Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Rev Mode Equation)

Notes: Used for P0300-P0308. Cal Name: KaMSFD_Cnt_RevAbnormal

y/x	0	1	2	3	4	5	6	7	8
1	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00

Supporting Table - P0300_Min_PatternMultiplier

Description: Crankshaft should return to normal after the misfire. If crankshaft snap value after single isolated misfire being evaulated is larger than the misfire's Jerk threshold times this multiplier, its not a real misfire.

Notes: Used for P0300-P0308. Cal Name: KtMSFD_K_SCD_MinPttrnRecogMult

y/x	0	1,000	2,000	2,500	3,000	3,500	4,000	5,000	6,500
1	1.10	1.10	0.75	0.85	0.85	0.60	0.70	0.80	0.80

Supporting Table - P0300_Max_PatternMultiplier

Description: Crankshaft should return to normal after the misfire. If crankshaft snap value after the misfire being evaulated is larger than the misfire's Jerk threshold times this multiplier, its not a real misfire. However, if random misfire occurs every engine cycle, more noise is allowed to be considered "normal" since the crankshaft does not have time to fully return to normal before the next misfire occurs.

Notes: Used for P0300-P0308. Cal Name: KtMSFD_K_SCD_MaxPttrnRecogMult

ĺ	y/x	0	1,000	2,000		3,000	3,500	4,000	5,000	6,500
	1	1.30	1.30	1.20	0.80	0.80	1.00	1.20	1.40	1.40

Supporting Table - P0300 Ring Filter

Description: Driveline Ring Filter
After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

Notes: Used for P0300-P0308. Cal Name: KaMSFD_Cnt_RingFilter

y/x	0	1	2	3	4	5	6	7	8
1	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00

Supporting Table - P0300 Number of Normals

Description: Number of Normals for the Driveline Ring Filter
After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

Notes: Used for P0300-P0308. Cal Name: KaMSFD_Cnt_NumOfNormalsFil

y/x	0	1	2	3	4	5	6	7	8
1	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00

Supporting Table - P0300 EngineOverSpeedLimit

Description: Engine OverSpeed Limit versus gear

Notes: Used for P0300-P0308. Cal Name: KaEOSC_n_EngOvrspdLimitGear

P0300	Engine	OverSp	eedLimit	- Part 1
-------	--------	--------	----------	----------

y/x	CeTGRR_e_TransGr1	CeTGRR_e_TransGr2	CeTGRR_e_TransGr3	CeTGRR_e_TransGr4	CeTGRR_e_TransGr5	CeTGRR_e_TransGr6	CeTGRR_e_TransGrE VT1
1	6,520	6,520	6,520	6,520	6,520	6,520	6,520

P0300 EngineOverSpeedLimit - Part 2

-	. cocc mgmoorerep							
ı						CeTGRR_e_TransGr7	CeTGRR_e_TransGr8	
-		VT2	eut	vrs	ark			
	1	6,520	4,020	4,020	4,020	6,250	6,250	

Supporting Table - P0324_P0326_P0331_AbnormalNoise_Threshold

Description: Fail threshold for the Knock Performance Abnormal Noise Diagnostic

Notes: Used for P0324, P0326 and P0331. Cal Name: KtKNKD_k_PerfAbnLimitLo. X-axis = Engine Speed (RPM). Diagnostic fails when VaKNKD_k_PerfCylAbnFiltIntnsity < KtKNKD_k_PerfAbnLimitLo

/sc	F00	14 000	1 500	To 000	0 500	2 000	2 500	14 000	4 500	E 000	TE 500	lc 000	C 500	7 000	7 500	lo 000	0.500
y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.110	0.115	0.120	0.125	0.130	0.135	0.140	0.145	0.150	0.155	0.160	0.165	0.170	0.175	0.180	0.185	0.190

Supporting Table - P0325_P0330_OpenCktThrshMin (20 kHz)

Description: Knock Open Circuit Diagnostic Minimum Threshold when using the 20 kHz method (see "OpenMethod" description)

Notes: Used for P0325 and P0330. Cal name: KtKNKD_k_OpenMin20K. x-axis = Engine Speed (RPM)

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:

i.e.: KtKNKD_k_OpenMin20K < VaKNKD_k_OpenFiltIntensity < KtKNKD_k_OpenMax20K.

١	y/x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
١	1	4.8008	4.5996	4.1992	3.8008	3.3008	2.6992	2.0996	1.6992	1.9004	2.0508	2.0996	2.1699	2.1992	2.1992	2.1992	2.1992	2.1992

Supporting Table - P0325_P0330_OpenCktThrshMax (20 kHz)

Description: Knock Open Circuit Diagnostic Maximum Threshold when using the 20 kHz method (see "OpenMethod" description)

Notes: Used for P0325 and P0330. Cal name: KtKNKD_k_OpenMax20K. x-axis = Engine Speed (RPM).

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:

i.e.: KtKNKD_k_OpenMin20K < VaKNKD_k_OpenFiltIntensity < KtKNKD_k_OpenMax20K.

Ì	//x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
	1	13.0000	13.0000	13.0000	13.0000	13.0000	13.0000	13.0000	13.0000	13.0000	13.0000	13.0000	13.0000	13.0000	13.0000	13.0000	13.0000	13.0000

Supporting Table - P0325_P0330_OpenCktThrshMin (Normal Noise)

Description: Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

Notes: Used for P0325 and P0330. Cal name: KtKNKD_k_OpenMinNN. x-axis = Engine Speed (RPM)

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:

i.e.: KtKNKD_k_OpenMinNN < VaKNKD_k_OpenFiltIntensity < KtKNKD_k_OpenMaxNN.

y/x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000

Supporting Table - P0325_P0330_OpenCktThrshMax (Normal Noise)

Description: Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

Notes: Used for P0325 and P0330. Cal name: KtKNKD_k_OpenMaxNN. x-axis = Engine Speed (RPM)

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:

i.e.: KtKNKD_k_OpenMinNN < VaKNKD_k_OpenFiltIntensity < KtKNKD_k_OpenMaxNN.

y/x	700	1.000	1.500	2.000	2.500	3.000	3.500	4.000	4,500	5.000	5,500	6.000	6.500	7.000	7.500	8.000	8,500
1	0.3848	,	,	,	,	-,	0.3496	,	0.3496	- ,	-	0.5703	0.5996	,	,	- ,	0.5996

Supporting Table - P06B6_P06B7_OpenTestCktThrshMin

Description: Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

Notes: Used for P0325 and P0330. Cal name: KtKNKD_k_OpenTestCktMin. x-axis = Engine Speed (RPM).

Diagnostic fails when the filtered diagnostic output is between the OpenTestCktThrshMin and OpenTestCktThrshMax:

i.e. KtKNKD_k_OpenTestCktMin < VaKNKD_k_OpenTestCktIntFilter < KtKNKD_k_OpenTestCktMax

- 14																		
	y/x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
	1	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000

Supporting Table - P06B6_P06B7_OpenTestCktThrshMax

Description: Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

Notes: Used for P0325 and P0330. Cal name: KtKNKD_k_OpenTestCktMax. x-axis = Engine Speed (RPM).

Diagnostic fails when the filtered diagnostic output is between the OpenTestCktThrshMin and OpenTestCktThrshMax:

i.e. KtKNKD_k_OpenTestCktMin < VaKNKD_k_OpenTestCktIntFilter < KtKNKD_k_OpenTestCktMax

- 14																		
	y/x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
	1	0.230	0.250	0.270	0.289	0.301	0.311	0.320	0.350	0.420	0.480	0.570	0.600	0.619	0.619	0.619	0.619	0.619

Supporting Table - P0324_P0326_P0331_AbnormalNoise_CylsEnabled

Description: Specifies which cylinders will be used for the Abnormal Noise portion of the performance diagnostics (1 = cylinder used, 0 = cylinder not used)

Notes: Used for P0324, P0326 and P0331. Cal name: KaKNKD_b_PerfAbnIncludeCyl. x-axis = Cylinder number in firing order (i.e. Cyl 0 = first cylinder in firing order, Cyl 1 = second cylinder in firing order....)

A cal value = 1 specifies the cylinder is used for the Abnormal Noise diagnostic. A cal value = 0 specifies the cylinder is not used. Only the first four values in the table are relavent for a four-cylinder engine and only the first six values in the table are relavent for a six-cylinder engine.

Typically, all cylinders are used. Cylinders are only excluded if the signal from that cylinder is weak and there is no separation between normal and faulted conditions (can occur if the sensor location results in poor signal-to-noise ratio for a given cylinder).

Ì	y/x	0	1	2	3	4	5	6	7
	1	1	1	1	1	0	0	0	0

Bundle Name: 5VoltReferenceA FA

P0641

Bundle Name: 5VoltReferenceB FA

P0651

Bundle Name: 5VoltReferenceMAP_OOR_FIt

P0697

Bundle Name: A/F Imbalance Bank1

P219A

Bundle Name: A/F Imbalance Bank2

P219B

Bundle Name: AAP_SnsrCktFP

Naturally aspirated: P2228, P2229. Turbocharged: P0237, P0238

Bundle Name: AAP_SnsrFA

Naturally Aspirated: P2227, P2228, P2229, P2230. Turbocharged: P0237, P0238.

Bundle Name: AAP_SnsrTFTKO

Naturally Aspirated: P2227, P2228, P2229, P2230. Turbocharged: P0237, P0238.

Bundle Name: AAP2_SnsrCktFP

P2228, P2229

Bundle Name: AAP2_SnsrFA P2227, P2228, P2229, P2230

Bundle Name: AAP2_SnsrTFTKO

P2227, P2228, P2229, P2230

Bundle Name: AccCktLo_FA

P2537

Bundle Name: AcceleratorPedalFailure

P2122, P2123, P2127, P2128, P2138, P0697, P06A3

Bundle Name: ACCMLostComm

U016B

Bundle Name: ACFailedOnSD

See ACCM Document

Bundle Name: ACHighSidePressSnsrCktFA

P0532, P0533

Bundle Name: ACThrmlRefrigSpdVld

See ACCM Document

Bundle Name: AfterThrottlePressTFTKO

Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.

Bundle Name: AfterThrottlePressureFA

Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.

Bundle Name: AfterThrottleVacuumTFTKO

Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.

Bundle Name: AIR System FA

P0411, P2440, P2444

Bundle Name: AIRPumpControlCircuit FA

P0418

Bundle Name: AIRSystemPressureSensor FA

P2430, P2431, P2432, P2433, P2435, P2436, P2437, P2438

Bundle Name: AIRValveControlCircuit FA

P0412

Bundle Name: AmbientAirDefault

Baro Sensor Present: P2227, P2228, P2229, P2230. No Baro Sensor Present: P0101, P0102, P0103, P0106, P0107, P0108, P0111, P0112, P0113, P0114, P0121, P0122, P012B, P012B, P012C, P012D, P0222,

P0223, P1221

Bundle Name: AmbPresDfltdStatus

Baro Sensor Present: P2227, P2228, P2229, P2230. No Baro Sensor Present: P0101, P0102, P0103, P0106, P0107, P0108, P0111, P0112, P0113, P0114, P0121, P0122, P012B, P012B, P012C, P012D, P0222,

P0223, P1221

Bundle Name: AmbPresSnsrCktFA

P2228, P2229

Bundle Name: AmbPresSnsrCktFP

P2228, P2229

Bundle Name: AnyCamPhaser FA

P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024

Bundle Name: AnyCamPhaser TFTKO

P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024

Bundle Name: BrakeBoosterSensorFA

P0556, P0557, P0558

Bundle Name: BrakeBoosterVacuumValid

P0556, P0557, P0558

Bundle Name: BSTR_b_ExcsvBstFA

P226B

Bundle Name: BSTR_b_ExcsvBstTFTKO

P226B

Bundle Name: BSTR_b_IC_PmpCktFA

P023A. P023C

Bundle Name: BSTR_b_PCA_CktFA

P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P0247, P0249, P0250

Bundle Name: BSTR b PCA CktLoFA

P0034, P0047, P0245, P0249

Bundle Name: BSTR_b_PCA_CktLoTFTKO

P0034, P0047, P0245, P0249

Bundle Name: BSTR b PCA CktTFTKO

P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P0247, P0249, P0250

Bundle Name: BSTR_b_PCA_FA

P0234, P0299, P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P2261, P0247, P0249, P0250

Bundle Name: BSTR_b_PCA_PstnSnsrFA

P003A, P2564, P2565

Bundle Name: BSTR b PCA PstnSnsrTFTKO

P003A, P2564, P2565

Bundle Name: BSTR_b_PCA_TFTKO

P0234, P0299, P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P2261, P0247, P0249, P0250

Bundle Name: BSTR b PresCntrlTooHiFA

P0234

Bundle Name: BSTR_b_PresCntrlTooHiTFTKO

P0234

Bundle Name: BSTR b PresCntrlTooLoFA

P0299

Bundle Name: BSTR_b_PresCntrlTooLoTFTKO

P0299

Bundle Name: BSTR_b_PstnCntrlFA

P166D, P166E

Bundle Name: BSTR b PstnCntrlTooHiFA

P166E

Bundle Name: BSTR_b_PstnCntrlTooHiTFTKO

P166E

Bundle Name: BSTR b PstnCntrlTooLoFA

P166D

Bundle Name: BSTR_b_PstnCntrlTooLoTFTKO

P166D

Bundle Name: BSTR_b_TurboBypassCktFA

P0033, P0034, P0035, P00C0, P00C1, P00C2

Bundle Name: BSTR_b_TurboBypassCktTFTKO

P0033, P0034, P0035, P00C0, P00C1, P00C2

Bundle Name: BSTR_b_TurboBypB_CktFA

P00C0, P00C1, P00C2

Bundle Name: BSTR b TurboBypB CktTFTKO

P00C0, P00C1, P00C2

Bundle Name: CamLctnExhFA

P0017, P0019, P0365, P0366, P0390, P0391

Bundle Name: CamLctnIntFA

P0016, P0018, P0340, P0341, P0345, P0346

Bundle Name: CamSensor_FA

P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391

Bundle Name: CamSensor TFTKO

P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391

Bundle Name: CamSensorAnyLctnTFTKO

P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391

Bundle Name: CamSensorAnyLocationFA

P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391

Bundle Name: CamSensorFA

P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391

Bundle Name: CamSensorTFTKO

P0016. P0017. P0018. P0019. P0340. P0341. P0345. P0346. P0365. P0366. P0390. P0391

Bundle Name: CatalystSysEfficiencyLoB1_FA

P0420

Bundle Name: CatalystSysEfficiencyLoB2_FA

P0430

Bundle Name: ClutchPstnSnsr FA

P0806, P0807, P0808

Bundle Name: ClutchPstnSnsrCktHi FA

P0808

Bundle Name: ClutchPstnSnsrCktLo FA

P0807

Bundle Name: ClutchPstnSnsrNotLearned

P080A

Bundle Name: CoolingFanSpeedTooHigh_FA

P0495

Bundle Name: CrankCamCorrelationTFTKO

P0016, P0017, P0018, P0019

Bundle Name: CrankExhaustCamCorrelationFA

P0017, P0019

Bundle Name: CrankExhaustCamCorrFA

P0017, P0019

Bundle Name: CrankIntakeCamCorrelationFA

	13 OBDG02B Engine Diagnostics	Supporting Information
	Fault Bundle Definitions	
P0016, P0018		
Bundle Name: CrankIntakeCamCorrFA		
P0016, P0018		
Bundle Name: CrankSensor_FA		
P0335, P0336		
Bundle Name: CrankSensor_TFTKO		
P0335, P0336		
Bundle Name: CrankSensorFA		
P0335, P0336		
Bundle Name: CrankSensorFaultActive		
P0335, P0336		
Bundle Name: CrankSensorTestFailedTKO		
P0335, P0336		
Bundle Name: CrankSensorTFTKO		
P0335, P0336		
Bundle Name: CylDeacSystemTFTKO		
P3400		
Bundle Name: CylnderDeacDriverTFTKO		
P3401, P3409, P3417, P3425, P3433, P3441, P3449		
Bundle Name: ECT_Sensor_Ckt_FA		
P0117, P0118, P0119		
Bundle Name: ECT_Sensor_Ckt_FP		
P0117, P0118		
Bundle Name: ECT_Sensor_Ckt_High_FP		
P0118		
Bundle Name: ECT_Sensor_Ckt_Low_FP		
P0117		
Bundle Name: ECT_Sensor_Ckt_TFTKO		
P0117, P0118, P0119		
Bundle Name: ECT_Sensor_Ckt_TPTKO		
P0117, P0118, P0019		
Bundle Name: ECT_Sensor_DefaultDetected		
P0117, P0118, P0116, P0125		
Bundle Name: ECT_Sensor_FA		
P0117, P0118, P0116, P0125, P0128		
Bundle Name: ECT_Sensor_Perf_FA		
P0116		

Bundle Name: ECT_Sensor_TFTKO

P0117, P0118, P0116, P0125, P0119

Bundle Name: EGRValve_FP

P0405, P0406, P042E

Bundle Name: EGRValveCircuit FA

P0403, P0404, P0405, P0406

Bundle Name: EGRValveCircuit_TFTKO

P0403, P0404, P0405, P0406

Bundle Name: EGRValvePerformance FA

P0401, P042E

Bundle Name: EGRValvePerformance_TFTKO

P0401, P042E

Bundle Name: EngineMetalOvertempActive

P1258

Bundle Name: EngineMisfireDetected_FA

P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308

Bundle Name: EngineMisfireDetected_TFTKO

P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308

Bundle Name: EngineModeNotRunTimer_FA

P2610

Bundle Name: EngineModeNotRunTimerError

P2610

Bundle Name: EnginePowerLimited

P0068, P0122, P0123, P0222, P0223, P0601, P0604, P0606, P1682, P16F3, P1104, P2100, P2101, P2102, P2103, P2176, P160E, P160D, P0191, P0192,

P0193, P00C8, P00C9, P16A0, P16A1, P16A2

Bundle Name: EngineTorqueEstInaccurate

EngineMisfireDetected FA, FuelInjedtorCircuit FA, FuelInjedtorCircuit TFTKO, FuelTrimSystemB1 FA, FuelTrimSystemB2 FA, MAF_SensorTFTKO, MAP_SensorTFTKO,

EGRValuePerforamnce FA

Bundle Name: EngModeNotRunTmErr

P2610

Bundle Name: EngOilModeledTempValid

ECT_Sensor_FA, IAT_SensorCircuitFA

Bundle Name: EngOilPressureSensorCktFA

P0522, P0523

Bundle Name: EngOilPressureSensorFA

P0521, P0522, P0523

Bundle Name: EngOilTempFA

EngOilTempSensorCircuitFA, EngOilModeledTempValid, P16F3

EngOilTempFA - Other Definitions:

P16F3 with GetXOYR_b_SecurityFlt(CeXOYR_e_EOTR_SecurityFlt)

Bundle Name: EngOilTempSensorCircuitFA

P0197, P0198

Bundle Name: Ethanol Composition Sensor FA

P0178, P0179, P2269

Bundle Name: EvapExcessPurgePsbl_FA

Conventional fuel system, P0442, P0455, P0458, P0496

Bundle Name: EvapPurgeSolenoidCircuit_FA

P0443, P0458, P0459

Bundle Name: EvapReducedPurgePsbl_FA

Only EREV sealed fuel system, P0443, P0446, P0449, P0459, P0497, P0499, P2419, P2422

Bundle Name: EvapVentSolenoidCircuit_FA

P0449, P0498, P0499

Bundle Name: ExhaustCamSensor FA

P0017, P0019, P0365, P0366, P0390, P0391

Bundle Name: ExhaustCamSensor_TFTKO

P0017, P0019, P0365, P0366, P0390, P0391

Bundle Name: ExhaustCamSensorFA

P0017, P0019, P0365, P0366, P0390, P0391

Bundle Name: ExhaustCamSensorTFTKO

P0017, P0019, P0365, P0366, P0390, P0391

Bundle Name: FanOutputDriver_FA

P0480, P0481, P0482, P0691, P0692, P0693, P0694, P0695, P0696, P1485 (EREV), P1486 (EREV), P1487 (EREV)

Bundle Name: FHPD_b_HPC_PresErrNeg_FA

P228D

Bundle Name: FHPD_b_HPC_PresErrNeg_TFTKO

P228D

Bundle Name: FHPD_b_HPC_PresErrPos_FA

P228C

Bundle Name: FHPD_b_HPC_PresErrPos_TFTKO

P228C

Bundle Name: FHPD_b_HPC_Windup_ TFTKO

P0089

Bundle Name: FHPD_b_HPC_Windup_FA

P0089

Bundle Name: FHPD_b_PumpCurr_FA

P163A

Bundle Name: FHPD_b_PumpCurr_TFTKO

P163A

Bundle Name: FHPR_b_FRP_SnsrCkt_FA

P0192, P0193

Bundle Name: FHPR b FRP SnsrCkt TFTKO

P0192, P0193

Bundle Name: FHPR_b_FRP_SnsrPerfDiag_FA

P0191

Bundle Name: FHPR_b_FRP_SnsrPerfDiag_TFTKO

P0191

Bundle Name: FHPR_b_PumpCkt_FA

P0090, P0091, P0092, P00C8, P00C9, P00CA

Bundle Name: FHPR_b_PumpCkt_TFTKO

P0090, P0091, P0092, P00C8, P00C9, P00CA

Bundle Name: FuelInjectorCircuit_FA

P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271,

PP0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216E, P217B, P217E, P2148, P2151, P2154, P2157, P216C, P216F, P217C, P217F,

P1248, P1249, P124A, P124B, P124C, P124D, P124E, P124F

Bundle Name: FuelInjectorCircuit_TFTKO

P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271,

PP0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216E, P217B, P217E, P2148, P2151, P2154, P2157, P216C, P216F, P217C, P217F,

P1248, P1249, P124A, P124B, P124C, P124D, P124E, P124F

Bundle Name: FuelLevelDataFault

P0461, P0462, P0463, P2066, P2067, P2068

Bundle Name: FuelTrimSystemB1_FA

P0171, P0172

Bundle Name: FuelTrimSystemB1_TFTKO

P0171, P0172

Bundle Name: FuelTrimSystemB2_FA

P0174, P0175

Bundle Name: FuelTrimSystemB2 TFTKO

P0174, P0175

Bundle Name: HumidityFA

P0097, P0098, P11C2, P11C3, P2227, P2228, P2229, P2230

Bundle Name: HumTempSnsrCktFA

P0097, P0098

Bundle Name: HumTempSnsrCktFP

P0097, P0098

Bundle Name: HumTempSnsrFA

P0096, P0097, P0098, P0099

Bundle Name: IAC SystemRPM FA

P0506, P0507

Bundle Name: IAT ContCorrFA

P2199

Bundle Name: IAT_SensorCircuitFA

P0112, P0113

Bundle Name: IAT SensorCircuitFP

P0112, P0113

Bundle Name: IAT_SensorCircuitTFTKO

P0112, P0113

Bundle Name: IAT_SensorFA P0111, P0112, P0113, P0114

Bundle Name: IAT_SensorTFTKO P0111, P0112, P0113, P0114

Bundle Name: IgnitionOffTimer_FA

P2610

Bundle Name: IgnitionOffTimeValid

P2610

Bundle Name: IgnitionOutputDriver_FA

P0351, P0352, P0353, P0354, P0355, P0356, P0357, P0358

Bundle Name: IntakeCamSensor_FA

P0016, P0018, P0340, P0341, P0345, P0346

Bundle Name: IntakeCamSensor_TFTKO

P0016, P0018, P0340, P0341, P0345, P0346

Bundle Name: IntakeCamSensorFA

P0016, P0018, P0340, P0341, P0345, P0346

Bundle Name: IntakeCamSensorTFTKO

P0016, P0018, P0340, P0341, P0345, P0346

Bundle Name: IntkCamPhaser_FA

P0010, P0011, P0020, P0021

Bundle Name: KS Ckt Perf B1B2 FA

P0324, P0325, P0326, P0327, P0328, P0330, P0332, P0333, P06B6, P06B7

Bundle Name: Long Name

Short Name

Bundle Name: LowFuelConditionDiagnostic

LowFuelConditionDiagnostic - Other Definitions:

Flag set to TRUE if the fuel level < 10.0 % AND

No Active DTCs: FuelLevelDataFault, P0462, P0463 for at least 30.0 seconds

Bundle Name: MAF_SensorCircuitFA

P0102, P0103, P010C, P010D

Bundle Name: MAF SensorCircuitTFTKO

P0102, P0103, P010C, P010D

Bundle Name: MAF_SensorFA

P0101, P0102, P0103, P010C, P010D

Bundle Name: MAF_SensorFP P0102, P0103, P010C, P010D

Bundle Name: MAF_SensorPerfFA

P0101

Bundle Name: MAF_SensorPerfTFTKO

P0101

Bundle Name: MAF_SensorTFTKO P0101, P0102, P0103, P010C, P010D

Bundle Name: MAF_SnsrCktFA

P121B, P121C

Bundle Name: MAF_SnsrCktTFTKO

P121B, P121C

Bundle Name: MAP_EngineVacuumStatus

P0106, P0107, P0108 Fault Active OR P0107, P0108 Fault Pending

Bundle Name: MAP_SensorCircuitFA

P0107, P0108

Bundle Name: MAP_SensorCircuitFP

P0107, P0108

Bundle Name: MAP_SensorFA

P0106, P0107, P0108

Bundle Name: MAP_SensorPerfFA

P0106

Bundle Name: MAP_SensorPerfTFTKO

P0106

Bundle Name: MAP_SensorTFTKO

P0106, P0107, P0108

Bundle Name: MnfdTempSensorCktFA

Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.

Bundle Name: MnfdTempSensorCktFP

Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.

Bundle Name: MnfdTempSensorCktTFTKO

Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.

Bundle Name: MnfdTempSensorFA

Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.

Bundle Name: MnfdTempSensorTFTKO

Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.

Bundle Name: ModuleOffTime_FA

P2610

Bundle Name: ModuleOffTimeErr

P2610

Bundle Name: no validity name is assigned to this fault bundle

Bundle Name: OAT_AmbientFilteredFA

ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor_FA, IAT_SensorFA, ECT_Sensor_DefaultDetected, MAF_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: not applicable. All other cases: not applicable.

Bundle Name: OAT_AmbientSensorFA

ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: not applicable.

Bundle Name: OAT PtEstFiltFA

ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor_FA, IAT_SensorFA, ECT_Sensor_DefaultDetected, MAF_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: VehicleSpeedSensor_FA, IAT_SensorFA, MAF_SensorFA. All other cases: EngModeNotRunTmErr, VehicleSpeedSensor FA, IAT_SensorFA, ECT_Sensor DefaultDetected.

Bundle Name: OAT PtEstRawFA

ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: IAT_SensorFA. All other cases: IAT_SensorFA, ECT_Sensor_DefaultDetected.

Bundle Name: OilPmpCktFA

P06DA, P06DB, P06DC

OilPmpCktFA - Other Definitions:

Output Driver Codes

Bundle Name: OilPmpFA

P06DA, P06DB, P06DC, P06DD, P06DE

OilPmpFA - Other Definitions:

FA only for Output Driver and rationality

Bundle Name: OilPmpStuckHigh

P06DA, P06DB, P06DD

OilPmpStuckHigh - Other Definitions:

TFTKO and FA

Bundle Name: OilPmpStuckLow

P06DC, P06DE

OilPmpStuckLow - Other Definitions:

Fault Bundle Definitions TFTKO and FA Bundle Name: OilPmpTFTKO P06DA, P06DB, P06DC, P06DD, P06DE OilPmpTFTKO - Other Definitions: TFTKO only for Output Driver and rationality Bundle Name: PowertrainRelayFault P1682 Bundle Name: PowertrainRelayStateOn Error P0685 Bundle Name: PowertrainRelayStateOn FA P0685 Bundle Name: PPS1_OutOfRange P2122, P2123 Bundle Name: PPS1_OutOfRange_Composite P2122, P2123, P06A3 Bundle Name: PPS2_OutOfRange P2127, P2128 Bundle Name: PPS2_OutOfRange_Composite P2127, P2128, P0697 Bundle Name: SCIAP_SensorCircuitFA P012C, P012D Bundle Name: SCIAP_SensorCircuitFP P012C, P012D Bundle Name: SCIAP_SensorFA P012B, P012C, P012D Bundle Name: SCIAP_SensorPerfFA P012B Bundle Name: SCIAP_SensorPerfTFTKO P012B Bundle Name: SCIAP_SensorTFTKO P012B, P012C, P012D Bundle Name: SuperchargerBypassValveFA P2261 Bundle Name: SystemVoltageHigh_FA P0563 Bundle Name: SystemVoltageLow_FA P0562 Bundle Name: TC_BoostPresSnsrCktFA

P0237, P0238

Bundle Name: TC BoostPresSnsrFA

P0236, P0237, P0238

Bundle Name: TCM_EngSpdReqCkt

P150C

Bundle Name: THMR AHV FA

P2681, P26A3, P26A6, P26A7, P26A9

Bundle Name: THMR_AWP_AuxPumpFA

B2920, B2923, B2922

Bundle Name: THMR ECT Sensor Ckt FA

P0116, P0117, P0118, P00B6

Bundle Name: THMR_Insuff_Flow_FA

P00B7

Bundle Name: THMR_RCT_Sensor_Ckt_FA

P00B3, P00B4

Bundle Name: THMR_SWP_Control_FA

P261D. P261A. P261C

Bundle Name: THMR_Therm_Control_FA

P0597, P0598, P0599

Bundle Name: ThrotTempSensorFA

Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099.

Naturally Aspirated: P0111, P0112, P0113, P0114.

Bundle Name: ThrotTempSensorTFTKO

Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099.

Naturally Aspirated: P0111, P0112, P0113, P0114.

Bundle Name: ThrottlePositionSnsrPerfFA

P0121

Bundle Name: ThrottlePositionSnsrPerfTFTKO

P0121

Bundle Name: TIAP_SensorPerfFA

P0236

Bundle Name: TPS FA

P0122, P0123, P0222, P0223, P2135

Bundle Name: TPS_FaultPending

P0122, P0123, P0222, P0223, P2135

Bundle Name: TPS_Performance_FA

P0068, P0121, P1104, P2100, P2101, P2102, P2103

Bundle Name: TPS_Performance_TFTKO

P0068, P0121, P1104, P2100, P2101, P2102, P2103

Bundle Name: TPS_TFTKO

P0122, P0123, P0222, P0223, P2135

Bundle Name: TPS ThrottleAuthorityDefaulted

P0068, P0122, P0123, P0222, P0223, P16F3, P1104, P2100, P2101, P2102, P2103, P2135

Bundle Name: TPS1_OutOfRange_Composite

P0122, P0123, P06A3

Bundle Name: TPS2_OutOfRange_Composite

P0222, P0223, P06A3

Bundle Name: Trans Output Rotations Rolling Count Validity

Bundle Name: Transfer Pump is Commanded On

Transfer Pump is Commanded On - Other Definitions:

Fuel Volume in Primary Fuel Tank < 0.0 liters AND

Fuel Volume in Secondary Fuel Tank ≥ 0.0 liters AND

Transfer Pump on Time < P0461, P2066, P2636: Transfer Pump Enable (see supporting table for numeric value) AND

Transfer Pump had been Off for at least 0.0 seconds AND

Evap Diagnostic (Purge Valve Leak Test, Large Leak Test, and Waiting for Purge) is not running AND

Engine Running

Bundle Name: Transmission Actual Gear Validity

Bundle Name: Transmission Engaged State Validity

Bundle Name: Transmission Estimated Gear Validity

Bundle Name: Transmission Gear Ratio Validity

Bundle Name: Transmission Gear Selector Position Validity

Bundle Name: Transmission Oil Temperature Validity

Bundle Name: Transmission Output Shaft Angular Velocity Validity

Bundle Name: Transmission Overall Actual Torque Ratio Validity

Bundle Name: Transmission Overall Estimated Torque Ratio Validity

Bundle Name: Transmission Shift Lever Position Validity

	Fault Bundle Definitions
Bundle Name: Transmission Turbine Angular Velocity Validity	
Bundle Name: TransmissionEngagedState_FA	
MYD/MYC/MYB:, P182E, P1915	
Bundle Name: TransmissionGearDefaulted	
MYD/MYC/MYB:, P182E, P1915	
Bundle Name: VehicleSpeedSensor_FA	
P0502, P0503, P0722, P0723	
Bundle Name: VehicleSpeedSensorError	
P0502, P0503, P0722, P0723	