

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Open – Bank 1	P0010	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply voltage is within limits Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	60 failures out of 70 samples 250 ms / sample, continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Performance – Bank 1	P0011	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Intake cam Bank 1) Cam Position Error > 5.00 deg. (CamPosErrorLimlc1)	DTC's are NOT active: P0010, IntakeCamSensorTFTKO CrankSensorTFTKO CrankIntakeCamCorrelationFA.	System Voltage > 11.00 Volts, Engine is running VVT is enabled Desired cam position > 0 Power Take Off (PTO) not active Both Desired & Measured cam positions cannot be < 5.00 (CamPosErrorLimlc1) or have both > 25.00 deg. (PerfMaxlc1) . Desired cam position cannot vary more than 4.00 Cam Deg for at least 2.00 sec. (StablePositionTimeIc1)	120.00 failures out of 150.00 samples 100 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Open – Bank 1	P0013	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply voltage is within limits Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	60 failures out of 70 samples 250 ms / sample, continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft System Performance – Bank 1	P0014	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Exhaust cam Bank 1) Cam Position Error > 5.00 deg. (CamPosErrorLimEc1)	DTC's are NOT active: P0013, ExhaustCamSensorTFTKO CrankSensorTFTKO CrankExhaustCamCorrelationFA	System Voltage > 11.00 Volts, Engine is running VVT is enabled Desired cam position > 0 Power Take Off (PTO) not active Both Desired & Measured cam positions cannot be < 5.00 deg. (CamPosErrorLimEc1) or have both > (25.00) (PerfMaxEc1). Desired cam position cannot vary more than 4.00 Cam Deg for at least 2.00 sec. (StablePositionTimeEc1)	120.00 failures out of 150.00 samples 100 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)- Camshaft Position (CMP) Correlation Bank 1 Sensor A	P0016	Detects cam to crank misalignment by monitoring if cam sensor pulse for bank 1 sensor A occurs during the incorrect crank position	4 cam sensor pulses more than -12.0 crank degrees before or 12.0 crank degrees after nominal position in one cam revolution.		Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic	P0335, P0336 P0340,P0341 5VoltReferenceA_FA 5VoltReferenceB_FA < 1.0 seconds	2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table "Cam Correlation Oil Temperature Threshold". One sample per cam rotation	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)- Camshaft Position (CMP) Correlation Bank 1 Sensor B	P0017	Detects cam to crank misalignment by monitoring if cam sensor pulse for bank 1 sensor B occurs during the incorrect crank position	4 cam sensor pulses more than -12.0 crank degrees before or 12.0 crank degrees after nominal position in one cam revolution.		Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic	P0335, P0336 P0365,P0366 5VoltReferenceA_FA 5VoltReferenceB_FA < 1.0 seconds	2 failures out of 3 tests. A failed test is 4 failures out of 5 samples. There is a delay after the first failed test to allow the camshaft position to return to the park position. This time is defined by the table "Cam Correlation Oil Temperature Threshold". One sample per cam rotation	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 1	P0030	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0031 may also set

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0031	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short- to-ground).	Short to ground: $\leq 0.5 \Omega$ impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0030 may also set

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0032	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power).	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve Control Circuit	P0033	Detect Turbocharger Bypass Valve - Open Circuit	ECM detects that commanded and actual states of output driver do not match because the output is open circuit		Diagnostic Enabled EnabledPowertrain relay Voltage Ignition run crank voltage Engine is not cranking	1 >= 11.00 Volts >= 5.00 Volts	10 failures out of 20 samples 1 sample every 100ms	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve Control Circuit Low	P0034	Detect Turbocharger Bypass Valve - Shorted to Ground	ECM detects that commanded and actual states of output driver do not match because the output is shorted to ground		Diagnostic Enabled EnabledPowertrain relay Voltage Ignition run crank voltage Engine is not cranking	1 >= 11.00 Volts >= 5.00 Volts	10 failures out of 20 samples 1 sample every 100ms	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve Control Circuit High	P0035	Detect Turbocharger Bypass Valve - Shorted to Power	ECM detects that commanded and actual states of output driver do not match because the output is shorted to power		Diagnostic Enabled EnabledPowertrain relay Voltage Ignition run crank voltage Engine is not cranking	1 >= Volts 11.00 >= 5.00 Volts	10 failures out of 20 samples 1 sample every 100ms	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 2	P0036	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit).	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0037 may also set

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0037	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short- to-ground).	Short to ground: $\leq 0.5 \Omega$ impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0036 may also set

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0038	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power).	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 1	P0053	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	$7.5 < \Omega < 13.0$	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,820 seconds -30.0 < °C < 45.0 < 31.9 volts < 0.05 seconds	Once per valid cold start	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0054	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	$7.5 < \Omega < 13.0$	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,820 seconds -30.0 < °C < 45.0 < 31.9 volts < 0.05 seconds	Once per valid cold start	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
MAP / MAF / Throttle Position Correlation	P0068	Detect when MAP and MAF do not match estimated engine airflow as established by the TPS	<p>Difference between MAP and estimated MAP exceeds threshold (kPa), or P0651 (5 Volt Ref), or P0107 (MAP circuit low), or P0108 (MAP circuit high) have failed this key cycle, then MAP portion of diagnostic fails</p> <p>Absolute difference between MAF and estimated MAF exceed threshold (grams/sec), or P0102 (MAF circuit low), or P0103 (MAF circuit hi) have failed this key cycle, or maximum MAF versus RPM (Table) is greater than or equal to maximum MAF versus battery voltage, then MAF portion of diagnostic fails</p>	<p>Table, f(TPS). See supporting tables: Delta MAP Threshold f(TPS)</p> <p>Table, f(TPS). See supporting tables: Delta MAF Threshold f(TPS)</p> <p>Table, f(RPM). See supporting tables: Maximum MAF f (RPM)</p> <p>Table, f(Volts). See supporting tables: Maximum MAF f (Volts)</p>	Engine Speed	<p>> 800 RPM</p> <p>Run/Crank voltage > 6.41</p>	<p>Continuously fail MAP and MAF portions of diagnostic for 0.1875 s</p> <p>Continuous in MAIN processor</p>	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Intake Air Temperature Sensor 2 Circuit Performance (applications with humidity sensor and manifold temperature sensor)	P0096	Detects an IAT2 sensor that has stuck in range by comparing to IAT and IAT3 at startup	ABS(Power Up IAT - Power Up IAT2)	> 25 deg C	Time between current ignition cycle and the last time the engine was running	> 28,800 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips	
			AND						
			ABS(Power Up IAT - Power Up IAT3)	<= 25 deg C	Powertrain Relay Voltage for a time	>= 11.00 Volts >= 0.9 seconds			
			AND		No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA			
			ABS(Power Up IAT2 - Power Up IAT3)	> 25 deg C					
			Power Up IAT is between Power Up IAT2 and Power Up IAT3		Time between current ignition cycle and the last time the engine was running	> 28,800 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met		
			AND						
			ABS(Power Up IAT2 - Power Up IAT3)	> 25 Deg C	Powertrain Relay Voltage for a time	>= 11.00 Volts >= 0.9 seconds			
			AND		No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA			
			ABS(Power Up IAT - Power Up IAT2) > ABS(Power Up IAT - Power Up IAT3)						
			Power Up IAT3 is between Power Up IAT and Power Up IAT2		Time between current ignition cycle and the last time the engine was running	> 28,800 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met		
			AND						
			ABS(Power Up IAT - Power Up IAT2)	> 25 deg C	Powertrain Relay Voltage for a time	>= 11.00 Volts >= 0.9 seconds			
			AND		No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA			
			ABS(Power Up IAT3 -						

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Power Up IAT2) > ABS(Power Up IAT3 - Power Up IAT)			HumTempSnsrCktFA		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 Low (applications with humidity)	P0097	Detects a continuous short to ground or open in the IAT 2 signal circuit	Raw IAT 2 Input	< 13 Hertz (~-60 deg C)	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 High (applications with humidity)	P0098	Detects a continuous high frequency in the IAT 2 signal circuit	Raw IAT 2 Input	> 390 Hertz (~150 deg C)	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp Sensor Circuit Low Voltage	P00B3	This DTC detects a short to ground in the RCT signal circuit or the RCT sensor.	RCT Resistance (@ 150°C)	< 34 Ohms	Engine run time OR IAT min	> 10.0 seconds ≤ 70.3 °C	5 failures out of 10 samples 1 sec/ sample Continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp Sensor Circuit High Voltage	P00B4	Circuit Continuity This DTC detects a short to high or open in the RCT signal circuit or the RCT sensor.	RCT Resistance (@ -60°C)	> 260,000 Ohms	Engine run time OR IAT min	> 60.0 seconds ≥ -7.0 °C	5 failures out of 10 samples 1 sec/ sample Continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp - Engine Coolant Temp (ECT) Correlation (DCRD)	P00B6	This DTC detects a difference between ECT and RCT after a soak condition.	<p>A failure will be reported if any of the following occur:</p> <p>1) Absolute difference between ECT at power up & RCT at power up is \geq an IAT based threshold table lookup value(fast fail).</p> <p>2) Absolute difference between ECT at power up & RCT at power up is $>$ by 20.0 °C and a block heater has not been detected.</p> <p>3) ECT at power up $>$ RCT at power up by 20.0 °C and the time spent cranking the engine without starting is greater than or equal to 10.0 seconds with the LowFuelConditionDiag</p>	<p>See the table named: P00B6_Fail if power up ECT exceeds RCT by these values in the Supporting tables section</p> <p>= False</p>	<p>No Active DTC's</p> <p>Engine Off Soak Time Propulsion Off Soak Time Non-volatile memory initialization</p> <p>Test complete this trip Test aborted this trip IAT LowFuelCondition Diag</p> <p>=====</p> <p>Block Heater detection is enabled when either of the following occurs:</p> <p>1) ECT at power up $>$ IAT at power up by 2) Cranking time</p> <p>=====</p> <p>Block Heater is detected and diagnostic is aborted when 1) or 2) occurs.</p> <p>1a) Vehicle drive time 1b) Vehicle speed</p> <p>1c) Additional Vehicle drive time is provided to 1a when Vehicle speed is</p>	<p>VehicleSpeedSensor_FA IAT_SensorCircuitFA THMR_RCT_Sensor_Ckt_FA THMR_ECT_Sensor_Ckt_FA IgnitionOffTimeValid TimeSinceEngineRunningValid $>$ 28,800 seconds $>$ 0 seconds = Not occurred</p> <p>= False = False \geq -7 °C = False</p> <p>=====</p> <p>$>$ 20.0 °C $<$ 10.0 Seconds</p> <p>=====</p> <p>$>$ 400 Seconds with $>$ 14.9MPH and</p> <p>0.00 times the seconds with vehicle speed below</p>	<p>1 failure 500 msec/ sample Once per valid cold start</p>	<p>Type B, 2 Trips</p>

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					below 1b as follows: 1d) IAT drops from power up IAT 2a) ECT drops from power up ECT 2b) Engine run time ===== Diagnostic is aborted when 3) or 4) occurs: 3) Engine run time with vehicle speed below 1b 4) Minimum IAT during test	1b $\geq 3.3^{\circ}\text{C}$ $> 2^{\circ}\text{C}$ Within < 60 Seconds ===== > 1800 Seconds $\leq -7.0^{\circ}\text{C}$		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Flow Insufficient	P00B7	This DTC detects a Insufficient Flow Condition (i.e.. Stuck Closed Thermostat)	Engine Coolant Temp (ECT) is greater than 124 Deg C and Difference between ECT and RCT is greater than 40 Deg C. When above is present for more than 5 seconds, fail counts start.		No Active DTC's Engine run time AND Engine Coolant Temp	THMR_RCT_Sensor_Ckt _FA THMR_ECT_Sensor_Ckt _FA > 30 seconds > 80.0 Deg C	30 failures out of 300 samples 1 sec/ sample Continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Pressure Measurement System - Multiple Sensor Correlation (turbocharged)	P00C7	Detects an inconsistency between pressure sensors in the induction system in which a particular sensor cannot be identified as the failed sensor	ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure) OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure) OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure) OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure)	> 10.0 kPa <= 10.0 kPa <= 10.0 kPa <= 10.0 kPa > 10.0 kPa <= 10.0 kPa <= 10.0 kPa > 10.0 kPa > 10.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating Manifold Pressure Manifold Pressure Baro Pressure Baro Pressure Turbocharger Boost Pressure Turbocharger Boost Pressure No Active DTCs: No Pending DTCs:	> 10.0 seconds >= 50.0 kPa <= 115.0 kPa >= 50.0 kPa <= 115.0 kPa >= 50.0 kPa <= 115.0 kPa EngineModeNotRunTimer Error MAP_SnsrFA AAP_SnsrFA AAP2_SnsrFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP	4 failures out of 5 samples 1 sample every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	> 10.0 kPa > 10.0 kPa				

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Intake Air Temperature Sensor 3 Circuit Performance (applications with humidity sensor and manifold temperature sensor)	P00E9	Detects an IAT3 sensor that has stuck in range by comparing to IAT and IAT2 at startup	ABS(Power Up IAT - Power Up IAT2)	<= 25 deg C	Time between current ignition cycle and the last time the engine was running	> 28,800 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips	
			AND			Powertrain Relay Voltage for a time			>= 11.00 Volts >= 0.9 seconds
			ABS(Power Up IAT - Power Up IAT3)	> 25 deg C	No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA			
			Power Up IAT is between Power Up IAT2 and Power Up IAT3		Time between current ignition cycle and the last time the engine was running	> 28,800 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met		
			AND		Powertrain Relay Voltage for a time	>= 11.00 Volts >= 0.9 seconds			
			ABS(Power Up IAT2 - Power Up IAT3)	> 25 Deg C	No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA			
			Power Up IAT2 is between Power Up IAT and Power Up IAT3		Time between current ignition cycle and the last time the engine was running	> 28,800 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met		
			AND		Powertrain Relay Voltage for a time	>= 11.00 Volts >= 0.9 seconds			
			ABS(Power Up IAT - Power Up IAT3) > ABS(Power Up IAT - Power Up IAT2)	> 25 deg C	No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA			

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Power Up IAT3) > ABS(Power Up IAT2 - Power Up IAT)			HumTempSnsrCktFA		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 3 Low (applications with manifold temperature and humidity)	P00EA	Detects a continuous short to ground in the IAT 3 signal circuit or the IAT 3 sensor	Raw IAT 3 Input	< 56 Ohms (~150 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 3 High (applications with manifold temperature and humidity)	P00EB	Detects a continuous open circuit in the IAT 3 signal circuit or the IAT 3 sensor	Raw IAT 3 Input	> 151,542 Ohms (~-60 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Low	P00F4	Detects a continuous short to power in the Humidity Sensor circuit	Humidity Duty Cycle	<= 5.0 %	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit High	P00F5	Detects a continuous open or short to low in the Humidity Sensor circuit	Humidity Duty Cycle	>= 95.0 %	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (turbocharged)	P0101	Determines if the MAF sensor is stuck within the normal operating range	See table " Turbocharger Intake Flow Rationality Diagnostic Failure Matrix " for combinations of model failures that can set this DTC. MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed	> 16 grams/sec > 20.0 kPa > 25.0 kPa > 25.0 kPa > 25.0 kPa > 250 kPa*(g/s) > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 100 Deg C >= 0.50 Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>See table "TIAP-MAP Correlation Offset"</p> <p>OR</p> <p>Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset"</p> <p>TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time</p> <p>High Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND Manifold Pressure</p> <p>AND</p>	<p>> 25.0 kPa</p> <p>> 2.0 seconds</p> <p>> 2.0 seconds</p> <p>> a threshold in gm/sec as a function of engine speed See table "TIAP-MAP Correlation Min Air Flow"</p> <p>> a threshold in kPa as a function of engine speed See table "TIAP-MAP Correlation Min MAP"</p>	<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>See Residual Weight Factor tables.</p> <p>MAP_SensorCircuitFA EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Filtered Mass Air Flow - Mass Air Flow Low Engine Air Flow is TRUE when Mass Air Flow AND Manifold Pressure AND Mass Air Flow - Filtered Mass Air Flow	< 2.0 gm/sec < a threshold in gm/sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow" < a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP" < 2.0 gm/sec				

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit Low Frequency	P0102	Detects a continuous short to low or a open in either the signal circuit or the MAF sensor	MAF Output	<= 1,400 Hertz (~ 0.85 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 8.0 Volts >= 1.0 seconds	200 failures out of 250 samples 1 sample every cylinder firing event	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit High Frequency	P0103	Detects a high frequency output from the MAF sensor	MAF Output	>= 14,500 Hertz (~ 282.7 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 8.0 Volts >= 1.0 seconds	200 failures out of 250 samples 1 sample every cylinder firing event	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (turbocharge d)	P0106	Determines if the MAP sensor is stuck within the normal operating range	See table " Turbocharger Intake Flow Rationality Diagnostic Failure Matrix " for combinations of model failures that can set this DTC. MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table " TIAP-MAP	> 16 grams/sec > 20.0 kPa > 25.0 kPa > 25.0 kPa > 25.0 kPa > 250 kPa*(g/s) > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 100 Deg C >= 0.50 Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Correlation Offset"</p> <p>OR</p> <p>Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset"</p> <p>TIAP Correlation is valid when</p> <p>High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time</p> <p>High Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND Manifold Pressure</p> <p>AND Filtered Mass Air Flow - Mass Air Flow</p>	<p>> 25.0 kPa</p> <p>> 2.0 seconds</p> <p>> 2.0 seconds</p> <p>> a threshold in gm/sec as a function of engine speed See table "TIAP-MAP Correlation Min Air Flow"</p> <p>> a threshold in kPa as a function of engine speed See table "TIAP-MAP Correlation Min MAP"</p> <p>< 2.0 gm/sec</p>	<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>See Residual Weight Factor tables.</p> <p>MAP_SensorCircuitFA EGRValvePerformance_FA MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Low Engine Air Flow is TRUE when Mass Air Flow	< a threshold in gm/sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow"				
			AND Manifold Pressure	< a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP"				
			AND Mass Air Flow - Filtered Mass Air Flow	< 2.0 gm/sec				
			Manifold Pressure OR Manifold Pressure	< 50.0 kPa > 115.0 kPa	Time between current ignition cycle and the last time the engine was running	> 10.0 seconds	4 failures out of 5 samples	
			OR ABS(Manifold Pressure - Baro Pressure)	> 10.0 kPa	Engine is not rotating	EngineModeNotRunTimer Error	1 sample every 12.5 msec	
			AND ABS(Turbocharger Boost Pressure - Manifold Pressure)	> 10.0 kPa	No Active DTCs:	MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA		
			AND ABS(Turbocharger Boost Pressure - Baro Pressure)	<= 10.0 kPa	No Pending DTCs:	MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit Low	P0107	Detects a continuous short to low or open in either the signal circuit or the MAP sensor.	MAP Voltage	< 3.0% of 5 Volt Range (This is equal to 0.15 Volts or -1.9 kPa)	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit High	P0108	Detects an open sensor ground or continuous short to high in either the signal circuit or the MAP sensor.	MAP Voltage	> 97.0 % of 5 Volt Range (This is equal to 4.85 Volts, or 291.9 kPa)	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Intake Air Temperature Sensor Circuit Performance (applications with humidity sensor and manifold temperature sensor)	P0111	Detects an IAT sensor that has stuck in range by comparing to IAT2 and IAT3 at startup	ABS(Power Up IAT - Power Up IAT2)	> 25 deg C	Time between current ignition cycle and the last time the engine was running	> 28,800 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips	
			AND						
			ABS(Power Up IAT - Power Up IAT3)	> 25 deg C	Powertrain Relay Voltage for a time	>= 11.00 Volts >= 0.9 seconds			
			AND		No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA			
			ABS(Power Up IAT2 - Power Up IAT3)	<= 25 deg C					
			Power Up IAT2 is between Power Up IAT and Power Up IAT3		Time between current ignition cycle and the last time the engine was running	> 28,800 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met		
			AND						
			ABS(Power Up IAT - Power Up IAT3)	> 25 deg C	Powertrain Relay Voltage for a time	>= 11.00 Volts >= 0.9 seconds			
			AND		No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA			
			ABS(Power Up IAT2 - Power Up IAT) > ABS(Power Up IAT2 - Power Up IAT3)						
			Power Up IAT3 is between Power Up IAT and Power Up IAT2		Time between current ignition cycle and the last time the engine was running	> 28,800 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met		
			AND						
			ABS(Power Up IAT - Power Up IAT2)	> 25 deg C	Powertrain Relay Voltage for a time	>= 11.00 Volts >= 0.9 seconds			
			AND		No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA			
			ABS(Power Up IAT3 -						

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Power Up IAT) > ABS(Power Up IAT3 - Power Up IAT2)			HumTempSnsrCktFA		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Low	P0112	Detects a continuous short to ground in the IAT signal circuit or the IAT sensor	Raw IAT Input	< 62 Ohms (~150 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit High	P0113	Detects a continuous open circuit in the IAT signal circuit or the IAT sensor	Raw IAT Input	> 126,840 Ohms (~-60 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Intermittent In-Range	P0114	Detects a noisy or erratic IAT signal circuit or IAT sensor	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current IAT reading - IAT reading from 100 milliseconds previous)	> 99,999,997,952.00 DegC 10 consecutive IAT samples	Continuous		4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Performance	P0116	This DTC detects ECT temp sensor stuck in mid range.	<p>A failure will be reported if any of the following (1-3) occur after the following soak conditions, Engine off time > 28,800 seconds Propulsion system off time > 0 seconds</p> <p>1) ECT at power up > IAT at power up by an IAT based table lookup value (fast fail).</p> <p>2) ECT at power up > IAT at power up by 20.0 Deg C and a block heater has not been detected.</p> <p>3) ECT at power up > IAT at power up by 20.0 Deg C and the time spent cranking the engine without starting is greater than 10.0 seconds with the LowFuelConditionDiag</p>	<p>See the table named: P0116_Fail if power up ECT exceeds IAT by these values in the Supporting tables section</p> <p>= False</p>	<p>No Active DTC's</p> <p>Non-volatile memory initialization</p> <p>Test complete this trip Test aborted this trip IAT LowFuelCondition Diag</p> <p>=====</p> <p>Block Heater detection is enabled when either of the following occurs:</p> <p>1) ECT at power up > IAT at power up by</p> <p>2) Cranking time</p> <p>=====</p> <p>Block Heater is detected and diagnostic is aborted when 1) or 2) occurs:</p> <p>1a) Vehicle drive time</p> <p>1b) Vehicle speed</p> <p>1c) Additional Vehicle drive time is provided to 1a when Vehicle speed is below 1b as follows:</p> <p>1d) IAT drops from power up IAT</p>	<p>VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_Ckt_FA IgnitionOffTimeValid</p> <p>= Not occurred</p> <p>= False = False ≥ -7 °C</p> <p>= False</p> <p>=====</p> <p>> 20.0 °C</p> <p>< 10.0 seconds</p> <p>=====</p> <p>> 400 seconds</p> <p>> 14.9 MPH</p> <p>0.50 times the seconds with vehicle speed below 1b</p> <p>≥ 3.3 °C</p>	<p>1 failure</p> <p>500 msec/ sample</p> <p>Once per valid cold start</p>	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					2a) ECT drops from power up ECT 2b) Engine run time ===== Diagnostic is aborted when 3) or 4) occurs: 3) Engine run time with vehicle speed below 1b 4) Minimum IAT during test	$\geq 2^{\circ}\text{C}$ Within ≤ 60 seconds ===== > 1800 seconds $\leq -7^{\circ}\text{C}$		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit Low	P0117	Circuit Continuity This DTC detects a short to ground in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ 150°C)	< 34 Ohms			5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit High	P0118	Circuit Continuity This DTC detects a short to high or open in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ -60°C)	> 260,000 Ohms	Engine run time OR IAT min	> 10.0 seconds ≥ -7.0 °C	5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Circuit Intermittent	P0119	Circuit Continuity This DTC detects large step changes in the ECT signal circuit or the ECT sensor. Allowable high and low limits are calculated for the next sample based on the previous sample.	ECT temperature step change: 1) positive step change is greater than calculated high limit OR 2) negative step change is lower than calculated low limit. The calculated high and low limits for the next reading use the following calibrations: 1) Sensor time constant 2) Sensor low limit 3) Sensor high limit *****Generic Example***** If the last ECT reading was 90 Deg C, the Time constant was calibrated at 10 seconds, the low limit was calibrated to -80 Deg C and the high limit was calibrated to 200 Deg C the calculated limits are 101 Deg C and 73 Deg C. The next reading (after the 90 Deg C reading) must be between 73 Deg C and 101 Deg C to be valid.	10.0 seconds -80.0 Deg C 200.0 Deg C	No Active DTC's	ECT_Sensor_Ckt_FP	3 failures out of 4 samples 1 sec/ sample Continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (turbocharge d)	P0121	Determines if the Throttle Position Sensor input is stuck within the normal operating range	See table " Turbocharger Intake Flow Rationality Diagnostic Failure Matrix " for combinations of model failures that can set this DTC. MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table " TIAP-MAP	> 16 grams/sec > 20.0 kPa > 25.0 kPa > 25.0 kPa > 25.0 kPa > 250 kPa*(g/s) > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 100 Deg C >= 0.50 Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Correlation Offset"</p> <p>OR</p> <p>Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset"</p> <p>TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time</p> <p>High Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND Manifold Pressure</p> <p>AND Filtered Mass Air Flow - Mass Air Flow</p>	<p>> 25.0 kPa</p> <p>> 2.0 seconds</p> <p>> 2.0 seconds</p> <p>> a threshold in gm sec as a function of engine speed See table "TIAP-MAP Correlation Min Air Flow"</p> <p>> a threshold in kPa as a function of engine speed See table "TIAP-MAP Correlation Min MAP"</p> <p>< 2.0 gm/sec</p>	<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>See Residual Weight Factor tables.</p> <p>MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Low Engine Air Flow is TRUE when Mass Air Flow AND Manifold Pressure AND Mass Air Flow - Filtered Mass Air Flow	< a threshold in gm sec as a function of engine speed See table " TIAP-Baro Correlation Max Air Flow " < a threshold in kPa as a function of engine speed See table " TIAP-Baro Correlation Max MAP " < 2.0 gm/sec				

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit Low	P0122	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage <	0.3250		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit High	P0123	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage >	4.750		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature Below Stat Regulating Temperature) (energy based "Deluxe" method	P0128	This DTC detects if the engine coolant temperature rises too slowly due to an ECT or Cooling system fault	<p>Energy is accumulated after the first combustion event using Range #1 or #2 below:</p> <p>Thermostat type is divided into normal (non-heated) and electrically heated.</p> <p>For this application the "type" cal (KeTHMG_b_TMS_ElectHstEquipped) = 1 If the type cal is equal to one, the application has an electrically heated t-stat, if equal to zero the the application has a non heated t-stat. See appropriate section below.</p> <p>***** Type cal above = 1 (Electrically heated t-stat) == == == == Range #1 (Primary) ECT reaches Commanded temperature minus 26 °C when Ambient min is ≤ 50 °C and > 10 °C. Note: Warm up target for range #1 will be at least 79 °C == == == == Range #2 (Alternate) ECT reaches Commanded temperature minus 46 °C when Ambient min is ≤ 10 °C and > -7 °C. Note: Warm up target for range #2 will be at least</p>	<p>See the two tables named: P0128_Maximum Accumulated Energy for Start-up ECT conditions - Primary and P0128_Maximum Accumulated Energy for Start-up ECT conditions - Alternate in the Supporting tables section.</p> <p>This diagnostic models the net energy into and out of the cooling</p>	<p>No Active DTC's</p> <p>Engine not run time (soaking time before current trip)</p> <p>Engine run time</p> <p>Fuel Condition</p> <p>Distance traveled</p> <p>***** If Engine RPM is continuously greater than for this time period</p> <p>The diagnostic test for this key cycle will abort *****</p> <p>***** If T-Stat Heater commanded duty cycle for this time period</p> <p>The diagnostic test for this</p>	<p>ECT_Sensor_Ckt_FA ECT_Sensor_Perf_FA VehicleSpeedSensor_FA OAT_PtEstFiltFA IAT_SensorCircuitFA MAF_SensorFA THMR_AWP_AuxPumpFA THMR_AHV_FA THMR_SWP_Control_FA THMR_SWP_NoFlow_FA THMR_SWP_FlowStuckOn_FA ETQR_IndTorqInaccurate</p> <p>≥ 1,800 seconds</p> <p>60 ≤ Eng Run Tme ≤ 1,400 seconds</p> <p>Ethanol ≤ 15 %</p> <p>≥ 2.00 km</p> <p>*****</p> <p>9,999 rpm 5.0 seconds</p> <p>*****</p> <p>> 5.0 % duty cycle > 5.0 seconds</p>	<p>1 failure to set DTC</p> <p>1 sec/ sample</p> <p>Once per ignition key cycle</p>	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			59 °C ***** Type cal above = 0 (non - heated t-stat) == == == == Range #1 (Primary) ECT reaches 79 °C when Ambient min is ≤ 50 °C and > 10 °C. == == == == Range #2 (Alternate) ECT reaches 59 °C when Ambient min is ≤ 10 °C and > -7 °C. *****	system during the warm-up process. The five energy terms are: heat from combustion, heat from after-run, heat loss to enviroment, heat loss to cabin and heat loss to DFCO.	key cycle will abort ***** ECT at start run	***** -10 ≤ ECT ≤ 50 °C		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 1	P0132	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	== Open Test Criteria == No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition ===== No Active DTC's Low Fuel Condition Diag Fuel Condition Initial delay after Open Test Criteria met (cold start condition) Initial delay after Open Test Criteria met (not cold start condition) Equivalence Ratio Air Per Cylinder Fuel Control State	===== TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 50 seconds ≤ 87 % Ethanol ===== MAP_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA AIR System FA = False ≤ 87 % Ethanol > 10.0 seconds when engine soak time > 28,820 seconds > 10.0 seconds when engine soak time ≤ 28,820 seconds 0.9805 ≤ ratio ≤ 1.0254 50 ≤ mgram ≤ 500 not = Power Enrichment	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for	> 3.0 seconds		

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Slow Response Bank 1 Sensor 1) (For use with ESPD	P0133	This DTC determines if the O2 sensor response time is degraded.	<p>Fault condition present when the average response time is calculated over the test time, and compared to the threshold.</p> <p>OR</p> <p>Slope Time L/R Switches</p> <p>OR</p> <p>Slope Time R/L Switches</p>	<p>Refer to P0133_O2S Slow Response Bank 1 Sensor 1 "Pass/Fail Threshold table" in the Supporting Tables tab</p> <p>< 5</p> <p>< 5</p> <p>The test averages the signal response time over 60.0 seconds when the signal is transitioning between 400 mvolts and 585 mvolts. An average rich to lean time and lean to rich time are each calculated separately.</p>	<p>No Active DTC's</p> <p>Bank 1 Sensor 1 DTC's not active</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA AIR System FA EthanolCompositionSensor_FA EngineMisfireDetected_FA</p> <p>P0131, P0132, P0134</p> <p>10.0 < Volts < 32.0 = Not active = Not active = Not active = Not active = Not active = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S1, B2S1 (if applicable)</p>	<p>Sample time is 60 seconds</p> <p>Frequency: Once per trip</p>	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					O2 Heater on for Learned Htr resistance Engine Coolant IAT Engine run Accum Time since any AFM status change Time since Purge On to Off change Time since Purge Off to On change Engine airflow Engine speed Fuel Condition Baro Air Per Cylinder Fuel Control State Closed Loop Active LTM fuel cell Transient Fuel Mass Baro Fuel Control State Fuel State Commanded Proportional Gain ===== All of the above met for	in Supporting Tables tab. ≥ 40 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") > 60 °C > -40 °C > 100 seconds > 0.0 seconds > 1.0 seconds > 1.0 seconds 10 ≤ grams/second ≤ 35 1,300 ≤ RPM ≤ 3,500 < 87 % Ethanol > 70 kpa ≥ 120 mGrams = Closed Loop = TRUE = Enabled ≤ 50.0 mgrams = Not Defaulted not = Power Enrichment DFCO not active ≥ 0.0 % ===== > 1.0 seconds		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Insufficient Activity Bank 1 Sensor 1	P0134	This DTC determines if the O2 sensor circuit is open.	Oxygen Sensor Signal	> 1,700 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition	TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 50 seconds ≤ 87 % Ethanol	100 failures out of 125 samples. Frequency: Continuous 100 msec loop	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 1	P0135	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	$0.3 < \text{Amps} < 2.5$	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA $10.0 < \text{Volts} < 32.0$ = Complete = Not active > zero > 30 seconds	8 failures out of 10 samples Frequency: 2 tests per trip 10 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0137	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 20 mvolts	No Active DTC's AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active All Fuel Injectors for active Cylinders Fuel Condition Fuel State All of the above met for	TPS_ThrottleAuthority DefaultedMAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA = Not active = Not active = Not active = Not active 10.0 < Volts < 32.0 = Not active = Not active = Not active = Not active = False 0.9805 ≤ ratio ≤ 1.0254 50 ≤ mgrams ≤ 500 = Closed Loop = TRUE Enabled (On) Ethanol <= 87 %DFCO not active > 3.0 seconds	380 failures out of 475 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0138	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	<p>== Open Test Criteria == No Active DTC's</p> <p>System Voltage AFM Status Heater Warm-up delay Engine Run Time Fuel Condition</p> <p>=====</p> <p>No Active DTC's</p> <p>Low Fuel Condition Diag Fuel Condition</p> <p>Initial delay after Open Test Criteria met (cold start condition)</p> <p>Initial delay after Open Test Criteria met (not cold start condition)</p> <p>Equivalence Ratio Air Per Cylinder Fuel Control State</p>	<p>=====</p> <p>TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts = All Cylinders active = Complete > 5 seconds ≤ 87 %Ethanol</p> <p>=====</p> <p>MAP_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA AIR System FA = False ≤ 87 % Ethanol</p> <p>> 15.0 seconds when engine soak time > 28,820 seconds</p> <p>> 15.0 seconds when engine soak time ≤ 28,820 seconds</p> <p>0.9805 ≤ ratio ≤ 1.0254 50 ≤ mgrams ≤ 500 not = Power Enrichment</p>	<p>100 failures out of 125 samples</p> <p>Frequency: Continuous in 100 milli - second loop</p>	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for	> 3.0 seconds		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Rich to Lean Bank 1 Sensor 2	P013A	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Rich to Lean voltages range during Rich to Lean transition. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Post O2 sensor normalized integral value OR The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 9.5 units > 75.0 grams (upper voltage threshold is 450 mvolts and lower voltage threshold is 150 mvolts)	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition Low Fuel Condition Diag Post fuel cell (Decel) Crankshaft Torque	TPS_ThrottleAuthorityDefault ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013B, P013E, P013F, P2270 or P2271 10.0 < Volts < 32.0 = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. = False = enabled < 100.0 Nm	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					DTC's Passed ===== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	P2270 (and P2272 if applicable) P013E (and P014A if applicable) =====		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Lean to Rich Bank 1 Sensor 2	P013B	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Lean to Rich voltages range during Lean to Rich transition. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	The EWMA of the Post O2 sensor normalized integral value OR The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 9.0 units > 220 grams (lower voltage threshold is 350 mvolts and upper voltage threshold is 600 mvolts)	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition Green Cat System Condition	TPS_ThrottleAuthorityDefault ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013A, P013E, P013F, P2270 or P2271 10.0 < Volts < 32.0 = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. = Not Valid, System is not valid until accumulated airflow is greater than	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Low Fuel Condition Diag Post fuel cell</p> <p>DTC's Passed</p> <p>=====</p> <p>After above conditions are met: Fuel Enrich mode continued.</p> <p>=====</p> <p>During this test the following must stay TRUE or the test will abort: $0.95 \leq \text{Fuel EQR} \leq 1.06$</p>	<p>360,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False = enabled</p> <p>P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable) P013F (and P014B if applicable)</p> <p>=====</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 2	P013E	This DTC determines if the post catalyst O2 sensor has an initial delayed response to an A/F change from Rich to Lean. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	Post O2 sensor voltage AND The Accumulated mass air flow monitored during the Delayed Response Test under DFCO DFCO begins after: 1) Catalyst has been rich for a minimum of AND 2) Catalyst Rich Accumulation Air Flow is greater or equal to	> 450 mvolts > 33 grams > 0 secs > 6 grams	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition Low Fuel Condition Diag Post fuel cell (Decel)	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_Sensor_FA MAF_Sensor_FA MAP_Sensor_FA AIR_System_FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013A, P013B, P013F, P2270 or P2271 10.0 < Volts < 32.0 = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. = False = enabled	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Crankshaft Torque DTC's Passed Number of fueled cylinders ===== After above conditions are met: DFCO mode entered (wo driver initiated pedal input).	< 100.0 Nm P2270 (and P2272 if applicable) ≤ 3 cylinders =====		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 2	P013F	This DTC determines if the post catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	Post O2 sensor voltage AND The Accumulated mass air flow monitored during the Delayed Response Test	< 350 mvolts > 250 grams	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition Green Cat System Condition	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013A, P013B, P013E, P2270 or P2271 10.0 < Volts < 32.0 = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. = Not Valid, System is not valid until accumulated airflow is greater than	Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Low Fuel Condition Diag Post fuel cell</p> <p>DTC's Passed</p> <p>Number of fueled cylinders =====</p> <p>After above conditions are met: Fuel Enrich mode entered. =====</p> <p>During this test the following must stay TRUE or the test will abort: 0.95 ≤ Fuel EQR ≤ 1.06</p>	<p>360,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False = enabled</p> <p>P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable)</p> <p>≥ 1 cylinders =====</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Insufficient Activity Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0140	This DTC determines if the O2 sensor circuit is open.	Oxygen Sensor Signal	> 1,700 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition	TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 50 seconds ≤ 87 % Ethanol	100 failures out of 125 samples. Frequency: Continuous 100 msec loop	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0141	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.3 > amps > 2.5	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA 10.0 < Volts < 32.0 = Complete = Not active > zero > 30 seconds	8 failures out of 10 samples Frequency: 2 tests per trip 10 seconds delay between tests and 1 second execution rate.	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 1	P015A	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Rich to Lean. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Pre O2 sensor normalized R2L time delay value OR [The Accumulated time monitored during the R2L Delayed Response Test (Gross failure). AND Pre O2 sensor voltage is	> 0.7 EWMA (sec) ≥ 2.0 Seconds > 550 mvolts	No Active DTC's System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition	TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA AIR_System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA P0131, P0132, P0134 10.0 < Volts < 32.0 = Not active = Not active = Not active = Not active = False = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for	Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponsesActive = TRUE, multiple tests per trip are allowed	Type A, 1 Trips EWMA

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>O2 Heater (pre sensor) on for Learned Htr resistance</p> <p>Engine Coolant IAT Engine run Accum</p> <p>Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)</p> <p>Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)</p> <p>Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell</p> <p>EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State</p>	<p>the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab.</p> <p>≥ 40 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>> 60 °C > -40 °C > 100 seconds</p> <p>1,500 ≤ RPM ≤ 3,200</p> <p>1,450 ≤ RPM ≤ 3,300</p> <p>3 ≤ gps ≤ 10</p> <p>28.0 ≤ MPH ≤ 80.8</p> <p>24.9 ≤ MPH ≤ 83.9</p> <p>0.92 ≤ C/L Int ≤ 1.08 = TRUE not in control of purge not in estimate mode = enabled</p> <p>= not active</p> <p>= not active</p> <p>≥ 60.0 sec 550 ≤ °C ≤ 900 = DFCO possible</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>=====</p> <p>All of the above met for at least 1.5 seconds, and then the Force Cat Rich intrusive stage is requested.</p> <p>=====</p> <p>Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders</p> <p>=====</p> <p>After above conditions are met: DFCO Mode is entered (wo driver initiated pedal input).</p>	<p>=====</p> <p>≥ 690 mvolts = DFCO active</p> <p>≤ 3 cylinders</p> <p>=====</p>		

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 1	P015B	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test which runs in an enriched fuel mode to achieve the required response.	<p>The EWMA of the Pre O2 sensor normalized L2R time delay value</p> <p>OR</p> <p>[The Accumulated time monitored during the L2R Delayed Response Test (Gross failure).</p> <p>AND</p> <p>Pre O2 sensor voltage is</p> <p>OR</p> <p>At end of Cat Rich stage the Pre O2 sensor output is</p>	<p>> 0.7 EWMA (sec)</p> <p>≥ 2.0 Seconds</p> <p>< 350 mvolts</p> <p>< 690 mvolts</p>	<p>No Active DTC's</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR_System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA P0131, P0132, P0134</p> <p>10.0 < Volts < 32.0 = Not active = Not active = Not active = Not active = False</p> <p>= Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for</p>	<p>Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponselsActive = TRUE, multiple tests per trip are allowed</p>	<p>Type A, 1 Trips EWMA</p>

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					O2 Heater (pre sensor) on for Learned Htr resistance Engine Coolant IAT Engine run Accum Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp	the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. ≥ 40 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") > 60 °C > -40 °C > 100 seconds 1,500 ≤ RPM ≤ 3,200 1,450 ≤ RPM ≤ 3,300 3 ≤ gps ≤ 10 28.0 ≤ MPH ≤ 80.8 24.9 ≤ MPH ≤ 83.9 0.92 ≤ C/L Int ≤ 1.08 = TRUE not in control of purge not in estimate mode = enabled = not active = not active ≥ 60.0 sec 550 ≤ °C ≤ 900		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Fuel State Number of fueled cylinders ===== When above conditions are met: Fuel Enrich mode is entered. ===== During this test: Engine Airflow must stay between: and the delta Engine Airflow over 12.5msec must be :	= DFCO inhibit ≥ 1 cylinders ===== ===== 3 ≤ gps ≤ 15 ≤ 0.6 gps		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Device Control EVAP Diag. No active DTC:	Not Active "tank pull down" Not Active IAC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR_System FA EvapExcessPrgePsbl_FA Ethanol Comp Snsr FA FuelInjectorCkt_FA EngMisfireDetected_FA EGRValvePerf_FA EGRValveCkt_FA MAP_EngVacuumStatus AmbPresDfItDStatus TC_BoostPresSnsrFA O2Snsr_B1_Snsr_1_FA		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Rich Bank 1	P0172	<p>Determines if the fuel control system is in a rich condition, based on the filtered long-term fuel trim metric.</p> <p>There are two methods to determine a Rich fault. They are Passive and Intrusive. A Passive Test decision can be made up until the time that purge is first enabled. From that point forward, rich faults can only be detected by turning purge off intrusively.</p> <p>Intrusive Test: If the filtered Purge Long Term Fuel Trim metric > 0.720 , the test passes without intrusively checking the filtered Non-Purge Long Term Fuel Trim metric. However if the filtered Purge Long Term Fuel Trim metric is <= 0.720 , purge is ramped off to determine if excess purge vapor is the cause of the rich condition.</p> <p>Performing intrusive tests too frequently may also affect EVAP and EPAIII emissions,</p>	<p>Passive Test: The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)</p> <p>Intrusive Test: For 3 out of 5 intrusive segments, the filtered Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)</p> <p>Segment Def'n: Segments can last up to 25 seconds and are separated by the lesser of 30 seconds of purge-on time or enough time to</p>	<p><= 0.715</p> <p><= 1.990</p> <p><= 0.720</p> <p><= 0.715</p> <p><= 1.990</p>		<p>Secondary Parameters and Enable Conditions are identical to those for P0171, with the exception that fuel level is not considered.</p>	<p>Frequency: 100 ms Continuous Loop</p>	<p>Type B, 2 Trips</p>

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and the execution frequency of other diagnostics.	purge 50 grams of vapor. A maximum of 5 completed segments or 15 attempts are allowed for each intrusive test. After an intrusive test report is completed, another intrusive test cannot occur for 300 seconds to allow sufficient time to purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge Long Term Fuel Trim metric > 0.720 for at least 150 seconds, indicating that the canister has been purged.					

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Open Circuit (PFI)	P0201	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0261 may also set (Injector 1 Short to Ground)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Open Circuit (PFI)	P0202	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0264 may also set (Injector 2 Short to Ground)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Open Circuit (PFI)	P0203	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0267 may also set (Injector 3 Short to Ground)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Open Circuit (PFI)	P0204	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0270 may also set (Injector 4 Short to Ground)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit Low	P0222	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage <	0.250		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit High	P0223	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage >	4.590		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Engine Overboost Turbocharger with wastegate. Not supercharger with mechanical compressor	P0234	Detect Negative Boost Pressure Control Deviation	Desired Boost Pressure - Actual Boost Pressure	< (KtBSTD_p_CntrlDevNegLim - KtBSTD_p_CntrlDevAmbAirCorr) See Tables in Supporting Tables Sheet	Diagnostic Enabled Engine Speed Engine Speed Desired Boost Pressure Desired Boost Pressure Desired Boost Pressure Derivative Desired Boost Pressure Derivative Ambient Pressure Ambient Pressure Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Wait for steady state: No Active DTCs:	1 > 2,450 rpm < 6,000 rpm > 135.0 kPa < 220.0 kPa > -70.0 kPa/s < 55.0 kPa/s > 60.0 kPa < 120.0 kPa > -40.0 Deg C < 120.0 Deg C > -40.0 Deg C < 80.0 Deg C > KtBSTD_t_CntrlDevEnableDelay See Table in Supporting Tables Sheet Desired Boost Pressure > BasicPressure AmbientAirDefault_Snr BSTR_b_PCA_CktFA BSTR_b_TurboBypassCktFA ECT_Sensor_FAIAT_Sen	20 failures out of 20 samples 1 sample every 100ms	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Active DVCs:	sorFA BSTR_b_ExcsvBstTFTK O BSTR_b_PCA_CktTFTK O TC_BoostPresSnsrFA AnyCamPhaser_FA BSTR_b_PresCntrlTooLo TFTKO BSTR_b_PresCntrlTooHiT FTKO EnginePowerLimited BSTR_b_DVC_PCA_DC_ Actv BSTR_b_DVC_PCA_Pstn Actv BSTR_b_DVC_TurboCom prBypActv		

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Boost Pressure (TIAP) Sensor Performance	P0236	Determines if the Turbocharger Boost (TIAP) Pressure Sensor input is stuck within the normal operating range	See table " Turbocharger Intake Flow Rationality Diagnostic Failure Matrix " for combinations of model failures that can set this DTC. MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP - TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table " TIAP-MAP Correlation Offset "	> 16 grams/sec > 20.0 kPa > 25.0 kPa > 25.0 kPa > 25.0 kPa > 250 kPa*(g/s) > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 100 Deg C >= 0.50 Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>OR</p> <p>Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset"</p> <p>TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time</p> <p>High Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND Manifold Pressure</p> <p>AND Filtered Mass Air Flow - Mass Air Flow</p>	<p>> 25.0 kPa</p> <p>> 2.0 seconds</p> <p>> 2.0 seconds</p> <p>> a threshold in gm/sec as a function of engine speed. See table "TIAP-MAP Correlation Min Air Flow"</p> <p>> a threshold in kPa as a function of engine speed. See table "TIAP-MAP Correlation Min MAP"</p> <p>< 2.0 gm/sec</p>	<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>See Residual Weight Factor tables.</p> <p>MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Low Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND Manifold Pressure</p> <p>AND Mass Air Flow - Filtered Mass Air Flow</p>	<p>< a threshold in gm/sec as a function of engine speed. See table "TIAP-Baro Correlation Max Air Flow"</p> <p>< a threshold in kPa as a function of engine speed. See table "TIAP-Baro Correlation Max MAP"</p> <p>< 2.0 gm/sec</p>				
			<p>Turbocharger Boost Pressure OR Turbocharger Bosst Pressure OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)</p>	<p>< 50.0 kPa > 115.0 kPa ≤ 10.0 kPa > 10.0 kPa > 10.0 kPa</p>	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Engine is not rotating</p> <p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>> 10.0 seconds</p> <p>EngineModeNotRunTimer Error MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA</p> <p>MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP</p>	<p>4 failures out of 5 samples</p> <p>1 sample every 12.5 msec</p>	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r Boost Pressure Sensor Circuit Low	P0237	Detects a continuous short to low or open in either the signal circuit or the turbocharger boost pressure sensor.	Turbocharger Boost Pressure Voltage	< 17.0 % of 5 Volt Range (This is equal to 0.85 Volts, or 49.6 kPa)	Engine Run Time	> 0.00 seconds	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r Boost Pressure Sensor Circuit High	P0238	Detects an open sensor ground or continuous short to high in either the signal circuit or the turbocharger boost pressure sensor.	Turbocharger Boost Pressure Voltage	> 78.0 % of 5 Volt Range (This is equal to 3.90 Volts, or 250.6 kPa)	Engine Run Time	> 0.00 seconds	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r Wastegate / Supercharge r Boost Solenoid A Control Circuit	P0243	Detect Turbocharger Boost Solenoid -Open Circuit	ECM detects that commanded and actual states of output driver do not match because the output is open circuit		Diagnostic Enabled Powertrain relay voltage Ignition run crank voltage Engine is not cranking	1 >= 11.00 Volts >= 5.00 Volts	10 failures out of 20 samples 1 sample every 100ms	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r Wastegate / Supercharge r Boost Solenoid A Control Circuit Low	P0245	Detect Turbocharger Boost Solenoid - Shorted to ground	ECM detects that commanded and actual states of output driver do not match because the output is shorted to ground		Diagnostic Enabled Powertrain relay voltage Ignition run crank voltage Engine is not cranking	1 >= 11.00 Volts >= 5.00 Volts	10 failures out of 20 samples 1 sample every 100ms	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Wastegate / Supercharger Boost Solenoid A Control Circuit High	P0246	Detect Turbocharger Boost Solenoid - Shorted to Power	ECM detects that commanded and actual states of output driver do not match because the output is shorted to power		Diagnostic Enabled Powertrain relay voltage Ignition run crank voltage Engine is not cranking	1 >= 11.00 Volts >= 5.00 Volts	10 failures out of 20 samples 1 sample every 100ms	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to ground (PFI)	P0261	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0201 may also set (Injector 1 Open Circuit)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to power (PFI)	P0262	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to ground (PFI)	P0264	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0202 may also set (Injector 2 Open Circuit)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to power (PFI)	P0265	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to ground (PFI)	P0267	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0203 may also set (Injector 3 Open Circuit)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to power (PFI)	P0268	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to ground (PFI)	P0270	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0204 may also set (Injector 4 Open Circuit)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to power (PFI)	P0271	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Engine Underboost Turbocharger with wastegate. Not supercharger with mechanical compressor	P0299	Detect Positive Boost Pressure Control Deviation	Desired Boost Pressure - Actual Boost Pressure	> (KtBSTD_p_CntrlDevPosLim + KtBSTD_p_CntrlDevAmbAirCorr) See Tables in Supporting Tables Sheet	Diagnostic Enabled Engine Speed Engine Speed Desired Boost Pressure Desired Boost Pressure Desired Boost Pressure Derivative Desired Boost Pressure Derivative Ambient Pressure Ambient Pressure Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Wait for steady state: No Active DTCs:	1 > 2,450 rpm < 6,000 rpm > 135.0 kPa < 220.0 kPa > -70.0 kPa/s < 55.0 kPa/s > 60.0 kPa < 120.0 kPa > -40.0 Deg C < 120.0 Deg C > -40.0 Deg C < 80.0 Deg C > KtBSTD_t_CntrlDevEnDelay See Table in Supporting Tables Sheet Desired Boost Pressure > Basic Pressure AmbientAirDefault_Snr BSTR_b_PCA_CktFA BSTR_b_TurboBypassCktFA ECT_Sensor_FA	25 failures out of 25 samples 1 sample every 100ms	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Active DVCs:	IAT_SensorFA BSTR_b_ExcsvBstTFTK O BSTR_b_PCA_CktTFTK O TC_BoostPresSnsrFA AnyCamPhaser_FA BSTR_b_PresCntrlTooLo TFTKO BSTR_b_PresCntrlTooHiT FTKO EnginePowerLimited BSTR_b_DVC_PCA_DC_ Actv BSTR_b_DVC_PCA_Pstn Actv BSTR_b_DVC_TurboCom prBypActv		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.		
Random Misfire Detected	P0300	These DTC's will determine if a random or a cylinder specific misfire is occurring by monitoring various terms derived from crankshaft velocity. The rate of misfire over an interval is compared to both emissions and catalyst damaging thresholds. The pattern of crankshaft acceleration after the misfire is checked to differentiate between real misfire and other sources of crank shaft noise.	Deceleration Value vs. Engine Speed and Engine load	[(>IdleSCD_Decel AND > IdleSCD_Jerk) OR (>SCD_Decel AND > SCD_Jerk) OR (>IdleCylModeDecel AND > IdleCylModeJerk) OR (>CylMode_Decel AND > CylMode_Jerk) OR (>RevMode_Decel) OR WHILE in Cylinder Deactivation mode: (> AFM_Decel)] - see details on Supporting Tables Tab (P0300 Section)	Engine Run Time	> 2 crankshaft revolution	Emission Exceedence = any (5) failed 200 rev blocks out of (16) 200 rev block tests	Type B, 2 Trips (Mil Flashes with Catalyst damage level of Misfire)		
Cylinder 1 Misfire Detected	P0301		The equation used to calculate deceleration value is tailored to specific vehicle operating conditions.		Engine Coolant Temp Or If ECT at startup Then ECT				-7 °C < ECT < 130 °C < -7 °C 21 °C < ECT < 130 °C	
Cylinder 2 Misfire Detected	P0302		The selection of the equation used is based on the 1st tables encountered that are not max of range. If all tables are max of range at a given speed/load, that speed load region is an Undetectable region see Algorithm Description Document for additional details.		System Voltage + Throttle delta - Throttle delta				9.00 < volts < 32.00 < 95.00 % per 25 ms < 95.00 % per 25 ms	Failure reported for (1) Exceedence in 1st (16) 200 rev block tests, or (4) Exceedences thereafter.
Cylinder 3 Misfire Detected	P0303				Early Termination option: (used on plug ins that may not have enough engine run time at end of trip for normal interval to complete.)				Not Enabled	OR when Early Termination Reporting = Enabled and engine rev > 1,000 revs and < 3,200 revs at end of trip
Cylinder 4 Misfire Detected	P0304									any Catalyst Exceedence = (1) 200 rev block as data supports for catalyst damage.
			Misfire Percent Emission Failure Threshold	≥ 2.50 % P0300			Failure reported with (1 or 3) Exceedences in FTP, or (1) Exceedence outside FTP.			
			Misfire Percent Catalyst Damage	> Catalyst_Damage_ Misfire_Percentage in Supporting Tables	(at low speed/loads, one cylinder may not cause cat damage)					

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			When engine speed and load are less than the FTP calcs (3) catalyst damage exceedences are allowed.	whenever secondary conditions are met. ≤ 0 FTP rpm AND ≤ 0 FTP % load disable conditions:	Engine Speed Engine Load Misfire counts Engine Speed No active DTCs:	> 2,000 rpm AND > 30 % load AND < 180 counts on one cylinder 530 < rpm < ((Engine Over Speed Limit) - 400) Engine speed limit is a function of inputs like Gear and temperature see EngineOverSpeedLimit in supporting tables TPS_FA EnginePowerLimited MAF_SensorTFTKO MAP_SensorTFTKO IAT_SensorTFTKO ECT_Sensor_Ckt_TFTKO 5VoltReferenceB_FA CrankSensorTFTKO CrankSensorFA CamLctnIntFA CamLctnExhFA CamSensorAnyLctnTFTKO O AnyCamPhaser_FA AnyCamPhaser_TFTKO AmbPresDfItDStatus	Continuous 4 cycle delay 4 cycle delay	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P0315 & engine speed	> 1,000 rpm	4 cycle delay	
					Fuel Level Low	LowFuelConditionDiagnostic	500 cycle delay	
					Cam and Crank Sensors	in sync with each other	4 cycle delay	
					Misfire requests TCC unlock	Not honored because Transmission in hot mode or POPD intrusive diagnostic running	4 cycle delay	
					Fuel System Status	≠ Fuel Cut	4 cycle delay	
					Active FuelManagement	Transition in progress	0 cycle delay	
					Undetectable engine speed and engine load region	Undetectable region from Malfunction Criteria	4 cycle delay	
					Abusive Engine Over Speed	> 8,191 rpm	0 cycle delay	
					Below zero torque (except CARB approved 3000 rpm to redline triangle.)	< ZeroTorqueEngLoad in Supporting Tables	4 cycle delay	
					Below zero torque: TPS Vehicle Speed	≤ 1 % > 30 mph	4 cycle delay	
					EGR Intrusive test	Active	0 cycle delay	
					Manual Trans	Clutch shift	4 cycle delay	
					Accel Pedal Position AND Automatic transmission shift	> 95.00 %	7 cycle delay	
					Driveline Ring Filter active			

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.</p> <p>Filter Driveline ring:</p> <p>Stop filter early:</p> <p>Abnormal engine speed oscillations: (Rough road etc) Off Idle, number of consecutive decelerating cylinders after "misfire": (Number of decels can vary with misfire detection equation)</p> <p>TPS Engine Speed Veh Speed</p> <p>Consecutive decels while in SCD Mode Cyl Mode Rev Mode</p> <p>Misfire Crankshaft Pattern Recognition checks each "misfire" candidate in 100 engine Cycle test to see if it looks like real misfire, or some disturbance like rough road. The check is</p>	<p>> "Ring Filter" # of engine cycles after misfire in Supporting Tables</p> <p>> "Number of Normals" # of engine cycles after misfire in Supporting Tables tab</p> <p>> 1 % > 1,000 rpm > 3 mph</p> <p>> Abnormal SCD Mode > Abnormal Cyl Mode > Abnormal Rev Mode in Supporting Tables</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>based on a multiplier times the ddt_jerk value used to detect misfire at that speed and load. At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present.</p> <p>Pattern Recog Enabled: Engine Speed Veh Speed</p> <p>"misfire" unrecognized if: Crankshaft snap after: isolated "misfire" repetative "misfire"</p> <p>Ratio of Unrecog/Recog</p> <p>Rough Road: Non-Crankshaft based:</p> <p>Rough Road Source</p> <p>IF Rough Road Source = WheelSpeedInECM ABS/TCS Wheel speed noise VSES</p> <p>IF Rough Road Source = "FromABS" ABS/TCS RoughRoad VSES</p> <p>IF Rough Road Source = "TOSS"</p>	<p>Enabled 700 < rpm < 5,000 > 3.1 mph</p> <p>> Min_PatternMultiplier > Max_PatternMultiplier in Supporting Tables</p> <p>> 0.70</p> <p>Disabled</p> <p>TOSS</p> <p>active > WSSRoughRoadThres active</p> <p>active detected active</p>	<p>discard test</p> <p>discard test</p> <p>discard test</p>	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					TOSS dispersion AND No Active DTCs	>TOSSRoughRoadThres in supporting tables Transmission Output Shaft Angular Velocity Validity TransmissionEngagedStat e_FA (Auto Trans only) Clutch Sensor FA (Manual Trans only)	discard test 4 cycle delay	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position System Variation Not Learned	P0315	Monitor for valid crankshaft error compensation factors	Sum of Compensation factors. Each Cylinder pair shares one compensation factor. A perfect factor would be 1.0000. Unlearned factors are defaulted out of range so the sum of factors would be out of range.	≥ 2.0040 OR ≤ 1.9960	OBD Manufacturer Enable Counter	MEC = 0	0.50 seconds Frequency Continuous100 msec	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Knock Sensor (KS) Performance Per Cylinder	P0324	This diagnostic checks for knock sensor performance out of the normal expected range on a per cylinder basis due to: 1. Excessive knock or 2. Abnormal engine noise or 3. Flat signal	Common Enable Criteria (Applies to all 3 parts of the performance diag)		Diagnostic Enabled? Engine Run Time Engine Speed Engine Air Flow ECT IAT	Yes ≥ 2.0 seconds ≤ 8,500 RPM ≥ 0 mg/cylinder and ≤ 2,000 mg/cylinder ≥ -40 deg's C ≥ -40 deg's C	First Order Lag Filters with Weight Coefficients	Type B, 2 Trips	
			Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag: -----						
			1. Excessive Knock Diag: Filtered Knock Intensity VaKNKD_k_PerfCylKnock IntFilt (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock) -----	> 0.61 (no units)	Engine Speed Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	≥ 580 RPM ≥ 100 Revs			Excessive Knk Weight Coefficient = 0.0300 Updated each engine event
2. Abnormal Noise Diag: Filtered FFT Intensity (where 'FFT Intensity' = Non-knocking, background noise)	< AbnormalNoise_Threshold (see Supporting Tables)	Individual Cylinders enabled for Abnormal Noise Engine Speed Cumulative Number of Engine Revs Above Min Eng Speed (per key	See AbnormalNoise_CylsEnabled (Supporting Tables) ≥ 2,500 RPM ≥ 100 Revs	Abn Noise Weight Coefficient = 0.0400 Updated each engine event					

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>-----</p> <p>3. Flat Signal Diag: Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock)</p> <p>VaKNKD_k_PerfCylFlatFil tInt</p>	<p>-----</p> <p>< 0.008 (no units)</p>	<p>cycle)</p> <p>-----</p> <p>Engine Speed</p> <p>Cumulative Number of Engine Revs Above Min Eng Speed (per keycycle)</p>	<p>-----</p> <p>≥ 8,500 RPM</p> <p>≥ 100 Revs</p>	<p>-----</p> <p>Flat Signal Weight Coefficient = 0.010</p> <p>Updated each engine event</p>	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank 1	P0325	<p>This diagnostic checks for an open in the knock sensor circuit</p> <p>There are two possible methods used:</p> <ol style="list-style-type: none"> 1. 20 kHz 2. Normal Noise <p>See Supporting Tables for method definition: P0325_P0330_OpenMethod</p> <p>Typical implementations:</p> <ol style="list-style-type: none"> A. Use 20 kHz method at all RPM (used when acceptable separation achieved at all RPM) or B. Use 20 kHz method at low/medium RPM and Normal Noise at high RPM 	Filtered FFT Output	<p>> OpenCktThrshMin and < OpenCktThrshMax</p> <p>See Supporting Tables</p> <p>Thresholds for OpenMethod = 20 kHz: OpenCktThrshMin (20 kHz) & OpenCktThrshMax (20 kHz)</p> <p>Thresholds for OpenMethod = NormalNoise: OpenCktThrshMin (Normal Noise) & OpenCktThrshMax (Normal Noise)</p>	<p>Diagnostic Enabled?</p> <p>Engine Run Time</p> <p>Engine Speed</p> <p>Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)</p> <p>Engine Air Flow</p> <p>ECT</p> <p>IAT</p>	<p>Yes</p> <p>≥ 2.0 seconds</p> <p>≥ 580 RPM and ≤ 8,500 RPM</p> <p>≥ 100 revs</p> <p>≥ 0 mg/cylinder and ≤ 2,000 mg/cylinder</p> <p>≥ -40 deg's C</p> <p>≥ -40 deg's C</p>	<p>First Order Lag Filter with Weight Coefficient</p> <p>Weight Coefficient = 0.0100</p> <p>Updated each engine event</p>	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Bank 1	P0326	This diagnostic checks for knock sensor performance out of the normal expected range, on a per sensor basis, due to 1. Excessive knock or 2. Abnormal engine noise or 3. Flat signal	Common Enable Criteria (Applies to all 3 parts of the performance diag)		Diagnostic Enabled? Engine Run Time Engine Speed Engine Air Flow ECT IAT	Yes ≥ 2.0 seconds ≤ 8,500 RPM ≥ 0 mg/cylinder and ≤ 2,000 mg/cylinder ≥ -40 deg's C ≥ -40 deg's C	First Order Lag Filters with Weight Coefficients Excessive Knk Weight Coefficient = 0.0100 Updated each engine event Abnormal Noise Weight Coefficient = 0.0100 Updated each engine event	Type B, 2 Trips
			Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag:					
			1. Excessive Knock Diag: Filtered Knock Intensity (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)	> 0.61 (no units)	Engine Speed Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	≥ 580 RPM ≥ 100 Revs		
2. Abnormal Noise Diag: Filtered FFT Intensity: (where 'FFT Intensity' = Non-knocking, background noise)	< AbnormalNoise_Threshold (see Supporting Tables)	Individual Cylinders enabled for Abnormal Noise Engine Speed Cumulative Number of Engine Revs Above Min Eng Speed (per key	See AbnormalNoise_ CylsEnabled (Supporting Tables) ≥ 2,500 RPM ≥ 100 Revs					

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			----- 3. Flat Signal Diag: Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock)	< 0.008 (no units)	cycle) ----- Engine Speed Cumulative Number of Engine Revs Above Min Eng Speed (per keycycle)	----- ≥ 8,500 RPM ≥ 100 Revs	----- Flat Signal Weight Coefficient = 0.010 Updated each engine event	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 1	P0327	This diagnostic checks for an out of range low knock sensor signal	Sensor Input or Return Signal Line	< 8.0 Percent (of 5 V reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 1	P0328	This diagnostic checks for an out of range high knock sensor signal	Sensor Input or Return Signal Line	> 39.0 Percent (of 5 Volt Reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Circuit	P0335	Determines if a fault exists with the crank position sensor signal	Time since last crankshaft position sensor pulse received	>= 4.0 seconds	Starter engaged AND (cam pulses being received OR (DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow	= FALSE = FALSE = FALSE > 1.5 grams/second))	Continuous every 100 msec	Type B, 2 Trips
			No crankshaft pulses received	>= 0.1 seconds	Engine is Running Starter is not engaged No DTC Active:	5VoltReferenceB_FA	Continuous every 12.5 msec	
			No crankshaft pulses received		Engine is Running OR Starter is engaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA P0365 P0366	2 failures out of 10 samples One sample per engine revolution	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Performance	P0336	Determines if a performance fault exists with the crank position sensor signal	Time in which 10 or more crank re-synchronizations occur	< 10.0 seconds	Engine Air Flow Cam-based engine speed No DTC Active:	>= 1.5 grams/second > 450 RPM 5VoltReferenceB_FA P0335	Continuous every 250 msec	Type B, 2 Trips
			No crankshaft synchronization gap found	>= 0.4 seconds	Engine is Running Starter is not engaged No DTC Active:	5VoltReferenceB_FA	Continuous every 12.5 msec	
			Time since starter engaged without detecting crankshaft synchronization gap	>= 1.5 seconds	Starter engaged AND (cam pulses being received OR (DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow	= FALSE = FALSE = FALSE > 1.5 grams/second))	Continuous every 100 msec	
			Crank pulses received in one engine revolution OR Crank pulses received in one engine revolution	< 51 > 65	Engine is Running OR Starter is engaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA P0365 P0366	8 failures out of 10 samples One sample per engine revolution	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor A	P0340	Determines if a fault exists with the cam position bank 1 sensor A signal	Time since last camshaft position sensor pulse received	>= 5.5 seconds	Starter engaged AND (cam pulses being received	= FALSE = FALSE = FALSE > 1.5 grams/second)	Continuous every 100 msec	Type B, 2 Trips
			OR		OR			
			Time that starter has been engaged without a camshaft sensor pulse	>= 4.0 seconds	AND DTC P0102 AND DTC P0103 AND Engine Air Flow			
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged No DTC Active:			
No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	Continuous every MEDRES event				
The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle				

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor A	P0341	Determines if a performance fault exists with the cam position bank 1 sensor A signal	The number of camshaft pulses received during first 12 MEDRES events is OR (There are 12 MEDRES events per engine cycle)	< 4 > 6	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	8 failures out of 10 samples Continuous every engine cycle	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT - for 3 DTC implementati on only	P0351	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT - for 3 DTC implementati on only	P0352	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	≥ 30 k Ω impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT - for 3 DCT implementati on only	P0353	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT - for 3 DTC implementati on only	P0354	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor B	P0365	Determines if a fault exists with the cam position bank 1 sensor B signal	Time since last camshaft position sensor pulse received	>= 5.5 seconds	Starter engaged AND (cam pulses being received	= FALSE = FALSE = FALSE > 1.5 grams/second)	Continuous every 100 msec	Type B, 2 Trips
			OR		OR			
			Time that starter has been engaged without a camshaft sensor pulse	>= 4.0 seconds	(DTC P0101 AND DTC P0102 AND DTC P0103 AND Engine Air Flow			
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged No DTC Active:			
No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	Continuous every MEDRES event				
The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle				

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor B	P0366	Determines if a performance fault exists with the cam position bank 1 sensor B signal	The number of camshaft pulses received during first 12 MEDRES events is OR (There are 12 MEDRES events per engine cycle)	< 4 > 6	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	5VoltReferenceA_FA 5VoltReferenceB_FA CrankSensorFA	8 failures out of 10 samples Continuous every engine cycle	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 1	P0420	<p>NOTE: The information contained below applies to applications that use the Idle Catalyst Monitor Algorithm</p> <p>The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (I.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Lean and Rich A/F excursions</p> <p>Normalized Ratio OSC Value Calculation Information and Definitions = 1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time) 2. BestFailing OSC value from a calibration table (based on temp and exhaust gas flow)</p>	Normalized Ratio OSC Value (EWMA filtered)	< 0.18	<p>There must be a valid idle period. The criteria are:</p> <p>Driver must be off the accel pedal. This checks that the final accel pedal position (comprehending deadband and hysteresis) is essentially zero.</p> <p>Idle Speed Control System Is Active</p> <p>Vehicle Speed</p> <p>Engine speed</p> <p>Engine run time</p> <p>Tests attempted this trip</p> <p>The catalyst diagnostic has not yet completed for the current trip.</p> <p>Catalyst Idle Conditions Met Criteria is satisfied which includes the General Enable met and the Valid Idle Period</p>	<p>< 1.24 MPH</p> <p>> 1,200 RPM for a minimum of 2 seconds since end of last idle period.</p> <p>></p> <p>CatmonMinEngineRunTimeToEnable This is a function of Coolant Temperature, please see "Supporting Tables" for details.</p> <p>< 255</p>	<p>1 test attempted per valid idle period</p> <p>Minimum of 1 test per trip</p> <p>Maximum of 6 tests per trip</p> <p>Frequency: Fueling Related : 12.5 ms</p> <p>OSC Measurements: 100 ms</p> <p>Temp Prediction: 12.5ms</p>	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>3. WorstPassing OSC value (based on temp and exhaust gas flow)</p> <p>Normalized Ratio Calculation = (1-2) / (3-2)</p> <p>A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part. The Catalyst Monitoring Test is done during idle. Several conditions must be met in order to execute this test. These conditions and their related values are listed in the secondary parameters area of this document.</p> <p>Refer to the P0420_WorstPassing OSC Table B1 and P0420_BestFailing OSC Table B1 table in the Supporting Tables tab for details</p>			<p>Criteria met, as well as:</p> <p>Green Converter Delay</p> <p>Induction Air</p> <p>Intrusive test(s): Fueltrim Post O2 EVAP EGROther vehicle functions:</p> <p>Power Take Off RunCrank Voltage Ethanol Estimation</p> <p>ECT</p> <p>Barometric Pressure</p> <p>Idle Time before going intrusive is</p> <p>Idle time is incremented if Vehicle speed</p> <p>Short Term Fuel Trim</p>	<p>Not Active</p> <p>> -20 ° C < 250 ° C</p> <p>Not Active</p> <p>Not Active > 10.90 Volts NOT in Progress</p> <p>> 40 ° C < 140 ° C</p> <p>> 70 KPA</p> <p>< 50 Seconds</p> <p>< 1.24 MPH and the drivers foot is off accel pedal and the idle speed control system is active as identified in the Valid Idle Period Criteria section.</p> <p>> 0.77 < 1.27</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Predicted catalyst temp AND Engine Airflow</p> <p>for at least</p> <p>with a closed throttle time</p> <p>Also, in order to increment the WarmedUpEvents counter, either the vehicle speed must exceed the vehicle speed cal or the driver must NOT be off the accel pedal as stated in the Valid Idle Period Criteria section above.</p>	<p>> 510.00 degC</p> <p>> CatmonMinAirflowForWarmCatalystDetermination table (g/s) (refer to "Supporting Tables" tab) (Based on engine coolant at the time the WarmedUpEvents counter resets to 0.)</p> <p>10 seconds</p> <p>< 90 seconds consecutively (closed throttle consideration involves having the driver off the accel pedal as stated in the Valid Idle Period Criteria Section) .</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Closed loop fueling (Please see "Closed Loop Enable Criteria" section of the "Supporting Tables" tab for details.) PRNDL Idle Stable Criteria: MAF Predicted catalyst temperature Engine Fueling Criteria at Beginning of Idle Period The following fueling related must also be met from between 4 and 7 seconds after the Catalyst Idle Conditions Met Criteria has been met for at least 4 seconds prior to allowing intrusive control: Number of pre-O2 switches Short Term Fuel Trim Avg Rapid Step Response	Enabled in Drive Range on an Auto Transmission vehicle. Must hold true from after Catalyst Idle Conditions Met to the end of test > 1.40 g/s < 6.20 g/s < 820 degC >= 2 > 0.90 < 1.05		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>(RSR) feature will initiate multiple tests:</p> <p>If the difference between current EWMA value and the current OSC Normalized Ratio value is</p> <p>and the current OSC Normalized Ratio value is</p> <p>Maximum RSR tests to detect failure when RSR is enabled.</p> <p>Green Converter Delay Criteria This is part of the check for the Catalyst Idle Conditions Met Criteria section</p> <p>The diagnostic will not be enabled until the following has been met:</p> <p>Predicted catalyst temperature</p> <p>for</p> <p>Note: this feature is only enabled when the vehicle is new and cannot be enabled in service</p> <p>PTO</p> <p>General Enable DTC's Not Set</p>	<p>> 0.53</p> <p><0.13</p> <p>18</p> <p>> 0 ° C</p> <p>0 seconds non-continuously.</p> <p>Not Active</p> <p>MAF_SensorFA MAF_SensorTFTKO AmbPresDfltStatus</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						IAT_SensorCircuitFA IAT_SensorCircuitTFTKO ECT_Sensor_FA O2S_Bank_1_Sensor_1_ FA O2S_Bank_1_Sensor_2_ FA O2S_Bank_2_Sensor_1_ FA O2S_Bank_2_Sensor_2_ FA FuelTrimSystemB1_FA FuelTrimSystemB1_TFTK O FuelTrimSystemB2_FA FuelTrimSystemB2_TFTK O EngineMisfireDetected_F A EvapPurgeSolenoidCircuit _FA IAC_SystemRPM_FA EGRValvePerformance_F A EGRValveCircuit_FA CamSensorAnyLocationF A CrankSensorFA TPS_Performance_FA EnginePowerLimited		

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Small Leak Detected (No ELCP - Conventional EVAP Diagnostic)	P0442	This DTC will detect a small leak ($\geq 0.020"$) in the EVAP system between the fuel fill cap and the purge solenoid. On some applications a small leak is defined as $\geq 0.025"$, $0.030"$, or $0.150"$. The engine off natural vacuum method (EONV) is used. EONV is an evaporative system leak detection diagnostic that runs when the vehicle is shut off when enable conditions are met. Prior to sealing the system and performing the diagnostic, the fuel volatility is analyzed. In an open system (Canister Vent Solenoid [CVS] open) high volatility fuel creates enough flow to generate a measurable pressure differential relative to atmospheric. After the volatility check, the vent solenoid will close. After the vent is closed, typically a build up of pressure from the hot soak begins (phase-1). The pressure typically will peak and then begin to decrease as the fuel cools. When	The total delta from peak pressure to peak vacuum during the test is normalized against a calibration pressure threshold table that is based upon fuel level and ambient temperature. (Please see P0442: EONV Pressure Threshold (Pascals) Table in Supporting Tables). The normalized value is calculated by the following equation: $1 - (\text{peak pressure} - \text{peak vacuum}) / \text{pressure threshold}$. The normalized value is entered into EWMA (with 0= perfect pass and 1= perfect fail). When EWMA is the DTC light is illuminated. The DTC light can be turned off if the EWMA is and stays below the EWMA fail threshold for 3 additional consecutive trips.	> 0.60 (EWMA Fail Threshold), ≤ 0.35 (EWMA Re-Pass Threshold)	Fuel Level Drive Time Drive length ECT Baro Distance since assembly plant Engine not run time before key off must be Time since last complete test if normalized result and EWMA is passing OR Time since last complete test if normalized result or EWMA is failing Estimated ambient temperature at end of drive Estimate of Ambient Air Temperature Valid ***** Conditions for Estimate of Ambient Air Temperature to be valid: 1. Cold Start	$10\% \leq \text{Percent} \leq 90\%$ ≥ 600 seconds ≥ 5.0 miles ≥ 63 °C ≥ 70 kPa ≥ 10.0 miles \leq refer to P0442: Engine Off Time Before Vehicle Off Maximum as a Function of Estimated Ambient Temperature Table in Supporting Tables. ≥ 17 hours ≥ 10 hours $0\text{ }^\circ\text{C} \leq \text{Temperature} \leq 34\text{ }^\circ\text{C}$ *****	Once per trip, during hot soak (up to 2,400 sec.). No more than 2 unsuccessful attempts between completed tests.	Type A, 1 Trips EWMA Average run length is 8 to 12 trips under normal conditions Run length is 3 to 6 trips after code clear or non-volatile reset

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		the pressure drops (-62.27) Pa from peak pressure, the vent is then opened for 60 seconds to normalize the system pressure. The vent is again closed to begin the vacuum portion of the test (phase-2). As the fuel temperature continues to fall, a vacuum will begin forming. The vacuum will continue until it reaches a vacuum peak. When the pressure rises 62.27 Pa from vacuum peak, the test then completes. If the key is turned on while the diagnostic test is in progress, the test will abort.			Startup delta deg C (ECT-IAT) OR 2. Short Soak and Previous EAT Valid Previous time since engine off OR 3. Less than a short soak and Previous EAT Not Valid Previous time since engine off AND Vehicle Speed AND Mass Air Flow Must expire Estimate of Ambient Temperature Valid Conditioning Time. P0442: Estimate of Ambient Temperature Valid Conditioning Time Table in Supporting Tables. OR 4. Not a Cold Start and greater than a Short Soak Previous time since engine off AND Vehicle Speed AND Mass Air Flow	≤ 8 °C ≤ 7,200 seconds ≤ 7,200 seconds ≥ 25 mph ≥ 7 g/sec ≥ 25 mph ≥ 7 g/sec		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Must expire maximum value in Estimate of Ambient Temperature Valid Conditioning Time. Please see P0442: Estimate of Ambient Temperature Valid Conditioning Time in Supporting Tables.</p> <p>*****</p> <p>1. High Fuel Volatility</p> <p>During the volatility phase, pressure in the fuel tank is integrated vs. volatility time. If the integrated pressure is then test aborts and unsuccessful attempts is incremented. This value equates to an average integrated fuel tank pressure > 1,245 Pa. Please see P0442: Volatility Time as a Function of Estimate of Ambient Temperature in Supporting Tables.</p> <p>OR</p> <p>2. Vacuum Refueling Detected</p> <p>See P0454 Fault Code for information on vacuum refueling algorithm.</p> <p>OR</p> <p>3. Fuel Level Refueling</p>	<p>*****</p> <p>< -5</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Detected</p> <p>See P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>4. Vacuum Out of Range and No Refueling</p> <p>See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>5. Vacuum Out of Range and Refueling Detected</p> <p>See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>6. Vent Valve Override Failed</p> <p>Device control using an off-board tool to control the vent solenoid, cannot exceed during the EONV test</p> <p>OR</p> <p>7. Key up during EONV test</p>	0.50 seconds		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs:	MAF_SensorFA ECT_Sensor_FA IAT_SensorFA VehicleSpeedSensor_FA IgnitionOffTimeValid AmbientAirDefault P0443 P0446 P0449 P0452 P0453 P0455 P0496		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Canister Purge Solenoid Valve Circuit (ODM) (No ELCP - Conventional EVAP Diagnostic - For 3 DTC Implementati on Only)	P0443	Diagnoses the canister purge solenoid low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	PT Relay Voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0458 may also set (Caniste r Purge Solenoid Short to Ground)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent System Performance (No ELCP - Conventional EVAP Diagnostic)	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filler, vent hose or EVAP canister. This test runs with normal purge and vent valve is open.	Vent Restriction Prep Test: Vented Vacuum for OR Vented Vacuum for Vent Restriction Test: Tank Vacuum for before Purge Volume After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time.	< -623 Pa 60 seconds > 1,245 Pa 60 seconds > 2,989 Pa 5 seconds ≥ 8 liters	Fuel Level System Voltage Startup IAT Startup ECT BARO No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts 4 °C ≤ Temperature ≤ 30 °C ≤ 35 °C ≥ 70 kPa MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454	Once per Cold Start Time is dependent on driving conditions Maximum time before test abort is 1,000 seconds	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent Solenoid Control Circuit (ODM) (No ELCP - Conventional EVAP Diagnostic - For 3 DTC Implementation Only)	P0449	Diagnoses the vent solenoid low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground			20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controllers P0498 may also set (Vent Solenoid Short to Ground)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Performance (No ELCP - Conventional EVAP Diagnostic)	P0451	The DTC will be set if the fuel tank vacuum sensor is out of range when it tries to re-zero prior to the phase-1 or phase-2 portions of the engine-off natural vacuum small leak test.	<p>The tank vacuum sensor voltage is compared to a window about the nominal sensor voltage offset (~1.5 volts)</p> <p>Upper voltage threshold (voltage addition above the nominal voltage)</p> <p>Lower voltage threshold (voltage subtraction below the nominal voltage)</p> <p>The difference between tank vacuum sensor voltage and the nominal offset voltage is then normalized against the appropriate threshold listed above to produce a ratio between 0.0 and 1.0. This normalized re-zero ratio is then filtered with a EWMA (with 0= perfect pass and 1=perfect fail).</p> <p>When EWMA is</p> <p>the DTC light is illuminated.</p> <p>The DTC light can be turned off if the EWMA is</p> <p>and stays below the EWMA fail threshold for 3 additional consecutive trips.</p>	<p>0.2 volts</p> <p>0.2 volts</p> <p>> 0.73 (EWMA Fail Threshold),</p> <p>≤ 0.40 (EWMA Re-Pass Threshold)</p>	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		This test is executed during an engine-off natural vacuum small leak test. The number of times that it executes can range from zero to two per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.	Type A, 1 Trips EWMA Average run length: 6 Run length is 2 trips after code clear or non-volatile reset

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Low Voltage (No ELCP - Conventional EVAP Diagnostic)	P0452	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too low out of range.	FTP sensor signal The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~3736 Pa).	< 0.15 volts (3.0 % of Vref or ~ 1,681 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples 12.5 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit High Voltage (No ELCP - Conventional EVAP Diagnostic)	P0453	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too high out of range.	FTP sensor signal The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~-3736 Pa).	> 4.85 volts (97 % of Vref or ~ -4,172 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples 12.5 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Intermittent (No ELCP - Conventional EVAP Diagnostic)	P0454	This DTC will detect intermittent tank vacuum sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	If an abrupt change in tank vacuum is detected the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that a refueling event occurred. If a refueling is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem. An abrupt change is defined as a change in vacuum: in the span of 1.0 seconds. But in 12.5 msec. A refueling event is confirmed if the fuel level has a persistent change of for 30 seconds during a 600 second refueling rationality test.	> 112 Pa < 249 Pa > 10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes and the canister vent solenoid is closed		This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures. 12.5 ms / sample	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Large Leak Detected (No ELCP - Conventional EVAP Diagnostic)	P0455	This DTC will detect a weak vacuum condition (large leak or purge blockage) in the EVAP system. Purge valve is controlled (to allow purge flow) and vent valve is commanded closed.	Purge volume while Tank vacuum After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time. Weak Vacuum Follow-up Test (fuel cap replacement test) Weak Vacuum Test failed. Passes if tank vacuum Note: Weak Vacuum Follow-up Test can only report a pass.	> 10 liters $\leq 1,868$ Pa $\geq 2,117$ Pa	Fuel Level System Voltage BARO Purge Flow No active DTCs: Cold Start Test If ECT > IAT, Startup temperature delta (ECT-IAT): Cold Test Timer Startup IAT Startup ECT Weak Vacuum Follow-up Test This test can run following a weak vacuum failure or on a hot restart.	10 % \leq Percent \leq 90 % 11 volts \leq Voltage \leq 32 volts ≥ 70 kPa ≥ 4.80 % MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454 ≤ 8 °C $\leq 1,000$ seconds 4 °C \leq Temperature ≤ 30 °C ≤ 35 °C	Once per cold start Time is dependent on driving conditions Maximum time before test abort is 1,000 seconds Weak Vacuum Follow-up Test With large leak detected, the follow-up test is limited to 1,300 seconds. Once the MIL is on, the follow-up test runs indefinitely.	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Purge Control Valve Circuit Low (No ELCP - Conventional EVAP Diagnostic)	P0458	Diagnoses the canister purge solenoid low side driver circuit for circuit faults	Voltage low during driver off state (indicates short to ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	PT Relay Voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0443 may also set (Caniste r Purge Solenoid Open Circuit)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Purge Control Valve Circuit High (No ELCP - Conventional EVAP Diagnostic)	P0459	Diagnoses the canister purge solenoid low side driver circuit for circuit faults	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	PT Relay Voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Performance (For use on vehicles with a single fuel tank)	P0461	This DTC will detect a fuel sender stuck in range in the primary fuel tank.	Delta fuel volume change over an accumulated 149 miles.	< 3 liters	Engine Running No active DTCs:	VehicleSpeedSensor_FA	250 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Low Voltage	P0462	This DTC will detect a fuel sender stuck out of range low in the primary fuel tank.	Fuel level Sender % of 5V range	< 10%			100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit High Voltage	P0463	This DTC will detect a fuel sender stuck out of range high in the primary fuel tank.	Fuel level Sender % of 5V range	> 60 %			100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Intermittent (No ELCP - Conventional EVAP Diagnostic)	P0464	This DTC will detect intermittent fuel level sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	<p>If a change in fuel level is detected, the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that an actual refueling event occurred. If a refueling event is confirmed, then the test sample is considered passing. Otherwise, if a refueling event is not confirmed, then the test sample is considered failing which indicates an intermittent signal problem.</p> <p>An intermittent fuel level signal problem is defined as:</p> <p>The fuel level changes by and does not remain for 30 seconds during a 600 second refueling rationality test.</p>	> 10 % > 10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		<p>This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.</p> <p>100 ms / sample</p>	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Open (ODM) (Not used on EREV)	P0480	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controllers P0691 may also set (Fan 1 Short to Ground).

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Open (ODM)	P0481	Diagnoses the cooling fan 2 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controllers P0693 may also set (Fan 2 Short to Ground)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Flow During Non- Purge (No ELCP - Conventional EVAP Diagnostic)	P0496	This DTC will determine if the purge solenoid is leaking to engine manifold vacuum. This test will run with the purge valve closed and the vent valve closed.	Tank Vacuum for Test time	> 2,491 Pa 5 seconds ≥ refer to P0496: Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level Table in Supporting Tables.	Fuel Level System Voltage BARO Startup IAT Startup ECT Engine Off Time No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts ≥ 70 kPa 4 °C ≤ Temperature ≤ 30 °C ≤ 35 °C ≥ 28,800.0 seconds MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454	Once per cold start Cold start: max time is 1,000 seconds	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Vent Solenoid Control Circuit Low (No ELCP - Conventional EVAP Diagnostic)	P0498	Diagnoses the vent solenoid low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short to ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground			20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0449 may also set (Vent Solenoid Open Circuit)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Vent Solenoid Control Circuit High (No ELCP - Conventional EVAP Diagnostic)	P0499	Diagnoses the vent solenoid low side driver circuit for circuit faults. If the P0499 is active, an intrusive test is performed with the vent solenoid commanded closed for 15 seconds.	Voltage low during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power			20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Low Engine Speed Idle System	P0506	This DTC will determine if a low idle exists	Filtered Engine Speed Error	> 95.00 rpm	Baro	> 70 kPa	Diagnostic runs in every 12.5 ms loop	Type B, 2 Trips
			filter coefficient	0.00300	Coolant Temp	> KeSPDD_T_EnbIECT_Mi n (60 °C) and < KfECTI_T_EngCoolHotHi Thresh (125 °C) Must verify KfECTI_T_EngCoolHotLo Thresh (120) is less than KfECTI_T_EngCoolHotHi Thresh (125)		
					Engine run time	≥ 60 sec		
					Ignition voltage	32 ≥ volts ≥ 11		
					Time since gear change	≥ 3 sec		
					Time since a TCC mode change	> 3 sec		
					IAT	> -20 °C		
					Vehicle speed	≤ 1.24 mph		
					Commanded RPM delta	≤ 25 rpm		
					Idle time	> 10 sec		
					For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 90.00 pct < 12.00 pct		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	PTO not active Transfer Case not in 4WD LowState Off-vehicle device control (service bay control) must not be active. following conditions not TRUE: (VeTESR_e_EngSpdReqI ntvType = CeTESR_e_EngSpdMinLi mit AND VeTESR_e_EngSpdReqR espType = CeTESR_e_NoSuggestio n) Clutch is not depressed TC_BoostPresSnsrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorCircuitFA EvapFlowDuringNonPurg e_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_F A IgnitionOutputDriver FA		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA FuelLevelDataFault LowFuelConditionDiagnostic Clutch Sensor FA AmbPresDfltStatus P2771		
					All of the above met for Idle time	> 10 sec		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Engine Speed Idle System	P0507	This DTC will determine if a high idle exists	Filtered Engine Speed Error filter coefficient	< -182.00 rpm 0.00300	Baro Coolant Temp Engine run time Ignition voltage Time since gear change Time since a TCC mode change IAT Vehicle speed Commanded RPM delta For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa > KeSPDD_T_EnbLECT_Mi n (60 °C) and < KfECTI_T_EngCoolHotHi Thresh (125 °C) Must verify KfECTI_T_EngCoolHotLo Thresh (120) is less than KfECTI_T_EngCoolHotHi Thresh (125) ≥ 60 sec 32 ≥ volts ≥ 11 ≥ 3 sec > 3 sec > -20 °C ≤ 1.24 mph ≤ 25 rpm > 90.00 pct or < 12.00 pct	Diagnostic runs in every 12.5 ms loop Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	PTO not active Transfer Case not in 4WD LowState Off-vehicle device control (service bay control) must not be active. following conditions not TRUE: (VeTESR_e_EngSpdReqI ntvType = CeTESR_e_EngSpdMinLi mit AND VeTESR_e_EngSpdReqR espType = CeTESR_e_NoSuggestio n) Clutch is not depressed TC_BoostPresSnsrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorCircuitFA EvapFlowDuringNonPurg e_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_F A IgnitionOutputDriver_FA TPS_FA TPS_Performance_FA VehicleSpeedSensor FA		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for Idle time	FuelLevelDataFaultLow FuelConditionDiagnostic Clutch SensorFA AmbPresDfltStatus P2771 > 10 sec		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Mutil-Function Switch Circuit	P0564	Detect when cruise control multi-function switch circuit (analog) voltage is in an illegal range	Cruise Control analog circuit voltage must be in an "illegal range" or "between ranges" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 0.794 seconds	MIL: Type C, No MIL Special Type C

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Resume Circuit	P0567	Detects a failure of the cruise resume switch in a continuously applied state	Cruise Control Resume switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 90.000 seconds	MIL: Type C, No MIL Special Type C

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Set Circuit	P0568	Detects a failure of the cruise set switch in a continuously applied state	Cruise Control Set switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 90.000 seconds	MIL: Type C, No MIL Special Type C

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Input Circuit	P0575	Detects rolling count or protection value errors in Cruise Control Switch Status serial data signal	If x of y rolling count / protection value faults occur, disable cruise for duration of fault		Cruise Control Switch Serial Data Error Diagnostic Enable	1.00	10 / 16 counts	MIL: Type C, No MIL Special Type C

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Range/ Performance	P057B	This diagnostic monitors the Brake Pedal Position Sensor for a stuck in range failure	.		Brake Pedal Position Sensor Circuit Range / Performance Diagnostic Enable	1.00 ignition voltage > 10.00		MIL: Type A, 1 Trips
			Calculated EWMA value must be greater than calibratable threshold after calibratable number of tests have completed to report a "test passed" for P057B	EWMA value looked up in supporting table P057B KtBRKI_K_FastTestPointWeight as a function of calculated brake pedal position delta EWMA value is > 0.70	calculated brake pedal position delta sample counter > 75.00 for fast test OR calculated brake pedal position delta sample counter > 1,000.00 for slow test	calculated brake pedal position delta > 10.00 OR (for slow test) shift lever has been in park once this key cycle vehicle speed >= 5.00 accelerator pedal position < 5.00	total number of EWMA tests > 15.00	
			Calculated EWMA Value must be less than calibratable threshold after calibratable number of tests have completed to report a "test failed" for P057B. This test runs once per key cycle	EWMA value looked up in supporting table P057B KtBRKI_K_CmpltTestPointWeight as a function of calculated brake pedal position delta EWMA value is less than 0.30	no DTC's active (P057C, P057D)	shift lever has been in park once this key cycle vehicle speed >= 5.00 accelerator pedal position < 5.00	total number of EWMA tests > 2.00	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Low	P057C	detects short to ground for brake pedal position sensor	If x of y samples are observed below failure threshold, default brake pedal position to zero percent.	5.00	Brake Pedal Position Sensore Low Voltage Diagnostic Enable	1.00	20 / 32.00 counts	MIL: Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit High	P057D	detects open circuit for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	95.00	Brake Pedal Position Sensore High Voltage Diagnostic Enable	1.00	20.00 / 32.00 counts	MIL: Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control Open Circuit	P0597	Diagnoses the T-stat Heater low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Run Crank Ignition in Range Engine not cranking Run Crank active == Above is true and == Last Open Circuit Test	= True = True = True =====	15 failures out of 30 samples 1 sec/ sample Continuous	Type B, 2 Trips Note: In certian controlle rs P0598 may also set

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control Circuit Low	P0598	Diagnoses the T-stat Heater low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short- to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run Crank Ignition in Range Engine not cranking Run Crank active == Above is true and == Last Ground Short Circuit Test	= True = True = True =====	15 failures out of 30 samples 1 sec/ sample Continuous	Type B, 2 Trips Note: In certian controlle rs P0597 may also set

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control Circuit High	P0599	Diagnoses the T-stat Heater low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Run Crank Ignition in Range Engine not cranking Run Crank active == Above is true and == Last Power Short Circuit Test	= True = True = True =====	15 failures out of 30 samples 1 sec/ sample Continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ColdStrtA_C amPstnB1	P05CC	Detects a VVT system error during Cold Starts by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Intake cam Bank 1) Cam Position Error > 5.00 deg.	DTC's are NOT active: P0010, IntakeCamSensorTFTKO CrankSensorTFTKO CrankIntakeCamCorrelationFA.	System Voltage > 11.00 Volts, Engine is running VVT is enabled CSER is active Desired cam position > 0 Power Take Off (PTO) not active Both Desired & Measured cam positions cannot be < 5.00 or have both > 25.00 deg. (PerfMaxlc1). Desired cam position cannot vary more than 4.00 Cam Deg for at least 2.00 sec. (StablePositionTimeIc1)	120.00 failures out of 150.00 samples 100 ms /sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ColdStrtB_C amPstnB1	P05CE	Detects a VVT system error during Cold Starts by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Exhaust cam Bank 1) Cam Position Error > 5.00 deg.	DTC's are NOT active: P0010, ExhaustCamSensorTFTKO CrankSensorTFTKO CrankExhaustCamCorrelationFA.	System Voltage > 11.00 Volts, Engine is running VVT is enabled CSER is active Desired cam position > 0 Power Take Off (PTO) not active Both Desired & Measured cam positions cannot be < 5.00 or have both > 25.00 deg. (PerfMaxEc1). Desired cam position cannot vary more than 4.00 Cam Deg for at least 2.00 sec. (StablePositionTimeEc1)	120.00 failures out of 150.00 samples 100 ms /sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if the calibration check sum is incorrect or the flash memory detects an uncorrectable error via the Error Correcting Code.	The Primary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	Type A, 1 Trips
			The Primary Processor's Error Correcting Code hardware in the flash memory detects an error. Covers all software and calibrations.	254 failures detected via Error Correcting Code			Diagnostic runs continuously via the flash hardware.	
			The Primary Processor's calculated checksum does not match the stored checksum value for a selected subset of the calibrations.	2 consecutive failures detected or 5 total failures detected.			Diagnostic runs continuously. Will report a detected fault within 200 ms.	
			The Secondary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	
				In all cases, the failure count is cleared when controller shuts down				

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Not Programmed	P0602	This DTC will be stored if the PCM is a service PCM that has not been programmed.	Output state invalid		PCM State	= crank or run PCM is identified through calibration as a Service PCM	Diagnostic runs at powerup and once per second continuously after that	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Long Term Memory Reset	P0603	Non-volatile memory checksum error at controller power-up	Checksum at power-up does not match checksum at power-down				Diagnostic runs at powerup Diagnostic reports a fault if 1 failure occurs	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM RAM Failure	P0604	Indicates that the ECM has detected a RAM fault	Indicates that the primary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	Type A, 1 Trips
			Indicates that the primary processor is unable to correctly read data from or write data to cached RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor is unable to correctly read data from or write data to TPU RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor detects a mismatch between the data and dual data is found during RAM updates. Detects a mismatch in data and dual data updates >	0.44000 s			When dual store updates occur.	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Indicates that the primary processor detects an illegal write attempt to protected RAM. Number of illegal writes are >	65,534 counts			Diagnostic runs continuously (background loop)	
			Indicates that the secondary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Fault	P0606	Indicates that the ECM has detected an internal processor integrity fault	Loss or invalid message of SPI communication from the Secondary Processor at initialization detected by the Primary Processor or loss or invalid message of SPI communication from the Secondary Processor after a valid message was received by the Primary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received		Run/Crank voltage >= 6.41 or Run/Crank voltage >= 11.00 , else the failure will be reported for all conditions	In the primary processor, 159 / 399 counts intermittent or 39 counts continuous; 39 counts continuous @ initialization. 12.5 ms /count in the ECM main processor	Type A, 1 Trips
			Loss or invalid message of SPI communication from the Primary Processor at initialization detected by the Secondary Processor or loss or invalid message of SPI communication from the Primary Processor after a valid message was received by the Secondary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received			In the secondary processor, 20 / 200 counts intermittent or 0.1875 s continuous; 0.4750 s continuous @ initialization. 12.5 ms /count in the ECM secondary processor	
			Checks for stack over or underflow in secondary processor by looking for corruption of known pattern at stack boundaries. Checks number of stack over/under flow since last powerup reset >=	5		KeMEMD_b_StackLimitTestEnbl == 1 Value of KeMEMD_b_StackLimitTestEnbl is: 1 . (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			MAIN processor is verified by responding to a seed sent from the secondary with a key response to secondary. Checks number of incorrect keys	2 incorrect seeds within 8 messages, 0.2000 seconds		ignition in Run or Crank	150 ms for one seed continually failing	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			received > or Secondary processor has not received a new within time limit					
			Time new seed not received exceeded			always running	0.450 seconds	
			MAIN processor receives seed in wrong order			always running	3 / 17 counts intermittent. 50 ms/count in the ECM main processor	
			2 fails in a row in the Secondary processor's ALU check			KePISD_b_ALU_TestEnbl d == 1 Value of KePISD_b_ALU_TestEnbl d is: 1. (If 0, this test is disabled)	25 ms	
			2 fails in a row in the Secondary processor's configuration register masks versus known good data			KePISD_b_ConfigRegTes tEnbl d == 1 Value of KePISD_b_ConfigRegTes tEnbl d is: 1. (If 0, this test is disabled)	12.5 to 25 ms	
			Secondary processor detects an error in the toggling of a hardware discrete line controlled by the MAIN processor: number of discrete changes > = or < = over time window(50ms)	7 17		KePISD_b_MainCPU_SO H_FltEnbl == 1 Value of KePISD_b_ConfigRegTes tEnbl d is: 1. (If 0, this test is disabled) time from initialization >= 0.4875 seconds	50 ms	
			memory and complement memory do not agree				0.19 seconds	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Software background task first pass time to complete exceeds			Run/Crank voltage > 6.41	360.000 seconds	
			2 fails in a row in the MAIN processor's ALU check			KePISD_b_ALU_TestEnbl d == 1 Value of KePISD_b_ALU_TestEnbl d is: 1 . (If 0, this test is disabled)	25 ms	
			2 fails in a row in the MAIN processor's configuration register masks versus known good data			KePISD_b_ConfigRegTestEnbl == 1 Value of KePISD_b_ConfigRegTestEnbl is: 1 . (If 0, this test is disabled)	12.5 to 25 ms	
			Checks number of stack over/under flow since last powerup reset >=	3		KeMEMD_b_StackLimitTestEnbl == 1 Value of KeMEMD_b_StackLimitTestEnbl is: 1 . (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			Voltage deviation >	0.4950		KePISD_b_A2D_CnvtrrTestEnbl == 1 Value of KePISD_b_A2D_CnvtrrTestEnbl is: 1 . (If 0, this test is disabled)	5 / 10 counts or 0.150 seconds continuous; 50 ms/count in the ECM main processor	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occurred since last	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_FlashECC_CktTestEnbl == 1 Value of KeMEMD_b_FlashECC_CktTestEnbl is: 1 . (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			controller initialization. Counter >=					
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_RAM_ECC_CktTestEnbl == 1 Value of KeMEMD_b_RAM_ECC_CktTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM variable, depends on length of time to write flash to RAM	
			MAIN processor DMA transfer from Flash to RAM has 1 failure			KePISD_b_DMA_XferTestEnbl == 1 Value of KePISD_b_DMA_XferTestEnbl is: 0. (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM	
			Safety critical software is not executed in proper order.	>= 1 incorrect sequence.		Table, f(Loop Time). See supporting tables: Program Sequence Watch Enable f(Loop Time) (If 0, this Loop Time test is disabled)	Fail Table, f(Loop Time). See supporting tables: PSW Sequence Fail f(Loop Time) / Sample Table, f(Loop Time)See supporting tables: PSW Sequence Sample f(Loop Time) counts 50 ms/count in	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			MAIN processor determines a seed has not changed within a specified time period within the 50ms task.	Previous seed value equals current seed value.		KePISD_b_SeedUpdKey StorFltEnbl == 1 Value of KePISD_b_SeedUpdKey StorFltEnbl is: 1. (If 0, this test is disabled)	the ECM main processor Table, f(Loop Time). See supporting tables: Last Seed Timeout f (Loop Time)	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit Low Voltage	P0628	Diagnoses the fuel pump relay control high side driver circuit for circuit faults	Voltage low during driver on state (indicates short to ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage Engine Speed	Voltage ≥ 11 volts ≥ 0 RPM	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module EEPROM Error	P062F	Indicates that the NVM Error flag has not been cleared	The next write to NVM will not succeed or the assembly calibration integrity check failed.		Ignition State	= unlock/accessory, run, or crank	1 test failure Diagnostic runs once at powerup	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VIN Not Programmed or Mismatched - Engine Control Module (ECM)	P0630	This DTC checks that the VIN is correctly written	At least one of the programmed VIN digits	= 00 or FF	OBD Manufacturer Enable Counter	= 0	250 ms / test Continuous	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #1 Circuit	P0641	Detects a continuous or intermittent short on the 5 volt reference circuit #1	ECM Vref1 < or ECM Vref1 > or the difference between ECM filtered Vref1 and Vref1 >	4.875 5.125 0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Open	P0650	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11 volts	20 failures out of 25 samples 50 ms / sample	Type B, No MIL NO MIL Note: In certain controllers P263A may also set (MIL Control Short to Ground)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #2 Circuit	P0651	Detects a continuous or intermittent short on the 5 volt reference circuit #2	ECM Vref2 < or ECM Vref2 > or the difference between ECM filtered Vref2 and Vref2 >	4.875 5.125 0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Open	P0685	Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω ohms impedance between signal and controller ground	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0686 may also set (Powertr ain Relay Control Short to Ground).

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Low	P0686	Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0685 may also set (Powertr ain Relay Control Open Circuit).

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) High	P0687	Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Feedback Circuit High	P0690	This DTC is a check to determine if the Powertrain relay is functioning properly.	Powertrain Relay Voltage	>= 4.00 volts will increment the fail counter	Powertrain relay commanded "OFF" No active DTCs:	>= 2.00 seconds PowertrainRelayStateOn_ FA	50 failures out of 63 samples 100ms / Sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Low Voltage (ODM)	P0691	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0480 may also set (Fan 1 Open Circuit).

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit High Voltage (ODM)	P0692	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Low Voltage (ODM)	P0693	Diagnoses cooling fan 2 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short- to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0481 may also set (Fan 2 Open Circuit).

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit High Voltage (ODM)	P0694	Diagnoses the cooling fan 2 relay control low side driver circuit for circuit faults	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #3 Circuit	P0697	Detects a continuous or intermittent short on the 5 volt reference circuit #3	ECM Vref3 < or ECM Vref3 > or the difference between ECM filtered Vref3 and Vref3 >	4.875 5.125 0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Control Module (FPCM) Requested MIL Illumination	P069E	Monitors the FPCM MIL request line to determine when the FPCM has detected a MIL illuminating fault.	Fuel Pump Control Module Emissions-Related DTC set			Time since power-up ≥ 3 seconds	Continuous	Type A, No MIL

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #4 Circuit	P06A3	Detects a continuous or intermittent short on the 5 volt reference circuit #4	ECM Vref4 < or ECM Vref4 > or the difference between ECM filtered Vref4 and Vref4 >	4.875 5.125 0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 1 Performance	P06B6	This diagnostic checks for a fault with the internal test circuit used only for the '20 kHz' method of the Open Circuit Diagnostic	FFT Diagnostic Output	> OpenTestCktThrshMin and < OpenTestCktThrshMax See Supporting Tables	Diagnostic Enabled? Engine Run Time Engine Speed Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above) Engine Air Flow	Yes ≥ 2.0 seconds > 580 RPM and < 3,000 RPM ≥ 200 Revs ≥ 0 mg/cylinder and ≤ 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient Weight Coefficient = 0.0070 Updated each engine event	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Module (TCM) Requested MIL Illumination	P0700	Monitors the TCM MIL request line to determine when the TCM has detected a MIL illuminating fault.	Transmission Emissions-Related DTC set			Time since power-up \geq 3 seconds	Continuous	Type A, No MIL

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Traction Control Torque Request Circuit	P0856	Determines if torque request from the EBTCM is valid	Serial Communication 2's complement message - (\$140 for PPEI2 or \$1C9 for PPEI3, \$1CA/\$1C6 for Hybrid)) OR Serial Communication message (\$140 for PPEI2 or \$1C9 for PPEI3, \$1CA/\$1C6 for Hybrid)) rolling count value OR Too many minimum limit torque request transitions occur from TRUE to FALSE to TRUE within a time period OR Torque request greater than torque request diagnostic maximum threshold	Message <> 2's complement of message Message rolling count value <> previous message rolling count value plus one Requested torque intervention type toggles from not increasing request to increasing request > 8,192 Nm for engine based traction torque system, OR > 999,999 Nm for axle based traction torque system	Serial communication to EBTCM (U0108) Power Mode Engine Running Status of traction in GMLAN message (\$4E9)	No loss of communication = Run = True = Traction Present	Count of 2's complement values not equal >= 10 Performed on every received message 10 rolling count failures out of 10 samples Performed on every received message >= 5 multi-transitions out of 5 samples. Performed every 200 ms >= 10 out of 10 samples Performed on every received message	Type C, No MIL Special Type C

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (turbocharged)	P1101	Determines if there are multiple air induction problems affecting airflow and/or manifold pressure.	See table " Turbocharger Intake Flow Rationality Diagnostic Failure Matrix " for combinations of model failures that can set this DTC. MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered TPS model fails when Filtered Throttle Model Error TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table " TIAP-MAP	> 16 grams/sec > 20.0 kPa > 25.0 kPa > 25.0 kPa > 25.0 kPa > 250 kPa*(g/s) > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 100 Deg C >= 0.50 Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Correlation Offset"</p> <p>OR</p> <p>Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset"</p> <p>TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time</p> <p>High Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND Manifold Pressure</p> <p>AND Filtered Mass Air Flow - Mass Air Flow</p>	<p>> 25.0 kPa</p> <p>> 2.0 seconds</p> <p>> 2.0 seconds</p> <p>> a threshold in gm sec as a function of engine speed See table "TIAP-MAP Correlation Min Air Flow"</p> <p>> a threshold in kPa as a function of engine speed See table "TIAP-MAP Correlation Min MAP"</p> <p>< 2.0 gm/sec</p>	<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>See Residual Weight Factor tables.</p> <p>MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Low Engine Air Flow is TRUE when Mass Air Flow AND Manifold Pressure AND Mass Air Flow - Filtered Mass Air Flow	< a threshold in gm sec as a function of engine speed See table " TIAP-Baro Correlation Max Air Flow " < a threshold in kPa as a function of engine speed See table " TIAP-Baro Correlation Max MAP " < 2.0 gm/sec				

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Emissions Reduction System Fault	P1400	Model based test computes power from exhaust flow and thermal energy resulting from elevated idle speed and retarded spark advance. Detects if the cold start emission reduction system has failed resulting in the delivered power being out of range.	<p>Average desired accumulated exhaust power - Average actual accumulated exhaust power (too much energy delivered to catalyst)</p> <p>Average desired accumulated exhaust power - Average actual accumulated exhaust power (too little energy delivered to catalyst)</p> <p>(EWMA filtered)</p> <p>Average Power = output of P1400_EngineSpeedResidual_Table * output of P1400_SparkResidual_Table</p> <p>NOTE: Desired accumulated power would use the desired catalyst light off spark and desired engine speed and the actual accumulated power would use the final commanded spark and actual engine speed. Refer to the Supporting Tables for details</p>	<p>< -32.00 KJ/s (high RPM failure mode)</p> <p>> 3.50 KJ/s (low RPM failure mode)</p>	<p>To enable the diagnostic, the Cold Start Emission Reduction Strategy must be Active per the following:</p> <p>Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure</p> <p>The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following:</p> <p>Catalyst Temperature AND Engine Run Time</p> <p>OR</p> <p>Engine Run Time</p> <p>OR</p> <p>Barometric Pressure</p>	<p>< 650.00 degC</p> <p>> -12.00 degC</p> <p><= 55.00 degC</p> <p>>= 70.00 KPa</p> <p>>= 800.00 degC</p> <p>>= 35.00 seconds</p> <p>></p> <p>CatalystLightOffExtendedEngineRunTimeExit</p> <p>This Extended Engine run time exit is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details.</p> <p>< 70.00 KPa</p>	<p>Runs once per trip when the cold start emission reduction strategy is active</p> <p>Frequency: 100ms Loop</p> <p>Test completes after 10 seconds of accumulated qualified data.</p>	EWMA Based - Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Other Enable Criteria:</p> <p>OBD Manufacturer Enable Counter</p> <p>Vehicle Speed</p> <p>Allow diagnostic to calculate residual in an off-idle state. If the value of the OffIdleEnable is equal to 1 then the "DriverOffAccelPedal" will not be checked. However, if the value of OffIdleEnable is 0 then driver must be off the accel pedal</p> <p>A change in throttle position (tip-in/tip-out) will initiate a delay in the calculation of the average qualified residual value. Therefore when the:</p> <p>Pedal Close Delay Timer</p> <p>the diagnostic will continue the calculation.</p> <p>For Manual Transmission vehicles:</p>	<p>0</p> <p>< 1.24 MPH</p> <p>0</p> <p>(A value of 1 allows diagnostic to run and calculate the residual while off idle. A value of 0 requires calculation of the residual at idle)</p> <p>> 5.00 seconds</p> <p>> 90.00 %</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Clutch Pedal Position</p> <p>Clutch Pedal Position</p> <p>The diagnostic will delay calculation of the residual value and potentially weight the residual calculation differently based on engine run time. This is to ensure the diagnostic is operating in idle speed control as well as during the peak catalyst light off period.</p> <p>The time weighting factor must be :</p> <p>General Enable:</p> <p>DTC's Not Set:</p>	<p>< 12.00 %</p> <p>> 0 These are scalar values that are a function of engine run time. Refer to ColdStartDiagnosticDelayBasedOnEngineRunTime and the cal axis, ColdStartDiagnosticDelayBasedOnEngineRunTimeCalAxis in the "Supporting Tables" for details.</p> <p>AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFP CrankSensorFaultActive FuelInjectorCircuit FA</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						MAF_SensorFA MAP_SensorFA EngineMisfireDetected_F A Clutch_Sensor_FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA 5VoltReferenceMAP_OO R_Fit TransmissionEngagedStat e_FA EngineTorqueInaccurate		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Steady State Actuation Fault	P1516	Detect an inability to maintain a steady state throttle position	The absolute difference between desired and indicated throttle position is >	2.00 percent		Run/Crank voltage > 6.41 Ignition voltage failure is false (P1682) TPS minimum learn is not active and Throttle is being Controlled Throttle is considered in a steadystate condition when the desired throttle position over a 12.5 ms period is < 0.25 percent for a settling time period > 4.00 s	0.49 ms	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Switch State Undertermin ed	P155A	Detects when cruise switch state cannot be determined, such as low voltage conditions	cruise switch state remains undetermined for greater than a calibratable time				fail continuously for greater than 15.5 seconds	MIL: Type C, No MIL Special Type C

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation	P1682	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage & the Powertrain Relay Ignition Voltage	Run/Crank – PT Relay Ignition >	3.00 Volts		Powertrain commanded on AND (Run/Crank voltage > Table, f(IAT). See supporting tables: PT Relay Pull-in Run/Crank Voltage f(IAT) OR PT Relay Ignition voltage > 5.50) AND Run/Crank voltage > 5.50 .	240 / 480 counts or 0.1750 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Redundant Memory Performance	P16F3	<p>Detect Processor Calculation faults due to RAM corruptions, ALU failures and ROM failures</p> <p>For all of the following cases: If the individual diagnostic threshold is equal to 2048 ms, this individual case is not applicable. If any of the following cases are X out of Y diagnostics and the fail (x) is greater than the sample (Y), this individual case is also not applicable.</p>	Desired Throttle Area calculated does not equal its redundant calculation	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	Type A, 1 Trips
			Equivalence Ratio torque compensation exceeds threshold	-47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Absolute difference between Equivalence Ratio torque compensation and its dual store out of bounds given by threshold	47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of Accessory torque and its redundant calculation is out of bounds given by threshold range	47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Filtered Air-per-cylinder and its redundant calculation is out of bounds given by threshold range	107.62 mg	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference between the previous Final Advance and the current Final Advance not Adjusted for Equivalence Ratio is out of bounds given by threshold range	10.23 degrees		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5 down time multiplier	
			Torque Learn offset is out of bounds given by threshold range	High Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold 0.00 Nm			multiplier	
			One step ahead calculation of air-per-cylinder and two step ahead is greater than threshold	80.00 mg		Engine speed > 500 rpm	Up/down timer 428 ms continuous, 0.5 down time multiplier	
			Difference between Unmanaged Spark and PACS Spark is greater than threshold	10.23 degrees	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Engine Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			Zero pedal axle torque is out of bounds given by threshold range	High Threshold 1,361.17 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Creep Coast Axle Torque is out of bounds given by threshold range	High Threshold 1,361.17 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Absolute difference of Friction torque and its redundant calculation is out of bounds given by threshold range	47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			Arbitrated Air-Per-Cylinder filter coefficient is out of bounds given by threshold range	High Threshold 1.000 Low Threshold 0.074	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Launch spark is active but the launch spark redundant path indicates it should not be active	N/A		Engine speed < 7,800.00 or 7,900.00 rpm (hysteresis pair)	Up/down timer 128 ms continuous, 0.5 down time multiplier	
			Rate limited vehicle speed and its dual store do not equal	N/A		Time since first CAN message with vehicle speed >= 0.500 sec	10 / 20 counts; 25.0msec/count	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Preload Throttle Area and its dual store do not equal	N/A	Ignition State	Accessory, run or crank AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded engine torque due to fast actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded engine torque due to slow actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			TOS to wheel speed conversion factor is out of bounds given by threshold	High Threshold: 1.10	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			range	T/C Range Hi 0.10 T/C Range Lo Low Threshold: 1.10 T/C Range Hi 0.10 T/C Range Lo				
			TOS to wheel speed conversion factor and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	
			Cylinders active greater than commanded	2 cylinders		Engine run flag = TRUE > 2.00 s Number of cylinder events since engine run > 24	Up/down timer 128 ms continuous, 0.5 down time multiplier	
						No fuel injector faults		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						active		
			Transfer case neutral request from four wheel drive logic does not match with operating conditions	N/A	Ignition State	Accessory, run or crank Transfer case range valid and not over-ridden FWD Apps only	32 / 6 counts; 25.0msec/count	
			Transfer case neutral and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	
			Driver progression mode and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Predicted torque for uncorrected zero pedal determination is greater than calculated limit.	Table, f(Engine, Oil Temp). See supporting tables + 47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Predicted Request Without Motor is greater than its redundant calculation plus threshold	46.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Immediate Request Without Motor is greater than its redundant calculation plus threshold	46.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Positive Torque Offset is greater than its redundant calculation plus threshold OR Positive Torque Offset is less than its redundant calculation minus threshold	47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Engine Request is greater than its redundant calculation plus threshold	47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Hybrid Predicted Crankshaft Request is greater than its redundant calculation plus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Hybrid Immediate Crankshaft Request is less than its redundant calculation minus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Regeneration Brake Assist is not within a specified range	Brake Regen Assist < 0 Nm or Brake Regen Assist >	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous.	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				1,000.00 Nm			0.5 down time multiplier	
			Cylinder Spark Delta Correction exceeds the absolute difference as compared to Unadjusted Cylinder Spark Delta	10.23 degrees	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			1. Cylinder Torque Offset exceeds step size threshold OR 2. Sum of Cylinder Torque Offset exceeds sum threshold	1. 47.00 Nm 2. 47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Capacity Minimum Immediate Without Motor is greater than its dual store plus threshold	47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Capacity Minimum Engine Off is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Engine Capacity Minimum Engine Immediate Without Motor is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Immediate Engine Request is greater than its redundant calculation plus threshold	47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Speed Lores Intake Firing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 128 ms continuous, 0.5 down time multiplier	
			Engine Speed Lores Intake Firing timing (event	N/A		Engine speed greater than 0rpm	Up/down timer 128	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			based) calculation does not equal its redundant calculation				ms continuous, 0.5 down time multiplier	
			Idle speed control calculated predicted minimum torque request exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: Speed Control External Load f(Oil Temp, RPM) + 47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Idle speed control calculated predicted minimum torque without reserves exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: Speed Control External Load f(Oil Temp, RPM) + 47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Difference between Driver Requested Immediate	1,361.17 Nm	Ignition State	Accessory, run or crank	Up/down timer 2.048	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Torque primary path and its secondary exceeds threshold				ms continuous, 0.5 down time multiplier	
			Driver Immediate Request is less than its redundant calculation minus threshold	1,361.17 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded Immediate Request is greater than its redundant calculation plus threshold OR Commanded Immediate Request is less than its redundant calculation minus threshold	1,361.17 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Immediate Response Type is set to Inactive	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Difference between Cruise Axle Torque Arbitrated Request and Cruise Axle Torque Request exceeds threshold	170.15 Nm		Cruise has been engaged for more than 4.00 seconds	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Desired engine torque request greater than redundant calculation plus threshold	46.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine min capacity above threshold	47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 138 ms continuous, 0.5 down time multiplier	
			No fast unmanaged retarded spark above the applied spark plus the threshold	Table, f(RPM,APC). See supporting tables: Delta Spark Threshold f (RPM,APC)		Engine speed greater than 0rpm	Up/down timer 128 ms continuous, 0.5 down time multiplier	
			Absolute difference of adjustment factor based on temperature and its dual store above threshold	2.76 m/s	Ignition State	Accessory, run or crank	Up/down timer 228 ms continuous, 0.5 down time multiplier	
			1. Absolute difference of redundant calculated engine speed above threshold	500 RPM		Engine speed greater than 0 RPM	Up/down timer 128 ms continuous, 0.5	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							down time multiplier	
			After throttle blade pressure and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Speed Control's Predicted Torque Request and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine oil temperature and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 438 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired throttle position greater than redundant calculation plus threshold	10.00 percent	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the rate limited pre-throttle pressure and its redundant calculation greater than threshold	0.06 kpa	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Throttle desired torque above desired torque plus threshold	47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Desired filtered throttle torque exceeds the threshold plus the higher of desired throttle torque or modeled throttle torque	47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			Torque feedback proportional term is out of allowable range or its dual store copy does not match	High Threshold 23.50 Nm Low Threshold -23.50 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Torque feedback integral term magnitude or rate of change is out of allowable range or its dual store copy do not match	High Threshold 44.06 Nm Low Threshold -47.00 Nm Rate of change threshold	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				2.94 Nm/loop				
			Difference of Final Torque feedback proportional plus integral term and its redundant calculation is out of bounds given by threshold range	High Threshold 47.00 Nm Low Threshold - 47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of torque desired throttle area and its redundant calculation is out of bounds given by threshold range	High Threshold 0.50 % Low Threshold - 0.50 %	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference of torque model coefficients and its redundant calculation is out of bounds given by threshold range	High Threshold 0.0000800 Low Threshold - 0.0000800	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Difference of base friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 47.00 Nm Low Threshold - 47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Accessory drive friction torque is out of bounds given by threshold range	High Threshold 47.00 Nm Low Threshold	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				0.00 Nm				
			AC friction torque is greater than commanded by AC control software or less than threshold limit	High Threshold 32.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference of Oil temperature delta friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 47.00 Nm Low Threshold - 47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Generator friction torque is out of bounds given by threshold range	High Threshold 47.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Supercharger friction torque is out of bounds given by threshold range	High Threshold 47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold 0.00 Nm				
			Filtered Torque error magnitude or its increase rate of change is out of allowable range or its dual store copy do not match	High Threshold 47.00 Nm Low Threshold -47.00 Nm Rate of change threshold 2.94 Nm/loop		Engine speed >0rpm MAF, MAP and Baro DTCs are false	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Torque error compensation is out of bounds given by threshold range	High Threshold 47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold 0.00 Nm			multiplier	
			Delta Torque Baro compensation is out of bounds given by threshold range	High Threshold 8.82 Nm Low Threshold -1.93 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			1. Difference of reserve torque value and its redundant calculation exceed threshold OR 2. Reserve request does not agree with operating conditions or Difference of final predicted torque and its redundant calculation	1. 46.00 Nm 2. N/A 3. 46.00 Nm 4. 46.00		1. & 2.: Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 47.00 Nm	Up/down timer 475 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			exceed threshold OR 3. Rate of change of reserve torque exceeds threshold, increasing direction only OR 4. Reserve engine torque above allowable capacity threshold	Nm	3. & 4.: Ignition State	3. & 4.: Accessory, run or crank		
			Engine Vacuum and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the calculated Intake Manifold Pressure during engine event versus during time event is greater than threshold	Table, f(Desired Engine Torque). See supporting tables: Delta MAP Threshold f(Desired Engine Torque)		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5 down time multiplier	
			Min. Axle Torque Capacity is greater than threshold	0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							ms continuous, 0.5 down time multiplier	
			Driver Predicted Request is greater than its redundant calculation plus threshold OR Driver Predicted Request is less than its redundant calculation minus threshold	1,361.17 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Cold Delta Friction Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Predicted torque for zero pedal determination is greater than calculated limit.	Table, f(Oil Temp, RPM). See supporting tables: Speed Control External Load f(Oil Temp, RPM) + 47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Axle Torque and its dual store do not match	1 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Steady State Estimated Engine Torque and its dual store are not equal	N/A		AFM not changing from Active to Inactive and preload torque not changing and one loop after React command Engine speed >0rpm	Up/down timer 1,988 ms continuous, 0.5 down time multiplier	
			Difference of Weighting factor for number of cylinders fueled and its	0.26		Engine run flag = TRUE > 10.00	Up/down timer 175 ms continuous,	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			redundant calculation is above threshold				0.5 down time multiplier	
			Difference of minimum spark advance limit and its redundant calculation is out of bounds given by threshold range	10.23 degrees	Ignition State	Accessory, run or crank	Up/down timer 128 ms continuous, 0.5 down time multiplier	
			Difference of commanded spark advance and adjusted delivered is out of bounds given by threshold range	10.23 degrees		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5 down time multiplier	
			Absolute difference between Estimated Engine Torque and its dual store are above a threshold	47.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference between Estimated Engine Torque without reductions due to torque control and its dual store are above a threshold	47.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by threshold range	10.23 degrees		Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 47.00 Nm	Up/down timer 428 ms continuous, 0.5 down time multiplier	
			Absolute difference of Engine Capacity Minimum Running Immediate Brake Torque Excluding Cylinder Sensitivity and its redundant calculation is out of bounds given by threshold range	47.00 Nm		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			One step ahead calculation of air-per-cylinder greater than two step ahead calculation by threshold for time	Threshold: Dynamically calculated based on current engine conditions Fault Pending Threshold: 100 ms		Engine speed > 500 rpm	Up/down timer 428 ms continuous, 0.5 down time multiplier	
			Rate limited cruise axle torque request and its dual store do not match within a threshold	170.15 Nm	Ignition State	Accessory, run or crank	Up/down timer 163 ms continuous, 0.5 down time multiplier	
			1. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its redundant calculation is out of bounds given by threshold range	1. 5.00 % 2. N/A 3. N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>OR</p> <p>2. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its dual store do not equal</p> <p>OR</p> <p>3. Absolute difference of Calculated accelerator pedal position and its dual store do not equal</p>					
			Commanded axle torque is greater than its redundant calculation by threshold	1,361.17 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded axle torque is less than its redundant calculation by threshold	2,041.76 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous,	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							0.5 down time multiplier	
			Preload timer and its redundant calculation do not equal	N/A	Ignition State	Accessory, run or crank AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			AC friction torque is greater than commanded by AC control software	32.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Speed Lores Intake Firing (time based) calculation does not equal its redundant calculation	N/A		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the calculated spark offset for	10.23 degrees		Engine speed >0rpm	Up/down timer 128	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			equivalence ratio and its redundant cacluation is greater than a threshold				ms continuous, 0.5 down time multiplier	
			Transmission Torque Request cacluations do not equal their dual stores	N/A		Run or Crank = TRUE > 0.50 s	16 / 32 counts; 25.0msec/count	
			Absolute difference of the predicted motor torque ACS and its redundant cacluation is greater than a threshold	0.01 Nm			Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Absolute difference of maximum throttle area and its redundant cacluation is greater than a threshold	15 mm ²			Up/down timer 228 ms continuous, 0.5 down time multiplier	
			Absolute difference of Desired TIAP and its redundant cacluation is greater than a threshold	5.00 kPa			Up/down timer 475 ms continuous, 0.5 down time multiplier	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Low- Bank 1	P2088	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.	Short to ground: ≤ 0.5 Ω to a voltage source within the Vehicle Ground Voltage Range relative to PWRGND	System supply voltage is within limits. Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	60 failures out of 70 samples250 ms / sample, continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit High – Bank 1	P2089	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply voltage is within limits. Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	60 failures out of 70 samples 250 ms / sample, continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Low – Bank 1	P2090	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.	Short to ground: ≤ 0.5 Ω to a voltage source within the Vehicle Ground Voltage Range relative to PWRGND	System supply voltage is within limits. Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	60 failures out of 70 samples 250 ms / sample, continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit High – Bank 1	P2091	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply voltage is within limits. Output driver is commanded on, Ignition switch is in crank or run position	> 11.00 Volts	60 failures out of 70 samples 250 ms / sample, continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Low Limit Bank 1 (Too Rich)	P2096	Determines if the post catalyst O2 sensor based fuel control system has utilized all or most of its low limit authority, indicating a rich emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too rich, the post catalyst O2 integral offset control is decreased. This results in lean bias fuel control in an attempt to correct the rich condition. A perfectly balanced control system (no rich or lean bias required) is represented by an integral offset value of "0" and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean). An integral offset value < 0 is indicative of the control system reacting to a rich post catalyst O2 sensor. If the failure is such that the control system utilizes all or most of its available authority, then P2096 will set.	Rich Fail counter High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18% for >= 5.0 seconds. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14% for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.	>= 250 counts per 300 sample counts Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration Ambient Air Pressure Engine AirFlow Intake Manifold Pressure Induction Air Temperature Start-up Coolant Temp. PTO Intrusive diag. fuel control Long Term Secondary Fuel Trim Enabled (see "Long Term Secondary Fuel Trim Enable Criteria" in Supporting Tables) High Vapor Conditions No Fault Active for:	No No Yes Yes Yes >= 70 kPa >= 0.0 g/s <= 10,000.0 >= 0 kPa <= 200 >= -20 deg. C <= 50 >= -20 deg. C Not Active Not Active Not Present AmbientAirDefault AIR_System FA Ethanol Composition Sensor FA ECT_Sensor_FA EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorFA CamSensorAnyLocationFA EvapEmissionSystem_FA EvapFlowDuringNonPurge_FA FuelTankPressureSnrCkt_FA	Frequency: Continuous Monitoring in 100ms loop. Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EvapPurgeSolenoidCircuit _FA EvapSmallLeak_FA EvapVentSolenoidCircuit_ FA FuelInjectorCircuit_FA MAF_SensorFA MAF_SensorTFTKO MAP_SensorFA MAP_EngineVacuumStat us EngineMisfireDetected_F A A/F Imbalance Bank1 O2S_Bank_1_Sensor_1_ FA O2S_Bank_1_Sensor_2_ FA The above general enable conditions must be true for: Minimum accumulated counts in each cell required before counters will increment for that cell: Deceleration 0 Idle 0 Cruise 0 Light Acceleration 400 Heavy Acceleration 400 (Note: A value in any of the above operating "cells" that is an order of magnitude (or more) higher than other cells is an indication that the diagnostic is not capable of diagnosing in that cell). For the cells identified as	> 5.0 seconds	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>enabled (i.e. those containing a "Yes" at the beginning of the Enable Conditions column), the fail counter will increment if the sample counter increments</p> <p>AND</p> <p>Post oxygen sensor control integral offset (in mV) is</p> <p>Deceleration Idle Cruise Light Acceleration Heavy Acceleration</p> <p>AND</p> <p>Post O2 Voltage is</p> <p>Deceleration Idle Cruise Light Acceleration Heavy Acceleration</p> <p>(Note: A value in any of the above operating "cells" that is greater than 900mV is an indication that the diagnostic is not capable of diagnosing in that cell).</p>	<p><=</p> <p>N/A (control min.= 0) N/A (control min.= 0) -150 (control min.= -150) -150 (control min.= -150) -150 (control min.= -150)</p> <p>></p> <p>765 mV 765 mV 765 mV 775 mV 775 mV</p>		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System High Limit Bank 1 (Too Lean)	P2097	Determines if the post catalyst O2 sensor based fuel control system has utilized all or most of its high limit authority, indicating a lean emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too lean, the post catalyst O2 integral offset control is increased. This results in rich bias fuel control in an attempt to correct the lean condition. A perfectly balanced control system (no rich or lean bias required) is represented by an integral offset value of "0" and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean). An integral offset value > 0 is indicative of the control system reacting to a lean post catalyst O2 sensor. If the failure is such that the control system utilizes all or most of its available authority, then P2097 will set.	Lean Fail counter High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18% for >= 5.0 seconds. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14% for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.	>= 250 counts per 300 sample counts Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	Same as P2096 except for the following: For the cells identified as enabled (i.e. those containing a "Yes" at the beginning of the Enable Conditions for P2096), the fail counter will increment if the sample counter increments AND Post oxygen sensor control integral offset (in mV) is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Heavy Acceleration (Note: A value in any of the above operating "cells" that is less than 100mV is an indication that the diagnostic is not capable of diagnosing in that cell).	>= N/A (control max.= 0) N/A (control max.= 0) 150 (control max.= 150) 150 (control max.= 150) 150 (control max.= 150) < 600 mV 600 mV 600 mV 550 mV 550 mV	Frequency: Continuous Monitoring in 100ms loop. Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Throttle Actuator Position Performance	P2101	1) Detect a throttle positioning error2) Throttle control is driving the throttle in the incorrect direction3) Throttle control exceeds the reduced power limit	Difference between measured throttle position and modeled throttle position >	10.00 percent	TPS minimum learn is not active and Throttle is being Controlled and (Engine Running or Ignition Voltage > or Ignition Voltage >)	Run/Crank voltage > 6.41 Ignition voltage failure is false (P1682)	15 counts; 12.5 ms/count in the primary processor	Type A, 1 Trips
			OR					
			Difference between modeled throttle position and measured throttle position >	10.00 percent	Ignition voltage failure is false (P1682)	TPS minimum learn is not active and Throttle is being Controlled AND ((Engine Running AND Ignition Voltage > 5.50) OR Ignition Voltage > 11.00)		
			Throttle Position >	37.60 percent		Powertrain Relay voltage > 6.41 TPS minimum learn is active	11 counts; 12.5 ms/count in the primary processor	
			Throttle Position >	50.00 percent		Powertrain Relay voltage > 6.41 Reduced Power is True	11 counts; 12.5 ms/count in the primary processor	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Lo	P2122	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage <	0.4625		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Hi	P2123	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage >	4.7500		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Lo	P2127	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage <	0.3250		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P0697)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Hi	P2128	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage >	2.6000		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P0697)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position (TP) Sensor 1-2 Correlation	P2135	Detects a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor	Difference between TPS1 displaced and TPS2 displaced >	7.022 % offset at min. throttle position with a linear threshold to 9.664 % at max. throttle position		Run/Crank voltage > 6.41 No TPS sensor faults (P0122, P0123, P0222, P0223) No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts or 58 counts continuous; 3.125 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min TPS1) and (normalized min TPS2) >	5.000 % Vref		Run/Crank voltage > 6.41 No TPS sensor faults (P0122, P0123, P0222, P0223) No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts or 58 counts continuous; 3.125 ms/count in the main processor	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1-2 Correlation	P2138	Detects a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor	Difference between APP1 displaced and APP2 displaced >	5.000 % offset at min. pedal position with a linear threshold to 10.001 % at max. pedal position		Run/Crank voltage > 6.41 No APP sensor faults (P2122, P2123,P2127, P2128) No 5V reference errors or faultst for # 3 & # 4 5V reference circuits (P06A3, P0697)	19 / 39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min APP1) and (normalized min APP2) >	5.000 % Vref		Run/Crank voltage > 6.41 No APP sensor faults (P2122, P2123,P2127, P2128) No 5V reference errors or faultst for # 3 & # 4 5V reference circuits (P06A3, P0697)	19 / 39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Minimum Throttle Position Not Learned	P2176	TP sensors were not in the minimum learn window after multiple attempts to learn the minimum.	<p>During TPS min learn on the Main processor, TPS Voltage ></p> <p>AND</p> <p>Number of learn attempts ></p>	<p>0.9550</p> <p>10 counts</p>		<p>Run/Crank voltage > 6.41</p> <p>TPS minimum learn is active</p>	2.0 secs	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling System Performance	P2181	This DTC detects thermostat malfunction (i.e. stuck open)	<p>This diagnostic can be calibrated to fail in <u>one</u> of two methods based on the following calibration. This application has been calibrated as a Type 0 .</p> <p><u>Type 0 - Airflow Method:</u> Engine Coolant Temp (ECT) is \leq commanded temperature minus 11 Deg C and normalized ratio is \leq than 0.65 . When above is present for more than 0 seconds, fail counts start. == Ratio Definition:=== Current temp difference between ECT and RCT minus PwrUp difference divided by total airgrams. Note: Minimum total airgrams is 500.0 grams.</p> <p><u>Type 1 - Energy Method:</u> Engine Coolant Temp (ECT) is \leq commanded temperature minus 11 Deg C and normalized ratio is \leq than 0.01 . When above is present for more than 0 seconds, fail counts start. == Ratio Definition:=== Current temp difference between ECT and RCT minus PwrUp difference divided by predicted energy.</p>		<p>No Active DTC's</p> <p>Engine not run time</p> <p>Engine run time</p> <p>Fuel Condition ECT at Power Up IAT min T-Stat Heater duty cycle commanded</p> <p>Type 0: Airflow range to accumulate</p> <p>Type 1: Minimum energy to enable</p>	<p>MAF_SensorFA IAT_SensorFA THMR_RCT_Sensor_Ckt_FA THMR_ECT_Sensor_Ckt_FA</p> <p>$\geq 7,200$ seconds</p> <p>$120 \leq \text{Time} \leq 1,400$ seconds</p> <p>Ethanol $\leq 100\%$ $-20.0 \leq \text{ECT} \leq 45.0$ °C -7 °C $\leq \text{IAT} \leq 60$ °C.</p> <p>$\leq 10\%$</p> <p>$11.0 \leq \text{Airflow} \leq 100.0$ gps</p> <p>10.0 kJ</p>	<p>225 failures out of 280 samples</p> <p>1 sec/ sample</p> <p>Once per ignition key cycle</p>	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 1 / 2 Correlation	P2199	Detects a difference between the IAT and IAT2 sensors	ABS (IAT - IAT2)	> 55.0 deg C	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Bank 1 Air-Fuel Ratio Imbalance	P219A	This monitor determines if a cylinder-to-cylinder air-fuel ratio imbalance is present on bank 1.	<p>Filtered Ratio ></p> <p>Note: The input to this metric is the pre catalyst oxygen sensor voltage. This voltage is used to generate a Variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to the air-fuel ratio imbalance (variance is higher with an imbalance than without). Multiple samples are collected in making a decision.</p> <p>The observed Variance is dependant on engine speed and load and so each result is normalized for speed and load by comparing it to a known "good system" result for that speed and load, and generating a Ratio metric.</p> <p>The Ratio metric is calculated by selecting the appropriate threshold calibration from a 17x17 table (Supporting Table "Variance Threshold Bank1") and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table</p>	0.75	<p>If the diagnostic has reported a failure on the prior trip, the Filtered Ratio must fall below 0.80 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing when the Filtered Ratio remains near the initial failure threshold of 0.75 .</p>	<p>System Voltage</p> <p>Fuel Level</p> <p>Engine Coolant Temperature</p> <p>Cumulative engine run time</p> <p>Diagnostic enabled at Idle (regardless of other operating conditions)</p> <p>Engine speed range</p> <p>Engine speed delta during a short term sample period</p> <p>Mass Airflow (MAF) range</p> <p>Cumulative delta MAF during a short term sample period</p> <p>Filtered MAF delta between samples Note: first order lag filter coefficient applied to MAF = 0.100</p> <p>Air Per Cylinder (APC)</p> <p>APC delta during short term sample period</p> <p>Filtered APC delta between samples</p>	<p>no lower than 11.0 Volts for more than 0.2 seconds</p> <p>> 10.0 percent AND no fuel level sensor fault</p> <p>> -20 degrees C</p> <p>> 130.0 seconds</p> <p>No</p> <p>900 to 6,000 RPM</p> <p>< 150 RPM</p> <p>12 to 500 g/s</p> <p>< 2 g/s</p> <p>< 0.25 g/s</p> <p>130 to 800 mg/cylinder</p> <p>< 60 mg/cylinder</p> <p>< 0.30 percent</p>	<p>Minimum of 1 test per trip, up to 12 tests per trip during RSR or FIR.</p> <p>The front O2 sensor voltage is sampled once per cylinder event. Therefore, the time required to complete a single test (when all enable conditions are met) decreases as engine speed increases. For example, 4.50 seconds of data is required at 1000 rpm while double this time is required at 500 rpm and half this time is required at 2000 rpm. This data is collected only when enable conditions are met, and as such significantly more operating time is required than is indicated above. Generally, a report will be</p>	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>(Supporting Table "Normalizer Bank1"). This quotient is then multiplied by a quality factor calibration from a 17 x 17 table (Supporting Table "Quality Factor Bank1"). This result is referred to as the Ratio. Note that the quality factor ranges between 0 and 1 and represents robustness to false diagnosis in the current operating region. Regions with low quality factors are not used.</p> <p>Finally, a EWMA filter is applied to the Ratio metric to generate the Filtered Ratio malfunction criteria metric. Generally, a normal system will result in a negative Filtered Ratio while a failing system will result in a positive Filtered Ratio.</p> <p>The range of the Filtered Ratio metric is application specific since both the emissions sensitivity and relationship between imbalance and the Variance metric are application specific.</p> <p>Some applications may need to command a unique cam phaser value before performing the</p>		<p>Note: first order lag filter coefficient applied to APC = 0.100</p> <p>Spark Advance</p> <p>Throttle Area (percent of max)</p> <p>Intake Cam Phaser Angle</p> <p>Exhaust Cam Phaser Angle</p> <p>Quality Factor (QF) QF calibrations are located in a 17x17 lookup table versus engine speed and load (Supporting Table "Quality Factor Bank1"). QF values less than "1" indicate that we don't have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data.</p> <p>Fuel Control Status Closed Loop and Long Term FT Enabled for:</p> <p>AIR pump not on CASE learn not active EGR - no device control, no intrusive diagnostics EVAP - no device control, no intrusive diagnostics Engine OverSpeed</p>	<p>5 to 55 degrees</p> <p>3 to 200 percent</p> <p>0 to 25 degrees</p> <p>0 to 25 degrees</p> <p>>= 0.99</p> <p>>= 1.2 seconds (Please see "Closed Loop Enable Criteria" and "Long Term FT Enable Criteria" in Supporting Tables)</p>	<p>made within 5 minutes of operation.</p> <p>For RSR or FIR, 12 tests must complete before the diagnostic can report.</p>	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>above calculations since cam phasing has been shown to have an impact on overall signal quality. This application Does Not Use this feature.</p>		<p>Protection Not Active Idle speed control normal PTO Not Active Injector base pulse width above min limit O2 Learned htr resistance</p> <p>Rapid Step Response (RSR): RSR will trigger if the Ratio result from the last test is AND it exceeds the last Filtered ratio by</p> <p>Once triggered, the filtered ratio is reset to:</p> <p>Fast Initial Response (FIR): FIR will trigger when an NVM reset or code clear occurs. Once triggered, the filtered ratio is reset to:</p> <p>No Fault Active for:</p>	<p>= Valid (the O2 heater resistance has learned since NVM reset)</p> <p>>= 1.50</p> <p>>= 2.00</p> <p>0.00</p> <p>0.00</p> <p>EngineMisfireDetected_FA MAP_SensorFA MAF_SensorFA ECT_Sensor_FA TPS_ThrottleAuthorityDefaulted FuelInjectorCircuit_FA AIR System FA EvapExcessPurgePsbl_FA CamSensorAnyLocationFA</p>		

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Performance (turbocharged)	P2227	Compares baro sensor to the calculated baro estimate (part throttle calculation or unthrottled MAP)	Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 15.0 kPa ≤ 0.06 miles	No Active DTCs:	AmbPresSnsrCktFA ECT_Sensor_Ckt_FA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips
			OR Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 20.0 kPa > 0.06 miles				
			Barometric Pressure OR Barometric Pressure OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	< 50.0 kPa > 115.0 kPa > 10.0 kPa ≤ 10.0 kPa > 10.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating No Active DTCs: No Pending DTCs:	> 10.0 seconds	4 failures out of 5 samples 1 sample every 12.5 msec	
						EngineModeNotRunTimer Error MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (boosted applications)	P2228	Detects a continuous short to low or open in either the signal circuit or the BARO sensor.	BARO Voltage	< 40.0 % of 5 Volt Range (2.0 Volts = 50.9 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (boosted applications)	P2229	Detects an open sensor ground or continuous short to high in either the signal circuit or the BARO sensor.	BARO Voltage	> 90.0 % of 5 Volt Range (4.5 Volts = 115.0 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Intermittent	P2230	Detects a noisy or erratic barometric pressure input	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current BARO reading - BARO reading from 12.5 milliseconds previous)	> 100 kPa 80 consecutive BARO samples			4 failures out of 5 samples Each sample takes 1.00 seconds	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve - Mechanical Turbocharger with wastegate. Not supercharger with mechanical compressor	P2261	Detect Stuck Closed Bypass Valve	Accumulation time is high pass filtered. Accumulated air mass flow or boost pressure larger then thresholds	0.25 Second < Accumulation time < 0.85 Second	Diagnostic Enabled Engine Speed Pressure ratio over the compressor Relative Boost Pressure (Boost - Ambient) and Negative Transient in Manifold Air Pressure	1 >= 1,800 rpm >KtBSTD_r_ExcsvBstPre sLim Enable condition kept true for 1.5 seconds extra See Tables in Supporting Tables Sheet IF (RelativeBoost < 3.0 kPa OR DerivativeMAP > 50.00 kPa/s) [FALSE] Else (RelativeBoost >= 40.0 kPa AND DerivativeMAP <= -150.00 kPa) [TRUE] > 6.0 percentEnable condition kept true for 0.70 seconds extra TC_BoostPresSnrFA MAF_SensorFABSTR_b_ TurboBypassCktFA	3 Failed tests out of 3 Tests 1 sample every 25ms	Type B, 2 Trips
			Filter Frequency	12.00 Hz				
			Filtered Air Mass Flow	> 50.000 g/s				
			Filtered Boost Pressure	> 40.00 kPa				
					Bypass Valve Commanded Open			
					No Active DTCs:			

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Post fuel cell (Decel) Crankshaft Torque EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State ===== All of the above met for at least 0.0 seconds, and then check the following Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) ===== All of the above met for at least 1.5 seconds, and then the Force Cat Rich intrusive stage is requested. ===== During Stuck Lean test the following must stay TRUE or the test will abort: 0.95 ≤ Commanded Fuel EQR ≤ 1.06	= enabled < 100.0 Nm = not active = not active ≥ 60.0 sec 550 ≤ °C ≤ 900 = DFCE possible ===== ===== 1,500 ≤ RPM ≤ 3,200 1,450 ≤ RPM ≤ 3,300 28.0 ≤ MPH ≤ 80.8 24.9 ≤ MPH ≤ 83.9		

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Rich Bank 1 Sensor 2	P2271	This DTC determines if the post catalyst O2 sensor is stuck in a normal rich voltage range and thereby can no longer be used for post oxygen sensor fuel control or for catalyst monitoring. The diagnostic is an intrusive test which requests the DFCO mode to achieve the required lean threshold.	Post O2 sensor signal AND The Accumulated mass air flow monitored during the Stuck Rich Voltage Test	> 100 mvolts > 35 grams	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage ICAT MAT Burnoff delay Green O2S Condition Low Fuel Condition Diag Engine Speed Engine Airflow Vehicle Speed Closed loop integral Closed Loop Active Evap Ethanol	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013A, P013B, P013E, P013F or P2270 10.0 < Volts < 32.0 = Not Valid = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. = False 1,500 ≤ RPM ≤ 3,200 3 ≤ gps ≤ 10 28.0 ≤ MPH ≤ 80.8 0.92 ≤ C/L Int ≤ 1.08 = TRUE not in control of purge not in estimate mode	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Take Off EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State DTC's Passed ===== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	= not active = not active = not active ≥ 60.0 sec 550 ≤ °C ≤ 900 DFCO possible = P2270 (and P2272 if applicable) = P013E (and P014A if applicable) = P013A (and P013C if applicable)		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT LOW - for 3 DTC implementati on only	P2300	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT High - for 3 DTC implementati on only	P2301	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT Low - for 3 DTC implementati on only	P2303	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT High - for 3 DTC implementati on only	P2304	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT Low - for 3 DTC implementati on only	P2306	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT High - for 3 DTC implementati on only	P2307	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT Low - for 3 DTC implementati on only	P2309	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT High - for 3 DTC implementati on only	P2310	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Torque Request Circuit	P2544	Determines if the torque request from the TCM is valid	Protect error - Serial Communication message - (\$199 - PTEI3) OR Rolling count error - Serial Communication message (\$199 - PPEI3) rolling count value OR Range Error - Serial Communication message - (\$199 - PTEI3) TCM Requested Torque Increase OR Multi-transition error - Trans torque intervention type request change	Message <> two's complement of message Message <> previous message rolling count value + one > 450 Nm Requested torque intervention type toggles from not increasing request to increasing request	Diagnostic enabled/ disabled Power Mode Ignition Voltage Engine Running Run/Crank Active No Serial communication loss to TCM (U0101)	Enabled = Run > 6.41 volts = True > 0.50 Sec No loss of communication	>= 10 Protect errors during key cycle. Performed on every received message >= 6 Rolling count errors out of 10 samples. Performed on every received message >= 6 range errors out of 10 samples. Performed on every received message >= 3 multi-transitions out of 5 samples. Performed every 200 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Off Timer Performance	P262B	<p>This DTC determines if the hardware timer does not initialize or count properly. There are two tests to ensure proper functioning of the timer: Count Up Test (CUT) and Range Test (RaTe).</p> <p>Count Up Test (CUT): Verifies that the HWIO timer is counting up with the proper increment.</p> <p>Range Test (RaTe): When the run/crank is not active both the hardware and mirror timers are started. The timers are compared when module shutdown is initiated or run/crank becomes active.</p>	<p>Count Up Test: Time difference between the current read and the previous read of the timer</p> <p>Range Test: The variation of the HWIO timer and mirror timer is</p>	<p>> 1.50 seconds</p> <p>> 24.87%.</p>			<p>Count Up Test: 4 failures out of 20 samples</p> <p>1 sec / sample</p> <p>Continuous while run/crank is not active and until controller shutdown is initiated.</p> <p>Range Test: Once per trip when controller shutdown is initiated or run/crank becomes active.</p>	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Low	P263A	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11 volts	20 failures out of 25 samples 50 ms / sample	Type B, No MIL NO MIL Note: In certain controllers P0650 may also set (MIL Control Open Circuit)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) High	P263B	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11 volts	20 failures out of 25 samples 50 ms / sample	Type B, No MIL NO MIL

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Output Speed Sensor (TOSS)	P0502	No activity in the TOSS circuit	TOSS Raw Speed	≤ 60 RPM	Engine Torque Minimum Throttle opening Engine Speed Ignition voltage PTO EngineTorquereInaccurate	90.0 ≤ N-M ≤ 8,191.8 ≥ 15.0 % 1,500 ≤ RPM ≤ 6,500 9.0 ≤ Volts ≤ 16.00 not active KeETQC_b_MinTransRemedial = TRUE: MSFR_b_EngMisfDtctd_FA, MAFR_b_MAF_SnsrTFTKO, MAPR_b_MAP_SnsrTFTKO KeETQC_b_MinTransRemedial = FALSE: FULR_b_FuellnjCkt_TFTKO, MAFR_b_MAF_SnsrTFTKO, XOYR_b_SecurityFit,	≥ 4.5 sec	Type B, 2 Trips
					P0503	Not failed this key cycle		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Output Speed Sensor (TOSS)	P0503	TOSS Signal Intermittent	Loop-to-Loop change in TOSS	≥ 350 RPM	Raw Output Speed Output Speed change Time since transfer case range change Ignition voltage Engine Speed Vehicle Speed PTO	> 200 RPM for ≥ 2.0 sec ≤ 175 RPM for ≥ 2.0 sec ≥ 3.0 sec 9.0 ≤ Volts ≤ 16.00 200 ≤ RPM ≤ 7,500 for ≥ 5.0 seconds ≤ 250.00 MPH for ≥ 5.0 sec not active	≥ 3.3 sec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control On Switch Circuit	P0565		Cruise Control On switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	MIL Type C, No MIL Special Type C

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi- function Circuit Low Voltage	P0580	detects short to ground failure for cruise multi-function switch circuit	Cruise Control analog circuit voltage must be in an "Open Short To Ground" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	MIL: Type C, No MIL Special Type C

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi-function Circuit High Voltage	P0581		Cruise Control analog circuit voltage must be in an "Short To Power" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	MIL: Type C, No MIL Special Type C

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Range / Performance	P0806	Detects if Clutch Pedal Position Sensor is Stuck in a range indicative of a vehicle NOT in gear, when the vehicle is determined to be in gear. Gear determination is made by verifying that the ratio of engine RPM versus Transmission Output Speed (N/TOS) represents a valid gear.	Filtered Clutch Pedal Position Error when the vehicle is determined to be in gear	> 4 %	N/TOS Ratio: Transfer Case: Vehicle speed: Engine Torque: Clutch Pedal Position: OR No Active DTCs:	Must match actual gear (i.e. vehicle in gear) Not in 4WD Low range > 1.2 MPH > EngTorqueThreshold (see Supporting Tables) < ResidualErrEnableLow (see Supporting Tables) > ResidualErrEnableHigh (see Supporting Tables) ClutchPstnSnsrCktHi FA ClutchPstnSnsrCktLo FA CrankSensor_FA Transmission Output Shaft Angular Velocity Validity VehicleSpeedSensor_FA	25 ms loop Continuous	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Low	P0807	Detects Continuous Circuit Out-of-Range Low or Open	Clutch Position Sensor Circuit for	< 4 % of Vref 200 counts out of 250 samples	Engine Not Cranking System Voltage No active DTCs:	> 10.0 Volts	25 ms loop Continuous	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit High	P0808	Detects Continuous Circuit Out-of-Range High	Clutch Position Sensor Circuit for	> 96 % of Vref 200 counts out of 250 samples	Engine Not Cranking System Voltage No active DTCs:	> 10.0 Volts	25 ms loop Continuous	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Not Learned	P080A	Detects Invalid Clutch Pedal Fully Applied Learn Position values	Fully Applied Learn Position OR	< 12.0 % > 35.0 %	OBD Manufacturer's Enable Counter	= 0	250 ms loop Continuous	Type A, 1 Trips

14 OBDG02 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Performance (For use on vehicles with mechanical transfer pump dual fuel tanks)	P0461	This DTC will detect a fuel sender stuck in range in the primary fuel tank.	<p>***** Fuel Level in Primary and Secondary Tanks Remain in an Unreadable Range too Long *****</p> <p>This subtest is not used</p> <p>If fuel volume in primary tank is and fuel volume in secondary tank and remains in this condition for</p> <p>OR ***** After Refuel Event *****</p> <p>If the secondary fuel volume changes by 1,024.0 liters from engine "off" to engine "on" the primary volume should change by 3.0 liters.</p> <p>OR ***** Distance Traveled without a Primary Fuel Level Change *****</p> <p>Delta fuel volume change over an accumulated 203 miles.</p>	<p>≥ 1,024.0 liters</p> <p>< 0.8 liters</p> <p>56 miles.</p> <p>< 3 liters</p>	<p>Engine Running</p> <p>No active DTCs:</p> <p>The shutdown primary tank volume + 3.0 liters must be</p>	<p>VehicleSpeedSensor_FA</p> <p>< 1,024.0 liters</p>	250 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Performance (For use on vehicles with mechanical transfer pump dual fuel tanks)	P2066	This DTC will detect a fuel sender stuck in range in the secondary fuel tank.	<p>***** Fuel Level in Primary and Secondary Tanks Remain in an Unreadable Range too Long *****</p> <p>This subtest is not used</p> <p>If fuel volume in primary tank is and fuel volume in secondary tank is and remains in this condition for</p> <p>OR ***** Fuel Level is in a Readable Range for both Primary and Secondary Tanks too Long *****</p> <p>This subtest is not used</p> <p>Volume in primary tank is and volume in secondary tank is and remains in this condition for</p> <p>OR ***** Distance Traveled without a Secondary Fuel Level Change *****</p> <p>If the vehicle is driven a</p>	<p>≥ 1,024.0 liters</p> <p>< 0.8 liters</p> <p>56 miles</p> <p>< 1,024 liters</p> <p>> 1 liters</p> <p>3,630 seconds</p>	<p>Engine Running</p> <p>No active DTCs:</p>	VehicleSpeedSensor_FA	250 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			distance of 174 miles without the secondary fuel level changing by 3 liters, then the sender must be stuck.					

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Circuit Low Voltage (For use on vehicles with dual fuel tanks)	P2067	This DTC will detect a fuel sender stuck out of range low in the secondary fuel tank.	Fuel level Sender % of 5V range	< 10%			100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Circuit High Voltage (For use on vehicles with dual fuel tanks)	P2068	This DTC will detect a fuel sender stuck out of range low in the secondary fuel tank.	Fuel level Sender % of 5V range	> 60 %			100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0096	Detects an IAT2 sensor that has stuck in range by comparing to IAT and engine coolant temperature at startup	ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up ECT – Power Up IAT2) >= ABS(Power Up ECT – Power Up IAT)	> 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Intermittent In-Range	P0099	Detects a noisy or erratic IAT 2 signal circuit or IAT 2 sensor	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current IAT 2 reading - IAT 2 reading from 100 milliseconds previous)	> 125.00 DegC 10 consecutive IAT 2 samples	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Intermittent	P00F6	Detects a noisy or erratic humidity sensor input	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current Humidity reading - Humidity reading from 100 milliseconds previous)	> 80 % 10 consecutive Humidity samples	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	4 failures out of 5 samples Each sample takes 1.00 seconds	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (naturally aspirated)	P0101	Determines if the MAF sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 500 kPa*(g/s) > 15 grams/sec > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 7,000 RPM >= -7 Deg C <= 125 Deg C >= -20 Deg C <= 125 Deg C >= 0.25 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM See Residual Weight Factor tables. No Active DTCs: MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA No Pending DTCs: EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (naturally aspirated)	P0106	Determines if the MAP sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 500 kPa*(g/s)	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 7,000 RPM >= -7 Deg C <= 125 Deg C >= -20 Deg C <= 125 Deg C >= 0.25 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM See Residual Weight Factor tables.	Continuous Calculations are performed every 12.5 msec	Type B, 2 Trips
			Manifold Pressure OR	< 50.0 kPa	Time between current ignition cycle and the last	4 failures out of 5 samples		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Manifold Pressure	> 115.0 kPa	time the engine was running Engine is not rotating No Active DTCs: No Pending DTCs:	> 6.0 seconds EngineModeNotRunTimer Error MAP_SensorFA AAP_SnsrFA MAP_SensorCircuitFP AAP_SnsrCktFP	1 sample every 12.5 msec	

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0111	Detects an IAT sensor that has stuck in range by comparing to IAT2 and engine coolant temperature at startup	ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up ECT – Power Up IAT) > ABS(Power Up ECT – Power Up IAT2)	> 25 deg C	Time between current ignition cycle and the last time the engine was running Powertrain Relay Voltage for a time No Active DTCs:	> 28,800 seconds >= 11.00 Volts >= 0.9 seconds PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (naturally aspirated)	P0121	Determines if the Throttle Position Sensor input is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	> 500 kPa*(g/s) > 15 grams/sec <= 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 7,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 125 Deg C >= 0.25 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est See Residual Weight Factor tables. No Active DTCs: MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA No Pending DTCs: EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Incorrect Airflow	P0411	Detects an insufficient flow condition. This test is run during Phase 1 (AIR pump commanded On, Valve commanded Open). Leaks downstream of the valve are detected via an evaluation of average pressure error and average "String Length"(SL) – a term that represents the absolute pressure delta accumulated every 6.25ms, then averaged over the duration of the test. Low SL values are indicative of downstream leaks or blockages.	Average Pressure Error or OR the following String Length (SL) Test: Average Pressure Error or and the Average String Length NOTE: Average Pressure Error is the average difference between the predicted pressure and the measured pressure	> 10.0 kPa < -4.9 kPa > 1.0 kPa < -1.0 kPa < SL Threshold Bank 1 Table	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not SL Stability time SL RPM range No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec > 5.0 seconds < 6,000 RPM > 6,500 AIRSystemPressureSens or FA AIRValveControlCircuit FA AIRPumpControlCircuit FA MAF_SensorFA AmbientAirDefault_NA IAT_SensorFA ECT_Sensor_FA EngineMisfireDetected_F A CatalystSysEfficiencyLoB 1_FA CatalystSysEfficiencyLoB 2_FA ControllerProcessorPerf_ FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA	Phase 1 Conditional test weight > 7.0 seconds Total 'String Length' accumulation time > 10.0 sec Frequency: Once per trip when AIR pump is commanded On Conditional test weight is calculated by multiplying the following Factors: Phase 1 Baro Test Weight Factor, Phase 1 MAF Test Weight Factor, Phase 1 System Volt Test Weight Factor, Phase 1 Ambient Temp Test Weight Factor (see Supporting Tables)	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Solenoid Control Circuit Open - For 3 DTC implementati on only	P0412	Diagnoses the Secondary AIR Solenoid Control Low Side Driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: >= 200K Ohms impedance between signal and controller ground	Powertrain Relay Voltage	>= 11.00 volts	100 failures out of 120 samples 250ms / sample	Type B, 2 Trips Note: In certain controlle rs P041F may also set (Second ary AIR solenoid control circuit low voltage)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Pump Control Circuit Open- For 3 DTC implementati on only	P0418	Diagnoses the Secondary AIR Pump Control Low Side Driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: >= 200K Ohms impedance between signal and controller ground	Powertrain relay Voltage	>= 11.00 volts	100 failures out of 120 samples 250ms / sample	Type B, 2 Trips Note: In certain controlle rs P2257 may also set (Second ary AIR Pump Control Circuit Low Voltage)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Solenoid Control Circuit Low Voltage	P041F	Diagnoses the Secondary AIR Solenoid Control Low Side Driver circuit for circuit faults	Voltage low during driver off state (indicates short- to-ground)	Short to ground: <= 0.5 Ohms impedance between signal and controller ground	Powertrain relay Voltage	>= 11.00 volts	100 failures out of 120 samples 250ms / sample	Type B, 2 Trips Note: In certain controlle rs P0412 may also set (Second ary AIR solenoid control circuit open)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Solenoid Control Circuit High Voltage	P044F	Diagnoses the Secondary AIR Solenoid Control Low Side Driver circuit for circuit faults	Voltage high during driver on state (indicates short- to-power)	Short to power: <= 0.5 Ohms impedance between signal and controller power	Powertrain relay Voltage	>= 11.00 volts	100 failures out of 120 samples 250ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Bank 1	P0660	Diagnoses the Intake Manifold Tuning (IMT) Valve low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: >= 200K Ohms impedance between signal and controller ground	Powertrain Relay Voltage Engine Speed	>= 11.00 Volts >= 400 RPM	32 failures out of 40 samples 1 sample every 12.5 msec	Type B, 2 Trips Note in certain controlle rs P0661 may also set (Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Low Voltage Bank 1)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Low Voltage Bank 1	P0661	Diagnoses the Intake Manifold Tuning (IMT) Valve low side driver circuit for circuit faults	Voltage low during driver off state (indicates short- to-ground or open circuit)	Short to ground: <= 0.5 Ohms impedance between signal and controller ground Open Circuit: >= 200K Ohms impedance between signal and controller ground	Powertrain Relay Voltage Engine Speed	>= 11.00 Volts >= 400 RPM	32 failures out of 40 samples 1 sample every 12.5 msec	Type B, 2 Trips Note in certain controlle rs P0660 may also set (Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Bank 1)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit High Voltage Bank 1	P0662	Diagnoses the Intake Manifold Tuning (IMT) Valve low side driver circuit for circuit faults	Voltage low during driver on state (indicates short- to-power)	Short to power: <= 0.5 Ohms impedance between signal and controller power	Powertrain Relay Voltage Engine Speed	>= 11.00 Volts >= 400 RPM	32 failures out of 40 samples 1 sample every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (naturally aspirated)	P1101	Determines if there are multiple air induction problems affecting airflow and/or manifold pressure.	Filtered Throttle Model Error AND (ABS(Measured Flow – Modeled Air Flow) Filtered OR ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 500 kPa*(g/s) > 15 grams/sec > 25.0 kPa) > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 7,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 125 Deg C >= 0.25 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor Based on MAF Est MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM See Residual Weight Factor tables. MAP_SensorCircuitFA EGRValvePerformance_FA A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Pending DTCs:	IAT_SensorFA EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Stuck Open	P2070	Detects an Intake Manifold Tuning Valve that is stuck in the open position	Time after the close command without the Intake Manifold Tuning Valve reaching the closed position	>= 5.00 seconds	Intake Manifold Tuning Valve is commanded closed No Active DTCs:	P0660 P0661 P0662 P2077 P2078	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Stuck Closed	P2071	Detects an Intake Manifold Tuning Valve that is stuck in the closed position	Time after the open command without the Intake Manifold Tuning Valve reaching the open position	>= 5.00 seconds	Intake Manifold Tuning Valve is commanded closed No Active DTCs:	P0660 P0661 P0662 P2077 P2078	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Position Sensor/ Switch Circuit Range/ Performance	P2076	Detects an Intake Manifold Tuning Valve Actuator that has initiated its learn sequence for too long a period of time, or too many times per ignition cycle	Valve Position AND Valve Position for a time period OR Valve Position AND Valve Position for a time period for	>= 5.0 % <= 35.0 % >= 5.0 seconds >= 5.0 % <= 35.0 % >= 0.2 seconds >= 10 times in one ignition cycle	Powertrain Relay Voltage Powertrain Relay Voltage Engine Run Time	>= 11.00 Volts <= 999.00 Volts >= 1.0 seconds	Executes every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Position Sensor/ Switch Circuit Low	P2077	Detects a continuous open or short to low in the Intake Manifold Tuning Valve Position Sensor circuit	Valve Position	>= 95.0 %	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Position Sensor/ Switch Circuit High	P2078	Detects a continuous short to high in the Intake Manifold Tuning Valve Position Sensor circuit	Valve Position	<= 5.0 %	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Performance (naturally aspirated)	P2227	Compares baro sensor to the calculated baro estimate (part throttle calculation or unthrottled MAP)	Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 15.0 kPa <= 0.06 miles	No Active DTCs:	AmbPresSnsrCktFA ECT_Sensor_Ckt_FA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips
			OR Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 20.0 kPa > 0.06 miles				
			Barometric Pressure OR Barometric Pressure	< 50.0 kPa > 115.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating No Active DTCs:	> 6.0 seconds	4 failures out of 5 samples 1 sample every 12.5 msec	
					No Pending DTCs:	EngineModeNotRunTimer Error MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP		

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (non-boosted applications)	P2228	Detects a continuous short to low or open in either the signal circuit or the BARO sensor.	BARO Voltage	< 40.0 % of 5 Volt Range (2.0 Volts = 50.9 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (non-boosted applications)	P2229	Detects an open sensor ground or continuous short to high in either the signal circuit or the BARO sensor.	BARO Voltage	> 90.0 % of 5 Volt Range (4.5 Volts = 115.0 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Pump Control Circuit Low Voltage	P2257	Diagnoses the Secondary AIR Pump Control Low Side Driver circuit for circuit faults	Voltage low during driver off state (indicates short- to-ground)	Short to ground: <= 0.5 Ohms impedance between signal and controller ground	Powertrain relay Voltage	>= 11.00 volts	100 failures out of 120 samples 250ms / sample	Type B, 2 Trips Note: In certain controlle rs P0418 may also set (Second ary AIR Pump Control Circuit Open)

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Pump Control Circuit High Voltage	P2258	Diagnoses the Secondary AIR Pump Control Low Side Driver circuit for circuit faults	Voltage high during driver on state (indicates short- to-power)	Short to power: <= 0.5 Ohms impedance between signal and controller power	Powertrain relay Voltage	>= 11.00 volts	100 failures out of 120 samples 250ms / sample	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Bank 1	P2430	This DTC detects a stuck in range pressure sensor signal when the AIR pump is commanded on.	Average Pressure Error AND Signal Variation	< 0.50 kPa < 1.00 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRSysPressSnsrB1CktL oFA AIRSysPressSnsrB1CktHi FA ControllerProcessorPerf_ FA	Stuck in range cumulative time > 5.0 seconds Frequency: Once per trip when SAI pump is commanded On	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Performance Bank 1	P2431	This DTC detects a skewed pressure sensor signal via a comparison of the AIR pressure sensor signal and estimated BARO, as well as an evaluation of the quality of the comparison.	Difference between AIR pressure sensor and BARO (Pump Commanded Off) or OR Difference between AIR pressure sensor and BARO (Pump Commanded On)	> 15.0 kPa < -15.0 kPa > 50.0 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Transfer Case not in 4WD Low Run/crank active No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRSysPressSnsrB1CktLoFA AIRSysPressSnsrB1CktHiFA MAF_SensorFA EngineMisfireDetected_FA ControllerProcessorPerf_FA	Skewed sensor cumulative test weight > 30.0 seconds Continuous 6.25ms loop Skewed sensor cumulatative test weight is based on distance from the last Baro update. See Baro Skewed Sensor Weight Factor table.	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Low Voltage Bank 1	P2432	This DTC detects an out of range low AIR pressure sensor signal	AIR Pressure Sensor signal	< 6 % of 5Vref for 800 failures out of 1,000 samples	No active DTCs:	ControllerProcessorPerf_ FA	1,000 samples (6.25 ms per sample) Continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Hi Voltage Bank 1	P2433	This DTC detects an out of range high AIR pressure sensor signal	AIR Pressure Sensor signal	> 94 % of 5Vref for 800 failures out of 1,000 samples	No active DTCs:	ControllerProcessorPerf_ FA	1,000 samples (6.25 ms per sample) Continuous	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Shut-off Valve Stuck Open	P2440	This DTC detects if the AIR system control valve is stuck open. This test is run during Phase 2 (Pump commanded On, valve commanded closed)	Average Pressure Error or	< Bank 1 Valve Pressure Error table > 32 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Stability Time AIR diagnostic Phase 1 passed No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec > 0.5 seconds AIRSystemPressureSens or FA AIRValveControlCircuit FA AIRPumpControlCircuit FA MAF_SensorFAAmbientAirDefault_NA IAT_SensorFAECT_Sensor_FA EngineMisfireDetected_FA CatalystSysEfficiencyLoB1_FA CatalystSysEfficiencyLoB2_FA ControllerProcessorPerf_FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA	Phase 2 Conditional test weight > 1.5 sec Frequency: Once per trip when AIR pump commanded On Conditional test weight is calculated by multiplying the following Factors: Phase 2 Baro Test Weight Factor, Phase 2 MAF Test Weight Factor, Phase 2 System Volt Test Weight Factor, Phase 2 Ambient Temp Test Weight Factor (see Supporting Tables)	Type B, 2 Trips

14 OBDG02 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pump Stuck On	P2444	This DTC detects if the SAI pump is stuck On. This test is run during Phase 3 (Pump commanded Off, valve commanded closed)	Average Pressure Error or	> Bank 1 Pump Pressure Error table < -32 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Stability Time AIR diagnostic Phase 1 passed AIR diagnostic Phase 2 passed No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for > 2.0 sec. < 5,000 RPM > 50 gm/s for > 3.0 sec. > 4.0 seconds Phase 3 cumulative test weight is based on the distance from the last Baro update. See Baro Skewed Sensor Weight Factor table. AIRSystemPressureSens orFA AIRValveControlCircuit FA AIRPumpControlCircuit FA MAF_SensorFA AmbientAirDefault_NA IAT_SensorFA ECT_Sensor_FA EngineMisfireDetected_F A CatalystSysEfficiencyLoB 1_FA CatalystSysEfficiencyLoB 2_FA ControllerProcessorPerf_ FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA	Phase 3 Cumulative test weight > 2.0 sec. Frequency: Once per trip when AIR pump commanded On	Type A, 1 Trips

Closed Loop Enable Clarification: Calibration values are in the Supporting Tables

Engine run time greater than

KtFSTA_t_ClosedLoopAutostart (HYBRID ONLY)

AutoStart Coolant	X1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Close Loop Enable Time	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11

and

KtFSTA_t_ClosedLoopTime

Start-Up Coolant	X1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Close Loop Enable Time	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11

and pre converter O2 sensor voltage less than

KfFULC_U_O2_SensorReadyThresh

Lo

Voltage <

for

KcFULC_O2_SensorReadyEvents

Time (events * 12.5 milliseconds) >

and

COSC (Converter Oxygen Storage Control) not enabled

and

Consumed AirFuel Ratio is stoichiometry i.e. not in component protection

and

POPD or Catalyst Diagnostic not intrusive

and

Turbo Scavenging Mode not enabled

and

All cylinders whose valves are active also have their injectors enabled

and

O2S_Bank_1_TFTKO, O2S_Bank_2_TFTKO, FuelInjectorCircuit_FA and CylinderDeacDriverTFTKO = False

Long Term FT Enable Criteria

Closed Loop Enable Clarification: Calibration values are in the Supporting Tables

**Closed Loop Enable and
Coolant greater than
KfFCLL_T_AdaptiveLoCoolant**

Coolant > XXXXCelcius

**or less than
KfFCLL_T_AdaptiveHiCoolant**

Coolant < XXXXCelcius

**and
KtFCLL_p_AdaptiveLowMAP_Limit**

Barometric Pressure	X1	X2	X3	X4	X5	X6	X7	X8	X9
Manifold Air Pressure	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9

**and
TPS_ThrottleAuthorityDefaulted =
False**

**and
Flex Fuel Estimate Algorithm is not active**

**and
Excessive fuel vapors boiling off from the engine oil algorithm (BOFR) is not
enabled**

**and
Catalyst or EVAP large leak test not
intrusive**

**Secondary Fuel Trim Enable
Criteria**

**Closed Loop Enable and
KfFCLP_U_O2ReadyThrshLo**

Voltage < XXXXmilliVolts

**for
KcFCLP_Cnt_O2RdyCyclesThrsh**

Time (events * 12.5 milliseconds) > XXXXevents

**Long Term Secondary Fuel Trim
Enable Criteria**

KtFCLP_t_PostIntglDisableTime

Closed Loop Enable Clarification: Calibration values are in the Supporting Tables

Start-Up Coolant	X1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Post Integral Enable Time	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11

Plus

KtFCLP_t_PostIntglRampInTime

Start-Up Coolant	X1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Post Integral Ramp In Time	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11

and

KeFCLP_T_IntegrationCatalystMax

Modeled Catalyst Temperature < XXXXCelcius

and

KeFCLP_T_IntegrationCatalystMin

Modeled Catalyst Temperature > XXXXCelcius

and

PO2S_Bank_1_Snsr_2_FA and

PO2S_Bank_2_Snsr_2_FA = False

and

(KeFCLP_Pct_CatAccuSlphrPostDsbl

Modeled converter sulfur percent < XXXX Percent

and

Post Integral < KaFCLP_U_SlphrintglOfst_Thrsh)

X axis: Post O2 Sensor

Y axis: Post O2 Mode

Z: Post Integral threshold

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Multiple DTC Use_Green Sensor Delay Criteria - Airflow

Description: This Calibration is the airflow (in gps) above which the green airflow is acculmulated to expire the condition.

Notes: Used for: P0133, P013A, P013B, P013C, P013D, P013E, P013F, P014A, P014B, P0153, P015A, P015B, P015C, P015D, P1133, P1153, P2270, P2271, P2272 and P2273. The specific diagnostic (from summary table) will not be enabled until the next ignition cycle after the airflow criteria below (by sensor location) has been met:

y/x	1
1	22

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Multiple DTC Use_Green Sensor Delay Criteria - Limit

Description: This Calibration is the accumulated airflow (in grams) limit above which the green condition is expired

Notes: Used for: P0133, P013A, P013B, P013C, P013D, P013E, P013F, P014A, P014B, P0153, P015A, P015B, P015C, P015D, P1133, P1153, P2270, P2271, P2272 and P2273. Note: This feature is only enabled when the vehicle is new and cannot be enabled in service

y/x	CiOXYR_O2_Bank1_Sensor1	CiOXYR_O2_Bank1_Sensor2	CiOXYR_O2_Bank2_Sensor1	CiOXYR_O2_Bank2_Sensor2
1	128,000	128,000	128,000	128,000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0016 P0017 P0018 P0019 Cam Correlation Oil Temperature Threshold

Description: KtEPSI_t_RtnHomeDlyLmt

Notes:

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	300.0	300.0	160.0	18.0	18.0	18.0	18.0	10.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P00B6_Fail if power up ECT exceeds RCT by these values

Description: KtTHMD_T_DCRD_FastFailTempDiff

Notes: X axis is IAT Temperature at Power up (° C), Z axis is the Fast Failure temp difference (° C) The 17 X-axis breakpoints for the table below are (L to R) -40, -28, -16, -4, 8, 20, 32, 44, 56, 68, 80, 92, 104, 116, 128, 140 and 152. Note: Remove for applications with single coolant sensor

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	80	80	80	60	60	40	40	30	30	30	30	30	30	30	30	30	30

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P012B_P0236_P1101 MAF Residual Weight Factor based on MAF Est

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAF Residual Weight Factor based on MAF Est

Notes:

y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P012B_P0236_P1101 MAF Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAF Residual Weight Factor based on RPM

Notes:

y/x	0	700	1,000	1,400	1,800	2,200	2,600	3,000	3,400	3,800	4,200	4,600	5,000	5,400	5,800	6,200	6,600
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.913	1.000	1.000	1.000	1.000	1.000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P012B_P0236_P1101 MAP1 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP1 Residual Weight Factor based on RPM

Notes:

y/x	0	700	1,000	1,400	1,800	2,200	2,600	3,000	3,400	3,800	4,200	4,600	5,000	5,400	5,800	6,200	6,600
1	1.000	1.000	1.000	1.000	0.794	0.866	1.000	0.923	0.987	1.000	1.000	1.000	1.000	0.864	1.000	1.000	1.000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P012B_P0236_P1101 MAP2 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP2 Residual Weight Factor based on RPM

Notes:

y/x	0	700	1,000	1,400	1,800	2,200	2,600	3,000	3,400	3,800	4,200	4,600	5,000	5,400	5,800	6,200	6,600
1	1.000	1.000	1.000	1.000	1.000	0.797	1.000	1.000	0.937	0.775	0.643	0.561	0.923	0.743	1.000	1.000	1.000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P012B_P0236_P1101 MAP3 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP3 Residual Weight Factor based on RPM

Notes:

y/x	0	700	1,000	1,400	1,800	2,200	2,600	3,000	3,400	3,800	4,200	4,600	5,000	5,400	5,800	6,200	6,600
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.924	1.000	1.000	1.000	1.000	1.000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P012B_P0236_P1101 TPS Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 TPS Residual Weight Factor based on RPM

Notes:

y/x	0	700	1,000	1,400	1,800	2,200	2,600	3,000	3,400	3,800	4,200	4,600	5,000	5,400	5,800	6,200	6,600
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P0236_P1101 TIAP Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P0236_P1101 TIAP Residual Weight Factor based on RPM

Notes:

y/x	0	700	1,000	1,400	1,800	2,200	2,600	3,000	3,400	3,800	4,200	4,600	5,000	5,400	5,800	6,200	6,600
1	1.000	0.510	1.000	0.914	0.882	0.844	0.887	0.822	1.000	1.000	1.000	0.909	0.839	0.811	0.833	1.000	1.000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Max Air Flow

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Max Air Flow

Notes:

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	3.0	3.7	4.7	4.9	7.3	9.0	10.8	12.5	12.5

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Max MAP

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Max MAP

Notes:

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	44.0	31.1	28.1	25.4	27.3	25.9	31.1	32.1	32.1

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Offset

Description: P0101_P0106_P0121_P0236_P1101 TIAP-Baro Correlation Offset

Notes:

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min Air Flow

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min Air Flow

Notes:

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	12.0	25.0	34.0	44.0	54.0	63.0	70.0	77.0	77.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min MAP

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Min MAP

Notes:

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	110.0	127.0	130.0	129.0	130.0	129.0	128.0	128.0	128.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Offset

Description: P0101_P0106_P0121_P0236_P1101 TIAP-MAP Correlation Offset

Notes:

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	1.0	1.0	1.0	1.0	2.0	2.0	2.0	3.0	3.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P0236_P1101 Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

Description: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

Notes: This table describes combinations of individual model failures that will set P0101, P0106, P0121, P0236 and P1101 on turbocharged applications.

y/x	1	2	3	4	5	6	7	8	9
1	MAF Model	MAP1 Model	MAP2 Model	MAP3 Model	TIAP1 Model	TPS Model	TIAP Correlation	TIAP Correlation	DTC Set
2	Failed	Failed	Failed	Failed	Failed	Failed	Failed	Valid	
3	F	F	F	F	F	F	F	F	No DTC
4	F	F	F	F	F	F	F	T	No DTC
5	F	F	F	F	F	F	T	F	No DTC
6	F	F	F	F	F	F	T	T	No DTC
7	F	F	F	F	F	T	F	F	No DTC
8	F	F	F	F	F	T	F	T	No DTC
9	F	F	F	F	F	T	T	F	No DTC
10	F	F	F	F	F	T	T	T	No DTC
11	F	F	F	F	T	F	F	F	No DTC
12	F	F	F	F	T	F	F	T	No DTC
13	F	F	F	F	T	F	T	F	No DTC
14	F	F	F	F	T	F	T	T	No DTC
15	F	F	F	F	T	T	F	F	P1101
16	F	F	F	F	T	T	F	T	P0121
17	F	F	F	F	T	T	T	F	P1101
18	F	F	F	F	T	T	T	T	P0236
19	F	F	F	T	F	F	F	F	P1101
20	F	F	F	T	F	F	F	T	P1101
21	F	F	F	T	F	F	T	F	P1101
22	F	F	F	T	F	F	T	T	P1101
23	F	F	F	T	F	T	F	F	P1101
24	F	F	F	T	F	T	F	T	P1101
25	F	F	F	T	F	T	T	F	P1101
26	F	F	F	T	F	T	T	T	P1101
27	F	F	F	T	T	F	F	F	P1101
28	F	F	F	T	T	F	F	T	P1101
29	F	F	F	T	T	F	T	F	P1101
30	F	F	F	T	T	F	T	T	P1101
31	F	F	F	T	T	T	F	F	P1101
32	F	F	F	T	T	T	F	T	P1101
33	F	F	F	T	T	T	T	F	P1101
34	F	F	F	T	T	T	T	T	P1101

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P0236_P1101 Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

35	F	F	T	F	F	F	F	F	P1101
36	F	F	T	F	F	F	F	T	P1101
37	F	F	T	F	F	F	T	F	P1101
38	F	F	T	F	F	F	T	T	P1101
39	F	F	T	F	F	T	F	F	P1101
40	F	F	T	F	F	T	F	T	P1101
41	F	F	T	F	F	T	T	F	P1101
42	F	F	T	F	F	T	T	T	P1101
43	F	F	T	F	T	F	F	F	P1101
44	F	F	T	F	T	F	F	T	P1101
45	F	F	T	F	T	F	T	F	P1101
46	F	F	T	F	T	F	T	T	P1101
47	F	F	T	F	T	T	F	F	P1101
48	F	F	T	F	T	T	F	T	P1101
49	F	F	T	F	T	T	T	F	P1101
50	F	F	T	F	T	T	T	T	P1101
51	F	F	T	T	F	F	F	F	P1101
52	F	F	T	T	F	F	F	T	P1101
53	F	F	T	T	F	F	T	F	P1101
54	F	F	T	T	F	F	T	T	P1101
55	F	F	T	T	F	T	F	F	P1101
56	F	F	T	T	F	T	F	T	P1101
57	F	F	T	T	F	T	T	F	P1101
58	F	F	T	T	F	T	T	T	P1101
59	F	F	T	T	T	F	F	F	No DTC
60	F	F	T	T	T	F	F	T	No DTC
61	F	F	T	T	T	F	T	F	No DTC
62	F	F	T	T	T	F	T	T	No DTC
63	F	F	T	T	T	T	F	F	P1101
64	F	F	T	T	T	T	F	T	P1101
65	F	F	T	T	T	T	T	F	P1101
66	F	F	T	T	T	T	T	T	P1101
67	F	T	F	F	F	F	F	F	P1101
68	F	T	F	F	F	F	F	T	P1101
69	F	T	F	F	F	F	T	F	P1101
70	F	T	F	F	F	F	T	T	P0236
71	F	T	F	F	F	T	F	F	P1101
72	F	T	F	F	F	T	F	T	P0121

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P0236_P1101 Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

73	F	T	F	F	F	T	T	F	P1101
74	F	T	F	F	F	T	T	T	P0236
75	F	T	F	F	T	F	F	F	P1101
76	F	T	F	F	T	F	F	T	P1101
77	F	T	F	F	T	F	T	F	P1101
78	F	T	F	F	T	F	T	T	P0236
79	F	T	F	F	T	T	F	F	P1101
80	F	T	F	F	T	T	F	T	P0121
81	F	T	F	F	T	T	T	F	P1101
82	F	T	F	F	T	T	T	T	P0236
83	F	T	F	T	F	F	F	F	P1101
84	F	T	F	T	F	F	F	T	P1101
85	F	T	F	T	F	F	T	F	P1101
86	F	T	F	T	F	F	T	T	P1101
87	F	T	F	T	F	T	F	F	P1101
88	F	T	F	T	F	T	F	T	P1101
89	F	T	F	T	F	T	T	F	P1101
90	F	T	F	T	F	T	T	T	P1101
91	F	T	F	T	T	F	F	F	P1101
92	F	T	F	T	T	F	F	T	P1101
93	F	T	F	T	T	F	T	F	P1101
94	F	T	F	T	T	F	T	T	P1101
95	F	T	F	T	T	T	F	F	P1101
96	F	T	F	T	T	T	F	T	P1101
97	F	T	F	T	T	T	T	F	P1101
98	F	T	F	T	T	T	T	T	P1101
99	F	T	T	F	F	F	F	F	P1101
100	F	T	T	F	F	F	F	T	P1101
101	F	T	T	F	F	F	T	F	P1101
102	F	T	T	F	F	F	T	T	P1101
103	F	T	T	F	F	T	F	F	P1101
104	F	T	T	F	F	T	F	T	P1101
105	F	T	T	F	F	T	T	F	P1101
106	F	T	T	F	F	T	T	T	P1101
107	F	T	T	F	T	F	F	F	P1101
108	F	T	T	F	T	F	F	T	P1101
109	F	T	T	F	T	F	T	F	P1101
110	F	T	T	F	T	F	T	T	P1101

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P0236_P1101 Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

111	F	T	T	F	T	T	F	F	P1101
112	F	T	T	F	T	T	F	T	P1101
113	F	T	T	F	T	T	T	F	P1101
114	F	T	T	F	T	T	T	T	P1101
115	F	T	T	T	F	F	F	F	P0106
116	F	T	T	T	F	F	F	T	P0106
117	F	T	T	T	F	F	T	F	P0106
118	F	T	T	T	F	F	T	T	P0106
119	F	T	T	T	F	T	F	F	P1101
120	F	T	T	T	F	T	F	T	P1101
121	F	T	T	T	F	T	T	F	P1101
122	F	T	T	T	F	T	T	T	P1101
123	F	T	T	T	T	F	F	F	P1101
124	F	T	T	T	T	F	F	T	P1101
125	F	T	T	T	T	F	T	F	P1101
126	F	T	T	T	T	F	T	T	P1101
127	F	T	T	T	T	T	F	F	P1101
128	F	T	T	T	T	T	F	T	P1101
129	F	T	T	T	T	T	T	F	P1101
130	F	T	T	T	T	T	T	T	P1101
131	T	F	F	F	F	F	F	F	P1101
132	T	F	F	F	F	F	F	T	P1101
133	T	F	F	F	F	F	T	F	P1101
134	T	F	F	F	F	F	T	T	P0236
135	T	F	F	F	F	T	F	F	P1101
136	T	F	F	F	F	T	F	T	P0121
137	T	F	F	F	F	T	T	F	P1101
138	T	F	F	F	F	T	T	T	P0236
139	T	F	F	F	T	F	F	F	P1101
140	T	F	F	F	T	F	F	T	P1101
141	T	F	F	F	T	F	T	F	P1101
142	T	F	F	F	T	F	T	T	P0236
143	T	F	F	F	T	T	F	F	P1101
144	T	F	F	F	T	T	F	T	P0121
145	T	F	F	F	T	T	T	F	P1101
146	T	F	F	F	T	T	T	T	P0236
147	T	F	F	T	F	F	F	F	P1101
148	T	F	F	T	F	F	F	T	P1101

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P0236_P1101 Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

149	T	F	F	T	F	F	T	F	P1101
150	T	F	F	T	F	F	T	T	P1101
151	T	F	F	T	F	T	F	F	P1101
152	T	F	F	T	F	T	F	T	P1101
153	T	F	F	T	F	T	T	F	P1101
154	T	F	F	T	F	T	T	T	P1101
155	T	F	F	T	T	F	F	F	P1101
156	T	F	F	T	T	F	F	T	P1101
157	T	F	F	T	T	F	T	F	P1101
158	T	F	F	T	T	F	T	T	P1101
159	T	F	F	T	T	T	F	F	P1101
160	T	F	F	T	T	T	F	T	P1101
161	T	F	F	T	T	T	T	F	P1101
162	T	F	F	T	T	T	T	T	P1101
163	T	F	T	F	F	F	F	F	P1101
164	T	F	T	F	F	F	F	T	P1101
165	T	F	T	F	F	F	T	F	P1101
166	T	F	T	F	F	F	T	T	P1101
167	T	F	T	F	F	T	F	F	P1101
168	T	F	T	F	F	T	F	T	P1101
169	T	F	T	F	F	T	T	F	P1101
170	T	F	T	F	F	T	T	T	P1101
171	T	F	T	F	T	F	F	F	P1101
172	T	F	T	F	T	F	F	T	P1101
173	T	F	T	F	T	F	T	F	P1101
174	T	F	T	F	T	F	T	T	P1101
175	T	F	T	F	T	T	F	F	P1101
176	T	F	T	F	T	T	F	T	P1101
177	T	F	T	F	T	T	T	F	P1101
178	T	F	T	F	T	T	T	T	P1101
179	T	F	T	T	F	F	F	F	P1101
180	T	F	T	T	F	F	F	T	P1101
181	T	F	T	T	F	F	T	F	P1101
182	T	F	T	T	F	F	T	T	P1101
183	T	F	T	T	F	T	F	F	P1101
184	T	F	T	T	F	T	F	T	P1101
185	T	F	T	T	F	T	T	F	P1101
186	T	F	T	T	F	T	T	T	P1101

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P0236_P1101 Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

187	T	F	T	T	T	F	F	F	P1101
188	T	F	T	T	T	F	F	T	P1101
189	T	F	T	T	T	F	T	F	P1101
190	T	F	T	T	T	F	T	T	P1101
191	T	F	T	T	T	T	F	F	P1101
192	T	F	T	T	T	T	F	T	P1101
193	T	F	T	T	T	T	T	F	P1101
194	T	F	T	T	T	T	T	T	P1101
195	T	T	F	F	F	F	F	F	P1101
196	T	T	F	F	F	F	F	T	P1101
197	T	T	F	F	F	F	T	F	P1101
198	T	T	F	F	F	F	T	T	P0236
199	T	T	F	F	F	T	F	F	P1101
200	T	T	F	F	F	T	F	T	P0121
201	T	T	F	F	F	T	T	F	P1101
202	T	T	F	F	F	T	T	T	P0236
203	T	T	F	F	T	F	F	F	P1101
204	T	T	F	F	T	F	F	T	P1101
205	T	T	F	F	T	F	T	F	P1101
206	T	T	F	F	T	F	T	T	P0236
207	T	T	F	F	T	T	F	F	P1101
208	T	T	F	F	T	T	F	T	P0121
209	T	T	F	F	T	T	T	F	P1101
210	T	T	F	F	T	T	T	T	P0236
211	T	T	F	T	F	F	F	F	P1101
212	T	T	F	T	F	F	F	T	P1101
213	T	T	F	T	F	F	T	F	P1101
214	T	T	F	T	F	F	T	T	P1101
215	T	T	F	T	F	T	F	F	P1101
216	T	T	F	T	F	T	F	T	P1101
217	T	T	F	T	F	T	T	F	P1101
218	T	T	F	T	F	T	T	T	P1101
219	T	T	F	T	T	F	F	F	P1101
220	T	T	F	T	T	F	F	T	P1101
221	T	T	F	T	T	F	T	F	P1101
222	T	T	F	T	T	F	T	T	P1101
223	T	T	F	T	T	T	F	F	P1101
224	T	T	F	T	T	T	F	T	P1101

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P0236_P1101 Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

225	T	T	F	T	T	T	T	F	P1101
226	T	T	F	T	T	T	T	T	P1101
227	T	T	T	F	F	F	F	F	P1101
228	T	T	T	F	F	F	F	T	P1101
229	T	T	T	F	F	F	T	F	P1101
230	T	T	T	F	F	F	T	T	P1101
231	T	T	T	F	F	T	F	F	P1101
232	T	T	T	F	F	T	F	T	P1101
233	T	T	T	F	F	T	T	F	P1101
234	T	T	T	F	F	T	T	T	P1101
235	T	T	T	F	T	F	F	F	P1101
236	T	T	T	F	T	F	F	T	P1101
237	T	T	T	F	T	F	T	F	P1101
238	T	T	T	F	T	F	T	T	P1101
239	T	T	T	F	T	T	F	F	P1101
240	T	T	T	F	T	T	F	T	P1101
241	T	T	T	F	T	T	T	F	P1101
242	T	T	T	F	T	T	T	T	P1101
243	T	T	T	T	F	F	F	F	P1101
244	T	T	T	T	F	F	F	T	P1101
245	T	T	T	T	F	F	T	F	P1101
246	T	T	T	T	F	F	T	T	P1101
247	T	T	T	T	F	T	F	F	P1101
248	T	T	T	T	F	T	F	T	P1101
249	T	T	T	T	F	T	T	F	P1101
250	T	T	T	T	F	T	T	T	P1101
251	T	T	T	T	T	F	F	F	P1101
252	T	T	T	T	T	F	F	T	P1101
253	T	T	T	T	T	F	T	F	P1101
254	T	T	T	T	T	F	T	T	P1101
255	T	T	T	T	T	T	F	F	P1101
256	T	T	T	T	T	T	F	T	P1101
257	T	T	T	T	T	T	T	F	P1101
258	T	T	T	T	T	T	T	T	P1101

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0116_Fail if power up ECT exceeds IAT by these values

Description: KtECTD_T_HSC_FastFailTempDiff

Notes: X axis is IAT Temperature at Power up (° C), Z axis is the Fast Failure temp difference (° C)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	106	94	82	70	60	46	40	30	30	30	30	30	30	30	37	49	61

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0128_Maximum Accumulated Energy for Start-up ECT conditions - Alternate

Description: Maximum Total Energy transferred to Cooling System for Ambient and Start-up ECT conditions (Alternate Test)

Notes: Z axis is the cooling system energy failure threshold (kJ), X axis is ECT Temperature at Power up (° C), (Deluxe version)

y/x	-20	-5	10	30	45	60	75
1	1,152	972	792	552	372	192	12

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0128_Maximum Accumulated Energy for Start-up ECT conditions - Primary

Description: Maximum Total Energy transferred to Cooling System for Ambient and Start-up ECT conditions (Primary Test)

Notes: Z axis is the cooling system energy failure threshold (kJ), X axis is ECT Temperature at Power up (° C) , (Deluxe version)

y/x	-20	-5	10	30	45	60	75
1	1,392	1,212	1,032	792	612	432	252

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0133_KnEOSD_t_ST_LRC_LimRS1

Description: KnEOSD_t_ST_LRC_LimRS1. X Table Axis (in sec) for P0133, L2R Reponse time breakpoints for table

Notes:

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.030	0.045	0.060	0.075	0.090	0.105	0.120	0.135	0.150	0.165	0.180	0.195	0.210	0.225	0.240	1.000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0133_KnEOSD_t_ST_RLC_LimRS1

Description: KnEOSD_t_ST_RLC_LimRS1. Y Table Axis (in sec) for P0133, R2L Reponse time breakpoints for table

Notes:

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.030	0.045	0.060	0.075	0.090	0.105	0.120	0.135	0.150	0.165	0.180	0.195	0.210	0.225	0.240	1.000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0133_O2S Slow Response Bank 1 Sensor 1 "Pass/Fail Threshold table"

Description: KaEOSD_x_ST_ResponseLimRS1[x][y]

Notes: X axis is Lean to Rich response time (in sec), Please see the table below named "KnEOSD_t_ST_LRC_LimRS1" for the 17 X axis table breakpoints. Y axis is Rich to Lean response time (sec), Please see the cal table below named "KnEOSD_t_ST_RLC_LimRS1" for the 17 Y axis table breakpoints. Z axis is the pass/fail result, Note: If the cell contains a "0" then the fault is indicated, if it contains a "1" a fault is not indicated.

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
2	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
3	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
4	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
5	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
6	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0
7	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
8	0	0	0	0	0	1	1	1	1	1	1	1	1	1	1	1	0
9	0	0	0	0	0	1	1	1	1	1	1	1	1	1	1	1	0
10	0	0	0	0	0	1	1	1	1	1	1	1	1	1	1	1	0
11	0	0	0	0	0	1	1	1	1	1	1	1	1	1	1	1	0
12	0	0	0	0	0	0	1	1	1	1	1	1	1	1	1	1	0
13	0	0	0	0	0	0	0	1	1	1	1	1	1	1	1	1	0
14	0	0	0	0	0	0	0	0	1	1	1	1	1	1	1	1	0
15	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P00C4_P2261_KtBSTD_r_SurgeLim

Description:

Notes:

y/x	16.0000	18.0000	36.0000	41.0000	77.0000	103.0000
1.0000	1.1200	1.2300	1.6000	1.8500	2.4600	3.2000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0234_KtBSTD_p_CntrlDevNegLim

Description:

Notes:

y/x	100.0000	120.0000	140.0000	160.0000	170.0000	180.0000	190.0000	200.0000	210.0000	220.0000
1,000.0000	-24.3600	-30.4500	-28.0140	-26.7960	-24.3600	-24.3600	-24.3600	-26.7960	-26.7960	-28.0018
1,500.0000	-48.7200	-36.5400	-28.0140	-26.7960	-24.3600	-24.3600	-24.3600	-26.7960	-26.7960	-28.0018
2,000.0000	-73.0800	-48.7200	-26.7960	-25.5780	-24.3600	-24.3600	-24.3600	-25.4562	-25.4562	-28.0018
2,500.0000	-80.3880	-53.5920	-26.7960	-22.7766	-21.6378	-22.9106	-24.1834	-25.4562	-25.4562	-28.0018
3,000.0000	-73.0800	-48.7200	-24.3600	-19.4880	-19.6707	-20.8278	-21.9849	-23.1420	-23.1420	-25.4562
3,500.0000	-73.0800	-48.7200	-19.4880	-19.4880	-19.6707	-20.8278	-21.9849	-23.1420	-23.1420	-25.4562
4,000.0000	-73.0800	-48.7200	-19.4880	-19.4880	-19.6707	-20.8278	-21.9849	-23.1420	-23.1420	-25.4562
4,500.0000	-73.0800	-48.7200	-19.4880	-19.4880	-19.6707	-20.8278	-21.9849	-23.1420	-23.1420	-25.4562
5,000.0000	-73.0800	-48.7200	-19.4880	-19.4880	-19.6707	-20.8278	-21.9849	-23.1420	-23.1420	-25.4562
6,000.0000	-73.0800	-48.7200	-19.4880	-19.4880	-19.6707	-20.8278	-21.9849	-23.1420	-23.1420	-25.4562

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0234_P0299_KtBSTD_p_CntrlDevAmbAirCorr

Description:

Notes:

y/x	60.0000	70.0000	80.0000	90.0000	100.0000	110.0000
2,000.0000	100.0000	100.0000	80.0000	30.0000	15.0000	0.0000
2,500.0000	100.0000	100.0000	50.0000	15.0000	0.0000	0.0000
3,000.0000	100.0000	50.0000	20.0000	10.0000	0.0000	0.0000
4,000.0000	100.0000	20.0000	10.0000	5.0000	0.0000	0.0000
5,000.0000	100.0000	10.0000	5.0000	0.0000	0.0000	0.0000
6,000.0000	100.0000	5.0000	5.0000	0.0000	0.0000	0.0000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0234_P0299_KtBSTD_p_CntrlDevPosLim

Description:

Notes:

y/x	100.0000	120.0000	140.0000	160.0000	170.0000	180.0000	190.0000	200.0000	210.0000	220.0000
1,000.0000	40.0000	35.0000	45.0000	67.0000	85.0000	107.0000	125.0000	137.0000	169.0000	189.0000
1,500.0000	30.0000	25.0000	27.0000	42.0000	52.0000	60.0000	79.0000	82.0000	102.0000	135.0000
2,000.0000	30.0000	27.6000	26.4000	25.2000	24.0000	30.0000	36.0000	42.0000	48.0000	48.0000
2,500.0000	30.0000	27.6000	24.0000	20.4000	20.4000	21.6000	22.8000	24.0000	25.2000	26.4000
3,000.0000	30.0000	27.6000	21.6000	19.2000	20.4000	21.6000	22.8000	24.0000	25.2000	26.4000
3,500.0000	30.0000	27.6000	20.4000	19.2000	20.4000	21.6000	22.8000	24.0000	25.2000	26.4000
4,000.0000	30.0000	27.6000	20.4000	19.2000	20.4000	21.6000	22.8000	24.0000	25.2000	26.4000
4,500.0000	30.0000	27.6000	20.4000	19.2000	20.4000	21.6000	22.8000	24.0000	25.2000	26.4000
5,000.0000	30.0000	27.6000	20.4000	19.2000	20.4000	21.6000	22.8000	24.0000	25.2000	26.4000
6,000.0000	30.0000	27.6000	20.4000	19.2000	20.4000	21.6000	22.8000	24.0000	25.2000	26.4000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0234_P0299_EnableDelay

Description: KtBSTD_t_CntrlDevEnbIDelay

Notes:

y/x	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	6,000
1	1.750	1.500	1.380	1.130	1.000	1.000	1.000	1.000	1.000	1.000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0068_Delta MAF Threshold f(TPS)

Description: Table of delta MAF values as a function of desired throttle position. The output of this table provides a delta MAF that if the measured minus the estimated MAF exceeds, is considered a fail.

Notes: P0068, KtTPSD_dm_MAF_DesThrDelt

y/x	5.00	12.00	15.00	20.00	25.00	30.00	35.00	40.00	60.00
1.00	6.00	7.00	8.03	11.77	15.71	22.55	33.63	58.00	170.00

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0068_Delta MAP Threshold f(TPS)

Description: Table of delta MAP values as a function of desired throttle position. The output of this table provides a delta MAP that if the measured minus the estimated MAP exceeds, is considered a fail.

Notes: P0068, KtTPSD_p_MAP_DesThrDelt

y/x	5.00	12.00	15.00	20.00	25.00	30.00	35.00	40.00	60.00
1.00	35.00	28.00	35.92	38.79	37.56	39.64	44.03	60.23	255.00

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0068_Maximum MAF f(RPM)

Description: Table of maximum MAF values vs. engine speed. This is the maximum MAF the engine can see under all ambient conditions.

Notes: P0068, KtTPSD_dm_MaxMAF_VsRPM

y/x	600.00	1,400.00	2,200.00	3,000.00	3,800.00	4,600.00	5,400.00	6,200.00	7,000.00
1.00	255.00	255.00	255.00	255.00	255.00	255.00	255.00	255.00	255.00

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0068_Maximum MAF f(Volts)

Description: Table of maximum MAF values vs. system voltage. The output of the air meter is clamped to lower values as system voltage drops off.

Notes: P0068, KtTPSD_dm_MaxMAF_VsVoltage

y/x	6.00	7.00	8.00	9.00	10.00	11.00	12.00	13.00	14.00
1.00	511.99	511.99	511.99	511.99	511.99	511.99	511.99	511.99	511.99

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage

Description: Identifies which Long Term Fuel Trim Cell I.D.s are used for diagnosis. Only cells identified as "CeFADD_e_NonSelectedCell" are not used for diagnosis.

Notes: DTCs: P0171, P0172, P0174, P0175; Calibration Name: KaFADD_e_SelectCellSet; Axis is Long Term Fuel Trim Cell I.D.

P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 1

y/x	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR_e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell

P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 2

y/x	CeFADR_e_Cell04_PurgOnAirMode 1	CeFADR_e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell

P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 3

y/x	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR_e_Cell10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell

P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 4

y/x	CeFADR_e_Cell12_PurgOffAirMode 1	CeFADR_e_Cell13_PurgOffAirMode 0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0606_Last Seed Timeout f(Loop Time)

Description: The max time for the Last Seed Timeout as a function of operating loop time sequence.

Notes: P0606, KaPISD_t_LastSeedTimeout[x]

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	0.175	0.175	0.175	409.594

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0606_Program Sequence Watch Enable f(Loop Time)

Description: The enabling flags for the program sequence watch as a function of operating loop time sequence.

Notes: P0606, KaPISD_b_ProgSeqWatchEnbl

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	1	1	1	0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0606_PSW Sequence Fail f(Loop Time)

Description: Fail threshold for PSW per operating loop.

Notes: P0606, KaPISD_Cnt_SequenceFail[x]

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	3	3	3	5

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0606_PSW Sequence Sample f(Loop Time)

Description: Sample threshold for PSW per operating loop.

Notes: P0606, KaPISD_Cnt_SequenceSmp[x]

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	4	4	4	4

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P1682_PT Relay Pull-in Run/Crank Voltage f(IAT)

Description: The Run/Crank voltages required to pull in the PT relay as a function of induction air temperature.

Notes: P1682, KtEROR_U_PT_RelayPullInEnbl

y/x	23.00	85.00	95.00	105.00	125.00
1.00	7.00	8.70	9.00	9.20	10.00

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P16F3_Delta MAP Threshold f(Desired Engine Torque)

Description: Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

Notes: P16F3, KtMAPI_p_ES_TB_MAP_DeltaThresh

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	28.00	28.00	28.00	28.00	28.00	28.00

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P16F3_Delta Spark Threshold f(RPM,APC)

Description: Threshold for determining when the difference between commanded spark and applied spark exceeds the torque security requirement. It is a function of engine rpm and APC.

Notes: P16F3, KtSPRK_phi_DeltTorqueScrtAdv

y/x	500.00	980.74	1,461.48	1,942.23	2,422.97	2,903.71	3,384.45	3,865.20	4,345.94	4,826.68	5,307.42	5,788.16	6,268.91	6,749.65	7,230.39	7,711.13	8,191.88
80.00	125.00	65.50	52.19	46.83	42.94	36.58	34.23	34.50	35.64	37.58	41.33	43.63	44.31	44.50	44.50	44.50	44.50
160.00	125.00	59.36	42.23	36.47	35.23	31.61	29.67	29.39	29.91	30.77	31.39	32.36	33.69	34.03	34.03	34.03	34.03
240.00	125.00	54.36	35.42	29.25	29.31	27.83	26.19	25.61	25.77	25.61	25.09	25.73	27.17	27.56	27.56	27.56	27.56
320.00	125.00	50.19	30.58	24.27	24.86	24.63	23.42	22.69	22.28	21.30	20.64	21.36	22.77	23.16	23.16	23.16	23.16
400.00	125.00	46.42	26.78	20.63	20.97	20.88	20.66	19.72	19.05	18.05	17.53	18.27	19.59	19.95	19.95	19.95	19.95
480.00	125.00	42.64	23.78	17.84	18.00	18.05	17.98	17.00	16.47	15.63	15.22	15.95	17.20	17.53	17.53	17.53	17.53
560.00	125.00	39.44	21.39	15.72	15.77	15.86	15.80	14.92	14.45	13.75	13.45	14.16	15.33	15.64	15.64	15.64	15.64
640.00	125.00	36.69	19.45	14.05	14.02	14.13	14.03	13.28	12.89	12.28	12.05	12.73	13.81	14.11	14.11	14.11	14.11
720.00	125.00	34.30	17.83	12.70	12.61	12.69	12.63	11.97	11.63	11.09	10.91	11.56	12.58	12.86	12.86	12.86	12.86
800.00	125.00	32.95	16.94	11.98	11.86	11.92	11.89	11.27	10.95	10.45	10.30	10.94	11.92	12.19	12.19	12.19	12.19
880.00	125.00	32.95	16.94	11.98	11.86	11.92	11.89	11.27	10.95	10.45	10.30	10.94	11.92	12.19	12.19	12.19	12.19
960.00	125.00	32.95	16.94	11.98	11.86	11.92	11.89	11.27	10.95	10.45	10.30	10.94	11.92	12.19	12.19	12.19	12.19
1,040.00	125.00	32.95	16.94	11.98	11.86	11.92	11.89	11.27	10.95	10.45	10.30	10.94	11.92	12.19	12.19	12.19	12.19
1,120.00	125.00	32.95	16.94	11.98	11.86	11.92	11.89	11.27	10.95	10.45	10.30	10.94	11.92	12.19	12.19	12.19	12.19
1,200.00	125.00	32.95	16.94	11.98	11.86	11.92	11.89	11.27	10.95	10.45	10.30	10.94	11.92	12.19	12.19	12.19	12.19
1,280.00	125.00	32.95	16.94	11.98	11.86	11.92	11.89	11.27	10.95	10.45	10.30	10.94	11.92	12.19	12.19	12.19	12.19
1,360.00	125.00	32.95	16.94	11.98	11.86	11.92	11.89	11.27	10.95	10.45	10.30	10.94	11.92	12.19	12.19	12.19	12.19

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P16F3_Speed Control External Load f(Oil Temp, RPM)

Description: Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

Notes: P16F3, KtSPDC_M_ExternalLoad

y/x	-40.00	-20.00	-10.00	0.00	50.00	90.00
300.00	4,096.00	4,096.00	4,096.00	4,096.00	4,096.00	4,096.00
500.00	4,096.00	4,096.00	4,096.00	4,096.00	4,096.00	4,096.00
600.00	80.00	70.00	70.00	70.00	70.00	70.00
700.00	80.00	70.00	60.00	55.00	55.00	35.00
800.00	80.00	70.00	60.00	55.00	55.00	35.00
900.00	80.00	70.00	60.00	55.00	55.00	35.00
1,000.00	80.00	70.00	60.00	55.00	55.00	35.00
1,100.00	80.00	70.00	60.00	55.00	55.00	35.00
1,300.00	80.00	70.00	60.00	55.00	55.00	35.00
1,500.00	80.00	70.00	60.00	55.00	55.00	35.00
1,700.00	80.00	70.00	60.00	55.00	55.00	35.00
2,000.00	60.00	50.00	29.70	28.00	25.30	25.00
2,500.00	45.30	40.80	37.90	35.80	32.90	32.90
3,000.00	45.30	40.80	37.90	35.80	32.90	32.90
4,000.00	45.30	40.80	37.90	35.80	32.90	32.90
5,000.00	45.30	40.80	37.90	35.80	32.90	32.90
6,000.00	45.30	40.80	37.90	35.80	32.90	32.90

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P219A Normalizer Bank1 Table

Description: Bank 1 Normalizer table used in the calculation of the Ratio for the current sample period.

Notes: DTCs: P219A; Calibration Name: KtFABD_U_Normalizer1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	700	900	1,100	1,300	1,500	1,700	1,900	2,100	2,300	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000
90	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
135	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
180	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
225	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00
270	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00
315	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00
360	6.00	6.00	6.00	6.00	6.00	6.00	6.00	6.00	6.00	6.00	6.00	6.00	6.00	6.00	6.00	6.00	6.00
405	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	9,999.00
450	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	9,999.00	9,999.00	9,999.00	9,999.00
495	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	9,999.00	9,999.00	9,999.00	9,999.00
540	9,999.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	9,999.00	9,999.00	9,999.00	9,999.00
585	9,999.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	9,999.00	9,999.00	9,999.00	9,999.00
630	9,999.00	9,999.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	9,999.00	9,999.00	9,999.00	9,999.00
675	9,999.00	9,999.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	9,999.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	9,999.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	9,999.00	9,999.00	9,999.00	9,999.00
900	9,999.00	9,999.00	9,999.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	9,999.00	9,999.00	9,999.00	9,999.00
1,080	9,999.00	9,999.00	9,999.00	9,999.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	9,999.00	9,999.00	9,999.00	9,999.00

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P219A Quality Factor Bank1 Table

Description: Bank 1 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

Notes: DTCs: P219A; Calibration Name: KtFABD_K_QualFactor1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	700	900	1,100	1,300	1,500	1,700	1,900	2,100	2,300	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000
90	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
135	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
180	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
225	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00
270	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
315	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
360	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00
405	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00
450	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
495	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
540	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
585	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
630	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
675	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
720	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
900	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
1,080	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P219A Variance Threshold Bank1 Table

Description: Bank 1 lookup table of Variance metric used to calculate the Ratio for the current sample period

Notes: DTCs: P219A; Calibration Name: KtFABD_U_VarThresh1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	700	900	1,100	1,300	1,500	1,700	1,900	2,100	2,300	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000
90	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
135	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
180	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
225	8.00	8.00	8.00	8.00	8.00	8.00	8.00	8.00	8.00	8.00	8.00	8.00	8.00	8.00	8.00	8.00	8.00
270	11.00	11.00	11.00	11.00	11.00	11.00	11.00	11.00	11.00	11.00	11.00	11.00	11.00	11.00	11.00	11.00	11.00
315	13.00	13.00	13.00	13.00	13.00	13.00	13.00	13.00	13.00	13.00	13.00	13.00	13.00	13.00	13.00	13.00	13.00
360	14.00	14.00	14.00	14.00	14.00	14.00	14.00	14.00	14.00	14.00	14.00	14.00	14.00	14.00	14.00	14.00	14.00
405	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
450	15.00	15.00	16.00	16.00	16.00	16.00	16.00	16.00	16.00	16.00	16.00	16.00	16.00	16.00	16.00	16.00	16.00
495	18.00	18.00	18.00	18.00	18.00	18.00	18.00	18.00	18.00	18.00	18.00	18.00	18.00	18.00	9,999.00	9,999.00	9,999.00
540	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	9,999.00	9,999.00	9,999.00
585	9,999.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	9,999.00	9,999.00	9,999.00
630	9,999.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	9,999.00	9,999.00	9,999.00
675	9,999.00	9,999.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	9,999.00	9,999.00	9,999.00
900	9,999.00	9,999.00	9,999.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	9,999.00	9,999.00	9,999.00
1,080	9,999.00	9,999.00	9,999.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	20.00	9,999.00	9,999.00	9,999.00

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KaFCLP_U_SlphrIntgIOfst_Thrsh

Description: Integral Offset voltage thresholds (bank and cell specific calcs) used with KeFCLP_Pct_CatAccuSlphrPostDsbl to check for sulphur poisoning.

Notes: millivolts

y/x	CiOXYR_O2_PostCat1	CiOXYR_O2_PostCat2
CiFCLP_Decel	2,048	2,048
CiFCLP_Idle	2,048	2,048
CiFCLP_Cruise	2,048	2,048
CiFCLP_LightAccel	2,048	2,048
CiFCLP_HeavyAccel	2,048	2,048

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KcFCLP_Cnt_O2RdyCyclesThrsh

Description: Number of post catalyst oxygen sensor samples which must be outside not ready window before post oxygen sensor is READY.

Notes: Time (events * 12.5 milliseconds)

y/x	
1	80

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KcFULC_O2_SensorReadyEvents

Description: Number of times an oxygen sensor value must be in range before declaring it ready

Notes: Time (events * 12.5 milliseconds)

y/x	
1	40

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_Pct_CatAccuSlphrPostDsbl

Description: Sulphur percent threshold above which post integral learning is disabled if the threshold criteria KaFCLP_U_SlphrIntglOfst_Thrsh is also met.

Notes: Percent

y/x	1
1	255

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_T_IntegrationCatalystMax

Description: Maximum allowed estimated catalytic converter temperature for post O2 integral terms to be updated.

Notes: Modeled catalyst Temperature in Celcius

y/x	1
1	1,000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_T_IntegrationCatalystMin

Description: Minimum allowed estimated catalytic converter temperature to begin using post O2 integration correction terms. Converter temperature must remain above this threshold to ramp-in the post O2 integration adjustments. Once the ramp-in has started, a converter temperature below this threshold will freeze the ramp-in multiplier. Post O2 integration will not be allowed below this converter temperature

Notes: Modeled catalyst Temperature in Celcius

y/x	1
1	300

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KfFCLL_T_AdaptiveHiCoolant

Description: LTM learning is inhibited if the engine coolant temperature is above this calibration.

Notes: Degrees Celcius

y/x	
1	120

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KfFCLL_T_AdaptiveLoCoolant

Description: LTM learning is inhibited if the engine coolant temperature is below this calibration.

Notes: Degrees Celcius

y/x	
1	38

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KfFCLP_U_O2ReadyThrshLo

Description: Lower threshold defining not ready window for post oxygen sensor voltage.

Notes: Voltage in millivolts

y/x	
1	950

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KfFULC_U_O2_SensorReadyThrshLo

Description: Lower limit checked against when determining if an oxygen sensor is in range

Notes: Voltage in millivolts

y/x	1
1	1,100

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFCLL_p_AdaptiveLowMAP_Limit

Description: KtFCLL_p_AdaptiveLowMAP_Limit

Notes: MAP in KPa

y/x	65	70	75	80	85	90	95	100	105
1	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFCLP_t_PostIntglDisableTime

Description: Disable integral offset after engine start for this amount of time.

Notes: Time in seconds

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	409.0	400.0	388.0	300.0	248.0	213.0	208.0	198.0	98.0	78.0	58.0	58.0	52.0	28.0	28.0	28.0	28.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFCLP_t_PostIntglRampInTime

Description: Time required to ramp integral offset to desired value.

Notes: Time in seconds

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	40.0	33.0	26.0	19.0	12.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFSTA_t_ClosedLoopAutostart

Description: Engine run time following an autostart, as a function of begin run coolant, which must be exceeded to enable CLOSED LOOP.

Notes: Time in seconds: Hybrid use Only

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	180.0	165.0	150.0	84.0	50.0	15.0	10.0	6.0	6.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFSTA_t_ClosedLoopTime

Description: Engine run time, as a function of startup coolant temperature, which must be exceeded to enable CLOSED LOOP.

Notes: Time in seconds

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	270.0	210.0	155.0	84.0	50.0	21.0	21.0	21.0	15.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0324_P0326_P0331_AbnormalNoise_CylsEnabled

Description: Specifies which cylinders will be used for the Abnormal Noise portion of the performance diagnostics (1 = cylinder used, 0 = cylinder not used)

Notes: Used for P0324, P0326 and P0331. Cal name: KaKNKD_b_PerfAbnIncludeCyl. x-axis = Cylinder number in firing order (i.e. Cyl 0 = first cylinder in firing order, Cyl 1 = second cylinder in firing order....)

A cal value = 1 specifies the cylinder is used for the Abnormal Noise diagnostic. A cal value = 0 specifies the cylinder is not used. Only the first four values in the table are relevant for a four-cylinder engine and only the first six values in the table are relevant for a six-cylinder engine.

Typically, all cylinders are used. Cylinders are only excluded if the signal from that cylinder is weak and there is no separation between normal and faulted conditions (can occur if the sensor location results in poor signal-to-noise ratio for a given cylinder).

y/x	0	1	2	3	4	5	6	7
1	1	1	1	1	0	0	0	0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0324_P0326_P0331_AbnormalNoise_Threshold

Description: Fail threshold for the Knock Performance Abnormal Noise Diagnostic

Notes: Used for P0324, P0326 and P0331. Cal Name: KtKNKD_k_PerfAbnLimitLo. X-axis = Engine Speed (RPM). Diagnostic fails when VaKNKD_k_PerfCylAbnFiltIntensity < KtKNKD_k_PerfAbnLimitLo

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.030	0.030	0.031	0.031	0.033	0.034	0.034	0.037	0.045	0.041	0.044	0.040	0.053	0.053	0.053	0.053	0.053

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0325_P0330_OpenCktThrshMax (20 kHz)

Description: Knock Open Circuit Diagnostic Maximum Threshold when using the 20 kHz method (see "OpenMethod" description)

Notes: Used for P0325 and P0330. Cal name: KtKNKD_k_OpenMax20K. x-axis = Engine Speed (RPM).

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:
i.e.: $KtKNKD_k_OpenMin20K < VaKNKD_k_OpenFiltIntensity < KtKNKD_k_OpenMax20K$.

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	2.0586	2.0801	2.0234	1.9082	1.7480	1.5605	1.3652	1.1758	1.0078	0.8828	0.8125	0.8164	0.9082	1.1094	1.4316	1.8945	2.5156

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0325_P0330_OpenCktThrshMax (Normal Noise)

Description: Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

Notes: Used for P0325 and P0330. Cal name: KtKNKD_k_OpenMaxNN. x-axis = Engine Speed (RPM)

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:

i.e.: $KtKNKD_k_OpenMinNN < VaKNKD_k_OpenFilIntensity < KtKNKD_k_OpenMaxNN$.

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.0000	0.0000	0.0000	0.0000	0.0078	0.0469	0.0684	0.0781	0.0801	0.0820	0.0840	0.1035	0.1328	0.1836	0.2578	0.3633	0.5059

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0325_P0330_OpenCktThrshMin (20 kHz)

Description: Knock Open Circuit Diagnostic Minimum Threshold when using the 20 kHz method (see "OpenMethod" description)

Notes: Used for P0325 and P0330. Cal name: KtKNKD_k_OpenMin20K. x-axis = Engine Speed (RPM)

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:
 i.e.: $KtKNKD_k_OpenMin20K < VaKNKD_k_OpenFiltIntensity < KtKNKD_k_OpenMax20K$.

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.7949	0.7930	0.7676	0.7227	0.6660	0.5996	0.5313	0.4668	0.4082	0.3652	0.3398	0.3379	0.3652	0.4297	0.5313	0.6797	0.8789

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0325_P0330_OpenCktThrshMin (Normal Noise)

Description: Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

Notes: Used for P0325 and P0330. Cal name: KtKNKD_k_OpenMinNN. x-axis = Engine Speed (RPM)

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:

i.e.: $KtKNKD_k_OpenMinNN < VaKNKD_k_OpenFilIntensity < KtKNKD_k_OpenMaxNN$.

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.0000	0.0000	0.0078	0.0117	0.0156	0.0176	0.0195	0.0215	0.0215	0.0215	0.0215	0.0215	0.0234	0.0254	0.0293	0.0352	0.0430

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0325_P0330_OpenMethod

Description:

Notes: Used for P0325 and P0330. Cal name: KtKNKD_e_OpenMethod. x-axis = Engine Speed Index, 500 to 8500 (RPM) by 500 rpm increments.

Selects 1 of 3 available methods: "20kHz Method", "Normal Noise Method," or "Disabled." The mode chosen dictates which set of threshold tables are used. Typically, either: A) the 20 kHz Method is used for all RPM or B) the 20 kHz Method is used for low/medium RPM and the Normal Noise Method is used for high RPM.

P0325_P0330_OpenMethod - Part 1

y/x	0	1	2	3	4	5
1	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z

P0325_P0330_OpenMethod - Part 2

y/x	6	7	8	9	10	11
1	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z

P0325_P0330_OpenMethod - Part 3

y/x	12	13	14	15	16	
1	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0420_BestFailingOSCTableB1

Description: This table is a 9x17 table of baseline Best Failing (e.g. threshold converter) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow,the BestFailing OSC value is found within this table for the measured temp and airflow and is used along with the OSC_TimeRaw (and the WorstPassing value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the identified BPU converter that is used for MIL illumination across the specific temp and airflow range for a given program.

Notes: KtCATD_t_1_OSC_BestFailing - Use for norm ratio calculation for P0420

y/x	1.40	1.70	2.00	2.30	2.60	2.90	3.20	3.50	3.80	4.10	4.40	4.70	5.00	5.30	5.60	5.90	6.20
511.97	12.25	10.62	9.15	7.71	6.37	5.33	4.68	4.23	3.68	3.26	2.80	2.46	2.07	1.74	1.50	1.32	1.17
550.61	13.42	11.79	10.00	8.48	6.94	5.97	5.37	4.72	4.14	3.76	3.22	2.88	2.50	2.00	1.69	1.47	1.21
589.27	14.36	12.68	10.83	9.08	7.67	6.69	5.94	5.33	4.80	4.26	3.80	3.32	2.83	2.42	2.00	1.61	1.32
627.91	15.54	13.64	11.61	9.79	8.27	7.25	6.58	5.94	5.40	4.80	4.27	3.72	3.13	2.71	2.14	1.77	1.40
666.55	16.44	14.41	12.38	10.58	8.93	7.92	7.09	6.50	5.86	5.29	4.65	4.04	3.55	2.94	2.43	1.94	1.54
705.19	17.16	15.12	13.18	11.42	9.64	8.62	7.71	6.88	6.31	5.78	5.06	4.42	3.88	3.27	2.67	2.14	1.70
743.84	17.88	15.84	13.91	12.17	10.44	9.26	8.42	7.56	6.95	6.34	5.64	4.91	4.29	3.59	2.92	2.29	1.88
782.48	18.64	16.44	14.68	12.93	11.19	9.94	9.07	8.20	7.52	6.76	6.01	5.25	4.58	3.87	3.21	2.51	2.01
821.13	19.02	17.01	15.30	13.68	11.79	10.54	9.71	8.84	8.01	7.17	6.42	5.63	4.87	4.25	3.55	2.85	2.24

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0420_P0430_CatmonMinAirflowForWarmCatalystDetermination

Description: This is a 1x3 table with the axis being engine coolant temperature. The implementation of this cal value as a table also included some changes to the way that the WarmedUpEvents counter increments and resets. To summarize, whenever WarmedUpEvents resets to 0 (this could be either at startup, if the closed throttle time exceeds a cal value, or if the predicted exhaust temperature falls below the ExhWarmMin cal value), the appropriate MinAirflowToWrmupCat value is chosen from the table based on engine coolant at the time the WarmedUpEvents counter reset to 0. This cal value is used along with the min exhaust temp to increment the WarmedUpEvents counter.

Notes: KtCATD_dm_MinAirFlowToWrmCat - Used for P0420 and P0430. Axis is the engine coolant and the output is the minimum airflow required to warmup the catalyst.

y/x	0	45	90
1	12	6	4

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0420_P0430_CatmonMinEngineRunTimeToEnable

Description: This cal value is a 1x5 array of minimum engine run time values based on powerup coolant temperatures. When the appropriate required minimum engine run time value is chosen based on the coolant temperature at powerup, this value is the minimum time from engine start before stabilized conditions are met. Used in determining if a ValidIdleIsMet condition exists.

Notes: KtCATD_t_EngRunTimeMin - Used for P0420 and P0430. Axis is the coolant and the output is the min engine run time

y/x	40	50	60	70	80
1	120	100	100	100	100

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0420_WorstPassingOSCTableB1

Description: This table is a 9x17 table of WorstPassing (e.g. 120k) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the WorstPassing OSC value is found within this table for the measured temp and airflow and is used along with the OSC_TimeRaw (and the BestFailing OSC value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the WPA part across the temp and airflow range.

Notes: KtCATD_t_1_OSC_WorstPassing - Use for norm ratio calculation for P0420

y/x	1.40	1.70	2.00	2.30	2.60	2.90	3.20	3.50	3.80	4.10	4.40	4.70	5.00	5.30	5.60	5.90	6.20
511.97	21.38	18.97	16.68	14.50	12.89	11.82	10.90	10.13	9.31	8.55	7.70	6.81	6.01	5.01	4.06	3.34	2.72
550.61	22.49	19.93	17.32	15.38	13.76	12.50	11.62	10.64	9.88	9.06	8.19	7.32	6.48	5.55	4.63	3.75	3.08
589.27	23.51	20.96	18.09	16.22	14.43	13.15	12.12	11.20	10.28	9.52	8.65	7.73	6.84	5.96	5.09	4.16	3.49
627.91	24.53	21.93	18.76	16.72	14.94	13.57	12.59	11.67	10.84	9.98	9.04	8.17	7.30	6.32	5.40	4.51	3.75
666.55	25.30	22.59	19.37	17.13	15.45	14.11	12.97	12.18	11.23	10.27	9.41	8.42	7.67	6.74	5.81	4.97	4.05
705.19	25.81	23.36	20.09	17.75	15.90	14.60	13.47	12.54	11.61	10.59	9.71	8.85	7.91	7.12	6.21	5.19	4.28
743.84	26.22	23.97	20.66	18.25	16.51	15.24	14.06	13.09	11.97	11.00	10.07	9.10	8.25	7.35	6.52	5.55	4.66
782.48	26.67	24.53	21.28	18.92	17.18	15.73	14.62	13.67	12.49	11.46	10.43	9.41	8.62	7.66	6.89	5.77	4.88
821.13	27.13	24.94	21.80	19.53	17.57	16.30	15.22	14.14	13.07	11.92	10.91	9.87	8.99	7.97	7.04	5.96	4.99

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P050D_P1400_CatalystLightOffExtendedEngineRunTimeExit

Description: Exit Catalyst Warm-up mode if Engine Run Time is greater than this value. This table is based on percent ethanol (x-axis) and catmon's NormRatio_EWMA value (y-axis). The NormRatio_EWMA value determines the state of the catalyst. Typically, NormRatio_EWMA values below 0.35 (0 is bad and 1 is good) represent catalysts that have degraded. The emission performance of these degraded catalysts can be improved by extending catalyst light off of GetE85R_Pct_FFS_CompAtEngFloat.

Notes: KtCSEC_t_ExtendedEngineExit. Used for both P050D and P1400.

y/x	0	25	50	75	100
0.000	35	35	35	35	35
0.125	35	35	35	35	35
0.250	35	35	35	35	35
0.375	35	35	35	35	35
0.500	35	35	35	35	35
0.625	35	35	35	35	35
0.750	35	35	35	35	35
0.875	35	35	35	35	35
1.000	35	35	35	35	35

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P06B6_P06B7_OpenTestCktThrshMax

Description: Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

Notes: Used for P0325 and P0330. Cal name: KtKNKD_k_OpenTestCktMax. x-axis = Engine Speed (RPM).

Diagnostic fails when the filtered diagnostic output is between the OpenTestCktThrshMin and OpenTestCktThrshMax:

i.e. $KtKNKD_k_OpenTestCktMin < VaKNKD_k_OpenTestCktIntFilter < KtKNKD_k_OpenTestCktMax$

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.025	0.031	0.037	0.065	0.090	0.135	0.184	0.234	0.279	0.320	0.350	0.367	0.365	0.346	0.299	0.227	0.123

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P06B6_P06B7_OpenTestCktThrshMin

Description: Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

Notes: Used for P0325 and P0330. Cal name: KtKNKD_k_OpenTestCktMin. x-axis = Engine Speed (RPM).

Diagnostic fails when the filtered diagnostic output is between the OpenTestCktThrshMin and OpenTestCktThrshMax:

i.e. $KtKNKD_k_OpenTestCktMin < VaKNKD_k_OpenTestCktIntFilter < KtKNKD_k_OpenTestCktMax$

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.008	0.006	0.012	0.022	0.035	0.039	0.051	0.084	0.094	0.100	0.098	0.086	0.063	0.025	0.000	0.000	0.000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P1400_ColdStartDiagnosticDelayBasedOnEngineRunTime

Description: Quality weight-based on engine run time. This allows adjustment of the weighting factors at various engine run times in order to prevent the updating of the cumulative quality timer or to change the value of the average qualified residual energy calculation to prevent false Fails of the diagnostic under circumstances inappropriate to update the calculation of the average qualified residual value.

Notes: KtCSED_K_TimeWght - This is used for P1400.

y/x	0	2	3	5	11	16	21	27	32
1	0	1	1	1	1	1	1	1	1

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P1400_ColdStartDiagnosticDelayBasedOnEngineRunTimeCalAxis

Description: This is the x-axis for the KtCSED_K_TimeWght calibration table. Refer to the description for KtCSED_K_TimeWght for details.

Notes: KnCSED_t_TimeWght - This is used for P1400.

y/x	1	2	3	4	5	6	7	8	9
1	0	2	3	5	11	16	21	27	32

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P1400_EngineSpeedResidual_Axis

Description: This calibration is used as the x-axis for KtCSED_dm_Exh. An engine speed value will be chosen from this axis based on the value of VeSPDR_n_EngDsrd or actual engine speed. Subsequently, the engine speed value chosen from KnCSED_n_Exh determines the appropriate exhaust airflow value from the KtCSED_dm_Exh calibration table.

Notes: KnCSED_n_Exh-Used for P1400

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	400	500	600	700	750	800	860	880	900	925	980	1,025	1,075	1,100	1,200	1,300	2,000

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P1400_EngineSpeedResidual_Table

Description: This 1x17 table of engine exhaust flow values is used to calculate both the desired and the actual engine exhaust flow based on desired and actual engine speed. The desired engine exhaust flow is gathered from the desired engine speed (VeSPDR_n_EngDsrd). The value used for the actual engine exhaust flow is based on the actual engine RPM value.

Notes: KtCSED_dm_Exh - Used for P1400

y/x	400	500	600	700	750	800	860	880	900	925	980	1,025	1,075	1,100	1,200	1,300	2,000
1	0	2	4	5	5	5	5	6	7	8	10	12	12	12	12	12	12

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P1400_SparkResidual_Axis

Description: Calibratable axis into KtCSED_E_ExhEngyPerUnitMass. This is a table of spark values. Spark value used for desired spark is the desired spark during cat light off. Actual spark value used is the final commanded spark.

Notes: KnCSED_phi_ExhEngyPerUnitMass - Used for P1400

y/x	1	2	3	4	5	6	7	8	9
1	-30.00	-20.00	-10.00	0.00	5.00	10.00	25.00	40.00	50.00

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P1400_SparkResidual_Table

Description: Predicted engine-out energy potential based on either the desired cold start spark advance value or the actual spark advance value. ExhEngyPerUnitMass calibration is used to calculate both desired exhaust energy and actual energy. The desired and actual exhaust energy per unit mass values are used in part to calculate the desired exhaust energy per unit time and actual exhaust energy per unit time. Both desired and actual go into the residual exhaust energy per unit time calculation.

Notes: KtCSED_E_ExhEngyPerUnitMass - Used for P1400

y/x	-30	-20	-10	0	5	10	25	40	50
1	1.12	1.06	1.00	1.00	1.00	1.00	1.00	0.90	0.90

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P057B KtBRKI_K_CmpltTestPointWeight

Description:

Notes:

y/x	0.000	0.010	0.020	0.020	0.050	0.100	0.150	0.250	1.000
1	0	0	0	1	1	1	1	1	1

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P057B KtBRKI_K_FastTestPointWeight

Description:

Notes:

y/x	0.000	0.050	0.080	0.250	0.350	0.450	0.550	0.750	1.000
1	1	1	1	1	1	1	1	1	1

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0011_CamPosErrorLimlc1

Description: P0011 - Cam Position Error Limit for performance diagnostic

Notes: KtPHSD_phi_CamPosErrorLimlc1

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	20.0	20.0	20.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
800	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,200	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,600	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,000	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,400	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,800	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,200	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,600	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,000	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,400	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,800	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,200	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,600	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,000	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,400	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,800	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0011_PerfMaxlc1

Description: P0011 - Range of phaser travel where diagnostic cannot make a decision if both desired & measured positions are greater than

Notes:

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	10.0	10.0	10.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
2	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
3	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
4	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
5	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
6	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
7	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
8	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
9	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
10	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
11	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
12	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
13	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
14	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
15	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
16	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
17	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0011_StablePositionTimelc1

Description: P0011 - Delay after transient move

Notes: KtPHSD_t_StablePositionTimelc1

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
800	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
1,200	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
1,600	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
2,000	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
2,400	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
2,800	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
3,200	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
3,600	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
4,000	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
4,400	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
4,800	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
5,200	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
5,600	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
6,000	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
6,400	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
6,800	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0014_CamPosErrorLimEc1

Description: P0014 - Cam Position Error Limit for performance diagnostic

Notes: KtPHSD_phi_CamPosErrorLimEc1

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	20.0	20.0	20.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
800	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,200	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
1,600	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,000	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,400	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
2,800	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,200	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
3,600	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,000	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,400	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
4,800	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,200	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
5,600	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,000	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,400	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0
6,800	20.0	20.0	20.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0014_PerfMaxEc1

Description: P0014 - Range of phaser travel where diagnostic cannot make a decision if both desired & measured positions are greater than

Notes:

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	10.0	10.0	10.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
2	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
3	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
4	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
5	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
6	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
7	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
8	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
9	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
10	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
11	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
12	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
13	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
14	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
15	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
16	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0
17	10.0	10.0	10.0	20.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0	25.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0014_StablePositionTimeEc1

Description: P0014 - Delay after transient move

Notes: KtPHSD_t_StablePositionTimeEc1

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
800	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
1,200	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
1,600	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
2,000	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
2,400	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
2,800	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
3,200	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
3,600	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
4,000	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
4,400	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
4,800	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
5,200	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
5,600	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
6,000	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
6,400	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0
6,800	100.0	80.0	20.0	10.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	5.0	10.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0442: Volatility Time as a Function of Estimate of Ambient Temperature

Description: Data is Volatility Time (in seconds) and Axis is Estimated Ambient Coolant in Deg C

Notes: KtEONV_t_VolatilityTimeMax

y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	30	30	30	30	40	50	70	90	170	170	170	170	170	170	170	170	170

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0442: Engine Off Time Before Vehicle Off Maximum as a Function of Est Ambient Temperature Table

Description: Data is Engine Off Time Before Vehicle Off Maximum Table (in seconds) and Axis is Estimated Ambient Coolant in Deg C

Notes: KtEONV_t_EngOffTimeBefVehOffMax

y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	44	44	44	44	68	82	105	153	320	480	480	480	480	480	480	480	480

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0442: EONV Pressure Threshold (Pascals) Table

Description: Data is EONV Pressure Threshold in Pascals, X axis (horizontal) is fuel level in % from 0 to 100 with step size 6.25, and Y axis (vertical) is temperature in deg C from -10 to 80 with step size 5.625

Notes: KtEONV_p_PressureThreshold

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
2	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
3	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
4	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
5	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
6	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
7	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
8	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
9	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
10	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
11	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
12	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
13	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
14	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
15	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
16	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0
17	-498.2	-498.2	-498.2	-498.2	-498.2	-498.2	-478.2	-458.3	-438.3	-418.4	-398.4	-378.5	-358.8	-338.8	-318.9	-299.0	-299.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0461, P2066, P2636: Transfer Pump Enable Time Table

Description: Data is TransferPumpOnTimeLimit (in seconds) and Axis is Fuel Level in %

Notes: KtFLVC_t_XferFuelPmpOnTmLim

P0461, P2066, P2636: Transfer Pump Enable Time Table - Part 1

y/x	0	3	6	9	13	16	19	22	25	28	31	34	38	41	44	47	50
1	30	35	40	45	50	55	60	65	70	85	90	95	135	135	160	160	260

P0461, P2066, P2636: Transfer Pump Enable Time Table - Part 2

y/x	53	56	59	63	66	69	72	75	78	81	84	88	91	94	97	100	
1	260	360	360	360	360	360	460	460	460	460	460	460	460	460	460	460	

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0496: Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level Table

Description: Data is Purge Valve Leak Test Engine Vacuum Test Time (in seconds) and Axis is Fuel Level in %

Notes: KtEVPD_t_PVLT_EngineVacTimeCold

y/x	0	6	12	19	25	31	37	44	50	56	62	69	75	81	87	94	100
1	100	100	80	75	70	65	60	60	60	60	60	55	50	45	40	30	30

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300 EngineOverSpeedLimit

Description: Engine OverSpeed Limit versus gear

Notes: Used for P0300-P0308. Cal Name: KaEOSC_n_EngOvrspdLimitGear

P0300 EngineOverSpeedLimit - Part 1

y/x	CeTGRR_e_TransGr1	CeTGRR_e_TransGr2	CeTGRR_e_TransGr3	CeTGRR_e_TransGr4	CeTGRR_e_TransGr5	CeTGRR_e_TransGr6	CeTGRR_e_TransGrEVT1
1	6,500	6,500	6,500	6,500	6,500	6,500	6,500

P0300 EngineOverSpeedLimit - Part 2

y/x	CeTGRR_e_TransGrEVT2	CeTGRR_e_TransGrNaut	CeTGRR_e_TransGrRvrs	CeTGRR_e_TransGrPark	CeTGRR_e_TransGr7	CeTGRR_e_TransGr8	
1	6,500	4,000	4,000	4,000	4,000	4,000	

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300 Number of Normals

Description: Number of Normals for the Driveline Ring Filter
 After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

Notes: Used for P0300-P0308. Cal Name: KaMSFD_Cnt_NumOfNormalsFil

y/x	0	1	2	3	4	5	6	7	8
1	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300 Ring Filter

Description: Driveline Ring Filter

After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

Notes: Used for P0300-P0308. Cal Name: KaMSFD_Cnt_RingFilter

y/x	0	1	2	3	4	5	6	7	8
1	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_Abnormal Cylinder Mode

Description: Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Cylinder Mode Equation)

Notes: Used for P0300-P0308. Cal Name: KaMSFD_Cnt_CylAbnormal

y/x	0	1	2	3	4	5	6	7	8
1	2.00	2.00	2.00	4.00	4.00	4.00	4.00	4.00	4.00

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_Abnormal Rev Mode

Description: Abnormal Rev Mode Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Rev Mode Equation)

Notes: Used for P0300-P0308. Cal Name: KaMSFD_Cnt_RevAbnormal

y/x	0	1	2	3	4	5	6	7	8
1	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_Abnormal SCD Mode

Description: Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (SCD Mode Equation)

Notes: Used for P0300-P0308. Cal Name: KaMSFD_Cnt_SCD_CylAbnormal

y/x	0	1	2	3	4	5	6	7	8
1	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_AFM_Decel

Description: Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_DoDCylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	
0	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
13	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
19	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
31	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
38	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
44	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
50	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
56	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
63	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
69	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
75	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
81	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
88	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
94	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
100	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_Catalyst_Damage_Misfire_Percentage

Description: Catalyst Damaging Misfire Percentage" Table whenever secondary conditions are met.

Notes: Used for P0300-P0308. Cal Name: KtMSFD_Pct_CatalystMisfire

y/x	0	1,000	2,000	3,000	4,000	5,000	6,000	7,000
0	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
10	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
20	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
30	22.5	22.5	22.5	22.5	22.5	22.5	22.5	22.5
40	22.5	22.5	22.5	22.5	22.5	22.5	22.0	21.0
50	22.5	22.5	22.5	22.5	21.5	20.5	17.5	16.5
60	22.5	22.5	22.5	20.5	17.5	16.5	15.5	15.0
70	22.5	21.0	19.5	19.0	13.5	15.5	19.0	21.0
80	22.5	19.0	17.0	14.5	12.5	18.0	21.0	22.0
90	22.0	17.5	14.0	12.5	14.5	18.5	22.0	22.5
100	21.5	20.0	18.5	12.5	15.5	20.5	22.5	22.5

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_CylMode_Decel

Description: Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_CylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	
10	700	550	450	380	320	270	230	190	160	105	80	68	50	40	34	28	23	20	15	12	10	9	7	5	5	5	5
12	755	590	485	410	345	290	245	205	170	115	85	72	55	40	36	24	21	20	16	12	10	9	7	5	5	5	5
15	795	640	525	435	365	305	260	220	180	125	90	75	60	42	38	32	21	20	16	12	10	9	7	5	5	5	5
18	840	685	565	475	395	335	285	240	200	135	100	80	65	52	40	30	25	20	17	13	10	9	7	5	5	5	5
22	930	765	645	540	460	390	325	270	230	155	115	90	74	60	47	37	30	25	15	13	10	9	7	5	5	5	5
26	1,050	875	745	630	530	450	380	320	270	185	135	105	85	69	55	45	37	30	16	14	11	10	7	6	5	5	5
31	1,160	980	840	720	610	520	445	380	325	235	175	140	110	90	72	58	48	38	24	15	12	10	7	6	6	5	5
38	1,270	1,085	935	805	695	595	510	440	380	280	215	170	135	110	88	72	58	47	28	18	13	10	8	7	6	5	5
45	1,380	1,195	1,035	895	775	680	575	500	435	330	260	205	165	130	105	85	69	55	34	21	15	11	9	7	8	7	7
54	1,490	1,300	1,130	980	850	740	640	560	490	380	300	235	190	150	120	98	79	63	40	23	17	12	11	10	9	8	8
65	1,660	1,440	1,250	1,090	950	830	720	630	545	425	340	270	215	175	140	110	90	72	47	27	21	15	14	13	12	11	11
77	1,840	1,600	1,390	1,210	1,050	910	790	690	600	475	380	300	240	195	155	123	100	80	53	31	24	18	15	14	13	12	12
91	2,000	1,740	1,510	1,310	1,140	990	860	750	655	525	420	330	265	215	170	135	110	88	60	36	28	21	18	15	14	13	13
107	2,170	1,890	1,640	1,430	1,240	1,080	940	820	710	575	460	360	290	235	185	148	120	96	66	42	33	25	23	19	17	15	15
125	2,320	2,020	1,760	1,530	1,330	1,160	1,010	880	770	625	500	390	315	255	200	160	130	104	72	48	38	29	27	23	21	19	19
145	2,500	2,170	1,890	1,640	1,430	1,240	1,080	940	830	675	540	420	340	275	215	173	140	112	79	54	43	32	32	27	23	21	21
155	2,670	2,320	2,020	1,760	1,530	1,330	1,160	1,010	890	725	580	450	365	295	230	185	150	120	85	60	48	36	38	31	27	24	24

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_CylMode_Jerk

Description: Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_ddt_CylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
10	1,330	1,110	920	770	640	530	440	365	300	220	150	105	78	68	48	39	33	33	29	25	17	16	14	13	13	12
12	1,390	1,160	960	810	680	560	470	390	325	240	165	105	85	65	52	42	35	33	29	25	17	16	14	13	13	12
15	1,570	1,310	1,090	910	750	620	520	430	360	260	180	125	91	72	56	43	39	33	29	25	17	16	14	13	13	12
18	1,890	1,570	1,310	1,090	910	750	620	520	435	305	210	145	105	82	65	51	45	35	29	25	17	16	14	13	13	12
22	2,280	1,900	1,590	1,330	1,110	920	770	640	530	360	245	175	125	100	80	66	52	39	33	25	18	16	14	13	13	12
26	2,650	2,210	1,850	1,530	1,270	1,070	880	740	620	415	285	200	145	113	93	74	62	50	37	25	20	17	14	13	13	12
31	3,410	2,830	2,370	1,980	1,650	1,380	1,140	950	780	510	330	235	170	130	105	90	77	65	39	26	22	20	17	16	13	12
38	4,080	3,410	2,830	2,370	1,980	1,650	1,380	1,140	950	600	385	275	195	150	125	105	91	78	44	29	23	21	18	17	14	13
45	4,850	4,040	3,370	2,810	2,340	1,950	1,630	1,350	1,120	710	440	320	230	175	145	125	105	91	50	31	25	22	20	17	16	14
54	5,540	4,620	3,850	3,210	2,680	2,240	1,860	1,550	1,290	830	510	370	265	210	170	145	125	105	57	35	27	23	21	17	16	14
65	6,250	5,210	4,340	3,610	3,020	2,510	2,090	1,740	1,460	950	590	430	310	245	200	170	145	125	66	40	31	26	23	21	18	17
77	6,990	5,820	4,850	4,040	3,370	2,810	2,340	1,950	1,630	1,070	660	495	365	295	240	200	170	145	76	46	35	29	26	23	21	18
91	7,740	6,450	5,370	4,470	3,730	3,110	2,590	2,160	1,790	1,200	750	560	425	340	280	235	195	170	88	52	39	33	30	27	23	21
107	8,450	7,050	5,880	4,900	4,080	3,410	2,830	2,370	1,980	1,320	850	620	480	390	325	275	230	195	91	60	46	39	36	33	27	25
125	9,330	7,770	6,470	5,400	4,500	3,740	3,120	2,600	2,170	1,440	950	700	540	440	370	310	260	220	104	69	56	48	44	39	34	30
145	10,300	8,580	7,150	5,950	4,970	4,130	3,450	2,870	2,390	1,560	1,050	770	600	495	415	350	295	245	117	78	70	59	52	46	40	36
155	11,260	9,390	7,830	6,530	5,430	4,520	3,770	3,150	2,630	1,730	1,140	850	660	550	460	390	325	275	130	88	83	68	59	52	46	42

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_IdleCylModeDecel

Description: Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMSFD_dt_IdleCylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
8	4,350	3,000	2,000	1,310	890	605	445	320	265	178	116	84	64
9	4,550	3,150	2,050	1,340	910	620	455	330	270	182	118	86	66
11	4,750	3,300	2,100	1,370	930	635	465	340	275	186	122	88	68
12	4,950	3,350	2,150	1,400	950	650	475	350	280	190	125	90	70
13	5,250	3,520	2,220	1,440	975	670	490	360	290	194	128	93	72
14	5,600	3,680	2,300	1,470	995	690	505	370	295	200	132	95	75
15	5,900	3,850	2,370	1,510	1,020	710	520	385	305	204	134	98	77
16	6,250	4,010	2,450	1,540	1,040	725	535	395	310	208	138	101	79
17	6,550	4,180	2,520	1,580	1,065	745	550	405	320	214	140	103	82
18	6,850	4,340	2,600	1,610	1,090	765	565	415	325	218	144	106	84
19	7,200	4,510	2,670	1,650	1,110	785	575	430	335	222	146	109	86
21	7,500	4,670	2,750	1,680	1,135	805	590	440	340	226	150	112	88
22	7,800	4,840	2,820	1,720	1,160	825	605	450	350	232	152	114	91
25	8,150	5,000	2,900	1,750	1,180	840	620	460	355	236	156	117	93
25	8,450	5,170	2,970	1,790	1,205	860	635	475	365	240	158	120	95
27	8,800	5,330	3,050	1,820	1,225	880	650	485	370	246	162	122	98
29	9,100	5,500	3,120	1,860	1,250	900	665	495	380	250	165	125	100

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_IdleCylModeJerk

Description: Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMSFD_ddt_IdleCylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
8	4,280	3,550	2,850	2,150	1,500	1,120	880	680	525	270	175	125	100
9	4,350	3,630	2,930	2,190	1,550	1,150	890	695	535	275	180	130	105
11	4,460	3,700	3,010	2,235	1,600	1,190	905	710	545	280	185	135	110
12	4,600	3,820	3,080	2,295	1,650	1,240	930	725	555	285	190	140	115
13	4,780	3,940	3,160	2,365	1,730	1,300	970	745	565	290	195	145	120
14	4,990	4,090	3,270	2,455	1,800	1,360	1,010	765	575	295	200	150	125
15	5,280	4,290	3,400	2,565	1,900	1,420	1,050	785	585	300	205	155	130
16	5,540	4,490	3,560	2,680	1,960	1,440	1,065	795	590	310	215	160	135
17	5,810	4,670	3,700	2,790	2,020	1,470	1,080	805	600	320	220	170	145
18	6,070	4,870	3,870	2,900	2,080	1,490	1,095	815	605	330	230	175	150
19	6,340	5,070	4,020	3,010	2,140	1,510	1,110	825	615	340	235	185	160
21	6,600	5,270	4,170	3,120	2,200	1,540	1,125	835	620	350	245	190	165
22	6,860	5,460	4,320	3,230	2,260	1,560	1,140	840	625	360	250	195	170
25	7,130	5,660	4,480	3,350	2,320	1,580	1,155	850	635	370	260	205	180
25	7,390	5,850	4,630	3,460	2,380	1,610	1,170	860	640	380	265	210	185
27	7,660	6,040	4,790	3,570	2,440	1,630	1,185	870	650	390	275	215	195
29	7,920	6,230	4,940	3,680	2,500	1,655	1,200	880	655	400	280	224	200

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_IdleSCD_Decel

Description: Crankshaft decel threshold while in SCD mode. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_dt_SCD_IdleMode

Note: Misfire's Load term is %, but not PID\$04. PID \$04 is not robust to temperature and altitude shifts. (especially decel and jerk thresholds since they track actual air trapped in cylinder)

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
9	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
11	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
13	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
15	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
17	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
19	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
21	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
27	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
29	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_IdleSCD_Jerk

Description: Crankshaft jerk threshold while in SCD mode. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_ddt_SCD_IdleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
9	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
11	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
13	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
15	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
17	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
19	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
21	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
25	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
27	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
29	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_Max_PatternMultiplier

Description: Crankshaft should return to normal after the misfire. If crankshaft snap value after the misfire being evaluated is larger than the misfire's Jerk threshold times this multiplier, its not a real misfire. However, if random misfire occurs every engine cycle, more noise is allowed to be considered "normal" since the crankshaft does not have time to fully return to normal before the next misfire occurs.

Notes: Used for P0300-P0308. Cal Name: KtMSFD_K_SCD_MaxPptrnRecogMult

y/x	0	1,000	1,500	2,000	2,500	3,000	3,500	4,000	5,500
1	1.70	1.70	1.70	1.70	1.70	1.70	1.70	1.70	1.70

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_Min_PatternMultiplier

Description: Crankshaft should return to normal after the misfire. If crankshaft snap value after single isolated misfire being evaluated is larger than the misfire's Jerk threshold times this multiplier, its not a real misfire.

Notes: Used for P0300-P0308. Cal Name: KtMSFD_K_SCD_MinPttrnRecogMult

y/x	0	1,000	1,500	2,000	2,500	3,000	3,500	4,000	5,500
1	1.00	1.00	1.10	1.20	1.30	1.35	1.25	1.30	1.30

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_RevMode_Decel

Description: Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_RevolutionMode

y/x	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
10	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	25	18	14	12	10
12	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	25	18	14	12	10
15	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	25	18	14	12	10
18	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	25	18	14	12	10
22	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	29	22	14	12	10
26	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	33	26	18	12	10
31	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	38	29	22	14	10
38	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	43	33	25	16	11
45	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	48	38	29	20	14
54	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	54	45	35	27	21
65	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	63	52	43	34	29
77	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	72	62	52	45	39
91	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	82	70	61	51	46
107	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	90	79	69	60	53
125	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	100	87	78	68	61
145	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	109	96	86	77	68
155	32,767	32,767	32,767	32,767	32,767	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	120	105	95	86	76

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_SCD_Decel

Description: Crankshaft decel threshold. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_dt_SCD_OffIdleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
15	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
31	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
38	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
45	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
54	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
65	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
77	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
91	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
107	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
125	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
145	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
155	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_SCD_Jerk

Description: Crankshaft jerk threshold. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF_ddt_SCD_OffIdleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
15	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
31	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
38	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
45	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
54	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
65	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
77	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
91	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
107	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
125	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
145	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
155	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_TOSSRoughRoadThres

Description: Only used if Rough Road source = TOSS: dispersion value on Transmission Output Speed Sensor above which rough road is indicated present

Notes: Used for P0300-P0308. Cal Name: KtRRDI_a_RoughRoadThresh

y/x	600	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000
100	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
300	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
600	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
900	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,200	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,500	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,800	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
2,100	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
2,400	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
2,700	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
3,000	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
3,300	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
3,600	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
4,200	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_WSSRoughRoadThres

Description: Only used if Wheel speed from ABS is used. If difference between wheel speed readings is larger than this limit, rough road is present

Notes: Used for P0300-P0308. Cal Name: KtRRDI_a_WhlSpdRoughRoadLim

y/x	0	12	24	36	48	60	72	85	97	109	121	133	145	157	169	181	193
1	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_ZeroTorqBaro

Description: adjusts zero torque for altitude

Notes: Used for P0300-P0308. Cal Name: KtMSFD_K_ZeroTorqBaro

y/x	65	70	75	80	85	90	95	100	105
1	0.82	0.85	0.88	0.90	0.93	0.95	0.97	1.00	1.03

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_ZeroTorqDoD

Description: Zero torque engine load while in Active Fuel Management

Notes: Used for P0300-P0308. Cal Name: KtMSFD_ZeroTorqDoD

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
1	15.20	14.30	13.70	13.10	12.90	12.70	11.80	11.40	11.30	11.00	10.80	10.80	10.70	10.70	10.80	10.80	10.90	11.00	14.00	16.50	19.50	22.50	25.50	28.50	32.00	35.00

14 OBDG02 ECM Supporting Tables

Initial Supporting table - P0300_ZeroTorqueEngLoad

Description: %air load that represents Zero Brake torque along the Neutral rev line. The Zero torque threshold is adjusted for Baro via P0300_ZeroTorqueBaro

Notes: Used for P0300-P0308. Cal Name: KtMISF_ZeroTorqSpd

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
1	15.20	14.30	13.70	13.10	12.90	12.70	11.80	11.40	11.30	11.00	10.80	10.80	10.70	10.70	10.80	10.80	10.90	11.00	14.00	16.50	19.50	22.50	25.50	28.50	32.00	35.00

14 OBDG02 ECM Supporting Tables

Fault Bundle Definitions

Bundle Name: 5VoltReferenceA_FA

P0641

Bundle Name: 5VoltReferenceB_FA

P0651

Bundle Name: 5VoltReferenceMAP_OOR_Fit

P0697

Bundle Name: A/F Imbalance Bank1

P219A

Bundle Name: A/F Imbalance Bank2

P219B

Bundle Name: AAP3_SnsrCktFA

P222C, P222D

Bundle Name: AAP3_SnsrCktFP

P222C, P222D

Bundle Name: AccCktLo_FA

P2537

Bundle Name: AcceleratorPedalFailure

P2122, P2123, P2127, P2128, P2138, P0697, P06A3

Bundle Name: ACCMLostComm

U016B

Bundle Name: ACFailedOnSD

See ACCM Document

Bundle Name: ACHighSidePressSnsrCktFA

P0532, P0533

Bundle Name: ACThrmlRefrigSpdVld

See ACCM Document

Bundle Name: AfterThrottlePressTFTKO

Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.

Bundle Name: AfterThrottlePressureFA

Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.

Bundle Name: AfterThrottleVacuumTFTKO

Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.

Bundle Name: AIR System FA

P0411, P2440, P2444

Bundle Name: AIRPumpControlCircuit FA

P0418, P2257, P2258

Bundle Name: AIRSystemPressureSensor FA

P2430, P2431, P2432, P2433, P2435, P2436, P2437, P2438

14 OBDG02 ECM Supporting Tables

Fault Bundle Definitions

Bundle Name: AIRValveControlCircuit FA
P0412, P041F, P044F
Bundle Name: AmbPresSnsr2_CktFA
P222C, P222D
Bundle Name: AnyCamPhaser_FA
P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, P2088, P2089, P2090, P2091, P2092, P2093, P2094, P2095
Bundle Name: AnyCamPhaser_TFTKO
P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, P2088, P2089, P2090, P2091, P2092, P2093, P2094, P2095
Bundle Name: BrakeBoosterSensorFA
P0556, P0557, P0558
Bundle Name: BrakeBoosterVacuumValid
P0556, P0557, P0558
Bundle Name: BSTR_b_IC_Pmp_EffPerfTFTKO
P026A
Bundle Name: CamLctnExhFA
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: CamLctnIntFA
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: CamSensor_FA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensor_TFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorAnyLctnTFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorAnyLocationFA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorFA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorTFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CatalystSysEfficiencyLoB1_FA
P0420
Bundle Name: CatalystSysEfficiencyLoB2_FA
P0430
Bundle Name: ClutchPstnSnsr FA
P0806, P0807, P0808
Bundle Name: ClutchPstnSnsrCktHi FA
P0808

14 OBDG02 ECM Supporting Tables

Fault Bundle Definitions

Bundle Name: ClutchPstnSnsrCktLo FA
P0807
Bundle Name: ClutchPstnSnsrNotLearned
P080A
Bundle Name: CommBusAOff_VICM_FA
U0073
Bundle Name: CommBusBOff_VICM_FA
U0074
Bundle Name: CoolingFanSpeedTooHigh_FA
P0495
Bundle Name: CrankCamCorrelationTFTKO
P0016, P0017, P0018, P0019
Bundle Name: CrankExhaustCamCorrelationFA
P0017, P0019
Bundle Name: CrankExhaustCamCorrFA
P0017, P0019
Bundle Name: CrankIntakeCamCorrelationFA
P0016, P0018
Bundle Name: CrankIntakeCamCorrFA
P0016, P0018
Bundle Name: CrankSensor_FA
P0335, P0336
Bundle Name: CrankSensor_TFTKO
P0335, P0336
Bundle Name: CrankSensorFA
P0335, P0336
Bundle Name: CrankSensorFaultActive
P0335, P0336
Bundle Name: CrankSensorTestFailedTKO
P0335, P0336
Bundle Name: CrankSensorTFTKO
P0335, P0336
Bundle Name: CylDeacDriverFault
P3401, P03403, P03404, P3409, P03411, P03412, P3417, P3419, P3420, P3425, P3427, P3428, P3433, P3435, P3436, P3441, P3443, P3444, P3449, P3451, P3452, P3457, P3459, P3460
Bundle Name: CylDeacSystemTFTKO
P3400
Bundle Name: ECT_Sensor_Ckt_FA

14 OBDG02 ECM Supporting Tables

Fault Bundle Definitions

P0117, P0118, P0119
Bundle Name: ECT_Sensor_Ckt_FP
P0117, P0118
Bundle Name: ECT_Sensor_Ckt_High_FP
P0118
Bundle Name: ECT_Sensor_Ckt_Low_FP
P0117
Bundle Name: ECT_Sensor_Ckt_TFTKO
P0117, P0118, P0119
Bundle Name: ECT_Sensor_Ckt_TPTKO
P0117, P0118, P0019
Bundle Name: ECT_Sensor_DefaultDetected
P0117, P0118, P0116, P0125
Bundle Name: ECT_Sensor_FA
P0117, P0118, P0116, P0125, P0128
Bundle Name: ECT_Sensor_Perf_FA
P0116
Bundle Name: ECT_Sensor_TFTKO
P0117, P0118, P0116, P0125, P0119
Bundle Name: EGRValve_FP
P0405, P0406, P042E
Bundle Name: EGRValveCircuit_FA
P0403, P0404, P0405, P0406
Bundle Name: EGRValveCircuit_TFTKO
P0403, P0404, P0405, P0406
Bundle Name: EGRValvePerformance_FA
P0401, P042E
Bundle Name: EGRValvePerformance_TFTKO
P0401, P042E
Bundle Name: ELCP_PumpCircuit_FA
P2400, P2401, P2402
Bundle Name: ELCP_SwitchCircuit_FA
P2418, P2419, P2420
Bundle Name: ELCP_Circuit_FA
P24BA, P24BB
Bundle Name: EngineMetalOvertempActive
P1258
Bundle Name: EngineMisfireDetected_FA

14 OBDG02 ECM Supporting Tables

Fault Bundle Definitions

P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308

Bundle Name: EngineMisfireDetected_TFTKO

P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308

Bundle Name: EngineModeNotRunTimer_FA

P2610

Bundle Name: EngineModeNotRunTimerError

P2610

Bundle Name: EnginePowerLimited

P0068, P00C8, P00C9, P00CA, P0090, P0091, P0092, P0122, P0123, P0191, P0192, P0193, P0222, P0223, P0601, P0604, P0606, P0697, P06A3, P06DB, P06DE, P0A1D, P1104, P127A, P127C, P127D, P15F2, P160D, P160E, P1682, P16A0, P16A1, P16A2, P16F3, P2100, P2101, P2102, P2103, P2122, P2123, P2127, P2128, P2135, P2138, P215B, P2176, P228C, P228D, U0073, U0074, U0293, U1817

Bundle Name: EngineTorqueEstInaccurate

EngineMisfireDetected_FA, FuelInjectorCircuit_FA, FuelInjectorCircuit_TFTKO, FuelTrimSystemB1_FA, FuelTrimSystemB2_FA, MAF_SensorTFTKO, MAP_SensorTFTKO, EGRValuePerforamnce_FA

Bundle Name: EngModeNotRunTmErr

P2610

Bundle Name: EngOilModeledTempValid

ECT_Sensor_FA, IAT_SensorCircuitFA

Bundle Name: EngOilPressureSensorCktFA

P0522, P0523

Bundle Name: EngOilPressureSensorFA

P0521, P0522, P0523

Bundle Name: EngOilTempFA

EngOilTempSensorCircuitFA, EngOilModeledTempValid, P16F3

EngOilTempFA - Other Definitions:

P16F3 with GetXOYR_b_SecurityFlt(CeXOYR_e_EOTR_SecurityFlt)

Bundle Name: EngOilTempSensorCircuitFA

P0197, P0198

Bundle Name: Ethanol Composition Sensor FA

P0178, P0179, P2269

Bundle Name: EvapEmissionSystem_FA

P0455, P0446

Bundle Name: EvapExcessPurgePsbl_FA

ELCP sealed/vented fuel system, P0442, P0455, P0458 OR Conventional fuel system, P0442, P0455, P0458, P0496

Bundle Name: EvapFlowDuringNonPurge_FA

P0496

Bundle Name: EvapPurgeSolenoidCircuit_FA

P0443, P0458, P0459

Bundle Name: EvapReducedPurgePsbl_FA

14 OBDG02 ECM Supporting Tables

Fault Bundle Definitions

ELCP sealed/vented fuel system, P0443, P0446, P0449, P0459, P0497, P0499, P1463, P2419, P2422 OR Conventional fuel system, P0443, P0446, P0455, P0459, P0498

Bundle Name: EvapSmallLeak_FA

P0442

Bundle Name: EvapVentSolenoidCircuit_FA

P0449, P0498, P0499

Bundle Name: ExhaustCamSensor_FA

P0017, P0019, P0365, P0366, P0390, P0391

Bundle Name: ExhaustCamSensor_TFTKO

P0017, P0019, P0365, P0366, P0390, P0391

Bundle Name: ExhaustCamSensorFA

P0017, P0019, P0365, P0366, P0390, P0391

Bundle Name: ExhaustCamSensorTFTKO

P0017, P0019, P0365, P0366, P0390, P0391

Bundle Name: FanOutputDriver_FA

P0480, P0481, P0482, P0691, P0692, P0693, P0694, P0695, P0696, P1485 (EREV), P1486 (EREV), P1487 (EREV)

Bundle Name: FHPD_b_HPC_PresErrNeg_FA

P228D

Bundle Name: FHPD_b_HPC_PresErrNeg_TFTKO

P228D

Bundle Name: FHPD_b_HPC_PresErrPos_FA

P228C

Bundle Name: FHPD_b_HPC_PresErrPos_TFTKO

P228C

Bundle Name: FHPD_b_HPC_Windup_TFTKO

P0089

Bundle Name: FHPD_b_HPC_Windup_FA

P0089

Bundle Name: FHPD_b_PumpCurr_FA

P163A

Bundle Name: FHPD_b_PumpCurr_TFTKO

P163A

Bundle Name: FHPR_b_FRP_SnsrCkt_FA

P0192, P0193, P127C, P127D

Bundle Name: FHPR_b_FRP_SnsrCkt_TFTKO

P0192, P0193, , P127C, P127D

Bundle Name: FHPR_b_FRP_SnsrPerfDiag_FA

P0191, P127A

Bundle Name: FHPR_b_FRP_SnsrPerfDiag_TFTKO

14 OBDG02 ECM Supporting Tables

Fault Bundle Definitions

P0191, P127A
Bundle Name: FHPR_b_PumpCkt_FA
P0090, P0091, P0092, P00C8, P00C9, P00CA
Bundle Name: FHPR_b_PumpCkt_TFTKO
P0090, P0091, P0092, P00C8, P00C9, P00CA
Bundle Name: FourWheelDriveLowStateInvalid
P2771
Bundle Name: FTP_SensorCircuit_FA
P0452, P0453
Bundle Name: FuelInjectorCircuit_FA
PFI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P0274, P0277, P0280, P0283 SIDI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216E, P217B, P217E, P2148, P2151, P2154, P2157, P216C, P216F, P217C, P217F, P1248, P1249, P124A, P124B, P124C, P124D, P124E, P124F
Bundle Name: FuelInjectorCircuit_TFTKO
PFI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P0274, P0277, P0280, P0283 SIDI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216E, P217B, P217E, P2148, P2151, P2154, P2157, P216C, P216F, P217C, P217F, P1248, P1249, P124A, P124B, P124C, P124D, P124E, P124F
Bundle Name: FuelLevelDataFault
P0461, P0462, P0463, P2066, P2067, P2068
Bundle Name: FuelTankPressureSnsrCkt_FA
P0452, P0453
Bundle Name: HumidityFA
P0097, P0098, P11C2, P11C3, P2227, P2228, P2229, P2230
Bundle Name: HumTempSnsrCktFA
P0097, P0098
Bundle Name: HumTempSnsrCktFP
P0097, P0098
Bundle Name: HumTempSnsrFA
P0096, P0097, P0098, P0099
Bundle Name: IAC_SystemRPM_FA
P0506, P0507
Bundle Name: IAT_ContCorrFA
P2199
Bundle Name: IAT_SensorCircuitFA
P0112, P0113
Bundle Name: IAT_SensorCircuitFP
P0112, P0113

14 OBDG02 ECM Supporting Tables

Fault Bundle Definitions

Bundle Name: IAT_SensorCircuitTFTKO
P0112, P0113
Bundle Name: IAT_SensorFA
P0111, P0112, P0113, P0114
Bundle Name: IAT_SensorTFTKO
P0111, P0112, P0113, P0114
Bundle Name: IgnitionOffTimer_FA
P2610
Bundle Name: IgnitionOffTimeValid
P2610
Bundle Name: IgnitionOutputDriver_FA
P0351, P0352, P0353, P0354, P0355, P0356, P0357, P0358, P2300, P2301, P2303, P2304, P2306, P2307, P2309, P2310, P2312, P2313, P2315, P2316, P2318, P2319, P2321, P2322
Bundle Name: IntakeCamSensor_FA
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntakeCamSensor_TFTKO
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntakeCamSensorFA
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntakeCamSensorTFTKO
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntkCamPhaser_FA
P0010, P0011, P0020, P0021, P2088, P2089, P2092, P2093
Bundle Name: KS_Ckt_Perf_B1B2_FA
P0324, P0325, P0326, P0327, P0328, P0330, P0332, P0333, P06B6, P06B7
Bundle Name: LostCommBCM_FA
U0140
Bundle Name: LostCommBusB_VICM_FA
U182D
Bundle Name: LowFuelConditionDiagnostic
LowFuelConditionDiagnostic - Other Definitions: Flag set to TRUE if the fuel level < 10.0 % AND No Active DTCs: FuelLevelDataFault, P0462, P0463 for at least 30.0 seconds
Bundle Name: MAF_SensorPerfFA
P0101
Bundle Name: MAF_SensorPerfTFTKO
P0101
Bundle Name: MAF_Snsr1_FA

14 OBDG02 ECM Supporting Tables

Fault Bundle Definitions

P0101, P0102, P0103
Bundle Name: MAF_Snsr2_FA
P010B, P010C, P010D
Bundle Name: MAP_EngineVacuumStatus
P0106, P0107, P0108 Fault Active OR P0107, P0108 Fault Pending
Bundle Name: MAP_SensorCircuitFA
P0107, P0108
Bundle Name: MAP_SensorCircuitFP
P0107, P0108
Bundle Name: MAP_SensorFA
P0106, P0107, P0108
Bundle Name: MAP_SensorPerfFA
P0106
Bundle Name: MAP_SensorPerfTFTKO
P0106
Bundle Name: MAP_SensorTFTKO
P0106, P0107, P0108
Bundle Name: MnfdTempSensorCktFA
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
Bundle Name: MnfdTempSensorCktFP
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
Bundle Name: MnfdTempSensorCktTFTKO
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
Bundle Name: MnfdTempSensorFA
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
Bundle Name: MnfdTempSensorTFTKO
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
Bundle Name: ModuleOffTime_FA
P2610
Bundle Name: ModuleOffTimeErr
P2610
Bundle Name: OAT_AmbientFilteredFA
ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor_FA, IAT_SensorFA, ECT_Sensor_DefaultDetected, MAF_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: not applicable. All other cases: not applicable.
Bundle Name: OAT_AmbientSensorFA
ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: not applicable. All other cases: not applicable.

14 OBDG02 ECM Supporting Tables

Fault Bundle Definitions

Bundle Name: OAT_EstAmbTemp_FA
ELCP sealed/vented fuel system, P0071, P0072, P0073, P0502, P0503, P0722, P0723 OR Conventional fuel system, P0071, P0072, P0073, P0074, P2610
Bundle Name: OAT_PtEstFiltFA
ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor_FA, IAT_SensorFA, ECT_Sensor_DefaultDetected, MAF_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: VehicleSpeedSensor_FA, IAT_SensorFA, MAF_SensorFA. All other cases: EngModeNotRunTmErr, VehicleSpeedSensor_FA, IAT_SensorFA, ECT_Sensor_DefaultDetected.
Bundle Name: OAT_PtEstRawFA
ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: IAT_SensorFA. All other cases: IAT_SensorFA, ECT_Sensor_DefaultDetected.
Bundle Name: OilPmpCktFA
P06DA, P06DB, P06DC
OilPmpCktFA - Other Definitions: Output Driver Codes
Bundle Name: OilPmpFA
P06DA, P06DB, P06DC, P06DD, P06DE
OilPmpFA - Other Definitions: FA only for Output Driver and rationality
Bundle Name: OilPmpStuckHigh
P06DA, P06DB, P06DD
OilPmpStuckHigh - Other Definitions: TFTKO and FA
Bundle Name: OilPmpStuckLow
P06DC, P06DE
OilPmpStuckLow - Other Definitions: TFTKO and FA
Bundle Name: OilPmpTFTKO
P06DA, P06DB, P06DC, P06DD, P06DE
OilPmpTFTKO - Other Definitions: TFTKO only for Output Driver and rationality
Bundle Name: PostCatFuelTrimHiB1
P2097
Bundle Name: PostCatFuelTrimHiB2
P2099
Bundle Name: PostCatFuelTrimLoB1
P2096
Bundle Name: PostCatFuelTrimLoB2
P2098
Bundle Name: PowertrainRelayStateOn_FA
P0685, P0686, P0687
Bundle Name: PPS1_OutOfRange

14 OBDG02 ECM Supporting Tables

Fault Bundle Definitions

P2122, P2123
Bundle Name: PPS1_OutOfRange_Composite
P2122, P2123, P06A3
Bundle Name: PPS2_OutOfRange
P2127, P2128
Bundle Name: PPS2_OutOfRange_Composite
P2127, P2128, P0697
Bundle Name: SCIAP_SensorCircuitFA
P012C, P012D
Bundle Name: SCIAP_SensorCircuitFP
P012C, P012D
Bundle Name: SCIAP_SensorFA
P012B, P012C, P012D
Bundle Name: SCIAP_SensorPerfFA
P012B
Bundle Name: SCIAP_SensorPerfTFTKO
P012B
Bundle Name: SCIAP_SensorTFTKO
P012B, P012C, P012D
Bundle Name: SuperchargerBypassValveFA
P2261
Bundle Name: SystemVoltageHigh_FA
P0563
Bundle Name: SystemVoltageLow_FA
P0562
Bundle Name: TCM_EngSpdReqCkt
P150C
Bundle Name: THMR_AHV_FA
P2681, P26A3, P26A6, P26A7, P26A9
Bundle Name: THMR_AWP_AuxPumpFA
B2920, B2923, B2922
Bundle Name: THMR_ECT_Sensor_Ckt_FA
P0116, P0117, P0118, P00B6
Bundle Name: THMR_Insuff_Flow_FA
P00B7
Bundle Name: THMR_RCT_Sensor_Ckt_FA
P00B3, P00B4
Bundle Name: THMR_SWP_Control_FA

14 OBDG02 ECM Supporting Tables

Fault Bundle Definitions

P261D, P261A, P261C

Bundle Name: THMR_SWP_FlowStuckOn_FA

P261A, P261D, P261E

Bundle Name: THMR_SWP_NoFlow_FA

P261B, P261C

Bundle Name: THMR_Therm_Control_FA

P0597, P0598, P0599

Bundle Name: ThrotTempSensorFA

Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.

Bundle Name: ThrotTempSensorTFTKO

Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.

Bundle Name: ThrottlePositionSnsrPerfFA

P0121

Bundle Name: ThrottlePositionSnsrPerfTFTKO

P0121

Bundle Name: TIAP_SensorPerfFA

P0236

Bundle Name: TPS_FA

P0122, P0123, P0222, P0223, P2135

Bundle Name: TPS_FaultPending

P0122, P0123, P0222, P0223, P2135

Bundle Name: TPS_Performance_FA

P0068, P0121, P1104, P2100, P2101, P2102, P2103

Bundle Name: TPS_Performance_TFTKO

P0068, P0121, P1104, P2100, P2101, P2102, P2103

Bundle Name: TPS_TFTKO

P0122, P0123, P0222, P0223, P2135

Bundle Name: TPS_ThrottleAuthorityDefaulted

P0068, P0122, P0123, P0222, P0223, P16F3, P1104, P2100, P2101, P2102, P2103, P2135

Bundle Name: TPS1_OutOfRange_Composite

P0122, P0123, P06A3

Bundle Name: TPS2_OutOfRange_Composite

P0222, P0223, P06A3

Bundle Name: Trans Output Rotations Rolling Count Validity

P0722, P0723, P077C, P077D

Bundle Name: TransActualGearValidity

14 OBDG02 ECM Supporting Tables

Fault Bundle Definitions

P182E, P1915

Bundle Name: Transfer Pump is Commanded On

Transfer Pump is Commanded On - Other Definitions:

Fuel Volume in Primary Fuel Tank < 0.0 liters AND

Fuel Volume in Secondary Fuel Tank ≥ 0.0 liters AND

Transfer Pump on Time < P0461, P2066, P2636: Transfer Pump Enable (see supporting table for numeric value) AND

Transfer Pump had been Off for at least 0.0 seconds AND

Evap Diagnostic (Purge Valve Leak Test, Large Leak Test, and Waiting for Purge) is not running AND

Engine Running

Bundle Name: Transmission Actual Gear Validity

P182E, P1915

Bundle Name: Transmission Engaged State Validity

P182E, P1915

Bundle Name: Transmission Estimated Gear Validity

P182E, P1915

Bundle Name: Transmission Gear Ratio Validity

P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0

Bundle Name: Transmission Gear Selector Position Validity

P182E, P1915

Bundle Name: Transmission Oil Temperature Validity

P0667, P0668, P0669, P0711, P0712, P0713

Bundle Name: Transmission Output Shaft Angular Velocity Validity

P0722, P0723, P077C, P077D

Bundle Name: Transmission Overall Actual Torque Ratio Validity

P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P182E, P1915

Bundle Name: Transmission Overall Estimated Torque Ratio Validity

P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P182E, P1915

Bundle Name: Transmission Shift Lever Position Validity

P182E, P1915

Bundle Name: Transmission Turbine Angular Velocity Validity

P0716, P0717, P07BF, P07C0

Bundle Name: TransmissionEngagedState_FA

P182E, P1915

Bundle Name: TransmissionGearDefaulted

P182E, P1915

Bundle Name: TransmissionOutputRotationalStatusValidity

P0722, P0723, P077C, P077D

Bundle Name: TransmissionRatioControlSystemFault

14 OBDG02 ECM Supporting Tables

Fault Bundle Definitions

P0751, P0752, P0756, P0757, P0973, P0974, P0976, P0977

Bundle Name: VCER_TorqueSecurity

P16F3

VCER_TorqueSecurity - Other Definitions:

P16F3 with GetXOYR_b_SecurityFlt(CeXOYR_e_AFM_PreloadAreaFlt, CeXOYR_e_AFM_PreloadTimerFlt, CeXOYR_e_AFM_DualPreloadAreaFlt, CeXOYR_e_CDAR_SecurityFlt)

Bundle Name: VehicleSpeedSensor_FA

P0502, P0503, P0722, P0723

Bundle Name: VehicleSpeedSensorError

P0502, P0503, P0722, P0723

Bundle Name: VentCircuit_FA

ELCP sealed/vented fuel system, P0449, P0498, P0499

Bundle Name: VICM_WakeupDiag_FA

P06E4

Bundle Name: VICM_WakeupDiag_TFTKO

P06E4

Bundle Name: VITR_LVT_FltBndl

P058B, P058D, P118C, P118D

14 OBDG02 ECM Supporting Tables

LD OBD Component System Table

STATE OF CALIFORNIA
California Environmental Protection Agency
AIR RESOURCES BOARD
MSCD/ESB-113 (NEW 1/11)

OBD II Gasoline Monitoring Requirements Checklist

Component/System	MONITORING REQUIREMENTS: List the DTC of the monitor that detects the following failure mode:									
Catalyst	(e)(1.2.2) Conversion Efficiency									
	P0420	NA	NA	NA	NA	NA	NA	NA	NA	NA
Heated Catalyst	(e)(2.2) Heating Performance									
	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Misfire	(e)(3.2.1) Catalyst Damage Misfire	(e)(3.2.2) FTP Level Misfire: First 1000-revs	(e)(3.2.2) FTP Level Misfire: 4 x 1000-revs							
	P0300	P0300	P0300	NA	NA	NA	NA	NA	NA	NA
Evaporative System	(e)(4.2.2)(A) Purge Flow	(e)(4.2.2)(B) 0.040" Leak Check	(e)(4.2.2)(C) 0.020" Leak Check	(e)(4.2.5) 0.090" Leak Check in Lieu of 0.040"						
	P0455	P0442	P0442	NA	NA	NA	NA	NA	NA	NA
Secondary Air	(e)(5.2.3) Insufficient Flow Emission Threshold	(e)(5.2.4) Functional Monitor In Lieu of Emission Threshold								
	P0411	P0411, P2440, P2444	NA	NA	NA	NA	NA	NA	NA	NA
Fuel System	(e)(6.2.1)(A) Emission Threshold	(e)(6.2.1)(B) Secondary Fuel Trim Emission Threshold	(e)(6.2.1)(C) Air-fuel Ratio Cylinder Imbalance	(e)(6.2.2) Adaptive Limits Reached	(e)(6.2.3) Secondary Fuel Trim Adaptive Limits Reached	(e)(6.2.4) Fails to Enter Closed Loop				
	P0171, P0172	P2096, P2097	P219A, P0300, P2096, P2097	P0171, P0172	P2096, P2097	NA	NA	NA	NA	NA
Upstream Exhaust Gas Sensor	(e)(7.2.1)(A) Emission Threshold	(e)(7.2.1)(B) Open Circuit	(e)(7.2.1)(B) Out-of-Range High	(e)(7.2.1)(B) Out-of-Range Low	(e)(7.2.1)(C) Feedback: Slow/fails to Enter, Default OL	(e)(7.2.1)(D) Sufficient for Other Diagnostics	(e)(7.2.3)(A) Heater Performance	(e)(7.2.3)(B) Heater Circuit Continuity		
	P0133, P0133, P015A, P015B	P0132, P0134	P0132	P0131	NA	P0131, P0132, P0134, P0133, P015A, P015B	P0053, P0135	P0030, P0031, P0032	NA	NA
Downstream Exhaust Gas Sensor	(e)(7.2.2)(A) Emissions Threshold	(e)(7.2.2)(B) Open Circuit	(e)(7.2.2)(D) Out-of-Range High	(e)(7.2.2)(D) Out-of-Range Low	(d)(2.2.3) & (e)(6.2.4) Feedback: Slow/fails to Enter, Default OL	(e)(7.2.2)(C) Sufficient for Other Diagnostics	(e)(7.2.3)(A) Heater Performance	(e)(7.2.3)(B) Heater Circuit Continuity		
	P013A, P013B, P013E, P013F	P0138, P0140	P0138, P2271	P0137, P2270	P0054, P0137, P0138, P0140, P0141, P013A, P013B, P013E, P013F, P2270, P2271	P013A, P013B, P013E, P013F, P2270, P2271	P0054, P0141	P0036, P0037, P0038	NA	NA

14 OBDG02 ECM Supporting Tables

LD OBD Component System Table

EGR	(e)(8.2.1)	(e)(8.2.1)	(e)(8.2.2)							
	Low Flow Emission Threshold	High Flow Emission Threshold	Functional Monitor in Lieu of Emission Threshold							
	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Crankcase Ventilation	(e)(9.2.2)									
	Disconnection									
	P0106, P0131, P0171, P0300	NA	NA	NA	NA	NA	NA	NA	NA	NA
Engine Cooling System	(e)(10.2.1)	(e)(10.2.2)(A)	(e)(10.2.2)(A)	(e)(10.2.2)(A)	(e)(10.2.2)(B)	(e)(10.2.2)(C)	(e)(10.2.2)(D)			
	Time to Reach Threshold Temp	ECT Open Circuit	ECT Out-of-Range High	ECT Out-of-Range Low	Time to Reach Closed Loop	ECT Stuck Below Highest Minimum Enable Temp	ECT Stuck Above Lowest Maximum Enable Temp			
	P0128, P2181	P0118, P0119, P00B4	P0118, P00B4	P0117, P00B3	NA	P0128, P00B6	P0116, P00B6	NA	NA	NA
Cold Start Strategy	(e)(11.2.1)(A)	(e)(11.2.1)(B)	(e)(11.2.2)(A)	(e)(11.2.2)(B)						
	Emission Threshold	Functional Monitor In Lieu of Emission Threshold	Phase-in Single Element Functional Monitor	Phase-in Emission Threshold						
	P1400	P1400, P05CC, P05CE	P0300, P1400, P05CC, P05CE	P1400	NA	NA	NA	NA	NA	NA
VVT System	(e)(13.2.1)	(e)(13.2.3)	(e)(13.2.2)	(e)(13.2.3)						
	Target Error Emission Threshold	Target Error Functional Monitor in Lieu of Emission Threshold	Slow Response Emission Threshold	Slow Response Functional Monitor in Lieu of Emission Threshold						
	P0011, P0014	P0011, P0014	P0011, P0014	P0011, P0014	NA	NA	NA	NA	NA	NA
Direct Ozone Reduction (DOR) System	(e)(14.2.1)	(e)(14.2.2)								
	Functional Monitor for <50% Std Credit	Emission Threshold Monitor for >50% Std Credit								
	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA

14 OBDG02 ECM Supporting Tables

LD OBD Monitor System Table

STATE OF CALIFORNIA
California Environmental Protection Agency
AIR RESOURCES BOARD
MSCD/ESB-113 (NEW 1/11)

OBD II Gasoline Monitoring Requirements Checklist

List the DTC of comprehensive component monitor that detects the following failure mode:

Monitor/System	Input Out-of-Range High	Input Out-of-Range Low	Input Open Circuit	Input Rationality Low	Input Rationality High	Input Other Rationality	Output Functional	Output Shorted High	Output Shorted Low	Output Open Circuit
	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
A/C Clutch Relay Control	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
A/C High Side	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
AIR Pressure Sensor Bank 1	P2433	P2432	P2432	P2431	P2431	P2430	NA	NA	NA	NA
AIR Pressure Sensor Bank 2	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
AIR Pump Command Bank 1	NA	NA	NA	NA	NA	NA	NA	P2258	P0418, P2257	P0418, P2257
AIR Pump Solenoid Relay	NA	NA	NA	NA	NA	NA	NA	P044F	P0412, P041F	P0412, P041F
Auto Start Stop Select Switch	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Auxiliary Water Pump driver	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Barometric Pressure	P2229	P2228	P2228	P2227	P2227	P00C7, P2230	NA	NA	NA	NA
Barometric Pressure B	NA	NA	NA	NA	NA	P00C7	NA	NA	NA	NA
Brake Booster Pressure	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Brake Pedal Position	P057D	P057C	P057C	NA	NA	P057B	NA	NA	NA	NA
CAM Phase Control Bank 1 Exhaust	NA	NA	NA	NA	NA	NA	P0014	P2091	P2090	P0013
CAM Phase Control Bank 1 Intake	NA	NA	NA	NA	NA	NA	P0011	P2089	P2088	P0010
CAM Phase Control Bank 2 Exhaust	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
CAM Phase Control Bank 2 Intake	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Cam Position Bank1 Exhaust	P0365	P0365	P0365	P0366	P0366	P0017	NA	NA	NA	NA
Cam Position Bank1 Intake	P0340	P0340	P0340	P0341	P0341	P0016	NA	NA	NA	NA
Cam Position Bank2 Exhaust	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Cam Position Bank2 Intake	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Camshaft Position Output Signal	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Canister Purge Solenoid	NA	NA	NA	NA	NA	NA	P0496	P0459	P0443, P0458	P0443, P0458
Canister Vent Solenoid	NA	NA	NA	NA	NA	NA	P0446	P0499	P0449, P0498	P0449, P0498
Charge Intercooler	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Clutch Pedal Position	P0808	P0807	P0807	P0806	NA	P080A	NA	NA	NA	NA
Crank Position	P0335	P0335	P0335	P0336	P0336	NA	NA	NA	NA	NA
Crankshaft Position Output Signal	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Cylinder Deactivate 1	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Cylinder Deactivate 2	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Cylinder Deactivate 3	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Cylinder Deactivate 4	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Cylinder Deactivate 5	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Cylinder Deactivate 6	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Cylinder Deactivate 7	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Cylinder Deactivate 8	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
EGR Valve Position	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
ELCP Pressure Sensor	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
ELCP Switching Valve	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA

14 OBDG02 ECM Supporting Tables

LD OBD Monitor System Table

ELCP Vacuum Pump	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Electrically Heated Thermostat driver	NA	NA	NA	NA	NA	NA	NA	P0599	P0598	P0597
Engine Metal Over Temperature Active	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Engine Oil Pressure	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
EST A	NA	NA	NA	NA	NA	NA	NA	P2301	P2300	P0351
EST B	NA	NA	NA	NA	NA	NA	NA	P2304	P2303	P0352
EST C	NA	NA	NA	NA	NA	NA	NA	P2307	P2306	P0353
EST D	NA	NA	NA	NA	NA	NA	NA	P2310	P2309	P0354
EST E	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
EST F	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
EST G	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
EST H	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
ETC Motor Close	NA	NA	NA	NA	NA	NA	P2101, P1516, P2176	NA	NA	NA
ETC Motor Open	NA	NA	NA	NA	NA	NA	P2101, P1516, P2176	NA	NA	NA
Fan Control #1	NA	NA	NA	NA	NA	NA	NA	P0692	P0480, P0691	P0480, P0691
Fan Control #2	NA	NA	NA	NA	NA	NA	NA	P0694	P0481, P0693	P0481, P0693
Fan Control #3	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fuel Composition	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fuel Economy Mode Switch Circuit	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fuel Injector A	NA	NA	NA	NA	NA	NA	NA	P0262	P0201, P0261	P0201, P0261
Fuel Injector B	NA	NA	NA	NA	NA	NA	NA	P0265	P0202, P0264	P0202, P0264
Fuel Injector C	NA	NA	NA	NA	NA	NA	NA	P0268	P0203, P0267	P0203, P0267
Fuel Injector D	NA	NA	NA	NA	NA	NA	NA	P0271	P0204, P0270	P0204, P0270
Fuel Injector E	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fuel Injector F	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fuel Injector G	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fuel Injector H	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fuel Level	P0463	P0462	P0463	NA	NA	P0461, P0464	NA	NA	NA	NA
Fuel Level 2	P2068	P2067	P2068	NA	NA	P0464, P2066	NA	NA	NA	NA
Fuel Pres Sensor "B"	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fuel Pump 1	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fuel Pump 2	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fuel pump Control	NA	NA	NA	NA	NA	NA	NA	NA	P0628	NA
Fuel Pump Driver Control Module	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fuel Pump Driver Module Control	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Fuel Tank Vapor Pressure Sensor	P0453	P0452	P0452	NA	NA	P0451, P0454	NA	NA	NA	NA
Humidity	P00F5	P00F4	P00F4	NA	NA	P00F6	NA	NA	NA	NA
Hybrid Control Torque Request Circuit	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Ignition Off Timer	NA	NA	NA	NA	NA	P262B	NA	NA	NA	NA
IMTV Position	P2078	P2077	P2077	P2070	P2071	P2076	NA	NA	NA	NA
Intake Air Temperature	P0113	P0112	P0113	P0111	P0111	P0114, P2199	NA	NA	NA	NA
Intake Air Temperature 2	P0098	P0097	P0098	P0096	P0096	P0099, P2199	NA	NA	NA	NA
Intake Air Temperature 3	P00EB	P00EA	P00EB	P00E9	P00E9	NA	NA	NA	NA	NA
Intake Manifold Runner Control	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Intake Manifold Tuning Valve Control	NA	NA	NA	NA	NA	NA	P2070, P2071	P0662	P0661	P0660

14 OBDG02 ECM Supporting Tables

LD OBD Monitor System Table

Knock Internal Circuit	NA	NA	NA	NA	NA	P06B6	NA	NA	NA	NA
Knock Internal Circuit #2	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Knock Sensor-Flat	P0328	P0327	P0325	P0326	P0324, P0326	NA	NA	NA	NA	NA
Knock Sensor-Flat #2	NA	NA	NA	NA	P0324	NA	NA	NA	NA	NA
Malfunction Indicator Lamp	NA	NA	NA	NA	NA	NA	NA	P263B	P0650, P263A	P0650, P263A
Manifold Absolute Pressure	P0108	P0107	P0107	P0106	P0106	P00C7, P1101	NA	NA	NA	NA
Mass Air Flow	P0103	P0102	P0102	P0101	P0101	P1101	NA	NA	NA	NA
Mass Air Flow 2	NA	NA	NA	NA	NA	P1101	NA	NA	NA	NA
Mass Air Flow Supply Voltage Control	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Outside Air Temperature	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Pedal Position 1	P2123	P2122	P2122	P2138	P2138	NA	NA	NA	NA	NA
Pedal Position 2	P2128	P2127	P2127	P2138	P2138	NA	NA	NA	NA	NA
Performance Traction Torque Request Circuit	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Powertrain Relay Control	NA	NA	NA	NA	NA	NA	NA	P0687	P0685, P0686	P0685, P0686
Powertrain Relay Feedback	NA	NA	NA	NA	P0690	NA	NA	NA	NA	NA
Reverse Inhibit	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
SENT Communication A Circuit (Throttle)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
SIDI High Pressure Pump	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
SIDI High Pressure Sensor	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
SIDI High Pressure Start	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
SIDI Ignition Module Supply Voltage - Group 1	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
SIDI Ignition Module Supply Voltage - Group 2	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
SIDI Injector Driver Circuit	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Skip Shift Solenoid	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Starter Relay Control	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Supercharger Bypass Control	NA	NA	NA	NA	NA	NA	P0299, P0234	P0246	P0245	P0243
Supercharger Inlet Pressure	NA	NA	NA	NA	NA	P00C7, P1101	NA	NA	NA	NA
System Voltage	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Throttle Position 1	P0123	P0122	P0122	P2135	P2135	P0068, P0121	NA	NA	NA	NA
Throttle Position 2	P0223	P0222	P0223	P2135	P2135	P0068, P0121	NA	NA	NA	NA
Traction Control Torque Request Circuit	NA	NA	NA	NA	NA	P0856	NA	NA	NA	NA
Transmission Control Torque Request Circuit	NA	NA	NA	NA	NA	P2544	NA	NA	NA	NA
Transmission Mode Switch	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Transmission Output Speed Hi : Replicated TOS	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Turbocharger Boost Pressure	P0238	P0237	P0237	P0236	P0236	P00C7, P1101	NA	NA	NA	NA
Turbocharger Bypass	NA	NA	NA	NA	NA	NA	P2261	P0035	P0034	P0033
Turbocharger Bypass B	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Turbocharger Wastegate B Control	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Turbocharger Wastegate Control	NA	NA	NA	NA	NA	NA	P0299, P0234	P0246	P0245	P0243
Two Stage Oil Pump	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Vehicle Speed	P0502	P0502	P0502	P0502	P0502	P0503	NA	NA	NA	NA
Vehicle Speed Sensor B	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA