Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Open – Bank 1	P0010	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply voltage is Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Performance – Bank 1	P0011	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Intake cam Bank 1)  Cam Position Error > (P0011_CamPosError Limlc1) deg	System Voltage Engine Running Power Take Off (PTO) active Desired cam position Desired AND Measured cam position  Desired cam position variation  No Active DTCs  Bundle: IntakeVVT_Enabled	> 11.00 Volts  = TRUE  = FALSE  > 0 deg  > (P0011_CamPosErrorLimlc1) deg AND < (P0011_PerfMaxlc1) deg  < 3.00 Deg for (P0011_P05CC_StablePositionTimelc1) sec  P0010 P2088 P2089  = TRUE (Reference Supporting Tables: P0011_P0021_P05CC_P 05CD_HiEngSpdHiDsbll c P0011_P0021_P05CC_P 05CD_LoRpmHiEnbllc P0011_P0021_P05CC_P 05CD_LoRpmLoDsbllc P0011_P0021_P05CC_P 05CD_LoRpmLoDsbllc P0011_P0021_P05CC_P 05CD_LoRpmLoDsbllc P0011_P0021_P05CC_P 05CD_LoRpmLoDsbllc P0011_P0021_P05CC_P 05CD_LoRpmLoDsbllc P0011_P0021_P05CC_P	100.00 failures out of 125.00 samples 100 ms /sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						05CD_LoPresLoDsbllc P0011_P0021_P05CC_P 05CD_EngOilPressEnbll c P0011_P0021_P05CC_P 05CD_P0014_P0024_P0 5CE_P05CF_ColdStartE ngRunning)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Open – Bank 1	P0013	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply  Output driver is commanded on  Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type B, 2 Trips

			Time Required	MIL Illum.
Achaust amshaft ystem error by comparing the desired and actual cam positions when VVT is activated  P0014  Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated  Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive  (Exhaust cam Bank 1)  Cam Position Error > (P0014_CamPosErro LimEc1) deg	Engine Running	> 11.00 Volts  = TRUE  = FALSE  > 0 deg  > (P0014_CamPosErrorLimEc1) deg AND  < (P0014_PerfMaxEc1) deg  < 3.00 deg for (P0014_P05CE_StablePositionTimeEc1) sec  P0013 P2090 P2091  = TRUE (Reference Supporting Tables:  P0014_P0024_P05CE_P 05CF_HiEngSpdHiDsblE c P0014_P0024_P05CE_P 05CF_HiEngSpdLoEnblEc P0014_P0024_P05CE_P 05CF_LoRpmHiEnblEc P0014_P0024_P05CE_P 05CF_LoRpmLoDsblEc P0014_P0024_P05CE_P	100.00 failures out of 125.00 samples 100 ms /sample	Type B, 2 Trips

Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P0014_P0024_P05CE_P 05CF_EngOilPressEnbl Ec P0011_P0021_P05CC_P 05CD_P0014_P0024_P0 5CE_P05CF_ColdStartE ngRunning)		
	Fault	Fault Code Monitor Description	Fault Code Monitor Description Malfunction Criteria  Malfunction Criteria  Malfunction Criteria	Fault Code Monitor Description Malfunction Criteria Threshold Value	Fault Code         Monitor Description         Malfunction Criteria         Threshold Value         Secondary Parameters           Image: Code Code Code Code Code Code Code Code	P0014_P0024_P05CE_P 05CF_EngOilPressEnbl Ec P0011_P0021_P05CC_P 05CD_P0014_P0024_P0 5CE_P05CF_ColdStartE	P0014_P0024_P05CE_P 05CF_EngOilPressEnbl Ec P0011_P0021_P05CC_P 05CD_P0014_P0024_P0 5CE_P05CF_ColdStartE

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)- Camshaft Position (CMP) Correlation Bank 1 Sensor A	P0016	Detects cam to crank misalignment by monitoring if cam sensor pulse for bank 1 sensor A occurs during the incorrect crank position	3 cam sensor pulses more than -9.4 crank degrees before or 10.8 crank degrees after nominal position in one cam revolution.		Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic	P0335, P0336 P0340,P0341 < 1.0 seconds	2 failures out of 3 tests.  A failed test is 4 failures out of 5 samples.  There is a delay after the first failed test to allow the camshaft position to return to the park position.  This time is defined by the table "P0016_P0017_P0018_P0019 Cam Correlation Oil Temperature Threshold".  One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)- Camshaft Position (CMP) Correlation Bank 1 Sensor B	P0017	Detects cam to crank misalignment by monitoring if cam sensor pulse for bank 1 sensor B occurs during the incorrect crank position	3 cam sensor pulses more than -9.4 crank degrees before or 10.8 crank degrees after nominal position in one cam revolution.		Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser is in "parked" position No Active DTCs: Time since last execution of diagnostic	P0335, P0336 P0365,P0366 < 1.0 seconds	2 failures out of 3 tests.  A failed test is 4 failures out of 5 samples.  There is a delay after the first failed test to allow the camshaft position to return to the park position.  This time is defined by the table "P0016_P0017_P0018_P0019 Cam Correlation Oil Temperature Threshold".  One sample per cam rotation	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 1	P0030	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0031 may also set

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0031	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short-to-ground).	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0030 may also set

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0032	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power).	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Ignition Voltage Engine Speed	> 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 2	P0036	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit).	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0037 may also set

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0037	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short-to-ground).	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0036 may also set

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0038	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power).	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Ignition Voltage Engine Speed	> 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 1	P0053	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	6.1 < Ω < 13.4	No Active DTC's  Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P262B IAT_SensorFA < 8.0 °C > 28,800 seconds -30.0 < °C < 255.0 < 32.0 volts < 0.05 seconds	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0054	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	6.1 < Ω < 13.4	No Active DTC's  Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P262B IAT_SensorFA < 8.0 °C > 28,800 seconds -30.0 < °C < 255.0 < 32.0 volts < 0.05 seconds	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
MAP / MAF / Throttle Position Correlation	P0068	Detect when MAP and MAF do not match estimated engine airflow as established by the TPS	and estimated MAP supporting tables: exceeds threshold (kPa), Delta MAP Threshold	Run/Crank voltage >	Continuously fail MAP and MAF portions of diagnostic for 0.1875 s  Continuous in MAIN processor	Type A, 1 Trips		
			Absolute difference between MAF and estimated MAF exceed threshold (grams/sec), or P0102 (MAF circuit low), or P0103 (MAF circuit hi) have failed this key cycle, or maximum MAF versus	Table, f(TPS). See supporting tables: Delta MAF Threshold f(TPS)				
			RPM (Table) is greater than or equal to maximum MAF versus battery voltage, then MAF portion of diagnostic fails	Table, f(RPM). See supporting tables: Maximum MAF f (RPM)				
				Table, f(Volts). See supporting tables: Maximum MAF f (Volts)				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0096	Detects an IAT2 sensor that has stuck in range by comparing to IAT and engine coolant temperature at startup	ABS(Power Up IAT - Power Up IAT2)  AND  ABS(Power Up ECT - Power Up IAT2) >= ABS(Power Up ECT - Power Up IAT)	> 25 deg C	Time between current ignition cycle and the last time the engine was running  Powertrain Relay Voltage for a time  No Active DTCs:	> 28,800 seconds  >= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 Low (applications with humidity)	P0097	Detects a continuous short to ground or open in the IAT 2 signal circuit	Raw IAT 2 Input	< 13 Hertz (~-60 deg C)	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 High (applications with humidity)	P0098	Detects a continuous high frequency in the IAT 2 signal circuit	Raw IAT 2 Input	> 390 Hertz (~150 deg C)	Powertrain Relay Voltage for a time  No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Intermittent In-Range	P0099	Detects a noisy or erratic IAT 2 signal circuit or IAT 2 sensor	String Length  Where: "String Length" = sum of "Diff" calculated over  And where: "Diff" = ABS(current IAT 2 reading - IAT 2 reading from 100 milliseconds previous)	> 100.00 DegC  10 consecutive IAT 2 samples	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp Sensor Circuit Low Voltage	P00B3	This DTC detects a short to ground in the RCT signal circuit or the RCT sensor.	RCT Resistance (@ 150°C)	< 34 Ohms	Engine run time OR IAT min	> 10.0 seconds ≤ 70.3 °C	5 failures out of 10 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp Sensor Circuit High Voltage	P00B4	Circuit Continuity This DTC detects a short to high or open in the RCT signal circuit or the RCT sensor.	RCT Resistance (@ -60°C)	> 260,000 Ohms	Engine run time OR IAT min	> 60.0 seconds ≥ -7.0 °C	5 failures out of 10 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Flow Insufficient	P00B7	This DTC detects a Insufficient Flow Condition (i.e Stuck Closed Thermostat)	Engine Coolant Temp (ECT) is greater than 120 Deg C and Difference between ECT and RCT is greater than 40 Deg C. When above is present for more than 5 seconds, fail counts start.		No Active DTC's  Engine run time AND Engine Coolant Temp	THMR_RCT_Sensor_Ckt _FA THMR_ECT_Sensor_Ckt _FA > 300 seconds > 80.0 Deg C	30 failures out of 300 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Low	P00F4	Detects a continuous short to power in the Humidity Sensor circuit	Humidity Duty Cycle	<= 5.0 %	1	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit High	P00F5	Detects a continuous open or short to low in the Humidity Sensor circuit	Humidity Duty Cycle	>= 95.0%	1	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Intermittent	P00F6	Detects a noisy or erratic humidity sensor input	String Length  Where: "String Length" = sum of "Diff" calculated over  And where: "Diff" = ABS(current Humidity reading - Humidity reading from 100 milliseconds previous)	> 80 %  10 consecutive Humidity samples	Powertrain Relay Voltage for a time  No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	4 failures out of 5 samples Each sample takes 1.00 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (naturally aspirated)	P0101	Determines if the MAF sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 500 kPa*(g/s) > 15.0 grams/sec > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 7,000 RPM >= -7 Deg C <= 125 Deg C >= -20 Deg C <= 125 Deg C >= 0.50  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  See Residual Weight Factor tables.	Calculation are performed every 12.5 msec	Type B, 2 Trips
					No Active DTCs:	MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA		
					No Pending DTCs:	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit Low Frequency	P0102	Detects a continuous short to low or a open in either the signal circuit or the MAF sensor	MAF Output	<= 1,837 Hertz (~ 0.10 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 10.0 Volts >= 1.0 seconds	200 failures out of 250 samples  1 sample every cylinder firing event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit High Frequency	P0103	Detects a high frequency output from the MAF sensor	MAF Output	>= 13,200 Hertz (~ 193.4 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 10.0 Volts >= 1.0 seconds	200 failures out of 250 samples 1 sample every cylinder firing event	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (naturally aspirated)	P0106	Determines if the MAP sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 500 kPa*(g/s) > 25.0 kPa > 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 7,000 RPM >= -7 Deg C <= 125 Deg C >= -20 Deg C <= 125 Deg C >= 0.50  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM  MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  See Residual Weight Factor tables.	Calculations are performed every 12.5 msec	Type B, 2 Trips
					No Active DTCs:  No Pending DTCs:	MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA EGRValve_FP		
					No Penaing DTCs:	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		
			Manifold Pressure OR	< 50.0 kPa	Time between current ignition cycle and the last		4 failures out of 5 samples	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Manifold Pressure	> 115.0 kPa	time the engine was running  Engine is not rotating	> 6.0 seconds	1 sample every 12.5 msec	
					No Active DTCs:	EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA		
					No Pending DTCs:	MAP_SensorCircuitFP AAP_SnsrCktFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit Low	P0107	Detects a continuous short to low or open in either the signal circuit or the MAP sensor.		< 3.0 % of 5 Volt Range (This is equal to 0.15 Volts or 3.5 kPa)	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit High	P0108	Detects an open sensor ground or continuous short to high in either the signal circuit or the MAP sensor.	J	> 90.0 % of 5 Volt Range (This is equal to 4.50 Volts, or 115.0 kPa)	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0111	Detects an IAT sensor that has stuck in range by comparing to IAT2 and engine coolant temperature at startup	ABS(Power Up IAT - Power Up IAT2)  AND  ABS(Power Up ECT - Power Up IAT) > ABS(Power Up ECT - Power Up IAT2)	> 25 deg C	Time between current ignition cycle and the last time the engine was running  Powertrain Relay Voltage for a time  No Active DTCs:	> 28,800 seconds  >= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Low	P0112	Detects a continuous short to ground in the IAT signal circuit or the IAT sensor	Raw IAT Input	< 62 Ohms (~150 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit High	P0113	Detects a continuous open circuit in the IAT signal circuit or the IAT sensor	Raw IAT Input	> 126,840 Ohms (~-60 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Intermittent In-Range	P0114	Detects a noisy or erratic IAT signal circuit or IAT sensor	String Length  Where: "String Length" = sum of "Diff" calculated over  And where: "Diff" = ABS(current IAT reading - IAT reading from 100 milliseconds previous)	> 80.00 DegC  10 consecutive IAT samples	Continuous		4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Performance	P0116	This DTC detects ECT temp sensor stuck in mid range.		See "P0116_Fail if power up ECT exceeds IAT by these values" in the Supporting tables section  = False	Non-volatile memory initization  Test complete this trip Test aborted this trip IAT LowFuelCondition Diag  ===================================	VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_Ckt_FA IgnitionOffTime Valid TimeSinceEngineRunning Valid = Not occurred = False = False ≥ -7 °C = False ====================================	1 failure 500 msec/ sample Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					1d) IAT drops from power up IAT	≥ 3.3 °C		
					2a) ECT drops from power up ECT	≥ 2 °C		
					2b) Engine run time	Within ≤ 60 seconds		
					Diagnostic is aborted when 3) or 4) occurs:	=======================================		
					3) Engine run time with vehicle speed below 1b	> 1800 seconds		
					4) Minimum IAT during test	≤-7°C		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit Low	P0117	Circuit Continuity This DTC detects a short to ground in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ 150°C)	< 34 Ohms			5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit High	P0118	Circuit Continuity This DTC detects a short to high or open in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ -60°C)	> 260,000 Ohms	Engine run time OR IAT min	> 15.0 seconds ≥ -7.0 °C	5 failures out of 6 samples  1 sec/ sample  Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Circuit Intermittent	P0119	Circuit Continuity This DTC detects large step changes in the ECT signal circuit or the ECT sensor. Allowable high and low limits are calculated for the next sample based on the previous sample.	ECT temperature step change:  1) postive step change is greater than calculated high limit  OR  2) negitive step change is lower than calculated low limit.  The calculated high and low limits for the next reading use the following calibrations:  1) Sensor time constant 2) Sensor low limit 3) Sensor high limit	15.0 seconds -65.0 Deg C 200.0 Deg C	No Active DTC's	ECT_Sensor_Ckt_FP	3 failures out of 4 samples 1 sec/ sample Continuous	Type B, 2 Trips
			If the last ECT reading was 90 Deg C, the Time constant was calibrated at 10 seconds, the low limit was calibrated to -80 Deg C and the high limit was calibrated to 200 Deg C the caluculated limits are 101 Deg C and 73 Deg C.  The next reading (after the 90 Deg C reading) must be between 73 Deg C and 101 Deg C to be valid.					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			*******					
								<u> </u>

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (naturally aspirated)	P0121	Determines if the Throttle Position Sensor input is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	> 500 kPa*(g/s) > 15.0 grams/sec <= 25.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 7,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 125 Deg C > = 0.50  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est  See Residual Weight Factor tables.	Calculation are performed every 12.5 msec	Type B, 2 Trips
					No Active DTCs:	MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA		
					No Pending DTCs:	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit Low	P0122	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage <	0.3250		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit High	P0123	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage >	4.750		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature Below Stat Regulating Temperature ) (energy based "Deluxe" method	P0128	This DTC detects if the engine coolant temperature rises too slowly due to an ECT or Cooling system fault	reaches Commanded temperature minus 46 °C when Ambient min is ≤ 10 °C and > -7 °C. Note: Warm up target for	See the two tables named: P0128_Maximum Accumulated Energy for Start-up ECT conditions - Primary and P0128_Maximum Accumulated Energy for Start-up ECT conditions - Alternate in the Supporting tables section. This diagnostic models the net energy into and out of the cooling	Engine not run time (soaking time before current trip)  Engine run time Fuel Condition Distance traveled  **********************************	ECT_Sensor_Ckt_FA ECT_Sensor_Perf_FA VehicleSpeedSensor_FA OAT_PtEstFiltFA IAT_SensorCircuitFA MAF_SensorFA THMR_AWP_AuxPumpF A THMR_SWP_Control_FA THMR_SWP_NoFlow_FA THMR_SWP_FlowStuckO n_FA ETQR_IndTorqInaccurate  ≥ 1,800 seconds  30 ≤ Eng Run Tme ≤ 1,800 seconds  Ethanol ≤ 87 %  ≥ 0.62 miles  ***********************************	1 failure to set DTC  1 sec/ sample Once per ignition key cycle	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			59 °C  ***********************************	system during the warm-up process.  The five energy terms are: heat from combustion, heat from after-run, heat loss to enviroment, heat loss to cabin and heat loss to DFCO.	key cycle will abort  **********  ECT at start run	*************************************		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 1	P0131	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 40.0 mVolts	AIR intrusive test Fuel intrusive test Idle intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control AIR Device Control Low Fuel Condition Diag Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active All Fuel Injectors for active Cylinders Fuel Condition Fuel State All of the above met for	TPS_ThrottleAuthorityDef aulted MAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA = Not active = Talse 0.9912 < ratio < 1.0137 60 < mgram < 500 = Closed Loop = TRUE  Enabled (On) Ethanol ≤ 87 % DFCO not active > 3.0 seconds	285 failures out of 350 samples  Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 1	P0132	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Low Fuel Condition Diag Initial delay after Open Test Criteria met (cold start condition) Initial delay after Open Test Criteria met (not cold start condition) Equivalence Ratio All of the above met for	TPS_ThrottleAuthority Defaulted MAF_SensorFA MAP_SensorFA ExcessPurgePsbl_FA FuelInjectorCircuit_FA EthanolCompositionSens or_FA AIR System FA  10.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds > 100.0 seconds when engine soak time > 28,800 seconds > 100.0 seconds when engine soak time ≤ 28,800 seconds  0.9912 ≤ ratio ≤ 1.0137 > 3.0 seconds	100 failures out of 125 samples  Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Slow Response Bank 1 Sensor 1) (For use with ESPD	P0133	This DTC determines if the O2 sensor response time is degraded.	Fault condition present when the average response time is caluclated over the test time, and compared to the threshold.  OR	Refer to P0133_O2S Slow Response Bank 1 Sensor 1 "Pass/Fail Threshold table" in the Supporting Tables tab	No Active DTC's	TPS_ThrottleAuthorityDef aulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg	Sample time is 60 seconds Frequency: Once per trip	Type B, 2 Trips
			Slope Time L/R Switches OR	< 5		e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt		
			Slope Time R/L Switches	< 5  The test averages the signal response time over 60.0 seconds		_FA FuelInjectorCircuit_FA AIR System FA EthanolCompositionSens or_FA EngineMisfireDetected_F A		
				when the signal is transitioning between 400 mvolts and 600 mvolts. An average rich to lean time and lean to rich time are	Bank 1 Sensor 1 DTC's not active  System Voltage EGR Device Control Idle Device Control	P0131, P0132, P0134 10.0 < Volts = Not active = Not active		
				each calculated separately.	Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition	= Not active = Not active = Not active = False = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow		
						and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S1, B2S1 (if applicable)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System					O2 Heater on for Learned Htr resistance  Engine Coolant IAT Engine run Accum  Time since any AFM status change Time since Purge On to Off change Time since Purge Off to On change  Engine airflow Engine speed Fuel Condition Baro Air Per Cylinder  Fuel Control State Closed Loop Active LTM fuel cell Transient Fuel Mass Baro Fuel Control State Fuel State Commanded Proportional Gain	in Supporting Tables tab.  ≥ 40 seconds = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" ) > 60 °C > -40 °C > 30 seconds  > 2.0 seconds  > 2.0 seconds  > 2.0 seconds  13 ≤ grams/second ≤ 30 1,200 <= RPM <= 3,500 < 87 % Ethanol > 70 kpa ≥ 100 mGrams  = Closed Loop = TRUE = Enabled ≤ 100.0 mgrams = Not Defaulted not = Power Enrichment DFCO not active ≥ 0.0 %		Illum.
					All of the above met for	> 1.0 seconds		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 1	P0135	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.3 < Amps < 2.5	No Active DTC's  System Voltage Heater Warm-up delay O2S Heater device control  B1S1 O2S Heater Duty Cycle  All of the above met for	ECT_Sensor_FA  10.0 < Volts = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 2 tests per trip 10 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0137	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 40 mvolts	AIR intrusive test Fuel intrusive test Idle intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control Low Fuel Condition Diag Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active All Fuel Injectors for active Cylinders Fuel Condition Fuel State All of the above met for	TPS_ThrottleAuthority DefaultedMAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA = Not active = Talse 0.9912 ≤ ratio ≤ 1.0137 60 ≤ mgrams ≤ 500 = Closed Loop = TRUE  Enabled (On) Ethanol <= 87 %DFCO not active  > 3.0 seconds	285 failures out of 350 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0138	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Low Fuel Condition Diag Initial delay after Open Test Criteria met (cold start condition) Initial delay after Open Test Criteria met (not cold start condition) Equivalence Ratio Fuel Control State All of the above met for	TPS_ThrottleAuthorityDef aulted MAF_SensorFA MAP_SensorFA ExcessPurgePsbl_FA FuelInjectorCircuit_FA EthanolCompositionSens or_FA AIR System_FA  10.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds = False > 150.0 seconds when engine soak time > 28,800 seconds > 150.0 seconds when engine soak time ≤ 28,800 seconds  0.9912 ≤ ratio ≤ 1.0137 not = Power Enrichment > 3.0 seconds	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Rich to Lean Bank 1 Sensor 2	P013A	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Rich to Lean voltages range during Rich to Lean transition. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Post O2 sensor normalized integral value  OR  The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units  > 10.0 grams (upper voltage threshold is 450 mvolts and lower voltage threshold is 150 mvolts)	B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013B, P013E, P013F, P2270 or P2271  10.0 < Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA
					Low Fuel Condition Diag	= False		
					Post fuel cell (Decel) Crankshaft Torque	= enabled < 125.0 Nm		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					DTC's Passed	P2270 (and P2272 if applicable) P013E (and P014A if applicable)		
					After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	=======================================		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Lean to Rich Bank 1 Sensor 2	P013B	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Lean to Rich voltages range during Lean to Rich transition. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	The EWMA of the Post O2 sensor normalized integral value  OR  The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units  > 140 grams (lower voltage threshold is 350 mvolts and upper voltage threshold is 650 mvolts)	No Active DTC's  B1S2 DTC's Not Active this key cycle  System Voltage Learned heater resistance	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013A, P013E, P013F, P2270 or P2271  10.0 < Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "H02S Heater Resistance DTC's" )	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA
					ICAT MAT Burnoff delay	= Not Valid		
					Green O2S Condition	= Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.		
					Green Cat System Condition	= Not Valid, System is not valid until accumulated airflow is greater than		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Diag Post fuel cell DTC's Passed	360,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).  = False = enabled  P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable) P13F (and P014B if applicable)		
					After above conditions are met: Fuel Enrich mode continued.  ===================================			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 2	P013E	This DTC determines if the post catalyst O2 sensor has an initial delayed response to an A/F change from Rich to Lean. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	Post O2 sensor voltage  AND  The Accumulated mass air flow monitored during the Delayed Response Test under DFCO  DFCO begins after: 1) Catalyst has been rich for a minimum of AND 2) Catalyst Rich Accumulation Air Flow is greater or equal to	> 450 mvolts  > 20 grams  > 0 secs  > 5 grams	No Active DTC's  B1S2 DTC's Not Active this key cycle  System Voltage Learned heater resistance	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013A, P013B, P013F, P2270 or P2271  10.0 < Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips
					ICAT MAT Burnoff delay Green O2S Condition	= Not Valid  = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.		
					Low Fuel Condition Diag  Post fuel cell (Decel)	= False = enabled		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Crankshaft Torque	< 125.0 Nm		
					DTC's Passed	P2270 (and P2272 if applicable)		
					Number of fueled cylinders	≤3 cylinders		
					After above conditions are met: DFCO mode entered (wo driver initiated pedal input).	=======================================		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 2	P013F	This DTC determines if the post catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	Post O2 sensor voltage AND The Accumulated mass air flow monitored during the Delayed Response Test	< 350 mvolts  > 260 grams	B1S2 DTC's Not Active this key cycle  System Voltage Learned heater resistance	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013A, P013B, P013E, P2270 or P2271  10.0 < Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed	Type B, 2 Trips
					ICAT MAT Burnoff delay	= Not Valid		
					Green Cat System	= Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.		
					Green Cat System Condition	= Not Valid, System is not valid until accumulated airflow is greater than		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Diag Post fuel cell DTC's Passed  Number of fueled cylinders  ———————————————————————————————————	360,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).  = False = enabled  P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable) P2271 (and P2273 if applicable)  ≥ 1 cylinders ====================================		
					≤ Fuel EQR ≤ 1.08			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0141	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.3 > amps > 2.5	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA 10.0 < Volts = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 2 tests per trip 10 seconds delay between tests and 1 second execution rate.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 1	P015A	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Rich to Lean. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Pre O2 sensor normalized R2L time delay value  OR  [The Accumulated time monitored during the R2L Delayed Response Test (Gross failure).  AND  Pre O2 sensor voltage is	> 0.6 EWMA (sec)  ≥ 2.5 Seconds  > 550 mvolts	System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition	TPS_ThrottleAuthorityDef aulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSens or_FA EngineMisfireDetected_F A P0131, P0132, P0134  10.0 < Volts = Not active = Not Alid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for	Frequency: Once per trip Note: if NaESPD_b_Fast InitRespIsActive = TRUE for the given Fuel Bank OR NaESPD_b_Rap idResponseIsAct ive = TRUE, multiple tests per trip are allowed	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					O2 Heater (pre sensor) on for Learned Htr resistance	the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab.  ≥ 40 seconds = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")		
					Engine Coolant IAT Engine run Accum	> 60 °C > -40 °C > 30 seconds		
					Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)	1,450 ≤ RPM ≤3,300 1,350 ≤ RPM ≤3,400		
					Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)	2≤ gps ≤ 20 43.5≤ MPH ≤ 80.2 38.5≤ MPH ≤ 82.0		
					Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell	0.75 ≤ C/L Int ≤ 1.07 = TRUE not in control of purge not in estimate mode = enabled		
					EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State	= not active = not active ≥ 60.0 sec 550 ≤ °C ≤ 900 = DFCO possible		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for at least 3.0 seconds, and then the Force Cat Rich intrusive stage is requested.  Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders  After above conditions are met: DFCO Mode is entered (wo driver initiated pedal input).	=====================================		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 1	P015B	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test which runs in an enriched fuel mode to achieve the required response.	The EWMA of the Pre O2 sensor normalized L2R time delay value  OR  [The Accumulated time monitored during the L2R Delayed Response Test (Gross failure).  AND  Pre O2 sensor voltage is  OR  At end of Cat Rich stage the Pre O2 sensor output is	> 0.6 EWMA (sec)  ≥ 2.5 Seconds  < 325 mvolts  < 680 mvolts	System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition	TPS_ThrottleAuthorityDef aulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSens or_FA EngineMisfireDetected_F A P0131, P0132, P0134  10.0 < Volts = Not active = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for	Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_Rap idResponselsAct ive = TRUE, multiple tests per trip are allowed	Type A, 1 Trips EWMA

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					O2 Heater (pre sensor) on for Learned Htr resistance	the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab.  ≥ 40 seconds = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance		
					Engine Coolant IAT Engine run Accum	DTC's") > 60 °C > -40 °C > 30 seconds		
					Engine Speed to initially enable test Engine Speed range to keep test enabled (after	1,450 ≤ RPM ≤ 3,300		
					initially enabled)  Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)	1,350 ≤ RPM ≤3,400  2 ≤ gps ≤ 20  43.5 ≤ MPH ≤ 80.2  38.5 ≤ MPH ≤ 82.0		
					Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time	0.75 ≤ C/L Int ≤ 1.07 = TRUE not in control of purge not in estimate mode = enabled = not active = not active ≥ 60.0 sec		
					Predicted Catalyst temp	550 ≤ °C ≤ 900		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Fuel State Number of fueled cylinders  ===================================	= DFCO inhibit ≥ 1 cylinders ====================================		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Lean Bank 1	P0171	Determines if the fuel control system is in a lean condition, based on the filtered long-term and short-term fuel trim.	The filtered long-term fuel trim metric  AND  The filtered short-term fuel trim metric (Note: any value below 0.95 effectively nullifies the short-term fuel trim criteria)	>= 1.350 >= 0.100	Engine speed BARO Coolant Temp MAP Inlet Air Temp MAF Fuel Level	400 <rpm< 7,000<br="">&gt; 70 kPa -20 &lt;°C&lt; 150 10 <kpa< 255<br="">-20 &lt;°C&lt; 150 1.0 <g 512.0<br="" s<="">&gt; 10 % or if fuel sender is faulty the diagnostic will bypass the fuel level criteria.</g></kpa<></rpm<>	Frequency: 100 ms Continuous Loop	Type B, 2 Trips
					Long Term Fuel Trim data accumulation:	> 34.0 seconds of data must accumulate on each trip, with at least 14.0 seconds of data in the current fuel trim cell before a pass or fail decision can be made.		
					Sometimes, certain Long- Term Fuel Trim Cells are not utilized for control and/or diagnosis	(Please see "Long-Term Fuel Trim Cell Usage" in Supporting Tables for a list of cells utilized for diagnosis)		
					Closed Loop Long Term FT	Enabled Enabled (Please see "Closed Loop Enable Criteria" and "Long Term FT Enable Criteria" in Supporting Tables.)		
					EGR Diag. Catalyst Diag. Post O2 Diag.	Intrusive Test Not Active Intrusive Test Not Active Intrusive Test Not Active		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Device Control EVAP Diag.	Not Active "tank pull down" Not Active		
					No active DTC:	IAC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR System FA EvapExcessPrgePsbl_FA Ethanol Comp Snsr FA FuelInjectorCkt_FA EngMisfireDetected_FA EGRValvePerf_FA EGRValveCkt_FA MAP_EngVacuumStatus AmbPresDfltdStatus TC_BoostPresSnsrFA O2Snsr_B1_Snsr_1_FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Rich Bank 1	control system is rich condition, b on the filtered lo term fuel trim me	Determines if the fuel control system is a rich condition, based on the filtered longterm fuel trim metric.	Passive Test: The filtered Non-Purge Long Term Fuel Trim metric AND	<= 0.700		Secondary Parameters and Enable Conditions are identical to those for P0171, with the exception that fuel level is not	Frequency: 100 ms Continuous Loop	Type B, 2 Trips
		There are two methods to determine a Rich fault. They are Passive and Intrusive. A Passive Test decision can be made up until the time that purge is	The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)	<= 2.000	considered.			
		first enabled. From that point forward, rich faults can only be detected by turning purge off intrusively.	Intrusive Test: For 2 out of 3 intrusive segments, the filtered Purge Long Term Fuel Trim metric	<= 0.705				
		Intrusive Test: If the filtered Purge Long Term Fuel Trim metric > 0.705, the test passes without intrusively checking the filtered Non-Purge	f the filtered Purge Long Term Fuel Trim metric > 0.705, the est passes without ntrusively checking the iltered Non-Purge Long Term Fuel Trim metric. However if the iltered Purge Long ferm Fuel Trim metric s <= 0.705, purge is ramped off to eletermine if excess ourge vapor is the  The filtered Non-Purge Long Term Fuel Trim metric  <= 0.700  <= 0.700  <= 0.700  <= 2.000  <= 2.000  <= 2.000  <= 2.000  <= 2.000  <= 2.000  <= 2.000  <= 2.000  <= 2.000  <= 2.000  <= 2.000  <= 2.000  <= 2.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <= 3.000  <=					
		Long Term Fuel Trim metric. However if the filtered Purge Long Term Fuel Trim metric is <= 0.705, purge is ramped off to determine if excess purge vapor is the cause of the rich						
F te	condition.  Performing intrusive tests too frequently may also affect EVAP and EPAIII emissions,	Segment Def'n: Segments can last up to 60 seconds and are separated by the lesser of 20 seconds of purge-on time or enough time to						

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and the execution frequency of other diagnostics.	purge 36 grams of vapor. A maximum of 3 completed segments or 20 attempts are allowed for each intrusive test. After an intrusive test report is completed, another intrusive test cannot occur for 100 seconds to allow sufficient time to purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge Long Term Fuel Trim metric > 0.705 for at least 150 seconds, indicating that the canister has been purged.					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Open Circuit - (PFI)	P0201	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type A, 1 Trips Note: In certain controlle rs P0261 may also set (Injector 1 Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Open Circuit - (PFI)	P0202	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type A, 1 Trips Note: In certain controlle rs P0264 may also set (Injector 2 Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Open Circuit - (PFI)	P0203	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type A, 1 Trips  Note: In certain controlle rs P0267 may also set (Injector 3 Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Open Circuit - (PFI)	P0204	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type A, 1 Trips  Note: In certain controlle rs P0270 may also set (Injector 4 Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit Low	P0222	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage <	0.250		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit High	P0223	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage >	4.590		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to ground (PFI)	P0261	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type A, 1 Trips Note: In certain controlle rs P0201 may also set (Injector 1 Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to power (PFI)	P0262	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	on state indicates short to	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running		20 failures out of 25 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to ground (PFI)	P0264	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type A, 1 Trips Note: In certain controlle rs P0202 may also set (Injector 2 Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to power (PFI)	P0265	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	on state indicates short to	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running		failures out of 25 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to ground (PFI)	P0267	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type A, 1 Trips  Note: In certain controlle rs P0203 may also set (Injector 3 Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Injector 3 Low side circuit shorted to power (PFI)	P0268	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running		failures out of 25 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to ground (PFI)	P0270	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	20 failures out of 25 samples 100 ms /sample Continuous	Type A, 1 Trips  Note: In certain controlle rs P0204 may also set (Injector 4 Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to power (PFI)	P0271	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	on state indicates short to	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running		failures out of 25 samples 100 ms /sample Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Random Misfire Detected  Cylinder 1 Misfire Detected  Cylinder 2 Misfire Detected  Cylinder 3 Misfire Detected	P0300 P0301 P0302 P0303	These DTC's will determine if a random or a cylinder specific misfire is occurring by monitoring various terms derived from crankshaft velocity. The rate of misfire over an interval is compared to both emissions and catalyst damaging thresholds. The pattern of crankshaft acceleration after the misfire is checked to	Crankshaft Deceleration Value(s) vs. Engine Speed and Engine load  The equation used to calculate deceleration value is tailored to specific vehicle operating conditions. The selection of the equation used is based on the 1st single cylinder continuous misfire threshold tables		Engine Run Time  Engine Coolant Temp Or If ECT at startup Then ECT  System Voltage + Throttle delta - Throttle delta	> 2 crankshaft revolution -7 °C < ECT < 125 °C < -7 °C 21 °C < ECT < 125 °C 9.00 < volts < 32.00 < 95.00 % per 25 ms < 95.00 % per 25 ms	Emission Exceedence = any (5) failed 200 rev blocks out of (16) 200 rev block tests  Failure reported for (1) Exceedence in 1st (16) 200 rev block tests, or (4) Exceedences thereafter.	Type B, 2 Trips (Mil Flashes with Catalyst damage level of Misfire)
Cylinder 4 Misfire Detected	P0304	differentiate between real misfire and other sources of crank shaft noise.	encountered that are not max of range. If all tables are max of range at a given speed/load, that speed load region is an <i>Undetectable region</i> see Algorithm Description Document for additional details.  SINGLE CYLINDER CONTINUOUS MISFIRE(	- see details of thresholds on Supporting Tables Tab (P0300 Section) > IdleSCD_Decel AND > IdleSCD_Jerk)	Early Termination option: (used on plug ins that may not have enough engine run time at end of trip for normal interval to complete.)	Not Enabled	OR when Early Termination Reporting = Enabled and engine rev > 1,000 revs and < 3,200 revs at end of	
			OR (Medres_Decel Medres_Jerk  OR (Lores_Decel Lores_Jerk  OR (Lores_Decel Lores_Jerk  OR RevBalanceTime	>SCD_Decel AND > SCD_Jerk)  >IdleCyl_Decel AND > IdleCyl_Jerk)  >CylModeDecel AND > CylModeJerk)  >RevMode_Decel			any Catalyst Exceedence = (1) 200 rev block as data supports for catalyst damage.	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Other patterns of misfire use adjustments to the single cylinder continuous misfire threshold tables:  RANDOM MISFIRE Use random misfire thresholds If no misfire for				Catalyst Failure reported with (1 or 3) Exceedences in FTP, or (1) Exceedence outside FTP. Continuous	
			(Medres_Decel	> IdleSCD_Decel * Random_SCD_Decel  > IdleSCD_Jerk * Random_SCD_Jerk				
			OR (Medres_Decel AND Medres_Jerk)	> SCD_Decel * Random_SCD_Decel > SCD_Jerk * Random_SCD_Jerk				
			OR (Lores_Decel AND Lores_Jerk)	> IdleCyl_Decel * RandomCylModDecel > IdleCyl_Jerk * RandomCylModeJerk				
			OR (Lores_Decel AND Lores_Jerk)	> CylModeDecel * RandomCylModDecel > CylModeJerk * RandomCylModeJerk				
			OR RevBalanceTime	> RevMode_Decel * RandomRevModDecl				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System	Code		AND Medres_Jerk)  OR (Medres_Decel AND Medres_Jerk)	Pair_SCD_Decel  > SCD_Jerk *     Pair_SCD_Jerk  > IdleCyl_Decel *     PairCylModeDecel  > IdleCyl_Jerk *     PairCylModeJerk  > CylModeDecel *     PairCylModeDecel  > CylModeJerk *     PairCylModeJerk				Illum.
			AND Above TRUE for) )	> 80 engine cycles out of 100 engine cycles				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			BANK MISFIRE Cylinders above Bank Thresholds (Medres_Decel AND Medres_Jerk)  OR (Medres_Decel AND Medres_Jerk)  OR (Lores_Decel AND Lores_Jerk)  OR (Lores_Jerk)	>= 3 cylinders  > IdleSCD_Decel * Bank_SCD_Decel  > IdleSCD_Jerk * Bank_SCD_Jerk  > SCD_Decel * Bank_SCD_Decel  > SCD_Jerk * Bank_SCD_Jerk  > IdleCyl_Decel * BankCylModeDecel  > IdleCyl_Jerk * BankCylModeJerk  > CylModeDecel * BankCylModeDecel  > CylModeJerk * BankCylModeJerk				
			CONSECUTIVE CYLINDER MISFIRE 1st cylinder uses single cyl continuous misfire thresholds; 2nd Cylinder uses: (Medres_Decel	> IdleSCD_Decel * ConsecSCD_Decel				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AND Medres_Jerk)	> IdleSCD_Jerk * ConsecSCD_Jerk				
			OR (Medres_Decel	> SCD_Decel * ConsecSCD_Decel				
			AND Medres_Jerk)	> SCD_Jerk * ConsecSCD_Jerk				
			OR (Lores_Decel	> IdleCyl_Decel * ConsecCylModDecel				
			AND Lores_Jerk)	> IdleCyl_Jerk * ConsecCylModeJerk				
			OR (Lores_Decel	> CylModeDecel * ConsecCylModDecel				
			AND Lores_Jerk)					
			CYLINDER DEACTIVATION MODE (Active Fuel Managment)					
			AFM: SINGLE CYLINDER CONTINUOUS MISFIRE (CylAfterDeacCyl_Decel	> CylModeDecel *				
			AND CylAfterDeacCyl_Jerk)					
			OR	> CylModeDecel *				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				CylBeforeAFM_Decel > CylModeJerk * ClyBeforeAFM_Jerk				
			AFM: RANDOM MISFIRE Use random misfire thresholds If no misfire for (CylAfterDeacCyl_Decel  AND CylAfterDeacCyl_Jerk)  (CylBeforeDeacCylDecel  AND CylBeforeDeacCylDecel  AND CylBeforeDeacCyl_Jerk)	> 3 Engine Cycles  > CylModeDecel * ClyAfterAFM_Decel * RandomAFM_Decl  > CylModeJerk * CylAfterAFM_Jerk * RandomAFM_Jerk  > CylModeDecel * ClyAfterAFM_Decel * RandomAFM_Decl  > CylModeJerk * CylAfterAFM_Jerk * RandomAFM_Jerk  - see details on Supporting Tables Tab (P0300 Section)				
			Misfire Percent Emission Failure Threshold	≥ 1.88 % P0300				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Misfire Percent Catalyst Damage  When engine speed and load are less than the FTP cals (3) catalyst damage exceedences are allowed.	> Catalyst_Damage_ Misfire_Percentage in Supporting Tables whenever secondary conditions are met.  ≤ 0 FTP rpm AND ≤ 0 FTP % load	(at low speed/loads, one cylinder may not cause cat damage) Engine Speed Engine Load Misfire counts	> 1,000 rpm AND > 25 % load AND < 180 counts on one cylinder		
				disable conditions:				
					Engine Speed	520 < rpm < ((Engine Over Speed Limit) - 150	4 cycle delay	
						Engine speed limit is a function of inputs like Gear and temperature		
						see EngineOverSpeedLimit in supporting tables		
					No active DTCs:	TPS_FA EnginePowerLimited MAF_SensorTFTKO MAP_SensorTFTKO IAT_SensorTFTKO ECT_Sensor_Ckt_TFTKO 5VoltReferenceB_FA CrankSensorTFTKO CrankSensorFA	4 cycle delay	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						CamLctnIntFA CamLctnExhFA CamSensorAnyLctnTFTK O AnyCamPhaser_FA AnyCamPhaser_TFTKO AmbPresDfltdStatus		
					P0315 & engine speed	> 1,000 rpm	4 cycle delay	
					Fuel Level Low	LowFuelConditionDiagnos tic	500 cycle delay	
					Cam and Crank Sensors	in sync with each other	4 cycle delay	
					Misfire requests TCC unlock	Not honored because Transmission in hot mode or POPD intrusive diagnostic running	4 cycle delay	
					Fuel System Status	≠ Fuel Cut	4 cycle delay	
					Active FuelManagement	Transition in progress	7 cycle delay	
					Undetectable engine speed and engine load region	Undetectable region from Malfunction Criteria	4 cycle delay	
					Abusive Engine Over Speed	> 7,250 rpm	0 cycle delay	
					Below zero torque (except CARB approved 3000 rpm to redline triangle.)	< ZeroTorqueEngLoad in Supporting Tables	4 cycle delay	
					Below zero torque: TPS Vehicle Speed	≤ 1 % > 19 mph	4 cycle delay	
					EGR Intrusive test	Active	12 cycle delay	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Manual Trans	Clutch shift	4 cycle delay	
					Accel Pedal Position AND Automatic transmission shift	> 95.00 %	7 cycle delay	
					After Fuel resumes on Automatic shift containing Fuel Cut		2 Cylinder delay	
					DRIVELINE RING FILTER After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early. Filter Driveline ring:	> "Ring Filter" # of		
					Stop filter early:	engine cycles after misfire in Supporting Tables  > "Number of Normals"  # of engine cycles after misfire in Supporting		
					ABNORMAL ENGINE SPEED OSCILLATION: (checks each "misfire" candidate in 100 engine Cycle test to see if it looks like some disturbance like rough road (abnormal). )	Tables tab		
					Used Off Idle, and while not shifting, TPS Engine Speed Veh Speed Auto Transmission	> 3 mph		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					indivdual candidate deemed abnormal if number of consecutive decelerating cylinders after "misfire": (Number of decels can vary with misfire detection equation) Consecutive decels while in SCD Mode Cyl Mode Rev Mode  At the end of 100 engine cycle test, the ratio of abnormal/candidate is checked to confirm if real misfire is present within the 100 engine cycles. abnormal candidates/ total candidates	> Abnormal SCD Mode > Abnormal Cyl Mode > Abnormal Rev Mode in Supporting Tables  > 0.50 ratio	discard 100 engine cycle test	
					MISFIRE CRANKSHAFT PATTERN RECOGNITION checks each "misfire" candidate in 100 engine Cycle test to see if overall crankshaft pattern looks like real misfire (recognized), or some disturbance like rough road (unrecognized).			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Jystem	Code				At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present within the 100 engine cycles. Typically used for checking a single misfire per engine cycle but can support some other patterns on some packages  Pattern Recog Enabled:  Pattern Recog Enabled during Cylinder Deac  Pattern Recog Enabled consecutive cyl pattrn	Enabled Not Enabled Disabled		
					Engine Speed Veh Speed  The 1st check for "recognized" is the 1st fired cylinder after the misfire candidate should both accelerate and jerk an amount based acceleration and jerk of Single Cylinder Misfire thresholds in effect at that speed and load. (CylAfter_Accel AND  CylAfter_Jerk)	630 < rpm < 6,100 > 3.1 mph  > Misfire_ decel * 1st_FireAftrMisfr_Acel > Misfire_Jerk * 1st_FireAftrMisfr_Jerk		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Additionally, the crankhaft is checked again a small calibratible number of cylinders later to see if the distrubance is still large like rough road, or has calmed down like real misfire. The size of disturbance is compared to a multiplier times the ddt_jerk value used to detect misfire at that speed and load. If there is repetitive misfire on consecutive engine cycles, the expected snap is adjusted due to the higher expected disturbance.			
					Num of Cylinders after misfire to start check of crankshaft snap "misfire" recognized if:	2 Cylinders		
					Crankshaft snap after: isolated "misfire"	< Misfire_Jerk * SnapDecayAfterMisfire		
					repetative "misfire"	< Misfire_Jerk * SnapDecayAfterMisfire * RepetSnapDecayAdjst in Supporting Tables	discard 100 engine cycle test	
					At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present.			
					Ratio of Unrecog/Recog	> 0.80		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					: NON-CRANKSHAFT BASED ROUGH ROAD: Rough Road Source  IF Rough Road Source = WheelSpeedInECM	Disabled  TOSS  active > WSSRoughRoadThres active  active  detected active  >TOSSRoughRoadThres in supporting tables  Transmission Output Shaft Angular Velocity Validity TransmissionEngagedStat e_FA (Auto Trans only) <clutch fa="" sensor=""> (Manual Trans only)</clutch>	discard 100 engine cycle test  discard 100 engine cycle test  discard 100 engine cycle test  4 cycle delay	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position System Variation Not Learned	P0315	Monitor for valid crankshaft error compensation factors	Sum of Compensation factors. Each Cylinder pair shares one compensation factor. A perfect factor would be 1.0000. Unlearned factors are defaulted out of range so the sum of factors would be out of range.	≥ 2.0040 OR ≤ 1.9960	OBD Manufacturer Enable Counter	MEC = 0	0.50 seconds Frequency Continuous100 msec	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
,	P0324	This diagnostic checks for knock sensor performance out of the normal expected range on a per cylinder basis due to:  1. Excessive knock or 2. Abnormal engine noise or 3. Flat signal	Common Enable Criteria (Applies to all 3 parts of the performance diag)  Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag:		Diagnostic Enabled? Engine Run Time Engine Speed Engine Air Flow  ECT IAT	Yes  ≥ 2.0 seconds  ≤ 5,000 RPM  ≥ 10 mg/cylinder and  ≤ 2,000 mg/cylinder  ≥ -40 deg's C  ≥ -40 deg's C	First Order Lag Filters with Weight Coefficients	Type B, 2 Trips
			1. Excessive Knock Diag: Filtered Knock Intensity  VaKNKD_k_PerfCylKnock IntFilt (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)	> 1.30 (no units)	Engine Speed  Cumlative Number of Engine Revs Above Min Eng Speed (per key cycle)	≥ 1,500 RPM ≥ 100 Revs	Excessive Knk Weight Coefficient = 0.0400 Updated each engine event	
			2. Abnormal Noise Diag: Filtered FFT Intensity  (where 'FFT Intensity' = Non-knocking, background noise)	<pre></pre>	Individual Cylinders enabled for Abnormal Noise  Engine Speed  Cumlative Number of Engine Revs Above Min Eng Speed (per key	See AbnormalNoise_ CylsEnabled (Supporting Tables)  ≥ 8,500 RPM  ≥ 400 Revs	Abn Noise Weight Coefficient = 0.0100  Updated each engine event	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					cycle)			
			3. Flat Signal Diag: Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock)  VaKNKD_k_PerfCylFlatFil tInt	< 0.008 (no units)	Engine Speed  Cumlative Number of Engine Revs Above Min Eng Speed (per keycycle)	≥ 8,500 RPM ≥ 400 Revs	Flat Signal Weight Coefficient = 0.010 Updated each engine event	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank	P0325	This diagnostic checks for an open in the knock sensor circuit	Filtered FFT Output	> OpenCktThrshMin and < OpenCktThrshMax	Diagnostic Enabled? Engine Run Time	Yes ≥ 2.0 seconds	First Order Lag Filter with Weight Coefficient	Type B, 2 Trips
1		There are two possible methods used: 1. 20 kHz 2. Normal Noise		See Supporting Tables	Engine Speed	≥ 650 RPM and ≤ 7,200 RPM	Weight Coefficient = 0.0100	
		See Supporting Tables for method definition: P0325_P0330_OpenM ethod		Thresholds for OpenMethod = 20 kHz: OpenCktThrshMin (20 kHz) & OpenCktThrshMax (20 kHz)	Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)	≥ 100 revs	Updated each engine event	
		Typical implementations: A. Use 20 kHz method at all RPM (used when acceptable separation achieved at all RPM) or		Thresholds for OpenMethod = NormalNoise: OpenCktThrshMin (Normal Noise) & OpenCktThrshMax (Normal Noise)	Engine Air Flow	≥ 40 mg/cylinder and ≤ 2,000 mg/cylinder ≥ -40 deg's C		
		B. Use 20 kHz method at low/medium RPM and Normal Noise at high RPM			IAT	≥ -40 deg's C		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Bank 1	Cnock Sensor (KS) Performance Bank 1  P0326  This diagnostic check for knock sensor performance out of to normal expected range on a per sensor basing due to	performance out of the normal expected range, on a per sensor basis, due to 1. Excessive knock or 2. Abnormal engine noise or	Common Enable Criteria (Applies to all 3 parts of the performance diag)  Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag:  1. Excessive Knock Diag: Filtered Knock Intensity	> 1.30 (no units)	Diagnostic Enabled? Engine Run Time Engine Speed Engine Air Flow  ECT IAT  Engine Speed Cumlative Number of	Yes  ≥ 2.0 seconds  ≤ 6,500 RPM  ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder  ≥ -40 deg's C  ≥ -40 deg's C  ≥ 8,500 RPM  ≥ 100 Revs	First Order Lag Filters with Weight Coefficients 	Type B, 2 Trips
			(where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)		Engine Revs Above Min Eng Speed (per key cycle)		0.0100 Updated each engine event	
	(where 'FFT Intensity' =	Filtered FFT Intensity: < AbnormalNoise_ (where 'FFT Intensity' = Threshold (see		Individual Cylinders enabled for Abnormal Noise	See AbnormalNoise_ CylsEnabled (Supporting Tables)	Abnormal Noise Weight Coefficient = 0.0100		
			5	Engine Speed  Cumlative Number of Engine Revs Above Min Eng Speed (per key	≥ 2,500 RPM ≥ 100 Revs	Updated each engine event		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					cycle)			
			3. Flat Signal Diag: Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock)	< 0.008 (no units)	Engine Speed  Cumlative Number of Engine Revs Above Min Eng Speed (per keycycle)	≥ 8,500 RPM ≥ 100 Revs	Flat Signal Weight Coefficient = 0.010 Updated each engine event	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 1		This diagnostic checks for an out of range low knock sensor signal	Sensor Input or Return Signal Line	< 8.0 Percent (of 5 V reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 1	P0328	This diagnostic checks for an out of range high knock sensor signal	Sensor Input or Return Signal Line	> 39.0 Percent (of 5 Volt Reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Circuit	P0335	Determines if a fault exists with the crank position sensor signal	Time since last crankshaft position sensor pulse received	>= 4.0 seconds	Starter engaged AND (cam pulses being received OR ( MAF_SensorFA AND Engine Air Flow	= FALSE > 2.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips
			No crankshaft pulses received	>= 0.1 seconds	Engine is Running Starter is not engaged		Continuous every 12.5 msec	
			No crankshaft pulses received		Engine is Running OR Starter is engaged No DTC Active:	P0365 P0366	2 failures out of 10 samples One sample per engine revolution	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Performance	Position (CKP) Sensor A	Determines if a performance fault exists with the crank position sensor signal	Time in which 10 or more crank resynchronizations occur	< 10.0 seconds	Engine Air Flow  Cam-based engine speed  No DTC Active:	>= 2.0 grams/second > 450 RPM P0335	Continuous every 250 msec	Type B, 2 Trips
			No crankshaft synchronization gap found	>= 0.4 seconds	Engine is Running Starter is not engaged		Continuous every 12.5 msec	
			Time since starter engaged without detecting crankshaft synchronization gap	>= 1.5 seconds	Starter engaged AND (cam pulses being received OR ( MAF_SensorFA AND Engine Air Flow	= FALSE > 2.0 grams/second ) )	Continuous every 100 msec	
			Crank pulses received in one engine revolution OR Crank pulses received in one engine revolution	< 51 > 65	Engine is Running OR Starter is engaged No DTC Active:	P0365 P0366	8 failures out of 10 samples  One sample per engine revolution	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor A	exists with the cam position bank 1 sensor	Time since last camshaft position sensor pulse received  OR  Time that starter has been engaged without a camshaft sensor pulse	>= 5.5 seconds >= 4.0 seconds	Starter engaged AND (crank pulses being received OR ( MAF_SensorFA AND Engine Air Flow	= FALSE > 2.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips	
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged		Continuous every 100 msec	
			No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized  Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged		Continuous every MEDRES event	
		The number of camshaft pulses received during 100 engine cycles	= 0	No DTC Active:  Crankshaft is synchronized  No DTC Active:	CrankSensor_FA  CrankSensor_FA	8 failures out of 10 samples  Continuous every engine cycle	_	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor A	P0341	Determines if a performance fault exists with the cam position bank 1 sensor A signal	The number of camshaft pulses received during first 12 MEDRES events is OR  (There are 12 MEDRES events per engine cycle)	< 4 > 6	Crankshaft is synchronized  Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged  No DTC Active:	CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	CrankSensorFA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT - for 3 DTC implementati on only	P0351	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for an Open Circuit fault.	driver high state (indicates	≥ 30 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT - for 3 DTC implementati on only	P0352	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for an Open Circuit fault.	driver high state (indicates	≥30 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT - for 3 DCT implementati on only	P0353	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for an Open Circuit fault.	driver high state (indicates	≥ 30 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT - for 3 DTC implementati on only	P0354	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for an Open Circuit fault.	driver high state (indicates	≥ 30 kΩ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor B	exists with the cam position bank 1 sensor	Time since last camshaft position sensor pulse received  OR  Time that starter has been engaged without a camshaft sensor pulse	>= 5.5 seconds >= 4.0 seconds	Starter engaged AND (crank pulses being received OR ( MAF_SensorFA AND Engine Air Flow	= FALSE > 2.0 grams/second ) )	Continuous every 100 msec	Type B, 2 Trips	
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged		Continuous every 100 msec	
			No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized  Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged		Continuous every MEDRES event	
			The number of camshaft pulses received during 100 engine cycles	= 0	No DTC Active:  Crankshaft is synchronized  No DTC Active:	CrankSensor_FA  CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle	_

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor B	P0366	Determines if a performance fault exists with the cam position bank 1 sensor B signal	The number of camshaft pulses received during first 12 MEDRES events is OR  (There are 12 MEDRES events per engine cycle)	< 4 > 6	Crankshaft is synchronized  Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged  No DTC Active:	CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 > 402	Crankshaft is synchronized No DTC Active:	CrankSensorFA	8 failures out of 10 samples Continuous every engine cycle	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Incorrect Airflow	P0411	Detects an insufficient flow condition. This test is run during Phase 1 (AIR pump commanded On, Valve commanded Open). Leaks downstream of the valve are detected via an evaluation of average pressure error and average "String Length"(SL) — a term that represents the absolute pressure delta accumulated every 6.25ms, then averaged over the duration of the test. Low SL values are indicative of downstream leaks or blockages.	Average Pressure Error or  OR the following String Length (SL) Test:  Average Pressure Error or  and the Average String Length  NOTE: Average Pressure Error is the average difference between the predicted pressure and the measured pressure	> 5.0 kPa < -4.9 kPa > 1.0 kPa < -1.0 kPa < SL Threshold Bank 1 Table	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not SL Stability time SL RPM range  No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec  > 5.0 seconds < 6,000 RPM > 6,500  AIRSystemPressureSens or FA AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRPumpControlCircuit FA AIRPumpControlCircuit FA CatalystSysEfficiencyLoB 1_FA CatalystSysEfficiencyLoB 1_FA CatalystSysEfficiencyLoB 2_FA ControllerProcessorPerf_FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA	Phase 1 Conditional test weight > 7.0 seconds  Total 'String Length' accumulation time > 10.0 sec  Frequency: Once per trip when AIR pump is commanded On  Conditional test weight is calculated by multiplying the following Factors: Phase 1 Baro Test Weight Factor, Phase 1 MAF Test Weight Factor, Phase 1 System Volt Test Weight Factor, Phase 1 Ambient Temp Test Weight Factor (see Supporting Tables)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Incorrect Airflow	P0411	Detects an insufficient flow condition. This test is run during Phase 1 (AIR pump commanded On, Valve commanded Open). Leaks downstream of the valve are detected via an evaluation of average pressure error and average "String Length" (SL) – a term that represents the absolute pressure delta accumulated every 6.25ms, then averaged over the duration of the test. Low SL values are indicative of downstream leaks or blockages.	Average Pressure Error or or or or OR the following String Length (SL) Test:  Average Pressure Error or or or or and the Average String Length or  NOTE: Average Pressure Error is the average difference between the predicted pressure and the measured pressure  OR The following string length ratio test between bank 1 and bank 2:  Calculate the ratio of the average string length difference between pressure sensor 1 and pressure sensor 2 and the string length value of either pressure sensor 1 or pressure sensor 1 or pressure	> 5.0 kPa Bank 1 > 5.0 kPa Bank 2 < -4.9 kPa Bank 1 < -4.9 kPa Bank 2  > 1.0 kPa Bank 2  > 1.0 kPa Bank 2 < -1.0 kPa Bank 2 < -1.0 kPa Bank 2  < SL Threshold Bank 1 Table < SL Threshold Bank 2 Table	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not SL Stability time  SL RPM range  No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec > 5.0 seconds Bank 1 > 5.0 seconds Bank 2 < 6,000 RPM or > 6,500  AIRSystemPressureSens or FA AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRPumpControlCircuit FA AIRPumpControlCircuit FA CT_SensorFA ECT_SensorFA ECT_SensorFA ECT_SensorFA CatalystSysEfficiencyLoB 1_FA CatalystSysEfficiencyLoB 2_FA ControllerProcessorPerf_FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA	Phase 1 Conditional test weight > 7.0 seconds  Total 'String Length' accumulation time: > 10.0 sec Bank1 > 10.0 sec Bank2  Frequency: Once per trip when AIR pump commanded On  Conditional test weight is calculated by multiplying the following Factors: Phase 1 Baro Test Weight Factor, Phase 1 MAF Test Weight Factor, Phase 1 System Volt Test Weight Factor, Phase 1 Ambient Temp Test Weight Factor (see Supporting Tables)	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			sensor 2 (whichever is greater)					
			String Length Ratio Or	> 1.50				
			Or String Length Ratio	< 0.50				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Solenoid Control Circuit Open	P0412	Diagnoses the Secondary AIR Solenoid Control Low Side Driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: >= 200K Ohms impedance between signal and controller ground	Powertrain Relay Voltage	>= 11.00 volts	20 failures out of 25 samples 250ms / sample	Type B, 2 Trips  Note: In certain controlle rs P041F may also set (Second ary AIR solenoid control circuit low voltage)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Pump Control Circuit Open	P0418	Diagnoses the Secondary AIR Pump Control Low Side Driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: >= 200K Ohms impedance between signal and controller ground	Powertrain relay Voltage	>= 11.00 volts	20 failures out of 25 samples 250ms / sample	Type B, 2 Trips  Note: In certain controlle rs P2257 may also set (Second ary AIR Pump Control Circuit Low Voltage)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Solenoid Control Circuit Low Voltage	P041F	Diagnoses the Secondary AIR Solenoid Control Low Side Driver circuit for circuit faults	Voltage low during driver off state (indicates short-to-ground)	Short to ground: <= 0.5 Ohms impedance between signal and controller ground	Powertrain relay Voltage	>= 11.00 volts	20 failures out of 25 samples 250ms / sample	Type B, 2 Trips Note: In certain controlle rs P0412 may also set (Second ary AIR solenoid control circuit Open)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 1	P0420	NOTE: The information below applies to applications that use the Decel Catalyst Monitor Algorithm  Oxygen StorageThe catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (I.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Rich (intrusive rich) and Lean (decel fuel cutoff) A/F excursions  Normalized Ratio OSC Value Calculation Information and Definitions = 1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time) 2. BestFailing OSC value from a calibration	Normalized Ratio OSC Value (EWMA filtered)	< 0.35	All enable criteria associated with P0420 can be found under P2270 - (O2 Sensor Signal Stuck Lean Bank 1 Sensor 2)  Rapid Step Response (RSR) feature will initiate multiple tests:  If the difference between current EWMA value and the current OSC Normalized Ratio value is and the current OSC Normalized Ratio value is  Maximum number of RSR tests to detect failure when RSR is enabled.  General Enable Criteria  In addition to the p-codes listed under P2270, the following DTC's shall also not be set:	> 0.41 <0.15 12  O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_2_FA	1 test attempted per valid decel period  Minimum of 1 test per trip  Maximum of 8 tests per trip  Frequency: Fueling Related: 12.5 ms  OSC Measurements: 100 ms  Temp Prediction: 12.5ms	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		table (based on temp and exhaust gas flow) 3. WorstPassing OSC value (based on temp and exhaust gas flow)						
		Normalized Ratio Calculation = (1-2) / (3-2)						
		A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part.						
		Refer to the P0420_WorstPassing OSCTableB1 and P0420_BestFailingOS CTableB1 in Supporting Tables tab for details						
		The Catalyst Monitoring Test is completed during a decel fuel cutoff event. This fuel cutoff event occurs following a rich instrusive fueling event initiated by the O2 Sensor Signal Stuck Lean Bank 1 Sensor 2 test (P2270). Several conditions must be met in order to execute this test.						
		These conditions and their related values are listed in the "Secondary						

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Parameters" and "Enable Conditions" section of this document for P2270 (O2 Sensor Signal Stuck Lean Bank 1 Sensor 2)						

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Small Leak Detected (No ELCP - Conventional EVAP Diagnostic with EAT using IAT Sensor)	P0442	This DTC will detect a small leak (≥ 0.020") in the EVAP system between the fuel fill cap and the purge solenoid. On some applications a small leak is defined as ≥ 0.025", 0.030", or 0.150". The engine off natural vacuum method (EONV) is used. EONV is an evaporative system leak detection diagnostic that runs when the vehicle is shut off when enable conditions are met. Prior to sealing the system and performing the diagnostic, the fuel volatility is analyzed. In an open system (Canister Vent Solenoid [CVS] open) high volatility fuel creates enough flow to generate a measurable pressure differential relative to atmospheric.After the volatility check, the vent solenoid will close. After the vent is closed, typically a build up of pressure from the hot soak begins (phase-1). The pressure typically will peak and then begin to decrease as the fuel cools. When	Threshold (Pascals) Table in Supporting Tables). The normalized value is calculated by the following equation: 1 - (peak pressure - peak vacuum) / pressure threshold. The normalized value is entered into EWMA (with 0= perfect pass and 1= perfect fail).	> 0.54 (EWMA Fail Threshold), ≤ 0.35 (EWMA Re- Pass Threshold)	Fuel Level Drive Time Drive length ECT Baro Distance since assembly plant Engine not run time before key off must be  Time since last complete test if normalized result and EWMA is passing  OR Time since last complete test if normalized result or EWMA is failing  Estimated ambient temperature at end of drive  Estimate of Ambient Air Temperature Valid ************************************	10 % ≤ Percent ≤ 90 % ≥ 600 seconds ≥ 5.0 miles ≥ 63 °C ≥ 70 kPa ≥ 10.0 miles  ≤ refer to P0442: Engine Off Time Before Vehicle Off Maximum as a Function of Estimated Ambient Temperature Table in Supporting Tables.  ≥ 17 hours  ≥ 10 hours  ○ °C≤Temperature≤ 34 °C	Once per trip, during hot soak (up to 2,400 sec.). No more than 2 unsuccessful attempts between completed tests.	Type A, 1 Trips EWMA Average run length is 8 to 12 trips under normal condition s Run length is 3 to 6 trips after code clear or non- volatile reset

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
	Fault Code	the pressure drops (-62.27) Pa from peak pressure, the vent is then opened for 60 seconds to normalize the system pressure. The vent is again closed to begin the vacuum portion of the test (phase-2). As the fuel temperature continues to fall, a vacuum will begin forming. The vacuum will continue until it reaches a vacuum peak. When the pressure rises 62.27 Pa from vacuum peak, the test then completes. If the key is turned on while the diagnostic test is in progress, the test will abort.		Threshold Value	Startup delta deg C (ECT-IAT)  OR 2. Short Soak and Previous EAT Valid  Previous time since engine off  OR 3. Less than a short soak and Previous EAT Not Valid  Previous time since engine off AND  Vehicle Speed AND  Mass Air Flow  Must expire Estimate of Ambient Temperature Valid Conditioning Time.  P0442: Estimate of Ambient Temperature Valid Conditioning Time Table in Supporting Tables.  OR 4. Not a Cold Start and greater than a Short Soak  Previous time since engine off AND		Time Required	
					Vehicle Speed AND Mass Air Flow	≥ 30 mph ≥ 7 g/sec		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Must expire maximum value in Estimate of Ambient Temperature Valid Conditioning Time. Please see P0442: Estimate of Ambient Temperature Valid Conditioning Time in Supporting Tables.  ***********************************	**************************************		
					See P0454 Fault Code for information on vacuum refueling algorithm.  OR 3. Fuel Level Refueling			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Detected			
					See P0464 Fault Code for information on fuel level refueling.			
					OR 4. Vacuum Out of Range and No Refueling			
					See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.			
					OR 5. Vacuum Out of Range and Refueling Detected			
					See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.			
					OR 6. Vent Valve Override Failed			
					Device control using an off-board tool to control the vent solenoid, cannot exceed during the EONV test	0.50 seconds		
					OR 7. Key up during EONV test			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs:	MAF_SensorFA ECT_Sensor_FA IAT_Sensor_FA VehicleSpeedSensor_FA IgnitionOffTimeValid AmbientAirDefault  P0443 P0446 P0449 P0452 P0453 P0455 P0496		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Canister Purge Solenoid Valve Circuit (ODM)  (No ELCP - Conventional EVAP Diagnostic - For 3 DTC Implementati on Only)	P0443	Diagnoses the canister purge solenoid low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedence between signal and controller ground	PT Relay Voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0458 may also set (Caniste r Purge Solenoid Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent System Performance (No ELCP - Conventional EVAP Diagnostic)	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filler, vent hose or EVAP canister.  This test runs with normal purge and vent valve is open.	Vent Restriction Prep Test: Vented Vacuum for OR Vented Vacuum for  Vent Restriction Test: Tank Vacuum for before Purge Volume  After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time.	<-623 Pa 60 seconds >1,245 Pa 60 seconds  > 2,989 Pa 5 seconds ≥ 8 liters	Fuel Level System Voltage  Startup IAT  Startup ECT BARO  No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts 4 °C ≤ Temperature ≤ 30 °C ≤ 35 °C ≥ 70 kPa  MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited  P0443 P0449 P0452 P0453 P0454	Once per Cold Start  Time is dependent on driving conditions  Maximum time before test abort is 1,000 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent Solenoid Control Circuit (ODM)  (No ELCP - Conventional EVAP Diagnostic - For 3 DTC Implementati on Only)	P0449	Diagnoses the vent solenoid low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedence between signal and controller ground			20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0498 may also set (Vent Solenoid Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Solenoid Control Circuit High Voltage	P044F	Diagnoses the Secondary AIR Solenoid Control Low Side Driver circuit for circuit faults	Voltage high during driver on state (indicates short- to-power)	Short to power: <= 0.5 Ohms impedance between signal and controller power	Powertrain relay Voltage	>= 11.00 volts	20 failures out of 25 samples 250ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Performance (No ELCP - Conventional EVAP Diagnostic)	P0451	The DTC will be set if the fuel tank vacuum sensor is out of range when it tries to re-zero prior to the phase-1 or phase-2 portions of the engine-off natural vacuum small leak test.	The tank vacuum sensor voltage is compared to a window about the nominal sensor voltage offset (~1.5 volts)  Upper voltage threshold (voltage addition above the nominal voltage)  Lower voltage threshold (voltage subtraction below the nominal voltage)  The difference between tank vacuum sensor voltage and the nominal offset voltage is then normalized against the appropriate threshold listed above to produce a ratio between 0.0 and 1.0. This normalized re-zero ratio is then filtered with a EWMA (with 0= perfect pass and 1=perfect fail).	0.2 volts 0.2 volts	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		This test is executed during an engine-off natural vacuum small leak test. The number of times that it executes can range from zero to two per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.	Type A, 1 Trips EWMA Average run length: 6 Run length is 2 trips after code clear or non- volatile reset
	t t	When EWMA is the DTC light is illuminated.	> 0.73 (EWMA Fail Threshold),					
		The DTC light can be turned off if the EWMA is and stays below the EWMA fail threshold for 3 additional consecutive trips.	≤0.40 (EWMA Re-Pass Threshold)					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Low Voltage  (No ELCP - Conventional EVAP Diagnostic)	P0452	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too low out of range.	The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~-3736 Pa).	< 0.15 volts (3.0 % of Vref or ~ 1,681 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples 12.5 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit High Voltage  (No ELCP - Conventional EVAP Diagnostic)	P0453	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too high out of range.	FTP sensor signal  The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~-3736 Pa).	> 4.85 volts (97 % of Vref or ~ -4,172 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples 12.5 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Intermittent (No ELCP - Conventional EVAP Diagnostic)	P0454	This DTC will detect intermittent tank vacuum sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	If an abrupt change in tank vacuum is detected the engine-off natural vacuum test is aborted due to an apparent refueling event.  Subsequent to the abort, a refueling rationality test is executed to confirm that a refueling event occurred. If a refueling is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem. An abrupt change is defined as a change in vacuum: in the span of 1.0 seconds. But in 12.5 msec. A refueling event is confirmed if the fuel level has a persistent change of for 30 seconds during a 600 second refueling rationality test.	>112 Pa < 249 Pa >10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes and the canister vent solenoid is closed		This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.  12.5 ms / sample	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Large Leak Detected (No ELCP - Conventional EVAP Diagnostic)	P0455	This DTC will detect a weak vacuum condition (large leak or purge blockage) in the EVAP system.  Purge valve is controlled (to allow purge flow) and vent valve is commanded closed.	Purge volume while Tank vacuum  After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time.  Weak Vacuum Follow-up Test (fuel cap replacement test) Weak Vacuum Test failed.  Passes if tank vacuum  Note: Weak Vacuum Follow-up Test can only report a pass.	> 15 liters ≤2,740 Pa	Fuel Level System Voltage  BARO Purge Flow  No active DTCs:  Cold Start Test  If ECT > IAT, Startup temperature delta (ECT-IAT): Cold Test Timer Startup IAT  Startup ECT  Weak Vacuum Follow-up Test This test can run following a weak vacuum failure or on a hot restart.	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts ≥ 70 kPa ≥ 2.80 %  MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited  P0443 P0449 P0452 P0453 P0454  ≤ 8 °C ≤ 1,000 seconds 4 °C≤Temperature≤ 30 °C ≤ 35 °C	Once per cold start  Time is dependent on driving conditions  Maximum time before test abort is 1,000 seconds  Weak Vacuum Follow-up Test  With large leak detected, the follow-up test is limited to 1,300 seconds. Once the MIL is on, the follow-up test runs indefinitely.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Purge Control Valve Circuit Low  (No ELCP - Conventional EVAP Diagnostic)	P0458	Diagnoses the canister purge solenoid low side driver circuit for circuit faults	Voltage low during driver off state (indicates short to ground)	Short to ground: ≤ 0.5 Ω impedence between signal and controller ground	PT Relay Voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips  Note: In certain controlle rs P0443 may also set (Caniste r Purge Solenoid Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Purge Control Valve Circuit High  (No ELCP - Conventional EVAP Diagnostic)	P0459		Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedence between signal and controller power	PT Relay Voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Performance	P0461	This DTC will detect a fuel sender stuck in range in the primary fuel tank.	Delta fuel volume change over an accumulated 149 miles.	< 3 liters	Engine Running No active DTCs:	VehicleSpeedSensor_FA	250 ms / sample	Type B, 2 Trips
(For use on vehicles with a single fuel tank)								

Component/ Fau System Cod		tor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Fuel Level Sensor 1 Circuit Low Voltage	fuel se range	OTC will detect a ender stuck out of low in the ry fuel tank.	Fuel level Sender % of 5V range	< 10 %			100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Fuel Level Sensor 1 Circuit High	P0463	This DTC will detect a fuel sender stuck out of range high in the	Fuel level Sender % of 5V range	> 60 %			100 failures out of 125 samples	Type B, 2 Trips
Voltage		primary fuel tank.					100 ms / sample	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Intermittent (No ELCP - Conventional EVAP Diagnostic)	P0464	This DTC will detect intermittent fuel level sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	If a change in fuel level is detected, the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that an actual refueling event occurred. If a refueling event is confirmed, then the test sample is considered passing. Otherwise, if a refueiling event is not confirmed, then the test sample is considered failing which indicates an intermittent signal problem.  An intermittent fuel level signal problem is defined as:  The fuel level changes by and does not remain for 30 seconds during a 600 second refueling rationality test.	> 10 % > 10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Open (ODM) (Not used on EREV)	P0480	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0691 may also set (Fan 1 Short to Ground).

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Open (ODM)	P0481	Diagnoses the cooling fan 2 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0693 may also set (Fan 2 Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Flow During Non- Purge (No ELCP - Conventional EVAP Diagnostic)	P0496	This DTC will determine if the purge solenoid is leaking to engine manifold vacuum.  This test will run with the purge valve closed and the vent valve closed.	Tank Vacuum for Test time	> 2,491 Pa 5 seconds  ≤ refer to P0496: Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level Table in Supporting Tables.	Fuel Level System Voltage  BARO Startup IAT  Startup ECT Engine Off Time  No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts ≥ 70 kPa 4 °C≤Temperature≤ 30 °C ≤ 35 °C ≥ 28,800.0 seconds  MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited  P0443 P0443 P0449 P0452 P0453 P0454	Once per cold start  Cold start: max time is 1,000 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Vent Solenoid Control Circuit Low	P0498	Diagnoses the vent solenoid low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short to ground)	Short to ground: ≤ 0.5 Ω impedence between signal and controller ground			20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle
(No ELCP - Conventional EVAP Diagnostic)								rs P0449 may also set (Vent Solenoid Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Vent Solenoid Control Circuit High	P0499	Diagnoses the vent solenoid low side driver circuit for circuit faults. If the P0499 is active, an intrusive test is performed with the vent solenoid commanded	Voltage low during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedence between signal and controller power			20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips
(No ELCP - Conventional EVAP Diagnostic)		closed for 15 seconds.						

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Low Engine Speed Idle System	P0506	This DTC will determine if a low idle exists	Filtered Engine Speed Error	> 91.00 rpm	Baro	> 70 kPa	Diagnostic runs in every 12.5 ms loop	Type B, 2 Trips
			filter coefficient	0.00300	Coolant Temp	> KeSPDD_T_EnblECT_Mi n (60 °C) and < KfECTI_T_EngCoolHotHi Thresh (124 °C) Must verify KfECTI_T_EngCoolHotLo Thresh (120) is less than KfECTI_T_EngCoolHotHi Thresh (124)	Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	
					Engine run time	≥ 60 sec		
					Ignition voltage	32 ≥ volts ≥ 11		
					Time since gear change	≥ 3 sec		
					Time since a TCC mode change	> 3 sec		
					IAT	> -20 °C		
					Vehicle speed	≤ 1.24 mph		
					Commanded RPM delta	≤ 25 rpm		
					Idle time	> 10 sec		
					For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 80.00 pct < 12.00 pct		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						PTO not active  Transfer Case not in 4WD LowState  Off-vehicle device control (service bay control) must not be active.  following conditions not TRUE: (VeTESR_e_EngSpdReql ntvType = CeTESR_e_EngSpdMinLi mit AND VeTESR_e_EngSpdReqR espType = CeTESR_e_NoSuggestio n)  Clutch is not depressed  TC_BoostPresSnsrFA		
					No active DTCs	ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorCircuitFA EvapFlowDuringNonPurg e_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_F A IgnitionOutputDriver_FA		

			TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA FuelLevelDataFault LowFuelConditionDiagnos tic Clutch Sensor FA AmbPresDfltdStatus P2771		
		All of the above met for Idle time	> 10 sec  The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop vehicle)		
_			All of the above met for Idle time	All of the above met for Idle time  > 10 sec  The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop	All of the above met for Idle time  > 10 sec  The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Engine Speed Idle System	P0507	This DTC will determine if a high idle exists	Filtered Engine Speed Error	< -182.00 rpm	Baro	> 70 kPa	Diagnostic runs in every 12.5 ms loop	Type B, 2 Trips
			filter coefficient	0.00300	Coolant Temp	KeSPDD_T_EnblECT_Mi n (60 °C) and < KfECTI_T_EngCoolHotHi Thresh (124 °C) Must verify KfECTI_T_EngCoolHotLo Thresh (120) is less than KfECTI_T_EngCoolHotHi Thresh (124)	Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	
					Engine run time	≥ 60 sec		
					Ignition voltage	32 ≥ volts ≥ 11		
					Time since gear change	≥ 3 sec		
					Time since a TCC mode change	> 3 sec		
					IAT	> -20 °C		
					Vehicle speed	≤ 1.24 mph		
					Commanded RPM delta	≤ 25 rpm		
					For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 80.00 pct < 12.00 pct		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	PTO not active  Transfer Case not in 4WD LowState  Off-vehicle device control (service bay control) must not be active.  following conditions not TRUE: (VeTESR_e_EngSpdReql ntvType =         CeTESR_e_EngSpdMinLi mit AND         VeTESR_e_EngSpdReqR espType =         CeTESR_e_NoSuggestio n)  Clutch is not depressed  TC_BoostPresSnsrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorCircuitFA EvapFlowDuringNonPurg e_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_F A IgnitionOutputDriver_FA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						FuelLevelDataFaultLow FuelConditionDiagnostic Clutch SensorFA AmbPresDfltdStatus P2771		
					All of the above met for Idle time	> 10 sec  The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop vehicle)		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Air Conditioning High Side Pressure Sensor (HSPS) Circuit Low Voltage	P0532	Determines if the Air Conditioning High Side Pressure Sensor circuit voltage is too low		< 2 percent	Sensor Present  Diagnostic enabled/ disabled	Enabled Enabled	100 failures out of 120 samples Performed every 25 msec	Type B, 2 Trips

	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Air Conditioning High Side Pressure Sensor (HSPS) Circuit High Voltage	P0533	Determines if the Air Conditioning High Side Pressure Sensor circuit voltage is too high	(AC High Side Pressure Sensor Circuit Voltage) / 5 Volts	> 98 percent	Sensor Present  Diagnostic enabled/ disabled	Enabled Enabled	100 failures out of 120 samples Performed every 25 msec	Type B, 2 Trips

Component/ Fau System Cod		Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Mutil- Functon Switch Circuit	:	Detect when cruise control multi-function switch circuit (analog) voltage is in an illegal range	Cruise Control analog circuit voltage must be in an "illegal range" or "between ranges" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 0.500 seconds	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control On Switch Circuit	P0565		Cruise Control On switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	MIL Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Resume Circuit	P0567	Detects a failure of the cruise resume switch in a continously applied state	Cruise Control Resume switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 89.000 seconds	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Set Circuit	P0568	Detects a failure of the cruise set switch in a continously applied state	Cruise Control Set switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 89.000 seconds	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Cancel Switch Circuit	P056C		Cruise Control Cancel switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Input Circuit	P0575	Detects rolling count or protection value errors in Cruise Control Switch Status serial data signal	If x of y rolling count / protection value faults occur, disable cruise for duration of fault		Cruise Control Switch Serial Data Error Diagnostic Enable	1.00	10 / 16 counts	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Range/ Performance	P057B	monitors the Brake Pedal Position Sensor for a stuck in range failure			Brake Pedal Position Sensor Circuit Range / Performance Diagnostic Enable	1.00 ignition voltage > 10.00		MIL: Type A, 1 Trips
			Calculated EWMA value must be greater than calibratable theshold after calibratable number of tests have completed to report a "test passed" for P057B	EWMA value looked up in supporting table P057B KtBRKI_K_FastTestPointWeight as a function of calculated brake pedal position delta EWMA value is > 0.70	calculated brake pedal position delta sample counter > 75.00 for fast test  OR  calculated brake pedal position delta sample counter > 1,000.00 for slow test	calculated brake pedal position delta > 5.21  OR (for slow test) shift lever has been in park once this key cycle vehicle speed >= 5.00 accelerator pedal position < 5.00	total number of EWMA tests > 15.00	
			Calculated EWMA Value must be less than calibratable threshold after calibratable number of tests have completed to report a "test failed" for P057B. This test runs once per key cycle	EWMA value looked up in supporting table P057B KtBRKI_K_CmpltTestP ointWeight as a function of calculated brake pedal position delta EWMA value is less thatn 0.30	no DTC's active (P057C, P057D)	shift lever has been in park once this key cycle vehicle speed >= 5.00 accelerator pedal position < 5.00	total number of EWMA tests > 2.00	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Low	P057C	detects short to ground for brake pedal position sensor		5.00	Brake Pedal Position Sensore Low Voltage Diagnostic Enable	1.00	20 / 32.00 counts	MIL: Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit High	P057D	detects open circuit for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	95.00	Brake Pedal Position Sensore High Voltage Diagnostic Enable	1.00	20.00/ 32.00 counts	MIL: Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi- function Circuit Low Voltage	P0580	detects short to ground failure for cruise multi- function switch circuit	Cruise Control analog circuit voltage must be in an "Open Short To Ground" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi- function Circuit High Voltage	P0581		Cruise Control analog circuit voltage must be in an "Short To Power" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control Open Circuit	P0597	Diagnoses the T-stat Heater low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Run Crank Ignition in Range  Engine not cranking Run Crank active  == Above is true and ==  Last Open Circuit Test	= True = True = True = True = = not Indeterminate	15 failures out of 30 samples 1 sec/ sample Continuous	Type B, 2 Trips Note: In certian controlle rs P0598 may also set

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control Circuit Low	P0598	Diagnoses the T-stat Heater low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run Crank Ignition in Range  Engine not cranking Run Crank active  == Above is true and ==  Last Ground Short Circuit Test	= True = True = True = True ====================================	15 failures out of 30 samples 1 sec/ sample Continuous	Type B, 2 Trips Note: In certian controlle rs P0597 may also set

	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control Circuit High	P0599	Diagnoses the T-stat Heater low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Run Crank Ignition in Range  Engine not cranking Run Crank active  == Above is true and ==  Last Power Short Circuit Test	= True = True = True = True ================================	15 failures out of 30 samples 1 sec/ sample Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if the calibration check sum is incorrect or the flash memory detects an uncorrectable error via the Error Correcting Code.	The Primary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	Type A, 1 Trips
		Error Correcting Code hardware in the flash memory detects an error Covers all software and calibrations.  The Primary Processor's calculated checksum does not match the store checksum value for a selected subset of the calibrations.  The Secondary Processor's calculated checksum does not match the stored checksum value. Covers all	hardware in the flash memory detects an error. Covers all software and	254 failures detected via Error Correcting Code			Diagnostic runs continuously via the flash hardware.	
			does not match the stored checksum value for a selected subset of the	2 consecutive failures detected or 5 total failures detected.			Diagnostic runs continuously. Will report a detected fault within 200 ms.	
			Processor's calculated checksum does not match the stored checksum	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	
				In all cases, the failure count is cleared when controller shuts down				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Not Programmed	P0602	This DTC will be stored if the ECU is a service part that has not been programmed.	Service (reflash) controller calibration present	= 1		none	Diagnostic runs at powerup and once per second continuously after that	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Long Term Memory Reset	P0603	Non-volatile memory checksum error at controller power-up	Checksum at power-up does not match checksum at power-down				Diagnostic runs at powerup  Diagnostic reports a fault if 1 failure occurs	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM RAM Failure	has detected a RAM fault	Indicates that the primary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	Type A, 1 Trips	
		Indicates that the primary processor is unable to correctly read data from or write data to cached RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)		
		proce corre or wri Detec	Indicates that the primary processor is unable to correctly read data from or write data to TPU RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
	process mismat data an found o updates mismat	Indicates that the primary processor detects a mismatch between the data and dual data is found during RAM updates. Detects a mismatch in data and dual data updates >	0.44000 s			When dual store updates occur.		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Indicates that the primary processor detects an illegal write attempt to protected RAM. Number of illegal writes are >	65,534 counts			Diagnostic runs continuously (background loop)	
			Indicates that the secondary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Fault	P0606	Indicates that the ECM has detected an internal processor integrity fault	Loss or invalid message of SPI communication from the Secondary Processor at initialization detected by the Primary Processor or loss or invalid message of SPI communication from the Secondary Processor after a valid message was received by the Primary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was recieved		Run/Crank voltage >= 6.41 or Run/Crank voltage >= 11.00, else the failure will be reported for all conditions	intermittent or 39 counts continuous; 39 counts continuous @ initialization. 12.5 ms /count in the ECM main processor	Type A, 1 Trips
			Loss or invalid message of SPI communication from the Primary Processor at initialization detected by the Secondary Processor or loss or invalid message of SPI communication from the Primary Processor after a valid message was received by the Secondary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was recieved			In the secondary processor, 20/200 counts intermittent or 0.1875 s continuous; 0.4750 s continuous @ initialization. 12.5 ms /count in the ECM secondary processor	
		Checks for stack over or underflow in secondary processor by looking for corruption of known pattern at stack boundaries. Checks number of stack over/ under flow since last powerup reset >=  MAIN processor is verified by responding to a seed sent from the secondary with a key response to secondary. Checks number of incorrect keys	underflow in secondary processor by looking for corruption of known pattern at stack boundaries. Checks number of stack over/ under flow since last	5		KeMEMD_b_StackLimitTe stEnbl == 1 Value of KeMEMD_b_StackLimitTe stEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			2 incorrect seeds within 8 messages, 0.2000 seconds		ignition in Run or Crank	150 ms for one seed continually failing		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			received > or Secondary processor has not received a new within time limit					
			Time new seed not received exceeded			always running	0.450 seconds	
			MAIN processor receives seed in wrong order			always running	3 / 17 counts intermittent. 50 ms/count in the ECM main processor	
			2 fails in a row in the Secondary processor's ALU check			KePISD_b_ALU_TestEnbl d == 1 Value of KePISD_b_ALU_TestEnbl d is: 1. (If 0, this test is disabled)	25 ms	
			2 fails in a row in the Secondary processor's configuration register masks versus known good data			KePISD_b_ConfigRegTes tEnbld == 1 Value of KePISD_b_ConfigRegTes tEnbld is: 1. (If 0, this test is disabled)	12.5 to 25 ms	
			Secondary processor detects an error in the toggling of a hardware discrete line controlled by the MAIN processor: number of discrete changes > = or < = over time window(50ms)	7 17		KePISD_b_MainCPU_SO H_FItEnbld == 1 Value of KePISD_b_ConfigRegTes tEnbld is: 0 . (If 0, this test is disabled) time from initialization >= 0.4875 seconds	50 ms	
			Software background task first pass time to complete exceeds			Run/Crank voltage > 6.41	360.000 seconds	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			2 fails in a row in the MAIN processor's ALU check			KePISD_b_ALU_TestEnbl d == 1 Value of KePISD_b_ALU_TestEnbl d is: 1. (If 0, this test is disabled)	25 ms	
			2 fails in a row in the MAIN processor's configuration register masks versus known good data			KePISD_b_ConfigRegTes tEnbld == 1 Value of KePISD_b_ConfigRegTes tEnbld is: 1. (If 0, this test is disabled)	12.5 to 25 ms	
			Checks number of stack over/under flow since last powerup reset >=	3		KeMEMD_b_StackLimitTe stEnbl == 1 Value of KeMEMD_b_StackLimitTe stEnbl is: 1. . (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			Voltage deviation >	0.4950		KePISD_b_A2D_CnvrtrTe stEnbId == 1 Value of KePISD_b_A2D_CnvrtrTe stEnbId is: 1. (If 0, this test is disabled)	5 / 10 counts or 0.150 seconds continuous; 50 ms/count in the ECM main processor	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occured since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_FlashECC_ CktTestEnbI == 1 Value of KeMEMD_b_FlashECC_ CktTestEnbI is: 1. (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	
			Checks for ECC (error	3 (results in MIL),		KeMEMD_b_RAM_ECC_	variable,	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occured since last controller initialization. Counter >=	5 (results in MIL and remedial action)		CktTestEnbl == 1 Value of KeMEMD_b_RAM_ECC_ CktTestEnbl is: 1. (If 0, this test is disabled)	depends on length of time to write flash to RAMvariable, depends on length of time to write flash to RAM	
			MAIN processor DMA transfer from Flash to RAM has 1 failure			KePISD_b_DMA_XferTest Enbld == 1 Value of KePISD_b_DMA_XferTest Enbld is: 0. (If 0, this test is disabled)	depends on length of time to	
			Safety critical software is not executed in proper order.	>= 1 incorrect sequence.		Table, f(Loop Time). See supporting tables: Program Sequence Watch Enable f(Loop Time)  (If 0, this Loop Time test is disabled)	Fail Table, f(Loop Time). See supporting tables: PSW Sequence Fail f (Loop Time)	
							Sample Table, f (Loop Time)See supporting tables: PSW Sequence Sample f(Loop Time)	
							counts 50 ms/count in the ECM main	
			MAIN processor	Previous seed value		KePISD b SeedUpdKey	processor Table, f(Loop	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			determines a seed has not changed within a specified time period within the 50ms task.	equals current seed value.		StorFltEnbl == 1 Value of KePISD_b_SeedUpdKey StorFltEnbl is: 1. (If 0, this test is disabled)	Time). See supporting tables: Last Seed Timeout f (Loop Time)	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Fuel Pump Relay Control Circuit Low Voltage	P0628	Diagnoses the fuel pump relay control high side driver circuit for circuit faults	Voltage low during driver on state (indicates short to ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage Engine Speed	Voltage ≥ 11 volts ≥ 0 RPM	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module EEPROM Error	P062F	Indicates that the NVM Error flag has not been cleared	The next write to NVM will not succeed or the assembly calibration integrity check failed.		Ignition State	= unlock/accessory, run, or crank	1 test failure  Diagnostic runs once at powerup	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VIN Not Programmed or Mismatched - Engine Control Module (ECM)	P0630	This DTC checks that the VIN is correctly written	At least one of the programmed VIN digits	= 00 or FF	OBD Manufacturer Enable Counter	= 0	250 ms / test Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #1 Circuit	P0641	Detects a continuous or intermittent short on the 5 volt reference circuit #1		4.875 5.125 0.0495		Run/Crank voltage > 6.41	19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Open	P0650	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Run/Crank Voltage  Remote Vehicle Start is not active	Voltage ≥ 11 volts	50 failures out of 63 samples 50 ms / sample	Type B, No MIL Note: In certain controlle rs P263A may also set (MIL Control Short to Ground)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #2 Circuit	P0651	Detects a continuous or intermittent short on the 5 volt reference circuit #2		4.875 5.125 0.0495		Run/Crank voltage > 6.41	19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Bank 1	P0660	Diagnoses the Intake Manifold Tuning (IMT) Valve low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: >= 200K Ohms impedance between signal and controller ground	Powertrain Relay Voltage Engine Speed	>= 11.00 Volts >= 400 RPM	40 failures out of 50 samples 1 sample every 12.5 msec	Type B, 2 Trips  Note in certain controlle rs P0661 may also set (Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Low Voltage Bank 1)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Low Voltage Bank 1	P0661	Diagnoses the Intake Manifold Tuning (IMT) Valve low side driver circuit for circuit faults	Voltage low during driver off state (indicates short-to-ground or open circuit)	Short to ground: <= 0.5 Ohms impedance between signal and controller ground  Open Circuit: >= 200K Ohms impedance between signal and controller ground	Powertrain Relay Voltage Engine Speed	>= 11.00 Volts >= 400 RPM	40 failures out of 50 samples  1 sample every 12.5 msec	Type B, 2 Trips  Note in certain controlle rs P0660 may also set (Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit Bank 1)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Solenoid Control Circuit High Voltage Bank 1	P0662	Diagnoses the Intake Manifold Tuning (IMT) Valve low side driver circuit for circuit faults	Voltage low during driver on state (indicates short- to-power)	Short to power: <= 0.5 Ohms impedance between signal and controller power	Powertrain Relay Voltage Engine Speed	>= 11.00 Volts >= 400 RPM	40 failures out of 50 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Open	P0685	Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω ohms impedance between signal and controller ground	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0686 may also set (Powertr ain Relay Control Short to Ground).

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Low	P0686	Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short- to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0685 may also set (Powertr ain Relay Control Open Circuit).

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) High	P0687	Diagnoses the powertrain relay control low side driver circuit for circuit faults		Short to power: ≤ 0.5 Ω impedance between signal and controller power	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Feedback Circuit High	P0690	This DTC is a check to determine if the Powertrain relay is functioning properly.	Powertrain Relay Voltage	>= 4.00 volts will increment the fail counter	Powertrain relay commanded "OFF"  No active DTCs:	>= 2.00 seconds  PowertrainRelayStateOn_ FA	50 failures out of 63 samples 100ms / Sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Low Voltage (ODM)	P0691	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0480 may also set (Fan 1 Open Circuit).

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Cooling Fan 1 Relay Control Circuit High Voltage (ODM)	P0692	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	on state (indicates short	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Low Voltage (ODM)	P0693	Diagnoses cooling fan 2 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short- to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0481 may also set (Fan 2 Open Circuit).

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit High Voltage (ODM)	P0694	Diagnoses the cooling fan 2 relay control low side driver circuit for circuit faults	, ·	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #3 Circuit	P0697			4.875 5.125 0.0495		Run/Crank voltage > 6.41	19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Control Module (FPCM) Requested MIL Illumination	P069E	Monitors the FPCM MIL request line to determine when the FPCM has detected a MIL illuminating fault.	Fuel Pump Control Module Emissions- Related DTC set			Time since power-up ≥ 3 seconds	Continuous	Type A, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #4 Circuit	P06A3			4.875 5.125 0.0495		Run/Crank voltage > 6.41	19/39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Control Module (TCM) Requested MIL Illumination	P0700	Monitors the TCM MIL request line to determine when the TCM has detected a MIL illuminating fault.	Transmission Emissions- Related DTC set			Time since power-up ≥ 3 seconds	Continuous	Type A, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Traction Control Torque Request Circuit	P0856	Determines if torque request from the EBTCM is valid	Serial Communication 2's complement message - (\$140 for PPEI2 or \$1C9 for PPEI3, \$1CA/\$1C6 for Hybrid))	Message <> 2's complement of message	Serial communication to EBTCM (U0108)  Power Mode Engine Running	No loss of communication  = Run = True	Count of 2's complement values not equal >= 6  Performed on every received message	Type C, No MIL Special Type C
			OR Serial Communication message (\$140 for PPEI2 or \$1C9 for PPEI3, \$1CA/ \$1C6 for Hybrid)) rolling count value	Message rolling count value <> previous message rolling count value plus one	Status of traction in GMLAN message (\$4E9)	= Traction Present	6 rolling count failures out of 10 samples  Performed on every received message	
			OR Too many minimum limit torque request transitions occur from TRUE to FALSE to TRUE within a time period	Requested torque intervention type toggles from not increasing request to increasing request			>= 3 multi- transitions out of 5 samples. Performed every 200 ms	
			OR Torque request greater than torque request diagnostic maximum threshold	> 250 Nm for engine based traction torque system, OR > 4,000 Nm for axle based traction torque system			>= 6 out of 10 samples  Performed on every received message	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (naturally aspirated)	P1101	Determines if there are multiple air induction problems affecting airflow and/or manifold pressure.	Filtered Throttle Model Error  AND  ( ABS(Measured Flow – Modeled Air Flow) Filtered OR ABS(Measured MAP – MAP Model 1) Filtered AND  ABS(Measured MAP – MAP Model 2) Filtered	<= 500 kPa*(g/s)  > 15.0 grams/sec  > 25.0 kPa)  > 25.0 kPa	Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 7,000 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 125 Deg C > -20 Deg C < 125 Deg C >= 0.50  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor Based on MAF Est  MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  See Residual Weight Factor tables.	Calculation are performed every 12.5 msec	Type B, 2 Trips
					No Active DTCs:	MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Pending DTCs:	IAT_SensorFA  EGRValve_FP  ECT_Sensor_Ckt_FP  IAT_SensorCircuitFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature Sensor Not Plausible) (TSRD	P111E	This DTC detects a difference between ECT and two other temp sensors after a soak condition.	Sensor usage definitions:  Sensor1 = CeECTD_e_ECT_Snsr (Sensor1 is the temp sensor most impacted by the block heater (if equipped))  Sensor2 = CeECTD_e_RCT_Snsr  Sensor3 = CeECTD_e_IAT_Snsr  ===================================	≥ 50.0 °C	Engine Off Soak Time Propulsion Off Soak Time Non-volatile memory initization  Test complete this trip Test aborted this trip Test disabled this trip Ambient LowFuelCondition Diag ====================================	VehicleSpeedSensor_FA IAT_SensorCircuitFA THMR_RCT_Sensor_Ckt _FA ECT_Sensor_Ckt_FA EngModeNotRunTmErr EngineModeNotRunTimer _FA OAT_PtEstFiltFA OAT_PtEstRawFA PSAR_PropSysInactveCr s_FA DRER_DiagSystemDsbl > 28,800 seconds > 0 seconds = Not occurred  = False = ===================================	1 failure to set DTC  1 sec/ sample  Once per valid cold start	Type B, 2 Trips
			2) Sensor1 power up temp is greater than Sensor2 and Sensor3 in this range: (and a block heater has not been detected) 3) Sensor1 power up temp is lower than	≥ 19.0 and < 50.0 °C	Block Heater detection is enabled when either of the following occurs:  1) Sensor1 power up temp is greater than Sensor2 and Sensor3 in this range:	≥19.0 °C and < 50.0 °C		
			Sensor2 and Sensor3 by this amount:  4) Sensor1 power up temp is ≥ Sensor2 and	≤ 19.0 Deg °C	2) Cranking time  ===================================	< 10.0 Seconds		

Component/ Fa System Co	ault ode	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System CC	oue -		Sensor3 by 19.0 °C and the time spent cranking the engine without starting is ≥ 10.0 seconds with the LowFuelConditionDiag	= False	when 1) or 2) occurs.  1a) IAT monitoring is enabled after the following Vehicle drive constraints 1b) Drive time  1c) Vehicle speed  1d) Additional Vehicle drive time is provided to 1b when Vehicle speed is below 1c as follows:  1e) IAT drops from power up IAT  2a) ECT monitoring is enabled after engine start in the following engine run time window  2b) Sensor1 temp derivative during the test is:  2c) Consectutive samples of 2b) being true are:  ===================================	> 400 Seconds with > 14.9 MPH and  0.50 times the seconds with vehicle speed below 1b ≥ 8.0 °C  5.0 <= seconds <= 15.0 < -0.10 °C/sec ≥ 4 samples ====================================		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temperature Sensor Not Plausible) (TSRD	P112F	This DTC detects a difference between RCT and two other temp sensors after a soak condition.	Sensor usage definitions:  Sensor1 = CeECTD_e_ECT_Snsr (Sensor1 is the temp sensor most impacted by the block heater (if equipped))  Sensor2 = CeECTD_e_RCT_Snsr  Sensor3 = CeECTD_e_IAT_Snsr	≥ 19.0 °C ≥ 19.0 °C	Engine Off Soak Time Propulsion Off Soak Time Non-volatile memory initization  Test complete this trip Test aborted this trip Test disabled this trip Ambient LowFuelCondition Diag	VehicleSpeedSensor_FA IAT_SensorCircuitFA THMR_RCT_Sensor_Ckt _FA ECT_Sensor_Ckt_FA EngineModeNotRunTimer Error EngineModeNotRunTimer _FA OAT_PtEstFiltFA OAT_PtEstRawFA PSAR_PropSysInactveCr s_FA DRER_DiagSystemDsbl > 28,800 seconds > 0 seconds = Not occurred  = False = False = False = False ≥ -7 °C = False	1 failure to set DTC 1 sec/ sample Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Emissions Reduction System Fault	P1400	Model based test computes power from exhaust flow and thermal energy resulting from elevated idle speed and retarded spark advance.  Detects if the cold start emission reduction system has failed resulting in the delivered power being out of range.	Average desired accumulated exhaust power - Average actual accumulated exhaust power (too much energy delivered to catalyst)  Average desired accumulated exhaust power - Average actual accumulated exhaust power (too little energy delivered to catalyst)  (EWMA filtered)  Average Power = output of P1400_EngineSpeedRes idual_Table * output of P1400_SparkResidual_T able NOTE: Desired accumulated power would use the desired catalyst light off spark and desired engine speed and the actual accumuated power would use the final commanded spark and actual engine speed. Refer to the Supporting Tables for details	< -32.00 KJ/s (high RPM failure mode)  > 6.50 KJ/s (low RPM failure mode)	To enable the diagnostic, the Cold Start Emission Reduction Strategy must be Active per the following:  Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure  The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following:  Catalyst Temperature AND Engine Run Time  OR  Engine Run Time  OR	< 300.00 degC  > -10.00 degC  <= 40.00 degC  >= 75.00 KPa  >= 1,000.00 degC  >= 20.00 seconds  > CatalystLightOffExtende dEngineRunTimeExit  This Extended Engine run time exit is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details.  < 75.00 KPa	Runs once per trip when the cold start emission reduction strategy is active  Frequency: 100ms Loop  Test completes after 10 seconds of accumulated qualified data.	EWMA Based - Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Other Enable Criteria:  OBD Manufacturer Enable Counter	0		
					Vehicle Speed	<1.24 MPH		
					Allow diagnostic to calculate residual in an off-idle state. If the value of the OffIdleEnable is equal to 1 then the "DriverOffAccelPedal" will not be checked. However, if the value of OffIdleEnable is 0 then driver must be off the accel pedal	0 (A value of 1 allows diagnostic to run and calculate the residual while off idle. A value of 0 requires calculation of the residual at idle)		
					A change in throttle position (tip-in/tip-out) will initiate a delay in the calculation of the average qualified residual value. Therefore when the:  Pedal Close Delay Timer	> 5.00 seconds		
					the diagnostic will continue the calculation.	2.00 Seconds		
					A change in gear will initiate a delay in the calculation of the average qualified residual value to allow time for the actual			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					engine speed and actual final commanded spark to achieve their desired values. Therefore, when the:			
					Gear Shift Delay Timer the diagnostic will continue the calculation	> 2.00 seconds		
					For Manual Transmission vehicles: Clutch Pedal Position Clutch Pedal Position	> 80.00 % < 12.00 %		
					The diagnostic will delay calculation of the residual value and potentially weight the residual calculation differently based on engine run time. This is to ensure the diagnostic is operating in idle speed control as well as during the peak catalyst light off period.  The time weighting factor must be:	> 0 These are scalar values that are a function of engine run time. Refer to ColdStartDiagnosticDel ayBasedOnEngineRunTime		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						and the cal axis, ColdStartDiagnosticDel ayBasedOnEngineRunTi meCalAxis in the "Supporting Tables" for details.		
					General Enable:			
					DTC's Not Set:	AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFP CrankSensorFaultActive FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA EngineMisfireDetected_F A ClutchPstnSnsr FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA 5VoltReferenceMAP_OO R_FIt TransmissionEngagedStat e_FA EngineTorqueEstInaccura te		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Engine Speed Request	P150C	Determines if engine speed request from the TCM is valid	Serial Communication rolling count value	+ 1 from previous \$19D message (PTEI3)	Diagnostic enable bit	1	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips
Circuit			Transmission engine speed protection	not equal to 2's complement of transmission engine speed request + Transmission alive rolling count	Engine run time	0.50 sec		
					# of Protect Errors	16 protect errors within the sample period 20		
					# of Alive Rolling Errors	5 rolling count errors out of 10 samples		
					No idle diagnostic 506/507 code	IAC_SystemRPM_FA		
					No Serial communication loss to TCM	(U0101)		
					Engine Running	= TRUE		
					Power mode	Run Crank Active		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Steady State Actuation Fault	P1516	Detect an inablity to maintain a steady state throttle position	The absolute difference between desired and indicated throttle position is >	2.00 percent		Run/Crank voltage > 6.41  Ignition voltage failure is false (P1682)  TPS minimum learn is not active and Throttle is being Controlled Throttle is considered in a steadystate condition when the desired throttle position over a 12.5 ms period is < 0.25 percent for a settling time period > 4.00 s	0.49 ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Switch State Undertermin ed	P155A	Detects when cruise switch state cannot be determined, such as low voltage conditions	cruise switch state remains undetermined for greater than a calibratable time				fail continuously for greater than 0.5 seconds	MIL: Type C, No MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation	P1682	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage & the Powertrain Relay Ignition Voltage	Run/Crank – PT Relay  gnition  >	3.00 Volts		Powertrain commanded on  AND  (Run/Crank voltage > Table, f(IAT). See supporting tables: PT Relay Pull-in Run/Crank Voltage f(IAT)  OR PT Relay Ignition voltage > 5.50 )  AND  Run/Crank voltage > 5.50 .	240 / 480 counts or 0.1750 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Redundant Memory Performance	P16F3	Detect Processor Calculation faults due to RAM corruptions, ALU failures and ROM failures  For all of the following cases: If the individual	Desired Throttle Area calculated does not equal its redundant calculation	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	Type A, 1 Trips
		diagnostic threshold is equal to 2048 ms, this individual case is not applicable. If any of the following cases are X out of Y diagnostics and the fail (x) is greater than the sample (Y), this individual case is also not applicable.	Equivance Ratio torque compensation exceeds threshold	-55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Absolute difference between Equivance Ratio torque compensation and its dual store out of bounds given by threshold	55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference of Accessory torque and its redundant calculation is out of bounds given by threshold range	55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Filtered Air-per-cylinder and its redundant calculation is out of bounds given by threshold range	105.99 mg	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference between the previous Final Advance and the current Final Advance not Adjusted for Equivalence Ratio is out of bounds given by threshold range	15.00 degrees		Engine speed >0rpm	Up/down timer 125 ms continuous, 0.5 down time multipier	-
			given by threshold range					
			Torque Learn offset is out of bounds given by threshold range	High Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold 0.00 Nm			multipier	
			One step ahead calculation of air-per-cylinder and two step ahead is greater than threshold	80.00 mg		Engine speed > 500 rpm	Up/down timer 428 ms continuous, 0.5 down time multipier	
			Difference between Unmanaged Spark and PACS Spark is greater than threshold	15.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded Predicted Engine Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multipier	
			Zero pedal axle torque is out of bounds given by threshold range	High Threshold 905.18 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Creep Coast Axle Torque is out of bounds given by threshold range	High Threshold 905.18 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Absolute difference of Friction torque and its redundant calculation is out of bounds given by threshold range	55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multipier	
			Arbitrated Air-Per-Cylinder filter coefficient is out of bounds given by threshold range		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Launch spark is active but the launch spark redundant path indicates it should not be active	N/A		Engine speed < 7,800.00 or 7,900.00 rpm (hysteresis pair)	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Rate limited vehicle speed and its dual store do not equal	N/A		Time since first CAN message with vehicle speed >= 0.500 sec	10 / 20 counts; 25.0msec/count	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Preload Throttle Area and its dual store do not equal	N/A	Ignition State	Accessory, run or crank AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Commanded engine torque due to fast actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded engine torque due to slow actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			TOS to wheel speed conversion factor is out of bounds given by threshold	High Threshold:	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			range	T/C Range Hi  0.10 T/C Range Lo  Low Threshold:  1.10 T/C Range Hi  0.10 T/C Range Lo				
			Cylinders active greater than commanded	2 cylinders		Engine run flag = TRUE > 2.00 s Number of cylinder events since engine run > 24 No fuel injector faults active	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Transfer case neutral request from four wheel drive logic does not match	N/A	Ignition State	Accessory, run or crank	32/6 counts; 25.0msec/count	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			with operating conditions			Transfer case range valid and not over-ridden		
						FWD Apps only		
			Driver progression mode and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Predicted torque for uncorrected zero pedal determination is greater than calculated limit.	Table, f(Engine, Oil Temp). See supporting tables + 55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	-
			Engine Predicted Request Without Motor is greater than its redundant calculation plus threshold	54.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Immediate Request Without Motor is greater than its redundant calculation plus threshold	54.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Positive Torque Offset is greater than its redundant calculation plus threshold  OR  Positive Torque Offset is less than its redundant calculation minus threshold	55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Predicted Engine Request is greater than its redundant calculation plus threshold	55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, down time multipier 0.5	
			Commanded Hybrid Predicted Crankshaft Request is greater than its redundant calculation plus threshold		Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Commanded Hybrid	4.096.00	Ignition State	Accessory, run or crank	Up/down timer	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Immediate Crankshaft Request is less than its redundant calculation minus threshold	Nm			2,048 ms continuous, 0.5 down time multipier	
			Regeneration Brake Assist is not within a specified range	Brake Regen Assist < 0 Nm or Brake Regen Assist > 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Cylinder Spark Delta Correction exceeds the absolute difference as compared to Unadjusted Cylinder Spark Delta	15.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Cylinder Torque Offset exceeds step size threshold  OR	1. 55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Sum of Cylinder Torque Offset exceeds sum threshold	2. 55.64 Nm				
			Engine Capacity Minimum Immediate Without Motor is greater than its dual store plus threshold	60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Capacity Minimum Engine Off is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Capacity Minimum Engine Immediate Without Motor is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Commanded Immediate Engine Request is greater than its redundant calculation plus threshold	55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Engine Speed Lores Intake Firing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Speed Lores Intake Firing timing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	-
			Idle speed control calculated predicted minimum torque request exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: <b>Speed Control</b> <b>External Load f(Oil</b> <b>Temp, RPM)</b> + 55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	-
			Idle speed control calculated predicted minimum torque without reserves exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: <b>Speed Control</b> <b>External Load f(Oil</b> <b>Temp, RPM)</b> + 55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference between Driver Requested Immediate Torque primary path and its secondary exceeds threshold	905.18 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	_
			Driver Immediate Request is less than its redundant calculation minus threshold	905.18 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	_
			Commanded Immediate Request is greater than its redundant calculation plus threshold  OR  Commanded Immediate	905.18 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Request is less than its redundant calculation minus threshold					
			Commanded Immediate Response Type is set to Inactive	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Difference between Cruise Axle Torque Arbitrated Request and Cruise Axle Torque Request exceeds threshold	113.15 Nm		Cruise has been engaged for more than 4.00 seconds	Up/down timer 2,048 ms continuous, 0.5 down time multipier	
			Desired engine torque request greater than	54.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 475	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			redundant calculation plus threshold				ms continuous, 0.5 down time multipier	
			Engine min capacity above threshold	55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 138 ms continuous, 0.5 down time multipier	
			No fast unmanaged retarded spark above the applied spark plus the threshold	Table, f(RPM,APC). See supporting tables: Delta Spark Threshold f (RPM,APC)		Engine speed greater than 0rpm	Up/down timer 125 ms continuous, 0.5 down time multipier	
			Absolute difference of adjustment factor based on temperature and its dual store above threshold	2.76 m/s	Ignition State	Accessory, run or crank	Up/down timer 228 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of redundant calculated engine speed above threshold	1,368 RPM		Engine speed greater than 0 RPM	Up/down timer 128 ms continuous, 0.5 down time multipier	
			After throttle blade pressure and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	_
			Speed Control's Preditcted Torque Request and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	_
			Engine oil temperature and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 438 ms continuous,	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							0.5 down time multipier	
			Desired throttle position greater than redundant calculation plus threshold	9.55 percent	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	_
			Absolute difference of the rate limited pre-throttle pressure and its redundant calculation greater than threshold	0.06 kpa	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Throttle desired torque above desired torque plus threshold	55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired filtered throttle torque exceeds the threshold plus the higher of desired throttle torque or modeled throttle torque	55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	-
			Torque feedback proportional term is out of allowable range or its dual store copy does not match	High Threshold 27.82 Nm  Low Threshold	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Torque feedback integral	-27.82 Nm	Ignition State	Accessory, run or crank	Up/down timer	-
			term magnitude or rate of change is out of allowable range or its dual store copy do not match	l -	ignition State	Accessory, run or crank	down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				-55.64 Nm				
				Rate of change threshold 3.48 Nm/loop				
				- Till 18 (18 )				
			Difference of Final Torque	High Threshold	Ignition State	Accessory, run or crank	Up/down timer	-
			feedback proportional plus integral term and its redundant calculation is out of bounds given by threshold range	55.64 Nm			475 ms continuous, 0.5 down time multipier	
				Low Threshold				
				- 55.64 Nm				
			Difference of torque desired throttle area and its redundant calculation	High Threshold 0.50 %	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous,	
			is out of bounds given by threshold range				0.5 down time	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold - 0.50 %			multipier	
			Difference of torque model coefficients and its redundant calculation is out of bounds given by threshold range	High Threshold 0.0001957 Low Threshold - 0.0001957	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Difference of base friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 55.64 Nm  Low Threshold - 55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Accessory drive friction torque is out of bounds given by threshold range	High Threshold 55.64 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			AC friction torque is greater than commanded by AC control software or less than threshold limit	High Threshold  40.00 Nm  Low Threshold  0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Difference of Oil temperature delta friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 55.64 Nm Low Threshold	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				- 55.64 Nm				
			Generator friction torque is out of bounds given by threshold range	High Threshold 55.64 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Supercharger friction torque is out of bounds given by threshold range	High Threshold 55.64 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System	Code		Filtered Torque error magnitude or its increase rate of change is out of allowable range or its dual store copy do not match	High Threshold 55.64 Nm  Low Threshold -55.64 Nm		Engine speed >0rpm MAF, MAP and Baro DTCs are false	Up/down timer 475 ms continuous, 0.5 down time multipier	illum.
				Rate of change threshold 3.48 Nm/loop				
			Torque error compensation is out of bounds given by threshold range	High Threshold 55.64 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Delta Torque Baro compensation is out of bounds given by threshold range	High Threshold 5.30 Nm  Low Threshold -2.19 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Difference of reserve torque value and its redundant calculation exceed threshold  OR      Reserve request does not agree with operating conditions or Difference of final predicted torque and its redundant calculation exeed threshold	1. 54.64 Nm 2. N/A 3. 54.64 Nm 4. 54.64 Nm		1. & 2.: Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 55.64 Nm	Up/down timer 475 ms continuous, 0.5 down time multipier	
			OR  3. Rate of change of reserve torque exceeds threshold, increasing direction only		3. & 4.: Ignition State	3. & 4.: Accessory, run or crank		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR  4. Reserve engine torque above allowable capacity threshold					
			Engine Vacuum and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference of the calculated Intake Manifold Pressure during engine event versus during time event is greater than threshold	Table, f(Desired Engine Torque). See supporting tables: Delta MAP Threshold f(Desired Engine Torque)		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Min. Axle Torque Capacity is greater than threshold	0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	-
			Driver Predicted Request	905.18	Ignition State	Accessory, run or crank	Up/down timer	1

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			is greater than its redundant calculation plus threshold  OR  Driver Predicted Request is less than its redundant calculation minus threshold	Nm			475 ms continuous, 0.5 down time multipier	
				N/A				
			Cold Delta Friction Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Predicted torque for zero pedal determination is greater than calculated limit.	Table, f(Oil Temp, RPM). See supporting tables: <b>Speed Control</b> <b>External Load f(Oil</b> <b>Temp, RPM)</b> + 55.64 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Predicted Axle Torque and its dual store do not match	1 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	-
			Steady State Estimated Engine Torque and its dual store are not equal	N/A		AFM not changing from Active to Inactive and preload torque not changing and one loop after React command Engine speed >0rpm	Up/down timer 1,988 ms continuous, 0.5 down time multipier	_
			Difference of Weighting factor for number of cylinders fueled and its redundant calculation is above threshold	0.26		Engine run flag = TRUE > 10.00 s	Up/down timer 175 ms continuous, 0.5 down time multipier	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference of minimum spark advance limit and its redundant calculation is out of bounds given by threshold range	15.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 128 ms continuous, 0.5 down time multipier	
			Difference of commanded spark advance and adjusted delivered is out of bounds given by threshold range	15.00 degrees		Engine speed >0rpm	Up/down timer 125 ms continuous, 0.5 down time multipier	
			Absolute difference between Estimated Engine Torque and its dual store are above a threshold	55.64 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Absolute difference between Estimated Engine Torque without reductions due to torque	55.64 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control and its dual store are above a threshold				down time multipier	
			Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by threshold range	15.00 degrees		Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 55.64 Nm	Up/down timer 428 ms continuous, 0.5 down time multipier	
			Absolute difference of Engine Capacity Minimum Running Immediate Brake Torque Excluding Cylinder Sensitivity and its redundant calculation is out of bounds given by threshold range			Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multipier	-
			One step ahead calculation of air-per-cylinder greater than two	Threshold: Dynamically calculated based on current		Engine speed > 500	Up/down timer 428 ms continuous.	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			step ahead calculation by threshold for time	engine conditions Fault Pending Threshold: 100 ms			0.5 down time multipier	
			Rate limited cruise axle torque request and its dual store do not match within a threshold	113.15 Nm	Ignition State	Accessory, run or crank	Up/down timer 163 ms continuous, 0.5 down time multipier	-
			1. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its redundant calculation is out of bounds given by threshold range	1. 5.00 % 2. N/A 3.	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	-
			OR  2. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			and its dual store do not equal					
			OR					
			3. Absolute difference of Calculated accelerator pedal position and its dual store do not equal					
			Commanded axle torque is greater than its redundant calculation by threshold	905.18 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Commanded axle torque is less than its redundant calculation by threshold	1,357.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	-
			Preload timer and its redundant calculation do	N/A	Ignition State	Accessory, run or crank	Up/down timer 2.048	-

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			not equal			AFM apps only	ms continuous, 0.5 down time multipier	
			AC friction torque is greater than commanded by AC control software	40.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multipier	-
			Engine Speed Lores Intake Firing (time based) calculation does not equal its redundant calculation	N/A		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multipier	
			Absolute difference of the calculated spark offset for equivalence ratio and its redundant cacluation is greater than a threshold	15.00 degrees		Engine speed >0rpm	Up/down timer 128 ms continuous, 0.5 down time multipier	_
			Transmission Torque	N/A		Run or Crank = TRUE >	16/32	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Request cacluations do not equal their dual stores			0.50 s	counts; 25.0msec/count	
			Absolute difference of the predicted motor torque ACS and its redundant cacluation is greater than a threshold	0.01 Nm			Up/down timer 2,048 ms continuous, 0.5 down time multipier	-
			Absolute difference of maximum throttle area and its redundant cacluation is greater than a threshold	15 mm2			Up/down timer 228 ms continuous, 0.5 down time multipier	
			Absolute difference of Desired TIAP and its redundant cacluation is greater than a threshold	5.00 kPa			Up/down timer 475 ms continuous, 0.5 down time multipier	
			Pedal learns and their redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Throttle learns and their redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	
			Desired Throttle Position and its redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multipier	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Stuck Open	P2070	Detects an Intake Manifold Tuning Valve that is stuck in the open position	Time after the close command without the Intake Manifold Tuning Valve reaching the closed position	>= 5.00 seconds	Intake Manifold Tuning Valve is commanded closed No Active DTCs:	P0660 P0661 P0662 P2077 P2078	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Stuck Closed	P2071	Detects an Intake Manifold Tuning Valve that is stuck in the closed position	Time after the open command without the Intake Manifold Tuning Valve reaching the open position	>= 5.00 seconds	Intake Manifold Tuning Valve is commanded closed No Active DTCs:	P0660 P0661 P0662 P2077 P2078	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Position Sensor/ Switch Circuit Range/ Performance	P2076	Detects an Intake Manifold Tuning Valve Actuator that has initiated its learn sequence for too long a period of time, or too many times per ignition cycle	Valve Position AND Valve Position for a time period  OR  Valve Position AND Valve Position for a time period  for	>= 5.0 % <= 35.0 % >= 5.0 seconds  >= 5.0 % <= 35.0 % >= 0.2 seconds >= 10 times in one ignition cycle	Powertrain Relay Voltage Powertrain Relay Voltage Engine Run Time	>= 11.00 Volts <= 999.00 Volts >= 1.0 seconds	Executes every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Position Sensor/ Switch Circuit Low	P2077	Detects a continuous open or short to low in the Intake Manifold Tuning Valve Position Sensor circuit	Valve Position	>= 95.0%	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Manifold Tuning (IMT) Valve Position Sensor/ Switch Circuit High	P2078	Detects a continuous short to high in the Intake Manifold Tuning Valve Position Sensor circuit	Valve Position	<= 5.0 %	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Low– Bank 1	P2088	Diagnoses the VVT system high side driver circuit for circuit faults.	commanded state of the driver and the actual state	≤ 0.5 Ω to a voltage source within the Vehicle Ground Voltage Range relative	System supply voltage  Output driver is commanded on  Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit High – Bank 1	P2089	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply  Output driver is commanded on  Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Low – Bank 1	P2090	Diagnoses the VVT system high side driver circuit for circuit faults.	commanded state of the driver and the actual state	Short to ground: ≤ 0.5 Ω to a voltage source within the Vehicle Ground Voltage Range relative to PWRGND	System supply voltage  Output driver is commanded on  Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit High – Bank 1	P2091	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power  Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply voltage  Output driver is commanded on  Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Low Limit Bank 1 (Too Rich)	P2096	Determines if the post catalyst O2 sensor based fuel control system has utilized all or most of it's low limit authority, indicating a rich emissions/exhaust gas condition.  Note: If the post catalyst O2 voltage is too rich, the post catalyst O2 integral offset control is decreased. This results in lean bias fuel control in an attempt to correct the rich condition. A perfectly balanced control system (no rich or lean bias required) is represented by an integral offset value of "0" and a post catalyst O2 sensor that is within it's optimal operating range (neither rich nor lean). An integral offset value < 0 is indicative of the control system reacting to a rich post catalyst O2 sensor. If the failure is such that the control system utilizes all or most of its available authority, then P2096 will set.	Rich Fail counter  High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18 % for >= 5.0 seconds.  Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14 % for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.	>= 800 counts per 1,000 sample counts  Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration Ambient Air Pressure Engine AirFlow Intake Manifold Pressure Induction Air Temperature Start-up Coolant Temp. PTO Intrusive diag. fuel control Long Term Secondary Fuel Trim Enabled (see "Long Term Secondary Fuel Trim Enable Criteria" in Supporting Tables) High Vapor Conditions No Fault Active for:	No No Yes No No >= 70 kPa >= 8.0 g/s <= 10,000.0 >= 10 kPa <= 255 >= -20 deg. C <= 150 >= -20 deg. C Not Active Not Active Not Active  Not Present  AmbientAirDefault AIR System FA Ethanol Composition Sensor FA ECT_Sensor_FA EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorFA CamSensorAnyLocationF A EvapEmissionSystem_FA EvapFlowDuringNonPurg e_FA FuelTankPressureSnsrCkt _FA	Frequency: Continuous Monitoring in 100ms loop.  Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System	Code				The above general enable conditions must be true for:  Minimum accumulated counts in each cell required before counters will increment for that cell: Deceleration Idle Cruise Light Acceleration Heavy Acceleration (Note: A value in any of the above operating "cells" that is an order of magnitude (or more) higher than other cells is an indication that the diagnostic is not capable of diagnosing in that cell).	EvapPurgeSolenoidCircuit _FA EvapSmallLeak_FA EvapVentSolenoidCircuit_FA FuelInjectorCircuit_FA MAF_SensorFA MAF_SensorFTKO MAP_SensorFA MAP_EngineVacuumStat us EngineMisfireDetected_F A A/F Imbalance Bank1 O2S_Bank_1_Sensor_1_ FA O2S_Bank_1_Sensor_2_ FA  > 0.0 seconds  300 300 300 300 300 300 300 300 300 3		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					enabled (i.e. those containing a "Yes" at the beginning of the Enable Conditions column), the fail counter will increment if the sample counter increments AND Post oxygen sensor control integral offset (in mV) is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Heavy Acceleration Heavy Acceleration Heavy Acceleration that the diagnostic is not capable of diagnosing in that cell).	<= -190 (control min.=-200) -190 (control min.=-200) -656 (control min.=-720) -710 (control min.=-720) -710 (control min.=-720) > 742 mV 742 mV 742 mV 742 mV 742 mV		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System High Limit Bank 1 (Too Lean)	P2097	Determines if the post catalyst O2 sensor based fuel control system has utilized all or most of it's high limit authority, indicating a lean emissions/exhaust gas condition.  Note: If the post catalyst O2 voltage is too lean, the post catalyst O2 integral offset control is increased. This results in rich bias fuel control in an attempt to correct the lean condition. A perfectly balanced control system (no rich or lean bias required) is represented by an integral offset value of "0" and a post catalyst O2 sensor that is within it's optimal operating range (neither rich nor lean). An integral offset value > 0 is indicative of the control system reacting to a lean post catalyst O2 sensor. If the failure is such that the control system utilizes all or most of its available authority, then P2097 will set.	High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18 % for >= 5.0 seconds.  Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14 % for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.	>= 800 counts per 1,000 sample counts  Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	Same as P2096 except for the following:  For the cells identified as enabled (i.e. those containing a "Yes" at the beginning of the Enable Conditions for P2096), the fail counter will increment if the sample counter increments AND Post oxygen sensor control integral offset (in mV) is Deceleration Idle Cruise Light Acceleration Heavy Acceleration Heavy Acceleration Idle Cruise Light Acceleration Heavy Acceleration Idle Cruise Light Acceleration Idle Cruise Light Acceleration Idle Cruise Light Acceleration Heavy Acceleration Indication The above operating "cells" that is less than ToomV is an indication That the diagnostic is not capable of diagnosing in that cell).	>= 190 (control max.= 200) 190 (control max.= 200) 656 (control max.= 720) 710 (control max.= 720) < 622 mV 622 mV 622 mV 622 mV 622 mV 622 mV	Frequency: Continuous Monitoring in 100ms loop.  Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Throttle Actuator Position Performance	P2101	1) Detect a throttle positioning error2) Throttle control is driving the throttle in the incorrect direction3) Throttle control exceeds the reduced power limit	Difference between measured throttle position and modeled throttle position >  OR  Difference between modeled throttle position and measured throttle position >	9.55 percent 9.55 percent	TPS minimum learn is not active and Throttle is being Controlled and (Engine Running or Ignition Voltage > or Ignition Voltage > )	Run/Crank voltage > 6.41  Ignition voltage failure is false (P1682)  TPS minimum learn is not active and Throttle is being Controlled  AND  ((Engine Running AND Ignition Voltage > 5.50 ) OR Ignition Voltage > 8.41 )	not	Type A, 1 Trips
			Throttle Position >	38.37 percent		Powertrain Relay voltage > 6.41  TPS minimum learn is active	11 counts; 12.5 ms/count in the primary processor	
			Throttle Position >	40.00 percent		Powertrain Relay voltage > 6.41 Reduced Power is True	11 counts; 12.5 ms/count in the primary processor	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Lo	P2122	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage <	0.4625		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Hi	P2123	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage >	4.7500		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Lo	P2127	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage <	0.3250		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P0697)	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Hi	P2128	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage >	2.6000		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P0697)	19/39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position (TP) Sensor 1-2 Correlation	P2135	Detects a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor	Difference between TPS1 displaced and TPS2 displaced >	7.022 % offset at min. throttle position with a linear threshold to 9.664 % at max. throttle position		Run/Crank voltage > 6.41  No TPS sensor faults (P0122, P0123, P0222, P0223)  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts or 58 counts continuous; 3.125 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min TPS1) and (normalized min TPS2) >	5.000 % Vref		Run/Crank voltage > 6.41  No TPS sensor faults (P0122, P0123, P0222, P0223)  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79/159 counts or 58 counts continuous; 3.125 ms/count in the main processor	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1-2 Correlation	P2138	Detects a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor	Difference between APP1 displaced and APP2 displaced >	5.000 % offset at min. pedal position with a linear threshold to 10.001 % at max. pedal position		Run/Crank voltage > 6.41  No APP sensor faults (P2122, P2123,P2127, P2128)  No 5V reference errors or faulst for # 3 & # 4 5V reference circuits (P06A3, P0697)	19/39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min APP1 ) and (normalized min APP2) >	5.000 % Vref		Run/Crank voltage > 6.41  No APP sensor faults (P2122, P2123,P2127, P2128)  No 5V reference errors or faulst for # 3 & # 4 5V reference circuits (P06A3, P0697)	19/39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Minimum Throttle Position Not Learned	P2176	TP sensors were not in the minmum learn window after multiple attempts to learn the minimum.	During TPS min learn on the Main processor, TPS Voltage >  AND  Number of learn attempts >	0.9550 10 counts		Run/Crank voltage > 6.41  TPS minimum learn is active  No previous TPS min learn values stored in long term memory	2.0 secs	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling System Performance	P2181	This DTC detects thermostat malfunction (i.e. stuck open)	This diagnostic can be calibrated to fail in one of two methods based on the following calibration. This application has been calibrated as a Type 0.  Type 0 - Airflow Method:		No Active DTC's  Engine not run time	MAF_SensorFA IAT_SensorFA THMR_RCT_Sensor_Ckt _FA THMR_ECT_Sensor_Ckt _FA THMR_AHV_FA ≥ 7,200 seconds	225 failures out of 280 samples 1 sec/ sample Once per ignition key cycle	Type B, 2 Trips
			Engine Coolant Temp (ECT) is ≤ commanded temperature minus 11 Deg C and normalized		Engine run time	120 ≤ Time ≤ 1,400 seconds		
			ratio is ≤ than 0.65.  When above is present for more than 0 seconds, fail counts start.  == Ratio Definition:=== Current temp difference		Fuel Condition ECT at Power Up IAT min T-Stat Heater duty cycle commanded	Ethanol ≤ 100 % -10.0 ≤ ECT ≤ 45.0 °C -7 °C ≤ IAT ≤ 60 °C.		
			between ECT and RCT minus PwrUp difference divided by total airgrams. Note: Minimum total airgrams is 500.0 grams.		Type 0: Airflow range to accumulate  Type 1: Minumum energy	11.0 ≤ Airflow ≤ 100.0 gps 240.0 kJ		
			Type 1 - Energy Method: Engine Coolant Temp (ECT) is ≤ commanded temperature minus 11 Deg C and normalized ratio is ≤ than 0.01. When above is present for more than 0 seconds, fail		to enable			
			counts start. == Ratio Definition:=== Current temp difference between ECT and RCT minus PwrUp difference divided by predicted energy.					

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 1 / 2 Correlation	P2199	Detects a difference between the IAT and IAT2 sensors	ABS (IAT - IAT2)	> 55.0 deg C	Powertrain Relay Voltage for a time No Active DTCs:	>= 11.00 Volts >= 0.9 seconds PowertrainRelayFault	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Bank 1 Air- Fuel Ratio Imbalance	P219A	This monitor determines if a cylinder-to-cylinder airfuel ratio imbalance is present on bank 1.	Filtered Ratio >  Note: The input to this metric is the pre catalyst oxygen sensor voltage. This voltage is used to generate a Variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to the air-fuel ratio imbalance (variance is higher with an imbalance than without). Multiple	0.25  If the diagnostic has reported a failure on the prior trip, the Filtered Ratio must fall below 0.25 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing when the Filtered Ratio remains near the initial failure threshold of 0.25.	System Voltage  Fuel Level  Engine Coolant Temperature  Cumulative engine run time  Diagnostic enabled at Idle (regardless of other operating conditions)	no lower than 11.0 Volts for more than 0.2 seconds  > 10.0 percent AND no fuel level sensor fault  > -20 degrees C  > 30.0 seconds	Minimum of 1 test per trip, up to 6 tests per trip during RSR or FIR.  The front O2 sensor voltage is sampled once per cylinder event. Therefore, the time required to complete a single test (when all enable	Type A, 1 Trips
			samples are collected in making a decision.  The observed Variance is dependant on engine speed and load and so	0.20	Engine speed range Engine speed delta during a short term sample period	1,200 to 3,200 RPM	conditions are met) decreases as engine speed increases. For example,	
			each result is normalized for speed and load by comparing it to a known "good system" result for		Mass Airflow (MAF) range Cumulative delta MAF during a short term	10 to 100 g/s	data is required at 1000 rpm while double this time is required	
			that speed and load, and generating a Ratio metric.  The Ratio metric is calculated by selecting the appropriate threshold calibration from a 17x17		sample period  Filtered MAF delta between samples Note: first order lag filter coefficient applied to MAF = 0.050	<0.20 g/s	at 500 rpm and half this time is required at 2000 rpm. This data is collected only when enable conditions are	
		table (Supporting Table "Variance Threshold	table (Supporting Table "Variance Threshold Bank1") and subtracting it from the measured Variance. The result is then divided by a normalizer calibration		Air Per Cylinder (APC)  APC delta during short term sample period  Filtered APC delta between samples	220 to 500 mg/cylinder <75 mg/cylinder <9.99 percent	met, and as such significantly more operating time is required than is indicated above. Generally, a report will be	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			(Supporting Table		Note: first order lag filter		made within 5	
l	1		"Normalizer Bank1").		coefficient applied to APC		minutes of	
	1		This quotient is then		= 0.100		operation.	1
l	1		multiplied by a quality					
			factor calibration from a 17 x 17 table (Supporting		Spark Advance	0 to 60 degrees	For RSR or FIR, 6 tests must	
	1		Table "Quality Factor		Throttle Area (percent of	2 to 100 percent	complete before	
			Bank1"). This result is referred to as the Ratio.		max)	·	the diagnostic can report.	
			Note that the quality factor ranges between 0 and 1		Intake Cam Phaser Angle	0 to 28 degrees		
	1		and represents		Exhaust Cam Phaser	0 to 28 degrees		
			robustness to false diagnosis in the current		Angle	o to zo dogrood		
			operating region. Regions with low quality factors		Quality Factor (QF) QF calibrations are	>= 0.99		
1	1	1	are not used.		located in a 17x17 lookup			
I					table versus engine speed			
l	1		Finally, a EWMA filter is		and load (Supporting			
l	1		applied to the Ratio metric		Table "Quality Factor			
l	1		to generate the Filtered		Bank1"). QF values less			
l	1		Ratio malfunction criteria		than "1" indicate that we			
l	1		metric. Generally, a		don't have 4sigma/2sigma			
	1		normal system will result		robustness in that region.			
	1		in a negative Filtered		The quality of the data is			
	1		Ratio while a failing		determined via statistical			
	1		system will result in a		analysis of Variance data.			
			positive Filtered Ratio.					
	1	1			Fuel Control Status			
	1	1	The range of the Filtered		Closed Loop and Long			
			Ratio metric is application		Term FT Enabled for:	>= 1.2 seconds		
	1	1	specific since both the			(Please see "Closed		
			emissions sensitivity and			Loop Enable Criteria"		
	1	1	relationship between			and "Long Term FT		
	1	1	imbalance and the			Enable Criteria" in		
			Variance metric are		AIR pump not on	Supporting Tables)		
I			application specific.		CASE learn not active			
	1	1			EGR - no device control,			
			Some applications may		no intrusive diagnostics			
			need to command a		EVAP - no device control,			
	1	1	unique cam phaser value		no intrusive diagnostics			
			before performing the		Engine OverSpeed			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			above calculations since cam phasing has been shown to have an impact on overall signal quality. This application Does Not Use this feature.		Protection Not Active Idle speed control normal PTO Not Active Injector base pulse width above min limit O2 Learned htr resistance Rapid Step Response (RSR): RSR will trigger if the Ratio result from the last test is AND it exceeds the last Filtered ratio by Once triggered, the filtered ratio is reset to:  Fast Initial Response (FIR): FIR will trigger when an NVM reset or code clear occurs. Once triggered, the filtered ratio is reset to:  No Fault Active for:	= Valid (the O2 heater resistance has learned since NVM reset)  >= 0.25  >= 0.30  0.00  EngineMisfireDetected_F A MAP_SensorFA MAF_SensorFA ECT_Sensor_FA TPS_ThrottleAuthorityDef aulted FuelInjectorCircuit_FA AIR System FA EvapExcessPurgePsbl_F A CamSensorAnyLocationF A FuelTrimSystemB1 FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						O2S_Bank_1_Sensor_1_ FA O2S_Bank_1_Sensor_2_ FA WRAF_Bank_1_FA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Performance (naturally aspirated)	P2227	Compares baro sensor to the calculated baro estimate (part throttle calculation or unthrottled MAP)	Difference between baro sensor reading and estimated baro when distance since last estimated baro update  OR  Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 15.0 kPa <= 0.06 miles > 20.0 kPa > 0.06 miles	No Active DTCs:	ECT_Sensor_Ckt_FA of 400 IAT_SensorFA	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips
			Barometric Pressure OR Barometric Pressure	< 50.0 kPa > 115.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating No Active DTCs:	> 6.0 seconds  EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA  MAP_SensorCircuitFP AAP_SnsrCktFP	4 failures out of 5 samples 1 sample every 12.5 msec	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (non- boosted applications)	P2228	Detects a continuous short to low or open in either the signal circuit or the BARO sensor.	BARO Voltage	< 40.0 % of 5 Volt Range (2.0 Volts = 50.9 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (non- boosted applications)	P2229	Detects an open sensor ground or continuous short to high in either the signal circuit or the BARO sensor.	BARO Voltage	> 90.0 % of 5 Volt Range (4.5 Volts = 115.0 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Intermittent	P2230	Detects a noisy or erratic barometric pressure input	String Length  Where: "String Length" = sum of "Diff" calculated over  And where: "Diff" = ABS(current BARO reading - BARO reading from 12.5 milliseconds previous)	> 200 kPa 80 consecutive BARO samples			4 failures out of 5 samples Each sample takes 1.00 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Pump Control Circuit Low Voltage	P2257	Diagnoses the Secondary AIR Pump Control Low Side Driver circuit for circuit faults	Voltage low during driver off state (indicates short-to-ground)	Short to ground: <= 0.5 Ohms impedance between signal and controller ground	Powertrain relay Voltage	>= 11.00 volts	20 failures out of 25 samples 250ms / sample	Type B, 2 Trips Note: In certain controlle rs P0418 may also set (Second ary AIR Pump Control Circuit Open)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR Pump Control Circuit High Voltage	P2258	Diagnoses the Secondary AIR Pump Control Low Side Driver circuit for circuit faults	Voltage high during driver on state (indicates short- to-power)	Short to power: <= 0.5 Ohms impedance between signal and controller power	Powertrain relay Voltage	>= 11.00 volts	20 failures out of 25 samples 250ms / sample	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
O2 Sensor Signal Stuck Lean Bank 1 Sensor 2	P2270	This DTC determines if the post catalyst O2 sensor is stuck in a normal lean voltage range and thereby can no longer be used for post oxygen sensor fuel control or for catalyst monitoring. The diagnostic is an intrusive test (during coast) which increases the delivered fuel to achieve the required rich threshold.	Post O2 sensor signal AND The Accumulated mass air flow monitored during the Stuck Lean Voltage Test	< 775 mvolts > 60 grams	B1S2 DTC's Not active this key cycle System Voltage Learned heater resistance  ICAT MAT Burnoff delay Green O2S Condition	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013A, P013B, P013E, P013F, P2270 or P2271  10.0 < Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. = False	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips	
						Pedal position	≤ 3.0 %		

Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Engine Airflow	2≤ gps ≤ 20		
				Closed loop integral Closed Loop Active Evap Ethanol	0.75 ≤ C/L Int ≤ 1.07 = TRUE not in control of purge not in estimate mode		
				Post fuel cell (Decel) Crankshaft Torque	= enabled < 125.0 Nm		
				EGR Intrusive diagnostic All post sensor heater	= not active		
				O2S Heater (post sensor) on Time	= not active ≥ 60.0 sec		
				Predicted Catalyst temp Fuel State	550 ≤ °C ≤ 900 = DFCO possible		
				All of the above met for at least 0.0 seconds, and then check the following	=========		
				Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)	1,450 ≤ RPM ≤ 3,300		
				Vehicle Speed to initially enable test Vehicle Speed range to	43.5≤ MPH ≤80.2		
				initially enabled) ====================================	38.5≤ MPH ≤82.0		
				least 3.0 seconds, and then the Force Cat Rich intrusive stage is requested.			
	Fault	Fault Code Monitor Description	Fault Code Monitor Description Malfunction Criteria	Fault Code Monitor Description Malfunction Criteria Threshold Value	Engine Airflow  Closed loop integral Closed Loop Active Evap Ethanol  Post fuel cell (Decel) Crankshaft Torque  EGR Intrusive diagnostic All post sensor heater delays  O2S Heater (post sensor) on Time  Predicted Catalyst temp Fuel State	Engine Airflow  Closed loop integral Closed Loop Active Evap Ethanol  Post fuel cell (Decel) Crankshaft Torque  EGR Intrusive diagnostic All post sensor heater delays O'25 Heater (post sensor) on Time  Predicted Catalyst temp Fuel State  All of the above met for at least 0.0 seconds, and then check the following Engine Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enable test Vehicle Speed to initially enabled  All of the above met for at least 3.0 seconds, and then the Force Cat Rich intrusive stage is requested.  All of the above met for at least 3.0 seconds, and then the Force Cat Rich intrusive stage is requested.	Engine Airflow  Closed Loop Active Evap Ethanol  Post fuel cell (Decel) Crankshaft Torque  EGR Intrusive diagnostic All post sensor heater delays OZS Heater (post sensor) on Time  Predicted Catalyst temp Fuel State  All of the above met for at least 0.0 seconds, and then the Force and least 1 velicled Speed to initially enable test Velicle Speed to initially enabled (after initially enable)  New Joseph Speed to initially enable test Velicled Speed to initially enable test Velicled Speed to initially enable test Velicled Speed to initially enabled)  1,450 ≤ RPM ≤ 3,400  43.5 ≤ MPH ≤ 80.2  38.5 ≤ MPH ≤ 82.0

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					During Stuck Lean test the following must stay TRUE or the test will abort: Commanded Fuel Crankshaft Torque	0.96 ≤ EQR ≤ 1.08 < 110.0 Nm		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Rich Bank 1 Sensor 2	P2271	This DTC determines if the post catalyst O2 sensor is stuck in a normal rich voltage range and thereby can no longer be used for post oxygen sensor fuel control or for catalyst monitoring. The diagnostic is an intrusive test which requests the DFCO mode to achieve the required lean threshold.	Post O2 sensor signal AND The Accumulated mass air flow monitored during the Stuck Rich Voltage Test	> 100 mvolts  > 3.0 grams	B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance	TPS_ThrottleAuthorityDef aulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_F A EthanolCompositionSens or_FA P013A, P013B, P013E, P013F or P2270  10.0 < Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" ) = Not Valid	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.	Type B, 2 Trips
					Green O2S Condition  Low Fuel Condition Diag	= Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. = False		
				Low Fuel Condition Diag  Engine Speed	in Supporting Tables tab.			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Engine Airflow Vehicle Speed Closed loop integral Closed Loop Active	2≤ gps ≤ 20 43.5 ≤ MPH ≤ 80.2 0.75 ≤ C/L Int ≤ 1.07 = TRUE		
					Evap Ethanol	not in control of purge not in estimate mode		
					Power Take Off EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor)	= not active = not active = not active		
					on Time  Predicted Catalyst temp Fuel State	≥ 60.0 sec 550 ≤ °C ≤ 900 DFCO possible		
					DTC's Passed	= P2270 (and P2272 if applicable) = P013E (and P014A if applicable) = P013A (and P013C if applicable)		
					After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT LOW - for 3 DTC implementati on only	P2300	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for a Short to Ground fault		≤ 100 Ω impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT High - for 3 DTC implementati on only	P2301	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for a Short to Power fault		≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT Low - for 3 DTC	P2303	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.		Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples	Type B, 2 Trips
implementati on only			high state (indicates	≤ 100 Ω impedance between signal and controller ground			100 msec rate	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT High - for 3 DTC implementati on only	P2304	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for a Short to Power fault		≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT Low - for 3 DTC implementati on only	P2306	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for a Short to Ground fault		≤ 100 Ω impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT High - for 3 DTC implementati on only	P2307	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage high during driver low state (indicates short-to-power)	≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT Low - for 3 DTC implementati on only	P2309	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for a Short to Ground fault		≤ 100 Ω impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT High - for 3 DTC implementati on only	P2310	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage high during driver low state (indicates short-to-power)	≤ 100 Ω impedance between signal and controller power	Engine running Ignition Voltage	> 5.00 Volts	20 Failures out of 25 Samples 100 msec rate	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Bank 1	P2430	This DTC detects a stuck in range pressure sensor signal when the AIR pump is commanded on.	Average Pressure Error AND Signal Variation	< 0.50 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRSysPressSnsrB1CktL oFA AIRSysPressSnsrB1CktHi FA ControllerProcessorPerf_ FA	Stuck in range cumulative time > 5.0 seconds  Frequency: Once per trip when SAI pump is commanded On	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Performance Bank 1	P2431	This DTC detects a skewed pressure sensor signal via a comparison of the AIR pressure sensor signal and estimated BARO, as well as an evaluation of the quality of the comparison.	Difference between AIR pressure sensor and BARO (Pump Commanded Off) or  OR  Difference between AIR pressure sensor and BARO (Pump Commanded On)	> 15.0 kPa  < -15.0 kPa  > 50.0 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Transfer Case not in 4WD Low Run/crank active No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec  AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRSysPressSnsrB1CktL oFA AIRSysPressSnsrB1CktHi FA MAF_SensorFA EngineMisfireDetected_F A ControllerProcessorPerf_ FA	Skewed sensor cumulative test weight > 30.0 seconds  Continuous 6.25ms loop  Skewed sensor cumulatative test weight is based on distance from the last Baro update. See Baro Skewed Sensor Weight Factor table.	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Low Voltage Bank 1	P2432	This DTC detects an out of range low AIR pressure sensor signal	AIR Pressure Sensor signal	< 6 % of 5Vref for 800 failures out of 1,000 samples	No active DTCs:	ControllerProcessorPerf_ FA	1,000 samples (6.25 ms per sample) Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pressure Sensor Circuit Hi Voltage Bank 1	P2433	This DTC detects an out of range high AIR pressure sensor signal	AIR Pressure Sensor signal	> 94 % of 5Vref for 800 failures out of 1,000 samples	No active DTCs:	ControllerProcessorPerf_ FA	1,000 samples (6.25 ms per sample) Continuous	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Shut-off Valve Stuck Open	P2440	This DTC detects if one or both of the AIR system control valves is stuck openThis test is run during Phase 2 (Pump commanded On, valve commanded closed)	Average Pressure Error or	< Bank 1 Valve Pressure Error table < Bank 2 Valve Pressure Error table > 32 kPa for either Bank	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Stability Time	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec > 0.5 seconds	Phase 2 Conditional test weight > 1.5 sec  Frequency: Once per trip when AIR pump commanded On	Type B, 2 Trips
					AIR diagnostic Phase 1 passed  No active DTCs:	AIRSystemPressureSens or FA AIRValveControlCircuit FA AIRPumpControlCircuit FA MAF_SensorFA AmbientAirDefault_NA IAT_SensorFA ECT_Sensor_FA EngineMisfireDetected_F A CatalystSysEfficiencyLoB 1_FA CatalystSysEfficiencyLoB 2_FA ControllerProcessorPerf_FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA	Conditional test weight is calculated by multiplying the following Factors: Phase 2 Baro Test Weight Factor, Phase 2 MAF Test Weight Factor, Phase 2 System Volt Test Weight Factor, Phase 2 Ambient Temp Test Weight Factor (see Supporting Tables)	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Shut-off Valve Stuck Open	P2440	This DTC detects if the AIR system control valve is stuck openThis test is run during Phase 2 (Pump commanded On, valve commanded closed)	Average Pressure Error or	< Bank 1 Valve Pressure Error table > 32 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Stability Time  AIR diagnostic Phase 1 passed  No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for 2.0 sec < 5,000 RPM > 50 gm/s for 3.0 sec > 0.5 seconds  AIRSystemPressureSens or FA AIRValveControlCircuit FA AIRPumpControlCircuit FA MAF_SensorFAAmbientAi rDefault_NA IAT_SensorFAECT_Sens or_FA EngineMisfireDetected_F A CatalystSysEfficiencyLoB 1_FA CatalystSysEfficiencyLoB 2_FA ControllerProcessorPerf_FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA	Phase 2 Conditional test weight > 1.5 sec  Frequency: Once per trip when AIR pump commanded On  Conditional test weight is calculated by multiplying the following Factors: Phase 2 Baro Test Weight Factor, Phase 2 MAF Test Weight Factor, Phase 2 System Volt Test Weight Factor, Phase 2 Ambient Temp Test Weight Factor (see Supporting Tables)	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Secondary AIR System Pump Stuck On	P2444	This DTC detects if the SAI pump is stuck On. This test is run during Phase 3 (Pump commanded Off, valve commanded closed)	Average Pressure Error or	> Bank 1 Pump Pressure Error table < -32 kPa	BARO Inlet Air Temp Coolant Temp Engine off time System Voltage MAP not Engine Speed MAF not Stability Time  AIR diagnostic Phase 1 passed AIR diagnostic Phase 2 passed  No active DTCs:	> 60 kPa > -10.0 deg C > -10.0 deg C < 80.0 > 3,600.0 seconds > 10.0 Volts < 32.0 < 20 kPa for > 2.0 sec. < 5,000 RPM > 50 gm/s for > 3.0 sec. > 4.0 seconds  Phase 3 cumulatative test weight is based on the distance from the last Baro update. See Baro Skewed Sensor Weight Factor table.  AIRSystemPressureSens orFA AIRValveControlCircuit FA AIRPumpControlCircuit FA AIRPumpControlCircuit FA AIRPumpControlCircuit FA CT_SensorFA ECT_SensorFA ECT_SensorFA ECT_SensorFA Ect_SensorFA CatalystSysEfficiencyLoB 1_FA CatalystSysEfficiencyLoB 2_FA ControllerProcessorPerf_FA IgnitionOutputDriver_FA FuelInjectorCircuit_FA	Phase 3 Cumlatative test weight > 2.0 sec. Frequency: Once per trip when AIR pump commanded On	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Control Torque Request	P2544	Determines if the torque request from the TCM is valid	Protect error - Serial Communication message - (\$199 - PTEI3)	Message <> two's complement of message	Diagnostic enabled/ disabled	Enabled	>= 16 Protect errors during key cycle.	Type B, 2 Trips
Circuit			OR		Power Mode	= Run	Performed on every received message	
			Rolling count error - Serial Communication message (\$199 - PPEI3) rolling count value	Message <> previous message rolling count value + one	Ignition Voltage	> 6.41 volts	>= 6 Rolling count errors out of 10 samples.	
			OR		Engine Running Run/Crank Active	= True > 0.50 Sec	Performed on every received message	
			Range Error - Serial Communication message - (\$199 - PTEI3) TCM Requested Torque Increase	> 450 Nm	No Serial communication loss to TCM (U0101)	No loss of communication	>= 6 range errors out of 10 samples. Performed on every received message	
			Multi-transition error - Trans torque intervention type request change	Requested torque intervention type toggles from not increasing request to increasing request			>= 3 multi- transitions out of 5 samples. Performed every 200 msec	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Off Timer Performance	P262B	This DTC determines if the hardware timer does not initialize or count properly. There are two tests to ensure proper functioning of the timer: Count Up Test (CUT) and Range Test (RaTe).  Count Up Test (CUT): Verifies that the HWIO timer is counting up with the proper increment.	Count Up Test:  Time difference between the current read and the previous read of the timer	> 1.50 seconds			Count Up Test: 4 failures out of 20 samples  1 sec / sample  Continuous while run/crank is not active and until controller shutdown is initiated.	Type B, 2 Trips
		Range Test (RaTe): When the run/crank is not active both the hardware and mirror timers are started. The timers are compared when module shutdown is initiated or run/crank becomes active.	Range Test: The variation of the HWIO timer and mirror timer is	> 24.87 %.			Range Test: Once per trip when controller shutdown is initiated or run/ crank becomes active.	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Low	P263A	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage  Remote Vehicle Start is not active	Voltage ≥ 11 volts	50 failures out of 63 samples 50 ms / sample	Type B, No MIL Note: In certain controlle rs P0650 may also set (MIL Control Open Circuit)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) High	P263B	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Run/Crank Voltage  Remote Vehicle Start is not active	Voltage ≥ 11 volts	4 failures out of 5 samples 50 ms / sample	Type B, No MIL NO MIL

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communicati on Bus A Off	U0073	This DTC monitors for a BUS A off condition	Bus off failures exceeds  before the sample time of is reached	5 counts (equivalent to 0.06 seconds) 0.56 seconds	General Enable Criteria: U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Ignition voltage	Not Active on Current Key Cycle Enabled Not Active  Not Active  >= 11.00 or >= 6.41 = run	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips
					Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line and Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds  CAN hardware is bus OFF for	= 0 (1 indicates enabled) = Active > 11.00		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With TCM	U0101	This DTC monitors for a loss of communication with the transmission control module	Message is not received from controller for Message \$0AB Message \$0BD Message \$0C7 Message \$0F9 Message \$189 Message \$199 Message \$19D Message \$1AF Message \$1BE Message \$1BF Message \$1F5 Message \$4C9	≥ 10.0 seconds	General Enable Criteria:  U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Ignition voltage  Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line and Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds  Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is	Not Active on Current Key Cycle Enabled Not Active  Not Active  >= 11.00 or >= 6.41 = run  = 0 (1 indicates enabled) = Active > 11.00	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					not active for	> 0.4000 seconds		
					U0101	Not Active on Current Key Cycle		
					тсм	is present on the bus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Fuel Pump Control Module	U0109	This DTC monitors for a loss of communication with the fuel pump control module	Message is not received from controller for Message \$1EB Message \$4D9	≥ 10.0 seconds ≥ 10.0 seconds	General Enable Criteria:  U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Ignition voltage  Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line and Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds  Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is	Not Active on Current Key Cycle Enabled Not Active  Not Active  >= 11.00 or >= 6.41 = run  = 0 (1 indicates enabled) = Active > 11.00	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					not active for	> 0.4000 seconds		
					U0109	Not Active on Current Key Cycle		
					Fuel Pump Control Module	is present on the bus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Anti- Lock Brake System (ABS) Control Module	U0121	This DTC monitors for a loss of communication with the Anti-Lock Brake System (ABS) Control Module (Non-OBD Module ID 243).	Message is not received from controller for  Message \$0C1  Message \$0C5  Message \$0D1	≥ 10.0 seconds ≥ 10.0 seconds ≥ 10.0 seconds	General Enable Criteria: U0073  Normal CAN transmission on Bus A  Device Control	Not Active on Current Key Cycle Enabled Not Active	Diagnostic runs in 12.5 ms loop	Type C, No MIL "Special Type C"
			Message \$1C6 Message \$1C7 Message \$1E9	≥ 10.0 seconds ≥ 10.0 seconds ≥ 10.0 seconds	High Voltage Virtual Network Management Ignition Voltage Criteria:	Not Active		
			Message \$2F1 Message \$2F9	≥ 10.0 seconds ≥ 10.0 seconds	Ignition voltage	>= 11.00 or >= 6.41		
					Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl	= run = 0 (1 indicates enabled)		
					Ignition Accessory Line and Battery Voltage	= Active > 11.00		
					General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds			
					Power Mode is in accessory or run or crank and High Voltage Virtual			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Network Management is not active for	> 0.4000 seconds		
					U0121	Not Active on Current Key Cycle		
					Anti-Lock Brake System Control Module	is present on the bus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Body Control Module	U0140	This DTC monitors for a loss of communication with the Body Control Module.	Message is not received from controller for Message \$0F1 Message \$12A Message \$1E1 Message \$1F1 Message \$1F3 Message \$3C9 Message \$3CB Message \$3F1 Message \$451 Message \$4D7 Message \$4E1 Message \$4E9	≥ 10.0 seconds	General Enable Criteria:  U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Ignition voltage  Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line and Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds  Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is	Not Active on Current Key Cycle Enabled Not Active  Not Active  >= 11.00 or >= 6.41 = run  = 0 (1 indicates enabled) = Active > 11.00  > 0.4000 seconds	Diagnostic runs in 12.5 ms loop	Type C, No MIL "Special Type C"

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					not active for U0140	Not Active on Current Key Cycle		
					Body Control Module	is present on the bus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Output Speed Sensor (TOSS)	P0502	No activity in the TOSS circuit	TOSS Raw Speed	≤ 60 RPM	Engine Torque Minimum Throttle opening Engine Speed Ignition voltage PTO EngineTorqureInaccurate	1,500 ≤ RPM ≤ 6,500  9.0 ≤ Volts ≤ 16.00  not active  KeETQC_b_MinTransRe medial = TRUE: MSFR_b_EngMisfDtctd_F A, MAFR_b_MAF_SnsrTFT KO, MAPR_b_MAP_SnsrTFT KO  KeETQC_b_MinTransRe medial = FALSE: FULR_b_FuelInjCkt_TFT KO, MAFR_b_MAF_SnsrTFT KO, MAFR_b_MAF_SnsrTFT KO, MAFR_b_MAF_SnsrTFT	≥ 4.5 sec	Type B, 2 Trips
					P0503	Not failed this key cycle		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Output Speed Sensor (TOSS)	P0503	TOSS Signal Intermittent	Loop-to-Loop change in TOSS	≥ 350 RPM	Raw Output SpeedOutput  Speed changeTime since transfer case range change  Ignition voltage  Engine Speed  Vehicle Speed	> 200 RPM for ≥ 2.0 sec ≤ 150 RPM for ≥ 2.0 sec ≥ 3.0 sec ≥ 3.0 sec 9.0 ≤ Volts ≤ 16.00 200 ≤ RPM ≤ 7,500 for ≥ 5.0 seconds ≤ 250.00 MPH for ≥ 5.0 sec not active	≥ 3.3 sec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Range / Performance	P0806	Detects if Clutch Pedal Position Sensor is Stuck in a range indicative of a vehicle NOT in gear, when the vehicle is determined to be in gear. Gear determination is made by verifying that the ratio of engine RPM versus Transmission Output Speed (N/TOS) represents a valid gear.	Filtered Clutch Pedal Position Error when the vehicle is determined to be in gear	> 3 %	N/TOS Ratio:  Transfer Case: Vehicle speed: Engine Torque:  Clutch Pedal Position:  OR  No Active DTCs:	Must match actual gear (i.e. vehicle in gear)  Not in 4WD Low range  > 6.2 MPH  > EngTorqueThreshold (see Supporting Tables)  < ResidualErrEnableLow (see Supporting Tables)  > ResidualErrEnableHigh (see Supporting Tables)  ClutchPstnSnsrCktHi FA ClutchPstnSnsrCktLo FA CrankSensor_FA Transmission Output Shaft Angular Velocity Validity VehicleSpeedSensor_FA	25 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Low	P0807	Detects Continuous Circuit Out-of-Range Low or Open	Clutch Position Sensor Circuit for	< 4 % of Vref  200 counts out of 250 samples	Engine Not Cranking System Voltage No active DTCs:	> 9.0 Volts	25 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Clutch Pedal Position Sensor Circuit High	P0808	Detects Continuous Circuit Out-of-Range High	Clutch Position Sensor Circuit for	> 96 % of Vref  200 counts out of 250 samples	Engine Not Cranking System Voltage No active DTCs:	> 9.0 Volts	25 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Not Learned	P080A	Detects Invalid Clutch Pedal Fully Applied Learn Position values	Fully Applied Learn Position OR	< 12.0 % > 35.0 %	OBD Manufacturer's Enable Counter	= 0	250 ms loop Continuous	Type A, 1 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve Control Circuit	P0033	Detect Turbocharger Bypass Valve - Open Circuit	ECM detects that commanded and actual states of output driver do not match because the output is open circuit		Diagnostic Enabled EnabledPowertrain relay Voltage Ignition run crank voltage Engine is not cranking	1 >= 11.00 Volts >= 5.00 Volts	failures out of 20 samples  1 sample every 100ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger	P0034	Detect Turbocharger Bypass Valve - Shorted	ECM detects that commanded and actual		Diagnostic Enabled	1	10	Type B, 2 Trips
Bypass		to Ground	states of output driver do		EnabledPowertrain relay	>=	failures out of	2 111100
Valve Control			not match because the output is shorted to		Voltage	11.00 Volts	20	
Circuit Low			ground		Ignition run crank voltage	>= 5.00 Volts	samples	
					Engine is not cranking		1 sample every 100ms	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger	P0035	Detect Turbocharger Bypass Valve - Shorted	ECM detects that commanded and actual		Diagnostic Enabled	1	10	Type B, 2 Trips
Bypass		to Power	states of output driver do		EnabledPowertrain relay	>=	failures out of	,50
Valve Control			not match because the output is shorted to power		Voltage	Volts 11.00	20	
Circuit High			output is shorted to power		Ignition run crank voltage	>= 5.00 Volts	samples	
					Engine is not cranking		1 sample every 100ms	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp - Engine Coolant Temp (ECT) Correlation (DCRD)	P00B6	This DTC detects a difference between ECT and RCT after a soak condition.	A failure will be reported if any of the following occur:  1) Absolute difference between ECT at power up & RCT at power up is ≥ an IAT based threshold table lookup value(fast fail).  2) Absolute difference between ECT at power up & RCT at power up is > by 20.0 °C and a block heater has not been detected.	up ECT exceeds RCT by these values in the Supporting tables section	No Active DTC's  Engine Off Soak Time Propulsion Off Soak Time Non-volatile memory initization  Test complete this trip Test aborted this trip IAT LowFuelCondition Diag	VehicleSpeedSensor_FA IAT_SensorCircuitFA THMR_RCT_Sensor_Ckt _FA THMR_ECT_Sensor_Ckt _FA IgnitionOffTimeValid TimeSinceEngineRunning Valid > 28,800 seconds > 0 seconds = Not occurred  = False = False ≥ -7 °C = False	1 failure 500 msec/ sample Once per valid cold start	Type B, 2 Trips
			3) ECT at power up > RCT at power up by 20.0 °C and the time spent cranking the engine without starting is greater than or equal to 10.0 seconds with the LowFuelConditionDiag	= False	Block Heater detection is enabled when either of the following occurs:  1) ECT at power up > IAT at power up by 2) Cranking time  ===================================	> 20.0 °C < 10.0 Seconds ====================================		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					below 1b as follows:	1b		
					1d) IAT drops from power up IAT	≥ 8.0°C		
					2a) ECT drops from power up ECT	> 2°C		
					2b) Engine run time	Within < 60 Seconds		
					Diagnostic is aborted when 3) or 4) occurs:	=======================================		
					3) Engine run time with vehicle speed below 1b	> 1800 Seconds		
					4) Minimum IAT during test	≤ -7.0 °C		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Pressure Measuremen t System -	P00C7	Detects an inconsistency between pressure sensors in the induction system in	ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost	> 10.0 kPa	Time between current ignition cycle and the last time the engine was running	> 10.0 seconds	4 failures out of 5 samples 1 sample every	Type B, 2 Trips
Multiple Sensor Correlation		which a particular sensor cannot be identified as the failed	Pressure - Manifold Pressure) AND	<= 10.0 kPa	Engine is not rotating	7 TO.O Seconds	12.5 msec	
(turbocharge d)		sensor	ABS(Turbocharger Boost Pressure - Baro Pressure)	<= 10.0 kPa	Manifold Pressure Manifold Pressure Baro Pressure Baro Pressure	>= 50.0 kPa <= 115.0 kPa >= 50.0 kPa <= 115.0 kPa		
			ABS(Manifold Pressure - Baro Pressure) AND	<= 10.0 kPa	Turbocharger Boost Pressure Turbocharger Boost Pressure	>= 50.0 kPa <= 115.0 kPa		
			ABS(Turbocharger Boost Pressure - Manifold Pressure) AND	> 10.0 kPa	No Active DTCs:	EngineModeNotRunTimer Error MAP_SensorFA		
			ABS(Turbocharger Boost Pressure - Baro Pressure)	<= 10.0 kPa		AAP_SnsrFA AAP2_SnsrFA		
			OR ABS(Manifold Pressure -		No Pending DTCs:	MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP		
			Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold	<= 10.0 kPa		7 2_5.15.5		
			Pressure - Marillold Pressure) AND ABS(Turbocharger Boost	<= 10.0 kPa				
			Pressure - Baro Pressure) OR	> 10.0 kPa				
			ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold	> 10.0 kPa				

Component	Foult	Monitor Description	Malfunction Criteria	Threshold Value		Enable Conditions	Time Required	MIL
Component/ System	Fault Code				Secondary Parameters	Enable Conditions	Time Required	Illum.
			Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	> 10.0 kPa				
			Pressure - Baro Pressure)	> 10.0 kPa				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 3 Circuit Performance	P00E9	Detects an IAT3 sensor that has stuck in range by comparing to IAT and IAT2 at startup	ABS(Power Up IAT - Power Up IAT2) AND	<= 25 deg C	Time between current ignition cycle and the last time the engine was running	> 28,800 seconds	Executes once at the beginning of each ignition cycle if enable conditions are	Type B, 2 Trips
(applications with humidity sensor and			ABS(Power Up IAT - Power Up IAT3)	> 25 deg C	Powertrain Relay Voltage for a time	>= 11.00 Volts >= 0.9 seconds	met	
manifold temperature sensor)	old rature	AND ABS(Power Up IAT2 - Power Up IAT3)	> 25 deg C	No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA			
			Power Up IAT is between Power Up IAT2 and Power Up IAT3  AND  ABS(Power Up IAT2 - Power Up IAT3)  AND  ABS(Power Up IAT - Power Up IAT3) > ABS(Power Up IAT3) > ABS(Power Up IAT - Power Up IAT - Power Up IAT2)	> 25 Deg C	Time between current ignition cycle and the last time the engine was running  Powertrain Relay Voltage for a time  No Active DTCs:	> 28,800 seconds  >= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	
			Power Up IAT2 is between Power Up IAT and Power Up IAT3 AND ABS(Power Up IAT - Power Up IAT3) AND ABS(Power Up IAT2 -	> 25 deg C	Time between current ignition cycle and the last time the engine was running  Powertrain Relay Voltage for a time  No Active DTCs:	> 28,800 seconds  >= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Power Up IAT3) > ABS(Power Up IAT2 - Power Up IAT)			HumTempSnsrCktFA		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 3 Low (applications with manifold temperature and humidity)		Detects a continuous short to ground in the IAT 3 signal circuit or the IAT 3 sensor	Raw IAT 3 Input	< 56 Ohms (~150 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 3 High (applications with manifold temperature and humidity)	P00EB	Detects a continuous open circuit in the IAT 3 signal circuit or the IAT 3 sensor	Raw IAT 3 Input	> 151,542 Ohms (~-60 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 3 Intermittent In-Range	POOEC	Detects a noisy or erratic IAT 3 signal circuit or IAT 3 sensor	String Length  Where: "String Length" = sum of "Diff" calculated over  And where: "Diff" = ABS(current IAT 3 reading - IAT 3 reading from 100 milliseconds previous)	> 80.00 DegC  10 consecutive IAT 3 samples	Continuous		4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (turbocharge d)	P0101	Determines if the MAF sensor is stuck within the normal operating range	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC.  MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered  MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered  MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered  MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered  TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered  TPS model fails when Filtered Throttle Model Error  TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP – measured MAP – measured MAP –	> 16 grams/sec  > 20.0 kPa  > 25.0 kPa  > 25.0 kPa  > 25.0 kPa  > 250 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,000 RPM > -7 Deg C < 126 Deg C > -20 Deg C < 100 Deg C  >= 0.50  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est  MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM  TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM  TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM  Filtered Throttle Model Error multiplied by TPS	Calculation are performed every 12.5 msec	Type B, 2 Trips
		offset as a function of engine speed	> 25.0 kPa		Residual Weight Factor based on RPM			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			See table "TIAP-MAP Correlation Offset"  OR  Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset"	> 25.0 kPa	No Active DTCs:	See Residual Weight Factor tables.  MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault		
			TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time	> 2.0 seconds > 2.0 seconds	No Pending DTCs:	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP		
			High Engine Air Flow is TRUE when Mass Air Flow  AND Manifold Pressure	> a threshold in gm/sec as a function of engine speed See table "TIAP-MAP Correlation Min Air Flow" > a threshold in kPa as a function of engine speed See table "TIAP-MAP Correlation Min MAP"				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Filtered Mass Air Flow - Mass Air Flow	< 2.0 gm/sec				
			Low Engine Air Flow is TRUE when Mass Air Flow	< a threshold in gm/sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow"				
			AND Manifold Pressure	< a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP"				
			AND Mass Air Flow - Filtered Mass Air Flow	< 2.0 gm/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (turbocharge d)	P0106	Determines if the MAP sensor is stuck within the normal operating range	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC.  MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered  MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered  MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered  MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered  TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered  TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered  TPS model fails when Filtered Throttle Model Error  TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP – measured MAP – offset as a function of engine speed See table "TIAP-MAP"	> 16 grams/sec  > 20.0 kPa  > 25.0 kPa  > 25.0 kPa  > 25.0 kPa  > 250 kPa*(g/s)	Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,000 RPM > -7 Deg C < 126 Deg C > -20 Deg C < 100 Deg C  >= 0.50  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est  MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM  TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM  TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM	Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Correlation Offset"			See Residual Weight		
						Factor tables.		
			OR					
1			Low Engine Air Flow is					
			TRUE		No Active DTCs:	MAP_SensorCircuitFA		
			AND		1407/6/1/6 2 1 63.	EGRValvePerformance_F		
l			Measured TIAP -			A		
1			measured Baro -			MAF_SensorCircuitFA		
l			offset as a function of			CrankSensor_FA		
l			engine speed	> 25.0 kPa		ECT_Sensor_FA		
			See table "TIAP-Baro Correlation Offset"			IAT_SensorFA MnfdTempSensorFA		
			Correlation Onset			TC_BoostPresSnsrCktFA		
			TIAP Correlation is valid			AmbientAirDefault		
			when					
					No Pending DTCs:	EGRValve_FP		
			High Engine Air Flow has			ECT_Sensor_Ckt_FP		
			been TRUE for a period of time	. 20 accords		IAT_SensorCircuitFP		
			OR	> 2.0 seconds		MnfdTempSensorCktFP		
			Low Engine Air Flow has					
			been TRUE for a period of					
			time	> 2.0 seconds				
			High Engine Air Flow is TRUE when					
			Mass Air Flow	> a threshold in				
				gm/sec as a function				
				of engine speed				
				See table "TIAP-MAP				
				Correlation Min Air Flow"				
			AND	I IOW				
			Manifold Pressure	> a threshold in kPa				
				as a function of				
				engine speed				
				See table "TIAP-MAP				
			AND	Correlation Min MAP				
			Filtered Mass Air Flow -					
			Mass Air Flow	< 2.0 gm/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Low Engine Air Flow is TRUE when Mass Air Flow  AND Manifold Pressure  AND Mass Air Flow - Filtered Mass Air Flow	< a threshold in gm/sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow"  < a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP"  < 2.0 gm/sec				
			Manifold Pressure OR Manifold Pressure OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	< 50.0 kPa > 115.0 kPa > 10.0 kPa > 10.0 kPa <= 10.0 kPa	Time between current ignition cycle and the last time the engine was running  Engine is not rotating  No Active DTCs:  No Pending DTCs:	> 10.0 seconds  EngineModeNotRunTimer Error MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA  MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP	4 failures out of 5 samples 1 sample every 12.5 msec	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (turbocharge d)	P0121	Determines if the Throttle Position Sensor input is stuck within the normal operating range	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC.  MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered  MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered  MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered  MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered  TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered  TPS model fails when ABS(Measured TIAP – TIAP Model 1) Filtered  TPS model fails when Filtered Throttle Model Error  TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP – measured MAP – offset as a function of engine speed See table "TIAP-MAP	> 16 grams/sec  > 20.0 kPa  > 25.0 kPa  > 25.0 kPa  > 25.0 kPa  > 250 kPa*(g/s)	Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,000 RPM > -7 Deg C < 126 Deg C > -20 Deg C < 100 Deg C  >= 0.50  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est  MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM  TIAP Model 1 Error multiplied by TPS Residual Weight Factor based on RPM  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM	Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Correlation Offset" OR			See Residual Weight Factor tables.		
			Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset"  TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of	> 25.0 kPa	No Active DTCs:  No Pending DTCs:	MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault EGRValve_FP ECT_Sensor_Ckt_FP		
			time OR Low Engine Air Flow has been TRUE for a period of time	> 2.0 seconds > 2.0 seconds		IAT_SensorCircuitFP MnfdTempSensorCktFP		
			High Engine Air Flow is TRUE when Mass Air Flow	> a threshold in gm sec as a function of engine speed See table "TIAP-MAP Correlation Min Air Flow"				
			AND Manifold Pressure	> a threshold in kPa as a function of engine speed See table "TIAP-MAP Correlation Min MAP"				
			AND Filtered Mass Air Flow - Mass Air Flow	< 2.0 gm/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Low Engine Air Flow is TRUE when Mass Air Flow  AND Manifold Pressure  AND Mass Air Flow - Filtered Mass Air Flow	< a threshold in gm sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow" < a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP" < 2.0 gm/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Insufficient Activity Bank 1 Sensor 1	P0134	This DTC determines if the O2 sensor circuit is open.	Oxygen Sensor Signal	> 1,700 mvolts	No Active DTC's  System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition	TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 50 seconds ≤ 87 % Ethanol	100 failures out of 125 samples. Frequency: Continuous 100 msec loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Insufficient Activity Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0140	This DTC determines if the O2 sensor circuit is open.	Oxygen Sensor Signal	> 1,700 mvolts	No Active DTC's  System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Fuel Condition	TPS_ThrottleAuthorityDef aulted MAF_SensorFA EthanolCompositionSens or_FA 10.0 < Volts < 32.0 = All Cylinders active = Complete > 5 seconds > 50 seconds ≤ 87 % Ethanol	100 failures out of 125 samples. Frequency: Continuous 100 msec loop	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Engine Overboost Turbocharge r with wastegate. Not supercharge r with mechanical compressor	P0234	Detect Negative Boost Pressure Control Deviation	Desired Boost Pressure - Actual Boost Pressure	< (KtBSTD_p_CntrlDevN egLim - KtBSTD_p_CntrlDevA mbAirCorr)  See Tables in Supporting Tables Sheet	Diagnostic Enabled Engine Speed Engine Speed Desired Boost Pressure Desired Boost Pressure Desired Boost Pressure Derivative Desired Boost Pressure Derivative Ambient Pressure Coolant Temp Coolant Temp Intake Air Temp Wait for steady state:  No Active DTCs:	1 > 2,450 rpm < 6,000 rpm > 135.0 kPa < 220.0 kPa < 220.0 kPa/s > -70.0 kPa/s < 55.0 kPa/s > 70.0 kPa < 120.0 kPa < 120.0 kPa < 120.0 Deg C < 126.0 Deg C < 40.0 Deg C < 80.0 Deg C  > MtBSTD_t_CntrlDevEnblD elay See Table in Supporting Tables Sheet  Desired Boost Pressure > BasicPressure  AmbientAirDefault_Snsr BSTR_b_PCA_CktFA BSTR_b_TurboBypassCkt FA ECT_Sensor_FAIAT_Sen	failures out of 20 samples  1 sample every 100ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Active DVCs:	sorFA BSTR_b_ExcsvBstTFTK O BSTR_b_PCA_CktTFTK O TC_BoostPresSnsrFA AnyCamPhaser_FA BSTR_b_PresCntrlTooLo TFTKO BSTR_b_PresCntrlTooHiT FTKO EnginePowerLimited  BSTR_b_DVC_PCA_DC_ Actv BSTR_b_DVC_PCA_Pstn Actv BSTR_b_DVC_TurboCom prBypActv		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r Boost Pressure (TIAP) Sensor Performance	P0236	Determines if the Turbocharger Boost (TIAP) Pressure Sensor input is stuck within the normal operating range	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC.  MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered  MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered  MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered  MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered  TIAP1 model fails when ABS(Measured TIAP - TIAP Model 1) Filtered  TPS model fails when Filtered TPS model fails when Filtered Throttle Model Error  TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table "TIAP-MAP Correlation Offset"	> 16 grams/sec  > 20.0 kPa  > 25.0 kPa	Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,000 RPM > -7 Deg C < 126 Deg C > -20 Deg C < 100 Deg C  >= 0.50  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est  MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM  TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM  TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM	Calculation are performed every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR  Low Engine Air Flow is TRUE AND  Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset"	> 25.0 kPa	No Active DTCs:	See Residual Weight Factor tables.  MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA		
			TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time	> 2.0 seconds	No Pending DTCs:	AmbientAirDefault  EGRValve_FP  ECT_Sensor_Ckt_FP  IAT_SensorCircuitFP  MnfdTempSensorCktFP		
			High Engine Air Flow is TRUE when Mass Air Flow	> a threshold in gm/sec as a function of engine speed. See table "TIAP-MAP Correlation Min Air Flow"				
			AND Manifold Pressure	> a threshold in kPa as a function of engine speed. See table "TIAP-MAP Correlation Min MAP"				
			AND Filtered Mass Air Flow - Mass Air Flow	< 2.0 am/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Low Engine Air Flow is TRUE when Mass Air Flow	< a threshold in gm/ sec as a function of engine speed. See table "TIAP-Baro Correlation Max Air Flow"				
			AND Manifold Pressure  AND Mass Air Flow - Filtered Mass Air Flow	< a threshold in kPa as a function of engine speed. See table "TIAP-Baro Correlation Max MAP" < 2.0 gm/sec				
			Turbocharger Boost Pressure OR Turbocharger Bosst Pressure	< 50.0 kPa > 115.0 kPa	Time between current ignition cycle and the last time the engine was running  Engine is not rotating	> 10.0 seconds	4 failures out of 5 samples 1 sample every 12.5 msec	
			ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND	<= 10.0 kPa > 10.0 kPa	No Active DTCs:  No Pending DTCs:	EngineModeNotRunTimer Error MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA MAP_SensorCircuitFP AAP_SnsrCktFP		
			ABS(Turbocharger Boost	> 10.0 kPa		AAP2_SnsrCktFP		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions		MIL Illum.
Turbocharge r Boost Pressure Sensor Circuit Low	P0237	Detects a continuous short to low or open in either the signal circuit or the turbocharger boost pressure sensor.	Turbocharger Boost Pressure Voltage	< 17.0 % of 5 Volt Range (This is equal to 0.85 Volts, or 49.6 kPa)	Engine Run Time	> 0.00 seconds	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r Boost Pressure Sensor Circuit High		Detects an open sensor ground or continuous short to high in either the signal circuit or the turbocharger boost pressure sensor.	Turbocharger Boost Pressure Voltage	> 95.0 % of 5 Volt Range (This is equal to 4.75 Volts, or 306.6 kPa)	Engine Run Time	> 0.00 seconds	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r Wastegate / Supercharge r Boost Solenoid A Control	P0243	Detect Turbocharger Boost Solenoid -Open Circuit	ECM detects that commanded and actual states of output driver do not match because the output is open circuit		Diagnostic Enabled  Powertrain relay voltage  Ignition run crank voltage  Engine is not cranking	1 >= 11.00 Volts >= 5.00 Volts	failures out of 20 samples	Type B, 2 Trips
Circuit							1 sample every 100ms	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r Wastegate / Supercharge r Boost Solenoid A Control Circuit Low	P0245	Detect Turbocharger Boost Solenoid - Shorted to ground	ECM detects that commanded and actual states of output driver do not match because the output is shorted to ground		Diagnostic Enabled  Powertrain relay voltage  Ignition run crank voltage  Engine is not cranking	1 >= 11.00 Volts >= 5.00 Volts	failures out of 20 samples 1 sample every 100ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharge r	P0246	Detect Turbocharger Boost Solenoid -	ECM detects that commanded and actual		Diagnostic Enabled	1	10	Type B, 2 Trips
Wastegate /		Shorted to Power	states of output driver do		Powertrain relay voltage	>= 11.00	failures out of	'
Supercharge			not match because the		lanition run orank valtage	Volts	20	
r Boost Solenoid A			output is shorted to power		Ignition run crank voltage	>=	samples	
Control					Engine is not cranking	5.00 Volts		
Circuit High							1 sample every	
							100ms	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Engine Underboost Turbocharge r with wastegate. Not supercharge r with mechanical compressor	P0299	Detect Positive Boost Pressure Control Deviation	Desired Boost Pressure - Actual Boost Pressure	(KtBSTD_p_CntrlDevP osLim + KtBSTD_p_CntrlDevA mbAirCorr)  See Tables in Supporting Tables Sheet	Diagnostic Enabled Engine Speed Engine Speed Desired Boost Pressure Desired Boost Pressure Desired Boost Pressure Derivative Desired Boost Pressure Derivative Ambient Pressure Ambient Pressure Coolant Temp Coolant Temp Intake Air Temp Wait for steady state:  No Active DTCs:	1 > 2,450 rpm < 6,000 rpm > 135.0 kPa < 220.0 kPa < 70.0 kPa/s < 55.0 kPa/s  > 70.0 kPa < 120.0 kPa < 120.0 kPa  > -40.0 Deg C < 126.0 Deg C < 80.0 Deg C  > MtBSTD_t_CntrlDevEnblD elay See Table in Supporting Tables Sheet Desired Boost Pressure > Basic Pressure AmbientAirDefault_Snsr BSTR_b_PCA_CktFA BSTR_b_TurboBypassCkt FA ECT_Sensor_FA	25 failures out of 25 samples  1 sample every 100ms	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Active DVCs:	IAT_SensorFA BSTR_b_ExcsvBstTFTK O BSTR_b_PCA_CktTFTK O TC_BoostPresSnsrFA AnyCamPhaser_FA BSTR_b_PresCntrlTooLo TFTKO BSTR_b_PresCntrlTooHiT FTKO EnginePowerLimited  BSTR_b_DVC_PCA_DC_ Actv BSTR_b_DVC_PCA_Pstn Actv BSTR_b_DVC_TurboCom prBypActv		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 1	P0420	NOTE: The information contained below applies to applications that use the Idle Catalyst Monitor Algorithm  The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (I.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Lean and Rich A/F excursions	Normalized Ratio OSC Value (EWMA filtered)	< 0.35	There must be a valid idle period. The criteria are:  Driver must be off the accel pedal. This checks that the final accel pedal position (comprehending deadband and hysteresis) is essentially zero.  Idle Speed Control System Is Active  Vehicle Speed  Engine speed  Engine run time	< 1.24 MPH > 1,200 RPM for a minimum of 2 seconds since end of last idle period.  > CatmonMinEngineRunTi meToEnable This is a function of Coolant Temperature, please see "Supporting Tables" for details.	1 test attempted per valid idle period  Minimum of 1 test per trip  Maximum of 6 tests per trip  Frequency: Fueling Related: 12.5 ms  OSC Measurements: 100 ms  Temp Prediction: 12.5ms	Type A, 1 Trips
		Normalized Ratio OSC Value Calculation Information and Definitions = 1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time) 2. BestFailing OSC value from a calibration table (based on temp and exhaust gas flow)			Tests attempted this trip  The catalyst diagnostic has not yet completed for the current trip.  Catalyst Idle Conditions Met Criteria is satified which includes the General Enable met and the Valid Idle Period	< 255		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		3. WorstPassing OSC			Criteria met, as well as:			
		value (based on temp and exhaust gas flow)			Green Converter Delay	Not Active		
		Normalized Ratio Calculation = (1-2) / (3-2)			Induction Air	>-20 ° C < 250 ° C		
		A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part. The Catalyst Monitoring			Intrusive test(s): Fueltrim Post O2 EVAP EGROther vehicle functions:	Not Active		
		Test is done during idle. Several conditions must be meet in order to execute this test. These conditions and			Power Take Off RunCrank Voltage Ethanol Estimation	Not Active > 10.90 Volts NOT in Progress		
		their related values are listed in the secondary parameters area of this document.			ECT	> 40 ° C < 140 ° C		
		Refer to the P0420_WorstPassing OSCTableB1 and			Barometric Pressure	> 70 KPA		
		P0420_BestFailingOS CTableB1 table in the Supporting Tables tab for details			Idle Time before going intrusive is	< 50 Seconds		
					Idle time is incremented if Vehicle speed	< 1.24 MPH and the drivers foot is off accel pedal and the idle speed control system is active as identified in the Valid Idle Period Criteria section.		
					Short Term Fuel Trim	> 0.77 < 1.27		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Predicted catalyst temp	> 440.00 degC		
					Engine Airflow	> CatmonMinAirflowForW armCatalystDeterminati on		
						table (g/s) (refer to "Supporting Tables" tab) (Based on engine coolant at the time the WarmedUpEvents counter resets to 0.)		
					for at least	5 seconds		
					with a closed throttle time	< 90 seconds consecutively (closed throttle consideration involves having the driver off the accel pedal as stated in the Valid Idle Period Criteria Section).		
					Also, in order to increment the WarmedUpEvents counter, either the vehicle speed must exceed the vehicle speed cal or the driver must NOT be off the accel pedal as stated in the Valid Idle Period Criteria section above.			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Closed loop fueling (Please see "Closed Loop Enable Criteria" section of the "Supporting Tables" tab for details.)			
					PRNDL	Enabled in Drive Range on an Auto Transmission vehicle.		
					Idle Stable Criteria:	Must hold true from after Catalyst Idle Conditions Met to the end of test		
					MAF	> 1.30 g/s < 6.00 g/s		
					Predicted catalyst temperature	< 900 degC		
					Engine Fueling Criteria at Beginning of Idle Period The following fueling related must also be met from between 4 and 7 seconds after the Catalyst Idle Conditions Met Criteria has been met for at least 4 seconds prior to allowing intrusive control:			
					Number of pre-O2 switches	>= 2		
					Short Term Fuel Trim Avg	> 0.90 < 1.05		
					Rapid Step Response			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(RSR) feature will initiate multiple tests:			
					If the difference between current EWMA value and the current OSC Normalized Ratio value is	> 0.52		
					and the current OSC Normalized Ratio value is	< 0.15		
					Maximum RSR tests to detect failure when RSR is enabled.	18		
					Green Converter Delay Criteria This is part of the check for the Catalyst Idle Conditions Met Criteria section			
					The diagnostic will not be enabled until the following has been met:			
					Predicted catalyst temperature for	> 0 ° C 0 seconds non- continuously.		
					Note: this feature is only enabled when the vehicle is new and cannot be enabled in service	Not Active		
					PTO General Enable DTC's Not Set	MAF_SensorFA MAF_SensorTFTKO AmbPresDfltdStatus		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						IAT_SensorCircuitFA IAT_SensorCircuitTFTKO ECT_Sensor_FA O2S_Bank_1_Sensor_1_ FA O2S_Bank_1_Sensor_2_ FA O2S_Bank_2_Sensor_1_ FA O2S_Bank_2_Sensor_2_ FA O2S_Bank_2_Sensor_2_ FA FuelTrimSystemB1_FA FuelTrimSystemB1_TFTK O FuelTrimSystemB2_TFTK O EngineMisfireDetected_F A EvapPurgeSolenoidCircuit_FA IAC_SystemRPM_FA EGRValvePerformance_F A EGRValveCircuit_FA CamSensorAnyLocationF A CrankSensorFA TPS_Performance_FA EnginePowerLimited		

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (turbocharge d)	P1101	Determines if there are multiple air induction problems affecting airflow and/or manifold pressure.	See table "Turbocharger Intake Flow Rationality Diagnostic Failure Matrix" for combinations of model failures that can set this DTC.  MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered  MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered  MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered  MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered  TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered  TPS model fails when Filtered Throttle Model Error	> 16 grams/sec  > 20.0 kPa  > 25.0 kPa  > 25.0 kPa  > 25.0 kPa  > 250 kPa	Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,000 RPM > -7 Deg C < 126 Deg C > -20 Deg C < 100 Deg C  >= 0.50  Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est  MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM  MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM  MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM  MAP Model 3 Error multiplied by MAP3 Residual Weight Factor based on RPM	Calculation are performed every 12.5 msec	Type B, 2 Trips
		TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP - measured MAP - offset as a function of engine speed See table "TIAP-MAP	> 25.0 kPa		TIAP Model 1 Error multiplied by TIAP Residual Weight Factor based on RPM  Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM			

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Correlation Offset" OR			See Residual Weight Factor tables.		
			Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table "TIAP-Baro Correlation Offset"  TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has	> 2.0 seconds	No Active DTCs:  No Pending DTCs:	MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault  EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP		
			been TRUE for a period of time	> 2.0 seconds				
			High Engine Air Flow is TRUE when Mass Air Flow	> a threshold in gm sec as a function of engine speed See table "TIAP-MAP Correlation Min Air Flow"				
			AND Manifold Pressure	> a threshold in kPa as a function of engine speed See table "TIAP-MAP Correlation Min MAP"				
			AND Filtered Mass Air Flow - Mass Air Flow	< 2.0 gm/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Low Engine Air Flow is TRUE when Mass Air Flow	< a threshold in gm sec as a function of engine speed See table "TIAP-Baro Correlation Max Air Flow"				
			AND Manifold Pressure AND Mass Air Flow - Filtered Mass Air Flow	< a threshold in kPa as a function of engine speed See table "TIAP-Baro Correlation Max MAP" < 2.0 gm/sec				

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Performance (turbocharge d)	P2227	Compares baro sensor to the calculated baro estimate (part throttle calculation or unthrottled MAP)	Difference between baro sensor reading and estimated baro when distance since last estimated baro update  OR  Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 15.0 kPa <= 0.06 miles > 20.0 kPa > 0.06 miles	No Active DTCs:	AmbPresSnsrCktFA ECT_Sensor_Ckt_FA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA	320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips
			Barometric Pressure OR Barometric Pressure OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	< 50.0 kPa > 115.0 kPa > 10.0 kPa <= 10.0 kPa > 10.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating No Active DTCs:	> 10.0 seconds  EngineModeNotRunTimer Error MAP_SensorFA TC_BoostPresSnsrCktFA AAP2_SnsrFA  MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP	4 failures out of 5 samples 1 sample every 12.5 msec	

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (boosted applications)	P2228	Detects a continuous short to low or open in either the signal circuit or the BARO sensor.	BARO Voltage	< 40.0 % of 5 Volt Range (2.0 Volts = 50.9 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (boosted applications)	P2229	Detects an open sensor ground or continuous short to high in either the signal circuit or the BARO sensor.	BARO Voltage	> 90.0 % of 5 Volt Range (4.5 Volts = 115.0 kPa)			320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve - Mechanical Turbocharge r with wastegate. Not supercharge r with mechanical compressor	P2261	Detect Stuck Closed Bypass Valve	Accumulation time is high pass filtered. Accumulated air mass flow or boost pressure larger then thresholds  Filter Frequency  Filtered Air Mass Flow  Filtered Boost Pressure	0.25 Second < Accumulation time < 0.85 Second  12.00 Hz > 50.000 g/s > 199.00 kPa	Diagnostic Enabled Engine Speed  Pressure ratio over the compressor  Relative Boost Pressure (Boost - Ambient) and Negative Transient in Manifold Air Pressure	1 >= 1,800 rpm >KtBSTD_r_ExcsvBstPre sLim Enable condition kept true for 1.5 seconds extra See Tables in Supporting Tables Sheet  IF (RelativeBoost < 3.0 kPa OR DerivativeMAP > 50.00 kPa/s) [FALSE] Else (RelativeBoost >= 40.0 kPa AND DerivativeMAP <= -150.00 kPa) [TRUE] > 6.0 percentEnable condition kept true for 0.70 seconds extra	3 Failed tests out of 3 Tests 1 sample every 25ms	Type B, 2 Trips
					Bypass Valve Commanded Open No Active DTCs:	TC_BoostPresSnsrFA MAF_SensorFABSTR_b_ TurboBypassCktFA		

Closed Loop Enab	le Clarifi	cation: C	alibratio	n values	are in the	Support	ing Table	es		
Engine run time greater than										
KtFSTA_t_ClosedLoopAutostart (HYBF	RID ONLY	<b>(</b> )								
AutoStart CoolantX1	X2	Х3	X4	X5	X6	X7	X8	X9	X10	X11
Close Loop Enable TimeY1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11
and										
KtFSTA_t_ClosedLoopTime										
Start-Up CoolantX1	X2	Х3	X4	X5	X6	X7	X8	X9	X10	X11
Close Loop Enable TimeY1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11
and pre converter 02 sensor voltage less										
than										
KfFULC_U_O2_SensorReadyThrsh										
Lo										
Voltage< XXX	XmilliVolt	S								
for										
KcFULC_O2_SensorReadyEvents										
Time (events * 12.5 milliseconds) > XXX	Xevents									
and										
COSC (Converter Oxygen Storage Contro	l) not									
enabled										
and										
Consumed AirFuel Ratio is stoichiometry	i.e. not i	n compo	nent							
protection										
and										
POPD or Catalyst Diagnostic not intrusive	<del>)</del>									
and										
Turbo Scavenging Mode not										
enabled										
and All cylinders whose valves are active also	hava th	oir inicot	oro							
enabled	mave un	en mject	015							
and										
O2S_Bank_ 1_TFTKO, O2S_Bank_ 2_TFT	KO Fual	Injector	ircuit F	∆ and						
CylnderDeacDriverTFTKO = False	ito, i uei	injector C	/!! Guit_! <i>F</i>	- alla						
The state of the										
Long Term FT Enable Criteria										

```
Closed Loop Enable Clarification: Calibration values are in the Supporting Tables
Closed Loop Enable and
Coolant greater than
KfFCLL T AdaptiveLoCoolant
                           Coolant> XXXXCelcius
or less than
KfFCLL_T_AdaptiveHiCoolant
                           Coolant< XXXXCelcius
and
KtFCLL p AdaptiveLowMAP Limit
               Barometric PressureX1
                                          X2
                                                                                                     X9
                                                           X4
                                                                   X5
                                                                            X6
                                                                                    X7
                                                                                             X8
               Manifold Air PressureY1
                                          Y2
                                                  Y3
                                                           Y4
                                                                   Y5
                                                                            Y6
                                                                                    Y7
                                                                                             Y8
                                                                                                     Y9
land
TPS_ThrottleAuthorityDefaulted =
False
and
Flex Fuel Estimate Algorithm is not active
and
Excessive fuel vapors boiling off from the engine oil algorithm (BOFR) is not
enabled
land
Catalyst or EVAP large leak test not
intrusive
Secondary Fuel Trim Enable
Criteria
Closed Loop Enable and
KfFCLP U O2ReadyThrshLo
                           Voltage< XXXXmilliVolts
for
KcFCLP Cnt O2RdyCyclesThrsh
    Time (events * 12.5 milliseconds) > XXXXevents
Long Term Secondary Fuel Trim
Enable Criteria
KtFCLP_t_PostIntglDisableTime
```

Closed Loop Enable Clarification: Calibration values are in the Supporting Tables													
Closed Loop Enable Clarification: Calibration values are in the Supporting Tables													
Start-Up CoolantX1	X2	Х3	X4	X5	X6	X7	X8	X9	X10	X11			
Post Integral Enable TimeY1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11			
Plus													
KtFCLP_t_PostIntglRampInTime	\/O	\/O	V/ 4	V.=	\/O	\/ <del>-</del> 7	1/0	V/0	\/40	3/44			
Start-Up CoolantX1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11			
Post Integral Ramp In TimeY1  and	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11			
KeFCLP_T_IntegrationCatalystMax													
	XCelcius	$\neg$											
and	<u>AOCIGIOS</u>												
KeFCLP_T_IntegrationCatalystMin Modeled Catalyst Temperature  > XXX  and PO2S_Bank_1_Snsr_2_FA and PO2S_Bank_2_Snsr_2_FA = False and (KeFCLP_Pct_CatAccuSlphrPostDsbl	XCelcius												
Modeled converter sulfur percent < XXXX	Percent												
and Post Integral < KaFCLP_U_SIphrIntglOfst_	_Thrsh)												
X axis: Post O2 Sensor Y axis: Post O2 Mode Z: Post Integral threshold													

Initial Supporting table - Multiple DTC Use_Green Sensor Delay Criteria - Airflow											
Description: This Calibration is the airflow (in gps) above which the green airflow is acculmulated to expire the condition.											
53, P015A, P015B, P015C, P015D, P1133, P1153, P2270, P2271, P2272 and P2273. The the airflow criteria below (by sensor location) has been met:											
//x											
1											

## Initial Supporting table - Multiple DTC Use\_Green Sensor Delay Criteria - Limit

Description: This Calibration is the acculmulated airflow (in grams) limit above which the green condition is expired

**Notes:** Used for: P0133, P013A, P013B, P013C, P013D, P013E, P013F, P014A, P014B, P0153, P015A, P015B, P015C, P015D, P1133, P1153, P2270, P2271, P2272 and P2273. Note: This feature is only enabled when the vehicle is new and cannot be enabled in service

	y/x	CiOXYR_O2_Bank1_Sensor1	CiOXYR_O2_Bank1_Sensor2	CiOXYR_O2_Bank2_Sensor1	CiOXYR_O2_Bank2_Sensor2
١	1	120,000	120,000	120,000	120,000

		Initia	Suppo	rting ta	ble - P0	Initial Supporting table - P0016_P0017_P0018_P0019 Cam Correlation Oil Temperature Threshold														
Descrip	Description: P0016_P0017_P0018_P0019 Cam Correlation Oil Temperature Threshold																			
Notes:	KtEPSI_t_	RtnHome	DlyLmt																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152			
1	300.0	300.0	160.0	18.0	18.0	18.0	18.0	10.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0			

	Initial Supporting table - P0101_P0106_P0121_P012B_P0236_P1101 MAP1 Residual Weight Factor based on RPM															PM	
Descript	Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP1 Residual Weight Factor based on RPM																
Notes:																	
y/x	y/x 0 800 1,500 2,500 2,800 3,100 3,200 3,300 3,500 4,000 4,200 4,500 5,000 5,500 6,500 7,000																
1	0.900	0.900	0.900	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

	Initial	Support	ing tab	le - P010	01_P010	)6_P012	21_P012	B_P02	36_P110	01 MAP	2 Resid	ual Weiç	ght Fact	or base	d on R	PM	
Descrip	Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP2 Residual Weight Factor based on RPM																
Notes:																	
y/x	0	800	1,500	2,500	2,800	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,500	6,500	7,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

	Initial S	Support	ing tabl	e - P010	)1_P010	06_P012	1_P012	B_P023	36_P110	1 MAP	3 Residu	ual Weig	ht Fact	or base	d on RF	PM	
Descript	i <b>on:</b> P0101	I_P0106_F	P0121_P01	2B_P0236	6_P1101 M	AP3 Resid	ual Weight	Factor ba	sed on RP	М							
Notes:																	
y/x	0	1,500	2,200	2,500	2,700	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,250	5,625	7,000
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

	Initial	Suppo	rting ta	ble - P0	101_P0	106_P0 <sup>-</sup>	121_P01	12B_P0	236_P1 <sup>′</sup>	101 TPS	Residu	ıal Weig	ht Facto	or base	d on RF	PM	
Descrip	tion: P010	1_P0106_	_P0121_P0	)12B_P023	6_P1101 T	TPS Residu	ual Weight	Factor bas	sed on RPI	Л							
Notes:																	
y/x	0	1,500	2,200	2,500	2,700	3,100	3,200	3,300	3,500	3,700	4,000	4,200	4,500	5,000	5,250	5,625	7,000
1	1 000	1 000	1 000	1 000	1 000	1 000	1 000	1 000	1 000	1 000	1 000	1 000	1 000	1 000	1 000	1 000	1 000

			Initia	I Suppo	rting ta	ble - P0	116_Fai	l if pow	er up E	CT exc	ceeds I	AT by th	ese valı	ues			
Descrip	Description: KtECTD_T_HSC_FastFailTempDiff																
Notes:	Caxis is IA	T Tempera	ature at Po	wer up (° C	, Z axis is	the Fast F	ailure temp	o differenc	e (° C)								
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	106	94	82	70	60	46	40	30	30	30	30	30	30	30	37	49	61

In	itial Supporting ta	ble - P0128_Maxi	mum Accumulat	ed Energy for Sta	art-up ECT condi	tions - Alternate	
Description: Maxim	num Total Energy transfer	red to Cooling System fo	r Ambient and Start-up	ECT conditions (Alternat	te Test)		
Notes: Z axis is the	cooling system energy fa	ilure threshold (kJ), X ax	is is ECT Temperature a	at Power up (° C), (Delux	ke version)		
y/x	-20	-7	10	30	45	59	75
1	11,800	10,240	8,200	5,800	4,000	2,320	1,120

lı	nitial Supporting t	able - P0128_Max	imum Accumula	ted Energy for St	art-up ECT cond	itions - Primary	
Description: Maxin	num Total Energy transfer	red to Cooling System fo	r Ambient and Start-up	ECT conditions (Primary	Test)		
Notes: Z axis is the	cooling system energy fa	ilure threshold (kJ), X ax	is is ECT Temperature a	at Power up (° C) , (Delu	xe version)		
y/x	-20	-7	10	30	45	59	75
1	14,000	12,700	11,000	9,000	7,500	6,100	4,500

				Init	ial Sup	porting	table -	P0133_	KnEOS	D_t_ST	_LRC_L	imRS1					
Descrip	Description: KnEOSD_t_ST_LRC_LimRS1. X Table Axis (in sec) for P0133, L2R Reponse time breakpoints for table																
Notes:																	
y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.012	0.026	0.039	0.052	0.061	0.068	0.074	0.075	0.078	0.084	0.091	0.101	0.113	0.139	0.184	0.214

				Init	ial Sup <sub>l</sub>	porting	table - F	P0133_k	(nEOS[	)_t_ST_	RLC_L	imRS1					
Descript	Description: KnEOSD_t_ST_RLC_LimRS1. Y Table Axis (in sec) for P0133, R2L Reponse time breakpoints for table																
Notes:																	
y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.012	0.026	0.039	0.052	0.061	0.068	0.074	0.075	0.078	0.084	0.091	0.101	0.113	0.139	0.184	0.214

#### Initial Supporting table - P0133\_O2S Slow Response Bank 1 Sensor 1 "Pass/Fail Threshold table"

**Description:** KaEOSD\_x\_ST\_ResponseLimRS1[x][y]

**Notes:** X axis is Lean to Rich response time (in sec), Please see the table below named "KnEOSD\_t\_ST\_LRC\_LimRS1" for the 17 X axis table breakpoints. Y axis is Rich to Lean response time (sec), Please see the cal table below named "KnEOSD\_t\_ST\_RLC\_LimRS1" for the 17 Y axis table breakpoints. Z axis is the pass/fail result, Note: If the cell contains a "0" then the fault is indicated, if it contains a "1" a fault is not indicated.

I.																	
y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0	0
1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0	0
2	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0	0
3	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
4	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
5	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
6	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
7	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0
8	0	0	0	1	1	1	1	1	1	1	1	0	0	0	0	0	0
9	0	0	0	0	0	1	1	1	1	1	1	0	0	0	0	0	0
10	0	0	0	0	0	0	0	1	1	1	1	0	0	0	0	0	0
11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
12	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
13	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
15	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

				lni	tial Sup	porting	table -	P0153_	KnEOS	D_t_ST	_LRC_L	imRS2					
Descrip	escription: KnEOSD_t_ST_LRC_LimRS2. X Table Axis (in sec) for P0153, L2R Reponse time breakpoints for table																
Notes:																	
y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.050	0.100	0.149	0.159	0.170	0.180	0.189	0.199	0.210	0.220	0.229	0.239	0.250	0.300	0.350	0.399

				lni	tial Sup	porting	table -	P0153_	KnEOS	D_t_ST	_RLC_l	imRS2					
Descri	Description: KnEOSD_t_ST_RLC_LimRS2. Y Table Axis (in sec) for P0153, R2L Reponse time breakpoints for table																
Notes:																	
y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.050	0.100	0.149	0.159	0.170	0.180	0.189	0.199	0.210	0.220	0.229	0.239	0.250	0.300	0.350	0.399

#### Initial Supporting table - P0153\_O2S Slow Response Bank 2 Sensor 1 "Pass/Fail Threshold table"

**Description:** KaEOSD\_x\_ST\_ResponseLimRS2[x][y]

**Notes:** X axis is Lean to Rich response time (in sec), Please see the table below named "KnEOSD\_t\_ST\_LRC\_LimRS2" for the 17 X axis table breakpoints. Y axis is Rich to Lean response time (sec), Please see the cal table below named "KnEOSD\_t\_ST\_RLC\_LimRS2" for the 17 Y axis table breakpoints. Z axis is the pass/fail result, Note: If the cell contains a "0" then the fault is indicated, if it contains a "1" a fault is not indicated.

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	4	4	4	4	7	4	4	4	4	4	4	4	12	10	4	4	10
0	1	1	1	1	1	1	[1	1	1	Т	1	1	1	1	1	1	1
1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
2	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
3	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
4	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
5	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
6	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
7	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
8	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
9	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
10	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
11	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
12	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
13	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
14	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
15	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
16	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1

# Initial Supporting table - P0011\_CamPosErrorLimIc1

Description:	D0011	- Cam	<b>Position</b>	Error	Limit for	nerformance	diadno	etic
Describtion:	PUUTT	- Cam	Position			benormance	e alaand	Stic

Notes: KtPHSD\_phi\_CamPosErrorLimIc1

Notes:	KIPHSD_p	oni_CamPo	sErrorLimi	C1													
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

Initial Supporting table - P0011_P0021_P05CC_P05CD_EngOilPressEnblic
Description: P0011 P0021 P05CC P05CD Delay time before the oil pressure enable flag is set assuming all the oil pressure enable criteria are met
Notes: KtPHSC t EngOilPressEnbllc

	Notes. K	11100_1_1	_ngOm res	SSLIIDIIC														
1	y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
ı	1	120	80	12	4	3	2	2	2	1	1	1	1	1	1	1	2	2

			In	itial Sup	porting	table -	P0011_	P0021_	Initial Supporting table - P0011_P0021_P05CC_P05CD_HiEngSpdHiDsbllc													
Descript	Description: P0011 P0021 P05CC P05CD Intake cam is disabled when engine speed exceeds this value																					
Notes: K	tPHSC_n_	HiEngSpd	HiDsbllc																			
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152					

8,000

8,000

8,000

8,000

8,000

8,000

8,000

8,000

8,000

8,000

8,000

8,000

8,000

8,000

8,000

8,000

8,000

			lni	itial Sup	porting	table -	P0011_	P0021_	P05CC_	P05CD	_HiEng	SpdLoE	inblic				
Descript	escription: P0011 P0021 P05CC P05CD Intake cam is enabled when engine speed remains below this value																
Notes: K	tPHSC_n_	HiEngSpd	LoEnblic														
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800

			I	nitial Sı	upportir	ng table	- P0011	I_P0021	_P05C0	C_P05C	D_LoPı	esHiEn	bllc				
Descript	escription: P0011 P0021 P05CC P05CD Intake cam is enabled when oil pressure exceeds this value																
Notes: K	(tPHSC_p_	_LoPresHiE	EnblEc														
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	150	150	150	150	150	150	150	150	150	150	150	150	150	150	150	150	150

			I	nitial Sເ	upportin	g table	- P0011	_P0021	_P05C0	C_P05C	D_LoPr	esLoDs	bllc				
Descript	escription: P0011 P0021 P05CC P05CD Intake cam is disabled when oil pressure falls below this value																
Notes: K	tPHSC_p_	_LoPresLoI	Osblic														
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100

			ı	nitial Su	upportir	ng table	- P0011	I_P0021	_P05C0	C_P05C	D_LoR <sub>l</sub>	omHiEn	bllc				
Descript	escription: P0011 P0021 P05CC P05CD Intake cam is enabled when engine speed exceeds this value.																
Notes: K	(tPHSC_n_	LoRpmHiE	nbllc														
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	450	450	450	450	450	450	450	450	450	450	450	450	450	450	450	450	450

			I	nitial Su	Initial Supporting table - P0011_P0021_P05CC_P05CD_LoRpmLoDsbllc														
Descript	Description: P0011 P0021 P05CC P05CD Intake cam is disabled when engine speed is below this value.																		
Notes: K	(tPHSC_n_	_LoRpmLo	Dsbllc																
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152		
1	325	325	325	325	325	325	325	325	325	325	325	325	325	325	325	325	325		

	Init	ial Sup	porting	table - F	0011_	P0021_F	P05CC_	P05CD_	P0014	_P0024	_P05CE	_P05CF	_ColdS	tartEng	Runnin	g	
<u> </u>	escription: P0011 P0021 P05CC P05CD P0014 P0024 P05CE P05C Engine running time must be greater than this threshold during a cold start to enable cam phasing otes: KtPHSR_t_ColdStartEngRunning																
Notes: k	(tPHSR_t_	_ColdStar	tEngRunnii	ng													
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	120	80	12	2	2	2	2	2	1	1	1	1	1	1	1	2	2

# Initial Supporting table - P0011\_P05CC\_StablePositionTimeIc1

Description: P0011 P05CC -	Delay after transient move
----------------------------	----------------------------

Notes: KtPHSD\_t\_StablePositionTimeIc1

Notes:	KIPHSD_I	_StablePos	sition I imelo	:1													
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
1,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
1,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
3,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
3,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0

## Initial Supporting table - P0011\_PerfMaxIc1

Description: P0011 - Range of phaser travel where diagnostic cannot make a decision if both desired & measured positions are greater than

#### Notes:

140163.	1																
y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
2	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
3	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
4	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
5	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
6	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
7	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
8	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
9	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
10	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
11	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
12	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
13	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
14	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
15	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
16	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
17	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0

# Initial Supporting table - P0014\_CamPosErrorLimEc1

Description:	D0014 Co	n Docition	Error Limit	t for norforn	aanaa diaa	naatia
Description:	P0014 - Cai	n Position	ı Error Limii	t for berforn	nance diad	nostic

Notes: KtPHSD\_phi\_CamPosErrorLimEc1

110103.	IXII I IOD_	prii_Cariii v	JSLII OI LIIII	LUI													
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

Initial Supporting table - P0014_P0024_P05CE_P05CF_EngOilPressEnblEc	
A POSCE POSCE Delay time before the oil pressure enable flag is set assuming all the oil pressure enable criteria are met	Ξ

Description: P0014 P0024 P05CE P05CF Delay time before the oil pressure enable flag is set assuming all the oil pressure enable criteria are met

**Notes:** KtPHSC\_t\_EngOilPressEnblEc

١	y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
١	1	10	10	10	4	3	2	2	2	1	1	1	1	1	1	1	2	2

Initial Supporting table - P0014_P0024_P05CE_P05CF_HiEngSpdHiDsblEc
Description: P0014 P0024 P05CE P05CF Exhaust cam is disabled when engine speed exceeds this value
Notes: KtPHSC n HiEngSpdHiDsblEc

Notes: KtPHSC_n_HiEngSpdHiD	sblEc
-----------------------------	-------

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000

			In	itial Sup	porting	table -	P0014_	P0024_	P05CE	_P05CF	_HiEng	SpdLoE	nblEc				
Descrip	<b>tion:</b> P001	4 P0024 P	05CE P05	CF Exhaus	t cam is en	abled whe	en engine s	peed rema	ains below	this value							
Notes: k	(tPHSC_n	_HiEngSpo	dLoEnblEc														
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800

Initial Supporting table - P0014_P0024_P05CE_P05CF_LoPresHiEnblEc
Description: P0014 P0024 P05CE P05CF Exhaust cam is enabled when oil pressure exceeds this value

**Notes:** KtPHSC\_p\_LoPresHiEnbllc

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	150	150	150	150	150	150	150	150	150	150	150	150	150	150	150	150	150

				Initial	Suppor	rting tab	le - P00	14_P00	24_P05	CE_P05	CF_Lol	PresLo[	OsbIEc				
Descrip	otion: P0	014 P0024	4 P05CE P	05CF Exh	aust cam i	s disabled	when oil pre	essure falls	below thi	s value							
Notes:	KtPHSC_	_p_LoPres	LoDsblEc														
v/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152

			I	nitial Su	pportin	g table	- P0014	_P0024	_P05CE	_P05C	F_LoRp	mHiEnk	olEc				
Descript	ion: P001	4 P0024 P0	05CE P050	CF Exhaus	t cam is en	abled whe	n engine s	peed exce	eds this va	lue.							
Notes: K	(tPHSC_n_	LoRpmHiE	nblEc														
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	450	450	450	450	450	450	450	450	450	450	450	450	450	450	450	450	450

Initial Supporting table - P0014_P0024_P05CE_P05CF_LoRpmLoDsblEc
P05CE P05CF Exhaust cam is disabled when engine speed is below this value.

Description: P0014 P0024 P0

Notes:	KtPHSC_n_I	LoRpm	LoDsblEc
--------	------------	-------	----------

y/x	-40	-28	-16	-4	8		32	44	56	68	80	92	104	116	128	140	152
1	325	325	325	325	325	325	325	325	325	325	325	325	325	325	325	325	325

# Initial Supporting table - P0014\_P05CE\_StablePositionTimeEc1

	Descript	i <b>on:</b> P0014	1 P05CE -	Delay after	r transient	move										
	Notes: K	tPHSD_t_	StablePosi	tionTimeEd	c1											
ı	v/v	-40	-28	1-16	1_1	Q	20	32	11	56	68	80	02	104	116	129

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
1,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
1,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
3,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
3,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0

## Initial Supporting table - P0014\_PerfMaxEc1

Description: P0014 - Range of phaser travel where diagnostic cannot make a decision if both desired & measured positions are greater than

#### Notes:

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
2	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
3	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
4	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
5	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
6	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
7	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
8	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
9	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
10	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
11	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
12	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
13	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
14	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
15	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
16	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
17	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5

### Initial Supporting table - P0068\_Delta MAF Threshold f(TPS)

**Description:** Table of delta MAF values as a function of desired throttle position. The output of this table provides a delta MAF that if the measured minus the estimated MAF exceeds, is considered a fail.

**Notes:** P0068, KtTPSD\_dm\_MAF\_DesThrDelt

y/x	0.69	5.00	10.00	15.00	20.00	25.00	30.00	40.00	55.00
1.00	10.00	11.43	13.38	14.33	16.32	22.16	28.16	70.00	120.00

### Initial Supporting table - P0068\_Delta MAP Threshold f(TPS)

**Description:** Table of delta MAP values as a function of desired throttle position. The output of this table provides a delta MAP that if the measured minus the estimated MAP exceeds, is considered a fail.

**Notes:** P0068, KtTPSD\_p\_MAP\_DesThrDelt

y/x	0.69	5.00	10.00	15.00	20.00	25.00	30.00	40.00	55.00
1.00	42.00	41.00	39.92	31.00	28.60	28.32	29.14	70.00	110.00

Initial Supporting table - P0068_Maximum MAF f(RPM)
---

**Description:** Table of maximum MAF values vs. engine speed. This is the maximum MAF the engine can see under all ambient conditions.

Notes: P0068, KtTPSD\_dm\_MaxMAF\_VsRPM

y/x	600.00	1,400.00	2,200.00	3,000.00	3,800.00	4,600.00	5,400.00	6,200.00	7,000.00
1.00	255.00	255.00	255.00	255.00	255.00	255.00	255.00	255.00	255.00

	Initial Supporting table - P0068_Maximum MAF f(Volts)											
Description	Description: Table of maximum MAF values vs. system voltage. The output of the air meter is clamped to lower values as system voltage drops off.											
Notes: P00	Notes: P0068, KtTPSD_dm_MaxMAF_VsVoltage											
v/x	6.00	7.00	8.00	9.00	10.00	11.00	12.00	13.00	14.00			

511.99

511.99

511.99

511.99

511.99

511.99

1.00

511.99

511.99

511.99

Initia	Initial Supporting table - P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on MAF Est																
Descript	Description: P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on MAF Est																
Notes:	Notes:																
y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350

Init	Initial Supporting table - P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on RPM																
Descrip	Description: P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on RPM																
Notes:																	
v/x	0	800	1.500	2.500	2.800	3.100	3.200	3.300	3.500	3.700	4.000	4.200	4.500	5.000	5.500	6.500	7.000

lr	Initial Supporting table - P0101_P0106_P010B_P0121_P0236_P1101 MAF2 Residual Weight Factor based on MAF Est																
Descript	Description: P0101_P0106_P010B_P0121_P0236_P1101 MAF2 Residual Weight Factor based on MAF Est																
Notes:	Notes:																
y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350

	Initial Supporting table - P0101_P0106_P010B_P0121_P0236_P1101 MAF2 Residual Weight Factor based on RPM																
Description: P0101_P0106_P010B_P0121_P0236_P1101 MAF2 Residual Weight Factor based on RPM																	
Notes:	Notes:																
y/x	y/x 0 800 1,500 2,500 2,800 3,100 3,200 3,300 3,500 4,000 4,200 4,500 5,000 5,500 6,500 7,000																
1	l1	11	11	1	11	1	1	l1	11	1	1	11	11	1	11	<b>I</b> 1	1

	Initial Supporting table - P0116_Fail if power up ECT exceeds IAT by these values																
Descrip	Description: KtECTD_T_HSC_FastFailTempDiff																
Notes:	Caxis is IA	T Tempera	ature at Po	wer up (° C	), Z axis is	the Fast F	ailure temp	o differenc	e (° C)								
y/x -40 -28 -16 -4 8 20 32 44 56 68 80 92 104 116 128 140 152																	
1	106 94 82 70 60 46 40 30 30 30 30 30 30 37 49 61																

Initi	Initial Supporting table - P0128_Maximum Accumulated Energy for Start-up ECT conditions - Alternate											
Description: KtECTR	Description: KtECTR_E_CTR_WrmUpEnrgyLimTest1											
Notes: Z axis is the co	ooling system energy fail	lure threshold (kJ), X ax	is is ECT Temperature a	at Power up (° C), (Delux	e version)							
y/x -20 -7 10 30 45 59 75												
1 11,800 10,240 8,200 5,800 4,000 2,320 1,120												

Ir	Initial Supporting table - P0128_Maximum Accumulated Energy for Start-up ECT conditions - Primary											
Description: KtECT	Description: KtECTR_E_CTR_WrmUpEnrgyLimTest0											
Notes: Z axis is the	cooling system energy fa	ilure threshold (kJ), X ax	is is ECT Temperature a	at Power up (° C) , (Delu	xe version)							
y/x -20 -7 10 30 45 59 75												
14,000 12,700 11,000 9,000 7,500 6,100 4,500												

Initial Supporting table - Po	171 P0172	P0174	P0175 Long	a-Term Fuel	Trim Cell Usage
				,	

Description: Identifies which	Long Term Fuel Trim Cell I.D.s are used for d	iagnosis. Only cells identified as "CeF	ADD_e_NonSelectedCell" are not use	d for diagnosis.							
Notes: DTCs: P0171, P0172,	P0174, P0175; Calibration Name: KaFADD_	e_SelectCellSet; Axis is Long Term F	uel Trim Cell I.D.								
P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 1											
y/x	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR_e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2							
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell							
P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 2											
y/x	CeFADR_e_Cell04_PurgOnAirMode	CeFADR_e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel							
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_NonSelectedCell							
P0171_P0172_P0174_P0175	Long-Term Fuel Trim Cell Usage - Part 3										
y/x	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR_e_Cell10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2							
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell							
P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 4											
y/x	CeFADR_e_Cell12_PurgOffAirMode	CeFADR_e_Cell13_PurgOffAirMode 0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel							
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_NonSelectedCell							

Initial Supporting table - P0300 EngineOverSpeedLimit													
Description: Engine OverSpeed Limit versus gear													
Notes: Used for	Notes: Used for P0300-P0308. Cal Name: KaEOSC_n_EngOvrspdLimitGear												
P0300 EngineO	P0300 EngineOverSpeedLimit - Part 1												
y/x	CeTGRR_e_TransGr1	CeTGRR_e_TransGr2	CeTGRR_e_TransGr3	CeTGRR_e_TransGr4	CeTGRR_e_TransGr5	CeTGRR_e_TransGr6	CeTGRR_e_TransGrE VT1						
1	6,500	6,500	6,500	6,500	6,500	6,500	6,500						
P0300 EngineO	P0300 EngineOverSpeedLimit - Part 2												
y/x CeTGRR_e_TransGrE CeTGRR_e_TransGrN CeTGRR_e_TransGrR CeTGRR_e_TransGrP CeTGRR_e_TransGr7 CeTGRR_e_TransGr8 VT2													
1	6,500	3,200	3,000	3,200	6,500	6,500							

Initial Supporting table - P0300 Number of Normals									
<b>Description:</b> Number of Normals for the Driveline Ring Filter After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.									
Notes: Used for P0300-P0308. Cal Name: KaMSFD_Cnt_NumOfNormalsFil									
y/x	0	1	2	3	4	5	6	7	8
1	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00

Initial Supporting table - P0300 Ring Filter											
<b>Description:</b> Driveline Ring Filter After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.											
Notes: Used for	P0300-P0308. Cal	Name: KaMSFD_C	nt_RingFilter								
y/x	0	1	2	3	4	5	6	7	8		
1	5.00 5.00 5.00 5.00 5.00 5.00 5.00										

# Initial Supporting table - P0300\_1st\_FireAftrMisfr\_Acel

Description: Multi	Description: Multiplier for establishing the expected acceleration of the cylinder after the misfire											
Notes: Used for P	Notes: Used for P0300 - P0308, Cal Name: KtMSFD_K_dt_CylAftMsfr											
y/x	2,000	2,400	4,500	5,000	6,000							
6	0.36	0.76	0.71	0.63	0.40							
8	0.14	0.75	0.75	0.75	0.44							
10	0.28	0.75	0.75	0.75	0.75							
16	0.18	0.40	0.71	0.71	0.57							
26	0.15	0.20	0.35	0.24	0.48							

# Initial Supporting table - P0300\_1st\_FireAftrMisfr\_Jerk

-1.20

-1.06

16 26 -1.10

-1.50

Description: Multi	Description: Multiplier for establishing the expected Jerk of the cylinder after the misfire										
Notes: Used for P	Notes: Used for P0300 - P0308, Cal Name: KtMSFD_K_ddt_CylAftMsfr										
y/x	2,000	2,400	4,500	5,000	6,000						
6	-0.50	-0.50	-0.50	-0.50	-0.50						
8	-0.50	-0.50	-0.50	-0.50	-0.50						
10	-0.70	-0.91	-1.32	-0.89	-1.07						

-1.50

-1.44

-1.55

-2.00

-1.30

-1.40

Initial Supporting table - P0300_Abnormal Cylinder Mode											
Description: Nu	Description: Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Cylinder Mode Equation)										
Notes: Used for	P0300-P0308. Ca	l Name: KaMSFD_0	Cnt_CylAbnormal								
y/x	//x 0 1 2 3 4 5 6 7 8										
1 3.00 3.00 3.00 4.00 4.00 4.00 4.00 4.00											

Initial Supporting table - P0300_Abnormal Rev Mode											
Description: Abnormal Rev Mode Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Rev Mode Equation)											
Notes: Used for I	P0300-P0308. Ca	l Name: KaMSFD_0	nt_RevAbnormal								
y/x	/x 0 1 2 3 4 5 6 7 8										
1	2.00 2.00 2.00 2.00 2.00 2.00 2.00 2.00										

Initial Supporting table - P0300_Abnormal SCD Mode											
Description: Nur	Description: Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (SCD Mode Equation)										
Notes: Used for I	P0300-P0308. Cal	Name: KaMSFD_C	nt_SCD_CylAbnor	mal							
y/x	/x 0 1 2 3 4 5 6 7 8										
1 2.00 2.00 2.00 2.00 2.00 2.00 2.00 2.0											

## Initial Supporting table - P0300\_Bank\_SCD\_Decel

Description: Mulitplier to SCD decel to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_MEDRES\_Bank

1111 1111 1 1111 1111 1111 1111 1111 1111											
y/x	400	550	700	800	900	1,000	1,200	1,400	1,600		
5	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60		
10	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60		
20	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60		
30	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60		
40	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60		
50	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60		
60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60		
80	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60		
100	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60		

## Initial Supporting table - P0300\_Bank\_SCD\_Jerk

**Description:** Mulitplier to Medres SCD jerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_MEDRES\_Bank

1101001 0000	Notes Cook for Cook, car Name: Name: B_I_aux_INEB/LEG_Saim											
y/x	400	550	700	800	900	1,000	1,200	1,400	1,600			
5	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
10	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
50	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
80	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
100	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			

## Initial Supporting table - P0300\_BankCylModeDecel

**Description:** Mulitplier to Lores Decel to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_LORES\_Bank

1101001 000	Notes: Cood for 1 Cood, Carinamic: Numer B_N_a_ECNEC_Barin											
y/x	1,000	1,100	1,200	1,400	1,900	3,000	3,500	5,000	6,000			
5	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60			
10	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60			
20	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60			
30	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60			
40	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60			
50	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60			
60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60			
80	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60			
100	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60			

# Initial Supporting table - P0300\_BankCylModeJerk

**Description:** Mulitplier to Lores Jerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_LORES\_Bank

1101001 000	News Cook in Food Food Food Family Cook Fa											
y/x	1,000	1,100	1,200	1,400	1,900	3,000	3,500	5,000	6,000			
5	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
10	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
50	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
80	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			
100	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00			

## Initial Supporting table - P0300\_Catalyst\_Damage\_Misfire\_Percentage

**Description:** Catalyst Damaging Misfire Percentage" Table whenever secondary conditions are met.

Notes: Used for P0300-P0308. Cal Name: KtMSFD\_Pct\_CatalystMisfire

140103. 030	Notes. Oscillot 1 0000 1 0000. Out Name: Name: D_1 0_outarysaviising										
y/x	0	1,000	2,000	3,000	4,000	5,000	6,000	7,000			
0	22.5	22.5	22.5	22.5	22.5	12.5	12.5	12.5			
10	22.5	22.5	22.5	22.5	22.5	12.5	12.5	8.0			
20	22.5	22.5	22.5	12.5	12.5	12.5	8.0	6.3			
30	22.5	22.5	22.5	12.5	12.5	8.0	6.3	6.3			
40	22.5	22.5	12.5	12.5	12.5	8.0	5.0	5.0			
50	22.5	22.5	12.5	12.5	8.0	6.3	5.0	5.0			
60	22.5	12.5	12.5	12.5	6.3	5.0	5.0	5.0			
70	12.5	12.5	12.5	8.0	6.3	5.0	5.0	5.0			
80	12.5	12.5	8.0	6.3	6.3	5.0	5.0	5.0			
90	12.5	12.5	8.0	6.3	6.3	5.0	5.0	5.0			
100	12.5	12.5	8.0	6.3	6.3	5.0	5.0	5.0			

## Initial Supporting table - P0300\_ConsecCylModDecel

**Description:** Mulitplier to Lores decel to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_LORES\_Consec

y/x	1,000	1,100	1,200	1,400	1,900	3,000	3,500	5,000	6,000		
2	0.40	0.40	0.40	0.40	0.40	0.40	0.40	0.40	0.40		
6	0.40	0.40	0.40	0.60	0.61	0.41	0.40	0.40	0.40		
8	0.60	0.60	0.60	0.82	0.90	0.62	0.40	0.40	0.40		
12	0.80	0.80	0.80	0.86	0.80	0.84	0.72	0.60	0.40		
14	0.87	0.87	0.87	0.92	0.71	0.82	0.68	0.63	0.40		
16	0.89	0.89	0.89	0.89	0.79	0.85	0.72	0.67	0.40		
20	0.87	0.92	0.92	0.98	0.83	0.76	0.83	0.79	0.56		
26	1.00	0.90	0.96	0.91	0.75	0.79	0.83	0.78	0.62		
40	1.00	0.96	0.97	0.95	0.81	0.83	0.93	0.85	0.72		

## Initial Supporting table - P0300\_ConsecCylModeJerk

**Description:** Mulitplier to Lores Jerk to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_LORES\_Consec

1101001 0000	11011 0000 1 0000	o, carramo: ramo	. B\_aa\Ee\\Ee						
y/x	1,000	1,100	1,200	1,400	1,900	3,000	3,500	5,000	6,000
2	0	0	0	0	0	0	-1	-1	-1
6	0	0	0	0	0	0	-1	-1	-1
8	0	0	0	0	0	0	-1	-1	-1
12	0	0	0	0	0	0	-1	-1	-1
14	0	0	0	0	0	0	-1	-1	-1
16	0	0	0	0	0	0	-1	-1	-1
20	0	0	0	0	0	0	0	-1	-1
26	0	0	0	0	0	0	0	0	-1
40	0	0	0	0	0	0	0	0	0

## Initial Supporting table - P0300\_ConsecSCD\_Decel

**Description:** Mulitplier to medres decel to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_MEDRES\_Consec

y/x	400	550	700	800	900	1,000	1,200	1,400	1,600
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
6	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
14	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
26	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## Initial Supporting table - P0300\_ConsecSCD\_Jerk

**Description:** Mulitplier to medres Jerk to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_MEDRES\_Consec

y/x	400	550	700	800	900	1,000	1,200	1,400	1,600
2	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
6	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
8	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
12	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
14	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
16	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
20	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
26	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

## Initial Supporting table - P0300\_CylAfterAFM\_Jerk

**Description:** Mulitplier to Lores Jerkl to account for different pattern of misfire after a deactivated cylider. Similar to the second cylinder of consecutive cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_LORES\_PostDeac

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
5	0	0	0	0	0	0	0	0	0
10	0	0	0	0	0	0	0	0	0
20	0	0	0	0	0	0	0	0	0
30	0	0	0	0	0	0	0	0	0
40	0	0	0	0	0	0	0	0	0
50	0	0	0	0	0	0	0	0	0
60	0	0	0	0	0	0	0	0	0
80	0	0	0	0	0	0	0	0	0
100	0	0	0	0	0	0	0	0	0

### Initial Supporting table - P0300\_CylBeforeAFM\_Decel

**Description:** Mulitplier to Lores decel to account for different pattern of misfire before a deactivated cylider, but after an active cylinder that follows an deactive cylinder on engine that supports cylinder deactivation in non even fire patterns.. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_LORES\_PreDeac

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
5	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
10	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
50	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
80	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
100	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## Initial Supporting table - P0300\_CylModeDecel

**Description:** Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF\_CylinderMode

					arrian		_ ,	illiueliv						T.	1					1	-1				T.	
y/x								1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
3	6,000	6,000	6,000	2,800	1,800	1,500	800	700	600	400	300	250	160	120	80	75	50	43	25	19	12	10	8	6	6	6
6	6,000	6,000	6,000	2,500	1,800	1,000	800	700	600	400	300	250	160	120	80	75	50	43	25	19	12	10	8	6	6	6
8	7,000	3,358	3,000	1,800	1,300	900	750	540	600	400	300	250	160	120	80	75	50	43	25	19	12	10	8	6	6	6
10	8,000	4,197	3,000	1,800	1,500	983	815	540	600	400	300	250	160	120	80	75	50	43	25	19	12	10	8	6	6	6
12	9,000	5,037	2,996	1,931	1,830	1,292	874	541	600	400	300	250	160	120	80	75	50	43	25	19	12	10	8	6	6	6
14	10,00 0	5,876	3,496	4,066	2,486	1,447	907	631	600	400	300	250	160	120	80	75	50	43	25	19	12	10	8	6	6	6
16	10,00 0	6,715	3,995	4,500	2,591	1,611	1,129	709	600	400	300	250	160	120	80	75	50	43	25	19	12	10	8	7	6	6
18	11,00 0	7,555	4,494	4,451	2,891	1,691	999	751	600	400	300	250	180	120	85	75	50	45	27	19	13	10	9	8	7	7
20	12,00 0	8,394	4,993	3,219	3,654	1,639	1,144	732	681	400	300	250	190	120	94	75	66	50	35	26	16	11	9	8	8	8
22	13,00 0	9,234	5,493	3,541	4,019	1,513	1,201	782	686	441	320	250	200	133	106	89	69	54	37	28	19	12	11	9	9	9
24	14,00 0	10,07 3	5,992	3,862	4,251	1,527	1,280	1,092	797	511	370	253	200	145	119	95	76	61	41	30	22	14	11	10	9	10
26	15,00 0	15,00 0	6,491	4,184	5,266	1,576	1,341	1,055	914	581	375	272	200	148	125	102	77	66	46	31	21	15	13	11	11	11
30	16,00 0	16,00 0	7,490	6,419	7,229	2,427	1,744	1,155	1,057	639	426	307	238	185	158	120	94	81	54	36	27	18	14	14	12	13
40	18,00 0	18,00 0	9,987	6,437	8,730	2,750	2,134	1,454	1,369	818	586	471	336	273	206	164	128	96	72	43	34	22	20	18	18	17
60	18,00 0	18,00 0	16,00 0	9,656	12,00 0	3,928	2,450	2,144	2,055	1,254	887	669	510	404	321	236	179	172	118	76	52	33	26	27	26	26
78	18,00 0	18,00 0	18,00 0	18,00 0	16,00 0	4,959	3,022	2,725	2,661	1,621	1,153	870	669	529	420	313	237	217	150	94	67	44	34	35	34	34
97	18,00 0	18,00 0	18,00 0	18,00 0	18,00 0	6,137	3,676	3,389	3,353	2,041	1,457	1,100	850	673	533	396	297	275	190	119	84	55	42	45	44	44

## Initial Supporting table - P0300\_CylModeJerk

**Description:** Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF\_ddt\_CylinderMode

Notes	s: Used	for P0	300-P0	308. C	al Nam	e: KtM	ISF_dd	t_Cylin	derMod	de																
y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
3				3,200				700	550	350	300	260	160	130		80	60	53	37	24	15	13	9	5	5	5
6	8,000	6,886	4,500	3,200	1,600	1,300	800	700	550	350	300	260	160	130	80	72	60	55	34	22	13	12	9	8	6	6
8	10,00 0	9,182	5,194	3,000	1,600	1,013	560	510	459	350	300	208	160	130	80	70	53	51	31	19	13	11	9	7	6	6
10	12,00 0	11,47 7	6,492	4,010	3,081	1,260	680	595	500	350	300	208	160	130	80	70	52	35	22	19	13	11	9	7	6	6
12	14,00 0	13,77 2	7,791	4,812	3,137	1,506	875	680	550	400	311	274	160	130	80	70	52	34	22	19	13	11	9	7	6	6
14	16,00 0	16,00 0	9,089	5,855	4,214	1,784	1,063	886	557	400	320	237	161	126	91	77	53	41	22	19	13	11	10	6	6	6
16	18,00 0	18,00 0	10,38 7	6,158	4,322	2,198	1,275	1,017	652	450	340	241	177	145	106	96	67	50	23	19	15	11	10	7	5	5
18	20,00 0	20,00 0	11,68 6	6,509	4,654	2,300	1,597	1,077	729	500	360	281	184	166	121	112	77	60	23	18	16	12	11	6	7	7
20	20,00 0	20,00 0	12,98 4	8,021	4,789	2,360	1,676	1,275	767	550	380	304	205	191	128	120	92	64	24	20	17	12	12	8	9	9
22	20,00 0	20,00 0	14,28 2	8,823	5,722	3,160	2,301	1,403	765	600	400	320	224	210	147	133	99	66	35	22	20	14	14	8	9	9
24	20,00 0	20,00 0	15,58 1	9,625	7,204	3,412	2,498	1,510	831	650	430	344	240	216	162	138	107	72	43	26	22	16	15	8	9	9
26	20,00 0	20,00 0	16,87 9	10,42 7	7,405	3,649	2,664	1,615	888	680	470	378	261	234	172	152	117	79	48	28	24	17	16	9	9	9
30	20,00 0	20,00 0	19,47 6	15,44 2	9,749	4,344	2,994	2,190	1,002	750	520	437	301	260	190	172	134	95	54	34	25	18	17	16	10	10
40	20,00 0	20,00 0	18,00 0	16,04 1	10,14 5	6,222	4,195	2,846	1,340	950	700	554	460	369	269	221	172	120	79	52	31	24	20	18	17	17
60	20,00 0	20,00 0	18,00 0	18,00 0	15,56 1	9,315	6,679	4,270	1,994	1,500	1,000	830	679	564	413	380	251	187	135	92	53	37	32	32	27	27
78	20,00 0	20,00 0	18,00 0	18,00 0	18,00 0	12,18 6	8,791	5,569	2,563	1,900	1,400	1,066	891	737	538	484	331	267	176	117	67	47	39	42	35	35
97	20,00 0		18,00 0	18,00 0	18,00 0	l -	11,20 5	7,053	3,214	2,500	1,800	1,336	1,133	933	680	613	416	336	226	151	84	59	49	54	45	45

## Initial Supporting table - P0300\_IdleCyl\_Decel

**Description:** Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMSFD\_dt\_ldleCylinderMode

Notes:	Used for P0300-	P0308. Carr	name: KtiviSF	D_at_laleCylin	deriviode								
y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	12,000	3,000	3,000	2,800	2,300	1,000	900	750	650	400	300	200	143
6	12,000	4,000	3,000	2,800	2,300	1,200	1,000	750	650	400	300	200	143
8	12,000	5,000	4,000	3,000	1,800	1,400	1,100	750	650	400	300	200	143
10	13,200	6,000	5,000	3,400	1,800	1,600	1,200	850	650	400	250	200	143
12	14,400	7,000	6,000	3,600	1,800	1,500	1,300	900	650	400	250	210	156
14	17,300	8,000	7,000	4,000	2,200	1,800	1,400	950	700	450	300	250	180
16	19,200	9,000	8,000	4,500	2,600	1,900	1,500	1,000	710	500	320	280	200
18	20,000	10,000	9,000	5,141	2,800	2,100	1,600	1,050	752	550	360	300	220
20	20,000	12,000	10,000	5,500	3,000	2,300	1,700	1,100	829	600	400	320	230
22	20,000	14,000	12,000	6,000	3,200	2,400	1,800	1,150	860	640	440	340	230
24	20,000	16,000	14,000	7,000	3,400	2,500	1,900	1,200	910	680	480	360	235
26	20,000	18,000	16,000	8,000	4,000	2,600	2,000	1,300	980	720	520	380	245
30	20,000	20,000	18,000	9,000	5,500	2,700	2,100	1,500	1,100	800	580	420	310
40	20,000	20,000	20,000	10,000	8,730	2,800	2,800	2,200	1,600	1,000	900	612	436
60	20,000	20,000	20,000	15,000	13,640	2,900	3,300	2,600	2,055	1,254	1,153	869	663
78	20,000	20,000	20,000	20,000	17,937	3,000	4,000	2,800	2,661	1,621	1,499	1,100	869
97	20,000	20,000	20,000	20,000	18,000	15,000	5,000	3,389	3,353	2,041	1,894	1,200	1,000

## Initial Supporting table - P0300\_IdleCyl\_Jerk

**Description:** Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMSFD\_ddt\_ldleCylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
}	12,000	6,375	4,845	3,188	2,062	1,600	1,300	850	637	450	300	200	140
3	12,000	5,100	3,570	2,423	1,785	1,600	1,300	850	638	450	300	189	140
3	12,000	5,100	3,800	3,500	1,900	1,600	1,300	850	638	450	300	186	140
10	13,200	6,000	5,000	4,000	1,913	1,700	1,300	850	762	510	350	271	160
12	14,400	8,000	6,000	4,500	2,600	2,400	1,753	1,000	950	510	380	295	208
14	17,300	10,000	7,000	5,000	3,000	2,500	1,981	1,500	1,100	658	400	308	210
16	19,200	11,000	8,000	5,500	3,100	2,600	2,042	1,700	1,225	708	450	314	230
18	21,600	13,000	9,000	6,000	3,200	2,800	2,138	1,908	1,303	809	571	365	239
20	25,800	19,200	10,000	6,220	3,300	3,000	2,200	2,000	1,370	890	585	395	266
22	25,800	19,200	11,000	6,500	3,500	3,300	2,300	2,100	1,700	1,006	613	416	291
24	28,800	19,200	12,000	7,000	3,600	3,400	2,500	2,300	1,890	1,100	655	447	312
26	28,800	19,200	13,000	7,500	4,000	3,500	2,618	2,400	2,050	1,150	734	492	340
30	28,800	19,200	14,000	8,000	6,000	4,344	2,994	2,500	2,225	1,200	782	568	392
40	28,800	19,200	19,200	16,041	10,145	6,222	4,195	2,846	2,400	1,218	1,073	720	598
60	30,000	19,200	19,200	19,200	15,561	9,315	6,679	4,270	2,500	1,795	1,656	1,079	883
78	30,000	19,200	19,200	19,200	19,200	12,186	8,791	5,569	2,600	2,307	2,150	1,386	1,159
97	30,000	19,200	19,200	19,200	19,200	15,466	10,000	7,053	3,214	2,893	2,713	1,737	1,473

### Initial Supporting table - P0300\_IdleSCD\_Decel

Description: Crankshaft decel threshold while in SCD mode. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF\_dt\_SCD\_IdleMode

Note: Misfire's Load term is %, but not PID\$04. PID\$04 is not robust to temperature and alititude shifts. (especially decel and jerk thresholds since they track actual air trapped in

cylinder)

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
6	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
3	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
10	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
12	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
14	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
16	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
18	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
20	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
22	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
24	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
26	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
30	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
10	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
60	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
78	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
97	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768

## Initial Supporting table - P0300\_IdleSCD\_Jerk

**Description:** Crankshaft jerk threshold while in SCD mode. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF\_ddt\_SCD\_ldleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
6	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
8	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
10	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
12	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
14	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
16	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
18	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
20	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
22	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
24	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
26	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
30	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
40	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
60	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
78	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
97	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768

## Initial Supporting table - P0300\_Pair\_SCD\_Decel

**Description:** Mulitplier to P0300\_SCD\_Decel to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_MEDRES\_Opp

		*							
y/x	400	550	700	800	900	1,000	1,200	1,400	1,600
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
6	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
14	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
26	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## Initial Supporting table - P0300\_Pair\_SCD\_Jerk

**Description:** Mulitplier to P0300\_SCD\_Jerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_MEDRES\_Opp

	-			•					
y/x	400	550	700	800	900	1,000	1,200	1,400	1,600
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
6	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
14	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
26	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## Initial Supporting table - P0300\_PairCylModeDecel

**Description:** Mulitplier to Cyl Mode Deceleration to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_LORES\_Opp

		-,		= - 1 1					
y/x	1,000	1,100	1,200	1,400	1,900	3,000	3,500	5,000	6,000
2	1.00	1.00	1.00	1.00	0.94	1.00	0.86	0.78	0.75
6	0.90	0.99	0.92	0.83	0.76	0.51	0.96	0.90	0.90
8	0.90	0.94	0.67	0.67	0.56	0.60	0.98	0.90	0.89
12	0.85	0.90	0.60	0.65	0.70	0.79	0.75	0.67	0.60
14	0.80	0.85	0.57	0.70	0.71	0.80	0.63	0.68	0.60
16	0.80	0.80	0.65	0.65	0.70	0.87	0.68	0.67	0.60
20	0.90	0.90	0.68	0.64	0.65	0.86	0.72	0.63	0.63
26	0.90	0.90	0.60	0.60	0.66	0.87	0.71	0.67	0.62
40	0.90	0.90	0.64	0.66	0.59	0.95	0.63	0.66	0.58

## Initial Supporting table - P0300\_PairCylModeJerk

**Description:** Mulitplier to P0300\_CylModeJerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_LORES\_Opp

		-,							
y/x	1,000	1,100	1,200	1,400	1,900	3,000	3,500	5,000	6,000
2	0.80	0.80	0.80	0.80	0.97	0.80	0.80	0.84	0.82
6	0.80	0.80	0.80	0.85	0.92	0.80	0.91	0.80	0.87
8	0.80	0.80	0.80	0.80	0.90	0.80	0.98	0.81	0.86
12	0.85	0.85	0.80	0.83	0.98	0.80	1.20	1.20	0.86
14	0.90	0.90	0.80	0.84	0.99	0.90	1.40	1.20	1.07
16	1.00	1.00	1.03	0.82	1.01	1.05	1.40	1.20	1.13
20	0.85	0.80	0.80	0.80	0.89	1.02	1.40	1.30	1.10
26	1.06	1.06	0.80	0.85	0.86	1.06	1.20	1.40	1.22
40	1.03	1.03	0.85	0.84	0.95	0.97	1.10	1.30	1.02

## Initial Supporting table - P0300\_Random\_SCD\_Decel

**Description:** Mulitplier to SCD\_Decel to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_MEDRES\_Emiss

1101001 000010	. 0000 . 0000, 00	ae. ramer b_r							
y/x	400	550	700	800	900	1,000	1,200	1,400	1,600
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
6	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
14	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
26	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## Initial Supporting table - P0300\_Random\_SCD\_Jerk

**Description:** Mulitplier to Random\_SCD\_Jerk to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_MEDRES\_Emiss

1101001 000010				11100					
y/x	400	550	700	800	900	1,000	1,200	1,400	1,600
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
6	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
14	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
26	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## Initial Supporting table - P0300\_RandomCylModDecel

**Description:** Multiplier to P0300\_CylMode\_Decel. account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308. Cal Name: KtMSFD\_K\_dt\_LORES\_Emiss

1101001 000010		arrame.rawerb_r	(_d(_E01(E0_E11110	<u> </u>					
y/x	1,000	1,100	1,200	1,400	1,900	3,000	3,500	5,000	6,000
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
6	1.10	1.20	1.10	1.00	1.00	1.00	1.00	1.00	1.00
8	1.40	1.40	1.10	1.10	1.00	1.00	1.00	1.00	1.00
12	1.40	1.40	1.60	1.50	1.00	1.20	1.50	1.50	1.00
14	1.30	1.40	1.40	1.60	1.05	1.40	1.50	1.50	1.60
16	1.30	1.40	1.40	1.80	1.10	1.40	1.50	1.50	1.70
20	1.30	1.40	1.40	1.80	1.20	1.40	1.50	1.50	1.80
26	1.30	1.40	1.40	1.40	1.40	1.40	1.30	1.30	1.65
40	1.30	1.40	1.50	1.40	1.40	1.40	1.40	1.40	1.80

## Initial Supporting table - P0300\_RandomCylModJerk

**Description:** Multiplier to P0300\_CylMode\_Jerk to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_LORES\_Emiss

		-,		=					
y/x	1,000	1,100	1,200	1,400	1,900	3,000	3,500	5,000	6,000
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
6	1.00	1.00	1.00	1.00	1.00	1.04	1.00	1.00	1.00
8	1.00	1.00	1.01	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.03	1.00	1.00	1.10	1.00	1.00	1.00
14	1.00	1.00	1.06	1.00	1.10	1.10	1.20	1.20	1.07
16	1.00	1.00	1.05	1.00	1.10	1.10	1.20	1.20	1.20
20	1.00	1.00	1.02	1.00	1.10	1.10	1.20	1.20	1.20
26	1.00	1.00	1.10	1.10	1.10	1.10	1.20	1.20	1.19
40	1.00	1.00	1.10	1.10	1.10	1.10	1.20	1.20	1.15

## Initial Supporting table - P0300\_RandomRevModDecl

**Description:** Mulitplier to P0300\_RevMode\_Decel to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_RevModeEmiss

1101001 00001	011 0000 1 0000	o, carramo ramo	n B_n_nonnedeE.	11100					
y/x	3,000	3,500	4,000	4,500	5,000	5,500	6,000	7,000	8,000
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
6	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
14	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
26	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

### Initial Supporting table - P0300\_RepetSnapDecayAdjst

**Description:** If misfire is present in consecutive engine cycles, this multiplier is applied to the misfire jerk threshold and compared to a crankshaft snap value after the misfire has taken place.. Table lookup as a function of engine rpm.

**Notes:** Used for P0300 - P0308, Cal Name:KtMSFD\_K\_dddt\_PostCylCnscMsfr

Î	y/x	800	1,400	1,600	1,800	2,300	3,600	4,600	5,500	6,000
	1	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## Initial Supporting table - P0300\_RevMode\_Decel

**Description:** Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF RevolutionMode

Notes:	Used for I	20300-P0	308. Cal	Name: Kt	MISF_Re	volutionIV	ioae												
y/x	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
3	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
6	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
8	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
10	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
12	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
14	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
16	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
18	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
20	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
22	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
24	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
26	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
30	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
40	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
60	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
78	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
97	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768

## Initial Supporting table - P0300\_SCD\_Decel

**Description:** Crankshaft decel threshold. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF\_dt\_SCD\_OffIdleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
6	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
8	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
10	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
12	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
14	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
16	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
18	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
20	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
22	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
24	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
26	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
30	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
40	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
60	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
78	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
97	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768

## Initial Supporting table - P0300\_SCD\_Jerk

**Description:** Crankshaft jerk threshold. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

Notes: Used for P0300-P0308. Cal Name: KtMISF\_ddt\_SCD\_OffIdleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
6	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
8	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
10	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
12	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
14	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
16	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
18	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
20	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
22	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
24	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
26	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
30	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
40	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
60	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
78	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768
97	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768	32,768

#### Initial Supporting table - P0300\_SnapDecayAfterMisfire

**Description:** multiplier times the ddt\_jerk value used used to detect misfire at that speed and load to see if size of disturbance has died down as expected of real misfire. Table lookup as a function of engine rpm and trans gear ratio.

Notes: Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dddt\_PostCylAft

y/x	800	1,400	1,600	1,800	2,300	3,600	4,600	5,500	6,000
1	1.00	1.00	1.30	1.00	0.75	0.75	1.00	1.00	1.00
1	0.75	0.75	0.75	0.75	1.00	1.00	0.80	1.00	1.00
1	0.75	0.75	0.75	1.00	0.85	1.20	0.80	1.00	1.00
2	0.75	0.75	0.75	0.75	0.95	1.25	1.05	1.00	1.00
3	1.00	0.90	1.10	0.90	0.75	1.00	0.75	0.75	0.75
4	0.75	0.75	0.75	0.75	0.75	1.00	1.10	1.10	1.10
6	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
6	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
6	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

# Initial Supporting table - P0300\_TOSSRoughRoadThres

**Description:** Only used if Rough Road source = TOSS: dispersion value on Transmission Output Speed Sensor above which rough road is indicated present

**Notes:** Used for P0300-P0308. Cal Name: KtRRDI\_a\_RoughRoadThresh

1101001	0000 101	1 0000 1	0000. Odi	rtaino. rt	bi_a_	rtouginte	aa i iii ooi	'											
y/x	600	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000
100	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
200	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
300	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
400	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
500	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
600	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
700	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
800	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
900	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,000	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,100	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,200	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,300	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0
1,400	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

	Initial Sup	porting table	- P0300	WSSRoughRoadThres
--	-------------	---------------	---------	-------------------

**Description:** Only used if Wheel speed from ABS is used. If difference between wheel speed readings is larger than this limit, rough road is present

Notes: Used for P0300-P0308. Cal Name: KtRRDI\_a\_WhlSpdRoughRoadLim

1	y/x	0	12	24	36	48		72	85	97	109	121	133	145	157	169	181	193
ı	1	0.55	0.58	0.61	0.64	0.67	0.70	0.73	0.76	0.79	0.80	0.80	0.80	0.80	0.80	0.80	0.80	0.80

			Initial Suppo	orting table - I	P0300_ZeroTo	orqBaro								
Description: adjusts zero torque for altitude														
Notes: Used for I	P0300-P0308. Cal	Name: KtMSFD_K_	_ZeroTorqBaro											
y/x	65	70	75	80	85	90	95	100	105					
1	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00					

# Initial Supporting table - P0300\_ZeroTorqueEngLoad

**Description:** %air load that represents Zero Brake torque along the Neutral rev line. The Zero torque threshold is adjusted for Baro via P0300\_ZeroTorqueBaro

**Notes:** Used for P0300-P0308. Cal Name: KtMISF\_ZeroTorqSpd

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
1	-3.50	-3.50	-4.00	-3.30	-3.50	-3.50	-3.20	-3.00	-3.00	-3.00	-3.00	-1.50	-1.00	0.00	0.60	0.60	0.60	0.60	2.20	3.80	5.39	6.99	8.59	10.18	11.78	13.38

#### Initial Supporting table - P0324\_P0326\_P0331\_AbnormalNoise\_CylsEnabled

**Description:** Specifies which cylinders will be used for the Abnormal Noise portion of the performance diagnostics (1 = cylinder used, 0 = cylinder not used)

Notes: Used for P0324, P0326 and P0331. Cal name: KaKNKD\_b\_PerfAbnIncludeCyl. x-axis = Cylinder number in firing order (i.e. Cyl 0 = first cylinder in firing order, Cyl 1 = second cylinder in firing order....)

A cal value = 1 specifies the cylinder is used for the Abnormal Noise diagnostic. A cal value = 0 specifies the cylinder is not used. Only the first four values in the table are relavent for a four-cylinder engine and only the first six values in the table are relavent for a six-cylinder engine.

Typically, all cylinders are used. Cylinders are only excluded if the signal from that cylinder is weak and there is no separation between normal and faulted conditions (can occur if the sensor location results in poor signal-to-noise ratio for a given cylinder).

y/x	0	1	2	3	4	5	6	7
1	1	1	1	1	0	0	0	0

# Initial Supporting table - P0324\_P0326\_P0331\_AbnormalNoise\_Threshold

**Description:** Fail threshold for the Knock Performance Abnormal Noise Diagnostic

Notes: Used for P0324, P0326 and P0331. Cal Name: KtKNKD\_k\_PerfAbnLimitLo. X-axis = Engine Speed (RPM). Diagnostic fails when VaKNKD\_k\_PerfCylAbnFiltIntnsity <

KtKNKD\_k\_PerfAbnLimitLo

	1			· ·				,									
y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.096	0.096	0.096	0.105	0.102	0.104	0.106	0.099	0.100	0.110	0.102	0.103	0.108	0.108	0.108	0.108	0.108

#### Initial Supporting table - P0325\_P0330\_OpenCktThrshMax (20 kHz)

**Description:** Knock Open Circuit Diagnostic Maximum Threshold when using the 20 kHz method (see "OpenMethod" description)

Notes: Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenMax20K. x-axis = Engine Speed (RPM).

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax: i.e.: KtKNKD\_k\_OpenMin20K < VaKNKD\_k\_OpenFiltIntensity < KtKNKD\_k\_OpenMax20K.

y/x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	12.7090	12.5703	12.1387	10.9180	9.2031	7.8477	7.0371	5.3203	5.5234	5.7676	5.5273	5.9727	5.9844	5.9844	5.9844	5.9844	5.9844

#### Initial Supporting table - P0325\_P0330\_OpenCktThrshMax (Normal Noise)

**Description:** Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

**Notes:** Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenMaxNN. x-axis = Engine Speed (RPM)

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:

i.e.: KtKNKD\_k\_OpenMinNN < VaKNKD\_k\_OpenFiltIntensity < KtKNKD\_k\_OpenMaxNN.

y/x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.3848	0.3848	0.3848	0.3848	0.3848	0.3848	0.3496	0.4102	0.3496	0.4609	0.5195	0.5703	0.5996	0.5996	0.5996	0.5996	0.5996

#### Initial Supporting table - P0325\_P0330\_OpenCktThrshMin (20 kHz)

Description: Knock Open Circuit Diagnostic Minimum Threshold when using the 20 kHz method (see "OpenMethod" description)

Notes: Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenMin20K. x-axis = Engine Speed (RPM)

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax: i.e.: KtKNKD\_k\_OpenMin20K < VaKNKD\_k\_OpenFiltIntensity < KtKNKD\_k\_OpenMax20K.

	y/x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
١	1	4.8359	4.7031	4.6406	4.1250	3.5352	2.9746	2.6738	2.0215	2.0684	2.2266	2.1992	2.4473	2.5117	2.5117	2.5117	2.5117	2.5117

#### Initial Supporting table - P0325\_P0330\_OpenCktThrshMin (Normal Noise)

**Description:** Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

**Notes:** Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenMinNN. x-axis = Engine Speed (RPM)

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:

i.e.: KtKNKD\_k\_OpenMinNN < VaKNKD\_k\_OpenFiltIntensity < KtKNKD\_k\_OpenMaxNN.

ì	//x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
	1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000

		Initia	al Suppo	rting tal	ole - PO	)442: Vo	olatility '	Time as	a Fund	tion of	Estimat	e of Am	bient To	emperat	ure		
Descrip	Description: Data is Volatility Time (in seconds) and Axis is Estimated Ambient Coolant in Deg C																
Notes:	Notes: KtEONV_t_VolatilityTimeMax																
y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	30	30	30	30	40	50	70	90	170	170	170	170	170	170	170	170	170

Supporting table - P0442: Engine Off Time Before Vehicle Off Maximum as a Function of Estimated Ambient Temperature Table

Description: Data is Engine Off Time Before Vehicle Off Maximum Table (in seconds) and Axis is Estimated Ambient Coolant in Deg C

**Notes:** KtEONV\_t\_EngOffTimeBefVehOffMax

y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	44	44	44	44	68	82	105	153	320	480	480	480	480	480	480	480	480

# Initial Supporting table - P0442: EONV Pressure Threshold (Pascals) Table

**Description:** Data is EONV Pressure Threshold in Pascals, X axis (horizontal) is fuel level in % from 0 to 100 with step size 6.25, and Y axis (vertical) is temperature in deg C from -10 to 80 with step size 5.625

Notes: KtEONV\_p\_PressureThreshold

110100	. 1((LO111_p		Timoonoid														
y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
2	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
3	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
4	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
5	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
6	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
7	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
8	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
9	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
10	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
11	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
12	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
13	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
14	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
15	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
16	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3
17	-448.3	-448.3	-448.3	-423.5	-398.4	-373.6	-348.8	-323.8	-299.0	-273.9	-249.1	-224.3	-224.3	-224.3	-224.3	-224.3	-224.3

			Initi	al Suppo	orting t	able - P	0461, P	2066, P	2636: 1	ransfer	Pump	Enable <sup>*</sup>	Time Ta	ble			
Descri	i <b>ption:</b> Da	ita is Trans	ferPumpOr	TimeLimit (i	n second	s) and Axis	s is Fuel Le	vel in %									
Notes	es: KtFLVC_t_XferFuelPmpOnTmLim																
P0461	, P2066, F	2636: Tra	nsfer Pum	p Enable Ti	me Table	- Part 1											
y/x	0	3	6	9	13	16	19	22	25	28	31	34	38	41	44	47	50
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
P0461	, P2066, F	2636: Tra	nsfer Pum	p Enable Ti	me Table	- Part 2											
/x	53	56	59	63	66	69	72	75	78	81	84	88	91	94	97	100	
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

		as a Function of Fuel Level Table

**Description:** Data is Purge Valve Leak Test Engine Vacuum Test Time (in seconds) and Axis is Fuel Level in %

**Notes:** KtEVPD\_t\_PVLT\_EngineVacTimeCold

y/x	0	6	12	19	25	31	37	44	50	56	62	69	75	81	87	94	100
1	100	100	80	75	70	65	60	60	60	60	60	55	50	45	40	30	30

	Initial Supporting	table - P0606_Last Seed <sup>-</sup>	Timeout f(Loop Time)											
<b>Description:</b> The max ti	Description: The max time for the Last Seed Timeout as a function of operating loop time sequence.													
Notes: P0606, KaPISD_	t_LastSeedTimeout[x]													
y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C										
1	0.175	0.175	0.175	409.594										

In	nitial Supporting table - P06	06_Program Sequence Wa	tch Enable f(Loop Time)									
Description: The enabling flags for the program sequence watch as a function of operating loop time sequence.												
Notes: P0606, KaPISD_b_ProgSeq	WatchEnbl											
y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C								
1	1	1	1	1								

	Initial Supporting table - P0606_PSW Sequence Fail f(Loop Time)														
Description: Fail threshold for PSW per operating loop.															
Notes: P0606, KaPISD_C	Notes: P0606, KaPISD_Cnt_SequenceFail[x]														
y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C											
1	3	3	3	3											

	Initial Supporting tabl	e - P0606_PSW Sequence	Sample f(Loop Time)											
Description: Sample threshold for PSW per operating loop.														
Notes: P0606, KaPISD_Cnt_Sequ	Notes: P0606, KaPISD_Cnt_SequenceSmpl[x]													
y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C										
1	4	4	4	4										

#### Initial Supporting table - P06B6\_P06B7\_OpenTestCktThrshMax

**Description:** Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

**Notes:** Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenTestCktMax. x-axis = Engine Speed (RPM).

Diagnostic fails when the filtered diagnostic output is between the OpenTestCktThrshMin and OpenTestCktThrshMax:

i.e. KtKNKD\_k\_OpenTestCktMin < VaKNKD\_k\_OpenTestCktIntFilter < KtKNKD\_k\_OpenTestCktMax

ĺ	y/x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
	1	0.166	0.166	0.176	0.191	0.176	0.207	0.238	0.330	0.385	0.467	0.543	0.666	0.666	0.666	0.666	0.666	0.666

#### Initial Supporting table - P06B6\_P06B7\_OpenTestCktThrshMin

**Description:** Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

**Notes:** Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenTestCktMin. x-axis = Engine Speed (RPM).

Diagnostic fails when the filtered diagnostic output is between the OpenTestCktThrshMin and OpenTestCktThrshMax:

i.e. KtKNKD\_k\_OpenTestCktMin < VaKNKD\_k\_OpenTestCktIntFilter < KtKNKD\_k\_OpenTestCktMax

y/x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.061	0.061	0.068	0.080	0.076	0.098	0.119	0.172	0.193	0.240	0.285	0.357	0.357	0.357	0.357	0.357	0.357

	Initial Supporting table - P16F3_Delta MAP Threshold f(Desired Engine Torque)													
Description: Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.														
Notes: P16F3, KtMAPI	Notes: P16F3, KtMAPI_p_ES_TB_MAP_DeltaThresh													
y/x	0.00	50.00	100.00	150.00	200.00	300.00								
1.00	28.32	28.32	28.32	28.32	28.32	28.32								

# Initial Supporting table - P16F3\_Delta Spark Threshold f(RPM,APC)

**Description:** Threshold for determining when the difference between commanded spark and applied spark exceeds the torque security requirement. It is a function of engine rpm and APC.

Notes: P16F3, KtSPRK\_phi\_DeltTorqueScrtyAdv

Į.																	
y/x	500.00	980.74	1,461.48	1,942.23	2,422.97	2,903.71	3,384.45	3,865.20	4,345.94	4,826.68	5,307.42	5,788.16	6,268.91	6,749.65	7,230.39	7,711.13	8,191.88
80.00	125.00	56.16	58.11	65.22	58.42	58.86	58.45	57.05	54.48	52.34	50.31	49.11	48.48	48.31	48.31	48.31	48.31
160.00	125.00	46.83	44.22	48.91	42.00	41.45	41.78	41.31	38.81	36.94	34.67	33.08	32.22	31.97	31.97	31.97	31.97
240.00	125.00	37.77	34.47	37.14	32.48	31.28	31.30	31.09	29.83	28.55	26.45	24.94	24.13	23.89	23.89	23.89	23.89
320.00	125.00	30.72	27.81	29.89	25.98	24.67	24.83	24.81	23.66	23.00	21.38	20.02	19.28	19.08	19.08	19.08	19.08
400.00	125.00	25.88	23.30	25.00	21.52	20.34	20.56	20.64	19.56	18.95	17.77	16.72	16.06	15.88	15.88	15.88	15.88
480.00	125.00	22.36	20.05	21.48	18.36	17.31	17.55	17.64	16.66	16.13	15.39	15.00	15.00	15.00	15.00	15.00	15.00
560.00	125.00	20.50	18.34	19.66	16.72	15.73	15.95	16.06	15.25	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
640.00	125.00	20.50	18.34	19.66	16.72	15.73	15.95	16.06	15.25	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
720.00	125.00	20.50	18.34	19.66	16.72	15.73	15.95	16.06	15.25	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
800.00	125.00	20.50	18.34	19.66	16.72	15.73	15.95	16.06	15.25	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
880.00	125.00	20.50	18.34	19.66	16.72	15.73	15.95	16.06	15.25	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
960.00	125.00	20.50	18.34	19.66	16.72	15.73	15.95	16.06	15.25	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
1,040.00	125.00	20.50	18.34	19.66	16.72	15.73	15.95	16.06	15.25	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
1,120.00	125.00	20.50	18.34	19.66	16.72	15.73	15.95	16.06	15.25	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
1,200.00	125.00	20.50	18.34	19.66	16.72	15.73	15.95	16.06	15.25	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
1,280.00	125.00	20.50	18.34	19.66	16.72	15.73	15.95	16.06	15.25	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
1,360.00	125.00	20.50	18.34	19.66	16.72	15.73	15.95	16.06	15.25	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00

# Initial Supporting table - P16F3\_Speed Control External Load f(Oil Temp, RPM)

**Description:** Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

Notes: P16F3, KtSPDC\_M\_ExternalLoad

· ·	AC CO	00.00	40.00	0.00	50.00	Jon 00
y/x	-40.00	-20.00	-10.00	0.00	50.00	90.00
350.00	4,096.00	4,096.00	4,096.00	4,096.00	4,096.00	4,096.00
450.00	1,412.00	1,412.00	1,412.00	1,412.00	1,412.00	1,412.00
550.00	150.00	150.00	150.00	150.00	150.00	150.00
650.00	150.00	150.00	150.00	150.00	150.00	150.00
670.00	150.00	150.00	150.00	150.00	150.00	150.00
770.00	150.00	150.00	150.00	150.00	150.00	150.00
900.00	150.00	150.00	150.00	150.00	150.00	150.00
1,100.00	150.00	150.00	150.00	150.00	150.00	150.00
1,300.00	150.00	150.00	150.00	150.00	150.00	150.00
1,500.00	150.00	150.00	150.00	150.00	150.00	150.00
1,600.00	150.00	150.00	150.00	150.00	150.00	150.00
1,850.00	150.00	150.00	150.00	150.00	150.00	150.00
2,100.00	150.00	150.00	150.00	150.00	150.00	150.00
3,100.00	150.00	150.00	150.00	150.00	150.00	150.00
4,100.00	150.00	150.00	150.00	150.00	150.00	150.00
6,100.00	150.00	150.00	150.00	150.00	150.00	150.00
6,400.00	150.00	150.00	150.00	150.00	150.00	150.00

# Initial Supporting table - P219A Normalizer Bank1 Table

**Description:** Bank 1 Normalizer table used in the calculation of the Ratio for the current sample period.

Notes: DTCs: P219A; Calibration Name: KtFABD\_U\_Normalizer1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,200	4,000	4,500	5,000	6,000
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
80	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
120	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
160	9,999.00	9,999.00	9,999.00	9,999.00	4.00	4.00	3.50	5.50	7.50	7.75	5.50	7.50	7.50	9,999.00	9,999.00	9,999.00	9,999.00
200	9,999.00	9,999.00	9,999.00	9,999.00	4.00	4.00	3.50	5.50	7.50	7.75	5.50	7.50	7.50	9,999.00	9,999.00	9,999.00	9,999.00
240	9,999.00	9,999.00	9,999.00	21.25	15.75	10.25	8.00	8.75	5.00	9.50	5.00	7.75	7.75	9,999.00	9,999.00	9,999.00	9,999.00
280	9,999.00	9,999.00	9,999.00	21.25	21.25	13.75	11.00	16.00	9.75	11.75	9.25	12.75	12.75	9,999.00	9,999.00	9,999.00	9,999.00
320	9,999.00	9,999.00	9,999.00	11.75	11.75	17.50	15.50	17.00	14.00	10.50	15.00	15.75	15.75	9,999.00	9,999.00	9,999.00	9,999.00
360	9,999.00	9,999.00	9,999.00	13.25	13.25	11.50	26.50	18.50	17.75	15.00	14.00	24.75	24.75	9,999.00	9,999.00	9,999.00	9,999.00
400	9,999.00	9,999.00	9,999.00	20.50	20.50	20.25	24.00	25.00	27.50	17.50	19.25	22.50	22.50	9,999.00	9,999.00	9,999.00	9,999.00
440	9,999.00	9,999.00	9,999.00	20.50	20.50	37.00	53.50	38.50	47.00	54.50	40.25	35.75	35.75	9,999.00	9,999.00	9,999.00	9,999.00
480	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	53.50	53.50	38.50	47.00	54.50	40.25	35.75	35.75	9,999.00	9,999.00	9,999.00	9,999.00
520	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
560	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
640	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
800	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00

#### Initial Supporting table - P219A Quality Factor Bank1 Table

Description: Bank 1 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

Notes: DTCs: P219A; Calibration Name: KtFABD\_K\_QualFactor1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,200	4,000	4,500	5,000	6,000
40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
80	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
120	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
160	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
200	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
240	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
280	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
320	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
360	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
400	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
440	0.00	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
480	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
520	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
560	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
640	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
720	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
800	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

# Initial Supporting table - P219A Variance Threshold Bank1 Table

Description: Bank 1 lookup table of Variance metric used to calculate the Ratio for the current sample period

Notes: DTCs: P219A; Calibration Name: KtFABD\_U\_VarThresh1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,200	4,000	4,500	5,000	6,000
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
80	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
120	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
160	9,999.00	9,999.00	9,999.00	9,999.00	7.75	7.75	7.25	6.75	5.75	6.00	6.00	3.25	3.25	9,999.00	9,999.00	9,999.00	9,999.00
200	9,999.00	9,999.00	9,999.00	9,999.00	7.75	7.75	7.25	6.75	5.75	6.00	6.00	3.25	3.25	9,999.00	9,999.00	9,999.00	9,999.00
240	9,999.00	9,999.00	9,999.00	10.50	10.50	10.50	8.25	7.00	9.00	5.50	6.25	5.75	5.75	9,999.00	9,999.00	9,999.00	9,999.00
280	9,999.00	9,999.00	9,999.00	10.50	10.50	9.00	11.00	7.50	9.00	5.00	6.00	4.50	4.50	9,999.00	9,999.00	9,999.00	9,999.00
320	9,999.00	9,999.00	9,999.00	16.50	16.50	10.75	11.75	9.00	9.25	8.50	6.75	5.75	5.75	9,999.00	9,999.00	9,999.00	9,999.00
360	9,999.00	9,999.00	9,999.00	15.50	15.50	15.00	10.50	8.75	11.50	9.50	9.00	6.00	6.00	9,999.00	9,999.00	9,999.00	9,999.00
400	9,999.00	9,999.00	9,999.00	15.00	15.00	13.25	12.50	10.50	12.00	15.75	9.75	12.25	12.25	9,999.00	9,999.00	9,999.00	9,999.00
440	9,999.00	9,999.00	9,999.00	15.00	15.00	12.25	11.25	12.25	15.00	10.50	7.50	10.00	10.00	9,999.00	9,999.00	9,999.00	9,999.00
480	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	11.25	11.25	12.25	15.00	10.50	7.50	10.00	10.00	9,999.00	9,999.00	9,999.00	9,999.00
520	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
560	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
640	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
800	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00

# Initial Supporting table - P0011\_CamPosErrorLimIc1

Description:	D0011	- Cam	Position	Error	Limit for	nerformanc	a diagnostic
Describtion:	PUUTT	- Cam	Position		Limit for	periormanc	e diadnostic

Notes: KtPHSD\_phi\_CamPosErrorLimIc1

Notes:	תנפחטט_	pni_CamP	oserrorlim	IC I													
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

Initial Supporting table - P0011_P0021_P05CC_P05CD_EngOilPressEnblic
Description: P0011 P0021 P05CC P05CD Delay time before the oil pressure enable flag is set assuming all the oil pressure enable criteria are met

**Notes:** KtPHSC\_t\_EngOilPressEnblIc

У	//x	-40	-28	-16	-4	8		32	44	56	68	80	92	104	116	128	140	152
1		120	80	12	4	3	2	2	2	1	1	1	1	1	1	1	2	2

Initial Supporting table - P0011_P0021_P05CC_P05CD_HiEngSpdHiDsbllc
Description: P0011 P0021 P05CC P05CD Intake cam is disabled when engine speed exceeds this value
Notes: KtPHSC_n_HiEngSpdHiDsbllc

Notes. R	1100_11_	riiLiigopa	IIDSbiic														
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000

	Initial Supporting table - P0011_P0021_P05CC_P05CD_HiEngSpdLoEnbllc																
Descrip	Description: P0011 P0021 P05CC P05CD Intake cam is enabled when engine speed remains below this value																
Notes:	Notes: KtPHSC_n_HiEngSpdLoEnblIc																
v/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152

7,800

7,800

7,800

7,800

7,800

7,800

7,800

7,800

7,800

7,800

7,800

7,800

7,800

7,800

7,800

7,800

7,800

			I	nitial Sı	upportir	ng table	- P0011	_P0021	_P05C0	C_P05C	D_LoPı	esHiEn	bllc				
Descript	Description: P0011 P0021 P05CC P05CD - Intake cam is enabled when oil pressure exceeds this value																
Notes: K	Notes: KtPHSC_p_LoPresHiEnblEc																
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	150	150	150	150	150	150	150	150	150	150	150	150	150	150	150	150	150

			I	nitial Su	upportin	ig table	- P0011	_P0021	_P05C0	C_P05C	D_LoPr	esLoDs	bllc				
Descript	Description: P0011 P0021 P05CC P05CD Intake cam is disabled when oil pressure falls below this value																
Notes: K	Notes: KtPHSC_p_LoPresLoDsbllc																
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100

	Initial Supporting table - P0011_P0021_P05CC_P05CD_LoRpmHiEnbllc																
Descrip	Description: P0011 P0021 P05CC P05CD Intake cam is enabled when engine speed exceeds this value.																
Notes:	Notes: KtPHSC_n_LoRpmHiEnblIc																
v/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152

Initial Supporting table - P0011_P0021_P05CC_P05CD_LoRpmLoDsbllc											
Description: P0011 P0021 P05CC P05CD Intake cam is disabled when engine speed is below this value.											
Netro: I/ADLICC o La David a Dabila											

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	325	325	325	325	325	325	325	325	325	325	325	325	325	325	325	325	325

#### Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_P0014\_P0024\_P05CE\_P05CF\_ColdStartEngRunning Description: P0011 P0021 P05CC P05CD P0014 P0024 P05CE P05C Engine running time must be greater than this threshold during a cold start to enable cam phasing **Notes:** KtPHSR\_t\_ColdStartEngRunning -28 -16 -40 y/x

# Initial Supporting table - P0011\_P05CC\_StablePositionTimeIc1

Notes: KtPHSD t StablePositionTimeIc1

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
100	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
300	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
1,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
1,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
3,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
3,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0

# Initial Supporting table - P0011\_PerfMaxIc1

Description: P0011 - Range of phaser travel where diagnostic cannot make a decision if both desired & measured positions are greater than

#### Notes:

110100	•																
y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
2	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
3	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
4	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
5	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
6	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
7	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
8	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
9	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
10	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
11	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
12	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
13	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
14	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
15	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
16	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0
17	20.0	20.0	20.0	22.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0	24.0

# Initial Supporting table - P0014\_CamPosErrorLimEc1

Description:	D0014 Co	m Docition D	Error Limit fo	ar narfarmanaa	diagnostic

Notes: KtPHSD\_phi\_CamPosErrorLimEc1

140163.	IXII 110D_	prii_Carrie	OSETTOTEIT														
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,200	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,600	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,000	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,400	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,800	10.0	10.0	10.0	8.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

# Initial Supporting table - P0014\_P0024\_P05CE\_P05CF\_EngOilPressEnblEc

Description: P0014 P0024 P05CE P05CF Delay time before the oil pressure enable flag is set assuming all the oil pressure enable criteria are met

**Notes:** KtPHSC\_t\_EngOilPressEnblEc

١	y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
١	1	10	10	10	4	3	2	2	2	1	1	1	1	1	1	1	2	2

Initial Supporting table - P0014_P0024_P05CE_P05CF_HiEngSpdHiDsblEc

Description: P0014 P0024 P05CE P05CF Exhaust cam is disabled when engine speed exceeds this value

Notes: KtPHSC\_n\_HiEngSpdHiDsblEc

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000

			In	itial Sup	porting	table -	P0014_	P0024_	P05CE_	P05CF	_HiEng	SpdLoE	nblEc				
Descrip	Description: P0014 P0024 P05CE P05CF Exhaust cam is enabled when engine speed remains below this value																
Notes: k	KtPHSC_n	_HiEngSpo	dLoEnblEc														
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800

Initial Supporting table - P0014_P0024_P05CE_P05CF_LoPresHiEnblEc
Description: P0014 P0024 P05CE P05CF Exhaust cam is enabled when oil pressure exceeds this value

**Notes:** KtPHSC\_p\_LoPresHiEnblIc

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	150	150	150	150	150	150	150	150	150	150	150	150	150	150	150	150	150

			lı	nitial Su	pportin	g table	- P0014	_P0024	_P05CE	_P05Cl	F_LoPro	esLoDsl	olEc				
Descript	Description: P0014 P0024 P05CE P05CF Exhaust cam is disabled when oil pressure falls below this value																
Notes: K	(tPHSC_p_	_LoPresLo[	OsbIEc														
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100

Initial Supporting table - P0014_P0024_P05CE_P05CF_LoRpmHiEnblEc

**Description:** P0014 P0024 P05CE P05CF Exhaust cam is enabled when engine speed exceeds this value.

**Notes:** KtPHSC\_n\_LoRpmHiEnblEc

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	450	450	450	450	450	450	450	450	450	450	450	450	450	450	450	450	450

Initial Supporting table - P0014_P0024_P05CE_P05CF_LoRpmLoDsblEc
Description: P0014 P0024 P05CE P05CF Exhaust cam is disabled when engine speed is below this value.
Notes: KtPHSC_n_LoRpmLoDsblEc

110100.10		LOTOPITIEOE	JODI LO														
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	325	325	325	325	325	325	325	325	325	325	325	325	325	325	325	325	325

# Initial Supporting table - P0014\_P05CE\_StablePositionTimeEc1

Notes: KtPHSD\_t\_StablePositionTimeEc1

,	1.0		1.40	1 4	lo.	loo	loo.	144	leo.	loo.	laa	laa	1404	440	1.00	14.40	450
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
1,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
1,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
2,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
3,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
3,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
4,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,200	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,600	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
6,000	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,400	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0
5,800	100.0	80.0	20.0	12.0	9.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	5.0	5.0	8.0

# Initial Supporting table - P0014\_PerfMaxEc1

Description: P0014 - Range of phaser travel where diagnostic cannot make a decision if both desired & measured positions are greater than

#### Notes:

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
2	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
3	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
,	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
3	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
,	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
)	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
0	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
1	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
2	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
3	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
4	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
5	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
6	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5
17	12.5	12.5	12.5	14.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5	16.5

# Initial Supporting table - P0171\_P0172\_P0174\_P0175 Long-Ter Fuel Tri Cell Usage Description: Identifies which Long Term Fuel Trim Cell I.D.s are used for diagnosis. Only cells identified as "CeFADD\_e\_NonSelectedCell" are not used for diagnosis. Notes: DTCs: P0171, P0172, P0174, P0175; Calibration Name: KaFADD\_e\_SelectCellSet; Axis is Long Term Fuel Trim Cell I.D.

<b>Description:</b> Identifies which being ferring der film de											
Notes: DTCs: P0171, P0172, P0174	, P0175; Calibration Name: KaFADD_	_e_SelectCellSet; Axis is Long Term F	uel Trim Cell I.D.								
P0171_P0172_P0174_P0175 Long-	Ter Fuel Tri Cell Usage - Part 1										
y/x	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR_e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2							
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell							
P0171_P0172_P0174_P0175 Long-Ter Fuel Tri Cell Usage - Part 2											
y/x	CeFADR_e_Cell04_PurgOnAirMode 1	CeFADR_e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel							
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_NonSelectedCell							
P0171_P0172_P0174_P0175 Long-	Ter Fuel Tri Cell Usage - Part 3										
y/x	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR_e_Cell10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2							
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell							
P0171_P0172_P0174_P0175 Long-Ter Fuel Tri Cell Usage - Part 4											
y/x	CeFADR_e_Cell12_PurgOffAirMode 1	CeFADR_e_Cell13_PurgOffAirMode 0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel							
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_NonSelectedCell							

### Initial Supporting table - P219A Normalizer Bank1 Table

**Description:** Bank 1 Normalizer table used in the calculation of the Ratio for the current sample period.

Notes: DTCs: P219A; Calibration Name: KtFABD\_U\_Normalizer1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,200	4,000	4,500	5,000	6,000
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
80	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
120	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
160	9,999.00	9,999.00	9,999.00	9,999.00	4.00	4.00	3.50	5.50	7.50	7.75	5.50	7.50	7.50	9,999.00	9,999.00	9,999.00	9,999.00
200	9,999.00	9,999.00	9,999.00	9,999.00	4.00	4.00	3.50	5.50	7.50	7.75	5.50	7.50	7.50	9,999.00	9,999.00	9,999.00	9,999.00
240	9,999.00	9,999.00	9,999.00	21.25	15.75	10.25	8.00	8.75	5.00	9.50	5.00	7.75	7.75	9,999.00	9,999.00	9,999.00	9,999.00
280	9,999.00	9,999.00	9,999.00	21.25	21.25	13.75	11.00	16.00	9.75	11.75	9.25	12.75	12.75	9,999.00	9,999.00	9,999.00	9,999.00
320	9,999.00	9,999.00	9,999.00	11.75	11.75	17.50	15.50	17.00	14.00	10.50	15.00	15.75	15.75	9,999.00	9,999.00	9,999.00	9,999.00
360	9,999.00	9,999.00	9,999.00	13.25	13.25	11.50	26.50	18.50	17.75	15.00	14.00	24.75	24.75	9,999.00	9,999.00	9,999.00	9,999.00
400	9,999.00	9,999.00	9,999.00	20.50	20.50	20.25	24.00	25.00	27.50	17.50	19.25	22.50	22.50	9,999.00	9,999.00	9,999.00	9,999.00
440	9,999.00	9,999.00	9,999.00	20.50	20.50	37.00	53.50	38.50	47.00	54.50	40.25	35.75	35.75	9,999.00	9,999.00	9,999.00	9,999.00
480	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	53.50	53.50	38.50	47.00	54.50	40.25	35.75	35.75	9,999.00	9,999.00	9,999.00	9,999.00
520	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
560	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
640	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
800	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00

#### Initial Supporting table - P219A Quality Factor Bank1 Table

Description: Bank 1 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

Notes: DTCs: P219A; Calibration Name: KtFABD\_K\_QualFactor1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

								· ·				` '	· ·				
y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,200	4,000	4,500	5,000	6,000
40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
80	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
120	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
160	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
200	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
240	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
280	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
320	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
360	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
400	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
440	0.00	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
480	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
520	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
560	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
640	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
720	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
800	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

### Initial Supporting table - P219A Variance Threshold Bank1 Table

Description: Bank 1 lookup table of Variance metric used to calculate the Ratio for the current sample period

Notes: DTCs: P219A; Calibration Name: KtFABD\_U\_VarThresh1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,200	4,000	4,500	5,000	6,000
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
80	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
120	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
160	9,999.00	9,999.00	9,999.00	9,999.00	7.75	7.75	7.25	6.75	5.75	6.00	6.00	3.25	3.25	9,999.00	9,999.00	9,999.00	9,999.00
200	9,999.00	9,999.00	9,999.00	9,999.00	7.75	7.75	7.25	6.75	5.75	6.00	6.00	3.25	3.25	9,999.00	9,999.00	9,999.00	9,999.00
240	9,999.00	9,999.00	9,999.00	10.50	10.50	10.50	8.25	7.00	9.00	5.50	6.25	5.75	5.75	9,999.00	9,999.00	9,999.00	9,999.00
280	9,999.00	9,999.00	9,999.00	10.50	10.50	9.00	11.00	7.50	9.00	5.00	6.00	4.50	4.50	9,999.00	9,999.00	9,999.00	9,999.00
320	9,999.00	9,999.00	9,999.00	16.50	16.50	10.75	11.75	9.00	9.25	8.50	6.75	5.75	5.75	9,999.00	9,999.00	9,999.00	9,999.00
360	9,999.00	9,999.00	9,999.00	15.50	15.50	15.00	10.50	8.75	11.50	9.50	9.00	6.00	6.00	9,999.00	9,999.00	9,999.00	9,999.00
400	9,999.00	9,999.00	9,999.00	15.00	15.00	13.25	12.50	10.50	12.00	15.75	9.75	12.25	12.25	9,999.00	9,999.00	9,999.00	9,999.00
440	9,999.00	9,999.00	9,999.00	15.00	15.00	12.25	11.25	12.25	15.00	10.50	7.50	10.00	10.00	9,999.00	9,999.00	9,999.00	9,999.00
480	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	11.25	11.25	12.25	15.00	10.50	7.50	10.00	10.00	9,999.00	9,999.00	9,999.00	9,999.00
520	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
560	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
640	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
800	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00

# Initial Supporting table - Closed Loop Enable Clarification - KaFCLP\_U\_SlphrIntglOfst\_Thrsh

Description: Integral Offset voltage thresholds (bank and cell specific cals) used with KeFCLP\_Pct\_CatAccuSlphrPostDsbl to check for sulphur poisoning.

Notes: millivolts

y/x	CiOXYR_O2_PostCat1	CiOXYR_O2_PostCat2
CiFCLP_Decel	2,048	2,048
CiFCLP_Idle	2,048	2,048
CiFCLP_Cruise	2,048	2,048
CiFCLP_LightAccel	2,048	2,048
CiFCLP_HeavyAccel	2,048	2,048

Initial Supporting table - Closed Loop Enable Clarification - KcFCLP_Cnt_O2RdyCyclesThrsh							
Description: Number of post catalyst oxygen sensor samples which must be outside not ready window before post oxygen sensor is READY.							
Notes: Time (events * 12.5 milliseconds)							
y/x	1						
1	10						

Initial Supporting table - Closed Loop Enable Clarification - KcFULC_O2_SensorReadyEvents							
Description: Number of times an oxygen sensor value must be in range before declaring it ready							
Notes: Time (events * 12.5 milliseconds)							
y/x	1						
1	10						

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_Pct_CatAccuSlphrPostDsbl							
Description: Sulphur percent threshold above which post integral learning is disabled if the threshold criteria KaFCLP_U_SlphrIntglOfst_Thrsh is also met.							
Notes: Percent							
y/x	1						
1	255						

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_T_IntegrationCatalystMax							
Description: Maximum allowed estimated catalytic converter temperature for post O2 integra	Description: Maximum allowed estimated catalytic converter temperature for post O2 integral terms to be updated.						
Notes: Modeled catalyst Temperature in Celcius							
y/x	1						
1	970						

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_T_IntegrationCatalystMin							
<b>Description:</b> Minimum allowed estimated catalytic converter temperature to begin using post O2 integration correction terms. Converter temperature must remain above this threshold to ramp-in the post O2 integration adjustments. Once the ramp-in has started, a converter temperature below this threshold will freeze the ramp-in multiplier. Post O2 integration will not be allowed below this converter temperature							
Notes: Modeled catalyst Temperature in Celcius							
y/x 1							
	425						

Initial Supporting table - Closed Loop Enable Clarification - KfFCLL_T_AdaptiveHiCoolant						
Description: LTM learning is inhibited if the engine coolant temperature is above this calibration.						
Notes: Degrees Celcius						
y/x	1					
1	255					

Initial Supporting table - Closed Loop Enable Clarification - KfFCLL_T_AdaptiveLoCoolant							
Description: LTM learning is inhibited if the engine coolant temperature is below this calibration.							
Notes: Degrees Celcius							
y/x	1						
1	45						

Initial Supporting table - Closed Loop Enable Clarification - KfFCLP_U_O2ReadyThrshLo						
Description: Lower threshold defining not ready window for post oxygen sensor voltage.						
Notes: Voltage in millivolts						
y/x	1					
1	1,100					

Initial Supporting table - Closed Loop Enable Clarification - KfFULC_U_O2_SensorReadyThrshLo						
Description: Lower limit checked against when determining if an oxygen sensor is in range						
Notes: Voltage in millivolts						
y/x	1					
1	1,100					

Initial Supporting table - Closed Loop Enable Clarification - KtFCLL_p_AdaptiveLowMAP_Limit											
Description: KtFCLL_p_AdaptiveLowMAP_Limit											
Notes: MAP in K	Pa										
y/x	y/x 65 70 75 80 85 90 95 100 105										
1	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0		

	Initial Supporting table - Closed Loop Enable Clarification - KtFCLP_t_PostIntglDisableTime																
Description: Disable integral offset after engine start for this amount of time.																	
Notes: Time in seconds																	
y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	400.0	360.0	320.0	280.0	240.0	200.0	160.0	120.0	120.0	120.0	120.0	120.0	60.0	60.0	90.0	120.0	150.0

	Initial Supporting table - Closed Loop Enable Clarification - KtFCLP_t_PostIntglRampInTime																
Descrip	Description: Time required to ramp integral offset to desired value.																
Notes: Time in seconds																	
y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

	Initial Supporting table - Closed Loop Enable Clarification - KtFSTA_t_ClosedLoopAutostart																
Descrip	Description: Engine run time following an autostart, as a function of begin run coolant, which must be exceeded to enable CLOSED LOOP.																
Notes:	Notes: Time in seconds: Hybrid use Only																
y/x	/x -40 -28 -16 -4 8 20 32 44 56 68 80 92 104 116 128 140 152																
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Initial Supporting table - Closed Loop Enable Clarification - KtFSTA_t_ClosedLoopTime									
Description: Engine run time, as a function of startup coolant temperature, which must be exceeded to enable CLOSED LOOP.									
Notes: Time in seconds									

110100. 11	Notes: Time in seconds																
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	180.0	120.0	70.0	40.0	26.0	26.0	26.0	12.0	6.0	4.0	2.0	1.0	1.0	1.0	1.0	1.0	1.0

	Initial Supporting table - P0411 Phase 1 Amb Temp Test Weight Factor														
Description: SA	Description: SAI Flow (Phase 1) Test ambient temperature weight factor.														
Notes: DTC: P0	Notes: DTC: P0411; Cal: KtAIRD_K_SAI_TstTempDsbld; Axis is Ambient (IAT) Temp (C).														
y/x	/x -30 -20 -10 0 10 20 30 40 50														
1	0.0 0.0 0.0 0.5 1.0 1.0 1.0 1.0 1.0														

	Initial Supporting table - P0411 Phase 1 Baro Test Weight Factor														
Description: SA	Description: SAI Flow (Phase 1) Test baro weight factor.														
Notes: DTC: P0	Notes: DTC: P0411; Cal: KtAIRD_K_SAI_TstBaroDsbld; Axis is atmospheric pressure (kPa)														
y/x	y/x 40 50 60 70 80 90 100 110 120														
1	0.0 0.0 0.5 1.0 1.0 1.0 1.0 1.0 0.0														

**Description:** KtAIRD\_K\_SAI\_TstMAF\_Dsbld: SAI Flow (Phase 1) Test MAF weight factor.

Notes: Axis is Mass Airflow (g/sec).

y/x	<b>(</b>	0.0	3.0	6.0	9.0	12.0	15.0	18.0	21.0	24.0	27.0	30.0	33.0	36.0	39.0	42.0	45.0	48.0
1.0	0	0.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	0.5	0.0	0.0	0.0	0.0	0.0

Initial Supporting table	P0411 Phase	1 System Volt	Tost Woight Factor
IIIIII Subbol IIII labie	- FU <del>T</del> II FIIASE	I OVSLEIII VUIL	i todi vvetutili i actor

**Description:** SAI Flow (Phase 1) Test system voltage weight factor.

Notes: DTC: P0411; Cal: KtAIRD\_K\_SAI\_TstVoltDsbld; Axis is system voltage (V).

y/x	5.0	6.0	7.0	8.0	9.0	10.0	11.0	12.0	13.0	14.0	15.0	16.0	17.0	18.0	19.0	20.0	21.0
1.0	0.0	0.0	0.0	0.0	0.0	0.5	0.8	1.0	1.0	1.0	1.0	1.0	0.8	0.5	0.5	0.5	0.5

# Initial Supporting table - P0411 SL Threshold Bank 1 Table

Description: Bank 1 SAI Flow (Phase 1) Test Average String Length failure threshold versus MAF (g/sec).

Notes: DTCs: P0411; Cal: KtAIRD\_dp\_SAI\_SL\_ThrshBank1

y/x	0.0	3.0	6.0	9.0	12.0	15.0	18.0	21.0	24.0	27.0	30.0	33.0	36.0	39.0	42.0	45.0	48.0
1.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

# Initial Supporting table - P0411 SL Threshold Bank 2 Table

**Description:** Bank 2 SAI Flow (Phase 1) Test Average String Length failure threshold versus MAF (g/sec).

**Notes:** DTCs: P0411; Cal: KtAIRD\_dp\_SAI\_SL\_ThrshBank2: For dual valve SAI systems only.

y/x	0.0	3.0	6.0	9.0	12.0	15.0	18.0	21.0	24.0	27.0	30.0	33.0	36.0	39.0	42.0	45.0	48.0
1.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

## Initial Supporting table - P0420\_BestFailingOSCTableB1

**Description:** This table is a 9x17 table of baseline Best Failing (e.g. threshold converter) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the BestFailing OSC value is found within this table for the measured temp and airflow and is used along with the OSC\_TimeRaw (and the WorstPassing value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the identified BPU converter that is used for MIL illumination across the specific temp and airflow range for a given program.

Notes: KtCATD\_t\_1\_OSC\_BestFailing - Used for norm ratio calculation for P0420

y/x	1.61	2.21	2.81	3.41	4.01	4.61	5.21	5.81	6.41	7.01	7.61	8.21	8.81	9.41	10.01	10.61	11.21
409.00	0.91	0.82	0.73	0.56	0.45	0.39	0.34	0.31	0.29	0.27	0.25	0.24	0.23	0.22	0.22	0.21	0.21
470.00	0.93	0.84	0.75	0.60	0.48	0.41	0.36	0.33	0.30	0.28	0.27	0.25	0.25	0.24	0.23	0.22	0.22
532.00	0.95	0.86	0.77	0.63	0.51	0.43	0.38	0.35	0.32	0.30	0.28	0.27	0.26	0.25	0.24	0.24	0.23
593.00	0.98	0.89	0.80	0.67	0.54	0.46	0.41	0.37	0.34	0.32	0.30	0.29	0.27	0.26	0.25	0.25	0.24
654.00	1.00	0.92	0.84	0.70	0.57	0.49	0.43	0.39	0.36	0.34	0.32	0.30	0.28	0.27	0.26	0.25	0.25
715.00	1.04	0.95	0.87	0.73	0.60	0.51	0.45	0.41	0.38	0.36	0.34	0.32	0.29	0.28	0.27	0.26	0.25
776.00	1.08	0.99	0.91	0.78	0.64	0.54	0.48	0.44	0.40	0.38	0.36	0.34	0.30	0.28	0.27	0.26	0.25
837.00	1.11	1.02	0.94	0.82	0.67	0.57	0.51	0.46	0.42	0.40	0.38	0.36	0.31	0.29	0.28	0.27	0.26
898.00	1.15	1.06	0.97	0.86	0.71	0.61	0.54	0.49	0.45	0.42	0.40	0.38	0.32	0.29	0.28	0.27	0.26

## Initial Supporting table - P0420\_WorstPassingOSCTableB1

**Description:** This table is a 9x17 table of WorstPassing (e.g. 120k) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the WorstPassing OSC value is found within this table for the measured temp and airflow and is used along with the OSC\_TimeRaw (and the BestFailing OSC value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the WPA part across the temp and airflow range.

Notes: KtCATD\_t\_1\_OSC\_WorstPassing - Used for NormRatio calculation for P0420

y/x	1.61	2.21	2.81	3.41	4.01	4.61	5.21	5.81	6.41	7.01	7.61	8.21	8.81	9.41	10.01	10.61	11.21
409.00	1.97	1.80	1.67	1.38	1.27	1.10	0.98	0.89	0.83	0.78	0.70	0.67	0.66	0.65	0.64	0.62	0.61
470.00	1.99	1.82	1.69	1.39	1.28	1.11	0.99	0.90	0.84	0.79	0.71	0.67	0.66	0.66	0.65	0.63	0.61
532.00	1.99	1.83	1.69	1.42	1.29	1.12	1.00	0.91	0.84	0.79	0.71	0.68	0.67	0.66	0.65	0.63	0.62
593.00	2.01	1.85	1.70	1.44	1.30	1.12	1.00	0.92	0.85	0.80	0.72	0.69	0.68	0.67	0.66	0.64	0.62
654.00	2.03	1.87	1.71	1.46	1.31	1.13	1.01	0.92	0.86	0.81	0.72	0.69	0.68	0.67	0.66	0.64	0.63
715.00	2.05	1.88	1.72	1.48	1.32	1.14	1.02	0.93	0.86	0.81	0.73	0.70	0.69	0.68	0.67	0.65	0.63
776.00	2.08	1.91	1.75	1.51	1.33	1.15	1.03	0.94	0.87	0.82	0.74	0.70	0.69	0.68	0.67	0.65	0.64
837.00	2.12	1.96	1.80	1.56	1.35	1.17	1.03	0.94	0.88	0.82	0.75	0.71	0.70	0.69	0.68	0.66	0.64
898.00	2.16	2.04	1.85	1.60	1.39	1.19	1.04	0.95	0.88	0.83	0.76	0.71	0.70	0.69	0.68	0.66	0.65

## Initial Supporting table - P050D\_P1400\_CatalystLightOffExtendedEngineRunTimeExit

**Description:** Exit Catalyst Warm-up mode if Engine Run Time is greater than this value. This table is based on percent ethanol (x-axis) and catmon's NormRatio\_EWMA value (y-axis). The NormRatio\_EWMA value determines the state of the catalyst. Typically, NormRatio\_EWMA values below 0.35 (0 is bad and 1 is good) represent catalysts that have degraded. The emission performance of these degraded catalysts can be improved by extending catalyst light off of GetE85R\_Pct\_FFS\_CompAtEngFloat.

**Notes:** KtCSEC\_t\_ExtendedEngineExit. Used for both P050D and P1400.

y/x	0	25	50	75	100
0.000	20	20	20	20	20
0.125	20	20	20	20	20
0.250	20	20	20	20	20
0.375	20	20	20	20	20
0.500	20	20	20	20	20
0.625	20	20	20	20	20
0.750	20	20	20	20	20
0.875	20	20	20	20	20
1.000	20	20	20	20	20

## Initial Supporting table - P1400\_ColdStartDiagnosticDelayBasedOnEngineRunTime

**Description:** Quality weight-based on engine run time. This allows adjustment of the weighting factors at various engine run times in order to prevent the updating of the cumulative quality timer or to change the value of the average qualified residual energy calculation to prevent false Fails of the diagnostic under circumstances inappropriate to update the calculation of the average qualified residual value.

**Notes:** KtCSED\_K\_TimeWght - This is used for P1400.

y/x	0	2	3	4	7	10	15	20	30
1	0	0	1	1	1	1	1	1	1

	Initial S	upporting tab	le - P1400_Co	ldStartDiagno	osticDelayBas	sedOnEnginel	RunTimeCalA	xis							
Description: This	Description: This is the x-axis for the KtCSED_K_TimeWght calibration table. Refer to the description for KtCSED_K_TimeWght for details.														
Notes: KnCSED_	t_TimeWght - This	is used for P1400.													
y/x	1	2	3	4	5	6	7	8	9						
1	0	2	3	4	7	10	15	20	30						

#### Initial Supporting table - P1400\_EngineSpeedResidual\_Axis

**Description:** This calibration is used as the x-axis for KtCSED\_dm\_Exh. An engine speed value will be chosen from this axis based on the value of VeSPDR\_n\_EngDsrd or actual engine speed. Subsequently, the engine speed value chosen from KnCSED\_n\_Exh determines the appropriate exhaust airflow value from the KtCSED\_dm\_Exh calibration table.

Notes: KnCSED\_n\_Exh - This is used for P1400

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	250	450	650	750	820	860	900	950	1,025	1,150	1,325	1,375	1,450	1,650	1,950	2,150	2,350

## Initial Supporting table - P1400\_EngineSpeedResidual\_Table

**Description:** This 1x17 table of engine exhaust flow values is used to calculate both the desired and the actual engine exhaust flow based on desired and actual engine speed. The desired engine exhaust flow is gathered from the desired engine speed (VeSPDR\_n\_EngDsrd). The value used for the actual engine exhaust flow is based on the actual engine RPM value.

Notes: KtCSED\_dm\_Exh - This is used for P1400

y/x	250	450	650	750	820	860	900	950	1,025	1,150	1,325	1,375	1,450	1,650	1,950	2,150	2,350
1	2	4	4	4	5	7	9	11	12	12	12	12	12	12	12	12	18

## Initial Supporting table - P1400\_SparkResidual\_Axis

**Description:** Calibratible axis into KtCSED\_E\_ExhEngyPerUnitMass. This is a table of spark value used for desired spark is the desired spark during cat light off. Actual spark value used is the final commanded spark.

Notes: KnCSED\_phi\_ExhEngyPerUnitMass - Used for P1400

Î	y/x	1.00	2.00	3.00	4.00	5.00	6.00		8.00	9.00
	1	-30	-20	-10	0	10	17(1)	30	40	50

## Initial Supporting table - P1400\_SparkResidual\_Table

**Description:** Predicted engine-out energy potential based on either the desired cold start spark advance value or the actual spark advance value. ExhEngyPerUnitMass used to calculate both desired exhaust energy and actual energy. The desired and actual exhaust energy per unit mass values are used in part to calculate the desired exhaust energy per unit time and actual exhaust energy per unit time. Both desired and actual go into the residual exhaust energy per unit time calculation.

Notes: KtCSED\_E\_ExhEngyPerUnitMass

y/x	-30	-20	-10	0	10	20	30	40	50
1	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## Initial Supporting table - P2431\_P2436 Baro Skewed Sensor Weight Factor

Description: The AIR Pressure Sensor Test quality factor based on the distance traveled since the last unthrottled ambient pressure update.

**Notes:** DTCs: P2431 & P2436; Cal: KtAIRD\_K\_APPD\_BaroQlty; P2436 is applicable on dual valve applications only. Axis is distance traveled from last Baro update in Km (1Km = 0.62 Miles).

ľ	y/x	0.0	2.0	4.0	6.0	8.0	10.0	12.0	14.0	16.0	18.0	20.0	22.0	24.0	26.0	28.0	30.0	32.0
	1.0		0.8	0.5	0.3	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0		0.0	0.0

Initial Supporting table - P2440 Bank 1 Valve Pressure Error												
Description: Sensor 1 minimum average pressure error (kPa) threshold for the valve-shut (Phase 2) test .												
Notes: DTC	Cs: P2440; Cal: Ka	aAIRD_p_VIvTstPres	ErrMin[CeAIRR_e	_PresSnsrOne]; Ax	ris is Conditional Te	est Weight Time in	seconds.					
y/x	y/x 0 1 2 3 4 5 6 7 8											
1	1 -3.0 -3.0 -3.0 -3.0 -3.0 -3.0 -3.0 -3.0											

Initial Supporting table - P2440 Bank 2 Valve Pressure Error												
Description: Sensor 2 minimum average pressure error (kPa) threshold for the valve-shut (Phase 2) test.												
Notes: DTCs:	: P2440; Cal: Ka	AIRD_p_VIvTstPre	sErrMin[CeAIRR_e	_PresSnsrTwo]; Fo	or dual valve SAI s	ystems only. Axis is	s Conditional Test W	eight Time in seco	nds.			
y/x	0	1	2	3	4	5	6	7	8			
1	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0	-3.0			

	Initial Supporting table - P2440 Phase 2 Amb Temp Test Weight Factor												
Description: Ambient Temperature component of the conditional test weight for the valve-shut (Phase 2) test.													
Notes: DTCs: P2	440; Cal: KtAIRD_l	K_VIvTstTempDsbld	; Axis is ambient to	emperature (IAT) in	Deg C.								
y/x	y/x   -30   -20   -10   0   10   20   30   40   50												
1	0.0 0.0 0.0 0.5 1.0 1.0 1.0 1.0 1.0												

Initial Supporting table - P2440 Phase 2 Baro Test Weight Factor													
Description: Ambient pressure component of the conditional test weight for the valve-shut (Phase 2) test .													
Notes: DT	Cs: P2440; Cal: Kt	AIRD_K_VIvTstBaro	Dsbld; Axis is am	bient pressure (kPa	a).								
y/x	y/x 40 50 60 70 80 90 100 110 120												
1	1 0.0 0.0 0.5 1.0 1.0 1.0 1.0 1.0 0.0												

Initial Supporting table - P2440 Phase 2 MAF Test Weight Factor
---

Description: Mass Airflow (MAF) component of the conditional test weight for the valve-shut (Phase 2) test.

Notes: DTCs: P2440; Cal: KtAIRD\_K\_VIvTstMAF\_Dsbld; Axis is mass airflow (g/s).

y/x	(	0.0	3.0	6.0	9.0	12.0	15.0	18.0	21.0	24.0	27.0	30.0	33.0	36.0	39.0	42.0	45.0	48.0
1.0	)	0.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	0.5	0.0	0.0	0.0	0.0	0.0

# Initial Supporting table - P2440 Phase 2 System Volt Test Weight Factor

**Description:** System Voltage component of the conditional test weight for the valve-shut (Phase 2) test.

Notes: DTCs: P2440; Cal: KtAIRD\_K\_VlvTstVoltDsbld; Axis is system volts (V).

y/x	5.0	6.0	7.0	8.0	9.0	10.0	11.0	12.0	13.0	14.0	15.0	16.0	17.0	18.0	19.0	20.0	21.0
1.0	0.0	0.0	0.0	0.0	0.0	0.5	0.8	1.0	1.0	1.0	1.0	1.0	0.8	0.5	0.5	0.5	0.5

Initial Supporting table - P2444 Bank 1 Pump Pressure Error													
Description: Sensor 1 maximum average pressure error threshold for the pump-off (Phase 3) test.													
Notes: DTCs: P	2444; Cal: KaAlf	RD_p_PmpTstPresE	rrMax[CeAIRR_e_Pro	esSnsrOne]; Axis is	Conditional Test W	eight Time in secor	nds.						
y/x	y/x 0 1 2 3 4 5 6 7 8												
1	2.0 2.0 2.0 2.0 2.0 2.0 2.0 2.0 2.0 2.0												

Initial Supporting table - P2444 Bank 2 Pump Pressure Error												
Description: Sensor 2 maximum average pressure error threshold for the pump-off (Phase 3) test.												
Notes: DTCs: I	P2444; Cal: KaA	\IRD_p_PmpTstPr	esErrMax[CeAIRF	R_e_PresSnsrTwo];	For dual sensor SA	Al systems only. Ax	is is Conditional Tes	st Weight Time in se	econds.			
y/x	0	1	2	3	4	5	6	7	8			
1	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0			

Initial Supporting table - P057B KtBRKI_K_CmpltTestPointWeight														
Description:	Description:													
Notes:	Notes:													
y/x	0.000	0.020	0.030	0.030	0.050	0.100	0.150	0.250	1.000					
1	0	0	0	1	1	1	1	1	1					

Initial Supporting table - P057B KtBRKI_K_CmpltTestPointWeight														
Description:	Description:													
Notes:	Notes:													
y/x	0.000	0.020	0.030	0.030	0.050	0.100	0.150	0.250	1.000					
1	0	0	0	1	1	1	1	1	1					

Initial Supporting table - P057B KtBRKI_K_FastTestPointWeight														
Description:	Description:													
Notes:	Notes:													
y/x	0.000	0.052	0.080	0.250	0.350	0.450	0.550	0.750	1.000					
1	0	1	1	1	1	1	1	1	1					

		Initial S	Supporting tak	ole - P057B Kt	BRKI_K_Fast	TestPointWei	ght								
Description:	escription:														
Notes:	Notes:														
y/x	0.000	0.052	0.080	0.250	0.350	0.450	0.550	0.750	1.000						
1	0	1	1	1	1	1	1	1	1						

#### Initial Supporting table - P0324\_P0326\_P0331\_AbnormalNoise\_CylsEnabled

**Description:** Specifies which cylinders will be used for the Abnormal Noise portion of the performance diagnostics (1 = cylinder used, 0 = cylinder not used)

Notes: Used for P0324, P0326 and P0331. Cal name: KaKNKD\_b\_PerfAbnIncludeCyl. x-axis = Cylinder number in firing order (i.e. Cyl 0 = first cylinder in firing order, Cyl 1 = second cylinder in firing order....)

A cal value = 1 specifies the cylinder is used for the Abnormal Noise diagnostic. A cal value = 0 specifies the cylinder is not used. Only the first four values in the table are relavent for a four-cylinder engine and only the first six values in the table are relavent for a six-cylinder engine.

Typically, all cylinders are used. Cylinders are only excluded if the signal from that cylinder is weak and there is no separation between normal and faulted conditions (can occur if the sensor location results in poor signal-to-noise ratio for a given cylinder).

y/x	0	1	2	3	4	5	6	7
1	1	1	1	1	0	0	0	0

# Initial Supporting table - P0324\_P0326\_P0331\_AbnormalNoise\_Threshold

**Description:** Fail threshold for the Knock Performance Abnormal Noise Diagnostic

Notes: Used for P0324, P0326 and P0331. Cal Name: KtKNKD\_k\_PerfAbnLimitLo. X-axis = Engine Speed (RPM). Diagnostic fails when VaKNKD\_k\_PerfCylAbnFiltIntnsity <

KtKNKD\_k\_PerfAbnLimitLo

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.096	0.096	0.096	0.105	0.102	0.104	0.106	0.099	0.100	0.110	0.102	0.103	0.108	0.108	0.108	0.108	0.108

#### Initial Supporting table - P0325\_P0330\_OpenCktThrshMax (20 kHz)

**Description:** Knock Open Circuit Diagnostic Maximum Threshold when using the 20 kHz method (see "OpenMethod" description)

Notes: Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenMax20K. x-axis = Engine Speed (RPM).

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax: i.e.: KtKNKD\_k\_OpenMin20K < VaKNKD\_k\_OpenFiltIntensity < KtKNKD\_k\_OpenMax20K.

y/x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	12.7090	12.5703	12.1387	10.9180	9.2031	7.8477	7.0371	5.3203	5.5234	5.7676	5.5273	5.9727	5.9844	5.9844	5.9844	5.9844	5.9844

# Initial Supporting table - P0325\_P0330\_OpenCktThrshMax (Normal Noise)

**Description:** Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

**Notes:** Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenMaxNN. x-axis = Engine Speed (RPM)

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:

i.e.: KtKNKD\_k\_OpenMinNN < VaKNKD\_k\_OpenFiltIntensity < KtKNKD\_k\_OpenMaxNN.

١	//x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1		0.3848	0.3848	0.3848	0.3848	0.3848	0.3848	0.3496	0.4102	0.3496	0.4609	0.5195	0.5703	0.5996	0.5996	0.5996	0.5996	0.5996

## Initial Supporting table - P0325\_P0330\_OpenCktThrshMin (20 kHz)

Description: Knock Open Circuit Diagnostic Minimum Threshold when using the 20 kHz method (see "OpenMethod" description)

Notes: Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenMin20K. x-axis = Engine Speed (RPM)

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax: i.e.: KtKNKD\_k\_OpenMin20K < VaKNKD\_k\_OpenFiltIntensity < KtKNKD\_k\_OpenMax20K.

y/x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	4.8359	4.7031	4.6406	4.1250	3.5352	2.9746	2.6738	2.0215	2.0684	2.2266	2.1992	2.4473	2.5117	2.5117	2.5117	2.5117	2.5117

### Initial Supporting table - P0325\_P0330\_OpenCktThrshMin (Normal Noise)

**Description:** Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

Notes: Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenMinNN. x-axis = Engine Speed (RPM)

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:

i.e.: KtKNKD\_k\_OpenMinNN < VaKNKD\_k\_OpenFiltIntensity < KtKNKD\_k\_OpenMaxNN.

y/x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000

## Initial Supporting table - P0325\_P0330\_OpenMethod

#### **Description:**

Notes: Used for P0325 and P0330. Cal name: KtKNKD\_e\_OpenMethod. x-axis = Engine Speed Index, 500 to 8500 (RPM) by 500 rpm increments.

Selects 1 of 3 available methods: "20kHz Method", "Normal Noise Method," or "Disabled." The mode chosen dictates which set of threshold tables are used. Typically, either: A) the 20 kHz Method is used for all RPM or B) the 20 kHz Method is used for low/medium RPM and the Normal Noise Method is used for high RPM.

P0325_P0330_Oper	nMethod* - Part 1					
y/x	0	1	2	3	4	5
1	CeKNKD_e_Open_20KH	CeKNKD_e_Open_20KH	CeKNKD_e_Open_20KH	CeKNKD_e_Open_20KH	CeKNKD_e_Open_20KH	CeKNKD_e_Open_20KH
	Z	Z	Z	Z	z	Z
P0325_P0330_Oper	nMethod* - Part 2					
y/x	6	7	8	9	10	11
1	CeKNKD_e_Open_20KH	CeKNKD_e_Open_20KH	CeKNKD_e_Open_20KH	CeKNKD_e_Open_20KH	CeKNKD_e_Open_20KH	CeKNKD_e_Open_20KH
	z	z	Z	Z	z	z
P0325_P0330_Oper	nMethod* - Part 3					
y/x	12	13	14	15	16	
1	CeKNKD_e_Open_20KH	CeKNKD_e_Open_None	CeKNKD_e_Open_None	CeKNKD_e_Open_None	CeKNKD_e_Open_None	

#### Initial Supporting table - P06B6\_P06B7\_OpenTestCktThrshMax

**Description:** Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

**Notes:** Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenTestCktMax. x-axis = Engine Speed (RPM).

Diagnostic fails when the filtered diagnostic output is between the OpenTestCktThrshMin and OpenTestCktThrshMax:

i.e. KtKNKD\_k\_OpenTestCktMin < VaKNKD\_k\_OpenTestCktIntFilter < KtKNKD\_k\_OpenTestCktMax

y.	/x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1		0.166	0.166	0.176	0.191	0.176	0.207	0.238	0.330	0.385	0.467	0.543	0.666	0.666	0.666	0.666	0.666	0.666

#### Initial Supporting table - P06B6\_P06B7\_OpenTestCktThrshMin

**Description:** Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

**Notes:** Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenTestCktMin. x-axis = Engine Speed (RPM).

Diagnostic fails when the filtered diagnostic output is between the OpenTestCktThrshMin and OpenTestCktThrshMax:

i.e. KtKNKD\_k\_OpenTestCktMin < VaKNKD\_k\_OpenTestCktIntFilter < KtKNKD\_k\_OpenTestCktMax

Î	y/x	700	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
	1	0.061	0.061	0.068	0.080	0.076	0.098	0.119	0.172	0.193	0.240	0.285	0.357	0.357	0.357	0.357	0.357	0.357

#### 15 OBDG02

#### **Fault Bundle Definitions**

Bundle Name: 5VoltReferenceA FA

P0641

Bundle Name: 5VoltReferenceB\_FA

P0651

Bundle Name: 5VoltReferenceMAP OOR Flt

P0697

Bundle Name: A/F Imbalance Bank1

P219A

Bundle Name: A/F Imbalance Bank2

P219B

Bundle Name: AAP\_SnsrCktFA

Naturally aspirated: P2228, P2229. Turbocharged: P0237, P0238

Bundle Name: AAP\_SnsrCktFP

Naturally aspirated: P2228, P2229. Turbocharged: P0237, P0238

Bundle Name: AAP SnsrFA

Naturally Aspirated: P2227, P2228, P2229, P2230. Turbocharged: P0237, P0238.

Bundle Name: AAP\_SnsrTFTKO

Naturally Aspirated: P2227, P2228, P2229, P2230. Turbocharged: P0237, P0238.

Bundle Name: AAP2\_SnsrCktFA

P2228, P2229

Bundle Name: AAP2 SnsrCktFP

P2228, P2229

**Bundle Name**: AAP2\_SnsrFA P2227, P2228, P2229, P2230

Bundle Name: AAP2 SnsrTFTKO

P2227, P2228, P2229, P2230

Bundle Name: AAP3\_SnsrCktFA

P222C, P222D

Bundle Name: AAP3 SnsrCktFP

P222C, P222D

Bundle Name: AccCktLo\_FA

P2537

Bundle Name: AcceleratorPedalFailure

P2122, P2123, P2127, P2128, P2138, P0697, P06A3

Bundle Name: ACCMLostComm

U016B

Bundle Name: ACFailedOnSD

See ACCM Document

#### 15 OBDG02

#### **Fault Bundle Definitions**

Bundle Name: ACHighSidePressSnsrCktFA

P0532, P0533

Bundle Name: ACThrmlRefrigSpdVld

See ACCM Document

Bundle Name: AfterThrottlePressTFTKO

Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.

Bundle Name: AfterThrottlePressureFA

Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.

Bundle Name: AfterThrottleVacuumTFTKO

Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.

Bundle Name: AIR System FA

P0411, P2440, P2444

Bundle Name: AIRPumpControlCircuit FA

P0418, P2257, P2258

Bundle Name: AIRSystemPressureSensor FA

P2430, P2431, P2432, P2433, P2435, P2436, P2437, P2438

Bundle Name: AIRValveControlCircuit FA

P0412, P041F, P044F

Bundle Name: AllTwoStepDrvr\_TFTKO

P16CF, P16D2, P16D3, P2645, P2648, P2649

Bundle Name: AllVCE Driver TFTKO

P16CF, P16D2, P16D3, P2645, P2648, P2649

Bundle Name: AmbientAirDefault

Baro Sensor Present: P2227, P2228, P2229, P2230. No Baro Sensor Present: P0101, P0102, P0103, P0106, P0107, P0108, P0111, P0112, P0113, P0114, P0121, P0122, P012B, P012B, P012C, P012D, P0222.

P0223, P1221

Bundle Name: AmbPresDfltdStatus

Baro Sensor Present: P2227, P2228, P2229, P2230. No Baro Sensor Present: P0101, P0102, P0103, P0106, P0107, P0108, P0111, P0112, P0113, P0114, P0121, P0122, P012B, P012B, P012C, P012D, P0222.

P0223, P1221

Bundle Name: AmbPresSnsr2\_CktFA

P222C, P222D

Bundle Name: AmbPresSnsrCktFA

P2228, P2229

Bundle Name: AmbPresSnsrCktFP

P2228, P2229

Bundle Name: AnyCamPhaser\_FA

P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, P2088, P2089, P2090, P2091, P2092, P2093, P2094, P2095, P05CC, P05CD, P05CE, P05CF,

P25CA, P25CB, P25CC, P25CD, P25CE, P25CF

#### 15 OBDG02

#### **Fault Bundle Definitions**

Bundle Name: AnyCamPhaser\_TFTKO

P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, P2088, P2089, P2090, P2091, P2092, P2093, P2094, P2095, P05CC, P05CD, P05CE, P05CF,

P25CA, P25CB, P25CC, P25CD, P25CE, P25CF

Bundle Name: BrakeBoosterSensorCktFA

P0557, P0558

Bundle Name: BrakeBoosterSensorFA

P0556, P0557, P0558

Bundle Name: BrakeBoosterVacuumValid

P0556, P0557, P0558

Bundle Name: BSTR\_b\_BoostSnsrFA

P0236, P0237, P0238

Bundle Name: BSTR b ExcsvBstFA

P226B

Bundle Name: BSTR b ExcsvBstTFTKO

P226B

Bundle Name: BSTR\_b\_IC\_Pmp\_EffPerfTFTKO

P026A

Bundle Name: BSTR\_b\_IC\_PmpCktFA

P023A, P023C

Bundle Name: BSTR b PCA CktFA

P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P0247, P0249, P0250

Bundle Name: BSTR\_b\_PCA\_CktLoFA

P0034, P0047, P0245, P0249

Bundle Name: BSTR\_b\_PCA\_CktLoTFTKO

P0034, P0047, P0245, P0249

Bundle Name: BSTR\_b\_PCA\_CktTFTKO

P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P0247, P0249, P0250

Bundle Name: BSTR\_b\_PCA\_FA

P0234, P0299, P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P2261, P0247, P0249, P0250

Bundle Name: BSTR b PCA PstnSnsrFA

P003A, P2564, P2565

Bundle Name: BSTR\_b\_PCA\_PstnSnsrTFTKO

P003A, P2564, P2565

Bundle Name: BSTR\_b\_PCA\_TFTKO

P0234, P0299, P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P2261, P0247, P0249, P0250

Bundle Name: BSTR\_b\_PresCntrlTooHiFA

P0234

Bundle Name: BSTR\_b\_PresCntrlTooHiTFTKO

## **Fault Bundle Definitions**

P0234

Bundle Name: BSTR\_b\_PresCntrlTooLoFA

P0299

Bundle Name: BSTR b PresCntrlTooLoTFTKO

P0299

Bundle Name: BSTR b PstnCntrlFA

P166D, P166E

Bundle Name: BSTR\_b\_PstnCntrlTooHiFA

P166E

Bundle Name: BSTR b PstnCntrlTooHiTFTKO

P166E

Bundle Name: BSTR\_b\_PstnCntrlTooLoFA

P166D

Bundle Name: BSTR\_b\_PstnCntrlTooLoTFTKO

P166D

Bundle Name: BSTR\_b\_TurboBypassA\_StkFA

P2261

**Bundle Name:** BSTR\_b\_TurboBypassCktFA

P0033, P0034, P0035, P00C0, P00C1, P00C2

Bundle Name: BSTR\_b\_TurboBypassCktTFTKO

P0033, P0034, P0035, P00C0, P00C1, P00C2

Bundle Name: BSTR b TurboBypB CktFA

P00C0, P00C1, P00C2

Bundle Name: BSTR\_b\_TurboBypB\_CktTFTKO

P00C0, P00C1, P00C2

Bundle Name: CamLctnExhFA

P0017, P0019, P0365, P0366, P0390, P0391

Bundle Name: CamLctnIntFA

P0016, P0018, P0340, P0341, P0345, P0346

Bundle Name: CamSensor FA

P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391

Bundle Name: CamSensor TFTKO

P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391

Bundle Name: CamSensorAnyLctnTFTKO

P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391

Bundle Name: CamSensorAnyLocationFA

P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391

Bundle Name: CamSensorFA

# **Fault Bundle Definitions**

P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391

Bundle Name: CamSensorTFTKO

P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391

Bundle Name: Catalyst Warmup Enabled

N/A

## Catalyst Warmup Enabled - Other Definitions:

To enable the Cold Start Emission Reduction Strategy:

Catalyst Temperature < 650.00 degC

AND

Engine Coolant > -12.00 degC

AND

Engine Coolant <= 55.00 degC

AND

Barometric Pressure>= 74.00 KPa

AND

DTC's Not Set:

ECT\_Sensor\_FA MAP SensorFA

The Cold Start Emission Reduction Strategy will remain active until:

Engine Run Time > P050D\_P1400\_CatalystLightOffExtendedEngineRunTimeExit This Extended Engine run time exit is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details.

OR

Catalyst Temperature >= 800.00 degC

AND

Engine Run Time >= 18.50 seconds

lor

Barometric Pressure < 74.00 KPa

Bundle Name: CatalystSysEfficiencyLoB1\_FA

P0420

Bundle Name: CatalystSysEfficiencyLoB2\_FA

P0430

Bundle Name: ClutchPstnSnsr FA

P0806, P0807, P0808

Bundle Name: ClutchPstnSnsrCktHi FA

P0808

## **Fault Bundle Definitions**

Bundle Name: ClutchPstnSnsrCktLo FA

P0807

Bundle Name: ClutchPstnSnsrNotLearned

P080A

Bundle Name: CommBusAOff\_VICM\_FA

U0073

Bundle Name: CommBusBOff\_VICM\_FA

U0074

Bundle Name: CoolingFanSpeedTooHigh\_FA

P0495

Bundle Name: CrankCamCorrelationTFTKO

P0016, P0017, P0018, P0019

Bundle Name: CrankExhaustCamCorrelationFA

P0017, P0019

Bundle Name: CrankExhaustCamCorrFA

P0017, P0019

Bundle Name: CrankIntakeCamCorrelationFA

P0016, P0018

Bundle Name: CrankIntakeCamCorrFA

P0016, P0018

Bundle Name: CrankSensor\_FA

P0335, P0336

Bundle Name: CrankSensor\_TFTKO

P0335, P0336

Bundle Name: CrankSensorFA

P0335, P0336

Bundle Name: CrankSensorFaultActive

P0335, P0336

Bundle Name: CrankSensorTestFailedTKO

P0335, P0336

Bundle Name: CrankSensorTFTKO

P0335, P0336

Bundle Name: CylDeacAllDriverFault

P3401, P03403, P03404, P3409, P03411, P03412, P3417, P3419, P3420, P3425, P3427, P3428, P3433, P3435, P3436, P3441, P3443, P3444, P3449, P3451,

P3452, P3457, P3459, P3460

Bundle Name: CylDeacDriverFault

P3401, P03403, P03404, P3409, P03411, P03412, P3417, P3419, P3420, P3425, P3427, P3428, P3433, P3435, P3436, P3441, P3443, P3444, P3449, P3451,

P3452, P3457, P3459, P3460

# **Fault Bundle Definitions** Bundle Name: CylDeacSystemTFTKO P3400 Bundle Name: ECT\_Sensor\_Ckt\_FA P0117, P0118 Bundle Name: ECT\_Sensor\_Ckt\_FP P0117, P0118 Bundle Name: ECT\_Sensor\_Ckt\_High\_FP P0118 Bundle Name: ECT\_Sensor\_Ckt\_Low\_FP P0117 Bundle Name: ECT\_Sensor\_Ckt\_TFTKO P0117, P0118 Bundle Name: ECT\_Sensor\_Ckt\_TPTKO P0117, P0118 Bundle Name: ECT Sensor DefaultDetected P0116, P0117, P0118, P0119, P111E Bundle Name: ECT\_Sensor\_FA P0116, P0117, P0118, P0119, P0128, P111E Bundle Name: ECT\_Sensor\_Perf\_FA P0116, P111E Bundle Name: ECT\_Sensor\_TFTKO P0116, P0117, P0118, P0119, P0128, P111E ECT\_Sensor\_TFTKO - Other Definitions: Bundle Name: EGRValve\_FP P0405, P0406, P042E Bundle Name: EGRValveCircuit\_FA P0403, P0404, P0405, P0406, P0489, P0490, P042E Bundle Name: EGRValveCircuit\_TFTKO P0403, P0404, P0405, P0406, P0489, P0490 Bundle Name: EGRValvePerformance FA P0404, P042E Bundle Name: EGRValvePerformance\_TFTKO P0404, P042E Bundle Name: ELCP\_PumpCircuit\_FA P2400, P2401, P2402

Bundle Name: ELCP\_SwitchCircuit\_FA

P2418, P2419, P2420

## **Fault Bundle Definitions**

Bundle Name: ELCPCircuit\_FA

P24BA, P24BB

Bundle Name: EngineMetalOvertempActive

P1258

**Bundle Name:** EngineMisfireDetected\_FA

P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308

Bundle Name: EngineMisfireDetected\_TFTKO

P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308

Bundle Name: EngineModeNotRunTimer FA

P262B

Bundle Name: EngineModeNotRunTimerError

P262B

Bundle Name: EnginePowerLimited

P0068, P00C8, P00C9, P00CA, P0090, P0091, P0092, P0122, P0123, P0191, P0192, P0193, P0222, P0223, P0601, P0604, P0606, P0697, P06A3, P06DB,

P06DE, P0A1D, P1104, P127A, P127C, P127D, P15F2, P160D, P160E, P1682, P16A0, P16A1, P16A2, P16F3, P2100, P2101, P2102, P2103, P2122, P2123,

P2127, P2128, P2135, P2138, P215B, P2176, P228C, P228D, U0073, U0074, U0293, U1817

Bundle Name: EngineTorqueEstInaccurate

EngineMisfireDetected\_FA, FuelInjedtorCircuit\_FA, FuelInjedtorCircuit\_TFTKO, FuelTrimSystemB1\_FA, FuelTrimSystemB2\_FA, MAF\_SensorTFTKO, MAP\_SensorTFTKO,

EGRValuePerforamnce FA, P16F3

EngineTorqueEstInaccurate - Other Definitions:

P16F3 with GetXOYR b SecurityFlt (CeXOYR e MAPR AfterThrotPresFlt, CeXOYR e MAPR EngineVacuumFlt, CeXOYR e MAPR IntkMnfdPresFlt,

CeXOYR\_e\_MAFR\_Ahead1vs2FinalFlt)

Bundle Name: EngModeNotRunTmErr

P262B

Bundle Name: EngOilModeledTempValid

ECT Sensor FA, IAT SensorCircuitFA

Bundle Name: EngOilPressureSensorCktFA

P0522, P0523

Bundle Name: EngOilPressureSensorFA

P0521, P0522, P0523

Bundle Name: EngOilTempFA

EngOilTempSensorCircuitFA, EngOilModeledTempValid, P16F3

EngOilTempFA - Other Definitions:

P16F3 with GetXOYR\_b\_SecurityFlt(CeXOYR\_e\_EOTR\_SecurityFlt)

Bundle Name: EngOilTempSensorCircuitFA

P0197, P0198

Bundle Name: Ethanol Composition Sensor FA

P0178, P0179, P2269

Bundle Name: EvapEmissionSystem FA

# **Fault Bundle Definitions**

P0455, P0446

Bundle Name: EvapExcessPurgePsbl FA

ELCP sealed/vented fuel system, P0442, P0455, P0458 OR Conventional fuel system, P0442, P0455, P0458, P0496

Bundle Name: EvapFlowDuringNonPurge\_FA

P0496

Bundle Name: EvapPurgeSolenoidCircuit\_FA

P0443, P0458, P0459

Bundle Name: EvapReducedPurgePsbl\_FA

ELCP sealed/vented fuel system, P0443, P0446, P0449, P0459, P0497, P0499, P1463, P2419, P2422 OR Conventional fuel system, P0443, P0446, P0455, P0459, P0498

Bundle Name: EvapSmallLeak\_FA

P0442

Bundle Name: EvapVentSolenoidCircuit\_FA

P0449, P0498, P0499

Bundle Name: ExhaustCamSensor\_FA

P0017, P0019, P0365, P0366, P0390, P0391

Bundle Name: ExhaustCamSensor\_TFTKO

P0017, P0019, P0365, P0366, P0390, P0391

Bundle Name: ExhaustCamSensorFA

P0017, P0019, P0365, P0366, P0390, P0391

Bundle Name: ExhaustCamSensorTFTKO

P0017, P0019, P0365, P0366, P0390, P0391

Bundle Name: ExhaustVVT\_Enabled

ExhaustVVT\_Enabled - Other Definitions:

ExhaustVVT\_Enabled= TRUE if:

DTCs not set:

CrankSensor\_TFTKO

ExhaustCamSensorTFTKO

CamLctnExhFA

AND

CrankExhaustCamCorrelationFA diagnostic has executed and passed

AND

Cam Edge Locations have been learned

AND

IntakeVVT\_Enabled = TRUE

# Fault Bundle Definitions

```
lor.
Intake Park Position is Retarded (CePHSR_e_Advanced)
AND
[Catalyst Warmup Enabled is TRUE AND
Engine Speed > 450.00 AND
Engine Run Time > P0011_P0021_P05CC_P05CD_P0014_P0024_P05CE_P05CF_ColdStartEngRunning]
lor
[Engine is running
                                      AND
Engine power is requested
                                      AND
ExhEngineSpeed is Enabled (see below)
                                      AND
ExhOilPressure is Enabled (see below)
                                      AND
ExhEngineOilTemp is Enabled (see below)
ExhEngineSpeed is Enabled if:
P0014 P0024 P05CE P05CF_LoRpmHiEnblEc < Engine RPM < P0014_P0024_P05CE_P05CF_HiEngSpdLoEnblEc
ExhEngineSpeed Disables if:
Engine RPM < P0014_P0024_P05CE_P05CF_LoRpmLoDsblEc
Engine RPM > P0014_P0024_P05CE_P05CF_HiEngSpdHiDsblEc
ExhOilPressure is Enabled if:
(Oil Pressure Sensor In Use (0.00) = 1.00 (Note: 1.00 equals TRUE) AND
Oil Pressure Sensor Present (0.00) = 1.00 (Note: 1.00 equals Present) AND
Oil Pressure > P0014_P0024_P05CE_P05CF_LoPresHiEnblEc
for P0014 P0024 P05CE P05CF EngOilPressEnblEc sec)
(Engine RPM > P0014 P0024 P05CE P05CF LoRpmHiEnblEc for
P0014_P0024_P05CE_P05CF_EngOilPressEnblEc sec)
ExhOilPressure Disables if:
(Oil Pressure Sensor In Use (0.00) = 1.00 (Note: 1.00 equals TRUE) AND
Oil Pressure Sensor Present (0.00) = 1.00 (Note: 1.00 equals Present) AND
Oil Pressure < P0014_P0024_P05CE_P05CF_LoPresLoDsblEc )
ExhEngineOilTemp is Enabled if:
-20.00 < Engine Oil Temp < 155.00
ExhEngineOilTemp Disables if:
```

## **Fault Bundle Definitions**

Engine Oil Temp < -22.00

OR

Engine Oil Temp > 160.00

Bundle Name: FanOutputDriver\_FA

P0480, P0481, P0482, P0691, P0692, P0693, P0694, P0695, P0696, P1485 (EREV), P1486 (EREV), P1487 (EREV)

Bundle Name: FHPD\_b\_FRP\_SnsrCkt\_FP

P0192, P0193, P16E4, P16E5, P128F, P128A

Bundle Name: FHPD\_b\_HPC\_PresErrNeg\_FA

P228D

Bundle Name: FHPD b HPC PresErrNeg TFTKO

P228D

Bundle Name: FHPD\_b\_HPC\_PresErrPos\_FA

P228C

Bundle Name: FHPD\_b\_HPC\_PresErrPos\_TFTKO

P228C

Bundle Name: FHPD b HPC Windup TFTKO

P0089

Bundle Name: FHPD\_b\_HPC\_Windup\_FA

P0089

Bundle Name: FHPD\_b\_PumpCurr\_FA

P163A

Bundle Name: FHPD\_b\_PumpCurr\_TFTKO

P163A

Bundle Name: FHPR\_b\_FRP\_SnsrCkt\_FA

P0192, P0193, P127C, P127D, P16E4, P16E5, P128F, P128A, P128B

Bundle Name: FHPR\_b\_FRP\_SnsrCkt\_TFTKO

P0192, P0193, , P127C, P127D, P16E4, P16E5, P128F, P128A, P128B

Bundle Name: FHPR\_b\_FRP\_SnsrPerfDiag\_FA

P0191, P127A

Bundle Name: FHPR\_b\_FRP\_SnsrPerfDiag\_TFTKO

P0191. P127A

Bundle Name: FHPR\_b\_PumpCkt\_FA

P0090, P0091, P0092, P00C8, P00C9, P00CA

Bundle Name: FHPR\_b\_PumpCkt\_FP

P0090, P0091, P0092, P00C8, P00C9, P00CA

Bundle Name: FHPR\_b\_PumpCkt\_TFTKO

P0090, P0091, P0092, P00C8, P00C9, P00CA

Bundle Name: FourWheelDriveLowStateInvalid

## **Fault Bundle Definitions**

P2771

Bundle Name: FPSR\_b\_SENT\_WaveForm\_FPBndl

P128F, P16E4, P16E5

Bundle Name: FTP SensorCircuit FA

P0452, P0453

Bundle Name: FuelInjectorCircuit FA

PFI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P0274, P0277, P0280, P0283 SIDI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0273, P0276, P0279, P0282, P0265, P0265, P0268, P0271, P0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216B, P217B, P217E, P2148, P2151, P2154, P2157, P216C,

P216F, P217C, P217F, P1248, P1249, P124A, P124B, P124C, P124D, P124E, P124F

Bundle Name: FuelInjectorCircuit\_TFTKO

PFI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P0274, P0277, P0280, P0283 SIDI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0265, P0265, P0268, P0271, P0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216B, P217B, P217B, P2148, P2151, P2154, P2157, P216C, P216F, P217C, P217F, P1248, P1249, P124B, P124B, P124D, P124E, P124F

Bundle Name: FuelLevelDataFault

P0461, P0462, P0463, P2066, P2067, P2068

Bundle Name: FuelPumpRlyCktFA

P0627, P0628, P0629

Bundle Name: FuelTankPressureSnsrCkt FA

P0452, P0453

Bundle Name: FuelTrimSystemB1\_FA

P0171, P0172, P11E9, P11EA

Bundle Name: FuelTrimSystemB1\_TFTKO

P0171, P0172, P11E9, P11EA

Bundle Name: FuelTrimSystemB2\_FA

P0174, P0175, P11EB, P11EC

Bundle Name: FuelTrimSystemB2\_TFTKO

P0174, P0175, P11EB, P11EC

Bundle Name: HumidityFA

P0097, P0098, P11C2, P11C3, P2227, P2228, P2229, P2230

Bundle Name: HumTempSnsrCktFA

P0097, P0098

Bundle Name: HumTempSnsrCktFP

P0097, P0098

**Bundle Name:** HumTempSnsrFA P0096, P0097, P0098, P0099

Bundle Name: IAC\_SystemRPM\_FA

P0506, P0507

# **Fault Bundle Definitions**

Bundle Name: IAT\_ContCorrFA

P2199

Bundle Name: IAT\_SensorCircuitFA

P0112, P0113

Bundle Name: IAT\_SensorCircuitFP

P0112, P0113

Bundle Name: IAT\_SensorCircuitTFTKO

P0112, P0113

**Bundle Name:** IAT\_SensorFA P0111, P0112, P0113, P0114

Bundle Name: IAT\_SensorTFTKO

P0111, P0112, P0113, P0114

Bundle Name: IgnitionOffTimer\_FA

P262B

Bundle Name: IgnitionOffTimeValid

P262B

Bundle Name: IgnitionOutputDriver\_FA

P0351, P0352, P0353, P0354, P0355, P0356, P0357, P0358, P2300, P2301, P2303, P2304, P2306, P2307, P2309, P2310, P2312, P2313, P2315, P2316,

P2318, P2319, P2321, P2322

Bundle Name: IntakeCamSensor FA

P0016, P0018, P0340, P0341, P0345, P0346

Bundle Name: IntakeCamSensor\_TFTKO

P0016, P0018, P0340, P0341, P0345, P0346

Bundle Name: IntakeCamSensorFA

P0016, P0018, P0340, P0341, P0345, P0346

Bundle Name: IntakeCamSensorTFTKO

P0016, P0018, P0340, P0341, P0345, P0346

Bundle Name: IntakeVVT\_Enabled

IntakeVVT Enabled - Other Definitions:

IntakeVVT\_Enabled = TRUE if:

DTCs not set:

CrankSensor TFTKO

IntakeCamSensor TFTKO

CamLctnIntFA

AND

CrankExhaustCamCorrelationFA diagnostic has executed and passed

# **Fault Bundle Definitions**

```
IAND
Cam Edge Locations have been learned
AND
[Catalyst Warmup Enabled = TRUE AND
Engine Speed > 450.00
                              AND
Engine Run Time > P0011 P0021 P05CC P05CD P0014 P0024 P05CE P05CF ColdStartEngRunning
OR
[Engine is running
                                      AND
Engine power is requested
                                      AND
IntEngineSpeed is Enabled (see below)
                                      AND
IntOilPressure is Enabled (see below)
                                      AND
IntEngineOilTemp is Enabled (see below) 1
IntEngineSpeed is Enabled if:
P0011_P0021_P05CC_P05CD_LoRpmHiEnbllc < Engine RPM < P0011_P0021_P05CC_P05CD_HiEngSpdLoEnbllc
IntEngineSpeed Disables if:
Engine RPM < P0011_P0021_P05CC_P05CD_LoRpmLoDsbllc
Engine RPM > P0011_P0021_P05CC_P05CD_HiEngSpdHiDsbllc
IntOilPressure is Enabled if:
(Oil Pressure Sensor In Use (0.00) = 1.00 (Note: 1.00 equals TRUE) AND
Oil Pressure Sensor Present (0.00) = 1.00 (Note: 1.00 equals Present) AND
Oil Pressure > P0011_P0021_P05CC_P05CD_LoPresHiEnbllc for P0011_P0021_P05CC_P05CD_EngOilPressEnbllc sec)
    OR
(Engine RPM > P0011_P0021_P05CC_P05CD_LoRpmHiEnbllc for P0011_P0021_P05CC_P05CD_EngOilPressEnbllc sec)
IntOilPressure Disables if:
(Oil Pressure Sensor In Use (0.00) = 1.00 (Note: 1.00 equals TRUE) AND
Oil Pressure Sensor Present (0.00) = 1.00 (Note: 1.00 equals Present) AND
Oil Pressure < P0011 P0021 P05CC P05CD LoPresLoDsbllc)
IntEngineOilTemp is Enabled if:
-20.00 < Engine Oil Temp < 155.00
IntEngineOilTemp Disables if:
Engine Oil Temp < -22.00
   OR
```

# **Fault Bundle Definitions**

Engine Oil Temp > 160.00

Bundle Name: IntkCamPhaser\_FA

P0010, P0011, P0020, P0021, P05CC, P05CD, P2088, P2089, P2092, P2093, P25CA, P25CB, P25CC, P25CD, P25CE, P25CF

Bundle Name: KS\_Ckt\_Perf\_B1B2\_FA

P0324, P0325, P0326, P0327, P0328, P0330, P0332, P0333, P06B6, P06B7

Bundle Name: LostCommBCM FA

U0140

Bundle Name: LostCommBusB\_VICM\_FA

U182D

Bundle Name: LowFuelConditionDiagnostic

**LowFuelConditionDiagnostic - Other Definitions:** Flag set to TRUE if the fuel level < 10.0 % AND

No Active DTCs: FuelLevelDataFault, P0462, P0463 for at least 30.0 seconds

Bundle Name: MAF SensorCircuitFA

P0102, P0103, P010C, P010D

Bundle Name: MAF\_SensorCircuitTFTKO

P0102, P0103, P010C, P010D

Bundle Name: MAF\_SensorFA

P0101, P0102, P0103, P010B, P010C, P010D

**Bundle Name:** MAF\_SensorFP P0102, P0103, P010C, P010D

Bundle Name: MAF\_SensorPerfFA

P0101

Bundle Name: MAF\_SensorPerfTFTKO

P0101

Bundle Name: MAF\_SensorTFTKO

P0101, P0102, P0103, P010B, P010C, P010D

Bundle Name: MAF\_Snsr1\_FA

P0101, P0102, P0103

Bundle Name: MAF Snsr2 FA

P010B, P010C, P010D

Bundle Name: MAF\_SnsrCktFA P0102, P0103, P010C, P010D

Bundle Name: MAF SnsrCktTFTKO

P0102, P0103, P010C, P010D

Bundle Name: MAP EngineVacuumStatus

P0106, P0107, P0108 Fault Active OR P0107, P0108 Fault Pending

## **Fault Bundle Definitions**

Bundle Name: MAP\_SensorCircuitFA

P0107, P0108

Bundle Name: MAP\_SensorCircuitFP

P0107, P0108

Bundle Name: MAP SensorFA

P0106, P0107, P0108

Bundle Name: MAP\_SensorPerfFA

P0106

Bundle Name: MAP SensorPerfTFTKO

P0106

Bundle Name: MAP SensorTFTKO

P0106, P0107, P0108

Bundle Name: MnfdTempSensorCktFA

Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.

Bundle Name: MnfdTempSensorCktFP

Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.

Bundle Name: MnfdTempSensorCktTFTKO

Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.

Bundle Name: MnfdTempSensorFA

Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099.

Naturally Aspirated: P0111, P0112, P0113, P0114.

Bundle Name: MnfdTempSensorTFTKO

Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099.

Naturally Aspirated: P0111, P0112, P0113, P0114.

Bundle Name: ModuleOffTime FA

P262B

Bundle Name: ModuleOffTimeErr

P262B

Bundle Name: O2S\_Bank\_ 1\_TFTKO

P0131, P0132, P0134, P2A00

Bundle Name: O2S Bank 2 TFTKO

P0151, P0152, P0154, P2A03

Bundle Name: O2S\_Bank\_1\_Sensor\_1\_FA

P2A00, P0131, P0132, P0133, P0134, P0135, P0053, P1133, P015A, P015B, P0030

Bundle Name: O2S Bank 1 Sensor 2 FA

P013A, P013B, P013E, P013F, P2270, P2271, P0137, P0138, P0140, P0141, P0054, P0036

Bundle Name: O2S Bank 2 Sensor 1 FA

P2A03, P0151, P0152, P0153, P0154, P0155, P0059, P1153, P015C, P015D, P0050

## **Fault Bundle Definitions**

Bundle Name: O2S\_Bank\_2\_Sensor\_2\_FA

P013C, P013D, P014A, P014B, P2272, P2273, P0157, P0158, P0160, P0161, P0060, P0056

Bundle Name: OAT\_AmbientFilteredFA

ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, IAT\_SensorFA, ECT\_Sensor\_DefaultDetected, MAF\_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, ECT\_Sensor\_DefaultDetected. IAT-Based OAT: not applicable. All other cases: not applicable.

Bundle Name: OAT\_AmbientSensorFA

ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, ECT\_Sensor\_DefaultDetected. IAT-Based OAT: not

applicable. All other cases: not applicable.

Bundle Name: OAT\_EstAmbTemp\_FA

ELCP sealed/vented fuel system, P0071, P0072, P0073, P0502, P0503, P0722, P0723 OR Conventional fuel system, P0071, P0072, P0073, P0074, P262B

Bundle Name: OAT\_PtEstFiltFA

ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, IAT\_SensorFA, ECT\_Sensor\_DefaultDetected, MAF\_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, ECT\_Sensor\_DefaultDetected. IAT-Based OAT: VehicleSpeedSensor\_FA, IAT\_SensorFA, MAF\_SensorFA. All other cases: EngModeNotRunTmErr, VehicleSpeedSensor\_FA, IAT\_SensorFA, ECT\_Sensor\_DefaultDetected.

Bundle Name: OAT PtEstRawFA

ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, ECT\_Sensor\_DefaultDetected. IAT-Based OAT: IAT\_SensorFA. All other cases: IAT\_SensorFA, ECT\_Sensor\_DefaultDetected.

Bundle Name: OilPmpCktFA

P06DA, P06DB, P06DC

OilPmpCktFA - Other Definitions:

Output Driver Codes

Bundle Name: OilPmpFA

P06DA, P06DB, P06DC, P06DD, P06DE

OilPmpFA - Other Definitions:

FA only for Output Driver and rationality

Bundle Name: OilPmpStuckHigh

P06DA, P06DB, P06DD

OilPmpStuckHigh - Other Definitions:

TFTKO and FA

Bundle Name: OilPmpStuckLow

P06DC, P06DE

OilPmpStuckLow - Other Definitions:

TFTKO and FA

Bundle Name: OilPmpTFTKO

P06DA, P06DB, P06DC, P06DD, P06DE

OilPmpTFTKO - Other Definitions:

TFTKO only for Output Driver and rationality

Bundle Name: OilSenDiagBndl\_TFTKO

P055B, P055C, P055D

Bundle Name: PO2S Bank 1 Snsr 2 FA

# **Fault Bundle Definitions**

P0137, P0138, P0140, P0036, P0054, P0141, P2270, P2271

Bundle Name: PO2S\_Bank\_2\_Snsr\_2\_FA

P0157, P0158, P0160, P0056, P0060, P0161, P2272, P2273

Bundle Name: PostCatAltFuelTrimHiB1 TFTKO

P11F0

Bundle Name: PostCatAltFuelTrimHiB2\_TFTKO

P11F2

Bundle Name: PostCatAltFuelTrimLoB1\_TFTKO

P11EF

Bundle Name: PostCatAltFuelTrimLoB2\_TFTKO

P11F1

Bundle Name: PostCatFuelTrimB1\_TFTKO

P11EF, P11F0, P2096, P2097

Bundle Name: PostCatFuelTrimB2\_TFTKO

P11F1, P11F2, P2098, P2099

Bundle Name: PostCatFuelTrimHiB1

P2097, P11F0

Bundle Name: PostCatFuelTrimHiB1\_TFTKO

P2097

Bundle Name: PostCatFuelTrimHiB2

P2099, P11F2

Bundle Name: PostCatFuelTrimHiB2\_TFTKO

P2099

Bundle Name: PostCatFuelTrimLoB1

P2096, P11E9

Bundle Name: PostCatFuelTrimLoB1\_TFTKO

P2096

Bundle Name: PostCatFuelTrimLoB2

P2098, P11F1

Bundle Name: PostCatFuelTrimLoB2 TFTKO

P2098

Bundle Name: PowertrainRelayFault

P1682

Bundle Name: PowertrainRelayStateOn\_Error

P0685

Bundle Name: PowertrainRelayStateOn\_FA

P0685

Bundle Name: PPS1\_OutOfRange

# **Fault Bundle Definitions** P2122, P2123 Bundle Name: PPS1\_OutOfRange\_Composite P2122, P2123, P06A3 Bundle Name: PPS2\_OutOfRange P2127, P2128 Bundle Name: PPS2\_OutOfRange\_Composite P2127, P2128, P0697 Bundle Name: SCIAP\_SensorCircuitFA P012C, P012D Bundle Name: SCIAP SensorCircuitFP P012C, P012D Bundle Name: SCIAP\_SensorFA P012B, P012C, P012D Bundle Name: SCIAP\_SensorPerfFA P012B Bundle Name: SCIAP\_SensorPerfTFTKO P012B Bundle Name: SCIAP\_SensorTFTKO P012B, P012C, P012D Bundle Name: SuperchargerBypassValveFA P2261 Bundle Name: SystemVoltageHigh\_FA P0563 Bundle Name: SystemVoltageLow\_FA P0562 Bundle Name: TC BoostPresSnsrCktFA P0237, P0238 Bundle Name: TC BoostPresSnsrFA P0236, P0237, P0238 Bundle Name: TCM\_EngSpdReqCkt P150C Bundle Name: THMR AHV FA P2681, P26A3, P26A6, P26A7, P26A9 THMR\_AHV\_FA - Other Definitions:

Bundle Name: THMR\_AWP\_AuxPumpFA

Bundle Name: THMR ECT Sensor Ckt FA

B269A, B269C, B269D

## **Fault Bundle Definitions**

P0116, P0117, P0118, P0119, P111E

Bundle Name: THMR Insuff Flow FA

P00B7

Bundle Name: THMR RCT Sensor Ckt FA

P00B3, P00B4

Bundle Name: THMR SWP Control FA

P261A, P261D, P261C

Bundle Name: THMR\_SWP\_FlowStuckOn\_FA

P261A, P261D, P261E

Bundle Name: THMR SWP NoFlow FA

P261B, P261C

Bundle Name: THMR Therm Control FA

P0597, P0598, P0599

Bundle Name: ThrotTempSensorFA

Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099.

Naturally Aspirated: P0111, P0112, P0113, P0114.

Bundle Name: ThrotTempSensorTFTKO

Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099.

Naturally Aspirated: P0111, P0112, P0113, P0114.

Bundle Name: ThrottlePositionSnsrPerfFA

P0121

Bundle Name: ThrottlePositionSnsrPerfTFTKO

P0121

Bundle Name: TIAP SensorPerfFA

P0236

Bundle Name: TPS FA

P0122, P0123, P0222, P0223, P16A0, P16A1, P16A2, P2135

Bundle Name: TPS\_FaultPending

P0122, P0123, P0222, P0223, P16A0, P16A1, P16A2, P2135

Bundle Name: TPS Performance FA

P0068, P0121, P1104, P2100, P2101, P2102, P2103

Bundle Name: TPS\_Performance\_TFTKO

P0068, P0121, P1104, P2100, P2101, P2102, P2103

**Bundle Name: TPS TFTKO** 

P0122, P0123, P0222, P0223, P16A0, P16A1, P16A2, P2135

Bundle Name: TPS\_ThrottleAuthorityDefaulted

P0068, P0122, P0123, P0222, P0223, P16F3, P16A0, P16A1, P16A2, P1104, P2100, P2101, P2102, P2103, P2135

Bundle Name: TPS1\_OutOfRange\_Composite

## **Fault Bundle Definitions**

P0122, P0123, P06A3, P16A0, P16A1, P16A2

Bundle Name: TPS2\_OutOfRange\_Composite

P0222, P0223, P06A3, P16A0, P16A1, P16A2

Bundle Name: Trans Output Rotations Rolling Count Validity

P0722, P0723, P077C, P077D

Bundle Name: TransActualGearValidity

P182E, P1915

Bundle Name: Transfer Pump is Commanded On

#### Transfer Pump is Commanded On - Other Definitions:

Fuel Volume in Primary Fuel Tank < 0.0 liters AND

Fuel Volume in Secondary Fuel Tank? 0.0 liters AND

Transfer Pump on Time < P0461, P2066, P2636: Transfer Pump Enable (see supporting table for numeric value) AND

Transfer Pump had been Off for at least 0.0 seconds AND

Evap Diagnostic (Purge Valve Leak Test, Large Leak Test, and Waiting for Purge) is not running AND

Engine Running

Bundle Name: Transmission Actual Gear Validity

P182E, P1915

Bundle Name: Transmission Engaged State Validity

P182E, P1915

**Bundle Name:** Transmission Estimated Gear Validity

P182E, P1915

**Bundle Name:** Transmission Gear Ratio Validity

P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0

**Bundle Name:** Transmission Gear Selector Position Validity

P182E, P1915

**Bundle Name:** Transmission Oil Temperature Validity

P0667, P0668, P0669, P0711, P0712, P0713

Bundle Name: Transmission Output Shaft Angular Velocity Validity

P0722, P0723, P077C, P077D

Bundle Name: Transmission Overall Actual Torque Ratio Validity

P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P182E, P1915

Bundle Name: Transmission Overall Estimated Torque Ratio Validity

P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P182E, P1915

**Bundle Name:** Transmission Shift Lever Position Validity

P182E, P1915

**Bundle Name:** Transmission Turbine Angular Velocity Validity

P0716, P0717, P07BF, P07C0

Bundle Name: TransmissionEngagedState FA

# **Fault Bundle Definitions**

P182E, P1915

Bundle Name: TransmissionGearDefaulted

P182E, P1915

Bundle Name: TransmissionOutputRotationalStatusValidity

P0722, P0723, P077C, P077D

Bundle Name: TransmissionRatioControlSystemFault

P0751, P0752, P0756, P0757, P0973, P0974, P0976, P0977

Bundle Name: TwoStepMechBndl\_FA

P2646, P2647, P16D0, P16D1

Bundle Name: TwoStepMechBndl\_TFTKO

P2646, P2647, P16D0, P16D1

Bundle Name: VCER\_TorqueSecurity

P16F3

VCER\_TorqueSecurity - Other Definitions:

P16F3 with GetXOYR\_b\_SecurityFlt(CeXOYR\_e\_AFM\_PreloadAreaFlt, CeXOYR\_e\_AFM\_PreloadTimerFlt, CeXOYR\_e\_AFM\_DualPreloadAreaFlt, CeXOYR\_e\_CDAR\_SecurityFlt)

Bundle Name: VehicleSpeedSensor\_FA

P0502, P0503, P0722, P0723

Bundle Name: VehicleSpeedSensorError

P0502, P0503, P0722, P0723

Bundle Name: VentCircuit FA

ELCP sealed/vented fuel system, P0449, P0498, P0499

Bundle Name: VICM\_WakeupDiag\_FA

P06E4

Bundle Name: VICM\_WakeupDiag\_TFTKO

P06E4

Bundle Name: VITR\_LVT\_FltBndl

P058B, P058D, P118C, P118D