

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Intake Camshaft Actuator Solenoid Circuit Open – Bank 1	P0010	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power  Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply voltage is within limits  Output driver is commanded on  Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples  250 ms /sample, continuous	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Performance – Bank 1	P0011	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Intake cam Bank 1) Cam Position Error > (P0011_CamPosErrorLimlc1) deg	System Voltage Engine Running Power Take Off (PTO) active Desired cam position Desired AND Measured cam position Desired cam position variation No Active DTCs Bundle: IntakeVVT_Enabled	> 11.00 Volts = TRUE = FALSE > 0 deg > (P0011_CamPosErrorLimlc1) deg AND < (P0011_PerfMaxlc1) deg < 7.50 Deg for (P0011_P05CC_StablePositionTimeIc1) sec P0010 P2088 P2089 = TRUE (Reference Supporting Tables: P0011_P0021_P05CC_P05CD_HiEngSpdHiDsblIc P0011_P0021_P05CC_P05CD_HiEngSpdLoEnblIc P0011_P0021_P05CC_P05CD_LoRpmHiEnblIc P0011_P0021_P05CC_P05CD_LoRpmLoDsblIc P0011_P0021_P05CC_P05CD_LoPresHiEnblIc P0011_P0021_P05CC_P05CD_LoPresLoDsblIc	100.00 failures out of 1,000.00 samples 100 ms /sample	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						P0011_P0021_P05CC_P 05CD_EngOilPressEnbl c P0011_P0021_P05CC_P 05CD_P0014_P0024_P0 5CE_P05CF_ColdStartE ngRunning  Reference Fault Bundles: CrankIntakeCamCorrFA IntakeCamSensorTFTK O CrankSensorTFTKO CamLctnIntFA)		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)- Camshaft Position (CMP) Correlation Bank 1 Sensor A	P0016	Detects cam to crank misalignment by monitoring if cam sensor pulse for bank 1 sensor A occurs during the incorrect crank position	2 cam sensor pulses more than -11.0 crank degrees before or 11.0 crank degrees after nominal position in one cam revolution.		Crankshaft and camshaft position signals are synchronized  Engine is Spinning  Cam phaser is in "parked" position  No Active DTCs:  Time since last execution of diagnostic	P0335, P0336 P0340,P0341   < 1.0 seconds	2 failures out of 3 tests.  A failed test is 4 failures out of 5 samples.  There is a delay after the first failed test to allow the camshaft position to return to the park position.  This time is defined by the table "P0016_P0017_ P0018_P0019_ Cam Correlation Oil Temperature Threshold".  One sample per cam rotation	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
O2S Heater Control Circuit Bank 1 Sensor 1	P0030	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controlle rs P0031 may also set

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
O2S Heater Control Circuit Bank1 Sensor1	P0031	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short- to-ground).	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controlle rs P0030 may also set

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0032	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power).	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
O2S Heater Control Circuit Bank 1 Sensor 2	P0036	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit).	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controlle rs P0037 may also set



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
O2S Heater Control Circuit Bank1 Sensor2	P0037	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short- to-ground).	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controlle rs P0036 may also set

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
O2S Heater Control Circuit Bank1 Sensor2	P0038	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power).	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
O2S Heater Control Circuit Bank 2 Sensor 1	P0050	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit).	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controlle rs P0051 may also set

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
O2S Heater Control Circuit Bank2 Sensor1	P0051	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short- to-ground).	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controlle rs P0050 may also set

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
O2S Heater Control Circuit Bank2 Sensor1	P0052	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power).	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
HO2S Heater Resistance Bank 1 Sensor 1	P0053	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	$3.1 < \Omega < 8.4$	No Active DTC's  Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,800 seconds -30.0 < °C < 45.0 < 32.0 volts < 0.04 seconds	Once per valid cold start	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
HO2S Heater Resistance Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0054	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	$3.1 < \Omega < 8.4$	No Active DTC's  Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,800 seconds -30.0 < °C < 45.0 < 32.0 volts < 0.04 seconds	Once per valid cold start	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
O2S Heater Control Circuit Bank 2 Sensor 2	P0056	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit).	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controllers P0057 may also set



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
O2S Heater Control Circuit Bank2 Sensor2	P0057	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short- to-ground).	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controlle rs P0056 may also set

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank2 Sensor2	P0058	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power).	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
HO2S Heater Resistance Bank 2 Sensor 1	P0059	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	$3.4 < \Omega < 8.6$	No Active DTC's  Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,800 seconds -30.0 < °C < 45.0 < 32.0 volts < 0.09 seconds	Once per valid cold start	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
HO2S Heater Resistance Bank 2 Sensor 2	P0060	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	$3.4 < \Omega < 8.6$	No Active DTC's  Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P2610 IAT_SensorFA < 8.0 °C > 28,800 seconds -30.0 < °C < 45.0 < 32.0 volts < 0.09 seconds	Once per valid cold start	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
MAP / MAF / Throttle Position Correlation	P0068	Detect when MAP and MAF do not match estimated engine airflow as established by the TPS	<p>Difference between MAP and estimated MAP exceeds threshold (kPa), or P0651 (5 Volt Ref), or P0107 (MAP circuit low), or P0108 (MAP circuit high) have failed this key cycle, then MAP portion of diagnostic fails</p> <p>Absolute difference between MAF and estimated MAF exceed threshold (grams/sec), or P0102 (MAF circuit low), or P0103 (MAF circuit hi) have failed this key cycle, or maximum MAF versus RPM (Table) is greater than or equal to maximum MAF versus battery voltage, then MAF portion of diagnostic fails</p>	<p>Table, f(TPS). See supporting tables: <b>Delta MAP Threshold f(TPS)</b></p> <p>Table, f(TPS). See supporting tables: <b>Delta MAF Threshold f(TPS)</b></p> <p>Table, f(RPM). See supporting tables: <b>Maximum MAF f (RPM)</b></p> <p>Table, f(Volts). See supporting tables: <b>Maximum MAF f (Volts)</b></p>	Engine Speed	<p>&gt; 800 RPM</p> <p>Run/Crank voltage &gt; 6.41</p>	<p>Continuously fail MAP and MAF portions of diagnostic for 0.1875 s</p> <p>Continuous in MAIN processor</p>	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Circuit Performance	P0071	Detects an OAT sensor that has stuck in range by comparing to IAT when conditions are appropriate	OAT-to-IAT engine off equilibrium counter	>= 300.0 counts	Time between current ignition cycle and the last time the engine was running	>= 28,800.0 seconds	Executed every 100 msec	Type B, 2 Trips
			(see below for description of this counter)		Engine is not running			
			If IAT >= OAT: IAT - OAT	> 15.0 deg C	Vehicle Speed	>= 15.5 MPH		
			If IAT < OAT: OAT - IAT	> 15.0 deg C	Coolant Temperature - IAT	< 15.0 degrees C		
			The "OAT-to-IAT engine off equilibrium counter" is a counter that is incremented or decremented based on vehicle speed when the engine is off. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared. The value that is added or subtracted to the counter every 100 msec is contained in table "P0071_OAT_Performance_Drive_Equilibrium_Engine_Off".		IAT - Coolant Temperature	< 15.0 degrees C		
					No Active DTCs:	VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_DefaultDetected MAF_SensorFA EngModeNotRunTmErr		
			OAT-to-IAT engine running equilibrium counter	>= 300.0 counts	Engine is running		Executed every 100 msec	
			(see below for description of this counter)		Vehicle Speed	>= 15.5 MPH		
			If IAT >= OAT: IAT - OAT	> 15.0 deg C	Engine air flow	>= 10.0 grams/second		
			If IAT < OAT:		No Active DTCs:	VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_DefaultDetected MAF_SensorFA		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>OAT - IAT</p> <p>The "OAT-to-IAT engine running equilibrium counter" is a counter that is incremented or decremented based on vehicle speed and engine air flow when the engine is running. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared. The value that is added or subtracted to the counter every 100 msec is contained in table "P0071_OAT_Performance_Drive_Equilibrium_Engine_Running".</p>	<p>&gt; 15.0 deg C</p>		<p>EngModeNotRunTmErr</p>		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Outside Air Temperature (OAT) Sensor Circuit Low	P0072	Detects a continuous short to ground in the OAT signal circuit or the OAT sensor	Raw OAT Input	<= 52 Ohms (~150 deg C)	Continuous		40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Outside Air Temperature (OAT) Sensor Circuit High	P0073	Detects a continuous open circuit in the OAT signal circuit or the OAT sensor	Raw OAT Input	>= 403,672 Ohms (~-60 deg C)	Continuous		40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Outside Air Temperature (OAT) Sensor Intermittent In-Range	P0074	Detects a noisy or erratic OAT signal circuit or OAT sensor	String Length  Where:  "String Length" = sum of "Diff" calculated over  And where: "Diff" = ABS(current OAT reading - OAT reading from 100 milliseconds previous)	> 100 DegC   25 consecutive OAT samples		Continuous	4 failures out of 5 samples  Each sample takes 2.50 seconds	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module SIDI High Pressure Pump min/ max authority	P0089	This DTC Diagnoses pump control windup to its max or min authority	High Pressure Fuel Pump Delivery Angle  High Pressure Fuel Pump Delivery Angle	$\geq 130^\circ$  Or $\leq 0^\circ$	Battery Voltage  Low Side Fuel Pressure  Engine Run Time    Barometric Pressure Inlet Air Temp  Fuel Temp  Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition	$\geq 11$ Volts  $> 0.275$ MPa  $\geq$ KtFHPD_t_PumpCntrlEng RunThrsh (see supporting tables) Enabled when a code clear is not active or not exiting device control Engine is not cranking  $\geq 70.0$ KPA $\geq -10.0$ degC  $-10 \leq \text{Temp degC} \leq 100$	Windup High -  750 failures out of 938 samples  Windup Low -  750 failures out of 938 Samples	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active			

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
High Pressure Pump Control Solenoid Enable Low Side Open Circuit	P0090	The DTC Diagnoses the High Pressure Pump Control Solenoid Enable Low Side Circuit for circuit faults.	Voltage low during driver off state indicates open circuit	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	Engine Speed  Battery Voltage	>= 50 RPM  >= 11 Volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
High Pressure Pump Control Solenoid Enable Low Side Short to Ground	P0091	The DTC Diagnoses the High Pressure Pump Control Solenoid Enable Low Side Circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground	Short to ground: ≤ 0.1 Amps between signal and controller ground	Engine Speed  Battery Voltage	>= 50 RPM  >= 11 Volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
High Pressure Pump Cntrl Solenoid Enable Low Side Short to Power	P0092	The DTC Diagnoses the High Pressure Pump Control Solenoid Enable Low Side Circuit for circuit faults.	Voltage high during driver off state indicates short to power	Short to power: ≤ 1.1 or 15 Amps selectable thershold based on High pressure Pump .	Engine Speed  Battery Voltage	>= 50 RPM >= 11 Volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Intake Air Temperature Sensor 2 Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0096	Detects an IAT2 sensor that has stuck in range by comparing to IAT and engine coolant temperature at startup	ABS(Power Up IAT - Power Up IAT2)  AND  ABS(Power Up ECT – Power Up IAT2) >= ABS(Power Up ECT – Power Up IAT)	> 25 deg C	Time between current ignition cycle and the last time the engine was running  Powertrain Relay Voltage for a time  No Active DTCs:	> 28,800 seconds  >= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Intake Air Temperature Sensor Circuit 2 Low (applications with humidity)	P0097	Detects a continuous short to ground or open in the IAT 2 signal circuit	Raw IAT 2 Input	< 13 Hertz (~-60 deg C)	Powertrain Relay Voltage for a time  No Active DTCs:	>= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Intake Air Temperature Sensor Circuit 2 High (applications with humidity)	P0098	Detects a continuous high frequency in the IAT 2 signal circuit	Raw IAT 2 Input	> 390 Hertz (~150 deg C)	Powertrain Relay Voltage for a time  No Active DTCs:	>= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Intake Air Temperature Sensor 2 Intermittent In-Range	P0099	Detects a noisy or erratic IAT 2 signal circuit or IAT 2 sensor	String Length  Where: "String Length" = sum of "Diff" calculated over  And where: "Diff" = ABS(current IAT 2 reading - IAT 2 reading from 100 milliseconds previous)	> 100.00 DegC  10 consecutive IAT 2 samples	Powertrain Relay Voltage for a time  No Active DTCs:	>= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault	4 failures out of 5 samples  Each sample takes 1.0 seconds	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Start Diagnostic	P00C6	The DTC Diagnoses the high side fuel pressure during engine cranking.	The ECM detects that the fuel pressure is not rising or has fallen beyond acceptable limits during engine cranking	<p>Pressure Fall Test: High Side Fuel Rail Pressure &lt;= Supporting Table KtFHPD_p_HPS_PressFallLoThrsh</p> <p>Pressure Rise Test: High Side Fuel Pressure &lt; Supporting Table KtFHPC_p_HighPressStart</p>	<p>Low side feed fuel pressure</p> <p>Engine Run Time Run/Crank Voltage Engine Coolant</p> <p>For each engine start, only 1 diagnostic is performed. The pressure rise test will run if High side fuel pressure is less than KtFHPC_p_HighPressStart, otherwise, the pressure fall diagnostic will run. The pressure fall runs when the engine is cranking.</p>	<p>&gt;= 0 KPA</p> <p>&lt; = 0 sec &gt; 8 Volts -100 &lt;= °C &lt;= 65</p> <p>All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT, IAT2 and ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and Manufacturers enable</p>	<p>Pressure Fall Test: Injected cylinder events &gt;= Supporting Table KtFHPD_Cnt_HPS_PressFallLoThrsh</p> <p>Pressure Rise Test: Time &gt;= Supporting Table KtFHPC_t_HighPressStartTmout</p>	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Barometric Pressure Inlet Air Temp	counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active >= 70.0 KPA >= -10.0 DegC		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Press Regulator Solenoid Supply Voltage Control High Side Circuit Open	P00C8	The DTC Diagnoses the Fuel Press Regulator Solenoid Supply Voltage Control Circuit for circuit faults.	Voltage High during driver off state indicates open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Press Regulator Solenoid Supply Voltage Control High Side Circuit Short to ground	P00C9	The DTC Diagnoses the Fuel Press Regulator Solenoid Supply Voltage Control Circuit for circuit faults.	Voltage low during driver on state indicates short to ground	Short to ground: ≤ 1.1 or 15 Amps selectable thershold based on High pressure Pump.	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Press Regulator Solenoid Supply Voltage Control High Side Circuit Short to power	P00CA	The DTC Diagnoses the Fuel Press Regulator Solenoid Supply Voltage Control Circuit for circuit faults.	Voltage high during driver off state indicates short to power	Short to Power: ≤ 0.1 Amps between signal and controller power	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Humidity Sensor Circuit Low	P00F4	Detects a continuous short to power in the Humidity Sensor circuit	Humidity Duty Cycle	<= 5.0 %	Powertrain Relay Voltage for a time  No Active DTCs:	>= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Humidity Sensor Circuit High	P00F5	Detects a continuous open or short to low in the Humidity Sensor circuit	Humidity Duty Cycle	>= 95.0 %	Powertrain Relay Voltage for a time  No Active DTCs:	>= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Humidity Sensor Circuit Intermittent	P00F6	Detects a noisy or erratic humidity sensor input	String Length  Where: "String Length" = sum of "Diff" calculated over  And where: "Diff" = ABS(current Humidity reading - Humidity reading from 100 milliseconds previous)	> 80 %  10 consecutive Humidity samples	Powertrain Relay Voltage for a time  No Active DTCs:	>= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault	4 failures out of 5 samples  Each sample takes 1.00 seconds	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (naturally aspirated)	P0101	Determines if the MAF sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 250 kPa*(g/s)  > 25.0 grams/sec  > 22.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 450 RPM <= 5,600 RPM >= -7 Deg C <= 129 Deg C >= -20 Deg C <= 129 Deg C  >= 0.50  Filtered Throttle Model Error multiplied by <b>TPS Residual Weight Factor based on RPM</b>  Modeled Air Flow Error multiplied by <b>MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est</b>  MAP Model 2 Error multiplied by <b>MAP2 Residual Weight Factor based on RPM</b>  See Residual Weight Factor tables.  No Active DTCs:  MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA  No Pending DTCs:  EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP	Continuous  Calculation are performed every 12.5 msec	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit Low Frequency	P0102	Detects a continuous short to low or a open in either the signal circuit or the MAF sensor	MAF Output	<= 1,000 Hertz (~ 1.43 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 8.0 Volts  >= 1.0 seconds	400 failures out of 500 samples  1 sample every cylinder firing event	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Mass Air Flow Sensor Circuit High Frequency	P0103	Detects a high frequency output from the MAF sensor	MAF Output	>= 14,500 Hertz (~ 1233.0 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 8.0 Volts  >= 1.0 seconds	400 failures out of 500 samples  1 sample every cylinder firing event	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (naturally aspirated)	P0106	Determines if the MAP sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 250 kPa*(g/s)	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 450 RPM <= 5,600 RPM >= -7 Deg C <= 129 Deg C >= -20 Deg C <= 129 Deg C  >= 0.50  Filtered Throttle Model Error multiplied by <b>TPS Residual Weight Factor based on RPM</b>  MAP Model 1 Error multiplied by <b>MAP1 Residual Weight Factor based on RPM</b>  MAP Model 2 Error multiplied by <b>MAP2 Residual Weight Factor based on RPM</b>  See Residual Weight Factor tables.	Continuous  Calculations are performed every 12.5 msec	Type B, 2 Trips
			Manifold Pressure OR	< 50.0 kPa	Time between current ignition cycle and the last	4 failures out of 5 samples		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Manifold Pressure	> 115.0 kPa	time the engine was running  Engine is not rotating  No Active DTCs:  No Pending DTCs:	> 5.0 seconds  EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA  MAP_SensorCircuitFP AAP_SnsrCktFP	1 sample every 12.5 msec	



### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit Low	P0107	Detects a continuous short to low or open in either the signal circuit or the MAP sensor.	MAP Voltage	< 3.0% of 5 Volt Range (This is equal to 0.15 Volts or 3.5 kPa)	Continuous		320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Manifold Absolute Pressure Sensor Circuit High	P0108	Detects an open sensor ground or continuous short to high in either the signal circuit or the MAP sensor.	MAP Voltage	> 90.0% of 5 Volt Range (This is equal to 4.50 Volts, or 115.1 kPa)	Continuous		320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Intake Air Temperature Sensor Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0111	Detects an IAT sensor that has stuck in range by comparing to IAT2 and engine coolant temperature at startup	ABS(Power Up IAT - Power Up IAT2)  AND  ABS(Power Up ECT – Power Up IAT) > ABS(Power Up ECT – Power Up IAT2)	> 25 deg C	Time between current ignition cycle and the last time the engine was running  Powertrain Relay Voltage for a time  No Active DTCs:	> 28,800 seconds  >= 11.00 Volts >= 0.9 seconds  PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA HumTempSnsrCktFA	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Intake Air Temperature Sensor Circuit Low	P0112	Detects a continuous short to ground in the IAT signal circuit or the IAT sensor	Raw IAT Input	< 58 Ohms (~150 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Intake Air Temperature Sensor Circuit High	P0113	Detects a continuous open circuit in the IAT signal circuit or the IAT sensor	Raw IAT Input	> 142,438 Ohms (~-60 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Intake Air Temperature Sensor Intermittent In-Range	P0114	Detects a noisy or erratic IAT signal circuit or IAT sensor	String Length  Where: "String Length" = sum of "Diff" calculated over  And where: "Diff" = ABS(current IAT reading - IAT reading from 100 milliseconds previous)	> 80.00 DegC  10 consecutive IAT samples	Continuous		4 failures out of 5 samples  Each sample takes 1.0 seconds	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Performance	P0116	This DTC detects ECT temp sensor stuck in mid range.	<p>A failure will be reported if any of the following occur:</p> <p>1) ECT at power up &gt; IAT at power up by an IAT based table lookup value after a minimum 28,800 second soak (fast fail).</p> <p>2) ECT at power up &gt; IAT at power up by 19.3 C after a minimum 28,800 second soak and a block heater has not been detected.</p> <p>3) ECT at power up &gt; IAT at power up by 19.3 C after a minimum 28,800 seconds soak and the time spent cranking the engine without starting is greater than 10.0 seconds with the LowFuelConditionDiag</p>	<p>See "<b>P0116_Fail if power up ECT exceeds IAT by these values</b>" in the Supporting tables section</p> <p>= False</p>	<p>No Active DTC's</p> <p>Non-volatile memory initialization</p> <p>Test complete this trip Test aborted this trip IAT LowFuelCondition Diag</p> <p>=====</p> <p>Block Heater detection is enabled when either of the following occurs:</p> <p>1) ECT at power up &gt; IAT at power up by</p> <p>2) Cranking time</p> <p>=====</p> <p>Block Heater is detected and diagnostic is aborted when 1) or 2) occurs:</p> <p>1a) Vehicle drive time</p> <p>1b) Vehicle speed</p> <p>1c) Additional Vehicle drive time is provided to 1a when Vehicle speed is below 1b as follows:</p>	<p>VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_Ckt_FA IgnitionOffTime Valid TimeSinceEngineRunning Valid</p> <p>= Not occurred</p> <p>= False = False ≥ -7 °C</p> <p>= False</p> <p>=====</p> <p>&gt; 19.3 °C</p> <p>&lt; 10.0 seconds</p> <p>=====</p> <p>&gt; 400 seconds</p> <p>with &gt; 14.9 MPH</p> <p>0.00 times the seconds with vehicle speed below 1b</p>	<p>1 failure</p> <p>500 msec/ sample</p> <p>Once per valid cold start</p>	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					1d) IAT drops from power up IAT  2a) ECT drops from power up ECT  2b) Engine run time  ===== Diagnostic is aborted when 3) or 4) occurs:  3) Engine run time with vehicle speed below 1b  4) Minimum IAT during test	$\geq 3.3^{\circ}\text{C}$  $\geq 1^{\circ}\text{C}$  Within $\leq 30$ seconds  =====  $> 1800$ seconds  $\leq -7^{\circ}\text{C}$		



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Engine Coolant Temp Sensor Circuit Low	P0117	Circuit Continuity This DTC detects a short to ground in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ 150°C)	< 45 Ohms			5 failures out of 6 samples  1 sec/ sample  Continuous	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit High	P0118	Circuit Continuity This DTC detects a short to high or open in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ -60°C)	> 419,000 Ohms	Engine run time OR IAT min	> 10.0 seconds  ≥ -7.0 °C	5 failures out of 6 samples  1 sec/ sample  Continuous	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Circuit Intermittent	P0119	Circuit Continuity This DTC detects large step changes in the ECT signal circuit or the ECT sensor. Allowable high and low limits are calculated for the next sample based on the previous sample.	ECT temperature step change:  1) positive step change is greater than calculated high limit  OR  2) negative step change is lower than calculated low limit.  The calculated high and low limits for the next reading use the following calibrations: 1) Sensor time constant 2) Sensor low limit 3) Sensor high limit  *****Generic Example*****  If the last ECT reading was 90 Deg C, the Time constant was calibrated at 10 seconds, the low limit was calibrated to -80 Deg C and the high limit was calibrated to 200 Deg C the calculated limits are 101 Deg C and 73 Deg C.  The next reading (after the 90 Deg C reading) must be between 73 Deg C and 101 Deg C to be valid.	13.0 seconds -70.0 Deg C 180.0 Deg C	No Active DTC's	ECT_Sensor_Ckt_FP	3 failures out of 4 samples  1 sec/ sample  Continuous	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			*****					

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (naturally aspirated)	P0121	Determines if the Throttle Position Sensor input is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	> 250 kPa*(g/s)  > 25.0 grams/sec  <= 22.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 450 RPM <= 5,600 RPM > -7 Deg C < 129 Deg C > -20 Deg C < 129 Deg C  >= 0.50  Filtered Throttle Model Error multiplied by <b>TPS Residual Weight Factor based on RPM</b>  Modeled Air Flow Error multiplied by <b>MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est</b>  See Residual Weight Factor tables.  No Active DTCs:  MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA  No Pending DTCs:  EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP	Continuous  Calculation are performed every 12.5 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
TPS1 Circuit Low	P0122	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage <	0.3250		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
TPS1 Circuit High	P0123	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage >	4.750		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature Below Stat Regulating Temperature ) (energy based "Deluxe" method	P0128	This DTC detects if the engine coolant temperature rises too slowly due to an ECT or Cooling system fault	<p>Energy is accumulated after the first combustion event using Range #1 or #2 below:</p> <p>Thermostat type is divided into normal (non-heated) and electrically heated.</p> <p>For this application the "type" cal (KeTHMG_b_TMS_ElectHstEquipped) = 0 If the type cal is equal to one, the application has an electrically heated t-stat, if equal to zero the the application has a non heated t-stat. See appropriate section below.</p> <p>***** Type cal above = 1 (Electrically heated t-stat) == == == == Range #1 (Primary) ECT reaches Commanded temperature minus 11 °C when Ambient min is ≤ 52 °C and &gt; 10 °C. Note: Warm up target for range #1 will be at least 65 °C == == == == Range #2 (Alternate) ECT reaches Commanded temperature minus 11 °C when Ambient min is ≤ 10 °C and &gt; -7 °C. Note: Warm up target for range #2 will be at least</p>	<p>See the two tables named: <b>P0128_Maximum Accumulated Energy for Start-up ECT conditions - Primary</b> and <b>P0128_Maximum Accumulated Energy for Start-up ECT conditions - Alternate</b> in the Supporting tables section.</p> <p>This diagnostic models the net energy into and out of the cooling</p>	<p>No Active DTC's</p> <p>Engine not run time (soaking time before current trip)</p> <p>Engine run time</p> <p>Fuel Condition</p> <p>Distance traveled</p> <p>***** If Engine RPM is continuously greater than for this time period</p> <p>The diagnostic test for this key cycle will abort *****</p> <p>***** If T-Stat Heater commanded duty cycle for this time period</p> <p>The diagnostic test for this</p>	<p>ECT_Sensor_Ckt_FA ECT_Sensor_Perf_FA VehicleSpeedSensor_FA OAT_PtEstFiltFA IAT_SensorCircuitFA MAF_SensorFA THMR_AWP_AuxPumpFA THMR_AHV_FA THMR_SWP_Control_FA THMR_SWP_NoFlow_FA THMR_SWP_FlowStuckOn_FA ETQR_IndTorqInaccurate</p> <p>≥ 1,800 seconds</p> <p>75 ≤ Eng Run Tme ≤ 1,470 seconds</p> <p>Ethanol ≤ 87 %</p> <p>≥ 0.75 miles</p> <p>*****</p> <p>6,000 rpm 5.0 seconds</p> <p>*****</p> <p>&gt; 20.0% duty cycle &gt; 5.0 seconds</p>	<p>1 failure to set DTC</p> <p>1 sec/ sample</p> <p>Once per ignition key cycle</p>	Type B, 2 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			50 °C ***** Type cal above = 0 (non - heated t-stat) == == == == Range #1 (Primary) ECT reaches 65 °C when Ambient min is ≤ 52 °C and > 10 °C. == == == == Range #2 (Alternate) ECT reaches 50 °C when Ambient min is ≤ 10 °C and > -7 °C. *****	system during the warm-up process.  The five energy terms are: heat from combustion, heat from after-run, heat loss to enviroment, heat loss to cabin and heat loss to DFCO.	key cycle will abort  ***** ECT at start run	***** -60 ≤ ECT ≤ 60 °C		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 1	P0131	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 40.0 mVolts	No Active DTC's  AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active All Fuel Injectors for active Cylinders Fuel Condition Fuel State  All of the above met for	TPS_ThrottleAuthorityDef aulted MAP_SensorFA AIR_System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA = Not active = Not active = Not active = Not active 10.0 < Volts = Not active = Not active = Not active = Not active = False 0.9922 < ratio < 1.0137 50 < mgram < 700 = Closed Loop = TRUE  Enabled (On) Ethanol ≤ 87% DFCO not active  > 5.0 seconds	285 failures out of 350 samples  Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 1	P0132	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	No Active DTC's  System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum  Low Fuel Condition Diag  Initial delay after Open Test Criteria met (cold start condition)  Initial delay after Open Test Criteria met (not cold start condition)  Equivalence Ratio  All of the above met for	TPS_ThrottleAuthority Defaulted MAF_SensorFA MAP_SensorFA ExcessPurgePsbl_FA FuelInjectorCircuit_FA EthanolCompositionSens or_FA AIR System FA  10.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds  = False  > 235.0 seconds when engine soak time > 28,800 seconds  > 235.0 seconds when engine soak time ≤ 28,800 seconds  0.9922 ≤ ratio ≤ 1.0137  > 2.0 seconds	100 failures out of 125 samples  Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
O2S Slow Response Bank 1 Sensor 1) (For use with ESPD	P0133	This DTC determines if the O2 sensor response time is degraded.	<p>Fault condition present when the average response time is calculated over the test time, and compared to the threshold.</p> <p>OR</p> <p>Slope Time L/R Switches</p> <p>OR</p> <p>Slope Time R/L Switches</p>	<p>Refer to <b>P0133_O2S Slow Response Bank 1 Sensor 1 "Pass/Fail Threshold table"</b> in the Supporting Tables tab</p> <p>&lt; 3</p> <p>&lt; 3</p> <p>The test averages the signal response time over 60.0 seconds when the signal is transitioning between 300 mvolts and 600 mvolts. An average rich to lean time and lean to rich time are each calculated separately.</p>	<p>No Active DTC's</p> <p>Bank 1 Sensor 1 DTC's not active</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefault MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA EthanolCompositionSensor_FA EngineMisfireDetected_FA</p> <p>P0131, P0132, P0134</p> <p>10.0 &lt; Volts = Not active = Not active = Not active = Not active = False = Not Valid, See definition of <b>Multiple DTC Use_Green Sensor Delay Criteria - Airflow</b> and <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S1, B2S1 (if applicable)</p>	<p>Sample time is 60 seconds</p> <p>Frequency: Once per trip</p>	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					O2 Heater on for Learned Htr resistance  Engine Coolant IAT Engine run Accum  Time since any AFM status change Time since Purge On to Off change Time since Purge Off to On change  Engine airflow Engine speed Fuel Condition Baro Air Per Cylinder  Fuel Control State Closed Loop Active LTM fuel cell Transient Fuel Mass Baro Fuel Control State Fuel State Commanded Proportional Gain  ===== All of the above met for	in Supporting Tables tab.  ≥ 40 seconds = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" ) > 50 °C > -40 °C > 30 seconds  > 2.0 seconds > 1.0 seconds > 2.0 seconds  20 ≤ grams/second ≤ 55 1,000 ≤ RPM ≤ 3,000 < 87 % Ethanol > 70 kpa ≥ 200 mGrams  = Closed Loop = TRUE = Enabled ≤ 100.0 mgrams = Not Defaulted not = Power Enrichment DFCO not active  ≥ 0.0 %  ===== > 2.0 seconds		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
O2S Heater Performance Bank 1 Sensor 1	P0135	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.3 < Amps < 3.1	No Active DTC's  System Voltage Heater Warm-up delay O2S Heater device control  B1S1 O2S Heater Duty Cycle  All of the above met for	ECT_Sensor_FA  10.0 < Volts = Complete  = Not active  > zero  > 120 seconds	8 failures out of 10 samples  Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0137	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 50 mvolts	No Active DTC's  AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active All Fuel Injectors for active Cylinders Fuel Condition Fuel State  All of the above met for	TPS_ThrottleAuthorityDef aultedMAP_SensorFAAIR System FAEthanol Composition Sensor FAEvapPurgeSolenoidCir cuit_FAEvapFlowDuringN onPurge_FAEvapVentSol enoidCircuit_FAEvapSmal lLeak_FAEvapEmissionSy stem_FAFuelTankPressur eSnsrCkt_FAFuelInjector Circuit_FA = Not active = Not active = Not active = Not active 10.0 < Volts = Not active = Not active = Not active = Not active = False 0.9922 ≤ ratio ≤ 1.0137 50 ≤ mgrams ≤ 700 = Closed Loop = TRUE  Enabled (On) Ethanol <= 87 % DFCO not active  > 5.0 seconds	320 failures out of 400 samples  Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0138	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	No Active DTC's  System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum  Low Fuel Condition Diag  Initial delay after Open Test Criteria met (cold start condition)  Initial delay after Open Test Criteria met (not cold start condition)  Equivalence Ratio Fuel Control State  All of the above met for	TPS_ThrottleAuthorityDefaulted MAF_SensorFA MAP_SensorFA ExcessPurgePsbI_FA FuelInjectorCircuit_FA EthanolCompositionSens or_FA AIR System_FA  10.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds  = False  > 235.0 seconds when engine soak time > 28,800 seconds  > 235.0 seconds when engine soak time ≤ 28,800 seconds  0.9922 ≤ ratio ≤ 1.0137 not = Power Enrichment  > 2.0 seconds	100 failures out of 125 samples  Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Rich to Lean Bank 1 Sensor 2	P013A	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Rich to Lean voltages range during Rich to Lean transition. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Post O2 sensor normalized integral value  OR  The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units   > 70.0 grams (upper voltage threshold is 450 mvolts and lower voltage threshold is 150 mvolts)	No Active DTC's   B1S2 DTC's Not Active this key cycle  System Voltage Learned heater resistance   ICAT MAT Burnoff delay Green O2S Condition       Low Fuel Condition Diag  Post fuel cell (Decel) Crankshaft Torque	TPS_ThrottleAuthorityDefault ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013B, P013E, P013F, P2270 or P2271  10.0 < Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" ) = Not Valid = Not Valid, See definition of <b>Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.  = False  = enabled < 125.0 Nm	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					DTC's Passed  ===== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	P2270 (and P2272 if applicable) P013E (and P014A if applicable)  =====		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Lean to Rich Bank 1 Sensor 2	P013B	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Lean to Rich voltages range during Lean to Rich transition. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	The EWMA of the Post O2 sensor normalized integral value  OR  The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units   > 200 grams (lower voltage threshold is 350 mvolts and upper voltage threshold is 650 mvolts)	No Active DTC's   B1S2 DTC's Not Active this key cycle  System Voltage Learned heater resistance   ICAT MAT Burnoff delay  Green O2S Condition   Green Cat System Condition	TPS_ThrottleAuthorityDefault ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013A, P013E, P013F, P2270 or P2271  10.0 < Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )  = Not Valid  = Not Valid, See definition of <b>Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.  = Not Valid, System is not valid until accumulated airflow is greater than	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Low Fuel Condition Diag Post fuel cell</p> <p>DTC's Passed</p> <p>=====</p> <p>After above conditions are met: Fuel Enrich mode continued.</p> <p>=====</p> <p>During this test the following must stay TRUE or the test will abort: 0.95 ≤ Fuel EQR ≤ 1.10</p>	<p>720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False = enabled</p> <p>P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable) P013F (and P014B if applicable)</p> <p>=====</p>		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Rich to Lean Bank 2 Sensor 2	P013C	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Rich to Lean voltages range during Rich to Lean transition. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Post O2 sensor normalized integral value  OR  The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units   > 70.0 grams (upper voltage threshold is 450 mvolts and lower voltage threshold is 150 mvolts)	No Active DTC's   B2S2 DTC's Not Active this key cycle  System Voltage Learned heater resistance   ICAT MAT Burnoff delay  Green O2S Condition    Low Fuel Condition Diag  Post fuel cell (Decel)	TPS_ThrottleAuthorityDefault ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013D, P014A, P014B, P2272 or P2273  10.0 < Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )  = Not Valid  = Not Valid, See definition of <b>Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 in Supporting Tables tab.  = False  = enabled	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Crankshaft Torque  DTC's Passed  ===== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	< 125.0 Nm  P2270 (and P2272 if applicable) P013E (and P014A if applicable)  =====		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Lean to Rich Bank 2 Sensor 2	P013D	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Lean to Rich voltages range during Lean to Rich transition. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	The EWMA of the Post O2 sensor normalized integral value  OR  The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.0 units   > 200 grams (lower voltage threshold is 350 mvolts and upper voltage threshold is 650 mvolts)	No Active DTC's   B2S2 DTC's Not Active this key cycle  System Voltage Learned heater resistance   ICAT MAT Burnoff delay  Green O2S Condition   Green Cat System Condition	TPS_ThrottleAuthorityDefault ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013C, P014A, P014B, P2272 or P2273  10.0 < Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )  = Not Valid  = Not Valid, See definition of <b>Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 in Supporting Tables tab.  = Not Valid, System is not valid until accumulated airflow is greater than	Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Low Fuel Condition Diag Post fuel cell</p> <p>DTC's Passed</p> <p>=====</p> <p>After above conditions are met: Fuel Enrich mode continued.</p> <p>=====</p> <p>During this test the following must stay TRUE or the test will abort: 0.95 ≤ Fuel EQR ≤ 1.10</p>	<p>720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False = enabled</p> <p>P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable) P013F (and P014B if applicable)</p> <p>=====</p>		



### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 2	P013E	This DTC determines if the post catalyst O2 sensor has an initial delayed response to an A/F change from Rich to Lean. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	<p>Post O2 sensor voltage</p> <p>AND</p> <p>The Accumulated mass air flow monitored during the Delayed Response Test under DFCO</p> <p>DFCO begins after:                      1) Catalyst has been rich for a minimum of                      AND                      2) Catalyst Rich Accumulation Air Flow is greater or equal to</p>	<p>&gt; 450 mvolts</p> <p>&gt; 60 grams</p> <p>&gt; 1 secs</p> <p>&gt; 10 grams</p>	<p>No Active DTC's</p> <p>B1S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>ICAT MAT Burnoff delay</p> <p>Green O2S Condition</p> <p>Low Fuel Condition Diag</p> <p>Post fuel cell (Decel)</p>	<p>TPS_ThrottleAuthorityDefault                      ECT_Sensor_FA                      IAT_SensorFA                      MAF_SensorFA                      MAP_SensorFA                      AIR System FA                      FuelInjectorCircuit_FA                      FuelTrimSystemB1_FA                      FuelTrimSystemB2_FA                      EngineMisfireDetected_FA                      EthanolCompositionSensor_FA                      P013A, P013B, P013F, P2270 or P2271</p> <p>10.0 &lt; Volts                      = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>= Not Valid</p> <p>= Not Valid, See definition of <b>Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.</p> <p>= False</p> <p>= enabled</p>	<p>Frequency:                      Once per trip                      Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Crankshaft Torque  DTC's Passed  Number of fueled cylinders ===== After above conditions are met: DFCO mode entered (wo driver initiated pedal input).	< 125.0 Nm  P2270 (and P2272 if applicable)  ≤ 7 cylinders =====		



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Low Fuel Condition Diag Post fuel cell</p> <p>DTC's Passed</p> <p>Number of fueled cylinders =====</p> <p>After above conditions are met: Fuel Enrich mode entered. =====</p> <p>During this test the following must stay TRUE or the test will abort: 0.95 ≤ Fuel EQR ≤ 1.10</p>	<p>720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False = enabled</p> <p>P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable)</p> <p>≥ 1 cylinders =====</p>		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
O2S Heater Performance Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0141	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.3 > amps > 2.9	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle  All of the above met for	ECT_Sensor_FA 10.0 < Volts = Complete  = Not active  > zero  > 120 seconds	8 failures out of 10 samples  Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate.	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 2 Sensor 2	P014A	This DTC determines if the post catalyst O2 sensor has an initial delayed response to an A/F change from Rich to Lean. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	<p>Post O2 sensor voltage</p> <p>AND</p> <p>The Accumulated mass air flow monitored during the Delayed Response Test under DFCO</p> <p>DFCO begins after:                      1) Catalyst has been rich for a minimum of                      AND                      2) Catalyst Rich Accumulation Air Flow is greater or equal to</p>	<p>&gt; 450 mvolts</p> <p>&gt; 60 grams</p> <p>&gt; 1 secs</p> <p>&gt; 10 grams</p>	<p>No Active DTC's</p> <p>B2S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>ICAT MAT Burnoff delay</p> <p>Green O2S Condition</p> <p>Low Fuel Condition Diag</p> <p>Post fuel cell (Decel)</p>	<p>TPS_ThrottleAuthorityDefault                      ECT_Sensor_FA                      IAT_SensorFA                      MAF_SensorFA                      MAP_SensorFA                      AIR_System FA                      FuelInjectorCircuit_FA                      FuelTrimSystemB1_FA                      FuelTrimSystemB2_FA                      EngineMisfireDetected_FA                      EthanolCompositionSensor_FA                      P013C, P013D, P014B, P2272 or P2273</p> <p>10.0 &lt; Volts                      = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>= Not Valid</p> <p>= Not Valid, See definition of <b>Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 in Supporting Tables tab.</p> <p>= False</p> <p>= enabled</p>	<p>Frequency:                      Once per trip                      Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed</p>	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Crankshaft Torque  DTC's Passed  Number of fueled cylinders =====  After above conditions are met: DFCO mode entered (wo driver initiated pedal input).	< 125.0 Nm  P2270 (and P2272 if applicable)  ≤ 7 cylinders =====		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 2 Sensor 2	P014B	This DTC determines if the post catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	<p>Post O2 sensor</p> <p>AND</p> <p>The Accumulated mass air flow monitored during the Delayed Response Test</p>	<p>&lt; 350 mvolts</p> <p>&gt; 400 grams.</p>	<p>No Active DTC's</p> <p>B2S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>ICAT MAT Burnoff delay</p> <p>Green O2S Condition</p> <p>Green Cat System Condition</p>	<p>TPS_ThrottleAuthorityDefault ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FAFuelInjectorCircuit_FAFuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013C, P013D, P014A, P2272 or P2273</p> <p>10.0 &lt; Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>= Not Valid</p> <p>= Not Valid, See definition of <b>Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 in Supporting Tables tab.</p> <p>= Not Valid, System is not valid until accumulated airflow is greater than</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed</p>	Type B, 2 Trips



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Low Fuel Condition Diag Post fuel cell</p> <p>DTC's Passed</p> <p>Number of fueled cylinders =====</p> <p>After above conditions are met: Fuel Enrich mode entered. =====</p> <p>During this test the following must stay TRUE or the test will abort: 0.95 ≤ Fuel EQR ≤ 1.10</p>	<p>720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False = enabled</p> <p>P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable)</p> <p>≥ 1 cylinders =====</p>		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 2 Sensor 1	P0151	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 40 mvolts	<p>No Active DTC's</p> <p>AIR intrusive test                      Fuel intrusive test                      Idle intrusive test                      EGR intrusive test                      System Voltage                      EGR Device Control                      Idle Device Control                      Fuel Device Control                      AIR Device Control                      Low Fuel Condition Diag                      Equivalence Ratio</p> <p>Air Per Cylinder                      Fuel Control State                      Closed Loop Active                      All Fuel Injectors for active Cylinders                      Fuel Condition                      Fuel State</p> <p>All of the above met for</p>	<p>TPS_ThrottleAuthority                      DefaultedMAP_SensorFA                      AIR System FA                      Ethanol Composition                      Sensor FA                      EvapPurgeSolenoidCircuit_FA                      EvapFlowDuringNonPurge_FA                      EvapVentSolenoidCircuit_FA                      EvapSmallLeak_FA                      EvapEmissionSystem_FA                      FuelTankPressureSnsrCkt_FA                      FuelInjectorCircuit_FA</p> <p>= Not active                      = Not active                      = Not active                      = Not active                      10.0 &lt; Volts                      = Not active                      = Not active                      = Not active                      = Not active                      = False                      0.9922 ≤ equiv. ratio ≤ 1.0137                      50 ≤ APC ≤ 700 mgrams                      = Closed Loop                      = TRUE</p> <p>Enabled (On)                      ≤ 87% Ethanol                      DFCO not active</p> <p>&gt; 5.0 seconds</p>	<p>285 failures out of 350 samples</p> <p>Frequency:                      Continuous in 100 milli - second loop</p>	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 2 Sensor 1	P0152	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	No Active DTC's  System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum  Low Fuel Condition Diag  Initial delay after Open Test Criteria met (cold start condition)  Initial delay after Open Test Criteria met (not cold start condition)  Equivalence Ratio  Fuel Control State  All of the above met for	TPS_ThrottleAuthorityDef aulted MAF_SensorFA MAP_SensorFA ExcessPurgePsbl_FA FuelInjectorCircuit_FA EthanolCompositionSens or_FA AIR System_FA  10.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds  = False  > 280.0 seconds when engine soak time > 28,800 seconds  > 280.0 seconds when engine soak time ≤ 28,800 seconds  0.9922 ≤ ratio ≤ 1.0137  not = Power Enrichment  > 2 seconds	100 failures out of 125 samples  Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
O2S Slow Response Bank 2 Sensor 1) (For use with ESPD	P0153	This DTC determines if the O2 sensor response time is degraded.	<p>Fault condition present when the average response time is calculated over the test time, and compared to the threshold.</p> <p>OR</p> <p>Slope Time L/R Switches</p> <p>OR</p> <p>Slope Time R/L Switches</p>	<p>&lt; 3</p> <p>&lt; 3</p>	<p>Refer to <b>P0153_O2S Slow Response Bank 2 Sensor 1 "Pass/Fail Threshold table"</b> in the Supporting Tables tab</p> <p>The test averages the signal response time over 60.0 seconds when the signal is transitioning between 300 mvolts and 600 mvolts. An average rich to lean time and lean to rich time are each calculated separately.</p>	<p>No Active DTC's</p> <p>Bank 2 Sensor 1 DTC's not active</p> <p>System Voltage</p> <p>EGR Device Control</p> <p>Idle Device Control</p> <p>Fuel Device Control</p> <p>AIR Device Control</p> <p>Low Fuel Condition Diag</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted</p> <p>MAP_SensorFA</p> <p>IAT_SensorFA</p> <p>ECT_Sensor_FA</p> <p>AmbientAirDefault</p> <p>MAF_SensorFA</p> <p>EvapPurgeSolenoidCircuit_FA</p> <p>EvapFlowDuringNonPurge_FA</p> <p>EvapVentSolenoidCircuit_FA</p> <p>EvapSmallLeak_FA</p> <p>EvapEmissionSystem_FA</p> <p>FuelTankPressureSnrCkt_FA</p> <p>FuelInjectorCircuit_FA</p> <p>AIR System FA</p> <p>EthanolCompositionSensor_FA</p> <p>EngineMisfireDetected_FA</p> <p>= P0151, P0152 or P0154</p> <p>10.0 &lt; Volts</p> <p>= Not active</p> <p>= Not active</p> <p>= Not active</p> <p>= Not active</p> <p>= Not active</p> <p>= False</p> <p>= Not Valid, See definition of <b>Multiple DTC Use_Green Sensor Delay Criteria - Airflow</b> and <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S1, B2S1 in Supporting</p>	<p>Sample time is 60 seconds</p> <p>Frequency: Once per trip</p>	<p>Type B, 2 Trips</p>

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					O2 Heater on for Learned Htr resistance  Engine Coolant IAT Engine run Accum  Time since any AFM status change Time since Purge On to Off change Time since Purge Off to On change  Engine airflow Engine speed Fuel Condition Baro Air Per Cylinder  Fuel Control State Closed Loop Active LTM fuel cell Transient Fuel Mass Baro Fuel Control State Fuel State Commanded Proportional Gain  ===== All of the above met for	Tables tab.  ≥ 40 seconds = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" ) > 50 °C > -40 °C > 30 seconds  > 2.0 seconds > 1.0 seconds > 2.0 seconds  20 ≤ grams/second ≤ 55 1,000 ≤ RPM ≤ 3,000 < 87 % Ethanol > 70 kpa ≥ 200 mGrams  = Closed Loop = TRUE = Enabled ≤ 100.0 mgrams = Not Defaulted not = Power Enrichment DFCO not active  ≥ 0.0 %  ===== > 2.0 seconds		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
O2S Heater Performance Bank 2 Sensor 1	P0155	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.3 > amps > 3.1	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle  All of the above met for	ECT_Sensor_FA 10.0 < Volts = Complete  = Not active  > zero  > 120 seconds	8 failures out of 10 samples  Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 2 Sensor 2	P0157	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 50 mvolts	No Active DTC's  AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active All Fuel Injectors for active Cylinders Fuel Condition Fuel State  All of the above met for	TPS_ThrottleAuthorityDef aulted MAP_SensorFA AIR_System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA = Not active = Not active = Not active = Not active 10.0 < Volts = Not active = Not active = Not active = Not active = False 0.9922 ≤ ratio ≤ 1.0137 50 ≤ mgrams ≤ 700 = Closed Loop = TRUE  Enabled (On) ≤ 87% Ethanol DFCO not active  > 5.0 seconds	320 failures out of 400 samples  Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 2 Sensor 2	P0158	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	No Active DTC's  System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum  Low Fuel Condition Diag  Initial delay after Open Test Criteria met (cold start condition)  Initial delay after Open Test Criteria met (not cold start condition)  Equivalence Ratio  Fuel Control State  All of the above met for	TPS_ThrottleAuthorityDefaulted MAF_SensorFA MAP_SensorFA ExcessPurgePsbl_FA FuelInjectorCircuit_FA EthanolCompositionSensor_FA AIR System_FA  10.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds  = False  > 280.0 seconds when engine soak time > 28,800 seconds  > 280.0 seconds when engine soak time ≤ 28,800 seconds  0.9922 ≤ ratio ≤ 1.0137  not = Power Enrichment  > 2 seconds	100 failures out of 125 samples  Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 1	P015A	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Rich to Lean. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Pre O2 sensor normalized R2L time delay value  OR [The Accumulated time monitored during the R2L Delayed Response Test (Gross failure).  AND Pre O2 sensor voltage is	> 0.6 EWMA (sec)   ≥ 2.5 Seconds   > 550 mvolts	No Active DTC's          System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag  Green O2S Condition	TPS_ThrottleAuthorityDefault MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA P0131, P0132, P0134  10.0 < Volts = Not active = Not active = Not active = Not active = False  = Not Valid, See definition of <b>Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for</b>	Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponsesActive = TRUE, multiple tests per trip are allowed	Type A, 1 Trips EWMA

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>O2 Heater (pre sensor) on for Learned Htr resistance</p> <p>Engine Coolant IAT Engine run Accum</p> <p>Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)</p> <p>Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)</p> <p>Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell</p> <p>EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State</p>	<p>the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab.</p> <p>≥ 40 seconds = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>&gt; 50 °C &gt; -40 °C &gt; 30 seconds</p> <p>1,000 ≤ RPM ≤ 2,300</p> <p>950 ≤ RPM ≤ 2,350</p> <p>4 ≤ gps ≤ 18</p> <p>42.3 ≤ MPH ≤ 74.6</p> <p>39.8 ≤ MPH ≤ 77.7</p> <p>0.75 ≤ C/L Int ≤ 1.08 = TRUE not in control of purge not in estimate mode = enabled</p> <p>= not active</p> <p>= not active</p> <p>≥ 60.0 sec 600 ≤ °C ≤ 900 = DFCO possible</p>		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>=====</p> <p>All of the above met for at least 1.0 seconds, and then the Force Cat Rich intrusive stage is requested.</p> <p>=====</p> <p>Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders</p> <p>=====</p> <p>After above conditions are met: DFCO Mode is entered (wo driver initiated pedal input).</p>	<p>=====</p> <p>≥ 690 mvolts = DFCO active</p> <p>≤ 7 cylinders</p> <p>=====</p>		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 1	P015B	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test which runs in an enriched fuel mode to achieve the required response.	<p>The EWMA of the Pre O2 sensor normalized L2R time delay value</p> <p>OR</p> <p>[The Accumulated time monitored during the L2R Delayed Response Test (Gross failure).</p> <p>AND</p> <p>Pre O2 sensor voltage is</p> <p>OR</p> <p>At end of Cat Rich stage the Pre O2 sensor output is</p>	<p>&gt; 0.6 EWMA (sec)</p> <p>≥ 2.5 Seconds</p> <p>&lt; 350 mvolts</p> <p>&lt; 690 mvolts</p>	<p>No Active DTC's</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefault MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA P0131, P0132, P0134</p> <p>10.0 &lt; Volts = Not active = Not active = Not active = Not active = False</p> <p>= Not Valid, See definition of <b>Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for</b></p>	<p>Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponsesActive = TRUE, multiple tests per trip are allowed</p>	<p>Type A, 1 Trips EWMA</p>

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>O2 Heater (pre sensor) on for for Learned Htr resistance</p> <p>Engine Coolant IAT Engine run Accum</p> <p>Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)</p> <p>Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)</p> <p>Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp</p>	<p>the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab.</p> <p>≥ 40 seconds = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>&gt; 50 °C &gt; -40 °C &gt; 30 seconds</p> <p>1,000 ≤ RPM ≤ 2,300</p> <p>950 ≤ RPM ≤ 2,350</p> <p>4 ≤ gps ≤ 18</p> <p>42.3 ≤ MPH ≤ 74.6</p> <p>39.8 ≤ MPH ≤ 77.7</p> <p>0.75 ≤ C/L Int ≤ 1.08 = TRUE not in control of purge not in estimate mode = enabled = not active = not active ≥ 60.0 sec</p> <p>600 ≤ °C ≤ 900</p>		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Fuel State Number of fueled cylinders  ===== When above conditions are met: Fuel Enrich mode is entered.  =====  During this test: Engine Airflow must stay between: and the delta Engine Airflow over 12.5msec must be :	= DFCO inhibit  ≥ 1 cylinders  =====  =====  4 ≤ gps ≤ 18  ≤ 13.5 gps		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 2 Sensor 1	P015C	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Rich to Lean. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Pre O2 sensor normalized R2L time delay value  OR [The Accumulated time monitored during the R2L Delayed Response Test (Gross failure).  AND Pre O2 sensor voltage is above]	> 0.6 EWMA (sec)   ≥ 2.5 Seconds   > 550 mvolts	No Active DTC's          System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag  Green O2S Condition	TPS_ThrottleAuthorityDefault MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA P0131, P0132, P0134  10.0 < Volts = Not active = Not active = Not active = Not active = False  = Not Valid, See definition of <b>Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for</b>	Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponsesActive = TRUE, multiple tests per trip are allowed	Type A, 1 Trips EWMA



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>O2 Heater (pre sensor) on for Learned Htr resistance</p> <p>Engine Coolant IAT</p> <p>Engine run Accum</p> <p>Engine Speed to initially enable test</p> <p>Engine Speed range to keep test enabled (after initially enabled)</p> <p>Engine Airflow</p> <p>Vehicle Speed to initially enable test</p> <p>Vehicle Speed range to keep test enabled (after initially enabled)</p> <p>Closed loop integral Closed Loop Active</p> <p>Evap Ethanol Post fuel cell</p> <p>EGR Intrusive diagnostic All post sensor heater delays</p> <p>O2S Heater (post sensor) on Time</p> <p>Predicted Catalyst temp</p>	<p>the following locations: B1S1, B2S1 in Supporting Tables tab.</p> <p>≥ 40 seconds = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>&gt; 50 °C</p> <p>&gt; -40 °C</p> <p>&gt; 30 seconds</p> <p>1,000 ≤ RPM ≤ 2,300</p> <p>950 ≤ RPM ≤ 2,350</p> <p>4 ≤ gps ≤ 18</p> <p>42.3 ≤ MPH ≤ 74.6</p> <p>39.8 ≤ MPH ≤ 77.7</p> <p>0.75 ≤ C/L Int ≤ 1.08 = TRUE</p> <p>not in control of purge</p> <p>not in estimate mode = enabled</p> <p>= not active</p> <p>= not active</p> <p>≥ 60.0 sec</p> <p>600 ≤ °C ≤ 900</p>		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Fuel State ===== All of the above met for at least 1.0 seconds, and then the Force Cat Rich intrusive stage is requested. ===== Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders ===== After above conditions are met: DFCO Mode is entered (wo driver initiated pedal input).	= DFCO possible ===== ===== ≥ 690 mvolts = DFCO active ≤ 7 cylinders =====		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 2 Sensor 1	P015D	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Lean to Rich. The diagnostic is an intrusive test which runs in an enriched fuel mode to achieve the required response.	<p>The EWMA of the Pre O2 sensor normalized L2R time delay value</p> <p>OR</p> <p>[The Accumulated time monitored during the L2R Delayed Response Test (Gross failure).</p> <p>AND</p> <p>Pre O2 sensor voltage is below]</p> <p>OR</p> <p>At end of Cat Rich stage the Pre O2 sensor output is</p>	<p>&gt; 0.6 EWMA (sec)</p> <p>≥ 2.5 Seconds</p> <p>&lt; 350 mvolts</p> <p>&lt; 690 mvolts</p>	<p>No Active DTC's</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefault MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR_System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA P0131, P0132, P0134</p> <p>10.0 &lt; Volts = Not active = Not active = Not active = Not active = False</p> <p>= Not Valid, See definition of <b>Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for</b></p>	<p>Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponsesActive = TRUE, multiple tests per trip are allowed</p>	Type A, 1 Trips EWMA

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>O2 Heater (pre sensor) on for for Learned Htr resistance</p> <p>Engine Coolant IAT Engine run Accum</p> <p>Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)</p> <p>Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)</p> <p>Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time</p> <p>Predicted Catalyst temp Fuel State</p>	<p>the following locations: B1S1, B2S1 in Supporting Tables tab.</p> <p>≥ 40 seconds = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>&gt; 50 °C &gt; -40 °C &gt; 30 seconds</p> <p>1,000 ≤ RPM ≤ 2,300</p> <p>950 ≤ RPM ≤ 2,350</p> <p>4 ≤ gps ≤ 18</p> <p>42.3 ≤ MPH ≤ 74.6</p> <p>39.8 ≤ MPH ≤ 77.7</p> <p>0.75 ≤ C/L Int ≤ 1.08 = TRUE not in control of purge not in estimate mode = enabled = not active = not active</p> <p>≥ 60.0 sec</p> <p>600 ≤ °C ≤ 900 = DFCO inhibit</p>		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Number of fueled cylinders  ===== When above conditions are met: Fuel Enrich mode is entered.  =====  During this test: Engine Airflow must stay between: and the delta Engine Airflow over 12.5msec must be :	$\geq 1$ cylinders  =====  $4 \leq \text{gps} \leq 18$  $\leq 13.5$ gps		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
O2S Heater Performance Bank 2 Sensor 2	P0161	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.3 > amps > 2.9	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle  All of the above met for	ECT_Sensor_FA 10.0 < Volts = Complete  = Not active  > zero  > 120 seconds	8 failures out of 10 samples  Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

## 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Lean Bank 1	P0171	Determines if the fuel control system is in a lean condition, based on the filtered long-term and short-term fuel trim.	<p>The filtered long-term fuel trim metric</p> <p>AND</p> <p>The filtered short-term fuel trim metric (Note: any value below 0.95 effectively nullifies the short-term fuel trim criteria)</p>	<p><math>\geq 1.345</math></p>      <p><math>\geq 0.100</math></p>	<p>Engine speed BARO Coolant Temp MAP Inlet Air Temp MAF Fuel Level</p>   <p>Long Term Fuel Trim data accumulation:</p>    <p>Sometimes, certain Long-Term Fuel Trim Cells are not utilized for control and/or diagnosis</p>  <p>Closed Loop Long Term FT</p>    <p>EGR Diag. Catalyst Diag. Post O2 Diag.</p>	<p>375 &lt;rpm&lt; 7,000 &gt; 70 kPa -20 &lt;°C&lt; 150 10 &lt;kPa&lt; 255 -20 &lt;°C&lt; 150 1.0 &lt;g/s&lt; 510.0 &gt; 10 % or if fuel sender is faulty the diagnostic will bypass the fuel level criteria.</p> <p>&gt; 25.0 seconds of data must accumulate on each trip, with at least 15.0 seconds of data in the current fuel trim cell before a pass or fail decision can be made.</p> <p>(Please see "Long-Term Fuel Trim Cell Usage" in Supporting Tables for a list of cells utilized for diagnosis)</p>  <p>Enabled Enabled (Please see "Closed Loop Enable Criteria" and "Long Term FT Enable Criteria" in Supporting Tables.)</p>   <p>Intrusive Test Not Active Intrusive Test Not Active Intrusive Test Not Active</p>	<p>Frequency: 100 ms Continuous Loop</p>	<p>Type B, 2 Trips</p>

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Device Control EVAP Diag.  No active DTC:	Not Active "tank pull down" Not Active  IAC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR_System FA EvapExcessPrgePsbl_FA Ethanol Comp Snsr FA FuelInjectorCkt_FA EngMisfireDetected_FA EGRValvePerf_FA EGRValveCkt_FA MAP_EngVacuumStatus AmbPresDfItDStatus TC_BoostPresSnsrFA O2Snsr_B1_Snsr_1_FA		



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Rich Bank 1	P0172	<p>Determines if the fuel control system is in a rich condition, based on the filtered long-term fuel trim metric.</p> <p>There are two methods to determine a Rich fault. They are Passive and Intrusive. A Passive Test decision can be made up until the time that purge is first enabled. From that point forward, rich faults can only be detected by turning purge off intrusively.</p> <p>Intrusive Test: If the filtered Purge Long Term Fuel Trim metric &gt; 0.750, the test passes without intrusively checking the filtered Non-Purge Long Term Fuel Trim metric. However if the filtered Purge Long Term Fuel Trim metric is &lt;= 0.750, purge is ramped off to determine if excess purge vapor is the cause of the rich condition.</p> <p>Performing intrusive tests too frequently may also affect EVAP and EPAIII emissions,</p>	<p>Passive Test: The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)</p> <p>Intrusive Test: For 3 out of 5 intrusive segments, the filtered Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)</p> <p>Segment Def'n: Segments can last up to 30 seconds and are separated by the lesser of 20 seconds of purge-on time or enough time to</p>	<p>&lt;= 0.745</p> <p>&lt;= 2.000</p> <p>&lt;= 0.750</p> <p>&lt;= 0.745</p> <p>&lt;= 2.000</p>		<p>Secondary Parameters and Enable Conditions are identical to those for P0171, with the exception that fuel level is not considered.</p>	<p>Frequency: 100 ms Continuous Loop</p>	<p>Type B, 2 Trips</p>

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and the execution frequency of other diagnostics.	purge 15 grams of vapor. A maximum of 5 completed segments or 20 attempts are allowed for each intrusive test. After an intrusive test report is completed, another intrusive test cannot occur for 300 seconds to allow sufficient time to purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge Long Term Fuel Trim metric > 0.750 for at least 200 seconds, indicating that the canister has been purged.					

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Lean Bank 2	P0174	Determines if the fuel control system is in a lean condition, based on the filtered long-term and short-term fuel trim.	The filtered long-term fuel trim metric  AND  The filtered short-term fuel trim metric (Note: any value below 0.95 effectively nullifies the short-term fuel trim criteria)	$\geq 1.345$    $\geq 0.100$	Engine speed BARO Coolant Temp MAP Inlet Air Temp MAF Fuel Level  Long Term Fuel Trim data accumulation:  Sometimes, certain Long-Term Fuel Trim Cells are not utilized for control and/or diagnosis  Closed Loop Long Term FT  EGR Diag. Catalyst Diag. Post O2 Diag. Device Control	375 <rpm< 7,000 > 70 kPa -20 <°C< 150 10 <kPa< 255 -20 <°C< 150 1.0 <g/s< 510.0 > 10% or if fuel sender is faulty the diagnostic will bypass the fuel level criteria.  > 25.0 seconds of data must accumulate on each trip, with at least 15.0 seconds of data in the current fuel trim cell before a pass or fail decision can be made.  (Please see <b>"Long-Term Fuel Trim Cell Usage"</b> in Supporting Tables for a list of cells utilized for diagnosis)  Enabled Enabled (Please see <b>"Closed Loop Enable Criteria"</b> and <b>"Long Term FT Enable Criteria"</b> in Supporting Tables.)  Intrusive Test Not Active Intrusive Test Not Active Intrusive Test Not Active Not Active	Frequency: 100 ms Continuous Loop	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					EVAP Diag.  No active DTC:	"tank pull down" Not Active  IAC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR_System FA EvapExcessPrgePsb1_FA Ethanol Comp Snsr FA FuelInjectorCkt_FA EngMisfireDetected_FA EGRValvePerf_FA EGRValveCkt_FA MAP_EngVacuumStatus AmbPresDfltStatus TC_BoostPresSnsrFA O2Snsr_B2_Snsr_1_FA		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Rich Bank 2	P0175	<p>Determines if the fuel control system is in a rich condition, based on the filtered long-term fuel trim metric.</p> <p>There are two methods to determine a Rich fault. They are Passive and Intrusive. A Passive Test decision can be made up until the time that purge is first enabled. From that point forward, rich faults can only be detected by turning purge off intrusively.</p> <p>Intrusive Test: If the filtered Purge Long Term Fuel Trim metric &gt; 0.750, the test passes without intrusively checking the filtered Non-Purge Long Term Fuel Trim metric. However if the filtered Purge Long Term Fuel Trim metric is &lt;= 0.750, purge is ramped off to determine if excess purge vapor is the cause of the rich condition.</p> <p>Performing intrusive tests too frequently may also affect EVAP and EPAIII emissions,</p>	<p>Passive Test: The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)</p> <p>Intrusive Test: For 3 out of 5 intrusive segments, the filtered Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)</p> <p>Segment Def'n: Segments can last up to 30 seconds and are separated by the lesser of 20 seconds of purge-on time or enough time to</p>	<p>&lt;= 0.745</p> <p>&lt;= 2.000</p> <p>&lt;= 0.750</p> <p>&lt;= 0.745</p> <p>&lt;= 2.000</p>		<p>Secondary Parameters and Enable Conditions are identical to those for P0174, with the exception that fuel level is not considered.</p>	<p>Frequency: 100 ms Continuous Loop</p>	<p>Type B, 2 Trips</p>

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and the execution frequency of other diagnostics.	<p>purge 15 grams of vapor.</p> <p>A maximum of 5 completed segments or 20 attempts are allowed for each intrusive test.</p> <p>After an intrusive test report is completed, another intrusive test cannot occur for 300 seconds to allow sufficient time to purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge Long Term Fuel Trim metric &gt; 0.750 for at least 200 seconds, indicating that the canister has been purged.</p>					

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pressure Sensor "B" Circuit Range/ Performance	P018B	This DTC detects a fuel pressure sensor response stuck within the normal operating range using an intrusive test ( see Notes)	Absolute value of fuel pressure change ( as sensed during intrusive test)	<= 30 kPa	a) Diagnostic KeFRPD_b_FPSS_DiagEnbld b) Engine Run Time c) Engine Fuel Flow d) Fu Pump Control Enabled e) Fu Pump Control State f) Emissions Fuel Level Low g) Validity status VeFRPD_b_FPSS_DataIntegrityOK IF [1] FRP Circuit Low Fault Active (DTC P018C) [2] FRP Circuit High Fault Active (DTC P018D) [3] Fu Pump Circuit Low Fault Active (DTC P0231) [4] Fu Pump Circuit High Fault Active (DTC P0232) [5] Fu Pump Circuit Open Fault Active (DTC P023F) [6] Reference Voltage Fault Status ( DTC P0641) [7] Fu Pump Control Module Driver Over-temperature Fault Active ( DTC P1255) [8] Fu Pump Driver Mod	a) == TRUE b) >= 5 sec c) > calibration value KeFRPD_dm_StkPresMin FuelFlow ( 0.047 gram/ sec typical) d) == TRUE e) Normal OR Fu Pres Snsr Stk Ctrl ( rationality) f) <> TRUE g) == TRUE IF [1] <> TRUE [2] <> TRUE [3] <> TRUE [4] <> TRUE [5] <> TRUE [6] <> Active This Key [7] <> TRUE [8] <> TRUE	1 sample / 12.5 millisecond Intrusive Test Duration: Fu Flow -related ( 5 to 12 sec)	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Ign Sw RunStart Pstn Ckt Low Fault Active (DTC P129D) [9] Fu Pump Driver Control Mod Enable Ckt Perf Fault Active(DTC P12A6)	[9] <> TRUE		



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Pressure Sensor "B" Circuit Low	P018C	This DTC detects if the fuel pressure sensor circuit is shorted low	Fuel Pressure Sensor Voltage Percent, 5.0V Nominal ((Abs( 5.0V - SensorV_actual) /5.0V) *100)	< 4.00	Ignition circuit input state	High ( Run or Crank)	64 failures / 80 samples  1 sample/12.5 ms	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Pressure Sensor "B" Circuit High	P018D	This DTC detects if the fuel pressure sensor circuit is shorted high	Fuel Pressure Sensor Voltage Percent, 5.0V Nominal ((Abs( 5.0V - SensorV_actual) /5.0V) *100)	> 96.00	Ignition circuit input state	High ( Run or Crank)	64 failures / 80 samples  1 sample/12.5 millisec	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Sensor Performance - Dual Sensor	P0191	The DTC Diagnoses a skewed fuel rail sensor 1 via a comparison of sensor 2 continuously when the engine is running and the commanded pressure is steady	Primary sensor (P1) vs. Secondary sensor (P2) performance rationality	<p>SIDI Dual High Pressure Sensor Equipped and SIDI High Pressure Sensor Performance Diagnostic Disabled</p> <p>Low Limit fail</p> <p>Filtered Fuel Control Error &lt;= supporting table P0191 - KtFHPD_cmp_DPS_FailLoThrsh (Dual sensors) and (Filtered Absolute delta between sensor1 and sensor2 &gt;= supporting table P0191 - KeFHPD_p_DPSPrsDiffFailThrsh (Dual Sensors)</p> <p>High Limit Fail:</p> <p>Filtered Fuel Control Error &gt;= Supporting table P0191 - KtFHPD_cmp_DPS_FailHiThrsh (Dual Sensors) ) and (Filtered Absolute delta between sensor1 and</p>	<p>Commanded Pressure rate of change (increasing or decreasing) &lt;</p> <p>for a period of time &gt;=</p> <p>Fuel pump temperature &lt;=</p> <p>Desired pressure &gt;=</p>	<p>0.70 mpa</p> <p>1.25 seconds</p> <p>1,000.00 degC</p> <p>-1.00 mpa</p> <p>Engine is not cranking</p> <p>Enabled when a code clear is not active or not exiting device control</p> <p>High Fuel pressure sensor ckt is Not FA</p>	<p>Filter Fuel Control Error term and Absolute delta between sensor1 and sensor2 exceed Low or High Fail limit for a duration &gt;= 1.50 seconds</p> <p>This is diagnostic runs Continuous</p>	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				sensor2 >= Supporting table P0191 - KeFHPD_p_DPSPrsDif fFailThrsh (Dual Sensors)  Note: fuel control error is calculated based on the squreroot of sensor1 divided by sensor2, this value is filter to ensure proper failure detection.  Absolute delta between sensor1 and sensor2 value is filter to ensure proper failure detection.				

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Sensor Out of Range Low	P0192	This DTC Diagnoses High Pressure Sensor Out of Range Low	High Pressure Fuel Sensor	SIDI High Pressure Sensor 1 Out of range Time Based Enabled  or  SIDI High Pressure Sensor 1 Out of range Engine Synchronous Enabled  <= 5 % of 5Vref	Battery Voltage	>= 11 Volts  Engine Running	Both Run Continuously Engine Synchronous Mode 800 failures out of 1,000 samples Time Based Mode 400 failures out of 500 samples 6.25 ms Sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Sensor Out of Range High	P0193	This DTC Diagnoses High Pressure Sensor Out of Range High	High Pressure Fuel Sensor	SIDI High Pressure Sensor 1 Out of range Time Based Enabled  or  SIDI High Pressure Sensor 1 Out of range Engine Synchronous Enabled  >= 95 % of 5Vref	Battery Voltage	>= 11 Volts  Engine Running	Both Run Continuously Engine Synchronous Mode 800 failures out of 1,000 samples Time Based Mode 400 failures out of 500 samples 6.25 ms Sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 1 Open Circuit - (SIDI)	P0201	This DTC Diagnoses Injector 1 enable low side driver circuit for circuit faults.	Low current through the low side driver during operation indicates open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Battery Voltage Engine Running	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 2 Open Circuit - (SIDI)	P0202	This DTC Diagnoses Injector 2 enable low side driver circuit for circuit faults.	Low current through the low side driver during operation indicates open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 3 Open Circuit - (SIDI)	P0203	This DTC Diagnoses Injector 3 enable low side driver circuit for circuit faults.	Low current through the low side driver during operation indicates open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Battery Voltage Engine Running	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 4 Open Circuit - (SIDI)	P0204	This DTC Diagnoses Injector 4 enable low side driver circuit for circuit faults.	Low current through the low side driver during operation indicates open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 5 Open Circuit - (SIDI)	P0205	This DTC Diagnoses Injector 5 enable low side driver circuit for circuit faults.	Low current through the low side driver during operation indicates open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Sec  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 6 Open Circuit - (SIDI)	P0206	This DTC Diagnoses Injector 6 enable low side driver circuit for circuit faults.	Low current through the low side driver during operation indicates open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 7 Open Circuit - (SIDI)	P0207	This DTC Diagnoses Injector 7 enable low side driver circuit for circuit faults.	Low current through the low side driver during operation indicates open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 8 Open Circuit - (SIDI)	P0208	This DTC Diagnoses Injector 8 enable low side driver circuit for circuit faults.	Low current through the low side driver during operation indicates open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit Low	P0222	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage <	0.250		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts;  57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
TPS2 Circuit High	P0223	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage >	4.590		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts;  57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Secondary Circuit Low	P0231	This DTC detects if the fuel pump control circuit is shorted to low	Power driver output current ( Fuel Pump Power Module Driver Circuit Ground Short enumeration)	Current $\geq$ 18.0 A ( Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate test state)	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType  b) Diagnostic KeFRPR_b_FPPM_ DrvrsGshdtDiagEnbld  c) Fuel Pump Control Enable command  d) Fuel Pump Control Enable time  e) System Voltage  f) FPPM Driver Status Alive Rolling Count Sample Faulted  g) Diagnostic feedback received  h) Fuel Pump Power Module output current	a) == CeFRPR_e_ECM_FPPM_ _Sys  b) == TRUE  c) == TRUE  d) $\geq$ calibration value KeFRPR_Cnt_FPPM_ GshdtDlyThrsh ( 0-80 sample loops)  e) $9v < \text{System V} < 32v$  f) $\neq$ TRUE  g) == TRUE  h) $< 75A$	64 failures / 80 samples  1 sample/12.5 millisec	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Secondary Circuit High	P0232	This DTC detects if the fuel pump control circuit is shorted to high voltage	Voltage offset relative to low state level of duty cycle pulse measured at fuel pump circuit	> 4.0 V	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType  b) Diagnostic KeFRPR_b_FPPM_ DrvrPshtDiagEnbld  c) Fuel Pump Control Enabled  d) FPPM Arbitrated Fu Pmp Duty Cycle Rate of Change  e) System voltage  f) FPPM Driver Status Alive Rolling Count Sample Faulted  g) Diagnostic feedback Received	a) == CeFRPR_e_ECM_ FPPM_Sys  b) == TRUE  c) == TRUE  d] >= calibration value KeFRPR_cmp_FPPM_ PshtDC_ROC_Min  e] 9v < System V > 32v  f] <> TRUE  g] == TRUE	64 failures / 80 samples  1 sample / 12.5 millisec	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Secondary Circuit Open	P023F	This DTC detects if the fuel pump control circuit is open	Output driver current ( Fuel Pump Power Module Driver Circuit Open enumeration)	Current <= 1.0 A (Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate)	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType  b) Diagnostic KeFRPR_b_FPPM_ OpenCktDiagEnbld  c) Arbitrated Fu Pmp Duty Cycle ( %)  d) Fuel Pump Control Enable Faulted  e) FPPM Fu Pmp Driver Over-temperature Faulted  f) FPPM Driver Status Alive Rolling Count Sample Faulted  g) Diagnostic feedback received  h) System Voltage	a) == CeFRPR_e_ECM_ FPPM_Sys  b) == TRUE  c) > calibration value KeFRPR_Pct_FPPM_ OpenCktDC_Thrsh ( 30% - 60%)  d] <> TRUE  e] <> TRUE  f] <> TRUE  g] == TRUE  h] 9v < System V > 32v	40 test failures / 80 test samples;  1 sample/12.5ms	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 1 Low side circuit shorted to ground (SIDI)	P0261	This DTC Diagnoses Injector 1 enable low side driver circuit for circuit faults.	Voltage low across low side drive during off state indicates short-to-ground	Short to ground: ≤ 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 1 Low side circuit shorted to power (SIDI)	P0262	This DTC Diagnoses Injector 1 enable low side driver circuit for circuit faults.	Voltage High across low side driver during On state indicates short to power	Short to power: 25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 2 Low side circuit shorted to ground (SIDI)	P0264	This DTC Diagnoses Injector 2 enable low side driver circuit for circuit faults.	Voltage low across low side drive during off state indicates short-to-ground	Short to ground: ≤ 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to power (SIDI)	P0265	This DTC Diagnoses Injector 2 enable low side driver circuit for circuit faults.	Voltage High across low side driver during On state indicates short to power	Short to power: 25 amp $\geq$ through low side driver	Battery Voltage Engine Run Time	$\geq$ 11 Volts $\geq$ 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 3 Low side circuit shorted to ground (SIDI)	P0267	This DTC Diagnoses Injector 3 enable low side driver circuit for circuit faults.	Voltage low across low side drive during off state indicates short-to-ground	Short to ground: ≤ 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 3 Low side circuit shorted to power (SIDI)	P0268	This DTC Diagnoses Injector 3 enable low side driver circuit for circuit faults.	Voltage High across low side driver during On state indicates short to power	Short to power: 25 amp $\geq$ through low side driver	Battery Voltage Engine Run Time	$\geq$ 11 Volts $\geq$ 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 4 Low side circuit shorted to ground (SIDI)	P0270	This DTC Diagnoses Injector 4 enable low side driver circuit for circuit faults.	Voltage low across low side drive during off state indicates short-to-ground	Short to ground: ≤ 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 4 Low side circuit shorted to power (SIDI)	P0271	This DTC Diagnoses Injector 4 enable low side driver circuit for circuit faults.	Voltage High across low side driver during On state indicates short to power	Short to power: 25 amp $\geq$ through low side driver	Battery Voltage Engine Run Time	$\geq$ 11 Volts $\geq$ 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 5 Low side circuit shorted to ground (SIDI)	P0273	This DTC Diagnoses Injector 5 enable low side driver circuit for circuit faults.	Voltage low across low side drive during off state indicates short-to-ground	Short to ground: ≤ 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 5 Low side circuit shorted to power (SIDI)	P0274	This DTC Diagnoses Injector 5 enable low side driver circuit for circuit faults.	Voltage High across low side driver during On state indicates short to power	Short to power: 25 amp $\geq$ through low side driver	Battery Voltage Engine Run Time	$\geq$ 11 Volts $\geq$ 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 6 Low side circuit shorted to ground (SIDI)	P0276	This DTC Diagnoses Injector 6 enable low side driver circuit for circuit faults.	Voltage low across low side drive during off state indicates short-to-ground	Short to ground: ≤ 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 6 Low side circuit shorted to power (SIDI)	P0277	This DTC Diagnoses Injector 6 enable low side driver circuit for circuit faults.	Voltage High across low side driver during On state indicates short to power	Short to power: 25 amp $\geq$ through low side driver	Battery Voltage Engine Run Time	$\geq$ 11 Volts $\geq$ 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 7 Low side circuit shorted to ground (SIDI)	P0279	This DTC Diagnoses Injector 7 enable low side driver circuit for circuit faults.	Voltage low across low side drive during off state indicates short-to-ground	Short to ground: ≤ 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 7 Low side circuit shorted to power (SIDI)	P0280	This DTC Diagnoses Injector 7 enable low side driver circuit for circuit faults.	Voltage High across low side driver during On state indicates short to power	Short to power: 25 amp $\geq$ through low side driver	Battery Voltage Engine Run Time	$\geq$ 11 Volts $\geq$ 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 8 Low side circuit shorted to ground (SIDI)	P0282	This DTC Diagnoses Injector 8 enable low side driver circuit for circuit faults.	Voltage low across low side drive during off state indicates short-to-ground	Short to ground: ≤ 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 8 Low side circuit shorted to power (SIDI)	P0283	This DTC Diagnoses Injector 8 enable low side driver circuit for circuit faults.	Voltage High across low side driver during On state indicates short to power	Short to power: 25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Random Misfire Detected	P0300	These DTC's will determine if a random or a cylinder specific misfire is occurring by monitoring various terms derived from crankshaft velocity. The rate of misfire over an interval is compared to both emissions and catalyst damaging thresholds. The pattern of crankshaft acceleration after the misfire is checked to differentiate between real misfire and other sources of crank shaft noise.	Crankshaft Deceleration Value(s) vs. Engine Speed and Engine load		Engine Run Time  Engine Coolant Temp Or If ECT at startup Then ECT	> 2 crankshaft revolution  -7 °C < ECT < 130 °C < -7 °C 21 °C < ECT < 130 °C	Emission Exceedence = any ( 5 ) failed 200 rev blocks out of ( 16 ) 200 rev block tests  Failure reported for (1) Exceedence in 1st ( 16 ) 200 rev block tests, or ( 4 ) Exceedences thereafter.  OR when Early Termination Reporting = Enabled and engine rev > 1,000 revs and < 3,200 revs at end of trip  any Catalyst Exceedence = ( 1 ) 200 rev block as data supports for catalyst damage.	Type B, 2 Trips (Mil Flashes with Catalyst damage level of Misfire)
Cylinder 1 Misfire Detected	P0301		The equation used to calculate deceleration value is tailored to specific vehicle operating conditions.		System Voltage + Throttle delta - Throttle delta	9.00 < volts < 32.00 < 95.00 % per 25 ms < 95.00 % per 25 ms		
Cylinder 2 Misfire Detected	P0302		The selection of the equation used is based on the 1st single cylinder continuous misfire threshold tables encountered that are not max of range. If all tables are max of range at a given speed/load, that speed load region is an <b>Undetectable region</b> see Algorithm Description Document for additional details.	- see details of thresholds on Supporting Tables Tab (P0300 Section)	Early Termination option: (used on plug ins that may not have enough engine run time at end of trip for normal interval to complete.)	Not Enabled		
Cylinder 3 Misfire Detected	P0303							
Cylinder 4 Misfire Detected	P0304							
Cylinder 5 Misfire Detected	P0305							
Cylinder 6 Misfire Detected	P0306							
Cylinder 7 Misfire Detected	P0307			SINGLE CYLINDER CONTINUOUS MISFIRE( (Medres_Decel Medres_Jerk	> IdleSCD_Decel AND > IdleSCD_Jerk)			
Cylinder 8 Misfire Detected	P0308		OR (Medres_Decel Medres_Jerk	>SCD_Decel AND > SCD_Jerk)				
			OR (Lores_Decel Lores_Jerk	>IdleCyl_Decel AND > IdleCyl_Jerk)				
			OR (Lores_Decel Lores_Jerk	>CylModeDecel AND > CylModeJerk)				
			OR RevBalanceTime	>RevMode_Decel				

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Other patterns of misfire use adjustments to the single cylinder continuous misfire threshold tables:</p> <p>RANDOM MISFIRE Use random misfire thresholds If no misfire for</p> <p>(Medres_Decel AND Medres_Jerk)</p> <p>OR (Medres_Decel AND Medres_Jerk)</p> <p>OR (Lores_Decel AND Lores_Jerk)</p> <p>OR (Lores_Decel AND Lores_Jerk)</p> <p>OR RevBalanceTime</p>	<p>&gt; 3 Engine Cycles</p> <p>&gt; <b>IdleSCD_Decel *</b> <b>Random_SCD_Decel</b></p> <p>&gt; <b>IdleSCD_Jerk *</b> <b>Random_SCD_Jerk</b></p> <p>&gt; <b>SCD_Decel *</b> <b>Random_SCD_Decel</b></p> <p>&gt; <b>SCD_Jerk *</b> <b>Random_SCD_Jerk</b></p> <p>&gt; <b>IdleCyl_Decel *</b> <b>RandomCylModDecel</b></p> <p>&gt; <b>IdleCyl_Jerk *</b> <b>RandomCylModeJerk</b></p> <p>&gt; <b>CylModeDecel *</b> <b>RandomCylModDecel</b></p> <p>&gt; <b>CylModeJerk *</b> <b>RandomCylModeJerk</b></p> <p>&gt; <b>RevMode_Decel *</b> <b>RandomRevModDecl</b></p>			<p>Catalyst Failure reported with (1 or 3) Exceedences in FTP, or (1) Exceedence outside FTP.</p> <p>Continuous</p>	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			PAIRED CYLINDER MISFIRE If a cylinder & it's pair are above PAIR thresholds (Medres_Decel AND Medres_Jerk) OR (Medres_Decel AND Medres_Jerk) OR (Lores_Decel AND Lores_Jerk) OR (Lores_Decel AND Lores_Jerk) OR (Revmode Active AND (within one engine cycle: 2nd largest Lores_Decel) AND Above TRUE for )	> <b>IdleSCD_Decel *</b> <b>Pair_SCD_Decel</b> > <b>IdleSCD_Jerk *</b> <b>Pair_SCD_Jerk</b> > <b>SCD_Decel *</b> <b>Pair_SCD_Decel</b> > <b>SCD_Jerk *</b> <b>Pair_SCD_Jerk</b> > <b>IdleCyl_Decel *</b> <b>PairCylModeDecel</b> > <b>IdleCyl_Jerk *</b> <b>PairCylModeJerk</b> > <b>CylModeDecel *</b> <b>PairCylModeDecel</b> > <b>CylModeJerk *</b> <b>PairCylModeJerk</b> > <b>CylModeDecel *</b> <b>PairCylModeDecel</b> > 50 engine cycles out of 100 engine cycles				

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			BANK MISFIRE Cylinders above Bank Thresholds  (Medres_Decel  AND Medres_Jerk)  OR (Medres_Decel  AND Medres_Jerk)  OR (Lores_Decel  AND Lores_Jerk)  OR (Lores_Decel  AND Lores_Jerk)	>= 3 cylinders  > <b>IdleSCD_Decel *</b> <b>Bank_SCD_Decel</b>  > <b>IdleSCD_Jerk *</b> <b>Bank_SCD_Jerk</b>  > <b>SCD_Decel *</b> <b>Bank_SCD_Decel</b>  > <b>SCD_Jerk *</b> <b>Bank_SCD_Jerk</b>  > <b>IdleCyl_Decel *</b> <b>BankCylModeDecel</b>  > <b>IdleCyl_Jerk *</b> <b>BankCylModeJerk</b>  > <b>CylModeDecel *</b> <b>BankCylModeDecel</b>  > <b>CylModeJerk *</b> <b>BankCylModeJerk</b>				
			CONSECUTIVE CYLINDER MISFIRE 1st cylinder uses single cyl continuous misfire thresholds; 2nd Cylinder uses: (Medres_Decel	> <b>IdleSCD_Decel *</b> <b>ConsecSCD_Decel</b>				

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>AND Medres_Jerk)</p> <p>OR (Medres_Decel</p> <p>AND Medres_Jerk)</p> <p>OR (Lores_Decel</p> <p>AND Lores_Jerk)</p> <p>OR (Lores_Decel</p> <p>AND Lores_Jerk)</p> <p>CYLINDER DEACTIVATION MODE (Active Fuel Managment)</p> <p>AFM: SINGLE CYLINDER CONTINUOUS MISFIRE (CylAfterDeacCyl_Decel</p> <p>AND CylAfterDeacCyl_Jerk)</p> <p>OR</p>	<p>&gt; IdleSCD_Jerk * ConsecSCD_Jerk</p> <p>&gt; SCD_Decel * ConsecSCD_Decel</p> <p>&gt; SCD_Jerk * ConsecSCD_Jerk</p> <p>&gt; IdleCyl_Decel * ConsecCylModDecel</p> <p>&gt; IdleCyl_Jerk * ConsecCylModeJerk</p> <p>&gt; CylModeDecel * ConsecCylModDecel</p> <p>&gt; CylModeJerk * ConsecCylModeJerk</p> <p>&gt; CylModeDecel * ClyAfterAFM_Decel</p> <p>&gt; CylModeJerk * CylAfterAFM_Jerk</p> <p>&gt; CylModeDecel *</p>				



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			(CylBeforeDeacCylDecel AND CylBeforeDeacCyl_Jerk)	<b>CylBeforeAFM_Decel</b> > <b>CylModeJerk *</b> <b>ClyBeforeAFM_Jerk</b>				
		AFM: RANDOM MISFIRE Use random misfire thresholds If no misfire for	(CylAfterDeacCyl_Decel AND CylAfterDeacCyl_Jerk)	> 3 Engine Cycles > <b>CylModeDecel *</b> <b>ClyAfterAFM_Decel *</b> <b>RandomAFM_Decl</b> > <b>CylModeJerk *</b> <b>CylAfterAFM_Jerk *</b> <b>RandomAFM_Jerk</b>				
			(CylBeforeDeacCylDecel AND CylBeforeDeacCyl_Jerk)	> <b>CylModeDecel *</b> <b>ClyAfterAFM_Decel *</b> <b>RandomAFM_Decl</b> > <b>CylModeJerk *</b> <b>CylAfterAFM_Jerk *</b> <b>RandomAFM_Jerk</b>				
				- see details on Supporting Tables Tab (P0300 Section)				
		Misfire Percent Emission Failure Threshold		≥ 2.19 % P0300				

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Misfire Percent Catalyst Damage	> <b>Catalyst_Damage_Misfire_Percentage</b> in Supporting Tables whenever secondary conditions are met.	(at low speed/loads, one cylinder may not cause cat damage)			
			When engine speed and load are less than the FTP calcs (3) catalyst damage exceedences are allowed.	≤ 2,300 FTP rpm AND ≤ 35 FTP % load	Engine Speed Engine Load Misfire counts	> 2,000 rpm AND > 10 % load AND < 180 counts on one cylinder		
				disable conditions:	Engine Speed	370 < rpm < ((Engine Over Speed Limit) - 400  Engine speed limit is a function of inputs like Gear and temperature  see <b>EngineOverSpeedLimit</b> in supporting tables	4 cycle delay	
					No active DTCs:	TPS_FA EnginePowerLimited MAF_SensorTFTKO MAP_SensorTFTKO IAT_SensorTFTKO ECT_Sensor_Ckt_TFTKO 5VoltReferenceB_FA CrankSensorTFTKO CrankSensorFA	4 cycle delay	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						CamLctnIntFA CamLctnExhFA CamSensorAnyLctnTFTK O AnyCamPhaser_FA AnyCamPhaser_TFTKO AmbPresDfstdStatus		
					P0315 & engine speed	> 1,000 rpm	4 cycle delay	
					Fuel Level Low	LowFuelConditionDiagnostic	500 cycle delay	
					Cam and Crank Sensors	in sync with each other	4 cycle delay	
					Misfire requests TCC unlock	Not honored because Transmission in hot mode or POPD intrusive diagnostic running	4 cycle delay	
					Fuel System Status	≠ Fuel Cut	4 cycle delay	
					Active FuelManagement	Transition in progress	7 cycle delay	
					Undetectable engine speed and engine load region	<b>Undetectable region</b> from Malfunction Criteria	4 cycle delay	
					Abusive Engine Over Speed	> 8,192 rpm	0 cycle delay	
					Below zero torque (except CARB approved 3000 rpm to redline triangle.)	< <b>ZeroTorqueEngLoad</b> in Supporting Tables	4 cycle delay	
					Below zero torque: TPS Vehicle Speed	≤ 1 % > 30 mph	4 cycle delay	
					EGR Intrusive test	Active	0 cycle delay	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Manual Trans  Accel Pedal Position AND Automatic transmission shift  After Fuel resumes on Automatic shift containing Fuel Cut  DRIVELINE RING FILTER After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early. Filter Driveline ring:  Stop filter early:  ABNORMAL ENGINE SPEED OSCILLATION: (checks each "misfire" candidate in 100 engine Cycle test to see if it looks like some disturbance like rough road (abnormal). )  Used Off Idle, and while not shifting, TPS Engine Speed Veh Speed Auto Transmission	Clutch shift  > 95.00 %          > "Ring Filter" # of engine cycles after misfire in Supporting Tables  > "Number of Normals" # of engine cycles after misfire in Supporting Tables tab          > 3 % > 950 rpm > 3 mph not shifting	4 cycle delay  7 cycle delay          2 Cylinder delay	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>individual candidate deemed abnormal if number of consecutive decelerating cylinders after "misfire": (Number of decels can vary with misfire detection equation)                      Consecutive decels while in SCD Mode                      Cyl Mode                      Rev Mode</p> <p>At the end of 100 engine cycle test, the ratio of abnormal/candidate is checked to confirm if real misfire is present within the 100 engine cycles.</p> <p>abnormal candidates/ total candidates</p> <p>MISFIRE CRANKSHAFT PATTERN RECOGNITION checks each "misfire" candidate in 100 engine Cycle test to see if overall crankshaft pattern looks like real misfire (recognized), or some disturbance like rough road (unrecognized).</p>	<p>&gt; <b>Abnormal SCD Mode</b>                      &gt; <b>Abnormal Cyl Mode</b>                      &gt; <b>Abnormal Rev Mode</b>                      in Supporting Tables</p> <p>&gt; 0.50 ratio</p>	<p>discard 100 engine cycle test</p>	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present within the 100 engine cycles. Typically used for checking a single misfire per engine cycle but can support some other patterns on some packages</p> <p>Pattern Recog Enabled:</p> <p>Pattern Recog Enabled during Cylinder Deac</p> <p>Pattern Recog Enabled consecutive cyl patrn</p> <p>Engine Speed Veh Speed</p> <p>The 1st check for "recognized" is the 1st fired cylinder after the misfire candidate should both accelerate and jerk an amount based acceleration and jerk of Single Cylinder Misfire thresholds in effect at that speed and load.</p> <p>(CylAfter_Accel AND CylAfter_Jerk)</p>	<p>Enabled</p> <p>Enabled</p> <p>Enabled</p> <p>1,000 &lt; rpm &lt; 3,000 &gt; 5.0 mph</p> <p>&gt; Misfire_decel * <b>1st_FireAftrMisfr_Acel</b></p> <p>&gt; Misfire_Jerk * <b>1st_FireAftrMisfr_Jerk</b></p>		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Additionally, the crankshaft is checked again a small calibratable number of cylinders later to see if the disturbance is still large like rough road, or has calmed down like real misfire. The size of disturbance is compared to a multiplier times the ddt_jerk value used to detect misfire at that speed and load. If there is repetitive misfire on consecutive engine cycles, the expected snap is adjusted due to the higher expected disturbance.</p> <p>Num of Cylinders after misfire to start check of crankshaft snap</p> <p>"misfire" recognized if: Crankshaft snap after: isolated "misfire"</p> <p>repetative "misfire"</p> <p>At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present.</p> <p>Ratio of Unrecog/Recog</p>	<p>3 Cylinders</p> <p>&lt; Misfire_Jerk * <b>SnapDecayAfterMisfire</b></p> <p>&lt; Misfire_Jerk * <b>SnapDecayAfterMisfire *</b> <b>RepetSnapDecayAdjst</b> in Supporting Tables</p> <p>&gt; 0.60</p>	<p>discard 100 engine cycle test</p>	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					: NON-CRANKSHAFT BASED ROUGH ROAD:  Rough Road Source  IF Rough Road Source = WheelSpeedInECM ABS/TCS Wheel speed noise VSES  IF Rough Road Source = "FromABS" ABS/TCS RoughRoad VSES  IF Rough Road Source = "TOSS" TOSS dispersion  AND No Active DTCs	Disabled  TOSS  active > <b>WSSRoughRoadThres</b> active  active detected active  > <b>TOSSRoughRoadThres</b> in supporting tables  Transmission Output Shaft Angular Velocity Validity TransmissionEngagedStat e_FA (Auto Trans only) Clutch Sensor FA (Manual Trans only)	discard 100 engine cycle test  discard 100 engine cycle test  discard 100 engine cycle test  4 cycle delay	



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Crankshaft Position System Variation Not Learned	P0315	Monitor for valid crankshaft error compensation factors	Sum of Compensation factors. Each Cylinder pair shares one compensation factor. A perfect factor would be 1.0000. Unlearned factors are defaulted out of range so the sum of factors would be out of range.	$\geq 4.0040$ OR $\leq 3.9960$	OBD Manufacturer Enable Counter	MEC = 0	0.50 seconds  Frequency Continuous100 msec	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Knock Sensor (KS) Performance Per Cylinder	P0324	This diagnostic checks for knock sensor performance out of the normal expected range on a per cylinder basis due to: 1. Excessive knock or 2. Abnormal engine noise or 3. Flat signal	Common Enable Criteria  (Applies to all 3 parts of the performance diag)		Diagnostic Enabled?	Yes		Type B, 2 Trips	
			Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag:		Engine Run Time	≥ 2.0 seconds			First Order Lag Filters with Weight Coefficients
			1. Excessive Knock Diag: Filtered Knock Intensity	> 1.50 (no units)	Engine Speed	≤ 8,500 RPM			
VaKNKD_k_PerfCylKnock IntFilt (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)		Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	≥ 148 Revs						
2. Abnormal Noise Diag: Filtered FFT Intensity	< P0324_P0326_P0331_AbnormalNoise_Threshold (Supporting Table)	Individual Cylinders enabled for Abnormal Noise	P0324_P0326_P0331_AbnormalNoise_CylsEnabled (1 = cylinder enabled, 0 = cylinder not enabled)			Abn Noise Weight Coefficient = 0.0400  Updated each engine event			
		(where 'FFT Intensity' = Non-knocking, background noise)			Engine Speed	≥ 8,500 RPM			
					Cumulative Number of Engine Revs Above Min	≥ 134 Revs			

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			----- 3. Flat Signal Diag: Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock)  VaKNKD_k_PerfCylFlatFil tInt	< 0.008 (no units)	Eng Speed (per key cycle)  ----- Engine Speed  Cumulative Number of Engine Revs Above Min Eng Speed (per keycycle)	----- ≥ 8,500 RPM  ≥ 20 Revs	----- Flat Signal Weight Coefficient = 0.010  Updated each engine event	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank 1	P0325	<p>This diagnostic checks for an open in the knock sensor circuit.</p> <p>There are two possible methods used:</p> <ol style="list-style-type: none"> <li>20 kHz</li> <li>Normal Noise</li> </ol> <p>See <b>Supporting Tables</b> for method definition: <b>P0325_P0330_OpenMethod</b></p> <p>Typical implementations:</p> <ol style="list-style-type: none"> <li>Use 20 kHz method at all RPM (used when acceptable separation achieved at all RPM) or</li> <li>Use 20 kHz method at low/medium RPM and Normal Noise at high RPM</li> </ol>	<p><b>Open Circuit Method chosen</b> (2 possible methods: 20 kHz or Normal Noise):</p> <p><b>Thresholds for OpenMethod = 20 kHz</b></p> <p>Filtered FFT Output</p> <p><b>Thresholds for OpenMethod = NormalNoise:</b></p> <p>Filtered FFT Output</p>	<p>Supporting Table: P0325_P0330_OpenMethod_2</p> <p>(See Supporting Tables)</p> <p>&gt; P0325_P0330_OpenCktThrshMin (20 kHz) <b>AND</b> &lt; P0325_P0330_OpenCktThrshMax (20 kHz)</p> <p>&gt; P0325_P0330_OpenCktThrshMin (Normal Noise) <b>AND</b> &lt; P0325_P0330_OpenCktThrshMax (Normal Noise)</p>	<p>Diagnostic Enabled?</p> <p>Engine Run Time</p> <p>Engine Speed</p> <p>Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)</p> <p>Engine Air Flow</p> <p>ECT</p> <p>IAT</p>	<p>Yes</p> <p>≥ 2.0 seconds</p> <p>≥ 400 RPM and ≤ 8,500 RPM</p> <p>≥ 250 revs</p> <p>≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder</p> <p>≥ -40 deg's C</p> <p>≥ -40 deg's C</p>	<p>First Order Lag Filter with Weight Coefficient</p> <p>Weight Coefficient = 0.0100</p> <p>Updated each engine event</p>	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Knock Sensor (KS) Performance Bank 1	P0326	This diagnostic checks for knock sensor performance out of the normal expected range, on a per sensor basis, due to 1. Excessive knock or 2. Abnormal engine noise or 3. Flat signal	Common Enable Criteria  (Applies to all 3 parts of the performance diag)		Diagnostic Enabled?  Engine Run Time  Engine Speed  Engine Air Flow  ECT  IAT	Yes  ≥ 2.0 seconds  ≤ 8,500 RPM  ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder  ≥ -40 deg's C  ≥ -40 deg's C		Type B, 2 Trips	
			----- Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag: -----						----- First Order Lag Filters with Weight Coefficients -----
			1. Excessive Knock Diag: Filtered Knock Intensity  (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)	> 1.50 (no units)	Engine Speed  Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	≥ 8,500 RPM  ≥ 100 Revs	----- Excessive Knk Weight Coefficient =  0.0100  Updated each engine event -----		
2. Abnormal Noise Diag:  Filtered FFT Intensity: (where 'FFT Intensity' = Non-knocking, background noise)	< P0324_P0326_P0331_AbnormalNoise_Threshhold (Supporting Table)	Individual Cylinders enabled for Abnormal Noise  Engine Speed  Cumulative Number of Engine Revs Above Min	P0324_P0326_P0331_AbnormalNoise_CylsEnabled (Supporting Table)  ≥ 2,000 RPM  ≥ 250 Revs	----- Abnormal Noise Weight Coefficient =  0.0100  Updated each engine event -----					

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			----- 3. Flat Signal Diag: Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock)	----- < 0.008 (no units)	Eng Speed (per key cycle)  ----- Engine Speed  Cumulative Number of Engine Revs Above Min Eng Speed (per keycycle)	----- ≥ 8,500 RPM  ≥ 5 Revs	----- Flat Signal Weight Coefficient =  0.010  Updated each engine event	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Knock Sensor (KS) Circuit Low Bank 1	P0327	This diagnostic checks for an out of range low knock sensor signal	Sensor Input or Return Signal Line	< 8.0 Percent  (of 5 V reference)	Diagnostic Enabled?  Engine Speed	Yes  > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Knock Sensor (KS) Circuit High Bank 1	P0328	This diagnostic checks for an out of range high knock sensor signal	Sensor Input or Return Signal Line	> 39.0 Percent  (of 5 Volt Reference)	Diagnostic Enabled?  Engine Speed	Yes  > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank 2	P0330	<p>This diagnostic checks for an open in the knock sensor circuit</p> <p>There are two possible methods used:</p> <ol style="list-style-type: none"> <li>20 kHz</li> <li>Normal Noise</li> </ol> <p>See <b>Supporting Tables</b> for method definition: <b>P0325_P0330_OpenMethod</b></p> <p>Typical implementations:</p> <ol style="list-style-type: none"> <li>Use 20 kHz method at all RPM (used when acceptable separation achieved at all RPM) or</li> <li>Use 20 kHz method at low/medium RPM and Normal Noise at high RPM</li> </ol>	<p><b>Open Circuit Method chosen</b> (2 possible methods: 20 kHz or Normal Noise):</p> <p><b>Thresholds for OpenMethod = 20 kHz</b></p> <p>Filtered FFT Output</p> <p><b>Thresholds for OpenMethod = NormalNoise:</b></p> <p>Filtered FFT Output</p>	<p>Supporting Table: P0325_P0330_OpenMethod_2</p> <p>(See Supporting Tables)</p> <p>&gt; P0325_P0330_OpenCktThrshMin (20 kHz) AND &lt; P0325_P0330_OpenCktThrshMax (20 kHz)</p> <p>&gt; P0325_P0330_OpenCktThrshMin (Normal Noise) AND &lt; P0325_P0330_OpenCktThrshMax (Normal Noise)</p>	<p>Diagnostic Enabled?</p> <p>Engine Run Time</p> <p>Engine Speed</p> <p>Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)</p> <p>Engine Air Flow</p> <p>ECT</p> <p>IAT</p>	<p>Yes</p> <p>≥ 2.0 seconds</p> <p>≥ 400 RPM and ≤ 8,500 RPM</p> <p>≥ 250 revs</p> <p>≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder</p> <p>≥ -40 deg's C</p> <p>≥ -40 deg's C</p>	<p>First Order Lag Filter with Weight Coefficient</p> <p>Weight Coefficient = 0.0100</p> <p>Updated each engine event</p>	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Knock Sensor (KS) Performance Bank 2	P0331	This diagnostic checks for knock sensor performance out of the normal expected range, on a per sensor basis, due to 1. Excessive knock or 2. Abnormal engine noise on a per bank basis or 3. Flat signal	Common Enable Criteria  (Applies to all 3 parts of the performance diag)		Diagnostic Enabled?  Engine Run Time  Engine Speed  Engine Air Flow  ECT  IAT	Yes  ≥ 2.0 seconds  ≤ 8,500 RPM  ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder  ≥ -40 deg's C  ≥ -40 deg's C		Type B, 2 Trips	
			----- Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag: -----						First Order Lag Filters with Weight Coefficients
			1. Excessive Knock Diag: Filtered Knock Intensity  (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)	> 1.50 (no units)	Engine Speed  Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	≥ 8,500 RPM  ≥ 100 Revs	Excessive knk Weight Coefficient =  0.0100  Updated each engine event		
2. Abnormal Noise Diag:  Filtered FFT Intensity:  (where 'FFT Intensity' = Non-knocking, background noise)	< P0324_P0326_P0331_ AbnormalNoise_Thres hold (Supporting Table)	Individual Cylinders enabled for Abnormal Noise  Engine Speed  Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	P0324_P0326_P0331_Ab normalNoise_CylsEnable d (Supporting Table)  ≥ 2,000 RPM  ≥ 250 Revs	Abnormal Noise Weight Coefficient =  0.0100  Updated each engine event					

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			3. Flat Signal Diag: Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock)	< 0.008 (no units)	Engine Speed  Cumulative Number of Engine Revs Above Min Eng Speed (per keycycle)	≥ 8,500 RPM  ≥ 5 Revs	Flat Signal Weight Coefficient = 0.010 Updated each engine event	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Knock Sensor (KS) Circuit Low Bank 2	P0332	This diagnostic checks for an out of range low knock sensor signal	Sensor Input or Return Signal Line	< 8.0 Percent  (of 5 Volt Reference)	Diagnostic Enabled?  Engine Speed	Yes  > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Knock Sensor (KS) Circuit High Bank 2	P0333	This diagnostic checks for an out of range high knock sensor signal	Sensor Input or Return Signal Line	> 39.00 Percent  (of 5 Volt Reference)	Diagnostic Enabled?  Engine Speed	Yes  > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Circuit	P0335	Determines if a fault exists with the crank position sensor signal	Time since last crankshaft position sensor pulse received	>= 4.0 seconds	Starter engaged AND (cam pulses being received OR ( MAF_SensorFA AND Engine Air Flow	= FALSE > 3.0 grams/second ) )	Continuous every 100 msec	Type B, 2 Trips
			No crankshaft pulses received	>= 0.3 seconds	Engine is Running Starter is not engaged		Continuous every 12.5 msec	
			No crankshaft pulses received		Engine is Running OR Starter is engaged  No DTC Active:	P0340 P0341	2 failures out of 10 samples  One sample per engine revolution	

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Performance	P0336	Determines if a performance fault exists with the crank position sensor signal	Time in which 10 or more crank re-synchronizations occur	< 10.0 seconds	Engine Air Flow Cam-based engine speed No DTC Active:	>= 3.0 grams/second > 450 RPM P0335	Continuous every 250 msec	Type B, 2 Trips
			No crankshaft synchronization gap found	>= 0.4 seconds	Engine is Running Starter is not engaged		Continuous every 12.5 msec	
			Time since starter engaged without detecting crankshaft synchronization gap	>= 3.3 seconds	Starter engaged AND (cam pulses being received OR ( MAF_SensorFA AND Engine Air Flow	= FALSE > 3.0 grams/second ) )	Continuous every 100 msec	
			Crank pulses received in one engine revolution OR Crank pulses received in one engine revolution	< 51 > 65	Engine is Running OR Starter is engaged No DTC Active:	P0340 P0341	8 failures out of 10 samples  One sample per engine revolution	



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor A	P0340	Determines if a fault exists with the cam position bank 1 sensor A signal	Time since last camshaft position sensor pulse received	>= 5.5 seconds	Starter engaged AND (crank pulses being received OR ( MAF_SensorFA AND Engine Air Flow	= FALSE > 3.0 grams/second ) )	Continuous every 100 msec	Type B, 2 Trips	
			OR						
			Time that starter has been engaged without a camshaft sensor pulse	>= 4.0 seconds					
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged		Continuous every 100 msec		
			No camshaft pulses received during first 24 MEDRES events (There are 24 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged		Continuous every MEDRES event		
			The number of camshaft pulses received during 100 engine cycles	= 0	No DTC Active:	CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle		
					No DTC Active:	CrankSensor_FA			

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor A	P0341	Determines if a performance fault exists with the cam position bank 1 sensor A signal	The number of camshaft pulses received during first 24 MEDRES events is OR  (There are 24 MEDRES events per engine cycle)	< 4 OR > 8	Crankshaft is synchronized  Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged  No DTC Active:	CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 OR > 402	Crankshaft is synchronized  No DTC Active:	CrankSensorFA	8 failures out of 10 samples  Continuous every engine cycle	

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT	P0351	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #2 CIRCUIT	P0352	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30$ k $\Omega$ impedance between signal and controller ground	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures  out of 63 Samples  100 msec rate	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT	P0353	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #4 CIRCUIT	P0354	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #5 CIRCUIT	P0355	Diagnoses Cylinder #5 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #6 CIRCUIT	P0356	Diagnoses Cylinder #6 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #7 CIRCUIT	P0357	Diagnoses Cylinder #7 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #8 CIRCUIT	P0358	Diagnoses Cylinder #8 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 1	P0420	NOTE: The information below applies to applications that use the Decel Catalyst Monitor Algorithm  Oxygen StorageThe catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (I.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Rich (intrusive rich) and Lean (decel fuel cutoff) A/F excursions  Normalized Ratio OSC Value Calculation Information and Definitions = 1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time) 2. BestFailing OSC value from a calibration	Normalized Ratio OSC Value (EWMA filtered)	< 0.36	All enable criteria associated with P0420 can be found under P2270 - (O2 Sensor Signal Stuck Lean Bank 1 Sensor 2)  Rapid Step Response (RSR) feature will initiate multiple tests:  If the difference between current EWMA value and the current OSC Normalized Ratio value is  and the current OSC Normalized Ratio value is  Maximum number of RSR tests to detect failure when RSR is enabled.  General Enable Criteria  In addition to the p-codes listed under P2270, the following DTC's shall also not be set:	> 0.62            6            O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_2_FA	1 test attempted per valid decel period  Minimum of 1 test per trip  Maximum of 3 tests per trip  Frequency: Fueling Related : 12.5 ms  OSC Measurements: 100 ms  Temp Prediction: 12.5ms	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>table (based on temp and exhaust gas flow) 3. WorstPassing OSC value (based on temp and exhaust gas flow)</p> <p>Normalized Ratio Calculation = (1-2) / (3-2)</p> <p>A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part.</p> <p>Refer to the <b>P0420_WorstPassing OSCTableB1</b> and <b>P0420_BestFailingOSCTableB1</b> in Supporting Tables tab for details</p> <p>The Catalyst Monitoring Test is completed during a decel fuel cutoff event. This fuel cutoff event occurs following a rich intrusive fueling event initiated by the O2 Sensor Signal Stuck Lean Bank 1 Sensor 2 test (P2270). Several conditions must be met in order to execute this test.</p> <p>These conditions and their related values are listed in the "Secondary</p>						

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Parameters" and "Enable Conditions" section of this document for P2270 (O2 Sensor Signal Stuck Lean Bank 1 Sensor 2)						

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 2	P0430	<p>Note: The information below applies to applications that use the Decel Catalyst Monitor Algorithm</p> <p>Oxygen StorageThe catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (I.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Rich (intrusive rich) and Lean (decel fuel cutoff) A/F excursions</p> <p>Normalized Ratio OSC Value Calculation Information and Definitions =                      1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time)                      2. BestFailing OSC value from a calibration</p>	Normalized Ratio OSC Value (EWMA filtered)	< 0.36	<p>All enable criteria associated with P0430 can be found under P2272 - (O2 Sensor Signal Stuck Lean Bank 2 Sensor 2)</p> <p>Rapid Step Response (RSR) feature will initiate multiple tests:</p> <p>If the difference between current EWMA value and the current OSC Normalized Ratio value is</p> <p>and the current OSC Normalized Ratio value is</p> <p>Maximum number of RSR tests to detect failure when RSR is enabled.</p> <p>General Enable Criteria</p> <p>In addition to the p-codes listed under P2272, the following DTC's shall also not be set:</p>	<p>&gt; 0.60</p> <p>&lt; 0.15</p> <p>6</p> <p>O2S_Bank_1_Sensor_1_FA                      O2S_Bank_1_Sensor_2_FA                      O2S_Bank_2_Sensor_1_FA                      O2S_Bank_2_Sensor_2_FA</p>	<p>1 test attempted per valid decel period</p> <p>Minimum of 1 test per trip</p> <p>Maximum of 3 tests per trip</p> <p>Frequency: Fueling Related : 12.5 ms</p> <p>OSC Measurements: 100 ms</p> <p>Temp Prediction: 12.5ms</p>	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>table (based on temp and exhaust gas flow) 3. WorstPassing OSC value (based on temp and exhaust gas flow)</p> <p>Normalized Ratio Calculation = (1-2) / (3-2)</p> <p>A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part.</p> <p>Refer to the <b>P0430_WorstPassing OSCTableB2</b> and <b>P0430_BestFailingOSCTableB2</b> in Supporting Tables tab for details</p> <p>The Catalyst Monitoring Test is completed during a decel fuel cutoff event. This fuel cutoff event occurs following a rich intrusive fueling event initiated by the O2 Sensor Signal Stuck Lean Bank 2 Sensor 2 test (P2272). Several conditions must be met in order to execute this test.</p> <p>These conditions and their related values are listed in the "Secondary</p>						

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Parameters" and "Enable Conditions" section of this document for P2272 (O2 Sensor Signal Stuck Lean Bank 2 Sensor 2)						



### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Small Leak Detected  (No ELCP - Conventional EVAP Diagnostic with EAT using OAT Sensor)	P0442	This DTC will detect a small leak (≥ 0.020") in the EVAP system between the fuel fill cap and the purge solenoid. On some applications a small leak is defined as ≥ 0.025", 0.030", or 0.150". The engine off natural vacuum method (EONV) is used. EONV is an evaporative system leak detection diagnostic that runs when the vehicle is shut off when enable conditions are met. Prior to sealing the system and performing the diagnostic, the fuel volatility is analyzed. In an open system (Canister Vent Solenoid [CVS] open) high volatility fuel creates enough flow to generate a measurable pressure differential relative to atmospheric. After the volatility check, the vent solenoid will close. After the vent is closed, typically a build up of pressure from the hot soak begins (phase-1). The pressure typically will peak and then begin to decrease as the fuel cools. When	The total delta from peak pressure to peak vacuum during the test is normalized against a calibration pressure threshold table that is based upon fuel level and ambient temperature. (Please see <b>P0442: EONV Pressure Threshold (Pascals) Table</b> in Supporting Tables). The normalized value is calculated by the following equation: 1 - (peak pressure - peak vacuum) / pressure threshold. The normalized value is entered into EWMA (with 0= perfect pass and 1= perfect fail).  When EWMA is  the DTC light is illuminated.  The DTC light can be turned off if the EWMA is  and stays below the EWMA fail threshold for 3 additional consecutive trips.	          ≤ 0.35 (EWMA Re-Pass Threshold)	Fuel Level Drive Time Drive length ECT Baro Distance since assembly plant Engine not run time before key off must be  Time since last complete test if normalized result and EWMA is passing  OR Time since last complete test if normalized result or EWMA is failing  Estimated Ambient Temperature (EAT) using OAT sensor at end of drive  Conditions for Estimated Ambient Temperature Using OAT Sensor to be Valid ***** 1. Startup OAT is less than previous trip EAT	10 % ≤ Percent ≤ 90 % ≥ 600 seconds ≥ 5.0 miles ≥ 63 °C ≥ 70 kPa ≥ 10.0 miles  ≤ refer to <b>P0442: Engine Off Time Before Vehicle Off Maximum as a Function of Estimated Ambient Temperature Table</b> in Supporting Tables.  ≥ 17 hours  ≥ 10 hours  0 °C ≤ Temperature ≤ 34 °C  *****	Once per trip, during hot soak (up to 2,400 sec.). No more than 2 unsuccessful attempts between completed tests.	Type A, 1 Trips  EWMA  Average run length is 8 to 12 trips under normal conditions  Run length is 3 to 6 trips after code clear or non-volatile reset

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		the pressure drops (-62.27) Pa from peak pressure, the vent is then opened for 60 seconds to normalize the system pressure. The vent is again closed to begin the vacuum portion of the test (phase-2). As the fuel temperature continues to fall, a vacuum will begin forming. The vacuum will continue until it reaches a vacuum peak. When the pressure rises 62.27 Pa from vacuum peak, the test then completes. If the key is turned on while the diagnostic test is in progress, the test will abort.			OR 2. Startup ECT - previous trip EAT  OR 3. Engine off time  OR 4. At startup, time since previous EAT valid and able to learn  OR 5. EAT - current OAT  OR 6. EAT < current OAT and speed timer and current OAT - EAT  Speed timer increments at 100 msec rate and increments vary based on vehicle speed as follows:  vehicle speed < 16 mph - 10.0 seconds 16 mph<speed< 47 mph 0.13 seconds 47 mph<speed< 123.7 0.25 seconds 123.7 mph<speed< 124.3 1.00 seconds  Speed timer can never be less than 0 seconds  ***** 1. High Fuel Volatility  During the volatility phase, pressure in the fuel tank is integrated vs. volatility time. If the integrated pressure is then test aborts and	≤ 0 °C  ≥ 7,200 seconds  ≤ 3,600 seconds  0 °C ≤ difference ≤ 2 °C  ≥ 240 seconds ≤ 2 °C  *****  < -5		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>unsuccessful attempts is incremented. This value equates to an average integrated fuel tank pressure &gt; 1,245 Pa. Please see <b>P0442: Volatility Time as a Function of Estimate of Ambient Temperature</b> in Supporting Tables.</p> <p>OR</p> <p>2. Vacuum Refueling Detected</p> <p>See P0454 Fault Code for information on vacuum refueling algorithm.</p> <p>OR</p> <p>3. Fuel Level Refueling Detected</p> <p>See P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>4. Vacuum Out of Range and No Refueling</p> <p>See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>5. Vacuum Out of Range</p>			

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					and Refueling Detected  See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.  OR 6. Vent Valve Override Failed  Device control using an off-board tool to control the vent solenoid, cannot exceed during the EONV test  OR 7. Key up during EONV test  No active DTCs:	0.50 seconds          MAF_SensorFA ECT_Sensor_FA IAT_SensorFA VehicleSpeedSensor_FA IgnitionOffTimeValid AmbientAirDefault   P0443 P0446 P0449 P0452 P0453 P0455 P0496		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Evaporative Emission (EVAP) Canister Purge Solenoid Valve Circuit (ODM)  (No ELCP - Conventional EVAP Diagnostic - For 3 DTC Implementation Only)	P0443	Diagnoses the canister purge solenoid low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	PT Relay Voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controllers P0458 may also set (Canister Purge Solenoid Short to Ground)

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent System Performance  (No ELCP - Conventional EVAP Diagnostic)	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filler, vent hose or EVAP canister.  This test runs with normal purge and vent valve is open.	Vent Restriction Prep Test: Vented Vacuum for OR Vented Vacuum for  Vent Restriction Test: Tank Vacuum for before Purge Volume  After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time.	< -623 Pa 60 seconds  > 1,245 Pa 60 seconds  > 2,989 Pa 5 seconds ≥ 12 liters	Fuel Level System Voltage  Startup IAT  Startup ECT BARO  No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts 4 °C ≤ Temperature ≤ 30 °C ≤ 35 °C ≥ 70 kPa  MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited  P0443 P0449 P0452 P0453 P0454	Once per Cold Start  Time is dependent on driving conditions  Maximum time before test abort is 1,000 seconds	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Evaporative Emission (EVAP) Vent Solenoid Control Circuit (ODM)  (No ELCP - Conventional EVAP Diagnostic - For 3 DTC Implementation Only)	P0449	Diagnoses the vent solenoid low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground			20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controllers P0498 may also set (Vent Solenoid Short to Ground)

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Performance  (No ELCP - Conventional EVAP Diagnostic)	P0451	The DTC will be set if the fuel tank vacuum sensor is out of range when it tries to re-zero prior to the phase-1 or phase-2 portions of the engine-off natural vacuum small leak test.	<p>The tank vacuum sensor voltage is compared to a window about the nominal sensor voltage offset (~1.5 volts)</p> <p>Upper voltage threshold (voltage addition above the nominal voltage)</p> <p>Lower voltage threshold (voltage subtraction below the nominal voltage)</p> <p>The difference between tank vacuum sensor voltage and the nominal offset voltage is then normalized against the appropriate threshold listed above to produce a ratio between 0.0 and 1.0. This normalized re-zero ratio is then filtered with a EWMA (with 0= perfect pass and 1=perfect fail).</p> <p>When EWMA is</p> <p>the DTC light is illuminated.</p> <p>The DTC light can be turned off if the EWMA is</p> <p>and stays below the EWMA fail threshold for 3 additional consecutive trips.</p>	<p>0.2 volts</p> <p>0.2 volts</p> <p>&gt; 0.73 (EWMA Fail Threshold),</p> <p>≤ 0.40 (EWMA Re-Pass Threshold)</p>	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		This test is executed during an engine-off natural vacuum small leak test. The number of times that it executes can range from zero to two per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.	Type A, 1 Trips  EWMA  Average run length: 6 Run length is 2 trips after code clear or non-volatile reset



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Tank Pressure (FTP) Sensor Circuit Low Voltage  (No ELCP - Conventional EVAP Diagnostic)	P0452	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too low out of range.	FTP sensor signal  The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~3736 Pa).	< 0.15 volts (3.0 % of Vref or ~ 1,681 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples  12.5 ms / sample	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Tank Pressure (FTP) Sensor Circuit High Voltage  (No ELCP - Conventional EVAP Diagnostic)	P0453	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too high out of range.	FTP sensor signal  The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~ -3736 Pa).	> 4.85 volts ( 97 % of Vref or ~ -4,172 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples  12.5 ms / sample	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Intermittent  (No ELCP - Conventional EVAP Diagnostic)	P0454	This DTC will detect intermittent tank vacuum sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	If an abrupt change in tank vacuum is detected the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that a refueling event occurred. If a refueling is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem. An abrupt change is defined as a change in vacuum: in the span of 1.0 seconds. But in 12.5 msec. A refueling event is confirmed if the fuel level has a persistent change of for 30 seconds during a 600 second refueling rationality test.	> 112 Pa < 249 Pa  > 10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes and the canister vent solenoid is closed		This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.  12.5 ms / sample	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Large Leak Detected  (No ELCP - Conventional EVAP Diagnostic)	P0455	This DTC will detect a weak vacuum condition (large leak or purge blockage) in the EVAP system.  Purge valve is controlled (to allow purge flow) and vent valve is commanded closed.	Purge volume while Tank vacuum  After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time.  Weak Vacuum Follow-up Test (fuel cap replacement test) Weak Vacuum Test failed.  Passes if tank vacuum  Note: Weak Vacuum Follow-up Test can only report a pass.	> 22 liters  ≤ 2,740 Pa          ≥ 3,487 Pa	Fuel Level System Voltage  BARO Purge Flow  No active DTCs:       Cold Start Test  If ECT > IAT, Startup temperature delta (ECT-IAT): Cold Test Timer Startup IAT  Startup ECT  Weak Vacuum Follow-up Test This test can run following a weak vacuum failure or on a hot restart.	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts ≥ 70 kPa ≥ 2.50 %  MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited  P0443 P0449 P0452 P0453 P0454    ≤ 8 °C ≤ 1,000 seconds 4 °C ≤ Temperature ≤ 30 °C  ≤ 35 °C	Once per cold start  Time is dependent on driving conditions  Maximum time before test abort is 1,000 seconds  Weak Vacuum Follow-up Test  With large leak detected, the follow-up test is limited to 0 seconds. Once the MIL is on, the follow-up test runs indefinitely.	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Evaporative Emission System Purge Control Valve Circuit Low  (No ELCP - Conventional EVAP Diagnostic)	P0458	Diagnoses the canister purge solenoid low side driver circuit for circuit faults	Voltage low during driver off state (indicates short to ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	PT Relay Voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controlle rs P0443 may also set (Caniste r Purge Solenoid Open Circuit)

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Evaporative Emission System Purge Control Valve Circuit High  (No ELCP - Conventional EVAP Diagnostic)	P0459	Diagnoses the canister purge solenoid low side driver circuit for circuit faults	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	PT Relay Voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Performance  (For use on vehicles with a single fuel tank)	P0461	This DTC will detect a fuel sender stuck in range in the primary fuel tank.	Delta fuel volume change over an accumulated 150 miles.	< 3 liters	Engine Running  No active DTCs:	VehicleSpeedSensor_FA	250 ms / sample	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Level Sensor 1 Circuit Low Voltage	P0462	This DTC will detect a fuel sender stuck out of range low in the primary fuel tank.	Fuel level Sender % of 5V range	< 10 %			100 failures out of 125 samples  100 ms / sample	Type B, 2 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Level Sensor 1 Circuit High Voltage	P0463	This DTC will detect a fuel sender stuck out of range high in the primary fuel tank.	Fuel level Sender % of 5V range	> 60 %			100 failures out of 125 samples  100 ms / sample	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Intermittent  (No ELCP - Conventional EVAP Diagnostic)	P0464	This DTC will detect intermittent fuel level sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	<p>If a change in fuel level is detected, the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that an actual refueling event occurred. If a refueling event is confirmed, then the test sample is considered passing. Otherwise, if a refueling event is not confirmed, then the test sample is considered failing which indicates an intermittent signal problem.</p> <p>An intermittent fuel level signal problem is defined as:</p> <p>The fuel level changes by and does not remain for 30 seconds during a 600 second refueling rationality test.</p>	> 10 % > 10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		<p>This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.</p> <p>100 ms / sample</p>	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cooling Fan 1 Relay Control Circuit Open (ODM) (Not used on EREV)	P0480	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples  100 ms / sample	Type B, 2 Trips  Note: In certain controllers P0691 may also set (Fan 1 Short to Ground).

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Flow During Non- Purge  (No ELCP - Conventional EVAP Diagnostic)	P0496	This DTC will determine if the purge solenoid is leaking to engine manifold vacuum.  This test will run with the purge valve closed and the vent valve closed.	Tank Vacuum for  Test time	> 2,491 Pa 5 seconds  ≤ refer to <b>P0496: Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level Table</b> in Supporting Tables.	Fuel Level System Voltage  BARO Startup IAT  Startup ECT Engine Off Time  No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts ≥ 70 kPa 4 °C ≤ Temperature ≤ 30 °C  ≤ 35 °C ≥ 28,800.0 seconds  MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited  P0443 P0449 P0452 P0453 P0454	Once per cold start  Cold start: max time is 1,000 seconds	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Evaporative Emission System Vent Solenoid Control Circuit Low  (No ELCP - Conventional EVAP Diagnostic)	P0498	Diagnoses the vent solenoid low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short to ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground			20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controlle rs P0449 may also set (Vent Solenoid Open Circuit)

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Evaporative Emission System Vent Solenoid Control Circuit High  (No ELCP - Conventional EVAP Diagnostic)	P0499	Diagnoses the vent solenoid low side driver circuit for circuit faults. If the P0499 is active, an intrusive test is performed with the vent solenoid commanded closed for 15 seconds.	Voltage low during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power			20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Low Engine Speed Idle System	P0506	This DTC will determine if a low idle exists	Filtered Engine Speed Error  filter coefficient	> 91.00 rpm  0.00300	Baro  Coolant Temp  Engine run time Ignition voltage Time since gear change  Time since a TCC mode change  IAT Vehicle speed Commanded RPM delta Idle time  For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa  > KeSPDD_T_EnblECT_Mi n ( 60 °C) and < KfECTI_T_EngCoolHotHi Thresh ( 128 °C) Must verify KfECTI_T_EngCoolHotLo Thresh ( 125 ) is less than KfECTI_T_EngCoolHotHi Thresh ( 128)  ≥ 60 sec 32 ≥ volts ≥ 11 ≥ 3 sec  > 3 sec  > -20 °C ≤ 1.24 mph ≤ 25 rpm > 10 sec  > 12.00 pct or < 75.00 pct	Diagnostic runs in every 12.5 ms loop  Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	PTO not active Transfer Case not in 4WD LowState Off-vehicle device control (service bay control) must not be active. following conditions not TRUE: (VeTESR_e_EngSpdReqIntvType = CeTESR_e_EngSpdMinLimit AND VeTESR_e_EngSpdReqRespType = CeTESR_e_NoSuggestion) Clutch is not depressed TC_BoostPresSnrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorCircuitFA EvapFlowDuringNonPurge_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_FA IgnitionOutputDriver FA		



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for Idle time	TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA FuelLevelDataFault LowFuelConditionDiagnos tic Clutch Sensor FA AmbPresDfltStatus P2771  > 10 sec  The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop vehicle)		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Engine Speed Idle System	P0507	This DTC will determine if a high idle exists	Filtered Engine Speed Error  filter coefficient	< -182.00 rpm  0.00300	Baro  Coolant Temp  Engine run time Ignition voltage Time since gear change Time since a TCC mode change IAT Vehicle speed Commanded RPM delta  For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa  > KeSPDD_T_EnblECT_Mi n ( 60 °C) and < KfECTI_T_EngCoolHotHi Thresh ( 128 °C) Must verify KfECTI_T_EngCoolHotLo Thresh ( 125 ) is less than KfECTI_T_EngCoolHotHi Thresh ( 128 )  ≥ 60 sec 32 ≥ volts ≥ 11 ≥ 3 sec ≥ 3 sec  > -20 °C ≤ 1.24 mph ≤ 25 rpm  > 12.00 pct or < 75.00 pct	Diagnostic runs in every 12.5 ms loop  Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	PTO not active  Transfer Case not in 4WD LowState  Off-vehicle device control (service bay control) must not be active.  following conditions not TRUE: (VeTESR_e_EngSpdReqI ntvType = CeTESR_e_EngSpdMinLi mit AND VeTESR_e_EngSpdReqR espType = CeTESR_e_NoSuggestio n)  Clutch is not depressed  TC_BoostPresSnsrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorCircuitFA EvapFlowDuringNonPurg e_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_F A IgnitionOutputDriver_FA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for Idle time	FuelLevelDataFaultLow FuelConditionDiagnostic Clutch SensorFA AmbPresDfltStatus P2771  > 10 sec  The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop vehicle)		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Rough Idle	P050D	Monitors the combustion performance when the cold start emission reduction strategy is active by accumulating and determining the percentage of engine cycles that have less than complete combustion relative to the total number of engine cycles in which Dual Pulse is active.	Deceleration index vs. Engine Speed Vs Engine load  Deceleration index calculation is tailored to specific vehicle. Tables used are 1st tables encountered that are not max of range. Undetectable region at a given speed/load point is where all tables are max of range point. see Algorithm Description Document for additional details.  Incomplete combustion identified by P0300 threshold tables:	(>Idle SCD AND >Idle SCD ddt Tables) OR (>Idle Cyl Mode AND > Idle Cyl Mode ddt Tables)	Misfire Algorithm Enabled (Refer to P0300 for Enablement Requirements)  OBD Manufacturer Enable Counter  To enable the diagnostic, the Cold Start Emission Reduction Strategy Must Be Active per the following:  Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure  In addition, Dual Pulse Strategy Is Enabled and Active Per the following:  Engine Speed  Accel Position  Engine Run Time  For the engine speeds and loads in which Dual Pulse is active:	= 0  < 300.00 degC > 17.00 degC <= 43.00 degC >= 75.00 KPa  >= 550.00 RPM <= 2,000.00 RPM  <= 1.00 Pct  < 100 seconds	Runs once per trip when the cold start emission reduction strategy is active and Dual Pulse is enabled and active.  Frequency: 100ms  Test completes after Dual Pulse is no longer active OR The first 500 engine cycles have been reached	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Dual Pulse Error induced misfires percentage  Dual Pulse Error induced misfires percentage  Engine Cycles  The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following:  Catalyst Temperature AND Engine Run Time  OR  Engine Run Time          OR  Barometric Pressure	>= catalyst damaging misfire  < 90% of the maximum achievable catalyst damaging misfire.  >= 50 < 501  >= 800.00 degC >= 1.00 seconds  > <b>CatalystLightOffExtendedEngineRunTimeExit</b>  This Extended Engine run time exit table is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details.          < 75.00 KPa		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Dual Pulse Strategy will exit per the following:  Engine Speed > 2,500.00 RPM OR Accel Position > 3.00 Pct  Engine Run Time >= 100 seconds  Dual Pulse Strategy will also exit if the any of the "Additional Dual Pulse Enabling Criteria" is not satisfied:  "Additional Dual Pulse Enabling Criteria":  Green Engine Enrichment Not Enabled  Misfire Converter Protection strategy Not being requested  Engine Metal Overtemp strategy Not being requested  Fuel control state Open Loop  Output State Control Not being requested for fuel  DOD Or DFCO Not Active  Power Enrichment Not Active  Dynamic Power Enrichment Not Active  Piston Protection Not Active  Hot Coolant Enrichment Not Active			

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Injector Flow Test  General Enable  DTC's Not Set:	Not Active  AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFA CrankSensorFaultActive FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA AnyCamPhaser_TFTKO Clutch Sensor FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA FuelInjectorCircuit_TFTK O FHPR_b_FRP_SnsrCkt_F A FHPR_b_FRP_SnsrCkt_T FTKO FHPR_b_PumpCkt_FA FHPR_b_PumpCkt_TFTK O TransmissionEngagedStat e_FA EngineTorqueEstInaccura te FuelPumpRlyCktFA		



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Sensor Performance - Two Stage Oil Pump	P0521	Determines if the Engine Oil Pressure (EOP) Sensor is stuck or biased in range	<p><b>Two Stage Oil Pump EOP Sensor Test with Engine Running</b></p> <p>If enabled:</p> <p><u>To Fail when previously passing with the engine running:</u></p> <p>Filtered Engine Oil Pressure below expected threshold</p> <p>OR</p> <p>Filtered Engine Oil Pressure above expected threshold</p> <p><u>To pass when previously failing:</u></p> <p>Filtered Engine Oil Pressure above low threshold plus an offset</p> <p>OR</p> <p>Filtered Engine Oil Pressure below high threshold minus an offset</p>	<p>Filtered Oil Pressure ≤ <b>LowMinOilPresFail</b> (Details on Supporting Tables Tab)</p> <p>OR</p> <p>Filtered Oil Pressure ≥ <b>(OP_HiStatePressure * 1.32 + 116.0 kPa)</b> (Details on Supporting Tables Tab)</p> <p>Filtered Oil Pressure ≥ 10.0 kPa+ <b>LowMinOilPresFail</b> (Details on Supporting Tables Tab)</p> <p>OR</p> <p>Filtered Oil Pressure ≤ <b>(OP_HiStatePressure * 1.32 + 116.0 kPa) -</b></p>	<p>Two Stage Oil Pump is Present = TRUE</p> <p>Engine Running Diagnostic Status</p> <p>Engine Off Rationality Test Diagnostic Reporting Status</p> <p>Oil Pressure Sensor In Use</p> <p>Engine Running</p> <p>Ambient Air Pressure</p> <p>Oil Aeration (= TRUE if engine speed &gt; 8,000 RPM for longer than 65,000.0 seconds)</p> <p>Filtered Engine Speed within range</p> <p>Modelled Oil Temperature within range</p> <p>No active DTC's</p>	<p>TRUE</p> <p>Enabled</p> <p>Test not report a fail state</p> <p>Yes</p> <p>≥ 30.0 seconds</p> <p>≥ 70.0 kPa</p> <p>FALSE</p> <p>1,000 RPM ≤ Filtered Engine Speed ≤ 4,500 RPM</p> <p>40.0 deg C ≤ Oil Temp ≤ 120.0 deg C</p> <p>Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensorFA EngOilPressureSensorCkt FA AmbientAirDefault EngOilTempFA</p>	<p>≥ 40 errors out of 50 samples.</p> <p>Performed every 100 msec</p> <p>≥ 10 passes out of 50 samples.</p> <p>Performed every 100 msec</p>	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				10.0 kPa  (Details on Supporting Tables Tab)				
			<b>Two Stage Oil Pump EOP Sensor Test with Engine Off</b>  If enabled:  <u>To Fail when previously passing with the engine off:</u>  Filtered Engine Oil Pressure greater than threshold	Filtered Oil Pressure ≥ 40.0 kPa	Two Stage Oil Pump is Present = TRUE  Engine Off Rationality Test Diagnostic Status  Engine Running Rationality Test Diagnostic Reporting Status  Modelled Oil Temperature  No Engine Movement  No active DTC's	TRUE  Enabled  Test not report a fail state  ≥ 60.0 deg C  > 10.0 seconds  EngineModeNotRunTimer _FA EngOilTempFA EngOilPressureSensorCkt FA CrankSensorFA	≥ 20 errors out of 40 samples.  Run once per trip	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Sensor Circuit Low Voltage	P0522	Determines if the Engine Oil Pressure (EOP) Sensor circuit voltage is too low	(Engine Oil Pressure Sensor Circuit Voltage) ÷ 5 Volts) *100	< 5.00 percent	Engine Speed Enable Engine Speed Disable  Oil Pressure Sensor In Use  Diagnostic Status	> 400 rpm < 350 rpm  Yes  Enabled	800 failures out of 1,000 samples  Performed every 6.25 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Engine Oil Pressure (EOP) Sensor Circuit High Voltage	P0523	Determines if the Engine Oil Pressure (EOP) Sensor circuit voltage is too high	(Engine Oil Pressure Sensor Circuit Voltage) ÷ 5 Volts) *100	> 95.00 percent	Oil Pressure Sensor In Use  Diagnostic Status	Yes  Enabled	800 failures out of 1,000 samples Performed every 6.25 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Air Conditioning High Side Pressure Sensor (HSPS) Circuit Low Voltage	P0532	Determines if the Air Conditioning High Side Pressure Sensor circuit voltage is too low	(AC High Side Pressure Sensor Circuit Voltage) ÷ 5 Volts) *100	< 3 percent	AC HSP Sensor Present  Diagnostic Status	Yes  Enabled	80 failures out of 100 samples  Performed every 25 msec	Type C, No MIL

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Air Conditioning High Side Pressure Sensor (HSPS) Circuit High Voltage	P0533	Determines if the Air Conditioning High Side Pressure Sensor circuit voltage is too high	(AC High Side Pressure Sensor Circuit Voltage) ÷ 5 Volts) *100	> 95 percent	AC HSP Sensor Present  Diagnostic Status	Yes  Enabled	80 failures out of 100 samples  Performed every 25 msec	Type C, No MIL

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cruise Control Mutil-Function Switch Circuit	P0564	Detect when cruise control multi-function switch circuit (analog) voltage is in an illegal range	Cruise Control analog circuit voltage must be in an "illegal range" or "between ranges" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 0.500 seconds	MIL: Type C, No MIL

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cruise Control On Switch Circuit	P0565		Cruise Control On switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	MIL Type C, No MIL



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cruise Control Resume Circuit	P0567	Detects a failure of the cruise resume switch in a continuously applied state	Cruise Control Resume switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 89.000 seconds	MIL: Type C, No MIL

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cruise Control Set Circuit	P0568	Detects a failure of the cruise set switch in a continuously applied state	Cruise Control Set switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 89.000 seconds	MIL: Type C, No MIL

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cruise Control Cancel Switch Circuit	P056C		Cruise Control Cancel switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	MIL: Type C, No MIL

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cruise Control Input Circuit	P0575	Detects rolling count or protection value errors in Cruise Control Switch Status serial data signal	If x of y rolling count / protection value faults occur, disable cruise for duration of fault		Cruise Control Switch Serial Data Error Diagnostic Enable	1.00	10 / 16 counts	MIL: Type C, No MIL

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Range/ Performance	P057B	This diagnostic monitors the Brake Pedal Position Sensor for a stuck in range failure	.		Brake Pedal Position Sensor Circuit Range / Performance Diagnostic Enable	1.00  ignition voltage > 10.00		MIL: Type A, 1 Trips
			Calculated EWMA value must be greater than calibratable threshold after calibratable number of tests have completed to report a "test passed" for P057B	EWMA value looked up in supporting table P057B KtBRKI_K_FastTestPointWeight as a function of calculated brake pedal position delta EWMA value is > 0.80	calculated brake pedal position delta sample counter > 50.00 for fast test  OR calculated brake pedal position delta sample counter > 1,000.00 for slow test	calculated brake pedal position delta > 8.00  OR (for slow test) shift lever has been in park once this key cycle vehicle speed >= 5.00 accelerator pedal position < 5.00	total number of EWMA tests > 20.00	
			Calculated EWMA Value must be less than calibratable threshold after calibratable number of tests have completed to report a "test failed" for P057B. This test runs once per key cycle	EWMA value looked up in supporting table P057B KtBRKI_K_CmpltTestPointWeight as a function of calculated brake pedal position delta EWMA value is less than 0.40	no DTC's active (P057C, P057D)	shift lever has been in park once this key cycle vehicle speed >= 5.00 accelerator pedal position < 5.00	total number of EWMA tests > 2.00	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Brake Pedal Position Sensor Circuit Low	P057C	detects short to ground for brake pedal position sensor	If x of y samples are observed below failure threshold, default brake pedal position to zero percent.	5.00	Brake Pedal Position Sensore Low Voltage Diagnostic Enable	1.00	20 / 32.00 counts	MIL: Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Brake Pedal Position Sensor Circuit High	P057D	detects open circuit for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	95.00	Brake Pedal Position Sensore High Voltage Diagnostic Enable	1.00	20.00 / 32.00 counts	MIL: Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cruise Control Multi-function Circuit Low Voltage	P0580	detects short to ground failure for cruise multi-function switch circuit	Cruise Control analog circuit voltage must be in an "Open Short To Ground" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	MIL: Type C, No MIL



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cruise Control Multi-function Circuit High Voltage	P0581		Cruise Control analog circuit voltage must be in an "Short To Power" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	MIL: Type C, No MIL

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if the calibration check sum is incorrect or the flash memory detects an uncorrectable error via the Error Correcting Code.	The Primary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	Type A, 1 Trips
			The Primary Processor's Error Correcting Code hardware in the flash memory detects an error. Covers all software and calibrations.	254 failures detected via Error Correcting Code			Diagnostic runs continuously via the flash hardware.	
			The Primary Processor's calculated checksum does not match the stored checksum value for a selected subset of the calibrations.	2 consecutive failures detected or 5 total failures detected.			Diagnostic runs continuously. Will report a detected fault within 200 ms.	
			The Secondary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	
				In all cases, the failure count is cleared when controller shuts down				

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Control Module Not Programmed	P0602	This DTC will be stored if the ECU is a service part that has not been programmed.	Service (reflash) controller calibration present	= 1		none	Diagnostic runs at powerup and once per second continuously after that	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Control Module Long Term Memory Reset	P0603	Non-volatile memory checksum error at controller power-up	Checksum at power-up does not match checksum at power-down				Diagnostic runs at powerup  Diagnostic reports a fault if 1 failure occurs	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM RAM Failure	P0604	Indicates that the ECM has detected a RAM fault	Indicates that the primary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	Type A, 1 Trips
			Indicates that the primary processor is unable to correctly read data from or write data to cached RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor is unable to correctly read data from or write data to TPU RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor detects a mismatch between the data and dual data is found during RAM updates. Detects a mismatch in data and dual data updates >	0.47116 s			When dual store updates occur.	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Indicates that the primary processor detects an illegal write attempt to protected RAM. Number of illegal writes are >	65,534 counts			Diagnostic runs continuously (background loop)	
			Indicates that the secondary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Fault	P0606	Indicates that the ECM has detected an internal processor integrity fault	Loss or invalid message of SPI communication from the Secondary Processor at initialization detected by the Primary Processor or loss or invalid message of SPI communication from the Secondary Processor after a valid message was received by the Primary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received		Run/Crank voltage >= 6.41 or Run/Crank voltage >= 11.00 , else the failure will be reported for all conditions	In the primary processor, 159 / 399 counts intermittent or 39 counts continuous; 39 counts continuous @ initialization. 12.5 ms /count in the ECM main processor	Type A, 1 Trips
			Loss or invalid message of SPI communication from the Primary Processor at initialization detected by the Secondary Processor or loss or invalid message of SPI communication from the Primary Processor after a valid message was received by the Secondary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received			In the secondary processor, 20 / 200 counts intermittent or 0.1875 s continuous; 0.4750 s continuous @ initialization. 12.5 ms /count in the ECM secondary processor	
			Checks for stack over or underflow in secondary processor by looking for corruption of known pattern at stack boundaries. Checks number of stack over/ under flow since last powerup reset >=	5		KeMEMD_b_StackLimitTestEnbl == 1 Value of KeMEMD_b_StackLimitTestEnbl is: 1 . (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			MAIN processor is verified by responding to a seed sent from the secondary with a key response to secondary. Checks number of incorrect keys	2 incorrect seeds within 8 messages, 0.2000 seconds		ignition in Run or Crank	150 ms for one seed continually failing	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			received > or Secondary processor has not received a new within time limit					
			Time new seed not received exceeded			always running	0.450 seconds	
			MAIN processor receives seed in wrong order			always running	3 / 17 counts intermittent. 50 ms/count in the ECM main processor	
			2 fails in a row in the Secondary processor's ALU check			KePISD_b_ALU_TestEnbl d == 1 Value of KePISD_b_ALU_TestEnbl d is: 1. (If 0, this test is disabled)	25 ms	
			2 fails in a row in the Secondary processor's configuration register masks versus known good data			KePISD_b_ConfigRegTes tEnbl d == 1 Value of KePISD_b_ConfigRegTes tEnbl d is: 1. (If 0, this test is disabled)	12.5 to 25 ms	
			Secondary processor detects an error in the toggling of a hardware discrete line controlled by the MAIN processor: number of discrete changes > = or < = over time window(50ms)	7 17		KePISD_b_MainCPU_SO H_FltEnbl d == 1 Value of KePISD_b_ConfigRegTes tEnbl d is: 0 . (If 0, this test is disabled)  time from initialization >= 0.4875 seconds	50 ms	
			Software background task first pass time to complete exceeds			Run/Crank voltage > 6.41	360.000 seconds	



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			2 fails in a row in the MAIN processor's ALU check			KePISD_b_ALU_TestEnbl == 1 Value of KePISD_b_ALU_TestEnbl is: 1. (If 0, this test is disabled)	25 ms	
			2 fails in a row in the MAIN processor's configuration register masks versus known good data			KePISD_b_ConfigRegTestEnbl == 1 Value of KePISD_b_ConfigRegTestEnbl is: 1. (If 0, this test is disabled)	12.5 to 25 ms	
			Checks number of stack over/under flow since last powerup reset >=	3		KeMEMD_b_StackLimitTestEnbl == 1 Value of KeMEMD_b_StackLimitTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			Voltage deviation >	0.4950		KePISD_b_A2D_CnvtrTestEnbl == 1 Value of KePISD_b_A2D_CnvtrTestEnbl is: 1. (If 0, this test is disabled)	5 / 10 counts or 0.150 seconds continuous; 50 ms/count in the ECM main processor	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_FlashECC_CktTestEnbl == 1 Value of KeMEMD_b_FlashECC_CktTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	
			Checks for ECC (error	3 (results in MIL),		KeMEMD_b_RAM_ECC_	variable,	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	5 (results in MIL and remedial action)		CktTestEnbl == 1 Value of KeMEMD_b_RAM_ECC_CktTestEnbl is: 1. (If 0, this test is disabled)	depends on length of time to write flash to RAM variable, depends on length of time to write flash to RAM	
			MAIN processor DMA transfer from Flash to RAM has 1 failure			KePISD_b_DMA_XferTestEnbl == 1 Value of KePISD_b_DMA_XferTestEnbl is: 0. (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM	
			Safety critical software is not executed in proper order.	>= 1 incorrect sequence.		Table, f(Loop Time). See supporting tables: <b>Program Sequence Watch Enable f(Loop Time)</b>  (If 0, this Loop Time test is disabled)	Fail Table, f(Loop Time). See supporting tables: <b>PSW Sequence Fail f(Loop Time)</b>  /  Sample Table, f(Loop Time) See supporting tables: <b>PSW Sequence Sample f(Loop Time)</b>  counts  50 ms/count in the ECM main processor	
			MAIN processor	Previous seed value		KePISD_b_SeedUpdKey	Table, f(Loop	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			determines a seed has not changed within a specified time period within the 50ms task.	equals current seed value.		StorFltEnbl == 1 Value of KePISD_b_SeedUpdKey StorFltEnbl is: 1. (If 0, this test is disabled)	Time). See supporting tables: <b>Last Seed Timeout f (Loop Time)</b>	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Pump Relay Control Circuit Low Voltage	P0628	Diagnoses the fuel pump relay control high side driver circuit for circuit faults	Voltage low during driver on state (indicates short to ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage  Engine Speed	Voltage ≥ 11 volts  ≥ 0 RPM	8 failures out of 10 samples  250 ms / sample	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Fuel Injector Control Performance	P062B	This DTC Diagnoses the internal fuel injector control module circuit for circuit faults.	Internal ECU Boost Voltage  OR  Internal ECU Boost Voltage  OR  Driver Status  OR  Driver Status	>= 90 Volts           =& Not Ready           = Uninitialized	Battery Voltage	>= 8 or >= 11  Enabled when a code clear is not active or not exiting device control Engine is not cranking Powertrain Relay Voltage within range	High Voltage - 160 failures out of 200 samples  Low Voltage - 160 failures out of 200 samples  Driver Status Not Ready- 160 failures out of 200 samples  Driver Status Uninitialized - Uninitialized state for >= 100 counts  All at 12.5ms per sample	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Control Module EEPROM Error	P062F	Indicates that the NVM Error flag has not been cleared	The next write to NVM will not succeed or the assembly calibration integrity check failed.		Ignition State	= unlock/accessory, run, or crank	1 test failure  Diagnostic runs once at powerup	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
VIN Not Programmed or Mismatched - Engine Control Module (ECM)	P0630	This DTC checks that the VIN is correctly written	At least one of the programmed VIN digits	= 00 or FF	OBD Manufacturer Enable Counter	= 0	250 ms / test Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
5 Volt Reference #1 Circuit	P0641	Detects a continuous or intermittent short on the 5 volt reference circuit #1	ECM Vref1 < or ECM Vref1 > or the difference between ECM filtered Vref1 and Vref1 >	4.875 5.125  0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Open	P0650	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Run/Crank Voltage  Remote Vehicle Start is not active	Voltage ≥ 11 volts	50 failures out of 63 samples  50 ms / sample	Type B, No MIL  NO MIL  Note: In certain controllers P263A may also set (MIL Control Short to Ground)

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
5 Volt Reference #2 Circuit	P0651	Detects a continuous or intermittent short on the 5 volt reference circuit #2	ECM Vref2 < or ECM Vref2 > or the difference between ECM filtered Vref2 and Vref2 >	4.875 5.125  0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Open	P0685	Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω ohms impedance between signal and controller ground	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controllers P0686 may also set (Powertrain Relay Control Short to Ground).

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Powertrain Relay Control (ODM) Low	P0686	Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controlle rs P0685 may also set (Powertr ain Relay Control Open Circuit).

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Powertrain Relay Control (ODM) High	P0687	Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples  250 ms / sample	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Powertrain Relay Feedback Circuit High	P0690	This DTC is a check to determine if the Powertrain relay is functioning properly.	Powertrain Relay Voltage	>= 4.00 volts will increment the fail counter	Powertrain relay commanded "OFF"  No active DTCs:	>= 2.00 seconds  PowertrainRelayStateOn_ FA	50 failures out of 63 samples  100ms / Sample	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cooling Fan 1 Relay Control Circuit Low Voltage (ODM)	P0691	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples  100 ms / sample	Type B, 2 Trips  Note: In certain controlle rs P0480 may also set (Fan 1 Open Circuit).

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cooling Fan 1 Relay Control Circuit High Voltage (ODM)	P0692	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples  100 ms / sample	Type B, 2 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
5 Volt Reference #3 Circuit	P0697	Detects a continuous or intermittent short on the 5 volt reference circuit #3	ECM Vref3 < or ECM Vref3 > or the difference between ECM filtered Vref3 and Vref3 >	4.875 5.125  0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
5 Volt Reference #4 Circuit	P06A3	Detects a continuous or intermittent short on the 5 volt reference circuit #4	ECM Vref4 < or ECM Vref4 > or the difference between ECM filtered Vref4 and Vref4 >	4.875 5.125  0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 1 Performance	P06B6	This diagnostic checks for a fault with the internal test circuit used only for the '20 kHz' method of the Open Circuit Diagnostic	FFT Diagnostic Output	> P06B6_P06B7_OpenT estCktThrshMin  <b>AND</b>  < P06B6_P06B7_OpenT estCktThrshMax  <b>See Supporting                      Tables</b>	Diagnostic Enabled?  Engine Run Time  Engine Speed  Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)  Engine Air Flow	Yes  ≥ 2.0 seconds  > 400 RPM and < 4,000 RPM  ≥ 500 Revs  ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient  Weight Coefficient =  0.0100  Updated each engine event	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 2 Performance	P06B7	This diagnostic checks for a fault with the internal test circuit used only for the '20 kHz' method of the Open Circuit Diagnostic	FFT Diagnostic Output	> P06B6_P06B7_OpenT estCktThrshMin  <b>AND</b>  < P06B6_P06B7_OpenT estCktThrshMax  <b>See Supporting                      Tables</b>	Diagnostic Enabled?  Engine Run Time  Engine Speed  Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)  Engine Air Flow	Yes  ≥ 2.0 seconds  > 400 RPM and < 4,000 RPM  ≥ 500 Revs  ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient  Weight Coefficient =  0.0100  Updated each engine event	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Two Stage Oil Pump Control Circuit Open	P06DA	Diagnoses the two stage oil pump low side driver for open circuit fault	Voltage low during driver off state (indicates an open circuit)	Open Circuit ≥ 200 k Ω impedance between signal and controller ground	Diagnostic Status  Powertrain Relay Voltage  Run/Crank Active  Cranking State	Enabled  ≥ 11.00  = True  = False	≥ 40 errors out of 50 samples.  Performed every 100 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Two Stage Oil Pump Control Circuit Short To Ground	P06DB	Diagnoses the two stage oil pump low side driver for Short to Ground circuit fault	Voltage low during driver off state (indicates an short circuit to Ground)	Short to Ground Circuit ≤ 0.5 Ω impedance between signal and controller ground	Diagnostic Status  Powertrain Relay Voltage  Run/Crank Active  Cranking State	Enabled  ≥ 11.00  = True  = False	≥ 40 errors  out of 50 samples.   Performed every 100 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Two Stage Oil Pump Control Circuit Short To Power	P06DC	Diagnoses the two stage oil pump low side driver for Short to Power circuit fault	Voltage low during driver on state (indicates an short to power)	Short to Power ≤ 0.5 Ω impedance between signal and controller power	Diagnostic Status  Powertrain Relay Voltage  Run/Crank Active  Cranking State	Enabled  ≥ 11.00  = True  = False	≥ 40 errors  out of 50 samples.   Performed every 100 msec	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Two Stage Oil Pump Control Circuit Performance - One Sided	P06DD	Diagnoses the two stage oil pump is stuck in the high pressure state	<p><u>Fail from passing state:</u></p> <p>Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is above a threshold</p>	<p>Oil Pressure delta = ABS [ Filtered Oil Pressure at beginning of state change - filtered oil pressure after 1.7 seconds]</p> <p>Oil Pressure delta ≤ <b>OP_StateChangeMin</b> (see P06DD details on Supporting Tables Tab)</p> <p>AND</p> <p>Filtered Oil Pressure ≥ <b>MinOilPresThresh</b> (see P06DD details on Supporting Tables Tab)</p>	<p><u>Common Criteria:</u></p> <p>Two Stage Oil Pump is Present</p> <p>Engine Running</p> <p>Ambient Air Pressure</p> <p>Oil Aeration (= TRUE if engine speed &gt; 8,000 RPM for longer than 65,000.0 seconds)</p> <p>No active DTC's for diagnosis enable:</p> <p>No active DTC's for control enable:</p> <p><u>Active Criteria:</u> One Sided Performance Test = Enabled</p> <p>Oil Pump in Low State</p> <p>Modelled Oil Temperature</p>	<p>TRUE</p> <p>≥ 30.0 seconds</p> <p>≥ 70.0 kPa</p> <p>FALSE</p> <p>Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensorFA EngOilPressureSensorCkt FA AmbientAirDefault EngOilTempFA OilPmpTFTKO</p> <p>Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccurate EngOilPressureSensorFA PowertrainRelayFault CrankSensorFaultActive</p> <p>Enabled</p> <p>&gt; 1.7 seconds</p> <p>40.0 deg C ≤ Oil Temp ≤</p>	<p>≥ 12 errors out of 15 samples.</p> <p>Run once per trip or activated by the Passive Test</p>	Type B, 2 Trips



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					within range  Filtered Engine Speed within range  Engine Torque within range  Delta Filtered Engine Speed within a range  Filtered Oil Pressure within range  <u>Passive Criteria:</u>  Active Test Passed  Filtered Engine Speed within range  Modelled Oil Temperature within range  Delta Filtered Engine Speed within a range	110.0 deg C  1,200 RPM ≤ Filtered Engine Speed ≤ 2,500 RPM  <b>MinEnableTorque_OP</b> ≤ Indicated Requested Engine Torque ≤ <b>MaxEnableTorque_OP</b> (see P06DD details on Supporting Tables Tab)  ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.70 seconds ] ≤ 250 RPM  Filtered Engine Oil Pressure ≥ <b>MinOilPressThresh</b> (see P06DD details on Supporting Tables Tab)  TRUE  1,000 RPM ≤ Filtered Engine Speed ≤ 4,500 RPM  40.0 deg C ≤ Oil Temp ≤ 120.0 deg C  ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.70 seconds ]		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Oil Pressure Delta < <b>OP_StateChangeMin</b> (see P06DD details on Supporting Tables Tab)	≤ 1,000 RPM  TRUE		
			<u>Fast Pass Condition</u>  Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is above a threshold	Oil Pressure delta =  ABS [ Filtered Oil Pressure at beginning of state change - filtered oil pressure after 1.7 seconds]  Oil Pressure delta ≤ <b>OP_StateChangeMin</b> (see P06DD details on Supporting Tables Tab)  AND  Filtered Oil Pressure ≥ <b>MinOilPressThresh</b> (see P06DD details on Supporting Tables Tab)	<u>Common Criteria:</u>  Two Stage Oil Pump is Present  Engine Running  Ambient Air Pressure  Oil Aeration (= TRUE if engine speed > 8,000 RPM for longer than 65,000.0 seconds)  No active DTC's for diagnosis enable:        No active DTC's for control enable:	TRUE  ≥ 30.0 seconds  ≥ 70.0 kPa  FALSE  Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensorFA EngOilPressureSensorCktFA AmbientAirDefault EngOilTempFA OilPmpTFTKO  Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccurate EngOilPressureSensorFA	0 errors out of 5 samples.  Run once per trip or activated by the Passive Test	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p><u>Active Criteria:</u> One Sided Performance Test = Enabled</p> <p>Oil Pump in Low State</p> <p>Modelled Oil Temperature within range</p> <p>Filtered Engine Speed within range</p> <p>Engine Torque within range</p> <p>Delta Filtered Engine Speed within a range</p> <p>Filtered Oil Pressure within range</p>	<p>PowertrainRelayFault CrankSensorFaultActive</p> <p>Enabled</p> <p>&gt; 1.7 seconds</p> <p>40.0 deg C ≤ Oil Temp ≤ 110.0 deg C</p> <p>1,200 RPM ≤ Filtered Engine Speed ≤ 2,500 RPM</p> <p><b>MinEnableTorque_OP</b> ≤ Indicated Requested Engine Torque ≤ <b>MaxEnableTorque_OP</b> (see P06DD details on Supporting Tables Tab)</p> <p>ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.70 seconds ] ≤ 250 RPM</p> <p>Filtered Engine Oil Pressure ≥ <b>MinOilPressThresh</b> (see P06DD details on Supporting Tables Tab)</p>		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Transmission Control Module (TCM) Requested MIL Illumination	P0700	Monitors the TCM MIL request line to determine when the TCM has detected a MIL illuminating fault.	Transmission Emissions-Related DTC set			Time since power-up ≥ 3 seconds	Continuous	Type A, No MIL

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Traction Control Torque Request Circuit	P0856	Determines if torque request from the EBTCM is valid	Serial Communication 2's complement message - (\$1C7/\$1C9 for engine torque, \$1CA/\$1C6 for axle torque)  OR Serial Communication message (\$1C7/\$1C9 for engine torque, \$1CA/\$1C6 for axle torque) rolling count index value  OR Too many minimum limit torque request transitions occur from TRUE to FALSE to TRUE within a time period  Torque request greater than torque request diagnostic maximum threshold	Message <> 2's complement of message  Message rolling count value <> previous message rolling count value plus one  Requested torque intervention type toggles from not increasing request to increasing request  > 250 Nm for engine torque based traction torque system, OR > 4,000 Nm for axle torque based traction torque system	Serial communication to EBTCM (U0108)  Power Mode Engine Running  Status of traction in GMLAN message (\$4E9)	No loss of communication  = Run = True  = Traction Present	>= 6 failures out of 10  Performed on every received message  6 rolling count failures out of 10 samples  Performed on every received message  >= 3 multi-transitions out of 5 samples.  Performed every 200 ms  >= 4 out of 10 samples  Performed on every received message	Type C, No MIL Safety Special Type C

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (naturally aspirated)	P1101	Determines if there are multiple air induction problems affecting airflow and/or manifold pressure.	Filtered Throttle Model Error  AND  ( ABS(Measured Flow – Modeled Air Flow) Filtered OR ABS(Measured MAP – MAP Model 1) Filtered  AND  ABS(Measured MAP – MAP Model 2) Filtered	<= 250 kPa*(g/s)   > 25.0 grams/sec  > 22.0 kPa )   > 22.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 450 RPM <= 5,600 RPM > -7 Deg C < 129 Deg C > -20 Deg C < 129 Deg C  >= 0.50  Filtered Throttle Model Error multiplied by <b>TPS Residual Weight Factor based on RPM</b>  Modeled Air Flow Error multiplied by <b>MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor Based on MAF Est</b>  MAP Model 1 Error multiplied by <b>MAP1 Residual Weight Factor based on RPM</b>  MAP Model 2 Error multiplied by <b>MAP2 Residual Weight Factor based on RPM</b>  See Residual Weight Factor tables.  MAP_SensorCircuitFA EGRValvePerformance_FA A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA	Continuous  Calculation are performed every 12.5 msec	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Pending DTCs:	IAT_SensorFA EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 1 low side circuit shorted to high side circuit	P1248	This DTC Diagnoses Injector 1 enable low side driver shorted to high side driver circuit faults.	Voltage high across low side and High side drivers during on state indicates low side shorted to high side	Low side shorted to High Side: 25 amp $\geq$ through low side driver	Battery Voltage Engine Run Time	$\geq$ 11 Volts $\geq$ 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 2 low side circuit shorted to high side circuit	P1249	This DTC Diagnoses Injector 2 enable low side driver shorted to high side driver circuit faults.	Voltage high across low side and High side drivers during on state indicates low side shorted to high side	Low side shorted to High Side: 25 amp $\geq$ through low side driver	Battery Voltage Engine Run Time	$\geq 11$ Volts $\geq 0$ Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 3 low side circuit shorted to high side circuit	P124A	This DTC Diagnoses Injector 3 enable low side driver shorted to high side driver circuit faults.	Voltage high across low side and High side drivers during on state indicates low side shorted to high side	Low side shorted to High Side: 25 amp $\geq$ through low side driver	Battery Voltage Engine Run Time	$\geq 11$ Volts $\geq 0$ Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 4 low side circuit shorted to high side circuit	P124B	This DTC Diagnoses Injector 4 enable low side driver shorted to high side driver circuit faults.	Voltage high across low side and High side drivers during on state indicates low side shorted to high side	Low side shorted to High Side: 25 amp $\geq$ through low side driver	Battery Voltage Engine Run Time	$\geq 11$ Volts $\geq 0$ Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 5 low side circuit shorted to high side circuit	P124C	This DTC Diagnoses Injector 5 enable low side driver shorted to high side driver circuit faults.	Voltage high across low side and High side drivers during on state indicates low side shorted to high side	Low side shorted to High Side: 25 amp $\geq$ through low side driver	Battery Voltage Engine Run Time	$\geq 11$ Volts $\geq 0$ Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 6 low side circuit shorted to high side circuit	P124D	This DTC Diagnoses Injector 6 enable low side driver shorted to high side driver circuit faults.	Voltage high across low side and High side drivers during on state indicates low side shorted to high side	Low side shorted to High Side: 25 amp $\geq$ through low side driver	Battery Voltage Engine Run Time	$\geq 11$ Volts $\geq 0$ Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 7 low side circuit shorted to high side circuit	P124E	This DTC Diagnoses Injector 7 enable low side driver shorted to high side driver circuit faults.	Voltage high across low side and High side drivers during on state indicates low side shorted to high side	Low side shorted to High Side: 25 amp $\geq$ through low side driver	Battery Voltage Engine Run Time	$\geq 11$ Volts $\geq 0$ Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 8 low side circuit shorted to high side circuit	P124F	This DTC Diagnoses Injector 8 enable low side driver shorted to high side driver circuit faults.	Voltage high across low side and High side drivers during on state indicates low side shorted to high side	Low side shorted to High Side: 25 amp $\geq$ through low side driver	Battery Voltage Engine Run Time	$\geq 11$ Volts $\geq 0$ Seconds  P062B not FA or TFTK	10 failures out of 20 samples 100 ms /sample Continuous	Type A, 1 Trips



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Over Temperature	P1255	To detect if an internal fuel pump driver over- temperature condition exists under normal operating conditions	Fuel Pump Driver Circuit Board temperature ( FP Driver Overtemperature enumeration)	T >= 160 degC ( Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate)	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType  b) Diagnostic KeFRPR_b_FPPM_ OvertempDiagEnbld  c] FPPM Driver Status Alive Rolling Count Sample Faulted  d] Diagnostic feedback received  e] System Voltage	a) == CeFRPR_e_ECM _FPPM_Sys  b) == TRUE  c] <> TRUE  d] == TRUE  e] 9V < System V < 32V	3 failures / 15 samples  1 sample / 12.5 millisec	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
High Pressure Sensor 2 Out of Range Low - Dual Sensor	P127C	This DTC Diagnoses High Pressure Sensor Out of Range Low	High Pressure Fuel Sensor 2	SIDI High Pressure Sensor 2 Out of range Enabled  <= 5 % of 5Vref	Battery Voltage	>= 11 Volts  Engine Running	Time Based Mode 400 failures out of 500 samples 6.25 ms Sample Continuous	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Sensor 2 Out of Range High - Dual Sensor	P127D	This DTC Diagnoses High Pressure Sensor Out of Range High	High Pressure Fuel Sensor 2	SIDI High Pressure Sensor 2 Out of range Enabled  >= 95 % of 5Vref	Battery Voltage	>= 11 Volts  Engine Running	Time Based Mode 400 failures out of 500 samples 6.25 ms Sample Continuous	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Module- Ignition Switch Run/ Start Position Circuit Low	P129D	To detect if the Run/ Start position circuit voltage is short to low / open	FPPM Run_Crank Active status	<> ECM Run_Crank Active status	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType b) Diagnostic KeFRPR_b_FPPM_RunC rnkRatlEnbld c) FPPM Control Status Alive Rolling Count result d) Diagnostic feedback received e) System Voltage	a) == CeFRPR_e_ECM_FPPM _Sys b) == TRUE c) == Valid d) == TRUE e) >= 0.0 v	64 failures / 80 samples  1 sample / 12.5 millisec	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Signal Message Counter Incorrect	P129E	To detect if the command message received as serial data from the engine control module is valid	FPPM Received Duty Cycle Rolling Count	<> Transmitted Duty Cycle Rolling Count ( ECM) ( Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate test state)	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType b) Fault state determination enabled c) FPPM Received Duty Cycle Count result d) FPPM Diagnostic feedback received e) CAN communication f) System Voltage	a) == CeFRPR_e_ECM_FPPM _Sys b) == TRUE c) == Valid d) == TRUE e) == Valid f) 9v < Sys Voltage > 32v	64 failures / 80 samples  1 sample / 12.5 millisec	Type A, 1 Trips
			FPPM Received Duty Cycle Protection Value	<> Transmitted Duty Cycle Protection Value ( ECM) ( Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate test state)	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType b) Fault state determination enabled c) FPPM Received Duty Cycle Protection Value result d) FPPM Diagnostic feedback received e) CAN communication f) System Voltage	a) == CeFRPR_e_ECM_FPPM _Sys b) == TRUE c) == Valid d) == TRUE e) == Valid f) 9v < Sys Voltage > 32v	64 failures / 80 samples  1 sample / 12.5 millisec	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Pump Driver Control Module Enable Circuit Performance	P12A6	To detect a driver control circuit signal stuck in normal operating range	FPPM Fuel Control Enable Active boolean	<> Fuel Control Enable variable (ECM)	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType b) Diagnostic KeFRPR_b_FPPM_FuelC ntrlEnblEnbld c) FPPM Control Data Rolling Count result d) Diagnostic feedback received e) System Voltage	a) == CeFRPR_e_ECM_FPPM _Sys b) == TRUE c) == Valid d) == TRUE e) >= 9.0 v	40 failures / 80 samples  1 sample / 12.5 millisec	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Control Status Signal Message Counter Incorrect	P12A8	To detect if the control status message transmitted as serial data from the driver control module is valid	FPPM Control Status Alive Rolling Count	<> ECM Control Status Alive Rolling Count ( Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate test state)	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType b) Fault state determination enabled c) FPPM Diagnostic feedback received	a) == CeFRPR_e_ECM_FPPM_Sys b) == TRUE c) == TRUE	64 failures / 80 samples  1 sample / 12.5 millisec	Type A, 1 Trips
			FPPM Power Consumption Alive Rolling Count	<> ECM Power Consumption Alive Rolling Count ( Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate test state)	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType b) Fault state determination enabled c) FPPM Diagnostic feedback received	a) == CeFRPR_e_ECM_FPPM_Sys b) == TRUE c) == TRUE	64 failures / 80 samples  1 sample / 12.5 millisec	
			FPPM Driver Status Alive Rolling Count	<> ECM Driver Status Alive Rolling Count ( Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate test state)	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType b) Fault state determination enabled c) FPPM Diagnostic feedback received	a) == CeFRPR_e_ECM_FPPM_Sys b) == TRUE c) == TRUE	64 failures / 80 samples  1 sample / 12.5 millisec	
			FPPM Hardware Status Alive Rolling Count	<> ECM Hardware Status Alive Rolling Count ( Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate test state)	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType b) Fault state determination enabled c) FPPM Diagnostic feedback received	a) == CeFRPR_e_ECM_FPPM_Sys b) == TRUE c) == TRUE	64 failures / 80 samples  1 sample / 12.5 millisec	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Coil Positive Voltage Circuit Group 1 * * SIDI ONLY * *	P135A	This diagnostic checks for voltage supply to the Ignition Coils (applicable only for SIDI applications)	Common Enable Criteria  Ignition Module Supply Voltage.  Three possible power supply sources for Ignition Coils (only 1 is used):  Case 1: Battery Case 2: Ignition Run/ Crank Case 3: PT Relay  Case Specific Enable Criteria	< 2.5 Volts  Ignition Coil Power Source =  (see corresponding case specific enable criteria below)  Case 1: Battery  Case 2: Ignition Run/ Crank  Case 3: PT Relay	Diagnostic Enabled?  PT Relay  Delay starting at Key-On  Ignition Run/Crank Voltage  PT Relay Voltage	Yes   5 Engine Revs  > 11.0 volts  > 11.0 volts	50 Failures out of 63 Samples  6.25 msec rate	Type A, 1 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Coil Positive Voltage Circuit Group 2 * * SIDI ONLY * *	P135B	This diagnostic checks for voltage supply to the Ignition Coils (applicable only for SIDI applications)	Common Enable Criteria		Diagnostic Enabled?	Yes	50 Failures out of 63 Samples  6.25 msec rate	Type: Type A, 1 Trips
			Ignition Module Supply Voltage.	< 2.5 Volts				
			Three possible power supply sources for Ignition Coils (only 1 is used):  Case 1: Battery Case 2: Ignition Run/ Crank Case 3: PT Relay	Ignition Coil Power Source =  (see corresponding case specific enable criteria below)	PT Relay			
			Additional Case Specific Enable Criteria	Case 1: Battery	Delay starting at Key-On	5 Engine Revs		
			Case 2: Ignition Run/ Crank	Ignition Run/Crank Voltage	> 11.0 volts			
			Case 3: PT Relay	PT Relay Voltage	> 11.0 volts			

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Emissions Reduction System Fault	P1400	Model based test computes power from exhaust flow and thermal energy resulting from elevated idle speed and retarded spark advance. Detects if the cold start emission reduction system has failed resulting in the delivered power being out of range.	<p>Average desired accumulated exhaust power - Average actual accumulated exhaust power (too much energy delivered to catalyst)</p> <p>Average desired accumulated exhaust power - Average actual accumulated exhaust power (too little energy delivered to catalyst)</p> <p>(EWMA filtered)</p> <p>Average Power = output of <b>P1400_EngineSpeedResidual_Table</b> * output of <b>P1400_SparkResidual_Table</b></p> <p>NOTE: Desired accumulated power would use the desired catalyst light off spark and desired engine speed and the actual accumulated power would use the final commanded spark and actual engine speed. Refer to the Supporting Tables for details</p>	<p>&lt; -32.00 KJ/s (high RPM failure mode)</p> <p>&gt; 3.75 KJ/s (low RPM failure mode)</p>	<p>To enable the diagnostic, the Cold Start Emission Reduction Strategy must be Active per the following:</p> <p>Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure</p> <p>The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following:</p> <p>Catalyst Temperature AND Engine Run Time</p> <p>OR</p> <p>Engine Run Time</p> <p>OR</p> <p>Barometric Pressure</p>	<p>&lt; 300.00 degC</p> <p>&gt; 17.00 degC</p> <p>&lt;= 43.00 degC</p> <p>&gt;= 75.00 KPa</p> <p>&gt;= 800.00 degC</p> <p>&gt;= 1.00 seconds</p> <p>&gt; <b>CatalystLightOffExtendedEngineRunTimeExit</b></p> <p>This Extended Engine run time exit is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details.</p> <p>&lt; 75.00 KPa</p>	<p>Runs once per trip when the cold start emission reduction strategy is active</p> <p>Frequency: 100ms Loop</p> <p>Test completes after 10 seconds of accumulated qualified data.</p>	EWMA Based - Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Other Enable Criteria:</p> <p>OBD Manufacturer Enable Counter</p> <p>Vehicle Speed</p> <p>Allow diagnostic to calculate residual in an off-idle state. If the value of the OffIdleEnable is equal to 1 then the "DriverOffAccelPedal" will not be checked. However, if the value of OffIdleEnable is 0 then driver must be off the accel pedal</p> <p>A change in throttle position (tip-in/tip-out) will initiate a delay in the calculation of the average qualified residual value. Therefore when the:</p> <p>Pedal Close Delay Timer</p> <p>the diagnostic will continue the calculation.</p> <p>A change in gear will initiate a delay in the calculation of the average qualified residual value to allow time for the actual</p>	<p>0</p> <p>&lt; 1.86 MPH</p> <p>0</p> <p>(A value of 1 allows diagnostic to run and calculate the residual while off idle. A value of 0 requires calculation of the residual at idle)</p> <p>&gt; 2.00 seconds</p>		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>engine speed and actual final commanded spark to achieve their desired values. Therefore, when the:</p> <p>Gear Shift Delay Timer</p> <p>the diagnostic will continue the calculation</p> <p>For Manual Transmission vehicles:</p> <p>Clutch Pedal Position</p> <p>Clutch Pedal Position</p> <p>The diagnostic will delay calculation of the residual value and potentially weight the residual calculation differently based on engine run time. This is to ensure the diagnostic is operating in idle speed control as well as during the peak catalyst light off period.</p> <p>The time weighting factor must be :</p>	<p>&gt; 1.50 seconds</p> <p>&gt; 12.00 %</p> <p>&lt; 75.00 %</p> <p>&gt; 0 These are scalar values that are a function of engine run time. Refer to <b>ColdStartDiagnosticDelayBasedOnEngineRunTime</b></p>		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					General Enable:  DTC's Not Set:	and the cal axis, <b>ColdStartDiagnosticDelayBasedOnEngineRunTimeCalAxis</b> in the "Supporting Tables" for details.  AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFP CrankSensorFaultActive FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA EngineMisfireDetected_FA Clutch Sensor FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA 5VoltReferenceMAP_OOR_Flt TransmissionEngagedState_FA EngineTorqueEstInaccurate		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Engine Speed Request Circuit	P150C	Determines if engine speed request from the TCM is valid	Serial Communication rolling count value  Transmission engine speed protection	+ 1 from previous \$19D message (PTEI3)  not equal to 2's complement of transmission engine speed request + Transmission alive rolling count	Diagnostic enable bit  Engine run time  # of Protect Errors  # of Alive Rolling Errors  No idle diagnostic 506/507 code  No Serial communication loss to TCM  Engine Running  Power mode	1  0.50 sec  12 protect errors within the sample period 20  6 rolling count errors out of 10 samples  IAC_SystemRPM_FA  (U0101)  = TRUE  Run Crank Active	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Steady State Actuation Fault	P1516	Detect an inability to maintain a steady state throttle position	The absolute difference between desired and indicated throttle position is >	2.00 percent		Run/Crank voltage > 6.41  Ignition voltage failure is false (P1682)  TPS minimum learn is not active and Throttle is being Controlled Throttle is considered in a steadystate condition when the desired throttle position over a 12.5 ms period is < 0.25 percent for a settling time period > 4.00 s	0.49 ms	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Adaptive Cruise Control Signal Circuit	P1553	Detects rolling count or protection value errors in Adaptive Cruise Control Axle Torque Command serial data signal	If x of y rolling count / protection value faults occur, disable adaptive cruise control for duration of fault		Adaptive Cruise Control Command Serial Data Error Diagnostic Enable	1.00	10 / 16 counts	MIL: Type C, No MIL



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cruise Control Switch State Undertermin ed	P155A	Detects when cruise switch state cannot be determined, such as low voltage conditions	cruise switch state remains undetermined for greater than a calibratable time				fail continuously for greater than 0.5 seconds	MIL: Type C, No MIL

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Front Object Detection Control Module Torque Request Signal Message Counter Incorrect	P15F6	Detects rolling count or protection value errors in Collision Preparation System Axle Torque Command serial data signal	If x of y rolling count / protection value faults occur, disable collision preparation system for duration of fault		Front Object Detection Module Torque Request Serial Data Error Diagnostic Enable	1.00	4 / 10 counts	MIL: Type C, No MIL

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Automatic Braking Engine Torque Request Signal Message Incorrect	P15F8	Detects rolling count or protection value errors Rear Virtual Bumper Axle Torque Command serial data signal	If x of y rolling count / protection value faults occur, disable rear virtual bumper or collision preparation system for duration of fault		Automatic Braking Engine Torque Request Serial Data Error Diagnostic Enable	1.00	4 / 10 counts	MIL: Type C, No MIL

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module SIDI High Pressure Pump current monitor	P163A	This DTC Diagnoses the current from the control area and compares it with calibrated thresholds to set current high and low flags	SIDI fuel pump High Current Test  Current  SIDI fuel pump Low Current Test  Current	    >= 14.00 Amps       <= 0.10 Amps	Battery Voltage  Low Side Fuel Pressure  Engine Run Time    Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement	>= 11 Volts  > 0.275 MPa  >= KtFHPD_t_PumpCntrlEngRunThrsh (see supporting tables) Enabled when a code clear is not active or not exiting device control Engine is not cranking	Current High -  750 failures out of 938 samples  Current Low -  750 failures out of 938 Samples	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active and Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -10.0 degC -10 <= Temp degC <= 100		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation	P1682	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage & the Powertrain Relay Ignition Voltage	Run/Crank – PT Relay Ignition  >	3.00 Volts		Powertrain commanded on  AND  (Run/Crank voltage > Table, f(IAT). See supporting tables: <b>PT Relay Pull-in Run/Crank Voltage f(IAT)</b>  OR PT Relay Ignition voltage > 5.50 )  AND  Run/Crank voltage > 5.50 .	240 / 480 counts or 0.1750 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
TPS SENT Comm Circuit Low	P16A0	Detects a Low Circuit Fault in the TPS SENT Communication Circuit	Voltage for wave pulse is below state threshold as defined by SAE J2716 SENT Protocol	0.5 V		Run/Crank voltage > 6.41	79 / 159 counts;  57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
TPS SENT Comm Circuit High	P16A1	Detects a High Circuit Fault in the TPS SENT Communication Circuit	Voltage for wave pulse is above state threshold as defined by SAE J2716 SENT Protocol	4.1 V		Run/Crank voltage > 6.41	79 / 159 counts;  57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
TPS SENT Comm Circuit Performance	P16A2	Detects a Message Fault in the TPS SENT Communication Circuit	Message Pulse < Message Pulse > or Message Age Limit >=  or Signal CRC fails	0.125977 ms 0.209991 ms  3.125 ms		Run/Crank voltage > 6.41	79 / 159 counts;  57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Internal Control Module Redundant Memory Performance	P16F3	Detect Processor Calculation faults due to RAM corruptions, ALU failures and ROM failures  For all of the following cases: If the individual diagnostic threshold is equal to 2048 ms, this individual case is not applicable. If any of the following cases are X out of Y diagnostics and the fail (x) is greater than the sample (Y), this individual case is also not applicable.	Desired Throttle Area calculated does not equal its redundant calculation	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	Type A, 1 Trips
			Equivalence Ratio torque compensation exceeds threshold	-94.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Absolute difference between Equivalence Ratio torque compensation and its dual store out of bounds given by threshold	94.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of Accessory torque and its redundant calculation is out of bounds given by threshold range	94.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Filtered Air-per-cylinder and its redundant calculation is out of bounds given by threshold range	28.39 mg	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference between the previous Final Advance and the current Final Advance not Adjusted for Equivalence Ratio is out of bounds given by threshold range	4.16 degrees		Engine speed >0rpm	Up/down timer 132 ms continuous, 0.5 down time multiplier	
			Torque Learn offset is out of bounds given by threshold range	High Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold  0.00 Nm			multiplier	
			One step ahead calculation of air-per-cylinder and two step ahead is greater than threshold	80.00 mg		Engine speed > 520 rpm	Up/down timer 459 ms continuous, 0.5 down time multiplier	
			Difference between Unmanaged Spark and PACS Spark is greater than threshold	10.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Engine Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			Zero pedal axle torque is out of bounds given by threshold range	High Threshold 1,599.00 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Creep Coast Axle Torque is out of bounds given by threshold range	High Threshold 1,599.00 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Absolute difference of Friction torque and its redundant calculation is out of bounds given by threshold range	94.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			Arbitrated Air-Per-Cylinder filter coefficient is out of bounds given by threshold range	High Threshold 1.000  Low Threshold 0.074	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Launch spark is active but the launch spark redundant path indicates it should not be active	N/A		Engine speed < 7,900.00 or 8,000.00 rpm (hysteresis pair)	Up/down timer 159 ms continuous, 0.5 down time multiplier	
			Rate limited vehicle speed and its dual store do not equal	N/A		Time since first CAN message with vehicle speed >= 0.500 sec	10 / 20 counts; 25.0msec/count	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Preload Throttle Area and its dual store do not equal	N/A	Ignition State	Accessory, run or crank  AFM apps only	Up/down timer 159 ms continuous, 0.5 down time multiplier	
			Commanded engine torque due to fast actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded engine torque due to slow actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			TOS to wheel speed conversion factor is out of bounds given by threshold	High Threshold: 1.10	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			range	T/C Range Hi  0.10 T/C Range Lo  Low Threshold:  1.10 T/C Range Hi  0.10 T/C Range Lo				
			Cylinders active greater than commanded	2 cylinders		Engine run flag = TRUE > 2.00s Number of cylinder events since engine run > 24  No fuel injector faults active	Up/down timer 159ms continuous, 0.5 down time multiplier	
			Transfer case neutral request from four wheel drive logic does not match	N/A	Ignition State	Accessory, run or crank	32 / 0 counts; 25.0msec/count	



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			with operating conditions			Transfer case range valid and not over-ridden  FWD Apps only		
			Driver progression mode and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Predicted torque for uncorrected zero pedal determination is greater than calculated limit.	Table, f(Engine, Oil Temp). See supporting tables + 94.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Predicted Request Without Motor is greater than its redundant calculation plus threshold	93.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Immediate Request Without Motor is greater than its redundant calculation plus threshold	93.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Positive Torque Offset is greater than its redundant calculation plus threshold  OR  Positive Torque Offset is less than its redundant calculation minus threshold	94.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Predicted Engine Request is greater than its redundant calculation plus threshold	94.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, down time multiplier 0.5	
			Commanded Hybrid Predicted Crankshaft Request is greater than its redundant calculation plus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Hybrid	4.096.00	Ignition State	Accessory, run or crank	Up/down timer	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Immediate Crankshaft Request is less than its redundant calculation minus threshold	Nm			2,048 ms continuous, 0.5 down time multiplier	
			Regeneration Brake Assist is not within a specified range	Brake Regen Assist < 0 Nm or Brake Regen Assist > 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Cylinder Spark Delta Correction exceeds the absolute difference as compared to Unadjusted Cylinder Spark Delta	10.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			1. Cylinder Torque Offset exceeds step size threshold  OR  2. Sum of Cylinder Torque Offset exceeds sum threshold	1. 94.00 Nm  2. 94.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Capacity Minimum Immediate Without Motor is greater than its dual store plus threshold	94.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Capacity Minimum Engine Off is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Capacity Minimum Engine Immediate Without Motor is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Immediate Engine Request is greater than its redundant calculation plus threshold	94.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Speed Loes Intake Firing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 159 ms continuous, 0.5 down time multiplier	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Speed Lores Intake Firing timing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 159 ms continuous, 0.5 down time multiplier	
			Idle speed control calculated predicted minimum torque request exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: <b>Speed Control External Load f(Oil Temp, RPM) + 94.00 Nm</b>	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Idle speed control calculated predicted minimum torque without reserves exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: <b>Speed Control External Load f(Oil Temp, RPM) + 94.00 Nm</b>	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference between Driver Requested Immediate Torque primary path and its secondary exceeds threshold	1,599.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Driver Immediate Request is less than its redundant calculation minus threshold	1,599.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded Immediate Request is greater than its redundant calculation plus threshold  OR  Commanded Immediate	1,599.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Request is less than its redundant calculation minus threshold					
			Commanded Immediate Response Type is set to Inactive	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Difference between Cruise Axle Torque Arbitrated Request and Cruise Axle Torque Request exceeds threshold	199.88 Nm		Cruise has been engaged for more than 4.00 seconds	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Desired engine torque request greater than	93.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			redundant calculation plus threshold				ms continuous, 0.5 down time multiplier	
			Engine min capacity above threshold	94.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 74 ms continuous, 0.5 down time multiplier	
			No fast unmanaged retarded spark above the applied spark plus the threshold	Table, f(RPM,APC). See supporting tables: <b>Delta Spark Threshold f (RPM,APC)</b>		Engine speed greater than 0rpm	Up/down timer 132 ms continuous, 0.5 down time multiplier	
			Absolute difference of adjustment factor based on temperature and its dual store above threshold	2.76 m/s	Ignition State	Accessory, run or crank	Up/down timer 103 ms continuous, 0.5 down time multiplier	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			1. Absolute difference of redundant calculated engine speed above threshold	200 RPM		Engine speed greater than 0 RPM	Up/down timer 159 ms continuous, 0.5 down time multiplier	
			After throttle blade pressure and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Speed Control's Predicted Torque Request and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine oil temperature and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 247 ms continuous,	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							0.5 down time multiplier	
			Desired throttle position greater than redundant calculation plus threshold	6.04 percent	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the rate limited pre-throttle pressure and its redundant calculation greater than threshold	0.06 kpa	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Throttle desired torque above desired torque plus threshold	94.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired filtered throttle torque exceeds the threshold plus the higher of desired throttle torque or modeled throttle torque	94.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Torque feedback proportional term is out of allowable range or its dual store copy does not match	High Threshold 47.00 Nm  Low Threshold -47.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Torque feedback integral term magnitude or rate of change is out of allowable range or its dual store copy do not match	High Threshold 88.13 Nm  Low Threshold	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				-94.00 Nm  Rate of change threshold  5.88 Nm/loop				
			Difference of Final Torque feedback proportional plus integral term and its redundant calculation is out of bounds given by threshold range	High Threshold  94.00 Nm  Low Threshold  - 94.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of torque desired throttle area and its redundant calculation is out of bounds given by threshold range	High Threshold  0.50 %	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold -0.50 %			multiplier	
			Difference of torque model coefficients and its redundant calculation is out of bounds given by threshold range	High Threshold 0.0001115 Low Threshold - 0.0001115	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Difference of base friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 94.00 Nm  Low Threshold - 94.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Accessory drive friction torque is out of bounds given by threshold range	High Threshold 94.00 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			AC friction torque is greater than commanded by AC control software or less than threshold limit	High Threshold 40.00 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of Oil temperature delta friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 94.00 Nm  Low Threshold	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				- 94.00 Nm				
			Generator friction torque is out of bounds given by threshold range	High Threshold 94.00 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Supercharger friction torque is out of bounds given by threshold range	High Threshold 94.00 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Filtered Torque error magnitude or its increase rate of change is out of allowable range or its dual store copy do not match	High Threshold 94.00 Nm  Low Threshold -94.00 Nm  Rate of change threshold 5.88 Nm/loop		Engine speed >0rpm MAF, MAP and Baro DTCs are false	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Torque error compensation is out of bounds given by threshold range	High Threshold 94.00 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Delta Torque Baro compensation is out of bounds given by threshold range	High Threshold 12.52 Nm  Low Threshold -8.96 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			1. Difference of reserve torque value and its redundant calculation exceed threshold  OR 2. Reserve request does not agree with operating conditions or Difference of final predicted torque and its redundant calculation exceed threshold  OR 3. Rate of change of reserve torque exceeds threshold, increasing direction only	1. 93.00 Nm  2. N/A  3. 93.00 Nm  4. 93.00 Nm	3. & 4.: Ignition State	1. & 2.: Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 94.00 Nm  3. & 4.: Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR  4. Reserve engine torque above allowable capacity threshold					
			Engine Vacuum and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the calculated Intake Manifold Pressure during engine event versus during time event is greater than threshold	Table, f(Desired Engine Torque). See supporting tables: <b>Delta MAP Threshold f(Desired Engine Torque)</b>		Engine speed >0rpm	Up/down timer 159 ms continuous, 0.5 down time multiplier	
			Min. Axle Torque Capacity is greater than threshold	0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Driver Predicted Request	1,599.00	Ignition State	Accessory, run or crank	Up/down timer	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			is greater than its redundant calculation plus threshold  OR  Driver Predicted Request is less than its redundant calculation minus threshold	Nm			475 ms continuous, 0.5 down time multiplier	
			Cold Delta Friction Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Predicted torque for zero pedal determination is greater than calculated limit.	Table, f(Oil Temp, RPM). See supporting tables: <b>Speed Control External Load f(Oil Temp, RPM) + 94.00 Nm</b>	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Predicted Axle Torque and its dual store do not match	1 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Steady State Estimated Engine Torque and its dual store are not equal	N/A		AFM not changing from Active to Inactive and preload torque not changing and one loop after React command  Engine speed >0rpm	Up/down timer 1,988 ms continuous, 0.5 down time multiplier	
			Difference of Weighting factor for number of cylinders fueled and its redundant calculation is above threshold	0.26		Engine run flag = TRUE > 10.00 s	Up/down timer 175 ms continuous, 0.5 down time multiplier	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference of minimum spark advance limit and its redundant calculation is out of bounds given by threshold range	4.16 degrees	Ignition State	Accessory, run or crank	Up/down timer 159 ms continuous, 0.5 down time multiplier	
			Difference of commanded spark advance and adjusted delivered is out of bounds given by threshold range	4.16 degrees		Engine speed >0rpm	Up/down timer 132 ms continuous, 0.5 down time multiplier	
			Absolute difference between Estimated Engine Torque and its dual store are above a threshold	94.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Absolute difference between Estimated Engine Torque without reductions due to torque	94.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5	



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control and its dual store are above a threshold				down time multiplier	
			Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by threshold range	4.16 degrees		Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 94.00 Nm	Up/down timer 459 ms continuous, 0.5 down time multiplier	
			Absolute difference of Engine Capacity Minimum Running Immediate Brake Torque Excluding Cylinder Sensitivity and its redundant calculation is out of bounds given by threshold range	94.00 Nm		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			One step ahead calculation of air-per-cylinder greater than two	Threshold: Dynamically calculated based on current		Engine speed > 520 rpm	Up/down timer 459 ms continuous,	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			step ahead calculation by threshold for time	engine conditions Fault Pending Threshold:  100 ms			0.5 down time multiplier	
			Rate limited cruise axle torque request and its dual store do not match within a threshold	199.88 Nm	Ignition State	Accessory, run or crank	Up/down timer 163 ms continuous, 0.5 down time multiplier	
			1. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its redundant calculation is out of bounds given by threshold range  OR  2. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions	1. 5.00 % 2. N/A 3. N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			and its dual store do not equal  OR  3. Absolute difference of Calculated accelerator pedal position and its dual store do not equal					
			Commanded axle torque is greater than its redundant calculation by threshold	1,599.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded axle torque is less than its redundant calculation by threshold	2,398.50 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Preload timer and its redundant calculation do	N/A	Ignition State	Accessory, run or crank	Up/down timer 159	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			not equal			AFM apps only	ms continuous, 0.5 down time multiplier	
			AC friction torque is greater than commanded by AC control software	40.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Speed Lores Intake Firing (time based) calculation does not equal its redundant calculation	N/A		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the calculated spark offset for equivalence ratio and its redundant cacluation is greater than a threshold	4.16 degrees		Engine speed >0rpm	Up/down timer 159 ms continuous, 0.5 down time multiplier	
			Transmission Torque	N/A		Run or Crank = TRUE >	16 / 32	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Request cacluations do not equal their dual stores			0.50 s	counts; 25.0msec/count	
			Absolute difference of the predicted motor torque ACS and its redundant cacluation is greater than a threshold	0.01 Nm			Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Absolute difference of maximum throttle area and its redundant cacluation is greater than a threshold	15 mm2			Up/down timer 103 ms continuous, 0.5 down time multiplier	
			Absolute difference of Desired TIAP and its redundant cacluation is greater than a threshold	5.00 kPa			Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Pedal learns and their redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Throttle learns and their redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Desired Throttle Position and its redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Transmission Mode Switch Signal Circuit  Include for programs that are NOT hybrid start stop conventional	P1762	Vehicles that are not hybrid start stop conventional applications, this diagnoses the transmission mode switch signal circuit (BCM to ECM Rolling Count check)	Rolling count value received from BCM does not match expected value	= TRUE	Engine Speed Engine Speed  Engine speed between min/max for  Vehicle Speed for	≥ 200 RPM ≤ 7,500 RPM  ≥ 5.0 seconds  ≤ 318.14 MPH ≥ 5.0 seconds	> 3 error counts for > 10.0 seconds  100 ms / sample	Type C, No MIL

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Intake Camshaft Actuator Solenoid Circuit Low– Bank 1	P2088	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.	Short to ground: ≤ 0.5 Ω to a voltage source within the Vehicle Ground Voltage Range relative to PWRGND	System supply voltage is within limits.  Output driver is commanded on  Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples  250 ms /sample, continuous	Type B, 2 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Intake Camshaft Actuator Solenoid Circuit High – Bank 1	P2089	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power  Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply voltage is within limits  Output driver is commanded on  Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples  250 ms /sample, continuous	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Low Limit Bank 1 (Too Rich)	P2096	Determines if the post catalyst O2 sensor based fuel control system has utilized all or most of its low limit authority, indicating a rich emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too rich, the post catalyst O2 integral offset control is decreased. This results in lean bias fuel control in an attempt to correct the rich condition. A perfectly balanced control system (no rich or lean bias required) is represented by an integral offset value of "0" and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean). An integral offset value < 0 is indicative of the control system reacting to a rich post catalyst O2 sensor. If the failure is such that the control system utilizes all or most of its available authority, then P2096 will set.	Rich Fail counter  High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18% for >= 5.0 seconds.  Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14% for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.	>= 320 counts per 400 sample counts  Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration  Ambient Air Pressure Engine AirFlow Intake Manifold Pressure Induction Air Temperature Start-up Coolant Temp. PTO Intrusive diag. fuel control  Long Term Secondary Fuel Trim Enabled (see "Long Term Secondary Fuel Trim Enable Criteria" in Supporting Tables)  High Vapor Conditions  No Fault Active for:	No No Yes Yes Yes  >= 70 kPa >= 0.0 g/s <= 10,000.0 >= 0 kPa <= 200 >= -20 deg. C <= 200 >= -20 deg. C Not Active Not Active  Not Present  AmbientAirDefault AIR_System FA Ethanol Composition Sensor FA ECT_Sensor_FA EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorFA CamSensorAnyLocationFA EvapEmissionSystem_FA EvapFlowDuringNonPurge_FA FuelTankPressureSnrCkt_FA	Frequency: Continuous Monitoring in 100ms loop.  Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EvapPurgeSolenoidCircuit_FA EvapSmallLeak_FA EvapVentSolenoidCircuit_FA FuelInjectorCircuit_FA MAF_SensorFA MAF_SensorTFTKO MAP_SensorFA MAP_EngineVacuumStat us EngineMisfireDetected_FA A/F Imbalance Bank1 O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA FA FA The above general enable conditions must be true for: > 0.0 seconds Minimum accumulated counts in each cell required before counters will increment for that cell: Deceleration 300 Idle 300 Cruise 0 Light Acceleration 200 Heavy Acceleration 300 (Note: A value in any of the above operating "cells" that is an order of magnitude (or more) higher than other cells is an indication that the diagnostic is not capable of diagnosing in that cell). For the cells identified as		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>enabled (i.e. those containing a "Yes" at the beginning of the Enable Conditions column), the fail counter will increment if the sample counter increments  AND  Post oxygen sensor control integral offset (in mV) is  Deceleration  Idle  Cruise  Light Acceleration  Heavy Acceleration  AND  Post O2 Voltage is  Deceleration  Idle  Cruise  Light Acceleration  Heavy Acceleration    (Note: A value in any of the above operating "cells" that is greater than 900mV is an indication that the diagnostic is not capable of diagnosing in that cell).</p>	<p>&lt;=  -140 (control min.= -150)  -140 (control min.= -150)  -390 (control min.= -400)  -390 (control min.= -400)  -390 (control min.= -400)    &gt;  765 mV  765 mV  765 mV  765 mV  765 mV</p>		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System High Limit Bank 1 (Too Lean)	P2097	Determines if the post catalyst O2 sensor based fuel control system has utilized all or most of its high limit authority, indicating a lean emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too lean, the post catalyst O2 integral offset control is increased. This results in rich bias fuel control in an attempt to correct the lean condition. A perfectly balanced control system (no rich or lean bias required) is represented by an integral offset value of "0" and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean). An integral offset value > 0 is indicative of the control system reacting to a lean post catalyst O2 sensor. If the failure is such that the control system utilizes all or most of its available authority, then P2097 will set.	Lean Fail counter  High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18% for >= 5.0 seconds.  Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14% for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.	>= 320 counts per 400 sample counts  Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	Same as P2096 except for the following:  For the cells identified as enabled (i.e. those containing a "Yes" at the beginning of the Enable Conditions for P2096), the fail counter will increment if the sample counter increments AND Post oxygen sensor control integral offset (in mV) is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Heavy Acceleration  (Note: A value in any of the above operating "cells" that is less than 100mV is an indication that the diagnostic is not capable of diagnosing in that cell).	>= 140 (control max.= 150) 140 (control max.= 150) 390 (control max.= 400) 390 (control max.= 400) 390 (control max.= 400)  < 680 mV 680 mV 680 mV 680 mV 680 mV	Frequency: Continuous Monitoring in 100ms loop.  Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Low Limit Bank 2 (Too Rich)	P2098	<p>Determines if the post catalyst O2 sensor based fuel control system has reached it's low limit authority, indicating a rich emissions/exhaust gas condition.</p> <p>Note: If the post catalyst O2 voltage is too rich, the post catalyst O2 integral offset control is decreased. This results in lean bias fuel control in an attempt to correct the rich post O2 voltage. Determines if the post catalyst O2 sensor based fuel control system has utilized all or most of it's low limit authority, indicating a rich emissions/exhaust gas condition.</p> <p>Note: If the post catalyst O2 voltage is too rich, the post catalyst O2 integral offset control is decreased. This results in lean bias fuel control in an attempt to correct the rich condition. A perfectly balanced control system (no rich or lean bias required) is represented by an integral offset value of</p>	<p>Rich Fail counter</p> <p>High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is <math>\geq 18\%</math> for <math>\geq 5.0</math> seconds.</p> <p>Diagnosis resumes if the purge valve is closed OR the percent vapor is <math>\leq 14\%</math> for <math>\geq 5.0</math> seconds. This was done to minimize disabling the diagnostic for longer than necessary.</p>	<p><math>\geq 320</math> counts per 400 sample counts</p> <p>Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.</p>	<p>Same as P2096 except for the following:</p> <p>Bank1 Fault Active criteria are replaced by the equivalent Bank2 Fault Active criteria.</p> <p>The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration</p> <p>Minimum accumulated counts in each cell required before counters will increment for that cell: Deceleration Idle Cruise Light Acceleration Heavy Acceleration</p> <p>(Note: A value in any of the above operating "cells" that is an order of magnitude (or more) higher than other cells is an indication that the diagnostic is not capable of diagnosing in that cell).</p> <p>For the cells identified as enabled (i.e. those containing a "Yes" at the beginning of the Enable Conditions column), the fail counter will increment</p>	<p>No No Yes Yes Yes</p> <p>300 300 0 200 300</p>	<p>Frequency: Continuous Monitoring in 100ms loop.</p> <p>Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.</p>	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>"0" and a post catalyst O2 sensor that is within it's optimal operating range (neither rich nor lean). An integral offset value &lt; 0 is indicative of the control system reacting to a rich post catalyst O2 sensor. If the failure is such that the control system utilizes all or most of its available authority, then P2098 will set.</p>			<p>if the sample counter increments AND Post oxygen sensor control integral offset is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Heavy Acceleration</p> <p>(Note: A value in any of the above operating "cells" that is greater than 900mV is an indication that the diagnostic is not capable of diagnosing in that cell).</p>	<p>&lt;= -140 (control min.= -150) -140 (control min.= -150) -390 (control min.= -400) -390 (control min.= -400) -390 (control min.= -400) &gt; 765 mV 765 mV 765 mV 765 mV 765 mV</p>		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System High Limit Bank 2 (Too Lean)	P2099	Determines if the post catalyst O2 sensor based fuel control system has utilized all or most of its high limit authority, indicating a lean emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too lean, the post catalyst O2 integral offset control is increased. This results in rich bias fuel control in an attempt to correct the lean condition. A perfectly balanced control system (no rich or lean bias required) is represented by an integral offset value of "0" and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean). An integral offset value > 0 is indicative of the control system reacting to a lean post catalyst O2 sensor. If the failure is such that the control system utilizes all or most of its available authority, then P2099 will set.	Lean Fail counter  High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18% for >= 5.0 seconds.  Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14% for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.	>= 320 counts per 400 sample counts  Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	Same as P2098 except for the following:  Bank1 Fault Active criteria are replaced by the equivalent Bank2 Fault Active criteria.  For the cells identified as enabled (i.e. those containing a "Yes" at the beginning of the Enable Conditions column for P2098), the fail counter will increment if the sample counter increments AND Post oxygen sensor control integral offset is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Heavy Acceleration  (Note: A value in any of the above operating "cells" that is less than 100mV is an indication that the diagnostic is not capable of diagnosing in that cell).	>= 140 (control max.= 150) 140 (control max.= 150) 390 (control max.= 400) 390 (control max.= 400) 390 (control max.= 400)  < 680 mV 680 mV 680 mV 680 mV 680 mV	Frequency: Continuous Monitoring in 100ms loop.  Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Throttle Actuator Position Performance	P2101	1) Detect a throttle positioning error2) Throttle control is driving the throttle in the incorrect direction3) Throttle control exceeds the reduced power limit	Difference between measured throttle position and modeled throttle position >	6.04 percent	TPS minimum learn is not active and Throttle is being Controlled and (Engine Running or Ignition Voltage > or Ignition Voltage > )	Run/Crank voltage > 6.41	15 counts; 12.5 ms/count in the primary processor	Type A, 1 Trips
			OR					
			Difference between modeled throttle position and measured throttle position >	6.04 percent	Ignition voltage failure is false (P1682)	TPS minimum learn is not active and Throttle is being Controlled		
			Throttle Position >	36.00 percent		Powertrain Relay voltage > 6.41	11 counts; 12.5 ms/count in the primary processor	
			Throttle Position >	29.50 percent		Powertrain Relay voltage > 6.41	11 counts; 12.5 ms/count in the primary processor	
						Reduced Power is True		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Lo	P2122	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage <	0.4625		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Hi	P2123	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage >	4.7500		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Accelerator Pedal Position (APP) Sensor 2 Lo	P2127	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage <	0.3250		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P0697)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Accelerator Pedal Position (APP) Sensor 2 Hi	P2128	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage >	2.6000		Run/Crank voltage > 6.41  No 5V reference error or fault for # 4 5V reference circuit (P0697)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Throttle Position (TP) Sensor 1-2 Correlation	P2135	Detects a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor	Difference between TPS1 displaced and TPS2 displaced >	6.797 % offset at min. throttle position with a linear threshold to 9.720 % at max. throttle position		Run/Crank voltage > 6.41  No TPS sensor faults (P0122, P0123, P0222, P0223)  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts or 58 counts continuous; 3.125 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min TPS1 ) and (normalized min TPS2) >	5.000 % Vref		Run/Crank voltage > 6.41  No TPS sensor faults (P0122, P0123, P0222, P0223)  No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts or 58 counts continuous; 3.125 ms/count in the main processor	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1-2 Correlation	P2138	Detects a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor	Difference between APP1 displaced and APP2 displaced >	5.000 % offset at min. pedal position with a linear threshold to 10.001 % at max. pedal position		Run/Crank voltage > 6.41  No APP sensor faults (P2122, P2123,P2127, P2128)  No 5V reference errors or faultst for # 3 & # 4 5V reference circuits (P06A3, P0697)	19 / 39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min APP1 ) and (normalized min APP2) >	5.000 % Vref		Run/Crank voltage > 6.41  No APP sensor faults (P2122, P2123,P2127, P2128)  No 5V reference errors or faultst for # 3 & # 4 5V reference circuits (P06A3, P0697)	19 / 39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 1 high side circuit shorted to ground	P2147	This DTC Diagnoses Injector 1 high side driver circuit for circuit faults.	Voltage high across High Side Driver during On state indicates short to ground	Short to Ground: 25 amp $\geq$ through High Side Driver	Battery Voltage Engine Run Time	$\geq$ 11 Volts $\geq$ 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 1 high side circuit shorted to power	P2148	This DTC Diagnoses Injector 1 high side driver circuit for circuit faults.	Voltage low across High side drive during off state indicates short to power.	Short to Power: ≤ 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 2 high side circuit shorted to ground	P2150	This DTC Diagnoses Injector 2 high side driver circuit for circuit faults.	Voltage high across High Side Driver during On state indicates short to ground	Short to Ground: 25 amp $\geq$ through High Side Driver	Battery Voltage Engine Run Time	$\geq$ 11 Volts $\geq$ 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 2 high side circuit shorted to power	P2151	This DTC Diagnoses Injector 2 high side driver circuit for circuit faults.	Voltage low across High side drive during off state indicates short to power.	Short to Power: ≤ 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 3 high side circuit shorted to ground	P2153	This DTC Diagnoses Injector 3 high side driver circuit for circuit faults.	Voltage high across High Side Driver during On state indicates short to ground	Short to Ground: 25 amp $\geq$ through High Side Driver	Battery Voltage Engine Run Time	$\geq$ 11 Volts $\geq$ 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 3 high side circuit shorted to power	P2154	This DTC Diagnoses Injector 3 high side driver circuit for circuit faults.	Voltage low across High side drive during off state indicates short to power.	Short to Power: ≤ 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 4 high side circuit shorted to ground	P2156	This DTC Diagnoses Injector 4 high side driver circuit for circuit faults.	Voltage high across High Side Driver during On state indicates short to ground	Short to Ground: 25 amp $\geq$ through High Side Driver	Battery Voltage Engine Run Time	$\geq$ 11 Volts $\geq$ 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 4 high side circuit shorted to power	P2157	This DTC Diagnoses Injector 4 high side driver circuit for circuit faults.	Voltage low across High side drive during off state indicates short to power.	Short to Power: ≤ 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 5 high side circuit shorted to ground	P216B	This DTC Diagnoses Injector 5 high side driver circuit for circuit faults.	Voltage high across High Side Driver during On state indicates short to ground	Short to Ground: 25 amp $\geq$ through High Side Driver	Battery Voltage Engine Run Time	$\geq$ 11 Volts $\geq$ 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 5 high side circuit shorted to power	P216C	This DTC Diagnoses Injector 5 high side driver circuit for circuit faults.	Voltage low across High side drive during off state indicates short to power.	Short to Power: ≤ 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 6 high side circuit shorted to ground	P216E	This DTC Diagnoses Injector 6 high side driver circuit for circuit faults.	Voltage high across High Side Driver during On state indicates short to ground	Short to Ground: 25 amp $\geq$ through High Side Driver	Battery Voltage Engine Run Time	$\geq$ 11 Volts $\geq$ 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 6 high side circuit shorted to power	P216F	This DTC Diagnoses Injector 6 high side driver circuit for circuit faults.	Voltage low across High side drive during off state indicates short to power.	Short to Power: ≤ 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Minimum Throttle Position Not Learned	P2176	TP sensors were not in the minimum learn window after multiple attempts to learn the minimum.	During TPS min learn on the Main processor, TPS Voltage >  AND  Number of learn attempts >	0.5740   10 counts		Run/Crank voltage > 6.41  TPS minimum learn is active  No previous TPS min learn values stored in long term memory	2.0 secs	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 7 high side circuit shorted to ground	P217B	This DTC Diagnoses Injector 7 high side driver circuit for circuit faults.	Voltage high across High Side Driver during On state indicates short to ground	Short to Ground: 25 amp $\geq$ through High Side Driver	Battery Voltage Engine Run Time	$\geq$ 11 Volts $\geq$ 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 7 high side circuit shorted to power	P217C	This DTC Diagnoses Injector 7 high side driver circuit for circuit faults.	Voltage low across High side drive during off state indicates short to power	Short to Power: ≤ 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector high side circuit shorted to ground	P217E	This DTC Diagnoses Injector high side driver circuit for circuit faults.	Voltage high across High Side Driver during n state indicates short to ground	Short to ground: 2 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Injector 8 high side circuit shorted to power	P217F	This DTC Diagnoses Injector 8 high side driver circuit for circuit faults.	Voltage low across High side drive during off state indicates short to power	Short to Power: ≤ 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds  P062B not FA or TFTK	10 failures out of 20 samples  100 ms /sample Continuous	Type A, 1 Trips



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Bank 1 Air-Fuel Ratio Imbalance	P219A	This monitor determines if a cylinder-to-cylinder air-fuel ratio imbalance is present on bank 1.	<p>Filtered Ratio &gt;</p> <p>Note: The input to this metric is the pre catalyst oxygen sensor voltage. This voltage is used to generate a Variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to the air-fuel ratio imbalance (variance is higher with an imbalance than without). Multiple samples are collected in making a decision.</p> <p>The observed Variance is dependant on engine speed and load and so each result is normalized for speed and load by comparing it to a known "good system" result for that speed and load, and generating a Ratio metric.</p> <p>The Ratio metric is calculated by selecting the appropriate threshold calibration from a 17x17 table (Supporting Table "<b>Variance Threshold Bank1</b>") and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table</p>	0.90	<p>System Voltage</p> <p>Fuel Level</p> <p>Engine Coolant Temperature</p> <p>Cumulative engine run time</p> <p>Diagnostic enabled at Idle (regardless of other operating conditions)</p> <p>Engine speed range</p> <p>Engine speed delta during a short term sample period</p> <p>Mass Airflow (MAF) range</p> <p>Cumulative delta MAF during a short term sample period</p> <p>Filtered MAF delta between samples Note: first order lag filter coefficient applied to MAF = 0.050</p> <p>Air Per Cylinder (APC)</p> <p>APC delta during short term sample period</p> <p>Filtered APC delta between samples</p>	<p>no lower than 10.0 Volts for more than 0.2 seconds</p> <p>&gt; 10.0 percent AND no fuel level sensor fault</p> <p>&gt; -20 degrees C</p> <p>&gt; 25.0 seconds</p> <p>No</p> <p>800 to 3,750 RPM</p> <p>&lt; 250 RPM</p> <p>5 to 1,000 g/s</p> <p>&lt; 5 g/s</p> <p>&lt; 0.70 g/s</p> <p>100 to 720 mg/cylinder</p> <p>&lt; 100 mg/cylinder</p> <p>&lt; 10.00 percent</p>	<p>Minimum of 1 test per trip, up to 6 tests per trip during RSR or FIR.</p> <p>The front O2 sensor voltage is sampled once per cylinder event. Therefore, the time required to complete a single test (when all enable conditions are met) decreases as engine speed increases. For example, 18.00 seconds of data is required at 1000 rpm while double this time is required at 500 rpm and half this time is required at 2000 rpm. This data is collected only when enable conditions are met, and as such significantly more operating time is required than is indicated above. Generally, a report will be</p>	Type A, 1 Trips

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>(Supporting Table "Normalizer Bank1"). This quotient is then multiplied by a quality factor calibration from a 17 x 17 table (Supporting Table "Quality Factor Bank1"). This result is referred to as the Ratio. Note that the quality factor ranges between 0 and 1 and represents robustness to false diagnosis in the current operating region. Regions with low quality factors are not used.</p> <p>Finally, a EWMA filter is applied to the Ratio metric to generate the Filtered Ratio malfunction criteria metric. Generally, a normal system will result in a negative Filtered Ratio while a failing system will result in a positive Filtered Ratio.</p> <p>The range of the Filtered Ratio metric is application specific since both the emissions sensitivity and relationship between imbalance and the Variance metric are application specific.</p> <p>Some applications may need to command a unique cam phaser value before performing the</p>		<p>Note: first order lag filter coefficient applied to APC = 0.050</p> <p>Spark Advance</p> <p>Throttle Area (percent of max)</p> <p>Intake Cam Phaser Angle</p> <p>Exhaust Cam Phaser Angle</p> <p>Quality Factor (QF) QF calibrations are located in a 17x17 lookup table versus engine speed and load (Supporting Table "Quality Factor Bank1"). QF values less than "1" indicate that we don't have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data.</p> <p>Fuel Control Status Closed Loop and Long Term FT Enabled for:</p> <p>AIR pump not on CASE learn not active EGR - no device control, no intrusive diagnostics EVAP - no device control, no intrusive diagnostics Engine OverSpeed</p>	<p>0 to 55 degrees</p> <p>0 to 200 percent</p> <p>0 to 30 degrees</p> <p>0 to 25 degrees</p> <p>&gt;= 0.99</p> <p>&gt;= 1.2 seconds (Please see "Closed Loop Enable Criteria" and "Long Term FT Enable Criteria" in Supporting Tables)</p>	<p>made within 5 minutes of operation.</p> <p>For RSR or FIR, 12 tests must complete before the diagnostic can report.</p>	

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			above calculations since cam phasing has been shown to have an impact on overall signal quality. This application Does Not Use this feature.		Protection Not Active Idle speed control normal PTO Not Active Injector base pulse width above min limit O2 Learned htr resistance  Rapid Step Response (RSR): RSR will trigger if the Ratio result from the last test is AND it exceeds the last Filtered ratio by  Once triggered, the filtered ratio is reset to:  Fast Initial Response (FIR): FIR will trigger when an NVM reset or code clear occurs. Once triggered, the filtered ratio is reset to:  No Fault Active for:	= Valid (the O2 heater resistance has learned since NVM reset)  >= 0.90 >= 0.90  0.00  0.00  EngineMisfireDetected_FA MAP_SensorFA MAF_SensorFA ECT_Sensor_FA TPS_ThrottleAuthorityDefaulted FuelInjectorCircuit_FA AIR System FA EvapExcessPurgePsbl_FA CamSensorAnyLocationFA		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Bank 2 Air-Fuel Ratio Imbalance	P219B	This monitor determines if a cylinder-to-cylinder air-fuel ratio imbalance is present on bank 2.	<p>Filtered Ratio &gt;</p> <p>Note: See P219A for a detailed description of this failure metric.</p> <p>Some applications may need to command a unique cam phaser value before performing the above calculations since cam phasing has been shown to have an impact on overall signal quality. This application Does Not Use this feature.</p>	0.50	<p>See Bank 1 (P219A) Secondary Parameters and Enable Conditions.</p> <p>Quality Factor (QF) QF calibrations are located in a 17x17 lookup table versus engine speed and load (Supporting Table "Quality Factor Bank2"). QF values less than "1" indicate that we don't have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data.</p> <p>Rapid Step Response (RSR): RSR will trigger if the Ratio result from the last test is AND it exceeds the last Filtered ratio by Once triggered, the filtered ratio is reset to:</p> <p>Fast Initial Response (FIR): FIR will trigger when an NVM reset or code clear occurs. Once triggered, the filtered ratio is reset to:</p>	<p>&gt;= 0.99</p> <p>&gt;= 0.50</p> <p>&gt;= 0.50</p> <p>0.00</p> <p>0.00</p>	See Bank 1 info	Type A, 1 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Performance (naturally aspirated)	P2227	Compares baro sensor to the calculated baro estimate (part throttle calculation or unthrottled MAP)	Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 15.0 kPa ≤ 0.06 miles	No Active DTCs:	AmbPresSnsrCktFA ECT_Sensor_Ckt_FA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA	320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips
			OR  Difference between baro sensor reading and estimated baro when distance since last estimated baro update	> 20.0 kPa > 0.06 miles				
			Barometric Pressure OR Barometric Pressure	< 50.0 kPa > 115.0 kPa	Time between current ignition cycle and the last time the engine was running  Engine is not rotating  No Active DTCs:  No Pending DTCs:	> 5.0 seconds  EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA  MAP_SensorCircuitFP AAP_SnsrCktFP	4 failures out of 5 samples  1 sample every 12.5 msec	

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Barometric Pressure (BARO) Sensor Circuit Low (non-boosted applications)	P2228	Detects a continuous short to low or open in either the signal circuit or the BARO sensor.	BARO Voltage	< 40.0% of 5 Volt Range (2.0 Volts = 51.0 kPa)			320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Barometric Pressure (BARO) Sensor Circuit High (non-boosted applications)	P2229	Detects an open sensor ground or continuous short to high in either the signal circuit or the BARO sensor.	BARO Voltage	> 90.0% of 5 Volt Range (4.5 Volts = 115.1 kPa)			320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Barometric Pressure (BARO) Sensor Circuit Intermittent	P2230	Detects a noisy or erratic barometric pressure input	String Length  Where: "String Length" = sum of "Diff" calculated over  And where: "Diff" = ABS(current BARO reading - BARO reading from 12.5 milliseconds previous)	> 100 kPa  80 consecutive BARO samples			4 failures out of 5 samples  Each sample takes 1.00 seconds	Type B, 2 Trips





15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Post fuel cell (Decel) Crankshaft Torque  EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time  Predicted Catalyst temp Fuel State  ===== All of the above met for at least 0.0 seconds, and then check the following  Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)  Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)  ===== All of the above met for at least 1.0 seconds, and then the Force Cat Rich intrusive stage is requested.  ===== During Stuck Lean test the following must stay TRUE or the test will abort: Commanded Fuel Crankshaft Torque	= enabled < 125.0 Nm  = not active = not active ≥ 60.0 sec  600 ≤ °C ≤ 900 = DFCO possible  =====  1,000 ≤ RPM ≤ 2,300  950 ≤ RPM ≤ 2,350  42.3 ≤ MPH ≤ 74.6  39.8 ≤ MPH ≤ 77.7  =====  0.95 ≤ EQR ≤ 1.10 < 125.0 Nm		



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Take Off EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time  Predicted Catalyst temp Fuel State  DTC's Passed  ===== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	= not active = not active = not active ≥ 60.0 sec  600 ≤ °C ≤ 900 DFCO possible  = P2270 (and P2272 if applicable) = P013E (and P014A if applicable) = P013A (and P013C if applicable)  =====		



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Post fuel cell (Decel) Crankshaft Torque  EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time  Predicted Catalyst temp Fuel State  ===== All of the above met for at least 0.0 seconds, and then check the following  Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)  Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)  ===== All of the above met for at least 1.0 seconds, and then the Force Cat Rich intrusive stage is requested. ===== During Stuck Lean test the following must stay TRUE or the test will abort: Commanded Fuel Crankshaft Torque	= enabled < 125.0 Nm  = not active = not active ≥ 60.0 sec  600 ≤ °C ≤ 900 = DFCO possible  =====  1,000 ≤ RPM ≤ 2,300  950 ≤ RPM ≤ 2,350  42.3 ≤ MPH ≤ 74.6  39.8 ≤ MPH ≤ 77.7  =====  0.95 ≤ EQR ≤ 1.10 < 125.0 Nm		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.





15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Take Off EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time  Predicted Catalyst temp Fuel State DTC's Passed  ===== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	= not active = not active = not active ≥ 60.0 sec  600 ≤ °C ≤ 900 = DFCO possible = P2270 (and P2272 if applicable) = P013E (and P014A if applicable) = P013A (and P013C if applicable)  =====		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump	P228C	This DTC Diagnoses the measured fuel rail pressure bias too low from desired fuel pressure.	Desired Pressure - Measure Pressure	>= 3.00 Mpa	Battery Voltage  Low Side Fuel Pressure  Engine Run Time  Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement	>= 11 Volts  > 0.275 MPa  >= KtFHPD_t_PumpCntrlEng RunThrsh (see supporting tables)  Enabled when a code clear is not active or not exiting device control Engine is not cranking	Pressure Error - 750 0 failures out of 938 samples	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active  Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -10.0 degC -10 <=Temp degC <= 100		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump	P228D	This DTC Diagnoses the measured fuel rail pressure bias too high from desired fuel pressure	Desired Pressure - Measure Pressure	<= -3.00 Mpa	Battery Voltage  Low Side Fuel Pressure  Engine Run Time  Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and	>= 11 Volts  > 0.275 MPa  >= KtFHPD_t_PumpCntrlEng RunThrsh (see supporting tables)  Enabled when a code clear is not active or not exiting device control Engine is not cranking	Pressure Error - 750 failures out of 938 samples	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Engine movement detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active  Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -10.0 DegC -10 <= Temp degC <= 100		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #1 CIRCUIT Low	P2300	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #1 CIRCUIT High	P2301	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #2 CIRCUIT Low	P2303	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #2 CIRCUIT High	P2304	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #3 CIRCUIT Low	P2306	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #3 CIRCUIT High	P2307	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #4 CIRCUIT Low	P2309	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT High	P2310	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #5 CIRCUIT Low	P2312	Diagnoses Cylinder #5 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage Low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #5 CIRCUIT High	P2313	Diagnoses Cylinder #5 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #6 CIRCUIT Low	P2315	Diagnoses Cylinder #6 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage low during driver high state (indicates short-to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #6 CIRCUIT High	P2316	Diagnoses Cylinder #6 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #7 CIRCUIT Low	P2318	Diagnoses Cylinder #7 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage low during driver high state (indicates short-to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #7 CIRCUIT High	P2319	Diagnoses Cylinder #7 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #8 CIRCUIT Low	P2321	Diagnoses Cylinder #8 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage low during driver high state (indicates short-to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
IGNITION CONTROL #8 CIRCUIT High	P2322	Diagnoses Cylinder #8 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.  Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running  Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Torque Request Circuit	P2544	Determines if the torque request from the TCM is valid	Protect error - Serial Communication message 2's complement not equal (\$189/\$199)  OR Rolling count error - Serial Communication message (\$189/\$199) rolling count index value  OR  Range Error - Serial Communication message - (\$189/\$199) TCM Requested Torque Increase  OR  Multi-transition error - Trans torque intervention type request change	Message <> two's complement of message   Message <> previous message rolling count value + one   > 765 Nm   Requested torque intervention type toggles from not increasing request to increasing request	Diagnostic Status  Power Mode  Ignition Voltage  Engine Running Run/Crank Active   No Serial communication loss to TCM (U0101)	Enabled  = Run  > 6.41 volts  = True  > 0.50 Sec   No loss of communication	>= 16 failures out of 20 samples.  Performed on every received message  >= 6 Rolling count errors out of 10 samples.  Performed on every received message  >= 6 range errors out of 10 samples.  Performed on every received message  >= 3 multi-transitions out of 5 samples. Performed every 200 msec	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Off Timer Performance	P262B	<p>This DTC determines if the hardware timer does not initialize or count properly. There are two tests to ensure proper functioning of the timer: Count Up Test (CUT) and Range Test (RaTe).</p> <p>Count Up Test (CUT): Verifies that the HWIO timer is counting up with the proper increment.</p> <p>Range Test (RaTe): When the run/crank is not active both the hardware and mirror timers are started. The timers are compared when module shutdown is initiated or run/crank becomes active.</p>	<p>Count Up Test: Time difference between the current read and the previous read of the timer</p> <p>Range Test: The variation of the HWIO timer and mirror timer is</p>	<p>&gt; 1.50 seconds</p> <p>&gt; 24.87 %.</p>			<p>Count Up Test: 4 failures out of 20 samples</p> <p>1 sec / sample</p> <p>Continuous while run/crank is not active and until controller shutdown is initiated.</p> <p>Range Test: Once per trip when controller shutdown is initiated or run/crank becomes active.</p>	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump "A" Low Flow / Performance	P2635	This DTC detects degradation in the performance of the SIDI electronically regulated fuel system	Filtered fuel rail pressure error	<= Low Threshold ( see Supporting Calibration tab)  OR  >= High Threshold ( see Supporting Calibration tab)  ( tabulated result: function of desired fuel rail pressure and fuel flow rate)	a] Fu Rail Pres Snsr Circuit Low Fault Active (DTC P018C)  b] Fu Rail Pres Snsr Circuit High Fault Active (DTC P018D)  c] Fu Rail Pres Snsr Perf Fault Active ( DTC P018B)  d] Fu Pump Circuit Low Fault Active ( DTC P0231)  e] Fu Pump Circuit High Fault Active ( DTC P0232)  f] Fu Pump Circuit Open Fault Active (DTC P023F)  g] Reference Voltage Fault Status (DTC P0641)  h] Fu Pump Driver Control Module Overtemperature Fault Active (DTC P1255)  j] Barometric Pressure Signal Valid (PPEI \$4C1)  k] Engine run time  l] Emissions Fuel Level Low (PPEI \$3FB)  m] Fu Pump Control Enabled	a] <> TRUE  b] <> TRUE  c] <> TRUE  d] <> TRUE  e] <> TRUE  f] <> TRUE  g] <> Active This Key  h] <> TRUE  j] == TRUE (for absolute fuel pressure sensor)  k] >= 30 sec  l] <> TRUE  m] == TRUE	1 sample / 12.5 millisec	Type B, 2 Trips



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					n] Fu Pump Control state p] System Voltage q] Fuel flow rate  r] Fuel Pressure Control System	n] == Normal p] 11V< System V <32V q1] > 0.047 gram/sec AND q2] <= Max allowed fuel flow rate (function of desired pressure and system voltage)(typically 11-50 gram/sec) r1] Not responding to overperformance due to pressure buildup during Deceleration Fuel Cut Off OR r2] Not responding to a decreasing desired fuel pres commnad		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Low	P263A	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage  Remote Vehicle Start is not active	Voltage ≥ 11 volts	50 failures out of 63 samples  50 ms / sample	Type B, No MIL  NO MIL  Note: In certain controllers P0650 may also set (MIL Control Open Circuit)

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) High	P263B	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Run/Crank Voltage  Remote Vehicle Start is not active	Voltage ≥ 11 volts	4 failures out of 5 samples  50 ms / sample	Type B, No MIL  NO MIL

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Chassis Control Module 1 Requested MIL Illumination	P26C8	Monitors the Chassis Control Module 1 MIL request line to determine when the Chassis Control Module 1 has detected a MIL illuminating fault.	Chassis Control Module 1 Emissions-Related DTC set			Time since power-up $\geq$ 3 seconds	Continuous	Type A, No MIL

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Deactivation System Performance	P3400	Detects a "failed to deactivate" condition when Deactivation Mode is allowed:	ABS(Measured MAP – MAP Model 2) Filtered AND ((Measured MAP – MAP Model 2) filtered) (stored from previous all-Cylinder mode event) - ((Measured MAP – MAP Model 2) filtered) (current)	< -10 kPa  > -10 kPa	<u>Diagnostic Enable Conditions:</u>  ECT IAT Engine RPM  Minimum total weight factor (all factors multiplied together)	> -7 and < 129 Deg C > -20 and < 129 Deg C > 450 and < 5,600 RPM  >= 0.50 factor  Filtered Throttle Model Error multiplied by <b>TPS Residual Weight Factor based on RPM</b> * Modeled Air Flow Error multiplied by <b>MAF Residual Weight Factor based on RPM</b> * MAP Model 1 Error multiplied by <b>MAP1 Residual Weight Factor based on RPM</b> * MAP Model 2 Error multiplied by <b>MAP2 Residual Weight Factor based on RPM</b> * <b>Lag Filter Coeff ( 1.00 )</b> (For details see P3400 "Residual Weight Factor" tables on Supporting Tables Tab).  MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA	320 cylinder deactivation lag residual failures out of 400 samples  Performed every 100 ms	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>No active DTC's Pending DTCs:for diagnsotic enable:</p> <p><u>CYLINDER DEACTIVATION CONTROL ENABLE CONDITIONS:</u></p> <p>Conditions below must be met for &gt;= 0.3 seconds before cylinder deactivation will begin in regular mode</p> <p><u>Neutral Idle Mode (NI) operational checks</u> Allowed in NI Time in NI NI mode shall be active Vehicle Speed for NI</p> <p>Vehicle Speed based on PRNDL for NI = FALSE</p> <p>Engine RPM lower limit for NI</p> <p>Transmission gear for NI = FALSE</p> <p>Torque based AFM entry</p>	<p>CrankSensor_FA ECT_Sensor_FA IAT_SensorFA</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP</p> <p>FALSE &gt;= 1.0 seconds &lt; 4.3 mph to Enter &gt; 0.0 mph to Exit</p> <p><b>VCE_PRNDL_NI_Disables</b> (For details see P3400 tables on Supporting Tables Tab).</p> <p>&gt; 475 rpm</p> <p><b>VCE_TransGear_DisablesNI</b> (For details see P3400 tables on Supporting Tables Tab)</p>		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					conditions: NI Mode Active  <u>Normal Mode operational checks:</u>  Engine running (based on engine off time)  Engine RPM  Vehicle Speed (in Gear) Vehicle Speed (P/N)  Vehicle Speed based on PRNDL  If TRUE, will enabled AFM only if transmission is not	Indicated Torque < <b>VCE_NormalMode_MaxTorque_Gr1 - Gr8</b> minus 10.0 Nm (For details see P3400 tables on Supporting Tables Tab)  Maximum 45.0 or > <b>VCEStartUpDelayTime</b> seconds (For details see P3400 tables on Supporting Tables Tab).  > <b>VCE_EngineRPM_LowerLmt + 75 RPM</b> AND < <b>VCE_EngineRPM_UpperLmt - 200 RPM</b> (For details see P3400 tables on Supporting Tables Tab).  >= 8.1 mph <= 5.0 mph  < <b>VCE_VehicleSpeed_PRNDL_Enable</b> (For details see P3400 tables on Supporting Tables Tab).  Feature is TRUE		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					in a defaulted state. Engine RPM PRNDL	> <b>VCE_EngineRPM_PRNDL_LowerLmt + 75 RPM</b> AND < <b>VCE_EngineRPM_PRNDL_UpperLmt - 200 RPM</b> (For details see P3400 tables on Supporting Tables Tab).		
					Engine coolant (deac)	>= 40 and <= 252 deg C		
					Ignition voltage	>= 11.0 volts		
					Engine Oil Temperature	>= 20 and <= 128 deg C		
					Engine Oil Pressure	>= 187 and <= 455 KPa		
					Oil pump intrusive test : (refer to P06DD and P06DE)	= FALSE		
					Oil aeration present	Aeration enabled by engine RPM > 3,100 for 10 second(s), disabled by engine RPM < 3,000 for 50 second(s)		
					Catalyst Warm up	Not active		
					POPD	Not active		
					Deceleration Fuel Cut Off	Not active		
					Fuel shut off (FSO) delay	Not Active >= 3 second(s)		
					Green Engine mode	Not Active		
					Pedal Position	< 48 pct		



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Brake booster vacuum  Transmission gear = FALSE  Gear Shift  4WD State  Time since last AFM mode event  After exiting AFM mode for max time, must be in all cylinder mode for  Tip in Bump  AFM is disabled at high percent ethanol  If feature is enabled, AFM is allowed only when percent ethanol learn is not in progress  AFIM diagnostic status  A/C clutch transition  ETC power management mode:  Heater performance:	>= 0 KPa  <b>VCE_TransGear_Disables</b> (For details see P3400 tables on Supporting Tables Tab).  not currently in progress  not = 4 low range  >= 3 second(s)  >= 60 second(s)  Not active  Ethanol concentration > 95 % disables AFM. Once disabled, ethanol concentration must be < 90 % to re-enable  Feature is FALSE  Not active  Not currently in progress  Not active  Not in heater performnce		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Torque based AFM entry conditions: ECO Mode Active</p> <p>Normal Mode</p> <p><u>IF DEACTIVATED, ANY OF THE CONDITIONS BELOW WILL FORCE CYLINDER REACTIVATION:</u></p> <p>If deactivation mode is active for then reactivation will occur if: Deac mode active</p> <p>Delta vacuum</p> <p>Vehicle Speed for NI exit</p> <p>ETC Power management mode</p> <p>Converter overtemp protect</p>	<p>mode</p> <p>Indicated Torque &lt; <b>VCE_ECOMode_MaxTorque_Gr1 - Gr8</b> minus <b>VCE_ECOMode_EnableTorqueHyst</b></p> <p>Indicated Torque &lt; <b>VCE_NormalMode_MaxTorque_Gr1 - Gr8</b> minus <b>VCE_NormalMode_EnableTorqueHyst</b> (For details see P3400 tables on Supporting Tables Tab).</p> <p>&gt;= 480 seconds &gt;= 600 seconds or &gt; 5 or &lt; -5 kPa</p> <p>&lt; 0 Kph</p> <p>Active</p> <p>Active</p>		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Hot coolant mode	Active		
					Engine running	= False		
					Engine overspeed protection	Active		
					Engine metal overtemp protect	Active		
					Cat. temp low	Active		
					Four Wheel Drive	In low range		
					Engine misfire	Detected		
					Heater performance	Active		
					POPD Intrusive tests (see P2270-P2273, P013A-P014B)	Active		
					Torque based AFM exit conditions:			
					ECO Mode Active	Indicated Torque < <b>VCE_ECOMode_MaxTorque_Gr1 - Gr8</b> Nm		
					Normal Mode	Indicated Torque < <b>VCE_NormalMode_MaxTorque_Gr1 - Gr8</b> Nm (For details see P3400 tables on Supporting Tables Tab).		
					Ignition voltage	< 11 volts		
					Engine coolant	< 36 or > 256 Deg C		
					Vehicle speed	< 6.8 mph		
					Brake booster vacuum	< 0 kPa		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Engine oil temperature Pedal Position Piston Protection No active DTC's for control enable:	< 18 or > 130 Deg C > 50 % Active Fault Bundles: EngOilPressureSensorFA EnginePowerLimited CrankSensorTFTKO EngineTorqueEstInaccurate VehicleSpeedSensorError ECT_Sensor_FA BrakeBoosterVacuumValid IAT_SensorFA CylDeacDriverFault CylDeacSystemTFTKO MAP_EngineVacuumStatus PowertrainRelayFault CamSensorAnyLctnTFTKO OilPmpStuckHigh VCER_TorqueSecurity FourWheelDriveLowStateInvalid		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cylinder 1 Deactivation Solenoid Control Circuit/Open	P3401	Diagnoses cylinder 1 deactivation solenoid control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 k Ω impedance between signal and controller ground	Diagnostic enabled/ disabled  Powertrain Relay Voltage  Engine RPM	Enabled  ≥ 11 volts  ≥ 400 rpm	≥ 20 errors out of 25 samples  Performed every 250 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cylinder 1 Deactivation Solenoid Control Circuit/Low	P3403	Diagnoses cylinder 1 deactivation solenoid control low side driver circuit for circuit faults	Voltage low during driver off state (indicates an short circuit to Ground)	Short to Ground Circuit ≤ 0.5 Ω impedance between signal and controller ground	Diagnostic enabled/ disabled  Powertrain Relay Voltage  Engine RPM	Enabled  ≥ 11 volts  ≥ 400 rpm	≥ 20 errors out of 25 samples  Performed every 250 msec	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 1 Deactivation Solenoid Control Circuit/High	P3404	Diagnoses cylinder 1 deactivation solenoid control low side driver circuit for circuit faults	Voltage low during driver on state (indicates an short to power)	Short to Power ≤ 0.5 Ω impedance between signal and controller power	Diagnostic enabled/ disabled  Powertrain Relay Voltage  Engine RPM	Enabled  ≥ 11 volts  ≥ 400 rpm	≥ 20 errors out of 25 samples  Performed every 250 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cylinder 4 Deactivation Solenoid Control Circuit/Open	P3425	Diagnoses cylinder 4 deactivation solenoid control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 k Ω impedance between signal and controller ground	Diagnostic enabled/ disabled  Powertrain Relay Voltage  Engine RPM	Enabled  ≥ 11 volts  ≥ 400 rpm	≥ 20 errors out of 25 samples  Performed every 250 msec	Type B, 2 Trips



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cylinder 4 Deactivation Solenoid Control Circuit/Low	P3427	Diagnoses cylinder 4 deactivation solenoid control low side driver circuit for circuit faults	Voltage low during driver off state (indicates an short circuit to Ground)	Short to Ground Circuit ≤ 0.5 Ω impedance between signal and controller ground	Diagnostic enabled/ disabled  Powertrain Relay Voltage  Engine RPM	Enabled  ≥ 11 volts  ≥ 400 rpm	≥ 20 errors out of 25 samples  Performed every 250 msec	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 4 Deactivation Solenoid Control Circuit/High	P3428	Diagnoses cylinder 4 deactivation solenoid control low side driver circuit for circuit faults	Voltage low during driver on state (indicates an short to power)	Short to Power ≤ 0.5 Ω impedance between signal and controller power	Diagnostic enabled/ disabled  Powertrain Relay Voltage  Engine RPM	Enabled  ≥ 11 volts  ≥ 400 rpm	≥ 20 errors out of 25 samples  Performed every 250 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cylinder 6 Deactivation Solenoid Control Circuit/Open	P3441	Diagnoses cylinder 6 deactivation solenoid control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 k Ω impedance between signal and controller ground	Diagnostic enabled/ disabled  Powertrain Relay Voltage  Engine RPM	Enabled  ≥ 11 volts  ≥ 400 rpm	≥ 20 errors out of 25 samples  Performed every 250 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cylinder 6 Deactivation Solenoid Control Circuit/Low	P3443	Diagnoses cylinder 6 deactivation solenoid control low side driver circuit for circuit faults	Voltage low during driver off state (indicates an short circuit to Ground)	Short to Ground Circuit ≤ 0.5 Ω impedance between signal and controller ground	Diagnostic enabled/ disabled  Powertrain Relay Voltage  Engine RPM	Enabled  ≥ 11 volts  ≥ 400 rpm	≥ 20 errors out of 25 samples  Performed every 250 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cylinder 6 Deactivation Solenoid Control Circuit/High	P3444	Diagnoses cylinder 6 deactivation solenoid control low side driver circuit for circuit faults	Voltage low during driver on state (indicates an short to power)	Short to Power ≤ 0.5 Ω impedance between signal and controller power	Diagnostic enabled/ disabled  Powertrain Relay Voltage  Engine RPM	Enabled  ≥ 11 volts  ≥ 400 rpm	≥ 20 errors out of 25 samples  Performed every 250 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cylinder 7 Deactivation Solenoid Control Circuit/Open	P3449	Diagnoses cylinder 7 deactivation solenoid control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 k Ω impedance between signal and controller ground	Diagnostic enabled/ disabled  Powertrain Relay Voltage  Engine RPM	Enabled  ≥ 11 volts  ≥ 400 rpm	≥ 20 errors out of 25 samples  Performed every 250 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cylinder 7 Deactivation Solenoid Control Circuit/Low	P3451	Diagnoses cylinder 7 deactivation solenoid control low side driver circuit for circuit faults	Voltage low during driver off state (indicates an short circuit to Ground)	Short to Ground Circuit ≤ 0.5 Ω impedance between signal and controller ground	Diagnostic enabled/ disabled  Powertrain Relay Voltage  Engine RPM	Enabled  ≥ 11 volts  ≥ 400 rpm	≥ 20 errors out of 25 samples  Performed every 250 msec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Cylinder 7 Deactivation Solenoid Control Circuit/High	P3452	Diagnoses cylinder 7 deactivation solenoid control low side driver circuit for circuit faults	Voltage low during driver on state (indicates an short to power)	Short to Power ≤ 0.5 Ω impedance between signal and controller power	Diagnostic enabled/ disabled  Powertrain Relay Voltage  Engine RPM	Enabled  ≥ 11 volts  ≥ 400 rpm	≥ 20 errors out of 25 samples  Performed every 250 msec	Type B, 2 Trips



15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communicati on Bus A Off	U0073	This DTC monitors for a BUS A off condition	Bus off failures exceeds  before the sample time of is reached	5 counts (equivalent to 0.06 seconds)  0.56 seconds	General Enable Criteria:  U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Ignition voltage  Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line and Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds  CAN hardware is bus OFF for	Not Active on Current Key Cycle  Enabled  Not Active  Not Active  >= 11.00 or >= 6.41  = run  = 0 ( 1 indicates enabled)  = Active  > 11.00        > 0.1125 seconds	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communicati on Bus B Off	U0074	This DTC monitors for a BUS B off condition	Bus off failures exceeds  before the sample time of is reached	5 counts (equivalent to 0.06 seconds)  0.56 seconds	General Enable Criteria:  U0074  Normal CAN transmission on Bus B  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Ignition voltage  Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line and Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds  CAN hardware is bus OFF for	Not Active on Current Key Cycle  Enabled  Not Active  Not Active  >= 11.00 or >= 6.41  = run  = 0 (1 indicates enabled)  = Active  > 11.00        > 0.1125 seconds	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With TCM	U0101	This DTC monitors for a loss of communication with the transmission control module	Message is not received from controller for		General Enable Criteria:		Diagnostic runs in 12.5 ms loop	Type B, 2 Trips
			Message \$0AB	≥ 10.0 seconds	U0073	Not Active on Current Key Cycle		
			Message \$0BD	≥ 10.0 seconds	Normal CAN transmission on Bus A	Enabled		
			Message \$0C7	≥ 10.0 seconds	Device Control	Not Active		
			Message \$0F9	≥ 10.0 seconds	High Voltage Virtual Network Management	Not Active		
			Message \$189	≥ 10.0 seconds	Ignition Voltage Criteria:			
			Message \$199	≥ 10.0 seconds	Ignition voltage	≥ 11.00 or ≥ 6.41		
			Message \$19D	≥ 10.0 seconds				
			Message \$1AF	≥ 10.0 seconds	Power Mode	= run		
			Message \$1BE	≥ 10.0 seconds	Off Cycle Enable Criteria:			
			Message \$1BF	≥ 10.0 seconds	KeCAND_b_OffKeyCycle DiagEnbl	= 0 (1 indicates enabled)		
			Message \$1F5	≥ 10.0 seconds				
Message \$4C9	≥ 10.0 seconds	Ignition Accessory Line and Battery Voltage	= Active > 11.00					
			General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds					
			Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is					

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					not active for  U0101  TCM	> 0.4000 seconds  Not Active on Current Key Cycle  is present on the bus		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Cruise Control Module	U0104	This DTC monitors for a loss of communication with the Cruise Control Module.	Message is not received from controller for  Message \$2CB  Message \$2CD	  ≥ 10.0 seconds  ≥ 10.0 seconds	General Enable Criteria:  U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Ignition voltage  Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line and Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds  Power Mode is in accessory or run or crank and High Voltage Virtual	Not Active on Current Key Cycle  Enabled  Not Active  Not Active  ≥= 11.00 or ≥= 6.41  = run  = 0 (1 indicates enabled)  = Active > 11.00	Diagnostic runs in 12.5 ms loop	Type C, No MIL

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Network Management is not active for  U0104  Cruise Control Module	> 0.4000 seconds  Not Active on Current Key Cycle  is present on the bus		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Anti-Lock Brake System (ABS) Control Module	U0121	This DTC monitors for a loss of communication with the Anti-Lock Brake System (ABS) Control Module (Non-OBD Module ID 243).	Message is not received from controller for Message \$0C1 Message \$0C5 Message \$0D1 Message \$1C6 Message \$1C7 Message \$1E9 Message \$2F1 Message \$2F9	≥ 10.0 seconds ≥ 10.0 seconds ≥ 10.0 seconds ≥ 10.0 seconds ≥ 10.0 seconds ≥ 10.0 seconds ≥ 10.0 seconds ≥ 10.0 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual	Not Active on Current Key Cycle Enabled Not Active Not Active ≥= 11.00 or ≥= 6.41 = run = 0 (1 indicates enabled) = Active > 11.00	Diagnostic runs in 12.5 ms loop	Type C, No MIL "Special Type C"

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Network Management is not active for  U0121  Anti-Lock Brake System Control Module	> 0.4000 seconds  Not Active on Current Key Cycle  is present on the bus		



**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Chassis Control Module A	U012A	This DTC monitors for a loss of communication with the Chassis Control Module A.	Message is not received from controller for  Message \$4DB	≥ 10.0 seconds	General Enable Criteria:  U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Ignition voltage  or >= 6.41  Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line  and Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is	Not Active on Current Key Cycle  Enabled  Not Active  Not Active  >= 11.00  = run  = 0 (1 indicates enabled)  = Active  > 11.00	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					not active for U012A CHCM A	> 0.4000 seconds Not Active on Current Key Cycle is present on the bus		

15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Body Control Module	U0140	This DTC monitors for a loss of communication with the Body Control Module.	Message is not received from controller for		General Enable Criteria:		Diagnostic runs in 12.5 ms loop	Type C, No MIL "Special Type C"
			Message \$0F1	≥ 10.0 seconds	U0073	Not Active on Current Key Cycle		
			Message \$12A	≥ 10.0 seconds	Normal CAN transmission on Bus A	Enabled		
			Message \$1E1	≥ 10.0 seconds	Device Control	Not Active		
			Message \$1F1	≥ 10.0 seconds	High Voltage Virtual Network Management	Not Active		
			Message \$1F3	≥ 10.0 seconds	Ignition Voltage Criteria:			
			Message \$3C9	≥ 10.0 seconds	Ignition voltage	≥ 11.00 or ≥ 6.41		
			Message \$3CB	≥ 10.0 seconds				
			Message \$3F1	≥ 10.0 seconds	Power Mode	= run		
			Message \$451	≥ 10.0 seconds	Off Cycle Enable Criteria:			
			Message \$4D7	≥ 10.0 seconds	KeCAND_b_OffKeyCycle DiagEnbl	= 0 (1 indicates enabled)		
			Message \$4E1	≥ 10.0 seconds	Ignition Accessory Line and Battery Voltage	= Active > 11.00		
Message \$4E9	≥ 10.0 seconds	General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds						
		Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is	> 0.4000 seconds					

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					not active for  U0140  Body Control Module	Not Active on Current Key Cycle  is present on the bus		

### 15 OBDG08A ECM Summary Tables (Initial DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Fuel Pump Driver Control Module	U18A2	This DTC monitors for a loss of communication with the Fuel Pump Driver Control Module on Bus B	<p>Message is not received from controller for</p> <p>Message \$0D5</p> <p>Message \$0D7</p>	<p>≥ 10.0 seconds</p> <p>≥ 10.0 seconds</p>	<p>General Enable Criteria:</p> <p>U0074</p> <p>Normal CAN transmission on Bus B</p> <p>Device Control</p> <p>High Voltage Virtual Network Management</p> <p>Ignition Voltage Criteria:</p> <p>Ignition voltage</p> <p>Power Mode</p> <p>Off Cycle Enable Criteria:</p> <p>KeCAND_b_OffKeyCycle DiagEnbl</p> <p>Ignition Accessory Line and Battery Voltage</p> <p>General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for &gt; 3.0000 seconds</p> <p>Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for</p>	<p>Not Active on Current Key Cycle</p> <p>Enabled</p> <p>Not Active</p> <p>Not Active</p> <p>≥= 11.00 or ≥= 6.41</p> <p>= run</p> <p>= 0 (1 indicates enabled)</p> <p>=Active</p> <p>&gt; 11.00</p> <p>&gt; 0.4000 seconds</p>	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					U18A2  Fuel Pump Driver Control Module	Not Active on Current Key Cycle  is present on the bus		

**15 OBDG08A ECM Summary Tables (Initial DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Pump Driver Control Module Lost Communication with ECM/PCM	U2616	To detect lost serial data communication from the power driver controller to the ECM	Timer - Fuel System Control message CAN \$0D9 not received ( FPPM Received Serial Data Communication Status)	t > 10 s ( Fu Pmp Pwr Mod smart device reports Faulted, Not Faulted or Indeterminate)	a) FPPM configuration KeFRPR_e_ChassisFuel PresSysType b) Fault state determination enabled c) Run_Crank status d) FPPM Control Status Alive Rolling Count result e) FPPM Diagnostic feedback received f) System Voltage	a) == CeFRPR_e_ECM_FPPM _Sys b) == TRUE c) == Active d) == Valid e) == TRUE f) 9v < Sys Voltage > 32v	64 failures / 80 samples  1 sample / 12.5 millisec	Type A, 1 Trips

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 3 Deactivation Solenoid Control Circuit/Open	P3417	Diagnoses cylinder 3 deactivation solenoid control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 k Ω impedance between signal and controller ground	Diagnostic enabled/ disabled  Powertrain Relay Voltage  Engine RPM	Enabled  ≥ 11 volts  ≥ 400 rpm	≥ 20 errors out of 25 samples Performed every 250 msec	Type B, 2 Trips



### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 3 Deactivation Solenoid Control Circuit/Low	P3419	Diagnoses cylinder 3 deactivation solenoid control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)Voltage low during driver off state (indicates an short circuit to Ground)	Open Circuit: ≥ 200 k Ω impedance between signal and controller groundShort to Ground Circuit ≤ 0.5 Ω impedance between signal and controller ground	Diagnostic enabled/ disabled  Powertrain Relay Voltage  Engine RPM	Enabled  ≥ 11 volts  ≥ 400 rpm	≥ 20 errors out of 25 samples Performed every 250 msec	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cylinder 3 Deactivation Solenoid Control Circuit/High	P3420	Diagnoses cylinder 3 deactivation solenoid control low side driver circuit for circuit faults	Voltage low during driver on state (indicates an short to power)	Short to Power $\leq 0.5 \Omega$ impedance between signal and controller power	Diagnostic enabled/ disabled  Powertrain Relay Voltage  Engine RPM	Enabled  $\geq 11$ volts  $\geq 400$ rpm	$\geq 20$ errors out of 25 samples Performed every 250 msec	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Open Circuit - (PFI)	P0201	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples  100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controlle rs P0261 may also set (Injector 1 Short to Ground)

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Open Circuit - (PFI)	P0202	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controlle rs P0264 may also set (Injector 2 Short to Ground)

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Open Circuit - (PFI)	P0203	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controlle rs P0267 may also set (Injector 3 Short to Ground)

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Open Circuit - (PFI)	P0204	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controlle rs P0270 may also set (Injector 4 Short to Ground)

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 Open Circuit - (PFI)	P0205	This DTC Diagnoses Injector 5 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short-to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controllers P0273 may also set (Injector 5 Short to Ground)

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 Open Circuit - (PFI)	P0206	This DTC Diagnoses Injector 6 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controlle rs P0276 may also set (Injector 6 Short to Ground)



### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 Open Circuit - (PFI)	P0207	This DTC Diagnoses Injector 7 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controlle rs P0279 may also set (Injector 7 Short to Ground)

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 8 Open Circuit - (PFI)	P0208	This DTC Diagnoses Injector 8 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controlle rs P0282 may also set (Injector 8 Short to Ground)

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to ground (PFI)	P0261	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controlle rs P0201 may also set (Injector 1 Open Circuit)

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to power (PFI)	P0262	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to ground (PFI)	P0264	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controlle rs P0202 may also set (Injector 2 Open Circuit)

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to power (PFI)	P0265	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to ground (PFI)	P0267	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controlle rs P0203 may also set (Injector 3 Open Circuit)

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to power (PFI)	P0268	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips



### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to ground (PFI)	P0270	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controlle rs P0204 may also set (Injector 4 Open Circuit)

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to power (PFI)	P0271	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 Low side circuit shorted to ground (PFI)	P0273	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controlle rs P0205 may also set (Injector 5 Open Circuit)

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 Low side circuit shorted to power (PFI)	P0274	This DTC Diagnoses Injector 5 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 Low side circuit shorted to ground (PFI)	P0276	This DTC Diagnoses Injector 6 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controlle rs P0206 may also set (Injector 6 Open Circuit)

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 Low side circuit shorted to power (PFI)	P0277	This DTC Diagnoses Injector 6 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 Low side circuit shorted to ground (PFI)	P0279	This DTC Diagnoses Injector 7 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controlle rs P0207 may also set (Injector 7 Open Circuit)

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 Low side circuit shorted to power (PFI)	P0280	This DTC Diagnoses Injector 7 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips



### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 8 Low side circuit shorted to ground (PFI)	P0282	This DTC Diagnoses Injector 8 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips  Note: In certain controlle rs P0208 may also set (Injector 8 Open Circuit)

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 8 Low side circuit shorted to power (PFI)	P0283	This DTC Diagnoses Injector 8 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration  Engine Running	>= 11 Volts >= 5 Seconds  >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Performance  (For use on vehicles with electric transfer pump dual fuel tanks)	P0461	This DTC will detect a fuel sender stuck in range in the primary fuel tank.	<p>***** Fuel Level in Primary and Secondary Tanks Remain in an Unreadable Range too Long *****</p> <p>This subtest is not used</p> <p>If fuel volume in primary tank is and fuel volume in secondary tank is and remains in this condition for</p> <p>OR ***** During Fuel Transfer *****</p> <p>During fuel transfer, when the enable conditions are met, at least 5.0 liters of fuel will be transferred from the secondary tank and 5.0 liters of fuel will be transferred into the primary tank within 300 seconds. There is a short delay of 20 seconds to allow fuel slosh to settle before the fail timer begins. If the secondary tank volume does decrease by the cal amount but the primary volume does not increase</p>	<p>≥ 1,024.0 liters</p> <p>&lt; 0.0 liters</p> <p>124 miles.</p>	<p>Engine Running</p> <p>No active DTCs:</p> <p>Transfer pump is commanded on for the maximum time limit referenced in <b>Transfer Pump Enable Time Table</b> (see Supporting Table)</p> <p>No device control for the transfer pump</p> <p>Fuel Volume in Secondary Tank</p> <p>Vehicle Speed</p>	<p>VehicleSpeedSensor_FA</p> <p>&lt; 136 liters</p> <p>&lt; 0 mph</p>	250 ms / sample	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			by the cal amount after the fail timer has expired, then P0461 sets.  OR ***** Distance Traveled without a Primary Fuel Level Change *****  Delta fuel volume change over an accumulated 72 miles.	< 3 liters				

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Sensor Performance - Single Stage Oil Pump	P0521	Determines if the Engine Oil Pressure (EOP) Sensor is stuck or biased in range	<p><b>Single Stage Oil Pump EOP Sensor Test with Engine Running</b></p> <p>If enabled:</p> <p><u>To fail a currently failing test:</u></p> <p>The filtered, weighted difference between measured EOP and predicted EOP (a function of engine speed and engine oil temp.):</p> <p><u>To pass a currently passing test:</u></p> <p>The filtered, weighted difference between measured EOP and predicted EOP (a function of engine speed and engine oil temp.):</p>	<p>&lt; -43.0 kPa OR &gt; 45.0 kPa</p> <p>&gt; -40.0 kPa AND &lt; 42.0 kPa</p>	<p>Two Stage Oil Pump is Present = FALSE</p> <p>Diagnostic Status</p> <p>Oil Pressure Sensor In Use</p> <p>Quality or weighting factor values less than "1" indicate that we don't have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data. Regions where diagnosis is possible have a quality or weighting factor value that is a function of engine speed, engine oil temperature, predicted oil pressure, and engine load stability.</p> <p><b>(RPM_Weighting_Factor * Oil_Temp_Weighting_Factor * Eng_Load_Stability_Weighting_Factor * Eng_Oil_Pred_Weighting_Factor)</b> with a first order filter coefficient of 0.01</p> <p>(See Details on P0521 Supporting Tables Tab) <b>RPM_Weighting_Factor</b> <b>RPM_Weighting_Factor</b></p>	<p>FALSE</p> <p>Enabled</p> <p>Yes</p> <p>&gt;= 0.30 weighting</p>	Performed every 100 msec	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					_X_Axis Oil_Temp_Weighting_Fa ctor Oil_Temp_Weighting_Fa ctor_Axis Eng_Load_Stability_Wei ghting_Factor Eng_Load_Stability_Wei ghting_Factor_Axis Eng_Oil_Pred_Weightin g_Factor Eng_Oil_Pred_Weightin g_Factor_Axis  No active DTC's	Fault bundles: EngOilPressureSensorCkt FA CrankSensorFA ECT_Sensor_FA MAF_SensorFA IAT_SensorFA		

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Metal Over temperature Active	P1258	The objective of the algorithm is to protect the engine in the event of engine metal overtemperature, mainly due to loss of coolant	Engine Coolant  For a period	>= 129 °C  >= 10 seconds	Engine Run Time  If feature was active and it set the coolant sensor fault then feature will be enabled on coolant sensor fault pending on the next trip.	>= 10 Seconds	Fault present for >= 0 seconds	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Performance  (For use on vehicles with electric transfer pump dual fuel tanks)	P2066	This DTC will detect a fuel sender stuck in range in the secondary fuel tank.	<p>*****</p> <p>Fuel Level in Primary and Secondary Tanks Remains in an Unreadable Range too Long</p> <p>*****</p> <p>This subset is not used</p> <p>If fuel volume in primary tank is and fuel volume in secondary tank is and remains in this condition for</p> <p>OR</p> <p>*****</p> <p>During fuel transfer</p> <p>*****</p> <p>When the enable conditions are met, 5.0 liters of fuel will be transferred from the secondary tank and 5.0 liters of fuel will be transferred into the primary tank within 300 seconds. There is a short delay of 20 seconds to allow fuel slosh to settle before the fail timer begins. If the secondary tank volume does not</p>	<p>≥ 1,024.0 liters</p> <p>&lt; 0.0 liters</p> <p>124 miles</p>	<p>Engine Running</p> <p>No active DTCs:</p> <p>Transfer pump is commanded on for the maximum time limit referenced in <b>Transfer Pump Enable Time Table</b> (see Supporting Table)</p> <p>No device control for the transfer pump</p> <p>Fuel volume in secondary tank</p>	<p>VehicleSpeedSensor_FA</p> <p>&lt; 136 liters</p>	250 ms / sample	Type B, 2 Trips





15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			distance of 103 miles without the secondary fuel level changing by 5 liters, then the sender must be stuck.		Pump On Time	≥ 600 seconds		

**15 OBDG08A ECM Summary Tables (Unique DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Level Sensor 2 Circuit Low Voltage  (For use on vehicles with dual fuel tanks)	P2067	This DTC will detect a fuel sender stuck out of range low in the secondary fuel tank.	Fuel level Sender % of 5V range	< 10 %			100 failures out of 125 samples  100 ms / sample	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Unique DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Level Sensor 2 Circuit High Voltage  (For use on vehicles with dual fuel tanks)	P2068	This DTC will detect a fuel sender stuck out of range low in the secondary fuel tank.	Fuel level Sender % of 5V range	> 60 %			100 failures out of 125 samples  100 ms / sample	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump 2 Relay Control Circuit Open	P2632	Diagnoses the secondary transfer fuel pump relay control high side driver circuit for circuit faults	Voltage high during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Run/Crank Voltage  Engine Speed	Voltage ≥ 11 volts  ≥ 400.00 RPM	20 failures out of 25 samples  250 ms / sample	Type C, No MIL  Not "Special" Type C  Note: In certain controllers P2634 may also set (Fuel Pump 2 Relay Short to Power).

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump 2 Relay Control Circuit Low	P2633	Diagnoses the secondary transfer fuel pump relay control high side driver circuit for circuit faults	Voltage low during driver on state (indicates short to ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage  Engine Speed	Voltage ≥ 11 volts  ≥ 400.00 RPM	20 failures out of 25 samples  250 ms / sample	Type C, No MIL  Not "Special" Type C

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump 2 Relay Control Circuit High	P2634	Diagnoses the secondary transfer fuel pump relay control high side driver circuit for circuit faults	Voltage high during driver off state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Run/Crank Voltage  Engine Speed	Voltage ≥ 11 volts  ≥ 400.00 RPM	20 failures out of 25 samples  250 ms / sample	Type C, No MIL  Not "Special" Type C  Note: In certain controlle rs P2632 may also set (Fuel Pump 2 Relay Open Circuit).

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump 2 Flow Insufficient  (For use on vehicles with electric transfer pump dual fuel tanks)	P2636	This DTC detects if there is insufficient fuel flow from the secondary to the primary tank.	***** During fuel transfer *****  When the enable conditions are met, 5.0 liters of fuel will be transferred from the secondary tank and 5.0 liters of fuel will be transferred into the primary tank within 300 seconds. There is a short delay of 20 seconds to allow fuel slosh to settle before the fail timer begins. If the secondary tank volume does not decrease by the cal amount and the primary volume does not increase by the cal amount after the fail timer has expired, then P2636 sets.  OR ***** Fuel Level in Secondary Tank Remains in an Unreadable Range too Long ***** Secondary fuel volume remains after a delay of 20 seconds to allow fuel slosh to settle.	> 136 liters	Transfer pump is commanded on for the maximum time limit referenced in <b>Transfer Pump Enable Time Table</b> (see Supporting Table)  No device control for the transfer pump  Fuel volume in secondary tank  Vehicle Speed  No active DTCs:  Engine Running    No device control for the transfer pump  Fuel volume in secondary tank Transfer Pump On Time Vehicle Speed  No active DTCs:	< 136 liters  < 0 MPH  VehicleSpeedSensor_FA	Secondary Fuel Transfer Pump on for 300 seconds	Type C, No MIL  Not "Special Type C"



15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Engine Running			

**15 OBDG08A ECM Summary Tables (Unique DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Composition Sensor Circuit Low	P0178	<p>Detects Out of Range Low Frequency Signal</p> <p>The ethanol sensor is designed to measure ethanol concentrations from E0 (50Hz) to E100 (150Hz), with a specified accuracy of 5% ethanol (i.e. 5Hz). Therefore, values less than 45Hz or greater than 155Hz are considered as faults.</p>	Flex Fuel Sensor Output Frequency	< 45 Hertz	Powertrain Relay	> 11.0 Volts	50 failures out of 63 samples 100 ms loop Continuous	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Unique DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Composition Sensor Circuit High	P0179	<p>Detects Out of Range High Frequency Signal</p> <p>The ethanol sensor is designed to measure ethanol concentrations from E0 (50Hz) to E100 (150Hz), with a specified accuracy of 5% ethanol (i.e. 5Hz). Therefore, values less than 45Hz or greater than 155Hz are considered as faults.</p>	Flex Fuel Sensor Output Frequency	> 155 Hertz <= 185	Powertrain Relay	> 11.0 Volts	50 failures out of 63 samples 100 ms loop Continuous	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transfer Case Speed Sensor Output (TCSS)	P2160	No activity in the TCSS Signal circuit	TCSS Raw Speed	≤ 50 RPM	Engine Torque Throttle Position Transmission gear Garage Shift PTO EngineTorqureInaccurate	240.0 ≤ N-M ≤ 8,191.8 20 ≤ % ≤ 99 Not in Park or Neutral Not active Not active Not a hybrid vehicle FALSE	≥ 5.0 sec	Type B, 2 Trips

**15 OBDG08A ECM Summary Tables (Unique DTCs)**

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Transfer Case Speed Sensor Output (TCSS)	P2161	TCSS Circuit Signal Intermittent	TCSS Loop-to-Loop speed decrease OR TCSS Loop-to-Loop speed increase	≥ 475 RPM  ≥ 225 RPM	Engine Speed  TCSS Speed  Transmission gear  Garage Shift  PTO  P2160	≥ 1,000 RPM  > 0  Not in Park or Neutral  Not active  Not active  CrankSensor_FA = FALSE  Not Fault Active	≥ 4.0 sec	Type B, 2 Trips

### 15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Conductivity Out Of Range (water in fuel)	P2269	Detects the presence of High Conductivity Fuel (e.g. water in fuel) via a specific range of sensor frequency. High conductivity in the fuel causes a significant upward shift in the sensor's output frequency.	Flex Fuel Sensor Output Frequency	> 185 Hertz	Powertrain Relay	> 11.0 Volts	50 failures out of 63 samples 100 ms loop Continuous	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Four Wheel Drive Low Switch Circuit	P2771	Fail Case 1: Continuous Open (Stuck Off) in the Four Wheel Drive Low Switch Circuit Fail Case 2: Ground (Stuck On) in the Four Wheel Drive Low Switch Circuit	4WD Low Switch Transfer case gear ratio  4WD Low Switch Transfer case gear ratio	= TRUE ≥ 2.600 and ≤ 2.800  = FALSE ≥ 0.900 and ≤ 1.100	Engine Torque  Engine Speed  Ignition voltage  Throttle position  Transmission Temperature  Engine Run time  Vehicle Speed  TPS_FA VehicleSpeedSensor_FA  EngineTorqureInaccurate  Transmission gear  P0502, P0503, P0722, P0723, P215C, P2160, P2161, U0101  Clutch  Transmission Input Speed Signal	30.0 ≤ N-M ≤ 8,191.8  1,000 ≤ RPM ≤ 5,500  9.0 ≤ Volts ≤ 32.00  3.0 ≤ % ≤ 99.0  -40.0 ≤ °C ≤ 130.0  >= 10.0 Sec  >= 5.00 Mph  False False  FALSE  Not in Park, Reverse, or Neutral  Not Fault Active  Engaged (Manual transmission only)  Valid (Automatic transmission only)	≥ 2.0 sec ≥ 7.0 sec	Type B, 2 Trips

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Transfer Case Control Module	U0102	This DTC monitors for a loss of communication with the transfer case control module	<p>Message is not received from controller for</p> <p>Message \$1CB</p> <p>Message \$1CC</p>	<p>≥ 10.0 seconds</p> <p>≥ 10.0 seconds</p>	<p>General Enable Criteria:</p> <p>U0073</p> <p>Normal CAN transmission on Bus A</p> <p>Device Control</p> <p>High Voltage Virtual Network Management</p> <p>Ignition Voltage Criteria:</p> <p>Ignition voltage</p> <p>Power Mode</p> <p>Off Cycle Enable Criteria:</p> <p>KeCAND_b_OffKeyCycle DiagEnbl</p> <p>Ignition Accessory Line and Battery Voltage</p> <p>General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for &gt; 3.0000 seconds</p> <p>Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is</p>	<p>Not Active on Current Key Cycle</p> <p>Enabled</p> <p>Not Active</p> <p>Not Active</p> <p>≥= 11.00 or ≥= 6.41</p> <p>= run</p> <p>= 0 (1 indicates enabled)</p> <p>= Active</p> <p>&gt; 11.00</p>	Diagnostic runs in 12.5 ms loop	Type C, No MIL



15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					not active for  U0102  TCCM	> 0.4000 seconds  Not Active on Current Key Cycle  is present on the bus		

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 1	P0420	<p>NOTE: The information contained below applies to applications that use the Idle Catalyst Monitor Algorithm</p> <p>The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (i.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (i.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Lean and Rich A/F excursions</p> <p>Normalized Ratio OSC Value Calculation Information and Definitions =                      1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time)                      2. BestFailing OSC value from a calibration table (based on temp and exhaust gas flow)</p>	Normalized Ratio OSC Value (EWMA filtered)	< 0.35	<p>There must be a valid idle period. The criteria are:</p> <p>Driver must be off the accel pedal. This checks that the final accel pedal position (comprehending deadband and hysteresis) is essentially zero.</p> <p>Idle Speed Control System Is Active</p> <p>Vehicle Speed</p> <p>Engine speed</p> <p>Engine run time</p> <p>Tests attempted this trip</p> <p>The catalyst diagnostic has not yet completed for the current trip.</p> <p>Catalyst Idle Conditions Met Criteria is satisfied which includes the General Enable met and the Valid Idle Period</p>	<p>&lt; 1.24 MPH</p> <p>&gt; 975 RPM for a minimum of 20 seconds since end of last idle period.</p> <p>&gt;  <b>CatmonMinEngineRunTimeToEnable</b>                      This is a function of Coolant Temperature, please see "Supporting Tables" for details.</p> <p>&lt; 255</p>	<p>1 test attempted per valid idle period</p> <p>Minimum of 1 test per trip</p> <p>Maximum of 8 tests per trip</p> <p>Frequency: Fueling Related : 12.5 ms</p> <p>OSC Measurements: 100 ms</p> <p>Temp Prediction: 12.5ms</p>	Type A, 1 Trips

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>3. WorstPassing OSC value (based on temp and exhaust gas flow)</p> <p>Normalized Ratio Calculation = (1-2) / (3-2)</p> <p>A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part. The Catalyst Monitoring Test is done during idle. Several conditions must be meet in order to execute this test. These conditions and their related values are listed in the secondary parameters area of this document.</p> <p>Refer to the <b>P0420_WorstPassing OSCTableB1</b> and <b>P0420_BestFailingOSCTableB1</b> table in the <b>Supporting Tables</b> tab for details</p>			<p>Criteria met, as well as:</p> <p>Green Converter Delay</p> <p>Induction Air</p> <p>Intrusive test(s): Fueltrim Post O2 EVAP EGROther vehicle functions:</p> <p>Power Take Off RunCrank Voltage Ethanol Estimation</p> <p>ECT</p> <p>Barometric Pressure</p> <p>Idle Time before going intrusive is</p> <p>Idle time is incremented if Vehicle speed</p> <p>Short Term Fuel Trim</p>	<p>Not Active</p> <p>&gt; -20 ° C &lt; 250 ° C</p> <p>Not Active</p> <p>Not Active &gt; 10.90 Volts NOT in Progress</p> <p>&gt; 40 ° C &lt; 129 ° C</p> <p>&gt; 70 KPA</p> <p>&lt; 50 Seconds</p> <p>&lt; 1.24 MPH and the drivers foot is off accel pedal and the idle speed control system is active as identified in the Valid Idle Period Criteria section.</p> <p>&gt; 0.90 &lt; 1.21</p>		

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Predicted catalyst temp AND Engine Airflow</p> <p>for at least</p> <p>with a closed throttle time</p> <p>Also, in order to increment the WarmedUpEvents counter, either the vehicle speed must exceed the vehicle speed cal or the driver must NOT be off the accel pedal as stated in the Valid Idle Period Criteria section above.</p>	<p>&gt; 420.00 degC</p> <p>&gt; <b>CatmonMinAirflowForWarmCatalystDetermination</b> table (g/s) (refer to "Supporting Tables" tab) (Based on engine coolant at the time the WarmedUpEvents counter resets to 0.)</p> <p>30 seconds</p> <p>&lt; 180 seconds consecutively (closed throttle consideration involves having the driver off the accel pedal as stated in the Valid Idle Period Criteria Section) .</p>		

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Closed loop fueling (Please see "Closed Loop Enable Criteria" section of the "Supporting Tables" tab for details.)</p> <p>PRNDL</p> <p>Idle Stable Criteria:</p> <p>MAF</p> <p>Predicted catalyst temperature</p> <p>Engine Fueling Criteria at Beginning of Idle Period The following fueling related must also be met from between 4 and 7 seconds after the Catalyst Idle Conditions Met Criteria has been met for at least 4 seconds prior to allowing intrusive control:</p> <p>Number of pre-O2 switches</p> <p>Short Term Fuel Trim Avg</p> <p>Rapid Step Response</p>	<p>Enabled in Drive Range on an Auto Transmission vehicle.</p> <p>Must hold true from after Catalyst Idle Conditions Met to the end of test</p> <p>&gt; 4.00 g/s &lt; 20.00 g/s</p> <p>&lt; 850 degC</p> <p>&gt;= 2</p> <p>&gt; 0.96 &lt; 1.04</p>		

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>(RSR) feature will initiate multiple tests:</p> <p>If the difference between current EWMA value and the current OSC Normalized Ratio value is</p> <p>and the current OSC Normalized Ratio value is</p> <p>Maximum RSR tests to detect failure when RSR is enabled.</p> <p>The diagnostic will not be enabled until the following has been met:</p> <p>PTO</p> <p>General Enable DTC's Not Set</p>	<p>&gt; 0.62</p> <p>&lt; 0.10</p> <p>24</p> <p>Not Active</p> <p>MAF_SensorFA MAF_SensorTFTKO AmbPresDfIttdStatus IAT_SensorCircuitFA IAT_SensorCircuitTFTKO ECT_Sensor_FA O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_2_FA FuelTrimSystemB1_FA FuelTrimSystemB1_TFTKO</p>		

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						FuelTrimSystemB2_FA FuelTrimSystemB2_TFTK O EngineMisfireDetected_FA EvapPurgeSolenoidCircuit_FA IAC_SystemRPM_FA EGRValvePerformance_FA EGRValveCircuit_FA CamSensorAnyLocationFA CrankSensorFA TPS_Performance_FA EnginePowerLimited		

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 2	P0430	<p>Note: The information below applies to applications that use the Idle Catalyst Monitor Algorithm</p> <p>The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (I.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Lean and Rich A/F excursions</p> <p>Normalized Ratio OSC Value Calculation Information and Definitions =</p> <ol style="list-style-type: none"> <li>1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time)</li> <li>2. BestFailing OSC value from a calibration table (based on temp and exhaust gas flow)</li> <li>3. WorstPassing OSC</li> </ol>	Normalized Ratio OSC Value (EWMA filtered)	< 0.35	<p>There must be a valid idle period. The criteria are:</p> <p>Driver must be off the accel pedal. This checks that the final accel pedal position (comprehending deadband and hysteresis) is essentially zero.</p> <p>Idle Speed Control System Is Active</p> <p>Vehicle Speed</p> <p>Engine speed</p> <p>Engine run time</p> <p>Tests attempted this trip</p> <p>The catalyst diagnostic has not yet completed for the current trip.</p> <p>Catalyst Idle Conditions Met Criteria is satisfied which includes the General Enable met and</p>	<p>&lt; 1.24 MPH</p> <p>&gt; 975 RPM for a minimum of 20 seconds since end of last idle period.</p> <p>&gt;</p> <p><b>CatmonMinEngineRunTimeToEnable</b> This is a function of Coolant Temperature, please see "Supporting Tables" for details.</p> <p>&lt; 255</p>	<p>1 test attempted per valid idle period</p> <p>Minimum of 1 test per trip</p> <p>Maximum of 8 tests per trip</p> <p>Frequency: Fueling Related : 12.5 ms</p> <p>OSC Measurements: 100 ms</p> <p>Temp Prediction: 12.5ms</p>	Type A, 1 Trips



15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>value (based on temp and exhaust gas flow)</p> <p>Normalized Ratio Calculation = (1-2) / (3-2)</p> <p>A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part. The Catalyst Monitoring Test is done during idle. Several conditions must be met in order to execute this test. These conditions and their related values are listed in the secondary parameters area of this document.</p> <p>Refer to the <b>P0430_WorstPassing OSCTableB2</b> and <b>P0430_BestFailingOSCTableB2</b> table in the <b>Supporting Tablestab</b> for details</p>			<p>the Valid Idle Period Criteria met, as well as:</p> <p>Green Converter Delay</p> <p>Induction Air</p> <p>Intrusive test(s): Fueltrim Post O2 EVAP EGROther vehicle functions:</p> <p>Power Take Off RunCrank Voltage Ethanol Estimation</p> <p>ECT</p> <p>Barometric Pressure</p> <p>Idle Time before going intrusive is</p> <p>Idle time is incremented if Vehicle speed</p> <p>Short Term Fuel Trim</p>	<p>Not Active</p> <p>&gt; -20 ° C &lt; 250 ° C</p> <p>Not Active</p> <p>Not Active &gt; 10.90 Volts NOT in Progress</p> <p>&gt; 40 ° C &lt; 129 ° C</p> <p>&gt; 70 KPA</p> <p>&lt; 50 Seconds</p> <p>&lt; 1.24 MPH and the drivers foot is off accel pedal and the idle speed control system is active as identified in the Valid Idle Period Criteria section.</p> <p>&gt; 0.90 &lt; 1.21</p>		

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Predicted catalyst temp AND Engine Airflow</p> <p>for at least with a closed throttle time</p> <p>Also, in order to increment the WarmedUpEvents counter, either the vehicle speed must exceed the vehicle speed cal or the driver must NOT be off the accel pedal as stated in the Valid Idle Period Criteria section above.</p> <p>Closed loop fueling (Please see "Closed Loop Enable Criteria" section of</p>	<p>&gt; 420.00 degC</p> <p>&gt; <b>CatmonMinAirflowForWarmCatalystDetermination</b></p> <p>table (g/s) (refer to "Supporting Tables" tab) (Based on engine coolant at the time the WarmedUpEvents counter resets to 0.)</p> <p>30 seconds</p> <p>&lt; 180 seconds consecutively (closed throttle consideration involves having the driver off the accel pedal as stated in the Valid Idle Period Criteria Section) .</p>		

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>the "Supporting Tables" tab for details.)</p> <p>PRNDL</p> <p>Idle Stable Criteria:</p> <p>MAF</p> <p>Predicted catalyst temperature</p> <p>Engine Fueling Criteria at Beginning of Idle Period The following fueling related must also be met from between 4 and 7 seconds after the Catalyst Idle Conditions Met Criteria has been met for at least 4 seconds prior to allowing intrusive control:</p> <p>Number of pre-O2 switches</p> <p>Short Term Fuel Trim Avg</p> <p>Rapid Step Response (RSR) feature will initiate multiple tests:</p>	<p>Enabled in Drive Range on an Auto Transmission vehicle.</p> <p>Must hold true from after Catalyst Idle Conditions Met to the end of test</p> <p>&gt; 4.00 g/s &lt; 20.00 g/s</p> <p>&lt; 850 degC</p> <p>&gt;= 2</p> <p>&gt; 0.96 &lt; 1.04</p>		

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If the difference between current EWMA value and the current OSC Normalized Ratio value is  and the current OSC Normalized Ratio value is  Maximum RSR tests to detect failure when RSR is enabled.  PTO  General Enable DTC's Not Set	> 0.62  < 0.10  24  Not Active  MAF_SensorFA MAF_SensorTFTKO AmbPresDfstdStatus IAT_SensorCircuitFA IAT_SensorCircuitTFTKO ECT_Sensor_FA O2S_Bank_1_Sensor_1_ FA O2S_Bank_1_Sensor_2_ FA O2S_Bank_2_Sensor_1_ FA O2S_Bank_2_Sensor_2_ FA FuelTrimSystemB1_FA FuelTrimSystemB1_TFTK O FuelTrimSystemB2_FA FuelTrimSystemB2_TFTK O EngineMisfireDetected_F A EvapPurgeSolenoidCircuit FA		

15 OBDG08A ECM Summary Tables (Unique DTCs)

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						IAC_SystemRPM_FA EGRValvePerformance_FA EGRValveCircuit_FA CamSensorAnyLocationFA CrankSensorFA TPS_Performance_FA EnginePowerLimited		

Closed Loop Enable Clarification: Calibration values are in the Supporting Tables

Engine run time greater than  
**KtFSTA\_t\_ClosedLoopAutostart (HYBRID ONLY)**  
     AutoStart CoolantX1      X2      X3      X4      X5      X6      X7      X8      X9      X10      X11  
     Close Loop Enable TimeY1      Y2      Y3      Y4      Y5      Y6      Y7      Y8      Y9      Y10      Y11  
 and  
**KtFSTA\_t\_ClosedLoopTime**  
     Start-Up CoolantX1      X2      X3      X4      X5      X6      X7      X8      X9      X10      X11  
     Close Loop Enable TimeY1      Y2      Y3      Y4      Y5      Y6      Y7      Y8      Y9      Y10      Y11  
 and pre converter O2 sensor voltage less  
 than  
**KfFULC\_U\_O2\_SensorReadyThrsh**  
 Lo  
     Voltage < XXXXmilliVolts  
 for  
**KcFULC\_O2\_SensorReadyEvents**  
     Time (events \* 12.5 milliseconds) > XXXXevents  
 and  
**COSC (Converter Oxygen Storage Control) not  
 enabled**  
 and  
**Consumed AirFuel Ratio is stoichiometry i.e. not in component  
 protection**  
 and  
**POPD or Catalyst Diagnostic not intrusive**  
 and  
**Turbo Scavenging Mode not  
 enabled**  
 and  
**All cylinders whose valves are active also have their injectors  
 enabled**  
 and  
**O2S\_Bank\_1\_TFTKO, O2S\_Bank\_2\_TFTKO, FuelInjectorCircuit\_FA and  
 CylinderDeacDriverTFTKO = False**

Long Term FT Enable Criteria

Closed Loop Enable Clarification: Calibration values are in the Supporting Tables

Closed Loop Enable and  
Coolant greater than  
KfFCLL\_T\_AdaptiveLoCoolant

Coolant > XXXXCelcius

or less than  
KfFCLL\_T\_AdaptiveHiCoolant

Coolant < XXXXCelcius

and  
KtFCLL\_p\_AdaptiveLowMAP\_Limit

Barometric Pressure	X1	X2	X3	X4	X5	X6	X7	X8	X9
Manifold Air Pressure	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9

and  
TPS\_ThrottleAuthorityDefaulted =  
False

and  
Flex Fuel Estimate Algorithm is not active

and  
Excessive fuel vapors boiling off from the engine oil algorithm (BOFR) is not  
enabled

and  
Catalyst or EVAP large leak test not  
intrusive

Secondary Fuel Trim Enable  
Criteria

Closed Loop Enable and  
KfFCLP\_U\_O2ReadyThrshLo

Voltage < XXXXmilliVolts

for  
KcFCLP\_Cnt\_O2RdyCyclesThrsh

Time (events \* 12.5 milliseconds) > XXXXevents

Long Term Secondary Fuel Trim  
Enable Criteria

KtFCLP\_t\_PostIntgIDisableTime

**Closed Loop Enable Clarification: Calibration values are in the Supporting Tables**

Start-Up Coolant	X1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Post Integral Enable Time	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11

Plus

**KtFCLP\_t\_PostIntgIRampInTime**

Start-Up Coolant	X1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Post Integral Ramp In Time	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11

and

**KeFCLP\_T\_IntegrationCatalystMax**

Modeled Catalyst Temperature < XXXXXCelcius

and

**KeFCLP\_T\_IntegrationCatalystMin**

Modeled Catalyst Temperature > XXXXXCelcius

and

**PO2S\_Bank\_1\_Snsr\_2\_FA and  
PO2S\_Bank\_2\_Snsr\_2\_FA = False**

and

**(KeFCLP\_Pct\_CatAccuSlphrPostDsbl**

**Modeled converter sulfur percent < XXXX Percent**

and

**Post Integral < KaFCLP\_U\_SlphrIntgIOfst\_Thrsh)**

**X axis: Post O2 Sensor**

**Y axis: Post O2 Mode**

**Z: Post Integral threshold**



**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - Multiple DTC Use\_Green Sensor Delay Criteria - Airflow**

**Description:** This Calibration is the airflow (in gps) above which the green airflow is accumulated to expire the condition.

**Notes:** Used for: P0133, P013A, P013B, P013C, P013D, P013E, P013F, P014A, P014B, P0153, P015A, P015B, P015C, P015D, P1133, P1153, P2270, P2271, P2272 and P2273. The specific diagnostic (from summary table) will not be enabled until the next ignition cycle after the airflow criteria below (by sensor location) has been met:

y/x	1
1	22

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - Multiple DTC Use\_Green Sensor Delay Criteria - Limit**

**Description:** This Calibration is the accumulated airflow (in grams) limit above which the green condition is expired

**Notes:** Used for: P0133, P013A, P013B, P013C, P013D, P013E, P013F, P014A, P014B, P0153, P015A, P015B, P015C, P015D, P1133, P1153, P2270, P2271, P2272 and P2273. Note: This feature is only enabled when the vehicle is new and cannot be enabled in service

y/x	CiOXYR_O2_Bank1_Sensor1	CiOXYR_O2_Bank1_Sensor2	CiOXYR_O2_Bank2_Sensor1	CiOXYR_O2_Bank2_Sensor2
1	120,000	120,000	120,000	120,000

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0016\_P0017\_P0018\_P0019 Cam Correlation Oil Temperature Threshold

**Description:** P0016\_P0017\_P0018\_P0019 Cam Correlation Oil Temperature Threshold

**Notes:** KtEPSI\_t\_RtnHomeDlyLmt

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	300.0	300.0	160.0	18.0	18.0	18.0	18.0	10.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0071\_OAT\_Performance\_Drive\_Equilibrium\_Engine\_Off

**Description:** OAT Performance Diagnostic counter increment for determining OAT-IAT equilibrium for engine off (for hybrid applications)

**Notes:**

y/x	0.0	20.0	30.0	45.0	60.0	75.0	90.0	105.0	120.0
1.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0	8.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0071\_OAT\_Performance\_Drive\_Equilibrium\_Engine\_Running

**Description:** OAT Performance Diagnostic counter increment for determining OAT-IAT equilibrium for engine running

**Notes:**

y/x	0.0	20.0	30.0	45.0	60.0	75.0	90.0	105.0	120.0
0.0	1.0	5.0	7.0	7.5	8.0	9.0	9.0	9.0	9.0
15.0	-5.0	1.0	2.0	2.5	3.0	3.5	4.0	4.5	5.0
25.0	-4.0	1.0	2.0	2.5	3.0	3.5	4.0	4.5	5.0
35.0	-2.0	1.0	2.0	2.5	3.0	3.5	4.0	4.5	5.0
45.0	-1.0	2.0	3.0	3.5	4.0	4.5	5.0	5.5	6.0
55.0	0.0	2.0	3.0	3.5	4.0	4.5	5.0	5.5	6.0
65.0	0.0	3.0	4.0	4.5	5.0	5.5	6.0	6.5	7.0
75.0	0.0	4.0	5.0	5.5	6.0	6.5	7.0	7.5	8.0
85.0	1.0	5.0	6.0	6.5	7.0	7.5	8.0	8.5	9.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial table - P0101\_P0106\_P010B\_P0121\_P0236\_P1101 Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

**Description:** Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

**Notes:** This table describes combinations of individual model failures that will set P0101, P0106, P010B, P0121, P0236 and P1101 on turbocharged applications.

y/x	1	2	3	4	5	6	7	8	9
1	MAF Model	MAP1 Model	MAP2 Model	MAP3 Model	TIAP1 Model	TPS Model	TIAP Correlation	TIAP Correlation	DTC Set
2	Failed	Failed	Failed	Failed	Failed	Failed	Failed	Valid	
3	F	F	F	F	F	F	F	F	No DTC
4	F	F	F	F	F	F	F	T	No DTC
5	F	F	F	F	F	F	T	F	No DTC
6	F	F	F	F	F	F	T	T	No DTC
7	F	F	F	F	F	T	F	F	No DTC
8	F	F	F	F	F	T	F	T	No DTC
9	F	F	F	F	F	T	T	F	No DTC
10	F	F	F	F	F	T	T	T	No DTC
11	F	F	F	F	T	F	F	F	No DTC
12	F	F	F	F	T	F	F	T	No DTC
13	F	F	F	F	T	F	T	F	No DTC
14	F	F	F	F	T	F	T	T	No DTC
15	F	F	F	F	T	T	F	F	P1101
16	F	F	F	F	T	T	F	T	P0121
17	F	F	F	F	T	T	T	F	P1101
18	F	F	F	F	T	T	T	T	P0236
19	F	F	F	T	F	F	F	F	P1101
20	F	F	F	T	F	F	F	T	P1101
21	F	F	F	T	F	F	T	F	P1101
22	F	F	F	T	F	F	T	T	P1101
23	F	F	F	T	F	T	F	F	P1101
24	F	F	F	T	F	T	F	T	P1101
25	F	F	F	T	F	T	T	F	P1101
26	F	F	F	T	F	T	T	T	P1101
27	F	F	F	T	T	F	F	F	P1101
28	F	F	F	T	T	F	F	T	P1101
29	F	F	F	T	T	F	T	F	P1101
30	F	F	F	T	T	F	T	T	P1101
31	F	F	F	T	T	T	F	F	P1101
32	F	F	F	T	T	T	F	T	P1101
33	F	F	F	T	T	T	T	F	P1101
34	F	F	F	T	T	T	T	T	P1101

15 OBDG08A ECM Diagnostic Supporting Tables

Initial table - P0101\_P0106\_P010B\_P0121\_P0236\_P1101 Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

35	F	F	T	F	F	F	F	F	P1101
36	F	F	T	F	F	F	F	T	P1101
37	F	F	T	F	F	F	T	F	P1101
38	F	F	T	F	F	F	T	T	P1101
39	F	F	T	F	F	T	F	F	P1101
40	F	F	T	F	F	T	F	T	P1101
41	F	F	T	F	F	T	T	F	P1101
42	F	F	T	F	F	T	T	T	P1101
43	F	F	T	F	T	F	F	F	P1101
44	F	F	T	F	T	F	F	T	P1101
45	F	F	T	F	T	F	T	F	P1101
46	F	F	T	F	T	F	T	T	P1101
47	F	F	T	F	T	T	F	F	P1101
48	F	F	T	F	T	T	F	T	P1101
49	F	F	T	F	T	T	T	F	P1101
50	F	F	T	F	T	T	T	T	P1101
51	F	F	T	T	F	F	F	F	P1101
52	F	F	T	T	F	F	F	T	P1101
53	F	F	T	T	F	F	T	F	P1101
54	F	F	T	T	F	F	T	T	P1101
55	F	F	T	T	F	T	F	F	P1101
56	F	F	T	T	F	T	F	T	P1101
57	F	F	T	T	F	T	T	F	P1101
58	F	F	T	T	F	T	T	T	P1101
59	F	F	T	T	T	F	F	F	No DTC
60	F	F	T	T	T	F	F	T	No DTC
61	F	F	T	T	T	F	T	F	No DTC
62	F	F	T	T	T	F	T	T	No DTC
63	F	F	T	T	T	T	F	F	P1101
64	F	F	T	T	T	T	F	T	P1101
65	F	F	T	T	T	T	T	F	P1101
66	F	F	T	T	T	T	T	T	P1101
67	F	T	F	F	F	F	F	F	P1101
68	F	T	F	F	F	F	F	T	P1101
69	F	T	F	F	F	F	T	F	P1101
70	F	T	F	F	F	F	T	T	P0236
71	F	T	F	F	F	T	F	F	P1101
72	F	T	F	F	F	T	F	T	P0121

15 OBDG08A ECM Diagnostic Supporting Tables

Initial table - P0101\_P0106\_P010B\_P0121\_P0236\_P1101 Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

73	F	T	F	F	F	T	T	F	P1101
74	F	T	F	F	F	T	T	T	P0236
75	F	T	F	F	T	F	F	F	P1101
76	F	T	F	F	T	F	F	T	P1101
77	F	T	F	F	T	F	T	F	P1101
78	F	T	F	F	T	F	T	T	P0236
79	F	T	F	F	T	T	F	F	P1101
80	F	T	F	F	T	T	F	T	P0121
81	F	T	F	F	T	T	T	F	P1101
82	F	T	F	F	T	T	T	T	P0236
83	F	T	F	T	F	F	F	F	P1101
84	F	T	F	T	F	F	F	T	P1101
85	F	T	F	T	F	F	T	F	P1101
86	F	T	F	T	F	F	T	T	P1101
87	F	T	F	T	F	T	F	F	P1101
88	F	T	F	T	F	T	F	T	P1101
89	F	T	F	T	F	T	T	F	P1101
90	F	T	F	T	F	T	T	T	P1101
91	F	T	F	T	T	F	F	F	P1101
92	F	T	F	T	T	F	F	T	P1101
93	F	T	F	T	T	F	T	F	P1101
94	F	T	F	T	T	F	T	T	P1101
95	F	T	F	T	T	T	F	F	P1101
96	F	T	F	T	T	T	F	T	P1101
97	F	T	F	T	T	T	T	F	P1101
98	F	T	F	T	T	T	T	T	P1101
99	F	T	T	F	F	F	F	F	P1101
100	F	T	T	F	F	F	F	T	P1101
101	F	T	T	F	F	F	T	F	P1101
102	F	T	T	F	F	F	T	T	P1101
103	F	T	T	F	F	T	F	F	P1101
104	F	T	T	F	F	T	F	T	P1101
105	F	T	T	F	F	T	T	F	P1101
106	F	T	T	F	F	T	T	T	P1101
107	F	T	T	F	T	F	F	F	P1101
108	F	T	T	F	T	F	F	T	P1101
109	F	T	T	F	T	F	T	F	P1101
110	F	T	T	F	T	F	T	T	P1101



15 OBDG08A ECM Diagnostic Supporting Tables

Initial table - P0101\_P0106\_P010B\_P0121\_P0236\_P1101 Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

111	F	T	T	F	T	T	F	F	P1101
112	F	T	T	F	T	T	F	T	P1101
113	F	T	T	F	T	T	T	F	P1101
114	F	T	T	F	T	T	T	T	P1101
115	F	T	T	T	F	F	F	F	P0106
116	F	T	T	T	F	F	F	T	P0106
117	F	T	T	T	F	F	T	F	P0106
118	F	T	T	T	F	F	T	T	P0106
119	F	T	T	T	F	T	F	F	P1101
120	F	T	T	T	F	T	F	T	P1101
121	F	T	T	T	F	T	T	F	P1101
122	F	T	T	T	F	T	T	T	P1101
123	F	T	T	T	T	F	F	F	P1101
124	F	T	T	T	T	F	F	T	P1101
125	F	T	T	T	T	F	T	F	P1101
126	F	T	T	T	T	F	T	T	P1101
127	F	T	T	T	T	T	F	F	P1101
128	F	T	T	T	T	T	F	T	P1101
129	F	T	T	T	T	T	T	F	P1101
130	F	T	T	T	T	T	T	T	P1101
131	T	F	F	F	F	F	F	F	P1101
132	T	F	F	F	F	F	F	T	P1101
133	T	F	F	F	F	F	T	F	P1101
134	T	F	F	F	F	F	T	T	P0236
135	T	F	F	F	F	T	F	F	P1101
136	T	F	F	F	F	T	F	T	P0121
137	T	F	F	F	F	T	T	F	P1101
138	T	F	F	F	F	T	T	T	P0236
139	T	F	F	F	T	F	F	F	P1101
140	T	F	F	F	T	F	F	T	P1101
141	T	F	F	F	T	F	T	F	P1101
142	T	F	F	F	T	F	T	T	P0236
143	T	F	F	F	T	T	F	F	P1101
144	T	F	F	F	T	T	F	T	P0121
145	T	F	F	F	T	T	T	F	P1101
146	T	F	F	F	T	T	T	T	P0236
147	T	F	F	T	F	F	F	F	P1101
148	T	F	F	T	F	F	F	T	P1101

15 OBDG08A ECM Diagnostic Supporting Tables

Initial table - P0101\_P0106\_P010B\_P0121\_P0236\_P1101 Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

149	T	F	F	T	F	F	T	F	P1101
150	T	F	F	T	F	F	T	T	P1101
151	T	F	F	T	F	T	F	F	P1101
152	T	F	F	T	F	T	F	T	P1101
153	T	F	F	T	F	T	T	F	P1101
154	T	F	F	T	F	T	T	T	P1101
155	T	F	F	T	T	F	F	F	P1101
156	T	F	F	T	T	F	F	T	P1101
157	T	F	F	T	T	F	T	F	P1101
158	T	F	F	T	T	F	T	T	P1101
159	T	F	F	T	T	T	F	F	P1101
160	T	F	F	T	T	T	F	T	P1101
161	T	F	F	T	T	T	T	F	P1101
162	T	F	F	T	T	T	T	T	P1101
163	T	F	T	F	F	F	F	F	P1101
164	T	F	T	F	F	F	F	T	P1101
165	T	F	T	F	F	F	T	F	P1101
166	T	F	T	F	F	F	T	T	P1101
167	T	F	T	F	F	T	F	F	P1101
168	T	F	T	F	F	T	F	T	P1101
169	T	F	T	F	F	T	T	F	P1101
170	T	F	T	F	F	T	T	T	P1101
171	T	F	T	F	T	F	F	F	P1101
172	T	F	T	F	T	F	F	T	P1101
173	T	F	T	F	T	F	T	F	P1101
174	T	F	T	F	T	F	T	T	P1101
175	T	F	T	F	T	T	F	F	P1101
176	T	F	T	F	T	T	F	T	P1101
177	T	F	T	F	T	T	T	F	P1101
178	T	F	T	F	T	T	T	T	P1101
179	T	F	T	T	F	F	F	F	P1101
180	T	F	T	T	F	F	F	T	P1101
181	T	F	T	T	F	F	T	F	P1101
182	T	F	T	T	F	F	T	T	P1101
183	T	F	T	T	F	T	F	F	P1101
184	T	F	T	T	F	T	F	T	P1101
185	T	F	T	T	F	T	T	F	P1101
186	T	F	T	T	F	T	T	T	P1101

15 OBDG08A ECM Diagnostic Supporting Tables

Initial table - P0101\_P0106\_P010B\_P0121\_P0236\_P1101 Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

187	T	F	T	T	T	F	F	F	P0101 or P010B
188	T	F	T	T	T	F	F	T	P0101 or P010B
189	T	F	T	T	T	F	T	F	P0101 or P010B
190	T	F	T	T	T	F	T	T	P0101 or P010B
191	T	F	T	T	T	T	F	F	P1101
192	T	F	T	T	T	T	F	T	P1101
193	T	F	T	T	T	T	T	F	P1101
194	T	F	T	T	T	T	T	T	P1101
195	T	T	F	F	F	F	F	F	P1101
196	T	T	F	F	F	F	F	T	P1101
197	T	T	F	F	F	F	T	F	P1101
198	T	T	F	F	F	F	T	T	P0236
199	T	T	F	F	F	T	F	F	P1101
200	T	T	F	F	F	T	F	T	P0121
201	T	T	F	F	F	T	T	F	P1101
202	T	T	F	F	F	T	T	T	P0236
203	T	T	F	F	T	F	F	F	P1101
204	T	T	F	F	T	F	F	T	P1101
205	T	T	F	F	T	F	T	F	P1101
206	T	T	F	F	T	F	T	T	P0236
207	T	T	F	F	T	T	F	F	P1101
208	T	T	F	F	T	T	F	T	P0121
209	T	T	F	F	T	T	T	F	P1101
210	T	T	F	F	T	T	T	T	P0236
211	T	T	F	T	F	F	F	F	P1101
212	T	T	F	T	F	F	F	T	P1101
213	T	T	F	T	F	F	T	F	P1101
214	T	T	F	T	F	F	T	T	P1101
215	T	T	F	T	F	T	F	F	P1101
216	T	T	F	T	F	T	F	T	P1101
217	T	T	F	T	F	T	T	F	P1101
218	T	T	F	T	F	T	T	T	P1101
219	T	T	F	T	T	F	F	F	P1101
220	T	T	F	T	T	F	F	T	P1101
221	T	T	F	T	T	F	T	F	P1101
222	T	T	F	T	T	F	T	T	P1101
223	T	T	F	T	T	T	F	F	P1101
224	T	T	F	T	T	T	F	T	P1101

15 OBDG08A ECM Diagnostic Supporting Tables

Initial table - P0101\_P0106\_P010B\_P0121\_P0236\_P1101 Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

225	T	T	F	T	T	T	T	F	P1101
226	T	T	F	T	T	T	T	T	P1101
227	T	T	T	F	F	F	F	F	P1101
228	T	T	T	F	F	F	F	T	P1101
229	T	T	T	F	F	F	T	F	P1101
230	T	T	T	F	F	F	T	T	P1101
231	T	T	T	F	F	T	F	F	P1101
232	T	T	T	F	F	T	F	T	P1101
233	T	T	T	F	F	T	T	F	P1101
234	T	T	T	F	F	T	T	T	P1101
235	T	T	T	F	T	F	F	F	P1101
236	T	T	T	F	T	F	F	T	P1101
237	T	T	T	F	T	F	T	F	P1101
238	T	T	T	F	T	F	T	T	P1101
239	T	T	T	F	T	T	F	F	P1101
240	T	T	T	F	T	T	F	T	P1101
241	T	T	T	F	T	T	T	F	P1101
242	T	T	T	F	T	T	T	T	P1101
243	T	T	T	T	F	F	F	F	P1101
244	T	T	T	T	F	F	F	T	P1101
245	T	T	T	T	F	F	T	F	P1101
246	T	T	T	T	F	F	T	T	P1101
247	T	T	T	T	F	T	F	F	P1101
248	T	T	T	T	F	T	F	T	P1101
249	T	T	T	T	F	T	T	F	P1101
250	T	T	T	T	F	T	T	T	P1101
251	T	T	T	T	T	F	F	F	P1101
252	T	T	T	T	T	F	F	T	P1101
253	T	T	T	T	T	F	T	F	P1101
254	T	T	T	T	T	F	T	T	P1101
255	T	T	T	T	T	T	F	F	P1101
256	T	T	T	T	T	T	F	T	P1101
257	T	T	T	T	T	T	T	F	P1101
258	T	T	T	T	T	T	T	T	P1101

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP1 Residual Weight Factor based on RPM**

**Description:** P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP1 Residual Weight Factor based on RPM

**Notes:**

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.000

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP2 Residual Weight Factor based on RPM**

**Description:** P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP2 Residual Weight Factor based on RPM

**Notes:**

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.000

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP3 Residual Weight Factor based on RPM

**Description:** P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP3 Residual Weight Factor based on RPM

**Notes:**

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.000

15 OBDG08A ECM Diagnostic Supporting Tables

**Initial Supporting table - P0101\_P0106\_P0121\_P012B\_P0236\_P1101 TPS Residual Weight Factor based on RPM**

**Description:** P0101\_P0106\_P0121\_P012B\_P0236\_P1101 TPS Residual Weight Factor based on RPM

**Notes:**

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.000



15 OBDG08A ECM Diagnostic Supporting Tables

**Initial Supporting table - P0101\_P0106\_P0121\_P012B\_P1101 Boost Residual Weight Factor based on % of Boost**

**Description:** P0101\_P0106\_P0121\_P012B\_P1101 Boost Residual Weight Factor based on % of Boost

**Notes:**

y/x	0	0	0	0	0	0	0	0	0	1	1	1	1	1	1	1	1
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0101\_P0106\_P0121\_P012B\_P1101 SCiAP1 Residual Weight Factor based on RPM**

**Description:** P0101\_P0106\_P0121\_P012B\_P1101 SCiAP1 Residual Weight Factor based on RPM

**Notes:**

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.000

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0101\_P0106\_P0121\_P012B\_P1101 SCiAP2 Residual Weight Factor based on RPM**

**Description:** P0101\_P0106\_P0121\_P012B\_P1101 SCiAP2 Residual Weight Factor based on RPM

**Notes:**

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.000

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0101\_P0106\_P0121\_P012B\_P1101 Supercharger Intake Flow Rationality Diagnostic Failure Matrix

**Description:** Supercharger Intake Flow Rationality Diagnostic Failure Matrix

**Notes:** This table describes combinations of individual model failures that will set P0101, P0106, P012B, P0121 and P1101 on supercharged applications.

y/x	1	2	3	4	5	6	7
1	TPS Model Failure	MAF Model Failure	MAP1 Model Failure	MAP2 Model Failure	SCIAP1 Model Failure	SCIAP2 Model Failure	DTC Set
2	F	F	F	F	F	F	No DTC
3	F	F	F	F	F	T	No DTC
4	F	F	F	F	T	F	No DTC
5	F	F	F	F	T	T	P012B
6	F	F	F	T	F	F	No DTC
7	F	F	F	T	F	T	P1101
8	F	F	F	T	T	F	P1101
9	F	F	F	T	T	T	P1101
10	F	F	T	F	F	F	No DTC
11	F	F	T	F	F	T	P1101
12	F	F	T	F	T	F	P1101
13	F	F	T	F	T	T	P1101
14	F	F	T	T	F	F	P0106
15	F	F	T	T	F	T	P1101
16	F	F	T	T	T	F	P1101
17	F	F	T	T	T	T	P1101
18	F	T	F	F	F	F	No DTC
19	F	T	F	F	F	T	P0101
20	F	T	F	F	T	F	No DTC
21	F	T	F	F	T	T	P0101 & P012B
22	F	T	F	T	F	F	P1101
23	F	T	F	T	F	T	P0101
24	F	T	F	T	T	F	P1101
25	F	T	F	T	T	T	P0101 & P012B
26	F	T	T	F	F	F	P1101
27	F	T	T	F	F	T	P1101
28	F	T	T	F	T	F	P1101
29	F	T	T	F	T	T	P1101
30	F	T	T	T	F	F	P1101
31	F	T	T	T	F	T	P1101
32	F	T	T	T	T	F	P1101
33	F	T	T	T	T	T	P1101
34	T	F	F	F	F	F	P0121

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0101\_P0106\_P0121\_P012B\_P1101 Supercharger Intake Flow Rationality Diagnostic Failure Matrix

35	T	F	F	F	F	T	No DTC
36	T	F	F	F	T	F	P0121
37	T	F	F	F	T	T	P1101
38	T	F	F	T	F	F	P1101
39	T	F	F	T	F	T	P1101
40	T	F	F	T	T	F	P1101
41	T	F	F	T	T	T	P1101
42	T	F	T	F	F	F	P0121
43	T	F	T	F	F	T	P1101
44	T	F	T	F	T	F	P0121
45	T	F	T	F	T	T	P1101
46	T	F	T	T	F	F	P1101
47	T	F	T	T	F	T	P1101
48	T	F	T	T	T	F	P1101
49	T	F	T	T	T	T	P1101
50	T	T	F	F	F	F	P0121
51	T	T	F	F	F	T	P1101
52	T	T	F	F	T	F	P0121
53	T	T	F	F	T	T	P1101
54	T	T	F	T	F	F	P1101
55	T	T	F	T	F	T	P1101
56	T	T	F	T	T	F	P1101
57	T	T	F	T	T	T	P1101
58	T	T	T	F	F	F	P0121
59	T	T	T	F	F	T	P1101
60	T	T	T	F	T	F	P0121
61	T	T	T	F	T	T	P1101
62	T	T	T	T	F	F	P1101
63	T	T	T	T	F	T	P1101
64	T	T	T	T	T	F	P1101
65	T	T	T	T	T	T	P1101

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0101\_P0106\_P0121\_P0236\_P1101 TIAP Residual Weight Factor based on RPM

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP Residual Weight Factor based on RPM

**Notes:**

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.000

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0101\_P0106\_P0121\_P0236\_P1101 TIAP-Baro Correlation Max Air Flow

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-Baro Correlation Max Air Flow

**Notes:**

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	2.6	3.3	4.5	5.4	7.0	8.8	11.0	12.4	12.4

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0101\_P0106\_P0121\_P0236\_P1101 TIAP-Baro Correlation Max MAP

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-Baro Correlation Max MAP

**Notes:**

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	34.1	27.3	26.1	25.4	25.7	24.1	29.5	29.4	29.4



15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0101\_P0106\_P0121\_P0236\_P1101 TIAP-Baro Correlation Offset

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-Baro Correlation Offset

**Notes:**

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0101\_P0106\_P0121\_P0236\_P1101 TIAP-MAP Correlation Min Air Flow

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-MAP Correlation Min Air Flow

**Notes:**

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	15.0	27.0	32.0	32.0	32.0	32.0	32.0	32.0	32.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0101\_P0106\_P0121\_P0236\_P1101 TIAP-MAP Correlation Min MAP

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-MAP Correlation Min MAP

**Notes:**

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	124.0	126.0	127.0	128.0	129.0	128.0	127.0	127.0	127.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0101\_P0106\_P0121\_P0236\_P1101 TIAP-MAP Correlation Offset

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-MAP Correlation Offset

**Notes:**

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	1.0	1.0	1.0	1.0	2.0	2.0	2.0	3.0	3.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0133\_KnEOSD\_t\_ST\_LRC\_LimRS1

**Description:** KnEOSD\_t\_ST\_LRC\_LimRS1. X Table Axis (in sec) for P0133, L2R Reponse time breakpoints for table

**Notes:**

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.030	0.045	0.060	0.075	0.090	0.105	0.120	0.135	0.150	0.165	0.180	0.195	0.210	0.225	0.240	1.000

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0133\_KnEOSD\_t\_ST\_RLC\_LimRS1

**Description:** KnEOSD\_t\_ST\_RLC\_LimRS1. Y Table Axis (in sec) for P0133, R2L Reponse time breakpoints for table

**Notes:**

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.045	0.060	0.075	0.090	0.105	0.120	0.135	0.150	0.165	0.180	0.195	0.210	0.225	0.240	0.255	1.000

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0133\_O2S Slow Response Bank 1 Sensor 1 "Pass/Fail Threshold table"

Description: KaEOSD\_x\_ST\_ResponseLimRS1[x][y]

Notes: X axis is Lean to Rich response time (in sec), Please see the table below named "KnEOSD\_t\_ST\_LRC\_LimRS1" for the 17 X axis table breakpoints. Y axis is Rich to Lean response time (sec), Please see the cal table below named "KnEOSD\_t\_ST\_RLC\_LimRS1" for the 17 Y axis table breakpoints. Z axis is the pass/fail result, Note: If the cell contains a "0" then the fault is indicated, if it contains a "1" a fault is not indicated.

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0	0
1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
2	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
3	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0
4	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
5	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
6	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
7	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
8	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
9	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
10	0	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
11	0	0	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
12	0	0	0	1	1	1	1	1	1	1	1	1	1	0	0	0	0
13	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
15	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0153\_KnEOSD\_t\_ST\_LRC\_LimRS2

**Description:** KnEOSD\_t\_ST\_LRC\_LimRS2. X Table Axis (in sec) for P0153, L2R Reponse time breakpoints for table

**Notes:**

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.030	0.045	0.060	0.075	0.090	0.105	0.120	0.135	0.150	0.165	0.180	0.195	0.210	0.225	0.240	1.000



**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0153\_KnEOSD\_t\_ST\_RLC\_LimRS2**

**Description:** KnEOSD\_t\_ST\_RLC\_LimRS2. Y Table Axis (in sec) for P0153, R2L Reponse time breakpoints for table

**Notes:**

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.045	0.060	0.075	0.090	0.105	0.120	0.135	0.150	0.165	0.180	0.195	0.210	0.225	0.240	0.255	1.000

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0153\_O2S Slow Response Bank 2 Sensor 1 "Pass/Fail Threshold table"

Description: KaEOSD\_x\_ST\_ResponseLimRS2[x][y]

Notes: X axis is Lean to Rich response time (in sec), Please see the table below named "KnEOSD\_t\_ST\_LRC\_LimRS2" for the 17 X axis table breakpoints. Y axis is Rich to Lean response time (sec), Please see the cal table below named "KnEOSD\_t\_ST\_RLC\_LimRS2" for the 17 Y axis table breakpoints. Z axis is the pass/fail result, Note: If the cell contains a "0" then the fault is indicated, if it contains a "1" a fault is not indicated.

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0	0
1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0	0
2	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
3	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0
4	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
5	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
6	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
7	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
8	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
9	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
10	0	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
11	0	0	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0
12	0	0	0	1	1	1	1	1	1	1	1	1	1	0	0	0	0
13	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
15	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0011\_CamPosErrorLimlc1**

**Description:** P0011 - Cam Position Error Limit for performance diagnostic

**Notes:** KtPHSD\_phi\_CamPosErrorLimlc1

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
1,200	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
1,600	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
2,000	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
2,400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
2,800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
3,200	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
3,600	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
4,000	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
4,400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
4,800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
5,200	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
5,600	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
6,000	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
6,400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
6,800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_EngOilPressEnbllc

**Description:** Delay time before the oil pressure enable flag is set assuming all the oil pressure enable criteria are met

**Notes:** KtPHSC\_t\_EngOilPressEnbllc

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_HiEngSpdHiDsbllc

**Description:** Intake cam is disabled when engine speed exceeds this value

**Notes:** KtPHSC\_n\_HiEngSpdHiDsbllc

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_HiEngSpdLoEnbllc

**Description:** Intake cam is enabled when engine speed remains below this value

**Notes:** KtPHSC\_n\_HiEngSpdLoEnbllc

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_LoPresHiEnblIc

**Description:** Intake cam is enabled when oil pressure exceeds this value

**Notes:** KtPHSC\_p\_LoPresHiEnblEc

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_LoPresLoDsbllc

**Description:** Intake cam is disabled when oil pressure falls below this value

**Notes:** KtPHSC\_p\_LoPresLoDsbllc

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	125	125	125	125	125	125	125	125	125	125	125	125	125	125	125	125	125



15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_LoRpmHiEnbllc

**Description:** Intake cam is enabled when engine speed exceeds this value.

**Notes:** KtPHSC\_n\_LoRpmHiEnbllc

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	900	900	900	900	875	875	875	875	875	875	875	875	950	1,000	1,250	1,400	1,900

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_LoRpmLoDsbllc

**Description:** Intake cam is disabled when engine speed is below this value.

**Notes:** KtPHSC\_n\_LoRpmLoDsbllc

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	800	800	800	800	750	750	750	750	750	750	750	750	750	750	800	800	800

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_P0014\_P0024\_P05CE\_P05CF\_ColdStartEngRunning

**Description:** Engine running time must be greater than this threshold during a cold start to enable cam phasing

**Notes:** KtPHSR\_t\_ColdStartEngRunning

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	15	15	14	13	12	11	10	9	8	7	6	5	4	4	4	4	4

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0011\_P05CC\_StablePositionTimeIc1**

**Description:** P0011 - Delay after transient move

**Notes:** KtPHSD\_t\_StablePositionTimeIc1

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
1,200	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
1,600	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
2,000	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
2,400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
2,800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
3,200	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
3,600	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
4,000	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
4,400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
4,800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
5,200	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
5,600	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
6,000	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
6,400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
6,800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0011\_PerfMaxlc1**

**Description:** P0011 - Range of phaser travel where diagnostic cannot make a decision if both desired & measured positions are greater than

**Notes:**

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
2	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
3	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
4	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
5	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
6	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
7	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
8	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
9	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
10	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
11	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
12	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
13	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
14	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
15	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
16	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
17	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0068\_Delta MAF Threshold f(TPS)

**Description:** Table of delta MAF values as a function of desired throttle position. The output of this table provides a delta MAF that if the measured minus the estimated MAF exceeds, is considered a fail.

**Notes:** P0068, KtTPSD\_dm\_MAF\_DesThrDelt

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	15.98	27.70	38.06	38.24	46.02	54.72	255.00	255.00	255.00

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0068\_Delta MAP Threshold f(TPS)

**Description:** Table of delta MAP values as a function of desired throttle position. The output of this table provides a delta MAP that if the measured minus the estimated MAP exceeds, is considered a fail.

**Notes:** P0068, KtTPSD\_p\_MAP\_DesThrDelt

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	17.38	26.25	26.70	20.46	16.33	17.92	255.00	255.00	255.00

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0068\_Maximum MAF f(RPM)**

**Description:** Table of maximum MAF values vs. engine speed. This is the maximum MAF the engine can see under all ambient conditions.

**Notes:** P0068, KtTPSD\_dm\_MaxMAF\_VsRPM

y/x	600.00	1,400.00	2,200.00	3,000.00	3,800.00	4,600.00	5,400.00	6,200.00	7,000.00
1.00	30.00	68.00	112.00	155.00	207.00	262.00	298.00	305.00	305.00



**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0068\_Maximum MAF f(Volts)**

**Description:** Table of maximum MAF values vs. system voltage. The output of the air meter is clamped to lower values as system voltage drops off.

**Notes:** P0068, KtTPSD\_dm\_MaxMAF\_VsVoltage

y/x	6.00	7.00	8.00	9.00	10.00	11.00	12.00	13.00	14.00
1.00	69.70	180.36	376.20	511.99	511.99	511.99	511.99	511.99	511.99

15 OBDG08A ECM Diagnostic Supporting Tables

**Initial Supporting table - P0101\_P0106\_P010B\_P0121\_P012B\_P0236\_P1101 MAF1 Residual Weight Factor based on MAF Est**

**Description:** P0101\_P0106\_P010B\_P0121\_P012B\_P0236\_P1101 MAF1 Residual Weight Factor based on MAF Est

**Notes:**

y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350
1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0101\_P0106\_P010B\_P0121\_P012B\_P0236\_P1101 MAF1 Residual Weight Factor based on RPM**

**Description:** P0101\_P0106\_P010B\_P0121\_P012B\_P0236\_P1101 MAF1 Residual Weight Factor based on RPM

**Notes:**

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0101\_P0106\_P010B\_P0121\_P0236\_P1101 MAF2 Residual Weight Factor based on MAF Est

**Description:** P0101\_P0106\_P010B\_P0121\_P0236\_P1101 MAF2 Residual Weight Factor based on MAF Est

**Notes:**

y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350
1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0101\_P0106\_P010B\_P0121\_P0236\_P1101 MAF2 Residual Weight Factor based on RPM**

**Description:** P0101\_P0106\_P010B\_P0121\_P0236\_P1101 MAF2 Residual Weight Factor based on RPM

**Notes:**

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0116\_Fail if power up ECT exceeds IAT by these values

**Description:** KtECTD\_T\_HSC\_FastFailTempDiff

**Notes:** X axis is IAT Temperature at Power up (° C), Z axis is the Fast Failure temp difference (° C)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	80	80	80	60	60	40	40	30	30	30	30	30	30	30	30	30	30

15 OBDG08A ECM Diagnostic Supporting Tables

**Initial Supporting table - P0128\_Maximum Accumulated Energy for Start-up ECT conditions - Alternate**

**Description:** KtECTR\_E\_CTR\_WrmUpEnrgyLimTest1

**Notes:** Z axis is the cooling system energy failure threshold (kJ), X axis is ECT Temperature at Power up (° C), (Deluxe version)

y/x	-20	-7	10	30	45	60	85
1	11,402	10,155	8,523	6,604	5,165	5,165	5,165

15 OBDG08A ECM Diagnostic Supporting Tables

**Initial Supporting table - P0128\_Maximum Accumulated Energy for Start-up ECT conditions - Primary**

**Description:** KtECTR\_E\_CTR\_WrmUpEnrgyLimTest0

**Notes:** Z axis is the cooling system energy failure threshold (kJ), X axis is ECT Temperature at Power up (° C) , (Deluxe version)

y/x	-20	-7	10	30	45	60	85
1	9,464	8,394	6,995	5,350	4,116	2,882	2,882



**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage**

**Description:** Identifies which Long Term Fuel Trim Cell I.D.s are used for diagnosis. Only cells identified as "CeFADD\_e\_NonSelectedCell" are not used for diagnosis.

**Notes:** DTCs: P0171, P0172, P0174, P0175; Calibration Name: KaFADD\_e\_SelectCellSet; Axis is Long Term Fuel Trim Cell I.D.

**P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage - Part 1**

y/x	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR_e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell

**P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage - Part 2**

y/x	CeFADR_e_Cell04_PurgOnAirMode 1	CeFADR_e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell

**P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage - Part 3**

y/x	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR_e_Cell10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell

**P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage - Part 4**

y/x	CeFADR_e_Cell12_PurgOffAirMode 1	CeFADR_e_Cell13_PurgOffAirMode 0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300 EngineOverSpeedLimit**

**Description:** Engine OverSpeed Limit versus gear

**Notes:** Used for P0300-P0308. Cal Name: KaEOSC\_n\_EngOvrspdLimitGear

**P0300 EngineOverSpeedLimit - Part 1**

y/x	CeTGRR_e_TransGr1	CeTGRR_e_TransGr2	CeTGRR_e_TransGr3	CeTGRR_e_TransGr4	CeTGRR_e_TransGr5	CeTGRR_e_TransGr6	CeTGRR_e_TransGrEVT1
1	6,000	6,000	6,000	6,000	5,700	5,700	6,000

**P0300 EngineOverSpeedLimit - Part 2**

y/x	CeTGRR_e_TransGrEVT2	CeTGRR_e_TransGrNeut	CeTGRR_e_TransGrRvs	CeTGRR_e_TransGrPark	CeTGRR_e_TransGr7	CeTGRR_e_TransGr8	
1	6,000	4,000	6,000	4,000	6,000	6,000	

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300 Number of Normals**

**Description:** Number of Normals for the Driveline Ring Filter  
 After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

**Notes:** Used for P0300-P0308. Cal Name: KaMSFD\_Cnt\_NumOfNormalsFil

y/x	0	1	2	3	4	5	6	7	8
1	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300 Ring Filter**

**Description:** Driveline Ring Filter  
After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

**Notes:** Used for P0300-P0308. Cal Name: KaMSFD\_Cnt\_RingFilter

y/x	0	1	2	3	4	5	6	7	8
1	7.00	7.00	7.00	7.00	7.00	7.00	7.00	7.00	7.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_1st\_FireAftrMisfr\_Acel**

**Description:** Multiplier for establishing the expected acceleration of the cylinder after the misfire

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_CylAftMsfr

y/x	900	1,200	1,600	2,000	3,000
8	0.65	0.65	0.65	0.65	0.65
14	0.63	0.65	0.65	0.65	0.65
20	0.41	0.50	0.65	0.65	0.65
26	0.24	0.45	0.65	0.58	0.59
40	0.10	0.50	0.44	0.48	0.60

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0300\_1st\_FireAftrMisfr\_Jerk

**Description:** Multiplier for establishing the expected Jerk of the cylinder after the misfire

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_CylAftMsfr

y/x	900	1,200	1,600	2,000	3,000
8	-0.50	-0.64	-0.72	-0.65	-0.50
14	-0.75	-0.70	-0.56	-0.93	-0.93
20	-1.00	-0.81	-0.57	-0.92	-0.92
26	-1.32	-0.70	-0.53	-0.91	-0.91
40	-1.33	-0.92	-0.67	-0.90	-0.90

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0300\_Abnormal Cylinder Mode**

**Description:** Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Cylinder Mode Equation)

**Notes:** Used for P0300-P0308. Cal Name: KaMSFD\_Cnt\_CylAbnormal

y/x	0	1	2	3	4	5	6	7	8
1	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_Abnormal Rev Mode**

**Description:** Abnormal Rev Mode Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Rev Mode Equation)

**Notes:** Used for P0300-P0308. Cal Name: KaMSFD\_Cnt\_RevAbnormal

y/x	0	1	2	3	4	5	6	7	8
1	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00



**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_Abnormal SCD Mode**

**Description:** Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (SCD Mode Equation)

**Notes:** Used for P0300-P0308. Cal Name: KaMSFD\_Cnt\_SCD\_CylAbnormal

y/x	0	1	2	3	4	5	6	7	8
1	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00	4.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_Bank\_SCD\_Decel**

**Description:** Multitplier to SCD decel to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_MEDRES\_Bank

y/x	400	500	600	700	800	900	1,000	1,100	1,200
12	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75
16	0.75	0.69	0.75	0.75	0.75	0.73	0.71	0.75	0.75
18	0.75	0.60	0.70	0.62	0.67	0.67	0.65	0.69	0.54
20	0.75	0.64	0.75	0.75	0.75	0.70	0.71	0.75	0.67
24	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75
30	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75
40	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75
60	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75
98	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_Bank\_SCD\_Jerk**

**Description:** Multitplier to Medres SCD jerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_MEDRES\_Bank

y/x	400	500	600	700	800	900	1,000	1,100	1,200
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
18	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_BankCylModeDecel**

**Description:** Multitplier to Lores Decel to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_LORES\_Bank

y/x	500	700	900	1,100	1,400	1,800	2,200	2,600	3,000
12	0.53	0.61	0.48	0.33	0.31	0.29	0.75	0.50	0.38
16	0.61	0.52	0.47	0.29	0.25	0.25	0.25	0.25	0.25
18	0.42	0.63	0.51	0.43	0.25	0.25	0.25	0.25	0.25
20	0.54	0.54	0.55	0.52	0.25	0.25	0.25	0.25	0.25
24	0.58	0.62	0.49	0.51	0.25	0.25	0.25	0.25	0.25
30	0.60	0.64	0.70	0.43	0.25	0.25	0.25	0.25	0.25
40	0.52	0.58	0.53	0.37	0.32	0.35	0.35	0.39	0.40
60	0.40	0.46	0.38	0.37	0.30	0.28	0.32	0.33	0.38
98	0.39	0.34	0.26	0.32	0.28	0.25	0.31	0.28	0.37

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_BankCylModeJerk**

**Description:** Multitplier to Lores Jerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_LORES\_Bank

y/x	500	700	900	1,100	1,400	1,800	2,200	2,600	3,000
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	0.94	0.70	0.70	0.70	0.70	0.70
18	1.00	1.00	1.00	0.89	0.70	0.70	0.70	0.70	0.70
20	0.91	1.00	1.00	0.88	0.70	0.70	0.70	0.70	0.70
24	0.80	0.95	0.97	1.03	0.70	0.70	0.70	0.70	0.70
30	0.71	0.86	0.87	0.99	0.70	0.70	0.70	0.70	0.70
40	0.70	0.70	0.70	0.74	0.70	0.70	0.70	0.70	0.71
60	0.70	0.70	0.70	0.70	0.70	0.70	0.70	0.70	0.70
98	0.70	0.70	0.70	0.70	0.70	0.70	0.70	0.70	0.70

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0300\_Catalyst\_Damage\_Misfire\_Percentage

**Description:** Catalyst Damaging Misfire Percentage" Table whenever secondary conditions are met.

**Notes:** Used for P0300-P0308. Cal Name: KtMSFD\_Pct\_CatalystMisfire

y/x	0	1,000	2,000	3,000	4,000	5,000	6,000	7,000
0	11.3	11.3	11.3	6.3	4.8	4.8	4.8	4.8
10	11.3	11.3	11.3	6.3	4.8	4.8	4.8	4.8
20	8.3	8.3	6.8	6.3	4.8	4.8	4.8	4.8
30	6.3	6.3	6.3	6.3	4.8	4.8	4.8	4.8
40	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
50	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
60	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
70	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
80	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
90	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
100	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_ClyAfterAFM\_Decel**

**Description:** Multitplier to Lores decel to account for different pattern of misfire after a deactivated cylider. Similar to the second cylinder of consecutive cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_LORES\_PostDeac

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00
12	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00
16	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00
20	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00
24	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00
25	0.65	0.62	0.56	0.63	0.51	0.50	0.50	0.80	1.00
40	0.56	0.53	0.53	0.58	0.54	0.50	0.50	0.80	1.00
60	0.80	0.80	0.80	0.80	0.80	0.80	0.80	0.80	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_ClyBeforeAFM\_Jerk**

**Description:** Multitplier to Lores decel to account for different pattern of misfire before a deactivated cylider, but after an active cylinder that follows an deactive cylinder on engine that supports cylinder deactivation in non even fire patterns.. Multipliers are a function of engine rpm and % engine Load.

**Notes:** KtMSFD\_K\_ddt\_LORES\_PreDeac KtMSFD\_K\_ddt\_LORES\_PreDeac

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
25	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00



**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_ConsecCylModDecel**

**Description:** Multitplier to Lores decel to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_LORES\_Consec

y/x	500	700	900	1,100	1,400	1,800	2,200	2,600	3,000
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_ConsecCylModeJerk**

**Description:** Multitplier to Lores Jerk to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_LORES\_Consec

y/x	500	700	900	1,100	1,400	1,800	2,200	2,600	3,000
8	0	0	0	0	0	0	0	0	0
12	0	0	0	0	0	0	0	0	-1
16	0	0	0	0	0	0	0	0	0
20	0	0	0	0	0	0	0	0	0
24	0	0	0	0	0	0	0	0	0
30	0	0	0	0	0	0	0	0	0
40	0	0	0	0	0	0	0	0	0
60	0	0	0	0	0	0	0	0	0
98	0	0	0	0	0	0	0	0	0

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_ConsecSCD\_Decel**

**Description:** Multitplier to medres decel to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_MEDRES\_Consec

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_ConsecSCD\_Jerk**

**Description:** Multitplier to medres Jerk to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_MEDRES\_Consec

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	0.00	0.00	-0.07	-0.14	-0.13	-0.14	-0.21	-0.23	0.13
12	0.00	0.00	0.00	-0.08	-0.08	-0.15	-0.10	-0.08	-0.11
16	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
20	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
24	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
30	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25
40	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25
60	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25
98	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25	0.25

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_CylAfterAFM\_Jerk**

**Description:** Multitplier to Lores JerkI to account for different pattern of misfire after a deactivated cylinder. Similar to the second cylinder of consecutive cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_LORES\_PostDeac

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	2	2	2	2	2	2	2	2	2
12	2	2	2	2	2	2	2	2	2
16	2	2	2	2	2	2	2	2	2
20	2	2	2	2	2	2	2	2	2
24	2	2	2	2	2	2	2	2	2
25	0	0	0	0	0	0	0	0	0
40	0	0	0	0	0	0	0	0	0
60	0	0	0	0	0	0	0	0	0
98	0	0	0	0	0	0	0	0	0

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_CylBeforeAFM\_Decel**

**Description:** Multiplier to Lores decel to account for different pattern of misfire before a deactivated cylinder, but after an active cylinder that follows an deactive cylinder on engine that supports cylinder deactivation in non even fire patterns.. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_LORES\_PreDeac

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
25	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_CylModeDecel**

**Description:** Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

**Notes:** Used for P0300-P0308. Cal Name: KtMISF\_CylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	1,268	1,153	750	507	350	220	150	105	80	50	34	22	18	13	12	9	8	7	7	6	5	4	4	4	3	3
6	1,268	1,153	750	507	350	220	150	105	80	50	34	22	18	13	12	9	8	7	7	6	5	4	4	4	3	3
8	1,489	1,354	825	540	375	260	161	125	93	56	38	24	20	15	12	9	8	7	7	6	5	4	4	4	3	3
10	1,712	1,556	919	600	440	310	190	145	110	65	45	37	27	20	15	12	10	7	7	5	5	4	4	4	3	3
12	1,933	1,757	987	666	505	378	242	188	139	87	60	45	35	24	20	16	13	9	7	5	5	4	4	4	3	3
14	2,154	1,958	1,056	720	554	429	282	220	162	102	75	52	40	27	24	18	15	11	8	5	5	4	4	4	3	3
16	2,375	2,159	1,125	773	604	481	323	251	185	117	85	60	46	31	27	21	17	13	9	6	5	4	4	4	3	3
18	2,596	2,360	1,193	826	654	532	363	282	208	131	96	67	52	35	31	23	19	15	10	6	5	4	4	4	3	3
20	2,818	2,562	1,262	879	704	583	404	314	232	146	107	75	58	39	34	26	21	16	11	7	5	4	4	4	3	3
22	3,039	2,763	1,331	932	754	634	444	345	255	160	117	82	63	43	37	29	23	18	13	8	5	4	4	4	3	3
24	3,260	2,964	1,399	985	804	685	484	376	278	175	128	89	69	47	41	31	26	20	15	8	5	5	4	4	3	3
26	3,482	3,165	1,468	1,039	853	736	525	408	301	190	139	97	75	51	44	34	28	21	17	9	6	6	4	4	3	3
30	3,925	3,568	1,605	1,145	953	839	605	470	347	219	160	112	86	59	51	39	32	25	19	11	7	6	4	4	4	4
40	5,031	4,574	1,949	1,411	1,202	1,095	807	627	463	292	213	149	115	78	68	52	43	33	25	15	9	6	4	4	4	4
60	7,245	6,586	2,635	1,943	1,700	1,606	1,211	941	695	437	320	224	173	118	102	78	64	49	30	18	12	8	7	6	4	4
78	9,181	8,346	3,236	2,408	2,136	2,054	1,564	1,215	897	565	413	289	223	152	132	101	83	63	35	22	15	10	8	7	5	5
97	11,394	10,358	3,923	2,940	2,634	2,566	1,967	1,529	1,129	711	520	363	281	191	165	127	104	80	40	26	18	11	9	8	7	7

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_CylModeJerk**

**Description:** Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

**Notes:** Used for P0300-P0308. Cal Name: KtMISF\_ddt\_CylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000	
3	1,268	1,153	750	507	350	220	150	105	80	50	32	22	17	12	11	8	7	6	0	0	0	0	0	0	0	0	0
6	1,268	1,153	750	507	350	220	150	105	80	50	32	22	17	12	11	8	7	6	0	0	0	0	0	0	0	0	0
8	1,489	1,354	825	540	375	260	158	123	93	54	36	22	18	14	11	9	7	6	0	0	0	0	0	0	0	0	0
10	1,712	1,556	919	600	440	310	190	145	110	65	45	37	25	19	14	11	9	6	0	0	0	0	0	0	0	0	0
12	1,933	1,757	987	666	505	378	237	184	139	88	60	44	34	23	19	15	12	8	0	0	0	0	0	0	0	0	0
14	2,154	1,958	1,056	720	554	429	277	215	162	103	74	51	40	26	23	17	14	11	0	0	0	0	0	0	0	0	0
16	2,375	2,159	1,125	773	604	481	316	246	185	117	85	59	45	30	26	20	16	12	0	0	0	0	0	0	0	0	0
18	2,596	2,360	1,193	826	654	532	356	276	208	132	95	66	51	34	29	22	18	14	0	0	0	0	0	0	0	0	0
20	2,818	2,562	1,262	879	704	583	396	307	232	147	106	73	56	38	32	25	20	15	0	0	0	0	0	0	0	0	0
22	3,039	2,763	1,331	932	754	634	435	338	255	161	117	81	62	42	35	27	22	17	0	0	0	0	0	0	0	0	0
24	3,260	2,964	1,399	985	804	685	475	368	278	176	127	88	68	45	39	30	24	18	0	0	0	0	0	0	0	0	0
26	3,482	3,165	1,468	1,039	853	736	514	399	301	190	138	95	73	49	42	32	26	20	0	0	0	0	0	0	0	0	0
30	3,925	3,568	1,605	1,145	953	839	593	461	347	220	159	110	85	57	48	37	30	23	0	0	0	0	0	0	0	0	0
40	5,031	4,574	1,949	1,411	1,202	1,095	791	614	463	293	212	147	113	76	65	50	40	31	0	0	0	0	0	0	0	0	0
60	7,245	6,586	2,635	1,943	1,700	1,606	1,187	921	695	440	318	220	169	113	97	74	60	46	0	0	0	0	0	0	0	0	0
78	9,181	8,346	3,236	2,408	2,136	2,054	1,533	1,190	897	568	410	284	219	146	125	96	78	59	0	0	0	0	0	0	0	0	0
97	11,394	10,358	3,923	2,940	2,634	2,566	1,928	1,497	1,129	714	516	358	275	184	157	121	98	75	0	0	0	0	0	0	0	0	0



**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_IdleCyl\_Decel**

**Description:** Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

**Notes:** Used for P0300-P0308. Cal Name: KtMSFD\_dt\_IdleCylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	1,268	1,153	750	507	350	220	150	105	75	50	34	22	18
6	1,268	1,153	750	507	350	220	150	105	75	50	34	22	18
8	1,489	1,354	825	540	375	260	158	115	75	56	38	24	20
10	1,712	1,556	902	573	385	275	175	115	80	60	52	37	27
12	1,933	1,757	970	626	415	303	200	125	80	70	60	45	35
14	2,154	1,958	1,039	680	464	354	257	150	90	75	75	52	40
16	2,375	2,159	1,108	733	514	406	296	206	125	85	85	60	46
18	2,596	2,360	1,193	826	654	532	356	282	208	131	96	67	52
20	2,818	2,562	1,262	879	704	583	396	314	232	146	107	75	58
22	3,039	2,763	1,331	932	754	634	435	345	255	160	117	82	63
24	3,260	2,964	1,399	985	804	685	475	376	278	175	128	89	69
26	3,482	3,165	1,468	1,039	853	736	514	408	301	190	139	97	75
28	3,704	3,366	1,537	1,093	902	787	553	430	324	204	149	102	78
30	3,926	3,567	1,606	1,147	951	838	592	461	347	218	160	109	83
32	4,148	3,768	1,675	1,201	1,000	889	631	492	370	232	171	116	88
34	4,370	3,969	1,744	1,255	1,049	940	670	523	393	246	182	123	93
36	4,592	4,170	1,813	1,309	1,098	991	709	554	416	260	193	130	98

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_IdleCyl\_Jerk**

**Description:** Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

**Notes:** Used for P0300-P0308. Cal Name: KtMSFD\_ddt\_IdleCylinderMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	1,268	1,153	750	507	350	220	150	105	75	50	32	22	17
6	1,268	1,153	750	507	350	220	150	105	75	50	32	22	17
8	1,489	1,354	825	540	375	260	158	115	75	54	36	22	18
10	1,712	1,556	902	573	390	275	175	120	80	60	50	37	25
12	1,933	1,757	970	626	415	303	200	125	80	65	60	44	34
14	2,154	1,958	1,039	680	464	354	257	150	90	80	74	51	40
16	2,375	2,159	1,108	733	514	406	296	205	130	90	85	59	45
18	2,596	2,360	1,193	826	654	532	356	282	208	132	95	66	51
20	2,818	2,562	1,262	879	704	583	396	315	232	147	106	73	56
22	3,039	2,763	1,331	932	754	634	435	345	255	161	117	81	62
24	3,260	2,964	1,399	985	804	685	475	375	278	176	127	88	68
26	3,482	3,165	1,468	1,039	853	736	514	408	301	190	138	95	73
28	3,704	3,366	1,537	1,093	902	787	553	430	324	204	149	102	78
30	3,926	3,567	1,606	1,147	951	838	592	461	347	218	160	109	83
32	4,148	3,768	1,675	1,201	1,000	889	631	492	370	232	171	116	88
34	4,370	3,969	1,744	1,255	1,049	940	670	523	393	246	182	123	93
36	4,592	4,170	1,813	1,309	1,098	991	709	554	416	260	193	130	98

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_IdleSCD\_Decel**

**Description:** Crankshaft decel threshold while in SCD mode. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

**Notes:** Used for P0300-P0308. Cal Name: KtMISF\_dt\_SCD\_IdleMode

Note: Misfire's Load term is %, but not PID\$04. PID \$04 is not robust to temperature and altitude shifts. (especially decel and jerk thresholds since they track actual air trapped in cylinder)

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	605	550	305	200	130	95	65	47	38	32,767	32,767	32,767	32,767
6	605	550	305	200	130	95	65	47	38	32,767	32,767	32,767	32,767
8	660	600	305	200	145	105	70	55	40	32,767	32,767	32,767	32,767
10	770	700	320	215	150	115	75	60	50	32,767	32,767	32,767	32,767
12	880	800	420	260	200	140	95	80	65	32,767	32,767	32,767	32,767
14	990	900	580	360	275	200	140	105	70	32,767	32,767	32,767	32,767
16	1,100	1,000	650	380	285	210	150	115	80	32,767	32,767	32,767	32,767
18	1,210	1,100	700	400	295	220	160	130	90	32,767	32,767	32,767	32,767
20	1,320	1,200	750	425	310	230	170	140	100	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_IdleSCD\_Jerk**

**Description:** Crankshaft jerk threshold while in SCD mode. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

**Notes:** Used for P0300-P0308. Cal Name: KtMISF\_ddt\_SCD\_IdleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	633	575	310	200	130	95	65	47	38	32,767	32,767	32,767	32,767
6	633	575	310	200	130	95	65	47	38	32,767	32,767	32,767	32,767
8	770	700	310	200	145	105	70	55	40	32,767	32,767	32,767	32,767
10	880	800	350	250	165	130	90	60	50	32,767	32,767	32,767	32,767
12	990	900	475	300	220	155	110	90	70	32,767	32,767	32,767	32,767
14	1,100	1,000	625	410	300	220	150	105	80	32,767	32,767	32,767	32,767
16	1,210	1,100	700	430	310	230	150	115	90	32,767	32,767	32,767	32,767
18	1,320	1,200	750	450	320	240	160	130	100	32,767	32,767	32,767	32,767
20	1,430	1,300	800	475	335	250	170	140	110	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_Pair\_SCD\_Decel**

**Description:** Multitplier to P0300\_SCD\_Decel to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_MEDRES\_Opp

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	1.00	0.71	0.80	0.84	0.87	0.71	0.71	0.66	0.88
12	1.00	0.78	0.73	0.85	0.78	0.79	0.83	0.88	0.77
16	0.95	0.82	0.77	0.87	0.96	0.95	0.87	0.82	0.88
20	0.92	0.85	0.80	0.88	0.95	0.96	0.97	0.93	0.90
24	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90
30	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90
40	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90
60	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90
98	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_Pair\_SCD\_Jerk**

**Description:** Multitplier to P0300\_SCD\_Jerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_MEDRES\_Opp

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_PairCylModeDecel**

**Description:** Multitplier to Cyl Mode Deceleration to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_LORES\_Opp

y/x	500	700	900	1,100	1,400	1,800	2,200	2,600	3,000
8	0.90	0.88	0.85	0.72	0.93	0.90	0.90	0.90	0.90
12	0.90	0.90	0.90	0.90	0.86	0.89	0.88	0.75	0.78
16	0.90	0.90	0.90	0.90	0.90	0.85	0.84	0.76	0.69
20	0.90	0.90	0.90	0.90	0.90	0.85	0.87	0.73	0.75
24	0.90	0.90	0.90	0.88	0.90	0.90	0.85	0.81	0.75
30	0.90	0.90	0.90	0.85	0.90	0.90	0.90	0.79	0.80
40	0.90	0.90	0.78	0.68	0.79	0.81	0.90	0.83	0.90
60	0.90	0.90	0.59	0.56	0.75	0.63	0.85	0.69	0.90
98	0.70	0.90	0.51	0.50	0.68	0.66	0.81	0.72	0.85

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0300\_PairCylModeJerk**

**Description:** Multitplier to P0300\_CylModeJerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_LORES\_Opp

y/x	500	700	900	1,100	1,400	1,800	2,200	2,600	3,000
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00



**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_Random\_SCD\_Decel**

**Description:** Multitplier to SCD\_Decel to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_MEDRES\_Emiss

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10
24	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10
30	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10
40	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10
60	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10
98	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_Random\_SCD\_Jerk**

**Description:** Multitplier to Random\_SCD\_Jerk to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_MEDRES\_Emiss

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_RandomAFM\_Decl**

**Description:** Multitplier to Cylinder\_Decel while in Cylinder Deactivation mode to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dt\_LORES\_AFM\_Emiss

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	4.00	4.00	4.00	3.50	3.50	3.50	3.50	3.50	3.50
12	3.50	3.50	3.50	3.00	3.00	3.00	3.00	3.00	3.00
16	3.00	3.00	3.00	2.50	2.50	2.50	2.50	2.50	2.50
20	2.50	2.50	2.50	2.50	2.50	2.50	2.50	2.50	2.50
24	2.50	2.50	2.50	2.50	2.00	2.00	2.00	2.00	2.00
25	2.50	2.25	1.60	1.60	1.60	1.60	1.60	1.60	1.60
40	2.25	1.75	1.60	1.60	1.60	1.60	1.60	1.60	1.60
60	1.75	1.60	1.60	1.60	1.60	1.60	1.60	1.60	1.60
98	1.60	1.60	1.60	1.60	1.60	1.60	1.60	1.60	1.60

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_RandomAFM\_Jerk**

**Description:** Multitplier to Cylinder\_Jerk while in Cylinder Deactivation mode to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_LORES\_AFM\_Emiss

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	11.00	11.00	11.00	8.00	8.00	8.00	8.00	8.00	8.00
12	11.00	11.00	11.00	6.00	6.00	6.00	6.00	6.00	6.00
16	10.00	10.00	10.00	4.00	4.00	4.00	4.00	4.00	4.00
20	8.00	8.00	8.00	3.00	3.00	3.00	3.00	3.00	3.00
24	5.00	4.00	3.00	2.50	2.50	2.50	2.50	2.50	2.50
25	5.00	4.00	3.00	2.25	2.00	2.00	2.00	2.00	2.00
40	3.50	3.00	2.50	2.00	2.00	2.00	2.00	2.00	2.00
60	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00
98	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_RandomCylModDecel**

**Description:** Multiplier to P0300\_CylMode\_Decel. account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308. Cal Name: KtMSFD\_K\_dt\_LORES\_Emiss

y/x	500	700	900	1,100	1,400	1,800	2,200	2,600	3,000
8	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15
12	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15
16	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15
20	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15
24	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15
30	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15
40	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15
60	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15
98	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_RandomCylModJerk**

**Description:** Multiplier to P0300\_CylMode\_Jerk to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_ddt\_LORES\_Emiss

y/x	500	700	900	1,100	1,400	1,800	2,200	2,600	3,000
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_RandomRevModDecl**

**Description:** Multitplier to P0300\_RevMode\_Decel to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_RevModeEmiss

y/x	3,001	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_RepetSnapDecayAdjst**

**Description:** If misfire is present in consecutive engine cycles, this multiplier is applied to the misfire jerk threshold and compared to a crankshaft snap value after the misfire has taken place.. Table lookup as a function of engine rpm.

**Notes:** Used for P0300 - P0308, Cal Name:KtMSFD\_K\_dddPostCylCnscMsfr

y/x	900	1,100	1,400	1,800	2,200	2,600	3,000	4,000	5,000
1	1.00	1.31	1.17	1.08	1.17	1.00	1.00	1.00	1.00



**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_RevMode\_Decel**

**Description:** Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

**Notes:** Used for P0300-P0308. Cal Name: KtMISF\_RevolutionMode

y/x	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	110	70	40	35	25	20	20	20
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	110	70	40	35	25	20	20	20
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	110	70	40	35	25	20	20	20
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	110	70	40	35	25	20	20	20
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	115	75	40	35	25	20	20	20
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	135	95	45	35	25	20	20	20
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	150	110	55	40	25	22	22	22
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	175	125	65	45	25	22	22	22
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	200	140	70	55	30	26	26	26
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	225	155	100	65	35	30	30	30
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	250	165	110	75	40	30	30	30
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	275	180	120	85	55	40	40	40
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	300	200	135	95	65	50	50	50
40	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	375	250	170	120	85	65	65	65
60	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	400	300	195	150	100	80	80	80
78	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	450	350	230	180	120	100	100	100
97	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	500	400	265	210	140	120	120	120

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_SCD\_Decel**

**Description:** Crankshaft decel threshold. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

**Notes:** Used for P0300-P0308. Cal Name: KtMISF\_dt\_SCD\_OffIdleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	660	600	315	210	135	100	65	47	38	32,767	32,767	32,767	32,767
6	660	600	315	210	135	100	65	47	38	32,767	32,767	32,767	32,767
8	770	700	315	210	145	105	70	55	40	32,767	32,767	32,767	32,767
10	880	800	325	225	155	120	80	60	50	32,767	32,767	32,767	32,767
12	990	900	475	275	210	150	100	80	65	32,767	32,767	32,767	32,767
14	1,100	1,000	600	360	275	200	140	105	70	32,767	32,767	32,767	32,767
16	1,210	1,100	650	380	285	210	150	115	80	32,767	32,767	32,767	32,767
18	1,320	1,200	700	400	295	220	160	130	90	32,767	32,767	32,767	32,767
20	1,430	1,300	750	425	310	230	170	140	100	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
40	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
60	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
78	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
97	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_SCD\_Jerk**

**Description:** Crankshaft jerk threshold. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

**Notes:** Used for P0300-P0308. Cal Name: KtMISF\_ddt\_SCD\_OffIdleMode

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	668	625	315	210	135	100	65	47	38	32,767	32,767	32,767	32,767
6	688	625	315	210	135	100	65	47	38	32,767	32,767	32,767	32,767
8	798	725	325	210	145	105	70	55	45	32,767	32,767	32,767	32,767
10	908	825	400	275	180	140	100	70	55	32,767	32,767	32,767	32,767
12	1,045	950	550	325	235	170	120	90	70	32,767	32,767	32,767	32,767
14	1,210	1,100	650	410	300	220	150	105	80	32,767	32,767	32,767	32,767
16	1,320	1,200	700	430	310	230	150	115	90	32,767	32,767	32,767	32,767
18	1,430	1,300	750	450	320	240	160	130	100	32,767	32,767	32,767	32,767
20	1,540	1,400	800	475	335	250	170	140	110	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
40	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
60	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
78	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
97	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_SnapDecayAfterMisfire**

**Description:** multiplier times the ddt\_jerk value used used to detect misfire at that speed and load to see if size of disturbance has died down as expected of real misfire. Table lookup as a function of engine rpm and trans gear ratio.

**Notes:** Used for P0300 - P0308, Cal Name: KtMSFD\_K\_dddt\_PostCylAft

y/x	900	1,100	1,400	1,800	2,200	2,600	3,000	4,000	5,000
0	1.17	1.23	1.50	1.65	1.42	1.97	2.00	2.00	2.00
1	1.17	1.23	1.50	1.65	1.42	1.97	2.00	2.00	2.00
1	1.17	1.23	1.50	1.65	1.42	1.97	2.00	2.00	2.00
1	1.10	1.14	1.54	1.28	1.25	1.15	1.43	1.43	1.43
1	1.97	2.00	2.00	1.44	1.39	1.67	1.67	1.67	1.67
2	1.92	1.41	1.39	1.63	1.54	1.80	1.83	1.83	1.83
4	1.88	1.41	1.57	1.47	1.59	2.00	2.00	2.00	2.00
5	2.00	1.67	1.83	1.47	1.59	2.00	2.00	2.00	2.00
5	2.00	1.67	1.83	1.47	1.59	2.00	2.00	2.00	2.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_TOSSRoughRoadThres**

**Description:** Only used if Rough Road source = TOSS: dispersion value on Transmission Output Speed Sensor above which rough road is indicated present

**Notes:** Used for P0300-P0308. Cal Name: KtRRDI\_a\_RoughRoadThresh

y/x	600	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000
100	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
300	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
500	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
700	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
900	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,100	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,300	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_WSSRoughRoadThres**

**Description:** Only used if Wheel speed from ABS is used. If difference between wheel speed readings is larger than this limit, rough road is present

**Notes:** Used for P0300-P0308. Cal Name: KtRRDI\_a\_WhlSpdRoughRoadLim

y/x	0	12	24	36	48	60	72	85	97	109	121	133	145	157	169	181	193
1	0.40	0.42	0.44	0.46	0.48	0.50	0.52	0.54	0.56	0.58	0.60	0.62	0.64	0.66	0.68	0.70	0.72

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_ZeroTorqBaro**

**Description:** adjusts zero torque for altitude

**Notes:** Used for P0300-P0308. Cal Name: KtMSFD\_K\_ZeroTorqBaro

y/x	65	70	75	80	85	90	95	100	105
1	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_ZeroTorqDoD**

**Description:** Zero torque engine load while in Active Fuel Management

**Notes:** Used for P0300-P0308. Cal Name: KtMSFD\_ZeroTorqDoD

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
1	1.40	1.40	1.40	1.40	1.40	1.40	1.40	1.20	1.10	0.90	0.60	0.50	0.60	0.60	0.40	0.30	0.30	0.30	-0.15	2.35	4.85	7.35	9.85	12.35	14.85	17.35



**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0300\_ZeroTorqueEngLoad**

**Description:** %air load that represents Zero Brake torque along the Neutral rev line. The Zero torque threshold is adjusted for Baro via P0300\_ZeroTorqueBaro

**Notes:** Used for P0300-P0308. Cal Name: KtMISF\_ZeroTorqSpd

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
1	-2.00	-2.00	-1.75	-1.50	-1.25	-1.00	-0.75	-0.50	-0.25	-0.15	-0.15	-0.15	-0.15	-0.15	-0.15	-0.15	-0.15	-0.15	-0.15	2.35	4.85	7.35	9.85	12.35	14.85	17.35

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0324\_P0326\_P0331\_AbnormalNoise\_CylsEnabled

**Description:** Specifies which cylinders will be used for the Abnormal Noise portion of the performance diagnostics (1 = cylinder used, 0 = cylinder not used)

**Notes:** Used for P0324, P0326 and P0331. Cal name: KaKNKD\_b\_PerfAbnIncludeCyl. x-axis = Cylinder number in firing order (i.e. Cyl 0 = first cylinder in firing order, Cyl 1 = second cylinder in firing order....)

A cal value = 1 specifies the cylinder is used for the Abnormal Noise diagnostic. A cal value = 0 specifies the cylinder is not used. Only the first four values in the table are relevant for a four-cylinder engine and only the first six values in the table are relevant for a six-cylinder engine.

Typically, all cylinders are used. Cylinders are only excluded if the signal from that cylinder is weak and there is no separation between normal and faulted conditions (can occur if the sensor location results in poor signal-to-noise ratio for a given cylinder).

y/x	0	1	2	3	4	5	6	7
1	1	1	1	1	1	1	1	1

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0324\_P0326\_P0331\_AbnormalNoise\_Threshold**

**Description:** Fail threshold for the Knock Performance Abnormal Noise Diagnostic

**Notes:** Used for P0324, P0326 and P0331. Cal Name: KtKNKD\_k\_PerfAbnLimitLo. X-axis = Engine Speed (RPM). Diagnostic fails when VaKNKD\_k\_PerfCylAbnFiltIntnsity < KtKNKD\_k\_PerfAbnLimitLo

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.058	0.057	0.057	0.063	0.069	0.064	0.086	0.110	0.145	0.182	0.165	0.186	0.186	0.186	0.186	0.186	0.186

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0325\_P0330\_OpenCktThrshMax (20 kHz)**

**Description:** Knock Open Circuit Diagnostic Maximum Threshold when using the 20 kHz method (see "OpenMethod" description)

**Notes:** Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenMax20K. x-axis = Engine Speed (RPM).

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:  
 i.e.: KtKNKD\_k\_OpenMin20K < VaKNKD\_k\_OpenFiltIntensity < KtKNKD\_k\_OpenMax20K.

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	4.8125	4.8125	4.8027	4.7832	4.7539	4.7129	4.6621	4.6035	4.5332	4.4531	4.3633	4.2637	4.1523	4.0332	3.9023	3.7637	3.6133

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0325\_P0330\_OpenCktThrshMax (Normal Noise)**

**Description:** Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

**Notes:** Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenMaxNN. x-axis = Engine Speed (RPM)

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:  
i.e.: KtKNKD\_k\_OpenMinNN < VaKNKD\_k\_OpenFiltIntensity < KtKNKD\_k\_OpenMaxNN.

y/x	2,700	2,900	3,000	3,250	3,500	3,750	4,000	4,250	4,500	4,750	5,000	5,500	6,000	6,500	7,000	7,500	8,500
1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0325\_P0330\_OpenCktThrshMin (20 kHz)**

**Description:** Knock Open Circuit Diagnostic Minimum Threshold when using the 20 kHz method (see "OpenMethod" description)

**Notes:** Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenMin20K. x-axis = Engine Speed (RPM)

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:  
 i.e.: KtKNKD\_k\_OpenMin20K < VaKNKD\_k\_OpenFiltIntensity < KtKNKD\_k\_OpenMax20K.

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	1.9746	1.9824	1.9883	1.9941	2.0020	2.0078	2.0156	2.0215	2.0273	2.0352	2.0430	2.0488	2.0547	2.1230	2.3730	2.6426	2.9336

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0325\_P0330\_OpenCktThrshMin (Normal Noise)**

**Description:** Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

**Notes:** Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenMinNN. x-axis = Engine Speed (RPM)

Diagnostic fails when the filtered diagnostic output is between the OpenCktThrshMin and OpenCktThrshMax:

i.e.: KtKNKD\_k\_OpenMinNN < VaKNKD\_k\_OpenFiltIntensity < KtKNKD\_k\_OpenMaxNN.

y/x	2,700	2,900	3,000	3,250	3,500	3,750	4,000	4,250	4,500	4,750	5,000	5,500	6,000	6,500	7,000	7,500	8,500
1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P0325\_P0330\_OpenMethod\_2**

**Description:** Defines which Knock Open Circuit Diagnostic method to use.

**Notes:** Used for P0325 and P0330. Cal name: KaKNKD\_e\_OpenMethod. x-axis = Engine Speed Index, 500 to 8500 (RPM) by 500 rpm increments.

Selects 1 of 3 available methods: "20kHz Method", "Normal Noise Method," or "Disabled." The mode chosen dictates which set of threshold tables are used. Typically, either: A) the 20 kHz Method is used for all RPM or B) the 20 kHz Method is used for low/medium RPM and the Normal Noise Method is used for high RPM.

**P0325\_P0330\_OpenMethod\_2 - Part 1**

y/x	0	1	2	3	4	5
1	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z

**P0325\_P0330\_OpenMethod\_2 - Part 2**

y/x	6	7	8	9	10	11
1	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z

**P0325\_P0330\_OpenMethod\_2 - Part 3**

y/x	12	13	14	15	16	
1	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	CeKNKD_e_Open_20KH z	



15 OBDG08A ECM Diagnostic Supporting Tables

**Initial Supporting table - P0442: Volatility Time as a Function of Estimate of Ambient Temperature**

**Description:** Data is Volatility Time (in seconds) and Axis is Estimated Ambient Coolant in Deg C

**Notes:** KtEONV\_t\_VolatilityTimeMax

y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	45	45	45	45	45	45	141	284	400	500	500	500	500	500	500	500	500

15 OBDG08A ECM Diagnostic Supporting Tables

**Initial table - P0442: Engine Off Time Before Vehicle Off Maximum as a Function of Estimated Ambient Temperature Table**

**Description:** Data is Engine Off Time Before Vehicle Off Maximum Table (in seconds) and Axis is Estimated Ambient Coolant in Deg C

**Notes:** KtEONV\_t\_EngOffTimeBefVehOffMax

y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	70	70	70	70	74	82	105	153	320	480	480	480	480	480	480	480	480

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0442: EONV Pressure Threshold (Pascals) Table**

**OBD GROUP: FGMXOBDG08A**

**TEST GROUP: FGMXT06.2374**

**EMISSIONS STDS: CAL---Bin 4, FED---Bin 4**

**Description:** Data is EONV Pressure Threshold in Pascals, X axis (horizontal) is fuel level in % from 0 to 100 with step size 6.25, and Y axis (vertical) is temperature in deg C from -10 to 80 with step size 5.625

**Notes:** KtEONV\_p\_PressureThreshold

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
2	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
3	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
4	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
5	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
6	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
7	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
8	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
9	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
10	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
11	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
12	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
13	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
14	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
15	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
16	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5
17	-435.9	-404.8	-373.6	-342.5	-311.4	-280.2	-249.1	-218.0	-186.8	-179.0	-171.2	-163.5	-155.7	-147.9	-140.1	-132.3	-124.5

15 OBDG08A ECM Diagnostic Supporting Tables

**Initial Supporting table - P0496: Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level Table**

**Description:** Data is Purge Valve Leak Test Engine Vacuum Test Time (in seconds) and Axis is Fuel Level in %

**Notes:** KtEVPD\_t\_PVLT\_EngineVacTimeCold

y/x	0	6	12	19	25	31	37	44	50	56	62	69	75	81	87	94	100
1	79	78	76	74	73	71	69	68	66	64	63	61	59	58	56	54	53

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0521\_LowMinOilPresFail - Two Stage Oil Pump

**Description:** Minimum expected oil pressure readings

**Notes:** For P0521: KtLUBD\_p\_OP\_SnsrMinOilPresFail with X Axis is defined by KnLUBD\_n\_OP\_SnsrMinRPMAs

y/x	1,000.0	1,500.0	2,000.0	2,500.0	3,000.0	3,500.0	4,000.0	4,500.0	5,000.0
1.0	90.0	117.0	125.0	135.0	145.0	155.0	240.0	267.0	267.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0606\_Last Seed Timeout f(Loop Time)

**Description:** The max time for the Last Seed Timeout as a function of operating loop time sequence.

**Notes:** P0606, KaPISD\_t\_LastSeedTimeout[x]

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	0.175	0.175	0.175	409.594

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0606\_Program Sequence Watch Enable f(Loop Time)

**Description:** The enabling flags for the program sequence watch as a function of operating loop time sequence.

**Notes:** P0606, KaPISD\_b\_ProgSeqWatchEnbl

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	1	1	1	1

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0606\_PSW Sequence Fail f(Loop Time)

**Description:** Fail threshold for PSW per operating loop.

**Notes:** P0606, KaPISD\_Cnt\_SequenceFail[x]

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	3	3	3	3



15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0606\_PSW Sequence Sample f(Loop Time)

**Description:** Sample threshold for PSW per operating loop.

**Notes:** P0606, KaPISD\_Cnt\_SequenceSmp[x]

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	4	4	4	4

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P06B6\_P06B7\_OpenTestCktThrshMax**

**Description:** Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

**Notes:** Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenTestCktMax. x-axis = Engine Speed (RPM).

Diagnostic fails when the filtered diagnostic output is between the OpenTestCktThrshMin and OpenTestCktThrshMax:

i.e.  $KtKNKD\_k\_OpenTestCktMin < VaKNKD\_k\_OpenTestCktIntFilter < KtKNKD\_k\_OpenTestCktMax$

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.102	0.107	0.109	0.127	0.156	0.174	0.344	0.438	1.074	1.098	0.941	1.195	1.494	1.830	2.205	2.621	3.076

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P06B6\_P06B7\_OpenTestCktThrshMin**

**Description:** Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

**Notes:** Used for P0325 and P0330. Cal name: KtKNKD\_k\_OpenTestCktMin. x-axis = Engine Speed (RPM).

Diagnostic fails when the filtered diagnostic output is between the OpenTestCktThrshMin and OpenTestCktThrshMax:

i.e.  $KtKNKD\_k\_OpenTestCktMin < VaKNKD\_k\_OpenTestCktIntFilter < KtKNKD\_k\_OpenTestCktMax$

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.057	0.059	0.059	0.068	0.072	0.084	0.129	0.158	0.262	0.242	0.328	0.463	0.607	0.777	0.977	1.209	1.475

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P06DD\_P06DE\_MaxEnableTorque\_OP

**Description:** Two Stage Oil Pump Rationality Test Torque Max Enable Threshold

**Notes:** For P06DD and P06DE: KtLUBD\_M\_OP\_InDiagEngTorqMax with X Axis is defined by KnLUBD\_n\_OP\_InDiEngTorqMxRPMAs

y/x	1,000.0	1,250.0	1,500.0	1,750.0	2,000.0	2,250.0	2,500.0	2,750.0	3,000.0
1.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P06DD\_P06DE\_MaxEnableTorque\_OP\_Axis

**Description:** Engine Speed Axis for Two Stage Oil Pump maximum torque enable threshold

**Notes:** KnLUBD\_n\_OP\_InDiEngTorqMxRPMAxs X Axis for KtLUBD\_M\_OP\_InDiagEngTorqMax

y/x	1	2	3	4	5	6	7	8	9
1	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P06DD\_P06DE\_MinEnableTorque\_OP**

**Description:** Two Stage Oil Pump Rationality Test Torque Min Enable Threshold

**Notes:** For P06DD and P06DE: KtLUBD\_M\_OP\_InDiagEngTorqMin with X Axis is defined by KnLUBD\_n\_OP\_InDiEngTorqMnRPMAs

y/x	1,000.0	1,250.0	1,500.0	1,750.0	2,000.0	2,250.0	2,500.0	2,750.0	3,000.0
1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P06DD\_P06DE\_MinEnableTorque\_OP\_Axis

**Description:** Engine Speed Axis for Two Stage Oil Pump minimum torque enable threshold

**Notes:** KnLUBD\_n\_OP\_InDiEngTorqMnRPMAs X Axis for KtLUBD\_M\_OP\_InDiagEngTorqMin

y/x	1	2	3	4	5	6	7	8	9
1	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P06DD\_P06DE\_MinOilPresThresh**

**Description:** Intrusive diagnostic minimum pressure limit that is a function of Engine Speed and Oil Temperature

**Notes:** For P06DD and P06DE: KtLUBD\_p\_InDiagMinPresThresh with X Axis is defined by KnLUBD\_n\_OP\_OilPresRPMMaxs and Y Axis is defined by KnLUBD\_T\_OP\_OilPresTempAxs

y/x	-7	0	20	40	60	80	100	110	120
1,000	81	81	81	81	81	81	81	81	81
1,500	104	104	104	104	104	104	104	104	104
2,000	118	118	118	118	118	118	118	118	118
2,500	127	127	127	127	127	127	127	127	127
3,000	135	135	135	135	135	135	135	135	135
3,500	145	145	145	145	145	145	145	145	145
4,000	183	183	183	183	183	183	183	183	183
4,500	199	199	199	199	199	199	199	199	199
5,000	206	206	206	206	206	206	206	206	206



15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P06DD\_P06DE\_OP\_HiStatePressure

**Description:** Two Stage Oil Pump Oil Pressure in High State

**Notes:** For P06DD and P06DE: KtLUBD\_p\_OP\_OilPresHighState with X Axis is defined by KnLUBD\_n\_OP\_OilPresRPMMaxs and Y Axis is defined by KnLUBD\_T\_OP\_OilPresTempAxs

y/x	-7.0	0.0	20.0	40.0	60.0	80.0	100.0	110.0	120.0
1,000.0	405.0	405.0	405.0	380.0	356.0	336.0	309.0	289.0	263.0
1,500.0	417.0	417.0	417.0	402.0	386.0	374.0	358.0	347.0	331.0
2,000.0	438.0	438.0	438.0	420.0	408.0	396.0	375.0	359.0	343.0
2,500.0	453.0	453.0	453.0	434.0	409.0	394.0	376.0	361.0	344.0
3,000.0	461.0	461.0	461.0	441.0	414.0	403.0	382.0	363.0	346.0
3,500.0	482.0	482.0	482.0	451.0	427.0	405.0	376.0	361.0	349.0
4,000.0	476.0	476.0	476.0	453.0	426.0	404.0	379.0	362.0	348.0
4,500.0	476.0	476.0	476.0	453.0	426.0	404.0	379.0	362.0	348.0
5,000.0	476.0	476.0	476.0	453.0	426.0	404.0	379.0	362.0	348.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P06DD\_P06DE\_OP\_LoStatePressure

**Description:** Two Stage Oil Pump Oil Pressure in Low State

**Notes:** For P06DD and P06DE: KtLUBD\_p\_OP\_OilPresLowState with X Axis is defined by KnLUBD\_n\_OP\_OilPresRPMMaxs and Y Axis is defined by KnLUBD\_T\_OP\_OilPresTempMaxs

y/x	-7	0	20	40	60	80	100	110	120
1,000	285	285	285	272	263	252	238	229	221
1,500	293	293	293	283	276	271	263	256	248
2,000	304	304	304	294	288	282	270	261	252
2,500	311	311	311	304	293	282	267	260	253
3,000	324	324	324	308	295	285	272	265	256
3,500	326	326	326	313	299	288	274	265	259
4,000	330	330	330	319	301	291	277	267	259
4,500	330	330	330	319	301	291	277	267	259
5,000	330	330	330	319	301	291	277	267	259

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P06DD\_P06DE\_OP\_PressureRPMAxis

**Description:** Engine Speed Axis for Two Stage Oil Pump Pressure estimate

**Notes:** KnLUBD\_n\_OP\_OilPresRPMAxis X Axis for KtLUBD\_p\_OP\_OilPresHighState X Axis

y/x	1	2	3	4	5	6	7	8	9
1	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P06DD\_P06DE\_OP\_PressureTempAxis

**Description:** Oil Temperature Axis for Two Stage Oil Pump Pressure estimate

**Notes:** KnLUBD\_T\_OP\_OilPresTempAxis Y Axis for KtLUBD\_p\_OP\_OilPresHighState

y/x	1.0	2.0	3.0	4.0	5.0	6.0	7.0	8.0	9.0
1.0	-7.0	0.0	20.0	40.0	60.0	80.0	100.0	110.0	120.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P06DD\_P06DE\_OP\_StateChangeMin

**Description:** Minimum allowed pressure change on a Two Stage Oil Pump state change

**Notes:** For P06DD and P06DE: KtLUBD\_p\_OP\_StateChangeMin with X Axis is defined by KnLUBD\_n\_OP\_OilPresRPMAx and Y Axis is defined by KnLUBD\_T\_OP\_OilPresTempAx

y/x	-7.0	0.0	20.0	40.0	60.0	80.0	100.0	110.0	120.0
1,000.0	60.0	60.0	60.0	54.0	47.0	42.0	22.0	0.0	0.0
1,500.0	62.0	62.0	62.0	60.0	55.0	51.0	44.0	43.0	26.0
2,000.0	60.0	60.0	60.0	63.0	60.0	50.0	48.0	47.0	35.0
2,500.0	54.0	54.0	54.0	62.0	36.0	33.0	40.0	50.0	46.0
3,000.0	73.0	73.0	73.0	52.0	35.0	32.0	32.0	39.0	40.0
3,500.0	78.0	78.0	78.0	30.0	20.0	23.0	29.0	36.0	45.0
4,000.0	73.0	73.0	73.0	29.0	10.0	12.0	31.0	39.0	45.0
4,500.0	73.0	73.0	73.0	29.0	10.0	12.0	31.0	39.0	45.0
5,000.0	73.0	73.0	73.0	29.0	10.0	12.0	31.0	39.0	45.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P1682\_PT Relay Pull-in Run/Crank Voltage f(IAT)

**Description:** The Run/Crank voltages required to pull in the PT relay as a function of induction air temperature.

**Notes:** P1682, KtEROR\_U\_PT\_RelayPullInEnbl

y/x	23.00	85.00	95.00	105.00	125.00
1.00	7.00	8.70	9.00	9.20	10.00

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P16F3\_Delta MAP Threshold f(Desired Engine Torque)

**Description:** Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

**Notes:** P16F3, KtMAPI\_p\_ES\_TB\_MAP\_DeltaThresh

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	16.33	16.33	16.33	16.33	16.33	16.33

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P16F3\_Delta Spark Threshold f(RPM,APC)**

**Description:** Threshold for determining when the difference between commanded spark and applied spark exceeds the torque security requirement. It is a function of engine rpm and APC.

**Notes:** P16F3, KtSPRK\_phi\_DeltTorqueScrtAdv

y/x	500.00	980.74	1,461.48	1,942.23	2,422.97	2,903.71	3,384.45	3,865.20	4,345.94	4,826.68	5,307.42	5,788.16	6,268.91	6,749.65	7,230.39	7,711.13	8,191.88
80.00	125.00	22.56	26.05	28.94	26.23	24.25	27.39	29.75	32.58	32.50	31.38	28.42	27.13	27.13	27.13	27.13	27.13
160.00	125.00	19.80	20.22	21.33	21.86	22.92	26.39	27.08	27.50	26.89	25.77	24.09	23.36	23.36	23.36	23.36	23.36
240.00	125.00	16.81	15.97	15.89	18.45	21.55	25.41	24.86	23.66	22.63	21.44	20.80	20.53	20.53	20.53	20.53	20.53
320.00	125.00	15.00	15.00	15.00	16.25	18.55	23.95	22.91	20.31	19.27	18.20	17.91	17.78	17.78	17.78	17.78	17.78
400.00	125.00	15.00	15.00	15.00	15.00	16.39	22.80	21.34	17.80	16.78	15.78	15.53	15.42	15.42	15.42	15.42	15.42
480.00	125.00	15.00	15.00	15.00	15.00	15.78	19.36	18.16	15.83	15.41	15.00	15.00	15.00	15.00	15.00	15.00	15.00
560.00	125.00	15.00	15.00	15.00	15.00	15.30	16.69	16.09	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
640.00	125.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
720.00	125.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
800.00	125.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
880.00	125.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
960.00	125.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
1,040.00	125.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
1,120.00	125.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
1,200.00	125.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
1,280.00	125.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
1,360.00	125.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00



**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P16F3\_Speed Control External Load f(Oil Temp, RPM)**

**Description:** Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

**Notes:** P16F3, KtSPDC\_M\_ExternalLoad

y/x	-40.00	-20.00	-10.00	0.00	50.00	90.00
350.00	500.00	500.00	500.00	500.00	500.00	500.00
450.00	500.00	500.00	500.00	500.00	500.00	500.00
520.00	500.00	500.00	500.00	500.00	500.00	500.00
600.00	500.00	500.00	500.00	500.00	200.00	200.00
700.00	500.00	500.00	500.00	500.00	175.00	175.00
800.00	150.00	150.00	150.00	150.00	150.00	150.00
900.00	150.00	150.00	150.00	150.00	39.48	26.07
1,000.00	150.00	150.00	150.00	150.00	50.16	35.14
1,100.00	163.02	153.64	127.83	102.02	82.82	46.64
1,350.00	154.43	145.05	117.43	90.13	51.93	50.43
1,600.00	125.91	117.58	90.79	45.41	45.41	43.91
1,850.00	96.76	89.47	43.38	38.26	38.26	36.76
2,100.00	40.79	35.58	31.41	26.29	26.29	24.79
3,100.00	23.56	18.35	14.19	9.06	9.06	7.56
4,100.00	6.73	1.52	-2.65	-7.77	-7.77	-9.27
6,100.00	-4.33	-9.54	-13.70	-18.83	-18.83	-20.33
6,400.00	-5.30	-10.51	-14.68	-19.81	-19.81	-21.31

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P219A Normalizer Bank1 Table**

**Description:** Bank 1 Normalizer table used in the calculation of the Ratio for the current sample period.

**Notes:** DTCs: P219A; Calibration Name: KtFABD\_U\_Normalizer1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	800	980	1,160	1,340	1,520	1,700	1,880	2,060	2,240	2,420	2,600	2,780	2,960	3,140	3,320	3,500	3,680
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
80	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
120	54.00	54.00	52.50	25.50	45.00	65.50	48.00	51.50	40.00	28.50	58.00	55.00	72.25	55.00	55.00	9,999.00	9,999.00
160	54.00	54.00	52.50	25.50	45.00	65.50	48.00	51.50	49.00	28.50	58.00	55.00	72.25	55.00	55.00	9,999.00	9,999.00
200	76.50	76.50	94.00	55.00	55.00	83.75	71.25	79.25	66.75	43.75	52.00	45.00	73.00	60.00	60.00	9,999.00	9,999.00
240	76.50	100.25	124.00	45.00	113.00	97.00	95.50	101.00	75.50	87.00	67.00	78.50	130.00	90.00	90.00	9,999.00	9,999.00
280	9,999.00	109.75	109.75	56.25	83.00	82.00	78.00	133.25	127.00	105.75	96.50	85.00	136.25	120.00	120.00	9,999.00	9,999.00
320	9,999.00	81.75	81.75	28.25	81.50	80.00	86.25	162.75	129.25	136.75	139.25	105.00	114.50	130.00	130.00	9,999.00	9,999.00
360	9,999.00	71.75	71.75	52.00	62.75	78.00	70.00	112.25	96.00	115.00	110.00	115.00	118.50	140.00	140.00	9,999.00	9,999.00
400	9,999.00	35.00	35.00	52.00	54.50	40.00	83.00	105.75	92.75	109.75	95.00	97.50	129.50	125.00	125.00	9,999.00	9,999.00
440	9,999.00	40.00	40.00	38.00	60.00	80.00	96.50	121.25	100.00	85.00	100.50	87.50	133.00	140.00	140.00	9,999.00	9,999.00
480	9,999.00	55.00	55.00	30.00	70.00	91.00	151.50	157.50	96.75	85.00	89.25	116.00	124.50	140.00	140.00	9,999.00	9,999.00
520	9,999.00	50.00	50.00	29.00	83.50	111.50	129.75	155.50	107.25	80.00	90.00	103.00	116.00	9,999.00	9,999.00	9,999.00	9,999.00
560	9,999.00	40.25	40.25	80.00	79.75	140.00	116.50	160.75	118.00	110.00	85.75	85.75	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
640	9,999.00	40.25	40.25	90.00	100.00	138.50	99.00	163.50	130.50	110.00	106.00	106.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	9,999.00	100.00	100.00	138.50	99.00	163.50	100.00	100.00	103.00	106.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
800	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	100.00	100.00	100.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P219A Quality Factor Bank1 Table**

**Description:** Bank 1 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

**Notes:** DTCs: P219A; Calibration Name: KtFABD\_K\_QualFactor1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	800	980	1,160	1,340	1,520	1,700	1,880	2,060	2,240	2,420	2,600	2,780	2,960	3,140	3,320	3,500	3,680
40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
80	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
120	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
160	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
200	0.00	1.00	1.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
240	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
280	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
320	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
360	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
400	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
440	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
480	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
520	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
560	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
640	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	0.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
720	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
800	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P219A Variance Threshold Bank1 Table**

**Description:** Bank 1 lookup table of Variance metric used to calculate the Ratio for the current sample period

**Notes:** DTCs: P219A; Calibration Name: KtFABD\_U\_VarThresh1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	800	980	1,160	1,340	1,520	1,700	1,880	2,060	2,240	2,420	2,600	2,780	2,960	3,140	3,320	3,500	3,680
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
80	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
120	16.00	16.00	17.50	45.00	29.50	20.50	27.00	24.25	26.00	27.75	17.00	25.00	15.00	15.00	15.00	9,999.00	9,999.00
160	16.00	16.00	17.50	45.00	29.50	20.50	27.00	24.25	28.50	27.75	17.00	25.00	15.00	15.00	15.00	9,999.00	9,999.00
200	33.50	33.50	36.00	58.00	55.50	35.00	28.75	20.75	33.25	37.00	28.00	30.00	19.25	15.00	15.00	9,999.00	9,999.00
240	33.50	47.00	60.50	95.00	67.00	60.00	54.50	29.00	49.50	41.00	45.25	41.50	25.00	20.00	20.00	9,999.00	9,999.00
280	9,999.00	70.25	70.25	95.00	87.00	78.00	72.00	47.25	53.00	56.50	54.50	65.00	40.00	30.00	30.00	9,999.00	9,999.00
320	9,999.00	98.25	98.25	131.75	88.50	85.00	75.50	57.25	70.75	57.00	60.75	75.00	50.00	40.00	40.00	9,999.00	9,999.00
360	9,999.00	108.25	108.25	128.00	107.25	92.00	100.00	83.75	104.00	80.00	90.00	75.00	60.00	40.00	40.00	9,999.00	9,999.00
400	9,999.00	145.00	145.00	128.00	115.50	140.00	95.00	94.25	107.25	85.25	95.00	92.50	60.00	45.00	45.00	9,999.00	9,999.00
440	9,999.00	140.00	140.00	162.00	180.00	120.00	92.00	91.50	100.00	115.00	99.50	107.50	80.00	50.00	50.00	9,999.00	9,999.00
480	9,999.00	125.00	125.00	180.00	150.00	129.00	82.00	66.75	104.00	115.00	130.75	104.00	92.00	50.00	50.00	9,999.00	9,999.00
520	9,999.00	130.00	130.00	191.00	176.50	128.50	99.75	80.50	112.75	140.00	130.00	117.00	104.00	9,999.00	9,999.00	9,999.00	9,999.00
560	9,999.00	139.75	139.75	140.00	160.25	120.00	113.50	85.00	120.00	130.00	134.25	134.25	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
640	9,999.00	139.75	139.75	140.00	140.00	121.50	131.00	84.25	111.50	130.00	134.00	134.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	9,999.00	140.00	140.00	121.50	131.00	84.25	130.00	130.00	132.00	134.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
800	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	130.00	130.00	130.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P219B Normalizer Bank2 Table**

**Description:** Bank 2 Normalizer table used in the calculation of the Ratio for the current sample period.

**Notes:** DTCs: P219B; Calibration Name: KtFABD\_U\_Normalizer2; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	800	980	1,160	1,340	1,520	1,700	1,880	2,060	2,240	2,420	2,600	2,780	2,960	3,140	3,320	3,500	3,680
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
80	19.75	19.75	19.50	21.00	20.25	24.00	24.00	11.00	11.00	12.25	9.50	12.00	15.25	12.50	12.50	9,999.00	9,999.00
120	19.75	19.75	19.50	21.00	20.25	24.00	24.00	11.00	11.00	12.25	9.50	12.00	15.25	12.50	12.50	9,999.00	9,999.00
160	48.00	48.00	38.00	31.50	21.75	14.50	17.50	9,999.00	12.25	13.50	13.00	24.75	24.75	32.00	32.00	9,999.00	9,999.00
200	31.50	31.50	45.00	65.50	37.50	35.50	20.50	20.50	9.00	9.00	12.25	15.00	29.75	39.75	39.75	9,999.00	9,999.00
240	31.50	31.50	52.75	52.75	27.25	25.00	22.75	21.75	9,999.00	9.00	19.75	16.75	39.25	58.00	58.00	9,999.00	9,999.00
280	9,999.00	43.75	38.25	33.00	44.00	34.25	34.75	21.75	31.50	32.75	23.00	45.25	56.50	70.75	70.75	9,999.00	9,999.00
320	9,999.00	43.75	43.75	58.75	45.00	38.25	48.25	44.00	41.25	42.50	61.25	67.00	72.75	112.50	112.50	9,999.00	9,999.00
360	9,999.00	64.50	64.50	101.25	79.00	52.00	54.25	48.75	56.00	93.50	78.00	128.75	102.00	115.50	115.50	9,999.00	9,999.00
400	9,999.00	69.25	77.50	93.75	81.50	81.50	51.00	50.00	112.00	134.25	144.25	141.00	122.50	149.25	149.25	9,999.00	9,999.00
440	9,999.00	74.00	74.00	85.75	71.75	77.00	58.75	63.50	115.00	138.50	173.50	169.00	136.75	153.00	153.00	9,999.00	9,999.00
480	9,999.00	118.00	118.00	151.75	98.00	104.25	67.50	181.00	156.50	165.50	193.00	182.00	156.50	172.25	172.25	9,999.00	9,999.00
520	9,999.00	137.50	137.50	163.75	157.00	134.50	131.50	159.50	157.25	193.75	213.50	193.50	179.00	175.50	172.25	9,999.00	9,999.00
560	9,999.00	132.25	132.25	201.00	178.00	183.00	163.50	160.00	198.00	191.50	211.75	203.50	191.25	179.00	9,999.00	9,999.00	9,999.00
640	9,999.00	132.25	132.25	204.25	207.50	162.50	173.00	181.00	182.50	215.00	210.75	207.00	203.50	9,999.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	9,999.00	207.50	171.50	135.50	143.00	173.50	181.25	198.00	204.50	210.75	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
800	9,999.00	9,999.00	9,999.00	9,999.00	135.50	135.50	143.00	173.50	181.25	198.00	198.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P219B Quality Factor Bank2 Table**

**Description:** Bank 2 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

**Notes:** DTCs: P219B; Calibration Name: KtFABD\_K\_QualFactor2; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	800	980	1,160	1,340	1,520	1,700	1,880	2,060	2,240	2,420	2,600	2,780	2,960	3,140	3,320	3,500	3,680
40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
80	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
120	0.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
160	0.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
200	0.00	1.00	0.00	1.00	0.00	1.00	1.00	0.00	0.00	1.00	0.00	1.00	0.00	1.00	0.00	0.00	0.00
240	0.00	0.00	0.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	0.00	0.00	0.00
280	0.00	0.00	0.00	1.00	1.00	1.00	0.00	1.00	0.00	0.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
320	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
360	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
400	0.00	0.00	0.00	1.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
440	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
480	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
520	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
560	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
640	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
720	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
800	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P219B Variance Threshold Bank2 Table**

**Description:** Bank 2 lookup table of Variance metric used to calculate the Ratio for the current sample period

**Notes:** DTCs: P219B; Calibration Name: KtFABD\_U\_VarThresh2; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	800	980	1,160	1,340	1,520	1,700	1,880	2,060	2,240	2,420	2,600	2,780	2,960	3,140	3,320	3,500	3,680
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
80	10.50	10.50	12.00	12.00	12.50	16.50	16.50	17.00	17.00	13.00	18.00	17.00	18.00	13.50	13.50	9,999.00	9,999.00
120	10.50	10.50	12.00	12.00	12.50	16.50	16.50	17.00	17.00	13.00	18.00	17.00	18.00	13.50	13.50	9,999.00	9,999.00
160	23.50	23.50	23.00	18.00	17.00	32.00	30.25	9,999.00	16.50	16.00	22.00	18.00	14.00	12.00	12.00	9,999.00	9,999.00
200	27.00	27.00	25.25	26.00	26.50	26.50	28.50	28.50	19.00	19.00	19.25	17.00	16.50	9.00	9.00	9,999.00	9,999.00
240	27.00	27.00	28.50	28.50	36.50	34.00	31.25	41.00	9,999.00	19.00	35.50	31.00	26.00	13.00	13.00	9,999.00	9,999.00
280	9,999.00	83.00	59.00	35.00	40.00	45.00	47.25	41.00	51.50	47.00	40.00	30.00	35.00	20.00	20.00	9,999.00	9,999.00
320	9,999.00	83.00	83.00	51.50	45.00	58.00	56.00	59.00	62.00	54.00	53.50	45.00	34.50	26.00	26.00	9,999.00	9,999.00
360	9,999.00	102.00	102.00	60.00	68.50	80.00	82.00	81.00	68.00	57.00	53.00	45.00	45.00	30.50	30.50	9,999.00	9,999.00
400	9,999.00	110.00	97.75	73.00	80.00	94.00	91.00	91.00	62.00	56.00	60.00	55.00	45.00	30.00	30.00	9,999.00	9,999.00
440	9,999.00	118.00	118.00	87.00	84.00	85.00	88.00	86.50	79.50	63.00	60.00	55.00	65.00	45.00	45.00	9,999.00	9,999.00
480	9,999.00	86.00	86.00	60.00	75.00	80.00	86.00	74.00	66.00	60.00	50.00	50.00	65.00	45.00	45.00	9,999.00	9,999.00
520	9,999.00	97.50	97.50	61.50	54.50	64.50	69.50	75.00	63.00	55.00	50.00	50.00	60.00	52.50	45.00	9,999.00	9,999.00
560	9,999.00	110.50	110.50	64.00	53.50	80.00	80.00	71.50	65.00	55.00	50.00	50.00	55.00	60.00	9,999.00	9,999.00	9,999.00
640	9,999.00	110.50	110.50	74.50	85.00	113.50	94.50	67.00	81.50	60.00	50.00	50.00	50.00	9,999.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	9,999.00	85.00	109.25	133.50	142.50	114.00	108.00	75.00	62.50	50.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
800	9,999.00	9,999.00	9,999.00	9,999.00	133.50	133.50	142.50	114.00	108.00	75.00	75.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P3400\_VCE\_ECOMode\_EnableTorqueHyst

**Description:** Entry threshold for torque based VCE mode selection when eco mode is active. VCE will be enabled for torque if the torque request is less than the max VCE torque minus this calibration in Nm.

**Notes:** P3400: KaVCEC\_M\_EcoRedTrqEnterThrsh

**P3400\_VCE\_ECOMode\_EnableTorqueHyst - Part 1**

y/x	CeTGRR_e_TransGr1	CeTGRR_e_TransGr2	CeTGRR_e_TransGr3	CeTGRR_e_TransGr4	CeTGRR_e_TransGr5	CeTGRR_e_TransGr6	CeTGRR_e_TransGrEVT1
1	10	10	10	10	10	10	10

**P3400\_VCE\_ECOMode\_EnableTorqueHyst - Part 2**

y/x	CeTGRR_e_TransGrEVT2	CeTGRR_e_TransGrNcut	CeTGRR_e_TransGrRvrs	CeTGRR_e_TransGrPark	CeTGRR_e_TransGr7	CeTGRR_e_TransGr8	
1	10	10	10	10	10	10	



**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_ECOMode\_MaxTorque\_Gr1**

**Description:** CeTGRR\_e\_TransGr1 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_EcoRedTrqMaxIndThrsh

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr1 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr1 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_ECOMode\_MaxTorque\_Gr2**

**Description:** CeTGRR\_e\_TransGr2 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_EcoRedTrqMaxIndThrsh

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr2 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr2 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P3400\_VCE\_ECOMode\_MaxTorque\_Gr3

**Description:** CeTGRR\_e\_TransGr3 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_EcoRedTrqMaxIndThrsh

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr3 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr3 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_ECOMode\_MaxTorque\_Gr4**

**Description:** CeTGRR\_e\_TransGr4 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_EcoRedTrqMaxIndThrsh

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr4 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr4 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_ECOMode\_MaxTorque\_Gr5**

**Description:** CeTGRR\_e\_TransGr5 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_EcoRedTrqMaxIndThrsh

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr5 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr5 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_ECOMode\_MaxTorque\_Gr6**

**Description:** CeTGRR\_e\_TransGr6 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_EcoRedTrqMaxIndThrsh

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr6 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr6 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_ECOMode\_MaxTorque\_Gr7**

**Description:** CeTGRR\_e\_TransGr7 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_EcoRedTrqMaxIndThrsh

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr7 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr7 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_ECOMode\_MaxTorque\_Gr8**

**Description:** CeTGRR\_e\_TransGr8 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_EcoRedTrqMaxIndThrsh

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr8 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_ECOMode\_MaxTorque\_Gr8 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192



**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_ECOMode\_MaxTorque\_Mode1**

**Description:** CeTGRR\_e\_TransEVT1 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_EcoRedTrqMaxIndThrsh

**P3400\_VCE\_ECOMode\_MaxTorque\_Mode1 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_ECOMode\_MaxTorque\_Mode1 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_ECOMode\_MaxTorque\_Mode2**

**Description:** CeTGRR\_e\_TransEVT2 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_EcoRedTrqMaxIndThrsh

**P3400\_VCE\_ECOMode\_MaxTorque\_Mode2 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_ECOMode\_MaxTorque\_Mode2 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_ECOMode\_MaxTorque\_Neutral**

**Description:** CeTGRR\_e\_TransNeut maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_EcoRedTrqMaxIndThrsh

**P3400\_VCE\_ECOMode\_MaxTorque\_Neutral - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_ECOMode\_MaxTorque\_Neutral - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_ECOMode\_MaxTorque\_Park**

**Description:** CeTGRR\_e\_TransPark maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_EcoRedTrqMaxIndThrsh

**P3400\_VCE\_ECOMode\_MaxTorque\_Park - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_ECOMode\_MaxTorque\_Park - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_ECOMode\_MaxTorque\_Reverse**

**Description:** CeTGRR\_e\_TransRvrs maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_EcoRedTrqMaxIndThrsh

**P3400\_VCE\_ECOMode\_MaxTorque\_Reverse - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_ECOMode\_MaxTorque\_Reverse - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_EngineRPM\_LowerLmt**

**Description:** Engine speed lower limit for AFM

**Notes:** For P3400: KaVCEC\_n\_EngineSpeedLowerLimit with axis defined by gear state. In VCE mode, engine speed less than this will force an exit. In non-VCE mode, engine speed greater than this plus hysteresis enables VCE mode.

**P3400\_VCE\_EngineRPM\_LowerLmt - Part 1**

y/x	CeTGRR_e_TransGr1	CeTGRR_e_TransGr2	CeTGRR_e_TransGr3	CeTGRR_e_TransGr4	CeTGRR_e_TransGr5	CeTGRR_e_TransGr6	CeTGRR_e_TransGrEVT1
1	700	625	625	625	625	625	625

**P3400\_VCE\_EngineRPM\_LowerLmt - Part 2**

y/x	CeTGRR_e_TransGrEVT2	CeTGRR_e_TransGrNcut	CeTGRR_e_TransGrRvrs	CeTGRR_e_TransGrPark	CeTGRR_e_TransGr7	CeTGRR_e_TransGr8	
1	625	625	625	625	625	625	

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P3400\_VCE\_EngineRPM\_PRNDL\_LowerLmt

**Description:** Engine speed lower limit based on PRNDL position

**Notes:** For P3400: KaVCEC\_n\_EngineSpeedLwrLmtPRNDL This is the lower engine speed limit for VCER based on PRNDL position. See VCE\_PRNDL\_Axis supporting table for axis definition

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P3400\_VCE\_EngineRPM\_PRNDL\_UpperLmt

**Description:** Engine speed upper limit based on PRNDL position

**Notes:** For P3400: KaVCEC\_n\_EngineSpeedUprLmtPRNDL This is the lower engine speed limit for VCER based on PRNDL position. See VCE\_PRNDL\_Axis supporting table for axis definition

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	
1	3,000	3,000	3,000	3,000	3,000	3,000	3,000	3,000	3,000	3,000	3,000	3,000	3,000	3,000	3,000	3,000	3,000	3,000	3,000	3,000	3,000



15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P3400\_VCE\_EngineRPM\_UpperLmt

**Description:** Engine speed upper limit for AFM

**Notes:** For P3400: KaVCEC\_n\_EngineSpeedUpperLimit: with axis defined by gear state. In VCE mode, engine speed greater than this will force an exit. In non-VCE mode, engine speed less than this minus hysteresis enables VCE mode.

**P3400\_VCE\_EngineRPM\_UpperLmt - Part 1**

y/x	CeTGRR_e_TransGr1	CeTGRR_e_TransGr2	CeTGRR_e_TransGr3	CeTGRR_e_TransGr4	CeTGRR_e_TransGr5	CeTGRR_e_TransGr6	CeTGRR_e_TransGrEVT1
1	2,900	2,900	2,900	2,900	2,900	2,900	2,900

**P3400\_VCE\_EngineRPM\_UpperLmt - Part 2**

y/x	CeTGRR_e_TransGrEVT2	CeTGRR_e_TransGrNout	CeTGRR_e_TransGrRvrs	CeTGRR_e_TransGrPark	CeTGRR_e_TransGr7	CeTGRR_e_TransGr8	
1	2,900	2,900	2,900	2,900	2,900	2,900	

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P3400\_VCE\_NormalMode\_EnableTorqueHyst

**Description:** Entry threshold for torque based VCE mode selection when eco mode is NOT active. VCE will be enabled for torque if the torque request is less than the max VCE torque minus this calibration in Nm.

**Notes:** For P3400: KaVCEC\_M\_RedTrqEnterThrsh

**P3400\_VCE\_NormalMode\_EnableTorqueHyst - Part 1**

y/x	CeTGRR_e_TransGr1	CeTGRR_e_TransGr2	CeTGRR_e_TransGr3	CeTGRR_e_TransGr4	CeTGRR_e_TransGr5	CeTGRR_e_TransGr6	CeTGRR_e_TransGrEVT1
1	160	160	30	30	30	30	10

**P3400\_VCE\_NormalMode\_EnableTorqueHyst - Part 2**

y/x	CeTGRR_e_TransGrEVT2	CeTGRR_e_TransGrNcut	CeTGRR_e_TransGrRvrs	CeTGRR_e_TransGrPark	CeTGRR_e_TransGr7	CeTGRR_e_TransGr8	
1	10	10	10	10	10	10	

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_NormalMode\_MaxTorque\_Gr1**

**Description:** CeTGRR\_e\_TransGr1 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is NOT active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_RedTrqMaxIndThrsh

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr1 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	179	179	180	183	186	188	191	194	194	195	195	196	196

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr1 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	196	196	197	197	197	198	198	199	200	201	202	203	204

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_NormalMode\_MaxTorque\_Gr2**

**Description:** CeTGRR\_e\_TransGr2 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is NOT active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_RedTrqMaxIndThrsh

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr2 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	179	179	180	183	186	188	191	194	194	195	195	196	196

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr2 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	196	196	197	197	197	198	198	199	200	201	202	203	204

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_NormalMode\_MaxTorque\_Gr3**

**Description:** CeTGRR\_e\_TransGr3 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is NOT active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_RedTrqMaxIndThrsh

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr3 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr3 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_NormalMode\_MaxTorque\_Gr4**

**Description:** CeTGRR\_e\_TransGr4 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is NOT active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_RedTrqMaxIndThrsh

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr4 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr4 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_NormalMode\_MaxTorque\_Gr5**

**Description:** CeTGRR\_e\_TransGr5 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is NOT active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_RedTrqMaxIndThrsh

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr5 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr5 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_NormalMode\_MaxTorque\_Gr6**

**Description:** CeTGRR\_e\_TransGr6 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is NOT active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_RedTrqMaxIndThrsh

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr6 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr6 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192



**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_NormalMode\_MaxTorque\_Gr7**

**Description:** CeTGRR\_e\_TransGr7 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is NOT active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_RedTrqMaxIndThrsh

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr7 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr7 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_NormalMode\_MaxTorque\_Gr8**

**Description:** CeTGRR\_e\_TransGr8 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is NOT active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_RedTrqMaxIndThrsh

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr8 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_NormalMode\_MaxTorque\_Gr8 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_NormalMode\_MaxTorque\_Mode1**

**Description:** CeTGRR\_e\_TransGrEVT1 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is NOT active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_RedTrqMaxIndThrsh

**P3400\_VCE\_NormalMode\_MaxTorque\_Mode1 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_NormalMode\_MaxTorque\_Mode1 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_NormalMode\_MaxTorque\_Mode2**

**Description:** CeTGRR\_e\_TransGrEVT2 maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is NOT active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_RedTrqMaxIndThrsh

**P3400\_VCE\_NormalMode\_MaxTorque\_Mode2 - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_NormalMode\_MaxTorque\_Mode2 - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_NormalMode\_MaxTorque\_Neutral**

**Description:** CeTGRR\_e\_TransGrNeut maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is NOT active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_RedTrqMaxIndThrsh

**P3400\_VCE\_NormalMode\_MaxTorque\_Neutral - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_NormalMode\_MaxTorque\_Neutral - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_NormalMode\_MaxTorque\_Park**

**Description:** CeTGRR\_e\_TransGrPark maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is NOT active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_RedTrqMaxIndThrsh

**P3400\_VCE\_NormalMode\_MaxTorque\_Park - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_NormalMode\_MaxTorque\_Park - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P3400\_VCE\_NormalMode\_MaxTorque\_Reverse**

**Description:** CeTGRR\_e\_TransGrRvrs maximum indicated torque (Nm) allowed in VCE mode when Eco Mode is NOT active. Function of engine speed.

**Notes:** For P3400: KaVCEC\_M\_RedTrqMaxIndThrsh

**P3400\_VCE\_NormalMode\_MaxTorque\_Reverse - Part 1**

y/x	500	600	700	800	900	1,000	1,100	1,200	1,300	1,400	1,500	1,600	1,700
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**P3400\_VCE\_NormalMode\_MaxTorque\_Reverse - Part 2**

y/x	1,800	1,900	2,000	2,100	2,200	2,300	2,400	2,500	2,600	2,700	2,800	2,900	3,000
1	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192	8,192

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P3400\_VCE\_PRNDL\_Axis**

**Description:** Definition of the PRNDL state in various calibrations axis for VCE mode

**Notes:** For P3400:

**P3400\_VCE\_PRNDL\_Axis - Part 1**

y/x	1	2	3	4	5
1	0	1	2	3	4
2	CeTRGR_e_PRNDL_Drive1	CeTRGR_e_PRNDL_Drive2	CeTRGR_e_PRNDL_Drive3	CeTRGR_e_PRNDL_Drive4	CeTRGR_e_PRNDL_Drive5

**P3400\_VCE\_PRNDL\_Axis - Part 2**

y/x	6	7	8	9	10
1	5	6	7	8	9
2	CeTRGR_e_PRNDL_Drive6	CeTRGR_e_PRNDL_Drive7	CeTRGR_e_PRNDL_Drive8	CeTRGR_e_PRNDL_Neutral	CeTRGR_e_PRNDL_Reverse

**P3400\_VCE\_PRNDL\_Axis - Part 3**

y/x	11	12	13	14	15
1	10	11	12	13	14
2	CeTRGR_e_PRNDL_Park	CeTRGR_e_PRNDL_Transitional1	CeTRGR_e_PRNDL_Transitional2	CeTRGR_e_PRNDL_Transitional4	CeTRGR_e_PRNDL_Transitional7

**P3400\_VCE\_PRNDL\_Axis - Part 4**

y/x	16	17	18	19	20
1	15	16	17	18	19
2	CeTRGR_e_PRNDL_Transitional8	CeTRGR_e_PRNDL_Transitional11	CeTRGR_e_PRNDL_Transitional13	CeTRGR_e_PRNDL_Illegal	



**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P3400\_VCE\_PRNDL\_NI\_Disables**

**Description:** Disables VCE mode in certain PRNDL positions when Neutral Idle Overrides (AFM at Idle) are active.

**Notes:** For P3400: KaVCEC\_b\_DisabledForPRNDL\_NI

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
1	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P3400\_VCE\_TransGear\_Axis**

**Description:** Definition of transmission gear for various calibration axis for VCE mode

**Notes:** For P3400:

**P3400\_VCE\_TransGear\_Axis - Part 1**

y/x	1	2	3	4	5	6	7
1	CeTGRR_e_TransGr1	CeTGRR_e_TransGr2	CeTGRR_e_TransGr3	CeTGRR_e_TransGr4	CeTGRR_e_TransGr5	CeTGRR_e_TransGr6	CeTGRR_e_TransGrEVT1

**P3400\_VCE\_TransGear\_Axis - Part 2**

y/x	8	9	10	11	12	13	
1	TransGrEVT2	CeTGRR_e_TransGrNeut	CeTGRR_e_TransGrRvrs	CeTGRR_e_TransGrPark	CeTGRR_e_TransGr7	CeTGRR_e_TransGr8	

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P3400\_VCE\_TransGear\_Disables

**Description:** Disables VCE mode for specific transmission gear state.

**Notes:** For P3400: KaVCEC\_b\_DisableForTransGr See VCE\_TransGear\_Axis supporting table for axis definition

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13
1	FALSE	FALSE	FALSE	FALSE	FALSE	FALSE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P3400\_VCE\_TransGear\_DisablesNI

**Description:** Disables VCE mode for specific transmission gear state when in Neutral Idle

**Notes:** For P3400: KaVCEC\_b\_DisableForTransGrNI See VCE\_TransGear\_Axis supporting table for axis definition

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13
1	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE	TRUE

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P3400\_VCE\_VehicleSpeed\_PRNDL\_Enable

**Description:** This disables VCE mode in certain PRNDL positions when vehicle speed is equal to or above this cal.

**Notes:** For P3400: KaVCEC\_v\_DisabledForPRNDL See VCE\_PRNDL\_Axis supporting table for axis definition

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
1	0	0	0	0	0	318	0	0	0	0	0	0	0	0	0	0	0	0	0	0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P3400\_VCEStartupDelayTime

**Description:** Engine running enablement based on an engine off time

**Notes:** For P3400: KtVCEC\_t\_StartupDelayTime with axis a function of engine mode not running time (VeEMDC\_t\_EngModeNotRun)

y/x	0	5	10	30	60	100	120	140	160	180	240	300	360	420	600	700	800
1	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20

15 OBDG08A ECM Diagnostic Supporting Tables

Unique Supporting table - P0461, P2066, P2636: Transfer Pump Enable Time Table

**Description:** Data is TransferPumpOnTimeLimit (in seconds) and Axis is Fuel Level in %

**Notes:** KtFLVC\_t\_XferFuelPmpOnTmLim

**P0461, P2066, P2636: Transfer Pump Enable Time Table - Part 1**

y/x	0	3	6	9	13	16	19	22	25	28	31	34	38	41	44	47	50
1	0	450	450	450	450	450	450	450	450	506	563	619	675	731	788	844	900

**P0461, P2066, P2636: Transfer Pump Enable Time Table - Part 2**

y/x	53	56	59	63	66	69	72	75	78	81	84	88	91	94	97	100	
1	956	1,013	1,069	1,125	1,181	1,238	1,294	1,350	1,406	1,463	1,519	1,575	1,631	1,688	1,744	1,800	

15 OBDG08A ECM Diagnostic Supporting Tables

Unique Supporting table - P0521\_Eng\_Load\_Stability\_Weighting\_Factor - Single Stage Oil Pump

**Description:** Engine Load Stability Weighting Factor - Single Stage Oil Pump

**Notes:** KtEOPD\_r\_EngLoadStblWeight with axis as Engine Load Stability defined by KnEOPD\_m\_EngLoadStabilityBpt

y/x	0	5	10	20	30	50	100	200	399
1	1.00	1.00	1.00	0.30	0.00	0.00	0.00	0.00	0.00



15 OBDG08A ECM Diagnostic Supporting Tables

Unique Supporting table - P0521\_Eng\_Load\_Stability\_Weighting\_Factor\_Axis - Single Stage Oil Pump

**Description:** Engine Load Stability Weighting Factor Axis - Single Stage Oil Pump

**Notes:** KnEOPD\_m\_EngLoadStabilityBpt engine load axis used by KtEOPD\_r\_EngLoadStblWeight

y/x	1	2	3	4	5	6	7	8	9
1	0	5	10	20	30	50	100	200	399

15 OBDG08A ECM Diagnostic Supporting Tables

Unique Supporting table - P0521\_Eng\_Oil\_Pred\_Weighting\_Factor - Single Stage Oil Pump

**Description:** Oil Pressure Predicted Weighting Factor - Single Stage Oil Pump

**Notes:** KtEOPD\_r\_EOP\_PredictWeight with axis as Predicted Oil Pressure defined by KnEOPD\_p\_EngOilPredictedBpt

y/x	0	170	200	275	360	375	400	500	600
1	0.00	0.10	1.00	1.00	1.00	1.00	1.00	0.86	0.00

15 OBDG08A ECM Diagnostic Supporting Tables

Unique Supporting table - P0521\_Eng\_Oil\_Pred\_Weighting\_Factor\_Axis - Single Stage Oil Pump

**Description:** Oil Pressure Predicted Weighting Factor Axis - Single Stage Oil Pump

**Notes:** KnEOPD\_p\_EngOilPredictedBpt predicted oil pressure axis used by KtEOPD\_r\_EOP\_PredictWeight

y/x	1	2	3	4	5	6	7	8	9
1	0	170	200	275	360	375	400	500	600

15 OBDG08A ECM Diagnostic Supporting Tables

Unique Supporting table - P0521\_Oil\_Temp\_Weighting\_Factor - Single Stage Oil Pump

**Description:** Oil Temperature Weighting Factor - Single Stage Oil Pump

**Notes:** KtEOPD\_r\_EOT\_Weight with axis as Oil Temperature defined by KnEOPD\_T\_EngFilteredBpt

y/x	-10	-5	60	80	90	100	120	130	140
1	0.00	0.70	0.70	0.70	0.70	0.70	0.70	0.00	0.00

15 OBDG08A ECM Diagnostic Supporting Tables

Unique Supporting table - P0521\_Oil\_Temp\_Weighting\_Factor\_Axis - Single Stage Oil Pump

**Description:** Oil Temperature Weighting Factor Axis - Single Stage Oil Pump

**Notes:** KnEOPD\_T\_EngFilteredBpt oil temperature axis for use by KtEOPD\_r\_EOT\_Weight

y/x	1	2	3	4	5	6	7	8	9
1	-10	-5	60	80	90	100	120	130	140

15 OBDG08A ECM Diagnostic Supporting Tables

Unique Supporting table - P0521\_RPM\_Weighting\_Factor - Single Stage Oil Pump

**Description:** Engine RPM Weighting Factor - Single Stage Oil Pump

**Notes:** KtEOPD\_r\_EngSpdWeight with axis as Engine RPM defined by KnEOPD\_n\_EngSpdFilteredBpt

y/x	0	900	1,000	1,500	2,000	2,500	2,600	3,000	6,000
1	0.00	0.00	0.45	0.45	0.45	0.45	0.00	0.00	0.00

15 OBDG08A ECM Diagnostic Supporting Tables

Unique Supporting table - P0521\_RPM\_Weighting\_Factor\_X\_Axis - Single Stage Oil Pump

**Description:** Engine RPM Weighting Factor Axis - Single Stage Oil Pump

**Notes:** KnEOPD\_n\_EngSpdFilteredBpt Engine RPM Axis for use by KtEOPD\_r\_EngSpdWeight

y/x	1	2	3	4	5	6	7	8	9
1	0	900	1,000	1,500	2,000	2,500	2,600	3,000	6,000

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KaFCLP\_U\_SlphrIntgIOfst\_Thrsh

**Description:** Integral Offset voltage thresholds (bank and cell specific calcs) used with KeFCLP\_Pct\_CatAccuSlphrPostDsbl to check for sulphur poisoning.

**Notes:** millivolts

y/x	CiOXYR_O2_PostCat1	CiOXYR_O2_PostCat2
CiFCLP_Decel	1,000	1,000
CiFCLP_Idle	1,000	1,000
CiFCLP_Cruise	1,000	1,000
CiFCLP_LightAccel	1,000	1,000
CiFCLP_HeavyAccel	1,000	1,000



15 OBDG08A ECM Diagnostic Supporting Tables

**Initial Supporting table - Closed Loop Enable Clarification - KcFCLP\_Cnt\_O2RdyCyclesThrsh**

**Description:** Number of post catalyst oxygen sensor samples which must be outside not ready window before post oxygen sensor is READY.

**Notes:** Time (events \* 12.5 milliseconds)

y/x	1
1	10

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KcFULC\_O2\_SensorReadyEvents

**Description:** Number of times an oxygen sensor value must be in range before declaring it ready

**Notes:** Time (events \* 12.5 milliseconds)

y/x	1
1	10

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP\_Pct\_CatAccuSlphrPostDsbl

**Description:** Sulphur percent threshold above which post integral learning is disabled if the threshold criteria KaFCLP\_U\_SlphrIntglOfst\_Thrsh is also met.

**Notes:** Percent

y/x	1
1	75

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP\_T\_IntegrationCatalystMax

**Description:** Maximum allowed estimated catalytic converter temperature for post O2 integral terms to be updated.

**Notes:** Modeled catalyst Temperature in Celcius

y/x	1
1	950

15 OBDG08A ECM Diagnostic Supporting Tables

**Initial Supporting table - Closed Loop Enable Clarification - KeFCLP\_T\_IntegrationCatalystMin**

**Description:** Minimum allowed estimated catalytic converter temperature to begin using post O2 integration correction terms. Converter temperature must remain above this threshold to ramp-in the post O2 integration adjustments. Once the ramp-in has started, a converter temperature below this threshold will freeze the ramp-in multiplier. Post O2 integration will not be allowed below this converter temperature

**Notes:** Modeled catalyst Temperature in Celcius

y/x	1
1	500

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KfFCLL\_T\_AdaptiveHiCoolant

**Description:** LTM learning is inhibited if the engine coolant temperature is above this calibration.

**Notes:** Degrees Celcius

y/x	1
1	140

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KfFCLL\_T\_AdaptiveLoCoolant

**Description:** LTM learning is inhibited if the engine coolant temperature is below this calibration.

**Notes:** Degrees Celcius

y/x	1
1	39

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KfFCLP\_U\_O2ReadyThrshLo

**Description:** Lower threshold defining not ready window for post oxygen sensor voltage.

**Notes:** Voltage in millivolts

y/x	1
1	1,100



15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KfFULC\_U\_O2\_SensorReadyThrshLo

**Description:** Lower limit checked against when determining if an oxygen sensor is in range

**Notes:** Voltage in millivolts

y/x	1
1	1,795

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFCLL\_p\_AdaptiveLowMAP\_Limit

**Description:** KtFCLL\_p\_AdaptiveLowMAP\_Limit

**Notes:** MAP in KPa

y/x	65	70	75	80	85	90	95	100	105
1	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFCLP\_t\_PostIntglDisableTime

**Description:** Disable integral offset after engine start for this amount of time.

**Notes:** Time in seconds

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	220.0	220.0	220.0	196.0	120.0	72.0	60.0	60.0	52.0	41.0	35.0	32.0	36.0	40.0	44.0	60.0	60.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFCLP\_t\_PostIntglRampInTime

**Description:** Time required to ramp integral offset to desired value.

**Notes:** Time in seconds

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	60.0	60.0	60.0	60.0	60.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFSTA\_t\_ClosedLoopAutostart

**Description:** Engine run time following an autostart, as a function of begin run coolant, which must be exceeded to enable CLOSED LOOP.

**Notes:** Time in seconds: Hybrid use Only

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	360.0	300.0	240.0	180.0	130.0	55.0	45.0	35.0	20.0	10.0	8.0	5.0	5.0	8.0	8.0	8.0	8.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFSTA\_t\_ClosedLoopTime

**Description:** Engine run time, as a function of startup coolant temperature, which must be exceeded to enable CLOSED LOOP.

**Notes:** Time in seconds

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	360.0	300.0	240.0	180.0	130.0	55.0	45.0	35.0	20.0	10.0	8.0	5.0	5.0	8.0	8.0	8.0	8.0

15 OBDG08A ECM Diagnostic Supporting Tables

**Initial Supporting table - P0089 - P163A - P228C - P228D - P0191 - KtFHPD\_t\_PumpCntrlEngRunThrsh**

**Description:** The High Pressure Control Performance Diagnostic and Pump Current Diagnostic will not run when the engine run time is below this timer following an engine start.

**Notes:**

y/x	-30	-20	-10	0	10	20	80	100	110
1	120.0	120.0	80.0	60.0	60.0	60.0	60.0	80.0	120.0

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P00C6 - KtFHPC\_p\_HighPressStart**

**Description:** This calibration is the minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery

**Notes:**

y/x	-40	-35	-30	-25	-20	-10	0	8	16	20	24	32	40	60	80	90	112
0	11.0	12.0	10.0	10.0	8.0	4.0	3.0	2.0	1.0	1.0	1.0	1.0	1.0	2.0	3.0	3.0	3.0
13	11.0	12.0	10.0	10.0	8.0	4.0	3.0	2.0	1.0	1.0	1.0	1.0	1.0	2.0	3.0	3.0	3.0
25	12.0	12.0	12.0	12.0	8.0	4.0	3.0	3.0	2.0	2.0	2.0	2.0	2.0	3.0	3.0	3.0	3.0
38	13.0	13.0	13.0	13.0	10.0	8.6	4.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
50	13.0	13.0	13.0	13.0	10.0	8.6	4.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
63	13.0	13.0	13.0	13.0	10.0	8.6	6.0	5.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
75	13.0	13.0	13.0	13.0	10.0	8.6	6.0	5.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
88	13.0	13.0	13.0	13.0	10.0	8.6	7.0	6.0	5.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
100	13.0	13.0	13.0	13.0	10.0	8.6	7.5	7.0	6.0	5.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0



15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P00C6 - KtFHPC\_t\_HighPressStartTmout

**Description:** High Pressure Pump Control Mode will exit (Fuel will be delivered) if this timeout in seconds is reached.

**Notes:**

y/x	-40	-35	-30	-25	-20	-10	0	8	16	20	24	32	40	60	80	90	112
1	10.0	10.0	10.0	10.0	10.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P00C6 - KtFHPD\_Cnt\_HPS\_PressFallLoThrsh

**Description:** The maximum acceptable counts of fuel rail pressure below KtFHPD\_p\_HPS\_PressFallLoThrsh after High Pressure Start (HPS) is executed but before engine is in run mode.

**Notes:**

y/x	-40	-35	-30	-25	-20	-10	0	8	16	20	24	32	40	60	80	90	112
0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
13	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
25	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
38	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
50	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
63	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
75	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
88	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
100	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P00C6 - KtFHPD\_p\_HPS\_PressFallLoThrsh

**Description:** The minimum acceptable value of fuel rail pressure after High Pressure Start (HPS) is executed. This ensures the pressure does not fall off drastically after High Pressure Start (HPS) is executed, but before engine is in run mode.

**Notes:** Axes are

y/x	-40	-35	-30	-25	-20	-10	0	8	16	20	24	32	40	60	80	90	112
0	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
13	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
25	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
38	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
50	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
63	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
75	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
88	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
100	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0191 - KeFHPD\_p\_DPSPrsDiffFailThrsh (Dual Sensors)

Description:

Notes:

y/x	1.00
1.00	1.00

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0191 - KtFHPD\_cmp\_DPS\_FailHiThrsh (Dual Sensors)

**Description:** High fail limit of fuel control due to pressure sensor error as Function of desired pressure

**Notes:**

y/x	0.00	0.40	2.50	3.00	8.00	20.00	24.00	28.00	32.00
1.00	1.22	1.22	1.22	1.22	1.22	1.22	1.22	1.22	1.22

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0191 - KtFHPD\_cmp\_DPS\_FailLoThrsh (Dual sensors)

**Description:** Low fail limit of fuel control due to pressure sensor error as Function of desired pressure

**Notes:**

y/x	0.00	0.40	2.50	3.00	8.00	20.00	24.00	28.00	32.00
1.00	0.86	0.86	0.86	0.86	0.86	0.86	0.86	0.86	0.86

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0191 - KtFHPD\_Cnt\_SnsPrfIdlePumpOffDly

**Description:** The delay counter following the disabling of the high pressure pump used Only for the Sensor Performance Idle Test

**Notes:**

y/x	0	13	25	38	50	63	75	88	100
65	390.0	390.0	390.0	390.0	390.0	390.0	390.0	390.0	390.0
70	380.0	380.0	380.0	380.0	380.0	380.0	380.0	380.0	380.0
75	370.0	370.0	370.0	370.0	370.0	370.0	370.0	370.0	370.0
80	360.0	360.0	360.0	360.0	360.0	360.0	360.0	360.0	360.0
85	350.0	350.0	350.0	350.0	350.0	350.0	350.0	350.0	350.0
90	340.0	340.0	340.0	340.0	340.0	340.0	340.0	340.0	340.0
95	330.0	330.0	330.0	330.0	330.0	330.0	330.0	330.0	330.0
100	320.0	320.0	320.0	320.0	320.0	320.0	320.0	320.0	320.0
105	320.0	320.0	320.0	320.0	320.0	320.0	320.0	320.0	320.0

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0191 - KtFHPD\_t\_SnsPrfStuckCrankTmout

**Description:** The maximum crank time allowed before allowing the Sensor Performance Stuck Test to fail

**Notes:**

y/x	-30	-20	-10	0	10	20	80	100	110
1	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0



**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0420\_BestFailingOSCTableB1**

**Description:** This table is a 9x17 table of baseline Best Failing (e.g. threshold converter) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow,the BestFailing OSC value is found within this table for the measured temp and airflow and is used along with the OSC\_TimeRaw (and the WorstPassing value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the identified BPU converter that is used for MIL illumination across the specific temp and airflow range for a given program.

**Notes:** KtCATD\_t\_1\_OSC\_BestFailing - Used for norm ratio calculation for P0420

y/x	6.19	6.61	7.03	7.46	7.88	8.30	8.72	9.15	9.57	9.99	10.42	10.84	11.26	11.68	12.11	12.53	12.95
636.00	1.27	1.11	1.03	0.94	0.86	0.77	0.76	0.68	0.66	0.63	0.58	0.57	0.57	0.52	0.51	0.46	0.42
670.00	1.34	1.19	1.09	1.00	0.92	0.84	0.83	0.82	0.79	0.77	0.63	0.62	0.60	0.55	0.54	0.49	0.47
704.00	1.42	1.28	1.19	1.06	0.98	0.91	0.90	0.88	0.86	0.85	0.69	0.66	0.64	0.58	0.57	0.53	0.51
737.00	1.50	1.40	1.27	1.12	1.04	0.96	0.95	0.94	0.93	0.91	0.77	0.73	0.68	0.64	0.61	0.58	0.54
771.00	1.59	1.50	1.37	1.19	1.10	1.05	1.04	1.03	1.01	0.99	0.85	0.80	0.72	0.71	0.67	0.62	0.60
805.00	1.68	1.59	1.44	1.32	1.19	1.13	1.12	1.11	1.10	1.05	0.92	0.87	0.80	0.79	0.73	0.68	0.65
839.00	1.78	1.65	1.52	1.41	1.28	1.18	1.16	1.15	1.14	1.09	0.99	0.93	0.89	0.87	0.80	0.78	0.76
873.00	1.88	1.71	1.60	1.46	1.36	1.22	1.21	1.19	1.17	1.12	1.05	0.98	0.97	0.96	0.87	0.84	0.82
906.00	1.99	1.80	1.67	1.50	1.41	1.28	1.26	1.21	1.19	1.15	1.12	1.06	1.05	1.03	0.91	0.87	0.84

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P0420\_P0430\_CatmonMinAirflowForWarmCatalystDetermination

**Description:** This is a 1x3 table with the axis being engine coolant temperature. The implementation of this cal value as a table also included some changes to the way that the WarmedUpEvents counter increments and resets. To summarize, whenever WarmedUpEvents resets to 0 (this could be either at startup, if the closed throttle time exceeds a cal value, or if the predicted exhaust temperature falls below the ExhWarmMin cal value), the appropriate MinAirflowToWrmupCat value is chosen from the table based on engine coolant at the time the WarmedUpEvents counter reset to 0. This cal value is used along with the min exhaust temp to increment the WarmedUpEvents counter.

**Notes:** KtCATD\_dm\_MinAirFlowToWrmCat - Used for P0420 and P0430. Axis is the engine coolant and the output is the minimum airflow required to warmup the catalyst.

y/x	0	45	90
1	12	8	4

15 OBDG08A ECM Diagnostic Supporting Tables

**Initial Supporting table - P0420\_P0430\_CatmonMinEngineRunTimeToEnable**

**Description:** This cal value is a 1x5 array of minimum engine run time values based on powerup coolant temperatures. When the appropriate required minimum engine run time value is chosen based on the coolant temperature at powerup, this value is the minimum time from engine start before stabilized conditions are met. Used in determining if a ValidIdleIsMet condition exists.

**Notes:** KtCATD\_t\_EngRunTimeMin - Used for P0420 and P0430. Axis is the coolant and the output is the min engine run time

y/x	40	50	60	70	80
1	30	30	30	30	30

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0420\_WorstPassingOSCTableB1**

**Description:** This table is a 9x17 table of WorstPassing (e.g. 120k) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the WorstPassing OSC value is found within this table for the measured temp and airflow and is used along with the OSC\_TimeRaw (and the BestFailing OSC value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the WPA part across the temp and airflow range.

**Notes:** KtCATD\_t\_1\_OSC\_WorstPassing - Used for NormRatio calculation for P0420

y/x	6.19	6.61	7.03	7.46	7.88	8.30	8.72	9.15	9.57	9.99	10.42	10.84	11.26	11.68	12.11	12.53	12.95
636.00	2.25	1.81	1.67	1.57	1.42	1.35	1.20	1.15	1.14	1.08	1.02	1.00	0.93	0.80	0.76	0.73	0.72
670.00	2.27	1.84	1.69	1.60	1.44	1.37	1.23	1.18	1.17	1.09	1.04	1.02	0.95	0.84	0.83	0.81	0.75
704.00	2.30	1.88	1.71	1.62	1.46	1.40	1.26	1.21	1.20	1.12	1.05	1.04	0.98	0.89	0.87	0.85	0.78
737.00	2.33	1.91	1.74	1.64	1.48	1.43	1.29	1.25	1.24	1.16	1.07	1.06	1.01	0.93	0.92	0.90	0.80
771.00	2.36	1.94	1.78	1.67	1.52	1.46	1.33	1.28	1.27	1.21	1.12	1.09	1.04	0.97	0.95	0.93	0.83
805.00	2.40	1.98	1.81	1.69	1.56	1.48	1.37	1.31	1.30	1.25	1.16	1.13	1.08	1.01	0.98	0.95	0.85
839.00	2.43	2.01	1.84	1.72	1.60	1.51	1.42	1.35	1.33	1.30	1.21	1.15	1.12	1.08	1.01	0.98	0.88
873.00	2.46	2.06	1.88	1.74	1.65	1.55	1.47	1.40	1.36	1.33	1.26	1.18	1.16	1.13	1.04	1.01	0.91
906.00	2.50	2.11	1.92	1.78	1.70	1.60	1.52	1.45	1.41	1.36	1.32	1.23	1.21	1.18	1.06	1.04	0.93

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0430\_BestFailingOSCTableB2**

**Description:** This table is a 9x17 table of baseline Best Failing (e.g. threshold converter) OSC times for catalyst Bank 2. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow,the BestFailing OSC value is found within this table for the measured temp and airflow and is used along with the OSC\_TimeRaw (and the WorstPassing value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the identified BPU converter that is used for MIL illumination across the specific temp and airflow range for a given program.

**Notes:** KtCATD\_t\_2\_OSC\_BestFailing - Used to calculate norm ratio for P0430

y/x	6.19	6.61	7.03	7.46	7.88	8.30	8.72	9.15	9.57	9.99	10.42	10.84	11.26	11.68	12.11	12.53	12.95
636.00	1.37	1.20	1.12	1.08	1.07	1.05	0.90	0.83	0.82	0.82	0.80	0.76	0.67	0.66	0.65	0.64	0.62
670.00	1.44	1.28	1.19	1.12	1.11	1.10	0.94	0.89	0.88	0.85	0.83	0.80	0.70	0.69	0.68	0.67	0.64
704.00	1.53	1.34	1.25	1.17	1.16	1.15	0.99	0.94	0.93	0.88	0.87	0.83	0.74	0.72	0.71	0.70	0.66
737.00	1.61	1.42	1.33	1.24	1.22	1.20	1.04	1.01	0.98	0.93	0.93	0.87	0.78	0.76	0.74	0.73	0.69
771.00	1.70	1.50	1.38	1.36	1.28	1.25	1.13	1.12	1.04	0.96	0.95	0.91	0.83	0.82	0.80	0.78	0.77
805.00	1.80	1.58	1.42	1.39	1.30	1.29	1.18	1.18	1.07	1.00	0.98	0.95	0.89	0.84	0.81	0.80	0.80
839.00	1.90	1.67	1.47	1.42	1.32	1.31	1.20	1.19	1.09	1.03	1.01	0.98	0.94	0.88	0.83	0.82	0.80
873.00	2.00	1.77	1.51	1.45	1.35	1.33	1.21	1.21	1.12	1.05	1.04	1.00	0.98	0.91	0.85	0.83	0.81
906.00	2.11	1.86	1.56	1.46	1.38	1.36	1.22	1.21	1.14	1.07	1.06	1.03	1.02	0.95	0.87	0.86	0.83

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P0430\_WorstPassingOSCTableB2**

**Description:** This table is a 9x17 table of WorstPassing (e.g. 120k) OSC times for catalyst Bank 2. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the WorstPassing OSC value is found within this table for the measured temp and airflow and is used along with the OSC\_TimeRaw (and the BestFailing OSC value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the WPA part across the temp and airflow range.

**Notes:** KtCATD\_t\_2\_OSC\_WorstPassing - Used for Norm Ratio calculation for P0430

y/x	6.19	6.61	7.03	7.46	7.88	8.30	8.72	9.15	9.57	9.99	10.42	10.84	11.26	11.68	12.11	12.53	12.95
636.00	1.98	1.86	1.77	1.55	1.52	1.45	1.34	1.31	1.22	1.16	1.11	1.06	1.02	1.00	0.97	0.92	0.85
670.00	2.04	1.89	1.79	1.57	1.54	1.47	1.35	1.32	1.23	1.18	1.13	1.08	1.03	1.02	0.99	0.94	0.86
704.00	2.09	1.94	1.81	1.59	1.57	1.49	1.37	1.34	1.27	1.21	1.15	1.09	1.06	1.04	1.00	0.96	0.88
737.00	2.14	1.98	1.84	1.62	1.60	1.51	1.39	1.36	1.29	1.23	1.18	1.11	1.08	1.05	1.01	0.98	0.89
771.00	2.19	2.02	1.86	1.65	1.64	1.54	1.42	1.39	1.32	1.25	1.20	1.13	1.10	1.08	1.03	1.00	0.90
805.00	2.23	2.06	1.88	1.69	1.68	1.57	1.44	1.41	1.33	1.27	1.22	1.16	1.13	1.10	1.05	1.02	0.91
839.00	2.27	2.11	1.90	1.70	1.68	1.60	1.46	1.43	1.35	1.29	1.25	1.18	1.16	1.13	1.07	1.04	0.92
873.00	2.31	2.15	1.93	1.73	1.71	1.65	1.48	1.45	1.38	1.31	1.27	1.22	1.19	1.15	1.09	1.06	0.94
906.00	2.34	2.19	1.94	1.75	1.73	1.69	1.50	1.48	1.40	1.34	1.29	1.24	1.21	1.18	1.12	1.08	0.95

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P050D\_P1400\_CatalystLightOffExtendedEngineRunTimeExit

**Description:** Exit Catalyst Warm-up mode if Engine Run Time is greater than this value. This table is based on percent ethanol (x-axis) and catmon's NormRatio\_EWMA value (y-axis). The NormRatio\_EWMA value determines the state of the catalyst. Typically, NormRatio\_EWMA values below 0.35 (0 is bad and 1 is good) represent catalysts that have degraded. The emission performance of these degraded catalysts can be improved by extending catalyst light off of GetE85R\_Pct\_FFS\_CompAtEngFloat.

**Notes:** KtCSEC\_t\_ExtendedEngineExit. Used for both P050D and P1400.

y/x	0	25	50	75	100
0.000	20	20	20	20	20
0.125	20	20	20	20	20
0.250	20	20	20	20	20
0.375	20	20	20	20	20
0.500	20	20	20	20	20
0.625	20	20	20	20	20
0.750	20	20	20	20	20
0.875	20	20	20	20	20
1.000	20	20	20	20	20

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P1400\_ColdStartDiagnosticDelayBasedOnEngineRunTime

**Description:** Quality weight-based on engine run time. This allows adjustment of the weighting factors at various engine run times in order to prevent the updating of the cumulative quality timer or to change the value of the average qualified residual energy calculation to prevent false Fails of the diagnostic under circumstances inappropriate to update the calculation of the average qualified residual value.

**Notes:** KtCSED\_K\_TimeWght - This is used for P1400.

y/x	0	2	2	4	5	10	15	20	30
1	0	0	1	1	1	1	1	1	1



15 OBDG08A ECM Diagnostic Supporting Tables

**Initial Supporting table - P1400\_ColdStartDiagnosticDelayBasedOnEngineRunTimeCalAxis**

**Description:** This is the x-axis for the KtCSED\_K\_TimeWght calibration table. Refer to the description for KtCSED\_K\_TimeWght for details.

**Notes:** KnCSED\_t\_TimeWght - This is used for P1400.

y/x	1	2	3	4	5	6	7	8	9
1	0	2	2	4	5	10	15	20	30

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P1400\_EngineSpeedResidual\_Axis**

**Description:** This calibration is used as the x-axis for KtCSED\_dm\_Exh. An engine speed value will be chosen from this axis based on the value of VeSPDR\_n\_EngDsrd or actual engine speed. Subsequently, the engine speed value chosen from KnCSED\_n\_Exh determines the appropriate exhaust airflow value from the KtCSED\_dm\_Exh calibration table.

**Notes:** KnCSED\_n\_Exh - This is used for P1400

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	650	725	750	785	800	850	900	950	1,000	1,040	1,080	1,100	1,150	1,175	1,200	1,300	1,500

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P1400\_EngineSpeedResidual\_Table

**Description:** This 1x17 table of engine exhaust flow values is used to calculate both the desired and the actual engine exhaust flow based on desired and actual engine speed. The desired engine exhaust flow is gathered from the desired engine speed (VeSPDR\_n\_EngDsrd). The value used for the actual engine exhaust flow is based on the actual engine RPM value.

**Notes:** KtCSED\_dm\_Exh - This is used for P1400

y/x	650	725	750	785	800	850	900	950	1,000	1,040	1,080	1,100	1,150	1,175	1,200	1,300	1,500
1	2	2	5	7	7	7	7	7	10	11	12	12	12	12	12	12	12

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P1400\_SparkResidual\_Axis

**Description:** Calibratable axis into KtCSED\_E\_ExhEngyPerUnitMass. This is a table of spark values. Spark value used for desired spark is the desired spark during cat light off. Actual spark value used is the final commanded spark.

**Notes:** KnCSED\_phi\_ExhEngyPerUnitMass - Used for P1400

y/x	1.00	2.00	3.00	4.00	5.00	6.00	7.00	8.00	9.00
1	-7	-5	-2	-1	3	5	10	12	15

**15 OBDG08A ECM Diagnostic Supporting Tables**

**Initial Supporting table - P1400\_SparkResidual\_Table**

**Description:** Predicted engine-out energy potential based on either the desired cold start spark advance value or the actual spark advance value. ExhEngyPerUnitMass calibration is used to calculate both desired exhaust energy and actual energy. The desired and actual exhaust energy per unit mass values are used in part to calculate the desired exhaust energy per unit time and actual exhaust energy per unit time. Both desired and actual go into the residual exhaust energy per unit time calculation.

**Notes:** KtCSED\_E\_ExhEngyPerUnitMass

y/x	-7	-5	-2	-1	3	5	10	12	15
1	1.10	1.10	1.10	0.98	0.98	0.98	0.98	0.60	0.60

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P057B KtBRKI\_K\_CmpltTestPointWeight

Description:

Notes:

y/x	0.000	0.050	0.080	0.250	0.350	0.450	0.550	0.750	1.000
1	0	1	1	1	1	1	1	1	1

15 OBDG08A ECM Diagnostic Supporting Tables

Initial Supporting table - P057B KtBRKI\_K\_FastTestPointWeight

Description:

Notes:

y/x	0.000	0.050	0.080	0.250	0.350	0.450	0.550	0.750	1.000
1	0	1	1	1	1	1	1	1	1

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P2635 Max Fuel Flow**

**Description:** P2635 Max Fuel Flow allowed -- diagnostic is disabled above this value

**Notes:**

y/x	200.0000	250.0000	300.0000	350.0000	400.0000	450.0000	500.0000	550.0000	600.0000
4.5000	36.8984	36.8984	36.8984	34.5625	32.0469	29.5703	27.1328	24.7266	22.3594
6.0000	36.8984	36.8984	36.8984	34.5625	32.0469	29.5703	27.1328	24.7266	22.3594
7.5000	36.8984	36.8984	36.8984	34.5625	32.0469	29.5703	27.1328	24.7266	22.3594
9.0000	36.8984	36.8984	36.8984	34.5625	32.0469	29.5703	27.1328	24.7266	22.3594
10.5000	36.8984	36.8984	36.8984	34.5625	32.0469	29.5703	27.1328	24.7266	22.3594
12.0000	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	35.0625	32.5938	30.1719
13.5000	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984
15.0000	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984
16.5000	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984
18.0000	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984
19.5000	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984
21.0000	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984
22.5000	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984
24.0000	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984
25.5000	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984
27.0000	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984
28.5000	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984	36.8984



**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P2635 Threshold High**

**Description:** P2635 Threshold - Under performing

**Notes:** Measured value = instantaneous Filtered Fuel Pressure Error

y/x	200.0	250.0	300.0	350.0	400.0	450.0	500.0	550.0	600.0
0.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
1.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
3.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
4.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
6.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
7.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
9.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
10.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
12.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
13.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
15.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
16.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
18.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
19.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
21.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
22.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
24.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
25.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
27.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
28.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
30.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
31.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
33.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
34.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
36.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
37.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
39.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
40.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
42.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
43.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
45.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
46.5	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0
48.0	30.0	37.5	45.0	52.5	60.0	67.5	75.0	82.5	90.0

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P2635 Threshold High RePass**

**Description:** P2635 Threshold Hysteresis - Under performing

**Notes:** Measured value = instantaneous Filtered Fuel Pressure Error

y/x	200.0	250.0	300.0	350.0	400.0	450.0	500.0	550.0	600.0
0.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
1.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
3.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
4.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
6.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
7.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
9.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
10.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
12.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
13.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
15.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
16.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
18.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
19.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
21.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
22.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
24.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
25.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
27.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
28.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
30.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
31.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
33.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
34.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
36.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
37.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
39.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
40.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
42.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
43.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
45.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
46.5	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5
48.0	25.5	31.9	38.3	44.6	51.0	57.4	63.8	70.1	76.5

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P2635 Threshold Low**

**Description:** P2635 Threshold - Over performing

**Notes:** Measured value = instantaneous Filtered Fuel Pressure Error

y/x	200.0	250.0	300.0	350.0	400.0	450.0	500.0	550.0	600.0
0.0	-260.0	-210.0	-160.0	-110.0	-60.0	-67.5	-75.0	-82.5	-90.0
1.5	-145.0	-125.0	-102.5	-81.3	-60.0	-67.5	-75.0	-82.5	-90.0
3.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
4.5	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
6.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
7.5	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
9.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
10.5	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
12.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
13.5	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
15.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
16.5	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
18.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
19.5	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
21.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
22.5	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
24.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
25.5	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
27.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
28.5	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
30.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
31.5	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
33.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
34.5	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
36.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
37.5	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
39.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
40.5	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
42.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
43.5	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
45.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
46.5	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0
48.0	-30.0	-37.5	-45.0	-52.5	-60.0	-67.5	-75.0	-82.5	-90.0

**15 OBDG08A ECM Diagnostic Supporting Tables**  
**Initial Supporting table - P2635 Threshold Low RePass**

**Description:** P2635 Threshold Hysteresis - Over performing

**Notes:** Measured value = instantaneous Filtered Fuel Pressure Error

y/x	200.0	250.0	300.0	350.0	400.0	450.0	500.0	550.0	600.0
0.0	-221.0	-178.5	-136.0	-93.5	-51.0	-57.4	-63.8	-70.1	-76.5
1.5	-123.3	-106.3	-87.1	-69.1	-51.0	-57.4	-63.8	-70.1	-76.5
3.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
4.5	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
6.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
7.5	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
9.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
10.5	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
12.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
13.5	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
15.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
16.5	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
18.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
19.5	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
21.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
22.5	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
24.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
25.5	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
27.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
28.5	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
30.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
31.5	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
33.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
34.5	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
36.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
37.5	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
39.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
40.5	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
42.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
43.5	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
45.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
46.5	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5
48.0	-25.5	-31.9	-38.3	-44.6	-51.0	-57.4	-63.8	-70.1	-76.5

## 15 OBDG08A Fault Bundle Definitions

<b>Bundle Name:</b> 5VoltReferenceA_FA
P0641
<b>Bundle Name:</b> 5VoltReferenceB_FA
P0651
<b>Bundle Name:</b> 5VoltReferenceMAP_OOR_Fit
P0697
<b>Bundle Name:</b> A/F Imbalance Bank1
P219A
<b>Bundle Name:</b> A/F Imbalance Bank2
P219B
<b>Bundle Name:</b> AAP_SnsrCktFA
Naturally aspirated: P2228, P2229. Turbocharged: P0237, P0238
<b>Bundle Name:</b> AAP_SnsrCktFP
Naturally aspirated: P2228, P2229. Turbocharged: P0237, P0238
<b>Bundle Name:</b> AAP_SnsrFA
Naturally Aspirated: P2227, P2228, P2229, P2230. Turbocharged: P0237, P0238.
<b>Bundle Name:</b> AAP_SnsrTFTKO
Naturally Aspirated: P2227, P2228, P2229, P2230. Turbocharged: P0237, P0238.
<b>Bundle Name:</b> AAP2_SnsrCktFA
P2228, P2229
<b>Bundle Name:</b> AAP2_SnsrCktFP
P2228, P2229
<b>Bundle Name:</b> AAP2_SnsrFA
P2227, P2228, P2229, P2230
<b>Bundle Name:</b> AAP2_SnsrTFTKO
P2227, P2228, P2229, P2230
<b>Bundle Name:</b> AAP3_SnsrCktFA
P222C, P222D
<b>Bundle Name:</b> AAP3_SnsrCktFP
P222C, P222D
<b>Bundle Name:</b> AccCktLo_FA
P2537
<b>Bundle Name:</b> AcceleratorPedalFailure
P2122, P2123, P2127, P2128, P2138, P0697, P06A3
<b>Bundle Name:</b> ACCMLostComm
U016B
<b>Bundle Name:</b> ACFailedOnSD
See ACCM Document

## 15 OBDG08A Fault Bundle Definitions

<b>Bundle Name:</b> ACHighSidePressSnsrCktFA
P0532, P0533
<b>Bundle Name:</b> ACThrmIRefrigSpdVld
See ACCM Document
<b>Bundle Name:</b> AfterThrottlePressTFTKO
Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.
<b>Bundle Name:</b> AfterThrottlePressureFA
Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.
<b>Bundle Name:</b> AfterThrottleVacuumTFTKO
Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.
<b>Bundle Name:</b> AIR System FA
P0411, P2440, P2444
<b>Bundle Name:</b> AIRPumpControlCircuit FA
P0418, P2257, P2258
<b>Bundle Name:</b> AIRSystemPressureSensor FA
P2430, P2431, P2432, P2433, P2435, P2436, P2437, P2438
<b>Bundle Name:</b> AIRValveControlCircuit FA
P0412, P041F, P044F
<b>Bundle Name:</b> AllTwoStepDrvr_TFTKO
P16CF, P16D2, P16D3, P2645, P2648, P2649
<b>Bundle Name:</b> AllVCE_Driver_TFTKO
P16CF, P16D2, P16D3, P2645, P2648, P2649
<b>Bundle Name:</b> AmbientAirDefault
Baro Sensor Present: P2227, P2228, P2229, P2230. No Baro Sensor Present: P0101, P0102, P0103, P0106, P0107, P0108, P0111, P0112, P0113, P0114, P0121, P0122, P0123, P012B, P012C, P012D, P0222, P0223, P1221
<b>Bundle Name:</b> AmbPresDfltStatus
Baro Sensor Present: P2227, P2228, P2229, P2230. No Baro Sensor Present: P0101, P0102, P0103, P0106, P0107, P0108, P0111, P0112, P0113, P0114, P0121, P0122, P0123, P012B, P012C, P012D, P0222, P0223, P1221
<b>Bundle Name:</b> AmbPresSnsr2_CktFA
P222C, P222D
<b>Bundle Name:</b> AmbPresSnsrCktFA
P2228, P2229
<b>Bundle Name:</b> AmbPresSnsrCktFP
P2228, P2229
<b>Bundle Name:</b> AnyCamPhaser_FA
P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, P2088, P2089, P2090, P2091, P2092, P2093, P2094, P2095, P05CC, P05CD, P05CE, P05CF, P25CA, P25CB, P25CC, P25CD, P25CE, P25CF

## 15 OBDG08A Fault Bundle Definitions

<b>Bundle Name:</b> AnyCamPhaser_TFTKO
P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, P2088, P2089, P2090, P2091, P2092, P2093, P2094, P2095, P05CC, P05CD, P05CE, P05CF, P25CA, P25CB, P25CC, P25CD, P25CE, P25CF
<b>Bundle Name:</b> BrakeBoosterSensorFA
P0556, P0557, P0558
<b>Bundle Name:</b> BrakeBoosterVacuumValid
P0556, P0557, P0558
<b>Bundle Name:</b> BSTR_b_BoostSnsrFA
P0236, P0237, P0238
<b>Bundle Name:</b> BSTR_b_ExcsvBstFA
P226B
<b>Bundle Name:</b> BSTR_b_ExcsvBstTFTKO
P226B
<b>Bundle Name:</b> BSTR_b_IC_Pmp_EffPerfTFTKO
P026A
<b>Bundle Name:</b> BSTR_b_IC_PmpCktFA
P023A, P023C
<b>Bundle Name:</b> BSTR_b_PCA_CktFA
P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P0247, P0249, P0250
<b>Bundle Name:</b> BSTR_b_PCA_CktLoFA
P0034, P0047, P0245, P0249
<b>Bundle Name:</b> BSTR_b_PCA_CktLoTFTKO
P0034, P0047, P0245, P0249
<b>Bundle Name:</b> BSTR_b_PCA_CktTFTKO
P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P0247, P0249, P0250
<b>Bundle Name:</b> BSTR_b_PCA_FA
P0234, P0299, P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P2261, P0247, P0249, P0250
<b>Bundle Name:</b> BSTR_b_PCA_PstnSnsrFA
P003A, P2564, P2565
<b>Bundle Name:</b> BSTR_b_PCA_PstnSnsrTFTKO
P003A, P2564, P2565
<b>Bundle Name:</b> BSTR_b_PCA_TFTKO
P0234, P0299, P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P2261, P0247, P0249, P0250
<b>Bundle Name:</b> BSTR_b_PresCntrlTooHiFA
P0234
<b>Bundle Name:</b> BSTR_b_PresCntrlTooHiTFTKO
P0234
<b>Bundle Name:</b> BSTR_b_PresCntrlTooLoFA

## 15 OBDG08A Fault Bundle Definitions

P0299
<b>Bundle Name:</b> BSTR_b_PresCntrlTooLoTFTKO
P0299
<b>Bundle Name:</b> BSTR_b_PstnCntrlFA
P166D, P166E
<b>Bundle Name:</b> BSTR_b_PstnCntrlTooHiFA
P166E
<b>Bundle Name:</b> BSTR_b_PstnCntrlTooHiTFTKO
P166E
<b>Bundle Name:</b> BSTR_b_PstnCntrlTooLoFA
P166D
<b>Bundle Name:</b> BSTR_b_PstnCntrlTooLoTFTKO
P166D
<b>Bundle Name:</b> BSTR_b_TurboBypassA_StkFA
P2261
<b>Bundle Name:</b> BSTR_b_TurboBypassCktFA
P0033, P0034, P0035, P00C0, P00C1, P00C2
<b>Bundle Name:</b> BSTR_b_TurboBypassCktTFTKO
P0033, P0034, P0035, P00C0, P00C1, P00C2
<b>Bundle Name:</b> BSTR_b_TurboBypB_CktFA
P00C0, P00C1, P00C2
<b>Bundle Name:</b> BSTR_b_TurboBypB_CktTFTKO
P00C0, P00C1, P00C2
<b>Bundle Name:</b> CamLctnExhFA
P0017, P0019, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> CamLctnIntFA
P0016, P0018, P0340, P0341, P0345, P0346
<b>Bundle Name:</b> CamSensor_FA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> CamSensor_TFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> CamSensorAnyLctnTFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> CamSensorAnyLocationFA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> CamSensorFA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> CamSensorTFTKO



## 15 OBDG08A Fault Bundle Definitions

P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> CatalystSysEfficiencyLoB1_FA
P0420
<b>Bundle Name:</b> CatalystSysEfficiencyLoB2_FA
P0430
<b>Bundle Name:</b> Clutch Sensor FA
P0806, P0807, P0808
<b>Bundle Name:</b> ClutchPositionSensorCircuitHi FA
P0808
<b>Bundle Name:</b> ClutchPositionSensorCircuitLo FA
P0807
<b>Bundle Name:</b> ClutchPstnSnsr FA
P0806, P0807, P0808
<b>Bundle Name:</b> ClutchPstnSnsrCktHi FA
P0808
<b>Bundle Name:</b> ClutchPstnSnsrCktLo FA
P0807
<b>Bundle Name:</b> ClutchPstnSnsrNotLearned
P080A
<b>Bundle Name:</b> CommBusAOff_VICM_FA
U0073
<b>Bundle Name:</b> CommBusBOff_VICM_FA
U0074
<b>Bundle Name:</b> CoolingFanSpeedTooHigh_FA
P0495
<b>Bundle Name:</b> CrankCamCorrelationTFTKO
P0016, P0017, P0018, P0019
<b>Bundle Name:</b> CrankExhaustCamCorrelationFA
P0017, P0019
<b>Bundle Name:</b> CrankExhaustCamCorrFA
P0017, P0019
<b>Bundle Name:</b> CrankIntakeCamCorrelationFA
P0016, P0018
<b>Bundle Name:</b> CrankIntakeCamCorrFA
P0016, P0018
<b>Bundle Name:</b> CrankSensor_FA
P0335, P0336
<b>Bundle Name:</b> CrankSensor_TFTKO

## 15 OBDG08A Fault Bundle Definitions

P0335, P0336
<b>Bundle Name:</b> CrankSensorFA
P0335, P0336
<b>Bundle Name:</b> CrankSensorFaultActive
P0335, P0336
<b>Bundle Name:</b> CrankSensorTestFailedTKO
P0335, P0336
<b>Bundle Name:</b> CrankSensorTFTKO
P0335, P0336
<b>Bundle Name:</b> CylDeacDriverFault
P3401, P03403, P03404, P3409, P03411, P03412, P3417, P3419, P3420, P3425, P3427, P3428, P3433, P3435, P3436, P3441, P3443, P3444, P3449, P3451, P3452, P3457, P3459, P3460
<b>Bundle Name:</b> CylDeacSystemTFTKO
P3400
<b>Bundle Name:</b> CylnderDeacDriverTFTKO
P3401, P3403, P3404, P3409, P3411, P3412, P3417, P3419, P3420, P3425, P3427, P3428, P3433, P3435, P3436, P3441, P3443, P3444, P3449, P3451, P3452, P3457, P3459, P3460
<b>Bundle Name:</b> ECT_Sensor_Ckt_FA
P0117, P0118
<b>Bundle Name:</b> ECT_Sensor_Ckt_FP
P0117, P0118
<b>Bundle Name:</b> ECT_Sensor_Ckt_High_FP
P0118
<b>Bundle Name:</b> ECT_Sensor_Ckt_Low_FP
P0117
<b>Bundle Name:</b> ECT_Sensor_Ckt_TFTKO
P0117, P0118
<b>Bundle Name:</b> ECT_Sensor_Ckt_TPTKO
P0117, P0118
<b>Bundle Name:</b> ECT_Sensor_DefaultDetected
P0116, P0117, P0118, P0119, P111E
<b>Bundle Name:</b> ECT_Sensor_FA
P0116, P0117, P0118, P0119, P0128, P111E
<b>Bundle Name:</b> ECT_Sensor_Perf_FA
P0116, P111E
<b>Bundle Name:</b> ECT_Sensor_TFTKO
P0116, P0117, P0118, P0119, P0128, P111E
<b>ECT_Sensor_TFTKO - Other Definitions:</b>

## 15 OBDG08A Fault Bundle Definitions

<b>Bundle Name:</b> EGRValve_FP
P0405, P0406, P042E
<b>Bundle Name:</b> EGRValveCircuit_FA
P0403, P0404, P0405, P0406, P0489, P0490, P042E
<b>Bundle Name:</b> EGRValveCircuit_TFTKO
P0403, P0404, P0405, P0406, P0489, P0490
<b>Bundle Name:</b> EGRValvePerformance_FA
P0404, P042E
<b>Bundle Name:</b> EGRValvePerformance_TFTKO
P0404, P042E
<b>Bundle Name:</b> ELCP_PumpCircuit_FA
P2400, P2401, P2402
<b>Bundle Name:</b> ELCP_SwitchCircuit_FA
P2418, P2419, P2420
<b>Bundle Name:</b> ELCP_Circuit_FA
P24BA, P24BB
<b>Bundle Name:</b> EngineMetalOvertempActive
P1258
<b>Bundle Name:</b> EngineMisfireDetected_FA
P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308
<b>Bundle Name:</b> EngineMisfireDetected_TFTKO
P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308
<b>Bundle Name:</b> EngineModeNotRunTimer_FA
P2610
<b>Bundle Name:</b> EngineModeNotRunTimerError
P2610
<b>Bundle Name:</b> EnginePowerLimited
P0068, P00C8, P00C9, P00CA, P0090, P0091, P0092, P0122, P0123, P0191, P0192, P0193, P0222, P0223, P0601, P0604, P0606, P0697, P06A3, P06DB, P06DE, P0A1D, P1104, P127A, P127C, P127D, P15F2, P160D, P160E, P1682, P16A0, P16A1, P16A2, P16F3, P2100, P2101, P2102, P2103, P2122, P2123, P2127, P2128, P2135, P2138, P215B, P2176, P228C, P228D, U0073, U0074, U0293, U1817
<b>Bundle Name:</b> EngineTorqueEstInaccurate
EngineMisfireDetected_FA, FuelInjectorCircuit_FA, FuelInjectorCircuit_TFTKO, FuelTrimSystemB1_FA, FuelTrimSystemB2_FA, MAF_SensorTFTKO, MAP_SensorTFTKO, EGRValuePerformance_FA
<b>Bundle Name:</b> EngModeNotRunTmErr
P2610
<b>Bundle Name:</b> EngOilModeledTempValid
ECT_Sensor_FA, IAT_SensorCircuitFA
<b>Bundle Name:</b> EngOilPressureSensorCktFA
P0522, P0523

## 15 OBDG08A Fault Bundle Definitions

<b>Bundle Name:</b> EngOilPressureSensorFA
P0521, P0522, P0523
<b>Bundle Name:</b> EngOilTempFA
EngOilTempSensorCircuitFA, EngOilModeledTempValid, P16F3
<b>EngOilTempFA - Other Definitions:</b>
P16F3 with GetXOYR_b_SecurityFlt(CeXOYR_e_EOTR_SecurityFlt)
<b>Bundle Name:</b> EngOilTempSensorCircuitFA
P0197, P0198
<b>Bundle Name:</b> Ethanol Composition Sensor FA
P0178, P0179, P2269
<b>Bundle Name:</b> EvapEmissionSystem_FA
P0455, P0446
<b>Bundle Name:</b> EvapExcessPurgePsbl_FA
ELCP sealed/vented fuel system, P0442, P0455, P0458 OR Conventional fuel system, P0442, P0455, P0458, P0496
<b>Bundle Name:</b> EvapFlowDuringNonPurge_FA
P0496
<b>Bundle Name:</b> EvapPurgeSolenoidCircuit_FA
P0443, P0458, P0459
<b>Bundle Name:</b> EvapReducedPurgePsbl_FA
ELCP sealed/vented fuel system, P0443, P0446, P0449, P0459, P0497, P0499, P1463, P2419, P2422 OR Conventional fuel system, P0443, P0446, P0455, P0459, P0498
<b>Bundle Name:</b> EvapSmallLeak_FA
P0442
<b>Bundle Name:</b> EvapVentSolenoidCircuit_FA
P0449, P0498, P0499
<b>Bundle Name:</b> ExhaustCamSensor_FA
P0017, P0019, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> ExhaustCamSensor_TFTKO
P0017, P0019, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> ExhaustCamSensorFA
P0017, P0019, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> ExhaustCamSensorTFTKO
P0017, P0019, P0365, P0366, P0390, P0391
<b>Bundle Name:</b> ExhaustVVT_Enabled
<b>ExhaustVVT_Enabled - Other Definitions:</b>
ExhaustVVT_Enabled = TRUE if:
<b>CrankExhaustCamCorrelationFA</b> diagnostic has executed and passed AND Cam Edge Locations have been learned AND

## 15 OBDG08A Fault Bundle Definitions

**CrankSensor\_TFTKO** = False AND  
**ExhaustCamSensorTFTKO** = False AND  
**CamLctnExhFA** = False AND  
(**IntakeVVT\_Enabled** = True OR Intake Park Position (CePHSR\_e\_Advanced) = CePHSR\_e\_Retarded) AND  
Engine Mode Run = True AND  
Engine Power Requested = True AND  
**ExhEngineSpeed** is Enabled AND  
**ExhOilPressure** is Enabled AND  
**ExhEngineOilTemp** is Enabled AND  
(Engine Power Requested = True  
OR  
**CSER\_Enabled** AND Engine Speed > 8,000.00 AND Engine Mode Run Time > **ColdStartEngRunning**)

\*\*\*\*\*

**ExhEngineSpeed** is Enabled if:  
**LoRpmHiEnbIEc** < Engine RPM < **HiEngSpdLoEnbIEc**

**ExhEngineSpeed** Disables if:  
Engine RPM < **LoRpmLoDsblEc**  
OR  
Engine RPM > **HiEngSpdHiDsblEc**

\*\*\*\*\*

**ExhOilPressure** is Enabled if:  
(Oil Pressure Sensor In Use ( 1.00 ) = 1.00 (Note: 1.00 equals TRUE) AND  
Oil Pressure Sensor Present ( 1.00 ) = 1.00 (Note: 1.00 equals Present) AND  
Oil Pressure > **LoPresHiEnbIEc** for **EngOilPressEnbIEc** sec)  
OR  
(Engine RPM > **LoRpmHiEnbIEc** for **EngOilPressEnbIEc** sec)

**ExhOilPressure** Disables if:  
Oil Pressure Sensor In Use ( 1.00 ) = 1.00 (Note: 1.00 equals TRUE) AND  
Oil Pressure Sensor Present ( 1.00 ) = 1.00 (Note: 1.00 equals Present) AND  
Oil Pressure < **LoPresLoDsblEc**

\*\*\*\*\*

**ExhEngineOilTemp** is Enabled if:  
-10.00 < Engine Oil Temp < 135.00

**ExhEngineOilTemp** Disables if:  
Engine Oil Temp < -12.00  
OR  
Engine Oil Temp > 140.00

**Bundle Name:** FanOutputDriver\_FA

## 15 OBDG08A Fault Bundle Definitions

P0480, P0481, P0482, P0691, P0692, P0693, P0694, P0695, P0696, P1485 (EREV), P1486 (EREV), P1487 (EREV)
<b>Bundle Name:</b> FHPD_b_HPC_PresErrNeg_FA
P228D
<b>Bundle Name:</b> FHPD_b_HPC_PresErrNeg_TFTKO
P228D
<b>Bundle Name:</b> FHPD_b_HPC_PresErrPos_FA
P228C
<b>Bundle Name:</b> FHPD_b_HPC_PresErrPos_TFTKO
P228C
<b>Bundle Name:</b> FHPD_b_HPC_Windup_TFTKO
P0089
<b>Bundle Name:</b> FHPD_b_HPC_Windup_FA
P0089
<b>Bundle Name:</b> FHPD_b_PumpCurr_FA
P163A
<b>Bundle Name:</b> FHPD_b_PumpCurr_TFTKO
P163A
<b>Bundle Name:</b> FHPR_b_FRP_SnsrCkt_FA
P0192, P0193, P127C, P127D
<b>Bundle Name:</b> FHPR_b_FRP_SnsrCkt_TFTKO
P0192, P0193, , P127C, P127D
<b>Bundle Name:</b> FHPR_b_FRP_SnsrPerfDiag_FA
P0191, P127A
<b>Bundle Name:</b> FHPR_b_FRP_SnsrPerfDiag_TFTKO
P0191, P127A
<b>Bundle Name:</b> FHPR_b_PumpCkt_FA
P0090, P0091, P0092, P00C8, P00C9, P00CA
<b>Bundle Name:</b> FHPR_b_PumpCkt_TFTKO
P0090, P0091, P0092, P00C8, P00C9, P00CA
<b>Bundle Name:</b> FourWheelDriveLowStateInvalid
P2771
<b>Bundle Name:</b> FTP_SensorCircuit_FA
P0452, P0453
<b>Bundle Name:</b> FuelInjectorCircuit_FA
PFI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P0274, P0277, P0280, P0283 SIDI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216E, P217B, P217E, P2148, P2151, P2154, P2157, P216C, P216F, P217C, P217F, P1248, P1249, P124A, P124B, P124C, P124D, P124E, P124F
<b>Bundle Name:</b> FuelInjectorCircuit_TFTKO

## 15 OBDG08A Fault Bundle Definitions

PFI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P0274, P0277, P0280, P0283  
 SIDI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216E, P217B, P217E, P2148, P2151, P2154, P2157, P216C, P216F, P217C, P217F, P1248, P1249, P124A, P124B, P124C, P124D, P124E, P124F

**Bundle Name:** FuelLevelDataFault

P0461, P0462, P0463, P2066, P2067, P2068

**Bundle Name:** FuelPumpRlyCktFA

P0627, P0628, P0629

**Bundle Name:** FuelTankPressureSnsrCkt\_FA

P0452, P0453

**Bundle Name:** FuelTrimSystemB1\_FA

P0171, P0172

**Bundle Name:** FuelTrimSystemB1\_TFTKO

P0171, P0172

**Bundle Name:** FuelTrimSystemB2\_FA

P0174, P0175

**Bundle Name:** FuelTrimSystemB2\_TFTKO

P0174, P0175

**Bundle Name:** HumidityFA

P0097, P0098, P11C2, P11C3, P2227, P2228, P2229, P2230

**Bundle Name:** HumTempSnsrCktFA

P0097, P0098

**Bundle Name:** HumTempSnsrCktFP

P0097, P0098

**Bundle Name:** HumTempSnsrFA

P0096, P0097, P0098, P0099

**Bundle Name:** IAC\_SystemRPM\_FA

P0506, P0507

**Bundle Name:** IAT\_ContCorrFA

P2199

**Bundle Name:** IAT\_SensorCircuitFA

P0112, P0113

**Bundle Name:** IAT\_SensorCircuitFP

P0112, P0113

**Bundle Name:** IAT\_SensorCircuitTFTKO

P0112, P0113

**Bundle Name:** IAT\_SensorFA

P0111, P0112, P0113, P0114

**Bundle Name:** IAT\_SensorTFTKO

## 15 OBDG08A Fault Bundle Definitions

P0111, P0112, P0113, P0114

**Bundle Name:** IgnitionOffTimer\_FA

P2610

**Bundle Name:** IgnitionOffTimeValid

P2610

**Bundle Name:** IgnitionOutputDriver\_FA

P0351, P0352, P0353, P0354, P0355, P0356, P0357, P0358, P2300, P2301, P2303, P2304, P2306, P2307, P2309, P2310, P2312, P2313, P2315, P2316, P2318, P2319, P2321, P2322

**Bundle Name:** IntakeCamSensor\_FA

P0016, P0018, P0340, P0341, P0345, P0346

**Bundle Name:** IntakeCamSensor\_TFTKO

P0016, P0018, P0340, P0341, P0345, P0346

**Bundle Name:** IntakeCamSensorFA

P0016, P0018, P0340, P0341, P0345, P0346

**Bundle Name:** IntakeCamSensorTFTKO

P0016, P0018, P0340, P0341, P0345, P0346

**Bundle Name:** IntakeVVT\_Enabled

**IntakeVVT\_Enabled - Other Definitions:**

**IntakeVVT\_Enabled** = TRUE if:

**CrankIntakeCamCorrelationFA** diagnostic has executed and passed AND

Cam Edge Locations have been learned AND

**CrankSensor\_TFTKO** = False AND

**IntakeCamSensorTFTKO** = False AND

**CamLctnIntFA** = False AND

Engine Mode Run = True AND

Engine Power Requested = True AND

**IntEngineSpeed** is Enabled AND

**IntOilPressure** is Enabled AND

**IntEngineOilTemp** is Enabled AND

(Engine Power Requested = True

OR

**CSER\_Enabled** AND Engine Speed > 8,000.00 AND Engine Mode Run Time > **ColdStartEngRunning**)

\*\*\*\*\*

**IntEngineSpeed** is Enabled if:

**LoRpmHiEnbllc** < Engine RPM < **HiEngSpdLoEnbllc**

**IntEngineSpeed** Disables if:

Engine RPM < **LoRpmLoDsbllc**

OR

Engine RPM > **HiEngSpdHiDsbllc**



## 15 OBDG08A Fault Bundle Definitions

\*\*\*\*\*

**IntOilPressure** is Enabled if:  
(Oil Pressure Sensor In Use ( 1.00) = 1.00 (Note: 1.00 equals "TRUE") AND  
Oil Pressure Sensor Present ( 1.00) = 1.00 (Note: 1.00 equals "Present") AND  
Oil Pressure > **LoPresHiEnblc** for **EngOilPressEnblc** sec)  
OR  
(Engine RPM > **LoRpmHiEnblc** for **EngOilPressEnblc** sec)

**IntOilPressure** Disables if:  
Oil Pressure Sensor In Use ( 1.00) = 1.00 (Note: 1.00 equals "TRUE") AND  
Oil Pressure Sensor Present ( 1.00) = 1.00 (Note: 1.00 equals "Present") AND  
Oil Pressure < **LoPresLoDsblc**

\*\*\*\*\*

**IntEngineOilTemp** is Enabled if:  
0.00 < Engine Oil Temp < 160.00

**IntEngineOilTemp** Disables if:  
Engine Oil Temp < -12.00  
OR  
Engine Oil Temp > 140.00

**Bundle Name:** IntkCamPhaser\_FA

P0010, P0011, P0020, P0021, P05CC, P05CD, P2088, P2089, P2092, P2093, P25CA, P25CB, P25CC, P25CD, P25CE, P25CF

**Bundle Name:** IntkCamPhsrCircuit\_TFTKO

P0010, P0020, P2088, P2089, P2092, P2093, P25CA, P25CB, P25CC, P25CD, P25CE, P25CF

**Bundle Name:** KS\_Ckt\_Perf\_B1B2\_FA

P0324, P0325, P0326, P0327, P0328, P0330, P0332, P0333, P06B6, P06B7

**Bundle Name:** LostCommBCM\_FA

U0140

**Bundle Name:** LostCommBusB\_VICM\_FA

U182D

**Bundle Name:** LowFuelConditionDiagnostic

**LowFuelConditionDiagnostic - Other Definitions:**

Flag set to TRUE if the fuel level < 10.0 % AND  
No Active DTCs: FuelLevelDataFault, P0462, P0463 for at least 30.0 seconds

**Bundle Name:** MAF\_SensorCircuitFA

P0102, P0103, P010C, P010D

**Bundle Name:** MAF\_SensorCircuitTFTKO

P0102, P0103, P010C, P010D

**Bundle Name:** MAF\_SensorFA

P0101, P0102, P0103, P010B, P010C, P010D

**Bundle Name:** MAF\_SensorFP

P0102, P0103, P010C, P010D

## 15 OBDG08A Fault Bundle Definitions

<b>Bundle Name:</b> MAF_SensorPerfFA
P0101
<b>Bundle Name:</b> MAF_SensorPerfTFTKO
P0101
<b>Bundle Name:</b> MAF_SensorTFTKO
P0101, P0102, P0103, P010B, P010C, P010D
<b>Bundle Name:</b> MAF_Snsr1_FA
P0101, P0102, P0103
<b>Bundle Name:</b> MAF_Snsr2_FA
P010B, P010C, P010D
<b>Bundle Name:</b> MAF_SnsrCktFA
P0102, P0103, P010C, P010D
<b>Bundle Name:</b> MAF_SnsrCktTFTKO
P0102, P0103, P010C, P010D
<b>Bundle Name:</b> MAP_EngineVacuumStatus
P0106, P0107, P0108 Fault Active OR P0107, P0108 Fault Pending
<b>Bundle Name:</b> MAP_SensorCircuitFA
P0107, P0108
<b>Bundle Name:</b> MAP_SensorCircuitFP
P0107, P0108
<b>Bundle Name:</b> MAP_SensorFA
P0106, P0107, P0108
<b>Bundle Name:</b> MAP_SensorPerfFA
P0106
<b>Bundle Name:</b> MAP_SensorPerfTFTKO
P0106
<b>Bundle Name:</b> MAP_SensorTFTKO
P0106, P0107, P0108
<b>Bundle Name:</b> MnfdTempSensorCktFA
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
<b>Bundle Name:</b> MnfdTempSensorCktFP
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
<b>Bundle Name:</b> MnfdTempSensorCktTFTKO
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
<b>Bundle Name:</b> MnfdTempSensorFA
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
<b>Bundle Name:</b> MnfdTempSensorTFTKO

## 15 OBDG08A Fault Bundle Definitions

Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.

**Bundle Name:** ModuleOffTime\_FA

P2610

**Bundle Name:** ModuleOffTimeErr

P2610

**Bundle Name:** O2S\_Bank\_1\_TFTKO

P0131, P0132, P0134, P2A00

**Bundle Name:** O2S\_Bank\_2\_TFTKO

P0151, P0152, P0154, P2A03

**Bundle Name:** O2S\_Bank\_1\_Sensor\_1\_FA

P2A00, P0131, P0132, P0133, P0134, P0135, P0053, P1133, P015A, P015B, P0030

**Bundle Name:** O2S\_Bank\_1\_Sensor\_2\_FA

P013A, P013B, P013E, P013F, P2270, P2271, P0137, P0138, P0140, P0141, P0054, P0036

**Bundle Name:** O2S\_Bank\_2\_Sensor\_1\_FA

P2A03, P0151, P0152, P0153, P0154, P0155, P0059, P1153, P015C, P015D, P0050

**Bundle Name:** O2S\_Bank\_2\_Sensor\_2\_FA

P013C, P013D, P014A, P014B, P2272, P2273, P0157, P0158, P0160, P0161, P0060, P0056

**Bundle Name:** OAT\_AmbientFilteredFA

ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, IAT\_SensorFA, ECT\_Sensor\_DefaultDetected, MAF\_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, ECT\_Sensor\_DefaultDetected. IAT-Based OAT: not applicable. All other cases: not applicable.

**Bundle Name:** OAT\_AmbientSensorFA

ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, ECT\_Sensor\_DefaultDetected. IAT-Based OAT: not applicable. All other cases: not applicable.

**Bundle Name:** OAT\_EstAmbTemp\_FA

ELCP sealed/vented fuel system, P0071, P0072, P0073, P0502, P0503, P0722, P0723 OR Conventional fuel system, P0071, P0072, P0073, P0074, P2610

**Bundle Name:** OAT\_PtEstFiltFA

ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, IAT\_SensorFA, ECT\_Sensor\_DefaultDetected, MAF\_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, ECT\_Sensor\_DefaultDetected. IAT-Based OAT: VehicleSpeedSensor\_FA, IAT\_SensorFA, MAF\_SensorFA. All other cases: EngModeNotRunTmErr, VehicleSpeedSensor\_FA, IAT\_SensorFA, ECT\_Sensor\_DefaultDetected.

**Bundle Name:** OAT\_PtEstRawFA

ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor\_FA, ECT\_Sensor\_DefaultDetected. IAT-Based OAT: IAT\_SensorFA. All other cases: IAT\_SensorFA, ECT\_Sensor\_DefaultDetected.

**Bundle Name:** OilPmpCktFA

P06DA, P06DB, P06DC

**OilPmpCktFA - Other Definitions:**

Output Driver Codes

**Bundle Name:** OilPmpFA

P06DA, P06DB, P06DC, P06DD, P06DE

**OilPmpFA - Other Definitions:**

## 15 OBDG08A Fault Bundle Definitions

FA only for Output Driver and rationality
<b>Bundle Name:</b> OilPmpStuckHigh
P06DA, P06DB, P06DD
<b>OilPmpStuckHigh - Other Definitions:</b> TFTKO and FA
<b>Bundle Name:</b> OilPmpStuckLow
P06DC, P06DE
<b>OilPmpStuckLow - Other Definitions:</b> TFTKO and FA
<b>Bundle Name:</b> OilPmpTFTKO
P06DA, P06DB, P06DC, P06DD, P06DE
<b>OilPmpTFTKO - Other Definitions:</b> TFTKO only for Output Driver and rationality
<b>Bundle Name:</b> OilSenDiagBndl_TFTKO
P055B, P055C, P055D
<b>Bundle Name:</b> PO2S_Bank_1_Snsr_2_FA
P0137, P0138, P0140, P0036, P0054, P0141, P2270, P2271
<b>Bundle Name:</b> PO2S_Bank_2_Snsr_2_FA
P0157, P0158, P0160, P0056, P0060, P0161, P2272, P2273
<b>Bundle Name:</b> PostCatFuelTrimHiB1
P2097
<b>Bundle Name:</b> PostCatFuelTrimHiB2
P2099
<b>Bundle Name:</b> PostCatFuelTrimLoB1
P2096
<b>Bundle Name:</b> PostCatFuelTrimLoB2
P2098
<b>Bundle Name:</b> PowertrainRelayFault
P1682
<b>Bundle Name:</b> PowertrainRelayStateOn_Error
P0685
<b>Bundle Name:</b> PowertrainRelayStateOn_FA
P0685
<b>Bundle Name:</b> PPS1_OutOfRange
P2122, P2123
<b>Bundle Name:</b> PPS1_OutOfRange_Composite
P2122, P2123, P06A3
<b>Bundle Name:</b> PPS2_OutOfRange
P2127, P2128

## 15 OBDG08A Fault Bundle Definitions

<b>Bundle Name:</b> PPS2_OutOfRange_Composite
P2127, P2128, P0697
<b>Bundle Name:</b> SCIAP_SensorCircuitFA
P012C, P012D
<b>Bundle Name:</b> SCIAP_SensorCircuitFP
P012C, P012D
<b>Bundle Name:</b> SCIAP_SensorFA
P012B, P012C, P012D
<b>Bundle Name:</b> SCIAP_SensorPerfFA
P012B
<b>Bundle Name:</b> SCIAP_SensorPerfTFTKO
P012B
<b>Bundle Name:</b> SCIAP_SensorTFTKO
P012B, P012C, P012D
<b>Bundle Name:</b> SuperchargerBypassValveFA
P2261
<b>Bundle Name:</b> SystemVoltageHigh_FA
P0563
<b>Bundle Name:</b> SystemVoltageLow_FA
P0562
<b>Bundle Name:</b> TC_BoostPresSnsrCktFA
P0237, P0238
<b>Bundle Name:</b> TC_BoostPresSnsrFA
P0236, P0237, P0238
<b>Bundle Name:</b> TCM_EngSpdReqCkt
P150C
<b>Bundle Name:</b> THMR_AHV_FA
P2681, P26A3, P26A6, P26A7, P26A9
<b>THMR_AHV_FA - Other Definitions:</b>
<b>Bundle Name:</b> THMR_AWP_AuxPumpFA
B269A, B269C, B269D
<b>Bundle Name:</b> THMR_ECT_Sensor_Ckt_FA
P0116, P0117, P0118, P0119, P111E
<b>Bundle Name:</b> THMR_Insuff_Flow_FA
P00B7
<b>Bundle Name:</b> THMR_RCT_Sensor_Ckt_FA
P00B3, P00B4

## 15 OBDG08A Fault Bundle Definitions

<b>Bundle Name:</b> THMR_SWP_Control_FA
P261A, P261D, P261C
<b>Bundle Name:</b> THMR_SWP_FlowStuckOn_FA
P261A, P261D, P261E
<b>Bundle Name:</b> THMR_SWP_NoFlow_FA
P261B, P261C
<b>Bundle Name:</b> THMR_Therm_Control_FA
P0597, P0598, P0599
<b>Bundle Name:</b> ThrotTempSensorFA
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
<b>Bundle Name:</b> ThrotTempSensorTFTKO
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
<b>Bundle Name:</b> ThrottlePositionSnsrPerfFA
P0121
<b>Bundle Name:</b> ThrottlePositionSnsrPerfTFTKO
P0121
<b>Bundle Name:</b> TIAP_SensorPerfFA
P0236
<b>Bundle Name:</b> TPS_FA
P0122, P0123, P0222, P0223, P16A0, P16A1, P16A2, P2135
<b>Bundle Name:</b> TPS_FaultPending
P0122, P0123, P0222, P0223, P16A0, P16A1, P16A2, P2135
<b>Bundle Name:</b> TPS_Performance_FA
P0068, P0121, P1104, P2100, P2101, P2102, P2103
<b>Bundle Name:</b> TPS_Performance_TFTKO
P0068, P0121, P1104, P2100, P2101, P2102, P2103
<b>Bundle Name:</b> TPS_TFTKO
P0122, P0123, P0222, P0223, P16A0, P16A1, P16A2, P2135
<b>Bundle Name:</b> TPS_ThrottleAuthorityDefaulted
P0068, P0122, P0123, P0222, P0223, P16F3, P16A0, P16A1, P16A2, P1104, P2100, P2101, P2102, P2103, P2135
<b>Bundle Name:</b> TPS1_OutOfRange_Composite
P0122, P0123, P06A3, P16A0, P16A1, P16A2
<b>Bundle Name:</b> TPS2_OutOfRange_Composite
P0222, P0223, P06A3, P16A0, P16A1, P16A2
<b>Bundle Name:</b> Trans Output Rotations Rolling Count Validity
P0722, P0723, P077C, P077D

## 15 OBDG08A Fault Bundle Definitions

<b>Bundle Name:</b> TransActualGearValidity
P182E, P1915
<b>Bundle Name:</b> Transfer Pump is Commanded On
<b>Transfer Pump is Commanded On - Other Definitions:</b> Fuel Volume in Primary Fuel Tank < 0.0 liters AND Fuel Volume in Secondary Fuel Tank ≥ 0.0 liters AND Transfer Pump on Time < P0461, P2066, P2636: Transfer Pump Enable (see supporting table for numeric value) AND Transfer Pump had been Off for at least 0.0 seconds AND Evap Diagnostic (Purge Valve Leak Test, Large Leak Test, and Waiting for Purge) is not running AND Engine Running
<b>Bundle Name:</b> Transmission Actual Gear Validity
P182E, P1915
<b>Bundle Name:</b> Transmission Engaged State Validity
P182E, P1915
<b>Bundle Name:</b> Transmission Estimated Gear Validity
P182E, P1915
<b>Bundle Name:</b> Transmission Gear Ratio Validity
P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0
<b>Bundle Name:</b> Transmission Gear Selector Position Validity
P182E, P1915
<b>Bundle Name:</b> Transmission Oil Temperature Validity
P0667, P0668, P0669, P0711, P0712, P0713
<b>Bundle Name:</b> Transmission Output Shaft Angular Velocity Validity
P0722, P0723, P077C, P077D
<b>Bundle Name:</b> Transmission Overall Actual Torque Ratio Validity
P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P182E, P1915
<b>Bundle Name:</b> Transmission Overall Estimated Torque Ratio Validity
P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P182E, P1915
<b>Bundle Name:</b> Transmission Shift Lever Position Validity
P182E, P1915
<b>Bundle Name:</b> Transmission Turbine Angular Velocity Validity
P0716, P0717, P07BF, P07C0
<b>Bundle Name:</b> TransmissionEngagedState_FA
P182E, P1915
<b>Bundle Name:</b> TransmissionGearDefaulted
P182E, P1915
<b>Bundle Name:</b> TransmissionOutputRotationalStatusValidity
P0722, P0723, P077C, P077D

## 15 OBDG08A Fault Bundle Definitions

<b>Bundle Name:</b> TransmissionRatioControlSystemFault
P0751, P0752, P0756, P0757, P0973, P0974, P0976, P0977
<b>Bundle Name:</b> TwoStepMechBndl_FA
P2646, P2647, P16D0, P16D1
<b>Bundle Name:</b> VCER_TorqueSecurity
P16F3
<b>VCER_TorqueSecurity - Other Definitions:</b> P16F3 with GetXOYR_b_SecurityFlt(CeXOYR_e_AFM_PreloadAreaFlt, CeXOYR_e_AFM_PreloadTimerFlt, CeXOYR_e_AFM_DualPreloadAreaFlt, CeXOYR_e_CDAR_SecurityFlt)
<b>Bundle Name:</b> VehicleSpeedSensor_FA
P0502, P0503, P0722, P0723
<b>Bundle Name:</b> VehicleSpeedSensorError
P0502, P0503, P0722, P0723
<b>Bundle Name:</b> VentCircuit_FA
ELCP sealed/vented fuel system, P0449, P0498, P0499
<b>Bundle Name:</b> VICM_WakeupDiag_FA
P06E4
<b>Bundle Name:</b> VICM_WakeupDiag_TFTKO
P06E4
<b>Bundle Name:</b> VITR_LVT_FltBndl
P058B, P058D, P118C, P118D







## 15 OBDG08A FSCM/ICCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Control Module Long Term Memory Reset	P0603	Non-volatile memory checksum error at controller power-up	Checksum at power-up	≠ checksum at power-down	Ignition OR Ign1 Accessory mode	Run or Crank  enabled	1 failure  Frequency: Once at power-up	DTC Type A 1 trip
Control Module Random Access Memory (RAM)	P0604	Indicates that control module is unable to correctly write and read data to and from RAM	Data read	≠ Data written	Ignition OR Ign1 Accessory mode	Run or Crank  enabled	1 failure if it occurs during the first RAM test of the ignition cycle, otherwise 5 failures  Frequency: Runs continuously in the background.	DTC Type A 1 trip
Control Module Internal Performance  1. Main Processor Configuration Register Test  2. Processor clock test	P0606	This DTC indicates the ECU has detected an internal processor fault or external watchdog fault (PID 2032 discriminates the source of the fault )	1. Register contents - All I/O configuration register faults -  2. - Processor clock fault - a. EE latch flag set in EEPROM OR  b. RAM latch flag.	1. <> correct value.  2. a. == 0x5A5A  b. == 0x5A	1. Ignition OR 2. Ign1 Accessory mode 3. For all I/O configuration register faults: •KeMEMD_b_ProcFitCfgRegEnbl  4. For Processor Clock Fault: •KeMEMD_b_ProcFitCLKDiagEnbl	1. Run or Crank  2. enabled  3. TRUE  4. TRUE	Tests 1 and 2 1 failure Frequency: Continuously (12.5ms)  Test 3 3 failures out of 15 samples  1 sample/12.5 ms	DTC Type A 1 trip

### 15 OBDG08A FSCM/ICCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
3. External watchdog test			3. - External Watchdog Fault - Software control of fuel pump driver	3. = Control Lost	5. For External Watchdog Fault: •KeFRPD_b_FPEExtWDogDiagEnbl  6. For External Watchdog Fault: •Control Module ROM(P0601)  7. For External Watchdog Fault: •Control Module RAM(P0604)	5. TRUE  6. not active  7. not active		
Control Module Long Term Memory (EEPROM) Performance	P062F	Indicates that the NVM Error flag has not been cleared	Last EEPROM write	Did not complete	Ignition OR Ign1 Accessory mode	Run or Crank  enabled	1 test failure Once on controller power-up	DTC Type B 2 trips
Active Grille Air Shutter Actuator 1 Signal Message Counter Incorrect	P151E	Detects loss of communication condition has occurred between ECU and device Active Grill Air Shutter "A" actuator	PWM Signal	Undetected	1. Ign Switch Power mode  2. Ignition Run_Crank Terminal Voltage	1. Run_Crank  2. 11V < voltage < 32V	Frequency: 100ms  150 failures out of 167 samples	DTC Type B 2 trips
Active Grille Air Shutter Actuator 2 Signal Message Counter Incorrect	P151F	Detects loss of communication condition has occurred between ECU and device Active Grill Air Shutter "B" actuator	PWM Signal	Undetected	1. Ign Switch Power mode	1. Run_Crank	Frequency: 100ms  150 failures out of 167 samples	DTC Type B 2 trips

## 15 OBDG08A FSCM/ICCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					2. Ignition Run_Crank Terminal Voltage	2. 11V < voltage < 32V		
Ignition 1 Switch Circuit Low Voltage	P2534	This DTC detects if the Ignition1 Switch circuit is shorted to low or open	Ignition 1 voltage	<= 6 V	Engine	Running	1 sample/25.0 ms  180 failures out of 200 samples	DTC Type A 1 trip
Ignition 1 Switch Circuit High Voltage	P2535	Detects if the Ignition1 Switch circuit is shorted to vehicle supply voltage	Ignition 1 voltage	> 11.7 V	Ignition Run_Crank terminal	Off	1 sample/25.0 ms  180 failures out of 200 samples	DTC Type A 1 trip
Control Module Communication Bus "A" Off	U0073	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off state	Bus Status	Off	Power mode	Run/Crank	5 failures out of 5 samples ( 5 seconds)	DTC Type B 2 trips
Lost Communication With ECM/PCM "A"	U0100	Detects that CAN serial data communication has been lost with the ECM	Message \$0C9	Undetected	1. Power mode  2. Ignition Run/Crank Voltage 3. U0073	1. Run/Crank  2. 11V<voltage<32V 3. not active	12 failures out of 12 samples (12 seconds)	DTC Type B 2 trips