99t65Y_HD_yE.doc

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	FAULT CODE STORAGE AND MIL ILLUMINATION
Barometric Pressure Circuit	P0107	0.78 volt to 4.86 volts 40kPa to 202kPa	Boost Pressure < 0.78 volts - same as - Boost Pressure < 40kPa	None	Diagnostic set conditions true for 2 seconds	В
Low Input		Detects baro sensor circuit open			Test performed continuously	
Barometric Pressure Circuit	P0108	0.78 volt to 4.86 volts 40kPa to 202kPa Detects baro sensor circuit short	Boost Pressure > 4.86 volts - same as - Boost Pressure > 202kPa	Engine Speed < 3506 RPM	Diagnostic set conditions true for 2 seconds	В
High Input		to high voltage			Test performed continuously	
Intake Air Temperature Circuit Low Input	P0112	0.24 volt to 4.86 volts -40°C to 152°C Detects a sensor circuit short to ground	Air temperature sensor voltage < 0.24 volt - same as - Air temperature > 160°C	Coolant temperature < 42.5°C	Diagnostic set conditions true for 2 seconds Test performed continuously	В
Intake Air Temperature Circuit High Input	P0113	0.24 volt to 4.86 volts -40°C to 152°C Detects a sensor circuit short to high voltage or a sensor circuit open	Air temperature sensor voltage > 4.86 volt - same as - Air temperature < -40°C	Engine has been running > 8 minutes	Diagnostic set conditions true for 2 seconds Test performed continuously	В
Engine Coolant Temperature Circuit Low Input	P0117	0.24 volt to 4.76 volts -40°C to 152°C Detects a sensor circuit short to ground	Coolant temperature sensor voltage < 0.24 volt - same as - Coolant temperature > 160°C		Diagnostic set conditions true for 2 seconds Test performed continuously	В
Engine Coolant Temperature Circuit High Input	P0118	0.24 volt to 4.76 volts -40°C to 152°C Detects a sensor circuit short to high high voltage or a sensor circuit open	Coolant temperature sensor voltage > 4.76 volt - same as - Coolant temperature < -40°C	Engine run timer > 8 minutes	Diagnostic set conditions true for 2 seconds Test performed continuously	В
Insufficient Coolant Temp for Stable Operation	P0126	Engine Temperature > 56°C Detects engine not warm enough for stable operation	Engine run time >= 600s Engine temperature < 56°C Fuel burned since start >= 1,000,000cu.mm. Total idle time since start < 450s - OR - Engine run time >= 300s	*Ambient air temperature < f(eng. startup temp); Ambient air temp > -7°C; -7°C < Engine start-up temp < 56°C; Engine is running; P0126 not yet passed; P0112, P0113, P0117 and P0118 not set. * See Table DGTCMIT *Ambient air temperature >= f(eng. startup temp);	Diagnostic set conditions true for 2 seconds	В
			Engine Temperature < 56°C Fuel burned since start >= 468,120cu.mm. Total idle time since start < 225s	Ambient air temperature >= ((eng. startup temp), Ambient air temp > -7°C; -7°C < Engine start-up temp < 56°C; Engine is running; P0126 not yet passed; P0112, P0113, P0117 and P0118 not set. * See Table DGTCMIT	Test performed once from start-up until a pass/fail/disable condition exists.	
Fuel Temperature Sensor Circuit Low Input	P0182	0.24 volts - 4.96 volts 17°C - 106°C Detects a sensor circuit short to ground	Fuel temperature < 0.24 volts - same as - Fuel temperature > 106°C	None	Diagnostic set conditions true for 2 seconds Test performed continuously	В
Fuel Temperature Sensor Circuit High Input	P0183	0.24 volts - 4.96 volts 17°C - 106°C Detects a sensor short to high voltage or sensor circuit open	Fuel temperature > 4.96 volts - same as - Fuel temperature < 18°C	Engine running > 8 minutes	Diagnostic set conditions true for 2 seconds Test performed continuously	В

* Backup fueling mode occurs if any of the following codes are set: P0251, P0335, P0370

99t65Y_HD_yE.doc

	Ī	ACCEPTABLE	PRIMARY	SECONDARY	MONITORING	FAULT CODE
SENSED	FAULT	OPERATING	MALFUNCTION	MONITORING	TIME LENGTH	STORAGE
PARAMETER	CODE	RANGE AND	DETECTION	PARAMETERS	AND FREQUENCY	AND MIL
		RATIONALITY	PARAMETERS	AND CONDITIONS	OF CHECK	ILLUMINATION
Fuel Injection	P0216	Desired timing - actual timing =<	Desired timing - actual timing >	Codes P0251, P0335 and P0370 clear	Diagnostic set conditions	
Timing Circuit		5 engine degrees	5 pump degrees	Engine not stalled	true for 2 seconds	В
Malfunction		Detects a failure of timing control under		No change in engine speed > 56 RPM for	Test performed	
		steady state conditions		a minimum of 5 seconds	continuously	
Lift Pump	P0231	Lift pump voltage > Ignition voltage - 4 volts	Lift pump voltage < Ignition voltage - 4 volts	Lift pump is commanded high	Lift pump commanded	
Voltage Low					high $> .5$ second	В
					Diagnostic set conditions	
		Detects a low voltage at the lift pump			true for 2 seconds	
		when the lift pump is commanded high			Test performed continuously	
Fuel Injection	P0251	Number of consecutive missing	Number of consecutive missing	Ratio of CAM to HRS = $1:64 \pm 4$		
Pump cam		CAM pulses < 8	CAM pulses >= 8			Α
	Í Í	Ratio of CAM to HRS = $1:64 \pm 4$	Ratio of CPS to HRS < 60:1 for		1	
		for 8 consecutive cylinders	240 cylinders if one bad ratio detected			
Position	Γ	Number of CAM pulses per #1 cylinder	Number of CAM pulses per #1 cylinder	RPM < 300	1	
Sensor (CAM)		event = 8. This must be true for $8 \# 1$	event <> 8 for 8 #1 cylinder events			
Malfunction	Í l	cylinder events for RPM < 300 or 32 #1	Number of CAM pulses per #1 cylinder	RPM >= 300		
		cylinder events for RPM >= 300 or 96 #1	event <> 8 for 32 #1 cylinder events	Ratio of CPS to HRS > 60:1		
	Í l	cylinder events for RPT >= 300	Number of CAM pulses per #1 cylinder	RPM >= 300		
		depending on the ration of CPS to HRS	event <> 8 for 96 #1 cylinder events	Ratio of CPS to HRS < 60:1	Test performed continuously	
Multiple	P0300	Number of detected misfire cylinders $=< 1$	Number of detected misfire cylinders > 1	$56^{\circ}C = < Coolant temperature < 104^{\circ}C$	Test performed for 90	
Misfire				Engine Speed = Idle	seconds once per	В
Detected					ignition cycle	
Cylinder 1	P0301	Cylinder #1 fuel rate	Cylinder #1 fuel rate greater than desired	$56^{\circ}C = < Coolant temperature < 104^{\circ}C$	Test performed for 90	
Misfire		adjustment < +24mm ³	fuel rate by ≥ 24 mm ³	Engine Speed = Idle	seconds once per	В
Detected					ignition cycle	

* Backup fueling mode occurs if any of the following codes are set: P0251, P0335, P0370

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	FAULT CODE STORAGE AND MIL ILLUMINATION
Cylinder 2 Misfire Detected	P0302	Cylinder #2 fuel rate adjustment < +24mm ³	Cylinder #2 fuel rate greater than desired fuel rate by >= 24mm ³	56°C =< Coolant temperature < 104°C Engine Speed = Idle	Test performed for 90 seconds once per ignition cycle	В
Cylinder 3 Misfire Detected	P0303	Cylinder #3 fuel rate adjustment < +24mm ³	Cylinder #3 fuel rate greater than desired fuel rate by >= 24mm ³	56°C =< Coolant temperature < 104°C Engine Speed = Idle	Test performed for 90 seconds once per ignition cycle	В
Cylinder 4 Misfire Detected	P0304	Cylinder #4 fuel rate adjustment < +24mm ³	Cylinder #4 fuel rate greater than desired fuel rate by >= 24mm ³	56°C =< Coolant temperature < 104°C Engine Speed = Idle	Test performed for 90 seconds once per ignition cycle	В
Cylinder 5 Misfire Detected	P0305	Cylinder #5 fuel rate adjustment < +24mm ³	Cylinder #5 fuel rate greater than desired fuel rate by >= 24mm ³	56°C =< Coolant temperature < 104°C Engine Speed = Idle	Test performed for 90 seconds once per ignition cycle	В
Cylinder 6 Misfire Detected	P0306	Cylinder #6 fuel rate adjustment < +24mm ³	Cylinder #6 fuel rate greater than desired fuel rate by >= 24mm ³	56°C =< Coolant temperature < 104°C Engine Speed = Idle	Test performed for 90 seconds once per ignition cycle	В
Cylinder 7	P0307	Cylinder #7 fuel rate	Cylinder #7 fuel rate greater than desired	56°C =< Coolant temperature < 104°C	Test performed for 90	

 $99t65Y_HD_yE.doc$

99t65Y_HD_yE.doc

Misfire Detected		adjustment < +24mm ³	fuel rate by ≥ 24 mm ³	Engine Speed = Idle	seconds once per ignition cycle	В
Cylinder 8 Misfire Detected	P0308	Cylinder #8 fuel rate adjustment < +24mm ³	Cylinder #8 fuel rate greater than desired fuel rate by >= 24mm ³	56°C =< Coolant temperature < 104°C Engine Speed = Idle	Test performed for 90 seconds once per ignition cycle	В
Engine Crankshaft	P0335	Number of consecutive missing CPS pulses < 8	Number of consecutive missing CPS pulses >= 8	Ratio of CPS to HRS = $1:64 + 4$		А
Position Sensor (CPS)		Number of CPS pulses per #1 cylinder event = 8. This must be true for 8 #1	Number of CPS pulses per #1 cylinder event <> 8 for 8 #1 cylinder events	RPM < 300		
Malfunction		cylinder events for RPM < 300 or 32 #1 cylinder events for RPM >= 300	Number of CPS pulses per #1 cylinder event <> 8 for 32 #1 cylinder events	RPM >= 300	Test performed continuously	
Fuel Injection Pump High Resolution	P0370	HRS pulses must be received by the PCM for every 8 CAM pulses	HRS free running pump counter = old count for > 8 consecutive CAM pulses	None		А
Angular Sensor (HRS) Malfunction					Test performed continuously	

* Backup fueling mode occurs if any of the following codes are set: P0251, P0335, P0370

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	FAULT CODE STORAGE AND MIL ILLUMINATION
Glow Plug Circuit Malfunction	P0380 Federal Relay	glowplug voltage - ignition voltage =< 2.0 volts Detects a faulty glowplug relay circuit	Glowplugs commanded off & raw feedback > 4.0 v - OR - Glowplugs commanded on & raw feedback < 4.0 v - OR - Glowplugs commanded on and glowplug voltage - ignition voltage > 2 v	A/D inputs settled	Diagnostic set conditions true for 2 seconds	В
	California Relay	Glowplugs commanded off & raw feedback < 2.0 v Glowplugs commanded on & raw feedback < 6.2 v raw feedback > 5.0 v	Glowplugs commanded off & raw feedback > 2.0 v -OR- Glowplugs commanded on & raw feedback > 6.2 v - OR - raw feedback < 5.0 v	A/D inputs settled		
					Test performed continuously	
Flash Memory Malfunction	P0601	Detects a Malfunction in the Flash Memory	Calculated checksum <> flashed calibration checksum		Test performed at power-up reset and continuously.	А
Control Module Programming Error	P0602	Detects a calibration that is not engine compatible.	Calibration is not engine run compatible		Test performed at power-up reset.	А
PCM Processor Fault Injection Pump	P0606	Detects a TIO malfunction -23 HRS Counts < Cal -	Advance angle read from TIO > 1102 HRS Counts CAM pulse edge detect counter > 6 slow CAM edge counts Cal - Filtered Advance > 23 HRS Counts	Engine Speed > 38 RPM Malf counter >= 6 TIO faults P0606 code set OR TIO malf (P0606) detected	Diagnostic set conditions true for 2 seconds Test performed continuously	А

99t65Y_HD_yE.doc

99t65Y_HD_yE.doc

Timing	1 1	Filtered Advance < 23 Hi Res Cnts	- OR -	None		В
Reference			Cal - Filtered Advance < -23 HRS Counts			
Offset Error					Test performed continuously	
Fuel Pump	P1218	0.27 volt to 4.29 volt	Fuel pump calibration resistor voltage <	Fuel pump calibration resistor invalid flag	Test performed at power-up	
Calibration			0.27 volt - OR -	set - OR -	and running reset	В
Resistor Fault		Detects an invalid fuel pump calibration	Fuel pump calibration resistor voltage >	Selected fuel pump calibration resistor	initialization	
		resistor learn	4.29 volts	address invalid		
PCM A/D	P1627	Less than 5 consecutive A/D read errors	5 consecutive A/D read errors occur		Diagnostic set conditions	
Intermittent On				None	true for 2 seconds	В
		Detects when 5 consecutive A/D				
		read errors occur			Test performed continuously	
Glow Plug	P1643	No ODM 'Open' Faults or 'Short' Fault	ODM 'Open' or 'Short' Fault Detected		Diagnostic set conditions	
Light Output		Glowplug light output voltage at PCM	Glowplug light output voltage at PCM does	None	true for 2 seconds	В
Circuit Failed		follows S/W command	not follow S/W command			
					Test performed continuously	

* Backup fueling mode occurs if any of the following codes are set: P0251, P0335, P0370

		ACCEPTABLE	PRIMARY	SECONDARY	MONITORING	FAULT CODE
SENSED	FAULT	OPERATING	MALFUNCTION	MONITORING	TIME LENGTH	STORAGE
PARAMETER	CODE	RANGE AND	DETECTION	PARAMETERS	AND FREQUENCY	AND MIL
		RATIONALITY	PARAMETERS	AND CONDITIONS	OF CHECK	ILLUMINATION
EPR Driver	P1653	No ODM 'Open' Faults or 'Short' Fault	ODM 'Open' or 'Short' Fault Detected		Diagnostic set conditions	
Circuit Failed		EPR output voltage at PCM	EPR output voltage at PCM does	Ignition > 8.0 volts	true for 2 seconds	В
		follows S/W command	not follow S/W command			
					Test performed continuously	

* Backup fueling mode occurs if any of the following codes are set: P0251, P0335, P0370

*T	'al	əle	S
· · I	aı	л	×3

* I abits	
DGTCMIT	
Start-up Engine Temperature	Ambient Air Temperature
-40°C	149.75
-16°C	149.75
8°C	16.25
32°C	-1
56°C	-13
80°C	-13
104°C	-13
128°C	-13
152°C	-13