SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND	PRIMARY MALFUNCTION DETECTION	SECONDARY MONITORING PARAMETERS	MONITORING TIME LENGTH AND FREQUENCY	FAULT CODE STORAGE AND MIL
	7040	RATIONALITY	PARAMETERS	AND CONDITIONS	OF CHECK	ILLUMINATION
Barometric	P0107	0.78 volt to 4.86 volts	Boost Pressure < 0.78 volts	N.	Diagnostic set conditions	D.
Pressure	a 55 1	40kPa to 202kPa	- same as -	None	true for 2 seconds	В
Circuit	(L57 only)	D 4 4 1	Boost Pressure < 40kPa		T. ( C 1 ( )	
Low Input		Detects baro sensor circuit open	100	D 1 2 1 2 2 1 2 2 1 2 2 1 2 2 2 2 2 2 2	Test performed continuously	
Barometric	P0108	0.78 volt to 4.86 volts	Boost Pressure > 4.86 volts	Engine Speed < 3506 RPM	Diagnostic set conditions	_
Pressure		40kPa to 202kPa	- same as -		true for 2 seconds	В
Circuit	(L57 only)	Detects baro sensor circuit short	Boost Pressure > 202kPa			
High Input		to high voltage			Test performed continuously	
Intake Air	P0112	0.24 volt to 4.86 volts	Air temperature sensor	Coolant temperature < 42.5°C	Diagnostic set conditions	
Temperature		-40°C to 152°C	voltage < 0.24 volt		true for 2 seconds	В
Circuit Low		Detects a sensor circuit short	- same as -		Test performed	
Input		to ground	Air temperature > 152°C		continuously	
Intake Air	P0113	0.24 volt to 4.86 volts	Air temperature sensor	Engine has been running > 8 minutes	Diagnostic set conditions	
Temperature		-40°C to 152°C	voltage > 4.86 volt		true for 2 seconds	В
Circuit High		Detects a sensor circuit short to high	- same as -		Test performed	
Input		voltage or a sensor circuit open	Air temperature $< -40^{\circ}$ C		continuously	
Engine	P0117	0.24 volt to 4.76 volts	Coolant temperature sensor		Diagnostic set conditions	
Coolant		-40°C to 152°C	voltage < 0.24 volt		true for 2 seconds	В
Temperature			- same as -		Test performed	
Circuit Low		Detects a sensor circuit short to	Coolant temperature > 152°C		continuously	
Input		ground				
Engine	P0118	0.24 volt to 4.76 volts	Coolant temperature sensor	Engine run timer > 8 minutes	Diagnostic set conditions	
Coolant		-40°C to 152°C	voltage > 4.76 volt		true for 2 seconds	В
Temperature		Detects a sensor circuit short to high	- same as -		Test performed	
Circuit High		high voltage or a sensor circuit open	Coolant temperature < -40°C		continuously	
Input						
Insufficient	P0126	Engine Temperature > 56°C	Engine run time >= 600s	*Ambient air temperature < f(eng. startup temp);	Diagnostic set conditions	
Coolant Temp			Engine temperature < 56°C	Ambient air temp $> -7^{\circ}$ C;	true for 2 seconds	В
for Stable		Detects engine not warm enough for	Fuel burned since start >= 1,000,000cu.mm.	-7°C < Engine start-up temp < 56°C;		
Operation		stable operation	Total idle time since start < 450s	Engine is running; P0126 not yet passed;		
				P0112, P0113, P0117 and P0118 not set.		
			- OR -	* See Table DGTCMIT		
			Engine run time >= 300s	*Ambient air temperature >= f(eng. startup temp);	1	
			Engine Temperature < 56°C	Ambient air temp $> -7^{\circ}$ C;		
			Fuel burned since start >= 468,120cu.mm.	-7°C < Engine start-up temp < 56°C;	Test performed	
			Total idle time since start < 225s	Engine is running; P0126 not yet passed;	once from start-up until a	
				P0112, P0113, P0117 and P0118 not set.	pass/fail/disable condition exists.	
				* See Table DGTCMIT		
Fuel	P0182	0.24 volts - 4.96 volts	Fuel temperature < 0.24 volts		Diagnostic set conditions	
Temperature		17°C - 106°C	- same as -	None	true for 2 seconds	В
Sensor Circuit		Detects a sensor circuit short	Fuel temperature > 106°C		Test performed	
Low Input		to ground			continuously	
Fuel	P0183	0.24 volts - 4.96 volts	Fuel temperature > 4.96 volts	Engine running > 8 minutes	Diagnostic set conditions	
Temperature		17°C - 106°C	- same as -		true for 2 seconds	В
Sensor Circuit		Detects a sensor short to high	Fuel temperature < 18°C		Test performed	
High Input		voltage or sensor circuit open	_		continuously	

<sup>\*</sup> Backup fueling mode occurs if any of the following codes are set: P0251, P0335, P0370

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	FAULT CODE STORAGE AND MIL ILLUMINATION
Fuel Injection Timing Circuit Malfunction	P0216	Desired timing - actual timing   =< 5 engine degrees Detects a failure of timing control under steady state conditions	Desired timing - actual timing   > 5 pump degrees	Codes P0251, P0335 and P0370 clear Engine not stalled No change in engine speed > 56 RPM for a minimum of 5 seconds	Diagnostic set conditions true for 2 seconds Test performed continuously	В
Lift Pump Voltage Low	P0231	Lift pump voltage > Ignition voltage - 4 volts  Detects a low voltage at the lift pump when the lift pump is commanded high	Lift pump voltage < Ignition voltage - 4 volts	Lift pump is commanded high	Lift pump commanded high > .5 second Diagnostic set conditions true for 2 seconds Test performed continuously	В
Wastegate Control Range/ Performance Failure	P0236 (not L57)		Final intake manifold pressure =< (Desired kPA - 20 kPa) - ((100kPa - Baro) /2)	Eng. speed > 2400 RPM; Fuel rate > 20 cu.mm.  Final intake manifold pressure =< (Desired kPa + 20kPa)  Condition 2 timer >= 10 seconds - OR -  1800 RPM < Eng. speed =< 2400 RPM; Fuel rate > 20 cu.mm  Final intake manifold pressure =< (110kPa) - ((100kPa - Baro)/2)		В
		Detects a failure of wastegate control system under steady state boost conditions.	- OR - Final intake manifold pressure > (Desired kPa + 20 kPa)	Condition 3 timer >= 12.8 seconds  Eng. speed > 2400 RPM  Condition 1 timer > 10 seconds	Test performed continuously	
Turbocharger Boost Sensor Circuit	P0237 (not L57)	0.78 volt to 4.86 volts 40kPa to 202kPa	Boost Pressure < 0.78 volts - same as - Boost Pressure < 40kPa	None	Diagnostic set conditions true for 2 seconds	В
Low Input Turbocharger Boost Sensor Circuit High Input	P0238 (not L57)	Detects boost sensor circuit open  0.78 volt to 4.86 volts  40kPa to 202kPa  Detects boost sensor circuit short  to high voltage	Boost Pressure > 4.86 volts - same as - Boost Pressure > 202kPa	Engine Speed < 3506 RPM	Test performed continuously  Diagnostic set conditions true for 2 seconds  Test performed continuously	В
Fuel Injection Pump cam  Position Sensor (CAM)	P0251	Number of consecutive missing  CAM pulses < 8  Ratio of CAM to HRS = 1:64 ± 4  for 8 consecutive cylinders  Number of CAM pulses per #1 cylinder event = 8. This must be true for 8 #1	Number of consecutive missing  CAM pulses >= 8  Ratio of CPS to HRS < 60:1 for 240 cylinders if one bad ratio detected  Number of CAM pulses per #1 cylinder event <> 8 for 8 #1 cylinder events	Ratio of CAM to HRS = 1:64 ± 4  RPM < 300		A
Malfunction		cylinder events for RPM < 300 or 32 #1 cylinder events for RPM >= 300 or 96 #1 cylinder events for RPT >= 300 depending on the ration of CPS to HRS	Number of CAM pulses per #1 cylinder event <> 8 for 32 #1 cylinder events Number of CAM pulses per #1 cylinder event <> 8 for 96 #1 cylinder events	RPM >= 300 $Ratio of CPS to HRS > 60:1$ $RPM >= 300$ $Ratio of CPS to HRS < 60:1$	Test performed continuously	
Multiple Misfire Detected	P0300	Number of detected misfire cylinders =< 1	Number of detected misfire cylinders > 1	56°C =< Coolant temperature < 104°C Engine Speed = Idle	Test performed for 90 seconds once per ignition cycle	В
Cylinder 1 Misfire Detected	P0301	Cylinder #1 fuel rate adjustment < +24mm³	Cylinder #1 fuel rate greater than desired fuel rate by >= 24mm <sup>3</sup>	56°C =< Coolant temperature < 104°C Engine Speed = Idle	Test performed for 90 seconds once per ignition cycle	В

<sup>\*</sup> Backup fueling mode occurs if any of the following codes are set: P0251, P0335, P0370

SENSED	FAULT	ACCEPTABLE OPERATING	PRIMARY MALFUNCTION	SECONDARY MONITORING	MONITORING TIME LENGTH	FAULT CODE STORAGE
PARAMETER	CODE	RANGE AND	DETECTION	PARAMETERS	AND FREQUENCY	AND MIL
		RATIONALITY	PARAMETERS	AND CONDITIONS	OF CHECK	ILLUMINATION
Cylinder 2	P0302	Cylinder #2 fuel rate	Cylinder #2 fuel rate greater than desired	56°C =< Coolant temperature < 104°C	Test performed for 90	
Misfire		adjustment < +24mm³	fuel rate by >= 24mm <sup>3</sup>	Engine Speed = Idle	seconds once per	В
Detected					ignition cycle	
Cylinder 3	P0303	Cylinder #3 fuel rate	Cylinder #3 fuel rate greater than desired	56°C =< Coolant temperature < 104°C	Test performed for 90	
Misfire		adjustment < +24mm³	fuel rate by >= 24mm <sup>3</sup>	Engine Speed = Idle	seconds once per	В
Detected					ignition cycle	
Cylinder 4	P0304	Cylinder #4 fuel rate	Cylinder #4 fuel rate greater than desired	$56^{\circ}\text{C} = < \text{Coolant temperature} < 104^{\circ}\text{C}$	Test performed for 90	
Misfire		adjustment < +24mm³	fuel rate by $\geq 24$ mm <sup>3</sup>	Engine Speed = Idle	seconds once per	В
Detected					ignition cycle	
Cylinder 5	P0305	Cylinder #5 fuel rate	Cylinder #5 fuel rate greater than desired	56°C =< Coolant temperature < 104°C	Test performed for 90	
Misfire		adjustment < +24mm³	fuel rate by $\geq 24$ mm <sup>3</sup>	Engine Speed = $Idle$	seconds once per	В
Detected					ignition cycle	
Cylinder 6	P0306	Cylinder #6 fuel rate	Cylinder #6 fuel rate greater than desired	56°C =< Coolant temperature < 104°C	Test performed for 90	
Misfire		adjustment < +24mm³	fuel rate by >= 24mm <sup>3</sup>	Engine Speed = Idle	seconds once per	В
Detected					ignition cycle	
Cylinder 7	P0307	Cylinder #7 fuel rate	Cylinder #7 fuel rate greater than desired	56°C =< Coolant temperature < 104°C	Test performed for 90	
Misfire		adjustment < +24mm³	fuel rate by $\geq 24$ mm <sup>3</sup>	Engine Speed = $Idle$	seconds once per	В
Detected					ignition cycle	
Cylinder 8	P0308	Cylinder #8 fuel rate	Cylinder #8 fuel rate greater than desired	56°C =< Coolant temperature < 104°C	Test performed for 90	
Misfire		adjustment < +24mm³	fuel rate by >= 24mm <sup>3</sup>	Engine Speed = $Idle$	seconds once per	В
Detected					ignition cycle	
Engine	P0335	Number of consecutive missing	Number of consecutive missing	Ratio of CPS to HRS = $1:64 + /-4$		
Crankshaft		CPS pulses < 8	CPS pulses >= 8			A
Position		Number of CPS pulses per #1 cylinder	Number of CPS pulses per #1 cylinder	RPM < 300		
Sensor (CPS)		event = $8$ . This must be true for $8 \# 1$	event <> 8 for 8 #1 cylinder events			
Malfunction		cylinder events for RPM < 300 or 32 #1	Number of CPS pulses per #1 cylinder	RPM >= 300		
		cylinder events for RPM >= 300	event <> 8 for 32 #1 cylinder events		Test performed continuously	
Fuel Injection	P0370	HRS pulses must be received by the	HRS free running pump			
Pump High		PCM for every 8 CAM pulses	counter = old count for > 8 consecutive	None		A
Resolution			CAM pulses			
Angular						
Sensor (HRS)						
Malfunction					Test performed continuously	

<sup>\*</sup> Backup fueling mode occurs if any of the following codes are set: P0251, P0335, P0370

SENSED PARAMETER	FAULT CODE	ACCEPTABLE OPERATING RANGE AND RATIONALITY	PRIMARY MALFUNCTION DETECTION PARAMETERS	SECONDARY MONITORING PARAMETERS AND CONDITIONS	MONITORING TIME LENGTH AND FREQUENCY OF CHECK	FAULT CODE STORAGE AND MIL ILLUMINATION
Glow Plug Circuit Malfunction	P0380 Federal Relay	glowplug voltage - ignition voltage   =<	Glowplugs commanded off & raw feedback > 4.0 v - OR - Glowplugs commanded on & raw feedback < 4.0 v - OR - Glowplugs commanded on and  glowplug voltage - ignition voltage  > 2 v	A/D inputs settled	Diagnostic set conditions true for 2 seconds	В
	California Relay	Glowplugs commanded off & raw feedback < 2.0 v	Glowplugs commanded off & raw feedback > 2.0 v -OR-	A/D inputs settled		

		Glowplugs commanded on & raw feedback < 6.2 v raw feedback > 5.0 v	Glowplugs commanded on & raw feedback $> 6.2 \text{ v}$ - OR - raw feedback $< 5.0 \text{ v}$			
					Test performed continuously	
Flash Memory	P0601		Calculated checksum <> flashed calibration			
Malfunction			checksum			A
		Detects a Malfunction in the Flash Memory			Test performed at power-up reset and continuously.	
Control	P0602		Calibration is not engine run compatible			
Module						A
Programming		Detects a calibration that			Test performed at power-up	
Error		is not engine compatible.			reset.	
PCM	P0606		Advance angle read from TIO >	Engine Speed > 38 RPM	Diagnostic set conditions	
Processor			1102 HRS Counts	Malf counter >= 6 TIO faults	true for 2 seconds	A
Fault		D	CAM pulse edge detect counter > 6 slow	P0606 code set OR TIO malf (P0606)		
T	D1211	Detects a TIO malfunction	CAM edge counts	detected	Test performed continuously	
Injection Pump Timing	P1214	-23 HRS Counts < Cal - Filtered Advance < 23 Hi Res Cnts	Cal - Filtered Advance > 23 HRS Counts	None		В
Reference		Filtered Advance \ 23 Hi Res Chis	- OK - Cal - Filtered Advance < -23 HRS Counts	None		Б
Offset Error			Car - Fritered Advance < -25 TRS Counts		Test performed continuously	
Fuel Pump	P1218	0.27 volt to 4.29 volt	Fuel pump calibration resistor voltage <	Fuel pump calibration resistor invalid flag	Test performed at power-up	
Calibration	11210	0.27 voil to 1.25 voil	0.27 volt - OR -	set - OR -	and running reset	В
Resistor Fault		Detects an invalid fuel pump calibration	Fuel pump calibration resistor voltage >	Selected fuel pump calibration resistor	initialization	_
		resistor learn	4.29 volts	address invalid		
PCM A/D	P1627	Less than 5 consecutive A/D read errors	5 consecutive A/D read errors occur		Diagnostic set conditions	
Intermittent On				None	true for 2 seconds	В
		Detects when 5 consecutive A/D				
		read errors occur			Test performed continuously	
Glow Plug	P1643	No ODM 'Open' Faults or 'Short' Fault	ODM 'Open' or 'Short' Fault Detected		Diagnostic set conditions	
Light Output		Glowplug light output voltage at PCM	Glowplug light output voltage at PCM does	None	true for 2 seconds	В
Circuit Failed		follows S/W command	not follow S/W command			
					Test performed continuously	

<sup>\*</sup> Backup fueling mode occurs if any of the following codes are set: P0251, P0335, P0370

CENCER	DANK T	ACCEPTABLE	PRIMARY	SECONDARY	MONITORING	FAULT CODE
SENSED	FAULT	OPERATING	MALFUNCTION	MONITORING	TIME LENGTH	STORAGE
PARAMETER	CODE	RANGE AND	DETECTION	PARAMETERS	AND FREQUENCY	AND MIL
		RATIONALITY	PARAMETERS	AND CONDITIONS	OF CHECK	ILLUMINATION
EPR Driver	P1653	No ODM 'Open' Faults or 'Short' Fault	ODM 'Open' or	'Short' Fault Detected	Diagnostic set conditions	
Circuit Failed		EPR output voltage at PCM	EPR output voltage at PCM does	Ignition > 8.0 volts	true for 2 seconds	В
		follows S/W command	not follow S/W command			
					Test performed continuously	
Wastegate	P1656	Number of ODM 'open' faults or 'short'	Number of ODM 'open' or 'short' faults		Diagnostic set conditions	
PWM Solinoid		faults < 2	detected >= 2	Ignition > 8.0 volts	true for 2 seconds	В
Driver	(not L57)	Wastegate PWM output voltage at PCM	Wastegate PWM output voltage at PCM			
Circuit Failed		follows S/W command	does not follow S/W command		Test performed continuously	

<sup>\*</sup> Backup fueling mode occurs if any of the following codes are set: P0251, P0335, P0370

\*Tables

DGTCMIT	
Start-up Engine Temperature	Ambient Air Temperature
-40°C	149.75
-16°C	149.75
8°C	16.25
32°C	-1
56°C	-13
80°C	-13
104°C	-13
128°C	-13
152°C	-13