

The monitoring system measures pressure change of closed EVAP system circuit under the depressurized condition. The system also measures pressure change of closed circuit to compensate evaporative pressure with the normal range pressure, if necessary.

EVAP System Monitoring System (ORVR)



IXSQ01111002-01

EVAP System Monitoring Procedure



IXSQ01111003-01

DTC Description / Detecting Condition / Confirmation Procedure

P0440, P0455

Refer to “DTC P0440 / P0455: EVAP Control System Malfunction / Leak Detected (Gross Leak)”.

EVAP Control System Monitor

Operation

| | |
|-------------------------|--|
| DTCs | P0440, P0455 (gross leak) |
| Monitor execution | Once per driving cycle |
| Sensors / Components OK | Engine speed, MAF, TP, ECT, Fuel tank pressure, Fuel level, IAC control system, MDP, Back-up Power, Primary / Secondary HO2S, Primary / Secondary HO2S Heater, VSS |
| Monitoring Duration | Min. 18 s |

Enable condition

| Parameter | Minimum | Maximum |
|-----------------------------------|-------------------|-------------------|
| Engine coolant temp. | 70 (158) °C (°F) | 110 (230) °C (°F) |
| Intake air temp. | -8 (17.6) °C (°F) | |
| Barometric pressure | 560 mmHg | |
| Fuel level | | 85% |
| Engine speed | 1000 rpm | 3500 rpm |
| Vehicle speed | 15 km/h | |
| MDP | 160 mmHg | |
| Fuel system status | Closed loop mode | |
| Calculated load value | 12.5% | |
| Purge accumulation time | 300 s | |
| Disablement period for fuel slosh | 20 s | |

Typical malfunction thresholds

| |
|---|
| P0440 |
| Tank pressure change during depressurized condition > 2.93 – 10.25 mmHg (G16) (according to fuel level) |
| Tank pressure change during depressurized condition > 4.39 – 11.72 mmHg (J20) (according to fuel level) |
| P0455 |
| Max tank pressure change < 2.9 mmHg |
| Tank pressure: -6.8 – 6.8 mmHg |

MODE \$06 Data

| Test item (related DTC) | Test value | | Description | Scaling |
|--|------------|------|------------------------------|---------------------------|
| | TID | CID | | |
| EVAP Control System (P0440 / P0455) | \$24 | \$00 | Differential pressure | *16.67/256/256 kPa |
| | \$24 | \$10 | Differential pressure | *16.67/256/256 kPa |
| | \$24 | \$20 | Differential rising pressure | (N-128)*16.67/256/256 kPa |
| | \$24 | \$30 | Differential pressure | (N-128)*16.67/256/256 kPa |
| | \$24 | \$31 | Differential pressure | (N-128)*16.67/256/256 kPa |
| | \$24 | \$40 | Differential pressure | (N-128)*16.67/256/256 kPa |
| | \$24 | \$41 | Differential pressure | (N-128)*16.67/256/256 kPa |

| Parameter | Minimum | Maximum |
|------------------------------------|----------------------------|---------|
| Fuel level | 15% | |
| Fuel control status | Idle with closed loop mode | |
| Preconditioning drive at > 32 km/h | 20 s | |

Typical malfunction thresholds

| |
|-------------------------------|
| P0131 |
| Phase 1 |
| Pull-up voltage > 4.5 V |
| Phase 2 |
| Max voltage average < 0.60 V |
| Min. voltage average < 0.30 V |
| P0132 |
| Max voltage average > 0.74 V |
| Min. voltage average > 0.34 V |

Secondary HO2S Circuit Monitor

Operation

| | |
|-------------------------|--------------------------------------|
| DTCs | P0136 |
| Monitor execution | Once per driving cycle |
| Sensors / components OK | ECT, Primary / Secondary HO2S heater |
| Monitoring Duration | Phase 1: 2 s Phase 2: 7 min |

Enable condition

| Parameter | Minimum | Maximum |
|---------------------------------|------------------|---------|
| Heater operation time (Phase 1) | 24 s | |
| Intake air temp. | -10 (14) °C (°F) | |
| Barometric pressure | 560 mmHg | |
| Fuel level | 15% | |
| Fuel system status | Closed loop mode | |
| CTP switch | OFF | |

Typical malfunction thresholds

| |
|-------------------------------------|
| Phase 1 |
| Pull-up voltage > 4.5 V |
| Phase 2 |
| Voltage average < 0.15 V or > 0.9 V |
| Max voltage average < 0.20 V |
| Min. voltage average > 0.40 V |

MODE \$06 Data

| Self diagnostic test item (related DTC) | Test value | | Description | Scaling |
|---|------------|------|---------------------------------|---------------|
| | TID | CID | | |
| O2S 1 circuit low volt (P0131) | \$26 | \$00 | Minimum terminal voltage | *5/256/256 V |
| | \$26 | \$10 | Minimum sensor voltage | *5/1024/256 V |
| | \$26 | \$11 | Maximum sensor voltage | *5/1024/256 V |
| O2S 1 circuit high volt (P0132) | \$27 | \$00 | Minimum terminal voltage | *5/256/256 V |
| | \$27 | \$01 | Minimum sensor voltage | *5/1024/256 V |
| | \$27 | \$02 | Maximum sensor voltage | *5/1024/256 V |
| Slow response (P0133) | \$28 | \$00 | Rich to lean sensor switch time | *0.01/256 s |
| | \$28 | \$01 | Lean to rich sensor switch time | *0.01/256 s |
| | \$28 | \$02 | Time between sensor transitions | *0.025/256 s |
| No activity detect (P0134) | \$29 | \$00 | Maximum sensor voltage | *5/1024/256 V |
| | \$29 | \$01 | Unexpected transition time | *0.5/256 s |

| Self diagnostic test item (related DTC) | Test value | | Description | Scaling |
|---|------------|------|--------------------------|---------------|
| | TID | CID | | |
| O2S 2 circuit volt (P0136) | \$2B | \$00 | Minimum terminal voltage | *5/256/256 V |
| | \$2B | \$10 | Mean sensor voltage | *5/256/256 V |
| | \$2B | \$10 | Mean sensor voltage | *5/256/256 V |
| | \$2B | \$11 | Minimum sensor voltage | *5/1024/256 V |
| | \$2B | \$12 | Maximum sensor voltage | *5/1024/256 V |

OBD System Description - HO2S Heater Monitor

print=OFF, SYSQ011111013 (03(01))

System description / monitoring procedure

For both primary and secondary HO2S heaters, the system monitors proper current and loaded voltage. The HO2S heaters are monitored once per driving cycle during monitoring conditions.

DTC Description / Detecting Condition / Confirmation Procedure

P0135

Refer to "DTC P0135: HO2S-1 Heater Circuit Malfunction".

P0141

Refer to "DTC P0141: HO2S-2 Heater Circuit Malfunction".

Primary HO2S Heater Monitor

Operation

| | |
|---------------------|------------|
| DTCs | P0135 |
| Monitor execution | Continuous |
| Monitoring Duration | 3 ms |

Enable condition

| Parameter | Minimum | Maximum |
|----------------|---------|---------|
| Heater control | On | |

Typical malfunction thresholds

| |
|-------------------------------------|
| Heater current < 0.15 A or > 4.03 A |
| Heater voltage < 10 V or > 13.8 V |

Secondary HO2S Heater Monitor

Operation

| | |
|---------------------|------------|
| DTCs | P0141 |
| Monitor execution | Continuous |
| Monitoring Duration | 3 s |

Enable condition

| Parameter | Minimum | Maximum |
|----------------|---------|---------|
| Heater control | On | |

Typical malfunction thresholds

| |
|-------------------------------------|
| Heater current < 0.22 A or > 4.03 A |
| Heater voltage < 10 V or > 13.8 V |

MODE \$06 Data

| Self diagnostic test item (related DTC) | Test value | | Description | Scaling |
|--|------------|------|--------------------------------|--------------|
| | TID | CID | | |
| O2S 1 heater circuit malfunction (P0135) | \$2D | \$00 | Duration of unexpected current | *0.025/256 s |
| | \$2D | \$01 | Duration of unexpected voltage | *0.025/256 s |
| O2S 2 heater circuit malfunction (P0141) | \$2E | \$00 | Duration of unexpected current | *0.025/256 s |
| | \$2E | \$01 | Duration of unexpected voltage | *0.025/256 s |

OBD System Description - EGR System Monitor

print=OFF, SYSQ011111014 (03/01)

System Description / Monitoring Procedure

To monitor electric controlled EGR system, the system measures pressure change caused by switching of the EGR valve during deceleration condition and also measures the voltage of EGR valve stepping motor electrical circuit continuously.

EGR System Monitoring System



IXSQ01111004-01

DTC Description / Detecting Condition / Confirmation Procedure

P0400

Refer to "DTC P0400: Exhaust Gas Recirculation (EGR) Flow Malfunction".

P0403

Refer to "DTC P0403: Exhaust Gas Recirculation (EGR) Circuit Malfunction".

EGR System Monitor

Operation

| | |
|-------------------------|-----------------------------|
| DTCs | P0400 |
| Monitor execution | Once per driving cycle |
| Sensors / components OK | MDP, TP, ECT, Back-up power |
| Monitoring Duration | 3 s |

Enable condition

| Parameter | Minimum | Maximum |
|---|--------------------|-------------------|
| Engine coolant temp. | 55 (131) °C (°F) | 110 (230) °C (°F) |
| Intake air temp. | -8 (17.6) °C (°F) | |
| Barometric pressure | 560 mmHg | |
| Engine speed | 1780 rpm | 4000 rpm |
| Vehicle speed | 50 km/h | |
| Engine speed change | | 100 rpm / s |
| EGR operation time | 30 s | |
| Time from switch change (A/C, PPS, P/N position switch) | 6.3 s | |
| Fuel control status | Fuel shut-off mode | |

Typical malfunction thresholds

| |
|---|
| MDP difference between EGR ON & OFF < 42.0 – 100.1 mmHg (1.6 L) (according to engine speed) |
| MDP difference between EGR ON & OFF < 28.8 – 93.7 mmHg (2.0 L) (according to engine speed) |

EGR System Circuit Monitor

Operation

| | |
|---------------------|------------|
| DTCs | P0403 |
| Monitor execution | Continuous |
| Monitoring Duration | 3 s |

Enable condition

| Parameter | Minimum | Maximum |
|---------------|---------|---------|
| Valve control | Low | |

Typical malfunction thresholds

| |
|----------------------|
| Monitor signal: High |
|----------------------|

MODE \$06 Data

| Self diagnostic test item (related DTC) | Test value | | Description | Scaling |
|--|------------|------|-----------------------|--------------------|
| | TID | CID | | |
| EGR (P0400) | \$30 | \$00 | Differential Pressure | *31.68/256/256 kPa |